

SIEMENS

SIMATIC

Programming with STEP 7

Manual

Preface	
Contents	
Introducing the Product and Installing the Software	1
Installation	2
Working Out the Automation Concept	3
Basics of Designing a Program Structure	4
Startup and Operation	5
Setting Up and Editing the Project	6
Editing Projects with Different Versions of STEP 7	7
Defining Symbols	8
Creating Blocks and Libraries	9
Creating Logic Blocks	10
Creating Data Blocks	11
Parameter Assignment for Data Blocks	12
Creating STL Source Files	13
Displaying Reference Data	14
Checking Block Consistency and Time Stamps as a Block Property	15
Configuring Messages	16
Controlling and Monitoring Variables	17
Establishing an Online Connection and Making CPU Settings	18
Downloading and Uploading	19
Testing with the Variable Table	20
Testing Using Program Status	21
Testing using the Simulation Program (Optional Package)	22
Diagnostics	23
Printing and Archiving	24
Working with M7 Programmable Control Systems	25
Tips and Tricks	26
Appendix	A
Index	

This manual is part of the documentation package with the order number:
6ES7810-4CA08-8BW0

Edition 03/2006
A5E00706944-01

Safety Guidelines

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring to property damage only have no safety alert symbol. The notices shown below are graded according to the degree of danger.



Danger

indicates that death or severe personal injury **will** result if proper precautions are not taken.



Warning

indicates that death or severe personal injury **may** result if proper precautions are not taken.



Caution

with a safety alert symbol indicates that minor personal injury can result if proper precautions are not taken.

Caution

without a safety alert symbol indicates that property damage can result if proper precautions are not taken.

Notice

indicates that an unintended result or situation can occur if the corresponding notice is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The device/system may only be set up and used in conjunction with this documentation. Commissioning and operation of a device/system may only be performed by **qualified personnel**. Within the context of the safety notices in this documentation qualified persons are defined as persons who are authorized to commission, ground and label devices, systems and circuits in accordance with established safety practices and standards.

Prescribed Usage

Note the following:



Warning

This device and its components may only be used for the applications described in the catalog or the technical description, and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens.

Correct, reliable operation of the product requires proper transport, storage, positioning and assembly as well as careful operation and maintenance.

Trademarks

All names identified by ® are registered trademarks of the Siemens AG.

The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

Purpose

This manual provides a complete overview of programming with **STEP 7**. It is designed to support you when installing and commissioning the software. It explains how to proceed when creating programs and describes the components of user programs.

The manual is intended for people who are involved in carrying out control tasks using STEP 7 and SIMATIC S7 automation systems.

We recommend that you familiarize yourself with the examples in the manual "Working with STEP 7 V5.4, Getting Started." These examples provide an easy introduction to the topic "Programming with STEP 7."

Basic Knowledge Required

In order to understand this manual, general knowledge of automation technology is required.

In addition, you must be familiar with using computers or PC-similar tools (for example, programming devices) with the MS Windows 2000 Professional, MS Windows XP Professional or MS Windows Server 2003 operating system.

Scope of the Manual

This manual is valid for release 5.4 of the STEP 7 programming software package.

You can find the latest information on the service packs:

- in the "readme.wri" file
- in the updated STEP 7 online help.

The topic "What's new?" in the online help offers an excellent introduction and overview of the newest STEP 7 innovations.

STEP 7 Documentation Packages

This manual is part of the documentation package "STEP 7 Basic Information."

The following table displays an overview of the STEP 7 documentation:

Documentation	Purpose	Order Number
STEP 7 Basic Information with <ul style="list-style-type: none"> • Working with STEP 7, Getting Started Manual • Programming with STEP 7 • Configuring Hardware and Communication Connections, STEP 7 • From S5 to S7, Converter Manual 	Basic information for technical personnel describing the methods of implementing control tasks with STEP 7 and the S7-300/400 programmable controllers.	6ES7810-4CA08-8BW0
STEP 7 Reference with <ul style="list-style-type: none"> • Ladder Logic (LAD) / Function Block Diagram (FBD) / Statement List (STL) for S7-300/400 manuals • Standard and System Function for S7-300/400 Volume 1 and Volume 2 	Provides reference information and describes the programming languages LAD, FBD and STL, and standard and system function extending the scope of the STEP 7 basic information.	6ES7810-4CA08-8BW1

Online Helps	Purpose	Order Number
Help on STEP 7	Basic information on programming and configuring hardware with STEP 7 in the form of an online help.	Part of the STEP 7 Standard software.
Reference helps on AWL/KOP/FUP Reference help on SFBs/SFCs Reference help on Organization Blocks	Context-sensitive reference information.	Part of the STEP 7 Standard software.

Further Support

If you have any technical questions, please get in touch with your Siemens representative or responsible agent.

You will find your contact person at:

<http://www.siemens.com/automation/partner>

You will find a guide to the technical documentation offered for the individual SIMATIC Products and Systems here at:

<http://www.siemens.com/simatic-tech-doku-portal>

The online catalog and order system is found under:

<http://mall.automation.siemens.com/>

Training Centers

Siemens offers a number of training courses to familiarize you with the SIMATIC S7 automation system. Please contact your regional training center or our central training center in D 90327 Nuremberg, Germany for details:

Telephone: +49 (911) 895-3200.

Internet: <http://www.sitrain.com>

Technical Support

You can reach the Technical Support for all A&D products

- Via the Web formula for the Support Request
<http://www.siemens.com/automation/support-request>
- Phone: + 49 180 5050 222
- Fax: + 49 180 5050 223

Additional information about our Technical Support can be found on the Internet pages <http://www.siemens.com/automation/service>

Service & Support on the Internet

In addition to our documentation, we offer our Know-how online on the internet at:

<http://www.siemens.com/automation/service&support>

where you will find the following:

- The newsletter, which constantly provides you with up-to-date information on your products.
- The right documents via our Search function in Service & Support.
- A forum, where users and experts from all over the world exchange their experiences.
- Your local representative for Automation & Drives.
- Information on field service, repairs, spare parts and more under "Services".

Contents

1	Introducing the Product and Installing the Software	1-1
1.1	Overview of STEP 7	1-1
1.2	The STEP 7 Standard Package	1-6
1.3	What's New in STEP 7, Version 5.4?	1-11
1.4	Extended Uses of the STEP 7 Standard Package	1-14
1.4.1	Engineering Tools	1-15
1.4.2	Run-Time Software	1-17
1.4.3	Human Machine Interface	1-19
2	Installation	2-1
2.1	Automation License Manager	2-1
2.1.1	User Rights Through The Automation License Manager	2-1
2.1.2	Installing the Automation License Manager	2-4
2.1.3	Guidelines for Handling License Keys	2-5
2.2	Installing STEP 7	2-6
2.2.1	Installation Procedure	2-8
2.2.2	Setting the PG/PC Interface	2-11
2.3	Uninstalling STEP 7	2-13
3	Working Out the Automation Concept	3-1
3.1	Basic Procedure for Planning an Automation Project	3-1
3.2	Dividing the Process into Tasks and Areas	3-2
3.3	Describing the Individual Functional Areas	3-4
3.4	Listing Inputs, Outputs, and In/Outs	3-6
3.5	Creating an I/O Diagram for the Motors	3-6
3.6	Creating an I/O Diagram for the Valves	3-7
3.7	Establishing the Safety Requirements	3-8
3.8	Describing the Required Operator Displays and Controls	3-9
3.9	Creating a Configuration Diagram	3-10
4	Basics of Designing a Program Structure	4-1
4.1	Programs in a CPU	4-1
4.2	Blocks in the User Program	4-2
4.2.1	Organization Blocks and Program Structure	4-3
4.2.2	Call Hierarchy in the User Program	4-9
4.2.3	Block Types	4-11
4.2.3.1	Organization Block for Cyclic Program Processing (OB1)	4-11
4.2.3.2	Functions (FC)	4-16
4.2.3.3	Function Blocks (FB)	4-17
4.2.3.4	Instance Data Blocks	4-20
4.2.3.5	Shared Data Blocks (DB)	4-23
4.2.3.6	System Function Blocks (SFB) and System Functions (SFC)	4-24

4.2.4	Organization Blocks for Interrupt-Driven Program Processing.....	4-26
4.2.4.1	Time-of-Day Interrupt Organization Blocks (OB10 to OB17)	4-26
4.2.4.2	Time-Delay Interrupt Organization Blocks (OB20 to OB23).....	4-28
4.2.4.3	Cyclic Interrupt Organization Blocks (OB30 to OB38).....	4-29
4.2.4.4	Hardware Interrupt Organization Blocks (OB40 to OB47).....	4-31
4.2.4.5	Startup Organization Blocks (OB100 / OB101 / OB102).....	4-32
4.2.4.6	Background Organization Block (OB90).....	4-34
4.2.4.7	Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122).....	4-36
5	Startup and Operation	5-1
5.1	Starting STEP 7	5-1
5.2	Starting STEP 7 with Default Start Parameters.....	5-3
5.3	Calling the Help Functions.....	5-5
5.4	Objects and Object Hierarchy.....	5-6
5.4.1	Project Object	5-8
5.4.2	Library Object	5-9
5.4.3	Station Object	5-10
5.4.4	Programmable Module Object.....	5-12
5.4.5	S7/M7 Program Object	5-14
5.4.6	Block Folder Object	5-16
5.4.7	Source File Folder Object.....	5-19
5.4.8	S7/M7 Program without a Station or CPU	5-20
5.5	User Interface and Operation	5-21
5.5.1	Operating Philosophy	5-21
5.5.2	Window Arrangement	5-22
5.5.3	Elements in Dialog Boxes.....	5-23
5.5.4	Creating and Managing Objects.....	5-24
5.5.5	Selecting Objects in a Dialog Box	5-29
5.5.6	Session Memory	5-30
5.5.7	Changing the Window Arrangement.....	5-31
5.5.8	Saving and Restoring the Window Arrangement	5-31
5.6	Keyboard Operation.....	5-32
5.6.1	Key Combinations for Menu Commands.....	5-32
5.6.2	Key Combinations for Moving the Cursor.....	5-34
5.6.3	Key Combinations for Selecting Text	5-36
5.6.4	Key Combinations for Access to Online Help.....	5-36
5.6.5	Key Combinations for Toggling between Windows	5-37
6	Setting Up and Editing the Project	6-1
6.1	Project Structure	6-1
6.2	What You Should Know About Access Protection	6-2
6.3	What You Should Know About The Change Log	6-4
6.4	Using Foreign-Language Character Sets	6-5
6.5	Setting the MS Windows Language	6-8
6.6	Setting Up a Project.....	6-9
6.6.1	Creating a Project.....	6-9
6.6.2	Inserting Stations	6-11
6.6.3	Inserting an S7/M7 Program.....	6-12
6.7	Editing a Project.....	6-14
6.7.1	Checking Projects for Software Packages Used.....	6-15

6.8	Managing Multilingual Texts	6-15
6.8.1	Types of Multilingual Texts	6-17
6.8.2	Structure of the Export File	6-18
6.8.3	Managing User Texts Whose Language Font is Not Installed	6-19
6.8.4	Information on the Log File	6-20
6.8.5	Optimizing the Source for Translation	6-21
6.8.6	Optimizing the Translation Process	6-22
6.9	Micro Memory Card (MMC) as a Data Carrier	6-23
6.9.1	What You Should Know About Micro Memory Cards (MMC)	6-23
6.9.2	Using a Micro Memory Card as a Data Carrier	6-25
6.9.3	Memory Card File	6-25
6.9.4	Storing Project Data on a Micro Memory Card (MMC)	6-26
7	Editing Projects with Different Versions of STEP 7	7-1
7.1	Editing Version 2 Projects and Libraries	7-1
7.2	Expanding DP Slaves That Were Created with Previous Versions of STEP 7	7-1
7.3	Editing Current Configurations with Previous Versions of STEP 7	7-3
7.4	Appending SIMATIC PC Configurations of Previous Versions	7-4
7.5	Displaying Modules Configured with Later STEP 7 Versions or Optional Packages	7-6
8	Defining Symbols	8-1
8.1	Absolute and Symbolic Addressing	8-1
8.2	Shared and Local Symbols	8-3
8.3	Displaying Shared or Local Symbols	8-4
8.4	Setting the Address Priority (Symbolic/Absolute)	8-5
8.5	Symbol Table for Shared Symbols	8-9
8.5.1	Structure and Components of the Symbol Table	8-9
8.5.2	Addresses and Data Types Permitted in the Symbol Table	8-11
8.5.3	Incomplete and Non-Unique Symbols in the Symbol Table	8-12
8.6	Entering Shared Symbols	8-13
8.6.1	General Tips on Entering Symbols	8-13
8.6.2	Entering Single Shared Symbols in a Dialog Box	8-14
8.6.3	Entering Multiple Shared Symbols in the Symbol Table	8-15
8.6.4	Using Upper and Lower Case for Symbols	8-16
8.6.5	Exporting and Importing Symbol Tables	8-18
8.6.6	File Formats for Importing/Exporting a Symbol Table	8-18
8.6.7	Editing Areas in Symbol Tables	8-21
9	Creating Blocks and Libraries	9-1
9.1	Selecting an Editing Method	9-1
9.2	Selecting the Programming Language	9-2
9.2.1	Ladder Logic Programming Language (LAD)	9-4
9.2.2	Function Block Diagram Programming Language (FBD)	9-5
9.2.3	Statement List Programming Language (STL)	9-6
9.2.4	S7 SCL Programming Language	9-7
9.2.5	S7-GRAPH Programming Language (Sequential Control)	9-8
9.2.6	S7 HiGraph Programming Language (State Graph)	9-9
9.2.7	S7 CFC Programming Language	9-10
9.3	Creating Blocks	9-11
9.3.1	Blocks Folder	9-11
9.3.2	User-Defined Data Types (UDT)	9-12
9.3.3	Block Properties	9-13
9.3.4	Displaying Block Lengths	9-15
9.3.5	Comparing Blocks	9-16
9.3.6	Rewiring	9-19

9.3.7	Attributes for Blocks and Parameters	9-19
9.4	Working with Libraries	9-20
9.4.1	Hierarchical Structure of Libraries	9-22
9.4.2	Overview of the Standard Libraries	9-22
10	Creating Logic Blocks	10-1
10.1	Basics of Creating Logic Blocks	10-1
10.1.1	Structure of the Program Editor Window	10-1
10.1.2	Basic Procedure for Creating Logic Blocks	10-3
10.1.3	Default Settings for the LAD/STL/FBD Program Editor	10-4
10.1.4	Access Rights to Blocks and Source Files	10-4
10.1.5	Instructions from the Program Elements Table	10-5
10.2	Editing the Variable Declaration	10-6
10.2.1	Using the Variable Declaration in Logic Blocks	10-6
10.2.2	Interaction Between The Variable Detail View And The Instruction List	10-8
10.2.3	Structure of the Variable Declaration Window	10-9
10.3	Multiple Instances in the Variable Declaration	10-10
10.3.1	Using Multiple Instances	10-10
10.3.2	Rules for Declaring Multiple Instances	10-11
10.3.3	Entering a Multiple Instance in the Variable Declaration Window	10-11
10.4	General Notes on Entering Statements and Comments	10-12
10.4.1	Structure of the Code Section	10-12
10.4.2	Procedure for Entering Statements	10-13
10.4.3	Entering Shared Symbols in a Program	10-14
10.4.4	Title and Comments for Blocks and Networks	10-15
10.4.5	Entering Block Comments and Network Comments	10-16
10.4.6	Working with Network Templates	10-17
10.4.7	Search Function for Errors in the Code Section	10-18
10.5	Editing LAD Elements in the Code Section	10-19
10.5.1	Settings for Ladder Logic Programming	10-19
10.5.2	Rules for Entering Ladder Logic Elements	10-19
10.5.3	Illegal Logic Operations in Ladder	10-22
10.6	Editing FBD Elements in the Code Section	10-23
10.6.1	Settings for Function Block Diagram Programming	10-23
10.6.2	Rules for Entering FBD Elements	10-24
10.7	Editing STL Statements in the Code Section	10-26
10.7.1	Settings for Statement List Programming	10-26
10.7.2	Rules for Entering STL Statements	10-26
10.8	Updating Block Calls	10-27
10.8.1	Changing Interfaces	10-28
10.9	Saving Logic Blocks	10-29
11	Creating Data Blocks	11-1
11.1	Basic Information on Creating Data Blocks	11-1
11.2	Declaration View of Data Blocks	11-2
11.3	Data View of Data Blocks	11-3
11.4	Editing and Saving Data Blocks	11-4
11.4.1	Entering the Data Structure of Shared Data Blocks	11-4
11.4.2	Entering and Displaying the Data Structure of Data Blocks Referencing an FB (Instance DBs)	11-5
11.4.3	Entering the Data Structure of User-Defined Data Types (UDT)	11-7
11.4.4	Entering and Displaying the Structure of Data Blocks Referencing a UDT	11-8
11.4.5	Editing Data Values in the Data View	11-9
11.4.6	Resetting Data Values to their Initial Values	11-9
11.4.7	Saving Data Blocks	11-10

12	Parameter Assignment for Data Blocks	12-1
12.1	Assigning Parameters to Technological Functions	12-2
13	Creating STL Source Files	13-1
13.1	Basic Information on Programming in STL Source Files.....	13-1
13.2	Rules for Programming in STL Source Files	13-2
13.2.1	Rules for Entering Statements in STL Source Files	13-2
13.2.2	Rules for Declaring Variables in STL Source Files	13-3
13.2.3	Rules for Block Order in STL Source Files.....	13-4
13.2.4	Rules for Setting System Attributes in STL Source Files	13-4
13.2.5	Rules for Setting Block Properties in STL Source Files	13-5
13.2.6	Permitted Block Properties for Each Block Type.....	13-7
13.3	Structure of Blocks in STL Source Files.....	13-7
13.3.1	Structure of Logic Blocks in STL Source Files	13-8
13.3.2	Structure of Data Blocks in STL Source Files	13-9
13.3.3	Structure of User-Defined Data Types in STL Source Files.....	13-9
13.4	Syntax and Formats for Blocks in STL Source Files	13-10
13.4.1	Format Table of Organization Blocks	13-10
13.4.2	Format Table of Function Blocks	13-11
13.4.3	Format Table of Functions.....	13-12
13.4.4	Format Table of Data Blocks	13-13
13.5	Creating STL Source Files	13-14
13.5.1	Creating STL Source Files	13-14
13.5.2	Editing S7 Source Files	13-14
13.5.3	Setting The Layout of Source Code Text	13-15
13.5.4	Inserting Block Templates in STL Source Files.....	13-15
13.5.5	Inserting the Contents of Other STL Source Files.....	13-15
13.5.6	Inserting Source Code from Existing Blocks in STL Source Files.....	13-16
13.5.7	Inserting External Source Files.....	13-16
13.5.8	Generating STL Source Files from Blocks	13-17
13.5.9	Importing Source Files.....	13-17
13.5.10	Exporting Source Files.....	13-18
13.6	Saving and Compiling STL Source Files and Executing a Consistency Check	13-19
13.6.1	Saving STL Source Files	13-19
13.6.2	Checking Consistency in STL Source Files.....	13-19
13.6.3	Debugging STL Source Files.....	13-19
13.6.4	Compiling STL Source Files	13-20
13.7	Examples of STL Source Files	13-21
13.7.1	Examples of Declaring Variables in STL Source Files	13-21
13.7.2	Example of Organization Blocks in STL Source Files	13-22
13.7.3	Example of Functions in STL Source Files.....	13-23
13.7.4	Example of Function Blocks in STL Source Files.....	13-25
13.7.5	Example of Data Blocks in STL Source Files	13-27
13.7.6	Example of User-Defined Data Types in STL Source Files	13-28
14	Displaying Reference Data	14-1
14.1	Overview of the Available Reference Data.....	14-1
14.1.1	Cross-Reference List.....	14-2
14.1.2	Program Structure	14-4
14.1.3	Assignment List	14-6
14.1.4	Unused Symbols.....	14-8
14.1.5	Addresses Without Symbols.....	14-9
14.1.6	Displaying Block Information for LAD, FBD, and STL	14-9

14.2	Working with Reference Data	14-10
14.2.1	Ways of Displaying Reference Data	14-10
14.2.2	Displaying Lists in Additional Working Windows	14-10
14.2.3	Generating and Displaying Reference Data	14-11
14.2.4	Finding Address Locations in the Program Quickly.....	14-12
14.2.5	Example of Working with Address Locations	14-13
15	Checking Block Consistency and Time Stamps as a Block Property	15-1
15.1	Checking Block Consistency	15-1
15.2	Time Stamps as a Block Property and Time Stamp Conflicts.....	15-3
15.3	Time Stamps in Logic Blocks	15-4
15.4	Time Stamps in Shared Data Blocks.....	15-5
15.5	Time Stamps in Instance Data Blocks.....	15-5
15.6	Time Stamps in UDTs and Data Blocks Derived from UDTs	15-6
15.7	Correcting the Interfaces in a Function, Function Block, or UDT	15-6
15.8	Avoiding Errors when Calling Blocks.....	15-7
16	Configuring Messages	16-1
16.1	The Message Concept.....	16-1
16.1.1	What Are the Different Messaging Methods?.....	16-1
16.1.2	Choosing a Messaging Method	16-3
16.1.3	SIMATIC Components.....	16-5
16.1.4	Parts of a Message.....	16-5
16.1.5	Which Message Blocks Are Available?	16-6
16.1.6	Formal Parameters, System Attributes, and Message Blocks	16-8
16.1.7	Message Type and Messages.....	16-9
16.1.8	How to Generate an STL Source File from Message-Type Blocks.....	16-10
16.1.9	Assigning Message Numbers.....	16-10
16.1.10	Differences Between Project-Oriented and CPU-Oriented Assignment of Message Numbers.....	16-11
16.1.11	Options for Modifying the Message Number Assignment of a Project.....	16-11
16.2	Project-Oriented Message Configuration	16-12
16.2.1	How to Assign Project-Oriented Message Numbers	16-12
16.2.2	Assigning and Editing Block-Related Messages	16-12
16.2.2.1	How to Create Block-Related Messages (Project-Oriented).....	16-13
16.2.2.2	How to Edit Block-Related Messages (Project-Oriented).....	16-16
16.2.2.3	How to Configure PCS 7 Messages (Project-Oriented)	16-16
16.2.3	Assigning and Editing Symbol-Related Messages.....	16-18
16.2.3.1	How to Assign and Edit Symbol-Related Messages (Project-Oriented)	16-18
16.2.4	Creating and Editing User-Defined Diagnostic Messages	16-19
16.3	CPU-Oriented Message Configuration	16-20
16.3.1	How to Assign CPU-Oriented Message Numbers.....	16-20
16.3.2	Assigning and Editing Block-Related Messages	16-21
16.3.2.1	How to Create Block-Related Messages (CPU-Oriented).....	16-21
16.3.2.2	How to Edit Block-Related Messages (CPU-Oriented)	16-24
16.3.2.3	How to Configure PCS 7 Messages (CPU-Oriented).....	16-25
16.3.3	Assigning and Editing Symbol-Related Messages.....	16-26
16.3.3.1	How to Assign and Edit Symbol-Related Messages (CPU-Oriented)	16-26
16.3.4	Assigning and Editing User-Specific Diagnostic Messages	16-27
16.4	Tips for Editing Messages	16-28
16.4.1	Adding Associated Values to Messages	16-28
16.4.2	Integrating Texts from Text Libraries into Messages	16-30
16.4.3	Deleting Associated Values	16-31
16.5	Translating and Editing Operator Related Texts	16-32
16.5.1	Translating and Editing User Texts	16-32

16.6	Translating and Editing Text Libraries	16-34
16.6.1	User Text Libraries	16-34
16.6.2	Creating User Text Libraries.....	16-34
16.6.3	How to Edit User Text Libraries.....	16-35
16.6.4	System Text Libraries	16-36
16.6.5	Translating Text Libraries	16-36
16.7	Transferring Message Configuration Data to the Programmable Controller	16-38
16.8	Displaying CPU Messages and User-Defined Diagnostic Messages	16-39
16.8.1	Configuring CPU Messages	16-42
16.8.2	Displaying Stored CPU Messages	16-42
16.9	Configuring the 'Reporting of System Errors'	16-43
16.9.1	Supported Components and Functional Scope.....	16-45
16.9.2	Settings for "Report System Error"	16-48
16.9.3	Generating Blocks for Reporting System Errors	16-49
16.9.4	Generated FB, DB	16-49
16.9.5	Creating Foreign-Language Message Texts in 'Report System Error'	16-51
17	Controlling and Monitoring Variables	17-1
17.1	Configuring Variables for Operator Control and Monitoring	17-1
17.2	Configuring Operator Control and Monitoring Attributes with Statement List, Ladder Logic, and Function Block Diagram	17-3
17.3	Configuring Operator Control and Monitoring Attributes via the Symbol Table	17-4
17.4	Changing Operator Control and Monitoring Attributes with CFC	17-5
17.5	Transferring Configuration Data to the Operator Interface Programmable Controller	17-6
18	Establishing an Online Connection and Making CPU Settings	18-1
18.1	Establishing Online Connections.....	18-1
18.1.1	Establishing an Online Connection via the "Accessible Nodes" Window.....	18-2
18.1.2	Establishing an Online Connection via the Online Window of the Project	18-3
18.1.3	Online Access to PLCs in a Multiproject.....	18-4
18.1.4	Password Protection for Access to Programmable Controllers.....	18-6
18.1.5	Updating the Window Contents	18-7
18.2	Displaying and Changing the Operating Mode.....	18-8
18.2.1	Displaying and Changing the Operating Mode.....	18-8
18.3	Displaying and Setting the Time and Date	18-9
18.3.1	CPU Clocks with Time Zone Setting and Summer/Winter Time	18-9
18.4	Updating the Firmware	18-10
18.4.1	Updating Firmware in Modules and Submodules Online	18-10
19	Downloading and Uploading	19-1
19.1	Downloading from the PG/PC to the Programmable Controller	19-1
19.1.1	Requirements for Downloading	19-1
19.1.2	Differences Between Saving and Downloading Blocks.....	19-2
19.1.3	Load Memory and Work Memory in the CPU.....	19-3
19.1.4	Download Methods Dependent on the Load Memory	19-4
19.1.5	Downloading a Program to the S7 CPU.....	19-5
19.1.5.1	Downloading with Project Management	19-5
19.1.5.2	Downloading without Project Management	19-6
19.1.5.3	Reloading Blocks in the Programmable Controller.....	19-6
19.1.5.4	Saving Downloaded Blocks on Integrated EPROM	19-7
19.1.5.5	Downloading via EPROM Memory Cards	19-7
19.2	Compiling and Downloading Several Objects from the PG.....	19-9
19.2.1	Requirements for and Notes on Downloading.....	19-9
19.2.2	Compiling and Downloading Objects.....	19-11

19.3	Uploading from the Programmable Controller to the PG/PC.....	19-13
19.3.1	Uploading a Station	19-14
19.3.2	Uploading Blocks from an S7 CPU.....	19-15
19.3.3	Editing Uploaded Blocks in the PG/PC.....	19-16
19.3.3.1	Editing Uploaded Blocks if the User Program is on the PG/PC	19-17
19.3.3.2	Editing Uploaded Blocks if the User Program is Not on the PG/PC.....	19-17
19.4	Deleting on the Programmable Controller	19-18
19.4.1	Erasing the Load/Work Memory and Resetting the CPU	19-18
19.4.2	Deleting S7 Blocks on the Programmable Controller	19-19
19.5	Compressing the User Memory (RAM)	19-20
19.5.1	Gaps in the User Memory (RAM)	19-20
19.5.2	Compressing the Memory Contents of an S7 CPU.....	19-21
20	Testing with the Variable Table	20-1
20.1	Introduction to Testing with Variable Tables	20-1
20.2	Basic Procedure when Monitoring and Modifying with the Variable Table	20-2
20.3	Editing and Saving Variable Tables.....	20-3
20.3.1	Creating and Opening a Variable Table	20-3
20.3.2	Copying/Moving Variable Tables.....	20-3
20.3.3	Saving a Variable Table.....	20-4
20.4	Entering Variables in Variable Table	20-4
20.4.1	Inserting Addresses or Symbols in a Variable Table.....	20-4
20.4.2	Inserting a Contiguous Address Range in a Variable Table.....	20-6
20.4.3	Inserting Modify Values	20-7
20.4.4	Upper Limits for Entering Timers.....	20-7
20.4.5	Upper Limits for Entering Counters	20-8
20.4.6	Inserting Comment Lines.....	20-9
20.4.7	Examples	20-9
20.5	Establishing a Connection to the CPU	20-13
20.6	Monitoring Variables	20-14
20.6.1	Introduction to Monitoring Variables	20-14
20.6.2	Defining the Trigger for Monitoring Variables	20-14
20.7	Modifying Variables	20-16
20.7.1	Introduction to Modifying Variables	20-16
20.7.2	Defining the Trigger for Modifying Variables	20-17
20.8	Forcing Variables.....	20-19
20.8.1	Safety Measures When Forcing Variables	20-19
20.8.2	Introduction to Forcing Variables.....	20-20
20.8.3	Differences Between Forcing and Modifying Variables.....	20-22
21	Testing Using Program Status	21-1
21.1	Program Status Display.....	21-2
21.2	What You Should Know About Testing in Single-Step Mode/Breakpoints.....	21-3
21.3	What You Should Know About the HOLD Mode	21-5
21.4	Program Status of Data Blocks	21-6
21.5	Setting the Display for Program Status	21-7
21.6	Setting the Mode for the Test	21-8
22	Testing using the Simulation Program (Optional Package)	22-1
22.1	Testing using the Simulation Program S7-PLCSIM (Optional Package)	22-1

23	Diagnostics	23-1
23.1	Hardware Diagnostics and Troubleshooting.....	23-1
23.2	Diagnostics Symbols in the Online View	23-3
23.3	Diagnosing Hardware: Quick View	23-5
23.3.1	Calling the Quick View.....	23-5
23.3.2	Information Functions in the Quick View	23-5
23.4	Diagnosing Hardware: Diagnostic View	23-6
23.4.1	Calling the Diagnostic View	23-6
23.4.2	Information Functions in the Diagnostic View.....	23-8
23.5	Module Information	23-9
23.5.1	Options for Displaying the Module Information	23-9
23.5.2	Module Information Functions	23-10
23.5.3	Scope of the Module Type-Dependent Information.....	23-12
23.5.4	Displaying the Module Status of PA Field Devices and DP Slaves After a Y-Link	23-13
23.6	Diagnosing in STOP Mode	23-15
23.6.1	Basic Procedure for Determining the Cause of a STOP	23-15
23.6.2	Stack Contents in STOP Mode.....	23-15
23.7	Checking Scan Cycle Times to Avoid Time Errors.....	23-17
23.8	Flow of Diagnostic Information	23-18
23.8.1	System Status List SSL	23-19
23.8.2	Sending Your Own Diagnostic Messages	23-22
23.8.3	Diagnostic Functions	23-23
23.9	Program Measures for Handling Errors.....	23-24
23.9.1	Evaluating the Output Parameter RET_VAL	23-25
23.9.2	Error OBs as a Reaction to Detected Errors	23-26
23.9.3	Inserting Substitute Values for Error Detection	23-31
23.9.4	I/O Redundancy Error (OB70).....	23-33
23.9.5	CPU Redundancy Error (OB72)	23-34
23.9.6	Time Error (OB80)	23-35
23.9.7	Power Supply Error (OB81).....	23-36
23.9.8	Diagnostic Interrupt (OB82).....	23-37
23.9.9	Insert/Remove Module Interrupt (OB83)	23-38
23.9.10	CPU Hardware Fault (OB84).....	23-39
23.9.11	Program Sequence Error (OB85).....	23-40
23.9.12	Rack Failure (OB86).....	23-41
23.9.13	Communication Error (OB87).....	23-42
23.9.14	Programming Error (OB121)	23-43
23.9.15	I/O Access Error (OB122).....	23-44
24	Printing and Archiving	24-1
24.1	Printing Project Documentation	24-1
24.1.1	Basic Procedure when Printing	24-2
24.1.2	Print Functions.....	24-2
24.1.3	Special Note on Printing the Object Tree	24-3
24.2	Archiving Projects and Libraries	24-4
24.2.1	Uses for Saving/Archiving.....	24-5
24.2.2	Requirements for Archiving	24-5
24.2.3	Procedure for Archiving/Retrieving.....	24-6
25	Working with M7 Programmable Control Systems	25-1
25.1	Procedure for M7 Systems	25-1
25.2	Optional Software for M7 Programming	25-3
25.3	M7-300/M7-400 Operating Systems.....	25-6

26	Tips and Tricks	26-1
26.1	Exchanging Modules in the Configuration Table	26-1
26.2	Projects with a Large Number of Networked Stations	26-1
26.3	Rearranging	26-2
26.4	Editing Symbols Across Multiple Networks	26-2
26.5	Testing with the Variable Table	26-3
26.6	Modifying Variables With the Program Editor	26-4
26.7	Virtual Work Memory	26-5
A	Appendix	A-1
A.1	Operating Modes	A-1
A.1.1	Operating Modes and Mode Transitions	A-1
A.1.2	STOP Mode	A-4
A.1.3	STARTUP Mode	A-5
A.1.4	RUN Mode	A-13
A.1.5	HOLD Mode	A-14
A.2	Memory Areas of S7 CPUs	A-15
A.2.1	Distribution of the Memory Areas	A-15
A.2.2	Load Memory and Work Memory	A-16
A.2.3	System Memory	A-18
A.2.3.1	Using the System Memory Areas	A-18
A.2.3.2	Process-Image Input/Output Tables	A-20
A.2.3.3	Local Data Stack	A-24
A.2.3.4	Interrupt Stack	A-25
A.2.3.5	Block Stack	A-26
A.2.3.6	Diagnostic Buffer	A-27
A.2.3.7	Evaluating the Diagnostic Buffer	A-27
A.2.3.8	Retentive Memory Areas on S7-300 CPUs	A-29
A.2.3.9	Retentive Memory Areas on S7-400 CPUs	A-30
A.2.3.10	Configurable Memory Objects in the Work Memory	A-31
A.3	Data Types and Parameter Types	A-32
A.3.1	Introduction to Data Types and Parameter Types	A-32
A.3.2	Elementary Data Types	A-33
A.3.2.1	Format of the Data Type INT (16-Bit Integers)	A-34
A.3.2.2	Format of the Data Type DINT (32-Bit Integers)	A-34
A.3.2.3	Format of the Data Type REAL (Floating-Point Numbers)	A-35
A.3.2.4	Format of the Data Types WORD and DWORD in Binary Coded Decimal Numbers	A-39
A.3.2.5	Format of the Data Type S5TIME (Time Duration)	A-40
A.3.3	Complex Data Types	A-41
A.3.3.1	Format of the Data Type DATE_AND_TIME	A-42
A.3.3.2	Using Complex Data Types	A-44
A.3.3.3	Using Arrays to Access Data	A-45
A.3.3.4	Using Structures to Access Data	A-48
A.3.3.5	Using User-Defined Data Types to Access Data	A-50
A.3.4	Parameter Types	A-52
A.3.4.1	Format of the Parameter Types BLOCK, COUNTER, TIMER	A-53
A.3.4.2	Format of the Parameter Type POINTER	A-53
A.3.4.3	Using the Parameter Type POINTER	A-54
A.3.4.4	Block for Changing the Pointer	A-55
A.3.4.5	Format of the Parameter Type ANY	A-58
A.3.4.6	Using the Parameter Type ANY	A-61
A.3.4.7	Assigning Data Types to Local Data of Logic Blocks	A-64
A.3.4.8	Permitted Data Types when Transferring Parameters	A-66
A.3.4.9	Transferring to IN_OUT Parameters of a Function Block	A-71

A.4	Working with Older Projects	A-72
A.4.1	Converting Version 1 Projects	A-72
A.4.2	Converting Version 2 Projects	A-73
A.4.3	Notes on STEP 7 V.2.1 Projects with GD Communication	A-74
A.4.4	DP-Slaves with Missing or Faulty GSD Files.....	A-74
A.5	Sample Programs	A-75
A.5.1	Sample Projects and Sample Programs.....	A-75
A.5.2	Sample Program for an Industrial Blending Process.....	A-77
A.5.2.1	Defining Logic Blocks	A-79
A.5.2.2	Assigning Symbolic Names	A-81
A.5.2.3	Creating the FB for the Motor	A-83
A.5.2.4	Creating the FC for the Valves	A-88
A.5.2.5	Creating OB1	A-90
A.5.3	Example of Handling Time-of-Day Interrupts	A-96
A.5.3.1	Structure of the User Program "Time-of-Day Interrupts"	A-96
A.5.3.2	FC12	A-98
A.5.3.3	OB10.....	A-100
A.5.3.4	OB1 and OB80	A-102
A.5.4	Example of Handling Time-Delay Interrupts.....	A-104
A.5.4.1	Structure of the User Program "Time-Delay Interrupts"	A-104
A.5.4.2	OB20.....	A-106
A.5.4.3	OB1.....	A-108
A.5.4.4	Example of Masking and Unmasking Synchronous Errors	A-110
A.5.4.5	Example of Disabling and Enabling Interrupts and Asynchronous Errors (SFC39 and SFC40)	A-115
A.5.4.6	Example of the Delayed Processing of Interrupts and Asynchronous Errors (SFC41 and SFC42)	A-116
A.6	Accessing Process and I/O Data Areas	A-117
A.6.1	Accessing the Process Data Area	A-117
A.6.2	Accessing the Peripheral Data Area.....	A-118
A.7	Setting the Operating Behavior	A-120
A.7.1	Changing the Behavior and Properties of Modules.....	A-121
A.7.2	Updating the Firmware (of the Operating System) in Modules and Submodules Offline.....	A-124
A.7.3	Using the Clock Functions.....	A-126
A.7.4	Using Clock Memory and Timers	A-128

Index

Index-1

1 Introducing the Product and Installing the Software

1.1 Overview of STEP 7

What is STEP 7?


STEP 7 is the standard software package used for configuring and programming SIMATIC programmable logic controllers. It is part of the SIMATIC industry software. There are the following versions of the STEP 7 Standard package:

- STEP 7 Micro/DOS and STEP 7 Micro/Win for simpler stand-alone applications on the SIMATIC S7-200.
- STEP 7 for applications on SIMATIC S7-300/S7-400, SIMATIC M7-300/M7-400, and SIMATIC C7 with a wider range of functions:
 - Can be extended as an option by the software products in the SIMATIC Industry Software (see also Extended Uses of the STEP 7 Standard Package)
 - Opportunity of assigning parameters to function modules and communications processors
 - Forcing and multicomputing mode
 - Global data communication
 - Event-driven data transfer using communication function blocks
 - Configuring connections

STEP 7 is the subject of this documentation, STEP 7 Micro is described in the "STEP 7 Micro/DOS" documentation.

Basic Tasks

When you create an automation solution with STEP 7, there are a series of basic tasks. The following figure shows the tasks that need to be performed for most projects and assigns them to a basic procedure. It refers you to the relevant chapter thus giving you the opportunity of moving through the manual to find task-related information.



Alternative Procedures

As shown in the figure above, you have two alternative procedures:

- You can configure the hardware first and then program the blocks.
- You can, however, program the blocks first without configuring the hardware. This is recommended for service and maintenance work, for example, to integrate programmed blocks into an existing project.

Brief Description of the Individual Steps

- **Install STEP 7 and license keys**
The first time you use STEP 7, install it and transfer the license keys from diskette to the hard disk (see also Installing STEP 7 and Authorization).
- **Plan your controller**
Before you work with STEP 7, plan your automation solution from dividing the process into individual tasks to creating a configuration diagram (see also Basic Procedure for Planning an Automation Project).
- **Design the program structure**
Turn the tasks described in the draft of your controller design into a program structure using the blocks available in STEP 7 (see also Blocks in the User Program).
- **Start STEP 7**
You start STEP 7 from the Windows user interface (see also Starting STEP 7).
- **Create a project structure**
A project is like a folder in which all data are stored in a hierarchical structure and are available to you at any time. After you have created a project, all other tasks are executed in this project (see also Project Structure).
- **Configure a station**
When you configure the station you specify the programmable controller you want to use; for example, SIMATIC 300, SIMATIC 400, SIMATIC S5 (see also Inserting Stations).
- **Configure hardware**
When you configure the hardware you specify in a configuration table which modules you want to use for your automation solution and which addresses are to be used to access the modules from the user program. The properties of the modules can also be assigned using parameters (see also Basic Procedure for Configuring Hardware).
- **Configure networks and communication connections**
The basis for communication is a pre-configured network. For this, you will need to create the subnets required for your automation networks, set the subnet properties, and set the network connection properties and any communication connections required for the networked stations (see also Procedure for Configuring a Subnet).
- **Define symbols**
You can define local or shared symbols, which have more descriptive names, in a symbol table to use instead of absolute addresses in your user program (see also Creating a Symbol Table).

- **Create the program**
Using one of the available programming languages create a program linked to a module or independent of a module and store it as blocks, source files, or charts (see also Basic Procedure for Creating Logic Blocks and Basic Information on Programming in STL Source Files).
- **S7 only: generate and evaluate reference data**
You can make use of these reference data to make debugging and modifying your user program easier (see also Overview of the Available Reference Data).
- **Configure messages**
You create block-related messages, for example, with their texts and attributes. Using the transfer program you transfer the message configuration data created to the operator interface system database (for example, SIMATIC WinCC, SIMATIC ProTool), see also Configuring Messages.
- **Configure operator control and monitoring variables**
You create operator control and monitoring variables once in STEP 7 and assign them the required attributes. Using the transfer program you transfer the operator control and monitoring variables created to the database of the operator interface system WinCC (see also Configuring Variables for Operator Control and Monitoring).
- **Download programs to the programmable controller**
S7 only: after all configuration, parameter assignment, and programming tasks are completed, you can download your entire user program or individual blocks from it to the programmable controller (programmable module for your hardware solution). (See also Requirements for Downloading.) The CPU already contains the operating system.
M7 only: choose a suitable operating system for your automation solution from a number of different operating systems and transfer this on its own or together with the user program to the required data medium of the M7 programmable control system.
- **Test programs**
S7 only: for testing you can either display the values of variables from your user program or a CPU, assign values to the variables, and create a variable table for the variables that you want to display or modify (see also Introduction to Testing with the Variable Table).
M7 only: test the user program with a high-level language-debugging tool.
- **Monitor operation, diagnose hardware**
You determine the cause of a module fault by displaying online information about a module. You determine the causes for errors in user program processing with the help of the diagnostic buffer and the stack contents. You can also check whether a user program can run on a particular CPU (see also Hardware Diagnostics and Displaying Module Information).
- **Document the plant**
After you have created a project/plant, it makes sense to produce clear documentation of the project data to make further editing of the project and any service activities easier (see also Printing Project Documentation). DOCPRO, the optional tool for creating and managing plant documentation, allows you to structure the project data, put it into wiring manual form, and print it out in a common format.

Specialized Topics

When you create an automation solution there are a number of special topics that may be of interest to you:

- Multicomputing - Synchronous Operation of Several CPUs (see also Multicomputing - Synchronous Operation of Several CPUs)
- More than One User Working in a Project (see also More than One User Editing Projects)
- Working with M7 Systems (see also Procedure for M7 Systems)

1.2 The STEP 7 Standard Package

Standards Used

The SIMATIC programming languages integrated in STEP 7 are compliant with EN 61131-3. The standard package matches the graphic and object oriented operating philosophy of Windows and runs under the operating system MS Windows 2000 Professional (as of now referred to as Windows 2000) as well as MS Windows XP Professional (as of now referred to as Windows XP) and MS Windows Server 2003.

Functions of the standard package

The standard software supports you in all phases of the creation process of an automation task, such as:

- Setting up and managing projects
- Configuring and assigning parameters to hardware and communications
- Managing symbols
- Creating programs, for example, for S7 programmable controllers
- Downloading programs to programmable controllers
- Testing the automation system
- Diagnosing plant failures

The STEP 7 software user interface has been designed to meet the latest state-of-the-art ergonomics and makes it easy for you to get started.

The documentation for the STEP 7 software product provides all the information online in the online Help and in electronic manuals in PDF format.

Applications in STEP 7


The STEP 7 Standard package provides a series of applications (tools) within the software:



You do not need to open the tools separately; they are started automatically when you select the corresponding function or open an object.

SIMATIC Manager

The SIMATIC Manager manages all the data that belong to an automation project – regardless of which programmable control system (S7/M7/C7) they are designed for. The tools needed to edit the selected data are started automatically by the SIMATIC Manager.



Symbol Editor

With the Symbol Editor you manage all the shared symbols. The following functions are available:

- Setting symbolic names and comments for the process signals (inputs/outputs), bit memory, and blocks
- Sort functions
- Import/export to/from other Windows programs

The symbol table created with this tool is available to all the other tools. Any changes to the properties of a symbol are therefore recognized automatically by all tools.

Diagnosing Hardware

These functions provide you with an overview of the status of the programmable controller. An overview can display symbols to show whether every module has a fault or not. A double-click on the faulty module displays detailed information about the fault. The scope of this information depends on the individual module:

- Display general information about the module (for example, order number, version, name) and the status of the module (for example, faulty)
- Display the module faults (for example, channel fault) for the central I/O and DP slaves
- Display messages from the diagnostic buffer

For CPUs the following additional information is displayed:

- Causes of faults in the processing of a user program
- Display the cycle duration (of the longest, shortest, and last cycle)
- MPI communication possibilities and load
- Display performance data (number of possible inputs/outputs, bit memory, counters, timers, and blocks)

Programming Languages

The programming languages Ladder Logic, Statement List, and Function Block Diagram for S7-300 and S7-400 are an integral part of the standard package.

- Ladder Logic (or LAD) is a graphic representation of the STEP 7 programming language. Its syntax for the instructions is similar to a relay ladder logic diagram: Ladder allows you to track the power flow between power rails as it passes through various contacts, complex elements, and output coils.
- Statement List (or STL) is a textual representation of the STEP 7 programming language, similar to machine code. If a program is written in Statement List, the individual instructions correspond to the steps with which the CPU executes the program. To make programming easier, Statement List has been extended to include some high-level language constructions (such as structured data access and block parameters).
- Function Block Diagram (FBD) is a graphic representation of the STEP 7 programming language and uses the logic boxes familiar from Boolean algebra to represent the logic. Complex functions (for example, math functions) can be represented directly in conjunction with the logic boxes.

Other programming languages are available as optional packages.

Hardware Configuration

You use this tool to configure and assign parameters to the hardware of an automation project. The following functions are available:

- To configure the programmable controller you select racks from an electronic catalog and arrange the selected modules in the required slots in the racks.
- Configuring the distributed I/O is identical to the configuration of the central I/O. Channel-granular I/O is also supported.
- In the course of assigning parameters to the CPU you can set properties such as startup behavior and scan cycle time monitoring guided by menus. Multicomputing is supported. The data entered are stored in system data blocks.
- In the course of assigning parameters to the modules, all the parameters you can set are set using dialog boxes. There are no settings to be made using DIP switches. The assignment of parameters to the modules is done automatically during startup of the CPU. This means, for example, that a module can be exchanged without assigning new parameters.
- Assigning parameters to function modules (FMs) and communications processors (CPs) is also done within the Hardware Configuration tool in exactly the same way as for the other modules. Module-specific dialog boxes and rules exist for every FM and CP (included in the scope of the FM/CP function package). The system prevents incorrect entries by only offering valid options in the dialog boxes.

NetPro (Network Configuration)

Using NetPro time-driven cyclic data transfer via the MPI is possible where you:

- Select the communication nodes
- Enter the data source and data target in a table; all blocks (SDBs) to be downloaded are generated automatically and completely downloaded to all CPUs automatically

Event-driven data transfer is also possible where you:

- Set the communication connections
- Select the communication or function blocks from the integrated block library
- Assign parameters to the selected communication or function blocks in your chosen programming language

1.3 What's New in STEP 7, Version 5.4?

The following subject areas have been updated:

- SIMATIC Manager
- Configuring and Diagnosing Hardware
- Configuring Networks and Connections
- Standard Libraries
- Report System Error

SIMATIC Manager

- As of STEP 7 V5.4, there are two formats available for displaying the date and the time. You can select a display in the respective STEP 7 national language and or in ISO 8601 standard format. To make this setting, go to the SIMATIC Manager, open the "Customize" dialog box and select the "Date and Time" tab.
- As of STEP 7 V5.4, you can have module times displayed in the local time for your programming device (PG)/PC. To make this setting, go to the SIMATIC Manager, open the "Customize" dialog box and select the "Date and Time" tab.
- As of STEP 7 V5.4, you have the option of restricting access to projects and libraries by assigning a passwords to them. In order to do this, you must have installed SIMATIC Logon V1.3 SP1 (as of now referred to as SIMATIC Logon) (see What You Should Know About Access).
- As of STEP 7 V5.4, after setting up access protection for projects and libraries, you have the option of keeping a change log that records online actions such as "Download", "Operating Mode Changes", and "Reset". In order to do this, you must have installed SIMATIC Logon V1.3 SP1 (as of now referred to as SIMATIC Logon) (see What You Should Know About Access Protection).

Configuring and Diagnosing Hardware

- The "Information and Maintenance" process is supported in order to be able to read identification data from or write identification data to modules. This function is also available in the SIMATIC Manager (see Identification and Maintenance (I&M)).
- Identification data can also be written to PROFIBUS DP interface modules during redundant mode (by means of "Accessible Nodes"). The interface module must support this function.
- CAx data can be imported and exported. In this way, data can be exchanged between STEP 7 and CAD systems or CAE engineering systems (see Exporting and Importing CAx Data)
- The firmware for PROFIBUS DP interface modules can also be updated during redundant mode, as long as such a module will support this process. Each of the redundantly used interface modules can now send the updated firmware through the active backplane bus to the other, redundant interface module.
- The "Software Redundancy" function now allows PA links with subordinate PA slaves to be copied and redundantly inserted (see Configuring SW Redundancy)
- Applications for editing objects in HW Config can now be started with the **Edit > Open Object** menu command (see Opening Objects in HW Config).
- You can configure a watchdog time for PROFINET IO devices (see Configuring the Watchdog Time)
- As of STEP 7 V5.4, you can have module times displayed in the local time of your programming device (PG)/PC.

Configuring Networks and Connections

- PROFINET IO with IRT Communication (Isochronous Realtime) is supported. This means that short and equal-length bus-cycle times can also be configured for PROFINET IO (see Introduction: Isochronous Realtime Ethernet).
- There is improved handling when inserting copied IO devices into another station. If the IP addresses are already assigned, you can specify the action to be taken upon insertion (retain addresses or assign new ones).
- In a manner similar to that for PROFIBUS DP slaves, you can now set the watchdog time for PROFINET IO devices: as an object property of the IO device in the "IO Cycle" tab.
- When using optical components for PROFIBUS DP: when configuring with an optical ring, you can specify the optical link modules (OLMs) to be used. This makes calculation of bus parameters more exact. In addition, it means that the bus cycle time can be shortened when higher-performance components are being used.

Standard Libraries

- The standard library "Communication Blocks" has been expanded with the blocks FB 67 and FB 68 for open TCP/IP communication.
- The standard library "Communication Blocks" has been expanded with the blocks FB 20, FB 21, FB 22 and FB 23 for cyclic accessing of user data in accordance with the German PROFIBUS User Organization [PROFIBUS Nutzerorganisation e.V. (PNO)].
- In addition to the existing redundancy library "Redundant IO (V1)", as of STEP 7 V5.4 there is the new block library "Redundant IO CGP" (channel granular peripheral devices). It supports redundancy for single module channels. You can find further information in the context-sensitive block help or the STEP 7 readme file. A current list of supported modules is available under the FAQs here: <http://support.automation.siemens.com/>.

Report System Error

- As of STEP 7 V5.4, a data block (DB 125) for PROFIBUS is supported. This data block can be used to output diagnostic events on an HMI device.

1.4 Extended Uses of the STEP 7 Standard Package

The standard package can be extended by optional software packages that are grouped into the following three software classes:

- Engineering Tools;
these are higher-level programming languages and technology-oriented software.
- Run-Time Software;
these contain off-the-shelf run-time software for the production process.
- Human Machine Interfaces (HMI);
this is software especially for operator control and monitoring.


The following table shows the optional software you can use depending on your programmable control system:

		STEP 7	
	S7-300 S7-400	M7-300 M7-400	C7-620
Engineering Tools			
• Borland C/C++		o	
• CFC	+ ¹⁾	+	+ ²⁾
• DOCPRO	+	+ ³⁾	+
• HARDPRO	+		
• M7 ProC/C++		o	
• S7 GRAPH	+ ¹⁾		+ ²⁾
• S7 HiGraph	+		+
• S7 PDIAG	+		
• S7 PLCSIM	+		+
• S7 SCL	+		+
• Teleservice	+	+	+
Run-Time Software			
• Fuzzy Control	+		+
• M7-DDE Server		+	
• M7-SYS RT		o	
• Modular PID Control	+		+
• PC-DDE Server	+		
• PRODAVE MPI	+		
• Standard PID Control	+		+
Human Machine Interface			
• ProAgent			
• SIMATIC ProTool			
• SIMATIC ProTool/Lite			o
• SIMATIC WinCC			
o = obligatory + = optional 1) = recommended from S7-400 upwards 2) = not recommended for C7-620 3) = not for C programs			

1.4.1 Engineering Tools

Engineering Tools are task-oriented tools that can be used to extend the standard package. Engineering Tools include:

- High-level languages for programmers
- Graphic languages for technical staff
- Supplementary software for diagnostics, simulation, remote maintenance, plant documentation etc.



High-Level Languages

The following languages are available as optional packages for use in programming the SIMATIC S7-300/S7-400 programmable logic controllers:

- S7 GRAPH is a programming language used to program sequential controls (steps and transitions). In this language, the process sequence is divided into steps. The steps contain actions to control the outputs. The transition from one step to another is controlled by switching conditions.
- S7 HiGraph is a programming language used to describe asynchronous, non-sequential processes in the form of state graphs. To do this, the plant is broken down into individual functional units which can each take on different states. The functional units can be synchronized by exchanging messages between the graphs.
- S7 SCL is a high-level text-based language to EN 61131-3 (IEC 1131-3). It contains language constructs similar to those found in the programming languages C and Pascal. S7 SCL is therefore particularly suitable for users familiar with high-level language programming. S7 SCL can be used, for example, to program complex or frequently recurring functions.

Graphic Language

CFC for S7 and M7 is a programming language for interconnecting functions graphically. These functions cover a wide range of simple logic operations through to complex controls and control circuits. A large number of such function blocks are available in the form of blocks in a library. You program by copying the blocks into a chart and interconnecting the blocks with connecting lines.


Supplementary Software

- Borland C++ (M7 only) contains the Borland development environment.
- With DOCPRO you can organize all configuration data created under STEP 7 into wiring manuals. These wiring manuals make it easy to manage the configuration data and allow the information to be prepared for printing according to specific standards.
- HARDPRO is the hardware configuration system for S7-300 with user support for large-scale configuration of complex automation tasks.
- M7 ProC/C++ (M7 only) allows integration of the Borland development environment for the programming languages C and C++ into the STEP 7 development environment.
- You can use S7 PLCSIM (S7 only) to simulate S7 programmable controllers connected to the programming device or PC for purposes of testing.
- S7 PDIAG (S7 only) allows standardized configuration of process diagnostics for SIMATIC S7-300/S7-400. Process diagnostics let you detect faults and faulty states of PLC I/O (for example, limit switch not reached).
- TeleService is a solution providing functions for online programming and servicing of remote S7 and M7 PLCs via the telecommunications network with your PG/PC.

1.4.2 Run-Time Software

Runtime software provides ready-to-use solutions you can call in user program and is directly implemented in the automation solution. It includes:

- Controllers for SIMATIC S7, for example, standard, modular and fuzzy logic control
- Tools for linking the programmable controllers with Windows applications
- A real-time operating system for SIMATIC M7



Controllers for SIMATIC S7

- Standard PID Control allows you to integrate closed-loop controllers, pulse controllers, and step controllers into the user program. The parameter assignment tool with integrated controller setting allows you to set the controller up for optimum use in a very short time.
- Modular PID Control comes into play if a simple PID controller is not sufficient to solve your automation task. You can interconnect the included standard function blocks to create almost any controller structure.
- With Fuzzy Control you can create fuzzy logic systems. These systems are used if the mathematical definition of processes is impossible or highly complex, if processes and sequencers do not react as expected, if linearity errors occur and if, on the other hand, information on the process is available.

Tools for Linking with Windows

- PRODAVE MPI is a toolbox for process data traffic between SIMATIC S7, SIMATIC M7, and SIMATIC C7. It automatically controls the data flow across the MPI interface.
- An M7 DDE server (**D**ynamic **D**ata **E**xchange) can be used to link Windows applications to process variables in SIMATIC M7, without additional programming effort.


Real-Time Operating System

- M7-SYS RT contains the operating system M7 RMOS 32 and system programs. It is a prerequisite for the use of the M7-ProC/C++ and CFC for SIMATIC M7 packages.

1.4.3 Human Machine Interface

Human Machine Interface (HMI) is a software especially designed for operator control and monitoring in SIMATIC.

- The open process visualization system SIMATIC WinCC is a standard operator interface with all the important operator control and monitoring functions which can be used in any branch of industry and with any technology.
- SIMATIC ProTool and SIMATIC ProTool/Lite are modern tools for configuring SIMATIC operator panels (OPs) and SIMATIC C7 compact devices.
- ProAgent is a diagnostics software that acquires information on the location and cause of errors in plants and machinery and thus offers fast and aimed process diagnostics.



2 Installation

2.1 Automation License Manager

2.1.1 User Rights Through The Automation License Manager

Automation License Manager

To use STEP 7 programming software, you require a product-specific license key (user rights). Starting with STEP 7 V5.3, this key is installed with the Automation License Manager.

The Automation License Manager is a software product from Siemens AG. It is used to manage the license keys (license modules) for all systems.

The Automation License Manager is located in the following places:

- On the installation device for a software product requiring a license key
- On a separate installation device
- As a download from the Internet page of A&D Customer Support at Siemens AG

The Automation License Manager has its own integrated online help. To obtain help after the license manager is installed, press F1 or select the **Help > Help on License Manager**. This online help contains detailed information on the functionality and operation of the Automation License Manager.

Licenses

Licenses are required to use STEP 7 program packages whose legal use is protected by licenses. A license gives the user a legal right to use the product. Evidence of this right is provided by the following:

- The CoL (**Certificate of License**), and
- The license key

Certificate of License (CoL)

The "Certificate of License" that is included with a product is the legal evidence that a right to use this product exists. This product may only be used by the owner of the Certificate of License (CoL) or by those persons authorized to do so by the owner.

License Keys

The license key is the technical representation (an electronic "license stamp") of a license to use software.

SIEMENS AG issues a license key for all of its software that is protected by a license. When the computer has been started, such software can only be used in accordance with the applicable license and terms of use after the presence of a valid license key has been verified.

Notes

- You can use the standard software without a license key to familiarize yourself with the user interface and functions.
 - However, a license is required and necessary for full, unrestricted use of the STEP 7 software in accordance with the license agreement
 - If you have **not** installed the license key, you will be prompted to do so at regular intervals.
-

License Keys can be stored and transferred among various types of storage devices as follows:

- On license key diskettes
- On the local hard disk
- On network hard disk

If software products for which no license is available are installed, you can then determine which license key is needed and order it as required.

For further information on obtaining and using license keys, please refer to the online help for the Automation License Manager.

Types of Licenses

The following different types of application-oriented user licenses are available for software products from Siemens AG. The actual behavior of the software is determined by which type license key is installed for it. The type of use can be found on the accompanying Certificate of License.

License Type	Description
Single License	The software can be used on any single computer desired for an unlimited amount of time.
Floating License	The software can be used on a computer network ("remote use") for an unlimited amount of time.
Trial License	The software can be used subject to the following restrictions: <ul style="list-style-type: none"> • A period of validity of up to a maximum of 14 days, • A total number of operating days after the day of first use, • A use for tests and validation (exemption from liability).
Rental License	The software can be used subject to the following restrictions: <ul style="list-style-type: none"> • A period of validity of up to a maximum of 50 days • A total number of operating hours of use
Upgrade License	Certain requirements in the existing system may apply with regard to software upgrades: <ul style="list-style-type: none"> • An upgrade license may be used to convert an "old version X" of the software to a newer version X+. • An upgrade may be necessary due to an increase in the volume of data being handled in the given system.

2.1.2 Installing the Automation License Manager

The Automation License Manager is installed by means of an MSI setup process. The installation software for the Automation License Manager is included on the STEP 7 product CD.

You can install the Automation License Manager at the same time you install STEP 7 or at a later time.

Notes

- For detailed information on how to install the Automation License Manager, please refer to the current "Readme.wri" file
 - The online help for the Automation License Manager contains all the information you need on the function and handling of License Keys.
-

Subsequent installation of license keys

If you start the STEP 7 software and no license keys are available, a warning message indicating this condition will be displayed.

Notes

- You can use the standard software without a license key to familiarize yourself with the user interface and functions.
 - However, a license is required and necessary for full, unrestricted use of the STEP 7 software in accordance with the license agreement
 - If you have **not** installed the license key, you will be prompted to do so at regular intervals.
-

You can subsequently install license keys in the following ways:

- Install license keys from diskettes
- Install license keys downloaded from the Internet. In this case, the license keys must be ordered first.
- Use floating license keys available in a network

For detailed information on installing license keys, refer to the online help for the Automation License Manager. To access this help, press F1 or select the **Help > Help on License Manager** menu command.

Notes

- In Windows 2000/XP/Server 2003, license keys will only be operational if they are installed on a local hard disk and have write-access status.
 - Floating licenses can also be used within a network ("remote" use).
-

2.1.3 Guidelines for Handling License Keys



Caution

Please note the information on handling license keys that is available in the online help on the Automation License Manager and also in the STEP 7 Readme.wri file on the installation CD-ROM. If you do not follow these guidelines, the license keys may be irretrievably lost.

To access online help for the Automation License Manager, press F1 for context-sensitive help or select the **Help > Help on License Manager** menu command.

This help section contains all the information you need on the function and handling of license keys.

2.2 Installing STEP 7

The STEP 7 Setup program performs an automatic installation. The complete installation procedure is menu controlled. Execute Setup using the standard Windows 2000/XP/Server 2003 software installation procedure.

The major stages in the installation are:

- Copying the data to your programming device
- Configuration of EPROM and communication drivers
- Installing the license keys (if desired)

Note

Siemens programming devices are shipped with the STEP 7 software on the hard disk ready for installation.

Installation requirements

- Operating system:
Microsoft Windows 2000 or Windows XP, Windows Server 2003.
- Basic hardware:
Programming device or PC with:
- Pentium processor (600 MHz)
- At least 256 MB RAM.
- Color monitor, keyboard and mouse, all of which are supported by Microsoft Windows

A programming device (PG) is a PC with a special compact design for industrial use. It is fully equipped for programming SIMATIC PLCs.

- Hard disk space:
Refer to the "README.WRI" file for information on required hard disk space.
- MPI interface (optional):
An MPI interface is only required to interconnect the PG/PC and the PLC if you want to use it for communication with the PLC under STEP 7.

In this case you require:

- A PC USB adapter that is connected to the communications port of your device, or
- An MPI module (for example, CP 5611) that is installed in your device.

PGs are supplied with an MPI interface.

- External prommer (optional)
An external prommer is only required if you want to program EPROMs with a PC.

Note

Refer to the information on STEP 7 installation in the README.WRI file and the "List of SIMATIC Software Packages compatible to the versions of the standard STEP 7 software package."

You can find the Readme file in the start menu under **Start > Simatic > Product Notes**.

The compatibility list is found via the Start menu, under **Start > Simatic > Documentation**.

2.2.1 Installation Procedure

Preparing for Installation

The operating system (Windows 2000, XP or Server 2003) must be started before you can start your software installation.

- You do not require an external storage medium if the installable STEP 7 software is already stored on the hard disk of the PG.
- To install from CD-ROM, insert the CD-ROM in the CD-ROM drive of your PC.

Starting the Installation Program

To install the software, proceed as follows:

1. Insert the CD-ROM and double click on the file "SETUP.EXE".
2. Follow the on-screen step-by-step instructions of the installation program.

The program guides you through all steps of the installation. You can go to the next step or return to the previous step.

During installation, the dialog boxes prompt you to make your choice from the displayed options. The following notes will help you to quickly and easily find the right answers.

If a Version of STEP 7 Is Already Installed...

If Setup detects another version of STEP 7 on the programming device, a corresponding message is displayed. You can then choose to:

- Abort the installation (so that you can uninstall the old STEP 7 version under Windows and then restart Setup, or
- Continue Setup and overwrite the previous version.

For well organized software management you should always uninstall any older versions before installing the new version. the disadvantage of overwriting previous versions with a new version is that when you subsequently uninstall the old software version some components of the old version may not be removed.

Selecting the Installation Options

You have three ways to select the scope of the installation:

- Standard setup: all dialog languages for the user interface, all applications, and all examples. Refer to the current Product Information for information on memory space required for this type of configuration.
- Basic setup: only one dialog language, no examples. Refer to the current Product Information for information on memory space required for this type of configuration.
- User-defined ("custom") setup: you can determine the scope of the installation, e.g. the programs, databases, examples, and communication functions.

ID Number

You will be prompted during setup to enter an ID number (found on the Software Product Certificate or on your license key diskette).

Installing License Keys

During setup, the program checks to see whether a corresponding license key is installed on the hard disk. If no valid license key is found, a message stating that the software can be used only with a license key is displayed. If you want, you can install the license key immediately or continue setup and then install the key later. If you want to install the license key now, insert the authorization diskette when prompted to do so.

PG/PC Interface Settings

During installation, a dialog box is displayed where you can assign parameters to the programming device/PC interface. You will find more information on it in "Setting the PG/PC Interface."

Assigning Parameters to Memory Cards

During installation, a dialog box is displayed where you can assign parameters to Memory Cards.

- You do not need an EPROM driver if you are not using any Memory Cards. Select the option "No EPROM Driver".
- Otherwise, select the entry which applies to your PG.
- If you are using a PC, you can select a driver for an external prommer. Here you must specify the port to which the prommer is connected (for example, LPT1).

You can change the set parameters after installation by calling the program "Memory Card Parameter Assignment" in the STEP 7 program group or in the Control Panel.

Flash-File Systems

In the dialog box for assigning memory card parameters, you can select to install a flash-file system.

The flash-file system is required, for example under SIMATIC M7 when you write individual files to an EPROM memory card without changing other contents of the Memory Card.

If you are using a suitable programming device (PG 720/PG 740/PG 760, Field PG and Power PG) or external prommer and you want to use this function, install the flash-file system.

If Errors Occur during the Installation

Setup may be cancelled due to the following errors:

- If an initialization error occurs immediately after the start of Setup, more than likely *setup* was not started under Windows.
- Insufficient hard disk space: Minimum free hard disk space required for a standard software installation is 100 Mbytes, regardless of the scope of your installation.
- Bad CD-ROM: If the CD is faulty, please contact your local Siemens representative.
- Operator error: Restart *setup* follow the instructions carefully.

After the installation has been completed...

An on-screen message reports the successful installation.

If any changes were made to system files during the installation, you are prompted to restart Windows. After this restart (warm restart) you can start the STEP 7 application, the SIMATIC Manager.

After successful installation, a program group for STEP 7 has been set up.

2.2.2 Setting the PG/PC Interface

Here you configure the communication between the PG/PC and the PLC. During installation, you are displayed a dialog for assigning parameters to the PG/PC interface. You can also open this dialog box after installation, by calling the program "Setting PG/PC Interface" in the STEP 7 program group. This enables you to modify the interface parameters at a later time, independently of the installation.

Basic Procedure

To operate an interface, you will require the following:

- Configurations in the operating system
- A suitable interface configuration

If you are using a PC with an MPI card or communications processors (CP), you should check the interrupt and address assignments in the Windows "Control Panel" to ensure that there are no interrupt conflicts and no address areas overlap.

In Windows 2000, Windows XP and Server 2003, the ISA component MPI-ISA card is no longer supported and therefore no longer offered for installation.

In order to make it easier to assign parameters to the programming device/PC interface, a dialog box will display a selection list of default basic parameter sets (interface configurations).

Assigning Parameters to the PG/PC Interface

Procedure (Detail are found in the Online Help):

1. Double-click on "Setting PG/PC Interface" in the "Control Panel" of Windows.
2. Set the "Access Point of Application" to "S7ONLINE."
3. In the list "Interface parameter set used", select the required interface parameter set. If the required interface parameter set is not displayed, you must first install a module or protocol via the "Select" button. The interface parameter set is then generated automatically. On plug-and-play systems, you can not install plug and play CPs manually (CP 5611 and CP 5511). They are integrated automatically in "Setting PG/PC Interface" after you have installed the hardware in your PG/PC.
 - If you select an interface which is capable of **automatic recognition of bus parameters** (for example, CP 5611 (Auto)), you can connect the programming device or the PC to the MPI or PROFIBUS without having to set bus parameters. If the transmission rate is < 187.5 Kbps, there may be a delay of up to one minute while the bus parameters are read.
Requirement for automatic recognition: Masters who broadcast bus parameters cyclically are connected to the bus. All new MPI components do this; for PROFIBUS subnets the cyclic broadcast of bus parameters must be enabled (default PROFIBUS network setting).
 - If you select an interface which **does not automatically recognize the bus parameters**, you can display the properties and adapt them to match the subnet.

Changes will also be necessary if conflicts with other settings arise (for example, interrupt or address assignments). In this case, make the appropriate changes with the hardware recognition and Control Panel in Windows (see below).



Caution

Do **not** remove any "TCP/IP" parameters from your interface configuration.

This could cause malfunctioning of other applications.

Checking the Interrupt and Address Assignments

If you use a PC with an MPI card, you should always check whether the default interrupt and the default address area are free.

2.3 Uninstalling STEP 7

Use the standard Windows method to uninstall STEP 7:


1. Double-click on the "Add/Remove Programs" icon in the "Control Panel." to start the Windows software installation dialog box.
2. Select the STEP 7 entry in the displayed list of installed software. Click the button to "Add/Remove" the software.
3. If the "Remove Shared File" dialog box appears, click the "No" button if you are uncertain.

3 Working Out the Automation Concept

3.1 Basic Procedure for Planning an Automation Project

This chapter outlines the basic tasks involved in planning an automation project for a programmable controller (PLC). Based on an example of automating an industrial blending process, you are guided step by step through the procedure.


There are many ways of planning an automation project. The basic procedure that you can use for any project is illustrated in the following figure.



3.2 Dividing the Process into Tasks and Areas


An automation process consists of a number of individual tasks. By identifying groups of related tasks within a process and then breaking these groups down into smaller tasks, even the most complex process can be defined.

The following example of an industrial blending process can be used to illustrate how to organize a process into functional areas and individual tasks:



Determining the Areas of a Process

After defining the process to be controlled, divide the project into related groups or areas:



As each group is divided into smaller tasks, the tasks required for controlling that part of the process become less complicated.

In our example of an industrial blending process you can identify four distinct areas (see table below). In this example, the area for ingredient A contains the same equipment as the area for ingredient B.

Functional Area	Equipment Used
Ingredient A	Feed pump for ingredient A Inlet valve for ingredient A Feed valve for ingredient A Flow sensor for ingredient A
Ingredient B	Feed pump for ingredient B Inlet valve for ingredient B Feed valve for ingredient B Flow sensor for ingredient B
Mixing tank	Agitator motor Switch for tank level measurement
Drain	Drain valve

3.3 Describing the Individual Functional Areas

As you describe each area and task within your process, you define not only the operation of each area, but also the various elements that control the area. These include:

- Electrical, mechanical, and logical inputs and outputs for each task
- Interlocks and dependencies between the individual tasks

The sample industrial blending process uses pumps, motors, and valves. These must be described precisely to identify the operating characteristics and type of interlocks required during operation. The following tables provide examples of the description of the equipment used in an industrial blending process. When you have completed description, you could also use it to order the required equipment.

Ingredients A/B: Feed Pump Motors
<p>The feed pump motors convey ingredients A and B to the mixing tank.</p> <ul style="list-style-type: none"> • Flow rate: 400 l (100 gallons) per minute • Rating: 100 kW (134 hp) at 1200 rpm
<p>The pumps are controlled (start/stop) from an operator station located near the mixing tank. The number of starts is counted for maintenance purposes. Both the counters and the display can be reset with one button.</p>
<p>The following conditions must be satisfied for the pumps to operate:</p> <ul style="list-style-type: none"> • The mixing tank is not full. • The drain valve of the mixing tank is closed. • The emergency off is not activated.
<p>The pumps are switched off if the following condition is satisfied:</p> <ul style="list-style-type: none"> • The flow sensor signals no flow 7 seconds after the pump motor is started. • The flow sensor signals that the flow has ceased.

Ingredients A/B: Inlet and Feed Valves
<p>The inlet and feed valves for ingredients A and B allow or prevent the flow of the ingredients into the mixing tank. The valves have a solenoid with a spring return.</p> <ul style="list-style-type: none"> • When the solenoid is activated, the valve is opened. • When the solenoid is deactivated, the valve is closed.
<p>The inlet and feed valves are controlled by the user program.</p>
<p>For the valves to be activated, the following condition must be satisfied:</p> <ul style="list-style-type: none"> • The feed pump motor has been running for at least 1 second.
<p>The pumps are switched off if the following condition is satisfied:</p> <ul style="list-style-type: none"> • The flow sensor signals no flow.


Agitator Motor
The agitator motor mixes ingredient A with ingredient B in the mixing tank.
<ul style="list-style-type: none"> • Rating: 100 kW (134 hp) at 1200 rpm
The agitator motor is controlled (start/stop) from an operator station located near the mixing tank. The number of starts is counted for maintenance purposes. Both the counters and the display can be reset with one button.
The following conditions must be satisfied for the pumps to operate:
<ul style="list-style-type: none"> • The tank level sensor is not signaling "Tank below minimum." • The drain valve of the mixing tank is closed. • The emergency off is not activated.
The pumps are switched off if the following condition is satisfied:
<ul style="list-style-type: none"> • The tachometer does not indicate that the rated speed has been reached within 10 seconds of starting the motor.

Drain Valve
The drain valve allows the mixture to drain (using gravity feed) to the next stage in the process. The valve has a solenoid with a spring return.
<ul style="list-style-type: none"> • If the solenoid is activated, the outlet valve is opened. • If the solenoid is deactivated, the outlet valve is closed.
The outlet valve is controlled (open/close) from an operator station.
The drain valve can be opened under the following conditions:
<ul style="list-style-type: none"> • The agitator motor is off. • The tank level sensor is not signaling "Tank empty." • The emergency off is not activated.
The pumps are switched off if the following condition is satisfied:
<ul style="list-style-type: none"> • The tank level sensor is indicating "Tank empty."

Switches for Tank Level Measurement
The switches in the mixing tank indicate the level in the tank and are used to interlock the feed pumps and the agitator motor.

3.4 Listing Inputs, Outputs, and In/Outs

After writing a physical description of each device to be controlled, draw diagrams of the inputs and outputs for each device or task area.




These diagrams correspond to the logic blocks to be programmed.

3.5 Creating an I/O Diagram for the Motors

Two feed pumps and one agitator are used in our example of an industrial blending process. Each motor is controlled by its own "motor block" that is the same for all three devices. This block requires six inputs: two to start or stop the motor, one to reset the maintenance display, one for the motor response signal (motor running / not running), one for the time during which the response signal must be received, and one for the number of the timer used to measure the time.

The logic block also requires four outputs: two to indicate the operating state of the motor, one to indicate faults, and one to indicate that the motor is due for maintenance.


An in/out is also necessary to activate the motor. It is used to control the motor but at the same time is also edited and modified in the program for the "motor block."



3.6 Creating an I/O Diagram for the Valves

Each valve is controlled by its own "valve block" that is the same for all valves used. The logic block has two inputs: one to open the valve and one to close the valve. It also has two outputs: one to indicate that the valve is open and the other to indicate that it is closed.

The block has an in/out to activate the valve. It is used to control the valve but at the same time is also edited and modified in the program for the "valve block."



3.7 Establishing the Safety Requirements

Decide which additional elements are needed to ensure the safety of the process - based on legal requirements and corporate health and safety policy. In your description, you should also include any influences that the safety elements have on your process areas.

Defining Safety Requirements

Find out which devices require hardwired circuits to meet safety requirements. By definition, these safety circuits operate independently of the programmable controller (although the safety circuit generally provides an I/O interface to allow coordination with the user program). Normally, you configure a matrix to connect every actuator with its own emergency off range. This matrix is the basis for the circuit diagrams of the safety circuits.

To design safety mechanisms, proceed as follows:

- Determine the logical and mechanical/electrical interlocks between the individual automation tasks.
- Design circuits to allow the devices belonging to the process to be operated manually in an emergency.
- Establish any further safety requirements for safe operation of the process.

Creating a Safety Circuit

The sample industrial blending process uses the following logic for its safety circuit:


- One emergency off switch shuts down the following devices independent of the programmable controller (PLC):
 - Feed pump for ingredient A
 - Feed pump for ingredient B
 - Agitator motor
 - Valves
- The emergency off switch is located on the operator station.
- An input to the controller indicates the state of the emergency off switch.

3.8 Describing the Required Operator Displays and Controls

Every process requires an operator interface that allows human intervention in the process. Part of the design specification includes the design of the operator console.

Defining an Operator Console

In the industrial blending process described in our example, each device can be started or stopped by a pushbutton located on the operator console. This operator console includes indicators to show the status of the operation (see figure below).



The console also includes display lamps for the devices that require maintenance after a certain number of starts and the emergency off switch with which the process can be stopped immediately. The console also has a reset button for the maintenance display of the three motors. Using this, you can turn off the maintenance display lamps for the motors due for maintenance and reset the corresponding counters to 0.


3.9 Creating a Configuration Diagram

After you have documented the design requirements, you must then decide on the type of control equipment required for the project.

By deciding which modules you want to use, you also specify the structure of the programmable controller. Create a configuration diagram specifying the following aspects:

- Type of CPU
- Number and type of I/O modules
- Configuration of the physical inputs and outputs

The following figure illustrates an example of an S7 configuration for the industrial blending process.



4 Basics of Designing a Program Structure

4.1 Programs in a CPU

A CPU will principally run two different programs:

- The operating system and
- The user program.

Operating System

Every CPU comes with an integrated operating system that organizes all CPU functions and sequences not associated with a specific control task. The tasks of the operating system include the following:

- Handling restart (warm start) and hot restart
- Update of the process image table of the inputs and output of the process image table of the outputs
- Calling the user program
- Acquisition of interrupt information and calling interrupt OBs
- Recognition of errors and error handling
- Management of the memory areas
- Communication with programming devices and other communication partners

You can influence CPU reactions in certain areas by modifying the operating system parameters (operating system default settings).

User Program

You create the user program and download it to the CPU. It contains all the functions required to process your specific automation task. The tasks of the user program include:

- Specifying the conditions for a restart (warm start) and hot restart on the CPU (for example, initializing signals with a particular value)
- Processing process data (for example, generating logical links of binary signals, fetching and evaluating analog signals, specifying binary signals for output, output of analog values)
- Reaction to interrupts
- Handling disturbances in the normal program cycle.

4.2 Blocks in the User Program

The STEP 7 programming software allows you to structure your user program, in other words to break down the program into individual, self-contained program sections. This has the following advantages:

- Extensive programs are easier to understand.
- Individual program sections can be standardized.
- Program organization is simplified.
- It is easier to make modifications to the program.
- Debugging is simplified since you can test separate sections.
- Commissioning your system is made much easier.

The example of an industrial blending process illustrated the advantages of breaking down an automation process into individual tasks. The program sections of a structured user program correspond to these individual tasks and are known as the blocks of a program

Block Types

There are several different types of blocks you can use within an S7 user program:

Block	Brief Description of Function	See Also
Organization blocks (OB)	OBs determine the structure of the user program.	Organization Blocks and Program Structure
System function blocks (SFB) and system functions (SFC)	SFBs and SFCs are integrated in the S7 CPU and allow you access to some important system functions.	System Function Blocks (SFB) and System Functions (SFC)
Function blocks (FB)	FBs are blocks with a "memory" which you can program yourself.	Function Blocks (FB)
Functions (FC)	FCs contain program routines for frequently used functions.	Functions (FC)
Instance data blocks (instance DB)	Instance DBs are associated with the block when an FB/SFB is called. They are created automatically during compilation.	Instance Data Blocks
Data blocks (DB)	DBs are data areas for storing user data. In addition to the data that are assigned to a function block, shared data can also be defined and used by any blocks.	Shared Data Blocks (DB)

OBs, FBs, SFBs, FCs, and SFCs contain sections of the program and are therefore also known as logic blocks. The permitted number of blocks per block type and the permitted length of the blocks is CPU-specific.

4.2.1 Organization Blocks and Program Structure

Organization blocks (OBs) represent the interface between the operating system and the user program. Called by the operating system, they control cyclic and interrupt-driven program execution, startup behavior of the PLC and error handling. You can program the organization blocks to determine CPU behavior.

Organization Block Priority

Organization blocks determine the sequence (start events) by which individual program sections are executed. An OB call can interrupt the execution of another OB. Which OB is allowed to interrupt another OB depends on its priority. Higher priority OBs can interrupt lower priority OBs. The background OB has the lowest priority.

Types of Interrupt and Priority Classes

Start events triggering an OB call are known as interrupts. The following table shows the types of interrupt in STEP 7 and the priority of the organization blocks assigned to them. Not all organization blocks listed and their priority classes are available in all S7 CPUs (see "S7-300 Programmable Controller, Hardware and Installation Manual" and "S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual").

Type of Interrupt	Organization Block	Priority Class (Default)	See also
Main program scan	OB1	1	Organization Block for Cyclic Program Processing (OB1)
Time-of-day interrupts	OB10 to OB17	2	Time-of-Day Interrupt Organization Blocks (OB10 to OB17)
Time-delay interrupts	OB20	3	Time-Delay Interrupt Organization Blocks (OB20 to OB23)
	OB21	4	
	OB22	5	
	OB23	6	
Cyclic interrupts	OB30	7	Cyclic Interrupt Organization Blocks (OB30 to OB38)
	OB31	8	
	OB32	9	
	OB33	10	
	OB34	11	
	OB35	12	
	OB36	13	
	OB37	14	
	OB38	15	

Type of Interrupt	Organization Block	Priority Class (Default)	See also
Hardware interrupts	OB40	16	Hardware Interrupt Organization Blocks (OB40 to OB47)
	OB41	17	
	OB42	18	
	OB43	19	
	OB44	20	
	OB45	21	
	OB46 OB47	22 23	
DPV1 interrupts	OB 55	2	Programming DPV1 Devices
	OB 56	2	
	OB 57	2	
Multicomputing interrupt	OB60 Multicomputing	25	Multicomputing - Synchronous Operation of Several CPUs
Synchronous cycle interrupt	OB 61	25	Configuring Short and Equal-Length Process Reaction Times on PROFIBUS-DP
	OB 62		
	OB 63		
	OB 64		
Redundancy errors	OB70 I/O Redundancy Error (only in H systems)	25	"Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)"
	OB72 CPU Redundancy Error (only in H systems)	28	
Asynchronous errors	OB80 Time Error	25 (or 28 if the asynchronous error OB exists in the startup program)	Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)
	OB81 Power Supply Error		
	OB82 Diagnostic Interrupt		
	OB83 Insert/Remove Module Interrupt		
	OB84 CPU Hardware Fault		
	OB 85 Program Cycle Error		
	OB86 Rack Failure OB87 Communication Error		
Background cycle	OB90	29 ¹⁾	Background Organization Block (OB90)
Startup	OB100 Restart (Warm start)	27	Startup Organization Blocks (OB100/OB101/OB102)
	OB101 Hot Restart	27	
	OB102 Cold Restart	27	
Synchronous errors	OB121 Programming Error	Priority of the OB that caused the error	Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)
	OB122 Access Error		

¹⁾ The priority class 29 corresponds to priority 0.29. The background cycle has a lower priority than the free cycle.

Changing the Priority

Interrupts can be assigned parameters with STEP 7. With the parameter assignment you can for example, deselect interrupt OBs or priority classes in the parameter blocks: time-of-day interrupts, time-delay interrupts, cyclic interrupts, and hardware interrupts.

The priority of organization blocks on S7-300 CPUs is fixed.

With S7-400 CPUs (and the CPU 318) you can change the priority of the following organization blocks with STEP 7:

- OB10 to OB47
- OB70 to OB72 (only H CPUs) and OB81 to OB87 in RUN mode.

The following priority classes are permitted:

- Priority classes 2 to 23 for OB10 to OB47
- Priority classes 2 to 28 for OB70 to OB72
- Priority classes 24 to 26 for OB81 to OB87; for CPUs as of approx. The middle of 2001 (Firmware Version 3.0) the ranges were extended: Priority classes 2 to 26 can be set for OB 81 to OB 84 as well as for OB 86 and OB 87.

You can assign the same priority to several OBs. OBs with the same priority are processed in the order in which their start events occur.

Error OBs started by synchronous errors are executed in the same priority class as the block being executed when the error occurred.

Local Data

When creating logic blocks (OBs, FCs, FBs), you can declare temporary local data. The local data area on the CPU is divided among the priority classes.

On S7-400, you can change the amount of local data per priority class in the "priority classes" parameter block using STEP 7.

Start Information of an OB

Every organization block has start information of 20 bytes of local data that the operating system supplies when an OB is started. The start information specifies the start event of the OB, the date and time of the OB start, errors that have occurred, and diagnostic events.

For example, OB40, a hardware interrupt OB, contains the address of the module that generated the interrupt in its start information.

Deselected Interrupt OBs


If you assign priority class 0 or assign less than 20 bytes of local data to a priority class, the corresponding interrupt OB is deselected. The handling of deselected interrupt OBs is restricted as follows:

- In RUN mode, they cannot be copied or linked into your user program.
- In STOP mode, they can be copied or linked into your user program, but when the CPU goes through a restart (warm start) they stop the startup and an entry is made in the diagnostic buffer.

By deselecting interrupt OBs that you do not require, you increase the amount of local data area available, and this can be used to save temporary data in other priority classes.


Cyclic Program Processing

Cyclic program processing is the "normal" type of program execution on programmable logic controllers, meaning the operating system runs in a program loop (the cycle) and calls the organization block OB1 once in every loop in the main program. The user program in OB1 is therefore executed cyclically.



Event-Driven Program Processing

Cyclic program processing can be interrupted by certain events (interrupts). If such an event occurs, the block currently being executed is interrupted at a command boundary and a different organization block that is assigned to the particular event is called. Once the organization block has been executed, the cyclic program is resumed at the point at which it was interrupted.




This means it is possible to process parts of the user program that do not have to be processed cyclically only when needed. The user program can be divided up into "subroutines" and distributed among different organization blocks. If the user program is to react to an important signal that occurs relatively seldom (for example, a limit value sensor for measuring the level in a tank reports that the maximum level has been reached), the subroutine that is to be processed when the signal is output can be located in an OB whose processing is event-driven.

Linear Versus Structured Programming

You can write your entire user program in OB1 (linear programming). This is only advisable with simple programs written for the S7-300 CPU and requiring little memory.

Complex automation tasks can be controlled more easily by dividing them into smaller tasks reflecting the technological functions of the process or that can be used more than once. These tasks are represented by corresponding program sections, known as the blocks (structured programming).




4.2.2 Call Hierarchy in the User Program

For the user program to function, the blocks that make up the user program must be called. This is done using special STEP 7 instructions, the block calls, that can only be programmed and started in logic blocks.

Order and Nesting Depth

The order and nesting of the block calls is known as the call hierarchy. The number of blocks that can be nested (the nesting depth) depends on the particular CPU.

The following figure illustrates the order and nesting depth of the block calls within a scan cycle.



There is a set order for creating blocks:

- You create the blocks from top to bottom, so you start with the top row of blocks.
- Every block that is called must already exist, meaning that within a row of blocks the order for creating them is from right to left.
- The last block to be created is OB1.

Putting these rules into practice for the example in the figure produces the following sequence for creating the blocks:


FC1 > FB1 + instance DB1 > DB1 > SFC1 > FB2 + instance DB2 > OB1

Note

If the nesting is too deep (too many levels), the local data stack may overflow (Also refer to Local Data Stack).

Block Calls

The following figure shows the sequence of a block call within a user program. The program calls the second block whose instructions are then executed completely. Once the second or called block has been executed, execution of the interrupted block that made the call is resumed at the instruction following the block call.



Before you program a block, you must specify which data will be used by your program, in other words, you must declare the variables of the block.

Note

OUT parameters must be described for each block call.

Note

The operating system resets the instances of SFB3 "TP" when a cold restart is performed. If you want to initialize instances of this SFB after a cold restart, you must call up the relevant instances of the SFB with PT = 0 ms via OB100. You can do this, for example, by performing an initialization routine in the blocks which contain instances of the SFB.

4.2.3 Block Types

4.2.3.1 Organization Block for Cyclic Program Processing (OB1)

Cyclic program processing is the "normal" type of program execution on programmable logic controllers. The operating system calls OB1 cyclically and with this call it starts cyclic execution of the user program.

Sequence of Cyclic Program Processing

The following table shows the phases of cyclic program processing:

Step	Sequence in CPUs to 10/98	Sequence in CPUs from 10/98
1	The operating system starts the cycle monitoring time.	The operating system starts the cycle monitoring time.
2	The CPU reads the state of the inputs of the input modules and updates the process image table of the inputs.	The CPU writes the values from the process image table of the outputs to the output modules.
3	The CPU processes the user program and executes the instructions contained in the program.	The CPU reads the state of the inputs of the input modules and updates the process image table of the inputs.
4	The CPU writes the values from the process image table of the outputs to the output modules.	The CPU processes the user program and executes the instructions contained in the program.
5	At the end of a cycle, the operating system executes any tasks that are pending, for example downloading and deleting blocks, receiving and sending global data.	At the end of a cycle, the operating system executes any tasks that are pending, for example downloading and deleting blocks, receiving and sending global data.
6	Finally, the CPU returns to the start of the cycle and restarts the cycle monitoring time.	Finally, the CPU returns to the start of the cycle and restarts the cycle monitoring time.

Process Images

So that the CPU has a consistent image of the process signals during cyclic program processing, the CPU does not address the input (I) and output (Q) address areas directly on the I/O modules but rather accesses an internal memory area of the CPU that contains an image of the inputs and outputs.

Programming Cyclic Program Processing

You program cyclic program processing by writing your user program in OB1 and in the blocks called within OB1 using STEP 7.

Cyclic program processing begins as soon as the startup program is completed without errors.

Interrupts



Cyclic program processing can be interrupted by the following:

- An interrupt
- A STOP command (mode selector, menu option on the programming device, SFC46 STP, SFB20 STOP)
- A power outage
- The occurrence of a fault or program error

Scan Cycle Time

The scan cycle time is the time required by the operating system to run the cyclic program and all the program sections that interrupt the cycle (for example, executing other organization blocks) and system activities (for example, updating the process image). This time is monitored.

The scan cycle time (T_C) is not the same in every cycle. The following figures show different scan cycle times ($T_{C1} \neq T_{C2}$) for CPUs up to 10/98 and CPUs from 10/98:



In the current cycle, OB1 is interrupted by a Time-Of-Day interrupt.

Cycle Monitoring Time


With STEP 7, you can modify the default maximum cycle monitoring time. If this time expires, the CPU either changes to STOP mode or OB80 is called in which you can specify how the CPU should react to this error.


Minimum Cycle Time

With STEP 7, you can set a minimum cycle time for S7-400 CPUs and the CPU 318. This is useful in the following situations:

- When the interval at which program execution starts in OB1 (main program scan) should always be the same or
- When the process image tables would be updated unnecessarily often if the cycle time is too short.

The following figures show the function of the cycle monitoring time in program processing in CPUs up to 10/98 and in CPUs from 10/98.





Updating the Process Image

During cyclic program processing by the CPU, the process image is updated automatically. With the S7-400 CPUs and the CPU 318 you can deselect the update of the process image if you want to:

- Access the I/O directly instead or
- Update one or more process image input or output sections at a different point in the program using system functions SFC26 UPDAT_PI and SFC27 UPDAT_PO.

Communication Load

You can use the CPU parameter "Scan Cycle Load from Communication" to control within a given framework the duration of communication processes that always increase the scan cycle time. Examples of communication processes include transmitting data to another CPU by means of MPI or loading blocks by means of a programming device.

Test functions with a programming device are barely influenced by this parameter. However, you can increase the scan cycle time considerably. In the process mode, you can limit the time set for test functions (S7-300 only).

How the Parameter works

The operating system of the CPU constantly provides the communication with the configured percent of the entire CPU processing capacity (time slice technique). If this processing capacity is not needed for the communication, it is available to the rest of the processing.

Effect on the Actual Scan Cycle Time

Without additional asynchronous events, the OB1 scan cycle time is extended by a factor that can be calculated according to the following formula:

$$\frac{100}{100 - \text{"Scan cycle load from communication (\%)\"}}$$

Example 1 (no additional asynchronous events):

When you set the load added to the cycle by communication to 50%, the OB1 scan cycle time can be doubled.

At the same time, the OB1 scan cycle time is also influenced by asynchronous events (such as hardware interrupts or cyclic interrupts). From a statistical point of view, even more asynchronous events occur within an OB1 scan cycle because of the extension of the scan cycle time by the communication portion. This causes an additional increase in the OB1 scan cycle. This increase depends on how many events occur per OB1 scan cycle and on the duration of event processing.

Example 2 (additional asynchronous events considered):

For a pure OB1 execution time of 500 ms, a communication load of 50% can result in an actual scan cycle time of up to 1000 ms (provided that the CPU always has enough communication jobs to process). If, parallel to this, a cyclic interrupt with 20 ms processing time is executed every 100 ms, this cyclic interrupt would extend the scan cycle by a total of $5 \cdot 20 \text{ ms} = 100 \text{ ms}$ without communication load. That is, the actual scan cycle time would be 600 ms. Because a cyclic interrupt also interrupts communication, it affects the scan cycle time by $10 \cdot 20 \text{ ms}$ with 50% communication load. That is, in this case, the actual scan cycle time amounts to 1200 ms instead of 1000 ms.

Note

- Check the effects of changing the value of the "Scan Cycle Load from Communication" parameter while the system is running.
 - The communication load must be taken into account when setting the minimum scan cycle time; otherwise time errors will occur.
-

Recommendations

- Where possible, apply the default value.
- Increase this value only if you are using the CPU primarily for communication purposes and your user program is not time critical.
- In all other cases, only reduce the value.
- Set the process mode (S7-300 only), and limit the time needed there for test functions.

4.2.3.2 Functions (FC)

Functions (FCs) belong to the blocks that you program yourself. A function is a logic block "without memory." Temporary variables belonging to the FC are saved in the local data stack. This data is then lost when the FC has been executed. To save data permanently, functions can also use shared data blocks.

Since an FC does not have any memory of its own, you must always specify actual parameters for it. You cannot assign initial values for the local data of an FC.

Application

An FC contains a program section that is always executed when the FC is called by a different logic block. You can use functions for the following purposes:

- To return a function value to the calling block (example: math functions)
- To execute a technological function (example: single control function with a bit logic operation).

Assigning Actual Parameters to the Formal Parameters

A formal parameter is a dummy for the "actual" parameter. Actual parameters replace the formal parameters when the function is called. You must always assign actual parameters to the formal parameters of an FC (for example, an actual parameter "I 3.6" to the formal parameter "Start"). The input, output and in/out parameters used by the FC are saved as pointers to the actual parameters of the logic block that called the FC.

Important Differences Between the Output Parameters of FCs and FBs

In function blocks (FB), a copy of the actual parameters in the instance DB is used when accessing the parameters. If an input parameter is not transferred or an output parameter is not write accessed when a FB is called, the older values still stored in the instance DB /Instance DB = memory of the FBs) will be used.

Functions (FC) have no memory. Contrary to FBs, the assignment of formal parameters to these FCs is therefore not optional, but rather essentially. FC parameters are accessed via addresses (pointers to targets across area boundaries). When an address of the data area (data block) or a local variable of the calling block is used as actual parameter, a copy of the actual parameter is saved temporarily to local data area of the calling block for the transfer of the parameter.

Caution

In this case, if no data are written to an OUTPUT parameter in an FC, the block may output random values!

As the calling block's local data area which is reserved for the copy is not assigned to the OUTPUT parameter, no data will be written to this area. It will therefore remain unchanged and the random value stored at this location will be output, because local data are not automatically set to "0" by default, for example.

Thus, observe the following points:

- If possible, initialize the OUTPUT parameters.
- Set and reset instructions depend on RLO. When these instructions are used to determine the value at an OUTPUT parameter, no value is generated if the result of a previous logic operation (RLO) = 0.
- Always ensure that data are written to the OUTPUT parameters - irrespective of any program paths in the block. Pay special attention to jump instructions, to the ENO output in LAD and FBD as well as to BEC (Block End Conditional) and the influence of MCR (Master Control Relay) instructions.

Note

Although the OUTPUT parameters of an FB or the INOUT parameters of an FC and FB will not output random values (the old output value - or input value as output value - is going to be maintained even if no data are written to the parameter) you should still observe the points above in order to avoid unintentional processing of "old" values.

4.2.3.3 Function Blocks (FB)

Function blocks (FBs) belong to the blocks that you program yourself. A function block is a block "with memory." It is assigned a data block as its memory (instance data block). The parameters that are transferred to the FB and the static variables are saved in the instance DB. Temporary variables are saved in the local data stack.

Data saved in the instance DB are not lost when execution of the FB is complete. Data saved in the local data stack are, however, lost when execution of the FB is completed.

Note

To avoid errors when working with FBs, read Permitted Data Types when Transferring Parameters in the Appendix.

Application

An FB contains a program that is always executed when the FB is called by a different logic block. Function blocks make it much easier to program frequently occurring, complex functions.

The following table shows which variables of the FB must be assigned actual parameters.

Variable	Data Type		
	Elementary Data Type	Complex Data Type	Parameter Type
Input	No parameter required	No parameter required	Actual parameter required
Output	No parameter required	No parameter required	Actual parameter required
In/out	No parameter required	Actual parameter required	–

Assigning Initial Values to Formal Parameters

You can assign initial values to the formal parameters in the declaration section of the FB. These values are written into the instance DB associated with the FB.

If you do not assign actual parameters to the formal parameters in the call statement, STEP 7 uses the values saved in the instance DB. These values can also be the initial values that were entered in the variable declaration table of an FB.

The following table shows which variables can be assigned an initial value. Since the temporary data are lost after the block has been executed, you cannot assign any values to them.

Variable	Data Type		
	Elementary Data Type	Complex Data Type	Parameter Type
Input	Initial value permitted	Initial value permitted	–
Output	Initial value permitted	Initial value permitted	–
In/out	Initial value permitted	–	–
Static	Initial value permitted	Initial value permitted	–
Temporary	–	–	–

4.2.3.4 Instance Data Blocks

An instance data block is assigned to every function block call that transfers parameters. The actual parameters and the static data of the FB are saved in the instance DB. The variables declared in the FB determine the structure of the instance data block. Instance means a function block call. If, for example, a function block is called five times in the S7 user program, there are five instances of this block.


Creating an Instance DB

Before you create an instance data block, the corresponding FB must already exist. You specify the number of the FB when you create the instance data block.

One Instance DB for Each Separate Instance

If you assign several instance data blocks to a function block (FB) that controls a motor, you can use this FB to control different motors.

The data for each specific motor (for example, speed, run-up time, total operating time) are saved in different data blocks. The DB associated with the FB when it is called determines which motor is controlled. With this technique, only one function block is necessary for several motors (see the following figure).




One Instance DB for Several Instances of an FB (Multiple Instances)

You can also transfer the instance data for several motors at the same time in one instance DB. To do this, you must program the calls for the motor controllers in a further FB and declare static variables with the data type FB for the individual instances in the declaration section of the calling FB.

If you use one instance DB for several instances of an FB, you save memory and optimize the use of data blocks.

In the following figure, the calling FB is FB21 "Motor processing," the variables are of data type FB22, and the instances are identified by Motor_1, Motor_2, and Motor_3.




In this example, FB22 does not need its own instance data block, since its instance data are saved in the instance data block of the calling FB.

One Instance DB for Several Instances of Different FBs (Multiple Instances)

In a function block you can call the instances of other existing FBs. You can assign the instance data required for this to the instance data block of the calling FB, meaning you do not need any additional data blocks for the called FBs in this case.

For these multiple instances in one instance data block, you must declare static variables with the data type of the called function block for each individual instance in the declaration section of the calling function block. The call within the function block does not then require an instance data block, only the symbolic name of the variable.

In the example in this figure, the assigned instance data are stored in a common instance DB.



4.2.3.5 Shared Data Blocks (DB)

In contrast to logic blocks, data blocks do not contain STEP 7 instructions. They are used to store user data, in other words, data blocks contain variable data with which the user program works. Shared data blocks are used to store user data that can be accessed by all other blocks.

The size of DBs can vary. Refer to the description of your CPU for the maximum possible size.


You can structure shared data blocks in any way to suit your particular requirements.

Shared Data Blocks in the User Program

If a logic block (FC, FB, or OB) is called, it can occupy space in the local data area (L stack) temporarily. In addition to this local data area, a logic block can open a memory area in the form of a DB. In contrast to the data in the local data area, the data in a DB are not deleted when the DB is closed, in other words, after the corresponding logic block has been executed.

Each FB, FC, or OB can read the data from a shared DB or write data to a shared DB. This data remains in the DB after the DB is exited.

A shared DB and an instance DB can be opened at the same time. The following figure shows the different methods of access to data blocks.



4.2.3.6 System Function Blocks (SFB) and System Functions (SFC)

Preprogrammed Blocks

You do not need to program every function yourself. S7 CPUs provide you with preprogrammed blocks that you can call in your user program.

Further information can be found in the reference help on system blocks and system functions (Jumps to Language Descriptions and Help on Blocks and System Attributes).

System Function Blocks

A system function block (SFB) is a function block integrated on the S7 CPU. SFBs are part of the operating system and are not loaded as part of the program. Like FBs, SFBs are blocks "with memory." You must also create instance data blocks for SFBs and download them to the CPU as part of the program.

S7 CPUs provide the following SFBs:

- For communication via configured connections
- For integrated special functions (for example, SFB29 "HS_COUNT" on the CPU 312 IFM and the CPU 314 IFM).

System Functions

A system function is a preprogrammed function that is integrated on the S7 CPU. You can call the SFC in your program. SFCs are part of the operating system and are not loaded as part of the program. Like FCs, SFCs are blocks "without memory."

S7 CPUs provide SFCs for the following functions:

- Copying and block functions
- Checking the program
- Handling the clock and run-time meters
- Transferring data sets
- Transferring events from a CPU to all other CPUs in multicomputing mode
- Handling time-of-day and time-delay interrupts
- Handling synchronous errors, interrupts, and asynchronous errors
- Information on static and dynamic system data, for example, diagnostics
- Process image updating and bit field processing
- Addressing modules
- Distributed I/O
- Global data communication
- Communication via non-configured connections
- Generating block-related messages

Additional Information

For more detailed information about SFBs and SFCs, refer to the "System Software for S7-300 and S7-400, System and Standard Functions" Reference Manual. The "S7-300 Programmable Controller, Hardware and Installation Manual" and "S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual" explain which SFBs and SFCs are available.

4.2.4 Organization Blocks for Interrupt-Driven Program Processing

4.2.4.1 Time-of-Day Interrupt Organization Blocks (OB10 to OB17)

The S7 CPUs provide the Time-Of-Day interrupt OBs that can be executed at a specified date or at certain intervals.

Time-Of-Day interrupts can be triggered as follows:

- Once at a particular time (specified in absolute form with the date)
- Periodically by specifying the start time and the interval at which the interrupt should be repeated (for example, every minute, every hour, daily).

Rules for Time-of-Day Interrupts

Time-Of-Day interrupts can only be executed when the interrupt has been assigned parameters and a corresponding organization block exists in the user program. If this is not the case, an error message is entered in the diagnostic buffer and asynchronous error handling is executed (OB80, see Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)).

Periodic Time-Of-Day interrupts must correspond to a real date. Repeating an OB10 monthly starting on January 31st is not possible. In this case, the OB would only be started in the months that actually have 31 days (that is, not in February, April, June, etc.).

A Time-Of-Day interrupt activated during startup (restart (warm restart) or hot restart) is only executed after the startup is completed.

Time-Of-Day interrupt OBs that are deselected by the parameter assignment cannot be started. The CPU recognizes a programming error and changes to STOP mode.

Following a restart (warm restart), Time-Of-Day interrupts must be set again (for example, using SFC30 ACT_TINT in the startup program).

Starting the Time-of-Day Interrupt

To allow the CPU to start a Time-Of-Day interrupt, you must first set and then activate the Time-Of-Day interrupt. There are three ways of starting the interrupt:

- Automatic start of the Time-Of-Day interrupt by assigning appropriate parameters with STEP 7 (parameter block "Time-Of-Day interrupts")
- Setting and activating the Time-Of-Day interrupt with SFC28 SET_TINT and SFC30 ACT_TINT from within the user program
- Setting the Time-Of-Day interrupt by assigning parameters with STEP 7 and activating the Time-Of-Day interrupt with SFC30 ACT_TINT in the user program.

Querying the Time-of-Day Interrupt

To query which Time-Of-Day interrupts are set and when they are set to occur, you can do one of the following:

- Call SFC31 QRY_TINT
- Request the list "interrupt status" of the system status list.

Deactivating the Time-of-Day Interrupt

You can deactivate Time-Of-Day interrupts that have not yet been executed with SFC29 CAN_TINT. Deactivated Time-Of-Day interrupts can be set again using SFC28 SET_TINT and activated with SFC30 ACT_TINT.

Priority of the Time-of-Day Interrupt OBs

All eight Time-Of-Day interrupt OBs have the same priority class (2) as default and are therefore processed in the order in which their start event occurs. You can, however, change the priority class by selecting suitable parameters.

Changing the Set Time

You can change the Time-Of-Day set for the interrupt as follows:

- A clock master synchronizes the time for masters and slaves.
- SFC0 SET_CLK can be called in the user program to set a new time.

Reaction to Changing the Time

The following table shows how Time-Of-Day interrupts react after the time has been changed.

If...	Then...
you move the time ahead and one or more Time-Of-Day interrupts were skipped,	OB80 is started and the Time-Of-Day interrupts that were skipped are entered in the start information of OB80.
you have not deactivated the skipped Time-Of-Day interrupts in OB80,	the skipped Time-Of-Day interrupts are no longer executed.
you have not deactivated the skipped Time-Of-Day interrupts in OB80,	the first skipped Time-Of-Day interrupt is executed, the other skipped Time-Of-Day interrupts are ignored.
you move the time back, the start events for the Time-Of-Day interrupts occur again,	the execution of the Time-Of-Day interrupt is repeated with S7-300-CPU s and not repeated for S7-400-CPU s and CPU 318 .

4.2.4.2 Time-Delay Interrupt Organization Blocks (OB20 to OB23)

The S7 CPUs provide time delay OBs with which you can program the delayed execution of parts of your user program.

Rules for Time-Delay Interrupts

Time delay interrupts can only be executed when the corresponding organization block exists in the CPU program. If this is not the case, an error message is entered in the diagnostic buffer and asynchronous error handling is executed (OB80, see Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)).

Time delay interrupt OBs that were deselected by the parameter assignment cannot be started. The CPU recognizes a programming error and changes to STOP mode.

Time delay interrupts are triggered when the delay time specified in SFC32 SRT_DINT has expired.

Starting the Time-Delay Interrupt

To start a time delay interrupt, you must specify the delay time in SFC32 after which the corresponding time delay interrupt OB is called. Refer to the "S7-300 Programmable Controller, Hardware and Installation Manual" and "S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual" for the maximum permitted length of the delay time.

Priority of the Time-Delay Interrupt OBs

The default priority for the time-delay interrupt OBs is priority class 3 to 6. You can assign parameters to change the priority classes.

4.2.4.3 Cyclic Interrupt Organization Blocks (OB30 to OB38)

The S7 CPUs provide cyclic interrupt OBs that interrupt cyclic program processing at certain intervals.

Cyclic interrupts are triggered at intervals. The time at which the interval starts is the mode transition from STOP to RUN.

Rules for Cyclic Interrupts

When you specify the intervals, make sure that there is enough time between the start events of the individual cyclic interrupts for processing the cyclic interrupts themselves.

If you assign parameters to deselect cyclic interrupt OBs, they can no longer be started. The CPU recognizes a programming error and changes to STOP mode.

Starting the Cyclic Interrupt

To start a cyclic interrupt, you must specify the interval in the cyclic interrupts parameter block using STEP 7. The interval is always a whole multiple of the basic clock rate of 1 ms.

Interval = n x basic clock rate 1 ms


Each of the nine available cyclic interrupt OBs has a default interval (see the following table). The default interval becomes effective when the cyclic interrupt OB assigned to it is loaded. You can, however, assign parameters to change the default values. Refer to your "S7-300 Programmable Controller, Hardware and Installation Manual" and your "S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual" for the upper limit.

Phase Offset in Cyclic Interrupts

To avoid cyclic interrupts of different cyclic interrupt OBs being started at the same point and possibly causing a time error (cycle time exceeded) you can specify a phase offset. The phase offset ensures that the execution of a cyclic interrupt is delayed by a certain time after the interval has expired.

Phase offset = $m \times \text{basic clock rate}$ (where $0 \leq m < n$)

The following figure shows how a cyclic interrupt OB with phase offset (OB37) is executed in contrast to a cyclic interrupt without phase offset (OB38).



Priority of the Cyclic Interrupt OBs

The following table shows the default intervals and priority classes of the cyclic interrupt OBs. You can assign parameters to change the interval and the priority class.

Cyclic Interrupt OB	Interval in ms	Priority Class
OB30	5000	7
OB31	2000	8
OB32	1000	9
OB33	500	10
OB34	200	11
OB35	100	12
OB36	50	13
OB37	20	14
OB38	10	15

4.2.4.4 Hardware Interrupt Organization Blocks (OB40 to OB47)

The S7 CPUs provide hardware interrupt OBs that react to signals from the modules (for example, signal modules (SMs), communications processors (CPs), function modules (FMs)). With STEP 7, you can decide which signal from a configurable digital or analog module starts the OB. With CPs and FMs, use the appropriate parameter assignment dialogs.

Hardware interrupts are triggered when a signal module with hardware interrupt capability and with an enabled hardware interrupt passes on a received process signal to the CPU or when a function module of the CPU signals an interrupt.

Rules for Hardware Interrupts

Hardware interrupts can only be executed when the corresponding organization block exists in the CPU program. If this is not the case, an error message is entered in the diagnostic buffer and asynchronous error handling is executed (OB80, see Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)).

If you have deselected hardware interrupt OBs in the parameter assignment, these cannot be started. The CPU recognizes a programming error and changes to STOP mode.

Assigning Parameters to Signal Modules with Hardware Interrupt Capability

Each channel of a signal module with hardware interrupt capability can trigger a hardware interrupt. For this reason, you must specify the following in the parameter sets of signal modules with hardware interrupt capability using STEP 7:

- What will trigger a hardware interrupt.
- Which hardware interrupt OB will be executed (the default for executing all hardware interrupts is OB40).

Using STEP 7, you activate the generation of hardware interrupts on the function blocks. You assign the remaining parameters in the parameter assignment dialogs of these function modules.

Priority of the Hardware Interrupt OBs

The default priority for the hardware interrupt OBs is priority class 16 to 23. You can assign parameters to change the priority classes.

4.2.4.5 Startup Organization Blocks (OB100 / OB101 / OB102)

Startup Types

There are three distinct types of startup:

- Hot restart (not in S7-300 and S7-400H)
- Restart (warm restart)
- Cold restart

The following table shows which OB the operating system calls in each startup type.

Startup Type	Related OB
Hot restart	OB101
Restart (warm restart)	OB100
Cold restart	OB102

Start Events for Startup OBs

The CPU executes a startup after the following events:

- After power up
- After you switch the mode selector from STOP to RUN/RUN-P
- After a request from a communication function
- After synchronizing in multicomputing mode
- In an H system after link-up (only on the standby CPU)

Depending on the start event, the CPU used, and its set parameters the relevant startup OB (OB100, OB101, or OB102) is called.

Startup Program

You can specify the conditions for starting up your CPU (initialization values for RUN, startup values for I/O modules) by writing your program for the startup in the organization blocks OB100 for restart (warm restart), OB101 for hot restart, or OB102 for cold restart.

There are no restrictions to the length of the startup program and no time limit since the cycle monitoring is not active. Time-driven or interrupt-driven execution is not possible in the startup program. During the startup, all digital outputs have the signal state 0.

Startup Type After Manual Restart

On S7-300 CPUs only a manual restart (warm restart) or cold restart (CPU 318-2 only) is possible.

On some S7-400 CPUs, you can restart manually using the mode selector and the startup type switch (CRST/WRST) if this is permitted by the parameter assignment you made with STEP 7. A manual restart (warm restart) is possible without specifically assigning parameters.

Startup Type After Automatic Restart

On S7-300 CPUs, only a restart (warm restart) is possible following power up.

On S7-400 CPUs, you can specify whether an automatic startup following power up leads to a restart (warm restart) or a hot restart.

Clearing the Process Image

When an S7-400 CPU is restarted, the remaining cycle is executed, and as default, the process image output table is cleared. You can prevent the process image being cleared if you want the user program to continue with the old values following a restart.

Module Exists/Type Monitoring

In the parameters, you can decide whether the modules in the configuration table are checked to make sure they exist and that the module type matches before the startup.

If the module check is activated, the CPU will not start up if a discrepancy is found between the configuration table and the actual configuration.

Monitoring Times

To make sure that the programmable controller starts up without errors, you can select the following monitoring times:

- The maximum permitted time for transferring parameters to the modules
- The maximum permitted time for the modules to signal that they are ready for operation after power up
- On S7-400 CPUs, the maximum time of an interruption during which a hot restart is permitted.

Once the monitoring times expire, the CPU either changes to STOP, or only a restart (warm restart) is possible.


4.2.4.6 Background Organization Block (OB90)

If you have specified a minimum scan cycle time with STEP 7 and this is longer than the actual scan cycle time, the CPU still has processing time available at the end of the cyclic program. This time is used to execute the background OB. If OB90 does not exist on your CPU, the CPU waits until the specified minimum scan cycle time has elapsed. You can therefore use OB90 to allow processes where time is not critical to run and thus avoid wait times.

Priority of the Background OB

The background OB has priority class 29, which corresponds to priority 0.29. It is therefore the OB with the lowest priority. Its priority class cannot be changed by reassigning parameters.

The following figure shows an example of processing the background cycle, the main program cycle, and OB10 (in CPUs as of 10/98).



- T_{max} = Maximum cycle time that can be set
- T_{min} = Minimum cycle time that can be set
- T_c = Actual scan cycle time
- T_{wait} = Difference between T_{min} and actual scan cycle time. In this time, occurred interrupts and the background OB can be processed
- PC = Priority class

Programming OB90

The run time of OB90 is not monitored by the CPU operating system so that you can program loops of any length in OB90. Ensure that the data you use in the background program are consistent by observing the following when programming:

- The reset events of OB90 (see the "System Software for S7-300 and S7-400, System and Standard Functions" Reference Manual)
- The process image update asynchronous to OB90.

4.2.4.7 Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122)

Types of Errors

The errors that can be detected by the S7 CPUs and to which you can react with the help of organization blocks can be divided into two basic categories:

- Synchronous errors: these errors can be assigned to a specific part of the user program. The error occurs during the execution of a particular instruction. If the corresponding synchronous error OB is not loaded, the CPU changes to STOP mode when the error occurs.
- Asynchronous errors: these errors cannot be directly assigned to the user program being executed. These are priority class errors, faults on the programmable logic controller (for example, a defective module), or redundancy errors. If the corresponding asynchronous error OB is not loaded, the CPU changes to STOP mode when the error occurs (exceptions: OB70, OB72, OB81, OB 87).

The following table shows the types of errors that can occur, divided up into the categories of the error OBs.

Asynchronous Errors/Redundancy Errors	Synchronous Errors
OB70 I/O Redundancy Error (only H CPUs)	OB121 Programming Error (for example, DB is not loaded)
OB72 CPU Redundancy Error (only in H CPUs, for example, failure of a CPU)	OB122 I/O Access Error (for example, access to a signal module that does not exist)
OB80 Time Error (for example, scan cycle time exceeded)	
OB81 Power Supply Error (for example, battery failure)	
OB82 Diagnostic Interrupt (for example, short circuit in the input module)	
OB83 Remove/Insert Interrupt (for example, removing an input module)	
OB84 CPU Hardware Fault (fault at the interface to the MPI network)	
OB85 Priority Class Error (for example, OB is not loaded)	
OB86 Rack Failure	
OB87 Communication Error (for example, incorrect message frame ID for global data communication)	

Using OBs for Synchronous Errors

Synchronous errors occur during the execution of a particular instruction. When these errors occur, the operating system makes an entry in the I stack and starts the OB for synchronous errors.

The error OBs called as a result of synchronous errors are executed as part of the program in the same priority class as the block that was being executed when the error was detected. The details about the error that triggered the OB call are in the start information for the OB. You can use this information to react to the error condition and then to return to processing your program (for example, if an access error occurs on an analog input module, you can specify a substitute value in OB122 using SFC44 RPL_VAL). The local data of the error OBs, do, however, take up additional space in the L stack of this priority class.

With S7-400 CPUs, one synchronous error OB can start a further synchronous error OB. This is not possible with S7-300 CPUs.

Using OBs for Asynchronous Errors

If the operating system of the CPU detects an asynchronous error, it starts the corresponding error OB (OB70 to OB73 and OB80 to OB87). The OBs for asynchronous errors have the highest priority as default and they cannot be interrupted by other OBs if all asynchronous error OBs have the same priority. If more than one asynchronous error OB with the same priority occurs simultaneously, they are processed in the order they occurred.

Masking Start Events

Using system functions (SFCs), you can mask, delay, or disable the start events for several OBs. For more detailed information about these SFCs and the organization blocks, refer to the "System Software for S7-300 and S7-400, System and Standard Functions" Reference Manual.

Type of Error OB	SFC	Function of the SFC
Synchronous error OBs	SFC36 MSK_FLT	Masks individual synchronous errors. Masked errors do not start an error OB and do not trigger programmed reactions
	SFC37 DMSK_FLT	Unmasks synchronous errors
Asynchronous error OBs	SFC39 DIS_IRT	Disables all interrupts and asynchronous errors. Disabled errors do not start an error OB in any of the subsequent CPU cycles and do not trigger programmed reactions
	SFC40 EN_IRT	Enables interrupts and asynchronous errors
	SFC41 DIS_AIRT	Delays higher priority interrupts and asynchronous errors until the end of the OB
	SFC42 EN_AIRT	Enables higher priority interrupts and asynchronous errors

Note

If you want interrupts to be ignored, it is more effective to disable them using an SFC, rather than to download an empty OB (with the contents BE).

5 Startup and Operation

5.1 Starting STEP 7



When you start Windows, you will find an icon for the SIMATIC Manager, the starting point for the STEP 7 software on the Windows interface.

The quickest method to start STEP 7 is to position the cursor on the icon and double-click. The window containing the SIMATIC Manager is then opened. From here you can access all the functions you have installed for the standard package and any optional packages.

Alternatively you can also start the SIMATIC Manager via the "Start" button in the taskbar of the operating system. You will find the entry under "Simatic".

Note

You will find more information about standard Windows operation and options in your Windows user's guide or in the online help of your Windows operating system.

SIMATIC Manager

The SIMATIC Manager is the basic application for configuring and programming. You can perform the following functions in the SIMATIC Manager:

- Set up projects
- Configure and assign parameters to hardware
- Configure hardware networks
- Program blocks
- Debug and commission your programs

Access to the various functions is designed to be object-oriented, and intuitive and easy to learn.

You can work with the SIMATIC Manager in one of two ways:

- Offline, without a programmable controller connected
- Online, with a programmable controller connected

Note the relevant safety notices in each case.

How to Proceed from Here

You create automation tasks in the form of "Projects." You will make it easier for yourself if you read up on the following basic topics before you start work:

- User interface
- Some basic operating steps
- Online help

5.2 Starting STEP 7 with Default Start Parameters

From STEP 7 V5.0 onwards, you can create several symbols in the SIMATIC Manager and specify start parameters in the call line. By doing this, you can cause the SIMATIC Manager to position on the object described by these parameters. This allows you to jump to the corresponding locations in a project immediately just by double-clicking.

On calling **s7tgotpx.exe**, you can specify the following start parameters:

/e <complete physical project path>

/o <logical path of the object, on which you want to position>

/h <ObjectID>

/onl

The start parameter **/onl** causes the project to be opened online and the specified path to be called.

/off

The start parameter **/off** causes the project to be opened offline and the specified path to be called.

/keep

The start parameter **/keep** causes the following to occur:

If the SIMATIC Manager is open, the already displayed projects are opened in addition to the new project to be explicitly opened by means of the command line. If the SIMATIC Manager is not yet open, then the new project is opened along with the projects stored in the session memory of the SIMATIC Manager. If this start parameter is not specified, the opened projects are closed first, the session memory is ignored and only the one specified project is opened.

The easiest way to establish suitable parameters is described below.

Establishing Parameters by Copying and Pasting

Proceed as follows:

1. On your desktop, create a new link to the file **s7tgotpx.exe**. This file is located in the installation directory under **S7bin**.
2. Display the properties dialog box.
3. Select the "Link" tab. The entry under "Target" should now be expanded as follows.
4. Select the required object in the SIMATIC Manager.
5. Copy the object to the clipboard using the key combination **CTRL+ALT+C**.
6. Position the cursor at the end of the "Target" entry in the "Link" tab.
7. Paste the contents of the clipboard using the key combination **CTRL+V**.
8. Close the dialog box by confirming with "OK."

Example of Parameters:

```
/e F:\SIEMENS\STEP7\S7proj\MyConfig\MyConfig.s7p /keep  
/o "1,8:MyConfig\SIMATIC 400(1)\CPU416-1\S7-Program(1)\Blocks\FB1"  
/h T00112001;129;T00116001;1;T00116101;16e /keep
```

Note on the Structure of the Project Path

The project path is the physical path in the file system.

The complete logical path has the following structure:

[View ID,online ID]:project name\{object name}\ object name

Example: /o 1.8:MyConfig\SIMATIC 400(1)\CPU416-1\S7-Program(1)\Blocks\FB1

Note on the Structure of the Logical Path

The complete logical path and the Object ID can only be created using the copy and paste functions.

However, it is also possible to specify the path which can be read by the user. In the example above, that would be:

/o "MyConfig\SIMATIC 400(1)\CPU416-1\S7-Program(1)\Blocks\FB1". By adding /onl or /off the user can specify whether the path is valid in the online or offline window. You do not need to specify this if you use the copy and paste functions.

Important: If the path contains blanks, it must be placed within quotation marks.

5.3 Calling the Help Functions

Online Help

The online help system provides you with information at the point where you can use it most efficiently. You can use the online help to access information quickly and directly without having to search through manuals. You will find the following types of information in the online help:

- **Contents:** offers a number of different ways of displaying help information
- **Context-sensitive Help (F1 key):** with the F1 key you access information on the object you just selected with the mouse or on the active dialog box or window
- **Introduction:** gives a brief introduction to the use, the main features, and the functional scope of an application
- **Getting Started:** summarizes the basic steps you need to execute to get started with the application
- **Using Help:** provides a description of ways of finding specific information in the online help
- **About:** provides information on the current version of the application

Via the Help menu you can also access topics which relate to the current dialog situation from every window.

Calling the Online Help

You can call the online help in one of the following ways:

- Select a menu command in the Help menu in the menu bar.
- Click the "Help" button in a dialog box. You are then shown help on this dialog box.
- Position the cursor in a window or dialog box on the topic you need help with and press the F1 key or select the menu command **Help > Context-sensitive Help**.
- Use the question mark cursor in Windows.

The last three of these ways of accessing the online help are known as context-sensitive help.


Calling the Quick Help

A quick help on buttons in the toolbar is displayed when you position the cursor on a button and leave it there for a moment.

5.4 Objects and Object Hierarchy

In the same way that the Windows Explorer shows the directory structure of folders and files, the object hierarchy for projects and libraries in STEP 7 is shown in the SIMATIC Manager.

The following figure shows an example of an object hierarchy.



Objects have the following functions:

- Carriers of object properties,
- Folders,
- Carriers of functions (for example, to start a particular application).

Objects as Carriers of Properties

Objects can carry both functions and properties (such as settings). When you select an object, you can perform one of the following functions with it:

- Edit the object using the menu command **Edit > Open Object**.
- Open a dialog box using the menu command **Edit > Object Properties** and set object-specific options.

A folder can also be a carrier of properties.

Objects as Folders

A folder (directory) can contain other folders or objects. These are displayed when you open the folder.

Objects as Carriers of Functions

When you open an object, a window is displayed in which you can edit the object.


An object is either a folder or a carrier of functions. An exception to this is stations: they are both folders (for programmable modules) and carriers of functions (used to configure the hardware).

- If you double-click a station, the objects contained in it are displayed: the programmable modules and the station configuration (station as a folder).
 - If you open a station with the menu command **Edit > Open Object**, you can configure this station and assign parameters to it (station as the carrier of a function). The menu command has the same effect as a double-click on the "Hardware" object.
-

5.4.1 Project Object

The project represents the entirety of all the data and programs in an automation solution, and is located at the top of an object hierarchy.

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	--

Symbol	Object Folder	Selection of Important Functions
	Project	<ul style="list-style-type: none"> • Creating a Project • Archiving Projects and Libraries • Managing Multilingual Texts • Checking Projects for Optional Packages Used • Printing Project Documentation • Rearranging • Translating and Editing Operator Related Texts • Inserting Operator Station Objects • More than One User Editing Projects • Converting Version 1 Projects • Converting Version 2 Projects • Setting the PG/PC Interface

Symbol	Objects in the Project Level	Selection of Important Objects
	Station: SIMATIC 300 station SIMATIC 400 station	<ul style="list-style-type: none"> Inserting Stations Stations are both objects (project level) and object folder (station level). Other functions can be found under Station Object
 	S7 program M7 program	<ul style="list-style-type: none"> S7/M7 Program without a Station or CPU S7/M7 programs are both objects (project level) and object folders (program level). Other functions can be found under S7/M7 Program Object
	Network for starting the tool for network configuration and setting the network properties.	<ul style="list-style-type: none"> Properties of Subnets and Communication Nodes Overview: Global Data Communication Procedure for Configuring Global Data Communication

5.4.2 Library Object

A library can contain S7/M7 programs and is used to store blocks. A library is located at the top of an object hierarchy.

   	<ul style="list-style-type: none"> Library Object S7/M7 Program Object Source File Folder Object Block Folder Object
--	---


Symbol	Object Folder	Selection of Important Functions
	Library	<ul style="list-style-type: none"> Overview of the Standard Libraries Working with Libraries Archiving Projects and Libraries

Symbol	Objects in the Library Level	Selection of Important Functions
 	S7 program M7 program	<ul style="list-style-type: none"> Inserting an S7/M7 Program S7/M7 programs are both objects (project level) and object folders (program level). Other functions can be found under S7/M7 Program Object

5.4.3 Station Object

A SIMATIC 300/400 station represents a S7 hardware configuration with one or more programmable modules.

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	---


Symbol	Object Folder	Selection of Important Functions
	Station	<ul style="list-style-type: none"> • Inserting a Station • Uploading a Station • Downloading a Configuration to a Programmable Controller • Uploading a Configuration from a Station • Displaying CPU Messages and User-Defined Diagnostic Messages • Configuring the 'Reporting of System Errors' • Diagnosing Hardware and Displaying Module Information • Displaying and Changing the Operating Mode • Displaying and Setting the Time and Date • Erasing the Load/Work Memory and Resetting the CPU
	SIMATIC PC Station (Not assigned)	<ul style="list-style-type: none"> • Creating and Assigning Parameters to SIMATIC PC Stations • Configuring Connections for a SIMATIC PC Station • Uploading a SIMATIC PC Station
	SIMATIC PC Station (Assigned)	<ul style="list-style-type: none"> • Highlighting the SIMATIC PC Station to be Configured in the Network View

Symbol	Objects in the Station Level	Selection of Important Functions
	Hardware	<ul style="list-style-type: none">• Basic Procedure for Configuring Hardware• Basic Steps for Configuring a Station• Overview: Procedure for Configuring and Assigning Parameters to a Local Configuration• Basic Procedure for Configuring a DP Master System• Configuring Multicomputing Operation
	Programmable module	<ul style="list-style-type: none">• Programmable modules are both objects (station level) and object folders ("Programmable Modules" level). Other functions can be found under Programmable Module Object

5.4.4 Programmable Module Object

A programmable module represents the parameter assignment data of a programmable module (CPUxxx, FMxxx, CPxxx). The system data of modules with no retentive memory (for example, CP441) are loaded via the CPU of the station. For this reason, no "system data" object is assigned to such modules and they are not displayed in the project hierarchy.

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	---


Symbol	Object Folder	Selection of Important Functions
	Programmable module	<ul style="list-style-type: none"> • Overview: Procedure for Configuring and Assigning Parameters to a Local Configuration • Displaying CPU Messages and User-Defined Diagnostic Messages • Configuring 'Reporting of System Errors' • Diagnosing Hardware and Displaying Module Information • Downloading via EPROM Memory Cards • Password Protection for Access to Programmable Controllers • Displaying the Force Values Window • Displaying and Changing the Operating Mode • Displaying and Setting the Time and Date • Setting the Operating Behavior • Erasing the Load/Work Memory and Resetting the CPU • Diagnostics Symbols in the Online View • Division of the Memory Areas • Saving Downloaded Blocks on Integrated EPROM • Updating the Operating System on the Programmable Logic Controller
	Object representing a programmable module	<ul style="list-style-type: none"> • Displaying Modules Configured with Later STEP 7 Versions

Symbol	Objects in the "Programmable Modules" level	Selection of Important Functions
  	Programs: S7 program M7 program Program	<ul style="list-style-type: none">• Inserting an S7/M7 Program• S7/M7 programs are both objects (project level) and object folders (program level). Other functions can be found under S7/M7 Program Object
	Connections for defining connections within the network	<ul style="list-style-type: none">• Networking Stations within a Project• Connection Types and Connection Partners• What You Should Know About the Different Connection Types• Entering a New Connection• Configuring Connections for Modules in a SIMATIC Station

5.4.5 S7/M7 Program Object

A (S7/M7) program folder contains software for S7/M7 CPU modules or software for non-CPU modules (for example, programmable CP or FM modules).

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	---

Symbol	Object Folder	Selection of Important Functions
	S7 Program	<ul style="list-style-type: none"> • Inserting an S7-/M7-Program • Setting the Address Priority • Basic Procedure for Creating Logic Blocks • Assigning Message Numbers • How to Assign and Edit User-Specific Diagnostics Messages (Project-Oriented) • How to Assign and Edit User-Specific Diagnostics Messages (CPU-Oriented) • Translating and Editing Operator Related Texts • Managing Multilingual Texts • Displaying CPU Messages and User-Defined Diagnostic Messages • Program Measures for Handling Errors
	M7 program	<ul style="list-style-type: none"> • Procedure for M7 Systems
	Program	<ul style="list-style-type: none"> • Creating the Software in the Project (General)


Symbol	Objects in the Program Level	Selection of Important Functions
	Source file folder	<ul style="list-style-type: none"> • Other functions can be found under Source File Folder Object
	Block folder	<ul style="list-style-type: none"> • Other functions can be found under Block Folder Object
	Text libraries folder	<ul style="list-style-type: none"> • User Text Libraries
	Symbol table for assigning symbols to signals and other variables	<ul style="list-style-type: none"> • Absolute and Symbolic Addressing • Structure and Components of the Symbol Table • Entering Shared Symbols • General Tips on Entering Symbols • How to Assign and Edit Symbol-Related Messages (Project-Oriented) • How to Assign and Edit Symbol-Related Messages (CPU-Oriented) • Translating and Editing Operator Related Texts • Configuring Operator Control and Monitoring Attributes via the Symbol Table • Editing the Communication Attribute • Exporting and Importing Symbol Tables

5.4.6 Block Folder Object

A block folder of an offline view can contain: logic blocks (OB, FB, FC, SFB, SFC), data blocks (DB), user-defined data types (UDT) and variable tables. The system data object represents system data blocks.

The block folder of an online view contains the executable program parts that have been downloaded to the programmable controller.

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	--

Symbol	Object Folder	Selection of Important Functions
	Blocks	<ul style="list-style-type: none"> • Downloading with Project Management • Downloading without Project Management • Overview of the Available Reference Data • Rewiring • Comparing Blocks • Translating and Editing Operator Related Texts • Jumps to Language Descriptions and Help on Blocks, System Attributes

Symbol	Objects in the Block Folder	Selection of Important Functions
	Blocks in general	<ul style="list-style-type: none"> • Basic Procedure for Creating Logic Blocks • Creating Blocks • Basic Information on Programming in STL Source Files • Comparing Blocks
	Organization Block (OB)	<p>Additional Functions:</p> <ul style="list-style-type: none"> • Introduction to Data Types and Parameter Types • Requirements for Downloading • Testing using Program Status • What You Should Know About Testing in Single-Step Mode/Breakpoints • Rewiring • Help on Blocks


Symbol	Objects in the Block Folder	Selection of Important Functions
	Function (FC)	<p>Additional Functions:</p> <ul style="list-style-type: none"> • Introduction to Data Types and Parameter Types • Requirements for Downloading • Testing using Program Status • What You Should Know About Testing in Single-Step Mode/Breakpoints • Rewiring • Attributes for Blocks and Parameters
	Function Block (FB)	<p>Additional Functions:</p> <ul style="list-style-type: none"> • Introduction to Data Types and Parameter Types • Using Multiple Instances • Requirements for Downloading • Testing Using Program Status • What You Should Know about Testing in Single-Step Mode/Breakpoints • Rewiring • Attributes for Blocks and Parameters • How to Assign and Edit Block-Related Messages (Project-Oriented) • How to Create Block-Related Messages (CPU-Oriented) • How to Configure PCS 7 Messages (Project-Oriented) • How to Configure PCS 7 Messages (CPU-Oriented) • Translating and Editing Operator Related Texts • Assigning Monitor/Control Attributes to Function Block Parameters
	User-Defined Data Type (UDT)	<ul style="list-style-type: none"> • Creating Blocks • Basic Information on Programming in STL Source Files • Introduction to Data Types and Parameter Types • Using User-Defined Data Types to Access Data • Attributes for Blocks and Parameters
	DB (Global Data Blocks)	<ul style="list-style-type: none"> • Data View of Data Blocks • Declaration View of Data Blocks • Requirements for Downloading • Program Status of Data Blocks • Introduction to Data Types and Parameter Types • Using Multiple Instances • Attributes for Blocks and Parameters • How to Assign and Edit Block-Related Messages (Project-Oriented) (Instance DBs Only) • How to Assign and Edit Block-Related Messages (CPU-Oriented) (Instance DBs Only) • How to Configure PCS7 Messages (Project-Oriented) (Instance DBs Only) • How to Configure PCS7 Messages (CPU-Oriented) (Instance DBs Only) • Translating and Editing Operator Related Texts (Instance Data Blocks Only)
	System Function (SFC)	<ul style="list-style-type: none"> • Requirements for Downloading • Attributes for Blocks and Parameters • Help on Blocks

Symbol	Objects in the Block Folder	Selection of Important Functions
	SFB (System Function Blocks)	<ul style="list-style-type: none"> • Requirements for Downloading • Attributes for Blocks and Parameters • How to Assign and Edit Block-Related Messages (Project-Oriented) • How to Create Block-Related Messages (CPU-Oriented) • How to Configure PCS7 Messages (Project-Oriented) • How to Configure PCS7 Messages (CPU-Oriented) • Translating and Editing Operator Related Texts • Help on Blocks
	Block with KNOW HOW protection	<ul style="list-style-type: none"> • Rules for Defining Block Properties in STL Sources • Block Properties
	Diagnostic-capable block	Additional information is available in the documentation for the S7-PDIAG optional package.
	Block was created with the F-FBD/-LAD/-STL/-DB programming language	Additional information is available in the documentation for the S7 Distributed Safety optional package.
{bmc Manager _Bst_Var.bmp	Variable Table (VAT)	<ul style="list-style-type: none"> • Basic Procedure when Monitoring and Modifying with the Variable Table • Introduction to Testing with the Variable Table • Introduction to Monitoring Variables • Introduction to Modifying Variables • Introduction to Forcing Variables
	System Data Block (SDB)	<p>System data blocks (SDBs) are only edited indirectly via functions:</p> <ul style="list-style-type: none"> • Introduction to Configuring Hardware • Properties of Subnets and Communication Nodes • Overview: Global Data Communication • Assigning and Editing Symbol-Related Messages • Requirements for Downloading

5.4.7 Source File Folder Object

A source file folder contains source programs in text format.

Position in the Project View

	<ul style="list-style-type: none"> • Project Object • Station Object • Programmable Module Object • S7/M7 Program Object • Source File Folder Object • Block Folder Object
---	---

Symbol	Object Folder	Selection of Important Functions
	Source File Folder	<ul style="list-style-type: none"> • Basic Information on Programming in STL Source Files • Exporting Source Files • Importing Source Files

Symbol	Objects in Source File Folder	Selection of Important Functions
	Source file (for example, STL source file)	<ul style="list-style-type: none"> • Basic Information on Programming in STL Source Files • Creating STL Source Files • Inserting Block Templates in STL Source Files • Inserting Source Code from Existing Blocks in STL Source Files • Checking Consistency in STL Source Files • Compiling STL Source Files • Generating STL Source Files from Blocks • Exporting Source Files • Importing Source Files
	Network template	<ul style="list-style-type: none"> • Working with Network Templates

5.4.8 S7/M7 Program without a Station or CPU

You can create programs without having configured a SIMATIC station beforehand. This means that you can initially work independently of the module and module settings you intend to program.

Creating an S7/M7 Program

1. Open the relevant project using the menu command **File > Open** or activate the project window.
2. Select the project in the project window of the offline view.
3. Select one of the following menu commands, depending on which programmable controller the program is being created for:
Insert > Program > S7 Program, if your program is to run on a SIMATIC S7 device.
Insert > Program > M7 Program, if your program is to run on a SIMATIC M7 device.

The S7/M7 program is added and arranged directly below the project in the project window. It contains a folder for the blocks and an empty symbol table. You can now create and program blocks.

Assigning a Program to a Programmable Module

When you insert programs that are not dependent on a particular module, you can easily assign them to a module later on by copying or moving these programs to the module symbol using the drag and drop function.

Adding a Program to a Library

If the program is to be used for a SIMATIC S7 programmable controller and you want to use it many times as a "software pool," you can also insert it in a library. However, when testing, the programs must lie directly under a project, because this is the only way in which to establish a connection to the programmable controller.

Accessing a Programmable Controller

Select the online view of the project. You can make the address settings in the dialog box containing the program properties.

Note

When deleting stations or programmable modules, you will be asked if you also want to delete the program contained within. If you choose not to delete the program, it will be attached directly below the project as a program without a station.

5.5 User Interface and Operation

5.5.1 Operating Philosophy

The aim: Easy Operation

It is the aim of the graphic user interface to provide maximum and intuitive operating comfort. You will therefore find objects you already know from your daily work, e.g. stations, modules, programs, blocks.

Actions you perform under STEP 7 include the creation, selection and manipulation of such objects.

Differences to Tool-Based Operation

When starting work with conventional tools, the first thing you have to do is to choose the appropriate tool for a specific solution and then call this tool.

The basic procedure of object-oriented operation is to select an object and then open it for editing.

Object oriented operation does not require knowledge of a special instruction syntax. On the GUI, icons you can open via menu command or mouse click represent objects.


When you open an object, the application automatically calls the appropriate software component for displaying or editing the content of the object.

Continue ...

Below we describe the basic actions for editing objects. Please pay proper attention to this topic, as all subsequent topics will be based on these basic operations.

5.5.2 Window Arrangement

The standard components of a window are shown in the following figure:



Title Bar and Menu Bar

The title bar and menu bar are always found at the top of a window. The title bar contains the title of the window and icons for controlling the window. The menu bar contains all menus available in the window.

Toolbar

The toolbar contains icons (or tool buttons) which provide shortcuts to frequently used and currently available menu bar commands via a single mouse click. A brief description of the function of the respective button is displayed together with additional information in the status bar when you position the cursor briefly on the button.

If access to a button is not possible in the current configuration, the button is grayed out.


Status Bar

The status bar displays context-specific information.

5.5.3 Elements in Dialog Boxes

Making Entries in Dialog Boxes

In dialog boxes you can enter information which is required for executing a particular task. The components which appear most frequently in dialog boxes are explained using the example in the following figure.




List Boxes and Combination Boxes

Text boxes sometimes have an arrow pointing downwards beside them. This arrow shows that there are more options available to choose from for this box. Click on the arrow to open a list box or combination box. If you click on an entry in the list, it is automatically displayed in the text box.

Tabs in Dialog Boxes

The content of some dialog boxes is organized using tabs to improve the clarity of the information by dividing the dialog box into tab cards (see figure below).



The names of the tab cards are shown on tabs along the top edge of the dialog box. To bring a particular tab card to the foreground, you simply click on its tab.

5.5.4 Creating and Managing Objects

Some basic processing steps are the same for all objects and do not depend on the object type. These standard handling sequences are summarized here. This knowledge of standard procedures is required to move on to other sections in the manual.

The usual sequence of steps when handling objects is:

- Create an object
- Select an object
- Perform actions with the object (for example, copy, delete).

Setting the Path to Create New Projects/Libraries

New user projects, libraries and multiprojects are stored in the default folder "\Siemens\Step7\S7proj". If you want to store them in another folder, you should set your custom path for these objects before you save projects, libraries and multiprojects for the first time. To do this, select the menu command **Options > Customize**. In the "General" tab of the dialog box displayed you can specify the path name under which you want to store new projects or libraries.

Creating Objects

The STEP 7 wizard "New Project" offers support with creating a new project and inserting objects. Use the menu command **File > "New Project" Wizard** to open the wizard. In the dialog boxes displayed you can set the structure of your project and then have the wizard create the project for you.

If you do not wish to use the wizard, you can create projects and libraries using the menu command **File > New**. These objects form the starting point of an object hierarchy. You can create all other objects in the hierarchy using the commands in the Insert menu, provided they are not created automatically. The exception to this are the modules in a SIMATIC station which are created when you configure the hardware or by using the "New Project" wizard.

Opening Objects

There are a number of ways to open an object in the detailed view:

- Double-click on the object icon
- Select the object and then the menu command **Edit > Open Object**. This only works for objects that are not folders.

Once you have opened an object, you can create or change its contents.

When you open an object that does not contain other objects, its contents are represented by a suitable software component in a new window for editing purposes. You cannot change objects whose contents are already being used elsewhere.

Note

Exception: Stations appear as folders for programmable modules (when you double-click them) and for the station configuration. If you double-click the "Hardware" object, the application for configuring hardware is started. Selecting the station and selecting the menu command **Edit > Open Object** has the same effect.

Building an Object Hierarchy

Use the "New Project" wizard to create the object hierarchy. When you open a folder, the objects it contains are displayed on the screen. You can now create more objects in the folder using the Insert menu, for example, additional stations in a project. Only the commands for those objects which can be inserted in the current folder are active in the Insert menu.

Setting Object Properties

Object properties are data belonging to the object which determine its behavior. The dialog box for setting object properties appears automatically when you create a new object and properties have to be set. The properties can also be changed at a later date.

Using the menu command **Edit > Object Properties**, a dialog box is opened in which you can display or set the properties for the selected object.

Using the menu command **Edit > Special Object Properties**, you can open dialog boxes and enter data required for operator control and monitoring functions and for configuring messages.

For example, in order to display the special object properties of a block for operator control and monitoring, the block must be marked as being relevant for operator control and monitoring, meaning that the system attribute "s7_m_c" must be set to the value "true" in the "Attributes" tab of the block properties.

Note

- Properties of the "System Data" folder and the "Hardware" object cannot be displayed or changed.
 - You cannot write in the dialog boxes for object properties of a read-only project. In this case, the input boxes are grayed out.
 - If you display the properties of programmable modules, you cannot edit the displayed parameters for reasons of consistency. To edit the parameters you must open the "Configuring Hardware" application.
 - If you change the settings for objects on the programming device (for example, the configuration data of a module), they are not yet effective in the target system, because the system data blocks in which the settings are saved have to be in the target system.
 - If you load an entire user program, the system data blocks are also automatically transferred. If you change the settings after having loaded the program, you can reload the "System data" object in order to transfer the settings to the target system.
 - It is strongly recommended to edit the folders exclusively with STEP 7, since they can be physically structured in a different way than you see in the SIMATIC Manager.
-

Cutting, Pasting, Copying

Most objects can be cut, pasted, or copied as usual under Windows. The menu commands for these functions are found in the Edit menu.

You can also copy objects by dragging and dropping. If you attempt to move or copy to an illegal destination, the cursor displays a prohibited sign as a warning.

When you copy an object, the whole hierarchy beneath it is also copied. This enables components you create in an automation task to be used again and again.

Note

The connection table in the "Connections" folder cannot be copied. Note that when you copy lists of operator-relevant texts, only those languages installed in the destination object are accepted.

You will find a step-by-step guide to copying under Copying Objects.

Renaming Objects

The SIMATIC Manager assigns standard names to some new objects. These names are generally formed from the type of object (if a number of objects of this type can be created in the same folder) and a number.

For example, the first S7 program will be named "S7 Program(1)", the second "S7 Program(2)" etc. The symbol table is simply called "Symbols" as it can only exist once in each folder.

You can change the names of most objects and assign them names which are more relevant to their content.

With projects, the directory names in the path must not have more than 8 characters. Otherwise, there may be problems when archiving and using "C for M7" (Borland compiler).

You can change the name of an object directly or using the object properties.

Directly:

When you slowly click twice on the name of a selected object, a frame appears around the text. You can then edit the name using the keyboard.

Using the menu:

Select the required object in the project window and select the menu command **Edit > Rename**. A frame appears around the text. You can then edit the name using the keyboard.

If you are not allowed to change the name:

If you are not allowed to change the name of an object, the input field is shown in gray in the dialog box, the current name is displayed, and text entries are not possible.

Note

If you move the mouse pointer out of the name box while editing the name and execute another action (for example, select a menu command), the edit procedure is terminated. The changed name is accepted and entered if it is allowed.

You will find a step-by-step guide to renaming under Renaming Objects.

Moving Objects

With the SIMATIC Manager you can move objects from one folder to another even if the destination is in another project. When you move a folder its contents are all moved as well.

Note

You cannot move the following objects:

- Connections
 - System data blocks (SDB) in the online view
 - System functions (SFC) and system function blocks (SFB) in the online view
-

You will find a step-by-step guide to moving under Moving Objects.

Sorting Objects

You can sort objects in the detailed view (menu command **View > Details**) according to their attributes. To do this, click on the corresponding header of the required attribute. When you click again, the sort order is reversed. Blocks of one type are sorted according to their numerical order, for example, FB1, FB2, FB11, FB12, FB21, FC1.

Default Sort Order

When you re-open a project, the objects in the detailed view are displayed according to a default sort order. Examples:

- Blocks are shown in the order "System data, OB, FB, FC, DB, UDT, VAT, SFB, SFC."
- In a project, all stations are shown first and then the S7 programs.

The default is not therefore an alphanumeric ascending or descending sort order in the detailed view.

Restoring the Default Sort Order

After resorting, for example, by clicking on the column header "Object Name," you can restore the default order if you proceed as follows:

- Click the column header "Type" in the detailed view.
- Close the project and open it again.

Deleting Objects

You can delete folders and objects. If you delete a folder, all the objects contained in it are also deleted.

You cannot undo the delete procedure. If you are not sure whether you really no longer need an object, it is better to archive the whole project first.

Note

You cannot delete the following objects:

- Connections
 - System data blocks (SDB) in the online view
 - System functions (SFC) and system function blocks (SFB) in the online view
-

You will find a step-by-step guide to deleting under Deleting Objects.

5.5.5 Selecting Objects in a Dialog Box


Selecting objects in a dialog box (browser) is an action which you will need regularly for a large number of different edit steps.

Calling the Browser

You call the browser dialog in the hardware configuration application, for example, using menu commands such as **Station > New/Open** (one exception is the basic application window "SIMATIC Manager").

Structure of a Browser Dialog

In the browser you have the following selection options as shown in the following figure.



5.5.6 Session Memory

The SIMATIC Manager can save the contents of windows (that is, the projects and libraries open), and the layout of the windows.

- Using the menu command **Options > Customize**, you define whether the window contents and layout are to be saved at the end of a session. At the start of the next session, these window contents and layout are restored. In the open projects, the cursor is positioned on the last folder selected.
- Using the menu command **Window > Save Settings** you save the current window contents and the window arrangement.
- Using the menu command **Window > Restore Settings** you restore the window contents and layout that you saved with the menu command **Window > Save Settings**. In the open projects, the cursor is positioned on the last folder selected.

Note

The window contents of online projects, the contents of the "Accessible Nodes" window, and the contents of the "S7 Memory Card" window are not saved.

Any passwords you may have entered for access to programmable controllers (S7-300/S7-400) are not saved at the end of a session.

5.5.7 Changing the Window Arrangement

To cascade all the displayed windows one behind the other, select one of the following options:

- Select the menu command **Window > Arrange > Cascade**.
- Press the key combination SHIFT + F5.

To arrange all the displayed windows from top to bottom on the screen, select the menu command **Window > Arrange > Horizontally**.

To arrange all the displayed windows from left to right on the screen, select the menu command **Window > Arrange > Vertically**.

5.5.8 Saving and Restoring the Window Arrangement

The STEP 7 applications have a feature which enables you to save the current window arrangement and restore it at a later stage. You can make the setting using the menu command **Options > Customize** in the "General" tab.

What Is Saved?

When you save the window layout the following information is recorded:

- Position of the main window
- Opened projects and libraries and their respective window positions
- Order of any cascaded windows

Note

The window content of online projects, the content of the "Accessible Nodes" window, and the content of the "S7 Memory Card" window are not saved.

Saving the Window Layout

To save the current window arrangement, select the menu command **Window > Save Settings**.

Restoring the Window Layout

To restore the saved window arrangement, select the menu command **Window > Restore Settings**.

Note

When you restore a window, only the part of the hierarchy containing the object that was selected when the window arrangement was saved is displayed in detail.

5.6 Keyboard Operation

International Key Names	German Key Names
HOME	POS1
END	ENDE
PAGE UP	BILD AUF
PAGE DOWN	BILD AB
CTRL	STRG
ENTER	Eingabetaste
DEL	ENTF
INSERT	EINFG

5.6.1 Key Combinations for Menu Commands

Every menu command can be selected by typing a key combination with the ALT key.

Press the following keys in the order shown:

- ALT key
- The letter underlined in the menu name you require (for example, ALT, F for the menu "File" - if the menu "File" is included in the menu bar). The menu is opened.
- The letter underlined in the menu command you require (for example, N for the menu command "New"). If the menu command has a submenu, the submenu is also opened. Proceed as above until you have selected the whole menu command by typing the relevant letters.

Once you have entered the last letter in the key combination, the menu command is executed.

Examples:

Menu Command Key Combination

File > Archive ALT, F, A

Window > Arrange > Cascade ALT, W, A, C

Shortcuts for Menu Commands

Command		Shortcut
New	(File Menu)	CTRL+N
Open	(File Menu)	CTRL+O
Save as	("File" Menu)	CTRL+S
Print > Object Table	("File" Menu)	CTRL+P
Print > Object Content	("File" Menu)	CTRL+ALT+P
Exit	("File" Menu)	ALT+F4
Cut	("Edit" Menu)	CTRL+X
Copy	("Edit" Menu)	CTRL+C
Paste	("Edit" Menu)	CTRL+V
Delete	("Edit" Menu)	DEL
Select All	("Edit" Menu)	CTRL+A
Rename	("Edit" Menu)	F2
Object Properties	("Edit" Menu)	ALT+RETURN
Open Object	("Edit" Menu)	CTRL+ALT+O
Compile	("Edit" Menu)	CTRL+B
Download	(PLC Menu)	CTRL+L
Diagnostics/Setting > Module Status	("PLC" Menu)	CTRL+D
Diagnostics/Setting > Operating Mode	("PLC" Menu)	CTRL+I
Update	("View" Menu)	F5
Updates the status display of the visible CPUs in the online view		CTRL+F5
Customize	("Options" Menu)	CTRL+ALT+E
Reference Data > Show	("Options" Menu)	CTRL+ALT+R
Arrange > Cascade	(Window Menu)	SHIFT+F5
Arrange > Horizontally	(Window Menu)	SHIFT+F2
Arrange > Vertically	(Window Menu)	SHIFT+F3
Context-Sensitive Help	(Help Menu)	F1 (If there is a current context, for example, a selected menu command, the relevant help topic is opened. Otherwise the help contents page is displayed.)

5.6.2 Key Combinations for Moving the Cursor

Moving the Cursor in the Menu Bar/Pop-Up Menus

To	Press
move to the menu bar	F10
move to the pop-up menu	SHIFT+F10
move to the menu that contains the letter or number underlined which you typed in	ALT+underlined character in a menu title
select the menu command whose underlined letter or number corresponds to the letter you have typed	Underlined character in the menu command
move one menu command to the left	LEFT ARROW
move one menu command to the right	RIGHT ARROW
move one menu command up	UP ARROW
move one menu command down	DOWN ARROW
activate the selected menu command	ENTER
deselect the menu name or close the open menu and return to the text	ESC

Moving the Cursor When Editing Text

To move	Press
one line up or one character to the left in a text consisting of only one line	UP ARROW
one line down or one character to the right in a text consisting of only one line	DOWN ARROW
one character to the right	RIGHT ARROW
one character to the left	LEFT ARROW
one word to the right	CTRL+RIGHT ARROW
one word to the left	CTRL+LEFT ARROW
to the beginning of the line	HOME
to the end of the line	END
to the previous screen	PAGE UP
to the next screen	PAGE DOWN
to the beginning of the text	CTRL+HOME
to the end of the text	CTRL+END

Moving the Cursor When Editing Tables

To move	Press
One row up	UP ARROW
One row down	DOWN ARROW
One character or cell to the left	RIGHT ARROW
One character or cell to the right	LEFT ARROW
To the beginning of the row	CTRL+RIGHT ARROW
To the end of the row	CTRL+LEFT ARROW
To the beginning of the cell	HOME
To the end of the cell	END
To the previous screen	PAGE-UP
To the next screen	PAGE-DOWN
To the beginning of the table	CTRL+HOME
To the end of the table	CTRL+END
In the symbol table only: to the "Symbol" column	SHIFT+HOME
In the symbol table only: to the "Comment" column	SHIFT+END

Moving the Cursor in Dialog Boxes

To	Press
move from one input box to the next (from left to right and from top to bottom)	TAB
move one input box in the reverse direction	SHIFT+TAB
move to the input box or option that contains the letter or number underlined which you typed in	ALT+underlined character in a menu title
select in a list of options	an arrow key
open a list of options	ALT+DOWN ARROW
select or deselect an item in a list	SPACEBAR
confirm the entries and close the dialog box ("OK" button)	ENTER
close the dialog box without saving the changes ("Cancel" button)	ESC

5.6.3 Key Combinations for Selecting Text

To select or deselect text	Press
one character at a time to the right	SHIFT+RIGHT ARROW
one character to the left	SHIFT+LEFT ARROW
to the beginning of a comment line	SHIFT+HOME
to the end of a comment line	SHIFT+END
one row in a table	SHIFT+SPACE
one line of text up	SHIFT+UP ARROW
one line of text down	SHIFT+DOWN ARROW
to the previous screen	SHIFT+PAGE UP
to the next screen	SHIFT+PAGE DOWN
the text to the beginning of the file	CTRL+SHIFT+HOME
the text to the end of the file	CTRL+SHIFT+END

5.6.4 Key Combinations for Access to Online Help

To	Press
open the Help	F1 (If there is a current context, for example, a selected menu command, the relevant help topic is opened. Otherwise the help contents page is displayed.)
activate the question mark symbol for context-sensitive help	SHIFT+F1
close the Help window and return to the application	ALT+F4

5.6.5 Key Combinations for Toggling between Windows

To	Press
toggle between the panes in a window	F6
return to the previous pane, if there is no dockable window	Shift+F6
toggle between the document window and a dockable window in the document (for example, variable declaration window). If there are no dockable windows, you can use this key combination to return to the previous pane.	Shift+F6
toggle between document windows	Ctrl+F6
return to the previous document window	Shift+Ctrl+F6
toggle between non-document windows (application framework and dockable windows in the application framework; when you return to the framework, this key combination activates the document window that was last active)	Alt+F6
return to the previous non-document window	Shift+Alt+F6
close the active window	Ctrl+F4

6 Setting Up and Editing the Project

6.1 Project Structure

Projects are used to store the data and programs which are created when you put together an automation solution. The data collected together in a project include:

- Configuration data on the hardware structure and parameters for modules,
- Configuration data for communication in networks, and
- Programs for programmable modules.

The main task when you create a project is preparing these data for programming.

Data are stored in a project in object form. The objects in a project are arranged in a tree structure (project hierarchy). The display of the hierarchy in the project window is similar to that of the Windows Explorer. Only the object icons have a different appearance.


The top end of the project hierarchy is structured as follows:

1. 1st Level: Project
2. 2nd Level: Subnets, stations, or S7/M7 programs
3. 3rd Level: depends on the object in level 2.

Project Window


The project window is split into two halves. The left half shows the tree structure of the project. The right half shows the objects that are contained in the object open in the left half in the selected view (large symbols, small symbols, list, or details).

Click in the left half of the window on the box containing a plus sign to display the full tree structure of the project. The resulting structure will look something like the following figure.



At the top of the object hierarchy is the object "S7_Pro1" as the icon for the whole project. It can be used to display the project properties and serves as a folder for networks (for configuring networks), stations (for configuring the hardware), and for S7 or M7 programs (for creating software). The objects in the project are displayed in the right half of the project window when you select the project icon. The objects at the top of this type of object hierarchy (libraries as well as projects) form the starting point in dialog boxes used to select objects.

Project View



You can display the project structure for the data available on the programming device in the component view "offline" and for the data available on the programmable control system in the component view "online" in project windows.

An additional view you can set is available if the respective optional package is installed: the plant view.

Note

Configuring hardware and networks can only be done in the "offline" view.

6.2 What You Should Know About Access Protection

As of STEP 7 V5.4, you have the option of restricting access to projects and libraries by assigning a passwords to them. In order to do this, you must have installed "SIMATIC Logon".

You can also enable, disable and display a change log.

If SIMATIC Logon is installed on your computer, you will have access to the following menu commands in the SIMATIC Manager. You can use these commands to manage access protection for a project or library:

- Access Protection, Enable
- Access Protection, Disable
- Access Protection, Manage Users
- Access Protection, Adjust in Multiproject
- Remove Access Protection und Change Log

To enable access protection, go to the SIMATIC Manager and select the **Options > Access Protection, Enable** menu command. This menu command opens a dialog box in which you can enable access protection by assigning a

project password. Once the password has been assigned, this password will have to be entered before the project or library concerned can be edited.

The **Remove Access Protection and Change Log** menu command removes access protection as well as the change log for a password-protected project or library. After having removed the access protection you can once again edit projects with a STEP 7 version prior to V5.4.

Note

- In order to enable or disable access protection, you must be authenticated in SIMATIC Logon as a project administrator.
 - When access protection is first enabled, the project format is changed. You will receive a message informing you that the changed project can no longer be edited with older versions of STEP 7.
 - The **Options >Access Protection >Remove Access Protection and Change Log** function allows projects or libraries to be once again edited with a STEP 7 version prior to V5.4. However, in this case, you will lose information about the users who have access to the project or library as well as all change logs.
 - The currently logged on user is shown in the status bar of the SIMATIC Manager.
 - The currently logged on project editor who enables the access protection is entered as the project administrator and is then prompted to assign a project password.
 - To open an access-protected project, you must be authenticated in SIMATIC Logon as a project administrator or project editor. Access protection must also be enabled or you must know the project password..
-

6.3 What You Should Know About The Change Log

As of STEP 7 V5.4, after setting up access protection for projects and libraries, you have the option of keeping a change log that records online actions.

Examples:

- Activate / Deactivate / Configure the access protection and change log
- Open / Close projects and libraries
- Download to PLC (system data)
- Selected operations for loading and copying blocks
- Activities for changing the operating mode
- Clear/Reset

You can display the change log and enter comments such as those explaining changes that you have made. For this functionality to be available, "SIMATIC Logon" must be installed.

To enable the change log, go to the SIMATIC Manager and select the **Options > Change Log, Enable** menu command. After you have enabled the change log, you can view it (menu command: **Options > Change Log, Display**) or disable it (menu command: **Options > Change Log, Disable**).

When you click on an object in the project structure (such as a project folder or subordinate station), the associated change log is displayed.

Note

- The **Options > Access Protection > Remove Access Protection and Change Log** function allows projects or libraries to be once again edited with a STEP 7 version prior to V5.4. However, in this case, you will lose information about the users who have access to the project or library as well as all change logs.
 - To execute this function, you must be authenticated as a project administrator in "SIMATIC Logon", and access protection for this project must be enabled
-

6.4 Using Foreign-Language Character Sets

As of STEP 7 V5.3 SP2, you can enter texts in foreign languages in projects and libraries even if these languages do not match the language that has been set for STEP 7. To do this, the corresponding Windows language must be set in the Control Panel of the operating system. This makes it possible, for example, to operate STEP 7 in the STEP 7 language English on a Chinese-language version of Windows but still allows Chinese text be entered.

In this case, the following types and options for language settings must be distinguished:

Windows Language Setting

This setting is made in the Windows Control Panel. Texts pertaining to the operating system are displayed in the language selected, and you can enter texts in foreign-language character strings.

Project Language

The project language is the language that is set in the Window Control Panel when a project is first created. Once chosen, this project language cannot be changed. However, with the "language-neutral" setting it is still possible to open a project on computers with other language settings in Windows. Before changing the project language to "language-neutral", make sure that only characters from the English-language character set (ASCII characters 0x2a - 0x7f) were previously used in the project when entering text.

To find out the project language for a project or a library, select the **Edit > Object Properties** menu command. In the dialog box that is then displayed you can also select the "Can be opened under any Windows language setting (language-neutral)" option.

If you copy a project by means of the **Save As** menu command and the project language is not the same as the current Windows language setting, you can then change the project language in the copied project to the language currently set in Windows. This will be useful in cases such as when you want to create language-specific variants of a project. In this case, the master project should contain only characters from the English-language character set (ASCII characters 0x2a - 0x7f). This will ensure that data corruption will not occur when the language-specific project is edited further in the respective language.

STEP 7 Language

The STEP 7 language is the one that you set in the SIMATIC Manager by using the **Options > Customize** menu command. This language is the one use for interface elements, menu command, dialog boxes and error messages in STEP 7.

If you are using another Windows language such as German, English, French, Italian or Spanish, you can ensure that the STEP 7 interface is correctly displayed by selecting English as the STEP 7 language.

Rules

If you will be editing your projects or libraries on computers that have different language settings, be sure to observe the following "rules and regulations" to prevent incompatibilities or data corruption from occurring when using a foreign-language character set:

- Install STEP 7 only in folders with names that contain the characters of the English character set (ASCII characters 0x2a - 0x7f).
- Only use project names and project paths with names that contain the characters of the English character set (ASCII characters 0x2a - 0x7f). For example, if you use German umlauts, Cyrillic or Chinese characters, then the project can only be opened on computers that have a compatible language setting in Windows.
- In multiprojects, only use projects and libraries with the same project language or those that are identified as being language-neutral ones. The multiproject itself is language-neutral.
- When creating libraries, always make them language-neutral to ensure that they can be used on computers with different Windows language settings. When assigning names to library projects, entering comments, or creating symbol names, etc. be sure to only use ASCII characters (0x2a - 0x7f) so that the libraries can be used without any problems.
- When importing/exporting hardware configurations or symbol tables, make sure that you only import/export language-compatible files.
- In the names of user-defined attributes, use only characters from the English-language character set (ASCII characters 0x2a - 0x7f).
- If, in an STL source, you are using characters that are not in the English character set (ASCII characters 0x2a - 0x7f) for the TITLE, AUTHOR, FAMILY block properties, then place these entries in single quote marks.

Notes

- If you change or copy projects or libraries that were created on a computer that is identified as being language-neutral with respect to the Windows language setting but is not compatible with the setting on the computer currently being used, data corruption may occur if characters that are not contained in the English character set (ASCII characters 0x2a - 0x7f) were used in the project or library.
For this reason, before editing "foreign" projects or libraries, make sure to check whether the Windows language setting on your computer matches the project language.
 - If you export hardware configurations or symbol tables that are to be imported in another Windows language setting, make sure that only characters from the English-language character set (ASCII characters 0x2a - 0x7f) were previously used and that no other language-specific characters such as German umlauts, Japanese characters or Cyrillic characters are present.
 - Exported hardware configurations or symbol tables that contain language-specific characters such as German umlauts, Japanese characters or Cyrillic characters may only be imported in the same Windows language setting from which they were exported. This means that if you import older symbol tables that might contain such language-specific characters, be sure to check the results carefully: the symbols must be unique, must not contain any question marks or other incorrect characters, and must be plausible.
 - If symbol tables contain special characters that are not defined ("known to") the current Windows language setting, then the question marks or other incorrect characters now part of the symbol names may cause problems and errors when sorting by names and comments.
 - Please note that with symbolic addressing the symbolic names must be written in quotation marks ("`<Symbolic Name>`").
-

Basic Procedure

To be able to enter text in foreign-language character sets in projects and libraries, proceed as follows:

1. In the Windows Control Panel, set the language setting to the language desired.
2. Create a project.
3. Enter the text in foreign-language characters.

For project and libraries that were created before STEP 7 V5.3 SP2, the project language is "not yet specified". In this case, you can select the **Edit > Object Properties** menu command to set the project language to the language currently set in Windows. Before doing so, make sure that the project does not contain any characters that are not defined in ("known to") the current Windows language setting.

6.5 Setting the MS Windows Language

To set the Windows language, proceed as follows:

Setting the Language in Windows XP and Windows Server 2003:

1. To set the desired display language for programs that do not support Unicode, select the following menu command sequence:
Control Panel > Regional and Language Options > Advanced > Language for non-Unicode programs.
2. To set the input language (standard regional settings properties), select the following menu command sequence:
Control Panel > Regional and Language Options > Languages > Details.
3. To set the input language (standard regional settings properties), select the following menu command sequence:
Control Panel > Regional and Language Options > Regional Settings (Standards and Formats).

You can enter texts in the desired language and display them correctly only after you have made all of these settings.

Setting the Language in Windows 2000:

1. To set the desired display language, select the following menu command sequence:
Control Panel > Regional Settings > General > Your locale (location).
2. To set the desired language, select the following menu command sequence:
Control Panel > Regional Settings > General > Set as Default.
3. To set the input language (standard regional settings properties), select the following menu command sequence:
Control Panel > Regional Settings > Input Locales.

You can enter texts in the desired language and display them correctly only after you have made all of these settings.

6.6 Setting Up a Project

6.6.1 Creating a Project

To construct a solution to your automation task using the framework of a project management, you will need to create a new project. The new project is created in the directory you set for projects in the "General" tab when you selected the menu command **Options > Customize**.

Note


The SIMATIC Manager allows names that are longer than eight characters. The name of the project directory is, however, cut off to eight characters. Project names must therefore differ in their first eight characters. The names are not case-sensitive.

You will find a step-by-step guide to creating a project under Creating a Project Manually or under Creating a Project Using the Wizard.

Creating a Project Using the Wizard

The easiest way to create a new project is using the "New Project" wizard. Use the menu command **File > "New Project" Wizard** to open the wizard. The wizard prompts you to enter the required details in dialog boxes and then creates the project for you. In addition to the station, CPU, program folder, source file folder, block folder, and OB1 you can even select existing OBs for error and alarm processing.

The following figure shows an example of a project created with the wizard.



Creating a Project Manually

You can also create a new project using the menu command **File > New** in the SIMATIC Manager. It already contains the "MPI Subnet" object.

Alternative Procedures

When editing a project, you are flexible as to the order in which you perform most of the tasks. Once you have created a project, you can choose one of the following methods:

- First configure the hardware and then create the software for it, or
- Start by creating the software independent of any configured hardware.

Alternative 1: Configure the Hardware First

If you want to configure the hardware first, proceed as described in Volume 2 of the Configuring Hardware with STEP 7 Manual. When you have done this, the "S7 Program" and "M7 Program" folders required to create software are already inserted. Then continue by inserting the objects required to create programs. Then create the software for the programmable modules.

Alternative 2: Create Software First

You can also create software without first having to configure the hardware; this can be done later. The hardware structure of a station does not have to be set for you to enter your programs.

The basic procedure is as follows:

1. Insert the required software folders (S7/M7 Program without a Station or CPU) in your project.
Here you are simply deciding whether the program folder is to contain S7 hardware or M7 hardware.
2. Then create the software for the programmable modules.
3. Configure your hardware.
4. Once you have configured the hardware, you can link the M7 or S7 program to a CPU.

6.6.2 Inserting Stations

In a project, the station represents the hardware structure of a programmable controller and contains the data for configuring and assigning parameters to individual modules.

New projects created with the "New Project" wizard already contain a station. Otherwise you can create the station using the menu command **Insert > Station**.

You can choose between the following stations:

- SIMATIC 300 station
- SIMATIC 400 station
- SIMATIC H station
- SIMATIC PC station
- PC/programming device
- SIMATIC S5
- Other stations, meaning non- SIMATIC S7/M7 and SIMATIC S5

The station is inserted with a preset name (for example, SIMATIC 300 Station(1), SIMATIC 300 Station(2), etc.). You can replace the name of the stations with a relevant name, if you wish.

You will find a step-by-step guide to inserting a station under Inserting a Station.

Configure the Hardware

When you configure the hardware you specify the CPU and all the modules in your programmable controller with the aid of a module catalog. You start the hardware configuration application by double-clicking the station.

For each programmable module you create in your configuration, an S7 or M7 program and a connection table ("Connections" object) are created automatically once you have saved and exited the hardware configuration. Projects created with the "New Project" wizard already contain these objects.

You will find a step-by-step guide to configuring under Configuring the Hardware, and detailed information under Basic Steps for Configuring a Station.

Creating a Connection Table

An (empty) connection table ("Connections" object) is created automatically for each programmable module. The connection table is used to define communication connections between programmable modules in a network. When it is opened, a window is displayed containing a table in which you define connections between programmable modules.

You will find detailed information under Networking Stations within a Project.

Next Steps

Once you have created the hardware configuration, you can create the software for your programmable modules (Also refer to Inserting a S7/M7 Program).

6.6.3 Inserting an S7/M7 Program

The software for programmable modules is stored in object folders. For SIMATIC S7 modules this object folder is called "S7 Program," for SIMATIC M7 modules it is called "M7 Program."

The following figure shows an example of an S7 program in a programmable module in a SIMATIC 300 station.



Existing Components

An S7/M7 program is created automatically for each programmable module as a container for the software:

The following objects already exist in a newly created S7 program:

- Symbol table ("Symbols" object)
- "Blocks" folder for containing the first block
- "Source Files" folder for source files

The following objects already exist in a newly created M7 program:

- Symbol table ("Symbols" object)
- "Blocks" folder

Creating S7 Blocks

You want to create Statement List, Ladder Logic, or Function Block Diagram programs. To do this, select the existing "Blocks" object and then select the menu command **Insert > S7 Block**. In the submenu, you can select the type of block you want to create (such as a data block, User-defined Data Type (UDT), function, function block, organization block, or variable table).

You can now open the (empty) block and start entering the Statement List, Ladder Logic, or Function Block Diagram program. You will find more information on this in Basic Procedure for Creating Logic Blocks and in the Statement List, Ladder Logic, and Function Block Diagram manuals.

Note

The object "System Data" (SDB) which may exist in a user program was created by the system. You can open it, but you cannot make changes to it for reasons of consistency. It is used to make changes to the configuration once you have loaded a program and to download the changes to the programmable controller.

Using Blocks from Standard Libraries

You can also use blocks from the standard libraries supplied with the software to create user programs. You access the libraries using the menu command **File > Open**. You will find further information on using standard libraries and on creating your own libraries in Working with Libraries and in the online help.

Creating Source Files/CFC Charts

You want to create a source file in a particular programming language or a CFC chart. To do this, select the "Source Files" or "Charts" object in the S7 program and then select the menu command **Insert > S7 Software**. In the submenu, you can select the source file that matches your programming language. You can now open the empty source file and start entering your program. You will find more information under Basic Information on Programming in STL Source Files.

Creating Programs for M7

You want to create programs for the operating system RMOS for a programmable module from the M7 range. To do this, select the M7 program and then select the menu command **Insert > M7 Software**. In the submenu, you can select the object that matches your programming language or operating system. You can now open the object you created to access the relevant programming environment.

Creating a Symbol Table

An (empty) symbol table ("Symbols" object) is created automatically when the S7/M7 program is created. When you open the symbol table, the "Symbol Editor" window opens displaying a symbol table where you can define symbols. You will find more information under Entering Multiple Shared Symbols in the Symbol Table.

Inserting External Source Files

You can create and edit source files with any ASCII editor. You can then import these files into your project and compile them to create individual blocks.

The blocks created when the imported source file is compiled are stored in the "Blocks" folder.

You will find more information under Inserting External Source Files.

S7/M7 Program without a Station or CPU

6.7 Editing a Project

Opening a Project

To open an existing project, enter the menu command **File > Open**. Then select a project in the dialog boxes that follow. The project window is then opened.

Note

If the project you require is not displayed in the project list, click on the "Browse" button. In the browser you can then search for other projects and include any projects you find in the project list. You can change the entries in the project list using the menu command **File > Manage**.

Copying a Project

You copy a project by saving it under another name using the menu command **File > Save As**.

You copy parts of a project such as stations, programs, blocks etc. using the menu command **Edit > Copy**.

You will find a step-by-step guide to copying a project under Copying a Project and Copying Part of a Project.

Deleting a Project

You delete a project using the menu command **File > Delete**.

You delete parts of a project such as stations, programs, blocks etc. using the menu command **Edit > Delete**.

You will find a step-by-step guide to deleting a project under Deleting a Project and Deleting Part of a Project.

6.7.1 Checking Projects for Software Packages Used

If a project that you are editing contains objects that were created with another software package, this software package is required to edit this project.

No matter what programming device you are using to work with multiprojects, projects or libraries, STEP 7 assists you by showing you what software packages and versions are required to do so.

This information on the software packages required is complete under the following conditions:

- If the project (or all projects in a multiproject) or library was created in STEP 7 as of V5.2.
- If you yourself have checked the project for any software packages used in creating it. To do this, first go to the SIMATIC Manager and select the project concerned. Then select the menu command **Edit > Object Properties**. In the dialog box that is displayed, select the "Required software packages" tab. The information in this tab will tell you whether you should check the project for software packages.

6.8 Managing Multilingual Texts

STEP 7 offers the possibility of exporting text that has been created in a project in one language, having it translated, re-importing it, and displaying it in the translated language.

The following text types can be managed in more than one language:

- Titles and comments
 - Block titles and block comments
 - Network titles and network comments
 - Line comments from STL programs
 - Comments from symbol tables, variable declaration tables, user-defined data types, and data blocks
 - Comments, state names, and transition names in HiGraph programs
 - Extensions of step names and step comments in S7-Graph programs
- Display texts
 - Message texts generated by STEP 7, S7-Graph, S7-HiGraph, S7-PDIAG or ProTool
 - System text libraries
 - User-specific text libraries
 - Operator-relevant texts
 - User texts

Export

Exporting is done for all blocks and symbol tables located under the selected object. An export file is created for each text type. This file contains a column for the source language and a column for the target language. Text in the source language must not be changed.

Import

During import, the contents of the target-language columns (right-hand column) are integrated into the selected object. Only those translations whose source text (exported text) match an existing text in the "Source Language" column are accepted.

Changing Languages

When changing languages, you can choose from all the languages that were specified during import into the selected project. The language change for "Title and Comments" is only applied to the selected object. A language change for "Display Texts" is always applied to the complete project.

Deleting a Language

When a language is deleted all the texts in this language are deleted from the internal database.

One language should always be available as a reference language in your project. This can, for example, be your local language. This language should not be deleted. During exporting and importing always specify this reference language as the source language. The target language can be set as desired.


Reorganize

During reorganization, the language is changed to the language currently set. The currently set language is the language that you selected as the "Language for future blocks". Reorganization only affects titles and comments.

Comment Management

You can specify how comments for blocks should be managed in projects with texts being managed in many languages.

Basic Procedure



6.8.1 Types of Multilingual Texts

For export, a separate file will be created for each type of text. This file will have the text type as its name and the export format as its extension (texttype.format: for example, SymbolComment.CSV or SymbolComment.XLS). Files that do not satisfy the naming convention cannot be used as source or target.

The translatable text within a project is divided into the following text types:

Text Type	Description
BlockTitle	Block title
BlockComment	Block comments
NetworkTitle	Network title
NetworkComment	Network comments
LineComment	Line comments in STL
InterfaceComment	Var_Section comments (declaration tables in code blocks) and UDT comments (user-defined data types) and Data block comments
SymbolComment	Symbol comments
S7UserTexts	Texts entered by the user which can be output on display devices
S7SystemTextLibrary	Texts of system libraries which are integrated into messages can be updated dynamically during runtime, and displayed on the PG or other display devices
S7UserTextLibrary	Texts of user libraries which are integrated into messages can be updated dynamically during runtime, and displayed on the PG or other display devices

Text Type	Description
HiGraphStateName	S7-HiGraph State name
HiGraphStateComment	
HiGraphTansionName	Transition name
HiGraphTransitionComment	Transition comment
S7GraphStateName	S7-Graph Step name extension
S7GraphStateComment	

Editors in other optional packages (such as ProTool, WinCC, etc.) may have other application-specific text types that are not described here.

6.8.2 Structure of the Export File

The export file is structured as follows:

Example:

\$_Languages		
7(1) English (USA)	9(1) English (USA)	
\$_Type(NetworkTitle)		
//Maximum text length: 64 characters		
//\$_Export on 16.11.2005 13:14:34		
First character sequence to be translated	Translation	test\S7 Program(1)\Blocks\OB1
Second character sequence to be translated	Translation	test\S7 Program(1)\Blocks\OB1
Character sequence that is not to be displayed in the translation	\$_hide	test\S7 Program(1)\Blocks\OB1



Fundamentally, the following applies:

- The following may not be changed, overwritten, or deleted:
 - Fields beginning with "\$_" (these are keywords)
 - The numbers for the language (in the example above: 9(1) for the source language English (USA) and 7(1) for the target language German).
- Each file holds the text for just a single test type. In the example, the text type is NetworkTitle (\$_Type(NetworkTitle)). The rules for the translator who will edit this file are contained in the introductory text of the export file itself.
- Additional information regarding the text or comments must always appear before the type definition (\$_Type...) or after the last column.

Note

If the column for the target language has been overwritten with "512(32) \$_Undefined," no target language was specified when the file was exported. To obtain a better overview, you can replace this text with the target language, for example, "9(1) English (US)" When importing the translated files, you must verify the proposed target language and, if necessary, select the correct language.

You can hide text not to be displayed in the target language by entering the keyword `$_hide`. This does not apply to comments on variables (InterfaceComment) and to symbols (SymbolComment).

Export File Format

You specify the format in which export files are to be saved.

If you have decided to use CSV format, you must keep in mind when editing in Excel that a CSV file can be only opened properly in Excel if the Open dialog is used. **Opening a CSV file by double-clicking in Explorer often results in an unusable file.** You will find it easier to work with CSV files in Excel if you use the following procedure:

1. Open the export file in Excel
2. Save the files as XLS files
3. Translate the text in the XLS files
4. Save the XLS files in Excel in CSV format.

Note

Export files may not be renamed.

6.8.3 Managing User Texts Whose Language Font is Not Installed

You can export user texts whose language font is not installed in your operating system, have them translated and then import them back in and save them for use in your project.

However, such texts can only be displayed on a computer that has the appropriate language font installed on it.

For example, if you have user texts that have to be translated into Russian and do not have a Cyrillic font installed on your operating system, proceed as follows:

1. Export the user text to be translated with the source language "English" and target language "Russian".
2. Send the export files to the translator, who will definitely have a Cyrillic font available.
3. Import the translated export files.
Result: The project is now available in English and Russian on your computer.
4. Save the whole project and send it to the customer who will use the Russian texts and will thus have a Cyrillic font available to display them.

6.8.4 Information on the Log File

Error messages and warnings that appear when working with text managed in many languages are output in a log file (TXT format). This file is stored in the same folder as the export files.

In general, the messages are self-explanatory. Any further explanations are listed below:

Warning

The text 'xyz' is already present in file 'xyz'. Any further occurrence of this text will be ignored.

Explanation

Regardless of its language, a text is used as the basis for the translation. If an identical text is used for different terms in more than one language or more than once in one language, it can no longer be uniquely identified and will thus not be translated.

Example:

\$ Languages	
7(1) Deutsch (Deutschland)	9(1) English (USA)
kein	none
keine	none
keiner	none

/
/

Source language
Target language

This only applies to titles and comments.

Remedy

Rename the texts concerned in the exported file (in the example, a single German word must be used instead of three different ones), and then re-import the texts.

6.8.5 Optimizing the Source for Translation

You can prepare the source material for translation by combining different terms and expressions.

Example

Before preparation (export file):

\$_Languages		
9(1) English (USA)	9 (1) English (USA)	
\$_Type(SymbolComment)		
Auto-enab.		
Automatic enable		
Auto-enable		

/ Source Language
 / Target Language

Combining to a single expression:

\$_Languages		
9 (1) English (USA)	9 (1) English (USA)	
\$_Type(SymbolComment)		
Auto-enab.	Auto-enable	
Automatic enable	Auto-enable	
Auto-enable	Auto-enable	

/ Source Language
 / Target Language

After preparation (that is, after import and subsequent export):

\$_Languages		
9 (1) English (USA)	9 (1) English (USA)	
\$_Type(SymbolComment)		
Auto-enable	Auto-enable	

/ Source Language
 / Target Language

6.8.6 Optimizing the Translation Process

If you have projects where the structure and text are similar to a previous project, you can optimize the translation process.

In particular, the following procedure is recommended for projects that were created by copying and then modifying.

Prerequisite

There must be an existing translated export target.

Procedure

1. Copy the export files into the project folder for the new project to be translated.
2. Open the new project and export the text (menu command **Options > Manage Multilingual Texts > Export**). Since the export target already exists, you will be asked whether the export target should be extended or overwritten.
3. Click on the Add button.
4. Have the export files translated (only new text needs to be translated).
5. Then import the translated files.

6.9 Micro Memory Card (MMC) as a Data Carrier

6.9.1 What You Should Know About Micro Memory Cards (MMC)

Micro Memory Cards (MMC) are plug-in memory cards, for example, for a CPU 31xC or an IM 151/CPU (ET 200S). Their most distinguishing feature is the highly compact design.

A new memory concept has been introduced for MMCs. It is briefly described below.

Content of the MMCs

The MMC serves as both the load memory and a data storage device (data carrier).

MMC as Load Memory

The MMCs contain the complete **load memory** for an MMC-compatible CPU. The load memory contains the program with the blocks (OBs, DBs, FCs, ...) as well as the hardware configuration. The contents of the load memory influence the functioning of the CPU. In the MMC's function as load memory, blocks and the hardware configuration with loading functions can be transferred from it (i.e. **Download** to CPU). Blocks downloaded to the CPU take effect immediately; however, the hardware configuration does so only after the CPU is restarted.

Response to Memory Reset

The blocks stored on the MMC are retained after a memory reset.

Loading and Deleting

You can overwrite the blocks on the MMC.

You can erase the blocks on the MMC.

You cannot restore overwritten or erased blocks.

Accessing Data Blocks on the MMC

On the MMC, you can use data blocks and data block contents to handle larger quantities of data or data rather scarcely required in the user program. New system operations are available for that purpose:

- SFC 82: creating data blocks in the load memory
- SFC 83: reading from the data block in the load memory
- SFC 84: writing to a data block in the load memory

MMC and Password Protection

If a CPU (i.e. a CPU in the 300-C family) that is fitted with a Micro Memory Card (MMC) is password-protected, then the user will also be prompted to enter this password when opening this MMC in the SIMATIC Manager (on a programming device/PC).

Displaying Memory Assignment in STEP 7

The display of the load memory assignment in the module status dialog ("Memory" tab) shows both the EPROM and the RAM area.

Blocks on MMCs show a 100% EPROM behavior.

6.9.2 Using a Micro Memory Card as a Data Carrier

A SIMATIC Micro Memory Card (MMC) can be used with STEP 7 in the same manner as any other type of external data storage medium.

After you have determined that the MMC has enough capacity to accommodate all the data to be stored, you can transfer any data visible in the operating system's file explorer to the MMC.

In this way, you can make additional drawings, service instructions and functional descriptions pertaining to your plant available to other personnel.

6.9.3 Memory Card File

Memory Card files (*.wld) are generated for the

- Software PLC **WinLC** (WinAC Basis and WinAC RTX) and
- SlotPLCs **CPU 41x-2 PCI** (WinAC Slot 412 and WinAC Slot 416).

The blocks and system data for a WinLC or CPU 41x-2 PCI can be saved in a Memory Card file as in an S7-Memory Card. The contents of these files then correspond to the contents of a corresponding Memory Card for a S7-CPU.

This file can then be downloaded by a menu command of the operating panel of the WinLC or CPU 41x-2 PCI into their download memories, corresponding to the downloading of the user program with STEP 7.

In the case of the CPUs 41x-2 PCI this file can be downloaded automatically when the PC operating system is started up, if the CPU 41x-2 PCI is not buffered and is only operated with a RAM Card ("Autoload" function).

Memory Card files are "normal" files in the sense of Windows, which can be moved, deleted or transported with a data medium with the Explorer.

For further information please refer to the corresponding documentation of the WinAC products.

6.9.4 Storing Project Data on a Micro Memory Card (MMC)

With STEP 7 you can store the data for your STEP 7 project as well as any other kind of data (such as WORD or Excel files) on a SIMATIC Micro Memory Card (MMC) in a suitable CPU or a programming device (PG)/PC. This allows you to access project data with programming devices that do not have the project saved on them.

Requirements

You can only store project data on an MMC if it is inserted in the slot of a suitable CPU or a programming device (PG)/PC and there is an online connection established.

Be sure that the MMC has enough capacity to accommodate all the data to be stored on it.

Data that can be stored on an MMC

After you have determined that the MMC has enough capacity to accommodate all the data to be stored, you can transfer all data visible in the operating system's file explorer to the MMC. These data can include the following:

- Complete project data for STEP 7
- Station configurations
- Symbol tables
- Blocks and sources
- Texts managed in many languages
- Any other kinds of data, such as WORD or Excel files

7 Editing Projects with Different Versions of STEP 7

7.1 Editing Version 2 Projects and Libraries

Version V5.2 of STEP 7 **no longer** supports **Changes in V2 Projects**. When you edit V2 projects or libraries, inconsistencies can occur such that V2 projects or libraries can no longer be edited with older versions of STEP 7.

In order to continue to edit V2 projects or libraries, a STEP 7 version older than V5.1 must be used.

7.2 Expanding DP Slaves That Were Created with Previous Versions of STEP 7

Constellations That Can Be Formed by Importing New *.GSD Files

New DP slaves can be accepted by the HW Config if you install new device database files (*.GSD files) into the Hardware Catalog. After installation, they are available in the Other Field Devices folder.

You cannot reconfigure or expand a modular DP slave in the usual manner if all of the following conditions exist:

- The slave was configured with a previous version of STEP 7.
- The slave was represented in the Hardware Catalog by a type file rather than a *.GSD file.
- A new *.GSD file was installed over the slave.

Remedy

If you want to use the DP slave with **new modules** that are described in the *.GSD file:

- Delete the DP slave and configure it again. Then the DP slave is described completely by the *.GSD file, not by the type file.

If you do **not want to use any new modules** that are described only in the *.GSD file:

- Under PROFIBUS-DP in the Hardware Catalog window, select the "Other FIELD DEVICES/Compatible PROFIBUS-DP Slaves" folder. STEP 7 moves the "old" type files into this folder when they are replaced by new *.GSD files. In this folder you will find the modules with which you can expand the already configured DP slave.

Constellation after Replacement of Type Files by GSD Files in STEP 7 V5.1 Service Pack 4

As of STEP 7 V5.1, Service Pack 4, the type files have been either updated or largely replaced by GSD files. This replacement only affects the catalog profiles supplied with STEP 7, not any catalog profiles that you may have created yourself.

DP slaves whose properties were previously determined by type files and are now determined by GSD files are still located in the same place in the hardware catalog.

The "old" type files were not deleted but moved to another place in the hardware catalog. They are now located in the catalog folder "**Other field devices\Compatible PROFIBUS DP slaves\...**".

Expanding an Existing DP Configuration with STEP 7, as of V5.1 Service Pack 4

If you edit a project that was created with a previous version of STEP 7 (earlier than V5.1, SP4) and you want to expand a modular DP slave, then you cannot use the modules or submodules taken from the usual place in the hardware catalog. In this case, use the DP slave found at "**Other FIELD DEVICES\Compatible PROFIBUS DP slaves\...**".

Editing a DP Configuration with an Earlier Version of STEP 7 V5.1, SP4)

If you configure an "updated" DP slave with STEP 7 as of V5.1, Service Pack 4 and then edit the project with a previous version of STEP 7 (earlier than STEP 7 V5.1, SP4), you will not be able to edit this DP slave since the GSD file used is unknown to the previous version.

Remedy: You can install the required GSD file in the previous version of STEP 7. In this case, the GSD file is stored in the project. If the project is subsequently edited with the current STEP 7 version will use the newly installed GSD file for the configuration.

7.3 Editing Current Configurations with Previous Versions of STEP 7

Configuring Direct Data Exchange (Lateral Communication)

Configuring direct data exchange with a DP master **without** a DP master system:

- Not possible with STEP7 V5.0, Service Pack 2 (or older version)
- Possible with STEP7 V5.0, as of Service Pack 3 and as of STEP 7 V5.1

If you save a DP master without its own DP master system with configured assignments for direct data exchange and you continue to edit this project with an older version of STEP 7 V5 (STEP 7 V5.0, Service Pack 2 (or older)), the following effects can occur:

- A DP master system is displayed with slaves that are used for a STEP 7-internal data storage area of the assignments for direct data exchange. These DP slaves do not belong to the displayed DP master system.
- You cannot connect a new or an orphaned DP master system to this DP master.

Online Connection to the CPU by Means of a PROFIBUS-DP Interface

Configuring the PROFIBUS-DP interface **without** a DP master system:

- STEP7 V5.0, Service Pack 2 (or older): a connection to the CPU by means of this interface is not possible.
- As of STEP7 V5.0, Service Pack 3: During compilation, system data for the PROFIBUS-DP interface are generated; a connection to the CPU by means of this interface is possible after downloading.

7.4 Appending SIMATIC PC Configurations of Previous Versions

PC Configurations of STEP 7 V5.1 Projects (up to SP 1)

As of STEP 7 V5.1, Service Pack 2 you can download communications to the PC station in the same way as to an S7-300 or S7-400 station (without having to take the roundabout via configuration file). Nevertheless, a configuration file is always generated during a storing or compiling operation in order to enable the transmission of the configuration to the target PC station using this method.

This bears the consequence that "older" PC stations cannot interpret some of the information included in the newly generated configuration files. STEP 7 automatically adapts itself to this circumstance:

- If you create a **new** SIMATIC PC station configuration with STEP 7 as of V5.1, Service Pack 2, STEP 7 assumes that the target PC station was configured with the help of SIMATIC NET CD as of 7/2001, that is, under the presumption that S7RTM (Runtime Manager) is installed. The configuration files are generated in such a way that they can be interpreted by a "new" PC station.
- If you append a SIMATIC PC station configuration of a previous version (for example, the PC station was configured with STEP 7 V5.1, Service Pack 1), STEP 7 does **not** presume that the target PC station was configured with the help of SIMATIC NET CD as of 7/2001. Those configuration files are then generated in such a way that they can be interpreted by an "old" PC station.

If this default behavior does not match your requirements, you can modify it as described below:

Setting in the Context Menu "Configuring Hardware ":

1. Open the PC station hardware configuration
2. Right-click on the station window (white area)
3. Select the context-sensitive menu "Station Properties"
4. Check or clear the "Compatibility" checkbox.

Setting in the Context Menu "Configuring Networks"

1. Open the network configuration
2. Highlight the PC station
3. Select the menu command **Edit > Object properties**
4. In the dialog, select the "Configuration" tab
5. Check or clear the "Compatibility" checkbox.

PC Configurations of STEP 7 V5.0 Projects

You must convert the station if you want to edit a SIMATIC PC station configuration with STEP 7 as of V5.0, Service Pack 3 to configure new components that are only supported by Service Pack 3 or higher:

1. In the SIMATIC Manager, highlight the SIMATIC PC station and select the menu command **Edit > Object properties**.
2. In the "Functions" tab of the properties dialog, click on the "Expand" button. The SIMATIC PC station is then converted. Now, it can only be edited with STEP 7 V5.0, Service Pack 3 or later versions.

7.5 Displaying Modules Configured with Later STEP 7 Versions or Optional Packages



As of STEP 7 V5.1 Service Pack 3, all modules are displayed, even those that were configured with a later STEP 7 version and are thus unknown to the "older" STEP 7. Modules configured with an optional package are also displayed, even if the required corresponding optional package is not installed on the programming device (PG) used to open the given project.

In previous STEP 7 versions, such modules and their subordinate objects were not displayed. In the current version, these objects are visible and can be edited to certain extent. For example, you can use this function to also change user programs, even if the project was created on another computer running a newer version of STEP 7 and the module (such as a CPU) cannot be configured with the existing earlier STEP 7 version because this module has new properties and new parameters.

The module "unknown" to STEP 7 is displayed as a generic, representative module with the following icon:



If you open the project with the appropriate STEP 7 version or with a compatible optional package, all modules are displayed their standard way and there are no restrictions on editing.

PG with latest STEP 7 / with optional package		PG with older STEP 7 / without optional package
		
	>>>---Project data--->>>	
Represented by "known", latest module		Represents the latest module as an "unknown" module
		

Working with a Representative Module in the SIMATIC Manager

The representative module is visible below the station level. All subordinate objects at this level such as user programs, system data and connection tables are visible and can be downloaded from the SIMATIC Manager.

You also open, edit, compile and load the user program (such as its blocks).

However, the following restrictions apply to projects with representative blocks:

- You cannot copy a station containing a representative block.
- In the menu command "Save project as..." the option "with reorganization" cannot be applied completely.
The representative module and all references and subordinate objects of this modules will be missing in the copied and reorganized project (for example, the user program).

Working with a Representative Module in the Hardware Configuration

The representative module is displayed at the slot where it was configured.

You can open this module, but you cannot change its parameters or download to it. The module properties are limited to those given in the "Representative" tab property sheet. The station configuration can not be changed (such as by adding new modules).

Hardware diagnostics (such as opening a station online) are also possible (to a limited extent: new diagnostic options and texts are not recognized.).

Working with a Representative Module in the Network Configuration

The representative module is also displayed in NetPro. In this case, the name of the module on the station is preceded by question mark.

A project with a representative module can only be opened write-protected in NetPro.

If you open the project in write-protected mode, you can display and print the network configuration. You can also obtain the connection status, which will at least contain the information supported by the STEP 7 version being used.

In general, however, you cannot make any changes or save, compile or download them.

Subsequent Installation of Modules

If the module is from a later version of STEP 7 and there is a HW update available for it, you can replace the representative module with the "real" one. Upon opening the station, you receive information on the necessary HW updates or optional packages, and you can install them using the dialog. As an alternative, you can install these modules by selecting the menu command **Options > Install HW Updates**.

8 Defining Symbols

8.1 Absolute and Symbolic Addressing

In a STEP 7 program you work with addresses such as I/O signals, bit memory, counters, timers, data blocks, and function blocks. You can access these addresses in your program absolutely, but your programs will be much easier to read if you use symbols for the addresses (for example, Motor_A_On, or other identifiers according to the code system used within your company or industry). An address in your user program can then be accessed via this symbol.

Absolute Addresses

An absolute address comprises an address identifier and a memory location (for example, Q 4.0, I 1.1, M 2.0, FB21).

Symbolic Addresses

You can make your program easier to read and simplify troubleshooting if you assign symbolic names to the absolute addresses.

STEP 7 can translate the symbolic names into the required absolute addresses automatically. If you would prefer to access ARRAYS, STRUCTs, data blocks, local data, logic blocks, and user-defined data types using symbolic names, you must first assign symbolic names to the absolute addresses before you can address the data symbolically.

You can, for example, assign the symbolic name MOTOR_ON to the address Q 4.0 and then use MOTOR_ON as an address in a program statement. Using symbolic addresses it is easier to recognize to what extent the elements in the program match the components of your process control project.

Note

Two consecutive underline characters (for example, MOTOR__ON) are not permitted in a symbolic name (variable ID).


Support with Programming

In the programming languages Ladder Logic, Function Block Diagram, and Statement List you can enter addresses, parameters, and block names as absolute addresses or as symbols.

Using the menu command **View > Display > Symbolic Representation** you can toggle between the absolute and symbolic representation of addresses.

To make it easier to program using symbolic addresses you can display the absolute address and the symbol comment that belongs with the symbol. You can activate this information using the menu command **View > Display > Symbol Information**. This means that the line comment following every STL statement contains more information. You cannot edit the display; you must make any changes in the symbol table or the variable declaration table.

The following figure shows you the symbol information in STL.



When you print out a block, the current screen representation with statement comments or symbol comments is printed.

8.2 Shared and Local Symbols

A symbol allows you to work with meaningful symbolic names instead of absolute addresses. The combination of short symbols and longer comments can be used effectively to make programming easier and program documentation better.

You should distinguish between local (block-specific) and shared symbols.

	Shared Symbols	Local Symbols
Validity	<ul style="list-style-type: none"> • Is valid in the whole user program, • Can be used by all blocks, • Has the same meaning in all blocks, • Must be unique in the whole user program. 	<ul style="list-style-type: none"> • Only known to the block in which it was defined, • The same symbol can be used in different blocks for different purposes.
Permitted characters	<ul style="list-style-type: none"> • Letters, numbers, special characters, • Accents other than 0x00, 0xFF, and quotation marks, • The symbol must be placed within quotation marks if you use special characters. 	<ul style="list-style-type: none"> • Letters, • Numbers, • Underscore (_).
Use	<ul style="list-style-type: none"> • You can define shared symbols for: • I/O signals (I, IB, IW, ID, Q, QB, QW, QD) • I/O inputs and outputs (PI, PQ) • Bit memory (M, MB, MW, MD) • Timers (T)/ counters (C) • Logic blocks (OB, FB, FC, SFB, SFC) • Data blocks (DB) • User-defined data types (UDT) • Variable table (VAT) 	<ul style="list-style-type: none"> • You can define local symbols for: • Block parameters (input, output, and in/out parameters), • Static data of a block, • Temporary data of a block.
Defined where?	Symbol table	Variable declaration table for the block

8.3 Displaying Shared or Local Symbols

You can distinguish between shared and local symbols in the code section of a program as follows:

- Symbols from the symbol table (shared) are shown in quotation marks "..".
- Symbols from the variable declaration table of the block (local) are preceded by the character "#".

You do not have to enter the quotation marks or the "#". When you enter your program in Ladder, FBD, or STL the syntax check adds these characters automatically.

If you are concerned that there may be some confusion because, for example, the same symbols are used in both the symbol table and the variable declaration, you must code the shared symbol explicitly when you want to use it. Any symbols without the respective coding are interpreted as block-specific (local) variables in this case.

Coding shared symbols is also necessary if the symbol contains blanks.

When programming in an STL source file the same special characters and guidelines for their use apply. Code characters are not added automatically in free-edit mode, but they are still necessary if you wish to avoid confusion.

Note

Using the menu command **View > Display > Symbolic Representation** you can toggle the display between the declared shared symbolic and the absolute addresses.

8.4 Setting the Address Priority (Symbolic/Absolute)

The address priority helps you to adapt the program code as you see fit when making changes in the symbol table, changing parameter names of data blocks or function blocks or when changing UDTs referring to component names or changing multiple instances

When making changes in the following situations, be sure to set the address priority carefully and with a definite purpose in mind. In order for you to benefit from address priority, each change procedure must be completed in itself before you start with another type of change.

To set the address priority, go to the SIMATIC Manager and select the block folder and then select the menu command **Edit > Object Properties**. In the "Address Priority" tab, you can make the settings that you deem appropriate.

Making optimal settings in address priority requires that the following situations for making a change be distinguished:

- Correction of Individual Names
- Switching Names or Assignments
- New Symbols, Variables, Parameters or Components

Note


Please be aware that the absolute block number is the determining factor when making block calls ("Call FC" or "Call FB, DB") for the logic block – even when symbolic address priority has been set!

Correction of Individual Names

Examples:

In the symbol table or in the program editor/block editor a spelling error in a name has to be corrected. This applies to all names in the symbol table as well as to all the names of parameters, variables or components that can be changed with the program editor/block editor.

Setting the Address Priority:



Tracking Changes:


In the SIMATIC Manager, select the block folder and then select the menu command **Edit > Check Block Consistency**. The "Check block consistency" function make the changes necessary in the individual blocks.

Switching Names or Assignments

Examples:

- The names of existing assignments in the symbol table are switched.
- Existing assignments in the symbol table are assigned new addresses.
- Variable names, parameter names or component names are switched in the program editor/block editor.

Setting the Address Priority:



Tracking Changes:

- In the SIMATIC Manager, select the block folder and then select the menu command **Edit > Check Block Consistency**. The "Check block consistency" function make the changes necessary in the individual blocks.


New Symbols, Variables, Parameters or Components

Examples:


- You are creating new symbols for addresses used in the program.
- You are adding new variable or parameters to data blocks, UDTs or function blocks.

Setting the Address Priority:

- For changes in the symbol table.



- For changes in the program/block editor.



Tracking Changes:

In the SIMATIC Manager, select the block folder and then select the menu command **Edit > Check Block Consistency**. The "Check block consistency" function make the changes necessary in the individual blocks.

8.5 Symbol Table for Shared Symbols

Shared symbols are defined in the symbol table.


An (empty) symbol table ("Symbols" object) is created automatically when you create an S7 or M7 program.

Validity

The symbol table is only valid for the module to which you link the program. If you want to use the same symbols in a number of different CPUs, you yourself must ensure that the entries in the various symbol tables all match up (for example, by copying the table).

8.5.1 Structure and Components of the Symbol Table

Structure of the Symbol Table



Row

	If the columns for "Special Object Properties" were hidden (the menu command View > Columns O, M, C, R, CC was deselected), this symbol appears in the row if the row concerned has at least one "Special Object Property" set for it.
--	--

"Status" Column

	The symbol name or address is identical to another entry in the symbol table.
	The symbol is still incomplete (the symbol name or the address is missing).

R/O/M/C/CC Columns

The columns R/O/M/CC show whether a symbol was assigned special object properties (attributes):

- R (monitoring) means that error definitions for process diagnostics were created for the symbol with the optional package S7-PDIAG (V5).
- O means that the symbol can be operated and monitored with WinCC.
- M means that a symbol-related message (SCAN) was assigned to the symbol.
- C means that the symbol is assigned communication properties.
- CC means that the symbol can be quickly and directly monitored and controlled in the program editor ('Control at Contact').

Click on the check box to enable or disable these "special object properties". You can also edit the "special object properties" via **Edit > Special Object Properties** menu command

"Symbol" Column

The symbolic name must not be longer than 24 characters.

You cannot assign symbols in the symbol table for addresses in data blocks (DBD, DBW, DBB, DBX). Their names are assigned in the data block declaration.

For organization blocks (OB) and some system function blocks (SFB) and system functions (SFC), predefined symbol table entries already exist which you can import into the table when you edit the symbol table of your S7 program. The import file is stored in the STEP 7 directory under ...\\S7data\\Symbol\\Symbol.sdf.

"Address" Column

An address is the identifier for a particular memory area and memory location.
Example: Input I 12.1

The syntax of the address is checked as it is entered.

"Data Type" Column

You can choose between a number of data types available in STEP 7. The data type field already contains a default data type which you may change, if necessary. If the change you make is not suitable for the address or its syntax is incorrect, an error message appears as you exit the field.

"Comment" Column

You can assign comments to all symbols. The combination of brief symbolic names and more detailed comments makes creating programs more effective and makes your program documentation more complete. A comment can be up to 80 characters in length.

Converting to C Variables

You can select symbols in the symbol table for an M7 program and convert them to corresponding C variables in conjunction with the ProC/C++ software option.

8.5.2 Addresses and Data Types Permitted in the Symbol Table

Only one set of mnemonics can be used throughout a symbol table. Switching between SIMATIC (German) and IEC (English) mnemonics must be done in the SIMATIC Manager using the menu command **Options > Customize** in the "Language" tab.

IEC	SIMATIC	Description	Data Type	Address Range
I	E	Input bit	BOOL	0.0 to 65535.7
IB	EB	Input byte	BYTE, CHAR	0 to 65535
IW	EW	Input word	WORD, INT, S5TIME, DATE	0 to 65534
ID	ED	Input double word	DWORD, DINT, REAL, TOD, TIME	0 to 65532
Q	A	Output bit	BOOL	0.0 to 65535.7
QB	AB	Output byte	BYTE, CHAR	0 to 65535
QW	AW	Output word	WORD, INT, S5TIME, DATE	0 to 65534
QD	AD	Output double word	DWORD, DINT, REAL, TOD, TIME	0 to 65532
M	M	Memory bit	BOOL	0.0 to 65535.7
MB	MB	Memory byte	BYTE, CHAR	0 to 65535
MW	MW	Memory word	WORD, INT, S5TIME, DATE	0 to 65534
MD	MD	Memory double word	DWORD, DINT, REAL, TOD, TIME	0 to 65532
PIB	PEB	Peripheral input byte	BYTE, CHAR	0 to 65535
PQB	PAB	Peripheral output byte	BYTE, CHAR	0 to 65535
PIW	PEW	Peripheral input word	WORD, INT, S5TIME, DATE	0 to 65534
PQW	PAW	Peripheral output word	WORD, INT, S5TIME, DATE	0 to 65534
PID	PED	Peripheral input double word	DWORD, DINT, REAL, TOD, TIME	0 to 65532
PQD	PAD	Peripheral output double word	DWORD, DINT, REAL, TOD, TIME	0 to 65532
T	T	Timer	TIMER	0 to 65535
C	Z	Counter	COUNTER	0 to 65535
FB	FB	Function block	FB	0 to 65535
OB	OB	Organization block	OB	1 to 65535
DB	DB	Data block	DB, FB, SFB, UDT	1 to 65535
FC	FC	Function	FC	0 to 65535
SFB	SFB	System function block	SFB	0 to 65535
SFC	SFC	System function	SFC	0 to 65535
VAT	VAT	Variable table		0 to 65535
UDT	UDT	User-defined data type	UDT	0 to 65535

8.5.3 Incomplete and Non-Unique Symbols in the Symbol Table

Incomplete Symbols

It is also possible to store incomplete symbols. You can, for example, enter only the symbol name first and then add the corresponding address at a later date. This means you can interrupt your work on the symbol table at any time, save the interim result, and complete your work another time. Incomplete symbols are identified in the "Status" column by the  symbol. When you come to use the symbol for creating software (without an error message appearing), you must have entered the symbolic name, the address, and the data type.

How Ambiguous Symbols Occur

Ambiguous symbols occur when you insert a symbol in the symbol table whose symbolic name and/or address was already used in another symbol row. This means both the new symbol and the existing symbol are ambiguous. This status is indicated by the symbol  in the "Status" column.

This happens, for example, when you copy and paste a symbol in order to change the details in the copy slightly.

Identification of Ambiguous Symbols

In the symbol table, ambiguous symbols are identified by highlighting them graphically (color, font). This change in their representation means they still require editing. You can either display all symbols or filter the view so that only unique or ambiguous symbols are displayed.

Making Symbols Unique

An ambiguous symbol becomes unique when you change the component (symbol and/or address) which caused this status. If two symbols are ambiguous and you change one of them to make it unique, the other one also becomes unique.

8.6 Entering Shared Symbols

There are three methods of entering symbols that can be used for programming at a later stage:

- **Via Dialog Box**
You can open a dialog box in the window where you are entering a program and define a new symbol or redefine an existing symbol. This procedure is recommended for defining individual symbols, for example, if you realize that a symbol is missing or you want to correct one while you are writing the program. This saves you displaying the whole symbol table.
- **Directly in the Symbol Table**
You can enter symbols and their absolute addresses directly in a symbol table. This procedure is recommended if you want to enter a number of symbols and for when you create the symbol table for a project because you have the symbols which were already assigned displayed on the screen, making it easier to keep an overview of the symbols.
- **Import Symbol Tables from Other Table Editors**
You can create the data for the symbol table in any table editor you are comfortable with (for example, Microsoft Excel) and then import the file you created into the symbol table.

8.6.1 General Tips on Entering Symbols

To enter new symbols in the symbol table, position the cursor in the first empty row of the table and fill out the cells. You can insert new rows before the current row in the symbol table using the menu command **Insert > Symbol**. If the row before the cursor position already contains an address, you will be supported when inserting new symbols by a presetting of the "Address" and "Data Type" columns. The address is derived from the previous row; the default data type is entered as data type.

You can copy and modify existing entries using the commands in the Edit menu. Save and then close the symbol table. You can also save symbols which have not been completely defined.

When you enter the symbols, you should note the following points:

Column	Note
Symbol	The name must be unique within the whole symbol table. When you confirm the entry in this field or exit the field, a non-unique symbol is marked. The symbol can contain up to 24 characters. Quotation marks (") are not permitted.
Address	When you confirm the entry in this field or exit the field, a check is made as to whether the address entered is allowed.
Data Type	When you enter the address, this field is automatically assigned a default data type. If you change this default, the program checks whether the new data type matches the address.
Comment	You can enter comments here to briefly explain the functions of the symbols (max. 80 characters). Entering a comment is optional.

8.6.2 Entering Single Shared Symbols in a Dialog Box

The procedure described below shows you how you can change symbols or define new symbols in a dialog box while programming blocks without having to display the symbol table.

This procedure is useful if you only want to edit a single symbol. If you want to edit a number of symbols, you should open the symbol table and work in it directly.

Activating Symbol Display in a Block

You activate the display of symbols in the block window of an open block using the menu command **View > Display > Symbolic Representation**. A check mark is displayed in front of the menu command to show that the symbolic representation is active.

Defining Symbols When Entering Programs

1. Make certain that the symbolic representation is switched on in the block window (menu command **View > Display > Symbolic Representation**.)
2. Select the absolute address in the code section of your program to which you want to assign a symbol.
3. Select the menu command **Edit > Symbol**.
4. Fill out the dialog box and close it, confirming your entries with "OK" and making sure you enter a symbol.

The defined symbol is entered in the symbol table. Any entries that would lead to non-unique symbols are rejected with an error message.

Editing in the Symbol Table

Using the menu command **Options > Symbol Table** you can open the symbol table to edit it.

8.6.3 Entering Multiple Shared Symbols in the Symbol Table

Opening the Symbol Table

There are a number of ways of opening a symbol table:

- Double-click the symbol table in the project window.
- Select the symbol table in the project window and select the menu command **Edit > Open Object**.

The symbol table for the active program is displayed in its own window. You can now create symbols or edit them. When you open a symbol table for the first time after it was created, it is empty.

Entering Symbols

To enter new symbols in the symbol table, position the cursor in the first empty row of the table and fill out the cells. You can insert new empty rows before the current row in the symbol table using the menu command **Insert > Symbol**. You can copy and modify existing entries using the commands in the Edit menu. Save and then close the symbol table. You can also save symbols that have not been completely defined.

Sorting Symbols

The data records in the symbol table can be sorted alphabetically according to symbol, address, data type, or comment.

You can change the way the table is sorted by using the menu command **View > Sort** to open a dialog box and define the sorted view.

Filtering Symbols

You can use a filter to select a subset of the records in a symbol table.

Using the menu command **View > Filter** you open the "Filter" dialog box.

You can define criteria which the records must fulfill in order to be included in the filtered view. You can filter according to:

- Symbol names, addresses, data types, comments
- Symbols with operator control and monitoring attribute, symbols with communication properties, symbols for binary variables for messages (bit memory or process input)
- Symbols with the status "valid," "invalid (non-unique, incomplete)"

The individual criteria are linked by an AND operation. The filtered records start with the specified strings.

If you want to know more about the options in the "Filter" dialog box, open the context-sensitive online help by pressing F1.

8.6.4 Using Upper and Lower Case for Symbols

No Distinction between Upper and Lower Case Characters

Previously it was possible to define symbols in STEP 7 which differed from one another only in the case used for individual characters. This was changed in STEP 7, V4.02. It is now no longer possible to distinguish between symbols on the basis of the case used.

This change was made in response to the wishes of our customers, and will greatly reduce the risk of errors occurring in a program. The restrictions which have been made to the symbol definition also support the aims of the PLCopen forum to define a standard for transferable programs.

Symbol definition based solely on a distinction between upper and lower case characters is now no longer supported. Previously, for example, the following definition was possible in the symbol table:

```
Motor1 = I 0.0
```

```
motor1 = I 1.0
```

The symbols were distinguished on the basis of the case used for the first letter. This type of differentiation carries with it a significant risk of confusion. The new definition eliminates this possible source of errors.

Effects on Existing Programs

If you have been using this criterion to distinguish between different symbols you may experience difficulties with the new definition if:

- Symbols differ from one another **only** in their use of upper and lower case characters
- Parameters differ from one another **only** in their use of upper and lower case characters
- Symbols differ from parameters **only** in their use of upper and lower case characters

All three of these conflicts can, however, be analyzed and resolved as described below.

Symbols which Differ from One Another Only in their Use of Upper and Lower Case Characters

Conflict:

If the symbol table has not yet been edited with the current version of the software, the first of the non-unique symbols in the table is used when source files are compiled.

If the symbol table has already been edited, such symbols are invalid; this means that the symbols are not displayed when blocks are opened and source files containing these symbols can no longer be compiled without errors.

Remedy:

Check your symbol table for conflicts by opening the table and saving it again. This action enables the non-unique symbols to be recognized. You can then display the non-unique symbols using the filter "Non-Unique Symbols" and correct them. You should also correct any source files which contain conflicts. You do not need to make any further changes to the blocks, as the current (now conflict-free) version of the symbol table is automatically used or displayed when a block is opened.

Parameters which Differ from One Another Only in their Use of Upper and Lower Case Characters

Conflict:

Source files containing such interfaces can no longer be compiled without errors. Blocks with such interfaces can be opened, but access to the second of these parameters is no longer possible. When you try to access the second parameter, the program automatically returns to the first parameter when the block is saved.

Remedy:

To check which blocks contain such conflicts, it is advisable to generate a source file for all the blocks of a program using the function "Generate Source File." If errors occur when you attempt to compile the source file you have created, there must be a conflict.

Correct your source files by ensuring that the parameters are unique; for example, by means of the "Find and Replace" function. Then compile the files again.

Symbols which Differ from Parameters Only in their Use of Upper and Lower Case Characters

Conflict:

If shared and local symbols in a source file only differ from one another in their use of upper and lower case characters, and if no initial characters have been used to identify shared ("symbol name") or local (#symbol name) symbols, the local symbol will always be used during compilation. This results in a modified machine code.

Remedy:

In this case it is advisable to generate a new source file from all of the blocks. This will automatically assign local and shared access with the corresponding initial characters and will ensure that they are handled correctly during future compilation procedures.

8.6.5 Exporting and Importing Symbol Tables

You can export the current symbol table to a text file in order to be able to edit it with any text editor.

You can also import tables created using another application into your symbol table and continue to edit them there. The import function can be used, for example, to include in the symbol table assignment lists created with STEP5/ST following conversion.

The file formats *.SDF, *.ASC, *.DIF, and *.SEQ are available to choose from.

Rules for Exporting

You can export the whole symbol table, a filtered subset of the symbol table, or rows selected in the table view.

The properties of symbols that you can set using the menu command **Edit > Special Object Properties** are not exported.

Rules for Importing

- For frequently used system function blocks (SFBs), system functions (SFCs) and organization blocks (OBs) predefined symbol table entries already exist in the file ...\\S7DATA\\SYMBOL\\SYMBOL.SDF which you can import as required.
- The properties of symbols that you can set using the menu command **Edit > Special Object Properties** are not taken into consideration when exporting and importing.

8.6.6 File Formats for Importing/Exporting a Symbol Table

The following file formats can be imported into or exported out from the symbol table:

- ASCII file format (ASC)
- Data Interchange Format (DIF)
You can open, edit, and save DIF files in Microsoft Excel.
- System Data Format (SDF)
You can open, edit, and save SDF files in Microsoft Access.
 - To import and export data to and from the Microsoft Access application, use the SDF file format.
 - In Access, select the file format "Text (with delimiters)".
 - Use the double inverted comma (") as the text delimiter.
 - Use the comma (,) as the cell delimiter.
- Assignment list (SEQ)
Caution: When exporting the symbol table to a file of the type .SEQ comments that are longer than 40 characters are truncated after the 40th character.

ASCII File Format (ASC)

File Type	*.ASC				
Structure:	Record length, delimiter comma, record				
Example:	126,green_phase_ped.	T	2	TIMER	Duration of green phase for pedestrians
	126,red_ped.	Q	0.0	BOOL	Red for pedestrians

Data Interchange Format (DIF)

File Type	*.DIF
Structure:	A DIF file consists of the file header and the data:

Header	TABLE	Start of a DIF File
	0,1	
	"<Title>"	Comment string
	VECTORS	Number of records in the file
	0,<No. of records>	
	""	
	TUPLES	Number of data fields in a record
	0,<No. of columns>	
	""	
	DATA	ID for the end of the header and start of the data
	0,0	
	""	
Data (per record)	<type>,<numeric value>	ID for the data type, numeric value
	<String>	Alphanumeric part or
	V	if the alphanumeric part is not used

Header: the file header must contain the record types TABLE, VECTORS, TUPLES, and DATA in the order specified. Before DATA, DIF files can contain further, optional record types. These are, however, ignored by the Symbol Editor.

Data: in the data part, each entry consists of three parts: the ID for the Type (data type), a numeric value, and an alphanumeric part.

You can open, edit, and save DIF files in Microsoft Excel. You should not use accents, umlauts, or other special language characters.

System Data Format (SDF)

File Type	*.SDF
Structure:	Strings in quotation marks, parts separated by commas
Example:	"green_phase_ped.,"T 2","TIMER","Duration of green phase for pedestrians" "red_ped.,"Q 0.0","BOOL","Red for pedestrians"

To open an SDF file in Microsoft Access you should select the file format 'Text (with delimiter)'. Use the double quotation mark (") as the text delimiter and the comma (,) as the field delimiter.

Assignment List (SEQ)

File Type	*.SEQ
Structure:	TAB Address TAB Symbol TAB Comment CR
Example:	T 2 green_phase_ped. Duration of green phase for pedestrians Q 0.0 red_ped. Red for pedestrians

TAB stands for the tabulator key (09H),
CR stands for carriage return with the RETURN key (0DH).

8.6.7 Editing Areas in Symbol Tables

As of STEP 7 V5.3, you can now select and edit contiguous areas within a symbol table. This means that you can copy and/or cut parts of one symbol table and insert them into another symbol table or delete them as required.

This makes it easier to update symbol tables by quickly transferring data from one symbol table to another.

Areas that can be selected:

- You can select entire rows as soon as you click in the first column in the row. If you want to select all the fields, ranging from the "Status" column to the "Comments" column, then these are also part of the selected row.
- You can select one or more contiguous fields as an overall area. To be able to select this area, all fields must belong to the "Symbol", "Address", "Data Type" and "Comments" columns. If you make an invalid selection, the menu commands for editing will not be available.
- The R, O, M, C, CC columns contain the special object properties for the respective symbols and are only copied if the "Also copy special object properties" check box is selected in the "Customize" dialog box (menu command Options > Customize).
- The contents of the R, O, M, C, CC columns are copied if these columns are displayed. To show or hide these columns, select the **View > R, O, M, C, CC Columns** menu command.

To edit a symbol table, proceed as follows:

1. Select the area that you want to edit in the symbol table by using either of the following methods:
 - Using the **mouse**, click in the starting cell, and while keeping the left mouse button depressed, move the mouse over the area that you want to select.
 - Using the **keyboard**, select the area by pressing the shift key and then the cursor (arrow) keys.
2. The selected area is shown in reverse video. The cell selected first is shown in normal display and is surrounded by a frame.
3. Edit the area selected as required.

9 Creating Blocks and Libraries

9.1 Selecting an Editing Method

Depending on the programming language you use to create a program, you can enter your program either in incremental input mode and/or free-edit (text) mode.

Incremental Editors for the Programming Languages Ladder Logic (LAD), Function Block Diagram (FBD), Statement List (STL), or S7-GRAPH

In the incremental input mode editors for Ladder, FBD, STL, and S7-GRAPH, you create **blocks** that are stored in the user program. You should choose to use incremental input mode if you want to check what you have entered immediately. This edit mode is particularly suitable for beginners. In incremental input mode, the syntax of each line or element is checked immediately after it has been entered. Any errors are indicated and must be corrected before completing the entry. Entries with correct syntax are automatically compiled and stored in the user program.

Any symbols used must be defined before editing the statements. If certain symbols are not available, the block can not be fully compiled; this inconsistent interim version can, however, be saved.

Source Code (Text) Editors for the Programming Languages STL, S7 SCL, or S7 HiGraph

In source code editors, you create **source code files** for subsequent compilation to generate blocks.

We recommend you use source code editing, as this is a highly efficient program editing and monitoring method.

The source code of the program or block is edited in a text file and then compiled.

The text files (source files) are stored in the sources folder of your S7 program, for example, as an **STL source file** or **SCL source file**. A source file can contain code for one or multiple blocks. The STL and SCL text editors allow you to generate source code for **OBs, FBs, FCs, DBs, and UDTs** (user-defined data types), though you can use them to create a complete user program. One such text file may contain the complete program (that is, all blocks) for a CPU.

When you compile the source file, the corresponding blocks will be generated and written to the user program. All symbols used must be defined before you can compile them. Data errors are not reported until the respective compiler interprets the source file.

It is imperative for compilation to stay conform with the prescribed syntax of the programming language. A syntax check is only performed on account of a user instruction or when the source file is compiled into blocks.

9.2 Selecting the Programming Language

Setting the Programming Language for the Editor

Before you generate a particular block or a source file, select the programming language and editor via the object properties. This selection determines which editor is started when the block or source file is opened.

Starting the Editor

Start the appropriate language editor either in SIMATIC Manager with a double-click on the corresponding object (block, source file, etc.), by selecting the menu command **Edit > Open Object** or click on the corresponding toolbar button.

To create an S7 program, the programming languages listed in the table are available to you. The STEP 7 programming languages LAD, FBD, and STL are supplied with the standard STEP 7 software package. You can purchase other programming languages as optional software packages.

You then have the choice of a number of different programming philosophies (Ladder Logic, Function Block Diagram, Statement List, standard language, sequential control, or status graph) and whether to use a text-based or a graphic programming language.

Select a programming language to determine the input mode (X).

Programming Language	User Group	Application	Incremental Input	Free-Edit Mode	Block can be Documented Back from the CPU
Statement List STL	Users who prefer programming in a language similar to machine code	Programs optimized in terms of run time and memory requirements	X	X	X
Ladder Logic LAD	Users who are accustomed to working with circuit diagrams	Programming of logic controls	X	–	X
Function Block Diagram FBD	Users who are familiar with the logic boxes of Boolean algebra	Programming of logic controls	X	–	X
F-LAD, F-FBD Optional package	Users who are familiar with the programming languages LAD and FBD.	Programming of safety programs for F-systems	X	–	X
SCL (Structured Control Language) Optional package	Users who have programmed in high-level languages such as PASCAL or C	Programming data processing tasks	–	X	–
S7-GRAPH	Users who want to work oriented on the technological functions and do not	Convenient description of sequential processes	X	–	X

Programming Language	User Group	Application	Incremental Input	Free-Edit Mode	Block can be Documented Back from the CPU
Optional package	have extensive knowledge of programming/PLCs				
HiGraph Optional package	Users who want to work oriented on the technological functions and do not have extensive knowledge of programming/PLCs	Convenient description of asynchronous, non-sequential processes	–	X	–
CFC Optional package	Users who want to work oriented on the technological functions without extensive programming or PLC experience	Description of continuous processes	–	–	–


If blocks contain no errors, you can switch between Ladder Logic, Function Block Diagram, or Statement List format. Program parts that cannot be displayed in the target language are shown in Statement List format.

Under STL, you can generate blocks from source files and vice versa.

9.2.1 Ladder Logic Programming Language (LAD)

The graphic programming language Ladder Logic (LAD) is based on the representation of circuit diagrams. The elements of a circuit diagram, e.g. normally open contacts and normally closed contacts, are combined to form networks. The code section of a logic block represents one or more networks.

Example of Networks in LAD




The programming language LAD is supplied with the standard STEP 7 software package. Programs are created under LAD with an incremental editor.

9.2.2 Function Block Diagram Programming Language (FBD)

The programming language Function Block Diagram (FBD) is based on graphic logic symbols also known in Boolean algebra. Complex functions such as math functions can also be displayed directly in combination with the logic boxes.

The programming language FBD is supplied with the standard STEP 7 software package.

Example of a Network in FBD



Programs are created in FBD with an incremental editor.

9.2.3 Statement List Programming Language (STL)

The programming language STL is a text-based programming language with a structure similar to machine code. Each statement represents a program processing operation of the CPU. Multiple statements can be linked to form networks.

Example of Networks in Statement List

```
Network 1: Control drain valve
A(
O
O #Coil
)
AN #Close
= #Coil
Network 2: Display "Valve open"
A #Coil
= #Disp_open
Network 3: Display "Valve closed"
AN #Coil
= #Disp_closed
```

The programming language STL is supplied with the standard STEP 7 software package. With this programming language, you can use incremental editors to edit S7 blocks and you can create and compile STL program source files in a source code editor to generate blocks.

9.2.4 S7 SCL Programming Language

The programming language SCL (Structured Control Language) is available as an optional package. This is a high-level text-based language whose global language definition conforms to IEC 1131-3. The language closely resembles PASCAL and, other than in STL, simplifies the programming of loops and conditional branches due to its high-level language commands, for example. SCL is therefore suitable for calculating equations, complex optimization algorithms, or the management of large data volume.

S7 SCL programs are written in the source code editor.

Example:

```
FUNCTION_BLOCK FB20
VAR_INPUT
END_VAL:          INT;
END_VAR
VAR_IN_OUT
IQ1 :             REAL;
END_VAR
VAR
INDEX:           INT;
END_VAR


BEGIN
CONTROL:=FALSE;
FOR INDEX:= 1 TO ENDVALUE DO
    IQ1:= IQ1 * 2;
    IF IQ1 >10000 THEN
        CONTROL = TRUE
    END_IF
END_FOR;
END_FUNCTION_BLOCK
```

9.2.5 S7-GRAPH Programming Language (Sequential Control)

The graphic programming language S7-GRAPH is available as optional package. It allows you to program sequential controls. This includes the creation of sequencers and the specification of corresponding step contents and transitions. You program the contents of the steps in a special programming language (similar to STL). Transitions are programmed in a Ladder Logic Editor (a light version of LAD).

S7-GRAPH displays even complex sequences very clearly and makes programming and troubleshooting more effective.

Example of a Sequential Control in S7-GRAPH



Blocks Created

With the S7-GRAPH editor you program the function block that contains the sequencer. A corresponding instance DB contains the data for the sequencer, e.g. the FB parameters, step and transition conditions. You can generate this instance DB automatically in the S7-GRAPH editor.

Source File


A text-based source file (GRAPH source file) can be generated from a function block created in S7-GRAPH which can be interpreted by OPs or text-based displays for displaying the sequencer.


9.2.6 S7 HiGraph Programming Language (State Graph)

The graphic programming language S7 HiGraph is available as an optional package. It allows you to program a number of the blocks in your program as status graphs. Here you split your system into dedicated functional units which can acquire different states and you define the transition conditions between states. You describe the actions assigned to the states and the conditions for the transitions between the states in a zoom-type language similar to Statement List.

You create a graph for each functional unit that describes the response of this functional unit. The plant graphs are gathered in graph groups. The graphs can communicate to synchronize functional units.

The well arranged view of the status transitions of a functional unit allows systematic programming and simplifies debugging. The difference between S7-GRAPH and S7-HiGraph is, that the latter acquires only one state (in S7-GRAPH: "step") at any one time. The figure below shows how to create graphs for functional units (example).





A graph group is stored in a HiGraph source file in the "Source" folder of the S7 program. This source file is then compiled to generate S7 blocks for the user program.

Syntax and formal parameters are checked after the last entry was made in a graph (when the working window is closed). Addresses and symbols are not checked until the source file is being compiled.

9.2.7 S7 CFC Programming Language

The optional software package CFC (*C*ontinuous *F*unction *C*hart) is a programming language used to link complex functions graphically.

You use the programming language S7 CFC to link existing functions. You do not need to program many standard functions yourself, instead you can use libraries containing standard blocks (for example, for logic, math, control, and data processing functions). To use CFC you do not require any detailed programming knowledge or specific knowledge of programmable control, and you can concentrate on the technology used in your branch of industry.

The program created is stored in the form of CFC charts. These are stored in the "Charts" folder beneath the S7 program. These charts are then compiled to form the S7 blocks for the user program.

You may want to create blocks to be connected yourself, in which case you program them for SIMATIC S7 with one of the S7 programming languages, and for SIMATIC M7 with C/C++.

9.3 Creating Blocks

9.3.1 Blocks Folder

You can create the program for an S7 CPU in the form of:

- Blocks
- Source files

The folder "Blocks" is available under the S7 program for storing blocks.

This block folder contains the blocks you need to download to the S7 CPU for your automation task. These loadable blocks include logic blocks (OBs, FBs, FCs) and data blocks (DB). An empty organization block OB1 is automatically created with the block folder because you will always need this block to execute your program in the S7 CPU.

The block folder also contains the following objects:

- The user-defined data types (UDT) you created. These make programming easier but are not downloaded to the CPU.
- The variable tables (VAT) that you can create to monitor and modify variables for debugging your program. Variable tables are not downloaded to the CPU.
- The object "System Data" (system data blocks) that contains the system information (system configuration, system parameters). These system data blocks are created and supplied with data when you configure the hardware.
- The system functions (SFC) and system function blocks (SFB) that you need to call in your user program. You cannot edit the SFCs and SFBs yourself.

With the exception of the system data blocks (which can only be created and edited via the configuration of the programmable logic controller), the blocks in the user program are all edited using the respective editor. This editor is started automatically by double-clicking the respective block.

Note

The blocks you programmed as source files and then compiled are also stored in the block folder.

9.3.2 User-Defined Data Types (UDT)

User-defined data types are special data structures you create yourself that you can use in the whole S7 program once they have been defined.

- User-defined data types can be used like elementary data types or complex data types in the variable declaration of logic blocks (FC, FB, OB) or as a data type for variables in a data block (DB). You then have the advantage that you only need to define a special data structure once to be able to use it as many times as you wish and assign it any number of variables.
- User-defined data types can be used as a template for creating data blocks with the same data structure, meaning you create the structure once and then create the required data blocks by simply assigning the user-defined data type (Example: Recipes: The structure of the data block is always the same, only the amounts used are different.)

User-defined data types are created in the SIMATIC Manager or the incremental editor – just like other blocks.

Structure of a User-Defined Data Type

When you open a user-defined data type, a new working window is displayed showing the declaration view of this user-defined data type in table form.

- The first and the last row already contain the declarations STRUCT and END_STRUCT for the start and the end of the user-defined data type. You cannot edit these rows.
- You edit the user-defined data type by typing your entries in from the second row of the declaration table in the respective columns.
- You can structure user-defined data types from:
 - Elementary data types
 - Complex data types
 - Existing user-defined data types

The user-defined data types in the S7 user program are not downloaded to the S7 CPU. They are either created directly using an incremental input editor and edited, or they are created when source files are compiled.

9.3.3 Block Properties

You can more easily identify the blocks you created if you use block properties and you can also protect these blocks from unauthorized changes.

You should edit the block properties when the block is open. In addition to the properties you can edit, the properties dialog box also displays data for your information only: you cannot edit this information.

The block properties and system attributes are also displayed in the SIMATIC Manager in the object properties for a block. Here you can only edit the properties NAME, FAMILY, AUTHOR, and VERSION.

You edit the object properties after you insert the block via the SIMATIC Manager. If a block was created using one of the editors and not in the SIMATIC Manager, these entries (programming language) are saved automatically in the object properties.

Note

The mnemonics you want to use to program your S7 blocks can be set in the SIMATIC Manager using the menu command **Options > Customize** and the "Language" tab.

Table of Block Properties

When entering block properties, you should observe the input sequence shown in the following table:

Keyword / Property	Meaning	Example
[KNOW_HOW_PROTECT]	Block protection; a block compiled with this option does not allow its code section to be viewed. The interface for the block can be viewed, but it cannot be changed.	KNOW_HOW_PROTECT
[AUTHOR:]	Name of author: company name, department name, or other name (max. 8 characters without blanks)	AUTHOR : Siemens, but no keyword
[FAMILY:]	Name of block family: for example, controllers (max. 8 characters without blanks)	FAMILY : controllers, but no keyword
[NAME:]	Block name (max. 8 characters)	NAME : PID, but no keyword
[VERSION: int1 . int2]	Version number of block (both numbers between 0 and 15, meaning 0.0 to 15.15)	VERSION : 3.10
[CODE_VERSION1]	ID whether a function block can have multiple instances declared or not. If you want to declare multiple instances, the function block should not have this property	CODE_VERSION1

Keyword / Property	Meaning	Example
[UNLINKED] for DBs only!	Data blocks with the UNLINKED property are only stored in the load memory. They take up no space in the working memory and are not linked to the program. They cannot be accessed with MC7 commands. Depending on the specific CPU, the contents of such a DB can be transferred to the working memory only with SFC 20 BLKMOV or SFC 83 READ_DBL.	
[Non-Retain]	Data blocks with this attribute are reset to the load values after every power OFF and power ON and after every STOP-RUN transition of the CPU.	
[READ_ONLY] for DBs only	Write protection for data blocks; its data can only be read and cannot be changed	READ_ONLY
Read-only block	A copy of a block that is stored in read-only status for reference purposes. This property can only be assigned in the program editor by selecting File > Store Read-Only menu command.	

The block protection KNOW_HOW_PROTECT has the following consequences:

- If you want to view a compiled block at a later stage in the incremental STL, FBD, or Ladder editors, the code section of the block cannot be displayed.
- The variable declaration table for the block displays only the variables of the declaration types var_in, var_out, and var_in_out. The variables of the declaration types var_stat and var_temp remain hidden.

Assignment: Block Property to Block Type

The following table shows which block properties can be declared for which block types:

Property	OB	FB	FC	DB	UDT
KNOW_HOW_PROTECT	•	•	•	•	–
AUTHOR	•	•	•	•	–
FAMILY	•	•	•	•	–
NAME	•	•	•	•	–
VERSION	•	•	•	•	–
UNLINKED	–	–	–	•	–
READ_ONLY	–	–	–	•	–
Non-Retain	–	–	–	•	–
Read-only block	•	•	•	•	•

The KNOW_HOW_PROTECT property can be set in a source file when you program the block. It is displayed in the "Block Properties" dialog box but cannot be changed.

9.3.4 Displaying Block Lengths

Block lengths are displayed in "bytes."

Display in the Block Folder Properties

The following lengths are displayed in the block folder properties in the offline view:

- Size (sum of all blocks without system data) in the load memory of the programmable controller
- Size (sum of all blocks without system data) in the work memory of the programmable controller
- Block lengths on the programming device (PG/PC) are not displayed in the block folder properties.

Display in the Block Properties

The following are displayed in the block properties:

- Required number of local data: size of the local data in bytes
- MC7: size of the MC7 code in bytes, or size of the DB user data
- Size of the load memory in the programmable controller
- Size of the work memory in the programmable controller: only displayed if hardware assignment is recognized.

For display purposes, it does not matter whether the block is located in the window of an online view or an offline view.

Display in the SIMATIC Manager (Details View)

If a block folder is opened and the "Details View" selected, the work memory requirement is displayed in the project window, irrespective of whether the block folder is located in the window of an online view or an offline view.

You can calculate the sum of the block lengths by selecting all the relevant blocks. In this case, the sum of the selected blocks is displayed in the status bar of the SIMATIC Manager.

No lengths are displayed for blocks which cannot be downloaded to the programmable controller (for example, variable tables).

Block lengths on the programming device (PG/PC) are not displayed in the Details view.

9.3.5 Comparing Blocks

Introduction

To compare blocks that are in different locations, you can start the block comparison process in either of the following ways:

- Go to the SIMATIC Manager and select the **Options > Compare Blocks** menu command. In the "Compare Blocks - Results" dialog box that is displayed, click the "Go to" button. The results of the comparison will appear in the program editor (LAD/FBD/STL) in the "Comparison" tab
- Go to the program editor. Select the **Options > Compare On-/Offline Partners** menu command.

The following sections explain how the block-comparison process functions. In the following discussion, a distinction is maintained between logic blocks (OBs, FBs, FCs) and data blocks (DBs).

How Block Comparison Works: Logic Blocks

In the first step of the process, STEP 7 compares the time stamps for the interfaces of the logic blocks to be compared. If these time stamps are identical, STEP 7 assumes that the interfaces are identical.

If the time stamps are different, STEP 7 then compares the data types in the interfaces step-by-step by section. When a difference is found, STEP 7 determines the first difference in a section; that is, in each case the **first** difference in the respective declaration ranges. Multi-instances and UDTs are also included in the comparison. If the data types in the sections are the same, STEP 7 then compares the initial values of the variables. All differences are displayed.

In the second step, STEP 7 checks the code by network by network (in case the "Execute code comparison" option was not selected, the code will still be compared if the "Go to" button in the Program Editor is clicked.).

First, the inserted or deleted networks are detected. The results of the comparison will show networks that are only present in one block. These will have the comment "only in".

Then, the remaining networks are compared until the **first** difference in statements is found. Statements are compared in the following manner:

- For the setting "Absolute address has priority", based on the absolute address
- For the setting "Symbol has priority", based on the symbol

Statements are considered to identical if their operators and addresses are the same.

If the blocks to be compared were programmed in different programming languages, STEP 7 performs the comparison based on the STL language.

Special feature of offline-offline comparisons:

In contrast to an offline-online comparison, in an offline-offline comparison, STEP 7 also detects the presence of different variable names. This additional step is not possible for an offline-offline comparison since only replacement symbols are available online.

Comments for block networks and lines as well as other block attributes (such as S7-PDIAG information and messages) are excluded from comparisons.

How Block Comparison Works: Data Blocks

In the first step of the process, STEP 7 compares the time stamps for the interfaces of the data blocks to be compared (as for logic blocks). If these time stamps are identical, STEP 7 assumes that the data structures are identical.

If the interface time stamps are different, STEP 7 then compares the data structures until the **first** difference is found. If the data structures are in the sections are identical, STEP 7 then compares the initial values and current values. All differences are displayed.

Special feature of offline-offline comparisons:

In contrast to an offline-online comparison, in an offline-offline comparison, STEP 7 also detects the presence of different variable names. This additional step is not possible for an offline-online comparison since only replacement symbols are available online.

Comments and structures for UDTs that are used in a data block are excluded from comparisons.

How Block Comparison Works: Data Types (UDT)

In the first step of the process, STEP 7 compares the time stamps for the interfaces of the data types to be compared (as for data blocks). If these time stamps are identical, STEP 7 assumes that the data structures are identical.

If the interface time stamps are different, STEP 7 then compares the data structures until the **first** difference is found. If the data structures are in the sections are identical, STEP 7 then compares the initial values. All differences are displayed.

How Block Comparison Works: Comparison in the Program Editor

1. Open the block to be compared to the loaded version.
2. Select the **Options > Compare On-/Offline Partners** menu command.

If the online partner is accessible, then the results of the comparisons will be displayed in the lower section of the program editor window in the "7:Comparison" tab.

Tip: If two networks are determined to be "different", then you can open the relevant network simply by double-clicking in its row.

How Block Comparison Works: Comparison in the SIMATIC Manager

1. In the SIMATIC Manager, select the block folder or the blocks to be compared.
2. Select the **Options > Compare Blocks** menu command.
3. In the "Compare Blocks" dialog box that is displayed, select the type of comparison (ONLINE/offline or Path1/Path2).
4. For a Path1/Path2 comparison: In the SIMATIC Manager, select the block folder or the blocks to be compared. These blocks are then automatically entered in the dialog box.
5. If also want to compare SDBs, select the "Including SDBs" check box.
6. If you also want to compare code, select the "Execute code comparison" check box. In a detailed comparison, in addition to the execution-related parts of the block (interface and code), any changes in the names for local variables and parameters are displayed. In addition, you can select the "Including blocks created in different programming languages" check box to compare blocks created in different programming languages (e.g. AWL, FUP....). In this case, the blocks are compared based on STL.
7. Confirm your settings in the dialog box by clicking "OK".

The results of the comparison are displayed in the "Compare Blocks - Results" dialog box.

To display the properties (i.e. time of last modification, checksum, etc.) of the compared blocks, click on the "Details" button in this dialog box

To open the program editor, in which the results of the comparison are displayed in the lower portion of the window, click the "Go to" button.

Note

When comparing an offline block folder with an online one, only loadable block types (OB, FB, ...) are compared.

When comparing offline/online or Path1/Path2, all blocks included in a multiple selection are compared, even if some of them are not loadable ones (i.e. variable tables or UDTs).

9.3.6 Rewiring

The following blocks and addresses can be rewired:

- Inputs, outputs
- Memory bits, timers, counters
- Functions, function blocks

To rewire:

1. Select the "Blocks" folder that contains the individual blocks you want to rewire in the SIMATIC Manager.
2. Select the menu command **Options > Rewire**.
3. Enter the required replacements (old address/new address) in the table in the "Rewire" dialog box.
4. Select the option "All addresses within the specified address area" if you want to rewire address areas (BYTE, WORD, DWORD).
Example: You enter IW0 and IW4 as the address areas. The addresses I0.0 – I1.7 are then rewired to the addresses I4.0 – I5.7. Addresses from the rewired area (for example, I0.1) can then no longer be entered in the table individually.
5. Click the "OK" button.

This starts the rewire process. After rewiring is completed, you can specify in a dialog box whether you want to see the info file on rewiring. This info file contains the address lists "Old address" and "New address." The individual blocks are listed with the number of wiring processes that have been carried out in each one.

When rewiring, the following should be noted:

- When you rewire (that is, rename) a block, the new block cannot currently exist. If the block exists, the process is interrupted.
- When you rewire a function block (FB), the instance data block is automatically assigned to the rewired FB. The instance DB does not change, that is, the DB number is retained.

9.3.7 Attributes for Blocks and Parameters

A description of the attributes can be found in the reference help on system attributes:

- [Jumps to Language Descriptions and Help on Blocks and System Attributes](#)

9.4 Working with Libraries

Libraries serve to store reusable program components for SIMATIC S7/M7. The program components can be copied to the library from existing projects or created directly in the library independently of other projects.

You can save yourself a lot of programming time and effort if you store blocks which you want to use many times in a library in an S7 program. You can copy them from there to the user program where they are required.

To create S7/M7 programs in a library, the same functions apply as for projects – with the exception of debugging.

Creating Libraries

You can create libraries just like projects using the menu command **File > New**. The new library is created in the directory you set for libraries in the "General" tab when you selected the menu command **Options > Customize**.

Note

The SIMATIC Manager allows names that are longer than eight characters. The name of the library directory is, however, cut off to eight characters. Library names must therefore differ in their first eight characters. The names are not case-sensitive. When this directory is opened in the Browser, the full name is displayed again, but when browsing for the directory, only the shortened name appears.

Note that you cannot use blocks from libraries of a new STEP 7 version in projects of an older STEP 7 version.

Opening Libraries

To open an existing library, enter the menu command **File > Open**. Then select a library in the dialog boxes that follow. The library window is then opened.

Note

If you cannot find the library you require in the library list, click the "Browse" button in the "Open" dialog box. The standard Windows browser then displays the directory structure in which you can search for the library.

Note that the name of the file always corresponds to the original name of the library when it was created, meaning any name changes made in the SIMATIC Manager are not made at file level.

When you select a library it is added to the library list. You can change the entries in the library list using the menu command **File > Manage**.

Copying Libraries

You copy a library by saving it under another name using the menu command **File > Save As**.

You copy parts of a library such as programs, blocks, source files etc. using the menu command **Edit > Copy**.

Deleting a Library

You delete a library using the menu command **File > Delete**.

You delete parts of a library such as programs, blocks, source files etc. using the menu command **Edit > Delete**.

9.4.1 Hierarchical Structure of Libraries

Libraries are structured in a hierarchical manner, just like projects:

- Libraries can contain S7/M7 programs.
- An S7 program can contain one "Blocks" folder (user program), one "Source Files" folder, one "Charts" folder, and one "Symbols" object (symbol table).
- An M7 program can contain charts and C programs for programmable M7 modules as well as a "Symbols" object (symbol table) and a "Blocks" folder for data blocks and variable tables.
- The "Blocks" folder contains the blocks that can be downloaded to the S7 CPU. The variable tables (VAT) and user-defined data types in the folder are not downloaded to the CPU.
- The "Source Files" folder contains the source files for the programs created in the various programming languages.
- The "Charts" folder contains the CFC charts (only if the S7 CFC optional software is installed).

When you insert a new S7/M7 program, a "Blocks" folder, "Source Files" folder (S7 only), and a "Symbols" object are inserted automatically in it.

9.4.2 Overview of the Standard Libraries

The STEP 7 standard software package contains the following standard libraries

- **System Function Blocks:** System Function Blocks (SFBs) and System Functions (SFCs)
- **S5-S7 Converting Blocks:** Blocks for converting STEP 5 programs
- **IEC Function Blocks:** Blocks for IEC functions, e.g. for processing time and date information, comparison operations, string processing and selecting the min./max. values
- **Organization Blocks:** Default organization blocks (OB)s
- **PID Control Blocks:** Function Blocks (FBs) for PID control
- **Communication Blocks:** Functions (FCs) and function blocks for SIMATICNET CPs.
- **TI-S7 Converting Blocks:** Standard functions for general use
- **Miscellaneous Blocks:** Blocks for time stamping and for TOD synchronization

When you install optional software packages, other libraries may be added.

Deleting and Installing the Supplied Libraries

You can delete the supplied libraries in SIMATIC Manager and then reinstall them. Run STEP 7 Setup to install the libraries..

Note

When you install STEP 7, the supplied libraries are always copied. If you edit these libraries, the modified libraries will be overwritten with the originals when STEP 7 is installed again.

For this reason, you should copy the supplied libraries before making any changes and then only edit the copies.

10 Creating Logic Blocks

10.1 Basics of Creating Logic Blocks

10.1.1 Structure of the Program Editor Window

The window of the program editor is split into the following areas:

Tables

The "Program Elements" tab displays a table of the program elements you can insert into your LAD, FBD or STL program. The "Call Structure" tab shows the call hierarchy of the blocks in the current S7 program.

Variable Declaration

The variable declaration is split in to the sections "Variable Table" and "Variable Detail View".

Instructions

The instruction list shows the block code that is to be processed by the PLC. It consists of one or several networks.

Details

The various tabs in the "Details" window provide functions, for example, for displaying error messages, editing symbols, providing address information, controlling addresses, comparing blocks and for editing error definitions for hardware diagnostics.

The screenshot displays the SIMATIC Manager software interface. The main window shows a ladder logic network with the following components:

- Network 3:** SR (Set, Reset) Memory Function block. The Set (S) input is connected to "Automatic_On" (normally open contact) and "Automatic_Mode" (normally closed contact). The Reset (R) input is connected to "Manual_On" (normally open contact). The Output (Q) is connected to "Automatic_Mode".
- Network 4:** Switching on the Petrol Engine. The Enable (EN) input is connected to "Petrol" (normally open contact). The Enable (ENO) output is connected to "Engine".

At the bottom of the window, there is a table with the following data:

Address	Symbol	Display format	Status value
1	I 0.5 "Automatic_On"	BOOL	
2	Q 4.2 "Automatic_Mod"	BOOL	
3	I 0.6 "Manual_On"	BOOL	


Below the table, there are navigation tabs: 2: Info, 3: Cross-References, and 4: Address info. The status bar at the bottom indicates "Press F1 to get Help." and "offline".

10.1.2 Basic Procedure for Creating Logic Blocks

Logic blocks (OBs, FBs, FCs) consist of a variable declaration section, a code section as well as their properties. When programming, you must edit the following three parts:

- **Variable declaration:** In the variable declaration you specify the parameters, system attributes for parameters, and local block-specific variables.
- **Code section:** In the code section you program the block code to be processed by the programmable controller. This consists of one or more networks. To create networks you can use, for example, the programming languages Ladder Logic (LAD), Function Block Diagram (FBD), or Statement List (STL).
- **Block properties:** The block properties contain additional information such as a time stamp or path that is entered by the system. In addition, you can enter your own details such as name, family, version, and author and you can assign system attributes for blocks.

In principle it does not matter in which order you edit the parts of a logic block. You can, of course, also correct them and add to them.



Note

If you want to make use of symbols in the symbol table, you should first check that they are complete and make any necessary corrections.

10.1.3 Default Settings for the LAD/STL/FBD Program Editor

Before you start programming, you should make yourself familiar with the settings in the editor in order to make it easier and more comfortable for you when programming.

Using the menu command **Options > Customize** you open a tabbed dialog box. In the various tabs you can make the following default settings for programming blocks, e.g. in the "General" tab:

- The fonts (type and size) for text and tables.
- Whether you want symbols and comments to be displayed with a new block.

You can change the settings for language, comments, and symbols during editing using the commands in the **View >...** menu.

You can change the colors used for highlighting, for example, networks or statement lines in the "LAD/FBD" tab.

10.1.4 Access Rights to Blocks and Source Files

When editing a project, a common database is often used, meaning that a number of personnel may want to access the same block or data source at the same time.


The read/write access rights are assigned as follows:

- **Offline editing:**
When you attempt to open a block/source file, a check is made to see whether you have 'write' access to the object. If the block/source file is already open, you can only work with a copy. If you then attempt to save the copy, the system queries whether you want to overwrite the original or save the copy under a new name.
- **Online editing:**
When you open an online block via a configured connection, the corresponding offline block is disabled, preventing it from being edited simultaneously.

10.1.5 Instructions from the Program Elements Table

The "Program elements" tab in the overview window provides LAD and FBD elements as well as already declared multiple instances, pre-configured blocks and blocks from libraries. You can access the tab via menu command **View > Tables**. You can also insert program elements in the code section using the menu command **Insert > Program Elements**.

Example of the "Program Elements" Tab in LAD



10.2 Editing the Variable Declaration

10.2.1 Using the Variable Declaration in Logic Blocks

After you open a logic block, a window opens that contains in the upper section the variable table and the variable detail view for the block as well as the instruction list in the lower section in which you edit the actual block code.

Example: Variable Views and Instruction List in STL

The screenshot shows the SIMATIC Manager interface for editing a function block. The window title is 'LAD/STL/FBD - [FB1 -- ZEn01_02_STEP7_STL_1-10\SIMATIC 3...'. The menu bar includes File, Edit, Insert, PLC, Debug, View, Options, Window, and Help. The interface is divided into three main sections:

- Left Panel (Tree View):** Shows a hierarchical structure under 'Interface'. The 'IN' folder is expanded, showing variables: Switch_On (highlighted), Switch_Off, Failure, and Actual_Speed. Other folders include OUT, IN_OUT, STAT, and TEMP.
- Top Right Panel (Table):** Titled 'Contents Of: 'Environment\Interface\IN'', it displays a table of variable declarations.

Name	Data Type	Address	Initial Value
Switch_On	Bool	0.0	
Switch_Off	Bool	0.1	
Failure	Bool	0.2	
Actual_Speed	Int	2.0	
- Bottom Panel (Code Editor):** Contains the STL code for the function block.


```

FB1 : Function Block for Controlling the Engine
Network 1: Switching on Engine, Negating Signals
    A    #Switch_On
    AN   "Automatic_Mode"
    S    #Engine_On
    O    #Switch_Off
    ON   #Failure
    R    #Engine_On
            
```

The status bar at the bottom indicates 'Press F1 to get Help.', 'offline', and 'Ab:'.

In the variable detail view, you specify the local variables and the formal parameters for the block as well as the system attributes for parameters. This has the following effects:

- During declaration, sufficient memory space is reserved for temporary variables in the local data stack, and in the case of function blocks, for static variables in the instance DB to be associated later.
- When setting input, output, and in/out parameters you also specify the "interface" for the call of a block in the program.
- When you declare the variables in a function block, these variables (with the exception of the temporary variables) also determine the data structure for every instance DB that is associated with the function block.
- By setting system attributes you assign special properties, for example, for the configuration of message and connection functions, for operator control and monitoring functions and the process control configuration.

10.2.2 Interaction Between The Variable Detail View And The Instruction List


The variable declaration and instruction list of logic blocks are closely related, because for programming the names specified in the variable declaration are used in the instruction list. All changes in the variable declaration will therefore influence the entire instruction list.

Action in the Variable Declaration	Reaction in the Code Section
Correct new entry	If invalid code present, previously undeclared variable now becomes valid
Correct name change without type change	Symbol is immediately shown everywhere with its new name
Correct name is changed to an invalid name	Code remains unchanged
Invalid name is changed to a correct name	If invalid code is present, it becomes valid
Type change	If invalid code is present, it becomes valid and if valid code is present, this may become invalid
Deleting a variable (symbolic name) used in the code	Valid code becomes invalid

Change to comments, faulty input of a new variable, change to an initial value, or deleting an unused variable has no effect on the instruction list.

10.2.3 Structure of the Variable Declaration Window

The variable declaration window consists of the overview of variables and of the variable detail view.



After you have generated and opened a new code block, a default variable table is displayed. It lists only the declaration types (in, out, in_out, stat, temp) permitted for the selected block, namely in the prescribed order. You can edit the default variable declaration that is displayed after you have generated a new OB.

Permitted data types of local data for the various block types are found under Assigning the Data Types To Local Data Of Code Blocks.

10.3 Multiple Instances in the Variable Declaration


10.3.1 Using Multiple Instances

It is possible that you may want to or have to use a restricted number of data blocks for instance data owing to the performance (for example, memory capacity) of the S7 CPUs you are using. If other existing function blocks are called in an FB in your user program (call hierarchy of FBs), you can call these other function blocks without their own (additional) instance data blocks.

Use the following solution:

- Include the function blocks you want to call as static variables in the variable declaration of the calling function block.
- In this function block, call other function blocks without their own (additional) instance data blocks.
- This concentrates the instance data in one instance data block, meaning you can use the available number of data blocks more effectively.

The following example illustrates the solution described: FB2 and FB3 use the instance DB of the function block FB1 from which they were called.



Only requirement: You must "tell" the calling function block which instances you are calling and what (FB) type these instances are. These details must be entered in the declaration window of the calling function block. The function block used must have at least one variable or parameter from the data area (VAR_TEMP cannot be used).

Do not use multiple instance data blocks if online changes are expected while the CPU is running. Surge-free reloading is only guaranteed when using instance data blocks.

10.3.2 Rules for Declaring Multiple Instances

The following rules apply to the declaration of multiple instances:

- Declaring multiple instances is only possible in function blocks that were created with STEP 7 from Version 2 onwards (see Block Attribute in the properties of the function block).
- In order to declare multiple instances, the function block must be created as a function block with multiple instance capability (default setting from STEP 7 Version x.x; can be deactivated in the editor using **Options > Customize**).
- An instance data block must be assigned to the function block in which a multiple instance is declared.
- A multiple instance can only be declared as a static variable (declaration type "stat").

Note

- You can also create multiple instances for system function blocks.
 - If the function block was not created as being able to have multiple instances and you want it to have this property, you can generate a source file from the function block in which you then delete the block property CODE_VERSION1 and then compile the function block again.
-

10.3.3 Entering a Multiple Instance in the Variable Declaration Window

1. Open the function block from which the subordinate function blocks are to be called.
2. Define a static variable in the variable declaration of the calling function block for each call of a function block for whose instance you do not want to use an instance data block.
 - In the variable table, select hierarchy level "STAT".
 - Enter a name for the FB call in the "Name" column of the variable detail view
 - Enter the function block you want to call in the "Data type" column as an absolute address or with its symbolic name.
 - You can enter any explanations required in the comment column.

Calls in the Code Section

When you have declared multiple instances, you can use FB calls without specifying an instance DB.

Example: If the static variable "Name: Motor_1 , Data type: FB20" is defined, the instance can be called as follows:

```
Call Motor_1      // Call of FB20 without instance DB
```

10.4 General Notes on Entering Statements and Comments


10.4.1 Structure of the Code Section

In the code section you program the sequence for your logic block by entering the appropriate statements in networks, depending on the programming language chosen. After a statement is entered, the editor runs an immediate syntax check and displays any errors in red and italics.

The code section for a logic block generally comprises a number of networks that are made up of a list of statements.


In a code section you can edit the block title, block comments, network title, network comments, and statement lines within the networks.

Structure of the Code Section Using the STL Programming Language as an Example



10.4.2 Procedure for Entering Statements

You can edit the parts of the code section in any order. We recommend you proceed as follows when you program a block for the first time:



You can make changes in either overwrite mode or insert mode. You switch between modes using the `INSERT` key.

10.4.3 Entering Shared Symbols in a Program

Using the menu command **Insert > Symbol** you can insert symbols in the code section of your program. If the cursor is positioned at the beginning, the end, or within a string, the symbol is already selected that starts with this string - if such a symbol exists. If you change the string, the selection is updated in the list.

Separators for the beginning and end of a string are, for example, blank, period, colon. No separators are interpreted within shared symbols.

To enter symbols, proceed as follows:

1. Enter the first letter of the required symbol in the program.
2. Press CTRL and J simultaneously to display a list of symbols. The first symbol starting with the letter you entered is already selected.
3. Enter the symbol by pressing RETURN or select another symbol.

The symbol enclosed in quotation marks is then entered instead of the first letter.

In general the following applies: if the cursor is located at the beginning, the end, or within a string, this string is replaced by the symbol enclosed in quotation marks when inserting a symbol.

10.4.4 Title and Comments for Blocks and Networks

Comments make your user program easier to read and therefore make commissioning and troubleshooting easier and more effective. They are an important part of the program documentation and should certainly be made use of.

Comments in LAD, FBD and STL Programs

The following comments are available:

- Block title: title for a block (max. 64 characters)
- Block comment: documents the whole logic block, for example, the purpose of the block
- Network title: title for a network (max. 64 characters)
- Network comment: documents the functions of a single network
- Comment column in the variable detail view: comments the declared local data
- Symbol comment: comments that were entered for an address when its symbolic name was defined in the symbol table.


You can display these comments using the menu command **View > Display with > Symbol Information**.

In the code section of a logic block you can enter the block title and network title, and block comments or network comments.

Block Title or Network Title

To enter a block or network title, position the cursor on the word "Title" to the right of the block name or network name (for example, Network 1: Title:). A text box is opened in which you can enter the title. This can be up to 64 characters long.


Block comments pertain to the whole logic block. There they can comment the function of the block. Network comments pertain to the individual networks and document details about the network.



To assign network titles automatically, select menu command **Options > Settings** and click on the option "Automatic Assignment of Network Title" in the "General" tab. The symbol comment of the first address entered will then be applied as network title.

Block Comments and Network Comments

You can toggle the view of the gray comment fields on and off using the menu command **View > Display with > Comments**. A double-click on the comment field opens the text box in which you can now enter your remarks. You are allowed 64 Kbytes per block for block comments and network comments.



10.4.5 Entering Block Comments and Network Comments

1. Activate the comments with the menu command **View > Display with > Comments** (a check mark is visible in front of the menu command).
2. Position the cursor in the gray field below the block name or below the network name by clicking with the mouse. The gray comment field appears white and has a border.
3. Enter your comment in the open text box. You are allowed 64 Kbytes per block for block comments and network comments.
4. Exit the text box by clicking with the mouse outside the text box, by pressing the TAB key, or using the key combination SHIFT+TAB.
5. If you select the menu command **View > Display with > Comments** again, you can switch off the comments again (the check mark disappears).

10.4.6 Working with Network Templates

When programming blocks, if you would like to use networks multiple times, you can store these networks in a library as network templates, complete with wildcards, if appropriate (for example, for addresses). The library must be available before you create the network template.

Creating a Network Template

Create a new library in the SIMATIC Manager if necessary. Select the menu command **Insert > Program > S7 Program** to insert a program into the library.

1. Open the block that contains the network(s) from which you want to create a network template.
2. In the opened block, replace the title, comment, or addresses with wildcards as required. You can use the strings %00 to %99 as wildcards. Wildcards for addresses are displayed in red. This is not a problem here because you will not be saving the block after you create the network template. You can replace the wildcards later with appropriate addresses when you insert the network template into a block.
3. Select "Network <No.>" of the network(s) you want to include in the network template.
4. Select the menu command **Edit > Create Network Template**.
5. Enter a meaningful comment for each wildcard used in the dialog box displayed.
6. Click the "OK" button.
7. Select the **source file folder** of the S7 program in your network template library in the browser that appears and enter a name for the network template.
8. Confirm your entry by clicking the "OK" button. The network template is stored in the selected library.
9. Close the block without saving it.

Inserting a Network Template in a Program

1. Open the block in which you want to insert the new network.
2. In the opened block, click in the network after which you want to insert a new network based on the network template.
3. Open the "Program Elements" tab (menu command **Insert > Program Elements**).
4. Open the "S7 Program" folder of the relevant library in the catalog.
5. Double-click the network template.
6. In the dialog box, enter the required replacements for the wildcards in the network template.
7. Click the "OK" button. The network template is then inserted after the current network.

Note

You can also drag and drop the template from the tab to the editor window.

10.4.7 Search Function for Errors in the Code Section

Errors in the code section are easy to recognize by their red color. To make it easier to navigate to errors that lie outside the visible area on the screen, the editor offers two search functions **Edit > Go To > Previous Error/Next Error**.

The search for errors goes beyond one network. This means that the whole code section is searched and not just one network or the area currently visible on the screen.

If you activate the status bar using the menu command **View > Status Bar**, notes on the errors found are displayed there.

You can also correct errors and make changes in overwrite mode. You toggle between insert mode and overwrite mode using the INSERT key.

10.5 Editing LAD Elements in the Code Section

10.5.1 Settings for Ladder Logic Programming

Setting the Ladder Logic Layout

You can set the layout for creating programs in the Ladder Logic representation type. The format you select (A4 portrait/landscape/maximum size) affects the number of Ladder elements that can be displayed in one rung.

1. Select the menu command **Options > Customize**.
2. Select the "LAD/FBD" tab in the following dialog box.
3. Select the required format from the "Layout" list box. Enter the required format size.

Settings for Printing

If you want to print out the Ladder code section, you should set the appropriate page format before you start to program the code section.

Settings in the "LAD/FBD" Tab

In the "LAD/FBD" tab which is accessed using the menu command **Options > Customize** you can make basic settings, e.g. concerning layout and address field width.

10.5.2 Rules for Entering Ladder Logic Elements

You will find a description of the Ladder Logic programming language representation in the "Ladder Logic for S7-300/400 - Programming Blocks" manual or in the Ladder Logic online help.

A Ladder network can consist of a number of elements in several branches. All elements and branches must be connected; the left power rail does not count as a connection (IEC 1131-3).

When programming in Ladder you must observe a number of guidelines. Error messages will inform you of any errors you make.

Closing a Ladder Network

Every Ladder network must be closed using a coil or a box. The following Ladder elements must not be used to close a network:

- Comparator boxes
- Coils for midline outputs $_/(#)_ /$
- Coils for positive $_/(P)_ /$ or negative $_/(N)_ /$ edge evaluation

Positioning Boxes

The starting point of the branch for a box connection must always be the left power rail. Logic operations or other boxes can be present in the branch before the box.

Positioning Coils

Coils are positioned automatically at the right edge of the network where they form the end of a branch.

Exceptions: Coils for midline outputs `_(#)_/` and positive `_(P)_/` or negative `_(N)_/` edge evaluation cannot be placed either to the extreme left or the extreme right in a branch. Neither are they permitted in parallel branches.

Some coils require a Boolean logic operation and some coils must not have a Boolean logic operation.

- Coils which require Boolean logic:
 - Output `_()`, set output `_(S)`, reset output `_(R)`
 - Midline output `_(#)_/`, positive edge `_(P)_/`, negative edge `_(N)_/`
 - All counter and timer coils
 - Jump if Not `_(JMPN)`
 - Master Control Relay On `_(MCR<)`
 - Save RLO into BR Memory `_(SAVE)`
 - Return `_(RET)`
- Coils which do not permit Boolean logic:
 - Master Control Relay Activate `_(MCRA)`
 - Master Control Relay Deactivate `_(MCRD)`
 - Open Data Block `_(OPN)`
 - Master Control Relay Off `_(MCR>)`

All other coils can either have Boolean logic operations or not.

The following coils must **not be used as parallel outputs**:

- Jump if Not `_(JMPN)`
- Jump `_(JMP)`
- Call from Coil `_(CALL)`
- Return `_(RET)`

Enable Input/Enable Output

The enable input "EN" and enable output "ENO" of boxes can be connected but this is not obligatory.

Removing and Overwriting

If a branch consists of only one element, the whole branch is removed when the element is deleted.

When a box is deleted, all branches which are connected to the Boolean inputs of the box are also removed with the exception of the main branch.

The overwrite mode can be used to simply overwrite elements of the same type.

Parallel Branches

- Draw OR branches from left to right.
- Parallel branches are opened downwards and closed upwards.
- A parallel branch is always opened after the selected Ladder element.
- A parallel branch is always closed after the selected Ladder element.
- To delete a parallel branch, delete all the elements in the branch. When the last element in the branch is deleted, the branch is removed automatically.


Constants

Binary links cannot be assigned constants (i.e. TRUE or FALSE). Instead, use addresses of the data type BOOL.

10.5.3 Illegal Logic Operations in Ladder


Power Flow from Right to Left

No branches may be created which may cause power to flow in the reverse direction. The following figure shows an example: With signal state "0" at I 1.4 a power flow from right to left would result at I 6.8. This is not permitted.



Short Circuit

No branches may be created which cause a short circuit. The following figure shows an example:



10.6 Editing FBD Elements in the Code Section

10.6.1 Settings for Function Block Diagram Programming

Setting the Function Block Diagram Layout

You can set the layout for creating programs in the Function Block Diagram representation type. The format you select (A4 portrait/landscape/maximum size) affects the number of FBD elements that can be displayed in one rung.

1. Select the menu command **Options > Customize**.
2. Select the "LAD/FBD" tab in the following dialog box.
3. Select the required format from the "Layout" list box. Enter the required format size.

Settings for Printing

If you want to print out the FBD code section, you should set the appropriate page format before you start to program the code section.

Settings in the "LAD/FBD" Tab

In the "LAD/FBD" tab which is accessed using the menu command **Options > Customize** you can make basic settings, e.g. concerning layout and address field width.

10.6.2 Rules for Entering FBD Elements

You will find a description of the programming language "FBD" in the "Function Block Diagram for S7-300/400 - Programming Blocks" manual or in the FBD online help.

An FBD network can consist of a number of elements. All elements must be interconnected (IEC 1131-3).

When programming in FBD, you must observe a number of rules. Error messages will inform you of any errors you make.

Entering and Editing Addresses and Parameters

When an FBD element is inserted, the characters ??? and ... are used as token characters for addresses and parameters.


- The red characters ??? stand for addresses and parameters which must be connected.
- The black characters ... stand for addresses and parameters which can be connected.

If you position the mouse pointer on the token characters, the expected data type is displayed.

Positioning Boxes

You can add standard boxes (flip flops, counters, timers, math operations, etc.) to boxes with binary logic operations (&, >=1, XOR). The exceptions to this rule are comparison boxes.

No separate logic operations with separate outputs can be programmed in a network. You can, however, assign a number of assignments to a string of logic operations with the help of a branch. The following figure shows a network with two assignments.



The following boxes can only be placed at the right edge of the logic string where they close the string:

- Set counter value
- Assign parameters and count up, assign parameters and count down
- Assign pulse timer parameters and start, assign extended pulse timer parameters and start
- Assign on-delay/off-delay timer parameters and start

Some boxes require a Boolean logic operation and some boxes must not have a Boolean logic operation.

Boxes which require Boolean logic:

- Output, set output, reset output `_[R]`
- Midline output `_[#]_`, positive edge `_[P]_`, negative edge `_[N]_`
- All counter and timer boxes
- Jump if Not `_[JMPN]`
- Master Control Relay On `_[MCR<]`
- Save RLO into BR Memory `_[SAVE]`
- Return `_[RET]`

Boxes which do not permit Boolean logic:

- Master Control Relay Activate [MCRA]
- Master Control Relay Deactivate [MCRD]
- Open Data Block [OPN]
- Master Control Relay Off [MCR>]

All other boxes can either have Boolean logic operations or not.

Enable Input/Enable Output

The enable input "EN" and enable output "ENO" of boxes can be connected but this is not obligatory.

Removing and Overwriting

When a box is deleted, all branches which are connected to the Boolean inputs of the box are also removed with the exception of the main branch.

The overwrite mode can be used to simply overwrite elements of the same type.

Constants

Binary links cannot be assigned constants (i.e. TRUE or FALSE). Instead, use addresses of the data type BOOL.

10.7 Editing STL Statements in the Code Section

10.7.1 Settings for Statement List Programming

Setting the Mnemonics

You can choose between two sets of mnemonics:

- German
- English.

You set the mnemonics in the SIMATIC Manager with the menu command **Options > Customize** in the "Language" tab before opening a block. While editing a block you cannot change the mnemonics.

You edit the **block properties** in their own dialog box.

In the editor you can have a number of blocks open and edit them alternately as required.

10.7.2 Rules for Entering STL Statements

You will find a description of the Statement List programming language representation in the "Statement List for S7-300/400 - Programming Blocks" manual or in the STL online help (Language Descriptions).

When you enter statements in STL in incremental input mode, you must observe the following basic guidelines:

- The order in which you program your blocks is important. Called blocks must be programmed before calling blocks.
- A statement is made up of a label (optional), instruction, address, and comment (optional).
Example: M001: A I 1.0 //Comment
- Every statement has its own line.
- You can enter up to 999 networks in a block.
- Each network can have up to approximately 2000 lines. If you zoom in or out, you can enter more or fewer lines accordingly.
- When entering instructions or absolute addresses, there is no distinction made between lower and upper case.

10.8 Updating Block Calls

You can use the menu command **Edit > Block Call > Update** in "LAD/STL/FBD - Programming S7 Blocks" to automatically update block calls which have become invalid. After you have carried out the following interface changes, you must perform an update:

- Inserted new formal parameters
- Deleted formal parameters
- Changed the name of formal parameters
- Changed the type of formal parameters
- Changed the order of formal parameters.

When assigning formal and actual parameters, you must follow the following rules in the order specified:

1. **Same parameter names:**
The actual parameters are assigned automatically, if the name of the formal parameter has remained the same.
Special case: In Ladder Logic and Function Block Diagram, the preceding link for binary input parameters can only be assigned automatically if the data type (BOOL) is the same. If the data type has been changed, the preceding link is retained as an open branch.
2. **Same parameter data types:**
After the parameters with the same name have been assigned, as yet unassigned actual parameters are assigned to formal parameters with the same data type as the "old" formal parameter.
3. **Same parameter position:**
After you have carried out rules 1 and 2, any actual parameters which have still not been assigned are now assigned to the formal parameters according to their parameter position in the "old" interface.
4. If actual parameters cannot be assigned using the three rules described above, they are deleted or, in the case of binary preceding links in Ladder Logic or Function Block Diagram, they are retained as open branches.

After carrying out this function, check the changes you have made in the variable declaration table and in the code section of the program.

10.8.1 Changing Interfaces

You can also use the incremental Editor to modify the interfaces of offline blocks that have been edited with STEP 7, version 5:

1. Make sure that all the blocks have been compiled with STEP 7, version 5. To do this, generate a source file for all the blocks and compile it.
2. Modify the interface of the relevant block.
3. Now open all the calling blocks one after another - the corresponding calls are displayed in red.
4. Select the menu command **Edit > Block Call > Update**.
5. Generate the relevant instance data blocks again.

Note

- Interface changes to a block opened online may cause the CPU to go into STOP mode.
 - Rewiring block calls
First modify the numbers of the called blocks and then execute the **Rewire** function to match up the calls.
-

10.9 Saving Logic Blocks

To enter newly created blocks or changes in the code section of logic blocks or in declaration tables in the programming device database, you must save the respective block. The data are then written to the hard disk of the programming device.

To save blocks on the hard disk of the programming device:

1. Activate the working window of the block you want to save.
2. Select one of the following menu commands:
 - **File > Save** saves the block under the same name.
 - **File > Save As** saves the block under a different S7 user program or under a different name. Enter the new path or new block name in the dialog box which then appears.

In both cases the block is saved only if its syntax contains no errors. Syntax errors are identified immediately when the block is created and are then displayed in red. These errors must be corrected before the block can be saved.

Note

- You can also save blocks or source files beneath other projects or libraries in the SIMATIC Manager (by dragging & dropping, for example).
 - You can only save blocks or complete user programs to a memory card in the SIMATIC Manager.
 - If problems occur when saving or compiling large blocks, you should reorganize the project. Use the menu command **File > Reorganize** in the SIMATIC Manager to do this. Then try to save or compile again.
-

11 Creating Data Blocks

11.1 Basic Information on Creating Data Blocks

The data block (DB) is a block in which you can, for example, store values for your machine or plant to access. In contrast to a logic block that is programmed with one of the programming languages Ladder Logic, Statement List, or Function Block Diagram, a data block contains only the variable declaration section. This means the code section is irrelevant here and so is programming networks.

When you open a data block, you can either view the block in the declaration view or in the data view. You can toggle between the two views with the menu commands **View > Declaration View** and **View > Data View**.

Declaration View

You use the declaration view if you want to:

- View or determine the data structure of shared data blocks,
- View the data structure of data blocks with an associated user-defined data type (UDT), or
- View the data structure of data blocks with an associated function block (FB).

The structure of data blocks that are associated with a function block or user-defined data type cannot be modified. To modify them you must first modify the associated FB or UDT and then create a new data block.

Data View

You use the data view if you want to modify data. You can only display, enter, or change the actual value of each element in the data view. In the data view of data blocks, the elements of variables with complex data types are listed individually with their full names.

Differences between Instance Data Blocks and Shared Data Blocks

A shared data block is not assigned to a logic block. It contains values required by the plant or machine and can be called directly at any point in the program.

An instance data block is a block that is assigned directly to a logic block, such as a function block. The instance data block contains the data that were stored in a function block in the variable declaration table.

11.2 Declaration View of Data Blocks

With data blocks which are not globally shared, the declaration view cannot be changed.

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable when you finish entering a declaration.
Declaration	This column is only displayed for instance data blocks. It shows you how the variables in the variable declaration of the function block are declared: <ul style="list-style-type: none"> • Input parameter (IN) • Output parameter (OUT) • In/out parameter (IN_OUT) • Static data (STAT)
Name	Enter the symbolic name you have to assign to each variable here.
Type	Enter the data type you want to assign to the variable (BOOL, INT, WORD, ARRAY, etc.). The variables can have elementary data types, complex data types, or user-defined data types.
Initial Value	Here you can enter the initial value if you do not want the software to use the default value for the data type entered. All values must be compatible with the data type. When you save a block for the first time, the initial value is used as the current value if you have not explicitly defined actual values for the variables. Please note: Initial values cannot be downloaded to the CPU.
Comment	Enter a comment in this field helps to document the variables. The comment can have up to 79 characters.

11.3 Data View of Data Blocks

The data view shows you the current values of all variables in the data block. You can only change these values in the data view. The table representation in this view is the same for all shared data blocks. For instance data blocks an additional "Declaration" column is displayed.

For variables with complex data types or user-defined data types, all elements are displayed in their own row with their full symbolic name in the data view. If the elements are in the IN_OUT area of an instance data block, the pointer points to the complex or user-defined data type in the "Actual Value" column.

The data view displays the following columns:

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable.
Declaration	This column is only displayed for instance data blocks. It shows you how the variables in the variable declaration of the function block are declared: <ul style="list-style-type: none"> • Input parameter (IN) • Output parameter (OUT) • In/out parameter (IN_OUT) • Static data (STAT)
Name	The symbolic name assigned in the variable declaration for the variable. You cannot edit this field in the data view.
Type	Displays the data type defined for the variable. For shared data blocks, only the elementary data types are listed here because the elements are listed individually in the data view for variables with complex or user-defined data types. For instance data blocks the parameter types are also displayed, for in/out parameters (IN_OUT) with complex or user-defined data types, a pointer points to the data type in the "Actual Value" column.
Initial Value	The initial value that you entered for the variable if you do not want the software to use the default value for the specified data type. When you save a data block for the first time, the initial value is used as the current value if you have not explicitly defined actual values for the variables. Please note: Unlike with actual values, initial values cannot be downloaded to the CPU.
Actual Value	Offline: The value that the variable had when the data block was opened or to which you last changed it and saved it (even if you opened the data block online, this display is not updated). Online: The current value on opening the data block is displayed but not updated automatically. To update the view, press F5. You can edit this field if it does not belong to an in/out parameter (IN_OUT) with a complex or user-defined data type. All values must be compatible with the data type. Please note. Only current values can be downloaded to the CPU/
Comment	The comment entered to document the variable. You cannot edit this field in the data view.

11.4 Editing and Saving Data Blocks

11.4.1 Entering the Data Structure of Shared Data Blocks

If you open a data block which is not assigned to a user-defined data type or function block, you can define its structure in the declaration view of the data block. With data blocks which are not shared, the declaration view cannot be changed.

1. Open a shared data block, meaning a block which is not associated with a UDT or FB.
2. Display the declaration view of the data block if this view is not set already.
3. Define the structure by filling out the table displayed in accordance with the information below.

With data blocks which are not shared, the declaration view cannot be modified.

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable when you finish entering a declaration.
Name	Enter the symbolic name you have to assign to each variable here.
Type	Enter the data type you want to assign to the variable (BOOL, INT, WORD, ARRAY, etc.). The variables can have elementary data types, complex data types, or user-defined data types.
Initial Value	Here you can enter the initial value if you do not want the software to use the default value for the data type entered. All values must be compatible with the data type. When you save a block for the first time, the initial value is used as the actual value if you have not explicitly defined actual values for the variables.
Comment	Entering an optional comment in this field helps to document the variable. The comment can have up to 80 characters.

11.4.2 Entering and Displaying the Data Structure of Data Blocks Referencing an FB (Instance DBs)

Input

When you associate a data block with a function block (instance DB), the variable declaration of the function block defines the structure of the data block. Any changes can only be made in the associated function block.

1. Open the associated function block (FB).
2. Edit the variable declaration of the function block.
3. Create the instance data block again.

Display

In the declaration view of the instance data block you can display how the variables in the function block were declared.

1. Open the data block.
2. Display the declaration view of the data block if this view is not set already.
3. See below for more information on the table displayed.

With data blocks which are not shared, the declaration view cannot be changed.

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable.
Declaration	<p>This column shows you how the variables in the variable declaration of the function block are declared:</p> <ul style="list-style-type: none"> • Input parameter (IN) • Output parameter (OUT) • In/out parameter (IN_OUT) • Static data (STAT) <p>The declared temporary local data of the function block are not in the instance data block.</p>
Name	The symbolic name assigned in the variable declaration of the function block.
Type	Displays the data type assigned in the variable declaration of the function block. The variables can have elementary data types, complex data types, or user-defined data types. If additional function blocks are called within the function block for whose call static variables have been declared, a function block or a system function block (SFB) can also be specified here as the data type.
Initial Value	<p>The initial value that you entered for the variable in the variable declaration of the function block if you do not want the software to use the default value.</p> <p>When you save a data block for the first time, the initial value is used as the actual value if you have not explicitly defined actual values for the variables.</p>
Comment	The comment entered in the variable declaration for the function block to document the data element. You cannot edit this field.

Note

For data blocks that are assigned to a function block, you can only edit the actual values for the variables. To enter actual values for the variables, you must be in the data view of data blocks.

11.4.3 Entering the Data Structure of User-Defined Data Types (UDT)

1. Open the user-defined data type (UDT).
2. Display the declaration view if this view is not set already.
3. Define the structure of the UDT by determining the sequence of variables, their data type, and an initial value if required using the information in the table below.
4. You complete the entry of a variable by exiting the row with the TAB key or RETURN.

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable when you finish entering a declaration.
Name	Enter the symbolic name you have to assign to each variable here.
Type	Enter the data type you want to assign to the variable (BOOL, INT, WORD, ARRAY, etc.). The variables can have elementary data types, complex data types, or their own user-defined data types.
Initial Value	Here you can enter the initial value if you do not want the software to use the default value for the data type entered. All values must be compatible with the data type. When you save an instance of the user-defined data type (or a variable, or a data block) for the first time, the initial value is used as the actual value if you have not explicitly defined actual values for the variables.
Comment	Entering a comment in this field helps to document the variables. The comment can have up to 80 characters.

11.4.4 Entering and Displaying the Structure of Data Blocks Referencing a UDT

Input

When you assign a data block to a user-defined data type, the data structure of the user-defined data type defines the structure of the data block. Any changes can only be made in the associated user-defined data type.

1. Open the user-defined data type (UDT).
2. Edit the structure of the user-defined data type.
3. Create the data block again.

Display

You can only display how the variables were declared in the user-defined data type in the declaration view of the data block.

1. Open the data block.
2. Display the declaration view of the data block if this view is not set already.
3. See below for more information on the table displayed.

The declaration view cannot be modified. Any changes can only be made in the associated user-defined data type.

Column	Explanation
Address	Displays the address which STEP 7 automatically assigns for the variable.
Name	The symbolic name assigned in the variable declaration of the user data type.
Type	Displays the data types assigned in the variable declaration of the user-defined data type. The variables can have elementary data types, complex data types, or user-defined data types.
Initial Value	The initial value that you entered for the variable in the user-defined data type if you do not want the software to use the default value. When you save a data block for the first time, the initial value is used as the actual value if you have not explicitly defined actual values for the variables.
Comment	The comment entered in the variable declaration for the user-defined data type to document the data element.

Note

For data blocks that are assigned to a user-defined data type, you can only edit the actual values for the variables. To enter actual values for the variables, you must be in the data view of data blocks.

11.4.5 Editing Data Values in the Data View

Editing actual values is only possible in the data view of data blocks.

1. If necessary, toggle to the table display in the data view using the menu command **View > Data View**.
2. Enter the required actual values for the data elements in the fields of the column "Actual Value." The actual values must be compatible with the data type of the data elements.

Any incorrect entries (for example, if an actual value entered is not compatible with the data type) made during editing are recognized immediately and shown in red. These errors must be corrected before saving the data block.

Note

Any changes to the data values are only retained once the data block has been saved.

11.4.6 Resetting Data Values to their Initial Values

Resetting data values is only possible in the data view of data blocks.

1. If necessary, toggle to the table display in the data view using the menu command **View > Data View**.
2. Select the menu command **Edit > Initialize Data Block** to do this.

All variables are assigned their intended initial value again, meaning the actual values of all variables are overwritten by their respective initial value.

Note

Any changes to the data values are only retained once the data block has been saved.

11.4.7 Saving Data Blocks

To enter newly created blocks or changed data values in data blocks in the programming device database, you must save the respective block. The data are then written to the hard disk of the programming device.

To save blocks on the hard disk of the programming device:

1. Activate the working window of the block you want to save.
2. Select one of the following menu commands:
 - **File > Save** saves the block under the same name.
 - **File > Save As** saves the block under a different S7 user program or under a different name. Enter the new path or new block name in the dialog box which then appears. With data blocks, you may not use the name DB0 because this number is reserved for the system.

In both cases the block is saved only if its syntax contains no errors. Syntax errors are identified immediately when the block is created and are then displayed in red. These errors must be corrected before the block can be saved.

Note

- You can also save blocks or source files beneath other projects or libraries in the SIMATIC Manager (by dragging & dropping, for example).
 - You can only save blocks or complete user programs to a memory card in the SIMATIC Manager.
 - If problems occur when saving or compiling large blocks, you should reorganize the project. Use the menu command **File > Reorganize** in the SIMATIC Manager to do this. Then try to save or compile again.
-

12 Parameter Assignment for Data Blocks

The function "Parameter Assignment for Data Blocks" allows you to do the following outside the LAD/STL/FBD program editor:

- Edit and download the actual values of instance data blocks to the PLC, without having to load the entire data block.
- Monitor instance data blocks online.
- Use the "S7_techparam" system attribute (Technological Functions) to easily assign parameters to instance data blocks and multiple instances and monitor them online.

Procedure:

1. In the SIMATIC Manager, double-click the instance data block to open it.
2. Answer the prompt asking if you want to open the function "Parameter Assignment for Data Blocks" with "Yes". **Result:** the instance DB is opened in the "Parameter Assignment for Data Blocks" application.
3. Choose the view in which the data block should be displayed by selecting the menu command **View > Data View** or **View > Declaration View**. In the case of instance data blocks or multiple instances with the "S7_techparam" system attribute, the "technological parameters" view is automatically opened.
4. Edit the instance data block as needed. Any pertinent information, warnings or errors will be displayed in the message window. To go to the location of a warning or error, double-click on the corresponding warning or error.
5. Download the changed actual value from the programming device (PG) to the CPU that you have assigned to the current S7 program (menu command **PLC > Download Parameter Setting Data**).
6. Select the menu command **Debug > Monitor** to display the program status for the opened blocks and then monitor the editing of the loaded actual values online.

Note

You can recognize data blocks that have the "S7_techparam" system. To determine whether a block has this system attribute, go to the SIMATIC Manager and select the block. Then select the menu command **Edit > Object Properties** and open the "Attributes" tab.

12.1 Assigning Parameters to Technological Functions

With the function "Parameter Assignment for Data Blocks" you can easily assign parameters to the temperature controller blocks FB 58 "TCONT_CP" and FB 59 "TCONT_S" that are supplied in the standard library and monitor them online.

To do so, proceed as follows:

1. In the SIMATIC Manager, open the STEP 7 standard library by selecting the menu command **File > Open > Libraries**.
2. Select "PID Control Blocks" and then click on "Blocks". Here you will find the following function blocks with the attribute "S7_techparam":
 - **FB 58 "TCONT_CP"**: Temperature controller for actuators with continuous or pulsing input signals
 - **FB 59 "TCONT_S"**: Temperature controller for integral-type actuators
3. Copy the appropriate function block (FB 58 or FB 59) from the standard library into your project.
4. Select the menu command **Insert > S7 Block > Data Block** to create an instance DB for the FB that you selected.
5. In the SIMATIC Manager, double-click the instance DB to open it and start the function "Parameter Assignment for Data Blocks".
Result: The instance DB is opened in the technological view. You can now easily assign parameters to the instance DB and monitor it online.
6. Enter suitable controller values in the technological view. Any pertinent information, warnings or errors will be displayed in the message window. To go to the location of a warning or error, double-click on the corresponding warning or error.

Note

You can determine if blocks that have the system attribute "S7_techparam" by selecting a block in the SIMATIC Manager, selecting the menu command **Edit > Object Properties** and then opening the "Attributes" tab.

13 Creating STL Source Files

13.1 Basic Information on Programming in STL Source Files

You can enter your program or parts of it as an STL source file and then compile it into blocks in one step. The source file can contain the code for a number of blocks, which are then compiled as blocks in one compilation run.

Creating programs using a source file has the following advantages:

- You can create and edit the source file with any ASCII editor, then import it and compile it into blocks using this application. The compilation process creates the individual blocks and stores them in the S7 user program.
- You can program a number of blocks in one source file.
- You can save a source file even if it contains syntax errors. This is not possible if you create logic blocks using an incremental syntax check. However, the syntax errors are only reported once you compile the source file.

The source file is created in the syntax of the programming language representation Statement List (STL). The source file is given its structure of blocks, variable declaration, and networks using keywords.

When you create blocks in STL source files you should note the following:

- Guidelines for Programming STL Source Files
- Syntax and Formats for Blocks in STL Source Files
- Structure of Blocks in STL Source Files

13.2 Rules for Programming in STL Source Files

13.2.1 Rules for Entering Statements in STL Source Files

An STL source file consists mainly of continuous text. To enable the file to be compiled into blocks, you must observe certain structures and syntax rules.

The following general guidelines apply to creating user programs as STL source files:

Topic	Rule
Syntax	The syntax of the STL statements is the same as in the incremental Statement List editor. One exception to this is the CALL instruction.
CALL	<p>In a source file, you enter parameters in brackets. The individual parameters are separated by a comma.</p> <p>Example: FC call (one line) CALL FC10 (param1 :=I0.0,param2 :=I0.1);</p> <p>Example: FB call (one line) CALL FB10, DB100 (para1 :=I0.0,para2 :=I0.1);</p> <p>Example: FB call (more than one line) CALL FB10, DB100 (para1 :=I0.0, para2 :=I0.1);</p> <p>Note: When calling a block, transfer the parameters in the defined order in the ASCII Editor. Otherwise the comment assignment for these lines may not match in the STL and source file views.</p>
Upper/lower case	<p>The editor in this application is not case-sensitive, the exception to this being system attributes and jump labels. When entering strings (data type STRING) you must also observe upper and lower case.</p> <p>Keywords are shown in upper case. When compiled, upper and lower case are not observed; therefore you can enter keywords in upper or lower case or a mixture of the two.</p>
Semicolon	Designate the end of every STL statement and every variable declaration with a semicolon (;). You can enter more than one statement per line.
Double slash (//)	Begin every comment with a double slash (//) and end the comment with RETURN (or line feed).

13.2.2 Rules for Declaring Variables in STL Source Files

For every block in the source file you must declare the required variables.

The variable declaration section comes before the code section of the block.

The variables must - if they are being used - be declared in the correct sequence for declaration types. This means all variables of one declaration type are together.

For Ladder, Function Block Diagram, and Statement List you fill out a variable declaration table, but here you have to work with the relevant keywords.

Keywords for Variable Declaration

Declaration Type	Keywords	Valid for...
Input parameters	"VAR_INPUT" Declaration list "END_VAR"	FBs, FCs
Output parameters	"VAR_OUTPUT" Declaration list "END_VAR"	FBs, FCs
In/out parameters	"VAR_IN_OUT" Declaration list "END_VAR"	FBs, FCs
Static variables	"VAR" Declaration list "END_VAR"	FBs
Temporary variables	"VAR_TEMP" Declaration list END_VAR	OBs, FBs, FCs

The keyword END_VAR denotes the end of a declaration list.

The declaration list is a list of the variables of a declaration type in which default values can be assigned to the variables (exception: VAR_TEMP). The following example shows the structure of an entry in the declaration list:

Duration_Motor1 : S5TIME := S5T#1H_30M ;

Variable	Data type	Default value
----------	-----------	---------------

Note

- The variable symbol must start with a letter. You may not assign a symbolic name for a variable that is the same as one of the reserved keywords.
- If variable symbols are identical in the local declarations and in the symbol table, you can code local variables by placing # in front of the name and putting variables in the symbol table in quotation marks. Otherwise, the block interprets the variable as a local variable.

13.2.3 Rules for Block Order in STL Source Files

Called blocks precede the calling blocks. This means:

- The OB1 used in most cases, which calls other blocks, comes last. Blocks that are called from OB1 must precede it.
- User-defined data types (UDT) precede the blocks in which they are used.
- Data blocks with an associated user-defined data type (UDT) follow the user-defined data type.
- Shared data blocks precede all blocks from which they are called.
- Instance data blocks follow the associated function block.
- DB0 is reserved. You cannot create a data block with this name.

13.2.4 Rules for Setting System Attributes in STL Source Files

System attributes can be assigned to blocks and parameters. They control the message configuration and connection configuration, operator interface functions, and process control configuration.

The following applies when entering system attributes in source files:

- The keywords for system attributes always start with S7_.
- The system attributes are placed in braces (curly brackets).
- Syntax: {S7_identifier := 'string'}
a number of identifiers are separated by ";".
- System attributes for blocks come before the block properties and after the keywords ORGANIZATION_ and TITLE.
- System attributes for parameters are included with the parameter declaration, meaning before the colon for the data declaration.
- A distinction is made between upper and lower case characters. This means that the correct use of upper and lower case characters is important when entering system attributes.

The system attributes for blocks can be checked or changed in incremental input mode using the menu command **File > Properties** under the "Attributes" tab.

The system attributes for parameters can be checked or changed in incremental input mode using the menu command **Edit > Object Properties**. The cursor must be positioned in the name field of the parameter declaration.

13.2.5 Rules for Setting Block Properties in STL Source Files

You can more easily identify the blocks you created if you use block properties and you can also protect these blocks from unauthorized changes.

The block properties can be checked or changed in incremental input mode using the menu command **File > Properties** under the "General - Part 1" and "General - Part 2" tabs.

The other block properties can only be entered in the source file.

The following applies in source files:

- Block properties precede the variable declaration section.
- Each block property has a line of its own.
- The line ends with a semicolon.
- The block properties are specified using keywords.
- If you enter block properties, they must appear in the sequence shown in the Table of Block Properties.
- The block properties valid for each block type are listed in the Assignment: Block Property to Block Type.

Note

The block properties are also displayed in the SIMATIC Manager in the object properties for a block. The properties AUTHOR, FAMILY, NAME, and VERSION can also be edited there.

Block Properties and Block Order

When entering block properties, you should observe the input sequence shown in the following table:

Order	Keyword / Property	Meaning	Example
1.	[KNOW_HOW_PROTECT]	Block protection; a block compiled with this option does not allow its code section to be viewed. The interface for the block can be viewed, but it cannot be changed.	KNOW_HOW_PROTECT
2.	[AUTHOR:]	Name of author: company name, department name, or other name (max. 8 characters without blanks)	AUTHOR : Siemens, but no keyword
3.	[FAMILY:]	Name of block family: for example, controllers (max. 8 characters without blanks)	FAMILY : controllers, but no keyword
4.	[NAME:]	Block name (max. 8 characters)	NAME : PID, but no keyword
5.	[VERSION: int1 . int2]	Version number of block (both numbers between 0 and 15, meaning 0.0 to 15.15)	VERSION : 3.10
6.	[CODE_VERSION1]	ID whether a function block can have multiple instances declared or not. If you want to declare multiple instances, the function block should not have this property	CODE_VERSION1
7.	[UNLINKED] for DBs only	Data blocks with the UNLINKED property are only stored in the load memory. They take up no space in the working memory and are not linked to the program. They cannot be accessed with MC7 commands. The contents of such a DB can be transferred to the working memory only with SFC 20 BLKMOV (S7-300. S7-400) or SFC 83 READ_DBL (S7-300C).	
8.	[READ_ONLY] for DBs only	Write protection for data blocks; its data can only be read and cannot be changed	FAMILY= Examples VERSION= 3.10 READ_ONLY

13.2.6 Permitted Block Properties for Each Block Type

The following table shows which block properties can be declared for which block types:

Property	OB	FB	FC	DB	UDT
KNOW_HOW_PROTECT	•	•	•	•	–
AUTHOR	•	•	•	•	–
FAMILY	•	•	•	•	–
NAME	•	•	•	•	–
VERSION	•	•	•	•	–
UNLINKED	–	–	–	•	–
READ_ONLY	–	–	–	•	–

Setting Block Protection with KNOW_HOW_PROTECT

You can protect your blocks from unauthorized users by setting block protection using the keyword `KNOW_HOW_PROTECT` when you program the block in the STL source file.

This block protection has the following consequences:

- If you want to view a compiled block at a later stage in the incremental STL, FBD, or Ladder editors, the code section of the block cannot be displayed.
- The variable declaration list for the block displays only the variables of the declaration types `var_in`, `var_out`, and `var_in_out`. The variables of the declaration types `var_stat` and `var_temp` remain hidden.
- The keyword `KNOW_HOW_PROTECT` is entered before any other block properties.

Setting Write Protection for Data Blocks with READ_ONLY

For data blocks, you can set up write protection so that the block is not overwritten during program processing. The data block must exist in the form of an STL source file to do this.

Use the keyword `READ_ONLY` in the source file to set write protection. This keyword must appear immediately before the variable declarations in a line on its own.

13.3 Structure of Blocks in STL Source Files

The blocks in STL source files are structured using keywords. Depending on the type of block, there are differences in the structure of:

- Logic blocks

- Data blocks
- User-defined data types (UDT)

13.3.1 Structure of Logic Blocks in STL Source Files

A logic block is made up of the following sections, each of which is identified by the corresponding keyword:

- Block start,
 - identified by keyword and block number or block name, for example
 - "ORGANIZATION_BLOCK OB1" for an organization block,
 - "FUNCTION_BLOCK FB6" for a function block, or
 - "FUNCTION FC1 : INT" for a function. With functions the function type is also specified. This can be an elementary or complex data type (with the exception of ARRAY and STRUCT) and defines the data type of the return value (RET_VAL). If no value is to be returned, the keyword VOID is given.
- Optional block title introduced by the keyword "TITLE" (max. length of title: 64 characters)
- Additional comments, beginning with a double slash // at the start of the line
- Block properties (optional)
- Variable declaration section
- Code section, beginning with "BEGIN." The code section consists of one or more networks that are identified by "NETWORK." You cannot enter a network number.
- Optional network for each network used, introduced by the keyword "TITLE =" (max. length of title: 64 characters)
- Additional comments for each network, beginning with a double slash // at the start of the line
- Block end, identified by END_ORGANIZATION_BLOCK, END_FUNCTION_BLOCK, or END_FUNCTION
- A blank must be placed between the block type and the block number. The symbolic block name can be identified by quotation marks to ensure that the symbolic names of local variables and names in the symbol table remain unique.

13.3.2 Structure of Data Blocks in STL Source Files

A data block consists of the following areas that are introduced by their respective keywords:

- Block start, identified by keyword and block number or block name, for example, DATA_BLOCK DB26
- Reference to an associated UDT or function block (optional)
- Optional block title introduced by the keyword TITLE = (entries longer than 64 characters are cut off)
- Optional block comment, beginning with a double slash //
- Block properties (optional)
- Variable declaration section (optional)
- Assignment section with default values, beginning with BEGIN (optional)
- Block end, identified by END_DATA_BLOCK

There are three types of data block:

- Data blocks, user-defined
- Data blocks with an associated user-defined data type (UDT)
- Data blocks with an associated function block (known as "instance" data blocks)

13.3.3 Structure of User-Defined Data Types in STL Source Files

A user-defined data type consists of the following areas that are introduced by their respective keywords:

- Block start, identified by keyword TYPE and number or name, for example, TYPE UDT20
- Structured data type
- Block end, identified by END_TYPE

When you enter a user-defined data type, you must ensure that user-defined data types precede the blocks in which they are used.

13.4 Syntax and Formats for Blocks in STL Source Files

The format tables show the syntax and formats that you should observe when programming STL source files. The syntax is represented as follows:

- Each element is described in the right column.
- Any elements that must be entered are shown in quotation marks.
- The square brackets [...] mean that the contents of these brackets are optional.
- Keywords are given in upper case letters.

13.4.1 Format Table of Organization Blocks

The following table shows a brief list of the format for organization blocks in an STL source file:

Structure	Description
"ORGANIZATION_BLOCK" ob_no or ob_name	ob_no is the block number, for example: OB1; ob_name is the symbolic name of the block as defined in the symbol table
[TITLE=]	Block title (entries longer than 64 characters are cut off)
[Block comment]	Comments can be entered after "///"
[System attributes for blocks]	System attributes for blocks
[Block properties]	Block properties
Variable declaration section	Declaration of temporary variables
"BEGIN"	Keyword to separate the variable declaration section from the list of STL instructions
NETWORK	Start of a network
[TITLE=]	Network title (max. 64 characters)
[Network comment]	Comments can be entered after "///"
List of STL instructions	Block instructions
"END_ORGANIZATION_BLOCK"	Keyword to end organization block

13.4.2 Format Table of Function Blocks

The following table shows a brief list of the format for function blocks in an STL source file:

Structure	Description
"FUNCTION_BLOCK" fb_no or fb_name	fb_no is the block number, for example FB6; fb_name is the symbolic name of the block as defined in the symbol table
[TITLE=]	Block title (entries longer than 64 characters are cut off)
[Block comment]	Comments can be entered after "//"
[System attributes for blocks]	System attributes for blocks
[Block properties]	Block properties
Variable declaration section	Declaration of input, output, and in/out parameters, and temporary or static variables The declaration of the parameters may also contain the declarations of the system attributes for parameters.
"BEGIN"	Keyword to separate the variable declaration section from the list of STL instructions
NETWORK	Start of a network
[TITLE=]	Network title (max. 64 characters)
[Network comment]	Comments can be entered after "//"
List of STL instructions	Block instructions
"END_FUNCTION_BLOCK"	Keyword to end function block

13.4.3 Format Table of Functions

The following table shows a brief list of the format for functions in an STL source file:

Structure	Description
"FUNCTION" fc_no : fc_type or fc_name : fc_type	fc_no is the block number, for example FC5; fc_name is the symbolic name of the block as defined in the symbol table; fc_type is the data type of the return value (RET_VAL) of the function. This can be an elementary or complex data type (with the exception of ARRAY and STRUCT) or VOID. If you want to use system attributes for the return value (RET_VAL), you must enter the system attributes for parameters in front of the colon for the data declaration.
[TITLE=]	Block title (entries longer than 64 characters are cut off)
[Block comment]	Comments can be entered after "///"
[System attributes for blocks]	System attributes for blocks
[Block properties]	Block properties
Variable declaration section	Declaration of input, output, and in/out parameters, and temporary variables
"BEGIN"	Keyword to separate the variable declaration section from the list of STL instructions
NETWORK	Start of a network
[TITLE=]	Network title (max. 64 characters)
[Network comment]	Comments can be entered after "///"
List of STL instructions	Block instructions
"END_FUNCTION"	Keyword to end function

13.4.4 Format Table of Data Blocks

The following table shows a brief list of the format for data blocks in an STL source file:

Structure	Description
"DATA_BLOCK" db_no or db_name	db_no is the block number, for example DB5; db_name is the symbolic name of the block as defined in the symbol table
[TITLE=]	Block title (entries longer than 64 characters are cut off)
[Block comment]	Comments can be entered after "/*"
[System attributes for blocks]	System attributes for blocks
[Block properties]	Block properties
Declaration section	Declaration whether the block is associated with a UDT or an FB, given as a block number or symbolic name as defined in the symbol table, or as a complex data type
"BEGIN"	Keyword to separate the declaration section from the list of value assignments
[Assignment of initial values]	Variables can have specific initial values assigned. Individual variables either have constants assigned or a reference is made to other blocks.
"END_DATA_BLOCK"	Keyword to end data block

13.5 Creating STL Source Files

13.5.1 Creating STL Source Files

The source file must be created in the source file folder beneath the S7 program. You can create source files in the SIMATIC Manager or the editor window.

Creating Source Files in the SIMATIC Manager

1. Open the appropriate "Source Files" folder by double-clicking on it.
2. To insert an STL source file select the menu command **Insert > S7 Software > STL Source File**.

Creating Source Files in the Editor Window

1. Select the menu command **File > New**.
2. In the dialog box, select the source file folder of the same S7 program that contains the user program with the blocks.
3. Enter a name for the new source file.
4. Confirm with "OK".

The source file is created under the name you entered and is displayed in a window for editing.

13.5.2 Editing S7 Source Files

The programming language and editor with which a source file is edited can be set in the object properties for the source file. This ensures that the correct editor and the correct programming language are started when the source file is opened for editing. The STEP 7 Standard package supports programming in STL source files.

Other programming languages are also available as optional packages. You can only select the menu command to insert the source file if the corresponding software option is loaded on your computer.

To edit an S7 source file, proceed as follows:

1. Open the appropriate "Source Files" folder by double-clicking on it.
2. Start the editor required for editing as follows:
 - Double-click the required source file in the right half of the window.
 - Select the required source file in the right half of the window and select the menu command **Edit > Open Object**.

13.5.3 Setting The Layout of Source Code Text

To improve readability of text in source files, select menu command **Options > Settings** and the "Source Code" tab. Specify the font, font style and color for the various elements of the source code.

For example, you can specify to display line numbers and to display keywords in upper case letters.

13.5.4 Inserting Block Templates in STL Source Files

Block templates for organization blocks (OB), function blocks (FB), functions (FC), data blocks (DB), instance data blocks, data blocks with associated user-defined data types, and user-defined data types (UDT) are available for programming in STL source files. The block templates make it easier to enter blocks in your source file and to observe syntax and structure guidelines.

To insert a block template, proceed as follows:

1. Activate the window of the source file in which you want to insert a block template.
2. Position the cursor at the point in the file after which you want to insert the block template.
3. Select one of the menu commands **Insert > Block Template > OB/FB/FC/DB/Instance DB/DB Referencing UDT/UDT**.

The block template is inserted in the file after the cursor position.

13.5.5 Inserting the Contents of Other STL Source Files

You can insert the contents of other source files into your STL source file.

Proceed as follows:

1. Activate the window of the source file in which you want to insert the contents of another source file.
2. Position the cursor at the location in the file after which you want to insert the source file.
3. Select the menu command **Insert > Object > File**.
4. Select the required source file in the dialog box which appears.

The contents of the selected source file are inserted after the cursor position. Line feeds (carriage returns) are retained.

13.5.6 Inserting Source Code from Existing Blocks in STL Source Files

You can insert the source code from other blocks into your STL source file which were created in Ladder, Function Block Diagram, or Statement List. This is possible for organization blocks (OB), function blocks (FB), functions (FC), data blocks (DB), and user-defined data types (UDT).

Proceed as follows:

1. Activate the window of the source file in which you want to insert a block.
2. Position the cursor at the location in the file after which you want to insert the source code from the block.
3. Select the menu command **Insert > Object > Block**.
4. Select the required block in the dialog box which appears.

An equivalent source file is generated from the block. The contents of the source file are inserted after the cursor position.

13.5.7 Inserting External Source Files

You can create and edit a source file with any ASCII editor, then import it into a project and compile it into individual blocks using this application. To do this, you must import the source files into the "Source Files" folder of the S7 program in whose S7 user program the blocks created during compilation are to be stored.

To insert an external source file, proceed as follows:

1. Select the source file folder of the S7 program in which the external source files are to be imported.
2. Select the menu command **Insert > External Source File**.
3. In the dialog box which appears, enter the source file you want to import.

The file name of the source file you are importing must have a valid file extension. STEP 7 uses the file extension to determine the source file type. This means, for example, that STEP 7 creates an STL source file when it imports a file with the extension **.AWL**. Valid file extensions are listed in the dialog box under "File Type."

Note

You can also use the menu command **Insert > External Source File** to import source files you created with STEP 7 version 1.

13.5.8 Generating STL Source Files from Blocks

You can generate an STL source file which you can edit with any text editor from existing blocks. The source file is generated in the source file folder of the S7 program.

To generate a source file from a block, proceed as follows:

1. In the program editor, select the menu command **File > Generate Source File**.
2. In the dialog box, select the source file folder in which you want to create the new source file.
3. Enter a name for the source file in the text box.
4. In the "Select STEP 7 Blocks" dialog box, select the block(s) which you want to generate as the given source file. The selected blocks are displayed in the right list box.
5. Confirm with "OK."

One continuous STL source file is created from the selected blocks and is displayed in a window for editing.

13.5.9 Importing Source Files

To import a source file from any directory into a project:

1. In the SIMATIC Manager, select the source file folder into which you want to import the source file.
2. Select the menu command **Insert > External Source File**.
3. In the dialog box displayed, select the destination directory and the source file to be imported.
4. Click the "Open" button.

13.5.10 Exporting Source Files

To export a source file from a project to any destination directory:

1. Select the source file in the source file folder.
2. Select the menu command **Edit > Export Source File** in the SIMATIC Manager.
3. Enter the destination directory and file name in the dialog box displayed.
4. Click the "Save" button.

Note

If the object name does not have a file extension, a file extension derived from the file type is added to the file name. For example, the STL source file "**prog**" is exported to the file "**prog.awl**."

If the object name already has a valid file extension, this is retained and not changed. For example, the STL source file "**prog.awl**" is exported to the file "**prog.awl**."

If an object name has an invalid file extension (meaning a period is contained in the name), no file extension is added.

You will find a list of valid file extensions in the "Export Source File" dialog box under "File type."

13.6 Saving and Compiling STL Source Files and Executing a Consistency Check

13.6.1 Saving STL Source Files

You can save an STL source file at any time in its current state. The program is not compiled and no syntax check is run, meaning any errors are saved as well.

Syntax errors are detected and reported only when the source file is compiled or following a consistency check.

To save a source file under the same name:

1. Activate the window for the source file you want to save.
2. Select the menu command **File > Save**.

To save a source file under a new name/in another project:

1. Activate the window for the source file you want to save.
2. Select the menu command **File > Save As**.
3. In the dialog box, select the source file folder in which you want to save the source file and enter its new name.

13.6.2 Checking Consistency in STL Source Files

Using the menu command **File > Consistency Check** you can display any syntax errors in the STL source file. In contrast to compiling, no blocks are generated.

When the consistency check is completed, a dialog box is displayed showing you the total number of errors found.

Any errors that are found are listed individually in the lower part of the window with a line reference. Correct these errors before compiling the source file so that all the blocks can be created.

13.6.3 Debugging STL Source Files

The active window for source files is split into two. The following errors are listed in the lower half:

- Errors found after compilation was initiated via menu command **File > Compile**.
- Errors found after a consistency check was initiated via menu command **File > Consistency Check**.

To find the location of an error in a source file, position the cursor on the "Error" tab of the message window. The faulty element is automatically highlighted in the code section and an error message is output at the status bar.

13.6.4 Compiling STL Source Files

Requirements

In order to be able to compile the program you created in a source file into blocks, the following requirements must be fulfilled:

- Only source files which are stored in the "Source Files" folder beneath an S7 program can be compiled.
- As well as the "Source Files" folder, a "Blocks" folder must also lie beneath the S7 program in which the blocks created during compilation can be stored. The blocks programmed in the source file are only created if the source file was compiled without error. If there are a number of blocks programmed in a source file, only those which contain no errors are created. You can then open these blocks, edit them, download them to the CPU, and debug them individually.

Procedure in the Editor

1. Open the source file you want to compile. The source file must be in the source file folder of the S7 program in whose S7 user program the compiled blocks are to be stored.
2. Select the menu command **File > Compile**.
3. The "Compiler Report" dialog box is displayed showing the number of lines compiled and syntax errors found.

The blocks specified for the file are only created once the source file has been compiled without errors. If there are a number of blocks programmed in a source file, only those which contain no errors are created. Warnings of errors do not prevent blocks being created.

Any syntax errors detected during compilation are shown in the lower part of the working window and must be corrected before the respective blocks can be created.

Procedure in the SIMATIC Manager

1. Open the appropriate "Source Files" folder by double-clicking on it.
2. Select one or more source files that you want to compile. You cannot start a compilation run for a closed source file folder to compile all the source files in it.
3. Select the menu command **File > Compile** to start compilation. The correct compiler is called for the source file you selected. The successfully compiled blocks are then stored in the block folder beneath the S7 program. Any syntax errors detected during compilation are displayed in a dialog box and must be corrected so that the blocks where the errors were found can be created as well.

13.7 Examples of STL Source Files

13.7.1 Examples of Declaring Variables in STL Source Files

Variables of Elementary Data Type

```

// Comments are separated from the declaration section by a double slash.
VAR_INPUT // Keyword for input variable
    in1 : INT; // Variable name and type are separated by ":"
    in3 : DWORD; // Every variable declaration is terminated with a semicolon
    in2 : INT := 10; // Optional setting for an initial value in the declaration
END_VAR // End declaration of variables of the same declaration type
VAR_OUTPUT // Keyword for output variable
    out1 : WORD;
END_VAR // Keyword for temporary variable
VAR_TEMP
    temp1 : INT;
END_VAR

```

Variable of Data Type Array

```

VAR_INPUT // Input variable
    array1 : ARRAY [1..20] of INT; // array1 is a one-dimensional array
    array2 : ARRAY [1..20, 1..40] of DWORD; // array2 is a two-dimensional array
END_VAR

```

Variables of Data Type Structure

```

VAR_OUT // Output variable
OUTPUT1: STRUCT // OUTPUT1 has the data type STRUCT
    var1 : BOOL; // Element 1 of the structure
    var2 : DWORD; // Element 2 of the structure
    END_STRUCT; // End of the structure
END_VAR

```

13.7.2 Example of Organization Blocks in STL Source Files

```

ORGANIZATION_BLOCK OB1
TITLE = Example for OB1 with different block calls
//The 3 networks show block calls
//with and without parameters

{S7_pdiag := 'true'} //System attribute for blocks
AUTHOR Siemens
FAMILY Example
NAME Test_OB
VERSION 1.1
VAR_TEMP
Interim value : INT; // Buffer
END_VAR

BEGIN

NETWORK
TITLE = Function call transferring parameters
// Parameter transfer in one line
CALL FC1 (param1 :=I0.0,param2 :=I0.1);

NETWORK
TITLE = Function block call
// transferring parameters
// Parameter transfer in more than one line
CALL Traffic light control , DB6 ( // Name of FB, instance data block
dur_g_p := S5T#10S, // Assign actual values to parameters

del_r_p := S5T#30S,
starter := TRUE,
t_dur_y_car := T 2,
t_dur_g_ped := T 3,
t_delay_y_car := T 4,
t_dur_r_car := T 5,
t_next_red_car := T 6,
r_car := "re_main", // Quotation marks show symbolic
y_car := "ye_main", // names entered in symbol table
g_car := "gr_main",
r_ped := "re_int",
g_ped := "gr_int");

NETWORK
TITLE = Function block call
// transferring parameters
// Parameter transfer in one line
CALL FB10, DB100 (para1 :=I0.0,para2 :=I0.1);

END_ORGANIZATION_BLOCK
    
```

13.7.3 Example of Functions in STL Source Files

```

FUNCTION FC1: VOID
// Only due to call
VAR_INPUT
  param1 : bool;
  param2 : bool;
END_VAR
begin
end_function

FUNCTION FC2 : INT
TITLE = Increment number of items
// As long as the value transferred is < 1000, this function
// increases the transferred value. If the number of items
// exceeds 1000, "-1" is returned via the return value
// for the function (RET_VAL).

AUTHOR          Siemens
FAMILY          Throughput check
NAME           :   INCR_ITEM_NOS
VERSION        :   1.0

VAR_IN_OUT
ITEM_NOS : INT;           // No. of items currently manufactured
END_VAR

BEGIN

NETWORK
TITLE = Increment number of items by 1
// As long as the current number of items lies below 1000,
// the counter can be increased by 1
L ITEM_NOS; L 1000;           // Example for more than one
> I; JC ERR;                 // statement in a line.
L 0; T RET_VAL;
L ITEM_NOS; INC 1; T ITEM_NOS; BEU;
ERR: L -1;
T RET_VAL;
END_FUNCTION

FUNCTION FC3 {S7_pdiag := 'true'} : INT
TITLE = Increment number of items
// As long as the value transferred is < 1000, this function
//increases the transferred value. If the number of items
//exceeds 1000, "-1" is returned via the return value
//for the function (RET_VAL).
//
//RET_VAL has a system attribute for parameters here

```

```
AUTHOR      :      Siemens
FAMILY      :      Throughput check
NAME        :      INCR_ITEM_NOS
VERSION     :      1.0

VAR_IN_OUT
ITEM_NOS {S7_visible := 'true'}: INT;      // No. of items currently manufactured
//System attributes for parameters
END_VAR

BEGIN

NETWORK
TITLE = Increment number of items by 1
// As long as the current number of items lies below 1000,
// the counter can be increased by 1
L ITEM_NOS; L 1000;      // Example for more than one
> I; JC ERR;      // statement in a line.
L 0; T RET_VAL;
L ITEM_NOS; INC 1; T ITEM_NOS; BEU;
ERR: L -1;
T RET_VAL;

END_FUNCTION
```

13.7.4 Example of Function Blocks in STL Source Files

```

FUNCTION_BLOCK FB6
TITLE = Simple traffic light switching
// Traffic light control of pedestrian crosswalk
// on main street

{S7_m_c := 'true'}           //System attribute for blocks
AUTHOR      :               Siemens
FAMILY     :               Traffic light
NAME       :               Traffic light01
VERSION    :               1.3

VAR_INPUT

starter     :               BOOL    :=    FALSE; // Cross request from pedestrian
t_dur_y_car :               TIMER;   // Duration green for pedestrian
t_next_r_car :              TIMER;   // Duration between red phases for cars
t_dur_r_car :               TIMER;
number      {S7_server := 'alarm_archiv'; S7_a_type := 'alarm_8'} :DWORD;
// Number of cars
// number has system attributes for parameters

END_VAR
VAR_OUTPUT

g_car       :               BOOL      :=    FALSE; // GREEN for cars_

END_VAR
VAR
condition   :               BOOL    :=    FALSE; // Condition red for cars
END_VAR

BEGIN
NETWORK
TITLE = Condition red for main street traffic
// After a minimum duration has passed, the request for green at the
// pedestrian crosswalk forms the condition red
// for main street traffic.
      A(
      A      #starter;           // Request for green at pedestrian crosswalk and
      A      #t_next_r_car;     // time between red phases up
      O      #condition;        // Or condition for red
      );
      AN    #t_dur_y_car;       // And currently no red light
      =     #condition;         // Condition red
NETWORK
TITLE = Green light for main street traffic
      AN    #condition;         // No condition red for main street traffic
      =     #g_car;             // GREEN for main street traffic

```

```
NETWORK
TITLE = Duration of yellow phase for cars
        // Additional program required for controlling
        // traffic lights

END_FUNCTION_BLOCK

FUNCTION_BLOCK FB10
VAR_INPUT
    para1 : bool;
    para2: bool;
end_var
begin
end_function_block

data_block db10
FB10
begin
end_data_block

data_block db6
FB6
begin
end_data_block
```

13.7.5 Example of Data Blocks in STL Source Files

Data Block:

```
DATA_BLOCK DB10
TITLE = DB Example 10
STRUCT
    aa : BOOL;      // Variable aa of type BOOL
    bb : INT; // Variable bb of type INT
    cc : WORD;
END_STRUCT;
BEGIN // Assignment of initial values
    aa := TRUE;
    bb := 1500;
END_DATA_BLOCK
```

Data Block with Associated User-Defined Data Type:

```
DATA_BLOCK DB20
TITLE = DB (UDT) Example
UDT 20 // Associated user-defined data type
BEGIN
    start := TRUE; // Assignment of initial values
    setp. := 10;
END_DATA_BLOCK
```

Note

The UDT used must come before the data block in the source file.

Data Block with Associated Function Block:

```
DATA_BLOCK DB30
TITLE = DB (FB) Example
FB30          // Associated function block
BEGIN
              start := TRUE;    // Assignment of initial values
              setp. := 10;
END_DATA_BLOCK
```

Note

The associated function block must come before the data block in the source file.

13.7.6 Example of User-Defined Data Types in STL Source Files

```
TYPE UDT20
STRUCT
              start : BOOL;      // Variable of type BOOL
              setp. : INT;       // Variable of type INT
              value : WORD;      // Variable of type WORD
END_STRUCT;
END_TYPE
```

14 Displaying Reference Data

14.1 Overview of the Available Reference Data

You can create and evaluate reference data to make it easier to debug and modify your user program. You use the reference data for the following:

- As an overview of your whole user program
- As the basis for changes and tests
- To complement your program documentation

The following table shows which information you can extract from the individual views:

View	Purpose
Cross-reference list	Overview of the addresses in the memory areas I, Q, M, P, T, C, and DB, FB, FC, SFB, SFC calls used in the user program. Using the menu command View > Cross References for Address , you can display all the cross-references including overlapping access to the selected address.
Assignment list for inputs, outputs, and bit memory	Overview of which bits of the addresses in the memory areas I, Q, and M, and which timers and counters (T and C) are already occupied within the user program; forms an important basis for troubleshooting or changes in the user program
Program structure	Call hierarchy of the blocks within a user program and an overview of the blocks used and their nesting levels
Unused symbols	Overview of all symbols which are defined in the symbol table but not used in the parts of the user program for which reference data are available
Addresses without symbols	Overview of all absolute addresses which are used in the parts of the user program for which reference data are available but for which no symbol has been defined in the symbol table

The reference data for the selected user program include all the lists in the table. It is possible to create and display one or more of the lists for one user program or for more than one user program.

Displaying a Number of Views Simultaneously

Displaying other lists in additional windows allows you, for example, to:

- Compare the same lists for different S7 user programs.
- Display various views of a list, for example, a cross-reference list, displayed differently and placed side by side on the screen. You can, for example, display only the inputs of an S7 user program in one of the cross-reference lists and only the outputs in another list.
- Open a number of lists for an S7 user program simultaneously, for example, program structure and cross-reference list.

14.1.1 Cross-Reference List

The cross-reference list provides an overview of the use of addresses within the S7 user program.

When you display the cross-reference list you obtain a list of the addresses of memory areas input (I), output (Q), bit memory (M), timer (T), counter (C), function block (FB), function (FC), system function block (SFB), system function (SFC), I/O (P) and data block (DB), as used in the S7 user program along with their addresses (absolute address or symbol) and usage. It is displayed in an active window. The working window's title bar shows the name of the user program to which the cross-reference list belongs.

Every line in the window corresponds to a cross-reference list entry. The search function makes it easier for you to find specific addresses and symbols.

The cross-reference list is the default view when you display reference data. You can change this default.

Structure

A cross-reference list entry consists of the following columns:

Column	Content/Meaning
Address (symbol)	Address
Block (symbol)	Block in which the address is used
Type	Whether a read (R) and/or write (W) access to the address is involved
Language	Information on the programming language used to create the block
Location	Double-click the location field to jump to the location of use for the selected address.

The Block, Type, Language and Location columns are displayed only if the corresponding properties were selected for the cross-reference list. This block information varies, depending on the programming language the block was written in.

You can set the column width in the cross-reference list shown on the screen as required using the mouse.

Sorting

The cross-reference list default option is to sort by memory areas. If you click a column header with the mouse, you can sort the entries of this column by the default sort criteria.

Example of Cross-Reference List Layout

Address (symbol)	Block (symbol)	Type	Language	Location
I1.0 (Motor on)	OB2	R	STL	Nw 2 Inst 33 /0
M1.2 (MemoryBit)	FC2	R	LAD	Nw 33
C2 (Counter2)	FB2		FBD	Nw2

14.1.2 Program Structure

The program structure describes the call hierarchy of the blocks within an S7 user program. You are also given an overview of the blocks used, their dependencies, and their local data requirements.

Using the menu command **View > Filter** in the "Generating Reference Data" window you open a tabbed dialog box. In the "Program Structure" tab you can set how you want the program structure displayed.

You can choose between:

- Call structure and
- Dependency structure

Symbols for the Program Structure


Symbol Meaning

- Block called normally (CALL FB10)
- Block called unconditionally (UC FB10)
- Block called conditionally (CC FB10)
- Data block
- Recursion
- Recursion and called conditionally
- Recursion and called unconditionally
- Block not called

- Recursions in the call are recognized and indicated graphically in the call structure.
- Recursions within the call hierarchy are indicated by different symbols.
- Regularly called blocks (CALL), conditionally called blocks (CC) or unconditionally called blocks (UC) are marked by different symbols.
- Blocks not called are displayed at the bottom of the call structure and marked with a black cross. There is no further breakdown of the call structure of a block which is not called.

Call Structure

The complete call hierarchy is displayed.



If the program structure is to be created for all organization blocks (OB) and OB1 is not in the S7 user program, or if a starting block was specified which is not present in the program, you are automatically prompted to specify another block for the program structure root.

Display of multiple calls of blocks can be deactivated by option settings, both for the call structure and for the dependency structure.

Displaying the Maximum Local Data Requirement in the Call Structure

To give you a quick overview of the local data requirement of the organization blocks in the user program displayed, the following can be displayed in the tree structure:

- The maximum local data requirement per OB and
- The local data requirement per path

You can activate and deactivate this display in the "Program Structure" tab.

If synchronous error OBs (OB121, OB122) are present, a plus sign and the additional requirement for the synchronous error OBs are displayed after the numerical value for the maximum local data requirement.

Dependency Structure

The dependency structure shows the dependency of each block in the project on other blocks. The block is displayed at the outer left and listed below in the indented segments are the blocks that call or use this block.

Displaying Deleted Blocks

Lines relating to deleted blocks are highlighted in red color.

14.1.3 Assignment List

The Assignment lists show you which addresses are already assigned in the user program. This display is an important basis for troubleshooting or making changes in the user program.

The I/Q/M assignment list display gives you an overview of which bit in which byte of the memory areas input (I), output (Q), bit memory (M), times (T) and counter (Z) is used. The I/Q/M assignment list is displayed in a working window.

The working window's title bar shows the name of the S7 user program to which the assignment list belongs.

I/Q/M Table

Each line contains one byte of the memory area in which the eight bits are coded according to their access. It also indicates whether the access is of a byte, word, or double word.

Identification in the I/Q/M Table

White background	The address is not accessed and thus not assigned.
X	The address is accessed directly.
Blue background	The address is accessed indirectly (byte, word, or double word access).

Columns in the I/Q/M Table

Column	Content/Meaning
7 6 5 4 3 2 1 0	Bit number of the corresponding byte
B	The byte is occupied by a one-byte access
W	The byte is occupied by a one-word access
D	The byte is occupied by a double-word access

Example

The following example shows the typical layout of an assignment list for inputs, outputs, and bit memory (I/Q/M).

△	7	6	5	4	3	2	1	0	B	W	D
IB0	X	X	X	X	X	X	X				
IB1		X	X	X		X	X	X			
QB4						X	X	X			
QB5		X	X	X		X	X	X			
MB1											
MB2											
MB3											
MB4											
MB5											

The first row shows the assignment of input byte IB 0. Inputs for address IB 0 are accessed directly (bit access). The columns "0", "1", "2", "3", "5", and "6" are identified with "X" for bit access.

There is also word access to memory bytes 1 and 2, 2 and 3 or 4 and 5. For this reason, a "bar" is shown in the "W" column, and the cells also have a light blue background. The black tip of the bar shows the start of word access.

T/C Table

Each row displays 10 timers or counters.

Example

	0	1	2	3	4	5	6	7	8	9
T 00-09	.	T1	T6	.	.	.
T 10-19	.	.	T12	T17	.	T19
T 20-29	T24
Z 00-09	.	.	Z2	Z7	.	.
Z 10-19	Z19
Z 20-29
Z 30-39	Z34

In this example, the timers T1, T6, T12, T17, T19, T24 and the counters Z2, Z7, Z19, Z34 are occupied.

The lists are sorted alphabetically. You can arrange the entries by clicking on the column title.

14.1.4 Unused Symbols

You are shown an overview of all the symbols with the following characteristics:

- The symbols defined in the symbol table.
- The symbols not used in the parts of the user program for which reference data exist.

They are displayed in an active window. The working window's title bar shows the name of the user program to which the list belongs.

Every line shown in the window corresponds to a list entry. A line consists of address, symbol, data type, and comment.

Column	Content/Meaning
Address	Absolute address
Data Type	Data type of the address
Comment	Comment on the address from the symbol table

Example of List of Unused Symbols Layout

Symbol	Address	Data Type	Comment
MCB1	I 103.6	BOOL	Motor circuit breaker 1
MCB2	I 120.5	BOOL	Motor circuit breaker 2
MCB3	I 121.3	BOOL	Motor circuit breaker 3

You can sort the entries by clicking the column title.

You can also remove symbols that are no longer needed from the list. To do this, select symbols in the list and then execute the "Delete symbols" function.

14.1.5 Addresses Without Symbols

When you display the list of addresses without symbols, you obtain a list of the elements which are used in the S7 user program, but which are not defined in the symbol table. They are displayed in an active window. The working window's title bar shows the name of the user program to which the list belongs.

A line consists of the address and the number of times that the address is used in the user program. The entries are sorted according to address.

Example:

Address	Number
Q 2.5	4
I 23.6	3
M 34.1	20

You can also assign names to addresses without symbols. To do this, select addresses in the list and then execute the "Edit symbols" function.

14.1.6 Displaying Block Information for LAD, FBD, and STL

Language relevant information for Ladder Logic, Function Block Diagram, and Statement List is displayed in the cross-reference list and the program structure. This information consists of the block language and details.

The "Program Structure" view only displays language relevant information if the filter is set to "Call Structure" in the "Program Structure" tab and if respective options were selected.

Language relevant information in the "Cross References" can be shown or hidden via menu command **View > Filter**.

- Activate the "Block language" and "Details" check box in the "Cross References" tab of the "Filter" dialog box to display the block language information.

Language relevant information varies according to the programming language the block was written in and is shown using abbreviations.

Language	Network	Statement	Instruction
STL	Nw	Inst	/
LAD	Nw		
FBD	Nw		

Nw and **Inst** specify in which network and in which statement the address is used (cross-reference list) or the block is called (program structure).

Displaying Block Information for the Optional Programming Languages

The online help topics on block information can be accessed if the corresponding optional package is installed.

14.2 Working with Reference Data

14.2.1 Ways of Displaying Reference Data

The following possibilities are available for displaying reference data:

Displaying from the SIMATIC Manager

1. In the project window in the component view offline, select the "Blocks" folder.
2. Select the menu command **Options > Reference Data > Display**.

Displaying from the Editor Window

1. Open a block in the "Blocks" folder.
2. In the window of the programming language editor, select the menu command **Options > Reference Data**.

The "Customize" dialog box is displayed. Here you can select the view that is shown first. The default view is the one in the application for displaying reference data that was closed last. You can suppress the dialog for future calls.

Displaying Directly from the Compiled Block

You can display the reference data for a compiled block directly from the language editor to get a current overview of your user program.

14.2.2 Displaying Lists in Additional Working Windows

Using the menu command **Window > New Window** you can open additional working windows and display other views of the reference data (for example, List of Unused Symbols).

You open a working window for previously hidden reference data using the menu command **Reference Data > Open**.

You can change to another view of the reference data by selecting one of the commands in the "View" menu or the corresponding button in the toolbar:

Reference Data View	Menu Command to Display this Reference Data View
Addresses Without Symbols	View > Addresses Without Symbols
Unused Symbols	View > Unused Symbols
Assignment	View > Assignment
Program Structure	View > Program Structure
Cross-Reference List	View > Cross References

14.2.3 Generating and Displaying Reference Data

Generating Reference Data:

1. In the SIMATIC Manager, select the block folder for which you want to generate reference data.
2. Select the menu command **Options > Reference Data > Generate** in the SIMATIC Manager.

Before generating reference data, the computer checks to see if any reference data are available and if so, whether the data are current.

- If reference data are available, they are generated.
- If the reference data available are not current, you can choose whether to update the reference data or whether to generate them again completely.

Displaying Reference Data:

Using the menu command **Options > Reference Data > Display** you can display the reference data.

Before displaying reference data, a check is made to ascertain whether any reference data exist and whether the existing reference data are current.

- If no reference data exist they are generated.
- If incomplete reference data exist, a dialog box is displayed showing a notice that the reference data are inconsistent. You can then decide whether you want to update the reference data and to what extent. You then have the following possibilities:

Choice	Meaning
For modified blocks only	The reference data are updated for any modified or new blocks; information on any blocks deleted is removed from the reference database.
For all blocks	The reference data are generated again from scratch for all blocks.
Do not update	The reference data are not updated.

In order to update the reference data, the blocks are recompiled. The appropriate compiler is called to compile each block. Using the menu command **View > Update** you can refresh the view of the reference data already displayed in the active window.

14.2.4 Finding Address Locations in the Program Quickly

You can use reference data to position the cursor at different locations of an address in the program when programming. To do this, you must have up-to-date reference data. However, you do not have to start the application for displaying reference data.

Basic Procedure

1. Select the menu command **Options > Reference Data > Generate** in the SIMATIC Manager to generate the current reference data. This step is only necessary if there are no reference data, or if you have old reference data.
2. Select the address in an open block.
3. Select the menu command **Edit > Go To > Instance**.
A dialog box is now displayed containing a list with all instances of the address in the program.
4. Select the option "Overlapping access to memory areas" if you also want to display the instances of addresses whose physical addresses or address area overlap with that of the called address. The "Address" column is added to the table.
5. Select a location in the list and click the "Go To" button.

If the reference data are not up-to-date when you open the dialog box, a message to this effect will appear. You can then update the reference data.

List of Locations

The list of locations in the dialog box contains the following details:

- The block in which the address is used
- The symbolic name of the block, if one exists
- Details, for example, information on the location and, if appropriate, the instruction, which depends on the original programming language of the block or source file (SCL)
- Language-dependent information
- Type of access to the address: read-only (R), write-only (W), read and write (RW), unknown (?).
- Block language

You can filter the display of locations and in this way view, for example, write access only for an address. The online help for this dialog box provides you with more detailed information on what to enter in the fields and the other information displayed.

Note

Reference data only exist offline. This function therefore always works with the cross references of the offline blocks, even if you call the function in an online block.

14.2.5 Example of Working with Address Locations

You want to determine at which locations output Q1.0 (direct/indirect) is set. The following STL code in OB1 is used as an example:

Network 1:

A Q 1.0 // irrelevant

= Q 1.1 // in this example

Network 2:

A M1.0

A M2.0

= Q 1.0 // assignment

Network 3:

//comment line only

SET

= M1.0 // assignment


Network 4:

A I 1.0

A I 2.0

= M2.0 // assignment

This results in the following assignment tree for Q1.0:



Then proceed as follows:

1. Position the cursor on Q1.0 (NW 1, Inst 1) in OB1 in the LAD/STL/FBD Editor.
2. Select the menu command **Edit > Go To > Location** or use the right mouse button to select "Go to Location."
The dialog box now displays all the assignments for Q1.0:
OB1 Cycle Execution NW 2 Inst 3 /= W STL
OB1 Cycle Execution NW 1 Inst 1 /A R STL
3. Jump to "NW 2 Inst 3" in the Editor using the "Go To" button in the dialog box:
Network 2:
A M1.0
A M2.0
= Q 1.0
4. The assignments to both M1.0 and M2.0 must now be checked. First position the cursor on M1.0 in the LAD/STL/FBD Editor.
5. Select the menu command **Edit > Go To > Location** or use the right mouse button to select "Go to Location." The dialog box now displays all the assignments for M1.0:
OB1 Cycle Execution NW 3 Inst 2 /= W STL
OB1 Cycle Execution NW 2 Inst 1 /A R STL
6. Jump to "NW 3 Inst 2" in the Editor using the "Go To" button in the dialog box.
7. In the LAD/STL/FBD Editor in Network 3, you will see the assignment to M1.0 is not important (because it is always TRUE) and that the assignment to M2.0 needs to be examined instead.

In STEP 7 versions earlier than V5, you would now have to run through the entire sequence of assignments all over again. The buttons ">>" and "<<" make this much simpler:

8. Place the open dialog box "Go to Location" on top, or call the function "Go to Location" in the LAD/STL/FBD Editor from your current position.
9. Click the "<<" button once or twice until all the locations of Q1.0 are displayed; the last jump location "NW 2 Inst 3" is selected.
10. Jump from the address locations dialog box to "NW 2 Inst 3" in the Editor using the "Go To" button (as in point 3):
Network 2:
A M1.0
A M2.0
= Q 1.0
11. In point 4, the assignment to M1.0 was checked. Now you have to check all the (direct/indirect) assignments to M2.0. Position the cursor on M2.0 in the Editor and call the function "Go to Location:" All the assignments to M2.0 are displayed:
OB1 Cycle Execution NW 4 Inst 3 /= W STL
OB1 Cycle Execution NW 2 Inst 2 /A R STL

12. Jump to "NW 4 Inst 3" in the LAD/STL/FBD Editor using the "Go To" button:

Network 4:

A I 1.0

A I 2.0

= M2.0

13. Now you have to check the assignments to I1.0 and I2.0. This process is not described in this example, because you proceed in the same way as before (point 4 onwards).

By switching between the LAD/STL/FBD Editor and the address locations dialog box, you can find and check the relevant locations in your program.

15 Checking Block Consistency and Time Stamps as a Block Property

15.1 Checking Block Consistency

Introduction

If the interfaces or the code of individual objects have to be adapted or extended, this can lead to time stamp conflicts. Time stamp conflicts can in turn cause block inconsistencies between calling objects and called objects or reference blocks and thus to a high amount correction work.

The "Check block consistency" function eliminates a lot of this correction work. The "Check block consistency" function removes a large part of all the time stamp conflicts and block inconsistencies. In the case of objects whose block inconsistencies could not be eliminated automatically, the function places you at the position to be changed in the corresponding editor, where you can carry out the required changes. All the block inconsistencies are eliminated and the objects are compiled step-by-step.

Requirements

It is only possible to check block consistency for projects created from STEP 7 V5.0, Service Pack 3. For older projects, you must first compile everything when starting the block consistency check (menu command **Program > Compile All**).

For objects created with an options package, the options package must be installed for the consistency check.

Starting the Block Consistency Check

At the start of the block consistency check, the time stamps of the block interfaces are checked, and objects that could cause block inconsistencies are highlighted in the tree view (Dependency Tree: References / Call Tree).

1. In the SIMATIC Manager, go to the project window, select the required block folder and then initiate the block consistency via menu command **Edit > Check Block Consistency**.
2. In "Check Block Consistency" select the menu command **Program > Compile** STEP 7 automatically recognizes the programming language for the relevant objects and calls the corresponding editor. As far as possible, the time stamp conflicts and block inconsistencies are corrected automatically and the objects are compiled. If the time stamp conflict or the inconsistency in an object cannot be eliminated automatically, an error message appears in the output window (refer to Step 3 for further procedures). This process is repeated automatically for all the objects in the tree view.
3. If it was not possible to eliminate all the block inconsistencies automatically during the compilation run, the corresponding objects are marked in the output windows as error messages. Position the mouse on the corresponding error entry and use the right-hand mouse to call the error display in the pop-up menu. The relevant error is opened and the program jumps to the positions to be changed. Eliminate all the block inconsistencies, and save and close the object. Repeat this process for all the objects marked as errors.
4. Start Steps 2 and 3 again. Repeat this process until no more errors are displayed in the message window.

15.2 Time Stamps as a Block Property and Time Stamp Conflicts

Blocks contain a code time stamp and an interface time stamp. These time stamps are displayed in the dialog box for the block properties. You can monitor the consistency of STEP 7 programs using time stamps.

STEP 7 displays a time stamp conflict if it detects a violation of the rules when comparing time stamps. The following violations may occur:

- A called block is more up-to-date than the calling block (CALL)
- A referenced block is more up-to-date than the block which is using it
- Examples of the second type of violation:
 - A UDT is more up-to-date than the block which is using it; that is, a DB or another UDT, or an FC, an FB, or an OB which is using the UDT in the variable declaration table.
 - An FB is more up-to-date than its corresponding instance DB.
 - An FB2 is defined as a multiple instance in FB1 and FB2 is more up-to-date than FB1.

Note

Even if the relationship between the interface time stamps is correct, inconsistencies may occur:

- The definition of the interface for the referenced block does not match the definition in the location at which it is used.

These inconsistencies are known as interface conflicts. They can occur, for example, when blocks are copied from different programs or when an ASCII source file is compiled and not all of the blocks in a program are generated.

15.3 Time Stamps in Logic Blocks

Code Time stamp

The time and date the block was created is entered here. The time stamp is updated:

- When the program code is changed
- When the interface description is changed
- When the comment is changed
- When an ASCII source file is created for the first time and compiled
- When the block properties ("Properties" dialog box) are changed

Interface Time stamp

The time stamp is updated:

- When the interface description is changed (changes to data types or initial values, new parameters)
- When an ASCII source file is created for the first time and compiled, if the interface is changed structurally.
- The time stamp is not updated:
 - When symbols are changed
 - When comments in the variable declaration are changed
 - When changes are made in the TEMP area

Rules for Block Calls

- The interface time stamp of the called block must be older than the code time stamp of the calling block.
- Only change the interface of a block if no block is open which calls this block. Otherwise, if you save the calling blocks later than the changed block, you will not recognize this inconsistency from the time stamp.

Procedure if a Time stamp Conflict Occurs

A time stamp conflict is displayed when the calling block is opened. After making changes to an FC or FB interface, all calls to this block in calling blocks are shown in expanded form.

If the interface of a block is changed, all blocks which call this block must be adjusted as well.

After making changes to an FB interface, the existing multiple instance definitions and instance data blocks must be updated.

15.4 Time Stamps in Shared Data Blocks

Code Time stamp

The time stamp is updated:

- When an ASCII source file is created for the first time
- When an ASCII source file is compiled
- When changes are made in the declaration view or in the data view of the block

Interface Time stamp

The time stamp is updated:

- When the interface description is changed in the declaration view (changes to data types or initial values, new parameters)

15.5 Time Stamps in Instance Data Blocks

An instance data block saves the formal parameters and static data for function blocks.

Code Time stamp

The time and date the instance data blocks were created is entered here. The time stamp is updated when you enter actual values in the data view of the instance data block. The user cannot make changes to the structure of an instance data block because the structure is derived from the associated function block (FB) or system function block (SFB).

Interface Time stamp

When an instance data block is created, the interface time stamp of the associated FB or SFB is entered.

Rules for Opening Without Conflicts

The interface time stamps of the FB/SFB and the associated instance data block must match.

Procedure if a Time stamp Conflict Occurs

If you change the interface of an FB, the interface time stamp of the FB is updated. When you open an associated instance data block, a time stamp conflict is reported because the time stamps of the instance data block and the FB no longer match. In the declaration section of the data block the interface is displayed with the symbols generated by the compiler (pseudo-symbols). The instance data block can now only be viewed.

To remedy time stamp conflicts of this type, you must create the instance data block for a changed FB again.

15.6 Time Stamps in UDTs and Data Blocks Derived from UDTs

User-defined data types (UDTs) can, for example, be used to create a number of data blocks with the same structure.

Code Time stamp

The code time stamp is updated on every change.

Interface Time stamp

The interface time stamp is updated when the interface description is changed (changes to data types or initial values, new parameters).

The interface time stamp of a UDT is also updated when the ASCII source file is compiled.

Rules for Opening Without Conflicts

- The interface time stamp of the user-defined data type must be older than the interface time stamp in logic blocks in which this data type is used.
- The interface time stamp of the user-defined data type must be identical to the time stamp of a data block derived from a UDT.
- The interface time stamp of the user-defined data type must be younger than the time stamp of a secondary UDT.

Procedure if a Time stamp Conflict Occurs

If you change a UDT definition that is used in a data block, function, function block, or another UDT definition, STEP 7 reports a time stamp conflict when the block is opened.

The UDT component is shown as a fanned-out structure. All variable names are overwritten by values preset by the system.

15.7 Correcting the Interfaces in a Function, Function Block, or UDT

If you need to correct the interface in an FB, FC, or UDT, proceed as follows to avoid time stamp conflicts:

1. Generate an STL source file from the block you want to change and all directly or indirectly referenced blocks.
2. Save the changes in the source file you generated.
3. Compile the modified source file back into blocks.

You can now save/download the interface changes.

15.8 Avoiding Errors when Calling Blocks

STEP 7 Overwrites Data in the DB Register

STEP 7 modifies the registers of the S7-300/S7-400 CPU when various instructions are executed. The contents of the DB and DI registers are, for example, swapped when you call an FB. This allows the instance DB of the called FB to be opened without losing the address of the previous instance DB.

If you work with absolute addressing, errors can occur accessing data saved in the registers. In some cases, the addresses in the register AR1 (address register 1) and in the DB register are overwritten. This means that you could read or write to the wrong addresses.



Danger

Danger of damage to property and persons when:

1. Using CALL FC, CALL FB, CALL multiple instance
2. Accessing a DB using the complete absolute address (for example DB20.DBW10)
3. Accessing variables of a complex data type

It is possible that the contents of DB registers (DB and DI), address registers (AR1, AR2), and accumulators (ACCU1, ACCU2) may be changed.

In addition, you cannot use the RLO bit of the status word as an additional (implicit) parameter when you call an FB or FC.

When using the programming techniques mentioned above, you must make sure that you save and restore the contents yourself; otherwise errors may occur.

Saving Correct Data

The contents of the DB register can cause critical situations if you access the absolute addresses of data using the abbreviated format. If, for example, you assume that DB20 is open (and that its number is saved in the DB register), you can specify DBX0.2 to access the data in bit 2 of byte 0 of the DB whose address is entered in the DB register (in other words DB20). If, however, the DB register contains a different DB number you access the wrong data.

You can avoid errors when accessing data of the DB register by using the following methods to address data:

- Use the symbolic address
- Use the complete absolute address (for example *DB20.DBX0.2*)

If you use these addressing methods, STEP 7 automatically opens the correct DB. If you use the AR1 register for indirect addressing, you must always load the correct address in AR1.

Situations in which Registers are Modified

The manipulation of the address registers for indirect addressing is relevant only in STL. The other languages do not support indirect access to the address registers.

The adaptation of the DB register by the compiler must be taken into account in all programming languages to ensure correct parameter transfer when blocks are called.

The contents of the address register AR1 and the DB register of the calling block are overwritten in the following situations:

Situation	Description
With actual parameters from a DB	<ul style="list-style-type: none"> Once you have assigned an actual parameter to a block from a DB (for example DB20.DBX0.2) STEP 7 opens the DB (DB20) and adapts the content of the DB register. The program then works with the adapted DB after the block call.
When calling blocks in conjunction with higher data types	<ul style="list-style-type: none"> After a block has been called from within an FC that transfers a component of a formal parameter of a higher data type (string, array, structure or UDT) to the called block, the content of AR1 and the DB register of the calling block are modified. The same applies to a call from within an FB if the parameter is in the VAR_IN_OUT area of the caller.
When accessing components of a higher data type	<ul style="list-style-type: none"> When an FB accesses a component of a formal parameter of a higher data type in the VAR_IN_OUT area (string, array, structure or UDT), STEP 7 uses the address register AR1 and the DB register. This means that the contents of both registers are modified. When an FC accesses a component of a formal parameter of a higher data type in the VAR_IN_OUT area (string, array, structure or UDT), STEP 7 uses the address register AR1 and the DB register. This means that the contents of both registers are modified.

Note

- When an FB is called from within a version 1 block, the actual parameter for the first Boolean IN or IN_OUT parameter is not transferred correctly if the command before the call does not limit the RLO. In this case, it is logically combined with the existing RLO.
 - When an FB is called (single or multiple instance), the address register AR2 is written to.
 - If the address register AR2 is modified in an FB, such by the operations UC, CC or CALL (Call FC/SFC without parameters), there is no guarantee that the FB will be executed correctly.
 - If the complete absolute DB address is not transferred to an ANY parameter, the ANY pointer does not get the DB number of the open DB. Instead, it always gets the number 0.
-

16 Configuring Messages

16.1 The Message Concept

Messages allow you to detect, localize, and remedy errors during processing on the programmable controllers quickly, thus reducing downtimes on a plant considerably.

Before messages can be output, they must first be configured.

With STEP 7, you can create and edit messages linked to events with assigned message texts and message attributes. You can also compile the messages and display them on display devices.


16.1.1 What Are the Different Messaging Methods?

There are different methods of creating messages.

Bit Messaging

Bit messaging requires the programmer to perform three steps:

- Create the user program on the programming device and set the required bit.
- Create an assignment list using any text editor in which a message text is assigned to the message bit (for example, M 3.1 = limit switch pressure).
- Create the list of message texts on the operator panel on the basis of the assignment list.




The operator interface system queries the programmable controller cyclically to see whether the message bit has changed or not. If the programmable controller signals a change, the corresponding message is displayed. The message receives the time stamp from the operator interface system.

Message Numbering

Message numbering requires the programmer to perform only one step:

- Create the user program on the programming device, set the required bit, and assign the required message text to the bit directly while programming.



There is no cyclic query of the programmable controller. When the programmable controller signals a change, the corresponding message number is passed to the operator interface system and the corresponding message text is displayed. The message receives the time stamp from the programmable controller and can therefore be traced more exactly than with bit messaging.

16.1.2 Choosing a Messaging Method

Overview

The following table shows the properties and requirements for the different messaging methods:

Message Numbering	Bit Messaging
<ul style="list-style-type: none"> • Messages are managed in a common database for programming device and operator panel • The load on the bus is low (programmable controller signals active) • Messages receive the timestamp from the programmable controller 	<ul style="list-style-type: none"> • There is no common database for the programming device and operator panel • The load on the bus is high (operator panel polls) • Messages receive the timestamp from the operator panel

The message numbering method recognizes the following three types of messages:

Block-Related Messages	Symbol-Related Messages	User-Defined Diagnostic Messages
<ul style="list-style-type: none"> • Synchronous to the program • Display using WinCC and ProTool (ALARM_S only) • Possible with S7-300/400 • Program by using message blocks: <ul style="list-style-type: none"> - ALARM - ALARM_8 - ALARM_8P - NOTIFY - NOTIFY_8P - ALARM_S(Q) - AR_SEND - ALARM_D(Q) • Transfer to the operator panel <ul style="list-style-type: none"> - for WinCC via AS-OS connection configuration - for ProTool via ProTool functions 	<ul style="list-style-type: none"> • Asynchronous to the program • Display using WinCC • Possible only with S7-400 • Configure via the symbol table • Download to the PLC via system data blocks (SDBs) • Transfer to the operator panel via AS-OS connection configuration 	<ul style="list-style-type: none"> • Synchronous to the program • Display in the diagnostic buffer on the programming device • Possible with S7-300/400 • Program using message block (system function) <ul style="list-style-type: none"> - WR_USMSG • No transfer to the operator panel

STEP 7 only supports the more user-friendly message numbering method which will be described in detail below. Bit messaging is configured in the HMI devices and is described there.


Examples of Message Numbering

Messaging Method	Application
Block-related messages	Used to report program-synchronous events, for example, to show that a controller has reached a limit value
Symbol-related messages	Used to report events that are independent of the program, for example, a switch setting being monitored
User-defined messages	Used to report diagnostic events in the diagnostic buffer, with each call of the SFC

16.1.3 SIMATIC Components

Overview

The following figure shows an overview of which SIMATIC components are involved in configuring and displaying messages.



16.1.4 Parts of a Message


How a message is displayed depends on the messaging method, the message block used, and the display device.

The possible parts of a message are listed in the following table:

Part	Description
Timestamp	Generated in the programmable controller when the message event occurs
Message state	The following states are possible: incoming, outgoing, outgoing without acknowledgement, outgoing with acknowledgement
Associated value	Some messages can be assigned a process value that can be evaluated by the message block used
Image	If the system crashes the messages that occurred can be displayed subsequently on the operator station
Message number	A unique number throughout the project or CPU (project-oriented or CPU-oriented). The number is assign by the system and identifies a message
Message texts	Configured by the user

Example

The following example shows an alarm message on an operator panel.



16.1.5 Which Message Blocks Are Available?

You can choose between the following message blocks, each of which contains a programmed message function:

- SFB 33: "ALARM"
- SFB 34: "ALARM_8"
- SFB 35 "ALARM_8P"
- SFB 36 "NOTIFY"
- SFC 18: "ALARM_S" and SFC 17: "ALARM_SQ"
- SFB 37: "AR_SEND" (for sending archives; no configuration of message texts and message attributes possible)
- SFB 31: "NOTIFY_8P"
- SFC 107: "ALARM_DQ"
- SFC 108: "ALARM_D"

Details are found in the reference online help on blocks.

When to Use Which Message Block

The following table helps you decide which message block to choose for your particular task. Selecting a message block depends on:

- The number of channels available in the block and therefore the number of signals that are monitored with each block call
- Whether messages are to be acknowledged
- The option of also specifying associated values
- The display devices to be used
- The project data for the CPU to be used.

Message Block	Channels	Acknowledgement	Associated Values	WinCC Display	ProTool Display	CPU Messages /S7 Status Display	PLC	Remarks
ALARM SFB33	1	Possible	Up to 10	Yes	No	No	S7-400	Sends a message for each incoming or outgoing edge
ALARM_8 SFB34	8	Possible	No	Yes	No	No	S7-400	Sends a message for each incoming or outgoing edge of one or more signals
ALARM_8P SFB35	8	Possible	Up to 10	Yes	No	No	S7-400	As ALARM_8
NOTIFY SFB36	1	No	Up to 10	Yes	No	No	S7-400	As ALARM
NOTIFY_8P SFB 31	8	No	up to 10	Yes	No	No	S7-400	As NOTIFY
AR_SEND SFB37	1			Yes	No	No	S7-400	Used to send an archive; no configuration of message texts and message attributes possible
ALARM_SQ SFC17	1	Possible	1	Yes	Yes*	Yes	S7-300/ S7-400	Not an edge change but every SFC call generates a message
ALARM_S SFC18	1	No	1	Yes	Yes*	Yes	S7-300/ S7-400	As ALARM_SQ
ALARM_DQ SFC 107	1	Possible	1	Yes	Yes	Yes	S7-300/400	As ALARM_SQ
ALARM_D SFC 108	1	No	1	Yes	Yes	Yes	S7-300/400	As ALARM_SQ
* depending on the OP type								

16.1.6 Formal Parameters, System Attributes, and Message Blocks

Formal Parameters as Message Number Inputs

For each message or group of messages you need a formal parameter in your program that you specify as the IN parameter in the variable overview of your program. This formal parameter is then used as a message number input and forms the basis of a message.

How to Provide Formal Parameters with System Attributes

As a prerequisite for starting message configuration, you must first provide the formal parameters with system attributes as follows:

1. Add the following system attributes for parameters: "S7_server" and "S7_a_type"
2. Assign values to the system attributes corresponding to the message blocks that you called in your program code. The value for "S7_server" is always "alarm_archiv", the value for "S7_a_type" corresponds to the called message block.

System Attributes and Corresponding Message Blocks

The message blocks themselves are not displayed as objects in the message server; instead, the display contains the corresponding values of the system attribute "S7_a_type". These values have the same names as the message blocks that exist as SFBs or SFCs (exception: "alarm_s").

S7_a_type	Message Block	Description	Properties
alarm_8	ALARM_8	SFB34	8 channels, can be acknowledged, no associated values
alarm_8p	ALARM_8P	SFB35	8 channels, can be acknowledged, up to 10 associated values per channel
notify	NOTIFY	SFB36	1 channel, cannot be acknowledged, up to 10 associated values
alarm	ALARM	SFB33	1 channel, can be acknowledged, up to 10 associated values
alarm_s	ALARM_S	SFC18	1 channel, cannot be acknowledged, up to 1 associated value
alarm_s	ALARM_SQ	SFC17	1 channel, can be acknowledged, up to 1 associated value
ar_send	AR_SEND	SFB37	Used to send an archive
notify_8p	NOTIFY_8P	SFB 31	8 channels, cannot be acknowledged, up to 10 associated values
alarm_s	ALARM_DQ	SFC 107	1 channel, cannot be acknowledged, up to 1 associated value
alarm_s	ALARM_D	SFC 108	1 channel, cannot be acknowledged, up to 1 associated value

You will find more detailed information in the reference online help on system attributes.

The system attributes are assigned automatically if the message blocks that you use in your program are SFBs or FBs with corresponding system attributes and are called as multiple instances.

16.1.7 Message Type and Messages

Message configuration allows you to use different procedures to create a message type or a message. This depends on the message-type block via which you gain access to message configuration.

The message-type block can be either a function block (FB) or an instance data block.

- With an FB you can create a message type to use as a type for creating messages. All entries you make for the message type are entered in the messages automatically. If you assign an instance data block to the function block, messages for the instance data block are generated automatically in accordance with the message type and assigned message numbers.
- For an instance data block, you can modify messages generated based on this message type for a specific instance.

The visible difference here is that message numbers are assigned for messages but not for message types.

Locking Data for a Message Type

Message configuration allows you to enter texts and attributes for event-dependent messages. You can also specify, for example, how you want to display the messages on specific display devices. To make it easier to generate messages, you can work with message types.

- When you enter data (attributes and texts) for the message type, you can specify whether they are to be locked or not. With locked attributes a key symbol is added next to the input box or a checkmark is placed in the "Locked" column. Locked texts show a checkmark in the "Locked" column.
- With the message type "locked data" you cannot make changes in the instance-specific messages. The data are only displayed.
- If you do need to make changes, you must go back to the message type, remove the lock, and make the changes there. The changes do not apply for instances that were generated before the change.

Modifying Data Of Message Types

Whether or not the modification of data at message types has an influence on the instances depends on whether you have assigned message numbers globally to the project (project-oriented message numbers) or to the CPU (CPU-oriented message numbers) when you generated your project.

- Assigning project-oriented message numbers: When you subsequently modify message type data you also want to apply to the instances, you must also modify data at the instances accordingly.

- Assigning CPU-oriented message numbers: Subsequent modifications of message type data are automatically applied at the instances.
Exceptions: You have previously modified data at the instance or have subsequently locked or unlocked message type data. If you copy an FB and an instance DB from a project with project-oriented message numbers to a project with CPU-oriented message numbers, you will then have to change the data at the instance in the same way you did it at the message type.

Caution:

- When you copy the instances to another program and do not include the message type, the instance might only be partially displayed. To remedy, copy the message type to the new program.
 - If texts and attributes for an instance are displayed in green, this means the following: these texts and attributes are still as they were configured in the message type. They have not been changed at the instance.
-

16.1.8 How to Generate an STL Source File from Message-Type Blocks

When you generate an STL source file from message-type blocks, the configuration information is also written to the source file.

This information is written to a pseudo-comment that begins with "\$ALARM_SERVER" and ends with "".

Caution

When you set a symbolic reference for a block, note that the symbol table may not be modified prior to the compilation of the source file.

When the source file contains multiple blocks, several pseudo-comment blocks will be joined to form a single comment block. Individual blocks with message attributes must not be deleted from the STL source file.

16.1.9 Assigning Message Numbers

You can specify if you want to assign message numbers for the project (project-oriented message numbers) or for the CPU (CPU-oriented message numbers). Assigning message numbers for the CPU has the advantage of allowing you to copy a program without having the message numbers change, in which case they would have to be recompiled. It is only possible to display message numbers for the CPU on an HMI device with the applications "WinCC V6.0" and/or "ProTool V6.0". If you are working with an earlier version of these applications, you have to select message numbers for the project.

16.1.10 Differences Between Project-Oriented and CPU-Oriented Assignment of Message Numbers

The table below lists the differences between project-oriented and CPU-oriented assignment of message numbers:

Project oriented	CPU oriented
Some of the message attributes and texts depend on the used HMI unit and must be configured display specific.	The assigned attributes and texts do not depend on the HMI unit used, that is, there is no need to enter further display devices or specify a display specific message for this device.
Programs must be recompiled after they have been copied.	Programs can be copied to other locations of a project and to other projects (cross-project copying). However, the program must be recompiled if only single blocks have been copied.
When you subsequently change message type data (texts and attributes), you must also modify the instances.	If you subsequently change message type data (texts and attributes), all changes are applied automatically to the instances (Exception: you have previously changed the data of the instance).
Texts can only be written on one line.	Texts can be written on several lines.

16.1.11 Options for Modifying the Message Number Assignment of a Project

In the "Message number" tab of the SIMATIC manager you can preset the way message numbers will be assigned (Menu command **Options > Customize**) to future projects and libraries. In this tab you determine whether the message numbers are to be assigned only to the CPU (CPU-oriented) or only to the project (project-oriented). You can also choose "Always ask for setting" if you want to specify the assignment later.

If the initially set default "CPU-oriented" or "project-oriented" was active when you created the project or library, you can no longer change the type of message number assignment for this project or library.

If you have set "project-oriented" unique message number assignment and want to set "CPU-oriented" unique assignment proceed as follows:

1. In SIMATIC Manager, select the corresponding project or library.
2. Select menu command **File > Save As**.
3. Enable the "With rearrangement" check box In the next dialog box and enter a new name.
4. Start the process with "Save As" and confirm your entries with "OK".
5. In one of the next dialogs you can specify "CPU-oriented" unique message number assignments.

You can use the **File > Delete** command to delete the original project or library.

Differences Between Project-Oriented and CPU-Oriented Assignment of Message Numbers

16.2 Project-Oriented Message Configuration

16.2.1 How to Assign Project-Oriented Message Numbers

Messages are identified by a number which is unique throughout a project. To achieve this, the individual STEP 7 programs are each allocated a number range within the total available range (1 to 2097151). If you copy a program and a conflict results - that is, if the same message numbers have already been assigned in the target range - the new program must be allocated a new number range. If such a situation arises, STEP 7 automatically opens the dialog box in which you can specify the new number range.

If no messages have been configured, you can also set or change the number range for an S7 program using the menu command **Edit > Special Object Properties > Message Numbers**.


By default, the message number range is assigned in steps of 20,000.

16.2.2 Assigning and Editing Block-Related Messages

Block-related messages are assigned to a block (instance DB). To create a block-related message, you can use system function blocks (SFBs) and system functions (SFCs) as message blocks.

16.2.2.1 How to Create Block-Related Messages (Project-Oriented)

Basic Procedure



Programming Message-Type Blocks (FB)

1. In the SIMATIC Manager select the function block (FB) for which you want to generate a block-related message and open this block with a double-click.

Result: The selected block is opened and displayed in the "LAD/STL/FBD" window.

2. Fill out the variable declaration table. For every message block that is called in the function block you must declare variables in the calling function block.

Enter the following variables in the variable overview column:

- For the parameter "IN" enter a symbolic name for the message block input, for example, "Meld01" (for message input 01) and the data type (must be "DWORD" without an initial value).
- For the parameter "STAT" enter a symbolic name for the message block to be called, for example, "alarm" and the corresponding data type, in this case "SFB33."

3. In the code section of the function block, insert the call for the selected message block, here "CALL alarm", and finish your entry with RETURN.

Result: The input variables for the called message block (here SFB33) are displayed in the code section of the function block.

4. Assign the symbolic name you assigned in step 2 for the message block input, here "Mess01," to the variable "EV_ID". The system attributes are now applied for the message of type "alarm".

Result: A flag should appear in the "Name" column for the parameter "IN" if the column is not selected. The selected block is then set as a message-type block. The required system attributes (for example, S7_server and S7_a_type) and the corresponding values are assigned automatically (Note: for certain SFCs you will have to assign the system attributes for the parameter "IN" yourself. To do this select the menu command **Edit > Object Properties** and then select the "Attributes" tab.).

Caution: If you do not call an SFB, but rather an FB that contains multiple instances and configured messages, you must also configure the messages of this FB, with multiple instances, in the calling block.

5. Repeat steps 2 to 4 for all calls to message blocks in this function block.
6. Save the block using the menu command **File > Save**.
7. Close the "LAD/STL/FBD" window.

Opening the Message Configuration Dialog Box

- Select the desired message block and then select the menu command **Edit > Special Object Properties > Message** in the SIMATIC Manager.

Result: The STEP 7 message configuration dialog box (standard dialog box) is opened. Information on opening the PCS7 Message Configuration function can be found under PCS 7 Message Configuration.

Editing a Message Type

1. Select the desired message block, open the message configuration, and enter the required message text in the "Text" and "Attributes" tabs or select the required message attributes.
If you selected a multi-channel message block (for example, "ALARM_8"), you can assign specific texts and, to certain extent, specific attributes to each subnumber.
2. Assign the required display devices to the message type by clicking the "New Device" button and selecting the required display devices in the "Add Display Device" dialog box.

In the following tabbed pages, enter the required texts and attributes for the display devices. Exit the dialog box with "OK".

Note

When editing the display device specific texts and attributes, please read the documentation supplied with your display device.

Creating Instance Data Blocks

1. When you have created a message type, you can associate instance data blocks to it and edit the instance-specific messages for these data blocks. To do this, in the SIMATIC Manager open the block that is to call your previously configured function block, for example, "OB1", by double-clicking it. In the open code section of the OB, enter the call ("CALL"), the name and number of the FB to be called and of the instance DB that you want to associate with the FB as an instance. Confirm your entry with RETURN.

Example: Enter "CALL FB1, DB1". If DB1 does not yet exist, confirm the prompt asking whether you want the instance DB created with "Yes."

Result: The instance DB is created. In the code section of the OB, the input variables of the associated FBs, here for example "Mess01," and the message number allocated by the system, here "1," are displayed.

2. Save the OB with the menu command **File > Save** and close the "LAD/STL/FBD" window.

Editing Messages

1. In SIMATIC Manager, select the generated instance DB, for example, "DB1" and then call the menu command **Edit > Special Object Properties > Message** to open the message configuration dialog box.

Result: The "Message Configuration" dialog box is opened and the selected instance DB with the message number allocated by the system is displayed.

2. Enter the required changes for the corresponding instance DB in the appropriate tabs and add other display devices if you wish. Exit the dialog box with "OK."

Result: The message configuration for the selected instance DB is then complete.

Transferring Configuration Data

- Transfer the configured data to the WinCC database (via the AS-OS connection configuration) or the ProTool database.

16.2.2.2 How to Edit Block-Related Messages (Project-Oriented)

1. In the SIMATIC Manager, select a block and then select the menu command **Edit > Special Object Properties > Message**.
2. In the folder structure, click a message block input or one of its subnumbers (if available).

Result: The tabbed section for a standard message is displayed.

3. Enter the required texts and attributes in the "Text" and "Attributes" tabs.

Result: You have created a standard message that can be displayed on all display devices.

4. Using the "New Device" button, add a new display device of the type "ProTool" (Opx) or "WinCC." Only those display devices on which the configured messages can be displayed are available for selection.

Result: The new device is added and selected, and the corresponding tabbed section is displayed.

5. Enter attributes and texts for the display-specific message in the display-specific "Texts" and "Attributes" tabs.

Result: You have created a message variation that is only used as the message for the selected display device.

If you want to edit other message variations for existing display devices:

- Select and open the message block in the detailed view by double-clicking it.

Result: The first display device is automatically selected and you can now edit display-specific message variations for it.

16.2.2.3 How to Configure PCS 7 Messages (Project-Oriented)

For editing message types and messages to be output on WinCC display devices, the PCS7 message configuration function in STEP 7 provides a user-friendly method of:

- Simplifying the configuration of display devices (created automatically)
- Simplifying the entry of attributes and texts for messages
- Ensuring that messages are standardized.

Opening the PCS7 Message Configuration Function

1. In the SIMATIC Manager, select the block (FB or DB) whose message texts you want to edit. Select the menu command **Edit > Object Properties** to open the dialog box for entering system attributes.
2. In the table shown, enter the system attribute "S7_alarm_ui" and the value: "1" (the value 0 disables the PCS7 message configuration tool). Property parameters can be set in LAD/STL/FBD. DBs generated afterwards and assigned to the corresponding FBs take on these attributes and can be switched independently of their message type (FB).

Note

A syntax check is performed when you enter the system attributes. Faulty entries are highlighted in red.

3. Exit the dialog box with "OK."
4. Select the menu command **Edit > Special Object Properties > Message**

Result: The "PCS7 Message Configuration" dialog box is opened.

Editing Message Types

1. In the SIMATIC Manager, select the FB whose message texts you want to edit, and open the PCS7 message configuration dialog box.

Result: The dialog box displays a tab for each message block for which you declared a variable in the FB.

2. Fill out the text boxes for the message components "Origin," "OS area," and "Batch ID."
3. Enter the message class and the event text for all events of the message blocks used and specify whether every event must be acknowledged individually.
4. For the message parts that apply for all instances and should not be changed, select the "Locked" check box.

Editing Messages

1. Open SIMATIC Manager. Select the instance DB whose message texts you want to edit and open PCS7 message configuration function.
2. Do not edit instance-specific message parts that are not locked.

16.2.3 Assigning and Editing Symbol-Related Messages

16.2.3.1 How to Assign and Edit Symbol-Related Messages (Project-Oriented)


Symbol-related messages (SCAN) are assigned directly to a signal in the symbol table. Permitted signals are all Boolean addresses: inputs (I), outputs (Q), and bit memory (M). You can assign these signals different attributes, messages texts, and up to 10 associated values with the message configuration function. You can make it easier to select signals in the symbol table by setting filters.

With a symbol related message you can scan a signal in a predefined time interval to determine whether a signal change has taken place.

Note

The time interval is dependent on the CPU used.

Basic Procedure



During processing, the signals for which you have configured messages are checked asynchronously to your program. The checks take place at the configured time intervals. The messages are displayed on the assigned display devices.

Caution

If you want to assign or edit symbol-related messages and, during the same work procedure, you have previously copied symbols between two symbol tables, you will then have to first close the symbol table that you no longer need to work in. Otherwise, you will not be able to save your message configurations. Under certain conditions, the last entries made in the message configuration dialog will be lost.

16.2.4 Creating and Editing User-Defined Diagnostic Messages

Using this function you can write a user entry in the diagnostic buffer and send a corresponding message which you create in the message configuration application. User-defined diagnostic messages are created by means of the system function SFC52 (WR_USMSG; Error Class A or B) which is used as a message block. You must insert the call for the SFC52 in your user program and allocate it the event ID.


Requirements

Before you can create a user-defined diagnostic message, you must have done the following:

- Created a project in the SIMATIC Manager
- Created a S7/M7 program in the project to which you want to assign one or more messages.

Basic Procedure

To create and display a user-defined diagnostic message, proceed as follows:



16.3 CPU-Oriented Message Configuration

16.3.1 How to Assign CPU-Oriented Message Numbers

Messages of the CPU are identified by a unique number. This is done by assigning each CPU a number area. Other than for assigning project-oriented message numbers, there is no need to assign a new number area to the new program. A new compilation of the program is therefore not required. Note the exception when you copy individual blocks: In this case, you must recompile the program in order to implement the modified message number.


Requirements

- WinCC V6.0
- ProTool V6.0

16.3.2 Assigning and Editing Block-Related Messages

16.3.2.1 How to Create Block-Related Messages (CPU-Oriented)

Principles of operation



Programming Message-Type Blocks (FB)

1. In SIMATIC Manager, select the function block (FB) for which you want to generate a block-related message and open it with a double-click.

Result: The selected block is opened and displayed in the "LAD/STL/FBD" window.

2. Fill out the variable declaration table. You must declare the corresponding variables in the calling function block for every message block that is called in the function block.

Enter the following variables in the variable overview column:

- For the parameter "IN" enter a symbolic name for the message block input, for example, "Meld01" (for message input 01) and the data type (must be "DWORD" without an initial value).

- For the parameter "STAT" enter a symbolic name for the message block to be called, for example, "alarm" and the corresponding data type, here "SFB33."
- 3. In the code section of the function block, insert the call for the selected message block, here "CALL alarm", and finish your entry with RETURN.

Result: The input variables for the called message block (here SFB 33) are displayed in the code section of the function block.

- 4. Assign the symbolic name you assigned in step 2. for the message block input, here "Mess01," to the variable "EV_ID".

Result: A flag should appear in the "Name" column for parameter "IN" if the column is not selected. The selected block is then set as a message-type block. The required system attributes (for example, S7_server and S7_a_type) and the corresponding values are assigned automatically (Note: for certain SFCs you will have to assign the system attributes for the parameter "IN" yourself. To do this select the menu command **Edit > Object Properties** and then select the "Attributes" tab.).

Caution: If you call an FB that contains multiple instances and configured messages instead of an SFB, you must also configure the messages of this FB in the calling block.

- 5. Repeat steps 2. to 4. for all calls to message blocks in this function block.
- 6. Save the block using the menu command **File > Save**.
- 7. Close the "LAD/STL/FBD" window.

Opening the Message Configuration Dialog Box

- Select desired message block and then select the menu command **Edit > Special Object Properties > Message** in the SIMATIC Manager.

Result: The STEP 7 message configuration dialog box is opened. Information on opening the PCS7 Message Configuration function can be found under PCS7 Message Configuration (CPU-Oriented).

Editing a Message Type

- Select the desired message block.
- Enter the required text in the appropriate columns or select the required attributes.
In the "Message Configuration" dialog box, you can click on the "More" button and enter the message text and additional text in the "Default Texts" tab
If you selected a multi-channel message block (for example, "ALARM_8"), you can assign specific texts and, to certain extent, specific attributes to each subnumber.
- If the texts or attributes for the instance should not be changed, you can lock them in the message type.

Creating Instance Data Blocks

1. When you have created a message type, you can associate instance data blocks to it and edit the instance-specific messages for these data blocks. To do this, in the SIMATIC Manager open the block that is to call your previously configured function block, for example, "OB1" by double-clicking it. In the open code section of the OB, enter the call ("CALL"), the name and number of the FB to be called and of the instance DB that you want to associate with the FB as an instance. Confirm your entry with RETURN.

Example: Enter "CALL FB1, DB1". If DB1 does not yet exist, confirm the prompt asking whether you want the instance DB created with "Yes."

Result: The instance DB is created. In the code section of the OB, the input variables of the associated FBs, here for example "Mess01," and the message number allocated by the system, here "1," are displayed.

2. Save the OB with the menu command **File > Save** and close the "LAD/STL/FBD" window.

Editing Messages

1. In the SIMATIC Manager, select the created instance DB, for example, "DB1" and select the menu command **Edit > Special Object Properties > Message** to open the message configuration dialog box.

Result: The "Message Configuration" dialog box is opened and the selected instance DB with the message number assigned by the system is displayed.

2. Enter the required changes for the corresponding instance DB in the appropriate tabs and add other display devices if you wish. Exit the dialog box with "OK."

Result: The message configuration for the selected instance DB is then complete.

Note

If texts and attributes for an instance are displayed in green, this means the following: these texts and attributes are still as they were configured in the message type. They have not been changed at the instance.

Transferring Configuration Data

- Transfer the configured data to the WinCC database (via the AS-OS connection configuration) or the ProTool database.

16.3.2.2 How to Edit Block-Related Messages (CPU-Oriented)

1. Select a message block, and then select the menu command **Edit > Special Object Properties > Message** to call message configuration.
2. Enter your required text in the "Default Texts" and "Additional Texts" columns. You can also click on the "More" button and enter your required text (with line breaks) in the "Default Texts" and "Additional Texts" dialog boxes.

Result: You have created a standard message.

Note

If texts and attributes for an instance are displayed in green, this means the following: these texts and attributes are still as they were configured in the message type. They have not been changed at the instance.

16.3.2.3 How to Configure PCS 7 Messages (CPU-Oriented)

For editing message types and messages to be output on WinCC display devices (as of V6.0), the PCS7 message configuration function in STEP 7 provides a user-friendly method of:

- Simplifying the configuration of display devices
- Simplifying the input of attributes and texts for messages
- Ensuring that messages are standardized.

Opening the PCS7 Message Configuration Function

1. In SIMATIC Manager, select the block (FB or DB) whose message texts you want to edit. Select the menu command **Edit > Object Properties** to open the dialog box for entering system attributes.
2. In the table shown, enter the system attribute "S7_alarm_ui" and the value: "1" (the value 0 disables the PCS7 message configuration tool). Property parameters can be set in LAD/STL/FBD. DBs generated afterwards and assigned to the corresponding FBs take on these settings and can be switched using their own attribute settings, independently of their message type (FB).

Note

A syntax check is performed when you enter the system attributes. Faulty entries are highlighted in red.

3. Exit the dialog box with "OK."
4. Select the menu command **Edit > Special Object Properties > Message**

Result: The "PCS7 Message Configuration" dialog box is opened.

Editing Message Types

1. In SIMATIC Manager, select the FB whose message texts you want to edit, and open the PCS7 message configuration dialog box.
2. Click on "More" to open the "Message text block". Fill out the text boxes for the message components "Origin," "OS area," and "Batch ID."
3. Enter the message class and the event text for all events of the message blocks used and specify whether every event must be acknowledged individually.
4. For the message parts that apply for all instances and should not be changed, select the "Locked" check box.

Editing Messages

1. Open SIMATIC Manager. Select the instance DB whose message texts you want to edit and open PCS7 message configuration function.
2. Do not edit instance-specific message parts that are not locked.

16.3.3 Assigning and Editing Symbol-Related Messages

16.3.3.1 How to Assign and Edit Symbol-Related Messages (CPU-Oriented)


Symbol related messages (SCAN) are assigned directly to a signal in the symbol table. Permitted signals are all Boolean addresses: inputs (I), outputs (Q), and bit memory (M). You can assign these signals different attributes, messages texts, and up to 10 associated values with the message configuration function. You can make it easier to select signals in the symbol table by setting filters.

With a symbol related message you can scan a signal in a predefined time interval to determine whether a signal change has taken place.

Note

The time interval is dependent on the CPU used.

Basic Procedure



During processing, the signals for which you have configured messages are checked asynchronously to your program. The checks take place at the configured time intervals. The messages are displayed on the assigned display devices.

Caution

If you want to assign or edit symbol-related messages and, during the same work procedure, you have previously copied symbols between two symbol tables, you will then have to first close the symbol table that you no longer need to work in. Otherwise, you will not be able to save your message configurations. Under certain conditions, the last entries made in the message configuration dialog will be lost.

16.3.4 Assigning and Editing User-Specific Diagnostic Messages

Using this function you can write a user entry in the diagnostic buffer and send a corresponding message which you create in the message configuration application. User-defined diagnostic messages are created by means of the system function SFC52 (WR_USMSG; Error Class A or B) which is used as a message block. You must insert the call for the SFC52 in your user program and allocate it the event ID.


Requirements

Before you can create a user-defined diagnostic message, you must have done the following:

- Created a project in the SIMATIC Manager
- Created a S7/M7 program in the project to which you want to assign one or more messages.

Basic Procedure

To create and display a user-defined diagnostic message, proceed as follows:



16.4 Tips for Editing Messages

16.4.1 Adding Associated Values to Messages

To add current information (such as from a process) to block-related and symbol-related messages, you can insert associated values at any point in a message text.

To add values, proceed as follows:

1. Create a block with the following structure:
`@<No. of associated value><Element type><Format code>@.`
2. Insert this block at the locations in the message text where the associated value is to be displayed.

Element Type

This parameter assigns a unique identification to the data type of the associated value:

Element Type	Data Type
Y	BYTE
W	WORD
X	DWORD
I	Integer
D	Integer
B	BOOL
C	CHAR
R	REAL

The element type only uniquely specifies the data type transferred by the PLC. It is not used as a casting operator.

Format Code

These codes specify the output format for the associated value on the display device. A format instruction is introduced by a "%" sign. For message texts, there are the following fixed message codes:

Format Code	Description
%[i]X	Hex value with i index
%[i]u	Unsigned decimal value with i index
%[i]d	Signed decimal value with i index
%[i]b	Binary value with i index
%[i][.y]f	Integer (fixed-point no.) Signed value with the format [-]dddd.dddd dddd: one or more digits with y places after the decimal point and i total places
%[i]s	Character string (ANSI string) with i places Characters are printed to the first 0 byte (00hex).
%t#<name of the text library>	Access to text library.

If the format code is too small, the value is still output in its full length.

If the format code is too large, an appropriate number of blanks is output before the value.

Note

Note that you can also optionally specify the "[i]", in which case you must leave out the brackets when you enter this parameter.

Examples of Associated Values

@1%6d@: The value from associated value 1 is displayed as a decimal number having a maximum of 6 places.

@2R%6f@: The value "5.4," for example, from associated value 2 is displayed as an integer "5.4" (three leading blanks).

@2R%2f@: The value "5.4," for example, from associated value 2 is displayed as an integer "5.4" (for a number of places that is too small, truncation does not occur).

@1W%t#Textbib1@: Associated value 1 of the data type WORD is the index with which the text to be used is referenced in the text library TextLib1.

Note

When using S7-PDIAG, you must always indicate "C" for the element type CHAR and "R" for the element type REAL. For all other element types valid for S7-PDIAG (BOOL, BYTE, WORD, INT, DWORD and DINT), you must always specify "X".

If you wish to pass one of the ALARM_S blocks more than one associated value, you can send an array with a maximum length of 12 bytes. This can be, for example, a maximum of 12 bytes or characters, a maximum of 6 words or Int or a maximum of 3 double words, real or DInt.

16.4.2 Integrating Texts from Text Libraries into Messages

You can integrate as many texts as you want from a maximum of four different text libraries into one message. The texts can be placed freely, so their use in foreign language messages is also guaranteed.

Proceed as follows:

1. In the SIMATIC Manager, select the CPU or an object subordinate to the CPU and select the menu command **Options > Text Libraries > System Text Libraries** or **Options > Text Libraries > User-Specific Text Libraries** to open a text library.

Caution

You can only integrate texts from user text libraries into messages if you have selected to assign message numbers to the CPU (CPU-oriented message numbers).

1. Determine the index of the text that you want to integrate.
2. At the place in the message where you want the text to appear, enter a placeholder in the format @[Index]%t#[Textbib]@

Note

[Index] = 1W, where 1W is the first associated value for the message of type WORD.

Example

Configured message text: Pressure rose @2W%t#Textbib1@

Text library with the name Textbib1:

Index	German	English
1734	zu hoch	too high

The second associated value transferred has been assigned the value 1734. The following message is displayed: Pressure rose too high.

16.4.3 Deleting Associated Values

You can delete associated values by deleting the character string in the message text which represents the associated value.

Proceed as follows:

1. Locate the block of information in the message text corresponding to the associated value that you want to delete.
The block begins with an @ sign, followed by a location designator identifying the associated value as well as a format code; it ends with another @ sign.
2. Delete this information from the message text.

16.5 Translating and Editing Operator Related Texts

Texts that are output on display devices during process editing were usually input in the same language used to program the automation solution.

It may often be the case that an operator who is to react to messages on a display device does not speak this language. This user needs texts written in his native language to ensure smooth, problem-free processing and quick reaction to messages output by the system.

STEP 7 allows you to translate any and all operator related texts into any language required. The only prerequisite for this is that you have already installed the language in your project (menu command: **Options > Language for Display Devices** in the SIMATIC Manager). The number of languages available is determined when Windows is installed (system property).

In this way you can be certain that any user faced with such a message at a later date will have it displayed in the appropriate language. This system feature considerably increases processing security and accuracy.

16.5.1 Translating and Editing User Texts

You can create user texts for an entire project, for S7 programs, the block folder or individual blocks, and for the symbol table if messages are configured in these objects. They contain all texts and messages that can be shown on display devices, for example. For one project, there can be several lists of operator related texts that you can translate into the required languages.

You can select the languages that are available in a project (menu command **Options > Language for Display Devices...**). You can also add or delete languages later.


Exporting and Importing Operator Related Texts

You can translate or edit operator related texts that were created in STEP 7 outside of STEP 7. To do this, export the displayed list of operator related texts in export files that you can edit with an ASCII-based Editor or a spreadsheet tool such as Microsoft EXCEL (Menu command **Options > Manage Multilingual Texts > Export**). After you have opened the file, the screen displays a table that contains a column for each language. The first column always displays the set standard language. After the texts have been translated, re-import them again in STEP 7.

You can only import operator related texts into the part of the project from which you exported them.

Basic Procedure

Ensure that you have set your target languages for the text translation in SIMATIC manager, under menu command **Options > Language for Display Devices**.



Note

You can print user text only under the application used for the translation.

16.6 Translating and Editing Text Libraries

16.6.1 User Text Libraries

A user text library lets you view text or text segments dynamically, depending on the associated value. Here, the associated value provides the text library index for the current text. A placeholder is entered at the position where the dynamic text is to be displayed.

You can create user libraries for a program in which you can enter text and select your own index. The application will automatically check the index in the user library for uniqueness. All messages available for this CPU can contain a cross-reference to a user text library.

The number of text libraries in a text library folder is unlimited. It is therefore possible, for example, to use the same program for different controlling tasks and merely adapt the text libraries to application requirements.

Caution

When you copy a message-type block that contains a cross-reference to a text library into another program, you must include the corresponding text libraries, or create a new text library of the same name or edit the cross-reference in the message text.

An index is always assigned by default when you create a text entry. When you enter a new line, the application proposes the next free index as the default. Ambiguous indexes are not permitted in text library and are rejected by the application.

16.6.2 Creating User Text Libraries

To create a user text library, proceed as follows:

1. In SIMATIC Manager, select the program or the subordinate object within the program for which you want to create a user text library. In SIMATIC Manager, select the menu command **Insert > Text Library > Text Library Folder**.

Result: The "Text Library" folder is created.

3. Now, select the "Text Library" folder. Select the menu command **Insert > Text Library > User Text Library** and name the text library.
4. To open the new text library, select menu command **Options > Text Libraries > User Text Library**
5. Now you can enter your text.

Note

An index is always assigned by default when you create a text entry. When you enter a new line, the application proposes the next free index as the default. Ambiguous indexes are not permitted in text library and are rejected by the application.

16.6.3 How to Edit User Text Libraries

To edit existing user text libraries, proceed as follows:

1. In SIMATIC Manager, select the program or the subordinate object within the program whose text library you want to edit and then select the menu command **Options > Text Libraries > User Text Library**.
2. Select the text library you want to open from the "Available Text Libraries" dialog box.
3. Edit the displayed texts. There are various editing functions available (such as Find and Replace).
You can enter your own texts. You can always change the index that is automatically generated for the texts. If you should happen enter a previously assigned index, its value is highlighted in red.
To insert a new row, select the menu command **Insert > New Row** or click on the corresponding toolbar icon.
4. If you require a hardcopy, print the texts.
5. Close the user text library after you have completed all tasks.
6. Close the application after you have edited all texts required.

Caution

When you copy a message-type block that contains a cross-reference to a text library into another program, you must include the corresponding text libraries, or create a new text library of the same name or edit the cross-reference in the message text.

When you change the name of an existing text library, you will render the associated values cross-referenced to this text library invalid in already configured messages!

16.6.4 System Text Libraries

System text libraries are automatically created when blocks are generated, e.g. in "Report System Errors". The user can not create system text libraries and can only edit existing text libraries.

All messages available for this CPU can contain a cross-reference to a text library.

16.6.5 Translating Text Libraries

System text libraries and user text libraries provide a list of texts that can be integrated into messages, updated dynamically at run time, and shown on a programming device or other display device.

The texts in system text libraries are provided by STEP 7 or STEP 7 optional packages. There can be several text libraries assigned to one CPU. You can translate these texts into the required languages.

In the SIMATIC Manager, you can select the languages that are available in a project (menu command **Options > Language for Display Devices...**). You can also add or delete languages later.

When you initiate the translation of a text library (Menu command **Options > Manage Multilingual Texts > Export**), an export file will be generated that you can edit under Microsoft EXCEL, for example. After you have opened the file, the screen displays a table that contains a column for each language

Caution

Never open a *.cvs export file with double-click on the file. Always use menu command **File > Open** under Microsoft EXCEL to open the file.

Note


You can print user text only in the application used for the translation.

Example of an export file

German	English
ausgefallen	Failure
gestört	Disruption
Parametrierfehler	Faulty parameter assignment

Basic Procedure

In the SIMATIC Manager, with the menu command **Options > Language for Display Devices...**, make sure that you have set the languages into which you want to translate a text library.



16.7 Transferring Message Configuration Data to the Programmable Controller

Overview


Use the transfer program AS-OS Engineering to transfer the message configuration data generated to the WinCC database.

Requirements

Before you start the transfer, the following requirements must be fulfilled:

- You have installed "AS-OS Engineering"
- You have generated the configuration data for creating messages.

Basic Procedure



16.8 Displaying CPU Messages and User-Defined Diagnostic Messages

With the "CPU Messages" function (Menu command **PLC > CPU Messages**), you can display asynchronous messages on diagnostic events and user-defined diagnostic messages as well as messages from ALARM_S blocks (SFC 18 and SFC 108 for generating block-related messages that are always acknowledged as well as SFC 17 and SFC 107 for generating block-related messages that can be acknowledged).

You can also start the message configuration application from the CPU Messages application using the menu command **Edit > Message > User-Defined Diagnostics** and create user-defined diagnostic messages. The requirement for this is that you started the CPU Messages application via an online project.

Display Options

With the "CPU Messages" function, you can decide whether and how online messages for selected CPUs are displayed.


- **"Highlight in the Task Bar"**: As soon as a message is received and the window is not on top, "CPU Message" is highlighted in the Windows task bar.
- **"Leave in the Background"**: The CPU messages are received in the background. The window remains in the background when new messages are received and can be brought to the foreground if required.
- **"Ignore Message"**: New CPU messages are **not** displayed and, in contrast to the other two modes, **not** archived.

In the "CPU Messages" window you can select the "Archive" tab or the "Interrupt" tab. In both tabs you can select the menu command **View > Display Info Text** to specify whether the messages are displayed with or without Info text. The user can sort the columns as required.

"Archive" Tab

Incoming messages are here displayed and archived, sorted by the event message time. The volume of the archive (between 40 and 3000 CPU messages) can be set via menu command **Options > Settings** in the "Settings - CPU Messages" dialog box. The oldest queued message will be deleted if the set archive volume is exceeded.

Acknowledgeable messages (ALARM_SQ and ALARM_DQ) are displayed in bold letters. You can acknowledge these messages under the menu command **Edit > Acknowledge CPU Message**.



"Interrupt" Tab

The status of queued messages from ALARM_S blocks that have not yet been received or acknowledged is also displayed in the "Interrupt" tab.

You can select the menu command **View > Multiline Messages** to display messages on one or more lines. In addition, you can sort the columns as necessary.


Updating Messages from ALARM_S Blocks

During updating all unsent or unacknowledged messages are entered in the archive again. The messages are updated:

- If a restart is performed on the module to which the messages relate (not a cold restart)
- If you click the option "A" for messages from ALARM_S Blocks in the module list.

Basic Procedure

To configure CPU messages for selected modules:



16.8.1 Configuring CPU Messages

To configure CPU messages for selected modules, proceed as follows:

1. In the SIMATIC Manager, start the CPU Messages application via an online project. To do this, select an S7 program online and call the CPU Messages application for the selected CPU using the menu command **PLC > CPU Messages**.

Result: The "CPU Messages" application window appears which lists the registered CPU.

2. You can extend the list of registered CPUs by repeating step 1. for other programs or interfaces.
3. Click the check box in front of the list entries and specify which messages should be received for the module:

A: activates messages from ALARM_S blocks (SFC 18 and SFC 108 for generating block-related messages that are always acknowledged as well as SFC 17 and SFC 107 for generating block-related messages that can be acknowledged), for example, reporting process diagnostic messages from S7 PDIAG, S7-GRAPH, or system errors.

W: activates diagnostic events.

4. Set the size of the archive.

Result: As soon as the above messages occur, they are written in the message archive and displayed in the form you selected.

Note

The CPUs for which you have called the menu command **PLC > CPU Messages** in the SIMATIC Manager are entered in the list of registered modules in the "CPU Messages" application window. The entries in the list are retained until they are deleted in the "CPU Messages" application window.

16.8.2 Displaying Stored CPU Messages

CPU messages are always recorded in the archive unless you have selected the menu command **View > Ignore Message**. All archived messages are always displayed.

16.9 Configuring the 'Reporting of System Errors'

Introduction

When a system error occurs, S7 components and DP standard slaves (slaves whose properties are determined by their GSD file) can trigger organization block calls.

Example: If there is a wire break, a module with diagnostic capability can trigger a diagnostic interrupt (OB82).

For the system errors that occur, the S7 components provide information. The start event information, that is, the local data of the assigned OB (which contain the data record 0, among other things), provide general information on the location (such as the logical address of the module) and type (such as channel error or backup failure) of the error.


In addition, the error can be specified in greater detail by means of additional diagnostic information (reading data record 1 with SFC51 or reading the diagnostic message of DP standard slaves with SFC13). Examples of this would be channel 0 or 1 and wire break or measuring-range overrun.

With the Report System Error function, STEP 7 offers a convenient way to display diagnostic information supplied by the component in message form..

The necessary blocks and message texts are automatically generated by STEP 7. All the user has to do is load the generated blocks into the CPU and transfer the texts to connected HMI devices.

You will find a complete overview of the supported diagnostic information for various slaves in the section Supported Components and Functional Scope

Basic Procedure



The messages are sent by means of the standard message path ALARM_S/SQ to CPU Messages on the programming device or to the connected HMI devices.

16.9.1 Supported Components and Functional Scope

The components of S7 300 stations, S7 400 stations, DP slaves, and WinAC are supported by Report System Error, as long as they support functions such as diagnostic interrupt insert/remove module interrupt, and channel-specific diagnostics.

The following components are **not** supported by Report System Error:

- M7, C7, and PROFIBUS-DP configurations on DP master interface module (CP 342-5 DP) in S7-300 stations

In the case of a restart, you must also note that missing interrupt messages can occur. This is because the message acknowledgement memory of the CPU cannot be deleted during restart but Report System Error resets the internal data.

In the two tables that follow, you will find all the diagnostic blocks of the various PROFIBUS slaves supported by "Report System Error"

Diagnostic Block	ID (faulty slot)	Channel Designation (channel error) 1)	Module Status (module error, incorrect/no module)	Device Designation
Header ID 2)	0x01	0x10	0x00 Type 0x82	0x00 + 1 Byte Diagnostic Info
ET 200S	Message: "Diagnostics is available"	Plain-Text Message	Plain-Text Message	-
ET 200M	Not Evaluated	Not Evaluated	Not Evaluated	-
ET 200X	Message: "Diagnostics is available"	-	-	-
ET 200X DESINA	Message: "Diagnostics is available"	Plain-Text Message	Plain-Text Message	-
ET 200L	not evaluated	-	-	-
ET 200B Digital				Message: "Module Malfunction"
ET 200B Analog		-	-	
ET 200C Digital				
ET 200 C Analog	Message: "Diagnostics Available"			Message: "Module Malfunction"
ET 200 U	Message: "Diagnostics Available"			Message: "Module Malfunction"
ET 200 iS	Message: "Diagnostics Available"	Plain-text message	Plain-text message	
ET 200 eco	-	-	-	Plain-text message
DP AS-i Link	Message: "Diagnostic data available"	-	Plain-text message	-

Diagnostics Block	DS0/DS1 1	Other Instancing
Header ID 2	0x00 Type 0x01	0x00 Other Type
ET 200S		
ET 200M	Plain-text message	Not Evaluated
ET 200X		
ET 200X DESINA	Plain-text message	
ET 200L	Plain-text message	
ET 200B Digital		
ET 200B Analog	Plain-text message	
ET 200 C Digital		
ET 200 C Analog	Plain-text message	
ET 200 iS	Plain-text message	
ET 200 eco	-	-
DP AS-i Link	Message: "Module error"	

In the tables that follow, you will find all the diagnostic blocks of the various PROFIBUS slaves supported by "Report System Error".

Diagnostics Block	ID (faulty slot)	Channel Designation (channel error 1)	Module Status (module error, incorrect/no module)	Device Designation
Header ID 2)	0x01	0x10	0x00 Type 0x82	0x00 + 1 Byte Diagnostic Info
ET 200 S	Message: "Diagnostics are available"	Plain-text Message	Plain-text Message	-
SCALANCE Switches	-	-	Plain-text Message	-

Diagnostics Block	DS0/DS1 1)	Other Instancing
Header ID 2	0x00 Type 0x01	0x00 Other Type
ET 200 S	-	-
SCALANCE switches	Plain-text message	Not evaluated

- 1) DS0: Standard diagnostics, for example module fault, external auxiliary voltage or front connector missing, extent 4 bytes, contained in the local data of the OB 82.
 DS1: Channel error, defined differently for each channel type, readable in the user program via SFC 51.
 The texts come from the S7 HW diagnostics.
- 2) Header identifier: Identifier in the diagnostic message which identifies different diagnostic parts.

The diagnostic message (also called Norm slave message) is made up of the diagnostic blocks mentioned above and can be read in the user program via SFC 13.

In STEP 7 the diagnostics message is displayed via the call of the module state in the on-line window "HW Config" (diagnose hardware) in the "DP Slave Diagnostics" tab card under "Hex display".

Diagnostic Repeater: The messages of the Diagnostic Repeater are output as plain-text. The text is read from the GSD file.

PROFINET

- With PROFINET IO, the channel diagnostics are output as a plain-text message.
- ET 200S: Slaves with packed addresses are supported.
- With PROFINET IO devices, manufacturer-specific diagnostics are supported.

16.9.2 Settings for "Report System Error"

You have several possibilities for calling the dialog for the settings:

- In HW Config, select the CPU for which you would like to configure the reporting of system errors. Then select the menu command **Options > Report System Error**.
- If you have already generated blocks for reporting system errors, you can call up the dialog by double-clicking a generated block (FB, DB).
- In the Properties dialog of the station, select the option for automatic call up during Save and Compile the configuration.

You get to the option for automatic call up during Save and Compile as follows:

1. In the SIMATIC Manager, select the appropriate station.
2. Select the menu command **Edit > Object Properties**.
3. Select the Settings tab.

Note

You can also open the "Settings" tab of the properties dialog in HW Config via menu command **Station > Properties**.

In the dialog box, enter the following, in addition to other things:

- Which FB and which assigned instance DB should be generated
- Whether reference data should be generated
- Whether warnings should always be displayed during the generation of Report System Error.
- Whether the dialog box should appear when Report System Error is automatically called after saving and compiling the configuration (see setting above)
- Generating error OBs: whether or not error OBs that are not yet available should be generated in the S7 program and in which OBs "Report System Error" is to be called.
- The CPU behavior on error: You can determine which error class event is trigger the CPU to STOP mode.
- The appearance of the messages (structure and order of the possible text parts)
- Whether messages should be acknowledgeable
- Which parameters the user block interface should contain

You can find more detailed information in the Help on the called dialog.

16.9.3 Generating Blocks for Reporting System Errors

After you have completed your settings for reporting system errors, you can generate the required blocks (FBs and DBs, including DBs that do not yet exist, depending on the configuration). To do this, click on the "Generate" button in the "Report System Errors" dialog box.

The following blocks are generated:

- Diagnostic FB (default: FB49)
- Instance DB for the diagnostic FB (default: DB49)
- Error OBs (if you have selected this option in the "OB Configuration" dialog box),
- Optional user block called by the diagnostic FB

16.9.4 Generated FB, DB

The generated FB evaluates the local data of the error OB, reads any additional diagnostic information of the S7 component that triggered the failure, and generates the appropriate message automatically.

The FB has the following properties:

- Language of generation RSE (Report System Error) (also applies to the generated instance DB)
- Know-how protected (also applies to the generated instance DB)
- Delays arriving interrupts during run time
- Calls up the dialog for setting the "Report System Error" function by means of double-click (also applies to the generated instance DB).

User Block

Because the diagnostics FB is know-how protected, you cannot edit it. However, the FB provides an interface for the user program so that you can access such things as the error status or the message number.

The block for evaluating in the user program (can be set in the User Block tab of the of the dialog) is called in the generated FB with the selected parameters. The following parameters are available:

Name	Data Type	Comments
EV_C	BOOL	//Message incoming (TRUE) or outgoing (FALSE)
EV_ID	DWORD	//Generated message number
IO_Flag	BYTE	//Input module: B#16#54 Output module: B#16#55
logAdr	WORD	//Logical address
TextlistId	WORD	//ID of the text library (default text library = 1)
ErrorNo	WORD	//Generated error number
Channel_Error	BOOL	//Channel error (TRUE)
ChannelNo	WORD	//Channel number
ErrClass	WORD	//Error Class
HErrClass	WORD	//Error Class of H Systems

If the user FB does not exist yet, it is created by the SFM with the selected parameters.

The error texts generated for standard errors are arranged as follows:

Error Number (decimal)		Error-OB Affected	Error Code in the OB	
from	to		from	to
1	86	OB 72	B#16#1	B#16#56
162	163	OB 70	B#16#A2	B#16#A3
193	194	OB 72	B#16#C1	B#16#C2
224		OB 73	B#16#E0	
289	307	OB 81	B#16#21	B#16#33
513	540	OB 82		
865	900	OB 83	B#16#61	B#16#84
1729	1763	OB 86	B#16#C1	B#16#C8

Error numbers greater than 12288 refer to channel errors. If you view the error number in hexadecimal representation, you can calculate the channel type and recognize the error bit. For an exact description, refer to the respective module help or channel help text.

Example:

12288 = W#16#3000 -> high byte 0x30 - 0x10 = channel type 0x20 (CP interface);
low byte 0x00, means error bit 0

32774 = W#16#8006 -> high byte 0x80 - 0x10 = channel type 0x70 (digital input);
low byte 0x06, means error bit 6

16.9.5 Creating Foreign-Language Message Texts in 'Report System Error'

You can display the messages configured in "Report System Error" in the languages that you installed when you installed STEP 7.

To do so, proceed as follows:

1. In the SIMATIC Manager, select the **Options > Display Language...** menu command. In the dialog box that is then displayed, add the desired language to your project.
2. Confirm your settings with "OK".
3. In HW Config, select the **Options > Report System Error...** menu command. In the dialog box that is then displayed, click the "Generate" button.
Result: The message texts are generated for all the languages that you installed, but they are only displayed in the language that you have set as the default in the "Add/Delete Language, Set Default Language" dialog box by clicking the "Set as Default" button.

Example

You have installed STEP 7 in German, English and French, and these languages are defined in your project. Now you generate the message texts as described above. To display the messages texts in a given language, set this language as the default in the "Add/Delete Language, Set Default Language" dialog box.

17 Controlling and Monitoring Variables

17.1 Configuring Variables for Operator Control and Monitoring

Overview

STEP 7 provides a user-friendly method of controlling and monitoring variables in your process or programmable controller using WinCC.

The advantage of this method over previous methods is that you no longer need to configure data separately for each operator station (OS), you simply configure once using STEP 7. You can transfer the data generated when you configure with STEP 7 to the WinCC database using the transfer program AS-OS Engineering (part of the software package "Process Control System PCS7"), during which the consistency of the data and their compatibility with the display system are checked. WinCC uses the data in variable blocks and graphic objects.

Using STEP 7, you can configure or modify operator control and monitoring attributes for the following variables:

- Input, output, and in/out parameters in function blocks
- Bit memory and I/O signals
- Parameters for CFC blocks in CFC charts

Basic Procedure

The procedure for configuring operator control and monitoring variables is dependent on the selecting programming/configuration language and the type of variables you want to control and monitor. The basic procedure always includes the following steps, however:

1. Assign system attributes for operator control and monitoring to the parameters of a function block or to the symbols in a symbol table.

The step is not required in CFC because you take blocks that have already been prepared from a library.

2. Assign the variables you want to control and monitor with the required attributes and logging properties in a dialog box (S7_m_c). In the Operator Interface dialog box (menu command **Edit > Special Object Properties > Operator Interface**), you can change WinCC attributes, such as limit values, substitute values, and protocol properties, etc.
3. Transfer the configuration data generated with STEP 7 to your display system (WinCC) by means of the AS-OS Engineering tool.

Naming Conventions

For the configuration data for WinCC to be saved and transferred, they are stored under a unique name automatically assigned by STEP 7. The names of the variables for operator control and monitoring, the CFC charts, and the S7 programs form part of this name and for this reason are subject to certain conventions:

- The names of the S7 programs in an S7 project must be unique (different stations may not contain S7 programs with the same name).
- The names of the variables, S7 programs, and CFC charts may not contain underscores, blanks, or the following special characters: ['] [.] [%] [-] [/] [*] [+].

17.2 Configuring Operator Control and Monitoring Attributes with Statement List, Ladder Logic, and Function Block Diagram


Overview

Using the procedure described below, you can make function block parameters suitable for operator control and monitoring and assign the required O, C, and M attributes to associated instance DBs or shared DBs in your user program.

Requirements

You must have created a STEP 7 project, an S7 program, and a function block.

Basic Procedure



17.3 Configuring Operator Control and Monitoring Attributes via the Symbol Table

Overview

Independent of the programming language used, you can configure the following variables using the procedure described below:


- Bit memory
- I/O signals

Requirement

Before you start, the following requirements must be fulfilled:

- You have created a project in the SIMATIC Manager.
- An S7 program with a symbol table must exist in this project.
- The symbol table must be open.

Basic Procedure



17.4 Changing Operator Control and Monitoring Attributes with CFC

Overview

With CFC, you create your user program by selecting blocks that already have operator control and monitoring capabilities from a library, and placing and linking them in a chart.

Requirement

You have inserted an S7 program in a STEP 7 project, created a CFC chart, and placed blocks in it.

Basic Procedure

Edit the object properties of the blocks.

Note

If you use blocks which you have created yourself and to which you have assigned the system attribute S7_m_c, you can give these blocks operator control and monitoring capabilities by activating the "Operator Control and Monitoring" check box in the "Operator Control and Monitoring" dialog box (menu command **Edit > Special Object Properties > Operator Control and Monitoring**).

17.5 Transferring Configuration Data to the Operator Interface Programmable Controller

Introduction

Using the transfer program AS-OS Engineering you transfer the configuration data for operator control and monitoring generated to the WinCC database.


Requirement

Before you start the transfer, the following requirements must be fulfilled:

- You have installed the program AS-OS Engineering.
- You have generated the configuration data for operator control and monitoring.

Basic Procedure

To transfer the configuration data for operator control and monitoring to the WinCC database, proceed as follows:



18 Establishing an Online Connection and Making CPU Settings

18.1 Establishing Online Connections

An online connection between programming device and programmable logic controller is needed to download S7 user programs/blocks, upload blocks from the S7 programmable controller to the programming device, and for other activities:

- Debugging user programs
- Displaying and changing the operating mode of the CPU
- Displaying and setting the time and date of the CPU
- Displaying module information
- Comparing blocks online and offline
- Diagnosing hardware

To establish an online connection, the programming device and programmable logic controller must be connected via a suitable interface (for example, multipoint interface (MPI)). You can then access the programmable controller via the online window of the project or the "Accessible Nodes" window.

18.1.1 Establishing an Online Connection via the "Accessible Nodes" Window

This type of access enables you to access a programmable logic controller quickly, for test purposes, for example. You can access all the accessible programmable modules in the network. Select this method if no project data about the programmable controllers are available on your programming device.

You open the "Accessible Nodes" window using the menu command **PLC > Display Accessible Nodes**. In the "Accessible Nodes" object, all the nodes accessible in the network are displayed with their address.

Nodes that cannot be programmed with STEP 7 (such as programming devices or operator panels) can also be displayed.

The following additional information can also be shown in parentheses:

- (direct): This node is directly connected to the programming device (programming device or PC).
- (passive): Programming and status/modify via PROFIBUS DP is not possible with this node
- (waiting): This node cannot be communicated with because its configuration does not match the rest of the settings in the network.

Finding directly connected nodes

The additional information "direct" is not supported for PROFINET nodes. To still be able to find directly connected nodes, select the **PLC > Diagnostics/Settings > Node Flashing Test** menu command.

In the dialog box that is displayed, you can set the flashing duration and then start the flashing test. The directly connected node will be identified by a flashing FORCE LED.

The flashing test cannot be carried out if the FORCE function is active.

18.1.2 Establishing an Online Connection via the Online Window of the Project

Select this method if you have configured the programmable controller in a project on your programming device/PC. You can open the online window in the SIMATIC Manager using the menu command **View > Online**. It displays the project data on the programmable controller (in contrast to the offline window that displays the project data on the programming device/PC). The online window shows the data on the programmable controller both for the S7 program and for the M7 program.

You use this view of the project for functions involving access to the programmable controller. Certain functions in the "PLC" menu of the SIMATIC Manager can be activated in the online window but not in the offline window.

There are two types of access as follows:

- **Access with Configured Hardware**
This means you can only access modules which were configured offline. Which online modules you can access is determined by the MPI address set when the programmable module was configured.
- **Access without Configured Hardware**
The requirement for this is an existing S7 program or M7 program which was created independently of the hardware (meaning it lies directly beneath the project). Which online modules you can access is determined here by specifying the corresponding MPI address in the object properties of the S7/M7 program.

Access via the online window combines the data on the programmable control system with the relevant data on the programming device. If, for example, you open an S7 block beneath a project online, the display is made up as follows:

- Code section of the block from the CPU in the S7 programmable logic controller, and
- Comments and symbols from the database in the programming device (provided they exist offline) When you open blocks directly in the connected CPU without an existing project structure, they are displayed as they are found in the CPU, which means without symbols and comments.

18.1.3 Online Access to PLCs in a Multiproject

Cross-project access with an assigned PG/PC

The "Assign PG/PC" function for the objects "PG/PC" and "SIMATIC PC Station" are also available for the multiproject.

You can specify the target module for online access in any project of the multiproject. This procedure is the same as if you were working with one project only.

Requirements


- PGs/PCs or PC stations you want to use for online access to PLCs must have been assigned in any one project of the multiproject.
Note: The assigned PG/PC or PC station is highlighted in yellow color when the corresponding project is open.
The PG/PC assignment is only visible if the PG that opens the project is properly assigned.
- The cross-project subnets are merged.
- All projects of the multiproject have been compiled and configuration data have been downloaded to the participating stations; for example, to provide routing information to all participating modules for establishing connections between the PG/PC and the target module.
- The target modules can be accessed across the networks.

Possible problems when working with distributed projects

The PG/PC assignment is not visible if the allocation of projects is changed and a project is opened on a PG/PC on which it was not created.

Nonetheless, the configured PG/PC object still maintains the "assigned" status - but with the "wrong" PG/PC.

In this case you must clear the existing assignment and then reassign the PG/PC object. Online access to modules available within the multiproject is then possible without any problem.



1. Save project A with assigned PG/PC on the network
2. Open the same project A with a different computer

Tip for working with distributed projects

If more than one of the team members want to access the PLCs online on their PG, it would be useful to create one "PG/PC" or "SIMATIC PC station" object in the multiproject and then set up an assignment for each one of the PGs.

Depending on which PG has opened the project, SIMATIC Manager indicates only the object assigned to this PG with a yellow arrow.

18.1.4 Password Protection for Access to Programmable Controllers

Using password protection you can:

- Protect the user program in the CPU and its data from unauthorized changes (write protection)
- Protect the programming know-how in your user program (read protection)
- Prevent online functions that would interfere with the process

You can only protect a module or the content of a MMC (e.g. for a CPU 31xC) with a password if the module supports this function.

If you want to protect a module or the content of a MMC with a password, you must define the protection level and set the password in the course of assigning the module parameters and then download the changed parameters to the module.

If you need to enter a password to execute an online function or access the content of a MMC, the "Enter Password" dialog box is displayed. If you enter the correct password, you are given access rights to modules for which a particular protection level was set during parameter assignment. You can then establish online connections to the protected module and execute the online functions belonging to that protection level.

Using the menu command **PLC > Access Rights > Setup**, you can call the "Enter Password" dialog box directly. By doing this, for example at the beginning of a session, you can enter the password once and will no longer be queried during later online accesses. The password remains effective until either the SIMATIC Manager is closed or the password is cancelled with the menu command **PLC > Access Rights > Cancel**.

CPU Parameter	Remarks
Test operation/process operation (not for S7-400 or CPU 318-2)	Can be set in the "Protection" tab. In process operation, test functions such as program status or monitor/modify variables are restricted so that the set permissible scan cycle time increase is not exceeded. This means, for example, that no call conditions are allowed in program status and the status display of a programmed loop is interrupted at the point of return. Testing using breakpoints and single-step program execution cannot be used in process operation. In test operation, all test functions via programming device/PC even if they cause considerable increases to the scan cycle time can be used without restrictions.
Protection level	Can be set in the "Protection" tab. You can make write or read/write access to the CPU dependent on knowing the correct password. The password is set in this tab.

18.1.5 Updating the Window Contents

You should note the following:

- Changes in the online window of a project as a result of user actions (for example, downloading or deleting blocks) are not automatically updated in any open "Accessible Nodes" windows.
- Any such changes in the "Accessible Nodes" window are not automatically changed in any open online windows of a project.

To update the display in a parallel open window, you must refresh the display in this window explicitly (using the menu command or the function key F5).

18.2 Displaying and Changing the Operating Mode

18.2.1 Displaying and Changing the Operating Mode

With this function you can, for example, switch the CPU to RUN again after correcting an error.

Displaying the Operating Mode

1. Open your project and select an S7/M7 program, or open the "Accessible Nodes" window using the menu command **PLC > Display Accessible Nodes** and select a node ("MPI=...").
2. Select the menu command **PLC > Diagnostics/Settings > Operating Mode**.

This dialog box displays the current and the last operating mode and the current setting of the mode selector on the module. For modules for which the current keyswitch setting cannot be displayed, the text "Undefined" is displayed.

Changing the Operating Mode

You can change the mode of the CPU using the buttons. Only those buttons are active that can be selected in the current operating mode.

18.3 Displaying and Setting the Time and Date

18.3.1 CPU Clocks with Time Zone Setting and Summer/Winter Time

In addition to the time-of-day/date you can also configure or evaluate the following settings in new CPUs (Firmware V3 or higher), using STEP 7 V5.1, Service Pack 2:

- Summer/Winter Time
- Offset factors for displaying time zones

Display of Time Zones

The system operates with a TOD that is global, continuous and free of interrupts, namely the Module Time.

The local automation system allows the calculation of a Local Time that differs from Module Time and which can be used by the user program. Local Time is not entered directly, but are rather calculated using the Module Time plus/minus a time difference to Module Time).

Summer/Winter Time

You can also set Summer or Winter Time when you set up the TOD and the date. When switching from summer time to winter time, for example, per user program only the time difference to the Module Time is taken into account. You can effect this change-over with a block made available to you via the Internet.

Reading and Adjusting the TOD and The TOD Status

The summer/winter time identifier and time difference to the Module Time are included in the Time-Of-Day (TOD) status.

You have the following options to read or adjust the TOD and its status:

With STEP 7 (online)

- Via menu command **PLC > Diagnostics/Setting > Adjust TOD** (read and adjust)
- Via the "Module Information" dialog box, "Time System" tab (read only)

In the user program

- SFC 100 "SET_CLKS" (read and adjust)
- SFC 51 "RDSYSST" with SZL 132, Index 8 (read only)

Time Stamp in the Diagnostic Buffer, Messages and OB-Start Information

Time stamps are generated using the Module Time.

TOD Interrupts

OB 80 is called if TOD interrupts were not triggered due to the "Time jump" when winter time is switched to summer time.

For summer/winter time conversion the periodicity is maintained for TOD interrupts with minute and hourly periodicity.

TOD Synchronization

A CPU that is configured as TOD Master (for example, in the CPU register "Diagnostics/Clock"), always synchronizes other clocks with the Module Time and the current TOD status.

18.4 Updating the Firmware

18.4.1 Updating Firmware in Modules and Submodules Online

As of STEP 7 V5.1 Service Pack 3, you can update modules or submodules on a station in a standardized way online. To do so, proceed as described below:

Concept

To update the firmware on a module such as a CPU, a CP or an IM, you must obtain the files (*.UPD) containing the latest firmware.


Select one of these files and download it to the module (PLC Menu).

Prerequisites

The module in the station whose firmware is to be updated must be online, such when the programming device (PG) is connected to the same MPI PROFIBUS or Ethernet as the module whose firmware is to be updated. The firmware can also be updated when the programming device (PG) is connected to the MPI interface of the DP master CPU and the module whose firmware is to be updated is connected at the PROFIBUS of the DP interface or the Ethernet of the PN interface. The CPU must support S7 routing between the MPI interface and the DP interface or between the MPI interface and the PN interface.

The module itself must support Firmware updates.

The files containing the latest firmware versions must be available in the file system on your PG/PC. Only files for **one** firmware version must be in one folder.



(1) PROFIBUS or Ethernet subnet

(2) MPI subnet

(3) CPU with MPI interface and DP interface or PN interface (with S7 routing)

Procedure in HW Config

1. Open the station containing the module to be updated.
2. Select the module
For PROFIBUS DP interface modules such as an IM 151, select the icon for the DP slave. In this case, it is the one that stands for ET 200S.
3. Select the menu command **PLC > Update Firmware**.
You can only activate the menu command if the selected module or the selected DP slave supports the "Update firmware" function.
4. In the "Update firmware" dialog that is displayed, click the "Browse" button and select the path to the firmware update files (*.UPD).
5. After you have selected a file, the lower fields of the "Update firmware" dialog will contain information telling you for which modules the file is suitable and as of which firmware version.
6. Click the "Run" button.
STEP 7 checks whether the selected file can be interpreted by the module. If the check result is positive, the file is downloaded to the module.
If the operating mode of the CPU needs to be changed, dialogs will prompt you to carry out these steps.
The module then carries out the firmware update independently.
Note: For a firmware update, such as to a CPU 317-2 PN/DP, a separate connection is usually established to the CPU. In such case, the process can be interrupted. If no resources are available for another connection, the existing connection is automatically used instead. In this case, the connection cannot be interrupted. The "Cancel" button in the transfer dialog is grayed out and unavailable.
7. In STEP 7, check (read out the CPU diagnostic buffer) whether the module was able to start up with the new firmware.

Procedure in SIMATIC Manager


The function can be activated when the window "Accessible Nodes" is open. The procedure corresponds to that in HW Config. The menu command also is PLC > Firmware update. STEP 7 however only checks if the module supports the function at the time of the execution.

Firmware Update for Modules in Redundant Mode

As of STEP 7 V5.4, a firmware updates for a modules during redundant mode is supported, such as for the IM 153-2BA00 with an active backplane bus at an H station. You can carry out a firmware update for the redundant IMs in one process; the redundant IM will automatically be provided with the latest firmware version.

Requirement: The programming device (PG) must be connected to the same PROFIBUS as one of the IMs and you perform the update by means of "Accessible Nodes" in the SIMATIC Manager.

Principle



Consequences of updating the firmware during operation

You can decide to activate the new firmware immediately after updating via an option in the update dialog.

If you select this option, the station performs a restart like after POWER OFF/POWER ON. As result, it may happen that a CPU remains in STOP mode or the processing of the user program is adversely affected. You will need to take appropriate precautions in the operation of your plant to anticipate and accommodate these conditions.

For example, during a restart all modules of the station will fail, including the existing F I/O.

The F I/O outputs a communication error to the interface during POWER OFF and switches off safely - it is passivated. This passivation is not cleared by restarting the interface. You must depassivate the modules individually. However, the safety-related applications will not run as a result of this.

Updating the Firmware (of the Operating System) in Modules and Submodules
Offline

19 Downloading and Uploading

19.1 Downloading from the PG/PC to the Programmable Controller

19.1.1 Requirements for Downloading

Requirements for Downloading to the Programmable Controller

- There must be a connection between your programming device and the CPU in the programmable controller (for example, via the multipoint interface).
- Access to the programmable controller must be possible.
- For the download of blocks to the PLC, the entry "STEP 7" must have been selected for "Use" in the object properties dialog of the project.
- The program you are downloading has been compiled without errors.
- The CPU must be in an operating mode in which downloading is permitted (STOP or RUN-P).
Note that in RUN-P mode the program will be downloaded a block at a time. If you overwrite an old CPU program doing this, conflicts may arise, for example, if block parameters have changed. The CPU then goes into STOP mode while processing the cycle. We therefore recommend that you switch the CPU to STOP mode before downloading.
- If you opened the block offline and want to download it, the CPU must be linked to an online user program in the SIMATIC Manager.
- Before you download your user program, you should reset the CPU to ensure that no "old" blocks are on the CPU.

STOP Mode

Set the operating mode from RUN to STOP before you do the following:

- Download the complete user program or parts of it to the CPU
- Execute a memory reset on the CPU
- Compress the user memory

Restart (Warm Restart (Transition to RUN Mode))

If you execute a restart (warm restart) in the "STOP" mode, the program is restarted and first processes the startup program (in the block OB100) in STARTUP mode. If the startup is successful, the CPU changes to RUN mode. A restart (warm restart) is required after the following:

- Resetting the CPU
- Downloading the user program in STOP mode

19.1.2 Differences Between Saving and Downloading Blocks

You should always distinguish between saving and downloading blocks.

	Saving	Downloading
Menu commands	File > Save File > Save As	PLC > Download
Function	The current status of the block in the editor is saved on the hard disk of the programming device.	The current status of the block in the editor is only downloaded to the CPU.
Syntax check	A syntax check is run. Any errors are reported in dialog boxes. The causes of the errors and the error locations are also shown. You must correct these errors before you save or download the block. If no errors are found in the syntax, the block is compiled into machine code and either saved or downloaded.	A syntax check is run. Any errors are reported in dialog boxes. The causes of the errors and the error locations are also shown. You must correct these errors before you save or download the block. If no errors are found in the syntax, the block is compiled into machine code and either saved or downloaded.

The table applies independent of whether you have opened the block online or offline.

Tip for Block Changes - Save First Then Download

To enter newly created blocks or changes in the code section of logic blocks, in declaration tables or to enter new or changed data values in data blocks, you must save the respective block. Any changes you make in the editor and transfer to the CPU using the menu command **PLC > Download**, -for example, for testing small changes-, must also be saved on the hard disk of the programming device in every case before you exit the editor. Otherwise, you will have different versions of your user program in the CPU and on the programming device. It is generally recommended that you save all changes first and then download them.


19.1.3 Load Memory and Work Memory in the CPU

After completing the configuration, parameter assignment, and program creation and establishing the online connection, you can download complete user programs or individual blocks to a programmable controller. To test individual blocks, you must download at least one organization block (OB) and the function blocks (FB) and functions (FC) called in the OB and the data blocks (DB) used. To download the system data created when the hardware was configured, the networks configured, and the connection table created to the programmable controller, you download the object "System Data".

You download user programs to a programmable controller using the SIMATIC Manager, for example, during the end phase of the program testing or to run the finished user program.

Relationship - Load Memory and Work Memory

The complete user program is downloaded to the load memory; the parts relevant to program execution are also loaded into the work memory.



CPU Load Memory

- The load memory is used to store the user program without the symbol table and the comments (these remain in the memory of the programming device).
- Blocks that are not marked as required for startup will be stored only in the load memory.
- The load memory can either be RAM, ROM, or EPROM memory, depending on the programmable controller.
- The load memory can also have an integrated EEPROM part as well as an integrated RAM part (for example, CPU 312 IFM and CPU 314 IFM).
- In S7-400, it is imperative that you use a memory card (RAM or EEPROM) to extend the load memory.

CPU Work Memory

The work memory (integrated RAM) is used to store the parts of the user program required for program processing.

Possible Downloading/Uploading Procedures

- You use the download function to download the user program or loadable objects (for example, blocks) to the programmable controller. If a block already exists in the RAM of the CPU, you will be prompted to confirm whether or not the block should be overwritten.
- You can select the loadable objects in the project window and download them from the SIMATIC Manager (menu command: **PLC > Download**).
- When programming blocks and when configuring hardware and networks you can directly download the object you were currently editing using the menu in the main window of the application you are working with (menu command: **PLC > Download**).
- Another possibility is to open an online window with a view of the programmable controller (for example, using **View > Online** or **PLC > Display Accessible Nodes**) and copy the object you want to download to the online window.

Alternatively you can upload the current contents of blocks from the RAM load memory of the CPU to your programming device via the load function.

19.1.4 Download Methods Dependent on the Load Memory

The division of the load memory of a CPU into RAM and EEPROM areas determines the methods available for downloading your user program or the blocks in your user program. The following methods are possible for downloading data to the CPU:

Load Memory	Method of Loading	Type of Communication between PG and PLC
RAM	Downloading and deleting individual blocks	Online PG - PLC connection
	Downloading and deleting a complete user program	Online PG - PLC connection
	Reloading individual blocks	Online PG - PLC connection
Integrated (S7-300 only) or plug-in EPROM	Downloading complete user programs	Online PG - PLC connection
Plug-in EPROM	Downloading complete user programs	External loading of the EPROM and inserting the memory card or via online connection on the PLC where the EPROM is inserted.

Downloading to the RAM via Online Connection

In the programmable controller the data are lost if there is a power failure and the RAM is not backed up. The data in the RAM will then be lost in this case.

Saving to EPROM Memory Card

Blocks or the user program are saved on an EPROM memory card which is then inserted in a slot on the CPU.

Memory cards are portable data media. They are written by the programming device and then inserted in the appropriate slot on the CPU.

The data stored on them are retained following power down and when the CPU is reset. The contents of the EPROM are copied to the RAM area of the CPU memory again when power returns following a memory reset of the CPU and power down if the RAM is not backed up.

Saving in the Integrated EPROM

For the CPU 312, you can also save the contents of the RAM to the integrated EPROM. The data in the integrated EPROM are retained during power down. The contents of the integrated EPROM are copied to the RAM area of the CPU memory again when power returns following power down and a memory reset of the CPU if the RAM is not backed up.

19.1.5 Downloading a Program to the S7 CPU

19.1.5.1 Downloading with Project Management

1. In the project window, select the user program or the blocks you want to download.
2. Download the selected objects to the programmable logic controller by selecting the menu command **PLC > Download**.

Alternative Procedure (Drag & Drop)

1. Open an offline window and an online window of your project.
2. Select the objects you want to download in the offline window and drag them to the online window.

19.1.5.2 Downloading without Project Management

1. Open the "Accessible Nodes" window using the menu command **PLC > Display Accessible Nodes** or by clicking the corresponding button in the toolbar.
2. Double-click in the "Accessible Nodes" window on the required node ("MPI=...") to display the "Blocks" folder.
3. Open the library or the project from which you want to download the user program or blocks to the programmable logic controller. Use the menu command **File > Open** for this.
4. In the window which opens for the project or the library, select the objects you want to download.
5. Download the objects to the programmable logic controller by copying them to the "Blocks" folder in the "Accessible Nodes" window using drag & drop.

19.1.5.3 Reloading Blocks in the Programmable Controller

You can overwrite blocks which already exist in the load memory (RAM) or work memory of the CPU in the S7 programmable logic controller with a new version (reload them). The existing version is then overwritten.

The procedure for reloading S7 blocks is the same as for downloading. A prompt simply appears, querying whether you want to overwrite the existing block.

A block stored in the EPROM cannot be deleted but is declared invalid once it is reloaded. The replacement block is loaded in the RAM. This creates gaps in the load memory or the work memory. If these gaps eventually mean that no new blocks can be downloaded, you should compress the memory.

Note

If the power goes down and then returns and the RAM does not have a battery backup, or following a memory reset of the CPU the "old" blocks become valid again.

19.1.5.4 Saving Downloaded Blocks on Integrated EPROM

For CPUs that have an integrated EPROM (such as CPU 312), you can save blocks from the RAM to the integrated EPROM so as not to lose the data following power off or memory reset.

1. Use the menu command **View > Online** to display a window containing the online view of an open project or open the "Accessible Nodes" window by clicking the "Accessible Nodes" button in the toolbar or selecting the menu command **PLC > Display Accessible Nodes**.
2. Select the S7 or M7 program in the online window of the project or the node in the "Accessible Nodes" window.
3. Select the "Blocks" folder on the CPU which you want to save using one of the following methods:
 - In the online window of the project if you are working with project management
 - In the "Accessible Nodes" window if you are working without project management
4. Select the menu command **PLC > Save RAM to ROM**.

19.1.5.5 Downloading via EPROM Memory Cards

Requirements

For access to EPROM memory cards in the programming device which are intended for an S7 programmable logic controller, you will require the appropriate EPROM drivers. For access to EPROM memory cards which are intended for an M7 programmable control system, the Flash File System must be installed (only possible on the PG 720, PG 740, and PG 760). EPROM drivers and the Flash File System are offered as options when you install the STEP 7 Standard package. If you are using a PC, an external programmer will be required to save to EPROM memory cards.

You can also install the drivers at a later date. To do this, call up the corresponding dialog box via **Start > Simatic > STEP 7 > Memory Card Parameter Assignment** or via the Control Panel (double-click the "Memory Card Parameter Assignment" icon).

Saving on the Memory Card

To save blocks or user programs to a memory card, proceed as follows:

1. Insert the memory card in the slot of your programming device.
2. Open the "Memory Card" window by:
 - Clicking the button for "Memory Card" in the toolbar. If necessary, activate the toolbar using the menu command **View > Toolbar**.
 - Alternatively, select the menu command **File > S7 Memory Card > Open**.
3. Open or activate one of the following windows displaying the blocks you want to save: The following windows are possible:
 - Project window, "ONLINE" view
 - Project window, "offline" view
 - Library window
 - "Accessible Nodes" window
4. Select the "Blocks" folder or individual blocks and copy them to the "S7 Memory Card" window.
5. If a block already exists on the memory card, an error message is displayed. In this case, erase the contents of the memory card and repeat the steps from 2.

19.2 Compiling and Downloading Several Objects from the PG

19.2.1 Requirements for and Notes on Downloading

Downloading Block Folders

For block folders, only logic blocks can be downloaded. Other objects in the block folder, such as system data (SDBs), etc. cannot be downloaded here. SDBs are downloaded through the "Hardware" object.

Note

For PCS 7 projects, blocks cannot be downloaded using the dialog "Compile and Download Objects"- just as they cannot be downloaded from the SIMATIC Manager. For PCS 7 projects, the following applies: PLCs must only be downloaded to by means of CFCs in order to ensure correct sequencing during the download. This must be done to prevent the CPU from going into STOP mode.

To determine whether the given project is a PCS 7 project, check the project properties.

Downloading the F-Shares of Failsafe Controllers

For security reasons, a password must be entered before modified F-shares can be downloaded. For this reason, with the "Compile and Download Objects" function, the download procedure will be aborted with an error message. In this case, load the appropriate parts of the program along with the optional package to the PLC.

Downloading the Hardware Configuration

Downloading the hardware configuration (i.e. downloading the offline SDBs) by means of the "Compile and Download Objects" function will only run without interruption for all selected objects if no error messages or prompts are triggered. The following section provides information on how to avoid such messages or prompts.

Requirements for Downloading the Hardware Configuration

- CPUs must be in STOP mode.
- It must be possible to establish online connections to the CPUs. In the case of the selected CPU or the selected block folder, password-protected CPUs require an authorized connection or entry of a password ("Edit" button) before the "Compile and Download Objects" function can be run.
- The interface of the target system that is being used for downloading must not be reconfigured to any substantial extent:
 - The interface address must not be changed.
 - If you change the network settings, this may mean that not all the modules will be able to be accessed.
- In the case of H-CPU, you can select the CPU to receive the download (H-CPU 0 or H-CPU 1) before running the "Compile and Download Objects" function (Select the "CPU" object and then click the "Edit" button).
- The following CPU parameters must not be changed:
 - The maximum size for local data and communications resources on the CPU ("Memory" tab)
 - The password protection for the F-CPU ("Protection" tab)
- For each configured module, the following conditions must be fulfilled:
 - The order number for the configured module must be identical with the order number of the module that is actually inserted.
 - The firmware version of the configured module must not be higher than the firmware version of the module that is actually inserted.
 - The station name, the name of the module and the plant designation must not have changed since the last download. However, you can assign a new plant designation.

Tips on the Download Procedure

- All offline SDBs will be downloaded (that is, in addition to the hardware configuration, also the connection SDBs and SDBs that were created through global data configurations).
- Downloading is only carried out if no errors occurred during the previous compilation process.
- During the download, any error feedback messages are suppressed. For example, if a CPU memory bottleneck occurs, the data will be compressed automatically without the user being informed.
- After the download is complete, the downloaded modules will be in STOP mode (except for those modules that are automatically stopped and restarted without the user being informed).

Tip

If, after the download is completed, a message appears stating that the download of the object was completed with warnings, then be sure to view the contents of the log. It may be that the object was either not downloaded or was not downloaded completely.

19.2.2 Compiling and Downloading Objects

In the "Compile and download objects" dialog you prepare the objects that can be selected in your project or multiproject for transfer to the PLC and their subsequent download (if desired). This dialog can be used for objects in a station, a project or a multiproject.

Depending on the object selected, certain information may not be displayed. In addition, not all the functions described below may be available for these objects. In particular, these restrictions may apply to objects that were created with optional software packages.

For blocks in a block folder "compile" means that the consistency of the blocks is checked. In the following, for simplicity, the consistency check for blocks will be referred to as compilation.

Procedure:

1. In SIMATIC Manager, select the object that you want to compile, or compile and download. The following objects can be selected in the SIMATIC Manager:
 - Multiproject
 - Project
 - Station
 - S7 program without station assignment
2. In the SIMATIC Manager, select menu command **PLC > Compile And Download Objects**.
3. Select "Only compile" if you want to perform a check of the blocks without downloading them to the PLC. Select this option if you do not want to download any of these objects to the PLC
4. To prevent incomplete downloads to stations due to compilation errors, select the check box "No download on compilation error". If this check box is selected, nothing will be downloaded. If the check box is not selected, then all objects compiled without error are downloaded. Objects that caused an error during compilation are not downloaded.
5. If you want to compile and download connections, select the corresponding check box for the "Connections" object.
6. A multiproject is particularly suited for use as a starting point, since all connection partners for cross-project connections can also be downloaded from this object.
7. In the "Compile" and "Download" columns, select the objects that you want to compile or download. Your selections will be indicated by checkmarks. If you selected "Compile only" in Step 3, the "Download" column will be grayed out and unavailable.
8. Click on "Start" to begin the compilation.

9. Follow the instructions on the screen.

After the compilation or download is complete, a full log is displayed. You can open the full log or single-object log at any time:

- Click on the "All" button to view the full log of the complete action.
- Click on "Single object" button to view only the log of the object you have selected in the object table.

Special considerations when compiling and downloading connections

If, in a module, you select the "Connections" object as the one to be **compiled**, then STEP 7 automatically selects the corresponding "Connections" object in the connection partner. By doing this, STEP 7 always creates consistent configuration data (system data blocks). The automatically selected objects cannot be directly deselected manually. However, the selection is automatically removed if the originally selected "Connections" object is also deselected.

If, in a module, you select the "Connections" object as the one to be **downloaded**, then STEP 7 automatically selects the "Compile" check box. In addition, STEP 7 also selects the "Compile" and "Download" check boxes for all connection partners. If only objects of the "Connections" type were selected, you can also download the connections when the CPU is in RUN-P operating mode.

You can use NetPro to download individual connections.

Compiling and downloading hardware: effects on connections

If you select the "Hardware" object as the one to be compiled or downloaded, all "Connections" objects below the hardware selected are also automatically selected to be compiled or downloaded. In this case, however, the connection objects at the connections partners are **not** automatically selected as well!

19.3 Uploading from the Programmable Controller to the PG/PC

This function supports you when carrying out the following actions:

- Saving information from the programmable controller (for example, for servicing purposes)
- Fast configuring and editing of a station, if the hardware components are available before you start configuring.

Saving Information from the Programmable Controller

This measure may be necessary if, for example, the offline project data of the version running on the CPU are not, or only partially, available. In this case, you can at least retrieve the project data that are available online and upload them to your programming device.

Fast Configuring

Entering the station configuration is easier if you upload the configuration data from the programmable controller to your programming device after you have configured the hardware and restarted (warm restart) the station. This provides you with the station configuration and the types of the individual modules. Then all you have to do is specify these modules in more detail (order number) and assign them parameters.

The following information is uploaded to the programming device:

- S7-300: Configuration for the central rack and any expansion racks
- S7-400: Configuration of the central rack with a CPU and signal modules without expansion racks
- Configuration data for the distributed I/O cannot be uploaded to the programming device.

This information is uploaded if there is no configuration information on the programmable controller; for example, if a memory reset has been carried out on the system. Otherwise, the **Upload** function provides much better results.

For S7-300 systems without distributed I/O, all you have to do is specify these modules in more detail (order number) and assign them parameters.

Note

When you upload data (if you do not already have an offline configuration), STEP 7 cannot determine all the order numbers of the components.

You can enter the "incomplete" order numbers when you configure the hardware using the menu command **Options > Specify Module**. In this way, you can assign parameters to modules that STEP 7 does not recognize (that is, modules that do not appear in the "Hardware Catalog" window); however, STEP 7 will not then check whether you are keeping to the parameter rules.

Restrictions when Uploading from the Programmable Controller

The following restrictions apply to the data uploaded from the programmable controller to the programming device:

- Blocks do not contain any symbolic names for parameters, variables, and labels
- Blocks do not contain any comments
- The entire program is uploaded with all the system data, whereby the system can only continue to process the system data belonging to the "Configuring Hardware" application
- The data for global data communication (GD) and configuring symbol-related messages cannot be processed further
- Force jobs are not uploaded to the programming device with the other data. They must be saved separately as a variable table (VAT)
- Comments in the module dialog boxes are not uploaded
- The names of the modules are only displayed if this option has been selected during configuration (HW Config: the option "Save object names in the programmable logic controller" in the dialog box under **Options > Customize**).

19.3.1 Uploading a Station

Using the menu command **PLC > Upload Station** you can upload the current configuration and all blocks from the programmable controller of your choice to the programming device.

To do this, STEP 7 creates a new station in the current project under which the configuration will be saved. You can change the preset name of the new station (for example, "SIMATIC 300-Station(1)"). The inserted station is displayed both in the online view and in the offline view.

The menu command can be selected when a project is open. Selecting an object in the project window or the view (online or offline) has no effect on the menu command.

You can use this function to make configuring easier.

- For S7-300 programmable controllers, the configuration for the actual hardware configuration is uploaded including the expansion racks, but without the distributed I/O (DP).
- For S7-400 programmable controllers, the rack configuration is uploaded without the expansion racks and without the distributed I/O.

With S7-300 systems without distributed I/O, all you have to do is specify the modules in more detail (order number) and assign them parameters.

Restrictions when Uploading Stations

The following restrictions apply to the data uploaded to the programming device:

- Blocks do not contain any symbolic names for parameters, variables, and labels
- Block do not contain any comments
- The entire program is uploaded with all the system data, whereby not all the data can be processed further
- The data for global data communication (GD), configuring symbol-related messages, and configuring networks cannot be processed further
- Force jobs cannot be uploaded to the programming device and then loaded back to the programmable controller.

19.3.2 Uploading Blocks from an S7 CPU

You can upload S7 blocks from the CPU to the hard disk of the programming device using the SIMATIC Manager. Uploading blocks to the programming device is useful in the following situations:

- Making a backup copy of the current user program loaded in the CPU. This backup can then be downloaded again, for example, following servicing or following a memory reset of the CPU by maintenance personnel.
- You can upload the user program from the CPU to the programming device and edit it there, for example, for troubleshooting purposes. In this case you do not have access to symbols or comments for program documentation. Therefore we recommend that this procedure is used only for service purposes.

19.3.3 Editing Uploaded Blocks in the PG/PC

Being able to upload blocks from the CPU to the programming device has the following uses:

- During the test phase, you can correct a block directly on the CPU and document the result.
- You can upload the current contents of blocks from the RAM load memory of the CPU to your programming device via the load function.

Note

Time stamp Conflicts when Working Online and Offline

The following procedures lead to time stamp conflicts and should therefore be avoided.

Time stamp conflicts result when you open a block online if:

- Changes made online were not saved in the offline S7 user program
- Changes made offline were not downloaded to the CPU

Time stamp conflicts result when you open a block offline if:

- An online block with a time stamp conflict is copied to the S7 user program offline and the block is then opened offline.
-

Two Distinct Cases

When uploading blocks from the CPU to the programming device, remember that there are two distinct situations:

1. The user program to which the blocks belong is located on the programming device.
2. The user program to which the blocks belong is not on the programming device.

This means that the program sections listed below, that cannot be downloaded to the CPU, are not available. These components are:

- The symbol table with the symbolic names of the addresses and the comments
- Network comments of a Ladder Logic or Function Block Diagram program
- Line comments of a Statement List program
- User-defined data types

19.3.3.1 Editing Uploaded Blocks if the User Program is on the PG/PC

To edit blocks from the CPU, proceed as follows:

1. Open the online window of the project in the SIMATIC Manager.
2. Select a "Blocks" folder in the online window. The list of loaded blocks is displayed.
3. Now select the blocks, open and edit them.
4. Select the menu command **File > Save** to save the change offline on the programming device.
5. Select the menu command **PLC > Download** to download the changed blocks to the programmable controller.

19.3.3.2 Editing Uploaded Blocks if the User Program is Not on the PG/PC

To edit blocks from the CPU, proceed as follows:

1. In the SIMATIC Manager, click the "Accessible Nodes" toolbar button or select the menu command **PLC > Display Accessible Nodes**.
2. Select the node ("MPI=..." object) from the list displayed and open the "Blocks" folder to display the blocks.
3. You can now open blocks and edit, monitor, or copy them as required.
4. Select the menu command **File > Save As** and enter the path for the programming device where you want to store the blocks in the dialog box.
5. Select the menu command **PLC > Download** to download the changed blocks to the programmable controller.

19.4 Deleting on the Programmable Controller

19.4.1 Erasing the Load/Work Memory and Resetting the CPU

Before downloading your user program to the S7 programmable controller, you should perform a memory reset on the CPU to ensure that no "old" blocks are still on the CPU.

Requirement for Memory Reset

The CPU must be in STOP mode to perform a memory reset (mode selector set to STOP, or to RUN-P and change the mode to STOP using the menu command **PLC > Diagnostics/Settings > Operating Mode**).

Performing a Memory Reset on an S7 CPU

When a memory reset is performed on an S7 CPU, the following happens:

- The CPU is reset.
- All user data are deleted (blocks and system data blocks (SDB) with the exception of the MPI parameters).
- The CPU interrupts all existing connections.
- If data are present on an EPROM (memory card or integrated EPROM), the CPU copies the EPROM contents back to the RAM area of the memory following the memory reset.

The contents of the diagnostic buffer and the MPI parameters are retained.

Performing a Memory Reset on M7 CPUs/FMs

When a memory reset is performed on an M7 CPU/FM, the following happens:

- The original state is restored.
- The system data blocks (SDB) with the exception of the MPI parameters are deleted.
- The CPU/FM breaks off all existing connections. User programs are retained and will continue running after you switch the CPU from STOP to RUN.

With the "memory reset" function you can restore the original state of the M7 CPU or FM following serious errors by deleting the current system data blocks (SDB) from the work memory and reloading the SDBs in the read-only memory. In some cases, a warm restart of the operating system will be required. To do this, you clear the M7 using the mode selector (switch to MRES position). A reset using the mode selector on SIMATIC M7 CPUs or FMs is only possible if the RMOS32 operating system is used on the CPU/FM.

19.4.2 Deleting S7 Blocks on the Programmable Controller

Deleting individual blocks on the CPU may be necessary during the test phase of the CPU program. Blocks are stored in the user memory of the CPU either in the EPROM or RAM (depending on the CPU and the load procedure).


- Blocks in the RAM can be deleted directly. The occupied space in the load or work memory becomes free and can be used again.
- Blocks in the integrated EPROM are always copied to the RAM area following a memory reset of the CPU. The copies in the RAM can be deleted directly. The deleted blocks are then marked in the EPROM as invalid until the next memory reset or power down without RAM backup. Following a memory reset or power down without RAM backup, the "deleted" blocks are copied from the EPROM to the RAM and become active. Blocks in the integrated EPROM (for example, in the CPU 312) are deleted by overwriting them with the new RAM contents.
- EPROM memory cards must be erased in the programming device.

19.5 Compressing the User Memory (RAM)

19.5.1 Gaps in the User Memory (RAM)

After deleting and reloading blocks, gaps can occur in the user memory (load and work memory) and reduce the usable memory area. With the compress function, the existing blocks are rearranged in the user memory without gaps, and a continuous free memory is created.

The following figure shows a diagram of how occupied blocks of memory are shifted together by the compress function.



Always Try to Compress the Memory in STOP Mode

Only if you compress the memory in "STOP" mode are all the gaps closed up. In the RUN-P mode (mode selector setting), the blocks currently being processed cannot be shifted since they are open. The compress function does not work in the RUN mode (mode selector setting) (write protection!).

19.5.2 Compressing the Memory Contents of an S7 CPU

Ways of Compressing the Memory

There are two methods of compressing the user memory, as follows:

- If there is insufficient memory available when you are downloading to the programmable controller, a dialog box appears informing you of the error. You can compress the memory by clicking the corresponding button in the dialog box.
- As a preventative measure, you can display the memory utilization (menu command **PLC > Diagnostics/Setting > Module Information**, "Memory" tab) and start the compressing function if required.

Procedure

1. Select the S7 program in the "Accessible Nodes" window or the online view of the project.
2. Select the menu command PLC > Diagnostics/Setting > Module Information.
3. In the dialog box which then appears, select the "Memory" tab. In this tabbed page there is a button for compressing the memory if the CPU supports this function.

20 Testing with the Variable Table

20.1 Introduction to Testing with Variable Tables

Variable tables offer the advantage of being able to store various test environments. Thus, tests and monitoring can be effortlessly reproduced during operation or for the purpose of service and maintenance. There is no limit to the number of variable tables that can be stored.

When testing using variable tables, the following functions are available:

- **Monitoring Variables**
This function enables you to display on the programming device/PC the current values of individual variables in a user program or a CPU.
- **Modifying Variables**
You can use this function to assign fixed values to individual variables of a user program or a CPU. Modifying values once and immediately is also possible when testing using program status.
- **Enable Peripheral Output and Activate Modify Values**
These two functions allow you to assign fixed values to individual I/O outputs of a CPU in STOP mode.
- **Forcing Variables**
You can use this function to assign individual variables of a user program or a CPU with a fixed value that cannot be overwritten by the user program.

You can assign or display the values for the following variables:

- Inputs, outputs, bit memory, timers, and counters
- Contents of data blocks
- I/O (periphery)

You enter the variables you want to display or modify in variable tables.

You can determine when and how often the variables are monitored or assigned new values by defining a trigger point and trigger frequency.

20.2 Basic Procedure when Monitoring and Modifying with the Variable Table

To use the **Monitor** and **Modify** functions, proceed as follows:

1. Create a new variable table or open an existing variable table.
2. Edit or check the contents of the variable table.
3. Establish an online connection between the current variable table and the required CPU using the menu command **PLC > Connect To**.
4. Using the menu command **Variable > Trigger**, select a suitable trigger point and set the trigger frequency.
5. The menu commands **Variable > Monitor** and **Variable > Modify** toggle the Monitor and Modify functions on and off.
6. Save the completed variable table using the menu command **Table > Save** or **Table > Save As**, so that you can call it up again at any time.

20.3 Editing and Saving Variable Tables

20.3.1 Creating and Opening a Variable Table

Before you can monitor or modify variables, you must create a variable table (VAT) and enter the required variables. To create a variable table, you can choose from one of the following methods:

In the SIMATIC Manager:

- Select the "Blocks" folder and the menu command **Insert > S7 Block > Variable Table**. In the dialog box, you can give the table a name ("Symbolic Name" text box). You can open the variable table by double-clicking the object.
- Select a connection or, in the online view, an S7 or M7 program from the list of accessible nodes. You create an unnamed variable table using the menu command **PLC > Monitor/Modify Variables**.

In "Monitor/Modify Variables":

- You can use the menu command **Table > New** to create a new variable table which is not yet assigned to any S7 or M7 program. You can open existing tables with **Table > Open**.
- You can use the corresponding symbols in the toolbar to create or open variable tables.

Once you have created a variable table, you can save it, print it out, and use it again and again for monitoring and modifying.

20.3.2 Copying/Moving Variable Tables

You can copy or move variable tables in block folders of an S7/M7 program.

Note the following when copying or moving variable tables:

- Existing symbols in the symbol table of the target program will be updated.
- When you move a variable table, the corresponding symbols from the symbol table of the source program will also be moved to the symbol table of the target program.
- When you delete variable tables from the block folder, the corresponding symbols from the symbol table of the S7/M7 program will also be deleted.
- If the target program already contains a variable table with the same name, the next-highest free number will be assigned when you copy the variable table.
- If the target program already contains a variable table with the same name, you can rename the variable table when copying (as a default a number is attached to the existing name).

20.3.3 Saving a Variable Table

You can use saved variable tables to monitor and modify variables when you test a program again.

1. Save the variable table using the menu command **Table > Save**.
2. If the variable table has been created, you must now give the variable table a name, for example, "ProgramTest_1."

When you save a variable table, all the current settings and the table format are saved. This means that the settings made under the menu item "Trigger" are saved.

20.4 Entering Variables in Variable Table

20.4.1 Inserting Addresses or Symbols in a Variable Table

Select the variables whose values you want to modify or monitor and enter them in the variable table. Start from the "outside" and work "inwards"; this means you should first select the inputs and then the variables that are influenced by the inputs and which influence the outputs, and finally the outputs.

If you want, for example, to monitor the input bit 1.0, the memory word 5, and the output byte 0, enter the following in the "Address" column:

Example:

```
I 1.0  
MW5  
QB0
```

Example of a Completed Variable Table

The following figure shows a variable table with the following visible columns: Address, Symbol, Display Format, Monitor Value, and Modify Value

	Address	Symbol	Display Format	Status Val	Force Val
1	//OB1 Network 1				
2	I 0.1	"Pushbutton 1"	BOOL	true	
3	I 0.2	"Pushbutton 2"	BOOL	true	
4	Q 4.0	"Green light"	BOOL	false	
5	//OB1 Network 3				
6	I 0.5	"Automatic On"	BOOL	true	
7	I 0.6	"Manual On"	BOOL	true	
8	Q 4.2	"Automatic mode"	BOOL	true	true
9	//OB1 call FB1 for petrol engine on				
10	I 1.0	"PE_on"	BOOL	false	
11	I 1.1	"PE_off"	BOOL	false	
12	I 1.2	"PE_failur"	BOOL	false	
13	Q 5.1	"PE_preset_reached"	BOOL	false	
14	Q 5.0	"PE_on"	BOOL	X	X true
15	//OB1 call FB1 for diesel engine on				
16	I 1.4	"DE_on"	BOOL	false	
17	I 1.5	"DE_off"	BOOL		

MPI = 3 (direct) Run

Notes on Inserting Symbols

- You enter the variable you want to modify with your address or as a symbol. You can enter symbols and addresses either in the "Symbol" column or in the "Address" column. The entry is then written automatically in the correct column. If the corresponding symbol is defined in the symbol table, the symbol column or the address column is filled out automatically.
- You can enter only those symbols that are already defined in the symbol table.
- You must enter a symbol exactly as it is defined in the symbol table.
- Symbol names that contain special characters must be enclosed in quotation marks (for example, "Motor.Off," "Motor+Off," "Motor-Off").
- To define new symbols in the symbol table select the menu command **Options > Symbol Table**. Symbol can also be copied from the symbol table and pasted in a variable table.

Syntax Check

When you enter variables in the variable table, a syntax check is carried out at the end of each line. Any incorrect entries are marked in red.

If you position the cursor in a row marked in red, a brief information is displayed telling you the cause of the error. Notes on correcting the error can be obtained by pressing F1.

Note

If you prefer to edit the variable table with the keyboard (without the mouse), you should keep the "Brief Information When Using the Keyboard" feature enabled.

If necessary, you can change the setting in the variable table by selecting the menu command **Option > Customize** and then selecting the "General" tab.

Maximum Size

A maximum of 255 characters per line are permitted in a variable table. A carriage return into the next row is not possible. A variable table can have up to a maximum of 1024 rows. This is then its maximum size.

20.4.2 Inserting a Contiguous Address Range in a Variable Table

1. Open a variable table.
2. Position the cursor in the row after which you want the range of contiguous addresses to be inserted.
3. Select the menu command **Insert > Range of Variables**. The "Insert Range of Variables" dialog box appears.
4. Enter an address as the start address in the "From Address" field.
5. Enter the number of rows to be inserted in the "Number" field.
6. Select the required display format from the list displayed.
7. Click the "OK" button.

The range of variables is inserted in the variable table.

20.4.3 Inserting Modify Values

Modify Value as Comment

If you want to make the "modify value" of a variable ineffective, use the **Variable > Modify Value as Comment** menu command. A comment marker "//" before the value to be modified of a variable indicates that it is without effect. The command marker "//" can also be inserted in front of the "modify value" instead of the menu command call. The ineffectiveness of the "modify value" can be reversed by calling up the **Variable > Modify Value as Comment** menu command again or by removing the comment marker.

20.4.4 Upper Limits for Entering Timers

Note the following upper limits for entering timers:

Example: W#16#3999 (maximum value in BCD format)

Examples:

Address	Monitor Format	Enter	Modify Value Display	Explanation
T 1	SIMATIC_TIME	137	S5TIME#130MS	Conversion to milliseconds
MW4	SIMATIC_TIME	137	S5TIME#890MS	Representation in BCD format possible
MW4	HEX	137	W#16#0089	Representation in BCD format possible
MW6	HEX	157	W#16#009D	Representation in BCD format not possible, therefore the monitor format SIMATIC_TIME cannot be selected

Note

- You can enter timers in millisecond steps but the value entered is adapted to the time frame. The size of the time frame depends on the size of the time value entered (137 becomes 130 ms; the 7 ms were rounded down).
- The modify values for addresses of the data type WORD, for example, IW1, are converted to BCD format. Not every bit pattern is a valid BCD number, however. If the entry cannot be represented as SIMATIC_TIME for an address of the data type WORD, the application reverts automatically to the default format (here: HEX, see Select Monitor Format, Default Command (View Menu)) so that the value entered can be displayed.

BCD Format for Variables in the SIMATIC_TIME Format

Values of variables in the SIMATIC_TIME format are entered in BCD format. The 16 bits have the following significance:

| 0 0 x x | h h h h | t t t t | u u u u |

Bits 15 and 14 are always zero.

Bits 13 and 12 (marked with xx) set the multiplier for bits 0 to 11:

00 => multiplier 10 milliseconds

01 => multiplier 100 milliseconds

10 => multiplier 1 second

11 => multiplier 10 seconds

Bits 11 to 8 hundreds (hhhh)

Bits 7 to 4 tens (tttt)

Bits 3 to 0 units (uuuu)

20.4.5 Upper Limits for Entering Counters

Note the following upper limits for entering counters:

Upper limit for counters: C#999

W#16#0999 (maximum value in BCD format)

Examples:

Address	Monitor Format	Enter	Modify Value Display	Explanation
C1	COUNTER	137	C#137	Conversion
MW4	COUNTER	137	C#89	Representation in BCD format possible
MW4	HEX	137	W#16#0089	Representation in BCD format possible
MW6	HEX	157	W#16#009D	Representation in BCD format not possible, therefore the monitor format COUNTER cannot be selected

Note

- If you enter a decimal number for a counter and do not mark the value with C#, this value is automatically converted to BCD format (137 becomes C#137).
 - The modify values for addresses of the data type WORD, for example, IW1, are converted to BCD format. Not every bit pattern is a valid BCD number, however. If the entry cannot be represented as COUNTER for an address of the data type WORD, the application reverts automatically to the default format (here: HEX, see Select Monitor Format, Default Command (View Menu)) so that the value entered can be displayed.
-

20.4.6 Inserting Comment Lines

Comment lines are introduced by the comment marker "//".

If you want to make one or more lines of the variable table ineffective (as a comment line), use the **Edit > Row not Effective** menu command or the corresponding symbol  in the toolbar.

20.4.7 Examples

20.4.7.1 Example of Entering Addresses in Variable Tables

Permitted Address:	Data Type:	Example (English Mnemonics):
Input Output Bit memory	BOOL	I 1.0 Q 1.7 M 10.1
Input Output Bit memory	BYTE	IB 1 QB 10 MB 100
Input Output Bit memory	WORD	IW 1 QW 10 MW 100
Input Output Bit memory	DWORD	ID 1 QD 10 MD 100
I/O (Input Output)	BYTE	PIB 0 PQB 1
I/O (Input Output)	WORD	PIW 0 PQW 1
I/O (Input Output)	DWORD	PID 0 PQD 1
Timers	TIMER	T 1
Counters	COUNTER	C 1
Data block	BOOL	DB1.DBX 1.0
Data block	BYTE	DB1.DBB 1
Data block	WORD	DB1.DBW 1
Data block	DWORD	DB1.DBD 1

Note

The entry "DB0. ..." is not permitted because it is already used internally.

In the Force Values Window

- When forcing with S7-300 modules, only inputs, outputs, and I/O (outputs) are allowed.
- When forcing with S7-400 modules, only inputs, outputs, bit memory, and I/O (inputs/outputs) are allowed.

20.4.7.2 Example of Entering a Contiguous Address Range

Open a variable table and call up the "Insert Range of Variables" dialog box with the menu command **Insert > Range of Variables**.

For the dialog box entries the following lines for bit memory are inserted in the variable table:

- From address: M 3.0
- Number: 10
- Display format: BIN

Address	Display Format
M 3.0	BIN
M 3.1	BIN
M 3.2	BIN
M 3.3	BIN
M 3.4	BIN
M 3.5	BIN
M 3.6	BIN
M 3.7	BIN
M 4.0	BIN
M 4.1	BIN

Note that in this example the designation in the "Address" column changes after the eighth entry.

20.4.7.3 Examples of Entering Modify and Force Values

Bit Addresses

Possible bit addresses	Permitted modify/force values
I1.0	true
M1.7	false
Q10.7	0
DB1.DBX1.1	1
I1.1	2#0
M1.6	2#1

Byte Addresses

Possible byte addresses	Permitted modify/force values
IB 1	2#00110011
MB 12	b#16#1F
MB 14	1F
QB 10	'a'
DB1.DBB 1	10
PQB 2	-12

Word Addresses

Possible word addresses	Permitted modify/force values
IW 1	2#0011001100110011
MW12	w#16#ABCD
MW14	ABCD
QW 10	b#(12,34)
DB1.DBW 1	'ab'
PQW 2	-12345
MW3	12345
MW5	s5t#12s340ms
MW7	0.3s or 0,3s
MW9	c#123
MW11	d#1990-12-31

Double Word Addresses

Possible double word addresses	Permitted modify/force values
ID 1	2#0011001100110011001100110011
MD 0	23e4
MD 4	2
QD 10	dw#16#abcdef10
QD 12	ABCDEF10
DB1.DBD 1	b#(12,34,56,78)
PQD 2	'abcd'
MD 8	l# -12
MD 12	l#12
MD 16	-123456789
MD 20	123456789
MD 24	t#12s345ms
MD 28	tod#1:2:34.567
MD 32	p#e0.0

Timers

Possible addresses of the type "Timer"	Permitted modify/force values	Explanation
T 1	0	Conversion to milliseconds (ms)
T 12	20	Conversion to ms
T 14	12345	Conversion to ms
T 16	s5t#12s340ms	
T 18	3	Conversion to 1s 300 ms
T 20	3s	Conversion to 1s 300 ms

Modifying a timer affects only the value, not the state. This means that the timer T1 can be modified to the value 0, without the result of logic operation for A T1 being changed.

The strings 5t, s5time can be written in either upper or lower case.

Counters

Possible addresses of the type "Counter"	Permitted modify/force values
C 1	0
C 14	20
C 16	c#123

Modifying a counter only affects the value, not the state. This means that Counter C1 can be modified to the value 0 without the result of logic operation for A C1 being changed.

20.5 Establishing a Connection to the CPU

In order to be able to monitor or modify the variables you entered in your current variable table (VAT), you must establish a connection to the appropriate CPU. It is possible to link each variable table with a different CPU.

Displaying an Online Connection

If an online connection exists, the term "ONLINE" in the title bar of the variable table window indicates this fact. The status bar displays the operating states "RUN", "STOP", "DISCONNECTED" or "CONNECTED", depending on the CPU.

Establishing an Online Connection to the CPU

If an online connection to the required CPU does not exist, use the menu command **PLC > Connect To > ...** to define a connection to the required CPU so that variables can be monitored or modified.

Interrupting the Online Connection to the CPU

Using the menu command **PLC > Disconnect** you interrupt the connection between the variable table and the CPU.

Note

If you created an unnamed variable table with the menu command **Table > New**, you can establish a connection to the last configured CPU configured if it is defined.

20.6 Monitoring Variables

20.6.1 Introduction to Monitoring Variables

The following methods are available to you for monitoring variables:

- Activate the Monitor function with the menu command **Variable > Monitor**. The values of the selected variables are displayed in the variable table in accordance with the trigger point and trigger frequency set. If you set the trigger frequency "Every cycle," you can toggle the Monitor function off again with the menu command **Variable > Monitor**.
- You can update the values of the selected variables once and immediately using the menu command **Variable > Update Monitor Values**. The current values of the selected variables are displayed in the variable table.

Aborting "Monitoring" with ESC

If you press ESC while the "Monitoring" function is active, the function is terminated without a query.

20.6.2 Defining the Trigger for Monitoring Variables

You can display on the programming device the current values of individual variables in a user program at a specific point during program processing (trigger point) in order to monitor them.


When you select a trigger point you determine the point in time at which the monitor values of variables will be displayed.

You can set the trigger point and a trigger frequency using the menu command **Variable > Trigger**.

Trigger	Possible Settings
Trigger point	Start of cycle End of cycle Transition from RUN to STOP
Trigger frequency	Once Every cycle

Trigger Point

The following figure shows the position of the trigger points.



To display the modified value in the "Status Value" column, you should set the trigger point for monitoring to "Start of cycle" and the trigger point for modifying to "End of cycle".

Trigger Immediately

You can update the values of selected variables using the menu command **Variable > Update Monitor Values**. This command is taken to mean "trigger immediately" and is executed as quickly as possible without reference to any point in the user program. These functions are mainly used for monitoring and modifying in STOP mode.

Trigger Frequency

The following table shows the effect that the trigger frequency has on the monitoring of variables:

	Trigger frequency: Once	Trigger frequency: Every cycle
Monitor Variables	<i>Update once</i> Dependent on trigger point	<i>Monitoring with a defined trigger</i> When testing a block you can track the progress of processing exactly.

20.7 Modifying Variables

20.7.1 Introduction to Modifying Variables

The following methods are available to you for modifying variables:

- Activate the Modify function with the menu command **Variable > Modify**. The user program applies the modify values for the selected variables from the variable table in accordance with the trigger point and trigger frequency set. If you set the trigger frequency "Every cycle," you can toggle the Modify function off again with the menu command **Variable > Modify**.
- You can update the values of the selected variables once and immediately using the menu command **Variable > Activate Modify Values**.

The functions Force and Enable Peripheral Output (PQ) provide other possibilities.

When Modifying, Note:

- Only those addresses that were visible in the variable table when you started modifying are modified.
If you decrease the size of the visible area of the variable table once you have started modifying, addresses may be modified that are no longer visible.
If the visible area of the variable table is made larger, there may be addresses visible that are not modified.
- Modifying cannot be undone (for example, with **Edit > Undo**).



Danger

Changing the variable values while a process is running can lead to serious damage to property or personnel if errors occur in the function or in the program. Make sure that no dangerous situations can occur before you execute the "Modify" function.

Aborting "Modifying" with ESC

If you press ESC while the "Modifying" function is in process, the function is aborted without a query.

20.7.2 Defining the Trigger for Modifying Variables

You can assign fixed values to individual variables of a user program (once or every cycle) at a specific point during program processing (trigger point).


When you select a trigger point you determine the point in time at which the modify values are assigned to the variables.

You can set the trigger point and a trigger frequency using the menu command **Variable > Trigger**.

Trigger	Possible Settings
Trigger point	Start of cycle End of cycle Transition from RUN to STOP
Trigger frequency	Once Every cycle

Trigger Point

The following figure shows the position of the trigger points.



The position of the trigger points shows:

- Modifying inputs is only useful with the trigger point "Start of cycle" (corresponds to the start of the user program OB 1), because otherwise the process image of the inputs is updated after modifying and therefore overwritten).
- Modifying outputs is only useful with the trigger point "End of cycle" (corresponds to the end of the user program OB 1), because otherwise the user program can overwrite the process image of the outputs).

To display the modified value in the "Status Value" column, you should set the trigger point for monitoring to "Start of cycle" and the trigger point for modifying to "End of cycle".

The following applies to trigger points when modifying variables:

- If you set "Once" as the trigger frequency, a message appears if the selected variables cannot be modified.
- With the trigger frequency "Every cycle," no message appears.

Trigger Immediately

You can modify the values of selected variables using the menu command **Variable > Activate Modify Values**. This command is taken to mean "trigger immediately" and is executed as quickly as possible without reference to any point in the user program. This function is used mainly for modifying in STOP mode.

Trigger Frequency

The following table shows the effect that the trigger condition set has on the modifying of variables:

	Trigger frequency: Once	Trigger frequency: Every cycle
Modify Variables	<i>Activate once</i> You can assign values to variables once, independent of the trigger point.	<i>Modifying with a defined trigger</i> By assigning fixed values you can simulate certain situations for your user program and use this to debug the functions you have programmed.

20.8 Forcing Variables

20.8.1 Safety Measures When Forcing Variables



Beware of Injury to Personnel and Damage to Property

Note that when using the "Force" function, any incorrect action could:

- Endanger the life or health of personnel or
- Cause damage to machines or the whole plant.



Caution

- Before you start the Force function you should check that nobody is executing this function on the same CPU at the same time.
- A Force job can only be deleted or terminated with the menu command **Variable > Stop Forcing**. Closing the force values window or exiting the "Monitoring and Modifying Variables" application does not delete the force job.
- Forcing cannot be undone (for example, with **Edit > Undo**).
- Read the information on the Differences between Forcing and Modifying Variables.
- If a CPU does not support the Force function, all menu commands in the Variable menu linked with forcing are deactivated.

If the output disable is deactivated with the menu command **Variable > Enable Peripheral Output**, all forced output modules output their force value.

20.8.2 Introduction to Forcing Variables

You can assign fixed values to individual variables of a user program so that they cannot be changed or overwritten even by the user program executing in the CPU. The requirement for this is that the CPU supports this function (for example, the S7-400 CPUs). By assigning fixed values to variables you can set specific situations for your user program and use this to test the programmed functions.

"Force Values" Window

Only when the "Force Values" window is active can the menu commands for forcing be selected.

To display this window, select the menu command **Variable > Display Force Values**.

You should only open one single "Force Values" window for a CPU. The variables together with their respective force values for the active force job are displayed in this window.

Example of a Force Values Window

		Address	Symbol	Display Format	Force Value
1	F	IB 0		HEX	B#16#10
2	F	Q 0.1		BOOL	true
3	F	Q 1.2		BOOL	true
4					

The name of the current online connection is shown in the **title bar**.

The data and time the force job was read from the CPU are shown in the **status bar**.

If no force job is active, the window is empty.

The different methods of **displaying variables** in the "Force Values" window have the following significance:

Display	Meaning
Bold:	Variables that are already assigned a fixed value in the CPU.
Normal:	Variables that are being edited.
Grayed out:	Variables of a module that is not present/inserted in the rack or Variables with an address error; an error message is displayed.

Using Forcible Addresses from the Variable Table

If you want to enter a variable from a variable table in the force value window, select the table and the required variable. Next, call menu command **Variable > Force values** to open the force value window. The variables a module can force will be entered in the force value window.

Using the Force Job from the CPU or Setting Up a New Force Job

If the "Force Values" window is open and active, another message is displayed:

- If you confirm it, the changes in the window are overwritten with the force job existing on the CPU. You can restore the previous window contents with the menu command **Edit > Undo**.
- If you cancel it, the current contents of the window are retained. You can then save the contents of the "Force Values" window as a variable table using the menu command **Table > Save As** or select the menu command **Variable > Force**: this writes the current contents of the window to the CPU as the new force job.

Monitoring and modifying variables is only possible in the variable table and not in the "Force Values" window.

Deleting Force Values

Call menu command **Variable > Display Force Values** to open the force value window. Next, you can call menu command **Variable > Delete Force** to delete the force values from the selected CPU.

Saving a Force Values Window

You can save the contents of the force values window in a variable table. Using the **Insert > Variable Table** menu command, you can reinsert the saved contents in a force values window.

Notes on Symbols in the Force Values Window

The symbols in the last active window are entered except if you opened the "Monitoring and Modifying Variables" application from another application which has no symbols.

If you cannot enter symbolic names, the "Symbol" column is hidden. The menu command **Options > Symbol Table** is deactivated in this case.

20.8.3 Differences Between Forcing and Modifying Variables

The following table summarizes the differences between forcing and modifying:

Feature / Function	Forcing with S7-400 (incl. CPU 318-2DP)	Forcing with S7-300 (without CPU 318-2DP)	Modify
Bit memory (M)	yes	–	yes
Timers and counters (T, C)	–	–	yes
Data blocks (DB)	–	–	yes
Peripheral inputs (PIB, PIW, PID)	yes	–	–
Peripheral outputs (PQB, PQW, PQD)	yes	–	yes
Inputs and outputs (I, Q)	yes	yes	yes
User program can overwrite the modify/force values	–	yes	yes
Replacing the force value effective without interruption	yes	yes	–
The variables retain their values when the application is exited	yes	yes	–
The variables retain their values after the connection to the CPU is broken	yes	yes	–
Addressing errors permitted: e.g. IW1 modify/force value: 1 IW1 modify/force value: 0	–	–	The last becomes effective
Setting triggers	Always trigger immediately	always trigger immediately	once or every cycle
Function only affects variable in visible area of active window	Affects all force values	affects all force values	yes

Note

- With "Enable Peripheral Outputs," the force values for forced peripheral outputs become effective on the corresponding output modules; the modify values for peripheral outputs, however, do not.
 - With forcing, the variable always has the forced value. This value is read during each read access to the user program. All forms of write access are ineffective.
 - With permanent modifying, read access to the program is effective and remains so until the next trigger point.
-

21 Testing Using Program Status

You can test your program by displaying the program status (RLO, status bit) or the contents of the corresponding registers for every instruction. You can define the scope of the information displayed in the "LAD/FBD" tab in the "Customize" dialog box. You open this dialog box using the menu command **Options > Customize** in the "LAD/STL/FBD: Programming Blocks" window.



Warning

Testing a program while a process is running can lead to serious damage to property or persons if errors occur in the function or in the program.

Ensure that no dangerous situations can occur before you execute this function.


Requirements

To display the program status, the following requirements must be fulfilled:

- You must have saved the block without errors and then downloaded it to the CPU.
- The CPU must be in operation and the user program running.

Basic Procedure for Monitoring the Program Status

It is strongly recommended that you do not call the whole program and debug it, but call the blocks one by one and debug them individually. You should start with the blocks in the last nesting level of the call hierarchy, for example, by calling them in OB1 and creating the environment to be tested for the block by monitoring and modifying variables.



To set breakpoints, and to execute the program in single-step mode, test operation mode must be set (see menu command **Debug > Operation**). These test functions are not possible in process operation mode.

21.1 Program Status Display

The display of the **program status** is updated cyclically. It begins with the selected network.

Preset Color Codes in LAD and FBD

- Status fulfilled: green continuous lines
- Status not fulfilled: blue dotted lines
- Status unknown: black continuous lines

The preset for line type and color can be changed under the menu command **Options > Customize**, "LAD/FBD" tab.

Status of Elements

- The status of a contact is:
 - Fulfilled if the address has the value "1,"
 - Not fulfilled if the address has the value "0,"
 - Unknown if the value of the address is unknown.
- The status of elements with enable output (ENO) corresponds to the status of a contact with the value of the ENO output as the address.
- The status of elements with a Q output corresponds to the status of a contact with the value of the address.
- The status for CALLs is fulfilled if the BR bit is set following the call.
- The status of a jump instruction is fulfilled if the jump is executed, meaning if the jump condition is fulfilled.
- Elements with enable output (ENO) are shown in black if the enable output is not connected.

Status of Lines

- Lines are black if they are not run through or if their status is unknown.
- The status of lines that start at the power rail is always fulfilled ("1").
- The status of lines at the start of parallel branches is always fulfilled ("1").
- The status of the line following an element is fulfilled if both the status of the line before the element and the status of the element are fulfilled.
- The status of the line following NOT is fulfilled if the status of the line before NOT is not fulfilled (and vice versa).
- The status of the line **after** an intersection of a number of lines is fulfilled if:
 - The status of at least one line **before** the intersection is fulfilled.
 - The status of the line before the branch is fulfilled.

Status of Parameters

- The values of parameters in **bold type** are current.
- The values of parameters in thin type result from a previous cycle; the program section was not processed in the current scan cycle.

21.2 What You Should Know About Testing in Single-Step Mode/Breakpoints

When testing in single-step mode you can do the following:

- Execute programs statement by statement (in single steps)
- Set breakpoints

The function "testing in single-step mode" is not possible for all programmable controllers (refer to the documentation for the relevant programmable controller).

Status Word									
/FC	<input type="checkbox"/>	STA	<input checked="" type="checkbox"/>	OS	<input type="checkbox"/>	CC0	<input type="checkbox"/>	BR	<input type="checkbox"/>
RLO	<input checked="" type="checkbox"/>	OR	<input type="checkbox"/>	OV	<input type="checkbox"/>	CC1	<input type="checkbox"/>		
Accu1	3039		Accu2	58					
AR1	0		AR2	84000000					
ShdDB			InstDB						

Requirements

- The test operation mode must be set. Testing in single-step mode is not possible in process operation mode (see menu command **Debug > Operation**).
- Testing in single-step mode is possible only in Statement List. For blocks in Ladder Logic or Function Block Diagram you must change the view using the menu command **View > STL**.
- The block must not be protected.
- The block must be open online.
- The opened block must not be changed in the Editor.

Number of Breakpoints

The number of breakpoints is variable and depends on the following:

- The number of breakpoints already set
- The number of variable statuses running
- The number of program statuses running

Refer to your programmable controller documentation to find out whether it supports testing in single-step mode.

You will find the menu commands you can use to set, activate, or delete breakpoints in the "Debug" menu. You can also select these menu commands using icons in the breakpoint bar. Display the breakpoint bar using the menu command **View > Breakpoint Bar**.

Permitted Test Functions

- Monitor/modify variables
- Module information
- Operating mode

Danger

Risk of dangerous plant status in HOLD mode.

21.3 What You Should Know About the HOLD Mode

If the program encounters a breakpoint, the programmable controller goes into the HOLD operating mode.

LED Display in HOLD Mode

- LED RUN flashes
- LED STOP is lit

Program Processing in HOLD Mode

- In HOLD mode, no S7 code is processed, meaning no priority classes are processed any further.
- All timers are frozen:
 - No timer cells are processed
 - All monitoring times are paused
 - The basic clock rate of the time-controlled levels are paused
- The real time clock continues to run
- For safety reasons, the outputs are always disabled in HOLD mode ("output disable").

Behavior following Power Supply Failure in HOLD Mode

- Programmable controllers with battery backup change to STOP mode and remain there following a power supply failure during HOLD mode and a subsequent return of power. The CPU does not execute an automatic restart (warm restart). From STOP mode you can determine how processing continues (for example, by setting/resetting breakpoints, executing a manual restart).
- Programmable controllers without battery backup are not "retentive" and therefore execute an automatic warm restart when power returns, regardless of the previous operating mode.

21.4 Program Status of Data Blocks

From STEP 7 version 5 onwards, it is possible to observe a data block online in the data view. The display can be activated either by an online data block or by an offline data block. In both cases, the contents of the online data block in the programmable controller are displayed.

The data block must not be modified before the program status is started. If there is a structural difference (declaration) between the online data block and the offline data block, the offline data block can be downloaded to the programmable controller directly on request.

The data block must be located in the "data view," so that the online values can be displayed in the "Actual Value" column. Only the part of the data block which is visible on the screen is updated. While the status is active, you cannot switch to the declaration view.

While the update is in progress, a green bar is visible in the status bar and the operating mode is displayed.

The values are issued in the format of the respective data type; the format cannot be changed.

After program status has been concluded, the "Actual Value" column displays again the contents which were valid before the program status. It is not possible to transfer the updated online values to the offline data block.

Updating data types:

All the elementary data types are updated in a shared DB, as well as in all the declarations (in/out/in-out/stat) of an instance data block.

Some data types cannot be updated. When the program status is active, fields in the "Actual Value" column which contain data which have not been updated are displayed with a gray background.

- The complex data types DATE_AND_TIME and STRING are not updated.
- In the complex data types ARRAY, STRUCT, UDT, FB, and SFB, only those elements which are elementary data types are updated.
- In the INOUT declaration of an instance data block only the pointer to the complex data type is displayed, not the elements of the data type itself. The pointer is not updated.
- Parameter types are not updated
- Introduction to Monitoring Variables.

21.5 Setting the Display for Program Status

You can set the display of the program status in a Statement List, Function Block Diagram, or Ladder Logic block yourself.

To set the display, proceed as follows:

1. Select the menu command **Options > Customize**.
2. In the "Customize" dialog box, select the "STL" tab or the "LAD/FBD" tab.
3. Select the required options for testing the program. You can display the following status fields.

Activate...	...To Display
Status bit	Status bit; bit 2 of the status word
RLO	Bit 1 of the status word; shows the result of a logic operation or a mathematical comparison
Standard status	Content of accumulator 1
Address register 1/2	Content of the respective address register with register-indirect addressing (area-internal or area-crossing)
Akku2	Content of accumulator 2
DB register 1/2	Content of the data block register, of the first and/or second open data block
Indirect	Indirect memory reference; pointer reference (address), not address content reference; for memory-indirect addressing only, not possible with register-indirect addressing. Contents of a timer word or counter word if corresponding instructions appear in the statement
Status word	All status bits of the status word

21.6 Setting the Mode for the Test

Procedure

1. Display the set test environment using the menu command **Debug > Operation**.
2. Select the required mode of operation. You can choose between test operation and process operation.

Mode of Operation	Explanation
Test operation	All test functions are possible without restriction. Significant increases to the CPU scan cycle time can occur because, for example, the status of statements in programmed loops is recorded in every cycle.
Process operation	The test function program status is restricted to guarantee the minimum possible load on the scan cycle time. <ul style="list-style-type: none">• This means, for example, that no call conditions are permitted.• The status display of a programmed loop is aborted at the point of return.• The test functions HOLD and single-step program execution are not possible.

Note

If the mode of operation was set when you assigned the CPU parameters, you can only change the mode by changing the parameters. Otherwise you can change the mode in the dialog box displayed.

22 Testing using the Simulation Program (Optional Package)

22.1 Testing using the Simulation Program S7-PLCSIM (Optional Package)

With the optional software package PLC Simulation you can run and test your program on a simulated programmable controller that exists on your computer or programming device (for example, Power PG). As the simulation is realized completely by the STEP 7 software, you do not require any S7 hardware (CPU or signal modules). Using the simulated S7 CPU you can test and troubleshoot programs for S7-300 and S7-400 CPUs.


This application provides a simple user interface for monitoring and modifying the various parameters that are used in your program (for example, for switching inputs on and off). You can also use the various applications in the STEP 7 software while your program is being processed by the simulated CPU. For example, you can monitor and modify variables with the variable table.

23 Diagnostics

23.1 Hardware Diagnostics and Troubleshooting

You can see whether diagnostic information is available for a module by the presence of diagnostics symbols. Diagnostics symbols show the status of the corresponding module and, for CPUs, the operating mode as well.

Diagnostics symbols are displayed in the project window in the online view as well as in the quick view (default setting) or the diagnostic view when you call the function "Hardware Diagnostics." Detailed diagnostic information is displayed in the "Module Information" application, which you can start by double-clicking a diagnostics symbol in the quick view or the diagnostic view.



How to Locate Faults

1. Open the online window for the project with the menu command **View > Online**.
2. Open all the stations so that the programmable modules configured in them are visible.
3. Check to see which CPU is displaying a diagnostics symbol indicating an error or fault. You can open the help page with an explanation of the diagnostics symbols using the F1 key.
4. Select the station that you want to examine.
5. Select the menu command **PLC > Diagnostics/Settings > Module Information...** to display the module information for the CPU in this station.
6. Select the menu command **PLC > Diagnostics/Settings > Hardware Diagnostics** to display the "quick view" with the CPU and the failed modules in this station. The display of the quick view is set as default (menu command **Option > Customize**, "View" tab).
7. Select a faulty module in the quick view.
8. Click the "Module Information" button to obtain the information on this module.
9. Click the "Open Station Online" button in the quick view to display the diagnostic view. The diagnostic view contains all the modules in the station in their slot order.
10. Double-click a module in the diagnostic view in order to display its module information. In this way, you can also obtain information for those modules that are not faulty and therefore not displayed in the quick view.

You do not necessarily have to carry out all of the steps; you can stop as soon as you have obtained the diagnostic information you require.

23.2 Diagnostics Symbols in the Online View

Diagnostics symbols are displayed in the online project window and in the hardware configuration window with the online view of configuration tables.

Diagnostics symbols make it easier for you to detect a fault. You can see by a glance at a module symbol whether diagnostic information is available. If there are no faults present, the symbols for the module types are displayed without additional diagnostics symbols.

If diagnostic information is available for a module, a diagnostics symbol is displayed in addition to the module symbol or the module symbol is displayed with reduced contrast.

Diagnostics Symbols for Modules (Example: FM / CPU)

Symbol	Meaning
	Mismatch between preset and actual configuration: the configured module does not exist or a different module type is inserted
	Fault: module has a fault. Possible causes: diagnostic interrupt, I/O access error, or error LED detected
	Diagnosis not possible: no online connection, or the CPU does not return diagnostic information to the module (for example, power supply, or submodule).

Diagnostics Symbols for Operating Modes (Example: CPU)

Symbol	Mode
	STARTUP
	STOP
	STOP triggered by STOP mode on another CPU in multicomputing operation
	RUN
	HOLD

Diagnostics Symbol for Forcing

Symbol	Mode
	<p>Variables are being forced on this module, meaning variables in the user program for the module are assigned fixed values that cannot be changed by the program.</p> <p>The symbol for forcing can also appear in combination with other symbols (here with the symbol for RUN mode).</p>

Updating the Display of Diagnostic Symbols

The appropriate window must be activated.

- Press F5 or
- Select the menu command **View > Update** in the window.

23.3 Diagnosing Hardware: Quick View

23.3.1 Calling the Quick View

The quick view offers you a quick way of using "Diagnosing Hardware" with less information than the more detailed displays in the diagnostic view of HW Config. The quick view is displayed as default when the "Diagnose Hardware" function is called.

Displaying the Quick View

You call this function from the SIMATIC Manager using the menu command **PLC > Diagnostics/Settings > Diagnose Hardware**.

You can use the menu command as follows:

- In the online window of the project if a module or an S7/M7 program is selected.
- If a node ("MPI=...") is selected in the "Accessible Nodes" window and this entry belongs to a CPU.

From the configuration tables displayed, you can select modules whose module information you want to display.

23.3.2 Information Functions in the Quick View

The following information is displayed in the quick view:

- Data for the online connection to the CPU
- Diagnostic symbol for the CPU
- Diagnostic symbols for the modules in which the CPU has detected a fault (for example, diagnostic interrupt, I/O access error)
- Module type and address of the module (rack, slot, DP master system with station number).


Other Diagnostic Options in the Quick View

- **Displaying the Module Information**
You can call this dialog box by clicking the "Module Information" button. The dialog box displays detailed diagnostic information, depending on the diagnostic capabilities of the selected module. In particular, you can display the entries in the diagnostic buffer via the diagnostic information of the CPU.
- **Displaying the Diagnostic View**
Using the "Open Station Online" button, you can open the dialog box which, in contrast to the quick view, contains a graphic overview of the whole station as well as configuration information. It focuses on the module which is highlighted in the list "CPU / Faulty Modules."

23.4 Diagnosing Hardware: Diagnostic View

23.4.1 Calling the Diagnostic View

Using this method you can open the "Module Information" dialog box for all modules in the rack. The diagnostic view (configuration table) shows the actual structure of a station at the level of the racks and DP stations with their modules.



Note

- If the configuration table is already open offline, you can also get the online view of the configuration table using the menu command **Station > Open Online**.
- Depending on the diagnostics capability of the module, a varying number of tabs are displayed in the "Module Information" dialog box.
- In the "Accessible Nodes" window, only the modules with their own node address (Ethernet, MPI or PROFIBUS address) are ever visible.

Calling from the ONLINE view of a project in the SIMATIC Manager

1. Establish an online connection to the programmable controller using the menu command **View > Online** in the project view in the SIMATIC Manager.
2. Select a station and open it with a double-click.
3. Then open the "Hardware" object in it. The diagnostic view is opened.

Now you can select a module and call up its module information using the menu command **PLC > Diagnostics/Settings > Module Information**.

Calling from the offline view of a project in the SIMATIC Manager

Execute the following steps:

1. Select a station from the project view of the SIMATIC Manager and open it with a double-click.
2. Then open the "Hardware" object in it. The configuration table is opened.
3. Select the **Station > Open Online** menu command.
4. The diagnostic view of HW Config is opened with the station configuration as determined from the modules (for example, CPU). The status of the modules is indicated by means of symbols. Refer to the online help for the meaning of the various symbols. Faulty modules and configured modules which are missing are listed in a separate dialog box. From this dialog box you can navigate directly to one of the selected module ("Go To" button).
5. Double-click the symbol for the module whose status you are interested in. A dialog box with tabs (depending on the type of module) gives you a detailed analysis of the module status.

Calling from the "Accessible Nodes" window in the SIMATIC Manager

Execute the following steps:

1. Open the "Accessible Nodes" window in the SIMATIC Manager using the menu command **PLC > Display Accessible Nodes**.
2. Select a node in the "Accessible Nodes" window.
3. Select the menu command **PLC > Diagnostics/Settings > Diagnose Hardware**.

Note

In the "Accessible Nodes" window, only the modules with their own node address (Ethernet, MPI or PROFIBUS address) are visible.

23.4.2 Information Functions in the Diagnostic View

In contrast to the quick view, the diagnostic view displays the entire station configuration available online. This consists of:

- Rack configurations
- Diagnostics symbols for **all** configured modules
From these, you can read the status of each module and, with CPU modules, the operating mode.
- Module type, order number and address details, comments on the configuration.

Additional Diagnostic Options in the Diagnostic View


By double-clicking a module, you can display the operating mode of this module.

23.5 Module Information

23.5.1 Options for Displaying the Module Information

You can display the "Module Information" dialog box from different starting points. The following procedures are examples of frequently used methods of calling module information:

- In the SIMATIC Manager from a window with the project view "online" or "offline."
- In the SIMATIC Manager from an "Accessible Nodes" window
- In the diagnostic view of HW Config



In order to display the status of a **module with its own node address**, you require an online connection to the programmable controller. You establish this connection via the online view of a project or via the "Accessible Nodes" window.

23.5.2 Module Information Functions

The module information functions can each be found in the various tabs within the "Module Information" dialog box. When displayed in an active situation, only those tabs relevant to the selected module are displayed.

Function/Tab	Information	Use
General	Identification data on the selected module; for example, order number, release number, status, slot in rack	The online information from the inserted module can be compared with the data for the configured module
Diagnostic Buffer	Overview of events in the diagnostic buffer and detailed information on the selected event	To find the cause of a CPU STOP and evaluate the events on the selected module leading to it Using the diagnostic buffer, errors in the system can still be analyzed at a later time to find the cause of a STOP or to trace back and categorize the occurrence of individual diagnostic events
Diagnostic Interrupt	Diagnostic data for the selected module	To evaluate the cause of a module fault
DP Slave Diagnostics	Diagnostic data for the selected DP slave (to EN 50170)	To evaluate the cause of a fault in a DP slave
Memory	Memory capacity. Current utilization of the work memory, load memory and retentive memory of the selected CPU or M7 function module	Before new or extended blocks are transferred to a CPU, to check whether sufficient load memory is available in the CPU/function module or to compress the memory content.
Scan Cycle Time	Duration of the longest, shortest, and last scan cycle of the selected CPU or M7 function module	To keep a check on the configured minimum cycle time, and the maximum and current cycle times
Time System	Current time, operating hours, and information about synchronizing clocks (synchronization intervals)	To display and set the time and date of a module and to check the time synchronization
Performance Data	Address areas and the available blocks for the selected module (CPU/FM)	Before and during the creation of a user program to check whether the CPU fulfils the requirements for executing a user program; for example, load memory size or size of the process image
Blocks (can be opened from the "Performance Data" tab)	Display of all block types available in the scope of supply of the selected module List of OBs, SFBs, and SFCs you can use for this module	To check which standard blocks your user program can contain or call to be able to run on the selected CPU.
Communication	Transmission rates, the overview of communication connections, the communication load, and the maximum message frame size on the communication bus of the selected module	To determine how many and which CPU or M7 FM connections are possible and how many are in use

Function/Tab	Information	Use
Stacks	Stacks tab: Can only be called up in STOP mode or HOLD mode. The B stack for the selected module is displayed. You can then also display the I stack, the L stack, and the nesting stack and jump to the error location in the interrupted block.	To determine the cause of a transition to STOP and to correct a block

Additional Information Displayed

For each tab, the following information is displayed:

- Online path to the selected module
- Operating mode of the corresponding CPU (for example, RUN, STOP)
- Status of the selected module (for example, error, OK)
- Operating mode of the selected module (for example, RUN, STOP) if it has its own operating mode (for example, CP 342-5)

The operating mode of the CPU itself and the status of the selected module cannot be displayed if the module information for a non-CPU module is opened from the "Accessible Nodes" window.

Displaying a Number of Modules Simultaneously

You can display the module information for a number of modules simultaneously. To do this, you must change to the respective module context, select another module, and then call the module information for it. Another "Module Information" dialog box is then displayed. Only one dialog box can be opened for each module.

Updating the Display of Module Information


Each time you switch to a tab in the "Module Information" dialog box, the data are read from the module again. While a page is displayed, however, the contents are not updated. If you click the "Update" button, you can read the data from the module without changing the tab.

23.5.3 Scope of the Module Type-Dependent Information

The scope of information that can be evaluated and displayed is dependent on:

- The module selected, and
- From which view you call the module information
 A full scope of information is available when called from the online view of the configuration tables or from the project window.
 A limited scope of information is available when called from the "Accessible Nodes" window.

Depending on the scope of the information, the modules are divided into the categories "with system diagnostic capability," "with diagnostic capability," or "without diagnostic capability." The following figure shows these categories:



- Modules with system diagnostic capability are, for example, the modules FM 351 and FM 354
- Modules with diagnostic capability are most analog signal modules.
- Modules without diagnostic capability are most digital signal modules.

Tabs Displayed

The table shows which property tabs are present in the "Module Information" dialog box for each module type.

Tab	CPU or M7 FM	Module with System Diagnostics Capability	Module with Diagnostics Capability	Module without Diagnostics Capability	DP Slave
General	yes	yes	yes	yes	yes
Diagnostic Buffer	yes	yes	–	–	–
Diagnostic Interrupt	–	yes	yes	–	yes
Memory	yes	–	–	–	–
Scan Cycle Time	yes	–	–	–	–
Time System	yes	–	–	–	–
Performance Data	yes	–	–	–	–
Stacks	yes	–	–	–	–
Communication	yes	–	–	–	–

Tab	CPU or M7 FM	Module with System Diagnostics Capability	Module with Diagnostics Capability	Module without Diagnostics Capability	DP Slave
DP Slave Diagnostics	–	–	–	–	yes
H state ¹⁾	yes	–	–	–	–

¹⁾ Only for CPUs in H systems

In addition to the information in the tabbed property sheets, the operating mode is displayed for modules with an operating mode. When you open the dialog box from the configuration tables online, the status of the module from the viewpoint of the CPU is displayed (for example, OK, fault, module not available).

23.5.4 Displaying the Module Status of PA Field Devices and DP Slaves After a Y-Link

As of STEP 7 V5.1 Service Pack 3, you can evaluate the module status of DP slaves and PA field devices "after" a DP/PA link (IM 157).

This affects the following configurations:


- IM 157 with DP/PA connectors for connecting a PROFIBUS-PA
- IM 157 as a redundant modular interface module for connecting a non-redundant PROFIBUS-DP ("Y-link")

In this configuration, the programming device (PG) is connected to the same PROFIBUS subnet as the DP/PA link.


In addition, there is another configuration option in which the PG is connected to an Industrial Ethernet and routes an S7-400 station to the PROFIBUS subnet.

The prerequisites for this setup are shown in the following diagram:


IM 157 with DP/PA connectors for connection to PROFIBUS-PA



IM 157 as Y-link



PG in an Industrial Ethernet



23.6 Diagnosing in STOP Mode

23.6.1 Basic Procedure for Determining the Cause of a STOP

To determine why the CPU has gone into "STOP" mode, proceed as follows:

1. Select the CPU that has gone into STOP.
2. Select the menu command **PLC > Diagnostics/Settings > Module Information**.
3. Select the "Diagnostic Buffer" tab.
4. You can determine the cause of the STOP from the last entries in the diagnostic buffer.

If a programming error occurs:

1. The entry "STOP because programming error OB not loaded" means, for example, that the CPU has detected a program error and then attempted to start the (non-existent) OB to handle the programming error. The previous entry points to the actual programming error.
2. Select the message relating to the programming error.
3. Click the "Open Block" button.
4. Select the "Stacks" tab.

23.6.2 Stack Contents in STOP Mode

By evaluating the diagnostic buffer and the stack contents you can determine the cause of the fault in the processing of the user program.

If, for example, the CPU has gone into STOP as a result of a programming error or the STOP command, the "Stacks" tab in the module information displays the block stack. You can display the contents of the other stacks using the "I Stack", "L Stack", and "Nesting Stack" buttons. The stack contents give you information on which instruction in which block led to the CPU going into STOP.

B Stack Contents

The B stack, or block stack, lists all the blocks that were called before the change to STOP mode and which were not completely processed.

I Stack Contents

When you click the "I Stack" button, the data at the interrupt location are displayed. The I stack, or interrupt stack, contains the data or the states which were valid at the time of the interrupt, for example:

- Accumulator contents and register contents
- Open data blocks and their size
- Content of the status word
- Priority class (nesting level)
- Interrupted block
- Block in which program processing continues after the interrupt

L Stack Contents

For every block listed in the B stack, you can display the corresponding local data by selecting the block and clicking the "L Stack" button.

The L stack, or local data stack, contains the local data values of the blocks the user program was working with at the time of the interrupt.

In-depth knowledge of the system is required to interpret and evaluate the local data displayed. The first part of the data displayed corresponds to the temporary variables for the block.

Nesting Stack Contents

When you click the "Nesting Stack" button, the contents of the nesting stack at the interrupt location are displayed.

The nesting stack is a memory area that the logic operations **A()**, **AN()**, **O()**, **ON()**, **X()**, and **XN()** use.

The button is only active if bracket expressions were still open at the time of interruption.

23.7 Checking Scan Cycle Times to Avoid Time Errors

The "Scan Cycle Time" tab in the module information gives information about the scan cycle times of the user program.

If the duration of the longest cycle time is close to the configured maximum scan cycle time, there is a danger that fluctuations in the cycle time might cause a time error. This can be avoided if you extend the maximum cycle time (watchdog time) of the user program.


If the cycle length is less than the configured minimum scan time, the cycle is automatically extended by the CPU/FM to the configured minimum cycle time. In the case of a CPU, the background OB (OB90) is processed during this extended time (if it has been downloaded).

Setting the Scan Cycle Time

You can set the maximum and minimum cycle times when you configure the hardware. To do this, double-click in the offline view of the configuration table on the CPU/FM to define its properties. You can enter the appropriate values in the "Cycle/Clock Memory" tab.

23.8 Flow of Diagnostic Information

The following figure shows the flow of diagnostic information in SIMATIC S7.



Displaying Diagnostic Information

You can read out the diagnostic entries using SFC51 RDSYSST in the user program or display the diagnostic messages in plain language with STEP 7.

They provide information about the following:

- Where and when the error occurred
- The type of diagnostic event to which the entry belongs (user-defined diagnostic event, synchronous/asynchronous error, operating mode change).

Generating Process Control Group Messages

The CPU enters events of the standard diagnostics and extended diagnostics in the diagnostic buffer. It also generates a process control group message for the standard diagnostic events if the following conditions are met:


- You have specified that process control messages will be generated in STEP 7.
- At least one display unit has logged on at the CPU for process control messages.
- A process control group message is only generated when there is not currently a process control group message of the corresponding class (there are seven classes).
- One process control group message can be generated per class.

23.8.1 System Status List SSL

The system status list (SSL) describes the current status of the programmable logic controller. It provides an overview of the configuration, the current parameter assignment, the current statuses and sequences on the CPU, and the modules belonging to it.

You can only read the data in the system status list but not modify them. It is a virtual list that is only created on request.

The information that you can display using the system status list can be divided into four areas.



Reading Out the System Status List

There are two ways of reading out the information in system status lists, as follows:

- Implicitly, via STEP 7 menu commands from the programming device (for example, memory configuration, static CPU data, diagnostic buffer, status displays).
- Explicitly, via the system function SFC 51 RDSYSST in the user program, by entering the number of the required partial system status list (see Help on Blocks)

System Data of the System Status List

System data are intrinsic or assigned characteristic data of a CPU. The following table shows the topics about which information can be displayed (partial system status lists):

Topic	Information
Module identification	Order number, type ID, and version of the module
CPU characteristics	Time system, system behavior (for example, multicomputing) and language description of the CPU
Memory areas	Memory configuration of the module (size of the work memory).
System areas	System memory of the module (for example, number of memory bits, timers, counters, memory type).
Block types	Which blocks (OB, DB, SDB, FC, FB) exist on the module, the maximum number of blocks of one type, and the maximum size of a block type
Assignment of interrupts and errors	Assignment of interrupts/errors to OBs
Interrupt status	Current status of interrupt processing/interrupts generated
Status of the priority classes	Which OB is being executed, which priority class is disabled due to the parameter setting
Operating mode and mode transition	Which operating modes are possible, the last operating mode change, the current operating mode

Diagnostic Status Data in the CPU

Diagnostic status data describe the current status of the components monitored by the system diagnostics. The following table shows the topics about which information can be displayed (partial system status lists):

Topic	Information
Communication status data	All the communication functions currently set in the system
Diagnostic modules	The modules with diagnostics capability logged on at the CPU
Start information list of the OB	Start information about the OBs of the CPU
Start event list	Start events and priority classes of the OBs
Module status information	Status information about all assigned modules that are plugged in, faulty, or generate hardware interrupts

Diagnostic Data on Modules

In addition to the CPU, there are also other modules with diagnostic capabilities (SMs, CPs, FMs) whose data are entered in the system status list. The following table shows the topics about which information can be displayed (partial system status list):

Topic	Information
Module diagnostic information	Module start address, internal/external faults, channel faults, parameter errors (4 bytes)
Module diagnostic data	All the diagnostic data of a particular module

23.8.2 Sending Your Own Diagnostic Messages

You can also extend the standard system diagnostics of SIMATIC S7 by using the system function SFC 52 WRUSMSG to:

- Enter your own diagnostic information in the diagnostic buffer (for example, information about the execution of the user program).
- Send user defined diagnostic messages to logged on stations (monitoring devices such as a PG, OP or TD).

User Defined Diagnostic Events

The diagnostic events are divided into event classes 1 to F. The user defined diagnostic events belong to event classes 8 to B. These can be divided into two groups, as follows:

- Event classes 8 and 9 include messages with a fixed number and predefined text that you can call up based on the number.
- Event classes A and B include messages to which you can assign a number (A000 to A0FF, B000 to B0FF) and text of your own choice.

Sending Diagnostic Messages to Stations

In addition to making a user defined entry in the diagnostic buffer, you can also send your own user defined diagnostic messages to logged on display devices using SFC52 WRUSMSG. When SFC52 is called with SEND = 1, the diagnostic message is written to the send buffer and automatically sent to the station or stations logged on at the CPU.

If it is not possible to send messages (for example, because no display device is logged on or because the send buffer is full) the user-defined diagnostic event is still entered in the diagnostic buffer.

Generating a Message with Acknowledgement

If you acknowledge a user defined diagnostic event and want to record the acknowledgement, proceed as follows:

- When the event enters the event state, write 1 to a variable of the type BOOL, when the event leaves the event state write 0 to the variable.
- You can then monitor this variable using SFB33 ALARM.

23.8.3 Diagnostic Functions

System diagnostics detect, evaluate, and report errors that occur within a programmable controller. For this purpose, every CPU and every module with system diagnostics capability (for example, FM 354) has a diagnostic buffer in which detailed information on all diagnostic events is entered in the order they occurred.

Diagnostic Events

The following entries are displayed as diagnostic events, for example:

- Internal and external faults on a module
- System errors in the CPU
- Operating mode changes (for example, from RUN to STOP)
- Errors in the user program
- Inserting/removing modules
- User messages entered with the system function SFC52

The content of the diagnostic buffer is retained following a memory reset. Using the diagnostic buffer, errors in the system can still be analyzed at a later time to find the cause of a STOP or to trace back and categorize the occurrence of individual diagnostic events

Acquiring Diagnostic Data

You do not need to program the acquisition of diagnostic data by system diagnostics. This is a standard feature that runs automatically. SIMATIC S7 provides various diagnostic functions. Some of these functions are integrated on the CPU, others are provided by the modules (SMs, CPs, and FMs).

Displaying Faults

Internal and external module faults are displayed on the front panels of the module. The LED displays and their evaluation are described in the S7 hardware manuals. With the S7-300, internal and external faults are displayed together as a group error.

The CPU recognizes system errors and errors in the user program and enters diagnostic messages in the system status list and the diagnostic buffer. These diagnostic messages can be read out on the programming device.

Signal and function modules with diagnostic capability detect internal and external module errors and generate a diagnostic interrupt to which you can react using an interrupt OB.

23.9 Program Measures for Handling Errors

When it detects errors in program processing (synchronous errors) and errors in the programmable controller (asynchronous errors), the CPU calls the appropriate organization block (OB) for the error:

Error	Error OB
I/O redundancy error	OB70
CPU redundancy error	OB72
Time error	OB80
Power supply error	OB81
Diagnostic interrupt	OB82
Insert/remove module interrupt	OB83
CPU hardware fault	OB84
Priority class error	OB85
Rack failure or failure of a station in the distributed I/O	OB86
Communication error	OB87
Programming error	OB121
I/O access error	OB122

If the appropriate OB is not available, the CPU goes into STOP mode (exceptions: OB70, OB72, OB81, OB87). Otherwise, it is possible to store instructions in the OB as to how it should react to this error situation. This means the effects of an error can be reduced or eradicated.

Basic Procedure

Creating and Opening the OB

1. Display the module information for your CPU.
2. Select the "Performance Data" tab.
3. Decide on the basis of the list displayed whether the OB you want to program is permitted for this CPU.
4. Insert the OB in the "Blocks" folder of your program and open the OB.
5. Enter the program for handling the error.
6. Download the OB to the programmable controller.

Programming Measures for Handling Errors

1. Evaluate the local data of the OB to determine the exact cause of the error. The variables OB8xFLTID and OB12xSWFLT in the local data contain the error code. Their meaning is described in the "System and Standard Functions Reference Manual."
2. Branch to the program segment which reacts to this error.

You will find an example of handling diagnostic interrupts in the reference online help on System and Standard Functions under the heading "Example of Module Diagnostics with SFC51 (RDSYSST)."

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.1 Evaluating the Output Parameter RET_VAL

Using the RET_VAL output parameter (return value), a system function indicates whether or not the CPU was able to execute the SFC function correctly

Error Information in the Return Value

The return value is of the integer data type (INT). The sign of an integer indicates whether it is a positive or negative integer. The relationship of the return value to the value "0" indicates whether or not an error occurred while the function was being executed (see table):

- If an error occurs while the function is being executed, the return value is less than "0." The sign bit of the integer is "1."
- If the function is executed free of errors, the return value is greater than or equal to "0." The sign bit of the integer is "0."

Processing of the SFC by the CPU	Return Value	Sign of the Integer
Error occurred	Less than "0"	Negative (sign bit is "1")
No error	Greater than or equal to "0"	Positive (sign bit is "0")

Reacting to Error Information

If an error occurs while an SFC is being executed, the SFC provides an error code in the return value (RET_VAL).

A distinction is made between the following:

- A general error code that all SFCs can output and
- A specific error code that the SFC can output depending on its specific function.

Transferring the Function Value

Some SFCs also use the output parameter RET_VAL to transfer the function value, for example, SFC64 TIMETCK transfers the system time it has read using RET_VAL.

You can find more detailed information on the output parameter RET_VAL in the Help on SFBs/SFCs.

23.9.2 Error OBs as a Reaction to Detected Errors

Detectable Errors


The system program can detect the following errors:

- CPU functioning incorrectly
- Error in the system program execution
- Errors in the user program
- Error in the I/Os

Depending on the type of error, the CPU is set to STOP mode or an error OB is called.

Programming Reactions

You can design programs to react to the various types of errors and to determine the way in which the CPU reacts. The program for a particular error can then be saved in an error OB. If the error OB is called, the program is executed.



Error OBs

A distinction is made between synchronous and asynchronous errors as follows:

- Synchronous errors can be assigned to an MC7 instruction (for example, load instruction for a signal module which has been removed).
- Asynchronous errors can be assigned to a priority class or to the entire programmable logic controller (for example, cycle time exceeded).


The following table shows what types of errors can occur. Refer to your "S7-300 Programmable Controller, Hardware and Installation Manual" or the "S7-400, M7-400 Programmable Controllers, Hardware and Installation Manual" for information as to whether your CPU provides the specified OBs.

Error Class	Error Type	OB	Priority
Redundancy	I/O redundancy error (only in H CPUs)	OB 70	25
	CPU redundancy error (only in H CPUs)	OB 72	28
Asynchronous	Time error	OB 80	26
	Power supply error	OB 81	(or 28 if the error OB is called
	Diagnostic Interrupt	OB 82	in the startup program)
	Insert/remove module interrupt	OB 83	
	CPU hardware fault	OB 84	
	Program sequence error	OB 85	
	Rack failure	OB 86	
	Communication error	OB 87	
Synchronous	Programming error	OB 121	Priority of the OB that caused the error
	I/O access error	OB 122	

Example of Using Error OB81

Using the local data (start information) of the error OB, you can evaluate the type of error that has occurred.

If, for example, the CPU detects a battery error, the operating system calls OB81 (see figure).



You can write a program that evaluates the event code triggered by the OB81 call. You can also write a program that brings about a reaction, such as activating an output connected to a lamp on the operator station.

Local Data of Error OB81

The following table shows the temporary variables that must be declared, in this case, in the variable declaration table of OB81.

The symbol *Battery error* (BOOL) must be identified as an output (for example, Q 4.0) so that other parts of the program can access these data.

Decl.	Name	Type	Description
TEMP	OB81EVCLASS	BYTE	Error class/error identifier 39xx
TEMP	OB81FLTID	BYTE	Error code: b#16#21 = At least one backup battery of the CPU is exhausted ¹⁾ b#16#22 = No backup voltage in the CPU b#16#23 = Failure of the 24-V power supply in the CPU ¹⁾ b#16#31 = At least one backup battery of an expansion rack is exhausted ¹⁾ b#16#32 = Backup voltage not present in an expansion rack ¹⁾ b#16#33 = Failure of the 24-V power supply of an expansion rack ¹⁾
TEMP	OB81PRIORITY	BYTE	Priority class = 26/28
TEMP	OB81OBNUMBR	BYTE	81 = OB81
TEMP	OB81RESERVED1	BYTE	Reserved
TEMP	OB81RESERVED2	BYTE	Reserved
TEMP	OB81MDLADDR	INT	Reserved
TEMP	OB81RESERVED3	BYTE	Only relevant for error codes B#16#31, B#16#32, B#16#33
TEMP	OB81RESERVED4	BYTE	
TEMP	OB81RESERVED5	BYTE	
TEMP	OB81RESERVED6	BYTE	
TEMP	OB81DATETIME	DATEAND TIME	Date and time at which the OB was started
¹⁾ = Not with the S7-300.			

Sample Program for the Error OB81

The sample STL program shows how you can read the error code in OB81.

The program is structured as follows:

- The error code in OB81 (OB81FLTID) is read and compared with the value of the event "battery exhausted" (B#16#3921).
- If the error code corresponds to the code for "battery exhausted," the program jumps to the label Berr and activates the output *batteryerror*.
- If the error code does not correspond to the code for "battery exhausted," the program compares the code with the code for "battery failure".
- If the error code corresponds to the code for "battery failure," the program jumps to the label Berr and activates the output *batteryerror*. Otherwise the block is terminated.

AWL	Description
L B#16#21	// Compare event code "battery exhausted" // (B#16#21) with
L #OB81_FLT_ID	// the error code for OB81.
==I	// If the same (battery is exhausted), // jump to Berr.
JC Berr	
L B#16#22	// Compare event code "battery failure" // (b#16#22) with
==I	// the error code for OB81.
JC BF	// If the same, jump to Berr.
BEU	// No message about battery failure
Berr: L B#16#39	// Compare the ID for the next event with
L #OB81_EV_CLASS	// the error code for OB81.
==I	// If a battery failure or an exhausted battery // is found,
S batteryerror	// set the output "battery error." // (Variable from the symbol table)
L B#16#38	// Compare the ID for the concluding event with
==I	// the error code for OB81.
R batteryerror	// reset the output "battery error, when // the error is fixed.

You can find detailed information on OBs, SFBs, and SFCs, as well as an explanation of event IDs, in the corresponding Help on Blocks.

Decl.	Name	Type	Description
TEMP	OB122EVCLASS	BYTE	Error class/error ID 29xx
TEMP	OB122SWFLT	BYTE	Error code: 16#42, 16#43, 16#44 ¹⁾ , 16#45 ¹⁾
TEMP	OB122PRIORITY	BYTE	Priority class = priority of the OB in which the error occurred
TEMP	OB122OBNUMBR	BYTE	122 = OB122
TEMP	OB122BLKTYPE	BYTE	Block type in which the error occurred
TEMP	OB122MEMAREA	BYTE	Memory area and type of access
TEMP	OB122MEMADDR	WORD	Address in the memory at which the error occurred
TEMP	OB122BLKNUM	WORD	Number of the block in which the error occurred
TEMP	OB122PRGADDR	WORD	Relative address of the instruction that caused the error
TEMP	OB122DATETIME	DATEANDTIME	Date and time at which the OB was started
TEMP	Error	INT	Saves the error code of SFC44

¹⁾ Not with the S7-300.

STL	Description
<pre> L B#16#2942 L #OB122SWFLT ==I JC Aerr L B#16#2943 <> I JC Stop </pre>	<p>Compare the event code of OB122 with the event code (B#16#2942) for the acknowledgement of a time error when reading the I/O. If the same, jump to "Aerr".</p> <p>Compare the event code of OB122 with the event code (B#16#2943) for an addressing error (writing to a module that does not exist). If not the same, jump to "Stop."</p>
<pre> Aerr: CALL "REPL_VAL" VAL := DW#16#2912 RETVAL := #Error L #Error L 0 ==I BEC </pre>	<p>Label "Aerr": transfers DW#16#2912 (binary 10010) to SFC44 (REPL_VAL). SFC44 loads this value in accumulator 1 (and substitutes the value that triggered the OB122 call). The SFC error code is saved in #Error.</p> <p>Compare #Error with 0 (if the same, no error occurred when executing OB122). End the block if no error occurred.</p>
<pre> Stop: CALL "STP" </pre>	<p>"Stop" label: calls SFC46 "STP" and changes the CPU to STOP mode.</p>

23.9.4 I/O Redundancy Error (OB70)

Description

The operating system of a H CPU calls OB70 if a loss of redundancy occurs on the PROFIBUS DP (for example, if there is a bus failure on the active DP master or an error in the DP slave interface module) or if the active DP master changes from DP slaves with switched I/Os.

Programming OB70

You must create OB70 as an object in your S7 program using STEP 7. Write the program to be executed in OB70 in the generated block and download it to the CPU as part of your user program.

You can use OB70, for example, for the following purposes:

- To evaluate the start information of OB70 and determine which event triggered the loss of I/O redundancy.
- To determine the status of your system using SFC51 RDSYSST (SZLID=B#16#71).

The CPU does not change to STOP mode if an I/O redundancy error occurs and OB70 is not programmed.

If OB70 is downloaded and the H system is not in redundant mode, OB70 is processed in both CPUs. The H system remains in redundant mode.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.5 CPU Redundancy Error (OB72)

Description

The operating system of the H CPU calls OB72 if one of the following events occurs:

- Loss of redundancy on the CPUs
- Comparison error (for example, RAM, PIQ)
- Standby-master switchover
- Synchronization error
- Error in a SYNC submodule
- Update process aborted
- OB72 is executed by all CPUs which are in RUN mode or STARTUP mode after an accompanying start event.

Programming OB72

You must create OB72 as an object in your S7 program using STEP 7. Write the program to be executed in OB72 in the generated block and download it to the CPU as part of your user program.

You can use OB72, for example, for the following purposes:

- To evaluate the start information of OB72 and determine which event triggered the loss of CPU redundancy.
- To determine the status of your system using SFC51 RDSYSST (SZLID=B#16#71).
- To react to the loss of CPU redundancy specifically for the plant.

The CPU does not change to STOP mode if a CPU redundancy error occurs and OB72 is not programmed.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.6 Time Error (OB80)

Description

The operating system of the CPU calls OB80 when a time error occurs. Time errors include the following, for example:

- Maximum cycle time exceeded
- Time-of-day interrupts skipped by moving the time forward
- Delay too great when processing a priority class

Programming OB80

You must create OB80 as an object in your S7 program using STEP 7. Write the program to be executed in OB80 in the generated block and download it to the CPU as part of your user program.

You can use OB80, for example, for the following purposes:

- To evaluate the start information of OB80 and to determine which time-of-day interrupts were skipped.
- By including SFC29 CANTINT, you can deactivate the skipped time-of-day interrupt so that it is not executed and only time-of-day interrupts relative to the new time will be executed.

If you do not deactivate skipped time-of-day interrupts in OB80, the first skipped time-of-day interrupt is executed, all others are ignored.

If you do not program OB80, the CPU changes to STOP mode when a time error is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.7 Power Supply Error (OB81)

Description

The operating system of the CPU calls OB81 if one of the following fails in a CPU or an expansion unit

- The 24-V voltage supply
- A battery
- The complete backup

This OB is also called when the problem has been eliminated (the OB is called when an event comes and goes).

Programming OB81

You must create OB81 as an object in your S7 program using STEP 7. Write the program to be executed in OB81 in the generated block and download it to the CPU as part of your user program.

You can, for example, use OB81 for the following purposes:

- To evaluate the start information of OB81 and determine which power supply error has occurred.
- To find out the number of the rack with the defective power supply.
- To activate a lamp on an operator station to indicate that maintenance personnel should replace a battery.

If you do not program OB81, the CPU does not change to STOP mode if a power supply error is detected. The error is, however, entered in the diagnostic buffer and the corresponding LED on the front panel indicates the error.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.8 Diagnostic Interrupt (OB82)

Description

The operating system of the CPU calls OB82 when a module with diagnostics capability on which you have enabled the diagnostic interrupt detects an error and when the error is eliminated (the OB is called when the event comes and goes).

Programming OB82

You must create OB82 as an object in your S7 program using STEP 7. Write the program to be executed in OB82 in the generated block and download it to the CPU as part of your user program.

You can, for example, use OB82 for the following purposes:

- To evaluate the start information of OB82.
- To obtain exact diagnostic information about the error that has occurred.

When a diagnostic interrupt is triggered, the module on which the problem has occurred automatically enters 4 bytes of diagnostic data and their start address in the start information of the diagnostic interrupt OB and in the diagnostic buffer. This provides you with information about when an error occurred and on which module.

With a suitable program in OB82, you can evaluate further diagnostic data for the module (which channel the error occurred on, which error has occurred). Using SFC51 RDSYSST, you can read out the module diagnostic data and enter this information in the diagnostic buffer with SFC52 WRUSRMSG. You can also send a user-defined diagnostic message to a monitoring device.

If you do not program OB82, the CPU changes to STOP mode when a diagnostic interrupt is triggered.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.9 Insert/Remove Module Interrupt (OB83)

Description

S7-400 CPUs monitor the presence of modules in the central rack and expansion racks at intervals of approximately 1 second.

After the power supply is turned on, the CPU checks whether all the modules listed in the configuration table created with STEP 7 are actually inserted. If all the modules are present, the actual configuration is saved and is used as a reference value for cyclic monitoring of the modules. In each scan cycle, the newly detected actual configuration is compared with the previous actual configuration. If there are discrepancies between the configurations, an insert/remove module interrupt is signaled and an entry is made in the diagnostic buffer and the system status list. In RUN mode, the insert/remove module interrupt OB is started.

Note

Power supply modules, CPUs, and IMs must not be removed in RUN mode.

Between removing and inserting a module, at least two seconds must be allowed to pass so that the CPU can detect that a module has been removed or inserted.

Assigning Parameters to a Newly Inserted Module

If a module is inserted in RUN mode, the CPU checks whether the module type of the new module matches the original module. If they match, the module is assigned parameters. Either the default parameters or the parameters you assigned with STEP 7 are transferred to the module.

Programming OB83

You must create OB83 as an object in your S7 program using STEP 7. Write the program to be executed in OB83 in the generated block and download it to the CPU as part of your user program.

You can use OB83, for example, for the following purposes:

- To evaluate the start information of OB83.
- By including system functions SFC55 to 59, to assign parameters to a newly inserted module.

If you do not program OB83, the CPU changes from RUN to STOP when an insert/remove module interrupt occurs.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.10 CPU Hardware Fault (OB84)

Description

The operating system of the CPU calls OB84 when an error is detected on the interface to the MPI network, to the communication bus, or to the network card for the distributed I/Os; for example, if an incorrect signal level is detected on the line. The OB is also called when the error is eliminated (the OB is called when the event comes and goes).

Programming OB84

You must create OB84 as an object in your S7 program using STEP 7. Write the program to be executed in OB84 in the generated block and download it to the CPU as part of your user program.

You can use OB84, for example, for the following purposes:

- To evaluate the start information of OB84.
- By including system function SFC52 WRUSMSG to send a message to the diagnostic buffer.

If you do not program OB84, the CPU changes to STOP mode when a CPU hardware fault is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.11 Program Sequence Error (OB85)

Description

The operating system of the CPU calls OB85:

- When a start event for an interrupt OB exists but the OB cannot be executed because it has not been downloaded to the CPU.
- When an error occurs accessing the instance data block of a system function block.
- When an error occurs updating the process image table (module does not exist or defective).

Programming OB85

You must create OB85 as an object in your S7 program using STEP 7. Write the program to be executed in OB85 in the generated block and download it to the CPU as part of your user program.

You can use OB85, for example, for the following purposes:

- To evaluate the start information of OB85 and determine which module is defective or not inserted (the module start address is specified).
- By including SFC49 LGCGADR to find out the slot of the module involved.

If you do not program OB85, the CPU changes to STOP mode when a priority class error is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.12 Rack Failure (OB86)

Description

The operating system of the CPU calls OB86 when it has detected one of the following events:

- Failure of a central expansion rack (not for S7-300) such as a broken connecting line, distributed power failure on a rack
- Failure of a master system or a slave (PROFIBUS DP) or failure of an IO system or an IO device (PROFINET IO)

OB86 is also called when the error is eliminated (the OB is called when the event comes and goes).

Programming OB86

You must create OB86 as an object in your S7 program using STEP 7. Write the program to be executed in OB86 in the generated block and download it to the CPU as part of your user program.

You can use OB86, for example, for the following purposes:

- To evaluate the start information of OB86 and determine which rack is defective or missing.
- To enter a message in the diagnostic buffer with system function SFC 52 WRUSMSG and to send the message to a monitoring device.

If you do not program OB86, the CPU changes to STOP mode when a rack failure is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.13 Communication Error (OB87)

Description

The operating system of the CPU calls OB87 when a communication error occurs in data exchange using communication function blocks or in global data communication, for example:

- When receiving global data, an incorrect frame ID was detected
- The data block for the status information of the global data does not exist or is too short.

Programming OB87

You must create OB87 as an object in your S7 program using STEP 7. Write the program to be executed in OB87 in the generated block and download it to the CPU as part of your user program.

You can use OB87, for example, for the following purposes:

- To evaluate the start information of OB87.
- To create a data block if the data block for the status information of global data communication is missing.

The CPU does not change to "STOP" mode when a communication error is detected and OB87 is not programmed.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.14 Programming Error (OB121)

Description

The operating system of the CPU calls OB121 when a programming error occurs, for example:

- Addressed timers do not exist.
- A called block is not loaded.

Programming OB121

You must create OB121 as an object in your S7 program using STEP 7. Write the program to be executed in OB121 in the generated block and download it to the CPU as part of your user program.

You can use OB121, for example, for the following purposes:

- To evaluate the start information of OB121.
- To enter the cause of an error in a message data block.

If you do not program OB121, the CPU changes to STOP mode when a programming error is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

23.9.15 I/O Access Error (OB122)

Description

The operating system of the CPU calls OB122 when a STEP 7 instruction accesses an input or output of a signal module to which no module was assigned at the last warm restart, for example:

- Errors with direct I/O access (module defective or missing)
- Access to an I/O address that is not known to the CPU.

Programming OB122

You must create OB122 as an object in your S7 program using STEP 7. Write the program to be executed in OB122 in the generated block and download it to the CPU as part of your user program.

You can use OB122, for example, for the following purposes:

- To evaluate the start information of OB122
- To call the system function SFC 44 and supply a substitute value for an input module so that program execution can continue with a meaningful, process-dependent value.

If you do not program OB122, the CPU changes to STOP mode when an I/O access error is detected.

You can find detailed information on OBs, SFBs, and SFCs in the corresponding Help on Blocks.

24 Printing and Archiving

24.1 Printing Project Documentation

Once you have finished creating the program for your automation task, you can print out all the important data for project documentation purposes using the print functions integrated in STEP 7.

Parts of the Project You Can Print

You can print the contents of objects both directly from the SIMATIC Manager and by opening the respective object and starting the print procedure.

The following parts of a project can be printed directly via the SIMATIC Manager:

- Object tree (structure of the project/library)
- Object lists (contents of an object folder)
- Object contents
- Messages

By opening the respective object, the following parts of a project can be printed:

- Blocks in Ladder Logic, Statement List, or Function Block Diagram representation or in other languages (optional software)
- Symbol table with the symbolic names for absolute addresses
- Configuration table with the arrangement of modules in the programmable controller and the module parameters
- Diagnostic buffer content
- Variable table with monitor formats, and monitor and modify values
- Reference data; such as cross-reference lists, assignment lists, program structures, lists of unused addresses, lists of addresses without symbols
- Global data table
- Module information with the module status
- Operator related texts (user texts and text libraries)
- Documents from optional packages such as other programming languages

DOCPRO Optional Package

To create, edit, and print standardized wiring manuals you can use the optional software package DOCPRO. This creates plant documentation that fulfils the DIN and ANSI standards.

24.1.1 Basic Procedure when Printing

To print, proceed as follows:

1. Open the appropriate object to display the information you want to print on the screen.
2. Open the "Print" dialog box using the menu command **File > Print** in the application window. Depending on which application you are in, the first entry in the menu bar may not be "File", but the object processed by the application, such as "Symbol Table."
3. If necessary, change the print options (printer, print range, number of copies etc.) in the dialog box and close it.

Some dialog boxes have a "Print" button, for example, the "Module Information" dialog box. Click this button to print the contents of the dialog box.

Blocks do not need to be opened. You can print them directly in the SIMATIC Manager using the menu command **File > Print**.

24.1.2 Print Functions

The following additional functions are available for printing print objects:

Print Objects	Menu Command	Function	Function	Function
		Print preview	Page setup, "Paper format" tab	Page setup, "Headers and Footers" tab
Blocks, STL source files	File > *	•	•	•
Module information		–	•	•
Global data table	GD Table > *	•	•	•
Configuration table	Station > *	•	•	•
Object, object folder	File > *	–	•	•
Reference data	Reference Data > *	•	•	•
Symbol table	Table > *	•	•	•
Variable table	Table > *	–	•	•
Connection table	Network > *	•	•	•
Operator related texts (user texts, text libraries)	Texts > *	•	•	•
* : The * symbol serves as a wildcard for the respective function in the menu command (e.g. print preview or page setup)				

Step-for-step instructions for printing the individual print objects can be found under:

How to Print.

Print Preview

You can use the "Print Preview" function to display the page layout of the document to be printed.

Note

The print format of the finished document is not displayed in the print preview.

Setting the Page Format and the Headers and Footers

You can set the paper size (such as A4, A5, Letter) and the page format and the orientation (portrait or landscape) for all documents that you want to print with the **File > Page Setup** menu command. In addition, you can select whether the settings should apply to the entire project only for the current session.

Adjust the layout of the document so that it matches the required paper format. If the document is too wide, the right-hand margin will be printed on a consecutive page.

If you select a page format with a margin (for example, A4 margin), the printed document has a margin on the left of the page that you can use to punch holes for binding.

To set headers and footers for the documents you want to print throughout the project or only for the current session, go to the "Labeling Fields" tab.

24.1.3 Special Note on Printing the Object Tree

In the "Print Object List" dialog box, in addition to the object list you can also print the object tree by selecting the option "Tree window."

If you select the option "All" under "Print range," the whole tree structure is printed. If you select the option button "Selection," the tree structure from the selected object downwards is printed.

Note

The settings made in the dialog box apply only to printing the list or tree and not for printing the contents of the objects; the settings in the relevant applications are used for this.

24.2 Archiving Projects and Libraries

You can store individual projects or libraries in compressed form in an archive file. This compressed storage procedure is possible on a hard disk or on a portable data medium (such as a floppy disk).

Archive Programs

In STEP 7, you can use the archive program of your choice. The archiving programs ARJ and PKZIP 4.0 are included as a part of the STEP 7 package. These programs and their descriptions are located in the installation path in the folder ...\\Step7\\S7bin\\.

You will require the following versions if you use one of the archive programs below (or a newer version):

- PKZip Commandline V4.0 (included with STEP 7)
- WinZip from version 6.0
- JAR from version 1.02
- ARJ V2.4.1a (only for retrieving archives, included with STEP 7)
- ARJ32 V3.x (only for retrieving archives)
- LHArc from version 2.13 (only for retrieving archives)

Special Issues

As of STEP 7 V5.2, only the archiving programs PKZip 4.0, JAR, WinZip are supported. However, the other programs listed above are supported for retrieval.

If, in earlier versions of STEP 7, the program ARJ32 V3.x was used to create archives, then these archives can only be retrieved with this same program.

Creating an archive with PKZIP V4.0 will take substantially more time on network drives than on local drives.

24.2.1 Uses for Saving/Archiving

Save As

With this function you create a **copy** of the project under another name.

You can use this function:

- To create backup copies
- To duplicate an existing project in order to adapt it for other purposes.

To use the fastest method of creating a copy, select the "Save As" option without rearranging in the dialog box. The whole file structure from the project directory down is copied without a check and saved under another name.

There must be sufficient space on the data medium to store the backup copy. Do not attempt to save projects to diskette as there will not generally be sufficient space available. To transport project data on diskette use the "Archive" function.

Saving with rearranging takes longer, but a message is displayed if an object cannot be copied and saved. Causes for this may be a missing optional package or defective data for an object.

Archive

You can store individual projects or libraries in compressed form in an archive file. This compressed storage procedure is possible on a hard disk or on a portable data medium (such as a floppy disk).

Only transport projects on diskette in the form of archive files. If the project is too large, select an archive program with which disk-crossing archives can be created.

Projects or libraries which were compressed into an archive file cannot be edited. If you want to edit them again you must unpack the data which means retrieving the project or library.

24.2.2 Requirements for Archiving

To archive a project or library, the following requirements must be fulfilled:

- You must have installed the archive program in your system. The link to STEP 7 is explained in the online help topic "Procedure for Archiving/Retrieving."
- All the data for the project without exception must be in the project directory or a subdirectory of the project. When working with the C development environment, it is possible to store data in other locations. These data would then not be included in the archive file.
- As of STEP 7 V5.2, only the archiving programs PKZip 4.0, JAR, WinZip are supported. However, for retrieval, the programs ARJ and LHArc are also supported.

24.2.3 Procedure for Archiving/Retrieving

You archive/retrieve your project or library using the menu command **File > Archive** or **File > Retrieve**.

Note

Projects or libraries which were compressed into an archive file cannot be edited. If you want to edit them again you must unpack the data which means retrieving the project or library.

When retrieving, the retrieved projects or libraries are automatically included in the project/library list.

Setting the Target Directory

To set the target directory, use the menu command **Options > Customize** in the SIMATIC Manager to open the "Customize" dialog box.

In the "Archive" tab of this dialog box you can switch the option "Check target directory on retrieval" on and off.

If this option is deactivated, the path set in the "General" tab of the same dialog box for "Storage location for projects" and "Storage location for libraries" is used as the target directory for retrieving.

Copying an Archive File to Diskette

You can archive a project/library and then copy the archive file to a diskette. It is also possible to select a floppy disk drive in the "Archive" dialog box as the target directory.

25 Working with M7 Programmable Control Systems

25.1 Procedure for M7 Systems

The standard PC architecture of the M7-300/M7-400 automation computer forms a freely programmable extension to the SIMATIC automation platform. You can program the user programs for SIMATIC M7 in a high-level language such as C or graphically using CFC (Continuous Function Chart).

To create the programs, you will also require the system software M7-SYS RT for M7-300/400 and a development environment for M7 programs (ProC/C++ or CFC) in addition to STEP 7.

Basic Procedure

When you create an automation solution with SIMATIC M7, there are a series of basic tasks. The following table shows the tasks that need to be performed for most projects and assigns them to a basic procedure. The table also gives references to the relevant chapter in this manual or other manuals.

Procedure	Description
Design automation solution	M7-specific; refer to: M7-SYS RT Programming Manual
Start STEP 7	As for S7
Create project structure Set up station Configure the hardware	As for S7
Configure communication connections	As for S7
Define symbol table	As for S7
Create C or CFC user program	M7-specific; refer to: ProC/C++
Configure operating system Install operating system on M7-300/M7-400 Download hardware configuration and user program to M7	M7-specific; refer to: M7-SYS RT User Manual
Test and debug user program	ProC/C++
Monitor operation and M7 diagnostics	As for S7, but without user-defined diagnostics
Printing and archiving	As for S7

What Is Different in M7?

For M7-300/M7-400, the following functions are not supported in STEP 7:

- Multicomputing - synchronous operation of several CPUs
- Force variables
- Global data communication
- User-defined diagnostics

Managing M7 Programmable Control Systems

STEP 7 offers you specific support with the following tasks on M7 programmable control systems:

- Installing an operating system on the M7-300/M7-400
- Configuring the operating system by editing system files
- Downloading user programs to the M7-300/M7-400
- Updating the firmware

To access M7 programmable control system management, select the following menu command from the context of a project that contains stations with M7 CPUs or FMs, with the M7 program folder selected:

PLC > Manage M7 System

You will find detailed instructions in the online help and user manual for M7-SYS RT.

25.2 Optional Software for M7 Programming

M7 Optional Software

STEP 7 provides you with the basic functions you require to do the following:

- Create and manage projects
- Configure and assign parameters to the hardware
- Configure networks and connections
- Manage symbol data

These functions are provided regardless of whether you are using a SIMATIC S7 or SIMATIC M7 programmable controller.


To create M7 applications, you will require the M7 optional software in addition to STEP 7.

Software	Content
M7-SYS RT	<ul style="list-style-type: none"> • M7 RMOS32 operating system • M7-API system library • Support for MPI
CFC for S7 and M7	Programming software for CFC (Continuous Function Chart) programs
M7-ProC/C++	<ul style="list-style-type: none"> • Link for the Borland development environment in STEP 7 • Symbol import editor and generator • Organon xdb386 high-level language debugging tool
Borland C++	Borland C/C++ development environment

In conjunction with the M7 optional software, STEP 7 can also support the following additional tasks:

- Downloading data to the M7 programmable control system via the multipoint interface (MPI)
- Requesting information about the M7 programmable control system
- Making particular settings on the M7 programmable control system and resetting the M7

The following figure shows the dependencies of the M7 optional software for M7 programming.



Summary

To create...	You will require the M7 software option...
C/C++ programs	2e M7-SYS RT 3e M7-ProC/C++ 4th Borland C++
CFC programs	1st M7-SYS RT 2nd CFC for S7 and M7 3rd Borland C++

Which Software Offers Which Type of Support?

The specific tools required to create M7 applications are partly integrated in STEP 7 and partly in the M7 software options.

The following table shows you which software package supports which tasks:

Software	Support Offered
STEP 7	<ul style="list-style-type: none"> • Installing the M7 operating system • Managing the M7 programmable control system • Downloading, starting, and deleting the M7 programs • Displaying status and diagnostic data • Resetting the CPU
M7-SYS RT	<p>The M7 operating system and M7 system software utilities help with the following:</p> <ul style="list-style-type: none"> • Controlling program processing • Managing memory and resources • Access to computer hardware and SIMATIC hardware • Handling interrupts • Diagnostics • Status monitoring • Communication
M7-ProC/C++	<ul style="list-style-type: none"> • By integrated code creation (integrating the Borland development environment into STEP 7) • By linking project symbols into the source code • By integrated debugging functions
Borland C++	<ul style="list-style-type: none"> • Creating C and C++ programs
CFC for S7 and M7	<ul style="list-style-type: none"> • Creating, testing, and debugging CFC programs • Starting and running CFC programs

25.3 M7-300/M7-400 Operating Systems

The utilities offered by the operating system are of prime importance for applications created using the high-level languages C and C++. The operating system takes on the following tasks for the application:

- Accessing the hardware
- Managing resources
- System integration
- Communication with other components in the system

To solve automation tasks, the M7 RMOS32 (**R**ealtime **M**ultitasking **O**perating **S**ystem) real-time operating system is used with the SIMATIC M7 automation computer. M7 RMOS32 has been extended to include a call interface, the M7 API (**A**pplication **P**rogramming **I**nterface) to integrate it into the SIMATIC system.

The real-time operating system M7 RMOS32 is used for 32-bit applications in time-critical, real-time, and multitasking solutions. It is available in the following configurations for M7 modules:

- M7 RMOS32
- M7 RMOS32 with MS-DOS

The operating system configuration you choose for your M7 programmable control system depends on the M7 modules you are using:

Operating System Configuration	Module / Main Memory	PROFIBUS-DP and TCP/IP Yes/No	Installation on Mass Memory
M7 RMOS32	FM 356-4 / 4 MB FM 356-4 / 8 MB CPU 388-4 / 8 MB FM 456-4 / 16 MB CPU 488-3 / 16 MB CPU 486-3 / 16 MB	No Yes Yes Yes Yes Yes	Memory card \geq 4 MB or hard disk
M7 RMOS32 with MS-DOS	FM 356-4 / 8 MB CPU 388-4 / 8 MB FM 456-4 / 16 MB CPU 488-3 / 16 MB CPU 486-3 / 16 MB	No No Yes Yes Yes	Memory card \geq 4 MB or hard disk

26 Tips and Tricks

26.1 Exchanging Modules in the Configuration Table

If you using HW Config to revise a station configuration and you want to exchange a module for one with a new order number for example, proceed as follows:

1. Use a drag-and-drop operation to drag the module from the Hardware Catalog window over the old module that is already placed.
2. Drop the new module. To the extent possible, the new module assumes the parameters of the one that was already inserted.

This procedure is faster than exchanging modules by deleting the old module and then inserting the new one and assigning parameters to it.

You can turn this function on or off in HW Config by means of the menu command **Options > Settings** ("Enable Module Swapping")

26.2 Projects with a Large Number of Networked Stations

If you configure all stations one after the other and then call NetPro by means of the menu command **Options > Configure Network** in order to configure connections, the stations are placed in the network view automatically. This procedure has the disadvantage that you then have to arrange the stations and subnets according to topological criteria later.

If your project includes a large number of networked stations and you want to configure connections between these stations, you should configure the system structure in the network view from the beginning to preserve the overview:

1. Create the new project in the SIMATIC Manager (menu command **File > New**).
2. Start NetPro (menu command **Options > Configure Network**)
3. Create in NetPro station for station as follows:
 - Use a drag-and-drop operation to place the station from the Catalog window.
 - Double-click the station to start HW Config.
 - Use a drag-and-drop operation to place the modules with communication capability (CPUs, CPs, FMs, IF modules) in HW Config.
 - If you want to network these modules, double-click on the corresponding rows in the configuration table to create new subnets and to network the interfaces.
 - Save the configuration and switch to NetPro.
 - In NetPro, position stations and subnets (move objects with the mouse until you have reached the position you want)
4. Configure the connections in NetPro and correct the networking where necessary.

26.3 Rearranging

If unexplained problems occur when working with STEP 7, it often helps to rearrange the database of the project or library.

Select the menu command **File > Rearrange** to do this. This removes any gaps which occur when contents are deleted, meaning that the amount of memory required for the project/library data is reduced.

The function optimizes the data storage for the project or library in a similar way to which a program defragments a hard disk also optimizes file storage on the hard disk.

The duration of the reorganization process depends on the amount of data to be moved around and may take some time. The function is therefore not executed automatically (for example, when you close a project) but must be triggered by the user when he/she wants to rearrange the project or library.

Requirement

Projects and libraries can only be rearranged if no objects in them are being edited by other applications and therefore locked for access.

26.4 Editing Symbols Across Multiple Networks

The LAD/STL/FBD program editor lets you view and edit the symbols of multiple networks.

1. Select a network name with a click on the network name (e.g. "Network 1").
2. Hold down the CTRL key and add further networks to your selection.
3. Right-click to call the context-sensitive menu command **Edit Symbols**.

Use the shortcut CTRL+A to select all networks of a block and then highlight a network name.

26.5 Testing with the Variable Table

For monitoring and modifying variables in the variable table, note the following editing tips:

- You can enter symbols and addresses in both the "Symbol" column as well as the "Address" column. The entry is written into the appropriate column automatically.
- To display the modified value, you should set the trigger point for "Monitoring" to "Beginning of Scan Cycle" and the trigger point for Modifying" to "End of Scan Cycle."
- If you place the cursor in a row that is marked with red, a brief information is displayed telling you the cause of the error. Press F1 to get suggestions for eliminating the error.
- You can enter only those symbols that are already defined in the symbol table. You must enter a symbol exactly as it is defined in the symbol table. Symbol names that contain special characters must be enclosed in quotation marks (for example, "Motor.Off," "Motor+Off," "Motor-Off").
- Warnings can be switched off in the "Online" tab ("Customize" dialog box).
- The connection can be changed without having previously disconnected the connection.
- The monitoring trigger can be defined while monitoring variables.
- You can modify selected variables by selecting the rows and executing the "Force" function. Only the highlighted variables are modified.
- Exiting without Confirmation:
If you press the ESC key while "Monitoring," "Modifying" "Release PQ," "Monitoring" and "Modifying" are terminated without asking if you want to exit.
- Entering a Contiguous Address Range:
Use the menu command **Insert > Range of Variables**.
- Displaying and Hiding Columns:
Use the following menu commands to display or hide individual columns:
Symbol: **View > Symbol**
Symbol comment: **View > Symbol Comment**
Presentation format of the status value: **View > Display Format**
Status value of the variables: **View > Status Value**
Modify value of the variables: **View > Modify Value**
- Changing the display format of several rows of the table at the same time:
 1. Select the area of the table in which you want to change the display format by holding the left mouse button down and dragging across the desired table area.
 2. Select the presentation with the menu command **View > Select Display Format**. The format is changed only for those rows of the selected table for which a format change is permitted.
- Input examples by means of the F1 key:
 - If you place the cursor in the address column and you press F1, you will get examples for address inputs.
 - If you place the cursor in the modify value column and you press F1, you will get examples for modify/force value inputs.

26.6 Modifying Variables With the Program Editor

In the program editor, you can program buttons for binary inputs and memory bits that offer you a quick and easy way to modify these addresses with mouse click.

Requirements

- In the symbol table, you have assigned this property to the address you want to modify via the menu command **Special Object Properties > Control at Contact**
- You have selected the "Control at Contact" option in the "General" tab of the LAD/STL/FBD program editor (Menu command **Options > Customize**).
- You have selected the menu command **Debug > Monitor**.

Triggering condition is here "permanent/at the cycle start".

The inputs actually available in your plant will be monitored for as long as you keep the button pressed. You can also modify multiple inputs via multiple selection (CTRL key).

In the case of bit memories or unavailable inputs, pressing the button will cause the status to be set to 1. The status will only be reset to 0 if this is explicitly requested through a context menu entry or in the variable table, or if the address is reset by the STEP 7 program.

In the case of a non-negated input or bit memory, pressing the button will cause the modify value "1" to apply; in the case of a negated input or bit memory, the modify value "0" will apply.

Note on WinCC

If you have started the program editor in WinCC via the operator control and monitoring of a variable, only the control options of WinCC are allowed. Otherwise, if the operator has been granted "Maintenance rights" of WinCC, both modify options are allowed.

Editing the "Control at Contact" Attribute

26.7 Virtual Work Memory

Another reason for problems occurring in STEP 7 may be insufficient virtual work memory.

To work with STEP 7 you should adjust the setting for the virtual memory. Proceed as follows:

1. Open the Control Panel, for example, via the Start menu **Start > Settings > Control Panel** and double-click on the icon "System".
XP only: Open under **START > Desktop > Properties > Advanced > System Performance > Settings**.
2. In Windows 2000, select the "Advanced" tab and click on the "System Performance Options" button.
Under Windows XP/Server 2003, select the "Advanced" tab in the "System settings" dialog box.
3. Click the "Change" button.
4. Enter at least 40 Mbytes as the "Minimum" and at least 150 Mbytes as the "Maximum."

Note

As the virtual memory is on the hard disk (default C:) and dynamic, you should ensure that sufficient memory is available for the directory TMP or TEMP (approx. 20 to 30 Mbytes):

- If the S7 project is also on the same partition on which the virtual memory is set, approximately twice the size of the S7 project should be available as free memory space.
 - If the project is stored on another partition, this requirement becomes irrelevant.
-

A Appendix

A.1 Operating Modes

A.1.1 Operating Modes and Mode Transitions

Operating Modes

Operating modes describe the behavior of the CPU at a particular point in time. Knowing the operating modes of CPUs is useful when programming the startup, testing the controller, and for troubleshooting.

The S7-300 and S7-400 CPUs can adopt the following operating modes:

- STOP
- STARTUP
- RUN
- HOLD

In STOP mode, the CPU checks whether all the configured modules or modules set by the default addressing actually exist and sets the I/Os to a predefined initial status. The user program is not executed in STOP mode.

In STARTUP mode, a distinction is made between the startup types "warm restart," "cold restart," and "hot restart:"

- In a warm restart, program processing starts at the beginning of the program with initial settings for the system data and user address areas (the non-retentive timers, counters, and bit memory are reset).
- In a cold restart, the process-image input table is read in and the STEP 7 user program is processed starting at the first command in OB1 (also applies to warm restart).
 - Any data blocks created by SFC in the work memory are deleted; the remaining data blocks have the preset value from the load memory.
 - The process image and all timers, counters, and bit memory are reset, regardless of whether they were assigned as retentive or not.

- In a hot restart, the program is resumed at the point at which it was interrupted (timers, counters, and bit memory are not reset). A hot restart is only possible on S7-400 CPUs.

In RUN mode, the CPU executes the user program, updates the inputs and outputs, services interrupts, and process error messages.

In HOLD mode, processing of the user program is halted and you can test the user program step by step. The HOLD mode is only possible when you are testing using the programming device.

In all these modes, the CPU can communicate via the multipoint interface (MPI).


Other Operating Modes

If the CPU is not ready for operation, it is in one of the following modes:

- Off, in other words, the power supply is turned off.
- Defective, in other words, a fault has occurred.
To check whether the CPU is really defective, switch the CPU to STOP and turn the power switch off and then on again. If the CPU starts up, display the diagnostic buffer to analyze the problem. If the CPU does not start up it must be replaced.

Operating Mode Transitions

The following figure shows the operating modes and mode transitions for S7-300 and S7-400 CPUs:



The table shows the conditions under which the operating modes can change.

Transition	Description
1.	After you turn on the power supply, the CPU is in STOP mode.
2.	The CPU changes to STARTUP mode: <ul style="list-style-type: none"> • After the CPU is changed to RUN or RUN-P using the key switch or by the programming device. • After a startup triggered automatically by turning on the power. • If the RESUME or START communication function is executed. In both cases the key switch must be set to RUN or RUN-P.

Transition	Description
3.	The CPU changes back to STOP mode when: <ul style="list-style-type: none"> • An error is detected during the startup. • The CPU is changed to STOP by the key switch or on the programming device. • A stop command is executed in the startup OB. • The STOP communication function is executed.
4.	The CPU changes to HOLD mode when a breakpoint is reached in the startup program.
5.	The CPU changes to STARTUP mode when the breakpoint in a startup program was set and the "EXIT HOLD" command was executed (test functions).
6.	The CPU changes back to STOP mode when: <ul style="list-style-type: none"> • The CPU is changed to STOP with the key switch or by the programming device. • The STOP communication command is executed.
7.	If the startup is successful, the CPU changes to RUN.
8.	The CPU changes back to STOP mode when: <ul style="list-style-type: none"> • An error is detected in RUN mode and the corresponding OB is not loaded. • The CPU is changed to STOP by the key switch or on the programming device. • A stop command is edited in the user program. • The STOP communication function is executed.
9.	The CPU changes to HOLD mode when a breakpoint is reached in the user program.
10.	The CPU changes to RUN mode when a breakpoint was set and the "EXIT HOLD" command is executed.

Operating Mode Priority

If a number of operating mode transitions are requested simultaneously, the operating mode with the highest priority is selected. If, for example, the mode selector is set to RUN and you attempt to set the CPU to STOP at the programming device, the CPU will change to STOP because this mode has the highest priority.

Priority	Mode
Highest	STOP
	HOLD
	STARTUP
Lowest	RUN

A.1.2 STOP Mode

The user program is not executed in STOP mode. All the outputs are set to substitute values so that the controlled process is in a safe state. The CPU makes the following checks:

- Are there any hardware problems(for example, modules not available)?
- Should the default setting apply to the CPU or are there parameter sets?
- Are the conditions for the programmed startup behavior satisfied?
- Are there any system software problems?

In STOP mode, the CPU can also receive global data and passive one-way communication is possible using communication SFBs for configured connections and communication SFCs for not configured connections.

Memory Reset

The CPU memory can be reset in STOP mode. The memory can be reset manually using the key switch (MRES) or from the programming device (for example, before downloading a user program).

Resetting the CPU memory returns the CPU to its initial status, as follows:

- The entire user program in the work memory and in the RAM load memory and all address areas are cleared.
- The system parameters and the CPU and module parameters are reset to the default settings. The MPI parameters set prior to the memory reset are retained.
- If a memory card (Flash EPROM) is plugged in, the CPU copies the user program from the memory card to the work memory (including the CPU and module parameters if the appropriate configuration data are also on the memory card).

The diagnostic buffer, the MPI parameters, the time, and the runtime meters are not reset.

A.1.3 STARTUP Mode

Before the CPU can start processing the user program, a startup program must first be executed. By programming startup OBs in your startup program, you can specify certain settings for your cyclic program.

There are three types of startup: warm restart, cold restart, and hot restart. A hot restart is only possible on S7-400 CPUs. This must be set explicitly in the parameter set for the CPU using STEP 7.

The features of the STARTUP mode are as follows:

- The program in the startup OB is processed (OB100 for warm restart, OB101 for hot restart, OB102 for cold restart).
- No time-driven or interrupt driven program execution is possible.
- Timers are updated.
- Runtime meters start running.
- Disabled digital outputs on signal modules (can be set by direct access).

Warm Restart

A warm restart is always permitted unless the system has requested a memory reset. A warm restart is the only possible option after:

- Memory reset
- Downloading the user program with the CPU in STOP mode
- I stack/B stack overflow
- Warm restart aborted (due to a power outage or changing the mode selector setting)
- When the interruption before a hot restart exceeds the selected time limit.

Manual Warm Restart

A manual warm restart can be triggered by the following:

- The mode selector
(the CRST/WRST switch - if available - must be set to CRST)
- The corresponding command on the programming device or by communication functions
(if the mode selector is set to RUN or RUN-P)

Automatic Warm Restart

An automatic warm restart can be triggered following power up in the following situations:

- The CPU was not in STOP mode when the power outage occurred.
- The mode selector is set to RUN or RUN-P.
- No automatic hot restart is programmed following power up.
- The CPU was interrupted by a power outage during a warm restart (regardless of the programmed type of restart).

The CRST/WRST switch has no effect on an automatic warm restart.

Automatic Warm Restart Without a Backup Battery

If you operate your CPU without a backup battery (if maintenance-free operation is necessary), the CPU memory is automatically reset and a warm restart executed after the power is turned on or when power returns following a power outage. The user program must be located on a flash EPROM (memory card).

Hot Restart

Following a power outage in RUN mode followed by a return of power, S7-400 CPUs run through an initialization routine and then automatically execute a hot restart. During a hot restart, the user program is resumed at the point at which its execution was interrupted. The section of user program that had not been executed before the power outage is known as the remaining cycle. The remaining cycle can also contain time-driven and interrupt driven program sections.

A hot restart is only permitted when the user program was not modified in STOP mode (for example, by reloading a modified block) and when there are no other reasons for a warm restart. Both a manual and automatic hot restart are possible.

Manual Hot Restart

A manual hot restart is only possible with the appropriate parameter settings in the parameter set of the CPU and when the STOP resulted from the following causes:

- The mode selector was changed from RUN to STOP.
- User-programmed STOPs, STOPs after calling OBs that are not loaded.
- The STOP mode was the result of a command from the programming device or a communication function.

A manual hot restart can be triggered by the following:

- The mode selector

The CRST/WRST must be set to WRST.

- The corresponding command on the programming device or by communication functions (mode selector set to RUN or RUN-P).
- When a manual hot restart is set in the parameter set of the CPU.

Automatic Hot Restart

An automatic hot restart can be triggered following power up in the following situations:

- The CPU was not in STOP or HOLD mode when the power outage occurred.
- The mode selector is set to RUN or RUN-P.
- Automatic hot restart following power up is set in the parameter set of the CPU.

The CRST/WRST switch has no effect on an automatic hot restart.

Retentive Data Areas Following Power Down

S7-300 and S7-400 CPUs react differently to power up following a power outage.

S7-300 CPUs (with the exception of the CPU 318) are only capable of a warm restart. With STEP 7, you can, however, specify memory bits, timers, counters, and areas in data blocks as retentive to avoid data loss caused by a power outage. When the power returns, an automatic warm restart with memory is executed.

S7-400 CPUs react to the return of power depending on the parameter settings either with a warm restart (following retentive or non-retentive power on) or a hot restart (only possible following retentive power on).

The following table shows the data that are retained on S7-300 and S7-400 CPUs during a warm restart, cold restart, or hot restart.

X	means	data retained
VC	means	logic block retained in EPROM, any overloaded logic blocks are lost
VX	means	data block is retained only if on the EPROM retentive data are taken from the NV-RAM (loaded or created data blocks in the RAM are lost)
0	means	data are reset or erased (content of DBs)
V	means	data are set to the initialization value taken from the EPROM memory
---	means	not possible as no NV-RAM available

The following table shows the data that are retained on work memory (EPROM and RAM load memory):

			EPROM	(Memory	Card	or	Integrated)		
	CPU	with	Backup	Battery		CPU	without	Backup	Battery
Data	Blocks in load memory	DB in work memory	Memory bits, timers, counters	Memory bits, timers, counters	Blocks in load memory	DB in work memory	DB in work memory	Memory bits, timers, counters	Memory bits, timers, counters
			(defined as retentive)	(defined as volatile)		(defined as retentive)	(defined as volatile)	(defined as retentive)	(defined as volatile)
Warm restart on S7-300	X	X	X	0	VC	VX	V	X	0
Warm restart on S7-400	X	X	X	0	VC	---	V	0	0
Cold restart on S7-300	X	0	0	0	VC	V	V	0	0
Cold restart on S7-400	X	0	0	0	VC	---	V	0	0
Hot restart on S7-400	X	X	X	X		Only	warm restart	permitted	

Startup Activities

The following table shows which activities are performed by the CPU during startup:

Activities in Order of Execution	In Warm Restart	In Cold Restart	In Hot Restart
Clear I stack/B stack	X	X	0
Clear volatile memory bits, timers, counters	X	0	0
Clear all memory bits, timers, counters	0	X	0
Clear process-image output table	X	X	selectable
Reset outputs of digital signal modules	X	X	selectable
Discard hardware interrupts	X	X	0
Discard time-delay interrupts	x	x	0
Discard diagnostic interrupts	X	X	X
Update the system status list (SZL)	X	X	X
Evaluate module parameters and transfer to modules or transfer default values	X	X	X
Execution of the relevant startup OB	X	X	X
Execute remaining cycle (part of the user program not executed due to the power down)	0	0	X
Update the process-image input table	X	X	X
Enable digital outputs (cancel OD signal) after transition to RUN	X	X	X
X means is performed			
0 means is not performed			

Aborting a Startup

If an error occurs during startup, the startup is aborted and the CPU changes to or remains in STOP mode.

An aborted warm restart must be repeated. After an aborted restart, both a warm restart and a hot restart are possible.

A startup (restart (warm restart) or hot restart) is not executed or it is aborted in the following situations:


- The operating mode switch of the CPU is set to STOP.
- A memory reset is requested.
- A memory card with an application code that is not permitted for STEP 7 is plugged in (for example, STEP 5).
- More than one CPU is inserted in the single processor mode.
- If the user program contains an OB that the CPU does not recognize or that has been disabled.
- If, after power on, the CPU recognizes that not all the modules listed in the configuration table created with STEP 7 are actually inserted (difference between preset and actual parameter assignment not permitted).
- If errors occur when evaluating the module parameters.

A hot restart is not executed or it is aborted in the following situations:

- The CPU memory was reset (only a warm restart is possible after memory reset).
- The interruption time limit has been exceeded (this is the time between exiting RUN mode until the startup OB including the remaining cycle has been executed).
- The module configuration has been changed (for example module replaced).
- The parameter assignment only permits a warm restart.
- When blocks have been loaded, deleted, or modified while the CPU was in STOP mode.

Sequence of Activities

The following figure shows the activities of the CPU during STARTUP and RUN:



Key to the figure "Activities of the CPU during STARTUP and RUN"

1. All peripheral outputs are switched to a safe state (default value = 0) on the hardware side by the I/O modules. This switch takes place regardless of whether the user program employs the outputs inside the process-image area or outside of it.

If you are using signal modules that have substitute value capability, you can assign parameters to the behavior of the outputs, such as Keep Last Value.

2. Necessary for processing the remaining scan cycle.
3. A current process-image input table is also available to the interrupt OBs the first time that they are called up.
4. You can determine the status of the local and distributed peripheral outputs in the first scan cycle of the user program by taking the following steps:
 - Use output modules to which you can assign parameters to enable the output of substitute values or to keep the last value.
 - For a hot restart: activate the CPU startup parameter "Reset outputs during hot restart" in order to output a 0 (corresponds to the default setting).
 - Preset the outputs in the startup OB (OB100, OB101, OB102).
5. In S7-300 systems that are not backed up, only those DB areas that were configured as retentive are retained.

A.1.4 RUN Mode

In RUN mode, the CPU executes the cyclic, time-driven, and interrupt-driven program, as follows:

- The process image of the inputs is read in.
- The user program is executed.
- The process-image output table is output.

The active exchange of data between CPUs using global data communication (global data table) and using communication SFBs for configured connections and using communication SFCs for non-configured connections is only possible in RUN mode.

The following table shows an example of when data exchange is possible in different operating modes:

Type of Communication	Mode of CPU 1	Direction of Data Exchange	Mode of CPU 2
Global data communication	RUN	↔	RUN
	RUN	→	STOP/HOLD
	STOP	←	RUN
	STOP	X	STOP
	HOLD	X	STOP/HOLD
One-way communication with communication SFBs	RUN	→	RUN
	RUN	→	STOP/HOLD
Two-way with communication SFBs	RUN	↔	RUN
One-way communication with communication SFCs	RUN	→	RUN
	RUN	→	STOP/HOLD
Two-way with communication SFCs	RUN	↔	RUN
↔ means data exchange is possible in both directions → means data exchange is possible in only one direction X means data exchange is not possible			

A.1.5 HOLD Mode

The HOLD mode is a special mode. This is only used for test purposes during startup or in RUN mode. The HOLD mode means the following:


- All timers are frozen: timers and runtime meters are not processed, monitoring times are stopped, the basic clock pulses of the time-driven levels are stopped.
- The real-time clock runs.
- Outputs are not enabled but can be enabled explicitly for test purposes.
- Inputs and outputs can be set and reset.
- If a power outage occurs on a CPU with a backup battery while in HOLD mode, the CPU changes to stop when the power returns but does not execute an automatic hot restart or restart (warm restart). CPUs without battery backup execute an automatic restart (warm restart) when power returns.
- Global data can be received and passive one-way communication using communication SFBs for configured connections and communication SFCs for non-configured connections is possible (see also table in RUN Mode).

A.2 Memory Areas of S7 CPUs

A.2.1 Distribution of the Memory Areas

The memory of an S7 CPU can be divided into three areas (see figure below):

- The load memory is used for user programs without symbolic address assignments or comments (these remain in the memory of the programming device). The load memory can be either RAM or EPROM.
- Blocks that are not marked as required for startup will be stored only in the load memory.
- The work memory (integrated RAM) contains the parts of the S7 program relevant for running your program. The program is executed only in the work memory and system memory areas.
- The system memory (RAM) contains the memory elements provided by every CPU for the user program, such as the process-image input and output tables, bit memory, timers, and counters. The system memory also contains the block stack and interrupt stack.
- In addition to the areas above, the system memory of the CPU also provides temporary memory (local data stack) that contains temporary data for a block when it is called. This data only remains valid as long as the block is active.



A.2.2 Load Memory and Work Memory

When you download the user program from the programming device to the CPU, only the logic and data blocks are loaded in the load and work memory of the CPU.


The symbolic address assignment (symbol table) and the block comments remain on the programming device.

Dividing Up the User Program

To ensure fast execution of the user program and to avoid unnecessary load on the work memory that cannot be expanded, only the parts of the blocks relevant for program execution are loaded in the work memory.

Parts of blocks that are not required for executing the program (for example, block headers) remain in the load memory.

The following figure shows a program being loaded in the CPU memory.



Note

Data blocks that are created in the user program with the help of system functions (for example, SFC22 CREAT_DB) are saved entirely in the work memory by the CPU.

Some CPUs have separately managed areas for code and data in the work memory. The size and assignment of these areas is shown in the "Memory" tab of the Module Information for these CPUs.

Identifying Data Blocks as "Not Relevant for Execution"

Data blocks that were programmed in a source file as part of an STL program can be identified as "Not Relevant for Execution" (keyword UNLINKED). This means that when they are downloaded to the CPU, the DBs are stored only in the load memory. The content of such blocks can, if necessary, be copied to the work memory using SFC20 BLKMOV.

This technique saves space in the work memory. The expandable load memory is then used as a buffer (for example, for formulas for a mixture: only the formula for the next batch is loaded in the work memory).

Load Memory Structure

The load memory can be expanded using memory cards. Refer to your "S7-300 Programmable Controller, Hardware and Installation Manual" and your "S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual" for the maximum size of the load memory.

The load memory can also have an integrated EPROM part as well as an integrated RAM part in S7-300 CPUs. Areas in data blocks can be declared as retentive by assigning parameters in STEP 7 (see Retentive Memory Areas on S7-300 CPUs).

In S7-400 CPUs, it is imperative that you use a memory card (RAM or EPROM) to expand the load memory. The integrated load memory is a RAM memory and is mainly used to reload and correct blocks. With the new S7-400 CPUs, additional work memory can also be plugged in.

Load Memory Behavior in RAM and EPROM Areas

Depending on whether you select a RAM or an EPROM memory card to expand the load memory, the load memory may react differently during downloading, reloading, or memory reset.

The following table shows the various loading methods:

Memory Type	Method of Loading	Type of Loading
RAM	Downloading and deleting individual blocks	PG-CPU connection
	Downloading and deleting an entire S7 program	PG-CPU connection
	Reloading individual blocks	PG-CPU connection
Integrated (S7-300 only) or plug-in EPROM	Downloading entire S7 programs	PG-CPU connection
Plug-in EPROM	Downloading entire S7 programs	Uploading the EPROM to the PG and inserting the memory card in the CPU Downloading the EPROM to the CPU

Programs stored in RAM are lost when you reset the CPU memory (MRES) or if you remove the CPU or RAM memory card.

Programs saved on EPROM memory cards are not erased by a CPU memory reset and are retained even without battery backup (transport, backup copies).

A.2.3 System Memory

A.2.3.1 Using the System Memory Areas

The system memory of the S7 CPUs is divided into address areas (see table below). Using instructions in your program, you address the data directly in the corresponding address area.

Address Area	Access via Units of Following Size	S7 Notation (IEC)	Description
Process image input table	Input (bit)	I	At the beginning of the scan cycle, the CPU reads the inputs from the input modules and records the values in this area.
	Input byte	IB	
	Input word	IW	
	Input double word	ID	
Process image output table	Output (bit)	Q	During the scan cycle, the program calculates output values and places them in this area. At the end of the scan cycle, the CPU sends the calculated output values to the output modules.
	Output byte	QB	
	Output word	QW	
	Output double word	QD	
Bit memory	Memory (bit)	M	This area provides storage for interim results calculated in the program.
	Memory byte	MB	
	Memory word	MW	
	Memory double word	MD	
Timers	Timer (T)	T	This area provides storage for timers.
Counters	Counter (C)	C	This area provides storage for counters.
Data block	Data block, opened with "OPN DB":	DB	Data blocks contain information for the program. They can be defined for general use by all logic blocks (shared DBs) or they are assigned to a specific FB or SFB (instance DB).
	Data bit	DBX	
	Data byte	DBB	
	Data word	DBW	
	Data double word	DBD	
	Data block, opened with "OPN DI":	DI	
	Data bit	DIX	
	Data byte	DIB	
	Data word	DIW	
Data double word	DID		
Local data	Local data bit	L	This area contains the temporary data of a block while the block is
	Local data byte	LB	

Address Area	Access via Units of Following Size	S7 Notation (IEC)	Description
	Local data word	LW	being executed. The L stack also provides memory for transferring block parameters and for recording interim results from Ladder Logic networks.
	Local data double word	LD	
Peripheral (I/O) area: inputs	Peripheral input byte	PIB	The peripheral input and output areas allow direct access to central and distributed input and output modules (DP).
	Peripheral input word	PIW	
	Peripheral input double word	PID	
Peripheral (I/O) area: outputs	Peripheral output byte	PQB	
	Peripheral output word	PQW	
	Peripheral output double word	PQD	

Refer to the following CPU manuals or instruction lists for information on which address areas are possible for your CPU:

- "S7-300 Programmable Controller, Hardware and Installation" Manual
- "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual
- "S7-300 Programmable Controller, Instruction List"
- "S7-400 Programmable Controller, Reference Guide"


A.2.3.2 Process-Image Input/Output Tables

If the input (I) and output (Q) address areas are accessed in the user program, the program does not scan the signal states on the digital signal modules but accesses a memory area in the system memory of the CPU and distributed I/Os. This memory area is known as the process image.

Updating the Process Image


The following figure shows the processing steps within a scan cycle.

Cyclic Program Processing (CPUs up to 10/98)



One of the internal tasks of the operating system (OS) is to read the status of inputs into the process image input table (PII). Once this step is complete, the user program is executed with all blocks that are called in it. The cycle ends with writing the process image output table (PIQ) to the outputs for the modules. Reading in the process image input table and writing the process image output table to the outputs for the modules is all independently controlled by the operating system.

Cyclic Program Processing (CPUs as of 10/98)



One of the internal tasks of the operating system (OS) is to write the process image output table (PIQ) to the outputs for the modules and to read in the status of inputs into the process image input table (PII). Once this step is complete, the user program is executed with all blocks that are called in it. Writing the process image output table to the outputs for the modules and reading in the process image input table is all independently controlled by the operating system.

Advantages of the Process Image

Compared with direct access to the input/output modules, the main advantage of accessing the process image is that the CPU has a consistent image of the process signals for the duration of one program cycle. If a signal state on an input module changes while the program is being executed, the signal state in the process image is retained until the process image is updated again in the next cycle. The process of repeatedly scanning an input signal within a user program ensures that consistent input information is always available.

Access to the process image also requires far less time than direct access to the signal modules since the process image is located in the internal memory of the CPU.

Part Process Images (Process-Image Partitions)

In addition to having the process image (process-image input table, PII, and process-image output table, PIQ) automatically updated by the operating system, you can assign parameters to a maximum of 15 partial process images for an S7-400 CPU (CPU-specific, no. 1 to no. 15, see the *S7-400, M7-400 Programmable Controllers Module Specifications Reference Manual*). This means that you can update sections of the process-image table, when necessary, independently of the cyclic updating of the process image table.

Each input/output address that you assign with STEP 7 to a process-image partition no longer belongs to the OB1 process-image input/output tables. Input and output address can only be assigned once through the OB 1 process image and all process-image partitions.

You define process-image partition with STEP 7 when you assign addresses (which input/output addresses of the modules are listed in which process-image partition). The process-image partition is updated either by the user with SFCs or automatically by the system by connecting to an OB.

Exception: Process image partitions for synchronous cycle interrupt OBs are not updated on the system side, even though they are linked to an OB (OB 61 to OB 64).

Note

For S7-300 CPUs, unassigned process-image inputs and outputs can be used as additional bit memory areas. Programs that use this capability can run on older (that is, before 4/99) S7-400 CPUs only under one of the following conditions:

For these S7-400 CPUs

- The process image areas used as bit memory must be located outside of the parameter assignment for "Size of the Process Image" or.
 - must be located in a process-image partition that is updated neither by the system nor by SFC26/SFC27.
-

Updating Part Process Images (Process-Image Partitions) with SFCs

You can use SFCs to update the entire process image or a process-image partition from your user program.

- Requirement: The process image in question is not updated by the system.
- SFC26 UPDAT_PI: Update process-image input table
- SFC27 UPDAT_PO: Update process-image output table.


System Update of the Part Process Images (Process-Image Partitions)

You can also have the system update process-image partitions automatically by calling an OB - similar to the (entire) process image, which is updated cyclically before or after OB1 is processed. You can assign this function as a parameter only for specific CPUs.

During operation, the assigned process-image partition is updated automatically:

- Before the OB is processed, the process-image partition for inputs
- After the OB is processed, the process-image partition for the outputs

You assign the parameters for the CPU, along with the priority of the OBs, to indicate which process-image partition is assigned to which OB.



I/O Access Error (PZF) during Update of the Process Image

The default reaction of the CPU families (S7-300 and S7-400) to an error during the update of the process image varies:

- S7-300: No entry is made in the diagnostic buffer, no OB is called, the corresponding input bytes are reset to "0" and will remain at "0" until the fault is gone again.
- S7-400: An entry is made in the diagnostic buffer and OB85 is started for each I/O access for each update of the corresponding process image. The faulty input bytes are reset to "0" each time the process image is accessed.

For new CPUs (as of 4/99), you can reassign parameters for the reaction to I/O access errors so that the CPU functions in one of the following manners:

- Generates an entry in the diagnostic buffer and starts OB85 only for incoming and outgoing PZF (before OB 85 is called, the faulty input bytes are reset to "0" and are no longer overwritten by the operating system until the outgoing PZF)
- Produces the default reaction of an S7-300 (does not call OB85; the corresponding input bytes are reset to "0" and are no longer overwritten by the operating system until the fault is cleared.)
- Produces the default reaction of an S7-400 (calls OB85 for each individual access; the faulty input bytes are reset to "0" each time the process image is accessed.)

How Often Does OB85 Start?

In addition to the reaction to PZF that is assigned as a parameter (incoming/outgoing, or for each I/O access), the address space of a module also influences how often OB85 starts:

For a module with an address space of up to a double word, OB85 starts once, for example, for a digital module with a maximum of 32 inputs or outputs, or for an analog module with two channels.

For modules with a larger address space, OB85 starts as often as access has to be made to it with double word commands, for example, twice for an analog module with four channels.

A.2.3.3 Local Data Stack


The L stack saves the following:

- The temporary variables of the local data of blocks
- The start information of the organization blocks
- Information about transferring parameters
- Interim results of the logic in Ladder Logic programs

When you are programming organization blocks, you can declare temporary variables (TEMP) that are only available when the block is executed and are then overwritten again. Before you access the local data stack for the first time, the local data must be initialized. In addition to this, every organization block also requires 20 bytes of local data for its start information.

The CPU has a limited amount of memory for the temporary variables (local data) of blocks currently being executed. The size of this memory area, the local data stack, is dependent on the CPU. The local data stack is divided up equally among the priority classes (default). This means that every priority class has its own local data area, thus guaranteeing that higher priority classes and their OBs also have space available for their local data.

The following figure shows the assignment of local data to the priority classes in an example in which in the L stack OB1 is interrupted by OB10 which is then interrupted by OB81.



Caution

All the temporary variables (TEMP) of an OB and its associated blocks are saved in the L stack. If you use too many nesting levels when executing your blocks, the L stack can overflow.

S7 CPUs change to STOP mode if the permitted L stack size for a program is exceeded.

Test the L stack (the temporary variables) in your program.

The local data requirements of synchronous error OBs must be taken into consideration.

Assigning Local Data to Priority Classes

Not every priority class requires the same amount of memory in the local data stack. By assigning parameters in STEP 7, you can set different sized local data areas for the individual priority classes for S7-400 CPUs and for the CPU 318. Any priority classes you do not require can be deselected. With S7-400 CPUs and the CPU 318 the memory area for other priority classes is then increased. Deactivated OBs are ignored during program execution and save cycle time.

With the other S7-300 CPUs every priority class is assigned a fixed amount of local data (256 bytes) that cannot be changed.

A.2.3.4 Interrupt Stack

If program execution is interrupted by a higher priority OB, the operating system saves the current contents of the accumulators and address registers, and the number and size of the open data blocks in the interrupt stack.

Once the new OB has been executed, the operating system loads the information from the I stack and resumes execution of the interrupted block at the point at which the interrupt occurred.

When the CPU is in STOP mode, you can display the I stack on a programming device using STEP 7. This allows you to find out why the CPU changed to STOP mode.


A.2.3.5 Block Stack

If processing of a block is interrupted by the call of another block or by a higher priority class (interrupt/error servicing), the B stack stores the following data:

- Number, type (OB, FB, FC, SFB, SFC), and return address of the block that was interrupted.
- Numbers of the data blocks (from the DB and DI register) that were open when the block was interrupted.

Using this data, the user program can then be resumed after the interrupt.

If the CPU is in STOP mode, you can display the B stack with STEP 7 on a programming device. The B stack lists all the blocks that had not been completely executed when the CPU changed to STOP mode. The blocks are listed in the order in which processing was started (see figure below).



Data Block Registers

There are two data block registers. These contain the numbers of opened data blocks, as follows:

- The DB register contains the number of the open shared data block
- The DI register contains the number of the open instance data block.

A.2.3.6 Diagnostic Buffer

The diagnostic buffer displays the diagnostic messages in the order in which they occur. The first entry contains the newest event. The number of entries in the diagnostic buffer is dependent on the module and its current operating mode.

Diagnostic events include the following:

- Faults on a module
- Errors in the process wiring
- System errors in the CPU
- Mode transitions on the CPU
- Errors in the user program
- User-defined diagnostic events (via the system function SFC52).

A.2.3.7 Evaluating the Diagnostic Buffer

One part of the system status list is the diagnostic buffer that contains more information about system diagnostic events and User-defined diagnostic events in the order in which they occurred. The information entered in the diagnostic buffer when a system diagnostic event occurs is identical to the start information transferred to the corresponding organization block.

You cannot clear the entries in the diagnostic buffer and its contents are retained even after a memory reset.

The diagnostic buffer provides you with the following possibilities:

- If the CPU changes to STOP mode, you can evaluate the last events leading up to the STOP and locate the cause.
- The causes of errors can be detected far more quickly increasing the availability of the system.
- You can evaluate and optimize the dynamic system response.

Organizing the Diagnostic Buffer

The diagnostic buffer is designed to act as a ring buffer for a maximum number of entries which is dependent on the individual module. This means that when the maximum number of entries is reached, the next diagnostic buffer event causes the oldest entry to be deleted. All entries then move back one place. This means that the newest entry is always the first entry in the diagnostic buffer. For the S7-300 CPU 314 the number of possible entries is 100:

The number of entries displayed in the diagnostic buffer is dependent on the module and its current operating mode. With some CPUs, it is possible to set the length of the diagnostic buffer.

Diagnostic Buffer Content

The **upper** list box contains a list of all the diagnostic events that occurred with the following information:

- Serial number of the entry (the newest entry has the number 1)
- Time and date of the diagnostic event: The time and date of the module are displayed if the module has an integrated clock. For the time data in the buffer to be valid, it is important that you set the time and date on the module and check it regularly.
- Short description of the diagnostic event

In the **lower** text box, all the additional information is displayed for the event selected in the list in the upper window. This information includes:

- Event number
- Description of the event
- Mode transition caused by the diagnostic event
- Reference to the location of the error in a block (block type, block number, relative address) which caused the entry in the buffer
- Event state being entered or left
- Additional information specific to the event

With the "Help on Event" button you can display additional information on the event selected in the upper list box.

Information on event IDs can be found in the Reference Help on System Blocks and System Functions (Jumps to Language Descriptions and Help on Blocks, System Attributes)

Saving the Contents in a Text File

Using the "Save As" button in the "Diagnostic Buffer" tab of the "Module Information" dialog box you can save the contents of the diagnostic buffer as ASCII text.

Displaying the Diagnostic Buffer

You can display the contents of the diagnostic buffer on the programming device via the "Diagnostic Buffer" tab in the "Module Information" dialog box or in a program using the system function SFC51 RDSYSST.

Last Entry before STOP

You can specify that the last diagnostic buffer entry before the transition from RUN to STOP is automatically sent to a logged on monitoring device (for example, PG, OP, TD) in order to locate and remedy the cause of the change to STOP more quickly.


A.2.3.8 Retentive Memory Areas on S7-300 CPUs

If a power outage occurs or the CPU memory is reset (MRES), the memory of the S7-300 CPU (dynamic load memory (RAM), work memory, and system memory) is reset and all the data previously contained in these areas is lost. With S7-300 CPUs, you can protect your program and its data in the following ways:

- You can protect all the data in the load memory, work memory, and in parts of the system memory with battery backup.
- You can store your program in the EPROM (either memory card or integrated on the CPU, refer to the "S7-300 Programmable Controller, Hardware and Installation" Manual).
- You can store a certain amount of data depending on the CPU in an area of the nonvolatile NVRAM.

Using the NVRAM

Your S7-300 CPU provides an area in the NVRAM (non-volatile RAM) (see figure below). If you have stored your program in the EPROM of the load memory, you can save certain data (if there is a power outage or when the CPU changes from STOP to RUN) by configuring your CPU accordingly.



To do this set the CPU so that the following data are saved in the nonvolatile RAM:

- Data contained in a DB (this is only useful if you have also stored your program in an EPROM of the load memory)
- Values of timers and counters
- Data saved in bit memory.

On every CPU, you can save a certain number of timers, counters, and memory bits. A specific number of bytes is also available in which the data contained in DBs can be saved.

The MPI address of your CPU is stored in the NVRAM. This makes sure that your CPU is capable of communication following a power outage or memory reset.

Using Battery Backup to Protect Data

By using a backup battery, the load memory and work memory are retentive during a power outage. If you configure your CPU so that timers, counters, and bit memory are saved in the NVRAM, this information is also retained regardless of whether you use a backup battery or not.

Configuring the Data of the NVRAM

When you configure your CPU with STEP 7, you can decide which memory areas will be retentive.

The amount of memory that can be configured in the NVRAM depends on the CPU you are using. You cannot back up more data than specified for your CPU.

A.2.3.9 Retentive Memory Areas on S7-400 CPUs

Operation Without Battery Backup

If you operate your system without battery backup, when a power outage occurs or when you reset the CPU memory (MRES), the memory of the S7-400 CPU (dynamic load memory (RAM), work memory, and system memory) is reset and all the data contained in these areas is lost.

Without battery backup, only a restart (warm restart) is possible and there are no retentive memory areas. Following a power outage, only the MPI parameters (for example, the MPI address of the CPU) are retained. This means that the CPU remains capable of communication following a power outage or memory reset.

Operation With Battery Backup

If you use a battery to back up your memory:

- The entire content of all RAM areas is retained when the CPU restarts following a power outage.
- During a restart (warm restart), the address areas for bit memory, timers, and counters is cleared. The contents of data blocks are retained.
- The contents of the RAM work memory are also retained apart from bit memory, timers, and counters that were designed as non-retentive.

Configuring Retentive Data Areas

You can declare a certain number of memory bits, timers, and counters as retentive (the number depends on your CPU). During a restart (warm restart) when you are using a backup battery, this data is also retained.

When you assign parameters with STEP 7, you define which memory bits, timers, and counters should be retained during a restart (warm restart). You can only back up as much data as is permitted by your CPU.

For more detailed information about defining retentive memory areas, refer to your "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual.

Configurable Memory Objects in the Work Memory

With some CPUs the size of objects such as local data or the diagnostic buffer can be set under "Configuring Hardware." If, for example, reduce the size of the preset values, a larger percentage of the work memory will be available elsewhere. You will find the settings for these CPUs in the "Memory" tab of the "Module Information" dialog box ("Details" button).

When you change the memory configuration and download the new configuration to the programmable controller, a cold restart is required on the CPU for the changes to come into effect.

A.2.3.10 Configurable Memory Objects in the Work Memory

With some CPUs, the size of objects such as local or the diagnostic buffer can be set in HW Config. If, for example, you reduce the default values, a larger section of the work memory is made available elsewhere. The settings for these CPUs can be displayed in the "Memory" tab of the Module Information ("Details" button).

After the memory configuration has been changed and downloaded to the programmable controller, you must perform a cold restart in order for the changes to become effective.

A.3 Data Types and Parameter Types

A.3.1 Introduction to Data Types and Parameter Types

All the data in a user program must be identified by a data type. The following data types are available:

- Elementary data types provided by STEP 7
- Complex data types that you yourself can create by combining elementary data types
- Parameter types with which you define parameters to be transferred to FBs or FCs

General Information

Statement List, Ladder Logic, and Function Block Diagram instructions work with data objects of specific sizes. Bit logic instructions work with bits, for example. Load and transfer instructions (STL) and move instructions (LAD and FBD) work with bytes, words, and double words.

A bit is a binary digit "0" or "1." A byte is made up of eight bits, a word of 16 bits, and a double word of 32 bits.

Math instructions also work with bytes, words, or double words. In these byte, word, or double word addresses you can code numbers of various formats such as integers and floating-point numbers.

When you use symbolic addressing, you define symbols and specify a data type for these symbols (see table below). Different data types have different format options and number notations.

This chapter describes only some of the ways of writing numbers and constants. The following table lists the formats of numbers and constants that will not be explained in detail.

Format	Size in Bits	Number Notation
Hexadecimal	8, 16, and 32	B#16#, W#16#, and DW#16#
Binary	8, 16, and 32	2#
IEC date	16	D#
IEC time	32	T#
Time of day	32	TOD#
Character	8	'A'

A.3.2 Elementary Data Types

Each elementary data type has a defined length. The following table lists the elementary data types.

Type and Description	Size in Bits	Format Options	Range and Number Notation (lowest to highest value)_	Example
BOOL(Bit)	1	Boolean text	TRUE/FALSE	TRUE
BYTE (Byte)	8	Hexadecimal number	B#16#0 to B#16#FF	L B#16#10 L byte#16#10
WORD (Word)	16	Binary number Hexadecimal number BCD Decimal number unsigned	2#0 to 2#1111_1111_1111_1111 W#16#0 to W#16#FFFF C#0 to C#999 B#(0.0) to B#(255.255)	L 2#0001_0000_0000_0000 L W#16#1000 L word#16#1000 L C#998 L B#(10,20) L byte#(10,20)
DWORD (Double word)	32	Binary number Hexadecimal number Decimal number unsigned	2#0 to 2#1111_1111_1111_1111_1111_1111_1111_1111 DW#16#0000_0000 to DW#16#FFFF_FFFF B#(0,0,0,0) to B#(255,255,255,255)	2#1000_0001_0001_1000_1011_1011_0111_1111 L DW#16#00A2_1234 L dword#16#00A2_1234 L B#(1, 14, 100, 120) L byte#(1,14,100,120)
INT (Integer)	16	Decimal number signed	-32768 to 32767	L 1
DINT (Integer, 32 bits)	32	Decimal number signed	L#-2147483648 to L#2147483647	L L#1
REAL (Floating-point number)	32	IEEE Floating-point number	Upper limit: $\pm 3.402823e+38$ Lower limit: $\pm 1.175495e-38$	L 1.234567e+13
S5TIME (SIMATIC time)	16	S7 time in steps of 10 ms (default)	S5T#0H_0M_0S_10MS to S5T#2H_46M_30S_0MS and S5T#0H_0M_0S_0MS	L S5T#0H_1M_0S_0MS L S5TIME#0H_1H_1M_0S_0MS
TIME (IEC time)	32	IEC time in steps of 1 ms, integer signed	-T#24D_20H_31M_23S_648MS to T#24D_20H_31M_23S_647MS	L T#0D_1H_1M_0S_0MS L TIME#0D_1H_1M_0S_0MS
DATE (IEC date)	16	IEC date in steps of 1 day	D#1990-1-1 to D#2168-12-31	L D#1996-3-15 L DATE#1996-3-15
TIME_OF_DAY (Time)	32	Time in steps of 1 ms	TOD#0:0:0.0 to TOD#23:59:59.999	L TOD#1:10:3.3 L TIME_OF_DAY#1:10:3.3
CHAR (Character)	8	ASCII characters	'A','B' etc.	L 'E'

A.3.2.3 Format of the Data Type REAL (Floating-Point Numbers)

Numbers in floating-point format are represented in the general form "number = $m * b$ to the power of E ." The base " b " and the exponent " E " are integers; the mantissa " m " is a rational number.

This type of number representation has the advantage of being able to represent both very large and very small values within a limited space. With the limited number of bits for the mantissa and exponent, a wide range of numbers can be covered.


The disadvantage is in the limited accuracy of calculations. For example, when forming the sum of two numbers, the exponents must be matched by shifting the mantissa (hence floating decimal point) since only numbers with the same exponent can be added.

Floating-point number format in STEP 7

Floating-point numbers in STEP 7 conform to the basic format, single width, described in the ANSI/IEEE standard 754-1985, *IEEE Standard for Binary Floating-Point Arithmetic*. They consist of the following components:

- The sign S
- The exponent $e = E + \text{bias}$, increased by a constant (bias = +127)
- The fractional part of the mantissa m .
The whole number part of the mantissa is not stored with the rest, because it is always equal to 1 within the valid number range.

The three components together occupy one double word (32 bits):



The following table shows the values of the individual bits in floating-point format.

Component of the Floating-Point Number	Bit Number	Value
Sign S	31	
Exponent e	30	2 to the power of 7
...
Exponent e	24	2 to the power of 1
Exponent e	23	2 to the power of 0
Mantissa m	22	2 to the power of -1
...
Mantissa m	1	2 to the power of -22
Mantissa m	0	2 to the power of -23

Using the three components **S**, **e**, and **m**, the value of a number represented in this form is defined by the formula:

$$\text{Number} = 1.m * 2 \text{ to the power of } (e - \text{bias})$$

Where:

- e: $1 \leq e \leq 254$
- Bias: bias = 127. This means that an additional sign is not required for the exponent.
- S: for a positive number, S = 0 and for a negative number, S = 1.

Value Range of Floating-Point Numbers

Using the floating-point format shown above, the following results:

- The smallest floating-point number = $1.0 * 2 \text{ to the power of } (1-127) = 1.0 * 2 \text{ to the power of } (-126)$
= 1.175 495E-38 and
- The largest floating-point number = $2-2 \text{ to the power of } (-23) * 2 \text{ to the power of } (254-127) = 2-2 \text{ to the power of } (-23) * 2 \text{ to the power of } (+127)$
= 3.402 823E+38

The number zero is represented with e = m = 0; e = 255 and m = 0 stands for "infinite."

Format	Range ¹⁾
Floating-point numbers according to the ANSI/IEEE standard	-3.402 823E+38 to -1.175 495E-38 and 0 and +1.175 495E-38 to +3.402 823E+38

The following table shows the signal state of the bits in the status word for the results of instructions with floating-point numbers that do not lie within the valid range:

Invalid Range for a Result	CC1	CC0	OV	OS
-1.175494E-38 < result < -1.401298E-45 (negative number) underflow	0	0	1	1
+1.401298E-45 < result < +1.175494E-38 (positive number) underflow	0	0	1	1
Result < -3.402823E+38 (negative number) overflow	0	1	1	1
Result > 3.402823E+38 (positive number) overflow	1	0	1	1
Not a valid floating-point number or invalid instruction (input value outside the valid value range)	1	1	1	1

Note when using mathematical operations:

The result "Not a valid floating-point number" is obtained, for example, when you attempt to extract the square root from -2. You should therefore always evaluate the status bits first in math operations before continuing calculations based on the result.

Note when modifying variables:

If the values for floating-point operations are stored in memory double words, for example, you can modify these values with any bit patterns. However, not every bit pattern is a valid number.

Accuracy when Calculating Floating-Point Numbers**Caution**

Calculations involving a long series of values including very large and very small numbers can produce inaccurate results.

The floating-point numbers in STEP 7 are accurate to 6 decimal places. You can therefore only specify a maximum of 6 decimal places when entering floating-point constants.

Note

The calculation accuracy of 6 decimal places means, for example, that the addition of $\text{number1} + \text{number2} = \text{number1}$ if number1 is greater than $\text{number2} * 10$ to the power of y , where $y > 6$:

$$100\,000\,000 + 1 = 100\,000\,000.$$

Examples of Numbers in Floating-Point Format

The following figure shows the floating-point format for the following decimal values:

- 10.0
- Pi (3.141593)
- Square root of 2 (1.414214)

The number 10.0 in the first example results from its floating-point format (hexadecimal representation: 4120 0000) as follows:


$$e = 2 \text{ to the power of } 7 + 2 \text{ to the power of } 1 = 2 + 128 = 130$$

$$m = 2 \text{ to the power of } (-2) = 0.25$$

This results in:

$$(1 + m) * 2 \text{ to the power of } (e - \text{bias}) = 1.25 * 2 \text{ to the power of } 3 = 10.0$$

$$[1.25 * 2 \text{ to the power of } (130-127) = 1.25 * 2 \text{ to the power of } 3 = 10.0]$$




A.3.2.4 Format of the Data Types WORD and DWORD in Binary Coded Decimal Numbers

The binary-coded decimal (BCD) format represents a decimal number by using groups of binary digits (bits). One group of 4 bits represents one digit of a signed decimal number or the sign of the decimal number. The groups of 4 bits are combined to form a word (16 bits) or double word (32 bits). The four most significant bits indicate the sign of the number (1111 indicates minus and 0000 indicates plus). Commands with BCD-coded addresses only evaluate the highest-value bit (15 in word, 31 in double word format). The following table shows the format and range for the two types of BCD numbers.


Format	Range
Word (16 bits, three-digit BCD number with sign)	-999 to +999
Double word (32 bits, seven-digit BCD number with sign)	-9 999 999 to +9 999 999

The following figures provide an example of a binary coded decimal number in the following formats:

- Word format




- Double word format



A.3.2.5 Format of the Data Type S5TIME (Time Duration)

When you enter time duration using the S5TIME data type, your entries are stored in binary coded decimal format. The following figure shows the content of the time address with a time value of 127 and a time base of 1 s.



When working with S5TIME, you enter a time value in the range of 0 to 999 and you indicate a time base (see the following table). The time base indicates the interval at which a timer decrements the time value by one unit until it reaches 0.

Time base for S5TIME

Time Base	Binary Code for Time Base
10 ms	00
100 ms	01
1 s	10
10 s	11

You can pre-load a time value using either of the following syntax formats:

- L¹⁾ W#16#wxyz
 - Where w = time base (that is, the time interval or resolution)
 - Where xyz = the time value in binary coded decimal format
- L¹⁾ S5T#aH_bbM_ccS_dddMS
 - Where a = hours, bb = minutes, cc = seconds, and dd = milliseconds
 - The time base is selected automatically and the value is rounded to the next lower number with that time base.

The maximum time value that you can enter is 9,990 seconds, or 2H_46M_30S.

¹⁾ = L only to be specified in STL programming

A.3.3 Complex Data Types

Complex data types define data groups that are larger than 32 bits or data groups consisting of other data types. STEP 7 permits the following complex data types:

- DATE_AND_TIME
- STRING
- ARRAY
- STRUCT
- UDT (user-defined data types)
- FBs and SFBs

The following table describes the complex data types. You define structures and arrays either in the variable declaration of the logic block or in a data block.

Data Type	Description
DATE_AND_TIME DT	Defines an area with 64 bits (8 bytes). This data type saves in binary coded decimal format:
STRING	Defines a group with a maximum of 254 characters (data type CHAR). The standard area reserved for a character string is 256 bytes long. This is the space required to save 254 characters and a header of 2 bytes. You can reduce the memory required for a string by defining the number of characters that will be stored in the character string (for example: string[9] 'Siemens').
ARRAY	Defines a multi-dimensional grouping of one data type (either elementary or complex). For example: "ARRAY [1..2,1..3] OF INT" defines an array in the format 2 x 3 consisting of integers. You access the data stored in an array using the Index ("[2,2]"). You can define up to a maximum of 6 dimensions in one array. The index can be any integer (-32768 to 32767).
STRUCT	Defines a grouping of any combination of data types. You can, for example, define an array of structures or a structure of structures and arrays.
UDT	Simplifies the structuring of large quantities of data and entering data types when creating data blocks or declaring variables in the variable declaration. In STEP 7, you can combine complex and elementary data types to create your own "user-defined" data type. UDTs have their own name and can therefore be used more than once.
FB, SFB	You determine the structure of the assigned instance data block and allow the transfer of instance data for several FB calls in one instance DB.

Structured data types are saved in accordance with word limits (WORD aligned).

A.3.3.1 Format of the Data Type DATE_AND_TIME

When you enter date and time using the DATE_AND_TIME data type (DT), your entries are stored in binary coded decimal format in 8 bytes. The DATE_AND_TIME data type has the following range:

DT#1990-1-1-0:0:0.0 to DT#2089-12-31-23:59:59.999

The following examples show the syntax for the date and time for Thursday, December 25, 1993, at 8:12 and 34,567 seconds in the morning. The following two formats are possible:

- DATE_AND_TIME#1993-12-25-8:12:34.567
- DT#1993-12-25-8:12:34.567

The following special IEC (International Electrotechnical Commission) standard functions are available for working with the DATE_AND_TIME data type:

- Convert date and time of day to the DATE_AND_TIME format
FC3: D_TOD_DT
- Extract the date from the DATE_AND_TIME format
FC6: DT_DATE
- Extract the day of the week from the DATE_AND_TIME format
FC7: DT_DAY
- Extract the time of day from the DATE_AND_TIME format
FC8: DT_TOD

The following table shows the contents of the bytes that contain the date and time information for the example Thursday, December 25, 1993, at 8:12 and 34,567 seconds in the morning.

Byte	Contents	Example
0	Year	B#16#93
1	Month	B#16#12
2	Day	B#16#25
3	Hour	B#16#08
4	Minute	B#16#12
5	Second	B#16#34
6	Two most significant digits of MSEC	B#16#56
7 (4MSB)	Two least significant digits of MSEC	B#16#7
7 (4LSB)	Day of week 1 = Sunday 2 = Monday ... 7 = Saturday	B#16#_5

The permitted range for the data type DATE_AND_TIME is:

- min.: DT#1990-1-1-0:0:0.0
- max.: DT#2089-12-31-23:59:59.999


	Possible Value Range	BCD Code
Year	1990 - 1999	90 - 99
	2000 - 2089	00 - 89
Month	1 - 12	01 - 12
Day	1 - 31	01 - 31
Hour	00 - 23	00 - 23
Minute	00 - 59	00 - 59
Second	00 - 59	00 - 59
Millisecond	0 - 999	000 - 999
Day of week	Sunday - Saturday	1 - 7

A.3.3.2 Using Complex Data Types

You can create new data types by combining the elementary and complex data types to create the following complex data types:


- Array (data type ARRAY): an array combines a group of one data type to form a single unit.
- Structure (data type STRUCT): a structure combines different data types to form a single unit.
- Character string (data type STRING): a character string defines a one-dimensional array with a maximum of 254 characters (data type CHAR). A character string can only be transferred as a unit. The length of the character string must match the formal and actual parameter of the block.
- Date and time (data type DATE_AND_TIME): the date and time data type stores the year, month, day, hours, minutes, seconds, milliseconds, and day of the week.

The following figure shows how arrays and structures can structure data types in one area and save information. You define an array or a structure either in a DB or in the variable declaration of an FB, OB, or FC.



Example 2

An array can also describe a multi-dimensional group of data types. The following figure shows a two-dimensional array of integers.



You access the data in a multi-dimensional array using the index. In this example, the first integer is `Op_temp[1,1]`, the third is `Op_temp[1,3]`, the fourth is `Op_temp[2,1]`, and the sixth is `Op_temp[2,3]`.

You can define up to a maximum of 6 dimensions (6 indexes) for an array. You could, for example, define the variable `Op_temp` as follows as a six-dimensional array:

```
ARRAY [1..3,1..2,1..3,1..4,1..3,1..4]
```

The index of the first element in this array is `Op_temp[1,1,1,1,1,1]`. The index of the last element `Op_temp[3,2,3,4,3,4]`.

Creating Arrays

You define arrays when you declare the data in a DB or in the variable declaration. When you declare the array, you specify the keyword (ARRAY) followed by the size in square brackets, as follows:

```
[lower limit value..upper limit value]
```

In a multi-dimensional array you also specify the additional upper and lower limit values and separate the individual dimensions with a comma. The following figure shows the declaration for creating an array of the format 2 x 3.

Address	Name	Type	Init. Value	Comment
0.0		STRUCT		
+0.0	Heat_2X3	ARRAY[1..2,1..3]		
*2.0		INT		
=6.0		END_STRUCT		

Entering Initial Values for an Array

You can assign an initial value to every array element when you create arrays. STEP 7 provides two methods for entering initial values:

- Entry of individual values: for each element of the array, you specify a value that is valid for the data type of the array. You specify the values in the order of the elements: [1,1]. Remember that the individual elements must be separated from each other by a comma.
- Specifying a repetition factor: with sequential elements that have the same initial value, you can specify the number of elements (the repetition factor) and the initial value for these elements. The format for entering the repetition factor is $x(y)$, where x is the repetition factor and y is the value to be repeated.

If you use the array declared in the above figure, you can specify the initial value for all six elements as follows: 17, 23, -45, 556, 3342, 0. You could also set the initial value of all six elements to 10 by specifying 6(10). You could specify specific values for the first two elements and then set the remaining four elements to 0 by specifying the following: 17, 23, 4(0).

Accessing Data in an Array

You access data in an array via the index of the specific element in the array. The index is used with the symbolic name.

Example: If the array declared in the above figure begins at the first byte of DB20 (motor), you access the second element in the array with the following address:

```
Motor.Heat_2x3[1,2].
```

Using Arrays as Parameters


You can transfer arrays as parameters. If a parameter is declared in the variable declaration as ARRAY, you must transfer the entire array (and not individual elements). An element of an array can, however be assigned to a parameter when you call a block, providing the element of the array corresponds to the data type of the parameter.

If you use arrays as parameters, the arrays do not need to have the same name (they do not even need a name). Both arrays (the formal parameter and the actual parameter) must however have the same structure. An array in the format 2 x 3 consisting of integers, for example, can only be transferred as a parameter when the formal parameter of the block is defined as an array in the format 2 x 3 consisting of integers and the actual parameter that is provided by the call operation is also an array in the format 2 x 3 consisting of integers.

A.3.3.4 Using Structures to Access Data

Structures

A structure combines various data types (elementary and complex data types, including arrays and structures) to form one unit. You can group the data to suit your process control. You can therefore also transfer parameters as a data unit and not as single elements. The following figure illustrates a structure consisting of an integer, a byte, a character, a floating-point number, and a Boolean value.



A structure can be nested to a maximum of 8 levels (for example, a structure consisting of structures containing arrays).

Creating a Structure

You define structures when you declare data within a DB or in the variable declaration of a logic block.

The following figure illustrates the declaration of a structure (*Stack_1*) that consists of the following elements: an integer (for saving the amount), a byte (for saving the original data), a character (for saving the control code), a floating-point number (for saving the temperature), and a Boolean memory bit (for terminating the signal).

Address	Name	Type	Init. value	Comment
0.0	Stack_1	STRUCT		
+0.0	Amount	INT	100	
+2.0	Original_data	BYTE		
+4.0	Control_code	CHAR		
+6.0	Temperature	REAL	120	
+8.0	End	BOOL	FALSE	
=10.0		END_STRUCT		

Assigning Initial Values for a Structure

If you want to assign an initial value to every element of a structure, you specify a value that is valid for the data type and the name of the element. You can, for example, assign the following initial values (to the structure declared in the above figure):

```
Amount          =      100
Original_data   =      B#(0)
Control_code    =      'C'
Temperature     =      120
End             =      False
```

Saving and Accessing Data in Structures

You access the individual elements of a structure. You can use symbolic addresses (for example, *Stack_1.Temperature*). You can, however, specify the absolute address at which the element is located (example: if *Stack_1* is located in *DB20* starting at byte 0, the absolute address for *amount* is *DB20.DBW0* and the address for *temperature* is *DB20.DBD6*).

Using Structures as Parameters


You can transfer structures as parameters. If a parameter is declared as `STRUCT` in the variable declaration, you must transfer a structure with the same components. An element of a structure can, however, also be assigned to a parameter when you call a block providing the element of the structure corresponds to the data type of the parameter.

If you use structures as parameters, both structures (for the formal parameters and the actual parameters) must have the same components, in other words the same data types must be arranged in the same order.

A.3.3.5 Using User-Defined Data Types to Access Data

User-Defined Data Types

User-defined data types (UDTs) can combine elementary and complex data types. You can assign a name to UDTs and use them more than once. The following figure illustrates the structure of a user-defined data type consisting of an integer, a byte, a character, a floating-point number, and a Boolean value.



Instead of entering all the data types singly or as a structure, you only need to specify "UDT20" as the data type and STEP 7 automatically assigns the corresponding memory space.

Creating a User-Defined Data Type

You define UDTs with STEP 7. The following figure shows a UDT consisting of the following elements: an integer (for saving the amount), a byte (for saving the original data), a character (for saving the control code), a floating-point number (for saving the temperature), and a Boolean memory bit (for terminating the signal). You can assign a symbolic name to the UDT in the symbol table (for example, *process data*).

Address	Name	Type	Init. value	Comment
0.0	Stack_1	STRUCT		
+0.0	Amount	INT	100	
+2.0	Original_data	BYTE		
+4.0	Control_code	CHAR		
+6.0	Temperature	REAL	120	
+8.0	End	BOOL	FALSE	
=10.0		END_STRUCT		

Once you have created a UDT, you can use the UDT like a data type if, for example, you declare the data type *UDT200* for a variable in a DB (or in the variable declaration of an FB).

The following figure shows a DB with the variables *process_data_1* with the data type *UDT200*. You only specify *UDT200* and *process_data_1*. The arrays shown in italics are created when you compile the DB.

Address	Name	Type	Init. Value	Comment
0.0		STRUCT		
+10.0	<i>Process_data_1</i>	UDT200		
=10.0		END_STRUCT		

Assigning Initial Values for a User-Defined Data Type

If you want to assign an initial value to every element of a user-defined data type, you specify a value that is valid for the data type and the name of the element. You can, for example, assign the following initial values (to the user-defined data type declared in the above figure):

```
Amount          = 100
Original_data   = B#16#0)
Control_code    = 'C'
Temperature     = 1.200000e+002
End             = False
```

If you declare a variable as a UDT, the initial values of the variables are the values you specified when you created the UDT.

Saving and Accessing Data in a User-Defined Data Type

You access the individual elements of a UDT. You can use symbolic addresses (for example *Stack_1.Temperature*). You can, however specify the absolute address at which the element is located (example: if *Stack_1* is located in DB20 starting at byte 0, the absolute address for *amount* is *DB20.DBW0* and the address for *temperature* is *DB20.DBD6*).


Using User-Defined Data Types as Parameters

You can transfer variables of the data type UDT as parameters. If a parameter is declared as UDT in the variable declaration, you must transfer a UDT with the same structure. An element of a UDT can, however, also be assigned to a parameter when you call a block providing the element of the UDT corresponds to the data type of the parameter.

Advantages of DBs with an Assigned UDT

By using UDTs you have created once, you can generate a large number of data blocks with the same data structure. You can then use these data blocks to enter different actual values for specific tasks.

If, for example, you structure a UDT for a formula (for example, for blending colors), you can assign this UDT to several DBs each containing different amounts.



The structure of the data block is determined by the UDT assigned to it.

A.3.4 Parameter Types

In addition to elementary and complex data types, you can also define parameter types for formal parameters that are transferred between blocks. STEP 7 recognizes the following parameter types:


- **TIMER or COUNTER:** this specifies a particular timer or particular counter that will be used when the block is executed. If you supply a value to a formal parameter of the TIMER or COUNTER parameter type, the corresponding actual parameter must be a timer or a counter, in other words, you enter "T" or "C" followed by a positive integer.
- **BLOCK:** specifies a particular block to be used as an input or output. The declaration of the parameter determines the block type to be used (FB, FC, DB etc.). If you supply values to a formal parameter of the BLOCK parameter type, specify a block address as the actual parameter. Example: "FC101" (when using absolute addressing) or "Valve" (with symbolic addressing).
- **POINTER:** references the address of a variable. A pointer contains an address instead of a value. When you supply a value to a formal parameter of the parameter type POINTER, you specify an address as the actual parameter. In STEP 7, you can specify a pointer in the pointer format or simply as an address (for example, M 50.0). Example of a pointer format for addressing the data beginning at M 50.0: P#M50.0
- **ANY:** this is used when the data type of the actual parameter is unknown or when any data type can be used. For more information about the ANY parameter type, refer to the sections "Format of the Parameter Type ANY" and "Using the Parameter Type ANY".

A parameter type can also be used in a user-defined data type (UDT). For more information about UDTs, refer to the section "Using User-Defined Data Types to Access Data".

Parameter	Capacity	Description
TIMER	2 bytes	Indicates a timer to be used by the program in the called logic block. Format: T1
COUNTER	2 bytes	Indicates a counter to be used by the program in the called logic block. Format: C10
BLOCK_FB BLOCK_FC BLOCK_DB BLOCK_SDB	2 bytes	Indicates a block to be used by the program in the called logic block. Format: FC101 DB42
POINTER	6 bytes	Identifies the address. Format: P#M50.0
ANY	10 Bytes	Is used when the data type of the current parameter is unknown. Format: P#M50.0 BYTE 10 ANY format for data types P#M100.0 WORD 5 L#1COUNTER 10 ANY format for parameter types

A.3.4.1 Format of the Parameter Types BLOCK, COUNTER, TIMER


STEP 7 stores the parameter types BLOCK, COUNTER, and TIMER as binary numbers in a word (32 bits). The following figure shows the format of these parameter types.



The permitted number of blocks, timers, and counters is dependent on the type of your S7 CPU. You will find more information on the permitted number of timers and counters and on the maximum number of available blocks in the data sheets for your CPU in the "S7-300 Programmable Controller, Hardware and Installation Manual" or in the "S7-400, M7-400 Programmable Controllers, Hardware and Installation Manual."

A.3.4.2 Format of the Parameter Type POINTER

The following figure shows the type of data that is stored in each byte.



The parameter type POINTER stores the following information:

- DB number (or 0 if the data are not stored in a DB)
- Memory area in the CPU (the following table shows the hexadecimal codes of the memory areas for the parameter type POINTER)

Hexadecimal Code	Memory Area	Description
b#16#81	I	Input area
b#16#82	Q	Output area
b#16#83	M	Bit memory area
b#16#84	DB	Data block
b#16#85	DI	Instance data block
b#16#86	L	Local data (L stack)
b#16#87	V	Previous local data

- Address of the data (in the format Byte.Bit)

STEP 7 provides the pointer format: p#memory_area byte.bit_address. (If the formal parameter was declared as the parameter type POINTER, you only need to indicate the memory area and the address. STEP 7 automatically reformats your entry into pointer format.) The following examples show how you enter the parameter type POINTER for the data that start at M50.0:
- P#M50.0
- M50.0 (if the formal parameter was declared as POINTER).

A.3.4.3 Using the Parameter Type POINTER

A pointer is used to point to an address. The advantage of this type of addressing is that you can modify the address of the statement dynamically during program processing.

Pointer for Memory-Indirect Addressing

Program statements that work with memory-indirect addressing are made up of an instruction, an address identifier, and an offset (the offset must be given in square brackets).

Example of a pointer in double word format:

L	P#8.7	Load the value of the pointer into accumulator 1.
T	MD2	Transfer the pointer to MD2.
A	I [MD2]	Query the signal state at input bit I 8.7 and
=	Q [MD2]	assign the signal state to output bit Q 8.7.

Pointer for Area-Internal and Area-Crossing Addressing

The program statements that work with these types of addressing are comprised of an instruction and the following parts: address identifier, address register identifier, offset.

The address register (AR1/2) and the offset must be specified together in square brackets.

Example for Area-Internal Addressing

The pointer contains no indication of a memory area:

L	P#8.7	Load the value of the pointer into accumulator 1.
LAR1		Load the pointer from accumulator 1 into AR1.
A	I [AR1, P#0.0]	Query the signal state at input bit I 8.7 and
=	Q [AR1, P#1.1]	assign the signal state to output bit Q 10.0.

The offset 0.0 has no influence. Output 10.0 is calculated from 8.7 (AR1) plus the offset 1.1. The result is 10.0 and not 9.8, see pointer format.

Example for Area-Crossing Addressing

In area-crossing addressing the memory area is indicated in the pointer (in the example I and Q).

L	P# I8.7	Load the value of the pointer and the area identification in accumulator 1.
LAR1		Load memory area I and the address 8.7 into AR1.
L	P# Q8.7	Load the value of the pointer and the area identification in accumulator 1.
LAR2		Load memory area Q and the address 8.7 into AR2.
A	[AR1, P#0.0]	Query the signal state at input bit I 8.7 and
=	[AR2, P#1.1]	assign the signal state to output bit Q 10.0.

The offset 0.0 has no influence. Output 10.0 is calculated from 8.7 (AR2) plus the offset 1.1. The result is 10.0 and not 9.8, see pointer format.

A.3.4.4 Block for Changing the Pointer

Using the sample block FC3 "Routing Pointers" it is possible to change the bit or byte address of a pointer. The pointer to be changed is transferred to the variable "pointer" when the FC is called (area-internal and area-crossing pointers in double word format can be used).

With the parameter "Bit-Byte" you can change the bit or byte address of the pointer (0: bit address, 1: byte address). The variable "Inc_Value" (in integer format) specifies the number that should be added to or subtracted from the address contents. You can also specify negative numbers to decrement the address.

With a bit address change, there is a carry over to the byte address (also when decrementing), for example:

- P#M 5.3, Bit_Byte = 0, Inc_Value = 6 => P#M 6.1 or
- P#M 5.3, Bit_Byte = 0, Inc_Value = -6 => P#M 4.5.

The area information of the pointer is not influenced by the function.

The FC intercepts an overflow/underflow of the pointer. In this case the pointer is not changed and the output variable "RET_VAL" (error handling possible) is set to "1" (until the next correct processing of FC3). This is the case where:

- 1. Bit address is selected and Inc_Value >7, or <-7
- 2. Bit or byte address is selected and the change would result in a "negative" byte address
- 3. Bit or byte address is selected and the change would result in an illegally large byte address.

Sample Block in STL to Change the Pointer

```

FUNCTION FC 3: BOOL
TITLE =Routing Pointers
//FC3 can be used to change pointers.
AUTHOR : AUT1CS1
FAMILY : INDADDR
NAME : ADDRPOINT
VERSION : 0.0

VAR_INPUT
    Bit_Byte : BOOL ; //0: Bit address, 1: byte address
    Inc_Value : INT ; //Increment (if value neg. => decrement/if
value pos. => increment)
END_VAR

VAR_IN_OUT
    Pointer : DWORD ; //Pointer to be changed
END_VAR
VAR_TEMP
    Inc_Value1 : INT ; //Interim value increment
    Pointer1 : DWORD ; //Interim value pointer
    Int_Value : DWORD ; //Auxiliary variable
END_VAR
BEGIN
NETWORK
TITLE =
//The block intercepts changes that change the area information of
//the pointer or that lead to "negative" pointers automatically.
    SET    ; //Set RLO to 1 and
    R      #RET_VAL; //reset overflow
    L      #Pointer; //Supply value to temporary
    T      #Pointer1; //interim value pointer
    L      #Inc_Value; //Supply value of temporary
    T      #Inc_Value1; //interim value increment
    A      #Bit_Byte; //If =1, byte address instruction
    JC     Byte; //Jump to byte address calculation
    L      7; //If value of increment > 7,
    L      #Inc_Value1;
    <I    ;
    S      #RET_VAL; //then set RET_VAL and
    JC     End; //jump to End
    L      -7; //If value of increment < -7,
    <I    ;
    S      #RET_VAL; //then set RET_VAL and
    JC     End; //jump to End
    A      L      1.3; //If bit 4 of the value = 1
                //(Inc_Value negative)

```

```

JC      neg; //then jump to bit address subtraction
L      #Pointer1; //Load pointer address information
L      #Inc_Value1; //and add the increment
+D      ;
JU      test; //Jump to test for negative result
neg:   L      #Pointer1; //Load pointer address information
L      #Inc_Value1; //Load the increment
NEGI   ; //Negate the negative value,
-D      ; //subtract the value
JU      test; //and jump to test
Byte:  L      0; //Start of byte address change
L      #Inc_Value1; //If increment >=0, then
<I     ;
JC      pos; //jump to addition, otherwise
L      #Pointer1; //Load pointer address information,
L      #Inc_Value1; //load the increment,
NEGI   ; //negate the negative value,
SLD    3; //shift the increment 3 digits to the left,
-D      ; //subtract the value,
JU      test; //and jump to test
pos:   SLD    3; //Shift the increment 3 digits to the left
L      #Pointer1; //Load pointer address information
+D      ; //Add increment
test:  T      #Int_Value; //Transfer results of calculation
//to Int_Value
A      L      7.3; //If invalid byte address (too large or
S      #RET_VAL; //negative), then set RET_VAL
JC      End; //and jump to End,
L      #Int_Value; //otherwise transfer result
T      #Pointer; //to pointer
End:   NOP    0;
END_FUNCTION

```

A.3.4.5 Format of the Parameter Type ANY


STEP 7 stores the parameter type ANY in 10 bytes. When constructing a parameter of the type ANY, you must ensure that all 10 bytes are occupied because the called block evaluates the whole contents of the parameter. If, for example, you specify a DB number in byte 4, you must also explicitly specify the memory area in byte 6.

STEP 7 manages the data of elementary and complex data types differently from the data for parameter types.

ANY Format for Data Types

For elementary and complex data types STEP 7 stores the following data:

- Data types
- Repetition factor
- DB number
- Memory area in which the information is stored
- Start address of the data



The repetition factor identifies a quantity of the indicated data type to be transferred by the parameter type ANY. This means you can specify a data area and also use arrays and structures in conjunction with the parameter type ANY. STEP 7 identifies arrays and structures as a number (with the help of the repetition factor) of data types. If, for example, 10 words are to be transferred, the value 10 must be entered for the repetition factor and the value 04 must be entered for the data type.

The address is stored in the format Byte.Bit where the byte address is stored in bits 0 to 2 of byte 7, in bits 0 to 7 of byte 8, and in bits 3 to 7 of byte 9. The bit address is stored in bits 0 to 2 of byte 9.

With a null pointer of the type NIL all bytes from byte 1 are assigned 0.


The following tables show the coding of the data types or of the memory areas for the parameter type ANY.

Coding of the Data Types		
Hexadecimal Code	Data Type	Description
b#16#00	NIL	Null pointer
b#16#01	BOOL	Bits
b#16#02	BYTE	Bytes (8 bits)
b#16#03	CHAR	Characters (8 bits)
b#16#04	WORD	Words (16 bits)
b#16#05	INT	Integers (16 bits)
B#16#06	DWORD	Words (32 bits)
b#16#07	DINT	Double integers (32 bits)
b#16#08	REAL	Floating-point numbers (32 bits)
b#16#09	DATE	Date
b#16#0A	TIME_OF_DAY (TOD)	Time of day
b#16#0B	TIME	Time
b#16#0C	S5TIME	Data type S5TIME
b#16#0E	DATE_AND_TIME (DT)	Date and time (64 bits)
b#16#13	STRING	String

Coding of the Memory Areas		
HexadecimalCode	Area	Description
b#16#81	I	Input area
b#16#82	Q	Output area
b#16#83	M	Bit memory area
b#16#84	DB	Data block
b#16#85	DI	Instance data block
b#16#86	L	Local data (L stack)
b#16#87	V	Previous local data

ANY Format for Parameter Types

For parameter types STEP 7 stores the data type and the address of the parameters. The repetition factor is always 1. Bytes 4, 5, and 7 are always 0. Bytes 8 and 9 indicate the number of the timer, counter, or block.



The following table shows the coding of the data types for the parameter type ANY for parameter types.

Hexadecimal Code	Data Type	Description
b#16#17	BLOCK_FB	FB number
b#16#18	BLOCK_FC	FC number
b#16#19	BLOCK_DB	DB number
b#16#1A	BLOCK_SDB	SDB number
b#16#1C	COUNTER	Counter number
b#16#1D	TIMER	Timer number

A.3.4.6 Using the Parameter Type ANY


You can define formal parameters for a block that are suitable for actual parameters of any data type. This is particularly useful when the data type of the actual parameter that is provided when the block is called is unknown or can vary (and when any data type is permitted). In the variable declaration of the block, you declare the parameter as data type ANY. You can then assign an actual parameter of any data type in STEP 7.

STEP 7 assigns 80 bits of memory for a variable of the ANY data type. If you assign an actual parameter to this formal parameter, STEP 7 codes the start address, the data type, and the length of the actual parameter in the 80 bits. The called block analyzes the 80 bits of data saved for the ANY parameter and obtains the information required for further processing.

Assigning an Actual Parameter to an ANY Parameter

If you declare the data type ANY for a parameter, you can assign an actual parameter of any data type to the formal parameter. In STEP 7, you can assign the following data types as actual parameters:

- Elementary data types: you specify the absolute address or the symbolic name of the actual parameter.
- Complex data types: you specify the symbolic name of the data with a complex data type (for example, arrays and structures).
- Timers, counters, and blocks: you specify the number (for example, T1, C20, or FB6).
- The following figure shows how data are transferred to an FC with parameters of the ANY data type.



In this example, FC100 has three parameters (*in_par1*, *in_par2*, and *in_par3*) declared as the ANY data type.

- When FB10 calls FC100, FB10 transfers an integer (the static variable speed), a word (MW100), and a double word to DB10 (DB10.DBD40).
- When FB11 calls FC100, FB11 transfers an array of real numbers (the temporary variable "Thermo"), a Boolean value (M 1.3), and a timer (T2).

Specifying a Data Area for an ANY Parameter

You can assign not only individual addresses (for example, MW100) to an ANY parameter but you can also specify a data area. If you want to assign a data area as the actual parameter, use the following format of a constant to specify the amount of data to be transferred:

p# Area ID Byte.Bit Data Type Repetition Factor

For the *data type* element, you can specify all elementary data types and the data type DATE_AND_TIME in the format for constants. If the data type is not BOOL, the bit address of 0 (x.0) must be specified. The following table illustrates examples of the format for specifying memory areas to be transferred to an ANY parameter.

Actual Parameter	Description
p# M 50.0 BYTE 10	Specifies 10 bytes in the byte memory area: MB50 to MB59.
p# DB10.DBX5.0 S5TIME 3	Specifies 3 units of data of the data type S5TIME, that are located in DB10: DB byte 5 to DB byte 10.
p# Q 10.0 BOOL 4	Specifies 4 bits in the output area: Q 10.0 to Q 10.3.

Example for Using the Parameter Type ANY

The following example shows how you can copy a memory area of 10 bytes using the parameter type ANY and the system function SFC20 BLKMOV.

STL	Explanation
FUNCTION FC10: VOID	
VAR_TEMP	
Source : ANY;	
Target : ANY;	
END_VAR	
BEGIN	
LAR1 P#Source;	Load the start address of the ANY pointer in AR1.
L B#16#10;	Load the syntax ID and
T LB[AR1,P#0.0];	transfer it to the ANY pointer.
L B#16#02;	Load data type Byte and
T LB[AR1,P#1.0];	transfer it to the ANY pointer.
L 10;	Load 10 bytes and
T LW[AR1,P#2.0];	transfer them to the ANY pointer.
L 22;	Source is DB22, DBB11
T LW[AR1,P#4.0];	
L P#DBX11.0;	
T LD[AR1,P#6.0];	
LAR1 P#Target;	Load the start address of the ANY pointer in AR1.
L B#16#10;	Load the syntax ID and
T LB[AR1,P#0.0];	transfer it to the ANY pointer.
L B#16#02;	Load data type Byte and
T LB[AR1,P#1.0];	transfer it to the ANY pointer.
L 10;	Load 10 bytes and
T LW[AR1,P#2.0];	transfer them to the ANY pointer.
L 33;	Target is DB33, DBB202
T LW[AR1,P#4.0];	
L P#DBX202.0;	
T LD[AR1,P#6.0];	
CALL SFC 20 (Call the system function BLKMOV
SRCBLK := Source,	Evaluate the BR bit and MW12
RET_VAL := MW 12,	
DSTBLK := Target	
);	
END_FUNCTION	

A.3.4.7 Assigning Data Types to Local Data of Logic Blocks

With STEP 7, the data types (elementary and complex data types and parameter types) that can be assigned to the local data of a block in the variable declaration are restricted.

Valid Data Types for the Local Data of an OB

The following table illustrates the restrictions (-) for declaring local data for an OB. Since you cannot call an OB, an OB cannot have parameters (input, output, or in/out). Since an OB does not have an instance DB, you cannot declare any static variables for an OB. The data types of the temporary variables of an OB can be elementary or complex data types and the data type ANY.

The valid assignments are shown by the ● symbol.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input	—	—	—	—	—	—	—
Output	—	—	—	—	—	—	—
In/out	—	—	—	—	—	—	—
Static	—	—	—	—	—	—	—
Temporary	●(1)	●(1)	—	—	—	—	●(1)

⁽¹⁾ Located in the L stack of the OB.

Valid Data Types for the Local Data of an FB

The following table illustrates the restrictions (-) for declaring local data for an FB. Due to the instance DB, there are less restrictions when declaring local data for an FB. When declaring input parameters there are no restrictions whatsoever; for an output parameter you cannot declare any parameter types, and for in/out parameters only the parameter types POINTER and ANY are permitted. You can declare temporary variables as the ANY data type. All other parameter types are illegal.

The valid assignments are shown by the ● symbol.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input	●	●	●	●	●	●	●
Output	●	●	—	—	—	—	—
In/out	●	●(1)(3)	—	—	—	●	●
Static	●	●	—	—	—	—	—
Temporary	●(2)	●(2)	—	—	—	—	●(2)

¹ Stored as a reference (48-bit pointer) in the instance data block.
² Located in the L stack of the FB.
³ STRINGS can be defined in the default length only.

Valid Data Types for the Local Data of an FC

The following table illustrates the restrictions (-) for declaring local data for an FC. Since an FC does not have an instance DB, it also has no static variables. For input, output, and in/out parameters of an FC, only the parameter types POINTER and ANY are permitted. You can also declare temporary variables of the ANY parameter type.

The valid assignments are shown by the ● symbol.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input	●	●(2)	●	●	●	●	●
Output	●	●(2)	—	—	—	●	●
In/out	●	●(2)	—	—	—	●	●
Temporary	●(1)	●(1)	—	—	—	—	●(1)
¹ Located in the L stack of the FC. ² STRINGS can be defined in the default length only.							

A.3.4.8 Permitted Data Types when Transferring Parameters

Rules for Transferring Parameters Between Blocks

When you assign actual parameters to formal parameters, you can specify either an absolute address, a symbolic name, or a constant. STEP 7 restricts the valid assignments for the various parameters. Output and in/out parameters, for example, cannot be assigned a constant value (since the purpose of an output or an in/out parameter is to change its value). These restrictions apply particularly to parameters with complex data types to which neither an absolute address nor a constant can be assigned.

The following tables illustrate the restrictions (-) involving the data types of actual parameters that are assigned to formal parameters.


The valid assignments are shown by the ● symbol.

		Elementary Data Types		
Declaration Type	Absolute Address	Symbolic Name (in the Symbol Table)	Temporary Local Symbol	Constant
Input	●	●	●	●
Output	●	●	●	—
In/out	●	●	●	—

		Complex Data Types		
Declaration Type	Absolute Address	Symbolic Name of the DB Element (in the Symbol Table)	Temporary Local Symbol	Constant
Input	—	●	●	—
Output	—	●	●	—
In/out	—	●	●	—

Valid Data Types for the Call of a Function by a Function

You can assign the formal parameters of a calling FC to the formal parameters of a called FC. The following figure illustrates the formal parameters of FC10 that are assigned as actual parameters to the formal parameters of FC12.




STEP 7 restricts the assignment of formal parameters of an FC as actual parameters for the formal parameters of a different FC. You cannot, for example, assign parameters with complex data types or a parameter type as the actual parameter.

The following table shows the permitted data types (●) when one FC calls another FC.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input → Input	●	—	—	—	—	—	—
Input → Output	—	—	—	—	—	—	—
Input → In/out	—	—	—	—	—	—	—
Output → Input	—	—	—	—	—	—	—
Output → Output	●	—	—	—	—	—	—
Output → In/out	—	—	—	—	—	—	—
In/out → Input	●	—	—	—	—	—	—
In/out → Output	●	—	—	—	—	—	—
In/out → In/out	●	—	—	—	—	—	—

Valid Data Types for the Call of a Function by a Function Block

You can assign the formal parameters of a calling FB to the formal parameters of a called FC. The following figure illustrates the formal parameters of FB10 that are assigned as actual parameters to the formal parameters of FC12.




STEP 7 restricts the assignment of the formal parameters of an FB to the formal parameters of an FC. You cannot, for example, assign parameters of the parameter type as actual parameters. The following table shows the permitted data types (●) when an FB calls an FC.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input → Input	●	●	—	—	—	—	—
Input → Output	—	—	—	—	—	—	—
Input → In/out	—	—	—	—	—	—	—
Output → Input	—	—	—	—	—	—	—
Output → Output	●	●	—	—	—	—	—
Output → In/out	—	—	—	—	—	—	—
In/out → Input	●	—	—	—	—	—	—
In/out → Output	●	—	—	—	—	—	—
In/out → In/out	●	—	—	—	—	—	—

Valid Data Types for the Call of a Function Block by a Function

You can assign the formal parameters of a calling FC to the formal parameters of a called FB. The following figure illustrates the formal parameters of FC10 that are assigned as actual parameters to the formal parameters of FB12.




STEP 7 restricts the assignment of formal parameters of an FC to the formal parameters of an FB. You cannot, for example, assign parameters with a complex data type as actual parameters. You can, however, assign input parameters of the parameter types TIMER, COUNTER, or BLOCK to the input parameters of the called FB.

The following table shows the permitted data types (●) when an FC calls an FB.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input → Input	●	—	●	●	●	—	—
Input → Output	—	—	—	—	—	—	—
Input → In/out	—	—	—	—	—	—	—
Output → Input	—	—	—	—	—	—	—
Output → Output	●	—	—	—	—	—	—
Output → In/out	—	—	—	—	—	—	—
In/out → Input	●	—	—	—	—	—	—
In/out → Output	●	—	—	—	—	—	—
In/out → In/out	●	—	—	—	—	—	—

Valid Data Types for the Call of a Function Block by a Function Block

You can assign the formal parameters of a calling FB to the formal parameters of a called FB. The following figure illustrates the formal parameters of FB10 that are assigned as actual parameters to the formal parameters of FB12.



STEP 7 restricts the assignment of the formal parameters of an FB to the formal parameters of another FB. You cannot, for example, assign input and output parameters with complex data types as the actual parameters for the input and output parameters of a called FB. You can, however, assign input parameters of the parameter types TIMER, COUNTER, or BLOCK to the input parameters of the called FB.

The following table shows the permitted data types (●) when an FB calls another FB.

Declaration Type	Elementary Data Types	Complex Data Types	Parameter Type				
			TIMER	COUNTER	BLOCK	POINTER	ANY
Input → Input	●	●	●	●	●	—	—
Input → Output	—	—	—	—	—	—	—
Input → In/out	—	—	—	—	—	—	—
Output → Input	—	—	—	—	—	—	—
Output → Output	●	●	—	—	—	—	—
Output → In/out	—	—	—	—	—	—	—
In/out → Input	●	—	—	—	—	—	—
In/out → Output	●	—	—	—	—	—	—
In/out → In/out	●	—	—	—	—	—	—

A.3.4.9 Transferring to IN_OUT Parameters of a Function Block

When complex data types are transferred to IN_OUT parameters of a function block (FB) the address of the variable is transferred (call by reference).

When elementary data types are transferred to IN_OUT parameters of a function block the values are copied into the instance data block before the function block is started and copied out of the instance data block after the function block is ended.

This means IN_OUT variables of elementary data type can be initialized with a value.

It is not possible, however, to specify a constant in place of an IN_OUT variable as the actual parameter in a call because a constant cannot be written to.

Variables of the data type STRUCT or ARRAY cannot be initialized because only one address is in the instance data block in this case.

A.4 Working with Older Projects

A.4.1 Converting Version 1 Projects

You can re-use projects you created with version 1 of STEP 7. To do this, you have to convert the version 1 projects to version 2 projects.

The following components of a version 1 project are retained:

- Project structure with programs
- Blocks
- STL source files
- Symbol table

The configuration of the hardware is not converted. You can copy the program components contained in the project to other projects. You can also add a station to the new project and configure and assign parameters to it.

Once you have converted to version 2 you can decide in a dialog box whether you now want to convert this version 2 project to a project in your current STEP 7 version.

Note

The individual blocks stay as version 1 blocks as regards their properties. The code generated in version 1 is not changed and the blocks cannot therefore be used in conjunction with multiple instances.

If you want to declare multiple instances in the converted blocks, generate STL source files from the converted blocks first using the "LAD/STL/FBD: Programming Blocks" application and then compile them back into blocks.

Programming multiple instances is a new feature of STEP 7 version 2 used to create function blocks (FB). If you want to continue using function blocks created with version 1 in the same way in a version 2 project, you do not need to convert them.

Procedure

To convert version 1 projects, proceed as follows:

1. Select the menu command **File > Open Version 1 Project**.
2. In the dialog box which appears, select the version 1 project which you want to use in version 2. You recognize a version 1 project by its extension *.s7a.
3. Then, in the next dialog box, enter the name of the new project to which you want the version 1 project to be converted.

A.4.2 Converting Version 2 Projects

In STEP 7 you can also open version 2 projects using the menu command **File > Open**.

Version 2 projects/libraries can be converted (migrated) to your current STEP 7 version using the menu command **File > Save As** and the option "Rearrange before saving." The project is then saved as a project with the current STEP 7 version.

You can edit projects and libraries from older STEP 7 versions retaining their format and save them by selecting the older STEP 7 version as the file type in the "Save Project As" dialog box. For example, to edit the objects with STEP 7 version 2.1, select "Project 2.x" or "Library 2.x" here (it is not possible to save as Version 2 as from Version 5.1 on. Also refer to Editing Version 2 projects and libraries).

Designation of the File Type

	STEP 7 V3	From STEP 7 V4
File type of the current version	Project3.x Library3.x	Project Library
File type of the older version	Project2.x Library2.x	Project2.x Library2.x

This means you only have access to the scope of functions of the older STEP 7 version. You can, however, still continue to manage the projects and libraries with the older STEP 7 version.

Note

The upgrade from version 3 to versions 4 and higher only involves a change in name: the format has remained identical. Therefore there is no file type "Project3.x" in STEP 7 V4.

Procedure

To convert version 2 projects to the format of the current STEP 7 version, proceed as follows:

1. Execute the "Save As" command in the File menu with the "Rearrange before saving" option for the project.
2. Select the file type "Project" in the "Save Project As" dialog box and click the "Save" button.

To convert version 2 projects to the current STEP 7 version while retaining their format, proceed as follows:

1. Execute step 1 above if necessary.
2. Select the file type of the older STEP 7 version in the "Save Project As" dialog box and click the "Save" button.

A.4.3 Notes on STEP 7 V.2.1 Projects with GD Communication

- If you want to convert a project with global data from STEP 7 V2.1 to STEP 7 V5, you must first open the GD table with STEP 7 V5.0 in the STEP 7 V2.1 project. The communication data configured previously are automatically converted into the new structure via GD communication.
- When you archive STEP 7 V2.1 projects, older programs (ARJ, PKZIP...) may issue an error message if the project contains files with names which are more than eight characters in length. This message also appears if the MPI network in the STEP 7 V2.1 project was edited with an ID which is more than 8 characters in length. In STEP 7 V2.1 projects with global data, edit a name for the MPI network which is a maximum of eight characters in length before you start to configure global data communication for the first time.
- If you want to rename a STEP 7 V2.1 project, you must reassign the headings of the columns (CPUs) in the GD table by re-selecting the appropriate CPU. If you restore the old project name, the assignments are displayed once more.

A.4.4 DP-Slaves with Missing or Faulty GSD Files

If you process older station configurations with STEP 7 Version 5.1, it is possible in rare cases that the GSD file of a DP slave is missing or cannot be compiled (for example, due to syntax errors in the GSD file).

In this case STEP 7 generates a "dummy" slave which represents the configured slave, for example after a station download to the programming device or after an older project has been opened and processed further. This "dummy" slave can only be processed to a limited extent. You cannot change the slave structure (DP identifiers) and the slave parameters. However, renewed downloading to the station is possible. The original configuration of the slave is retained. The complete DP slave can also be deleted.

Reconfiguring and Assigning Parameters to the DP Slave

If you wish to reconfigure or reassign parameters to the DP slave, you have to request an up-to-date GSD file for this DP slave from the manufacturer and make it available by using the menu command **Options > Install GSD Files**.

After the correct GSD file has been installed, it is used to represent the DP slave. The DP slave contains its data and can be processed again completely.

A.5 Sample Programs

A.5.1 Sample Projects and Sample Programs

The STEP 7 installation CD contains a number of sample projects that are listed below. You will find the sample projects in the "open" dialog of the SIMATIC Manager ("Sample Projects" tab). Other sample projects may also be added when optional packages are installed. For information on these sample projects, refer to the documentation for the optional packages.

Examples and Sample Projects	Included on CD	Described in this Documentation	Description in OB1
"ZEn01_01_STEP7_**" to "ZEn01_06_STEP7_**" projects (getting started and exercises)	•	Separate Manual	•
"ZEn01_11_STEP7_DezP" project (sample PROFIBUS DP configuration)	•	-	-
"ZEn01_08_STEP7_Blending" project (industrial blending process)	•	•	-
"ZEn01_09_STEP7_Zebra" project (traffic signal control at a zebra crossing/crosswalk)	•		•
"Zen01_10_STEP7_COM_SFB" project (data exchange between two S7-400 CPUs)	•		•
"ZXX01_14_HSystem_S7400H" project (starting project for fault-tolerant systems)	•	Separate manual	•
"ZXX01_15_HSystem_RED_IO" project (starting project for fault-tolerant systems with redundant I/O devices)	•	Separate manual	•
"Zen01_11_STEP7_COM_SFC1" and "Zen01_12_STEP7_COM_SFC2" project (data exchange using communication SFCs for non-configured connections)	•		•
Project "ZEn01_13_STEP7_PID-Temp" (Example for temperature controllers FB 58 and FB 59)	•		•
Example of handling time-of-day interrupts		•	
Example of handling time-delay interrupts		•	
Example of masking and unmasking synchronous errors		•	
Example of disabling and enabling interrupts and asynchronous errors		•	
Example of the delayed processing of interrupts and asynchronous errors		•	

The emphasis of the examples is not on teaching a particular programming style or the specialist knowledge needed to control a particular process. The examples are simply intended to illustrate the steps that must be followed to design a program.

Deleting and Installing the Supplied Sample Projects

The supplied sample projects can be deleted in the SIMATIC Manager and then reinstalled. To install the sample projects, you must start the STEP 7 V5.0 setup program. The sample projects can be installed selectively at a later date. Copies of the supplied sample projects and self-created sample projects made using the menu command "Save As" can only be saved as user projects.

Note

When STEP 7 is installed, the supplied sample projects are copied, unless otherwise specified. If you have edited the supplied sample projects, these modified projects are overwritten with the originals when STEP 7 is reinstalled.


For this reason, you should copy the supplied sample projects before making any changes and then only edit the copies.

A.5.2 Sample Program for an Industrial Blending Process

The sample program makes use of information that you have already read in part 1 of the manual about controlling an industrial blending process.

Task

Two ingredients (ingredient A and ingredient B) are mixed together in a mixing tank by an agitator. The finished product is drained from the tank through a drain valve. The following figure shows a diagram of the sample process.



Describing the Parts of a Process

Part 1 of the manual included a description of how you divide up the sample process into functional areas and individual tasks. The individual areas are described below.

The area for ingredients A and B:

- The pipes for each of the ingredients are equipped with an inlet and a feed valve and feed pump.
- The inlet pipes also have flow sensors.
- Turning on the feed pumps must be interlocked when the tank level sensor indicates that the tank is full.
- The activation of the feed pumps must be interlocked when the drain valve is open.
- The inlet and feed valves must be opened at the earliest 1 second after starting the feed pump.
- The valves must be closed immediately after the feed pumps stop (signal from the flow sensor) to prevent ingredients leaking from the pump.
- The activation of the feed pumps is combined with a time monitoring function, in other words, within 7 seconds after the pumps start, the flow sensor must report a flow.
- The feed pumps must be turned off as quickly as possible if the flow sensor no longer signals a flow while the feed pumps are running.
- The number of times that the feed pumps are started must be counted (maintenance interval).

Mixing tank area:

- The activation of the agitator motor must be interlocked when the tank level sensor indicates "level below minimum" or the drain valve is open.
- The agitator motor sends a response signal after reaching the rated speed. If this signal is not received within 10 seconds after the motor is activated, the motor must be turned off.
- The number of times that the agitator motor starts must be counted (maintenance interval).
- Three sensors must be installed in the mixing tank:
 - Tank full: a normally closed contact. When the maximum tank level is reached, the contact is opened.
 - Level in tank above minimum: a normally open contact. If the minimum level is reached, the contact is closed.
 - Tank not empty: a normally open contact. If the tank is not empty, the contact is closed.

Drain area:

- Drainage of the tank is controlled by a solenoid valve.
- The solenoid valve is controlled by the operator, but must be closed again at the latest when the "tank empty" signal is generated.
- Opening the drain valve is interlocked when
 - the agitator motor is running
 - the tank is empty

Operator Station

To allow an operator to start, stop, and monitor the process, an operator station is also required. The operator station is equipped with the following:


- Switches for controlling the most important stages of the process. Using the "reset maintenance display" switch, you can turn off the maintenance display lamps for the motors due for maintenance and reset the corresponding counters for the maintenance interval to 0.
- Display lamps to indicate the status of the process.
- The emergency stop switch.

A.5.2.1 Defining Logic Blocks

You structure the program by distributing the user program in various blocks and by establishing a hierarchy for block calls.

Hierarchy of the Block Calls

The following figure shows the hierarchy of the blocks to be called in the structured program.



- OB1: The interface to the operating system of the CPU and contains the main program. In OB1 the blocks FB1 and FC1 are called and the specific parameters required to control the process are transferred.
- FB1: The feed pump for ingredient A, the feed pump for ingredient B and the agitator motor can be controlled by a single function block because the requirements (on, off, count applications etc.) are identical.
- Instance DB 1-3: The actual parameters and the static data for controlling the feed pumps for ingredient A, ingredient B and for the agitator motor are different and are therefore stored in three instance DBs associated with FB1.
- FC1: The inlet and feed valves for ingredients A and B and the drain valve also use a common logic block. As only the function "open and close" must be programmed, one single FC is sufficient.

A.5.2.2 Assigning Symbolic Names

Defining Symbolic Names

Symbols are used in the sample program and they must be defined in the symbol table using STEP 7. The following tables show the symbolic names and the absolute addresses of the program elements used.

Symbolic Addresses for Feed Pump, Agitator Motor, and Inlet Valves			
Symbolic Name	Address	Data Type	Description
Feed_pump_A_start	I0.0	BOOL	Starts the feed pump for ingredient A
Feed_pump_A_stop	I0.1	BOOL	Stops the feed pump for ingredient A
Flow_A	I0.2	BOOL	Ingredient A flowing
Inlet_valve_A	Q4.0	BOOL	Activates the inlet valve for ingredient A
Feed_valve_A	Q4.1	BOOL	Activates the feed valve for ingredient A
Feed_pump_A_on	Q4.2	BOOL	Lamp for "feed pump ingredient A running"
Feed_pump_A_off	Q4.3	BOOL	Lamp for "feed pump ingredient A not running"
Feed_pump_A	Q4.4	BOOL	Activates the feed pump for ingredient A
Feed_pump_A_fault	Q4.5	BOOL	Lamp for "feed pump A fault"
Feed_pump_A_maint	Q4.6	BOOL	Lamp for "feed pump A maintenance"
Feed_pump_B_start	I0.3	BOOL	Starts the feed pump for ingredient B
Feed_pump_B_stop	I0.4	BOOL	Stops the feed pump for ingredient B
Flow_B	I0.5	BOOL	Ingredient B flowing
Inlet_valve_B	Q5.0	BOOL	Activates the inlet valve for ingredient A
Feed_valve_B	Q5.1	BOOL	Activates the feed valve for ingredient B
Feed_pump_B_on	Q5.2	BOOL	Lamp for "feed pump ingredient B running"
Feed_pump_B_off	Q5.3	BOOL	Lamp for "feed pump ingredient B not running"
Feed_pump_B	Q5.4	BOOL	Activates the feed pump for ingredient B
Feed_pump_B_fault	Q5.5	BOOL	Lamp for "feed pump B fault"
Feed_pump_B_maint	Q5.6	BOOL	Lamp for "feed pump B maintenance"
Agitator_running	I1.0	BOOL	Response signal of the agitator motor
Agitator_start	I1.1	BOOL	Agitator start button
Agitator_stop	I1.2	BOOL	Agitator stop button
Agitator	Q8.0	BOOL	Activates the agitator
Agitator_on	Q8.1	BOOL	Lamp for "agitator running"
Agitator_off	Q8.2	BOOL	Lamp for "agitator not running"
Agitator_fault	Q8.3	BOOL	Lamp for "agitator motor fault"
Agitator_maint	Q8.4	BOOL	Lamp for "agitator motor maintenance"

Symbolic Addresses for Sensors and Displaying the Level of the Tank			
Symbolic Name	Address	Data Type	Description
Tank_below_max	I1.3	BOOL	Sensor "mixing tank not full"
Tank_above_min	I1.4	BOOL	Sensor "mixing tank above minimum level"
Tank_not_empty	I1.5	BOOL	Sensor "mixing tank not empty"
Tank_max_disp	Q9.0	BOOL	Lamp for "mixing tank full"
Tank_min_disp	Q9.1	BOOL	Lamp for "mixing tank below minimum level"
Tank_empty_disp	Q9.2	BOOL	Lamp for "mixing tank empty"

Symbolic Addresses for the Drain Valve			
Symbolic Name	Address	Data Type	Description
Drain_open	I0.6	BOOL	Button for opening the drain valve
Drain_closed	I0.7	BOOL	Button for closing the drain valve
Drain	Q9.5	BOOL	Activates the drain valve
Drain_open_disp	Q9.6	BOOL	Lamp for "drain valve open"
Drain_closed_disp	Q9.7	BOOL	Lamp for "drain valve closed"

Symbolic Addresses for the Other Program Elements			
Symbolic Name	Address	Data Type	Description
EMER_STOP_off	I1.6	BOOL	EMERGENCY STOP switch
Reset_maint	I1.7	BOOL	Reset switch for the maintenance lamps on all motors
Motor_block	FB1	FB1	FB for controlling pumps and motor
Valve_block	FC1	FC1	FC for controlling the valves
DB_feed_pump_A	DB1	FB1	Instance DB for controlling feed pump A
DB_feed_pump_B	DB2	FB1	Instance DB for controlling feed pump B
DB_agitator	DB3	FB1	Instance DB for controlling the agitator motor

A.5.2.3 Creating the FB for the Motor


What is Required of the FB?

The FB for the motor contains the following logical functions:

- There is a start and a stop input.
- A series of interlocks allow the operation of the devices (pumps and agitator motor). The status of the interlocks is saved in the temporary local data (L stack) of OB1 ("Motor_enable," "Valve_enable") and is logically combined with the start and stop inputs when the FB for the motor is processed.
- Feedback from the devices must appear within a certain time. Otherwise, it is assumed that an error or fault has occurred. The function then stops the motor.
- The point in time and the duration of the response or error/fault cycle must be specified.
- If the start button is pressed and the motor enabled, the device switches itself on and runs until the stop button is pressed.
- When the device is switched on, a timer starts to run. If the response signal from the device is not received before the timer has expired, the device stops.

Specifying the Inputs and Outputs

The following figure shows the inputs and outputs of the general FB for the motor.



Defining the Parameters for the FB

If you use a multiple instance FB for the motor (for controlling both pumps and the motor) you must define general parameter names for the inputs and outputs.

The FB for the motor in the sample process requires the following:

- It must have signals from the operator station to stop and start the motor and pumps.
- It requires a response signal from the motor and pumps to indicate that the motor is running.
- It must calculate the time between sending the signal to activate the motor and receiving the response signal. If no response signal is received in this time, the motor must be switched off.
- It must turn the lamps on the operator station on and off.
- It supplies a signal to activate the motor.

These requirements can be specified as inputs and outputs to the FB. The following table shows the parameters of the FB for the motor in our sample process.

Parameter Name	Input	Output	In/Out
Start	n		
Stop	n		
Response	n		
Reset_maint	n		
Timer_No	n		
Response_Time	n		
Fault		n	
Start_Dsp		n	
Stop_Dsp		n	
Maint		n	
Motor			n

Declaring the Variables of the FB for the Motor

You must declare the input, output, and in/out parameters of the FB for the motor.

Address	Declaration	Name	Type	Initial Value
0.0	IN	Start	BOOL	FALSE
0.1	IN	Stop	BOOL	FALSE
0.2	IN	Response	BOOL	FALSE
0.3	IN	Reset_Maint	BOOL	FALSE
2.0	IN	Timer_No	TIMER	
4.0	IN	Response_Time	S5TIME	S5T#0MS
6.0	OUT	Fault	BOOL	FALSE
6.1	OUT	Start_Dsp	BOOL	FALSE
6.2	OUT	Stop_Dsp	BOOL	FALSE
6.3	OUT	Maint	BOOL	FALSE
8.0	IN_OUT	Motor	BOOL	FALSE
10.0	STAT	Time_bin	WORD	W#16#0
12.0	STAT	Time_BCD	WORD	W#16#0
14.0	STAT	Starts	INT	0
16.0	STAT	Start_Edge	BOOL	FALSE

With FBs, the input, output, in/out, and static variables are saved in the instance DB specified in the call statement. The temporary variables are stored in the L stack.

Programming the FB for the Motor

In STEP 7, every block that is called by a different block must be created before the block containing its call. In the sample program, you must therefore create the FB for the motor before OB1.

The code section of FB1 appears as follows in the STL programming language:

Network 1 Start/stop and latching

```
A(  
O #Start  
O #Motor  
)  
AN #Stop  
= #Motor
```

Network 2 Startup monitoring

```
A #Motor  
L #Response_Time  
SD #Timer_No  
AN #Motor  
R #Timer_No  
L #Timer_No  
T #Timer_bin  
LC #Timer_No  
T #Timer_BCD  
A #Timer_No  
AN #Response  
S #Fault  
R #Motor
```

Network 3 Start lamp and fault reset

```
A #Response  
= #Start_Dsp  
R #Fault
```

Network 4 Stop lamp

```
AN #Response  
= #Stop_Dsp
```

Network 5 Counting the starts

```
A #Motor  
FP #Start_Edge  
JCN lab1  
L #Starts  
+ 1  
T #Starts  
  
lab1: NOP 0
```

Network 6 Maintenance lamp

```
L #Starts  
L 50  
>=|  
= #Maint
```

Network 7 Reset counter for number of starts

```
A #Reset_Maint
A #Maint
JCN      END
L 0
T #Starts
END: NOP 0
```

Creating the Instance Data Blocks

Create three data blocks and open them one after another. In the "New Data Block" dialog box select the option "Data block referencing a function block." In the "Reference" list box select "FB1." The data blocks are then specified as instance data blocks with a fixed assignment to FB1.

A.5.2.4 Creating the FC for the Valves

What is Required of the FC?

The function for the inlet and feed valves and for the drain valve contains the following logical functions:


- There is an input for opening and an input for closing the valves.
- Interlocks allow the valves to be opened. The state of the interlocks is saved in the temporary local data (L stack) of OB1 ("Valve_enable") and is logically combined with the inputs for opening and closing when the FC for the valves is processed.

The following table shows the parameters that must be transferred to the FC.

Parameters for the Valves	Input	Output	In/Out
Open	✓		
Close	✓		
Dsp_Open		✓	
Dsp_Closed		✓	
Valve			✓

Specifying the Inputs and Outputs

The following figure shows the inputs and outputs of the general FC for the valves. The devices that call the FB for the motor transfer input parameters. The FC for the valves returns output parameters.



Declaring the Variables of the FC for the Valves

Just as with the FB for the motor, you must also declare the input, output, and in/out parameters for the FC for the valves (see following variable declaration table).

Address	Declaration	Name	Type	Initial Value
0.0	IN	Open	BOOL	FALSE
0.1	IN	Close	BOOL	FALSE
2.0	OUT	Dsp_Open	BOOL	FALSE
2.1	OUT	Dsp_Closed	BOOL	FALSE
4.0	IN_OUT	Valve	BOOL	FALSE

With FCs, the temporary variables are saved in the L stack. The input, output, and in/out variables are saved as pointers to the logic block that called the FC. Additional memory space in the L stack (after the temporary variables) is used for these variables.

Programming the FC for the Valves

The FC1 function for the valves must be created before OB1 since the called blocks must be created before the calling blocks.

The code section of FC1 appears as shown below in the STL programming language:

Network 1 Open/close and latching

```

A(
O #Open
O #Valve
)
AN #Close
= #Valve

```

Network 2 Display "valve open"

```

A #Valve
= #Dsp_Open

```

Network 3 Display "valve closed"

```

AN #Valve
= #Dsp_Closed

```

A.5.2.5 Creating OB1

OB1 decides the structure of the sample program. OB1 also contains the parameters that are transferred to the various functions, for example:

- The STL networks for the feed pumps and the agitator motor supply the FB for the motor with the input parameters for starting ("Start"), stopping ("Stop"), for the response ("Response"), and for resetting the maintenance display ("Reset_Maint"). The FB for the motor is processed in every cycle of the PLC.
- If the FB for the motor is processed, the inputs Timer_No and Response_Time inform the function of the timer being used and which time must be measured.
- The FC for the valves and the FB for the motors are processed in every program cycle of the programmable controller because they are called in OB1.

The program uses the FB for the motor with different instance DBs to handle the tasks for controlling the feed pumps and the agitator motor.

Declaring Variables for OB1


The variable declaration table for OB1 is shown below. The first 20 bytes contain the start information of OB1 and must not be modified.

Address	Declaration	Name	Type
0.0	TEMP	OB1_EV_CLASS	BYTE
1.0	TEMP	OB1_SCAN1	BYTE
2.0	TEMP	OB1_PRIORITY	BYTE
3.0	TEMP	OB1_OB_NUMBR	BYTE
4.0	TEMP	OB1_RESERVED_1	BYTE
5.0	TEMP	OB1_RESERVED_2	BYTE
6.0	TEMP	OB1_PREV_CYCLE	INT
8.0	TEMP	OB1_MIN_CYCLE	INT
10.0	TEMP	OB1_MAX_CYCLE	INT
12.0	TEMP	OB1_DATE_TIME	DATE_AND_TIME
20.0	TEMP	Enable_motor	BOOL
20.1	TEMP	Enable_valve	BOOL
20.2	TEMP	Start_fulfilled	BOOL
20.3	TEMP	Stop_fulfilled	BOOL
20.4	TEMP	Inlet_valve_A_open	BOOL
20.5	TEMP	Inlet_valve_A_closed	BOOL
20.6	TEMP	Feed_valve_A_open	BOOL
20.7	TEMP	Feed_valve_A_closed	BOOL
21.0	TEMP	Inlet_valve_B_open	BOOL
21.1	TEMP	Inlet_valve_B_closed	BOOL
21.2	TEMP	Feed_valve_B_open	BOOL
21.3	TEMP	Feed_valve_B_closed	BOOL
21.4	TEMP	Open_drain	BOOL
21.5	TEMP	Close_drain	BOOL
21.6	TEMP	Valve_closed_fulfilled	BOOL

Creating the Program for OB1

In STEP 7, every block that is called by a different block must be created before the block containing its call. In the sample program, you must therefore create both the FB for the motor and the FC for the valves before the program in OB1.

The blocks FB1 and FC1 are called more than once in OB1; FB1 is called with different instance DBs:



The code section of OB1 appears as shown below in the STL programming language:

Network 1 Interlocks for feed pump A

```
A "EMER_STOP_off"
A "Tank_below_max"
AN "Drain"
= #Enable_Motor
```

Network 2 Calling FB Motor for ingredient A

```
A "Feed_pump_A_start"
A #Enable_Motor
= #Start_Fulfilled
A(
O "Feed_pump_A_stop"
ON #Enable_Motor
)
= #Stop_Fulfilled
CALL "Motor_block", "DB_feed_pump_A"
Start :=#Start_Fulfilled
Stop :=#Stop_Fulfilled
Response :="Flow_A"
Reset_Maint :="Reset_maint"
Timer_No :=T12
Reponse_Time:=S5T#7S
Fault :="Feed_pump_A_fault"
Start_Dsp :="Feed_pump_A_on"
Stop_Dsp :="Feed_pump_A_off"
Maint :="Feed_pump_A_maint"
Motor :="Feed_pump_A"
```

Network 3 Delaying the valve enable ingredient A

```
A "Feed_pump_A"
L S5T#1S
SD T 13
AN "Feed_pump_A"
R T 13
A T 13
= #Enable_Valve
```

Network 4 Inlet valve control for ingredient A

```
AN "Flow_A"
AN "Feed_pump_A"
= #Close_Valve_Fulfilled
CALL "Valve_block"
Open :=#Enable_Valve
Close :=#Close_Valve_Fulfilled
Dsp_Open :=#Inlet_Valve_A_Open
Dsp_Closed:=#Inlet_Valve_A_Closed
Valve :="Inlet_Valve_A"
```

Network 5 Feed valve control for ingredient A

```

AN "Flow_A"
AN "Feed_pump_A"
=      #Close_Valve_Fulfilled
CALL   "Valve_block"
      Open  :=#Enable_Valve
      Close :=#Close_Valve_Fulfilled
      Dsp_Open   :=#Feed_Valve_A_Open
      Dsp_Closed:=#Feed_Valve_A_Closed
      Valve  :="Feed_Valve_A"

```

Network 6 Interlocks for feed pump B

```

A  "EMER_STOP_off"
A  "Tank_below_max"
AN "Drain"
=  "Enable_Motor"

```

Network 7 Calling FB Motor for ingredient B

```

A      "Feed_pump_B_start"
A      #Enable_Motor
=      #Start_Fulfilled
A(
O      "Feed_pump_B_stop"
ON #Enable_Motor
)
=      #Stop_Fulfilled
CALL   "Motor_block", "DB_feed_pump_B"
      Start :=#Start_Fulfilled
      Stop  :=#Stop_Fulfilled
      Response :="Flow_B"
      Reset_Maint :="Reset_maint"
      Timer_No :=T14
      Reponse_Time:=S5T#7S
      Fault :="Feed_pump_B_fault"
      Start_Dsp :="Feed_pump_B_on"
      Stop_Dsp :="Feed_pump_B_off"
      Maint :="Feed_pump_B_maint"
      Motor :="Feed_pump_B"

```

Network 8 Delaying the valve enable ingredient B

```

A  "Feed_pump_B"
L  S5T#1S
SD T 15
AN "Feed_pump_B"
R  T 15
A  T 15
=  #Enable_Valve

```

Network 9 Inlet valve control for ingredient B

```

AN "Flow_B"
AN "Feed_pump_B"
=      #Close_Valve_Fulfilled
CALL   "Valve_block"
      Open  :=#Enable_Valve
      Close :=#Close_Valve_Fulfilled
      Dsp_Open   :=#Inlet_Valve_B_Open
      Dsp_Closed:=#Inlet_Valve_B_Closed
      Valve  :="Inlet_Valve_B"

```

Network 10 Feed valve control for ingredient B

```

AN "Flow_B"
AN "Feed_pump_B"
=      #Close_Valve_Fulfilled
CALL   "Valve_block"
      Open  :=#Enable_Valve
      Close :=#Close_Valve_Fulfilled
      Dsp_Open   :=#Feed_Valve_B_Open
      Dsp_Closed:=#Feed_Valve_B_Closed
      Valve  :="Feed_Valve_B"

```

Network 11 Interlocks for agitator

```

A "EMER_STOP_off"
A "Tank_above_min"
AN "Drain"
= #Enable_Motor

```

Network 12 Calling FB Motor for agitator

```

A      "Agitator_start"
A      #Enable_Motor
=      #Start_Fulfilled
A(
O      "Agitator_stop"
ON #Enable_Motor
)
=      #Stop_Fulfilled
CALL   "Motor_block", "DB_Agitator"
      Start :=#Start_Fulfilled
      Stop  :=#Stop_Fulfilled
      Response :="Agitator_running"
      Reset_Maint :="Reset_maint"
      Timer_No :=T16
      Reponse_Time:=S5T#10S
      Fault :="Agitator_fault"
      Start_Dsp :="Agitator_on"
      Stop_Dsp :="Agitator_off"
      Maint :="Agitator_maint"
      Motor :="Agitator"

```

Network 13 Interlocks for drain valve

```
A "EMER_STOP_off"
A "Tank_not_empty"
AN "Agitator"
= "Enable_Valve"
```

Network 14 Drain valve control

```
A "Drain_open"
A #Enable_Valve
= #Open_Drain
A(
O "Drain_closed"
ON #Enable_Valve
)
= #Close_Drain
CALL "Valve_block"
Open :=#Open_Drain
Close :=#Close_Drain
Dsp_Open :="Drain_open_disp"
Dsp_Closed :="Drain_closed_disp"
Valve :="Drain"
```

Network 15 Tank level display

```
AN "Tank_below_max"
= "Tank_max_disp"
AN "Tank_above_min"
= "Tank_min_disp"
AN "Tank_not_empty"
= "Tank_empty_disp"
```

A.5.3 Example of Handling Time-of-Day Interrupts

Structure of the User Program "Time-of-Day Interrupts"

FC12

OB10

OB1 and OB80

A.5.3.1 Structure of the User Program "Time-of-Day Interrupts"

Task

Output Q 4.0 should be set in the time from Monday, 5.00 am to Friday, 8.00 pm. In the time from Friday, 8.00 pm to Monday, 5.00 am the output Q 4.0 should be reset.

Translating into a User Program

The following table shows the sub-tasks of the blocks used.

Block	Sub-Task
OB1	Calls the function FC12
FC12	Depending on the state of the output Q 4.0, the time-of-day interrupt status, and the inputs I 0.0 and I 0.1 <ul style="list-style-type: none"> • Specify the starting time • Set the time-of-day interrupt • Activate the time-of-day interrupt • CAN_TINT
OB10	Depending on the current day of the week <ul style="list-style-type: none"> • Specify the starting time • Set or reset output Q 4.0 • Set next time-of-day interrupt • Activate next time-of-day interrupt
OB80	Set output Q 4.1 Store start event information of OB80 in bit memory area

Addresses Used

The following table shows the shared addresses used. The temporary local variables are declared in the declaration section of the respective block.

Address	Meaning
I0.0	Input to enable "set time-of-day interrupt" and "activate time-of-day interrupt"
I0.1	Input to cancel a time-of-day interrupt
Q4.0	Output set/reset by the time-of-day interrupt OB (OB10)
Q4.1	Output set by a time error (OB80)
MW16	STATUS of the time-of-day interrupt (SFC31 "QRY_TINT")
MB100 to MB107	Memory for start event information of OB10 (time-of-day only)
MB110 to MB129	Memory for start event information of OB80 (time error)
MW200	RET_VAL of SFC28 "SET_TINT"
MB202	Binary result (status bit BR) buffer for SFCs
MW204	RET_VAL of SFC30 "ACT_TINT"
MW208	RET_VAL of SFC31 "QRY_TINT"

System Functions and Functions Used

The following system functions are used in the programming example:

- SFC28 "SET_TINT" : Set Time-of-Day Interrupt
- SFC29 "CAN_TINT" : Cancel Time-of-Day Interrupt
- SFC30 "ACT_TINT" : Activate Time-of-Day Interrupt
- SFC31 "QRY_TINT" : Query Time-of-Day Interrupt
- FC3 "D_TOD_DT" : Combine DATE and TIME_OF_DAY to DT

A.5.3.2 FC12

Declaration Section

The following temporary local variables are declared in the declaration section of FC12:

Variable Name	Data Type	Declaration	Comment
IN_TIME	TIME_OF_DAY	TEMP	Start time
IN_DATE	DATE	TEMP	Start date
OUT_TIME_DATE	DATE_AND_TIME	TEMP	Start date/time converted
OK_MEMORY	BOOL	TEMP	Enable for setting time-of-day interrupt

STL Code Section

Enter the following STL user program in the code section of FC12:

STL (FC12)	Explanation
Network 1	
CALL SFC 31	SFC QRY_TINT
OB_NO := 10	Query STATUS of time-of-day interrupts
RET_VAL:= MW 208	
STATUS := MW 16	
Network 2:	
AN Q 4.0	Specify start time dependent on Q 4.0
JC mond	(in variable
L D#1995-1-27	#IN_DATE and #IN_TIME)
T #IN_DATE	Start date is a Friday
L TOD#20:0:0.0	
T #IN_TIME	
JU cnvrt	
mond: L D#1995-1-23	
T #IN_DATE	Start date is a Monday
L TOD#5:0:0.0	
T #IN_TIME	
cnvrt: NOP 0	

STL (FC12)	Explanation
<pre> Network 3: CALL FC 3 IN1 := #IN_DATE IN2 := #IN_TIME RET_VAL := #OUT_TIME_DATE </pre>	Convert format from DATE and TIME_OF_DAY to DATE_AND_TIME (for setting time-of-day interrupt)
<pre> Network 4: A I 0.0 AN M 17.2 A M 17.4 = #OK_MEMORY </pre>	All requirements for setting time-of-day interrupt fulfilled? (Input for enable set and time-of-day interrupt not active and time-of-day interrupt OB is loaded) If so, set time-of-day interrupt...
<pre> Network 5: A #OK_MEMORY JNB m001 CALL SFC 28 OB_NO := 10 SDT := #OUT_TIME_DATE PERIOD := W#16#1201 RET_VAL := MW 200 </pre>	
<pre> m001 A BR = M 202.3 </pre>	...and activate time-of-day interrupt.
<pre> Network 6: A #OK_MEMORY JNB m002 CALL SFC 30 OB_NO := 10 RET_VAL := MW 204 </pre>	
<pre> m002 A BR = M 202.4 </pre>	If input for canceling time-of-day interrupts is set, cancel time-of-day interrupt.
<pre> Network 7: A I 0.1 JNB m003 CALL SFC 29 OB_NO := 10 RET_VAL := MW 210 </pre>	
<pre> m003 A BR = M 202.5 </pre>	

A.5.3.3 OB10

Declaration Section

In contrast to the default declaration section of OB10 the following temporary local variables are declared:

- Structure for the entire start event information (STARTINFO)
- Within the STARTINFO structure a structure for the time (T_STMP)
- Other temporary local variables WDAY, IN_DATE, IN_TIME, and OUT_TIME_DATE

Variable Name	Data Type	Declaration	Comment
STARTINFO	STRUCT	TEMP	Entire start event information of OB10 declared as structure
E_ID	WORD	TEMP	Event ID:
PR_CLASS	BYTE	TEMP	Priority class
OB_NO	BYTE	TEMP	OB number
RESERVED_1	BYTE	TEMP	Reserved
RESERVED_2	BYTE	TEMP	Reserved
PERIOD	WORD	TEMP	Periodicity of time-of-day interrupt
RESERVED_3	DWORD	TEMP	Reserved
T_STMP	STRUCT	TEMP	Structure for time-of-day details
YEAR	BYTE	TEMP	
MONTH	BYTE	TEMP	
DAY	BYTE	TEMP	
HOUR	BYTE	TEMP	
MINUTES	BYTE	TEMP	
SECONDS	BYTE	TEMP	
MSEC_WDAY	WORD	TEMP	
	END_STRUCT	TEMP	
	END_STRUCT	TEMP	
WDAY	INT	TEMP	Day of the week
IN_DATE	DATE	TEMP	Input variable for FC3 (conversion of time format)
IN_TIME	TIME_OF_DAY	TEMP	Input variable for FC3 (conversion of time format)
OUT_TIME_DATE	DATE_AND_TIME	TEMP	Output variable for FC3 and input variable for SFC28

STL Code Section

Enter the following STL user program in the code section of OB10:

STL (OB10)	Explanation
Network 1	
L #STARTINFO.T_STMP.MSEC_WDAY	Select day of week
L W#16#F	
AW	
T #WDAY	and store.
Network 2:	
L #WDAY	If day of week is not Monday, then
L 2	specify Monday, 5.00 am as next starting
<>I	time and reset output Q 4.0.
JC mond	
Network 3:	
L D#1995-1-27	Otherwise, if day of week is Monday,
T #IN_DATE	specify Friday, 8.00 pm (20.00) as next
L TOD#20:0:0.0	starting time and set output Q 4.0.
T #IN_TIME	
SET	
= Q 4.0	
JU cnvrt	
mond:	
L D#1995-1-23	
T #IN_DATE	
L TOD#5:0:0.0	
T #IN_TIME	
CLR	Starting time specified.
= Q 4.0	Convert specified starting time to
	format DATE_AND_TIME (for SFC28).
cnvrt: NOP	0
Network 4:	
CALL FC 3	Set time-of-day interrupt.
IN1 := #IN_DATE	
IN2 := #IN_TIME	
RET_VAL := #OUT_TIME_DATE	
Network 5:	
CALL SFC 28	
OB_NO := 10	
SDT := #OUT_TIME_DATE	
PERIOD := W#16#1201	
RET_VAL := MW 200	
A BR	
= M 202.1	
Network 6:	
CALL SFC 30	Activate time-of-day interrupt.
OB_NO := 10	
RET_VAL := MW 204	
A BR	
= M 202.2	
Network 7:	
CALL SFC 20	Block transfer: save time of day from
SRCBLK := #STARTINFO.T_STMP	start event information of OB10 to the
RET_VAL := MW 206	memory area MB100 to MB107.
DSTBLK := P#M 100.0 BYTE 8	

A.5.3.4 OB1 and OB80

As the start event information of OB1 (OB for cyclic program) is not evaluated in this example, only the start event information of OB80 is displayed.

OB1 Code Section

Enter the following STL user program in the code section of OB1:

STL (OB1)	Explanation
CALL FC 12	Calls the function FC12

OB80 Declaration Section

In contrast to the default declaration section of OB80 the following temporary local variables are declared:

- Structure for the entire start event information (STARTINFO)
- Within the STARTINFO structure a structure for the time (T_STMP)

Variable Name	Data Type	Declaration	Comment
STARTINFO	STRUCT	TEMP	Entire start event information of OB80 declared as structure
E_ID	WORD	TEMP	Event ID:
PR_CLASS	BYTE	TEMP	Priority class
OB_NO	BYTE	TEMP	OB number
RESERVED_1	BYTE	TEMP	Reserved
RESERVED_2	BYTE	TEMP	Reserved
A1_INFO	WORD	TEMP	Additional information about the event that caused the error
A2_INFO	DWORD	TEMP	Additional information about the event ID, priority class, and OB no. of the error
T_STMP	STRUCT	TEMP	Structure for time-of-day details
YEAR	BYTE	TEMP	
MONTH	BYTE	TEMP	
DAY	BYTE	TEMP	
HOUR	BYTE	TEMP	
MINUTES	BYTE	TEMP	
SECONDS	BYTE	TEMP	
MSEC_WDAY	WORD	TEMP	
	END_STRUCT	TEMP	
	END_STRUCT	TEMP	

OB80 Code Section

Enter the following STL user program in the code section of OB80 that is called by the operating system if a time error occurs:

STL (OB80)	Explanation
Network 1	
AN Q 4.1	Set output Q 4.1 if time error occurred.
S Q 4.1	
CALL SFC 20	Block transfer: save entire start event information to memory area MB110 to MB129.
SRCBLK := #STARTINFO	
RET_VAL := MW 210	
DSTBLK := P#M 110.0 Byte 20	

A.5.4 Example of Handling Time-Delay Interrupts

Structure of the User Program "Time-of-Day Interrupts"

FC12

OB10

OB1 and OB80

A.5.4.1 Structure of the User Program "Time-Delay Interrupts"

Task

When input I 0.0 is set, output Q 4.0 should be set 10 seconds later. Every time input I 0.0 is set, the delay time should be restarted.

The time (seconds and milliseconds) of the start of the time-delay interrupt should appear as a user-specific ID in the start event information of the time-delay interrupt OB (OB20).

If I 0.1 is set in these 10 seconds, the organization block OB20 should not be called; meaning the output Q 4.0 should not be set.

When input I 0.2 is set, output Q 4.0 should be reset.

Translating into a User Program

The following table shows the sub-tasks of the blocks used.

Block	Sub-Task
OB1	Read current time and prepare for start of time-delay interrupt Dependent on edge change at input I 0.0, start time-delay interrupt Depending on the status of the time-delay interrupt and the edge change at input I 0.1, cancel time-delay interrupt Dependent on the state of input I 0.2, reset output Q 4.0
OB20	Set output Q 4.0 Read and prepare current time Save start event information to bit memory area

Addresses Used

The following table shows the shared addresses used. The temporary local variables are declared in the declaration section of the respective block.

Address	Meaning
I0.0	Input to enable "start time-delay interrupt"
I0.1	Input to cancel a time-delay interrupt
I0.2	Input to reset output Q 4.0
Q4.0	Output set by the time-delay interrupt OB (OB20)
MB1	Used for edge flag and binary result (status bit BR) buffer for SFCs
MW4	STATUS of time-delay interrupt (SFC34 "QRY_TINT")
MD10	Seconds and milliseconds BCD-coded from the start event information of OB1
MW 100	RET_VAL of SFC32 "SRT_DINT"
MW102	RET_VAL of SFC34 "QRY_DINT"
MW104	RET_VAL of SFC33 "CAN_DINT"
MW106	RET_VAL of SFC20 "BLKMOV"
MB120 to MB139	Memory for start event information of OB20
MD140	Seconds and milliseconds BCD-coded from the start event information of OB20
MW144	Seconds and milliseconds BCD-coded from the start event information of OB1; acquired from start event information of OB20 (user-specific ID SIGN)

System Functions Used

The following SFCs are used in the user program "time-delay interrupts:"

- SFC32 "SRT_DINT" : Start Time-Delay Interrupt
- SFC33 "CAN_DINT" : Cancel Time-Delay Interrupt
- SFC34 "QRY_DINT" : Query Status of a Time-Delay Interrupt

A.5.4.2 OB20

Declaration Section

In contrast to the default declaration section of OB20 the following temporary local variables are declared:

- Structure for the entire start event information (STARTINFO)
- Within the STARTINFO structure a structure for the time (T_STMP)

Variable Name	Data Type	Declaration	Comment
STARTINFO	STRUCT	TEMP	Start information for OB20
E_ID	WORD	TEMP	Event ID:
PC_NO	BYTE	TEMP	Priority class
OB_NO	BYTE	TEMP	OB number
D_ID 1	BYTE	TEMP	Data ID 1
D_ID 2	BYTE	TEMP	Data ID 2
SIGN	WORD	TEMP	User-specific ID
DTIME	TIME	TEMP	Time with which the time-delay interrupt is started
T_STMP	STRUCT	TEMP	Structure for time-of-day details (time stamp)
YEAR	BYTE	TEMP	
MONTH	BYTE	TEMP	
DAY	BYTE	TEMP	
HOUR	BYTE	TEMP	
MINUTES	BYTE	TEMP	
SECONDS	BYTE	TEMP	
MSEC_WDAY	WORD	TEMP	
	END_STRUCT	TEMP	
	END_STRUCT	TEMP	

Code Section

Enter the following STL user program in the code section of OB20:

STL (OB20)	Explanation
Network 1	
SET	Set output Q 4.0 unconditionally
= Q 4.0	
Network 2:	
L QW 4	Activate output word immediately
T PQW 4	
Network 3:	
L #STARTINFO.T_STMP.SECONDS	Read seconds from start event information
T MW 140	
L #STARTINFO.T_STMP.MSEC_WDAY	Read milliseconds and day of week from start event information
T MW 142	
L MD 140	
SRD 4	Eliminate day of week and write milliseconds back (now BCD-coded in MW 142)
T MD 140	
Network 4:	Read starting time of time-delay interrupt (= call SFC32) from start event information
L #STARTINFO.SIGN	
T MW 144	
Network 5:	Copy start event information to memory area (MB120 to MB139)
CALL SFC 20	
SRCBLK := STARTINFO	
RET_VAL := MW 106	
DSTBLK := P#M 120.0 Byte 20	

A.5.4.3 OB1

Declaration Section

In contrast to the default declaration section of OB1 the following temporary local variables are declared:

- Structure for the entire start event information (STARTINFO)
- Within the STARTINFO structure a structure for the time (T_STMP)

Variable Name	Data Type	Declaration	Comment
STARTINFO	STRUCT	TEMP	Start information for OB1
E_ID	WORD	TEMP	Event ID:
PC_NO	BYTE	TEMP	Priority class
OB_NO	BYTE	TEMP	OB number
D_ID 1	BYTE	TEMP	Data ID 1
D_ID 2	BYTE	TEMP	Data ID 2
CUR_CYC	INT	TEMP	Current cycle time
MIN_CYC	INT	TEMP	Minimum cycle time
MAX_CYC	INT	TEMP	Maximum cycle time
T_STMP	STRUCT	TEMP	Structure for time-of-day details (time stamp)
YEAR	BYTE	TEMP	
MONTH	BYTE	TEMP	
DAY	BYTE	TEMP	
HOUR	BYTE	TEMP	
MINUTES	BYTE	TEMP	
SECONDS	BYTE	TEMP	
MSEC_WDAY	WORD	TEMP	
	END_STRUCT	TEMP	
	END_STRUCT	TEMP	

Code Section

Enter the following STL user program in the code section of OB1:

STL (OB1)	Explanation
Network 1	
L #STARTINFO.T_STMP.SECONDS	Read seconds from start event
T MW 10	information
L #STARTINFO.T_STMP.MSEC_WDAY	Read milliseconds and day of week from
T MW 12	start event information
L MD 10	Eliminate day of week and
SRD 4	write milliseconds back (now BCD-coded
T MD 10	in MW 12)
Network 2:	Positive edge at input I 0.0?
A I 0.0	
FP M 1.0	
= M 1.1	
Network 3:	If so, start time-delay interrupt
A M 1.1	(starting time of time-delay interrupt
JNB m001	assigned to the parameter SIGN)
CALL SFC 32	
OB_NO := 20	
DTIME := T#10S	
SIGN := MW 12	
RET_VAL:= MW 100	
m001: NOP 0	Query status of time-delay interrupt
	(SFC QRY_DINT)
Network 4:	
CALL SFC 34	
OB_NO := 20	
RET_VAL:= MW 102	Positive edge at input I 0.1?
STATUS := MW 4	
Network 5:	
A I 0.1	
FP M 1.3	
= M 1.4	...and time-delay interrupt is activated
	(bit 2 of time-delay interrupt STATUS)?
Network 6:	Then cancel time-delay interrupt
A M 1.4	
A M 5.2	
JNB m002	
CALL SFC 33	Reset output Q 4.0 with input I 0.2
OB_NO := 20	
RET_VAL:= MW 104	
m002: NOP 0	
A I 0.2	
R Q 4.0	

A.5.4.4 Example of Masking and Unmasking Synchronous Errors

The following example of a user program illustrates how to mask and unmask synchronous errors. Using SFC36 "MSK_FLT" the following errors are masked in the programming error filter:

- Area length error when reading
- Area length error when writing

With a second call of SFC36 "MSK_FLT" an access area can also be masked:

- I/O access error when writing

With SFC38 "READ_ERR" the masked synchronous errors are queried. The "I/O access error when writing" is unmasked again with SFC37 "DMSK_FLT."

Code Section

Below you will find the OB1 in which the example of the user program was programmed in Statement List.

STL (Network 1)	Explanation
AN M 255.0	Non-retentive memory bit M 255.0 (only in first run = 0)
JNB m001	
CALL SFC 36	SFC36 MSK_FLT (mask synchronous errors) Bit 2 = Bit 3 = 1 (BLFL and BLFS are masked)
PRGFLT_SET_MASK :=DW#16#C	All bits=0 (no access errors are masked)
ACCFLT_SET_MASK :=DW#16#0	Return value
RET_VAL :=MW 100	Output current programming error filter to MD10
PRGFLT_MASKED :=MD 10	Output current access error filter to MD14
ACCFLT_MASKED :=MD 14	Set M255.0 if masking successful
m001: A BR	
S M 255.0	

STL (Network 2)	Explanation
CALL SFC 36	SFC36 MSK_FLT (mask synchronous errors) All bits=0 (no further programming errors masked)
PRGFLT_SET_MASK :=DW#16#0	Bit 3 = 1 (write access errors are masked)
ACCFLT_SET_MASK :=DW#16#8	Return value
RET_VAL :=MW 102	Output current programming error filter to MD20
PRGFLT_MASKED :=MD 20	Output current access error filter to MD24
ACCFLT_MASKED :=MD 24	

STL (Network 3)		Explanation
AN	M 27.3	Block end if write access error (bit 3 in ACCFLT_MASKED) not masked
BEC		

STL (Network 4)		Explanation
L	B#16#0	Write access (with value 0) to PQB 16
T	PQB 16	

STL (Network 5)		Explanation
CALL	SFC 38	SFC38 READ_ERR (query synchronous errors)
PRGFLT_QUERY	:=DW#16#0	All bits=0 (no programming errors queried)
ACCFLT_QUERY	:=DW#16#8	Bit 3 = 1 (write access error queried)
RET_VAL	:=MW 104	Return value
PRGFLT_CLR	:=MD 30	Output current programming error filter to MD30
ACCFLT_CLR	:=MD 34	Output current access error filter to MD34
A	BR	No error occurred and write access error detected
A	M 37.3	Invert RLO
NOT		M 0.0=1 if PQB 16 present
=	M 0.0	

STL (Network 6)		Explanation
L	B#16#0	Write access (with value 0) to PQB 17
T	PQB 17	

STL (Network 7)	Explanation
CALL SFC 38	SFC38 READ_ERR (query synchronous errors)
PRGFLT_QUERY :=DW#16#0	All bits=0 (no programming errors queried)
ACCFLT_QUERY :=DW#16#8	Bit 3 = 1 (write access error queried) Return value
RET_VAL :=MW 104	Output current programming error filter to MD30
PRGFLT_CLR :=MD 30	Output current access error filter to MD34
ACCFLT_CLR :=MD 34	No error occurred and write access error detected
A BR	Invert RLO
A M 37.3	M 0.1=1 if PQB 17 present
NOT	
= M 0.1	

STL (Network 8)	Explanation
L B#16#0	
T PQB 18	Write access (with value 0) to PQB 18

STL (Network 9)	Explanation
CALL SFC 38	SFC38 READ_ERR (query synchronous errors)
PRGFLT_QUERY :=DW#16#0	All bits=0 (no programming errors queried)
ACCFLT_QUERY :=DW#16#8	Bit 3 = 1 (write access error queried) Return value
RET_VAL :=MW 104	Output current programming error filter to MD30
PRGFLT_CLR :=MD 30	Output current access error filter to MD34
ACCFLT_CLR :=MD 34	No error occurred and write access error detected
A BR	Invert RLO
A M 37.3	M 0.2=1 if PQB 18 present
NOT	
= M 0.2	

STL (Network 10)	Explanation
L B#16#0	
T PQB 19	Write access (with value 0) to PQB 19

STL (Network 11)	Explanation
CALL SFC 38	SFC38 READ_ERR (query synchronous errors)
PRGFLT_QUERY :=DW#16#0	All bits=0 (no programming errors queried)
ACCFLT_QUERY :=DW#16#8	Bit 3 = 1 (write access error queried) Return value
RET_VAL :=MW 104	Output current programming error filter to MD30
PRGFLT_CLR :=MD 30	Output current access error filter to MD34
ACCFLT_CLR :=MD 34	No error occurred and write access error detected
A BR	
A M 37.3	Invert RLO
NOT	M 0.3=1 if PQB 19 present
= M 0.3	

STL (Network 12)	Explanation
CALL SFC 37	SFC37 DMSK_FLT (unmask synchronous errors)
PRGFLT_RESET_MASK :=DW#16#0	All bits=0 (no further programming errors unmasked)
ACCFLT_RESET_MASK :=DW#16#8	Bit 3 = 1 (write access error unmasked) Return value
RET_VAL :=MW 102	Output current programming error filter to MD20
PRGFLT_MASKED :=MD 20	Output current access error filter to MD24
ACCFLT_MASKED :=MD 24	

STL (Network 13)	Explanation
A M 27.3	Block end if write access error (bit 3 in ACCFLT_MASKED) not unmasked
BEC	

STL (Network 14)	Explanation
A M 0.0	
JNB m002	
L IB 0	Transfer IB0 to PQB 16 if present
T PQB 16	
m002: NOP 0	

STL (Network 15)	Explanation
A M 0.1	
JNB m003	
L IB 1	Transfer IB1 to PQB 17 if present
T PQB 17	
m003: NOP 0	

STL (Network 16)	Explanation
A M 0.2	
JNB m004	
L IB 2	Transfer IB2 to PQB 18 if present
T PQB 18	
m004: NOP 0	

STL (Network 17)		Explanation
A	M 0.3	
JNB	m005	
L	IB 3	Transfer IB3 to PQB 19 if present
T	PQB 19	
m005:	NOP 0	

A.5.4.5 Example of Disabling and Enabling Interrupts and Asynchronous Errors (SFC39 and SFC40)

In this example of a user program, a program section is assumed that cannot be interrupted by interrupts. For this program section, OB35 calls (time-of-day interrupt) are disabled using SFC 39 "DIS_IRT" and later enabled again using SFC 40 "EN_IRT".

SFC39 and SFC40 are called in OB1:

STL (OB1)	Explanation
A M 0.0	Program section that can be interrupted without problems:
S M 90.1	
A M 0.1	
S M 90.0	
:	Program section that must not be interrupted by interrupts:
:	
CALL SFC 39	Disable and discard interrupts
MODE :=B#16#2	Mode 2: disable individual interrupt OBs
OB_NO :=35	Disable OB35
RET_VAL :=MW 100	
:	
:	
L PIW 100	
T MW 200	
L MW 90	
T MW 92	
:	
:	
CALL SFC 40	Enable interrupts
MODE :=B#16#2	Mode 2: enable individual interrupt OBs
OB_NO :=35	Enable OB35
RET_VAL :=MW 102	
	Program section that can be interrupted without problems:
A M 10.0	
S M 190.1	
A M 10.1	
S M 190.0	
:	
:	

A.5.4.6 Example of the Delayed Processing of Interrupts and Asynchronous Errors (SFC41 and SFC42)

In this example of a user program, a program section is assumed that cannot be interrupted by interrupts. For this program section, interrupts are delayed using SFC41 "DIS_AIRT" and later enabled again using SFC42 "EN_AIRT."

SFC41 and SFC42 are called in OB1:

STL (OB1)	Explanation
A M 0.0	Program section that can be interrupted without problems:
S M 90.1	
A M 0.1	
S M 90.0	
:	Program section that must not be interrupted by interrupts:
:	
CALL SFC 41	
RET_VAL :=MW 100	
L PIW 100	Disable and delay interrupts
T MW 200	
L MW 90	
T MW 92	
:	Enable interrupts
:	
:	
CALL SFC 42	
RET_VAL :=MW 102	The number of set interrupt disables is in the return value
L MW 100	
DEC 1	The number of set interrupt disables is in the return value
L MW 102	
<>I	The number must have the same value after the interrupt is enabled as before the interrupt disable (here "0")
JC err	
A M 10.0	Program section that can be interrupted without problems:
S M 190.1	
A M 10.1	
S M 190.0	
:	The number of set interrupt disables is displayed
:	
BEU	
err: L MW 102	
T QW 12	

A.6 Accessing Process and I/O Data Areas

A.6.1 Accessing the Process Data Area

The CPU can access inputs and outputs of central and distributed digital input/output modules either indirectly using the process image tables or directly via the backplane/P bus.

The CPU accesses inputs and outputs of central and distributed analog input/output modules directly via the backplane/P bus. You can also enter the addresses of analog modules in the process image area.

Addressing Modules

You assign the addresses used in your program to the modules when you configure the modules with STEP 7, as follows:

- With central I/O modules: arrangement of the rack and assignment of the modules to slots in the configuration table.
- For stations with a distributed I/O (PROFIBUS DP or PROFINET IO): arrangement of the DP slaves or IO devices with the PROFIBUS address or device name and assignment of the modules to slots.

By configuring the modules, it is no longer necessary to set addresses on the individual modules using switches. As a result of the configuration, the programming device sends data to the CPU that allow the CPU to recognize the modules assigned to it.

Peripheral I/O Addressing

There is a separate address area for inputs and outputs. This means that the address of a peripheral area must not only include the byte or word access type but also the I identifier for inputs and Q identifier for outputs.

The following table shows the available peripheral address areas.

Address Area	Access via Units of Following Size	S7 Notation (IEC)
Peripheral (I/O) area: inputs	Peripheral input byte	PIB
	Peripheral input word	PIW
	Peripheral input double word	PID
Peripheral (I/O) area: outputs	Peripheral output byte	PQB
	Peripheral output word	PQW
	Peripheral output double word	PQD

To find out which address areas are possible on individual modules, refer to the following manuals:

- CPU 31xC and CPU 31x, Technical Data
- S7-400 Programmable Controllers, CPU Data

Module Start Address

The module start address is the lowest byte address of a module. It represents the start address of the user data area of the module and is used in many cases to represent the entire module.

The module start address is, for example, entered in hardware interrupts, diagnostic interrupts, insert/remove module interrupts, and power supply error interrupts in the start information of the corresponding organization block and is used to identify the module that initiated the interrupt.

A.6.2 Accessing the Peripheral Data Area

The peripheral data area can be divided into the following:

- User data and
- Diagnostic and parameter data.

Both areas have an input area (can only be read) and an output area (can only be written).

User Data

User data is addressed with the byte address (for digital signal modules) or the word address (for analog signal modules) of the input or output area. User data can be accessed with load and transfer commands, communication functions (operator interface access), or by transferring the process image. User data can be any of the following:

- Digital and analog input/output signals from signal modules
- Control and status information from function modules
- Information for point-to-point and bus connections from communication modules (only S7-300)

When transferring user data, a consistency of a maximum of 4 bytes can be achieved (with the exception of DP standard slaves, see Setting the Operating Behavior). If you use the "transfer double word" statement, four contiguous and unmodified (consistent) bytes are transferred. If you use four separate "transfer input byte" statements, a hardware interrupt OB could be inserted between the statements and transfer data to the same address so that the content of the original 4 bytes is changed before they were all transferred.

Diagnostic and Parameter Data

The diagnostic and parameter data of a module cannot be addressed individually but are always transferred in the form of complete data records. This means that consistent diagnostic and parameter data are always transferred.

The diagnostic and parameter data is accessed using the start address of the module and the data record number. Data records are divided into input and output data records. Input data records can only be read, output data records can only be written. You can access data records using system functions or communication functions (user interface). The following table shows the relationship between data records and diagnostic and parameter data.

Data	Description
Diagnostic data	If the modules are capable of diagnostics, you obtain the diagnostic data of the module by reading data records 0 and 1.
Parameter data	If the modules are configurable, you transfer the parameters to the module by writing data records 0 and 1.

Accessing Data Records

You can use the information in the data records of a module to reassign parameters to configurable modules and to read diagnostic information from modules with diagnostic capability.

The following table shows which system functions you can use to access data records.

SFC	Purpose
Assigning parameters to modules	
SFC55 WR_PARM	Transfers the modifiable parameters (data record 1) to the addressed signal module
SFC56 WR_DPARM	Transfers parameters from SDBs 100 to 129 to the addressed signal module
SFC57 PARM_MOD	Transfers parameters from SDBs 100 to 129 to the addressed signal module
SFC58 WR_REC	Transfers any data record to the addressed signal module
Reading out diagnostic information	
SFC59 RD_REC	Reads the diagnostic data

Note

If a DPV1 slave is configured using a GSD file (GSD as of Rev. 3) and the DP interface of the DP master is set to "**S7 compatible**", then data records must not be read from or written to the I/O modules in the user program with SFC 58/59 or SFB 53/52. The reason is that in this case the DP master addresses the incorrect slot (configured slot +3).

Remedy: Set the interface for the DP master to "DPV1".

Addressing S5 Modules

You can access S5 modules as follows:

- By connecting an S7-400 to SIMATIC S5 expansion racks using the interface module IM 463-2
- By plugging in certain S5 modules in an adapter casing in the central rack of the S7-400

How you address S5 modules with SIMATIC S7 is explained in the "S7-400, M7-400 Programmable Controllers, Hardware and Installation" Manual or the description supplied with the adapter casing.

A.7 Setting the Operating Behavior

This chapter explains how you can modify certain properties of S7-300 and S7-400 programmable controllers by setting system parameters or using system functions (SFCs).

You will find detailed information on the module parameters in the STEP 7 online help and in the following manuals:

- "S7-300 Programmable Controller, Hardware and Installation" Manual
- "S7-300, M7-300 Programmable Controllers, Module Specifications" Reference Manual
- "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual

You will find all you need to know about SFCs in the "System Software for S7-300 and S7-400, System and Standard Functions" Reference Manual.

Addressing DP Standard Slaves

If you want to exchange data longer than 4 bytes with DP standard slaves, you must use special SFCs for this data exchange.

CPUs that support the exchange of consistent data (> 4 bytes) by means of the I/O area do not need SFCs 14/15 (see Distributed Reading and Writing of Consistent Data).

SFC	Purpose
Assigning parameters to modules	
SFC15 DPWR_DAT	Transfers any data to the addressed signal module
Reading out diagnostic information	
SFC13 DPNRM_DG	Reads the diagnostic information (asynchronous read access)
SFC14 DPRD_DAT	Reads consistent data (length 3 or greater than 4 bytes)

When a DP diagnostic frame arrives, a diagnostic interrupt with 4 bytes of diagnostic data is signaled to the CPU. You can read out these 4 bytes using SFC13 DPNRM_DG.

A.7.1 Changing the Behavior and Properties of Modules

Default Settings

- When supplied, all the configurable modules of the S7 programmable controller have default settings suitable for standard applications. With these defaults, you can use the modules immediately without making any settings. The default values are explained in the module descriptions in the following manuals:
- "S7-300 Programmable Controller, Hardware and Installation" Manual
- "S7-300, M7-300 Programmable Controllers, Module Specifications" Reference Manual
- "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual

Which Modules Can You Assign Parameters To?

You can, however, modify the behavior and the properties of the modules to adapt them to your requirements and the situation in your plant. Configurable modules are CPUs, FMs, CPs, and some of the analog input/output modules and digital input modules.

There are configurable modules with and without backup batteries.

Modules without backup batteries must be supplied with data again following any power down. The parameters of these modules are stored in the retentive memory area of the CPU (indirect parameter assignment by the CPU).

Setting and Loading Parameters

You set module parameters using STEP 7. When you save the parameters, STEP 7 creates the object "System Data Blocks" that is downloaded to the CPU with the user program and transferred to the modules when the CPU starts up.

Which Settings Can Be Made?

The module parameters are divided into parameter blocks. Which parameter blocks are available on which CPU is explained in the "S7-300 Programmable Controller, Hardware and Installation" Manual and the "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual.

Examples of parameter blocks:

- Startup behavior
- Cycle
- MPI
- Diagnostics
- Retentive data
- Clock memory
- Interrupt handling
- Onboard I/Os (only for the S7-300)
- Protection level
- Local data
- Real-time clock
- Asynchronous errors

Parameter Assignment with SFCs

In addition to assigning parameters with STEP 7, you can also include system functions in the S7 program to modify module parameters. The following table shows which SFCs transfer which module parameters.

SFC	Purpose
SFC55 WR_PARM	Transfers the modifiable parameters (data record 1) to the addressed signal module
SFC56 WR_DPARAM	Transfers the parameters from the corresponding SDBs to the addressed signal module
SFC57 PARM_MOD	Transfers all parameters from the corresponding SDBs to the addressed signal module
SFC58 WR_REC	Transfers any data record to the addressed signal module

The system functions are described in detail in the "System Software for S7-300 and S7-400, System and Standard Functions" Reference Manual.

Which module parameters can be modified dynamically is explained in the following manuals:

- "S7-300 Programmable Controller, Hardware and Installation" Manual
- "S7-300, M7-300 Programmable Controllers, Module Specifications" Reference Manual
- "S7-400, M7-400 Programmable Controllers, Module Specifications" Reference Manual

A.7.2 Updating the Firmware (of the Operating System) in Modules and Submodules Offline

The following section describes how to transfer a new firmware version (new operating system version) to a module or a CPU by means of a memory card.

The update requires the following two steps:

1. Create an "update memory card" (transfer the update files to a memory card) with the programming device (PG) or PC with an external prommer.
2. Using the "update memory card", update the operating system on the CPU.

Requirements

- Memory card with sufficient storage capacity. For information on this, refer to the download pages at customer support. This is where you will also find the update files.
- Programming device (PG) or PC set up to program memory cards.

To transfer the update files to a memory card, proceed as follows:

1. Create a new directory with the Windows Explorer.
2. Transfer the desired update file to this directory and unzip it there. This directory will then contain the UPD file.
3. Insert the S7 memory card into the programming device (PG) or the prommer.
4. Delete the memory card (menu command: **File > S7 Memory Card > Delete** in the SIMATIC Manager).
5. Select the **PLC > Update Operating System** menu command in the SIMATIC Manager.
6. In the dialog box that is displayed, select the directory with the UPD files.
7. Double-click the UPD file.
This action starts the programming process. When this process is ended, the message "The firmware update for the module was successfully transferred to the S7 memory card" is displayed.

Updating the Operating System:

1. Insert the memory card with the update into the PLC (i.e. in the CPU)
2. Switch off the power supply (PS) unit for the CPU.
3. Insert the prepared memory card with the update into the CPU.
4. Switch the power for the CPU back on.
The operating system is transferred from the S7 memory card to the internal FLASH EPROM.
During this time, all LEDs on the CPU are lit up.
5. After about two minutes, the update is finished. To indicate that the update is finished, the STOP LED on the CPU flashes slowly (system request for memory reset)

6. Switch the power off at the power supply unit and, where appropriate, insert the S7 memory card that is intended for the operation.
7. Switch the power back on. The CPU executes an automatic memory reset. After that, the CPU is ready for operation.
8. Updating Firmware in Modules and Submodules

A.7.3 Using the Clock Functions

All S7-300/S7-400 CPUs are equipped with a clock (real-time clock or software clock). The clock can be used in the programmable controller both as clock master or clock slave with external synchronization. The clock is required for Time-Of-Day interrupts and runtime meters.

Time Format

The clock always indicates the time (minimum resolution 1 s), date, and weekday. With some CPUs it is also possible to indicate milliseconds (refer to the "S7-300 Programmable Controller, Hardware and Installation" Manual and "S7-400, M7-400 Programmable Controllers Module Specifications" Reference Manual).

Setting and Reading the Time

You set the time and date for the CPU clock by calling SFC0 SET_CLK in the user program or with a menu option on the programming device to start the clock. Using SFC1 READ_CLK or a menu option on the programming device, you can read the current date and time on the CPU.

Note

To prevent the time from being displayed differently on HMI systems, you should set **winter time** on the CPU.

Assigning Parameters for the Clock

If more than one module equipped with a clock exists in a network, you must set parameters using STEP 7 to specify which CPU functions as master and which as slave when the time is synchronized. When setting these parameters, you also decide whether the time is synchronized via the communication bus or via the multipoint interface and the intervals at which the time is automatically synchronized.

Synchronizing the Time

To make sure that the time is the same on all modules in the network, the slave clocks are synchronized by the system program at regular (selectable) intervals. You can transfer the date and time from the master clock to the slave clocks using system function SFC48 SFC_RTCB.

Using a Runtime Meter

A runtime meter counts the operating hours of connected equipment or the total runtime hours of the CPU.

In STOP mode, the runtime meter is stopped. Its count value is retained even after a memory reset. During a restart (warm restart), the runtime meter must be restarted by the user program; during a hot restart, it continues automatically if it had already been started.

You can set the runtime meter to an initial value using SFC2 SET_RTM. You can start or stop the runtime meter with SFC3 CTRL_RTM. You can read the current total operating hours and the state of the counter ("stopped" or "counting") with SFC4 READ_RTM.

A CPU can have up to eight run-time meters. Numbering starts at 0.

A.7.4 Using Clock Memory and Timers

Clock Memory

The clock memory is a memory byte that changes its binary state periodically at a pulse-pause ratio of 1:1. You select which memory byte is used on the CPU when you assign parameters for the clock memory using STEP 7.

Uses

You can use clock memory bytes in the user program, for example, to activate flashing lights or to trigger periodic activities (for example, measuring an actual value).

Possible Frequencies

Each bit of the clock memory byte is assigned a frequency. The following table shows the assignment:

Bit of the Clock Memory Byte	7	6	5	4	3	2	1	0
Period Duration (s)	2.0	1.6	1.0	0.8	0.5	0.4	0.2	0.1
Frequency (Hz)	0.5	0.625	1	1.25	2	2.5	5	10

Note

Clock memory bytes are not synchronous with the CPU cycle, in other words, in long cycles, the state of the clock memory byte may change several times.

Timers

Timers are a memory area of the system memory. You specify the function of a timer in the user program (for example, on-delay timer). The number of timers available depends on the CPU.

Note

- If you use more timers in your user program than the CPU permits, a synchronous error is signaled and OB121 started.
 - On the S7-300 (with the exception of the CPU 318), timers can be started and updated simultaneously only in OB1 and OB100; in all other OBs timers can only be started.
-

Index

- "
- "Accessible Nodes" Window 18-2
- *
- *.awl -File 6-25
- *.GSD File 7-1
- *.k7e -Datei 6-25
- *.k7p -File 6-25
- *.sdf -File 6-25
- A**
- Absolute and Symbolic Addressing 8-1
- Access Rights 18-6
- Access Rights to Blocks and Source Files 10-4
- Accessing the Peripheral Data Area A-118
- Accessing the Process Data Area A-117
- ACT_TINT 4-25, 4-26
- Activating 8-14
 - Display of Symbols in the Block 8-14
- Activating the Display of Symbols in the Block 8-14
- Actual Parameters 4-15
- Adding Associated Values to Messages 16-28
- Address Areas A-18, A-19
- Address Assignments
 - Checking 2-12
- Address Priority (Symbolic/Absolute) 8-5
- Addresses
 - Inserting in a Variable Table 20-4
 - Rewiring 9-19
 - Without Symbols 14-10
- Addresses and Data Types Permitted in the Symbol Table 8-11
- Addresses Without Symbols 14-9
- Addressing 8-1, A-120
 - Absolute 8-1, 8-2
 - area-crossing A-54, A-55
 - area-internal A-54
 - DP Standard Slaves A-120
 - Memory Indirect A-54
 - Symbolic 8-1, 8-2, 8-4
- Addressing Modules A-117
- Addressing S5 Modules A-120
- ANY A-52, A-58, A-59, A-60, A-61, A-62, A-63
- Archive
 - CPU Messages 16-39, 16-41
- Archiving
 - Procedure 24-6
 - Projects and Libraries 24-4
 - Requirements 24-5
 - STEP 7 V.2.1 Projects with Global Data Communication A-74
 - Uses 24-5
- ARRAY A-41, A-44, A-45, A-46, A-47
- Assigning and Editing Block-Related Messages 16-12
- Assigning Data Types to Local Data of Logic Blocks A-64
 - Assigning A-64
- Assigning Message Numbers 16-10
- Assigning Parameters
 - Signal Modules with Hardware Interrupt Capability 4-30
- Assigning Parameters to Data Blocks 12-1
- Assigning Parameters to Technological Functions 12-2
- Assigning Parameters to the PG/PC Interface 2-11
- Assigning Symbolic Names A-81
- Assignment of Message Numbers 16-11
- Associated Value
 - Adding to Messages 16-28
- Asynchronous Errors 23-27
 - Delayed Processing A-116
 - Disabling and Enabling A-115
 - OB81 23-28, 23-29, 23-30
 - Using OBs to React to Errors 4-35
- Attributes for Blocks and Parameters 9-19
- Automation License Manager 2-1
- Avoiding Errors when Calling Blocks 15-7

B

- B Stack
 - Data saved in the B Stack A-26
 - Nested Calls A-26
 - Background OB
 - Priority 4-33
 - Programming 4-34
 - Background OB (OB90) 4-33
 - Background Organization Block (OB90) 4-33
 - Basic Information
 - on Data Blocks 11-1
 - Basic Information on Programming in STL
 - Source Files 13-1
 - Basic Procedure
 - for Determining the Cause of a STOP 23-15
 - Planning an Automation Project 3-1
 - when Printing 24-2
 - Basic Procedure for
 - Creating Logic Blocks 10-3
 - Basic Time (see Module Time) 18-9
 - Battery Backup A-30
 - BCD A-39
 - Binary Coded Decimal A-39
 - Bit Messaging 16-1, 16-2
 - BLKMOV A-17
 - BLOCK A-52, A-53
 - Block Calls 4-8, 4-9
 - Block Comment 10-15
 - Block Comments
 - Entering 10-16
 - Block Consistency
 - Checking 15-1
 - Block Folder 5-16
 - Block Folder Object 5-16
 - Block Folder Properties 9-15
 - Displaying Block Lengths 9-15
 - Block for Changing the Pointer A-55
 - Block Lengths 9-15
 - Displaying 9-15
 - Block Properties 9-13, 9-14, 10-3
 - Block Property
 - Time Stamp 15-3
 - Block Stack A-15, A-26
 - Block Title 10-15
 - BLOCK_DB A-52
 - BLOCK_FB A-52
 - BLOCK_FC A-52
 - BLOCK_SDB A-52
 - Block-Related Messages (Project-Oriented)
 - generating 16-13
 - Blocks 15-1
 - Access Rights 10-4
 - Attributes 9-19
 - Comparing 9-18
 - Creating with S7-GRAPH 9-8
 - Deleting on the Programmable Controller 19-19
 - Entering in STL 10-13
 - Reloading in the Programmable Controller 19-6
 - Rewiring 9-19
 - Saving 10-29
 - Uploading from an S7 CPU 19-15
 - Blocks Folder 9-11
 - Blocks for Reporting System Errors
 - Generating 16-49
 - BOOL A-33
 - Area A-33
 - Boxes
 - Positioning 10-19, 10-24
 - Removing
 - Changing 10-24
 - Breakpoint Bar 21-4
 - Browser 5-29
 - Buttons 5-22
 - Toolbar 5-22
 - Buttons in the Toolbar 5-22
 - BYTE A-33
 - Area A-33
- C**
- Call Hierarchy in the User Program 4-8
 - Calling
 - Module Information from the Project View (Online) 23-6
 - Calling the Help Functions 5-5
 - Calling the Quick View 23-5
 - CAN_TINT 4-26
 - Certificate of License 2-1, 2-3
 - CFC 9-10
 - CFC Program 25-1
 - CFC Programming Language 9-2
 - Changing Interfaces 10-28
 - Changing Operator Control and Monitoring
 - Attributes with CFC 17-5
 - Changing the Behavior and Properties of Modules A-121
 - Changing the Declaration Type
 - changing 10-9
 - Changing the Operating Mode 18-8
 - Changing the Window Arrangement 5-31
 - CHAR A-33
 - Checking 13-19
 - Consistency in STL Source Files 13-19
 - Checking Block Consistency 15-1
 - Checking Projects for Software Packages Used 6-14
 - Checking Scan Cycle Times to Avoid Time Errors 23-17
 - Choosing a Messaging Method 16-3

- Clock A-126
 - Parameter Assignment A-126
 - Synchronizing A-126
- Clock Functions A-126
- Clock Memory A-128
- Code Section 10-3, 10-6
 - Editing 10-12
 - Search Function for Errors 10-18
 - Structure 10-12
- Coils
 - Positioning 10-20
- Combination Box
 - Definition 5-23
- Comment Character 20-4
- Comment Line 20-4
- Comment Lines
 - Inserting 20-9
- Comments
 - for Blocks 10-15
 - for Networks 10-15
- Communication Error (OB87) 23-42
- Communication Error Organization Block 23-42
- Compare Preset and
 - Actual Parameters A-5
- Comparing Blocks 9-16
- Comparing On-/Offline Partners 9-16
- Compatibility 7-1, 7-3, A-74
- Compatibility (DP slaves) A-74
- Compatibility (V2 Projects and Libraries 7-1
- Compiling 13-20
 - STL Source Files 13-20
- Compiling and Downloading Objects 19-11
- Compiling Objects 19-11
- Complex Data Types A-41, A-44, A-45, A-48
- Compressing 19-21
 - the Memory Contents of an S7 CPU 19-21
 - User Memory 19-20
- Compressing the User Memory 19-20
- Configurable Memory Objects in the Work Memory A-31
- Configurable Modules A-121
- Configuration Data 17-1, 17-2
 - Transferring 16-38, 17-6
- Configuration Diagram
 - Creating 3-10
- Configuration Table 26-1
- Configuring CPU Messages 16-42
- Configuring Hardware 26-1
- Configuring Messages for System Errors 16-43
- Configuring Operator Control and Monitoring Attributes via the Symbol Table 17-4
- Configuring Operator Control and Monitoring Attributes with Statement List Ladder Logic and Function Block Diagram 17-3
- Configuring the Reporting of System Errors 16-43
- Configuring Variables for Operator Control and Monitoring 17-1
- Connection Table 6-11
- Connection Test (See Flashing Test) 18-2
- Connection to the CPU
 - Establishing 20-13
- Context-Sensitive Help 5-5
- Continuing to Edit Version 2 Projects and Libraries 7-1
- Continuous Function Chart 9-2, 9-10
- Control at Contact 26-4
- Converting A-74
 - Project with Global Data Communication A-74
- Converting Version 1 Projects A-72
- Converting Version 2 Projects A-73
- Copying/Moving Variable Tables 20-3
- Correcting a Memory Bottleneck 19-20
- Correcting the Interfaces
 - in a Function 15-6
 - Function Block or UDT 15-6
- Counter 14-6
 - Assignment List 14-6, 14-7
- COUNTER A-52, A-53
 - Memory Area Retentive A-29
- Counters
 - Upper Limits for Entering 20-8
- CPU 22-1
 - Operating Modes A-1, A-2
 - Resetting 19-18
 - Simulating 22-1
- CPU 31xC 6-22, 6-24, 6-25
- CPU Clocks with Time Zone Setting 18-9
- CPU Hardware Fault (OB84) 23-39
- CPU Hardware Fault Organization Block 23-39
- CPU Messages
 - Archive Size 16-39
 - Displaying 16-39
- CPU Operating System A-124
- CPU Oriented 16-11
- CPU Redundancy Error (OB72) 23-34
- CREAT_DB A-16
- Creating 5-24, A-87
 - FB for the Motor A-83, A-84, A-85, A-86
 - FC for the Valves A-88, A-89
 - OB1 for the Sample Industrial Blending Process A-90
 - Objects 5-24

- STL Source Files 13-14
- User Programs 10-3
- Variable Table 20-3
- Creating a Configuration Diagram 3-10
 - Example of Industrial Blending Process 3-10
- Creating a Data Block in Load Memory 6-22
- Creating a Project 6-9
- Creating a Sample FB for the Industrial Blending Process A-83
- Creating a Sample FC for the Industrial Blending Process A-88
- Creating an I/O Diagram for the Motors 3-6
- Creating an I/O Diagram for the Valves 3-7
- Creating an Input Diagram for the Motors 3-6
- Creating an Input Diagram for the Valves 3-7
- Creating an Object 5-24
- Creating an Output Diagram for the Motors 3-6
- Creating an Output Diagram for the Valves 3-7
- Creating and Editing User-Defined Diagnostic Messages 16-19
- Creating and Managing Objects 5-24
- Creating Foreign-Language Message Texts in Report System Error' 16-51
- Creating Sequential Controls 9-8
 - with S7-GRAPH 9-8
- Creating User Text Libraries 16-34
- Cross-Reference List 14-2, 14-3
- CRST/WRST A-5, A-6, A-7
- CTRL_RTM A-127
- Cycle 4-3
- Cyclic Interrupt
 - Rules 4-28
 - Starting 4-28
- Cyclic Interrupt Organization Blocks (OB30 to OB38) 4-28
- Cyclic Interrupts 4-28, 4-29
- Cyclic Program Execution 4-2

- D**
- Data Block
 - Shared 4-22
 - Structure 4-22
- Data Block (DB) A-29
 - Instance Data Blocks 4-19
 - Retentive A-29
- Data Block Register A-26
- Data Blocks 11-1, 12-1
 - Assigning Parameters to 12-1
 - Basic Information 11-1
 - Data View 11-3
 - Declaration View 11-2
 - Editing Data Values in the Data View 11-9
 - Format Table 13-13
 - Resetting Data Values to their Initial Values 11-9
 - Saving 11-10
- Data Blocks (DB)
 - Instance Data Blocks 4-17
- Data Blocks in STL Source Files 13-27
 - Example 13-27, 13-28
- Data Carrier 6-24
- Data exchange
 - in different operating modes A-13
- Data Record
 - Accessing A-119, A-121
 - Reading A-119
 - Writing A-119
- Data Storage 6-24
- Data Type 9-12
 - DINT A-34
 - DWORD A-39
 - INT A-34
 - S5TIME A-40
 - User-Defined 9-12
 - WORD A-39
- Data Types A-32, A-61, A-62
 - ARRAY A-41
 - BOOL A-33
 - BYTE A-33
 - Complex A-41
 - DATE_AND_TIME A-41, A-42
 - Description A-33
 - Double Word (DWORD) A-33
 - Elementary A-33
 - FB
 - SFB 4-16, A-41
 - REAL A-35
 - STRING A-41
 - STRUCT A-41
 - UDT A-41
 - User Defined A-41
 - Word (WORD) A-33
- Data Values 11-9
 - Editing in the Data View of Data Blocks 11-9
 - Resetting to their Initial Values 11-9
- Data View of Data Blocks 11-3
- DATE_AND_TIME A-41, A-42, A-43, A-44
- Daylight saving time 18-9
- DB 4-22
- Deactivating
 - Time-of-Day Interrupt 4-25
- Debugging STL Source Files 13-19
- Declaration View of Data Blocks 11-2
- Declaring Local Variables A-90

- OB for the Sample Industrial Blending Process A-90
- Declaring Parameters A-88
 - FC for the Sample Industrial Blending Process A-88
- Declaring Local Data A-64
- Default Settings for the LAD/STL/FBD Program Editor 10-4
- Defective
 - CPU Operating Mode A-1
- Defining 8-14
 - Symbols when Programming 8-14
 - the Trigger for Modifying Variables 20-17
 - the Trigger for Monitoring Variables 20-14
- Defining Logic Blocks A-79
- Delayed Processing of Interrupts and Asynchronous Errors A-116
 - Example A-116
- Delaying
 - Start Events 4-36
- Deleting
 - S7 Blocks on the Programmable Controller 19-19
 - STEP 7 Objects 5-24
- Deleting Associated Values 16-31
- Describing the Individual Functional Areas 3-4
- Describing the Operator Console
 - Example of Industrial Blending Process 3-9
- Describing the Required Operator Displays and Controls 3-9
- Detailed Comparison 9-18
- Detectable Errors 23-26
- Determining the Cause of a STOP 23-15
- Diagnosing Hardware
 - Detailed Diagnostic View 23-8
 - Quick View 23-5
- Diagnostic Buffer A-27, A-28
 - Contents 23-23, A-27, A-28
 - Definition A-27
 - Displaying A-28
 - Evaluating A-27
 - Reading 23-18
- Diagnostic Data on Modules 23-21
- Diagnostic Event 23-23, A-27
- Diagnostic Functions 23-23
- Diagnostic Interrupt (OB82) 23-37
- Diagnostic Interrupt Organization Block 23-37, 23-39
- Diagnostic Message
 - Sending to Nodes 23-22
 - Writing Your Own 23-22
- Diagnostic Status Data 23-21
- Diagnostics Symbols 23-3
 - in the Online View 23-3
- Dialog Boxes 5-23
- Differences Between Project-Oriented and CPU-Oriented Assignment of Message Numbers 16-11
- Differences Between Saving and Downloading Blocks 19-2
- DINT A-33, A-34
- Direct Data Exchange (Lateral Communication) 7-3
- DIS_AIRT 4-36
- DIS_IRT 4-36
- Disabling Interrupts and Asynchronous Errors A-115
 - Example A-115
- Display Language 16-32
- Display Options
 - for CPU Messages and User-Defined Diagnostic Messages 16-39
- Displaying
 - Addresses Without Symbols 14-10
 - Block Information for LAD FBD and STL 14-9
 - Block Lengths 9-15
 - Data Structure of Data Blocks Referencing an (Instance DBs) 11-5
 - Deleted Blocks 14-5
 - Lists in Additional Working Windows 14-10
 - Maximum Local Data Requirement in the Tree Structure 14-4
 - Missing Symbols 14-10
 - Module Information 23-2
 - Program Structure 14-10
 - Reference Data 14-10, 14-11
 - Shared or Local Symbols 8-4
 - Unused Addresses 14-10
- Displaying Accessible Nodes 18-2
- Displaying CPU Messages and User-Defined Diagnostic Messages 16-39
- Displaying Modules Configured with Later STEP 7 Versions or Optional Packages 7-6
- Displaying Stored CPU Messages 16-42
- Displaying the Operating Mode 18-8
- Distributed I/O 7-1, 7-3
- Distribution of the Memory Areas A-15
- Dividing a Process into Tasks and Areas for Example of Industrial Blending Process 3-2
- Dividing the Process into Tasks and Areas 3-2
- DMSK_FLT 4-36
- Documentation 1-1, 1-4, 5-6, 5-8, 24-1
- Double Integer (32 Bit) A-34
- Double Word (DWORD) A-33

- Area A-33
- Download Methods Dependent on the Load Memory 19-4
- Download Objects 19-11
- Downloaded Blocks
 - Saving on Integrated EPROM 19-7
- Downloading 19-9, 19-10, A-17
 - Requirements 19-1
 - Several Objects (see Compiling and Downloading Objects) 19-9
 - User Program A-16
 - User Programs 19-3
 - Without Project Management 19-6
- Downloading via EPROM Memory Cards 19-7
- Downward Compatibility 7-3
- DP Slaves 7-1, 7-2
- DP slaves with missing or faulty GSD files A-74
- DP Standard Slaves A-120
- DP/PA-Link (IM 157) 23-13
- DPNRM_DG A-120
- DPRD_DAT A-120
- DPWR_DAT A-120
- Dummy slave A-74
- DWORD A-33, A-39

E

- Editing 8-14
 - Data Values in the Data View of Data Blocks 11-9
 - S7 Source Files 13-14
 - the Symbol Table 8-14
 - Uploaded Blocks
 - if the User Program is Not on the PG/PC 19-17
 - if the User Program is on the PG/PC 19-17
- Editing Areas in Symbol Tables 8-21
- Editing Current Configurations with Previous Versions of STEP 7 7-3
- Editing Libraries (Version 2) 7-1
- Editing Projects (Version 2) 7-1
- Editing Symbol Tables 8-21
- Editing Symbols Across Multiple Networks 26-2
- Editing Uploaded Blocks in the PG/PC 19-16
- Editor
 - Settings for STL 10-4
- Elementary Data Types A-33
- Elements in Dialog Boxes 5-23
- EN_AIRT 4-36
- EN_IRT 4-36
- Enabling Interrupts and Asynchronous Errors A-115

- Example A-115
- Engineering Tools 1-14
- Entering 11-5
 - Block Comments and Network Comments 10-16
 - Data Structure of Data Blocks Referencing an FB (Instance DBs) 11-5
 - Data Structure of User-Defined Data Types (UDT) 11-7
 - Multiple Instance in the Variable Declaration Window 10-11
 - Shared Symbols in a Program 10-14
 - Single Shared Symbols in a Dialog Box 8-14
- Entering and Displaying the Data Structure of Data Blocks Referencing an FB (Instance DBs) 11-5
- Entering and Displaying the Structure of Data Blocks Referencing a UDT 11-8
- Entering Multiple Shared Symbols in the Symbol Table 8-15
- Entering Shared Symbols 8-13
- Entering Symbols 8-15
- Entering the Data Structure of Shared Data Blocks 11-4
- EPROM A-29
- EPROM Area A-16
- Erasing 19-18
 - Load/Work Memory 19-18
- Erasing the Load/Work Memory and Resetting the CPU 19-18
- Error Detection
 - OB Types
 - OB81 23-26
 - Sample Programs
 - Substitute Values 23-31
 - Using Error OBs to React to Errors 4-35
- Error Handling Organization Blocks (OB70 to OB87 / OB121 to OB122) 4-35
- Error OB 23-26, 23-27, 23-28
 - OB Types
 - OB121 and OB122 4-35
 - OB70 and OB72 4-35
 - OB80 to OB87 4-35
 - Using Error OBs to React to Events 4-35
- Error OBs 4-35, 4-36
- Error OBs as a Reaction to Detected Errors 23-26
- Error Search
 - in Blocks 10-18
- Errors (see Compiling and Downloading Objects) 19-11
- Establish
 - Online Connections 18-1

- Establishing
 - Online Connection via the "Accessible Nodes" Window 18-2
 - Online Connection via the Online Window of the Project 18-3
 - Establishing a Connection to the CPU 20-13
 - Establishing the Safety Requirements 3-8
 - Evaluating the Diagnostic Buffer A-27
 - Evaluating the Output Parameter RET_VAL 23-25
 - Example 13-22
 - Entering a Contiguous Address Area 20-10
 - Entering Addresses in Variable Tables 20-9
 - for Disabling and Enabling Interrupts and Asynchronous Errors (SFC39 and SFC40) A-115
 - for Masking and Unmasking Synchronous Errors A-110
 - for the Delayed Processing of Interrupts and Asynchronous Errors (SFC41 and SFC42) A-116
 - of Data Blocks in STL Source Files 13-27
 - of Function Blocks in STL Source Files 13-25
 - of Functions in STL Source Files 13-23
 - of Handling Time-of-Day Interrupts A-96
 - of Organization Blocks in STL Source Files 13-22
 - of User-Defined Data Types in STL Source Files 13-28
 - Example of Working with Address Locations 14-13
 - Examples 20-11
 - Entering Modify and Force Values 20-11
 - of Declaring Variables in STL Source Files 13-21
 - Exceeding the L Stack A-24
 - Exchanging Modules 26-1
 - Exchanging Modules in the Configuration Table 26-1
 - Expanding DP Slaves (Created with Previous Versions of STEP 7) 7-1
 - Export file 6-17, 6-18
 - Exporting
 - Source Files 13-18
 - Symbol Table 8-18
 - Extended Uses of the STEP 7 Standard Package 1-13
- F**
- Faults
 - Locating 23-1
 - FB 4-16, 4-17, 4-18, A-41
 - FBD 9-5
 - Displaying Block Information 14-9
 - Rules 10-24
 - FBD Elements 10-24
 - Representation 10-23
 - Rules for Entering 10-24
 - FBD Layout 10-23
 - FC 4-15, 4-16
 - FC12 A-98
 - FEPROM A-29
 - File Formats for Importing/Exporting a Symbol Table 8-18
 - Filtering Symbols 8-15
 - Finding Address Locations in the Program Quickly 14-12
 - Finding Nodes on the Subnet 18-2
 - Firmware Update A-124
 - Flash-File System 2-8
 - Flashing Test 18-2
 - Floating-Point Numbers A-35, A-36, A-37
 - Flow
 - of Diagnostic Information 23-18
 - Folder 9-11
 - Blocks 9-11
 - for the CPU 16-11
 - for the project 16-11
 - FORCE LED Flashing 18-2
 - Force Values 20-11
 - Examples of Entering 20-11
 - Forcing Variables 20-20
 - Introduction 20-20
 - Safety Measures 20-19
 - Formal Parameters
 - System Attributes and Message Blocks 16-8
 - Format
 - BLOCK A-53
 - COUNTER A-53
 - TIMER A-53
 - Format of the Data Type DATE_AND_TIME A-42
 - Format of the Data Type DINT (32-Bit Integers) A-34
 - Format of the Data Type INT (16-Bit Integers) A-34
 - Format of the Data Type REAL (Floating-Point Numbers) A-35
 - Format of the Data Type S5TIME (Time Duration) A-40

Format of the Data Types WORD and
DWORD in Binary Coded Decimal
Numbers A-39
Format of the Parameter Type ANY A-58
Format of the Parameter Type POINTER
A-53
Format of the Parameter Types BLOCK
COUNTER
TIMER A-53
Format Table of Data Blocks 13-13
Format Table of Function Blocks 13-11
Format Table of Functions 13-12
Format Table of Organization Blocks 13-10
Formats for Blocks in
STL Source Files 13-10
Function
Correcting the Interface 15-6
Function (FC) A-88
Function Block
Correcting the Interface 15-6
Function Block (FB) A-83
Function Block Diagram 9-5
Function Block Diagram Programming
Language (FBD) 9-5
Function Block Diagram(FBD) 9-2
Function Blocks 13-11
Format Table 13-11
Function Blocks (FB) 4-16
Actual Parameters 4-17, 4-18
Application 4-16
Function Blocks in STL Source Files 13-25
Example 13-25
Functional Scope of Report System Errors
16-45
Functions 24-2
Format Table 13-12
Functions (FC) 4-15
Application 4-15
Functions in STL Source Files 13-23
Example 13-23, 13-24

G

Gaps in the User Memory (RAM) 19-20
GD Communication A-74
General Tips
on Entering Symbols 8-13
Generating
Reference Data 14-11
STL Source Files from Blocks 13-17
Generating and Displaying Reference Data
14-11
Generating Blocks for Reporting System
Errors 16-49
Global Data Communication A-74
Global Symbols
Entering in a Program 10-14

GSD file A-74
Guidelines
Handling License Keys 2-5
Guidelines for Handling License Keys 2-5

H

Handling Errors 23-25
Handling Large Projects 26-1
Hardware Diagnostics and Troubleshooting
23-1
Hardware Interrupt 4-30
Priority 4-30
Rules 4-30
Starting 4-30
Hardware Interrupt Organization Blocks
(OB40 to OB47) 4-30
Hardware Interrupts 4-30
Headers and Footers 24-3
Help (Online)
Calling 5-5
Topics 5-5
Hierarchical Structure of Libraries 9-22
HiGraph 9-3
HOLD
CPU Operating Mode A-1
HOLD Mode A-14
Hot Restart A-5, A-6, A-7, A-8, A-9, A-10
Abort A-5
Automatic A-6, A-7
Manual A-5, A-6
How to Assign and Edit Symbol-Related
Messages (CPU-Oriented) 16-26
How to Assign and Edit Symbol-Related
Messages (Project-Oriented) 16-18
How to Assign CPU-Oriented Message
Numbers 16-20
How to Assign Project-Oriented Message
Numbers 16-12
How to Configure PCS 7 Messages (CPU-
Oriented) 16-25
How to Configure PCS 7 Messages
(Project-Oriented) 16-16
How to Create Block-Related Messages
(CPU-Oriented) 16-21
How to Edit Block-Related Messages
(CPU-Oriented) 16-24
How to Edit Block-Related Messages
(Project-Oriented) 16-16
Human Machine Interface 1-18

I

- I Stack
 - Description A-25
- I/O
 - Address Areas A-117
 - I/O Access Error (OB122) 23-44
 - I/O Access Error (PZF) during Update of the Process Image A-20
 - I/O Access Error Organization Block 23-44
 - I/O Data A-118
 - I/O Redundancy Error (OB70) 23-33
 - I/O Redundancy Error Organization Block 23-33, 23-34
 - Icon for unknown modules 7-6
 - Icons for Objects in the SIMATIC Manager 5-6
 - ID Number
 - Entering 2-8
 - Identifying Nodes Directly Connected to a Programming Device/PG 18-2
 - Illegal Logic Operations in Ladder 10-22
 - IM 157 (DP/PA link) 23-13
 - Importing
 - External Source File 6-12
 - Source Files 13-17
 - Symbol Table 8-18
 - IN (Variable Declaration) A-64
 - In/out Parameters A-64, A-65
 - IN_OUT (Variable Declaration) A-64
 - IN_OUT Parameters of a Function Block A-71
 - Incompatibility A-74
 - Incomplete and Non-Unique Symbols in the Symbol Table 8-12
 - Indirect Parameter Assignment A-121
 - Industrial Blending Process A-83, A-88, A-90
 - Information Functions 23-12
 - Information Functions in the Diagnostic View 23-8
 - Information Functions in the Quick View 23-5
 - Information on the Log File 6-19
 - Input Parameters A-64
 - Inputs
 - Assignment List 14-6
 - Process Image A-20
 - Insert/Remove Module Interrupt (OB83) 23-38
 - Insert/Remove Module Interrupt Organization Block 23-38
 - Inserting
 - Addresses or Symbols in a Variable Table 20-4
 - Block Templates in
 - STL Source Files 13-15
 - Comment Lines 20-9
 - Contents of Other
 - STL Source Files 13-15
 - Modify Values 20-7
 - Source Code from Existing Blocks in
 - STL Source Files 13-16
 - Substitute Values for
 - Error Detection 23-31
 - Inserting a Contiguous Address Range in a Variable Table 20-6
 - Inserting an S7/M7 Program 6-12
 - Inserting Block Templates in STL Source Files 13-15
 - Inserting External Source Files 13-16
 - Inserting Program Elements 10-5
 - Inserting Source Code from Existing Blocks in STL Source Files 13-16
 - Inserting Stations 6-11
 - Installation Errors 2-8
 - Installation Procedure 2-8
 - Installation Requirements 2-6
 - Installing
 - STEP 7 2-6, 2-7
 - Installing STEP 7 2-6
 - Installing the Automation License Manager 2-4
 - Instance 4-19, 4-20, 4-21
 - Instance Data Block A-29
 - Retentive A-29
 - Instance Data Blocks 4-19
 - Creating Multiple Instances for an FB 4-16
 - Time Stamps 15-5
 - Instance DB 4-19, 4-20, 4-21
 - Instruction List 10-8
 - Instructions from the Program Elements Table 10-5
 - INT A-33, A-34
 - Integer (16 Bit) A-34
 - Interaction Between The Variable Detail View And The Instruction List 10-8
 - Interrupt Assignments
 - Checking 2-11
 - Interrupt Stack A-15, A-25
 - Interrupt-Driven Program Execution 4-2
 - Interruption Time A-10
 - Interrupts A-115, A-116
 - Delayed Processing A-116
 - Disabling and Enabling A-115
 - Introduction A-32
 - Introduction to Data Types and Parameter Types A-32
 - Introduction to Forcing Variables 20-20
 - Introduction to Testing with the Variable Table 20-1

K

- k7e 6-25
- k7p 6-25
- Key Combinations
 - for Access to Online Help 5-36
 - for Menu Commands 5-33
 - for Moving the Cursor 5-34
 - for Selecting Text 5-36
- Key Combinations for Toggling between Windows 5-37
- Keyboard Control 5-32

L

- L Stack A-24
 - Assigning Memory to Local Variables A-24
 - Overwriting A-24
 - Storing Temporary Variables 4-16
- LAD 9-4
 - Displaying Block Information 14-9
- Ladder Elements
 - Representation 10-19
- Ladder Layout 10-19
- Ladder Logic 9-4
 - Guidelines 10-19
- Ladder Logic (LAD) 9-2
- Ladder Logic Programming Language (LAD) 9-4
- Language
 - for Display 16-32
- Language Editors
 - Starting 9-2
- Large Projects 26-1
- Lateral Communication 7-3
- Libraries 6-13
 - Archiving 24-4
 - Hierarchical Structure 9-22
 - Rearranging 26-2
 - Working with 9-20
- Library 5-9
- Library Object 5-9
- License 2-1, 2-2, 2-3
- License Key 2-1, 2-2, 2-3
- License Keys 2-5
- License Manager 2-1, 2-2
- Linear Programming 4-2
- List Box 5-23
- Listing In/Outs 3-6
- Listing Inputs 3-6
 - Outputs
 - and In/Outs 3-6
- Listing Outputs 3-6
- Lists
 - of Operator Related Texts 16-32
- Load Memory 19-3, 19-4, A-15, A-16
- Load Memory and Work Memory A-16

- Load Memory and Work Memory in the CPU 19-3
- Local Data Requirements 14-4
- Local Data Stack A-15, A-24, A-25
- Local time 18-9
- Locating Faults 23-1
- Logic Blocks A-79
 - in the Incremental Editor 10-3
 - Saving 10-29
 - Structure 10-3
 - Time Stamps 15-4

M

- M7 Program 6-13
- M7 Programming
 - Optional Software 25-3, 25-4
- M7-300/M7-400
 - Operating Systems 25-1
- M7-300/M7-400 Operating Systems 25-6
- Make (see Checking Block Consistency) 15-1
- Managing
 - Objects 5-24, 5-25, 5-26, 5-27, 5-28
- Managing Multilingual Texts 6-14
- Managing User Texts Whose Language Font is Not Installed 6-18
- Masking
 - Start Events 4-35
- Masking Synchronous Errors A-110
 - Example A-110
- Memory A-31
 - Configurable A-31
- Memory Area A-29
 - Memory Area
 - Retentive A-29, A-30
- Memory Areas A-15
 - Address Areas A-18
 - Load Memory A-15
 - Retentive A-29, A-30
 - Special Features with S7-300 A-16
 - Special Features with S7-400 A-16
 - System Memory A-15
 - Work Memory A-15
- Memory bit
 - Assignment List 14-6
- Memory Card A-17
 - Assigning Parameters 2-9
- Memory Card file 6-24
- Memory Reset A-4
- Message
 - Example 16-6
 - Parts 16-5
- Message Blocks
 - Overview 16-6
- Message Configuration
 - SIMATIC Components 16-5

- Transferring Data to WinCC 16-38
 - Message number assignment 16-11
 - Message Numbering 16-2
 - Message Numbers 16-11
 - Message Type 16-9, 16-10
 - Message Type and Messages 16-9
 - Messages (CPU-Oriented)
 - symbol-related 16-26
 - Messages (Project-Oriented)
 - symbol-related 16-18
 - Message-type Block 16-14, 16-22
 - Messaging Numbers 16-10
 - Assigning 16-10
 - Micro Memory Card (MMC) 6-24, 6-25
 - Micro Memory Cards (MMC) 6-22
 - MMC 6-22, 6-23, 6-24, 6-25
 - Mnemonics
 - Setting 10-26
 - Mode Transitions A-2, A-3
 - Modify Values 20-11
 - Examples of Entering 20-11
 - Inserting 20-7
 - Modifying
 - Basic Procedure 20-2
 - Modifying Variables
 - Introduction 20-16
 - Modifying Variables With the Program
 - Editor 26-4
 - Module 22-1
 - Simulating 22-1
 - Module Exists/Type Monitoring
 - Startup OBs 4-31
 - Module icon for unknown modules 7-6
 - Module Information 23-7, 23-13
 - Calling from the Project View (Online) 23-6
 - Displaying 23-2
 - Displaying for PA Field Devices 23-13
 - Displaying for PA Field Devices After a Y-Link 23-13
 - Options for Displaying 23-9
 - Updating 23-11
 - Module Information Functions 23-10
 - Module Parameters A-121, A-122, A-123
 - Transferring with SFCs A-121
 - Transferring with STEP 7 A-121
 - Module Start Address A-117
 - Module Status 23-12
 - Information Functions 23-10
 - Module Time 18-9, 18-10
 - Modules 26-1
 - Exchanging 26-1
 - Parameter Assignment A-121, A-123
 - Monitoring
 - Basic Procedure 20-2
 - Monitoring Times 4-32
 - Monitoring Variables 20-14
 - Defining the Trigger 20-14
 - Introduction 20-14
 - Motors 3-6
 - Creating an I/O Diagram 3-6
 - Moving
 - Object 5-24, 5-25, 5-26, 5-27, 5-28
 - MPI Card for PG/PC 2-11
 - MPI FW Update 18-10
 - MPI Interface 2-6, 2-7
 - MPI-ISA Card (Auto) 2-11
 - MSK_FLT 4-36
 - Multiple Instance 4-16
 - entering in the Variable Declaration Window 10-11
 - Multiple instances
 - Use 10-10
 - Multiple Instances 4-21
 - Rules 10-11
 - Multiproject
 - Online Access to PLCs in 18-4
- ## N
- Naming Conventions 17-2
 - for Configuration Data 17-1
 - Nested Calls of Logic Blocks A-26
 - Effects on the B Stack and L Stack A-26
 - Nesting A-26
 - Nesting Depth 4-8
 - Network Comment 10-15
 - Network Comments
 - Entering 10-16
 - Network Templates
 - Working with 10-17
 - Network Title 10-15
 - Networks 9-5
 - Ladder Logic 10-19
 - Non-Retain 9-14
 - Non-Volatile RAM A-29
 - Notes on STEP 7 V.2.1 Projects with GD
 - Communication A-74
 - Number Notation A-32
 - NVRAM A-29, A-30
- ## O
- OB 4-2, 4-3, 4-4, 4-5, 4-6
 - OB1 A-90, A-91, A-92, A-108
 - OB1 and OB80 A-102
 - OB10 A-100, A-101
 - OB100 A-5
 - OB101 A-5, A-12
 - OB102 A-5
 - OB121 23-43
 - OB122 23-44
 - OB20 A-106
 - OB70 23-33
 - OB72 23-34

- OB80 23-35
- OB81 23-36
- OB82 23-37
- OB83 23-38
- OB84 23-39
- OB85 23-40, A-23
- OB86 23-41
- OB87 23-42
- Object
 - Cutting
 - Copying
 - Pasting 5-26
 - Deleting 5-28
 - Moving 5-27
 - Opening 5-25
 - Properties 5-25, 5-26, 5-27
 - Renaming 5-26, 5-27
 - Selecting 5-29
- Object Hierarchy 5-6
 - Building 5-25
- Objects 5-6, 5-7
 - as Carriers of Functions 5-7
 - as Carriers of Properties 5-6
 - as Folders 5-6
 - Managing 5-24
- Objects and Object Hierarchy 5-6
- Offline Updating of the Firmware in Modules and Submodules A-124
- Offset factor 18-9
- Online Access to PLCs in a Multiproject 18-4
- Online Connection
 - Establishing via the "Accessible Nodes" Window 18-2
 - Establishing via the Online Window of the Project 18-3
- Online Connection by Means of DP Interface 7-3
- Online Connections
 - Establish 18-1
- Online Help
 - Calling 5-5
 - Changing the Font Size 5-5
 - Topics 5-5
- Online Updating of Firmware in Modules and Submodules 18-10
- Online View 23-3
 - Diagnostic Symbols 23-4
- Opening
 - Symbol Table 8-15
 - Variable Table 20-3
- Operating Mode A-2, A-3
 - Displaying and Changing 18-8
 - HOLD A-1, A-2, A-3
 - RUN A-1, A-2, A-3
 - STARTUP A-5
 - STARTUP A-1, A-2, A-3
 - STOP A-4
- Operating Mode STOP 23-15
 - Stack Contents 23-15, 23-16
- Operating Modes
 - Priority A-3
- Operating Modes and Mode Transitions A-1
- Operating Philosophy 5-21
- Operating System
 - Tasks 4-1
- Operator Console 3-9
- Operator Control and Monitoring Attributes
 - 17-1
 - CFC 17-5
 - Configuring with STL
 - LAD
 - FBD 17-3
 - Configuring with Symbol Table 17-4
- Operator Displays and Controls
 - Example of Industrial Blending Process 3-9
- Operator Related Texts
 - Exporting/Importing 16-32
 - Requirements 16-32
- Optimizing the Source for Translation 6-20
- Optimizing the Translation Process 6-21
- Optional Package 22-1
- Optional Software for M7 Programming 25-4
- Options for Displaying the Module Information 23-9
- Options for Modifying the Message
 - Number Assignment of a Project 16-11
- Organization Block (OB) 4-33
 - Background OB (OB90) 4-2
- Organization Blocks 13-10
 - Creating an OB for the Sample Industrial Blending Process A-90
 - Definition 4-2
 - Error Detection
 - OB122
 - Substitute Values 23-31
 - Format Table 13-10
 - Priority Classes 4-2, 4-4, 4-5
 - Reacting to Errors 4-35
- Organization Blocks and Program Structure 4-2
- Organization Blocks in STL Source File 13-22
 - Example 13-22
- OUT (Variable Declaration) A-64
- Output Parameter 23-25, 23-26
 - Evaluating RET_VAL 23-25
- Output Parameters A-64
- Outputs
 - Assignment List 14-6
 - Process Image A-20

- Overview 1-4, 14-1, 16-6
 - Message Blocks 16-6
 - of the Available Reference Data 14-1
- Overview of STEP 7 1-1
- Overview of the Available Reference Data 14-1
- Overview of the Standard Libraries 9-22
- Overwrite Mode 10-18
- Overwriting the L Stack A-24

- P**
- PA Field Devices 23-13
- Page Format
 - Setting 24-3
- Parameter Assignment A-126
 - Clock A-126
 - Indirect A-121
 - with SFCs A-123
 - with STEP 7 A-123
- Parameter Type POINTER
 - Using A-54
- Parameter Types A-52, A-61
- Parameters 9-19
 - Attributes 9-19
- Parent/Child Structure 14-4
- PARAM_MOD A-119, A-123
- Part Process Image (Process Image Partition) A-20
 - System Update A-22
 - Updating with SFCs A-20
- Parts of a Message 16-5
- Password 18-6
- Password Protection for Access to Programmable Controllers 18-6
- PC Station 7-4, 7-5
- Peripheral Data A-118
- Permitted Block Properties for Each Block Type 13-7
- Permitted Data Types when Transferring Parameters A-66
- PG/PC Interface 2-11
 - Parameter Assignment 2-11
- Phase Offset 4-29
- Planning an Automation Project
 - Basic Procedure 3-1
 - Creating a Configuration Diagram 3-10
 - Creating an I/O Diagram
 - for the Motors 3-6
 - Creating an I/O Diagram
 - for the Valves 3-7
 - Describing the
 - Individual Function Areas 3-4
 - Describing the Required Operator
 - Displays and Controls 3-9
 - Dividing the Process into Tasks and Areas 3-2
 - Establishing the
 - Safety Requirements 3-8
 - Listing Inputs
 - Outputs
 - and In/Outs 3-6
 - Pointer A-54, A-55, A-56, A-57
 - POINTER A-52, A-53, A-54
 - Positioning
 - Boxes 10-24, 10-25
 - Power Failure A-5
 - Power Flow 10-22
 - Power Supply Error (OB81) 23-36
 - Power Supply Error
 - Organization Block 23-36
 - Preventing Personal Injury 20-20
 - Preventing Property Damage 20-20
 - Printer
 - Setting Up 24-2
 - Printing
 - Blocks 24-1
 - Configuration Table 24-1
 - Diagnostic Buffer Content 24-1
 - Global Data Table 24-1
 - Reference Data 24-1
 - Symbol Table 24-1
 - Variable Table 24-1
 - Printing Project Documentation 24-1
 - Priority
 - Background OB 4-33
 - Hardware Interrupt 4-30
 - Time-Delay Interrupt 4-27
 - Time-of-Day Interrupt 4-25
 - Priority (Symbolic/Absolute Address) 8-5
 - Procedure 24-6
 - for Archiving/Retrieving 24-6
 - for Entering Statements 10-13
 - for M7 Systems 25-1
 - Process
 - Dividing into Tasks 3-2
 - Process control dialog
 - see How to Configure of PCS 7
 - Messages (CPU-Oriented) 16-25
 - Process Control Dialog
 - see How to Configure PCS 7 Messages (Project-Oriented) 16-16
 - Process Image A-20
 - Clearing 4-32
 - Inputs/Outputs A-20
 - Process Monitoring 17-1, 20-2
 - PROFIBUS 18-11, 18-12
 - PROFIBUS DP 7-2
 - PROFIBUS PA Devices 23-13
 - PROFIBUS-DP 7-3
 - PROFINET Nodes 18-2
 - Program Creation
 - General Procedure 1-1
 - Program Editor 9-16, 9-17, 9-18, 10-1

- Program Execution
 - Cyclic 4-2, 4-4, 4-5, 4-6
 - Interrupt-Driven 4-2
 - Program Measures for
 - Handling Errors 23-24
 - Program Sequence Error (OB85) 23-40
 - Program Sequence Error Organization
 - Block 23-40
 - Program Status
 - Setting the Display 21-7
 - Testing with 21-1
 - Program Status Display 21-2
 - Program Status of Data Blocks 21-6
 - Program Structure 14-4, 14-5
 - Displaying 14-10
 - Programmable Controller
 - Reloading Blocks 19-6
 - Programmable Module Object Folder 5-12
 - Programming
 - Background OB 4-33
 - Transferring Parameters 4-16
 - Using Data Blocks 4-16
 - Programming Error (OB121) 23-43
 - Programming Error
 - Organization Block 23-43
 - Programming Language
 - S7-GRAPH (Sequential Control) 9-8
 - Selecting 9-2
 - Programming Languages 1-6, 1-9
 - Function Block Diagram (FBD) 9-5
 - Ladder Logic (LAD) 9-4
 - S7 CFC 9-10
 - S7 HiGraph 9-9
 - S7 SCL 9-7
 - STL 9-6
 - Programming Steps
 - S7 1-4
 - Programs in a CPU 4-1
 - Project 5-8, 5-9
 - Creating Manually 6-9
 - Creating Using the Wizard 6-9
 - Project Documentation
 - Printing 24-1
 - Project Language 6-5, 6-6, 6-7
 - Project Object 5-8
 - Project Structure 6-2
 - Project View 6-2
 - Project Window 6-1, 6-2
 - Project-Oriented 16-11
 - Projects 24-4
 - Archiving 24-4
 - Rearranging 26-2
 - Renaming 5-24
 - Projects with a Large Number of Networked Stations 26-1
 - PZF (I/O Access Error) A-20
- Q**
- QRY_TINT 4-26
 - Querying
 - Time-of-Day Interrupt 4-25
 - Quick View of the
 - Diagnostic Information 23-5
- R**
- Rack Failure (OB86) 23-41
 - Rack Failure Organization Block 23-41
 - RAM A-15, A-29
 - RAM Area A-16, A-30
 - RDSYSST 23-18, 23-20, A-28
 - READ_CLK A-126
 - READ_RTM A-126
 - Reading and Adjusting the TOD and the TOD Status 18-9
 - Reading from a Data Block in
 - Load Memory 6-22
 - REAL A-33, A-35
 - Rearranging Projects and Libraries 26-2
 - Redundant Mode 18-12
 - Reference Data 14-1
 - Application 14-1
 - Displaying 14-10, 14-11
 - Generating 14-11
 - Reloading Blocks in the Programmable Controller 19-6
 - Remaining Cycle A-6, A-9, A-10
 - Renaming A-74
 - Projects 5-24, 5-26
 - STEP 7 V.2.1 Projects with Global Data Communication A-74
 - Report System Errors 16-45
 - Supported Components 16-45
 - Reporting System Errors 16-43, 16-49
 - Representation
 - FBD Elements 10-23
 - Ladder Elements 10-19
 - STL 10-26
 - Representation of unknown modules 7-6
 - Representative modules 7-6
 - Requirements 19-1
 - Archiving 24-5
 - for Downloading 19-1
 - Requirements for and Notes on Downloading 19-9
 - Resetting 11-9
 - Data Values to their Initial Values 11-9
 - the CPU 19-18
 - Restoring
 - Window Arrangement 5-31
 - Retentive Memory Areas on S7-300 CPUs A-29
 - Retentive Memory Areas on S7-400 CPUs A-30

- Retentivity
 - on Power Failure A-5
 - Retrieving
 - Procedure 24-6
 - Rewiring 9-19
 - Addresses 9-19
 - Blocks 9-19
 - Ring Buffer (Diagnostic Buffer) A-27
 - RPL_VAL 23-31
 - Rules 8-18
 - Cyclic Interrupt 4-28
 - FBD 10-24
 - for Block Order in STL Source Files 13-4
 - for Declaring Multiple Instances 10-11
 - for Declaring Variables in STL Source Files 13-3
 - for Exporting the Symbol Table 8-18
 - for Importing the Symbol Table 8-18
 - for Setting Block Properties in STL Source Files 13-5
 - for Setting System Attributes in STL Source Files 13-4
 - Hardware Interrupt 4-30
 - Ladder Logic 10-19
 - Statement List 10-26
 - Time-Delay Interrupt 4-27
 - Time-of Day-Interrupt 4-25
 - Rules for Entering FBD Elements 10-24
 - Rules for Entering Ladder Logic Elements 10-19
 - Rules for Entering STL Statements 10-26
 - RUN
 - CPU Activities A-5
 - CPU Operating Mode A-1
 - RUN Mode A-13
 - Run-Time Meter A-126
 - Run-Time Software 1-16
- S**
- S5 TIME A-33
 - S5TIME A-40
 - S7 CFC Programming Language 9-10
 - S7 Export File 6-25
 - S7 HiGraph 9-9
 - S7 HiGraph Programming Language (State Graph) 9-9
 - S7 Program
 - Inserting 6-13
 - S7 SCL Programming Language 9-7
 - S7 Source Files 13-14
 - Editing 13-14
 - S7/M7 Program 5-14
 - S7/M7 Program Folder 5-14
 - S7/M7 Program without a Station or CPU 5-20
 - S7-GRAPH 9-2, 9-8
 - S7-Routing 18-10
 - Safety Measures When Forcing Variables 20-19
 - Safety Notes A-24
 - Exceeding the L Stack A-24
 - Overwriting the L Stack A-24
 - Safety Requirements 3-8
 - Example of an Industrial Blending Process 3-8
 - Sample Program A-79, A-81, A-86, A-88, A-90, A-91, A-110, A-115, A-116
 - Sample Program for an Industrial Blending Process A-77
 - Sample Programs A-75, A-83
 - FB for the Industrial Blending Process A-83
 - FC for an Industrial Blending Process A-88
 - Industrial Blending Process A-77
 - Creating a Configuration Diagram 3-10
 - Describing the Individual Functional Tasks and Areas 3-4
 - Describing the Individual Tasks and Areas
 - Creating an I/O Diagram 3-6
 - Describing the Operator Displays and Controls 3-9
 - Describing the
 - Safety Requirements 3-8
 - Dividing the Process into Tasks and Areas 3-2
 - Inserting Substitute Values 23-31
 - OB for the Sample Industrial Blending Process A-90
 - Reaction to Battery Error 23-26
 - Substitute Values 23-31
 - Sample Projects A-75, A-76
 - Save as 6-25
 - Saving
 - Blocks 10-29
 - Data Blocks 11-10
 - Downloaded Blocks on Integrated EPROM 19-7
 - Logic Blocks 10-29
 - STL Source Files 13-19
 - Uses 24-5
 - Variable Table 20-4
 - Window Arrangement 5-31
 - SCAN Message
 - see Symbol-Related Messages (Project-Oriented) 16-18
 - SCAN messages (CPU-Oriented)
 - see Symbol-Related Message 16-26
 - SCL 9-2, 9-7
 - Scope of the Module Type-Dependent Information 23-12
 - sdf 6-25

- Search Function for Errors in the Code
 - Section 10-18
- Selecting
 - Editing Method 9-1
 - Programming Language 9-2
- Selecting Objects in a Browser 5-29
- Sending
 - Your Own Diagnostic Messages 23-22
- Session Memory 5-30
- SET_CLK 4-26, A-126
- SET_CLKS 18-9
- SET_RTM A-126
- SET_TINT 4-25, 4-26
- Setting
 - Operating Behavior A-120
 - Virtual Work Memory 26-5
- Setting the Address Priority (Symbolic/Absolute) 8-5
- Setting the Display for Program Status 21-7
- Setting The Layout of Source Code Text 13-15
- Setting The Layout of Source Code Text Code 13-15
- Setting the Mnemonics 10-26
- Setting the Mode for the Test 21-8
- Setting the MS Windows Language 6-8
- Setting the PG/PC Interface 2-11
- Settings for Function Block Diagram Programming 10-23
- Settings for Ladder Logic Programming 10-19
- Settings for Reporting System Errors 16-48
- Settings for Statement List Programming 10-26
- Setup
 - Entering ID Number 2-8
 - Flash-File System 2-8
 - Memory Card Parameters 2-9
- SFB 4-23, A-41
- SFB33 16-7
- SFB34 16-7
- SFB35 16-7
- SFB36 16-7
- SFB37 16-7
- SFC 4-23
 - Using A-20
- SFC 13 DPNRM_DG A-120
- SFC 14 DPRD_DAT A-120
- SFC 15 DPWR_DAT A-120
- SFC 55 WR_PARM A-121
- SFC 56 WR_DPARM A-121
- SFC 57 PARM_MOD A-121
- SFC0 SET_CLK A-126
- SFC1 READ_CLK A-126
- SFC100 'SET_CLKS' 18-9
- SFC17/18 16-6
- SFC2 SET_RTM A-127
- SFC20 BLKMOV A-16
- SFC22 CREAT_DB A-16
- SFC26 UPDAT_PI A-20
- SFC27 UPDAT_PO A-20
- SFC28 SET_TINT 4-25, A-96
 - Example in STL A-96
- SFC29 CAN_TINT 4-25, A-96
 - Example in STL A-96
- SFC3 CTRL_RTM A-126
- SFC30 ACT_TINT 4-25, A-96
 - Example in STL A-96
- SFC31 QRY_TINT 4-25, A-96
 - Example in STL A-96
- SFC32 SRT_DINT 4-27
- SFC36 MSK_FLT 4-35
 - Example in LAD A-110
 - Example in STL A-110
- SFC37 DMSK_FLT 4-35
 - Example in LAD A-110
 - Example in STL A-110
- SFC38 READ_ERR
 - Example in LAD A-110
 - Example in STL A-110
- SFC39 DIS_IRT 4-35
 - Example in STL A-115
- SFC4 READ_RTM A-127
- SFC40 EN_IRT 4-35
 - Example in STL A-115
- SFC41 DIS_AIRT 4-35
 - Example in STL A-116
- SFC42 EN_AIRT 4-35
 - Example in STL A-116
- SFC44 RPL_VAL 23-31
- SFC48 SNC_RTCB A-126
- SFC51 RDSYSST 23-18, 23-19, A-27
- SFC52 WR_USMSG 23-22
- SFC55 WR_PARM A-118
- SFC56 WR_DPARM A-118
- SFC57 PARM_MOD A-118
- SFC82 6-22
- SFC83 6-22
- SFC84 6-22
- Shared and Local Symbols 8-3
- Shared Data Blocks 11-4
 - Entering the Data Structure 11-4
 - Time Stamps 15-5
- Shared Data Blocks (DB) 4-22
- Short Circuit
 - Ladder Logic
 - Illegal Logic Operations 10-22
- Signal Module 22-1
 - Simulating 22-1
- Signal Modules with Hardware Interrupt Capability
 - Assigning Parameters 4-30
- SIMATIC Components 16-5

- SIMATIC Manager 5-1, 9-16, 9-18
 - Displaying Block Lengths 9-15
- SIMATIC PC - Appending Configurations of Previous Versions 7-4
- SIMATIC PC Station 7-4
- Simulating a CPU or Signal Module 22-1
- Simulation Program 22-1
- Slaves with missing
 - or faulty GSD files A-74
- SlotPLC 6-24
- SNC_RTCB A-126
- Software Packages
 - Checking Projects for 6-14
- Software PLC 6-24
- Sorting in the Cross Reference List 14-2
- Sorting Symbols 8-15
- Source Code 13-15
- Source File Folder 5-19
- Source File Folder Object 5-19
- Source Files 13-18
 - Access Rights 10-4
 - Exporting 13-18
 - External 6-13
 - Generating STL Source Files
 - from Blocks 13-17
 - Importing 13-17
 - Inserting External Source Files 13-16
 - Rules for Block Order in STL Source Files 13-4
 - Rules for Declaring Variables in STL Source Files 13-3
 - Rules for Entering Statements in STL Source Files 13-2
 - Rules for Setting Block Properties in STL Source Files 13-5
 - Rules for Setting System Attributes in STL Source Files 13-4
 - Saving STL Source Files 13-19
- Source Files in S7-GRAPH 9-8
- Special Note on Printing the Object Tree 24-3
- SRT_DINT 4-27
- SSL 23-19
- Stack Contents in STOP Mode 23-15
- Standard Libraries 9-22
 - Overview 9-22
- Standard Library 6-12
- Start Address A-118
- Start Events
 - Delaying 4-35
 - Masking 4-36
 - Startup OBs 4-31
- Starting
 - Cyclic Interrupt 4-28, 4-29
 - Hardware Interrupt 4-30
 - Time-Delay Interrupt 4-27
 - Time-of-Day Interrupt 4-25, 4-26
- Starting STEP 7 Installation 2-8
- Starting STEP 7 with Default Start Parameters 5-3
- STARTUP A-5, A-9, A-10, A-11, A-12
 - Abort A-5
 - CPU Activities A-5
 - CPU Operating Mode A-1
 - Startup OB A-5, A-9, A-10, A-12
 - Startup OBs 4-31
 - Module Exists/Type Monitoring 4-32
 - Start Events 4-31
 - Startup Organization Blocks (OB100 / OB101 / OB102) 4-31
 - Startup Program 4-31
- STAT (Variable Declaration) A-64
- State Graph 9-9
- Statement List 9-6, 10-26
 - Representation 10-26
 - Rules 10-26
- Statement List (STL) 9-2
- Statement List Programming Language (STL) 9-6
- Statements
 - Entering
 - Procedure 10-13
- Station 5-10, 5-11
 - Inserting 6-11
 - Uploading 19-15
- Station Object 5-10
- Status Bar
 - Example 5-22
- STEP 7 1-6, 1-7, 1-9
 - Error OBs
 - Reacting to Errors 4-35
 - Errors During Installation 2-8
 - Installation 2-6, 2-7
 - Removing 2-13
 - Starting the Software 5-1
 - Uninstalling 2-13
 - User Interface 5-22
- STEP 7
 - Programming Languages 1-6
 - Standard Software 1-6
- STL 9-6
 - Displaying Block Information 14-9
 - Entering Blocks 10-13
- STL Editor
 - Settings 10-4
- STL Source File 13-10
 - Formats for Blocks 13-10
- STL source files
 - Creating 13-14
- STL Source Files 13-1
 - Basic Information on Programming 13-1
 - Checking Consistency 13-19
 - Compiling 13-20
 - Debugging 13-19

- Example of Data Blocks 13-27
- Example of Function 13-23
- Example of Function Blocks 13-25
- Example of Organization Blocks 13-22
- Example of User-Defined Data Types 13-28
- Examples of Declaring Variables 13-21
- Generating from Blocks 13-17
- Inserting Block Templates 13-15
- Inserting External Source Files
 - External Source Files 13-16
- Inserting Source Code from Existing Blocks 13-16
- Inserting the Contents of Other STL Source Files 13-15
- Rules for Block Order 13-4
- Rules for Declaring Variables 13-3
- Rules for Entering
 - for Entering Statements in STL Source Files 13-2
- Rules for Setting Block Properties 13-5
- Rules for Setting System Attributes 13-4
- Saving 13-19
- Structure of Blocks 13-7
- Structure of Data Blocks 13-9
- Structure of Logic Blocks 13-8
- Structure of User-Defined Data Types 13-9
- Syntax for Blocks 13-10
- STOP
 - CPU Operating Mode A-1
- STOP Mode A-4
- Storing Project Data on a Micro Memory Card (MMC) 6-25
- STRING A-41, A-44
- STRUCT A-41, A-44, A-48
- Structure 9-12
 - Blocks in STL Source Files 13-7
 - Cross-Reference List 14-2, 14-3
 - Data Blocks in STL Source Files 13-9
 - Load Memory A-16, A-17
 - Logic Blocks in STL Source Files 13-8
 - of the Code Section 10-12
 - of the User Program "Time-of-Day Interrupts" A-96
- UDT 9-12
- User-Defined Data Type (UDT) 9-12
- User-Defined Data Types in STL Source Files 13-9
 - Variable Declaration Window 10-9
- Structure and Components of the Symbol Table 8-9
- Structure of the export file 6-17
- Structure of the Program Editor Window 10-1
- Structure of the User Program "Time-Delay Interrupts" A-104
- Structured Control Language 9-7
- Structured Data Types A-41
- Structured Programming 4-7
- Substitute Value
 - Using SFC44 (RPL_VAL) 23-31
- Summer/winter time 18-9, 18-10
- Supported Components and Functional Scope 16-45
- Symbol Table 8-4
 - File Formats for
 - Importing/Exporting 8-18
 - for Shared Symbols 8-9
 - Opening 8-15
 - Permitted Addresses 8-11
 - Permitted Data Types 8-11
 - Structure and Components 8-9
- Symbolic Addressing 8-4
 - Sample Program A-81
- Symbolic Names A-81
 - Assigning A-81
- Symbol-Related Messages (CPU-Oriented)
 - Assignment to the Symbol Table 16-26
 - Permitted signals 16-26
- Symbol-Related Messages (Project-Oriented)
 - Assignment to the Symbol Table 16-18
 - permitted Signals 16-18
- Symbols 8-1, 8-2, 8-4, 8-16
 - Defining when Programming 8-14
 - Entering 8-15
 - Filtering 8-15
 - for the Program Structure 14-4, 14-5
 - Inserting in a Variable Table 20-4
 - Local 8-3
 - Shared 8-3
 - Sorting 8-15
 - STEP 7 Objects 5-6
 - Unused 14-8
 - Upper and Lower Case 8-16
- Symbols for Objects in the SIMATIC Manager 5-6
- Synchronizing A-126
 - Clock A-126
- Synchronous Errors A-110
 - Masking and Unmasking A-110
 - Using OBs to React to Errors 4-35
- Syntax for Blocks in STL Source Files 13-10
- System Attributes
 - for Configuration of PCS 7 Messages (CPU-Oriented) 16-25
 - for configuring PCS 7 Messages (Project-Oriented) 16-16
 - for Message Configuration 16-8
 - for Parameters 10-6
 - in the Symbol Table 8-9, 8-10
- System Data 23-20

- System Diagnostics
 - Extending 23-22
 - System Error 23-23
 - System Function Blocks 4-23
 - System Function Blocks (SFB) and System Functions (SFC) 4-23
 - System Functions 4-23
 - System Memory A-15, A-18
 - System Parameters A-120
 - System Status List 23-19, 23-20, 23-21
 - Contents 23-19
 - Reading 23-19
 - System Text Libraries 16-36
- T**
- Tabs in Dialog Boxes 5-23
 - Tasks
 - Example of Industrial Blending Process 3-2
 - Tasks and Areas
 - Example of Industrial Blending Process 3-4
 - TEMP (Variable Declaration) A-64
 - Temporary Variables A-64, A-65
 - Test
 - Setting the Mode 21-8
 - Testing 20-1
 - Using Program Status 21-1
 - using the Simulation Program (Optional Package) 22-1
 - with the Variable Table 20-1
 - Testing in Single-Step Mode 21-3, 21-4
 - Testing with the Variable Table 26-3
 - Text Libraries 16-36
 - Translating 16-36
 - Text Library 16-30, 16-31
 - Integrating Texts into Messages 16-30
 - Text Lists
 - see Lists of User Texts 16-32
 - The Message Concept 16-1
 - The STEP 7 Standard Package 1-7
 - Time A-33
 - Reading A-126
 - Setting A-126
 - Time Error (OB80) 23-35
 - Time Error Organization Block 23-35
 - Time Format A-126
 - TIME OF DAY A-33
 - Time stamp 18-9
 - Time Stamp Conflicts 15-3
 - Time Stamps 15-5
 - as a Block Property 15-3
 - in Instance Data Blocks 15-5
 - in Logic Blocks 15-4
 - in Shared Data Blocks 15-5
 - Time stamps in UDTs and Data Blocks
 - Derived from UDTs 15-6
 - Time Zones 18-9
 - Time-Delay Interrupt
 - Priority 4-27
 - Rules 4-27
 - Starting 4-27
 - Time-Delay Interrupt Organization Blocks (OB20 to OB23) 4-27
 - Time-Delay Interrupts 4-27
 - Time-of-Day Interrupt
 - Changing the Time 4-26
 - Deactivating 4-26
 - Priority 4-26
 - Querying 4-26
 - Rules 4-25
 - Starting 4-25
 - Time-of-Day Interrupt Organization Blocks (OB10 to OB17) 4-25
 - Time-of-Day Interrupts 4-25
 - Handling A-96
 - Structure A-96
 - TIMER A-52, A-53
 - Timers
 - Upper Limits for Entering 20-7
 - Timers (T) A-128
 - Memory Area Retentive A-29
 - Times 14-6
 - Assignment List 14-6
 - Tips and Tricks 26-1, 26-2, 26-3, 26-5
 - Title Bar 5-22
 - Titles
 - for Blocks 10-15
 - for Networks 10-15
 - TOD Interrupt 18-9
 - TOD Status 18-10
 - TOD Synchronization 18-10
 - Toggling between Windows 5-37
 - Toolbar
 - Buttons 5-22
 - Transferring Configuration Data to the Operator Interface Programmable Controller 17-6
 - Transferring Configuration Data to the Programmable Controller 16-38
 - Transferring Parameters
 - Saving the Transferred Values 4-16
 - Transferring to IN_OUT Parameters of a Function Block A-71
 - Translating and Editing
 - Operator Related Texts 16-32
 - Translating and Editing User Texts 16-32
 - Tree Structure 14-4
 - Trigger Frequency 20-14
 - Trigger Point
 - Setting 20-14

- Troubleshooting 23-1
 - Sample Programs 23-26
 - Type File 7-1
 - Types of Interrupt 4-2
 - Types of Licenses 2-3
 - Enterprise License 2-1
 - Floating License 2-3
 - Rental License 2-3
 - Trial License 2-3
 - Upgrade License 2-1
 - Types of Multilingual Texts 6-16

 - U**
 - UDT 9-12, A-41, A-50, A-51
 - Uninstalling STEP 7 2-13
 - Uninstalling the User Authorization 2-5
 - Unmasking
 - Start Events 4-35
 - Unmasking Synchronous Errors A-110
 - Example A-110
 - Unused Addresses
 - Displaying 14-10
 - Unused Symbols 14-8
 - UPDAT_PI A-20
 - UPDAT_PO A-20
 - Update (CPU Operating System) A-124
 - Updating 18-13, A-124, A-125
 - Firmware (of the Operating System) in Modules and Submodules Offline A-124
 - Process Image A-20, A-21, A-22, A-23
 - Updating Block Calls 10-27
 - Updating Firmware 18-10
 - Updating Firmware in Modules and Submodules Online 18-10
 - Updating the Operating System (see Updating Firmware in Modules and Submodules Online) 18-10
 - Updating the Operating System of Modules and Submodules Offline A-124
 - Updating the Window Contents 18-7
 - Uploaded Blocks
 - Editing in the PG/PC 19-16
 - Uploading
 - Blocks from an S7 CPU 19-15
 - Station 19-14
 - Uploading from the Programmable Controller to the PG/PC 19-13
 - Upper and Lower Case 8-16, 8-17
 - Symbols 8-16, 8-17
 - Upper Limits for Entering Counters 20-8
 - Upper Limits for Entering Timers 20-7
 - User Data A-118
 - User Interface 5-22
 - User Memory 19-20
 - Compressing 19-20
 - User Program A-16
 - Downloading A-16
 - in the CPU Memory A-16
 - Tasks 4-1
 - User Programs
 - Downloading 19-3
 - User Rights Through The Automation License Manager 2-1
 - User Text Libraries 16-34
 - User-Defined Data Type
 - Correcting the Interface 15-6
 - User-Defined Data Types A-51
 - User-Defined Data Types (UDT) 9-12
 - Entering the Structure 11-7
 - User-Defined Data Types in STL Source Files 13-28
 - Example 13-28
 - User-Defined Diagnostic Messages
 - Creating and Editing 16-19
 - User-Defined Diagnostic Messages Displaying 16-39
 - Uses for Saving/Archiving 24-5
 - Using
 - SFC A-20
 - Using a Micro Memory Card as a Data Carrier 6-24
 - Using Arrays to Access Data A-45
 - Using Clock Memory and Timers A-128
 - Using Complex Data Types A-44
 - Using Foreign-Language Character Sets 6-5
 - Using Multiple Instances 10-10
 - Using Older Projects A-72, A-73
 - Using Structures to Access Data A-48
 - Using the Clock Functions A-126
 - Using the Parameter Type ANY A-61
 - Using the Parameter Type POINTER A-54
 - Using the System Memory Areas A-18
 - Using the Variable Declaration in Logic Blocks 10-6
 - Using User-Defined Data Types to Access Data A-50
-
- V**
- Valves 3-7
 - Creating an I/O Diagram 3-7
- Variable Declaration Table 10-3, 10-6, 23-29
 - FC for the Sample Industrial Blending Process A-88
 - for OB81 23-26
 - OB for the Sample Industrial Blending Process A-90
 - Purpose 10-6
 - System Attributes for Parameters 10-7
- Variable Declaration Window

- Entering a Multiple Instance entering 10-11
 - Variable Detail View 10-8
 - Structure 10-9
 - Variable Table 20-3
 - Copying/Moving 20-3
 - Creating and Opening 20-3
 - Editing 20-4
 - Example 20-4, 20-5
 - Example of Entering Addresses 20-9
 - Inserting a Contiguous Address Range 20-6
 - Inserting Addresses or Symbols 20-4
 - Maximum Size 20-6
 - Saving 20-1, 20-4
 - Syntax Check 20-6
 - Using 20-1
 - Variables 17-1, 17-2
 - Modifying 20-16
 - Monitoring 20-14
 - Operator Control and Monitoring 17-1, 17-2
 - Version 1 Projects A-72
 - Converting A-72
 - Version 2 Projects A-73
 - Converting A-73
 - Virtual Work Memory
 - Setting 26-5
- W**
- Warm Restart A-5, A-6, A-7, A-8, A-9, A-10
 - Abort A-5
 - Automatic A-5
 - Automatic without a Backup Battery A-5
 - Manual A-5
 - Warning A-24
 - Exceeding the L Stack A-24
 - Overwriting the L Stack A-24
 - What Are the Different Messaging Methods? 16-1
 - What You Should Know About HOLD Mode 21-5
 - What You Should Know About Micro Memory Cards (MMC) 6-22
 - What You Should Know About Testing in Single-Step Mode/Breakpoints 21-3
 - What You Should Know About the HOLD Mode 21-5
 - Which Message Blocks Are Available? 16-6
 - Which Message Blocks Exist? 16-6
 - WinAC 6-24
 - Window Arrangement 5-22
 - Changing 5-31
 - Restoring 5-31
 - Saving 5-31
 - Window Contents 18-7
 - Updating 18-7
 - Windows 5-37
 - Toggling 5-37
 - Windows Language Settings 6-6
 - WinLC 6-24
 - Winter time 18-9, 18-10
 - WORD A-33, A-39
 - Word (WORD) A-33
 - Area A-33
 - Work Memory 19-3, 19-4, A-15, A-16, A-17
 - Working Area of a Window 5-22
 - Working with Libraries 9-20
 - Working with Network Templates 10-17
 - Working with Version 2 Projects and Libraries 7-1
 - WR_DPARM A-119, A-123
 - WR_PARM A-119, A-123
 - WR_USMSG 23-22
 - Writing to a Data Block in Load Memory 6-22
- Y**
- Y link 23-13

