

SIMATIC

System Software for M7-300 and M7-400 Installation and Operation

User Manual

This manual is part of the documentation package with the order number:

6ES7802-0FA14-8BA0

Preface, Table of Contents

Product Overview

1

Installing on PC or Programming Device

2

Installing the M7-300/400 Systems

3

Operator and Monitor Interface

4

Using Mass Storage

5

Low-Level Debugger

6

Loadable Drivers

7

Appendix

Operating Systems and Performance Characteristics

A

CLI Commands

B

Debugger Commands

C

System Status List SZL

D

Diagnostic Data

E

Glossary, Index

Safety Guidelines

This manual contains notices which you should observe to ensure your own personal safety, as well as to protect the product and connected equipment. These notices are highlighted in the manual by a warning triangle and are marked as follows according to the level of danger:



Danger

indicates that death, severe personal injury or substantial property damage **will** result if proper precautions are not taken.



Warning

indicates that death, severe personal injury or substantial property damage **can** result if proper precautions are not taken.



Caution

indicates that minor personal injury or property damage can result if proper precautions are not taken.

Note

draws your attention to particularly important information on the product, handling the product, or to a particular part of the documentation.

Qualified Personnel

Only **qualified personnel** should be allowed to install and work on this equipment. Qualified persons are defined as persons who are authorized to commission, to ground, and to tag circuits, equipment, and systems in accordance with established safety practices and standards.

Correct Usage

Note the following:



Warning

This device and its components may only be used for the applications described in the catalog or the technical description, and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens.

This product can only function correctly and safely if it is transported, stored, set up and installed correctly, and operated and maintained as recommended.

Trademarks

SIMATIC®, SIMATIC HMI® and SIMATIC NET® are registered trademarks of SIEMENS AG.

Some of the other designations used in these documents are also registered trademarks; the owner's rights may be violated if they are used by third parties for their own purposes.

Copyright Siemens AG 1998 All rights reserved

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Siemens AG
Automation and Drives Group
Industrial Automation Systems
P.O.Box 4848, D- 90327 Nuremberg

Disclaimer of Liability

We have checked the contents of this manual for agreement with the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are welcomed.

© Siemens AG 1998
Technical data subject to change.

Preface

Purpose

This manual is intended as support documentation for the installation and operation of M7 300 and M7 400 automation systems under M7 RMOS32 operating system control. It provides information on the following topics:

- The M7 RMOS32 hardware and software environment
- Installation of the system software on PC or PG
- Installation of the system software on the M7-300 or M7-400 PLC system
- Settings and configuration options
- Operating the M7-300 or M7-400 via remote terminal
- The M7 RMOS32 command line interpreter (CLI)
- The M7 RMOS32 low-level debugger

Audience

This manual is intended primarily for M7-300 and M7-400 automation system set-up and start-up personnel.

Scope of This Manual

The manual applies for M7-300 and M7-400 automation systems under M7-SYS RT V 4.0 operating system control.

What is New?

This manual provides the following new topics and reference information on changes and extensions of functions supported by version V4.0 of the system software.

Topic	Chapter
Released operating system configurations: M7 RMOS32 on hard disk and M7 RMOS 32 with MS DOS on memory card	3.4, 3.5
Modifying system configuration files using the SIMATIC Manager	3.9
Communication via Industrial Ethernet (TCP/IP)	A.1
PING command for TCP/IP	B.22

Scope of the Documentation Package

The system software for M7-300 and M7-400 programmable controllers that use the M7-SYS RT software package is documented in a three-manual documentation package which can be ordered separately from the M7-SYS RT software package. The manuals are listed in the table below.


Manual	Contents
System Software for M7-300 and M7-400 Installation and Operation User Manual	Installing and operating M7-300 and M7-400 programmable controllers
System Software for M7-300 and M7-400 Program Design Programming Manual	Designing and writing C/C++ programs
System Software for M7-300 and M7-400 System and Standard Functions Reference Manual	Detailed information on programming with M7-SYS

Feedback

We need your help to enable us to provide you and future M7-SYS RT users with optimum documentation. If you have any questions or comments on this *manual*, please fill in the remarks form at the end of the manual and return it to the address shown on the form. We would be grateful if you could also take the time to answer the questions giving your personal opinion of the manual.

SIMATIC Customer Support Hotline

Contactable worldwide round the clock:



Nuremberg

SIMATIC BASIC Hotline

Local time: Mo.-Fr. 8:00 to 18:00

Phone: +49 (911) 895-7000

Fax: +49 (911) 895-7002

E-Mail: simatic.support@nbgm.siemens.de

SIMATIC Premium Hotline

(Calls billed, only with SIMATIC Card)

Time: Mo.-Fr. 0:00 to 24:00

Phone: +49 (911) 895-7777

Fax: +49 (911) 895-7001

Johnson City

SIMATIC BASIC Hotline

Local time: Mo.-Fr. 8:00 to 17:00

Phone: +1 423 461-2522

Fax: +1 423 461-2231

E-Mail: simatic.hotline@sea.siemens.com

Singapore

SIMATIC BASIC Hotline

Local time: Mo.-Fr. 8:30 to 17:30

Phone: +65 740-7000

Fax: +65 740-7001

E-Mail: simatic@singnet.com.sg

SIMATIC Customer Support Online Services

The SIMATIC Customer Support team provides you with comprehensive additional information on SIMATIC products via its online services:

- You can obtain general current information:
 - On the **Internet** at <http://www.ad.siemens.de/simatic>
 - Using **fax polling** no. 08765-93 02 77 95 00
- Current Product Information leaflets and downloads which you may find useful for your product are available:
 - On the **Internet** at <http://www.ad.siemens.de/support/html-00/>
 - Via the **Bulletin Board System** (BBS) in Nuremberg (*SIMATIC Customer Support Mailbox*) at the number +49 (911) 895-7100.

To access the mailbox, use a modem with up to V.34 (28.8 kbps), whose parameters you should set as follows: 8, N, 1, ANSI, or dial in using ISDN (x.75, 64 kbps).

SIMATIC Training Center

Siemens also offers a number of training courses to introduce you to the SIMATIC S7 and M7 automation systems. Please contact your regional training center or the central training center in Nuremberg, Germany for details:

D-90327 Nuremberg, Tel. (+49) (911) 895 3154.

Further Support

If you have any further questions about SIMATIC products, please contact your Siemens partner at your local Siemens representative's or regional office. You will find the addresses in our catalogs and in Compuserve (`go autforum`).

Table of Contents

1	Product Overview	1-1
1.1	M7 Optional Packages	1-2
1.2	Operating Systems for M7-300 and M7-400	1-4
1.3	Brief Description of M7 RMOS32	1-7
1.4	Brief Description of M7 RMOS32 for MS DOS	1-8
2	Installing on PC or Programming Device	2-1
2.1	Installing M7-SYS RT V4.0	2-1
2.2	Installation of Several M7-SYS Versions	2-3
3	Installing the M7 Programmable Control Systems	3-1
3.1	General Remarks on Installation	3-2
3.2	Data Security in the Event of a Power Failure	3-7
3.3	Installing M7 RMOS32 on Memory Card	3-8
3.4	Installing M7 RMOS32 with MS DOS on Memory Card	3-10
3.5	Installing M7 RMOS32 on Hard Disk	3-12
3.6	Installing M7 RMOS32 with MS DOS on Hard Disk	3-14
3.7	Reinstallation of the M7 Operating System	3-15
3.8	Updating the Firmware	3-16
3.9	Modifying Configuration Files	3-19
3.10	The RMOS.INI File	3-23
3.11	The INITTAB File	3-26
4	Operator and Monitor Interface	4-1
4.1	Operation via Remote Terminal	4-1
4.2	Using the Command Line Interpreter (CLI)	4-3
4.3	Transferring Programs To and Deleting Programs From the M7 Programmable Control System	4-10
4.4	Starting Application Programs on the M7 Programmable Control System	4-15
4.5	Information and Control Functions for M7-300 and M7-400	4-16
5	Using Mass Storage	5-1
5.1	Formatting Memory Cards and OSDs	5-2
5.2	Formatting Hard Disks and Diskettes	5-3

5.3	Hard Disk Partitioning Program HDPART	5-4
5.4	Formatting Memory Cards and OSDs under MS-DOS	5-8
5.5	Using Memory Cards	5-10
5.6	The REMAP_A Program	5-11
6	Low-Level Debugger	6-1
6.1	Task Mode and Monitor Mode	6-2
6.2	Operator Control of the Debuggers	6-5
6.3	Syntax	6-7
6.4	Debugger Commands	6-9
7	Loadable Drivers	7-1
7.1	What You Need to Know About Loadable Drivers	7-1
7.2	Loading a Driver	7-2
A	Operating Systems and Performance Features	A-1
A.1	Performance Features of the CPUs and Function Modules	A-2
A.2	Configuration of M7 RMOS32	A-5
A.3	Main Memory Allocation	A-9
A.4	Configuration of M7 RMOS32 for DOS	A-10
A.5	Components of M7 RMOS32-DOS	A-15
A.5.1	RM3PMEM.SYS	A-16
A.5.2	RM3RESET.SYS	A-17
A.6	Special Features under M7 RMOS32-DOS	A-18
B	CLI Commands	B-1
B.1	BYT8250	B-3
B.2	CANCEL	B-5
B.3	CD	B-6
B.4	CHGKBD	B-7
B.5	COPY	B-8
B.6	CPRI	B-10
B.7	DATE	B-11
B.8	DEL	B-12
B.9	DEVICE	B-13
B.10	DIR	B-16
B.11	DISMOUNT	B-17
B.12	ECHO	B-18
B.13	ERROR	B-19
B.14	EXIT	B-20

B.15	FORMAT	B-21
B.16	FTLFORM	B-22
B.17	HELP	B-24
B.18	MD	B-25
B.19	MOUNT	B-26
B.20	NPX – Not for Later Versions	B-27
B.21	PATH	B-28
B.22	PING	B-30
B.23	PROMPT	B-31
B.24	RD	B-32
B.25	RDISK	B-33
B.26	RENAME	B-34
B.27	SCANDISK	B-35
B.28	SESSION	B-37
B.29	SET	B-38
B.30	START	B-39
B.31	SYSTAT	B-40
B.32	TIME	B-41
B.33	VER	B-42
B.34	CLI Error Messages	B-43
C	Debugger Commands	C-1
C.1	Debugger Syntax Rules	C-3
C.2	ASM	C-7
C.3	BASE	C-9
C.4	BREAKS	C-10
C.5	CALCULATE	C-11
C.6	CALL	C-12
C.7	CHANGE	C-13
C.8	CONT	C-14
C.9	CPUREG	C-15
C.10	DIR	C-16
C.11	DISPLAY	C-19
C.12	EVALUATE	C-20
C.13	EXIT	C-21
C.14	EXITK	C-22

C.15	FILL	C-23
C.16	FREETASK	C-24
C.17	GO	C-25
C.18	HALT	C-26
C.19	HELP	C-27
C.20	IN	C-28
C.21	INHIB	C-29
C.22	KILL	C-30
C.23	LINES	C-31
C.24	LOADTASK	C-32
C.25	MONITOR	C-34
C.26	OUT	C-35
C.27	QUALIFY	C-36
C.28	QUERY	C-37
C.29	REGS	C-39
C.30	REPORT	C-41
C.31	SET	C-47
C.32	STACK	C-49
C.33	START	C-50
C.34	STEP	C-51
C.35	SVC	C-52
C.36	SWITCH	C-54
C.37	TASK	C-55
C.38	TCB	C-56
C.39	TCD	C-57
C.40	Debugger Error Messages	C-58
D	System Status List SZL	D-1
D.1	Overview of the System Status List (SZL)	D-2
D.2	Structure of an SZL Partial List	D-3
D.3	SZL-ID	D-4
D.4	Possible SZL Partial Lists	D-5
D.5	SZL-ID W#16#xy11 - Module Identification	D-6
D.6	SZL-ID W#16#xy12 - CPU Characteristics	D-7
D.7	SZL-ID W#16#xy13 - User Memory Areas	D-8
D.8	SZL-ID W#16#xy14 - System Areas	D-10

D.9	SZL-ID W#16#xy15 - Block Types	D-11
D.10	SZL-ID W#16#xy22 - Interrupt Status	D-12
D.11	SZL-ID W#16#xy24 - Operating Mode and Operating Mode Transition ..	D-13
D.12	SZL-ID W#16#xy32 - Communication Status Data	D-16
D.13	Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0001	D-17
D.14	Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0005	D-18
D.15	Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0008	D-19
D.16	SZL-ID W#16#xy91 - Module Status Information	D-20
D.17	SZL-ID W#16#xy92 - Rack/Station Status Information	D-23
D.18	SZL-ID W#16#xyA0 - Diagnostic Buffer	D-25
D.19	SZL-ID W#16#00B1 - Module Diagnostic Information	D-26
D.20	SZL-ID W#16#00B2 - Diagnostic Data Record 1 with Geographical Address	D-27
D.21	SZL-ID W#16#00B3 - Module Diagnostic Data via Logical Base Address	D-28
D.22	SZL-ID W#16#00B4 – Diagnostic Data of a DP Slave	D-29
E	Diagnostic Data	E-1
	Glossary	
	Index	

Product Overview

STEP 7 and the M7 optional packages make it possible for you to use high-level programming languages such as C or C++ as well as graphic programming software such as CFC (Continuous Function Chart) to write user programs for the M7-300 and M7-400 programmable controllers.

This chapter discusses the various options available for writing user programs for M7-300 and M7-400 programmable controllers. It also provides an overview of the system software for M7-300 and M7-400.

M7 Optional Packages

In addition to STEP 7, you need the system software for M7-300 and M7-400 as well as a development environment for M7 programs (ProC/C++ or CFC) in order to write the programs. These software components are described in the chapters below.

Chapter Overview

Section	Title	Page
1.1	M7 Optional Packages	1-2
1.2	Operating systems for M7-300 and M7-400	1-4
1.3	Brief description of M7 RMOS32	1-7
1.4	Brief description of M7 RMOS32 for MS DOS	1-8

1.1 M7 Optional Packages

STEP 7 provides you with the basic functionality you need in order to

- generate and manage projects,
- configure and initialize M7 system hardware,
- configure network segments and connections,
- manage symbolic data.

This functionality is provided regardless of whether your PLC system is a SIMATIC S7 or a SIMATIC M7.

Because SIMATIC S7 and SIMATIC M7 systems use different operating systems and runtime software, the PLC system affects primarily application programming.

In addition to STEP 7, you need the M7 optional packages in order to write M7 user programs.

Table 1-1 Optional Packages for M7 Programming

Software	Contents
M7-SYS RT	<ul style="list-style-type: none">• M7 RMOS32 operating system• M7 API system library• MPI support
CFC	Programming software for CFC applications (CFC = Continuous Function Chart)
M7-ProC/C++	<ul style="list-style-type: none">• Linking of Borland development environment in STEP 7• Symbol import editor and generator• Organon debugger xdb386
Borland C++	Borland C++-development environment

Together with the M7 optional packages, STEP 7 also supports the following activities:

- Transfer of data to the M7 system via MPI
- Scanning information about the M7 system
- Making specific settings and executing a memory reset on the M7 system

Dependencies

The diagram below shows the dependencies of the M7 optional packages:




Figure 1-1 Dependencies of the M7 Optional Packages for M7 Programming

Table 1-2 Summary

Programs to be written	Required M7 optional packages
C/C++-programs	<ol style="list-style-type: none"> 1. M7-SYS RT 2. M7-ProC/C++ 3. Borland C++
CFC-programs	<ol style="list-style-type: none"> 1. M7-SYS RT 2. CFC 3. Borland C++

Tools

Some of the specific tools needed to write M7 applications are integrated in STEP 7, others in the M7 optional packages.

The table below tells you which tools are integrated in each package.

Table 1-3 Tools for Writing M7 User Programs

Package	Support
STEP 7	<ul style="list-style-type: none"> • Installation of the M7 operating system • Management of the M7 PLC system • Transfer, starting and deleting of M7 user programs • Calling of status and diagnostic data • CPU memory reset
M7-SYS RT	Support through M7 operating system and system software services for: <ul style="list-style-type: none"> • Program run control • Memory and resources management • Access to CPU and SIMATIC hardware • Interrupt handling • Diagnostics • Status monitoring and • Communication
M7-ProC/C++	<ul style="list-style-type: none"> • Support through integrated code generation (integration of the Borland development environment in STEP 7) • Support through linking of project symbols into the source code and • Support through integrated debugger functionality
Borland C++	<ul style="list-style-type: none"> • Support for the writing of C and C++ programs
CFC	<ul style="list-style-type: none"> • Support for writing, testing, and debugging of CFC programs and • Support for starting and executing CFC programs

1.2 Operating Systems for M7-300 and M7-400

Because of its standardized PC architecture, the M7-300 and M7-400 programmable controllers constitute a programmable expansion of the SIMATIC automation platform. The user programs for SIMATIC M7 can be written in a high-level language such as C or in the CFC graphic language.

For applications written in the high-level programming languages C and C++, the services provided by the operating system are extremely important. The operating system performs the following tasks for these applications:

- Accessing the hardware
- Managing resources
- System linking
- Communicating with other system components

Real-Time Operating System

The SIMATIC M7 programmable controller is equipped with the M7 RMOS32 operating system (RMOS stands for **R**eal-time **M**ultitasking **O**perating **S**ystem) in order to accomplish automation tasks. For use in the SIMATIC system, M7 RMOS32 has been expanded by a call interface referred to as M7-API (API stands for **A**pplication **P**rogramming **I**nterface).

Operating System-Configurations for M7

The M7 RMOS32 real-time operating system is designed for 32-bit applications used to solve real-time and multitasking jobs. It is available in the following configurations for M7 modules:

- M7 RMOS32
- M7 RMOS32 with MS-DOS

Which operating system configuration is right for your M7 automation system depends on which M7 modules are used (see Table 1-4).

Table 1-4 Software/Hardware Configurations

Operating System	Module/ Main Memory	PROFIBUS DP Yes/No	Installation on Mass Storage Unit
M7 RMOS32	FM 356-4 / 4MB	No	Memory card ≥ 4 MB or hard disk
	FM 356-4 / 8MB	Yes	
	CPU 388-4 / 8MB	Yes	
	FM 456-4 / 16MB	Yes	
	CPU 488-3 / 16MB	Yes	
	CPU 486-3 / 16MB	Yes	
M7 RMOS32 with MS-DOS	CPU 388-4 / 8MB	No	Memory card ≥ 4 MB or hard disk
	FM356-4 / 8MB	No	
	FM 456-4 / 16MB	Yes	
	CPU 488-3 / 16MB	Yes	
	CPU 486-3 / 16MB	Yes	

Hardware configurations with PROFIBUS-DP and TCP/IP are supported only with the following operating systems:

- M7 RMOS32 with at least 8 MB main memory
- M7 RMOS32 with MS-DOS with 16 MB main memory

Additional Hardware

M7 RMOS32 with MS-DOS can be used only on M7 modules equipped with a VGA monitor and keyboard via the IF962-VGA interface submodule.

Mass Storage

M7 CPU modules and M7 application modules are equipped with the following types of mass storage (see Table 1-5):

- Memory cards (such as those in S7-CPU)
- Hard disk and diskette

All programmable M7 modules can be optionally equipped with a hard disk and a 3.5 inch diskette drive via the MSM expansion board. As is the case with the memory card, you can address the diskette on both the PC or programming device and the M7-300/400 system.

- On-board silicon disk (OSD)
This mass storage medium has the same performance characteristics as a hard disk drive on which application programs can be stored. The FM 456-4 application module can be optionally equipped with an OSD.

Table 1-5 Mass Storage for M7 Systems

Mass Storage	Capacity	M7-300 Module	M7-400 Module
Hard disk	from 512MB	MSM 378	MSM 478
3.5 inch diskette	1.44MB	MSM 378	MSM 478
Memory Card	2 ^{*)} , 4, 8, 16 MB	CPU 388-4 FM 356-4	CPU 488/486-3 FM 456-4
OSD	4MB	-	Optional in FM 456-4

*) Not for a complete operating system

Note

For details on which system variants are supported by the current product version as regards their main memory configurations and mass storage media, please refer to Table 1-4 on page 1-5.

1.3 Brief Description of M7 RMOS32

Characteristic Features

M7 RMOS32 has the following characteristic features:

- Preconfigured operating system variant for M7-300 and M7-400 CPUs and FMs
- Sole control of the hardware by M7 RMOS32
- Defined response times in the microsecond or millisecond range, real-time capability for measuring, open-loop control and closed-loop control

Device Control

The following devices can be controlled by M7 RMOS32:

- Four M7 RMOS32 consoles via EGA/VGA
- One M7 RMOS32 console on COM1 and one on COM2
- One printer on LPT1 (Centronics interface)
- One memory card
- One on-board silicon disk (OSD)
- MSM 378 or MSM 478 mass storage module with one hard disk and one 1.44 MB diskette drive

Interrupts

M7 RMOS32 handles all interrupts.

File Management System

All drives (diskette, hard disk, memory card and OSD) are managed by the RMOS's HSFS file management system (HSFS stands for High Speed File System). An automatic hard disk recognition facility integrates the hard disk in the HSFS.

Command Line Interpreter (CLI)

Similar to the DOS command line interpreter but with commands for M7 RMOS32. The M7 RMOS32 console is used for CLI entries.

Low-Level Debugger

Integrated low-level debugger. The debugger is serviced via the M7 RMOS32 console.

1.4 Brief Description of M7 RMOS32 for MS DOS

Characteristic Features

M7 RMOS32 for MS DOS has the following characteristic features:

- Preconfigured real-time multitasking operating system for PC-compatible systems
- MS-DOS V6.22 executes as M7 RMOS32 task
- Defined response times in the microsecond or millisecond range, real-time capability for measuring, open-loop control and closed-loop control

Booting

MS-DOS is always booted first. M7 RMOS32 is started by MS-DOS via a special load program.

Device Control

The graphic card and the keyboard are controlled by MS-DOS.

All drives (diskette, hard disk, etc.) known to BIOS are controlled by MS-DOS.

The interrupt controller and the timer chip are controlled by M7 RMOS32. The functions necessary for MS-DOS are simulated.

Other devices and interfaces can be handled by either MS-DOS or M7 RMOS32. This is specified in the configuring phase.

Interrupt Handling

Timer interrupts are serviced by M7 RMOS32. The timer interrupt for MS-DOS is simulated by M7 RMOS32.

Keyboard, hard disk and diskette interrupts are handled by MS-DOS.

All other interrupts can be handled by either MS-DOS or M7 RMOS32. This is specified in the configuring phase.

File Management System

MS-DOS's own file management system is used.

The data media are made accessible to M7 RMOS32.

Memory Allocation

The memory area from address 0 to address 10FFFFH is always reserved for MS-DOS.

The memory area starting with address 110000H is allocated to M7 RMOS32 during booting.

Monitor and Keyboard

Under MS DOS, the monitor and the keyboard can be alternately allocated to MS DOS or M7 RMOS32 via hot key <Ctrl>+<Esc>. Under M7 RMOS32, keyboard and monitor can be allocated to four different consoles with <F1>...<F4>.

Interaction Between M7 RMOS32 Multitasking and MS DOS

In contrast to the MS DOS file management system, M7 RMOS32 also permits quasi-parallel file operations, for example simultaneous reading and writing of files on the diskette or hard disk. One advantage of this functionality is that, while a diskette is being formatted, parallel file operations for real-time tasks on other mass media (hard disk, memory card) are possible.

Note

Under M7 RMOS32, DOS calls without multitasking capability are interlocked and the requests thus serviced in succession.

For mass storage operations, this means, for instance, that file operations for real-time tasks are halted while a diskette is being formatted (under DOS).

Please note that no file access operations may take place under MS-DOS during the execution of real-time tasks.

Restart

The MS-DOS task can be restarted with the key combination <Ctrl>+<Alt>+. A restart boots only MS-DOS, not M7 RMOS32.

During the restart, specific M7 RMOS32 tasks may be started. However, these tasks must first be logged on or off via special functions.

Error Handling

Privilege violations in the MS-DOS task are intercepted by M7 RMOS32. The MS-DOS program is then automatically aborted.

Illegal I/O commands, that is access operations to a device under M7 RMOS32 control, are intercepted by M7 RMOS32.

Installing on PC or Programming Device

2

This chapter provides information needed for successful installation of the M7-SYS RT software package.

Chapter Overview

Section	Title	Page
2.1	Installation of M7-SYS RT V4.0	2-1
2.2	Installation of several M7-SYS versions	2-3

2.1 Installing M7-SYS RT V4.0

The M7-SYS RT software package must be installed on PC or on the programming device. It contains a setup program which automatically performs all installation tasks. During installation, you are guided step for step by input prompts displayed on the monitor screen.

Hardware Prerequisites

In order to install the M7-SYS RT software package on a PC or programming device, the following hardware prerequisites must be fulfilled:

- There must be at least 10 Mbytes of free space available on the PC's or programming device's hard disk
- There must be at least 1 Mbyte of free space available on drive C: for the setup program. The temporary setup files are erased following successful installation.

Software Prerequisites

In order to install the M7-SYS software package on a PC or programming device, the following software prerequisites must be fulfilled:

- The **Windows 95** or **Windows NT** operating system must be installed on the PC or programming device
- The **STEP 7** basic software version 4.02 must be installed on the PC or programming device. M7-SYS can be installed on STEP 7 version 3.2 as well, but in this case the new functionality is not available. For instructions on how to install STEP 7, please refer to the STEP 7 User Manual.

You need administrator's privileges in order to install M7-SYS RT under Windows NT.

Procedure

1. Exit all STEP 7 applications.
2. Insert the first diskette in the drive and start the Setup program for M7-SYS. The M7-SYS files are then copied to the PC/programming device and entries are made in the MS Windows files. Important information on handling will be displayed during the Setup process.
3. Upon completion, an event box is displayed to show successful termination of the installation procedure.
4. Before you use M7-SYS, your PC/programming device must be restarted. Only then do all the settings become active.



Caution

M7-SYS registers itself in MS Windows 95/NT system files. With MS Windows utilities such as Explorer, you cannot move M7-SYS files or folders, nor can you modify M7-SYS data in the MS Windows register. Programs will not run properly after such changes.

Uninstall

Use the Control Panel to uninstall M7-SYS RT as usual in Windows 95/NT.

Note

If more than one M7-SYS version are installed on the PC/programming device, you must uninstall them together. If you uninstall only one version, the common files are deleted.

When removing M7-SYS from the PC/programming device (Windows 95 only), entries which were made in the WINSTART.BAT file by the system are not deleted.

2.2 Installation of Several M7-SYS Versions

STEP 7 V3.1 allows working with two or more M7-SYS versions simultaneously on the PC/programming device. Please consider the following, when using several M7-SYS versions:

- Installation sequence:
Newer versions must be installed **after** the older ones in order to prevent overwriting the newer common files by the old ones.
- Uninstall:
Uninstall of only one of the M7-SYS versions is not possible because of the common data. If more than one versions are installed, you must deinstall them together.
- Downward compatibility of user programs is not supported.
I.e. programs that were compiled and linked with M7-SYS RT V4.0 cannot be executed on an M7-300/400 with an M7-SYS V2.0 or V1.2 operating system.
- Upward compatibility of user programs is supported except for Windows 3.11 programs. I.e. programs that were compiled and linked with M7-SYS V1.2 or V2.0 can be executed on an M7-300/400 with an M7-SYS RT V4.0 operating system (M7 RMOS32 possibly with MS DOS).

Selecting the operating system version for an M7-300/400

You can select the operating system version during the installation of the operating system on an M7 CPU or M7 FM (using the command **PLC > Manage M7 System**).

Updating from V1.2 to V2.0 or V4.0

When replacing a CPU 488-4/5 by a CPU 486-3 or a CPU 488-3, you have to update from V1.2 to V2.0 or V4.0.

Installing the M7 Programmable Control Systems

3

This chapter deals with the following topics:

- How to prepare for installation
- How to install and reinstall an operating systems on the M7 programmable control systems
- How to update the firmware
- Configuration options for M7 RMOS32

Menu Command

The SIMATIC manager is used for installation on the M7 programmable control system. To invoke the M7 programmable control system manager, select "M7 Program" and call the following menu command from within the context of a project containing stations with M7 CPUs or FMs:

PLC ► Manage M7 System

Chapter Overview

Section	Description	Page
3.1	General Remarks on Installation	3-2
3.2	Data Security in the Event of a Power Failure	3-7
3.3	Installing M7 RMOS32 on Memory Card	3-8
3.4	Installing M7 RMOS32 with MS DOS on Memory Card	3-10
3.5	Installing M7 RMOS32 on Hard Disk	3-12
3.6	Installing M7 RMOS32 with MS DOS on Hard Disk	3-14
3.7	Reinstallation of the M7 Operating System	3-15
3.8	Updating the Firmware	3-16
3.9	Modifying Configuration Files	3.9
3.10	The RMOS.INI File	3-23
3.11	The INITTAB File	3-26

3.1 General Remarks on Installation

Reason for Installation

The reason for installation is the transfer of a complete operating system configuration, including M7 system software, to the **target medium**, the mass storage unit of an M7 system.

This section provides an overview of installation options and basic procedures. You will find step-by-step installation instructions in the sections below as well as in the On-Line Help for M7 Programmable Control System Manager.

Installation Options

Depending on the mass storage unit of the M7 programmable control system, a distinction is made between:

1. Installation on hard disk. If this is the first installation, the M7 programmable control system does not yet have an executable operating system, and an MPI link is not yet possible.
2. Installation on memory card. A memory card can accommodate a complete M7 RMOS32 operating system with application programs.

Basic Procedures

Proceed as follows to install an operating system:

1. Select object "M7 program" in your project.
2. Call the menu command
PLC ► Manage M7 System.
3. Open the "Install Operating System" tab.
4. Make the following selections (see Figure 3-1):
 - Operating system configuration
 - Operating system version in the programming device (only if you have installed several versions of M7-SYS on the programming device/PC)
 - Medium
 - Local drive (only on programming device/PC with Windows 95) and remote drive when using medium "MPI/RFS"
5. Activate "Install"




Figure 3-1 "Install Operating System" Tab (on programming device/PC with Windows NT)

Operating System Versions

In the programming device:

Select here the version of the operating system you have installed on your M7 programmable control system. This step is only required if you have installed several versions of the M7-SYS option software on the programming device. You can only select those versions that are released for the module (see also M7-SYS Product Information).

In the PLC system:

If an on-line connection to the M7 programmable control system is possible, the current operating system version is displayed in this tab provided it can be determined.

Selecting an Operating System

Select an operating system configuration from the "Possible Configurations" field. Selection of an operating system configuration depends on the type of application programs to run on the M7 programmable control system. Table 3-1 shows when to select which operating system. Also note the hardware dependencies in Table 1-4 on page 1-5.

Table 3-1 Operating System Configurations

Application Programs	Operating System Configuration
M7 RMOS32 applications only	M7 RMOS32
M7 RMOS32- and MS DOS applications	M7 RMOS32 & MS DOS

The memory requirement for M7 RMOS32 without MS DOS is no more than 3 Mbytes on the target medium. To this you must add the memory requirements of your application programs.

See the M7-SYS Product Information for details of which operating system configurations are released for which mass storage media. Non-released configurations cannot be installed.

Selecting a Medium

The following **installation media** are presented as options in the "Medium" field:

- MPI/RFS:

Select "MPI/RFS" (RFS stands for **R**emote **F**ile **S**ystem) if the operating system is to be installed on the M7 programmable control system's hard disk. In order to use this installation medium, an MPI link must be established between PC/programming device and M7 programmable control system.

When using MPI/RFS, the operating system is always installed on the M7 programmable control system's hard disk. For all installations via MPI/RFS, you also need a **boot medium** (see page 3-5).

- Memory Card

Select "Memory card" when the operating system is to be installed on the memory card. The operating system and the application programs are transferred from the programming device to the memory card.

The memory card is then inserted in the M7 programmable control system and the M7 programmable control system is booted.

In order to use a memory card, you require a programming device 720/740/760 or a PC with external EPROM programming facility.

Note

A 1.44 MB diskette can hold a minimal M7 RMOS32 system, but it cannot be used as target medium for installation of the operating system on the M7-300 or M7-400. You can use a floppy disk as boot medium or as data medium for application programs.

A suitable selection list supports choosing of a medium. "Memory card", for example, is included in the selection list only when your PC or programming device is equipped with a memory card drive.

Selecting a Local Drive and a Remote Drive

When using "MPI/RFS" as installation medium, an MPI communication link is established between the local drive of the PC/ programming device and a drive on the M7 programmable control system.

Local drive:

The selection list shows you the available drive identifiers on the PC or programming device from which you may choose. The local drive must be selected only on PCs or programming devices with Windows 95, under Windows NT the selection is deactivated.

Remote drive:

The selection list shows you the available drive identifiers on the M7 programmable control system from which you can select the required mass storage unit. Normally (unless specified otherwise), the drives are allocated as shown in the following table.

Table 3-2 Drive Allocation (Default) on the M7 Programmable Control System

Drive	Remote Drive Identification	
	MS DOS	M7 RMOS32
Memory card	A: or B:	M0:
Hard disk	C:, D:, ...	C:, D:, ...
On board silicon disk	D:, E:, ... With hard disk C: Without hard disk	M1:

Boot Medium

When you install the operating system on the M7 programmable control system's hard disk, you also need a boot medium. The term boot medium is used to identify a data carrier from which the programmable control system is booted on power-up. The boot medium contains a minimal version of the M7 RMOS32 operating system. During booting, the sections of the operating system needed for executing the application programs and for communication purposes are loaded into work memory.

Following boot medium start up, an MPI link can be established between the PC or programmable device and the M7 programmable control system.

Data media with booting capability for the M7 programmable control systems are:

- 3.5 inch/1.44 MB diskettes or
- Memory card with a capacity of 2 MB or more

Installing MS DOS

Before installing the operating system configuration with MS DOS, you must install MS DOS V6.22 on the M7 programmable control system.

Partitioning the Hard Disk

If you install the operating system on the hard disk, we recommend that you create two partitions for reasons of data security in the event of a power failure (see Section 3.2). You can partition the hard disk using the following calls:

- **hdpart** under M7 RMOS32 (see Chapter 5)
- **fdisk** under MS DOS

Formatting the Target Medium

As a rule, the target medium is formatted prior to initial installation of the operating system. In the case of M7 operating system configurations, you must format the target medium in the following cases:

Operating System	Formatting of Target Medium
M7 RMOS32	Prior to each complete installation or reinstallation, since M7 RMOS32 must always be written to the start of the memory when running without MS DOS.
M7 RMOS32 with MS DOS	Prior to the initial installation of MS DOS.

During installation of M7 RMOS32 without MS DOS, you will be prompted to format the hard disk as target medium. You will find details on how to proceed in Chapter 5.

Installing into an MPI Subnet

If you use a boot medium when installing M7 RMOS32 on an M7 CPU or FM that has been assigned MPI parameters differing from the standard setting, then sporadically a serious fault can occur during power up and the installation is aborted.

Remedy: In order to install the operating system choose one of the following:

- disconnect the module from the MPI subnet and connect the programming device locally during installation or
- configure the MPI subnet twice. Proceed as follows:
 - Configure the MPI subnet by assigning the standard MPI parameters.
 - Install the operating system.
 - Configure the MPI subnet again and reassign the parameters as required.

3.2 Data Security in the Event of a Power Failure

Concept

The M7-300/400 automation computer has several different mass storage media: Hard disk, memory card and OSD, whose file systems are managed by the operating system.



Caution

If a power failure occurs during a write operation to a mass data storage unit, data may be corrupted or lost.

As the system software (operating system, configuration files, etc.) is also located on the mass storage medium, a power failure during a write access can result in the system no longer being bootable.

To solve this problem, we recommend that you work with at least two mass storage media (or two partitions on the hard disk):

- One boot drive (boot partition) containing the operating system and the files relevant to the system and to which no write accesses are made during operation and
- One data drive (data partition) containing the user programs and the areas of read-only, back-up and load memory areas, and to which write accesses during operation are permitted.

On hard disk the boot partition is always C:.

Procedure

You can use the following procedure to ensure data consistency on the mass storage medium in the event of a power failure:

- Install the operating system on the boot partition on the hard disk or on its own mass storage medium. Ensure that no write accesses are made to the boot partition or mass storage medium of the operating system during operation. This ensures that the operating system and the system data remain intact following a power failure, meaning a complete restart can always be performed.
- Do not create the directories for the back-up memory, the permanent load memory and the read-only memory on the same drive as the operating system but on the data drive on which you write during operation. For this purpose, you must assign the relevant path names to the environment variables BACKDIR, RAMDIR and ROMDIR in the \ETC\INITTAB file on the boot drive.
- Install the user programs on the data drive.

3.3 Installing M7 RMOS32 on Memory Card

Initial State

Your M7 programmable control system has no hard disk or diskette drive.

Prerequisites

In this case, you can use the memory card as target medium. A memory card can accommodate a complete M7 RMOS32 operating system with application programs (see Table 3-2).

Requirements:

- A memory card drive on your programming device 720/740/760 or a PC with external EPROM programming facility
- A memory card with a capacity of 4 MB or more

Procedure

Proceed as follows to activate a memory card-resident M7 RMOS32 operating system:

1. Select from your project the M7 program assigned to M7-CPU/FM
2. Start the M7 Manager with the menu command
PLC ► Manage M7 System
3. Open the “Install Operating System” tab.
4. Install an M7 RMOS32 operating system locally on the memory card by making the following selections:
 - Medium: “Memory card”
 - Possible configuration: “M7 RMOS32”
5. Select “Install”. Information relating to current events is displayed in the dialog field.

Result: The operating system and the complete M7 system software are transferred to the memory card.

6. Transfer your application program, together with all associated project data, to the memory card locally. To do so, switch to the “Programs” tab and proceed as described under “Transferring M7 Programs via Data Carrier”, page 4-13. This step is optional.
7. Insert the memory card into the M7 programming control system and restart the system. Set up the BIOS if required (see the Hardware Manuals for more details).

Result: The M7 programming control system boots with the new operating system. Your application program is started.

3.4 Installing M7 RMOS32 with MS DOS on Memory Card

Initial State

Your M7 programming control system has no hard disk or diskette drive.

Prerequisites

In this case, the memory card is used as target medium. A memory card can accommodate a complete M7 RMOS32 operating system with application programs (see Table 3-2). Depending on the size of the memory card (capacity of 8 MB or more), you can also install MS DOS or a subset of MS DOS on the card.

Requirements:

- A memory card drive on your programming device 720/740/760 or a PC with external EPROM programming facility
- A memory card with a capacity of 8 MB or more
- MS DOS installation diskettes

Basic Procedure

Proceed as follows to install an M7 RMOS32 operating system with MS DOS on a memory card:

1. Format the memory card and install MS DOS or the parts of MS DOS you need on it. Carry out this installation in the DOS box of Windows 95/NT.
2. Install M7 RMOS32 for MS DOS on the memory card and use it to start your M7 programming control system. Carry out this installation under STEP 7 control.

Installing MS DOS on Memory Card

Proceed as follows to install MS DOS on a memory card:

1. Insert MS DOS V6.22 installation diskette 1 and the memory card in the appropriate drives on your PC or programming device.
2. Call the following command in the DOS box on your PC or programming device:
under Windows 95: `<STEP7_Directory>\s7bin\s7ofornx <m:> /s<a:>`
under Windows NT: `<STEP7_Directory>\s7bin\s7ofornx <m:> /s<a:>`
 where
 - `<m:>` is the identifier of the memory card drive on the PC or programming device
 - `<a:>` is the identifier of the diskette drive on the PC or programming device

Result: The memory card is formatted as boot medium, and the MS DOS system files are copied to it, that is, io.sys, msdos.sys and command.com.

You must then copy the portions of MS DOS which you need for your application from the MS DOS diskettes to the memory card. The data on the MS DOS installation diskettes are compressed, and cannot be processed with Setup until they have been decompressed. The following steps must be taken in order to copy files directly from an installation diskette without using Setup:

3. Copy file EXPAND.EXE from installation diskette 1 to the PC's or programming device's hard disk.
4. Insert the diskette containing the file to be decompressed into drive A:.
 If you do not know which diskette contains the desired file, open the PACKING.LST file on installation diskette 1. The PACKING.LST file contains the names of the files on the installation diskettes.
5. Enter the following in response to the input prompt:

expand *x: filename1 y: directory filename2*

For parameter *x*, enter the identifier for the diskette drive from which you are copying. For *filename1*, enter the name of the compressed file. For parameter *y*, enter the identifier for the target drive (memory card). For *directory*, enter the name of the directory in which the decompressed file is to be stored. For *filename2*, enter the name of the file which is to contain the decompressed data.

Result: The compressed file is stored in decompressed form on your target drive.

Repeat for all files to be transferred to the memory card.

Following completion of MS DOS installation, you can install M7 RMOS32 for MS DOS on the memory card.

Installing M7 RMOS32 for MS DOS

In order to start an M7 RMOS32 operating system with MS DOS on a memory card, you need the memory card on which you installed MS DOS (see page 3-11). Proceed as follows:

1. Select from your project the M7 program assigned to M7-CPU/FM.
2. Start the M7 Manager with the menu command
PLC ▶ Manage M7 System
3. Open the “Install Operating System” tab.
4. Install M7 RMOS32 for MS DOS locally on the memory card by making the following selections:
 - Medium: “Memory card”
 - Possible configuration: “M7 RMOS32 & MS DOS”
5. Select “Install”. Information relating to current events is displayed in the dialog field.

Result: The operating system and the complete M7 system software are transferred to the memory card.

6. Transfer your application program, together with all associated project data, to the memory card locally. To do so, switch to the “Programs” tab and proceed as described under “Transferring M7 Programs via Data Carrier”, Page 4-13. This step is optional.
7. Insert the memory card in the M7 programmable control system and start your M7 operating system.

Result: The M7 programmable control system boots with the new operating system from the memory card. Your application program is started.

3.5 Installing M7 RMOS32 on Hard Disk

Initial State

Originally, no executable operating system has yet been installed on the M7 programmable control system, and no MPI link is possible.

Prerequisites

In order to install M7 RMOS32 on the M7 programmable control system's hard disk, you require the following:

- An MSM 378 or 478 mass storage module on your M7 programmable control system
- A boot medium (1.44 Mbyte diskette or a memory card \geq 2 Mbytes)

Procedure

Proceed as follows:

1. Select from your project the M7 program assigned to M7-CPU/FM and start the M7 Manager with the menu command:

PLC ► Manage M7 System

2. Open index "Install Operating System" and make the following selections:

- Medium: "MPI/RFS"
- Possible configuration: "M7 RMOS32"
- Local drive: The first free drive, for instance F:
- Remote drive: C: for hard disk

3. Select "Install"

You will be informed of current events and instructed to enter any necessary information by prompts displayed in the dialog fields.

Essentially, you must do the following:

4. Select a boot medium (floppy disk or memory card).

Result: A minimal M7 RMOS32 operating system will be installed on the selected boot medium

5. Insert the boot medium in the M7 programmable control system's drive and start the M7 programmable control system. **Result:** The M7 programmable control system is booted with the new operating system and an MPI link established between the PC or programming device and the M7 programmable control system.

6. Partition and format the hard disk via RTI (Remote Terminal Interface) or at the local console of the M7 programmable control system. For more information please refer to Sections 3.2 and Section 5.2.

Result: The hard disk is partitioned and formatted. The M7 RMOS32 operating system and any application programs are then installed on the M7-300 or M7-400 hard disk via the MPI link.

To transfer your application program to the M7 programmable control system, open the "Programs" tab and proceed as described under "Transferring Programs via MPI/RFS", page 4-12.

7. Restart the M7 programmable control system via the mode selector and, if necessary, set up the BIOS. **Result:** The M7 programmable control system boots with the new operating system from the hard disk. Your application program, if any, is started.

3.6 Installing M7 RMOS32 with MS DOS on Hard Disk

Initial State

Originally, no executable operating system is installed on the M7 programmable control system, and no MPI connection is possible.

Prerequisites

The following is required to install M7 RMOS32 with MS DOS on the M7 programmable control system's hard disk:

- An MSM 378 or 478 mass storage module on your M7 programmable control system
- A boot medium (1.44 MB diskette or a memory card ≥ 2 MB)
- MS DOS installation diskettes. **MS DOS V6.22 must be installed on the M7 programmable control system's hard disk.**

Procedure

To install M7 RMOS32 with MS DOS on an M7 programmable control system with hard disk, you must carry out the following steps in the order given:

1. Select from your project the M7 program assigned to M7-CPU/FM and start the M7 Manager with the menu command:
PLC ► Manage M7 System
2. Open index "Install Operating System" and make the following selections:
 - Medium: "MPI/RFS"
 - Possible configuration: "M7 RMOS32 & MS DOS"
 - Local drive: The first free drive, for example F:
 - Remote drive: C: for hard disk
3. Select "Install".

You will be informed of current events and instructed to enter any necessary information by prompts displayed in the dialog fields. Essentially, you must do the following:
4. Select a boot medium (floppy disk or memory card). **Result:** A minimal M7 RMOS32 operating system is installed on the boot medium.
5. Select drives for the operating system and data (see Section 3.2).

6. Insert the boot medium in the M7 programmable control system's drive and start the M7 programmable control system. **Result:** The M7 programmable control system boots with the new operating system and an MPI link is established between the PC or programming device and the M7 programmable control system. Then, M7 RMOS32 for MS DOS and any application programs are installed on the M7-300 or M7-400 system's hard disk via the MPI link.

To transfer your application program to the M7 programmable control system, open the "Programs" tab and proceed as described under "Transferring M7 Programs via MPI/RFS", page 4-12.

7. Restart the M7 programmable control system via the mode selector and set BIOS Setup if necessary. **Result:** The M7 programmable control system boots with the new operating system from the hard disk. Your application program, if any, is started.

3.7 Reinstallation of the M7 Operating System

Initial State

If the M7 programmable control system's hard disk already contains an operating system, you can initiate **reinstallation** via "MPI/RFS", that is, you can change, expand or upgrade the operating system on your M7 programmable control system.

See the M7-SYS Product Information for details of which operating system configurations are released for which mass storage devices.

Note

During reinstallation the configuration files such as for example INITTAB or RMOS.INI are also transferred to the M7 system. If you have modified these files locally on the M7 without using the SIMATIC Manager menu command **PLC ► Manage M7 System**, you must save them before reinstallation, in order to avoid overwriting.

Reinstallation on Hard Disk

Table 3-3 shows you what you must do in the different cases to reinstall an operating system on the hard disk. The basic procedure is the same as that used for initial installation, and is described in detail in Sections 3.5 and 3.6.

Table 3-3 Reinstallation on Hard Disk

Current OS	OS To Be (Re)installed	
	M7 RMOS32	M7 RMOS32 with MS DOS
M7 RMOS32	Same as initial installation of M7 RMOS32	Format destination medium, install MS DOS locally, re-install M7 RMOS32
M7 RMOS32 with MS DOS	Same as initial installation of M7 RMOS32	Only one new M7 RMOS32 component is reinstalled

Reinstallation on Memory Card

Reinstallation of M7 RMOS32 on memory card always entails complete reinstallation. As a rule, only the M7 RMOS32 component is reinstalled in the case of M7 RMOS32 with MS DOS.

Additional Information

You will find details on individual steps as well as additional information on installing the various operating system configurations in the M7 programmable control system manager's on-line Help screens.

3.8 Updating the Firmware

On the M7-300/400 CPUs and application modules there is firmware specific to the module, such as the BIOS. You can update the firmware via the M7 programmable control system management.

The firmware can be updated independently of or in conjunction with the system software for M7-300/M7-400.

The version of the firmware in the M7 programmable control system and in the programming device is displayed in the "Update Firmware" tab. This makes it easier to check to see if the firmware requires to be updated: Updating of the firmware is only necessary if the firmware version in the M7 programmable control system is older than the firmware version in the programming device.

If you install the operating system via MPI/RFS, the firmware version is checked automatically. If the version of the firmware on the M7 programmable control system does not match the installed operating system, you will receive the relevant message.

Requirement

To update the firmware of an M7-300/M7-400 CPU or function module, you will require a boot medium (floppy disk or memory card).

The update must be performed within the context of a project which contains the M7 stations (CPUs or FMs) with a selected "M7 Program".



Caution

Hardware damage:

The line power must on no account be switched off during the update as this could result in damage to the module.

Loss of data:

After updating the firmware, you must run the BIOS setup and save your configuration even if you choose to work with the default values (see Section 12.4 in the S7-400, M7-400 Programmable Controllers Module Specifications, Reference Manual and Chapter 10 of the manual M7-300 Programmable Controller, Installation and Hardware). Any changes made to the BIOS settings before updating will be lost and must be entered again.




Figure 3-2 "Update Firmware" Tab

Versions and Revision Levels

"Operating System Version in Programming Device" list field

Select here the version of the operating system that you want to install or have already installed on your M7 programmable control system. This step is only

required if you have installed several versions of the M7-SYS option software on the programming device.

Firmware version, hardware version (revision level)

The following versions are displayed if an MPI connection to the M7 programmable control system exists:

- Current firmware version in the programming device
- Firmware version in the M7 programmable control system
- M7 programmable control system hardware revision level

Procedure

To update the firmware of an M7 programmable control system, follow the steps outlined below:

1. Select the M7 program container associated with the M7 CPU or FM.
2. Call the menu command **PLC ► Manage M7 System** and open the "Update Firmware" tab (see Figure 3-2).
3. Select the boot medium: floppy disk or memory card.
4. Select the version of the operating system from the list field "Operating System Version in Programming Device". This step is only required if you have installed several versions of the M7-SYS option software on the programming device.
5. Click the "Create" button.

Result: The boot medium is formatted (with a warning) and the new firmware is installed on it.

6. Insert the boot medium into the M7 programmable control system and start the M7-CPU/FM.

Result: If you boot the M7 programmable control system with this data medium, the firmware is updated automatically. The update is completed when the following LEDs are lit continuously:

- The USR LED on the M7-300 CPU/FM
- The USR1 LED on the M7-400 CPU/FM

7. Remove the boot medium from the M7 programmable control system and boot it from the preset mass storage medium (memory card, hard disk, etc.).

Note

If the firmware on the boot medium is incompatible with the module type or older than the existing firmware version, the firmware **not updated** and the fault LED (SF LED on the M7-300 and INTF LED on the M7-400) lights up. This also applies if an attempt is made to install the identical firmware version.

In the Event of a Fault

Take the following measures, in the event of a fault:

1. Remove the boot medium from the M7 programmable control system.
2. Check in case the version of the BIOS on the M7-300/400 module is higher than the version of the new firmware. If this is the case, an update is not required and is also not possible.
3. Check whether the module in your project agrees with the module type of the M7 programmable control system. If this is not the case, adapt your project accordingly and carry out the firmware update again.

3.9 Modifying Configuration Files

Configuration Files

M7-SYS RT V 4.0 supports modification of the configuration files of M7 RMOS32 in the SIMATIC Manager of STEP 7. Under the “Configure Operating System” tab in the “Manage M7 PLC System” window, you can select the following operating system configuration files and edit them.

File	Description	See
RMOS.INI	Configuration file for M7 RMOS 32	Sec. 3.10
INITTAB	Initialization file for M7 system server	Sec. 3.11
CLISTART.BAT	Initialization file for CLI	Sec. 4.2
HOSTS	List of nodes for TCP/IP	Programming Manual, Sec. 8.12
SERVICES	TCP/IP services	Programming Manual, Sec. 8.12

The files are stored for each CPU or FM module in the relevant “M7 program” container of the project.

Basic Procedures

You can modify the configuration files as follows:

- Edit the files that are located in the project on the PC or programming device and then load them onto the M7 system. This procedure is recommended, in particular, on installing a new version of the operating system, but it is also recommended generally.
- Load the configuration files that are located on the M7 system into the programming device, edit them and load them back onto the M7 system. This procedure is appropriate when a previously installed operating system is being modified, e.g. for entering new communication nodes in the HOSTS file.

You can load modified configuration files into the M7 system:

- Separately, using the “Download” button in the “Configure Operating System” tab or
- With the entire operating system on installation in the “Install Op. System” tab.

If you use the default configuration files, no modifications are necessary.




Figure 3-3 “Configure Operating System” Tab

Note

It is only possible to edit the configuration files for the M7-SYS RT V4.0 system software and to load them into the M7-300/400. This function is not supported for previous versions of M7-SYS. We recommend that all changes to the configuration files are only implemented on the PC or programming device and that the modified files are then loaded into the M7-300/400. This prevents inconsistency between the project in the PC or programming device and the operating system on the M7-300/400.

Modifying the Configuration Files in the Project

Proceed as follows:

1. Select the M7 program container to which the M7 module (CPU or FM) is assigned.
2. Call the menu command **PLC ► Manage M7 PLC System** and open the “Configure Op. System” tab (see Figure 3-3).
3. In the “Medium” field, select the transfer medium for loading
If your M7 system has a hard disk, select “MPI/RFS”, otherwise select another data carrier.
4. Select the local drive and the partner drive. It is only possible to select these options, if you have set the medium as “MPI/RFS”.
Local drive (only under Windows 95):
Select the drive identifier via which you want to access the M7 system. It is recommended that you use the first available character.
Partner drive:
Select the drive that you want to access, i.e. the drive on which the operating system is installed.
5. In the “Configuration” field, select the operating system whose configuration files you would like to edit.
6. Select the file that you want to edit from the “Editable Files” field.
7. Click the “Edit in PG” button
The selected file will be opened using the notepad editor.
8. Edit the file and save it.
9. Repeat steps 6 to 8 for each file that you want to edit.
10. Load the configuration files by:
 - Clicking the “Download” button to load the marked configuration file(s) onto the medium indicated or
 - Installing this operating system configuration onto the M7-300/400, in which case, the modified configuration files are transferred automatically.

Modifying the Configuration Files in the M7 System

Proceed as follows:

1. Select the M7 program container assigned to the M7 module (CPU or FM).
2. Call the menu command **PLC ► Manage M7 PLC System** and open the “Configure Op. System” tab (see Figure 3-3).
3. In the “Medium” field, select the transfer medium for uploading into the programming device (PG).

If your M7 system has a hard disk, select “MPI/RFS”, otherwise select another data carrier.

4. Select the local drive and the partner drive. It is only possible to select these options, if you have set the medium as “MPI/RFS”.

Local drive (only under Windows 95):

Select the drive identifier via which you want to access the M7 system. It is recommended that you use the first available character.

Partner drive:

Select the drive that you want to access, i.e. the drive on which the operating system is installed.

5. In the “Configuration” field, select the operating system whose configuration files you would like to edit.
6. Select the file that you want to edit from the “Editable Files” field.
7. Click the “Upload” button
The selected file will be loaded into the programming device from the M7 system and overwrites the file of the same name in the project.
8. Click the “Edit in PG” button
The selected file will be opened using the notepad editor.
9. Edit the file and save it.
10. Repeat steps 5 to 8 for each file that you want to edit.
11. Click the “Download” button to load the marked configuration file(s) onto the medium indicated.

When Do the Changes Become Effective?

The changes to the configuration files become effective as follows:

File	Changes become effective..
RMOS.INI and INITTAB	When the M7-300/400 is rebooted
CLISTART.BAT	When the CLI is restarted (<CTRL>+<R>)
HOSTS and SERVICES	On the next access via one of the functions of the socket library

3.10 The RMOS.INI File

The rmos.ini file is a software configuration file for the M7 RMOS32 operating system. It is an ASCII text format file, and can be edited to tailor the operating system's performance to suit your requirements. The file is read and evaluated on operating system start-up. Any new parameters go into force on a cold operating system restart.

Note

The operating system is preconfigured for your M7-300 or M7-400 hardware configuration; as a rule, no changes in file rmos.ini are necessary.

Should any modifications to this file become necessary, please change only those parts of the file discussed below.

run Command

The `run` command makes it possible to call an executable command from the rmos.ini file. CLI commands are not available to run. In contrast to the other configuration data, which have to be placed in a specific section, run may be located anywhere in the file.

When the relevant line is encountered, the command specified with run is loaded and executed. When it terminates, it is removed and processing of the file continues.

Example:

The `run` command to activate the German keyboard is:

```
RUN=M0:\BIN\chgkbd KBDGER
```

File Structure

Keywords enclosed in brackets separate the file into sections. Each section may contain several entries. Each entry is defined on a separate line. A value assignment is made using an equal sign followed by one or more parameters. Entries can be omitted, in which case they are replaced by default values. A comment for a line must begin with a semicolon or the letters REM.

RMOS Section

Some of the entries which may be included in the RMOS section are as follows:

[RMOS]	Identifies the RMOS section
picenable	Enable for specific hardware interrupt request inputs in the programmable interrupt control blocks. Drivers and other RMOS routines which rely on hardware interrupts enable the relevant inputs themselves. With picenable , you can enable additional interrupt inputs needed for your own interrupt service routines. Example for enabling IRQ12 and IRQ15: picenable=IRQ12,IRQ15
logsvcx	Specifies whether error messages of the system calls are to be output on the monitor screen. Options: YES Output to screen NO No output to screen Example for no output to screen: logsvcx=NO
sysdev	Definition of the system console. Specifies the name of the device driver (also see Appendix A.2). Options: BYT_COM1/2 For COM1 or COM2 BYT_EGA1 to 3 For EGA/VGA 1 to 3 (M7 RMOS32 without MS DOS only) none no system console Default sysdev=none Example for system console on COM1: sysdev=BYT_COM1
device	The <code>device</code> command loads a driver or generates a driver unit. The syntax and parameters are described in Appendix B.9. The <code>device</code> command calls in the <code>rmos.ini</code> file and in the CLI differ in the following way: The <code>device</code> command is followed by: <ul style="list-style-type: none">• a space – in the CLI• a "=" character in the <code>rmos.ini</code> Examples: Load 3964 driver without generating a unit: DEVICE=\M7RMOS32\3964.DRV Generate a driver unit for SER8250 on COM2: DEVICE=SER8250 COM2 IRQ:3 BASE:0x2F8 MODE:9600-N-8-1

Note

Activate the screen output of the error messages

`logsvcx=YES`

for test purposes only. During operation, this can lead to high task change times in the execution of your program.



Caution

If you have set up a system console on one of the serial interfaces COM1/COM2 with the entry:

```
sysdev=BYT_COM1
```

you must not use this serial interface for communication with one of the loadable drivers 3964R or SER8250, otherwise the output of the system console will be controlled by the new driver. It is directed to the port and can cause conflicts with the communications partner, for example, if an error message is output on the system console.

RMOS DOS Section

Some of the entries which may be included in the RMOS DOS section are as follows:

[RMOS DOS]	Identifies the RMOS DOS section
RESERVE_COMx	This entry reserves COM1, COM2 and so on for M7 RMOS32. Default: REM RESERVE_COM2 Each default includes a comment; the COM2 interface is also available for DOS. Remove the comment initiation letters REM to reserve the COM2 interface exclusively for M7 RMOS32.
MAX_PORT_NUMBER	This entry disables the port shadow. Default: MAX_PORT_NUMBER = 0XFFFF The value is preset and may not be changed.

3.11 The INITTAB File

Contents

The INITTAB file contains calls for starting the M7 system servers and the user programs. It is written in ASCII text format. The file is read and evaluated when the operating system starts up. New entries become effective once the operating system has been restarted.

Structure of the File

An entry has the following syntax:

<Start ID> <Path> [<Call parameter>]

Example:

```
0 \SRVBASICSrv.EXE 340 1
```

The start ID can be 0, 1 or 2. The values 0 and 1 are reserved for the M7 system servers. Application programs are entered with the start ID of 2.

The path is entered with reference to the main directory of the drive.

Call parameters are optional.

Each entry is specified in one line. You can use the “#” character to change the subsequent characters into a comment.



Caution

The M7 system servers are preconfigured for your M7-300/400 hardware and software configuration. These calls must not be modified; any changes would affect the system response!

Please only change the calls for the user programs, where necessary.

4

Operator and Monitor Interface

This chapter covers the following topics:

- How to operate the M7 programmable control system via remote terminal
- How to use the command line interpreter (CLI)
- How to transfer application programs to the M7 programmable control system and start them
- Information and control functions you may use

Chapter Overview

Section	Title	Page
4.1	Operation via Remote Terminal	4-1
4.2	Using the Command Line Interpreter (CLI)	4-3
4.3	Transferring programs to and deleting them from the M7 programmable control system	4-10
4.4	Starting application programs on the M7 programmable control system	4-15
4.5	Information and control functions for the M7-300 and M7-400	4-16

4.1 Operation via Remote Terminal

What is a “Remote Terminal”?

The remote terminal interface (RTI) makes it possible to operate an M7 programmable control system from a PC or programming device as though it were being operated via a local terminal under M7 RMOS32. An MPI link is required for communications between the M7 programmable control system and the PC or programming device.

You have the following possibilities via remote terminal:

- Use of the command line interpreter (CLI)
- Use of the low-level debugger

Starting the Remote Terminal

Proceed as follows to start the remote terminal:

1. Activate "Start" in the Windows 95/NT task bar to select:
Start ▶ SIMATIC ▶ STEP 7 ▶ Remote Terminal

This opens a dialog field for entering the associated MPI address (see Figure 4-1).




Figure 4-1 Dialog for Opening the Remote Terminal

2. Enter the MPI address (the default is 2) in the "Host name" field and select *OK*. The dialog field is closed and a RMOS console opened.

MPI Addresses

The address must be entered in the following form for FM456 modules: **<H>,<T>**, where

- **<H>** is the MPI address of CPU4xx in the MPI subnet and
- **<T>** is the identifier (TSAP-ID) for the FM 456.

TSAP-ID

The TSAP-ID depends on the rack and slot number of the FM456, and is a composite of the following:




Figure 4-2 Structure of the TSAP-ID

Example:

The FM456 in rack 1, slot 4 (240CH) has the TSAP-ID 9228 and the CPU's MPI address is 3. In this case, the entry would be:

3,9228

Using the CLI

To start the command line interpreter (CLI) via remote terminal, enter **<CTRL>R**. You can skip entry of the start file by pressing the Enter key, which initiates execution of default start file CLISTART.BAT and starts the CLI.

For further details, refer to Chapter 4.2 and Appendix B.

Using the Low-Level Debugger

To start the low-level debugger via the remote terminal, enter **<CTRL>D**.

For additional information, refer to Chapter 6 and Appendix C.

Ending the Remote Terminal Session

The remote terminal session can be terminated at any time by entering **<CTRL>Z**.

4.2 Using the Command Line Interpreter (CLI)

Purpose of the CLI: Operator Interface

The command line interpreter (CLI) is a user interface for the M7 RMOS32 operating system. CLI enables the starting and interactive operator servicing of commands and reloadable programs.

Component Functions

The CLI comprises the following:

- CLI task (shell)
- Program manager
- Reloadable commands
- Runtime environment for reloadable tasks
- CLI Start-up batch file CLISTART.BAT

CLI Task

In the RMOS system, the CLI is a dynamic task. The time period during which the CLI task is executing is referred to as a session. A session can take place on any console. The console on which a CLI session was started is the standard input and output unit for that session. The CLI task builds on the program manager's function interface. The default priority for the task is 64.

Program Manager

The program manager manages all executing CLI commands.

Its most important jobs include the following:

- Locating programs via a search path
- Diverting input and output where applicable
- Management of background jobs
- Management of reusable code segments
- Aborting of tasks through <Ctrl>+<C> or CANCEL
- In-line commands

In-line commands are linked with the program manager and thus with the RMOS operating system. They are called in the CLI task as subroutines. The in-line commands are also available without file management system (HSFS).

Reloadable Commands

Reloadable commands are programs which can be called via the CLI user interface. For example, the commands `dir`, `copy` and `rename` are implemented as reloadable programs.

Runtime Environment

The runtime environment is a fixed component of the CLI. It

- opens inputs and outputs stdin, stdout and stderr, taking into account any rerouting;
- breaks the command line down into the C format (argc/argv);
- initializes C Runtime Library on a task-specific basis.

CLISTART.BAT

When a CLI session is started, a batch file can be opened, for example to set such parameters as search path, prompt and current directory.

Starting the CLI

Options for starting the CLI include INITTASK and a dispatcher task which starts the CLI in the event of unexpected input. Both options have been implemented, that is to say, on system startup, the CLI is started on the main console. The CLI can be started on all consoles with the key combination <Ctrl>+<R>.

When started by the INITTASK, the CLI calls the CLISTART.BAT file in the boot drive's main directory.

When started via dispatcher task <Ctrl><R>, the name used to execute a file with the extension BAT is prompted. If <Return> is pressed without an entry being made, the standard file (CLISTART.BAT) stipulated for starting by the INITTASK is processed.

Commands and Programs Started by the CLI

Commands and programs started by the CLI are referred to as jobs. They can execute in the foreground (in connection with the console) or in the background (with no connection to the console on which they were started).

Jobs can be nested. Using batch files or the function interface, a job can start other jobs. A calling job is referred to as father, called jobs as children. A child can call other children. The CLI manages all tasks and commands started via the CLI itself or via the CLI function interface as jobs. From the viewpoint of the nucleus, however, there are also tasks which are started via SVC calls. These are not known to the CLI, and are therefore not jobs.

All jobs are controlled by the CLI that started them. The CLI also manages the following assignments:

- Each job has a job number, which is assigned by the CLI on start-up.
- Each job is assigned to the directory set at the time it is called.
For example, the command `DIR a:\bin > list.txt` is entered in the current directory A:. File LIST.TXT is thus created or overwritten in directory A:
- Each job is assigned a standard input, standard output and error output device. In the case of foreground jobs, the CLI's console is set for all input and output. The NUL device is assigned as input and output device for background jobs. The assignments can be diverted (see page 4-8).

Editing Commands

Keyboard entries on the command line are handled by the BYT driver. A separate history buffer, in the specified length, is available for each CLI session, that is to say, previously entered commands can be selected with the arrow keys.

Command lines can be edited with the following keys:

Letters, Numbers	Always overwrite existing characters
Arrow keys	The Right Arrow and Left Arrow keys move the cursor The Up Arrow and Down Arrow keys copy a previously entered command from the buffer to the command line
INS	Generates and inserts a space
DEL<Ctrl> (Backspace)	Replaces the character at the left of the cursor with a space Same as DEL
<Ctrl>+<A>	Deletes the line from the cursor position to the end of the line
<Ctrl>+<F>	Deletes the character at the cursor position
<Ctrl>+<H>	Same as Backspace
<Ctrl>+<X>	Deletes the line from the start to the current cursor position
<Ctrl>+<Z>	Terminates input during console copy, for instance the command <code>copy con file.txt.</code>

Names

Names may contain all characters allowed in DOS. This means that, in names, all characters greater than ASCII 0x21 which do not have one of the following functions are allowed:

Dummy character:

In file names, the dummy character (joker, wildcard) "*" stands for indeterminate name extensions of no more than the maximum permissible length.

In file names, the dummy character "?" identifies precisely one indeterminate character.

Drive specifications:

Drive specifications are terminated with the ":" character.

Directory Names

Directory names must be separated from succeeding file or directory names by "/" or "\". These two characters are identical in their function.

For each job, there is a current directory. Paths and routes can be absolute, that is to say, they may be specified beginning with the drive identifier, or relative, that is, the structure is specified on the basis of the current directory. In the latter case, the two dots ".." represent the higher directory.

Examples of valid file identification entries are:

```
C:\CLISTART.BAT
C:CLI\BIN\DIR.386
DIR.386
..\DIR.386
BIN\DIR.386
```

Extensions

Generally, the CLI uses DOS-compatible file names. Reloadable programs and CLI commands may be specified without a file extension. The CLI searches for the extension in a directory level in the following order:

```
386, EXE, BAT
```

Note

DOS programs existing in the form of .EXE files cannot be executed by the CLI.

The CLI converts the file names, directories and drives into upper-case letters. The arguments on the command line, however, are forwarded as they are. A program executing under CLI control may thus contain parameters written in lower case.

Diverting Input and Output

Input to and output from a command or task can be diverted to a file or an interface.

This is possible in the following cases:

- All CLI commands
- All programs which, through the use of standard C functions, read their input from `stdin` and write their output to `stdout` or `stderr`.

stdout

Diversion is specified by entering one of the following options on the command line:

```
> <File>  
or  
1> <File>)
```

diverts all output to `stdout` to the specified file. The file is created or overwritten.

```
>> <File>  
or  
1>> <File>
```

routes all output to `stdout` to the specified file. If the file already exists, outputs are written at the end of the file; if the file does not yet exist, it is created.

stderr

The option

```
2> <File>
```

routes all output to `stderr` to the specified file. The file is created or overwritten.

```
2>> <File>
```

routes all output to `stderr` to the specified file. If the file already exists, outputs are written at the end of the file. If the file does not yet exist, it is created.

stdin

The option

```
< <File>
```

causes input from stdin to be read from the specified file.

Examples:

```
DIR >NUL  
DIR > DIR.LIS
```

A device name may be specified instead of a file name (COM1, LPT1, etc.). Any device name used must be entered as BYT-driver-compatible unit in the RMOS Catalog.

If output is to be suppressed altogether, an option is available for diverting it to the NUL file.

Accessing Drives

Under the RMOS file management system, drives (volumes) must be logged on (MOUNT) prior to use. This can be done in several ways. A drive is logged on automatically when a file is **opened**. The drive then remains logged on even when the file open is terminated with error.

If an attempt is made to access a drive without explicitly opening a file, for instance in the case of the command `dir A:`, the drive must be logged on with MOUNT before it can be accessed.

A drive can also be logged on automatically with an appropriate PATH setting when a command is not reached at all or is reached via a path element which does not occur until later.

Printing Under M7 RMOS32

To print a file under M7 RMOS32 (without MS-DOS), enter the following command in the CLI:

Printer on LPT port:

```
copy <filename> BYT_LPT1
```

Printer on COM port:

```
copy <filename> BYT_COM1
```

Descriptions of CLI Commands

You find detailed descriptions of CLI commands in Appendix B.

4.3 Transferring Programs To and Deleting Programs From the M7 Programmable Control System

Application

STEP 7 provides options for doing the following using the M7 Manager:

- Transferring M7 application programs with all associated project data either separately or together with the operating system to the M7 programmable control system
- Deleting arbitrary software components (M7 programs) from the M7 programmable control system

You can also transfer M7 programs to the M7 PLC system and manage them with the special development tools contained in the M7 optional packages, such as CFC or the Organon debugger (refer to the documentation for the relevant option software). These tools do not transfer the programs permanently to mass storage, however, but only load them temporarily into the M7 programmable control system's RAM.

Prerequisites

In order to transfer application programs to the M7 programmable control system via MPI, an operating system must be available which can start the M7-300 or M7-400 and establish an MPI connection to the PC or programming device.

Apart from that, you can also install your M7 application program together with the operating system.

Basic Procedure

Proceed as follows to transfer a C, C++ program to the M7 programmable control system:

1. Select an M7 program container which is allocated to an M7 module (CPU or FM).
2. In your project, call the menu command **PLC ► Manage M7 System**.
3. Open the "Programs" tab.
4. Make the following selections (see Figure 4-3):
 - Programs on the programming device
 - Transfer and target medium
 - Local drive (only with Windows 95) and remote drive when using medium "MPI/RFS"
5. Activate "Install"

All other activities depend on the medium selected.

Selecting Programs

The “Programming Device” field shows all C, C++ programs assigned in your project to the M7 programmable control system. You can select one or more of these for transferring programs to the M7 programmable control system. The programs already available on the PLC system are listed in the “PLC system” field.

Transfer Medium

There are two ways of transferring the M7 application programs with STEP7:

- On-line via MPI/RFS
- Off-line via floppy diskette or memory card

Selecting a Local Drive and a Remote Drive

As is the case for operating system installation, you may select a local and a remote drive when using “MPI/RFS” as the installation transfer medium (see page 3-4).




Figure 4-3 “Programs” Tab

Note

If the operating system is installed on the hard disk, we recommend, for data security reasons (see Section 3.2), that you install the application programs on a different drive to the operating system.

Transferring M7 Programs via MPI/RFS

In an on-line transfer, the required program sections are transferred directly via MPI to the PLC system's mass storage, and the relevant Start Batch files are entered in the PLC system's `\etc\inittab` file so that the programs can be started automatically on the next system startup. In addition, a special description file is transferred for each M7 program; each contains all information needed to display and delete that particular program. The name of each description file is automatically generated from the name of the respective program, whereby care is taken to ensure that each file name is unique on the PLC system.

Proceed as follows to transfer M7 programs to the M7 programmable control system via MPI/RFS:

1. Start the M7 programmable control system. You may also use a diskette or memory card with boot capability for system start up.
2. Start the M7 Manager with the menu command
PLC ► Manage M7 system
3. Open the "Programs" tab.
4. Make the following selections (see Figure 4-3):
 - Medium: "MPI/RFS"
 - Local drive (only Windows 95): The first free drive, for instance F:
 - Remote drive: C: or D: for hard disk
 - The required application programs from the "Programming Device" list
5. Select "Install".

Result: An MPI connection is established to the M7 system and the selected software components are transferred to the PLC system drive. All programs transferred are displayed in the "PLC system" field.

The programs are started automatically on the next system startup.

During execution of these steps, information on current events is displayed in the dialog field.



Caution

Should files of the same name already exist on the PLC system, this transfer procedure will overwrite them! There is no automatic rename and no automatic backup!

Transferring M7-Programs via Data Carrier

In an off-line transfer, all files are first copied to a diskette or memory card. In addition, an installation file with the name **m7swins.bat**, which helps make it possible to transfer the programs last selected from the diskette or memory card to the M7 programmable control system's mass storage, is generated on the data carrier. The m7swins.bat file must execute under M7 RMOS32's CLI.

Note

When transferring off-line via the memory card to an M7 programmable control system with M7 RMOS32/DOS, you must change the entry

M7INSTDRIVE=M0:

in the **m7swins.bat** file to

M7INSTDRIVE=B:

Proceed as follows to transfer M7 programs off-line via data carrier:

1. Start the M7 Manager with the menu command
PLC► Manage M7 system
2. Insert the data carrier in the PC's or programming device's drive.
3. Open the "Programs" tab.
4. Make the following selections (see Figure 4-3):
 - "Floppy disk" or "Memory card" as medium and
 - The required application programs from the "Programming Device" list
5. Activate "Install".
Result: The selected software components are transferred to the data carrier.
6. Insert the data carrier in the M7 programmable control system.
7. Start the CLI locally on the M7-300 or M7-400 or via remote terminal.
8. Call the **m7swins.bat** batch file located on the data carrier to copy the software components to the hard disk. Batch file m7swins.bat always copies to the currently active drive, that is, to copy from diskette to the hard disk, for instance, enter the following command sequence:

```
cd c:\
A:\m7swins.bat
```



Caution

If files of the same name already exist on the PLC system, they will be overwritten!

9. The batch files for starting the programs are not entered automatically in the M7 programmable control system's `\etc\inittab`. Instead, temporary file `\etc\inittab.ins`, which contains all necessary entries, is generated on the data carrier. To start the programs automatically on the next M7-300/M7-400 system start, you must use the editor to transfer these entries to the M7 programmable control system's `\etc\inittab` file.

Rules for Off-Line Transfer

When you transfer M7 programs off-line via data carrier to the PLC system, a special description file is generated on the data carrier for each program. Each description file contains all information needed to display and delete the respective program. The name of a description file is generated automatically from the name of the associated program. In order to ensure that this file name is and remains unique on the PLC system, one of the following conditions must be fulfilled:

- The first five characters in the names of programs defined for an M7 CPU or M7 FM must differ.
- All programs belonging to a CPU or FM must be copied to the data carrier and transferred from there to the M7 programmable control system.

Note

Failure to observe this rule may result in the absence from the "PLC system" list of a software component in the event of a subsequent access operation via MPI, which would mean that that component could no longer be deleted.

Deleting M7 Programs

Proceed as follows to delete M7 programs on-line from the M7 programmable control system:

1. Carry out steps 1 to 4 as though transferring application programs via MPI/RFS.
2. Select the software components to be deleted from the "PLC system" list.
3. Activate "Delete".

Result: The selected software components are deleted from the PLC system drive.

4.4 Starting Application Programs on the M7 Programmable Control System

Starting M7 Programs

The following options are available for starting application programs on the M7 programmable control system:

1. During operation, programs can be started by the operator via the local console or the remote terminal interface (RTI).
2. On system startup, programs can be started by making an appropriate entry in the `etc\inittab` file, which is read immediately following the completion of system startup. The file contains the calls for all programs that are to execute automatically on system startup.

If you install the application programs together with the operating system or via "MPI/RFS", they are automatically entered in the `etc\inittab` file.

If you transfer the programs, without operating system, via data carrier (diskette or memory card), you must make the entries yourself if programs are to be executed automatically on system startup. You will find the relevant entries in the `etc\inittab.ins` file.

Starting Programs via the CLI

During a CLI session, you can start an application program by calling that program in the command line, for example

- `c:\testprog`

The program can be terminated by entering `<CTRL>c`.



Caution

Programs that are terminated by entering `<CTRL>c` do not free their allocated resources, which may cause the system servers to crash.

Please use the call *inhibitabort* in order to prevent your application program from being aborted and make sure that all allocated resources are freed.

We recommend you to reboot the operating system before restarting an aborted program.

4.5 Information and Control Functions for M7-300 and M7-400

Information Functions

The menu command **PLC system ► Module status** allows you to obtain the following information on M7 CPUs via the PC or programming device:

- Time system and CPU time
- M7-CPU data
- User memory capacity utilization
- CPU cycle times
- Status of the communications connections
- Contents of the diagnostic buffer

Differences between M7 and S7 Modules

In contrast to S7 modules, you can **not** obtain the following information for M7 CPUs and FMs:

- Block data and
- Stack contents

The relevant registers and fields are accessible via the user interface, but are empty.

CPU-Messages

The “**CPU Messages**” function makes it possible to output asynchronous messages pertaining to error events as well as user-defined messages.

Settings

As on the S7-CPU, you can make the following settings on M7-CPU:

- Change operating mode, CPU memory reset
- Set time and date

Monitoring and Modifying Variables

The menu command **PLC system Monitor/Modify Variables** provides the following functions for processing the variable table:

- Read data blocks, inputs, outputs and bit memories (flags).
- Write data blocks, inputs, outputs and bit memories (flags).

Note

Forcing of variable values is not supported on the SIMATIC M7.

Controlling the outputs is not possible in the STOP operating mode, because the Output Disable (OD) signal cannot be deactivated. You must switch to RUN mode in order to do this.

Where To Find Information

You will find detailed information on the above-listed functions in the following source material:

- The STEP 7 Manual and
- The STEP 7 on-line help

5

Using Mass Storage

In this chapter, you learn

- How to format memory cards and OSDs under M7 RMOS32 and MS-DOS, and
- How to initialize and partition hard disks and diskettes under M7 RMOS32.

Chapter Overview

Section	Title	Page
5.1	Formatting memory cards and OSDs	5-2
5.2	Formatting hard disks and diskettes	5-3
5.3	Hard disk partitioning program HDPART	5-4
5.4	Formatting memory cards and OSDs under MS-DOS	5-8
5.5	Using memory cards	5-10
5.6	The REMAP_A program	5-11

5.1 Formatting Memory Cards and OSDs

How Are Memory Cards and OSDs Formatted?

The following commands are available for formatting memory cards and OSDs:

Under MS-DOS on an M7-300 or M7-400:

Use the **ftlform.exe** command (see page 5-8).

Under MS-DOS on a programming device:

Use one of the following commands (see also page 5-8)

- **step7\bin\s7oformx.exe** under Windows 95
- **step7\bin\s7ofornx.exe** under Windows NT

Under M7 RMOS32:

Use the **bin\ftlform.386** command (see page B-22). This command can be called only locally on the M7 programmable control system or via remote terminal.

All commands have the following syntax:

ftlform <drive_to_format:> [/option]

s7oformx <drive_to_format:> [/option]

s7ofornx <drive_to_format:> [/option]

where the options have a different meaning under MS-DOS than under M7 RMOS32.

Memory cards can be formatted on both your PC or programming device and on the M7 programmable control system. On-board silicon disks (OSDs) can be formatted locally on the M7 programmable control system or via remote terminal.

Formatting under MS-DOS

Under MS-DOS, the drive from which the system files are to be copied to the boot medium is entered following the **/s** option.

Examples:

Formatting of the memory card, drive B: as boot medium (the MS-DOS installation diskette is in drive a:):

```
s7oformx b: /s a: in the DOS window of the PC/programming device
```

Simple formatting of the OSD on the M7 programmable control system

```
ftlform <drive>:
```

where **<drive>:** is the drive to format. Usually the OSD is assigned the first free drive letter after the hard disk partitions (see Table 3-2 on page 3-5).

Formatting under M7 RMOS32

Under M7 RMOS32, the system file to be copied to the boot medium is entered following the **/s** option. If no file is specified, default system file RM3_PC1.SYS is copied. The command must be called from the root directory (C:) in which this file is located.

Example - Formatting of the memory card as boot medium:

```
bin\ftlform M0: /s
```

5.2 Formatting Hard Disks and Diskettes

How Are Hard Disks and Diskettes Formatted?

Hard disks and diskettes are formatted with the **format** command. This command can be called under both M7 RMOS32 and MS-DOS, or in the DOS window of Windows 95 on the PC or programming device, and has the same syntax in both cases. You will find a detailed description of the command under M7 RMOS32 in Appendix B.

In the following, only formatting under M7 RMOS32 is discussed. For details on formatting under MS-DOS, please refer to the MS-DOS manual.

Note

From Version V 2.0 of the system software for M7-300/400, hard disks with a capacity greater than 516×10^6 bytes can be managed.

Formatting the Hard Disk for the First Time

The boot partition must be reformatted prior to every installation of M7 RMOS32 (without MS-DOS) on the M7 programmable control system's hard disk. Proceed as follows to format a hard disk as a boot medium under M7 RMOS32 for the first time:

1. Start the CLI locally on the M7-300 or M7-400 or via the remote terminal interface.
2. Enter the following commands:

```
HDPART (see 5.3) and restart the M7 programmable control system
```

```
FORMAT C: (see B.15)
```

```
FORMAT D:
```

```
... (when there are more than one partition)
```

```
RDISK (see B.25)
```

The HDPART Command

This commands provides you with the following menus:

1. Add partition
2. Change partition (enter the letter **B** in the "Status" column to identify the partition as boot partition)
3. Accept partition table

For additional information, see Section 5.3.

Reformatting a Hard Disk

If a logical partition has already been generated on the hard disk, partitioning and initialization (`RDISK`) are unnecessary. Proceed as follows:

1. Start the CLI locally on the M7-300 or M7-400 or via the remote terminal interface.
2. Enter the following commands:

`DISMOUNT` (this step is necessary only when the partition to be formatted is mounted; see B.11)

`FORMAT C:` (see B.15)

`RDISK` (see B.25)

Formatting Diskettes

Diskettes are formatted with the CLI command **FORMAT** (see Section B.15).

5.3 Hard Disk Partitioning Program HDPART

You can use the hard disk partitioning program HDPART to partition your hard disk.

Start

Under the CLI, you need enter only the file name and the path to the program to start the program, for example:

```
C:\BIN\HDPART
```

Operator Prompting

The program is menu-assisted. An input menu consists of input fields. You can go from one input field to the next with `<TAB>`. An input field can be edited with the Backspace key and deleted with `<Ctrl>+<X>`. Press `<Esc>` to rescind all entries and return to the preceding menu.

Partitioning

When called, HDPART logs on, for example, as follows:

```
(c) Siemens AG, RMOS3 Partdisk, Hard disk Partition Program Vx.y
Selected: Device 04H, Unit 00H
Work on this Unit (y/n) ?
```

If access to the hard disk driver's unit is not possible, you will be prompted for a new unit ID. Otherwise you must confirm the unit shown on the screen or choose another unit.

Select one of the unit IDs from the list provided and press <Return>. Your selection takes you to the following submenus:

Main Menu

The partitioning data are displayed in tabular form.

Each line in the table refers to a partition, and contains the type, status, first LBA (logical block address), last LBA, first cylinder, last cylinder, and the amount of space already reserved in the partition (in percent). If you have not yet generated a partition, only the table's header line is displayed.

Part-No	Status	Type	1st LBA	Last LBA	1st Cyl	Last Cyl	% of all
1	B	DOS-4	64	56944	0	203	20%
2		DOS-4	56960	85392	203	304	10%
3		DOS12	85408	100000	305	357	5%
4		DOS-3	100016	150000	357	535	17%

1. Accept Partition Table
2. Change Partition Table
3. Add one Partition
4. Abort without Changes

Enter Selection:

The meanings of the various values are discussed in detail in the chapter entitled "Structure of the Partitioning Table". Select one of the values from the list provided and press <Return>. Your selection takes you to the following submenus:

The Accept Menu

1 Accept Partition Table

The partition values displayed on the monitor are acceptable, and you wish to confirm them. You will be prompted to confirm your intention to write the data to the disk in order to avoid any unintentional destruction of disk data.

Write changes to disk (y/n) ?

If you enter n, the menu function is terminated without any data being written to the disk. If you confirm with y, the data needed for automatic hard disk recognition (by x_hd_init) are written to the disk and the function terminated.

Program terminated normally

Note

It is this command which writes the settings selected in the “2 Change Partition Table” and “3 Add One Partition” submenus back to the hard disk.

The Change Menu

2 Change Partition Table

You can change the partition data in this submenu.

Note

The partition to be changed must not be mounted. Please call the CLI command DISMOUNT before calling HDPART.

The partition table is displayed line by line.

Part-No	Status	Type	1st LBA	Last LBA	1st Cyl	Last Cyl	% of all
1	B	DOS-4	64	56944	0	203	20%

On this line, you can make changes simply by overwriting the values displayed. Changes from field to field (with <TAB>) modify the dependent parameters accordingly, but these modifications are not verified. The next partition is presented for editing when you press <Return>.

When there are no more partitions and no more free areas on the disk, all partition data are listed and control returned to the preceding menu.

If no partitions have as yet been generated on the hard disk, the entire disk is presented as a single partition. In the `Part-No` column, the partition number is preceded by the letter N, which identifies a new partition. You can make this partition smaller by changing the values in columns `1st LBA`, `Last LBA`, `1st Cyl` or `Last Cyl`. Once you have chosen the size you want and pressed `<Return>`, the rest of the hard disk is presented as partition in the next input field.

If the hard disk is already partitioned, areas to be redefined must first be erased. A partition is erased by entering 0 in the `Type` column and pressing `<Return>`.

When you have defined all areas or pressed `<Esc>`, the entire partition table is displayed. A check is made to see whether there are any overlapping partitions. The partition numbers of overlapping partitions, if any, are preceded by the letter o. This means that you must select this menu once again and modify the partition data accordingly.

The Add Menu

3 Add one Partition

This submenu allows you to add a new partition. The first gap found on the hard disk is presented as new partition entry. This submenu is suppressed if the hard disk has already been subdivided into the maximum permissible number of partitions (which is 4) or when there is no free space left on the hard disk.

The Abort Menu:

4 Abort without changes

This entry terminates the system function without saving the changes made in "2 Change Partition Table" or "3 Add one Partition".

Structure of the Partition Table

The partition table fields output by the HDPART program have the following meanings:

Table 5-1 Structure of the Partition Table

Field	Description
Part-No	Sequence number of the partitions, beginning with 1. This field cannot be edited.
Status	This field contains the status of the partition, B standing for the boot partition. Entry of a space identifies the current partition as unbootable.

Table 5-1 Structure of the Partition Table

Field	Description
Type	This field shows the type of partition. The following values are permissible: DOS-3 DOS Partition < 32 Mbytes with 16-Bit-FAT entries DOS-4 DOS Partition > 32 Mbytes with 16-Bit-FAT entries DOS12 DOS Partition < 32 Mbytes with 12-Bit-FAT entries EXTND Extended partition (possible for HD0 only; may appear only once in a partition table) 0 Delete current partition; entry at first input position only, followed by <Return>
1st LBA	First LBA in the partition
Last LBA	Last LBA in the partition
1st Cyl	First cylinder in the partition
Last Cyl	Last cylinder in the partition
% of all	Size of the partition in relation to the total hard disk capacity

5.4 Formatting Memory Cards and OSDs under MS-DOS

Syntax

The following programs are used to format flash drives:

- FTLFORM.EXE on M7 programmable control systems
- S7OFORMX.EXE on programming devices or PCs with Windows 95 or S7OFORNX.EXE on programming devices or PCs with Windows NT.

(the DOS command FORMAT is not supported by the drives).

Since both commands have the same syntax, only FTLFORM is described in detail in the following.

The command is called at the command line level:

```
c:>FTLFORM X:/Options
```

where X identifies the drive to be formatted.

When the call is issued without any parameters or with only the /h or /? parameter, a Help menu is displayed:

```
USAGE: FTLFORM <drive:> [/option[sclmnb]]
```

Options

The options may be prefaced by “-” or “/”, and no distinction is made between upper case and lower case. Options must be separated from one another by a space. The program supports the following options:

- /b Batch mode. The program's input requests to the user are suppressed.
- /c<Filename> Format with configuration file. If no file name is specified, the program attempts to open file FTLFORM.CFG as configuration file. If this is not possible, the program aborts with error. The syntax for the configuration file is discussed in detail in the next section.
- /l<Filename> Format with output file. All output from the program is diverted to a file. If no file name is specified, all output goes to file FTLFORM.LOG. All of the program's input requests to the user are suppressed.
- /m Create partition table (master boot record). A partition table is always generated when an on-board silicon disk (OSD) is formatted.
- /n No Messages. All output to screen as well as all of the program's input requests to the user are suppressed.
- /s<Drive> Copy DOS system files. If no drive is specified, the system files are sought first on drive C:, then on drive A:.
- /? or /h Display Help menu.

Configuration File

The configuration file is an ASCII file which enables user-specific formatting of flash media. The file is subdivided into sections; each section begins with a section name and ends where a new section begins or at end-of-file.

Commentary lines begin with a “#” character and may be inserted anywhere in the file.

System Files

Header: [SYS_FILES]

This section contains the names of the system files to be copied to the medium. A separate line must be used for each file name. A maximum of three system files may be specified.

Bootstrap Loader

Header: [BOOT_RECORD]

This section contains the name of a binary file to be copied to the medium as bootstrap loader (section 0 of the partition). The program checks to see whether the file fulfills the minimum requirements for a bootstrap loader (file length 512 bytes, 55AAh at the end of the file).

The code is not checked for executability!

Partition Table

Header: [MASTER_BOOT_RECORD]

This section contains the name of a binary file to be copied to the medium as partition table (sector 0 of the medium).

The program checks to see whether the file fulfills the minimum requirements for a master boot record (file length 512 bytes, 55AAh at the end of the file). The code is not checked for executability!

Application ID

The application ID "M7-DOS" is entered in the memory card's condition code memory following error-free formatting.

5.5 Using Memory Cards

Removing/Inserting the Memory Card

If you remove the memory card during operation and insert it again, you must proceed as follows:

1. Change to the root directory of the memory card M0:\.
2. Execute the **dismount** command for the memory card. This ensures that the memory card is not accessed. If the **dismount** has been successful, you can remove the memory card.

After inserting the memory card, the root directory is mounted automatically.

Note

After removing/inserting the memory card no memory reset is requested by the operating system.

Permanent Load Memory on Memory Card

If the permanent load memory (directory \RAMDIR) is located on the memory card, you must not remove the memory card during operation, as configuration data will be lost in the event of a power failure.

5.6 The REMAP_A Program

Function

Make floppy A: accessible again under MS-DOS

Call

The call is made **under MS-DOS** without any parameters:

```
A:>REMAP_A
FTL100 Remap Drive A: Utility Px.yy
      Copyright SCM Microsystems GmbH 1995
      Drive A: remapped
B:>
```

Description

In a system with an A: drive for floppies, the BIOS expansion for memory cards and OSDs checks during initialization to see whether there is a diskette in the drive. If there is not, drive B: takes over for all access operations to drive A: if the system is equipped with a memory card in order to make booting from the memory card possible.

After booting, however, the floppy drive must once again be made accessible to the system. This is done with the command REMAP_A.EXE.

The program itself switches the current drive to drive B: when A: is the current drive at the time of the program call.

Note

Default under M7 RMOS32 with MS-DOS: The call is always entered in the AUTOEXEC.BAT file.

6

Low-Level Debugger

In this chapter, you learn

- How the low-level debugger works, and
- How to use the low-level debugger.

Chapter Overview

Section	Description	Page
6.1	Task mode and monitor mode	6-2
6.2	Operator control of the debugger	6-5
6.3	General rules of syntax	6-7
6.4	Brief description of debugger commands	6-9

6.1 Task Mode and Monitor Mode

The debugger's default mode is the Task mode, the mode used for testing programs at the task level. In this mode, breakpoints may be set at the task level only, not in the code of RMOS drivers.

RMOS drivers may be tested in Monitor mode only.

A mode is entered either by issuing the appropriate command or via a special breakpoint handling routine.

In addition, the debugger contains an interface for the CAD-UL debugger Organon XDB.




Figure 6-1 Task Mode and Monitor-Mode

Debugger Prompt

The debugger prompt shows the current mode and the current context:

Prompt	Mode	
	Monitor Mode	Task Mode
Escape context		DEBUG_T>
Breakpoint context	DEBUG_MB>	DEBUG_TB>
Prompt for host debugger	>	>

For reasons of compatibility, only an abbreviated prompt > is initially output.

The HELP command can be called to switch from the abbreviated prompt (>) to the detailed prompt, for instance `DEBUG_T>` or `DEBUG_TB>`.

A return to the abbreviated prompt (>) is initiated by entering special commands forwarded by the host debugger, for instance `v` or `V`.

Task Mode

The Task mode is the mode used for testing at the task level, and is the debugger's default mode. The debugger executes as separate task, and is under operating system control. The debugger is allotted CPU time by the scheduler.

Breakpoints can be set to halt a specific task without immediately affecting other tasks (real-time behavior on the part of the debugger).

When a task encounters a breakpoint, it assumes the "Blocked, debugger breakpointed" status and the debugger task enters the Breakpoint context. The halted task's registers, stack and all required memory areas can be displayed and, if necessary, modified.

A switch from Task mode to Monitor mode can be made either via a monitor breakpoint (see QUALIFY) or via the MONITOR command.

Monitor Mode

In Monitor mode, the debugger, as monitor program, takes over control of the application. As soon as the debugger enters the Monitor mode, all interrupts are disabled and all other operating system activities suspended, that is, all tasks are halted (no real-time behavior).

Once a monitor breakpoint has been reached, the monitor can no longer be invoked as task. Instead, the debugger is called as a function of the interrupted program. The interrupted program's stack is not affected, the debugger's stack being used instead. The status of the interrupted program is stored in a breakpoint structure (shadow register), and can be displayed and modified while the debugger is executing.

When the debugger is exited (GO/STEP/EXITK), the register values are taken from the breakpoint structure (shadow register), the interrupts enabled, and the interrupted program resumed. At this point, control is returned to the operating system.

In monitor breakpoint context, it is not possible to switch to the Task mode using the TASK command. Only when a subsequent GO command is issued is program scanning resumed and the Monitor mode exited.

Note:

- In Monitor mode, task-specific commands are no longer permitted. Because the interrupts are disabled, the communications interface is operated using the polling method.
- Monitor mode is available only at a serial interface, and cannot be used on the BYT driver's EGA units.
- The debugger is not suitable for testing drivers which access the same serial interface controller that the debugger uses.
- In Task mode, the debugger can be interrupted at any time by a monitor breakpoint.

If the debugger is interrupted by a monitor breakpoint during output of its prompt, the prompt is incomplete following a GO command in Monitor mode.

- No DATA ACCESS breakpoints may be set on system variables such as XCIRB or XUCB when testing drivers in Monitor mode, as the debugger also accesses these variables.

Note

The debugger does not intervene in the system until requested to do so. The tasks to be tested should be in RAM, as this allows for faster program changes and the setting of an unlimited number of breakpoints.

The INT-3 statement (the CPU's only one-byte interrupt instruction) and the single-step interrupt INT 1 are used for debugger breakpoints.

6.2 Operator Control of the Debuggers

The Meaning of Context

The manner in which the debugger was activated and the sequences of operations which were interrupted help determine the different functions of the debugger commands. The term “context” is used to help differentiate. The context influences the definition of specific command functions or their usability.

A distinction is made between two different types of context:

1. **Escape context:**
When the debugger was last started by pressing a key on the terminal (task started via unexpected input), the rules for Escape context apply. Above all, this means that none of a task's registers may be manipulated. The commands for task register manipulation are not available, and the debugger executes with its own task ID and its own priority. The character code for a task start via unexpected input is configurable.
2. **Breakpoint context:**
The rules for Breakpoint context apply when the debugger was activated by a breakpoint (INT3 or debug register breakpoint). When, in this case, a task encounters a breakpoint, the task is halted and the debugger started. In Breakpoint context, the contents of the halted task's registers (that is, the CPU registers at the moment of interruption) can be displayed and modified. Control is returned to the interrupted task with GO or EXITK. EXITK also resets all breakpoints.

The debugger's priority in Breakpoint context is 255.

Task Execution

The debugger can inhibit task execution, that is to say, with the exception of the debugger, no task can execute. This may be done by invoking the INHIB command or when the debugger task is started (is determined during configuring). The status of all tasks remains unchanged (hold status) until task execution is once again enabled (debugger termination or INHIB). Any SVCs already initiated in a task are completed when this is not contingent on task execution. `RmIO-` calls, for instance, are completed; the calling task is then in the READY.EXIT state; EXITK and GO terminate the debugger, cancelling the blocking of task execution.

Debugger Start

Each time it is started, the debugger logs on with:

```
RMOS3 DYNAMIC DEBUGGER, Vm.n
```

Note

If you start multiple low-level debuggers for the same task, data inconsistencies can occur in the internal registers of the task. Please start **only one** low-level debugger for a task, in order to avoid such inconsistencies.

Initialization of the Console

When the debugger loads the program, the system console is already initialized by the Borland start-up code.

In order to detour the console anyway, the “startup” pragma must be used in the test program (see example below).

```
void debug_init (void);
void debug_init (void)
{
    ...
    xinit(...); // Use RmGetEntry to find the Device ID and Unit
    ID
}
#pragma startup debug_init 0
```

Breakpoints in Code Areas with Disabled Scheduler

If a breakpoint is set into a critical code area that is protected against preemption by the *RmDisableScheduler* / *RmEnableScheduler* calls, then the scheduling is reenabled as soon as the breakpoint is reached. The explanation is, that the task is blocked by the debugger when reaching a breakpoint, and a blocked task is not allowed to disable the scheduler.

Omitted Breakpoints

When the test program stops at a data breakpoint located at a place where an execution breakpoint has already been set, then the Low-Level Debugger notices only the data breakpoint (e.g. an Organon XDB tracepoint). The execution breakpoint is omitted upon resuming the test program.

6.3 Syntax

The debugger logs on with the input prompt:

```
DEBUG_T>
```

and expects the following input format:

```
[<repetition factor><empty>]<command>[;[<repetition
factor><empty>]<command>]...<return>
```

where

```
<command> =<command word><DEL><Arg1><DEL><Arg2>...<Return>
```

The repetition factor specifies the number of times the command is to execute. A repetition factor of 0 means that the command is to execute an arbitrary number of times. This parameter is optional.

The command word comprises several characters, and defines the required function. The number of arguments depends on the command.

The debugger's command words are listed in tabular form. The CPU register names `<cpureg>` are only allowed in the breakpoint context. All command words may also be entered in abbreviated form as long as the abbreviation used for a specific command makes that command distinguishable from all others. BREAKS, for example, can be abbreviated with BRE, BREA or BREAK, START command with STAR, but not with ST, since this abbreviation cannot be distinguished from STACK. An abbreviation must consist of at least 3 letters (exception: EX for EXIT).

Command words may be entered in either upper or lower case. The debugger does not begin to evaluate an input line until CR (Carriage Return) has been input.

The debugger prompts for any parameters not entered with the command. When a command is entered without its parameters, the debugger displays an appropriate message and awaits entry of those parameters (interactive command input).

In a command line containing several numeric parameters, parameters containing a sign, for example -1, must be entered in parentheses, that is, (-1). Failure to do so would cause the sign to be treated as an operator, and there would be no separation from the preceding parameter.

An input line may contain more than one command. Several commands, separated from one another by semicolon, may be entered on one line, the number of commands being limited only by the length of the line itself. A repetition factor may precede a command name, and specifies the number of times that command is to execute. If the repetition factor for a command is zero, that command is executed continuously, and can be aborted only with CTRL-C.

Numerical values are normally interpreted as either decimal or hexadecimal values, the BASE command being used to specify which of the two is to apply. BASE=10 specifies decimal, BASE=16 hexadecimal. By using a prefix, however, individual values can be entered in hexadecimal, decimal, octal, binary or ASCII.

Prefixes for the base:	0x	Hexadecimal
	0n	Decimal
	0o	Octal
	0m	Binary
	' '	ASCII

An ASCII value is assumed when one or more than one character is enclosed in apostrophes ('). In the case of two characters, the leftmost character corresponds to the high-value byte of the word.

The following number notations in a line are synonymous:

```
0n09    0x09    0o011    0m00001001    (non-printable character)
0n14    0x0E    0o016    0m00001110    (non-printable character)
0n65    0x41    0o101    0m01000001    'A'
```

Floating-point numbers must be written with decimal point or exponent. In the case of real numbers output with DISPLAY, the digits in the exponent are to be interpreted as decimal.

Examples for floating-point numbers:

```
CALC 3.141592654E+5 * 2.718281828E-3
+8.53973422234649D+002
```

When the rules of syntax are not observed during command input, the debugger responds with its general error message:

```
Syntax error!
```

and prompts for a retry.

In the following sections, debugger output is shown in different fonts. In addition, the following abbreviations are used:

```
xx          Current memory contents
CR          Command termination with Carriage Return
```

You will find the detailed command syntax in the Reference Section, Appendix C.

6.4 Debugger Commands

Overview

The debugger commands can be grouped as follows:

Mode Switching

monitor	Switch the debugger to Monitor mode
task	Switch the debugger to Task mode

Tasks

start	Start DORMANT task
halt	Halt task
cont	Resume halted task
query	Query task status
tcb	Display data from a task's TCB
tcd	Display data from a task's TCD
inhib	Allow/inhibit task processing
loadtask	Load task
freetask	Free a dynamically loaded task
call	Execute a program

Breakpoints

set	Set breakpoint(s)
breaks	List breakpoint(s)
kill	Reset breakpoint(s)
qualify	Initialize breakpoint
switch	Switch breakpoint context

Memory and Registers

display	Display memory contents
change	Display/modify memory bytes
fill	Fill memory block with byte values
regs	Display all registers
cpureg	Check/modify register contents
stack	Display stack
asm	Disassemble memory contents

Control Passing

go	Resume interrupted task and exit debugger
step	Execute step trace
exitk	Reset breakpoints and resume interrupted task
exit	Exit debugger

Input/Output

in	Read from I/O port
out	Output to I/O port

System

svc	Generate supervisor call
dir	Display resource catalog entries
report	Resource report
lines	Page-by-page output on/off

Numeric

help	Help command
evaluate	Compute integer expression
calculate	Compute floating-point expression
base	Set number base

Loadable Drivers

In this chapter you learn:

- Which loadable drivers you can use
- How to load a driver and generate driver units

Chapter Overview

Section	Description	Page
7.1	What You Need to Know About Loadable Drivers	7-1
7.2	Loading a Driver	7-2

7.1 What You Need to Know About Loadable Drivers

What is a Driver?

Input/output operations are handled by M7 RMOS32 using device drivers, abbreviated to device or driver, and their subsidiary components, the units. A device driver is a software module that controls and manages one or more I/O devices of the same type, or their controllers. I/O devices of the same type are, for example, multiple terminals controlled via RS-232 (V.24) interfaces.

In the following paragraphs, the terms device and unit always refer to controllers and connected I/O devices which are served by the driver. Devices can be I/O devices or memories.

What Loadable Drivers are Available?

Unlike permanently integrated drivers, loadable drivers can be integrated on demand, in order to control certain I/O devices. As from Version V2.0 of the system software for M7-300/400, the following loadable drivers are available:

- 3964 driver
- ser8250 driver

The drivers provide a standardized interface over which M7 RMOS 32 tasks can communicate with the drivers, in order to load a driver or access the devices.

3964 Driver

Character device driver for access to the serial interface using the 3964 protocol. The driver supports both the 3964 and the 3964R protocols. Both are secure protocols, where data transfer between communication partners takes place transparently in asynchronous half-duplex mode.

The difference between 3964 and 3964R is that, with 3964, the sender transmits a block check character to the receiver after connection shutdown. The block check character is an XOR of all transferred data bytes.

SER8250 Driver

Character device driver for simple access to the serial interface. The driver supports both bitwise transfer and the transfer of character strings.

Hardware

The drivers can address the following hardware interfaces (units):

- The COM port of CPU 388-4 and FM 356-4
- The COM ports of interface module IF 961-COM
- Other serial interfaces based on the UART 8250 on short AT cards.

7.2 Loading a Driver

Introduction

Before you can use a loadable driver, the driver must be loaded and one or more units generated. There are following ways to do this:

- On system power-up in the configuration file RMOS.INI
- During normal operation:
 - in the CLI command interpreter
 - in the user program

Loading a Driver on System Power-Up

In order to load a driver on system power-up, call the command `DEVICE` in the RMOS section of the configuration file `RMOS.INI`:

```
DEVICE = <path name> <unit name> [<unit parameter>]
```

The driver is loaded and entered in the resource catalog. A unit can optionally also be generated. If only the name of the unit is specified, a unit is generated with the default parameters.

If you subsequently want to generate further units of this driver, call the command `DEVICE` again one or more times in the configuration file `RMOS.INI`:

```
DEVICE = <catalog name> <unit name> [<unit parameter>]
```

If only the name of the unit is specified, a unit is generated with the default parameters.

Loading a Driver with CLI

A loadable driver can also be loaded during normal operation using the CLI command interpreter. The `DEVICE` command is used for this purpose. The procedure and command syntax for loading the driver and generating the unit are identical to the entry in the `RMOS.INI` file (see above “Loading a Driver on System Power-Up”).

The `DEVICE` command calls in the `rmos.ini` file and in CLI differ with respect to the following: The `DEVICE` command is followed by:

- A space - in CLI
- A “=” character - in `rmos.ini`

Loading a Driver from the User Program

The `RmLoadDevice` function call of the RMOS API is available for loading a driver and generating units in the user program. The description and use of the function call can be found in the section “Loadable drivers” of the programming manual.

Removing a Driver

Loaded drivers cannot be removed from the operating system while it is running.

Loading the 3964 Driver

The following examples illustrate how to load the 3964 driver.

In the rmos.ini file

- Load 3964 driver in the rmos.ini file without generating a unit:

```
DEVICE = \M7RMOS32\3964.DRV
```

- Load 3964 driver and unit for COM1 with default:

```
DEVICE = \M7RMOS32\3964.DRV COM1 IRQ:4 BASE:0x3F8  
MODE:19200-N-8-1 PROT:1-1
```

The driver is loaded and a unit named COM1 is generated with the following driver-specific parameters: 19 200 bit/s, no parity bit, 8 data bits, 1 stop bit, 3964R protocol, master.

In CLI:

- Generate a driver unit for 3964 on COM2:

```
DEVICE 3964 3964_COM2 IRQ:3 BASE:0x2F8 MODE:19200  
-N-8-1 PROT:1-1
```

Loading the SER8250 Driver

The following examples illustrate how to load the SER8250 driver.

In the rmos.ini file

- Load SER8250 driver without generating a unit:

```
DEVICE = \M7RMOS32\SER8250.DRV
```

- Load SER8250 driver and unit for COM1 with default:

```
DEVICE = \M7RMOS32\SER8250.DRV COM1 IRQ:4  
BASE:0x3F8 MODE:19200-N-8-1
```

The driver is loaded and a unit named COM_1 is generated with the following driver-specific parameters: 19 200 bit/s, no parity bit, 8 data bits, 1 stop bit.

In CLI:

- Generate a driver unit for SER8250 on COM2:

```
DEVICE SER8250 COM2 IRQ:3 BASE:0x2F8 MODE:9600-N-8-1
```


Faulty Initialization of Reloadable Driver Units

If you pass wrong unit parameters to the DEVICE command, the following happens: The driver unit is created and initialized with wrong parameters or with no parameters at all. The faulty initialization cannot be cancelled by a new call to the DEVICE command with the same unit name and new unit parameters.

To initialize the unit with the right parameters proceed as follows:

- In the RMOS.INI file: Correct the DEVICE entry in the RMOS.INI file and reboot the M7-300/400.
- In the CLI:
 - Reboot the M7-300/400.
 - Repeat the DEVICE command with correct parameters in order to create a new unit.

Operating Systems and Performance Features

A

In this chapter, you will learn

- The performance features of the M7 CPUs and function modules
- How the different operating system variants are configured,
- How main memory is allocated, and
- Which M7 RMOS32-DOS components are available.

Reader's Note

Read this chapter only when you need to reconfigure your operating system.

Chapter Overview

Section	Description	Page
A.1	Performance features of the CPUs and function modules	A-2
A.2	Configuration: M7 RMOS32	A-5
A.3	Main memory allocation	A-9
A.4	Configuration of M7 RMOS32 for MS DOS	A-10
A.5	Components of M7 RMOS32-DOS	A-15
A.6	Special features under M7 RMOS32-DOS	A-18

A.1 Performance Features of the CPUs and Function Modules

The CPUs and FMs of the M7-300/400 product family differ in their performance ranges.

Performance Feature	CPU 388-4, FM 356-4	CPU 488-3, CPU 486-3 FM 456-4
Size of the process image, inputs and outputs	256 bytes	512 bytes
I/O address area, digital inputs/outputs	8 Kbytes	
I/O address area, analog inputs/outputs	8 Kbytes	
Bit memories	8*64 Kbits (8*65535) from M 0.0 to M 65535.7	
Counters	0	
Timers	0	
Clock memories	0	
Operating hours counter	0	
Blocks:		
OBs	0	
FBs	0	
FCs	0	
DBs	128 ^{*)}	
SFBs	0	
SFCs	0	
Communications via MPI		
• Transmission rate	187,5 kbps and 19.2 kbps ^{**)}	
• Number of stations		
– Without repeaters	max. 32	
– With repeaters	max. 127	
• PDU size	max. 960 bytes	
PROFIBUS DP communications via IF 964-DP	Yes (see Table on page 1-5)	Yes
• Transmission rate	9600 bps to 12 Mbps	9600 bps to 12 Mbps
• Number of stations	96	96
Industrial Ethernet (TCP/IP) communications via CP 1401	Yes (see Table on page 1-5)	Yes
• Transmission rate	10 Mbps	10 Mbps
• Number of sockets	44	44
*) The numbers from 0 to 0xFFFF are possible, but the recommended maximum is 128 data blocks.		
**) Supported in M7-SYS RT V4.0 (see below)		

MPI, PROFIBUS-DP and Industrial Ethernet (TCP/IP) Connections

CPU 488-3, CPU 486-3:

Up to 64 connections can be established on a CPU of the M7-400 range. These can be distributed over the following resources:

- Up to 44 connections via the multipoint interface
- Up to 56 connections via the communication bus
- Up to 16 connections via PROFIBUS-DP (IF 964-DP).
- Up to 16 connections via Industrial Ethernet (CP 1401).

Of the 64 connections, 4 connections are always reserved for the remote file system and 4 connections for the remote terminal and the Organon debugger. One programming device connection and one OP connection are also reserved. The remaining connections are available for configuring.

FM 456-4:

Communication connections can be established on an FM 456-4 as follows:

- Up to 12 connections via the communication bus without IF 964-DP and CP 1401
- Additionally up to 16 connections via PROFIBUS-DP (IF 964-DP).
- Additionally up to 16 connections via Industrial Ethernet (CP 1401).

For example, a maximum of 44 connections can be established on an FM 456-4 with IF 964-DP and CP 1401. Of these connections, one connection is always reserved for the remote file system and one connection is reserved for the remote terminal and the Organon debugger. One programming device connection and one OP connection are also reserved for each interface submodule used. The remaining connections are available for configuring.

CPU 388-4, FM 356-4:

Up to 64 connections can be established in an M7-300 automation computer. These can be distributed over the following resources:

- Up to 44 connections via the multipoint interface
- Up to 16 connections via PROFIBUS-DP (IF 964-DP).
- Up to 16 connections via Industrial Ethernet (CP 1401).

Of the 64 connections, 4 connections are always reserved for the remote file system and 4 connections for the remote terminal and the Organon debugger. One programming device connection and one OP connection are also reserved for the MPI and for each interface submodule used. The remaining connections are available for configuring.

Note

Unconfigured connections and connections between subnetworks are not currently accounted for in the STEP 7 resource control. These must be subtracted in each case from the number of remaining connections available for configuring.

Retentive Data

The static RAM (SRAM) area holds retentive process data (data blocks and bit memories, that are available even after power failure. In the "Retentive memory" tab of the M7-300/400 CPU and FM, you can configure:

- up to 32 data blocks and
- up to 256 bit memories

as retentive data areas (in the SRAM).

In order to configure a data block as retentive, enter the value $\neq 0$ in the "Number of memory bytes from MB0" field. This makes the **entire** data block retentive. The sum of the bytes of all retentive data blocks must not exceed 56 Kbytes.

Clock Synchronization

With STEP 7 V4.0 the SIMATIC M7 can take part in the clock synchronization as a slave. Clock synchronization is always configured within a communication area that is either an MPI subnet or a SIMATIC station (via communication bus or P bus). A clock master, usually an S7-300/400 CPU, can be configured for each communication area. The clock master sends the current time of day cyclically with a synchronization interval while the other nodes of the subnet or of the SIMATIC station are slaves or neutrals.

Table A-1 shows the synchronization types that can be assigned to M7 modules in the "Diagnostics / Clock" tab. A "-" means that no clock synchronization can be configured.

Table A-1 SIMATIC M7 Clock Synchronization

Module	Synchronization Type	
	In PLC (SIMATIC Station)	On the MPI Subnet
CPU 388-4	-	Slave
FM 356-4	Slave (via P bus)	-
CPU 488-3 CPU 486-3	Slave (via communication bus, in a CR2 rack)	Slave
FM 456-4	Slave (via communication bus)	-

Correction Factor

Additionally the inaccuracy of the module's internal clock can be compensated once a day with a correction factor of -10000 to $+10000$ ms/day. The default value is 0. The correction is not carried out at one go but is distributed continually over the day. In M7 modules the correction factor is related to the software clock. No correction is carried out during power off.

FM 356-4 with Local Bus Segment

An FM 356-4 with local bus segment in the RUN operating mode forwards the synchronization frames from the CPU to the modules of the local bus segment.

19.2 kbps on MPI

You need 19.2 kbps if a module that supports only this transmission rate, e.g. a CPU 214, is connected to the MPI subnet.

Note

Up to 8 communication nodes (CPUs, programming devices, OPs, FMs and CPs) are allowed in a subnet with 19.2 kbps.

Please note that older versions of M7-SYS do not support the 19.2 kbps transmission rate and that it can be assigned only with version V 4.2 or higher of STEP 7.

Please consult the *S7 200 System Manual* for more information.

A.2 Configuration of M7 RMOS32

Device Unit Allocation

A: Disk drive A:	The parameters are taken from CMOS
C: Hard disk drive(s)	On system startup, the partitions from the first hard disk are integrated automatically. The system recognizes DOS-compatible partitions. Beginning with C, each partition is assigned a sequence letter: C: Partition 1 D: Partition 2
M0:	Memory card
M1	On-board silicon disk (OSD)

EGA/VGA Configuration

In order to allow visual distinctions, the following colors were assigned in the preconfigured software:

RMOS console 0:	Unit 0: White
RMOS console 1	Unit 1: Red
RMOS console 2	Unit 2: Blue
RMOS console 3	Unit 3: Green

You can press <Ctrl>+<D> to activate a debugger on the output units and <Ctrl>+<R> to activate the command line interpreter (CLI).

System Console

The system console is the output unit for RMOS system messages. The default is no RMOS system console. The system console can be routed to a device, for instance COM1/2 or EGA/VGA1 to EGA/VGA3, via an entry in the RMOS.INI file.

On system startup, the system console is automatically activated (when configured in the RMOS.INI file) and the CLI started. Another output unit can be selected with function key F2, F3 or F4.

Operating System Cycle

The operating system cycle is one millisecond, that is, the shortest interval for the `RmPauseTask` and `RmRestartTask` calls is one millisecond.

C Runtime Library CRUN

The configured C runtime support corresponds to ANSI's Draft International Standard ISO/IEC DIS 9899 (published in 1990). The functions are discussed in detail in the Reference Manual.

System Tasks

The following RMOS system tasks are configured:

CLI_DPAT	CLI distributor task	<Ctrl>+<D> starts a debugger. <Ctrl>+<R> starts the CLI log-on task, which then starts the CLI.
REP	Resource-reporter task	Output to unit 0. Called via the debugger with START2 or the REP command.
DEB_0 DEB_1 DEB_2 DEB_3	Four debuggers	Activated with <Ctrl>+<D>.
ERRLOG	Error logger task	
REMOTE	REMOTE task	Task for loading via serial port.
HSF_A HSF_B HSF_R	HSFS tasks for diskette drives	HSFS starts a task for each storage medium.
RMCONF	RMOS startup task	
BU_COUNT	Busy task	Computes the system on-load.
CLI_CLEANUP	CLI task for background jobs	Cleans up memory following termination of background jobs.
CLI_JOB_0	The CLI's basic task	CLI prompt
HSF_C	Task for hard disk partition C:	An HSFS task is started for each hard disk partition.

Note

When <Ctrl>+<D> is entered, the distributor task checks to see whether or not a debugger was started, and, if so, restarts it. If the console doesn't have a debugger, a new debugger task is generated and started.

Configuration of the File Management System

Diskette drive A
C: = Hard disk partition 1
(D: = Hard disk partition 2)
.
.
M0: = Memory card.
M1: = OSD

M7 RMOS32 Drivers

The following M7 RMOS32 drivers are configured:

BYT driver: Device 0
Unit 0: System console (EGA/VGA-unit 0), keyboard (input)
Unit 1: EGA/VGA-unit 1
Unit 2: EGA/VGA-unit 2
Unit 3: EGA/VGA-unit 3
Unit 4: Serial interface (COM1, 19200 bit/s)
Unit 5: Serial interface (COM2, 19200 bit/s)
Unit 6: Printer (LPT1: Centronics)

FD0 driver, diskette driver: Device 1, unit 0, unit 1

HD0 driver, hard disk driver: Device 3, unit 0, unit 1

Memory card driver

OSD driver

Boot Procedure

The RMOS boot procedure is based on the DOS convention, that is, on a system reset, the BIOS stored on EPROM loads the RMOS boot sector (512 bytes) from the respective boot medium (diskette, hard disk, memory card) into system memory beginning at address 0:0x7C00. The boot sector's code is then executed; it is this code which loads and starts the memory-mapped RMOS system. The RMOS system must be the first entry in the boot medium's main directory.

Boot Medium

An RMOS boot sector is created on hard disk and diskettes with the RDISK utility. On memory cards, an RMOS boot sector is created with the FTLFORM utility.

File Management System

M7 RMOS32 contains the High-Speed File System, or HSFS for file management. The file management system can manage data media, or volumes, which have a DOS-compatible format.

The hard disk is integrated in the file management system on system startup. In an initial phase, the HD0 driver is initialized; this phase uses the BIOS ROM table data to which interrupt vectors 41H and 46H point. Once the driver for unit 0 (drive C) and unit 1 (unit D) has been initialized, the file management system is initialized in the second phase. In this phase, each DOS partition is assigned a "volume name".

The hard disk is partitioned and initialized with the HDPART utility.

Watchdog

The programmable CPUs/FMs each have a watchdog for monitoring the user programs. The watchdog is set cyclically by the system software. If a fault (for example, shortage of resources) causes the cyclical setting to fail, the module will be reset after expiry of the monitoring time.

A.3 Main Memory Allocation

Main memory is allocated as follows in M7 RMOS32 and M7 RMOS32 with MS-DOS:

Table A-2 M7-300/M7-400 Main Memory Allocation

Address	Contents
1MB to 15MB 16MB to max. capacity	User memory
15MB to 16MB	PROFIBUS-DP
E 8000H to F FFFFH	BIOS
E 0000H to E 7FFFH	Unassigned (32K)
D 4000H to D FFFFH	Unassigned (48K)
D 0000H to D 3FFFH	Reserved for CP 1401 (16K)
C F000H to C FFFFH	Unassigned (4K)
C C000H to C EFFFH	Memory card and/or OSD, otherwise unassigned (12K)
C 8000H to C BFFFH	CPU 388-4, FM 356-4: SRAM CPU 488/486-3, unassigned (16K) FM 456-4 reserved (16K)
C 0000H to C 7FFFH	Shadow VGA-BIOS (32K)
A 0000H to B FFFFH	VGA (128K)
0 0000H to 9 FFFFH	640 K system memory area

Memory Areas for AT Cards

AT cards inserted in the ATM 478 expansion module can reserve the following memory areas:

Area	M7 RMOS32	M7 RMOS32 with MS-DOS	
		Without EMS	With EMS
D 4000H to E 7FFFH	80K	80K	16K ³⁾
C 8000H to C BFFFH ¹⁾	16K	16K	16K
C C000H to C EFFFH ²⁾	12K	12K	12K
C F000H to C FFFFH	4K	4K	4K

- 1) This area is available only in conjunction with CPU 488/486-3; in the case of CPU 388-4 and FM 356-4, it is reserved for SRAM.
- 2) The area is available only in the absence of a memory card or OSD.
- 3) When the driver software under MS-DOS requires expanded memory (EMS), the EMM386 memory manager reserves 64 Kbytes in the range D0000H to E7FFFH if it is to be operated in EMS mode.

A.4 Configuration of M7 RMOS32 for DOS

Mass Storage

- A: Diskette drive
- B: Memory card-drive
- C: Hard disk drive or OSD (if there is no hard disk)
- D: ... OSD if there is no hard disk, or additional hard disk partitions

All mass storage is controlled by the DOS file management system.

Parallel Ports

All parallel ports are controlled by MS-DOS.

Serial Ports

COM1 is controlled by MS-DOS.

COM2 is controlled by the M7 RMOS32 operating system's BYT driver. COM2 is provided for connection of a terminal (19200 baud, 8 data bits, parity off, 2 stop bits, 3-wire line (TxD, RxD, GND) and in the M7-side connector DTR connected with DSR, RTS and CTS).

COM2 can be set as M7 RMOS32 system console, that is, all system output goes over this port.

Operating System Cycle

The operating system has a cycle time of 1 millisecond, that is, the shortest interval for the `RmPauseTask` and `RmRestartTask` calls is 1 millisecond.

C Runtime Library CRUN

The configured C runtime supporter CRUN conforms to ANSI's Draft International Standard ISO/IEC DIS 9899 (published in 1990). The functions are discussed individually and in detail in the Reference Manual.

System Tasks

The following RMOS system tasks are configured:

WINCOND_0 to WINCOND_7	Virtual console (demon)	
CLI_DPAT	CLI distributor task	<Ctrl>+<D> starts a debugger. <Ctrl>+<R> starts the CLI's log-on task, which then starts the CLI.
REP	Resource reporter task	
DEB_0 DEB_1 DEB_2	Three debuggers	Activate with <Ctrl>+<D>.
ERRLOG	Error logger task	
REMOTE	REMOTE-task	
RMCONF	RMOS-startup-task	
DOS_HSFS	HSFS task for file management system	
DOS_TASK	DOS task	Is catalogued under second name DOS.
CLI_CLEANUP	CLI task for background jobs	Cleans up memory on termination of a background job.
BU_COUNT	Busy task	Computes the system on-load.

Drivers

The following RMOS drivers are configured:

BYT driver:	Device 0	
	Unit 0:	System console (COM2)
VC driver:	Device 1	
	Unit 0	Units mapped to monitor and keyboard by the
	to	DOS program RM3_CON.EXE.
	Unit 7	

Resources

10	Static mailboxes
10	Static global event flag groups
10	Static semaphores
1	Memory pool

Memory Pool

A memory pool is available, and is configured as HEAP:

The size of the pool depends on the amount of memory provided for RMOS.

Boot Procedure

DOS is booted first. The RM3PMEM.SYS driver must be the first entry in the CONFIG.SYS file. The driver decides how to divide the available memory between RMOS and DOS on the basis of its call parameters.

When DOS is restarted independently of RMOS, the RM3RESET driver must be entered immediately behind RM3PMEM.SYS or, when a memory manager is used, behind that memory manager. RM3RESET.SYS stores the current DOS memory map (approximately 800 Kbytes) in the memory area reserved for RMOS. The load address at which the RMOS system is then physically loaded is relocated accordingly.

The memory-resident DOS program RM3_TSR.EXE is started from the AUTOEXEC.BAT file before RMOS is loaded.

M7 RMOS32 is loaded with load program RUN_RM3.EXE. This program reads RMOS system file RM3DOS.LOC and loads the system into the memory area reserved for M7 RMOS32. The current DOS system is not overwritten. After loading, M7 RMOS32 is started directly. The DOS system is, as it were, on "hold".

The initialization task then starts the DOS task.

The DOS task initializes the entire RMOS-DOS environment and reactivates the on-hold DOS system. From the DOS operating system's point of view, the only program executed up to this point was the RUN_RM3.EXE load program.

Memory Allocation

Following RMOS-DOS booting and startup, memory is allocated as shown in Table A-2 on page A-9.

Restart Using <Ctrl> <Alt>

DOS can be restarted without interrupting the RMOS system run. A restart can be triggered with the key combination <Ctrl>+<Alt>+ or via RMOS by starting the DOS restart task or issuing a function call for another task.

Prerequisite to a restart is that the RM3RESET.SYS driver be correctly installed in CONFIG.SYS.

File Management System

Under RMOS-DOS, hard disk(s) and diskette drive(s) are always managed by DOS. RMOS has no direct disk access.

The RMOS-DOS file management system is an interface between the RMOS file management system (HSFS) and the DOS file management system which makes it possible for an RMOS task to access DOS-controlled drives. It is linked into the HSFS via the network interface as network task. RMOS task calls to the file management system are thus first received by the HSFS, then forwarded to the DOS file management system.

Drives

In the M7 RMOS32 with MS-DOS operating system configuration, 26 drives, with the names A to Z, are defined. This allows you to access all drives configured under DOS. It makes no difference whether these drives are implemented under DOS with network software or are just local.

Task Management under M7 RMOS32 with MS-DOS

M7 RMOS32 can interrupt MS-DOS programs:

Note

MS-DOS is a single-task operating system.

This means that an MS-DOS program can be interrupted at any time by a program started by M7 RMOS32. No other MS-DOS program can run, for example, when the RMOS console (a TSR-DOS program) is active.

To avoid this, use the remote terminal interface (see Section 4.1).

In M7 RMOS32 with MS-DOS systems, access to the mass storage medium and input/output devices (VGA monitor and keyboard) is via the DOS file system. However, the time required for these accesses is not deterministic, and the user task (including, for example, important control tasks) can be subjected to waiting times that do not correspond to the priority assigned.

Conversely, M7 RMOS32 activities can be interrupted by DOS commands:

The **dir** command under MS-DOS holds up running file system activities under M7 RMOS32. For example, if the **dir** command is called while downloading data blocks to the M7, the download is held up and not continued until completion of the **dir** command.

Note

To avoid undesired effects, read/write procedures on the DOS file system and accesses to input/output devices should be transferred to an autonomous lower-priority task.

Interfaces Between M7 RMOS32 and MS DOS

M7 RMOS32 with MS DOS supports function calls for communication between the two operating systems. These interfaces are preserved for compatibility with earlier versions and are not for further development.

A.5 Components of M7 RMOS32-DOS

The following programs are entered in system files AUTOEXEC.BAT and CONFIG.SYS as defaults:

In AUTOEXEC.BAT:

- REMAP_A.EXE - Make floppy A: accessible once again under MS-DOS
- RM3_CON.EXE - Drivers for virtual RMOS consoles
- RM3_TSR.EXE - Interface between RMOS and DOS
- RUN_RM3.EXE - For loading and starting RMOS

In CONFIG.SYS:

- RM3PMEM.SYS - For dividing memory between RMOS and DOS
- RM3RESET.SYS - For restarting DOS

Note

The operating system is preconfigured for your M7-300 or M7-400 hardware configuration. Normally, no changes are required in the AUTOEXEC.BAT and CONFIG.SYS files.

If necessary, please change only the entries discussed in the following.

A.5.1 RM3PMEM.SYS

Function

RM3PMEM.SYS is a DOS device driver which determines how memory is to be divided between RMOS and DOS.

Syntax

DEVICE=<directory>RM3PMEM.SYS RMOSSTART=nnnnn
(in the CONFIG.SYS file)

Description

RMOSSTART = nnnnn	nnnnn specifies the physical memory address at which the RMOS section of memory begins. The value is entered as hexadecimal number. A value smaller than 110 000 is invalid. The default value can be configured, for example 380 000 with 8 Mb of main memory.
----------------------	---

This driver reserves the memory area beginning with the address specified by the RMOSSTART parameter and ending at the physical end of memory for RMOS. DOS has access only to that section of memory preceding this area, that is, the section ending at the specified address. The parameter value may be given only in 4 Kbyte increments.

Note

The memory area reserved for RMOS must be at least 4.5 Mbytes.

A.5.2 RM3RESET.SYS

Function

RM3RESET.SYS is a DOS device driver needed to restart DOS.

Syntax

(in the CONFIG.SYS file)

```
DEVICE=<directory>RM3RESET.SYS
```

Description

This driver is required only when DOS is to be restarted while RMOS is executing. RM3RESET.SYS stores the current DOS memory image (approx. 800 Kbytes) at the beginning of the memory area reserved for RMOS and relocates the RMOS load address accordingly.

A.6 Special Features under M7 RMOS32-DOS

Programs Which Cannot Execute under RMOS-DOS

A number of DOS program cannot execute under RMOS-DOS, namely:

- programs which reprogram the interrupt controller, and
- programs which reprogram timer 0 or timer 1. Access to timer 2, however, is permissible.

Software using one of the following DOS extenders cannot run on M7 RMOS32 with MS DOS, for example:

- Phar Lap TNT DOS-Extender (e.g. under DOS Visual C++, MASM V6.1, ACAD V12, Borland C V4.02, V4.5)
- DOS/4GW 32-Bit DOS-Extender of Rational Systems (contained for example in Watcom C++ 9.5)
- DOSX from Symantec C++ Professional 6.1

The use of the Quick-C editor under MS-DOS can lead to sporadic crashes of the M7 RMOS32 operating system.

Note

M7 RMOS32 with MS-DOS is **not released** for use with the Quick-C development environment.

The use of this editor is not permitted during normal operation.

DOS Debugger

When a debugger is used in the DOS task, it is not possible to execute an INT n command in Single Step mode when this interrupt is serviced by RMOS-DOS rather than by DOS. This always applies to the EMS interrupt (67H) and the interrupt (73H) used by the RM3_TSR program. It is recommended that a breakpoint be set after the INT n command instead of using Single Step mode.

RMOS DOS File Management System

There are a number of differences between the RMOS-DOS file management system and the original HSFS. These differences originate from the inherent differences between the DOS and the RMOS file management systems.

Maximum Number of Open Files

The maximum number of open files under the RMOS-DOS file management system is 64, and is also restricted by the following variables:

- The number specified in “FILES=nn” in DOS file CONFIG.SYS.
- The size of the Job File Table (JFT) in memory-resident DOS program RM3_TSR.EXE. This table has 64 entries.

Each of the variables mentioned above implies the possible number of open files. The smallest of these values defines the maximum permissible number of open files in your system.

Reading a Directory File

The HSFS permits opening and reading of a directory file. This is not possible with the DOS file management system.

The RMOS-DOS file management system allows a directory file to be opened, but not to be read. The channel number returned by RMOS-DOS can subsequently be used when opening files in this directory.

32-Bit-Directory Entry

Under HSFS, the entire 32-bit directory entry is returned. Under DOS, the directory file cannot be read. RMOS-DOS therefore generates a pseudo directory entry containing the following fields:

- File name,
- File attributes,
- Date and time,
- File size.

The first cluster number in the file is not included in this pseudo directory entry.

Wrong Console Setting after MS-DOS Reset

If the assignment of the RMOS console after resetting MS-DOS does not match the initial setting, reset MS-DOS again in order to restore the correct console setting.

Start Message under MS-DOS

If you attempt to start an RMOS application under MS-DOS, the following error message appears: “This program must be run under Win32”.

Note: Please start the program under M7 RMOS32, e.g. in the CLI.

DOS Breakdown

If you switch to M7 RMOS32 (CTRL-ESC) while **edit** of MS DOS is active, then an MS DOS breakdown may occur.

Remedy: Avoid this problem by doing one of the following:

- Exit the **edit** application before switching to M7 RMOS32
- Enter the DOSKEY command to the AUTOEXEC.BAT file.

CLI Commands

B

Chapter Overview

Section	Command	Description	Page
B.1	BYT8250	Parameterization of the BYT driver for the serial interface (UART)	B-3
B.2	CANCEL	Abort job	B-5
B.3	CD	Change from one directory to another or display the current directory	B-6
B.4	CHGKBD	Change keyboard layout	B-7
B.5	COPY	Copy one or more files, optionally with subdirectories	B-8
B.6	CPRI	Change task priority of a CLI job	B-10
B.7	DATE	Display/modify the current date	B-11
B.8	DEL	Delete one or more files	B-12
B.9	DEVICE	Load a driver or generate a driver unit	B-13
B.10	DIR	List directory contents	B-16
B.11	DISMOUNT	Dismount volume	B-17
B.12	ECHO	Switch command line display during batch file processing on or off, or issue a message	B-18
B.13	ERROR	Display error level and its meaning	B-19
B.14	EXIT	Terminate CLI task	B-20
B.15	FORMAT	Format diskette or hard disk	B-21
B.16	FTLFORM	Format memory card or OSD	B-22
B.17	HELP	Output command overview or syntax description of individual commands	B-24
B.18	MD	Create new directory	B-25
B.19	MOUNT	Mount a volume or display status of all drives	B-26
B.20	NPX	Prefix for starting a program which uses the numeric coprocessor	B-27
B.21	PATH	Define the file path for loadable CLI commands	B-28
B.22	PING	Check if TCP/IP network host is alive	B-30
B.23	PROMPT	Change the CLI prompt	B-31
B.24	RD	Delete an empty subdirectory	B-32

Section	Command	Description	Page
B.25	RDISK	Install boot sector on hard disk or diskette	B-33
B.26	RENAME	Rename one or more files or directories	B-34
B.27	SCANDISK	Check and interactively repair a mass storage device	B-35
B.28	SESSION	Start a foreground task at another terminal	B-37
B.29	SET	Define an environment string	B-38
B.30	START	Start a background job	B-39
B.31	SYSTAT	Display active CLI jobs	B-40
B.32	TIME	Display/modify the current time	B-41
B.33	VER	Output RMOS system information	B-42
B.34	CLI Error Messages		B-43

Note

Each command description specifies whether the command is an inline or a loadable command.

For the user it is immaterial whether a command is inline or loadable. The only discernible difference is that inline commands cannot be aborted and that they need not be loaded before they can be called. This means that inline commands can be executed in diskless systems.

B.1 BYT8250**Function** Parameterization of the BYT driver for the serial interface (UART)

Loadable command

Syntax `byt8250 name port baud mode [irq entry [unstack key1 key2]]`

Parameter Name	Meaning
name	Name of the unit (BYT_COM1, BYT_COM2)
port	Port address of the UART block (hex) For BYT_COM1 0x3F8, for BYT_COM2 0x2F8.
baud	Baud rate of the UART block (decimal)
mode	<p>Operating mode of the UART block (hex)</p> <p>Data and stop bits</p> <p>0x02 7 Data bits 0x03 8 Data bits 0x00 1 Stop bit 0x04 2 Stop bits</p> <p>Parity</p> <p>0x00 No parity 0x18 Even parity 0x08 Uneven parity</p> <p>Emulation</p> <p>0x0000 SME emulation 0x1000 VT100 emulation</p> <p>Modus</p> <p>0x0100 Transparent mode 0x0000 Terminal mode</p> <p>The respective values must be linked with OR.</p> <p>Example:</p> <p>The Hex value 0x1103 indicates the following operating mode: The UART block works with 8 data bits, 1 stop bit, no parity, VT100 emulation in transparent mode.</p>
irq	Hardware interrupt for the UART block (dec) e.g. 4=IRQ4 For BYT_COM1 4, for BYT_COM2 3.
entry	Catalog entry under which the address of the interrupt handler is stored. For BYT driver always X_BYT_COM_INTR.

Parameter Name	Meaning
unstask	Name of the Unsolicited Task. For BYT driver always CLI_DPAT. The CLI_DPAT unsolicited task takes over the start of the CLI or the debugging tool depending on the key combination (CTRL+R or CTRL+D).
key1 key2	Key combinations to start the Unsolicited Task. 1=CTRL+A,..., 26=CTRL+Z For the task CLI_DPAT always 4 18. The key combination CTRL+D starts the debugging tool, the combination CTRL+R starts the CLI.

Description

The command `byt8250` allows the UART block parameters to be changed for the serial port.

name here is the name of the unit, *port* the port address and *baud* the baud rate of the UART block. *mode* specifies the operating mode of the UART block.

Under *irq* the hardware interrupt of the UART block is specified in decimal form. *entry* specifies the catalog entry for the address of the respective interrupt handler.

unstask is the name of the Unsolicited Task. It allows executable programs to be started via the key combinations specified with *key1 key2*.

Note

A unit set up with the command `byt8250` may not be used as a system console.

Example

```
byt8250 BYT_COMNEW 0x2F8 19200 0x1003 3 X_BYT_COM_INTR CLI_DPAT 4 18
```

After this call, the UART block with port address 0x2F8 (corresponding to BYT_COM2) is assigned to the unit BYT_COMNEW. A unit which was already assigned is then still present but can no longer access the UART block.

You can also enter this command in the system file RMOS.INI. You must precede the command with `RUN =`.

```
RUN = byt8250 BYTE_COMNEW 0x2F8 19200 0x1003 3 X_BYT_COM_INTR
CLI_DPAT 4 18
```

This automatically reconfigures the unit each time the system is booted.

B.2 CANCEL

Function Abort job

Inline command

Syntax `cancel <job number>`

Parameter Name	Meaning
job number	Job number specified at start of task. This is the number displayed by the SYSTAT command.

Description

The job specified by *job number* is aborted. Foreground jobs cannot be aborted with `CANCEL`. For special conditions after program abortion see also User Manual, Section 15.4.3.

If a batch file is executed as background job, the originally started job might be waiting for another CLI job to be completed. In this case you have two options:

- By specifying the job number of the originally started background job both jobs are automatically aborted, first the subordinate and then the original job.
- By specifying the job number of the subordinate job only this job is aborted. The original job continues executing by invoking the next command of the batch file.

The job number of the subordinate job is also displayed by the `SYSTAT` command.

Inline commands and foreground jobs cannot be aborted with `CANCEL`.

Note

`<Ctrl>+<C>` is not effective when scheduling is disabled (`RmDisableScheduler`).

Example

```
CANCEL 2
```

Aborts background job #2.

B.3 CD

Function Change from one directory to another or display the current directory
Inline command

Syntax `cd [<directory>]`

Parameter Name	Meaning
directory	Valid directory in standard notation, with or without drive specification.

Description

CD determines the current drive and directory. The directory can be defined relative to the root directory or to the current directory. The parent directory can be specified by "..". An input without parameters displays the current directory.

Every task works with its own current drive and directory which it can change with the CRUN function `chdir`. When a job is started (in the foreground or background) the current drive and directory are set to match those of the CLI session.

A change to another drive automatically causes that drive to be mounted with MOUNT.

In contrast to DOS, the CLI does not recognize a current drive but **only one** current directory (per CLI task) which contains the drive. The specification `A:` is equivalent to `A:\.`

Example

```
CD MY_DIR
CD ..\TEMP
CD \TOOLS
CD A:
CD A:\INC
```

B.4 CHGKBD

Function Change keyboard layout

Loadable command

Syntax chgkbd <type>

Parameter Name	Meaning
type	Keyboard layout specification There are six variants: KBDUSE (United States English) KBDUKE (United Kingdom English) KBDGER (German) KPDFRE (French) KBDITA (Italian) KBDSPA (Spanish)

Description

CHGKBD changes the keyboard to the layout specified with *type*.

The six optional KBDxxx.SYS keyboard layout files must be located in the same directory as the command CHGKBD.

Example

```
CHGKBD KBDGER
```

Changes to the German keyboard layout.

If you want to change automatically to the keyboard layout during system startup, you can achieve this by inserting the following entry in RMOS.INI file at arbitrary position.

```
RUN=C:\BIN\CHGKBD.386 KBDGER
```

The command CHGKBD and the keyboard layout files must be located in directory C:\BIN.

B.5 COPY

Function Copy one or more files, optionally with subdirectories

Loadable command

Syntax `copy <old file spec> [<new file spec>] [/S] [/L]`

Parameter Name	Meaning
old file spec	The file or files to be copied. The wildcards * and ? can be used to specify file names and extension.
new file spec	The directory or the file name for the new file(s). The wildcards * and ? can be used to specify file names and extension. In this case the corresponding fields of the input file specification are used.
/S	Causes the contents of any subdirectories to be copied as well. The target directories are created, if they do not exist.
/L	Causes the file names to be printed after copying.

Description

The files specified by `old file spec` are copied to `new file spec`. If `new file spec` is omitted the files are copied to the current directory.

`COPY` supports the use of device names instead of file names. This means that a file can be copied to a device, device input copied to a file, and device input copied to another device. The possible device names are entered in the resource catalog. The name `CON` can be used additionally to specify the current console.

Example

```
COPY A:\REPORT.LIS
```

Copies the file `A:\REPORT.LIS` to the current directory.

```
copy A:\*.* /S
```

Copies all files from drive `A:` to the current directory. Any subdirectories are also copied.

```
COPY TEST.* OLD_TEST.*
```

Copies all files in the current directory with the name TEST and arbitrary extension to the files with the name OLD_TEST, preserving the old extension. e.g., TEST.C is copied to OLD_TEST.C, and TEST.EXE is copied to OLD_TEST.EXE.

```
COPY CLISTART.BAT CON
```

Copies the file CLISTART.BAT to the console.

```
COPY CLISTART.BAT BYT_LPT1
```

Copies the file CLISTART.BAT to the printer port LPT1, provided BYT_LPT1 has been entered in the resource catalog as type `rio byte` (scanned with the low-level debugger command: `DIR unit long`).

```
COPY CON TEMP.BAT
```

Copies any subsequent input at the console to the file TEMP.BAT, until a CTRL-Z is detected in the input.

```
COPY CON BYT_LPT1
```

Copies any subsequent input at the console to the printer port LPT1, until a CTRL-Z is detected in the input, provided BYT_LPT1 is entered in the resource catalog as type `rio byte`.

The input characters are copied line by line.

B.6 CPRI

Function Change task priority of a CLI job

Inline command

Syntax `cpri <job number> <priority>`

Parameter Name	Meaning
Job number	Job number specified when the job was started. The number can be displayed with the <code>SYSTAT</code> command.
Priority	New task priority.

Description

The priority of the background job specified by *job number* is set to *priority*.

If a batch file is executing as background job, it can happen that the originally started job is waiting for the completion of another CLI job.

In this case only the priority of the originally started job is changed. It is possible, however, to change the priority of a subordinate job by specifying its own job number. The job number of the subordinate job can also be displayed with the `SYSTAT` command.

Example

```
CPRI 3 64
```

Sets the priority of background job numbers 3 to 64.

B.7 DATE

Function Display/modify the current date

Loadable command

Syntax `date [<date>]`

Parameter Name	Meaning
date	New date with format <day>-<month>-<year>.

Description

If `DATE` is specified without parameters, the current date is displayed and you are prompted for the input of a new date. Pressing just <Return> leaves the date unchanged.

The date input is restricted to calendar dates between 01-01-1980 and 31-12-2059.

The month can be entered as a number or as a 3-character abbreviation (in English).

The year can be entered as 2-digit or 4-digit number. 2-digit numbers in the range 80 to 99 correspond to the years 1980 to 1999. 2-digit numbers in the range 00 to 59 correspond to the years 2000 to 2059.

You can omit the year, or the month and year. The default values are then taken from the current date.

Example

```
DATE
Current date is Monday 17-FEB-1992
Enter new date (dd-mm-yy):

DATE 18-FEB-92

DATE 18-FEB

DATE 18-2-1992

DATE 19
```

B.8 DEL**Function** Delete one or more files

Loadable command

Syntax del <file spec> [/P] [/L]

Parameter Name	Meaning
file spec	The file or files to be deleted. The wildcards * and ? can be used to specify file names and extension.
/P	Prompts you to acknowledge each individual file deletion.
/L	Causes the files to be printed after being deleted.

Description

The specified files are deleted.

Example

```
DEL TEMP.*
```

Deletes all files with the name TEMP in the current directory.

```
DEL *.TMP
```

Deletes all files with the extension TMP in the current directory.

```
DEL *.TMP /P
```

Prompts you for deletion of all files with the extension TMP in the current directory. If you acknowledge the deletion the file is actually deleted.

```
DEL A:\WORK\REPORT.LIS
```

Deletes the file A:\WORK\REPORT.LIS.

B.9 DEVICE

Function Load a driver or generate a driver unit

Loadable command

Syntax Load driver:

DEVICE <path name> [<unit name> [<unit parameter>]]

Generate driver unit:

DEVICE <catalog name> <unit name> [<unit parameter>]

Parameter Name	Meaning
path name	Complete path name of the driver file, e.g. \M7RMOS32\3964.DRV
catalog name	Name under which the driver is entered in the catalog: 3964 or SER8250. The correct upper/lower case notation must be used.
unit name	User-defined name of the unit to be generated.
unit parameter	Driver-specific parameters

Driver-specific Parameters

The driver-specific parameters are required for the generation of the unit. They consist of a sequence of character strings separated by spaces. The generic form of such a string is:

```
<key word> : <par_1> - <par_2> - ... <par_n> ...
```

A string consists of a keyword followed by subsidiary parameters separated by hyphens.

Parameters for 3964 and SER8250

The driver-specific parameters for 3964 are:

```
IRQ:<irq number> BASE:<i/o base address> [MODE:<baud
rate>-<parity>-<data bit>-<stop bit>]
[PROT:<protocol>-<master/slave>]
```

The driver-specific parameters for SER 8250 are:

```
IRQ:<irq number> BASE:<i/o base address> [MODE:<baud
rate>-<parity>-<data bit>-<stop bit>] [BUFFER:<size>]
```

Parameter Name	Meaning
IRQ:<irq number>	Interrupt number of the port over which the driver is to communicate, e.g.: IRQ:4 for COM1.
BASE:<i/o base address>	I/O base address of the port over which the driver is to communicate, e.g.: BASE:0x3F8 for COM1.
MODE:<baud>-<parity>-<data>-<stop> baud parity data stop	Communication parameters. If the MODE parameter is missing, the default is MODE:19200-N-8-1. Transmission rate (e.g. 19200 bit/s) Parity bit (e.g. N for 'none', E for 'even', O for 'odd', M for 'mark', S for 'space') Number of data bits Number of stop bits
PROT:<protocol>-<master> protocol master	Protocol parameters, for 3964 driver only. If the PROT parameter is missing, the default is PROT:1-1 Protocol selection: 1 for 3964, 0 for 3964 Selection of master or slave: 1 for master, 0 for slave
BUFFER:<size>	Size of the background buffer in bytes, for SER8250 drivers only. Default: BUFFER:256.

Description

The DEVICE command must be called in the following sequence - in the RMOS.INI file or in the CLI:

1. Loading the driver using the path name of the driver file.
DEVICE <path name> [<unit name> [<unit parameter>]]
The driver is entered in the resource catalog at the time of loading. A driver unit can optionally also be generated during loading of the driver. A driver can only be loaded once.
2. Generating a unit using the catalog name of the driver.
DEVICE <catalog name> <unit name> [<unit parameter>]
Further DEVICE calls can only be used to generate units. The catalog name of the driver and the unit parameters must be specified in order to generate the units.

Only one unit can exist per hardware interface. A DEVICE call that generates a unit under a new name for an existing interface (IRQ and BASE) overwrites the old unit.

Note

The hardware parameters for the serial interfaces for M7 can be found in the sections "CPU 388-4 central processing unit" and "Interface module IF 962-COM" in the "M7-300, Hardware and Installation" manual, or in the section "Interface module IF 962-COM" in the "S7-400, M7-400 Module Specifications" manual.

Example

Load 3964 driver without generating a unit:

```
DEVICE \M7RMOS32\3964.DRV
```

Generate driver unit for 3964 on COM1:

```
DEVICE 3964 3964_COM1 IRQ:4 BASE:0x3F8 MODE:19200-N-8-1 PROT:1-1
```

Load SER8250 driver:

```
DEVICE \M7RMOS32\SER8250.DRV
```

Generate driver unit for SER8250 on COM2:

```
DEVICE SER8250 COM2 IRQ:3 BASE:0x2F8 MODE:9600-N-8-1
```

B.10 DIR**Function** List directory contents

Loadable command

Syntax dir [<filename>] [/P] [/W] [/S]

Parameter Name	Meaning
filename	The directory or the files to be listed. The wildcards * and ? can be used to specify file names.
/P	Causes the directory to be output page by page.
/W	Causes the directory to be output in five columns.
/S	Causes subdirectories to be output as well.

Description

DIR is used to list the files in a directory or in a directory tree. Normally, file names are listed with date, time and size. The switch /W causes file names only to be output. At the end of the list the total size of all listed files and the available memory space on the data medium is output. If the file name is omitted, the current directory is listed. The file specification can be an arbitrary (valid) path with or without drive specification.

Example

```
DIR
DIR *.TXT
DIR TEMP.*
DIR A:\*.*
DIR /W /S
DIR ..
```

B.11 DISMOUNT

Function Dismount volume

Inline command

Syntax `dismount <drive>: [/F]`

Parameter Name	Meaning
drive	The drive containing the volume to be dismounted.
/F	The specified drive is force-dismounted.

Description

In general the HSFS requires a volume to be dismounted before you can remove it from a drive or before you switch the system off.

Under the HSFS a volume is dismounted with the `DISMOUNT` command; this requires that there are no open files on the drive. The switch `/F` allows you to dismount a volume even if files are still open on the drive. These files are closed in proper fashion. The error message `H_NO_SUCH_CHANNEL` is returned to programs which use the corresponding channel numbers.

It is always the volume which is mounted, not the drive, even though the latter is specified as parameter.

If the drive (or a directory of the drive) is contained in the file path, the volume can be remounted by entering an appropriate command.

Example

```
DISMOUNT A:
```

B.12 ECHO

Function Switch command line display during batch file processing on or off, or issue a message

Inline command

Syntax `echo [ON | OFF | <message>]`

Description

The CLI default is ECHO OFF.

During batch file processing the CLI determines the setting, i.e., the batch file commands are not displayed. The display of batch file commands can be activated with ECHO ON and deactivated again with ECHO OFF.

The command ECHO <message> writes <message> to stdout. Text lines can be written to a file by redirecting stdout to a file.

Example

```
ECHO OFF
ECHO ON
ECHO Start of Batchfile DO_IT.BAT
ECHO Processing completed. >> work.log
```


B.13 ERROR**Function** Display error level and its meaning

Loadable command

Syntax error [<errorlevel>]

Parameter Name	Meaning
errorlevel	Status as 4-digit hexadecimal number.

Description

On completion of a CLI command or any other program the error level is set equal to the exit status of the command or program.

`ERROR` without parameters reads the current error level and outputs the number in hexadecimal format. Whenever possible the meaning of the error level is also given.

`ERROR <errorlevel>` outputs the meaning of the error level specified by the parameter.

In both cases the `ERROR` command completes with the exit status equal to the previous error level, i.e., the error level is not modified by the command.

`ERROR` assumes a 16-bit error level with the following format:

- 0 = Success
- otherwise
- High byte (Bit8..15)
 - Hex 81 : Taskloader error code
 - Hex 82 : CLI error code
 - Hex 83 : HSFS error code
- Low byte (Bit0..7)
 - Error code

Note

The high-byte value hex 83 for HSFS error codes is generated by the CLI.

Example

```
ERROR
```

B.14 EXIT

Function Terminate CLI task
 Inline command

Syntax `exit`

Description

The `EXIT` command terminates the CLI task.

Note

`EXIT` completes with the exit status `E_CLI_EXIT_STATUS` which terminates the CLI task. You can terminate the CLI task by using this exit status in your user programs.

Example

```
EXIT
```

B.15 FORMAT

Function Format diskette or hard disk

Loadable command

Syntax format <drive>: /F

Parameter Name	Meaning
drive	The drive containing the volume to be formatted.

Description

Formats a diskette and creates the root directory. A data volume can only be formatted when it is **not** mounted.

Only 1.44-Mbytes diskettes can be formatted.

The /F option allows formatting of a data medium even if the bit for format protection is set in the HSFS (See CRUN calls **changevib** and **createvib**).

Example

```
FORMAT A:
```

B.16 FTLFORM**Function** Format memory card or OSD

Loadable command

Syntax `ftlform <drive:> [/n] [/s [<file>]] [/b] [/m] [/c[<file>]] [/?/h]`

Parameter Name	Meaning
<i>drive:</i>	Drive containing the memory card to be formatted (M0 or M1).
<i>n</i>	No prompts are output during formatting..
<i>s[<file>]</i>	The system file designated by <i>file</i> is transferred to the memory card following completion of the formatting procedure.
<i>b</i>	The command executes in Batch mode.
<i>m</i>	The Master Boot Record is copied.
<i>c[<file>]</i>	The configuration file designated by <i>file</i> is loaded.
? or <i>h</i>	Output command syntax.

Description

The FTLFORM command formats the memory card in the drive designated by *drive* (M0 or M1). A Help screen to the command syntax is displayed when the ? or *h* parameter is specified.

The *n* parameter suppresses the output of prompts during formatting.

When the *s* parameter is specified, FTLFORM transfers the system file designated by *file* to the memory card upon completion of the formatting procedure. If no file is specified, file RM3_PC1.SYS in the current directory is transferred to the memory card. In addition, a boot sector is generated on the memory card in the drive designed by the *drive:* parameter, thus making it possible to use the memory card as boot medium.

When the *b* parameter is specified, the command executes in Batch mode.

The Master Boot Record is copied with the *m* parameter.

When the *c* parameter is specified, the configuration file designated by *file* is loaded. The default is file FTLFORM.CFG. The configuration file determines all further conditions for the subsequent formatting procedure.

The configuration file is divided into three sections.

[SYS_FILES] The system files are entered with their complete path specifications in this section. The maximum permissible number of files in this section is three.

[BOOT_RECORD] The name of the (binary) boot loader (512 bytes), with its complete path, is specified in this section. Following completion of the formatting procedure, the boot loader is transferred to the boot sector of the memory card.

[MASTER_BOOT_RECORD]
The name of the (binary) master boot loader, with complete path, is specified in this section.

The specifications in sections [SYS_FILES] and [BOOT_RECORD] are mandatory, as there are no default values for them.

Sections without entries are not permitted, that is, if the entry for [BOOT_RECORD] is erased, then the section identifier must also be deleted.

Comments for additional information are identified by a "#", and thus ignored during processing.

Example for a configuration file:

```
[SYS_FILES]
c:\rmos3\boot\rmos.sys

[BOOT_RECORD]
c:\rmos3\boot\rmosload

#The files contain software release V3.12.09
```

Example

```
ftlform -s M0:
```

A security prompt is displayed prior to formatting.

```
Application Identification of drive M0: is M7-DOS
Are you sure to format drive M0: ? [y/N]
```

The default is N (for No).

Enter y and confirm with Return. The memory card is then formatted and the result of the formatting procedure displayed.

```
Formatting M0: ...
M0: formatted: 829 KB useable
```

The default system file is then transferred and the memory card ID set to M7-DOS.

```
Copying system files...
    RM3_PC1.SYS
Setting application ID of drive M0: to M7-DOS
```

B.17 HELP

Function Output command overview or syntax description of individual commands

Loadable command

Syntax help [<command>]

Parameter Name	Meaning
command	CLI command for which syntax information is required.

Description

HELP without parameters outputs an overview of all CLI commands.

HELP <command> outputs a description of the specified command.

Example

```
HELP
```

```
HELP DIR
```

B.18 MD**Function** Create new directory

Loadable command

Syntax md <directory>

Parameter Name	Meaning
directory	The directory to be created in standard notation, with or without drive specification.

Description

MD creates a new directory. The directory can be specified relative to the root directory or the current directory. The parent directory can be specified by “..”.

Example

```
MD TEMP
```

Creates the directory TEMP as subdirectory of the root directory in the current drive.

```
MD \TEMP
```

Creates the directory TEMP as subdirectory of the root directory of the current directory.

```
MD ..\TEMP
```

Creates the directory TEMP as subdirectory of the parent directory of the current directory.

```
MD A:\TEMP
```

Creates the directory TEMP as subdirectory of the root directory in drive A:.

B.19 MOUNT

Function Mount a volume or display status of all drives

Inline command

Syntax mount [<drive>:]

Parameter Name	Meaning
drive	The drive containing the volume to be mounted.

Description

In general the HSFS requires a volume to be mounted before use (`MOUNT`) and dismounted after use (`DISMOUNT`). The command `MOUNT <drive>:` attempts to mount the volume in the specified drive.

`MOUNT` without parameters outputs a list of all configured drives plus their current status (`MOUNTED` or `DISMOUNTED`).

It is always the volume which is mounted, not the drive, even though the latter is specified as parameter.

A change to another drive (`cd`) causes the volume in that drive to be mounted automatically.

Example

```
MOUNT A:
```


B.20 NPX – Not for Later Versions**Function** Prefix for starting a program which uses the numeric coprocessor

Note

This command is no longer required from Version V2.0, because the system automatically detects when the numeric coprocessor must be used for a task. The command continues to be supported for compatibility reasons but is **not to be used in later versions**.

B.21 PATH**Function** Define the file path for loadable CLI commands

Inline command

Syntax `path [<directory>] [<directory>...]``path ;`

Parameter Name	Meaning
<code>directory</code>	Valid directory in the standard notation or %PATH%

Description

`PATH` defines the file path for loadable CLI commands. The file path consists of a list of directories, separated by a semicolon.

If you enter a command the CLI searches in the following order for an inline or loadable command:

- First the CLI searches for an inline command.
- Then the CLI searches for an executable file or a batch file in the current directory.
- Then the CLI searches for an executable file or a batch file sequentially in all directories.

The search is terminated with the first inline or loadable command found.

`PATH` followed by a blank and semicolon defines an empty file path.

`PATH ;` defines an empty file path.

The specification `%PATH%` corresponds to the current file path. This form can be used to extend the file path (see Example).

Note

A semicolon at the end of the file path is permitted but not necessary. All directories in the file path should be complete path names including a drive specification.

The file path and the `PATH` command have the same function as under DOS.

Example

```
PATH C:\CLI;C:\TOOLS
```

Defines a file path consisting of the two directories C:\CLI and C:\TOOLS.

```
PATH %PATH%;C:\PROJECT
```

Extends the file path by directory C:\PROJECT. If the previous path name was C:\CLI;C:\TOOLS, the new path will be C:\CLI;C:\TOOLS;C:\PROJECT.

```
PATH ;
```

Defines an empty path name.

```
PATH
```

Displays the current path name.

B.22 PING

Loadable command

Function Check if TCP/IP network host is alive**Syntax** ping <host>
ping [s] <host> [<data_size> [<count >]]

Parameter Name	Meaning
host	Name or IP address of the communication host
-s	Send datagrams
data_size	Size of the datagram package in bytes; default package size is 64 bytes.
count	Number of requests to be sent (optional)

Description

ping sends a datagram to elicit a response from the specified <host>. If <host > responds, **ping** will print

<host> is alive

on the current console (standard output) and exit. Otherwise after 5 seconds, it will output the following message:

no answer from <host>.

When the **-s** flag is specified, **ping** sends one datagram per second, and prints one line of output for every response it receives. No output is produced if there is no response. In this second form, **ping** computes round trip times and packet loss statistics; it displays a summary of this information upon termination.

When using **ping** for fault isolation, first **ping** the local host to verify that the local network interface is running.

Example

```
ping 142.120.12.320
```

B.23 PROMPT

Function Change the CLI prompt

Inline command

Syntax `prompt [[<text>][<character>]...`

Parameter Name	Meaning
text	Prompt text
\$<character>	Control character, see below

Description

This command changes the CLI prompt. The prompt is stored in the environment.

The prompt can contain control characters of the format “\$<character>” which are expanded by the CLI. Valid control characters:

\$q	= sign
\$\$	\$ sign
\$t	current time
\$d	current date
\$p	current directory including drive
\$v	current CLI version
\$g	> character
\$l	< character
\$b	character
\$_	one line feed
\$e	Escape
\$h	Backspace

If you enter the command `PROMPT` without parameters the `PROMPT` environment string is deleted. The default prompt “>” is used thereafter.

Example

```
PROMPT $P$G
```

Sets the prompt to “<current directory>>”, e.g.: `C:\MY_DIR>`

B.24 RD**Function** Delete an empty subdirectory

Loadable command

Syntax rd <directory>

Parameter Name	Meaning
directory	Directory to be removed; in standard notation, with or without drive specification.

Description

The specified directory is deleted if

- if it is empty and
- if no other task has opened it as a file.

Example

RD TEMP

Deletes the subdirectory TEMP from the current directory.

B.25 RDISK**Function** Install boot sector on hard disk

Loadable command

Syntax RDISK [RM3_PC1.SYS]

Parameter Name	Meaning
RM3_PC1.SYS	Name of the boot file. The specification is optional, but the name RM3_PC1.SYS is mandatory.

Description

RDISK installs a boot sector on the C: partition of the hard disk. The system file RM3_PC1.SYS is used as boot file.

Before calling RDISK, you must partition the hard disk with HDPART and format it with FORMAT.

Before execution starts, you are prompted to confirm whether the boot sector is to be installed, for example at the first installation:

```
Install boot sector on drive C: (y/n)?
```

or, when a boot sector is already installed:

```
Overwrite active boot sector on drive C: (y/n)?
```

In both cases the command is executed only if you confirm with *y*.

Upon completion RDISK outputs the following message or error message:

```
RMOS PC1 boot sector installed for file RM3_PC1.SYS boot
after successful installation of the boot sector.
```

```
RMOS PC1 boot sector not installed
```

in case of error or if RDISK was prematurely aborted by the user.

B.26 RENAME**Function** **Rename one or more files or directories**

Loadable command

Syntax **rename <old file spec> <new file spec> [/L]**

Parameter Name	Meaning
old file spec	The file/files or directory/directories to be renamed. The wildcards * and ? can be used in the file/directory specifications.
new file spec	The new file or directory name(s). The wildcards * and ? can be used in the file/directory specifications. In this case the corresponding fields of the input file/directory specification are used. The new file or directory name(s) may not contains a drive or directory specification.
L	Causes the new file or directory name(s) to be displayed after renaming.

Description

The file/files or directory/directories specified by <old file spec> are renamed to <new file spec>. The files or directories remain in their original directory.

Example

```
RENAME TEST.PLM TEST.C
```

Renames the file TEST.PLM to TEST.C.

```
RENAME DUMMY.DIR TEST.DIR
```

Renames the directory DUMMY.DIR to TEST.DIR.

```
RENAME TEMP.* SAVE.*
```

Renames all files and directories in the current directory with the name TEMP to SAVE. The extensions are left unchanged.

B.27 SCANDISK

Function Check and interactively repair a mass storage device

Reloadable command

Syntax `scandisk <drive>: [/F | /A] [/T]`

Parameter Name	Meaning
drive	Drive of the mass storage device to be checked.
/F	Display errors and fix them after user query
/A	Display errors and fix them automatically
/T	Terse output, no file name logging

Description

SCANDISK checks the file system consistency on the selected medium - hard disk, diskette or memory card and interactively repairs it.

SCANDISK is a CLI command for M7 RMOS32 only. Please note that under M7 RMOS32 with MS-DOS the mass storage is controlled by DOS and therefore must be checked under DOS. Generally the consistency of network file systems must be checked on the respective host system.

During its operation SCANDISK has exclusive access to the selected drive so that other programs cannot access it.

SCANDISK shows the progress of its operation and displays the errors found. If the /T option has been omitted, the names of the checked files are displayed as well. At the end a short statistics on the drive contents is displayed.

When errors are found, the following actions are available:

Option	Error handling
none	Errors are displayed without being fixed
/F	Errors are displayed and fixed according to the user query
/A	Errors are displayed and fixed automatically

Errors and Remedies

scandisk can detect the following types of errors and propose the following remedies:

Type of error	Remedy
The boot sector contains invalid values for size, File Allocation Table (FAT) length or root directory.	Abort: Probably not a DOS file system.
FAT copies differ from the first FAT.	Renew backup copies from the first FAT.
A file name contains an invalid character: [\ / . : ? *] or a control character.	Replace the invalid character with one of the following if possible [@ \$ %]. If this is not possible, assign the file a check file *) name.
Cross links (clusters used more than once).	Copy the cluster chain starting with the multiple used cluster and integrate it into the file.
A cluster chain contains entries that exceed the size of the medium.	Place the end of file behind the last valid cluster and adjust the file length.
A file of length 0 contains a valid start cluster.	Set file length to the value resulting from the cluster chain.
A file of length $\neq 0$ contains an invalid start cluster	Set file length to 0.
The file length exceeds the amount of chained clusters.	Adjust the file length to the size of the chained clusters.
The file length is smaller than the amount of chained clusters.	Adjust the file length to include the complete last cluster.
The file's cluster chain points to own clusters (recursive clusters).	Place the end of file behind the last valid cluster and adjust the file length.
The file's cluster chain points to an unused cluster.	Integrate the new cluster into chain and adjust the file length accordingly.
The directory attribute is set, but the file length doesn't fit and the first characters are not "." or "..".	Convert to file.
Lost files: There are clusters in use that are assigned to no file.	Store contiguous clusters as check files *) in the root directory \.
*) a check file is named "FILExxxx.CHK" with xxxx a continuously incremented numeral.	

Example

```
scandisk A: /A
```

Checks the file system on diskette drive A: and fixes errors automatically.

B.28 SESSION**Function** Start a foreground task at another terminal

Inline command

Syntax `session <device> <unit> <command>`

Parameter Name	Meaning
device	Device driver number of the terminal driver (usually the BYT driver).
unit	Device unit number of the terminal to be used.
command	CLI command to be executed as foreground task.

Description

`SESSION` starts a foreground job without waiting for its completion. A foreground task differs from a background job in that the use of a terminal is involved. `<command>` can be any loadable CLI command or program. If some parameters are omitted when the `SESSION` command is invoked, these parameters are prompted for interactively.

You can also use the pseudo command `CLI` as `<command>` which starts the CLI task, i.e., a new CLI session.

The C streams `stdin`, `stdout` and `stderr` for the started foreground job are directed to the specified terminal.

Example

```
SESSION 0 1 HSFSTEST
```

Starts the program `HSFSTEST` (not part of the CLI) as an interactive program on device 0 unit 1.

```
SESSION 0 1 CLI
```

Starts an interactive CLI session on device 1 unit 0.

```
SESSION 0 1 CLI C:\CLI\CLISTART.BAT
```

Starts an interactive CLI session on device 1 unit 0. The file `CLISTART.BAT` is executed when the CLI task is invoked.

B.29 SET**Function** Define an environment string

Inline command

Syntax set [<string_1>=<string_2>]**Description**

This command defines an environment string with the CRUN function `putenv`. If `<String_2>` is omitted, `<String_1>` is removed from the environment.

If the command `SET` is entered without parameters all current environment strings are displayed.

Note

A separate environment is maintained for each task managed by the CRUN. You can use environment string in CLI commands by enclosing the names in % signs, e.g., `%TEMPDIR%`. You can access environment strings in programs by using the ANSI C function `getenv` which is supported by the CRUN.

Example

```
SET TEMPDIR=C:\TEMP
```

Sets the environment string `TEMPDIR` equal to `C:\TEMP`.

```
SET TEMPDIR=
```

Removes the environment string `TEMPDIR` from the environment.

```
SET
```

Lists all current environment strings.

B.30 START**Function** Start a background job

Inline command

Syntax start [/N] [/P=nn] <command>

Parameter Name	Meaning
N	Specifies that a numeric coprocessor is used.
P=nn	Specifies the task priority between 0 and 255.
command	Valid loadable CLI command, program or a batch file.

Description

START starts a background job. `stdin`, `stdout` and `stderr` can be redirected with the characters “<” and “>” which apply to both the **START** command and the started background job. If not specified explicitly, `stdin`, `stdout` and `stderr` are set to the NUL file. If the priority is omitted, the background job’s priority is set equal to priority of the CLI session minus 1.

The background job is assigned a job number which can be used in **CANCEL** and **CPRI** commands. If <command> is a batch file, a new CLI task is started as background job which executes the batch file.

By definition, a background job does not have a console. If you require a job which outputs data to a console, you must use the **SESSION** command which starts a job without waiting for its completion.

The foreground job continues executing immediately the background job is started. If an error occurs during construction of the background job’s program environment, it can happen that the background job terminates itself without issuing a message. This can happen, e.g., when `stdout` is redirected to a file which can neither be opened nor created.

Example

```
START /P=10 COPY A:\*.* C:\
```

B.31 SYSTAT

Function Display active CLI jobs

Inline command

Syntax `systat`

Description

Active CLI jobs are displayed in the following format:

Tsk	Pjob	Job	Pri	Command	stdout	Start time
1Eh		0	64	CLI C:\CLISTART.BAT	Device=0 Unit=0	31-MAY-1992 09:14:06
1Eh	0	3	64	systat	Device=0 Unit=0	31-MAY-1992 09:29:38
22h		1	64	CLI C:\CLISTART.BAT	Device=0 Unit=1	31-MAY-1992 09:14:12
26h	1	2	64	dir c: /s	Device=0 Unit=1	31-MAY-1992 09:29:37

The columns have the following meaning:

Tsk	Task ID (assigned at task start)
Pjob	Number of the parent job
Job	Job number
Pri	Job priority
Command	Command or the task itself
stdout	The job's output unit/file
Start time	Date and time when the job was started

Inline commands, loadable commands, CLI sessions and all tasks started from the CLI are listed. The CLI session is executed by the pseudo command `CLI <batchfile>`.

Example

```
SYSTAT
```

B.32 TIME**Function** Display/modify the current time

Loadable command

Syntax time [<time>]

Parameter Name	Meaning
time	New time in the format <hours>:<minutes>:<seconds>.

Description

If `TIME` is entered without parameters, the current time is displayed and the commands waits for you enter a new time. By pressing <RETURN> the time is left unchanged. In your input you can omit seconds, or minutes and seconds. The default values are both 0.

Example

```
TIME
Current time 16:21:03
Enter new time:
TIME 16:41
```

B.33 VER**Function** Output M7 RMOS32 system information

Inline command

Syntax `ver [/v /d]`

Parameter Name	Meaning
/v	Output additional information
/d	Output debug information

Description

This command initiates the output of system information in the following form:

The current version is output unless the relevant parameters are entered:

```
RMOS3 Version 4.00.00
```

Parameter /v can be used to provide further information on the system. The information is output in the following sequence:

```
RMOS3 Version 4.00.00
running the file C:\RM3_PC1.SYS on a Pentium processor, FPU present
```

The parameter /d can be used to provide more detailed debug information. The information is output in the following sequence:

```
RMOS3 Version 4.00.00
running the file C:\RM3_PC1.SYS on a Pentium processor, FPU present
flat code selector is 0x60, flat data selector is 0x64
system rate is 10 msec
46 SMRs of 80 are available (SMR out of bound reached 0 times)
there are 2 interrupt controllers available
PIC Nr.      Base      Mask
1           0x60     0x20
2           0x70     0x00
```


B.34 CLI Error Messages

The following error codes are used as exit status by all CLI commands.

The meaning of the error codes can be displayed with the CLI ERROR command. These values are defined in the file CLI.H.

Error Number	Error Message	Meaning
0	E_CLI_OK	No error
0x8201	E_CLI_NOT_RESIDENT	Not a resident task
0x8202	E_CLI_FILE_FORMAT	Illegal file format
0x8203	E_CLI_DYNAMIC_MEM	Insufficient dynamic memory
0x8204	E_CLI_INTERNAL_ERROR	Internal error
0x8205	E_CLI_LTT_FULL	Loaded Task Table (LTT) full
0x8206	E_CLI_CJT_FULL	CLI job table (CJT) full
0x8207	E_CLI_CREATE_ERROR	Create task error
0x8208	E_CLI_START_ERROR	Start task error
0x8209	E_CLI_DELSK_ERROR	Delete task error
0x820A	E_CLI_LT_ACTIVE	The specified loaded task is active
0x820B	E_CLI_JOB_ACTIVE	The specified CLI job is active
0x820C	E_CLI_FILE_NOT_FOUND	File not found
0x820D	E_CLI_NOT_A_CLI_JOB	Task is not a CLI job
0x820E	E_CLI_NOT_A_CRUN_JOB	Task is not a CRUN task
0x820F	E_CLI_NOT_INLINE	Not an inline command
0x8210	E_CLI_SYNTAX_ERROR	Syntax error
0x8211	E_CLI_ENVIRONMENT_FULL	No memory for a new environment available
0x8212	E_CLI_NO_COMMAND	Command not available
0x8213	E_CLI_EOF	End of file
0x8214	E_CLI_EXIT_STATUS	Exit status (returned by EXIT command)
0x8215	E_CLI_CATALOG_FULL	RMOS catalog full
0x8216	E_CLI_CREATESEMA_ERROR	Create semaphore error
0x8217	E_CLI_REDIR_STDIN_FAIL	Error redirecting stdin
0x8218	E_CLI_REDIR_STDOUT_FAIL	Error redirecting stdout
0x8219	E_CLI_REDIR_STDERR_FAIL	Error redirecting stderr
0x821A	E_CLI_UNKNOWN_SWITCH	Unknown switch
0x821B	E_CLI_TOO_MANY_PARAMS	Too many parameters
0x821C	E_CLI_INVALID_FILENAME	Invalid filename
0x821D	E_CLI_INVALID_LT_INDEX	Invalid loaded task index
0x821E	E_CLI_INVALID_JOB_INDEX	Invalid CLI job index

Error Number	Error Message	Meaning
0x821F	E_CLI_TOO_FEW_PARAMS	Too few parameters
0x8220	E_CLI_FILE_READ_ERROR	File read error
0x8221	E_CLI_FILE_WRITE_ERROR	File write error
0x8222	E_CLI_COPY_TO_SELF	Attempt to copy a file to itself
0x8223	E_CLI_UNEXPECTED_EOF	Unexpected end of file
0x8224	E_CLI_PERMANENT_TASK	CLI permanent task
0x8225	E_CLI_NO_PROMPT	Missing prompt definition
0x8226	E_CLI_JOB_ABORTED	The job has been aborted
0x8227	E_CLI_NOT_A_DEVICE	Not a device name
0x8228	E_CLI_MKDIR_FAIL	Make directory error
0x8229	E_CLI_BATCH_FILE	This is a batch file
0x822A	E_CLI_NOT_MOUNTED	Volume not mounted
0x822B	E_CLI_INVALID_WILDCARD	Invalid use of wildcards
0x822C	E_CLI_NOT_A_DIRECTORY	Not a directory
0x822D	E_CLI_DIR_OPEN_FAIL	Directory open error
0x822E	E_CLI_FILE_OPEN_FAIL	File open error
0x822F	E_CLI_FILE_CLOSE_FAIL	File close error
0x8230	E_CLI_SVC_ERROR	SVC error
0x8231	E_CLI_DEV_READ_ERROR	Device read error
0x8232	E_CLI_DEV_WRITE_ERROR	Device write error
0x8233	E_CLI_IS_A_DIRECTORY	The file is a directory
0x8234	E_CLI_INLINE	Inline CLI command
0x8235	E_CLI_COMPLETED	CLI job is completed
0x8236	E_CLI_UNINITIALISED	CLI job is uninitialized
0x8237	E_CLI_OUT_OF_RANGE	Index out of range
0x8238	E_CLI_NO_SPACE_FOR_NPX	No space for NPX context when creating task
0x8239	E_CLI_NO_PARENT_JOB	No parent job
0x823A	E_CLI_INVALID_VOL_NAME	Invalid volume name
0x823B	E_CLI_MOUNTED	Volume is mounted
0x823C	E_CLI_INVALID_DATE_TIME	Invalid date or time format
0x823D	E_CLI_READ_ONLY	File is write-protected

Return Values of Task Loader

The table below shows the values returned by the `stl_load` and `stl_free` task loader functions and what these values mean. These errors may be flagged while tasks are being loaded by the CLI.

Return Number	Error Message	Meaning
0H	<code>E_LD_OK</code>	Load successful.
8100H	<code>E_LD_NO_REG_INIT</code>	Initial register values are not available (i.e. no initial address). The program was still loaded.
8101H	<code>E_LD_NO_FIXUPS</code>	An STL or PE module without relocation information has been loaded. In the case of the STL module, the relocation information items of BND386 are generated by means of the RCONFIGURE option. It is not necessarily available in an STL module since it is not normally required by other operating systems. This information might not be necessary for RMOS either, for example, if a program consists of one segment only.
8110H	<code>E_LD_FILE_OPEN_FAIL</code>	The program file could not be opened. Probably it does not exist.
8111H	<code>E_LD_FILE_FORMAT</code>	The file format is not known. The format can be identified as follows by means of the first byte or word in the file: STL: 1. word = 0206H PE: 1. 16-bit-word = "M2" 1. 32-bit word of NEW EXE header = 00004550H, Magic number of optional header == 0413
8112H	<code>E_LD_UNEXPECTED_EOF</code>	Insufficient or no bytes at all were transferred during a read access to the file.
8113H	<code>E_LD_DYNAMIC_MEMORY</code>	Insufficient or no memory at all could be allocated.
8114H	<code>E_LD_ABSOLUTE</code>	The module contains one or more segments assigned to fixed addresses, or it is a PE system file.
8115H	<code>E_LD_DALOC</code>	An error occurred when calling <code>stl_free</code> . The loader result segment was overwritten.
8116H	<code>E_LD_NULL_POINTER</code>	<code>stl_free</code> was called up with a pointer to the loader result segment, which has the value zero.
8117H	<code>E_LD_OVERLAY</code>	The module includes an overlay description.
8118H	<code>E_LD_INVALID_TASK_OR_DRIVER</code>	Not a RMOS application/driver The program is not an M7 RMOS32 application.
8130H	<code>E_LD_PROCESSOR_TYPE</code>	The processor type specified in the module header is neither 80386, 80486 nor Pentium.

Return Number	Error Message	Meaning
8131H	E_LD_NON_EXECUTABLE	The module is not assigned the attribute "executable" as specified in the module header. This means that undefined symbols appeared during linking. In the case of the PE format, this may also mean that the program is unrelated and that an attempt to load a library image has been made.
8132H	E_LD_MULTI_LDT	The module contains several local descriptor tables (LDTs)
8133H	E_LD_GATES_PRESENT	The DESCRP record contains gate descriptors.
8134H	E_LD_NO_STACK_DESC	No stack segment is defined.
8135H	E_LD_NULL_SEG_FIXUP	The module includes a fixup to a target segment whose selector does not correspond to any code or data segment.
8136H	E_LD_BAD_SEG_FIXUP	The module contains a fixup to a target segment the selector of which is invalid.
8137H	E_LD_ACCESS_RIGHTS	An error occurred when calling <code>RmChangeDescriptorAccess</code>
8138H	E_LD_ITERATE	An "iterated data segment" has the attribute iBSS.
8140H	E_LD_FIXUP_FORMAT	The format of a fixup is either illegal or not supported.
8141H	E_LD_USE16	A segment has the USE16 attribute. RMOS3 supports segments with the attribute USE32 only.
8150H	E_LD_SEEK	The file position could not be set as required.
8151H	E_LD_DLL	The file is a dynamic link library.
8152H	E_LD_INVALID_DESCRIPTOR	An error occurred when converting a segment address to a physical address.
8153H	E_LD_TOO_MANY_OBJECTS	Too many objects
8158H	E_LD_OUT_OF_SEMAPHORES	Couldn't create a semaphore The STL_SEMA semaphore required for the task loader could not be created.
8159H	E_LD_CATALOG_EXCEEDED	Couldn't catalog semaphore The STL_SEMA semaphore required for the task loader could not be cataloged

Debugger Commands

C

Chapter Overview

This chapter lists the low-level debugger commands in alphabetical order.

Section	Contents	Page
C.1	Syntax of the debugger commands	C-3
C.2	ASM	C-7
C.3	BASE	C-9
C.4	BREAKS	C-10
C.5	CALCULATE	C-11
C.6	CALL	C-12
C.7	CHANGE	C-13
C.8	CONT	C-14
C.9	CPUREG	C-15
C.10	DIR	C-16
C.11	DISPLAY	C-19
C.12	EVALUATE	C-20
C.13	EXIT	C-21
C.14	EXITK	C-22
C.15	FILL	C-23
C.16	FREETASK	C-24
C.17	GO	C-25
C.18	HALT	C-26
C.19	HELP	C-27
C.20	IN	C-28
C.21	INHIB	C-29
C.22	KILL	C-30
C.23	LINES	C-31
C.24	LOADTASK	C-32
C.25	MONITOR	C-34
C.26	OUT	C-35
C.27	QUALIFY	C-36

Section	Contents	Page
C.28	QUERY	C-37
C.29	REGS	C-39
C.30	REPORT	C-41
C.31	SET	C-47
C.32	STACK	C-49
C.33	START	C-50
C.34	STEP	C-51
C.35	SVC	C-52
C.36	SWITCH	C-54
C.37	TASK	C-55
C.38	TCB	C-56
C.39	TCD	C-57
C.40	Error messages from the debugger	C-58

C.1 Debugger Syntax Rules

The general format of a Debugger command:

```
[<repetitionfactor><empty>]<Command>[;[<repetition
factor><empty><Command>]...<return>
```

where

```
<Command> = <Command word><DEL><Arg1><DEL><Arg2> . . . <Return>
```

If urgently required arguments are omitted, the debugger prompts for their input in a new line and indicates in the prompt the type of arguments expected.

This section lists frequently occurring arguments in the command input.

Address

```
<address>    {<selector>:<offset>|<abs_addr>{L|P}}
```

```
<selector>  Selector which references a descriptor in the current GDT or LDT
<selector> can be <expr>
```

```
<offset>    32-bit value, <offset> can be <expr>
```

```
<abs_addr>  is an absolute 32-bit address
```

```
L/P        Keyword for linear/physical address (currently only linear address,
even if P specified)
```

```
<expr>     (see below)
```

For specifying a selector segment registers can be used. The task register name are available only in breakpoint context. A selector must always refer to a valid segment descriptor (ER/RW). If this is not the case, the error message

```
WRONG_SELECTOR
```

is issued. The input of a selector is assumed as default for the following commands, if only an offset value is specified for the address.

A cataloged address can also be entered within inverted commas if it has been entered in the catalog as a MISC or SYSTEM type.

```
ID=selector (if = 0, then IDE = linear address)
```

```
IDE=offset
```

This applies for the commands ASM, CALL, CHANG, DISPL, FILL and SET and not for: CALC, EVAL, GO and START.

Expression <expr>

An expression specified by <expr> can consist of: constants, register contents, memory contents, input ports, and combinations with arithmetic and logical operators.

<expr>	[[{- ~}] <term> [[{+ - ^ ' & << >>} <term>]...]
<term>	<factor>[[{* / %}<factor>]...]
<factor>	{<ident> <const> (<expr>)}
<ident>	{<cpureg> <memory> <port>}
<cpureg>	{CS DS ES SS FS GS EIP EAX EBX ECX EDX EDI ESI ESP EBP EFL CR0 IP AX BX CX DX DI SI BP FL AL AH BL BH CL CH DL DH GDTR LDTR IDTR TR CR0 CR2 CR4 ¹⁾ DR0 DR1 DR2 DR3 DR6 DR7 TR1 ²⁾ TR2 ²⁾ TR3 ¹⁾ TR4 ¹⁾ TR5 ¹⁾ TR6 TR7 TR9 ²⁾ TR10 ²⁾ TR11 ²⁾ TR12 ²⁾ }
	1) only 486 processor with CUID and above
	2) only Pentium processor and above
<memory>	{BYTE WORD DWORD POI SPOI}'['<address>'] <port> {INB INW IND} '['<port_address>']
<port_address>	<expr>
~	NOT
-	Negation
+ - * /	Basic arithmetic operations
%	Remainder after integer division
^	XOR
	OR
&	AND
<<	Left shift
>>	Right shift

Constant (const)

Constants can be entered as hexadecimal, decimal or octal numbers, but also in ASCII notation. Constants are differentiated by their memory format:

Byte, Word, Dword, Qword

Delimiter (DEL)

The following characters are valid delimiters:

Blank ()

Comma (,)

Equals sign (=)

More than one delimiter may be placed between consecutive arguments.

Format

<format> {[<memory_format>][<display_format>][data_type]}

<memory_format> {byte|word|dword|qword}

selects the element length of a specified memory area

byte 1 byte

word 2 bytes

dword 4 bytes

qword 8 bytes

<display_format> {Mask|Octal|Hex|Unsigned|Signed|Ascii}

selects the display format at the console

Mask Display as bit pattern: xxxx xxxx

Octal Display as octal number

Unsigned Display as unsigned decimal number

Signed Display as signed decimal number

Hex Display as hexadecimal number

Ascii Display as character string (1 byte per character)

<data_type> {Short|Long|Float|Double|Tempreal|Pointer|Spointer}

contains memory_format + display_format

Short Signed word

Long Signed dword

Pointer (Long Pointer) 16-bit selector:32-bit segment

Spointer (Short Pointer) 16-bit selector:16-bit segment

Float 4-byte real number

Double 8-byte real number

Tempreal 10-byte real number

Task ID

<task_id> <expr>

Valid values for <task_id> are 0..2047 plus 0FFFFH.

A cataloged address can also be entered within inverted commas (everywhere with the exception of quality and report task).

Breakpoints

For setting breakpoints you have to differentiate between hard breakpoints, soft breakpoints and Debugregister breakpoints. Hard and soft breakpoints replace the opcode by an INT3 instruction and can be used only if the program code is located in RAM. Soft breakpoints are temporary, ie, they are automatically deleted after processing. In contrast, hard breakpoints remain until they are deleted with `KILL`.

Debugregister breakpoints are available for 80386/80486 and Pentium processors where they can be used as breakpoints for memory read and write operations. The processors also support testing with execution breakpoints for program code which is located in EPROM.

<breakpoint>{ \$|@|E|{M|W}{B|W|D}}1...0F

\$ Set soft breakpoint

@ Set hard breakpoint

Breakpoint in debugregister:

E Execution Breakpoint in Debugregister

MB Modify (Read or Write) Byte Breakpoint

MW Modify (Read or Write) Word Breakpoint

MD Modify (Read or Write) Dword Breakpoint

WB Write Byte Breakpoint

WW Write Word Breakpoint

WD Write Dword Breakpoint

C.2 ASM

Function Disassemble memory contents

Syntax ASM <address> [{LEN <expr> | TO <expr>}]

Description

ASM disassembles memory from <address>, with the contents interpreted as 8086/80186/80286/80386/80486, Pentium or 8087/80287/80387 code.

If the keyword TO is entered, <expr> indicates the offset value for the end of the disassembled memory area. LEN <expr> specifies the number of instruction sequences directly. Without a length specification 10 lines are displayed.

The console output can be halted or terminated via the keyboard (<Ctrl>+S, <Ctrl>+Q, <Ctrl>+C).

Note

Note regarding 80386/80486 Protected Mode:

If <address> is specified by a selector, the associated descriptor must be of type code segment. The default bit in the code segment descriptor determines the disassembling mode (USE32/USE16) and thus the meaning of the operand and address prefixes. If a linear/physical address is specified, disassembly always follows USE 32 conventions. Output of the instruction addresses depends on the address specification on command entry, either as linear address or as selector:offset. In **breakpoint context** the code area following the breakpoint can be disassembled by specifying address CS:EPI.

Example

Disassemble the first 20 instructions of task with ID=2. The code start is available from the TCD block.

```

DEBUG_T>TCD 2<CR>
Task entry point: 005C:00008A5F, TCD address= 0074:000406B,
DS = 0000, ES = 0000, Stack base = 0084:00002308

DEBUG_T>ASM 5C:8A5F LEN 20<CR>
005C:00008A5F  A0D2010000      MOV     AL,BYTE PTR  [01D2]
005C:00008A64  08C0             OR      AL,AL
005C:00008A66  0F844B020000    JZ      08CB7       ; (= $+0251)
005C:00008A6C  3C12             CMP     AL,12
005C:00008A6E  750C             JNZ     08A7C       ; (= $+0E)
005C:00008A70  C605D003000001  MOV     BYTE PTR [03D0],01
005C:00008A77  E9BF000000      JMP     08B3B       ; (= $+0C5)
005C:00008A7C  0FB605D2010000  MOVZX  EAX,BYTE PTR [01D2]
005C:00008A83  6BC80F          IMUL   ECX,EAX,0F
005C:00008A86  0FB799AC020000  MOVZX  EBX,WORD PTR [ECX+02AC]
005C:00008A8D  81FBFFFF0000    CMP     EBX,0FFFF
005C:00008A93  7409             JZ      08A9E       ; (= $+0B)
005C:00008A95  663B1DD6010000  CMP     BX,WORD PTR [01D6]
005C:00008A9C  752D             JNZ     08ACB       ; (= $+2F)
005C:00008A9E  0FB605D2010000  MOVZX  EAX,BYTE PTR [01D2]
005C:00008AA5  6BD00F          IMUL   EDX,EAX,0F
005C:00008AA8  8A9AA3020000    MOV     BL,BYTE PTR [EDX+02A3]
005C:00008AAE  3A1DD4010000    CMP     BL,BYTE PTR [01D4]
005C:00008AB4  7515             JNZ     08ACB       ; (= $+17)
005C:00008AB6  668B9AAE020000  MOV     BX,WORD PTR [EDX+02AE]
005C:00008ABD  664B             DEC     BX
005C:00008ABF  66899AAE020000  MOV     WORD PTR [EDX+02AE],BX
005C:00008AC6  6609DB          OR      BX,BX
005C:00008AC9  742D             JZ      08AF8       ; (= $+2F)
005C:00008ACB  C6050402000019  MOV     BYTE PTR [0204],19
005C:00008AD2  C6050502000004  MOV     BYTE PTR [0205],04
005C:00008AD9  66A1D6010000    MOV     AX,WORD PTR [01D6]
005C:00008ADF  66A306020000    MOV     WORD PTR [0206],AX
005C:00008AE5  B804020000      MOV     EAX,0204
005C:00008AEA  1E              PUSH   DS
005C:00008AEB  50              PUSH   EAX
005C:00008AEC  E887C40000      CALL  014F78       ; (= $+0C48D)

```

C.3 BASE

Function Select number base

Syntax BASE [{10|16}]

Description

BASE without parameter specification displays the currently selected number base. BASE=10 selects decimal number interpretation, BASE=16 hexadecimal number interpretation. The format set with BASE can be overridden with the following prefixes for individual number inputs:

0x	hexadecimal
0n	decimal
0o	octal
0m	dual
"	ASCII

C.4 BREAKS

Function List breakpoint(s)

Syntax BREAKS

Description

BREAKS lists all currently set breakpoints along with the associated addresses. The addresses are displayed in the standard format segment:offset, selector:offset, or linear address (see SET command). Output is hexadecimal.

Example

see QUALIFY

C.5 CALCULATE

Function Calculate floating-point expression

Syntax CALCULATE <real_expr>

```

<real_expr>  [-] <term> [[{+|-} <term>]...]
<term>      <factor> [[{*|/} <factor>]...]
<factor>    {<ident>|<const>|(<expr>)}
<ident>     {<32bitreg>|<Speicher>}
<32bitreg>  {EAX|EBX|ECX|EDX|EDI|ESI|ESP|EBP}
<Speicher>  {Float|Double|Tempreal} '['<address>']'

-           Negation
+ - * /     Basic arithmetic operation

```

Syntax for the input of floating-point numbers:

```

<real_const>
[ {+|-} ] <digit> [ '.' [ [ <digit> ] ... ] [ E [ {+|-} ] [ [ <digit> ] ... ] ] ]
<digit>    { 0|1|2|3|4|5|6|7|8|9 } (Nuc1/2:18.7.9.2)

```

Description

The specified expression is evaluated and the result displayed at the console. Calculation is always in longreal format. The exponent can only be specified as E. The format decides which output form is used: E, D, T (Float, Double, Tempreal).

Example

```

DEBUG_T>CALC 3.141592654E+5 * 2.718281828E-3
              +8.53973422234649D+002

```

C.6 CALL

Function Execute program

Syntax CALL <address> [<stacksize>][<datasize>][NPX]

<stacksize> = <expr.> Length of stack segment in bytes, 64 KBytes max, default 400

<datasize> = <expr.> Length of data segment in bytes, 64 Kbytes, default value 100 bytes

Description

This executes an user program which was previously loaded into memory.

The Debugger creates and starts a task which makes a call (FARÿCall) to the specified address (start parameter). The task is entered in the resource catalog with the string "CALL_XXXX" (XXXX=task ID). In the case of a linear/physical address specification a descriptor is generated (ER,USE32). The Debugger does not wait for task completion so that several tasks can be started in parallel.

On completion of the user program, the resource entry is deleted and the SVC `delete` is issued. The task is then deleted. For the data segment and the stack segment a standard memory area as defined above is allocated. The DS, ES and SS register in the TCD are initialized accordingly.

Note

This command is available in task mode only.

C.7 CHANGE

Function Test/modify memory bytes

Syntax CHANGE [<format>] <address> [<expr>[,<expr>]...]

Description

The memory area from address <address> is overwritten with the new values <expr>. As many elements are overwritten as values are entered. If the list of values is omitted, Debugger displays the contents of <address> in the selected format; the contents can then be modified by entering a new value. After you enter <CR> the command continues with the next address. By entering an invalid character, eg, 'Q', you can terminate the command.

A string entry enclosed by apostrophes is interpreted as input value and each character is written as a byte, independent of the selected memory format.

Memory contents are modified without read-after-write control.

CHANGE is terminated by entering q.

Example

Enter the text string ABCDEF starting at address 1A4:4E30.

```
DEBUG_T>CHANGE WORD 1A4:4E30 4241 4443 4645 <CR>
DEBUG_T>
```

C.8 CONT

Function Continue Halted Task

Syntax CONT <task_id>

Description

CONT releases the task identified by <task_id> from the WAITING state. This command can only be issued, if the task was either halted by the Debugger, or halted at a breakpoint set by the Debugger and flagged accordingly (status 26 and status 2A respectively).

Note

This command is available in task mode only.

Example

```
DEBUG_T>CONT 3 <CR>
DEBUG_T>
```

C.9 CPUREG

Function Test/modify register contents

Syntax <cpureg>[<expr>]

<cpureg> {CS|DS|ES|SS|FS|GS|EIP|EAX|EBX|ECX|EDX|EDI|ESI|
ESP|EBP|EFL|CR0|IP|AX|BX|CX|DX|DI|SI|BP|FL|AL|AH|
BL|BH|CL|CH|DL|DH}

Description

Breakpoint context only:

The contents of <cpureg> are displayed and can be modified, as required, by entering a new value. The register value is left unchanged, if just <CR> is entered.

Example

see REGS

C.10 DIR

Function List directory entries

Syntax DIR [<SYM_NAM>] [LONG]

Description

DIR lists on the console all CATALOG entries designated <SYM_NAM>. The entries are output in abbreviated form, unless the full output is requested with [LONG].

If the parameter is omitted, all directory entries are listed.

Valid parameters:

Resource type	Value	Symbolic name
Task	00H	TASK
Device driver	01H	DRIV
Memory pool	02H	POOL
Semaphore	03H	SEMA
Global event flag	04H	FLAG
Controlled access	05H	CTRL
Local mailbox	06H	LMBX
Reserved	07H	MISC
User-defined	08H	USER
Discrete I/O byte	09H	DSCT
Device unit	0AH	UNIT
Message queue	0BH	MSGQ

Note

This command is available in task mode only.

The symbolic names for the resources may not be abbreviated.

Example

Output of resource entries

```
>dir
Cataloged resources
Symbolic-name  kind  id          Symbolic-name  kind  id
BU_COUNT      TASK  001CH      BYT            DRIV  0000H
BYT_COM1      UNIT  0004H      BYT_COM2      UNIT  0005H
BYT_EGA_0     UNIT  0000H      BYT_EGA_1     UNIT  0001H
BYT_EGA_2     UNIT  0002H      BYT_EGA_3     UNIT  0003H
CLI_CLEAN_UP  TASK  001AH      CLI_DPAT      TASK  0000H
CLI_JOB_0     TASK  0020H      CLI_MANAGER   SEMA  000BH
CRUN          MISC  007DH      CRUN_GEN      SEMA  000DH
CRUN_HANDLE   SEMA  000EH      CRUN_ID       SEMA  000CH
DEB_0         TASK  0002H      DEB_1         TASK  0003H
DEB_2         TASK  0004H      DEB_3         TASK  0005H
ERRLOG        TASK  0006H      FD0           DRIV  0001H
FD0_0         UNIT  0000H      HD0           DRIV  0002H
HD0_0         UNIT  0000H      HSF_GLOB     SEMA  000AH
HSF_A         TASK  0008H      HSF_C         TASK  001EH
REMOTE        TASK  0007H      REP           TASK  0001H
RMOSCONF      TASK  0009H      SYSCON       UNIT  0000H

>dir task
Cataloged resources
Symbolic-name  kind  id          Symbolic-name  kind  id
BU_COUNT      TASK  001CH      CLI_CLEAN_UP  TASK  001AH
CLI_DPAT      TASK  0000H      CLI_JOB_0     TASK  0020H
DEB_0         TASK  0002H      DEB_1         TASK  0003H
DEB_2         TASK  0004H      DEB_3         TASK  0005H
ERRLOG        TASK  0006H      HSF_A         TASK  0008H
HSF_C         TASK  001EH      REMOTE        TASK  0007H
REP           TASK  0001H      RMOSCONF      TASK  0009H

>dir long
Cataloged resources
Symbolic-name  kind  id          ide
BU_COUNT      TASK  001CH      FFFFFFFFH
BYT           DRIV  0000H      FFFFFFFFH
BYT_COM1      UNIT  0004H      00010000H  device-id: 00 type: RIO byte
BYT_COM2      UNIT  0005H      00010000H  device-id: 00 type: RIO byte
BYT_EGA_0     UNIT  0000H      00010000H  device-id: 00 type: RIO byte
BYT_EGA_1     UNIT  0001H      00010000H  device-id: 00 type: RIO byte
BYT_EGA_2     UNIT  0002H      00010000H  device-id: 00 type: RIO byte
BYT_EGA_3     UNIT  0003H      00010000H  device-id: 00 type: RIO byte
CLI_CLEAN_UP  TASK  001AH      FFFFFFFFH
CLI_DPAT      TASK  0000H      FFFFFFFFH
CLI_JOB_0     TASK  0020H      FFFFFFFFH
CLI_MANAGER   SEMA  000BH      FFFFFFFFH
CRUN          MISC  007DH      FFFFFFFFH
CRUN_GEN      SEMA  000DH      FFFFFFFFH
CRUN_HANDLE   SEMA  000EH      FFFFFFFFH
```

```

CRUN_ID      SEMA    000CH    FFFFFFFFH
DEB_0       TASK    0002H    FFFFFFFFH
DEB_1       TASK    0003H    FFFFFFFFH
DEB_2       TASK    0004H    FFFFFFFFH
DEB_3       TASK    0005H    FFFFFFFFH
ERRLOG      TASK    0006H    FFFFFFFFH
FD0         DRIV    0001H    FFFFFFFFH
FD0_0       UNIT    0000H    00020001H    device-id: 01 type: RIO block
HD0         DRIV    0002H    FFFFFFFFH
HD0_0       UNIT    0000H    00020002H    device-id: 02 type: RIO block
HSFS_GLOB   SEMA    000AH    FFFFFFFFH
HSF_A       TASK    0008H    FFFFFFFFH
HSF_C       TASK    001EH    FFFFFFFFH
REMOTE      TASK    0007H    FFFFFFFFH
REP         TASK    0001H    FFFFFFFFH
RMOSCONF    TASK    0009H    FFFFFFFFH
SYSCON      UNIT    0000H    00010000H    device-id: 00 type: RIO byte

```

>dir unit long

Cataloged resources

```

Symbolic-name  kind  id      ide
BYT_COM1       UNIT  0004H   00010000H    device-id: 00 type: RIO byte
BYT_COM2       UNIT  0005H   00010000H    device-id: 00 type: RIO byte
BYT_EGA_0      UNIT  0000H   00010000H    device-id: 00 type: RIO byte
BYT_EGA_1      UNIT  0001H   00010000H    device-id: 00 type: RIO byte
BYT_EGA_2      UNIT  0002H   00010000H    device-id: 00 type: RIO byte
BYT_EGA_3      UNIT  0003H   00010000H    device-id: 00 type: RIO byte
FD0_0          UNIT  0000H   00020001H    device-id: 01 type: RIO block
HD0_0          UNIT  0000H   00020002H    device-id: 02 type: RIO block
SYSCON         UNIT  0000H   00010000H    device-id: 00 type: RIO byte

```

C.11 DISPLAY

Function Display memory contents

Syntax `DISPLAY [<format>] <address> [{LEN|TO} <expr>]`

Description

The memory area from <address> is displayed at the console in the selected format. Without LEN one line is displayed. Without <format> the default BYTE HEX is assumed. If the address specification does not contain a segment/selector, the most recently specified selector/segment is used (default: null selector).

In byte format the ASCII representation is also given. None-graphic characters are indicated by a period. Real numbers are always displayed in exponential representation.

Note

For space reasons, the ASCII representation has been suppressed in this example. Screen output can be interrupted by entering <Ctrl>+S or <Ctrl>+Q, and terminated by <Ctrl>+C. The address is displayed either as selector:offset or as absolute address, depending on the specification in the command line.

The floating-point data type are supported by DISPLAY, FILL and CHANGE only if CALCULATE was configured, since otherwise the modules for the computation of floating-point expressions are not linked.

Example

Display memory area from 100:0 with length 0FH

```
DEBUG_T>DISPLAY 100:0 LEN 0F<CR>
0100:0000  xx xx xx xx xx xx xx xx xx xx xx xx xx xx xx
DEBUG_T>
```

C.12 EVALUATE

Function Evaluate integer expression

Syntax EVALUATE <expr>

Description

An expression <expr> may contain:
 Constants, register contents, memory contents, input ports, combinations of arithmetic and boolean operators.

Example

```

<expr>      [ {-|~} ] <term> [ [ {+|-|^|'| '&|<<|>>} <term> ] ... ]
<term>     <factor> [ [ {*|/|%} <factor> ] ... ]
<factor>   { <ident> | <const> | ( <expr> ) }
<ident>    { <cpureg> | <memory> | <port> }
<cpureg>   { CS | DS | ES | SS | FS | GS | EIP | EAX | EBX | ECX | EDX | EDI | ESI | ESP |
            EBP | EFL | CR0 | IP | AX | BX | CX | DX | DI | SI | BP | FL | AL | AH | BL | BH |
            CL | CH | DL | DH | GDTR | LDTR | IDTR | TR | CR0 | CR2 | CR4 | DR0 | DR1 |
            DR2 | DR3 | DR6 | DR7 | TR11 | TR22 | TR31 | TR41 | TR51 | TR6 |
            TR7 | TR92 | TR102 | TR112 | TR122 }
<memory>   { BYTE | WORD | DWORD | POI | SPOI } ' [ ' <address> ' ] '
<port>     { INB | INW | IND } ' [ ' <port_address> ' ] '
<port_address> <expr>
    
```

1) only 486 processor with CUID and above

2) only Pentium processor and above

~	NOT
-	Negation
+ - * /	Basic arithmetic operations
%	Remainder after integer division
^	XOR
	OR
&	AND
<<	Left shift
>>	Right shift

The given expression is calculated and the result displayed on the console. The calculation is always performed in long-number format. The result is output in the three number bases (8/10/16) and in ASCII representation.

C.13 EXIT

Function Terminate Debugger

Syntax EXIT

Description

EXIT terminates the Debugger task. When the Debugger is exited in **breakpoint context** with EXIT the interrupted task is not continued. All set breakpoints remain set.

Example

```
DEBUG_T>EXIT <CR>
```

C.14 EXITK

Function Delete Breakpoints and Continue Halted Task

Syntax EXITK

Description

All breakpoints are deleted. If the current task is in the breakpoint context, it is continued. The debugger task is then terminated. (This corresponds to the GO command, with the difference that all breakpoints are first deleted.)

Example

```
DEBUG_T>EXITK <CR>
```

C.15 FILL

Function Fill memory block with specified byte value

Syntax FILL [<format>] <address> {LEN|TO} <expr>=<expr>[[,<expr>]...]

Description

The memory area from address <address> is filled with byte values up to the specified length. The values must match the memory format, otherwise they are converted to modulo <format> .

The Debugger performs no read-after-write control.

Example

Write 55H to memory from 1A4:0 to 1A4:FF

```
DEBUG_T>FILL BYTE 1A4:0 TO 0FF 55 <CR>
DEBUG_T>
```

C.16 FREETASK

Function Release dynamically loaded task

Syntax FREETASK <task_id>

Description

This command deletes a task which was previously loaded with `loadtask` or via the CLI.

The call only has effect if the task specified by <task_id> is in DORMANT state. The Loader Result Segment, as well as all the task's memory areas associated with the loader result segment, are also released.

Note

This command is available in task mode only.

C.17 GO**Function** Continue halted task and terminate debugger**Syntax** **GO** [**<start_address>**] [**[\$<address1>**] [**[\$<address2>]]**

<code><start_address></code>	Task entry address
<code><address1></code>	Soft breakpoint address
<code><address2></code>	Soft breakpoint address

Description**Breakpoint context only:**

GO transfers control to the task which was interrupted by the breakpoint. The task continues operation at address `<start_address>`, if specified, otherwise at the address stored in the CS:EIP register pair. The optional arguments `[$<address1>`, `[$<address2>` allow one or two breakpoint(s) (`$0X` and/or `$0Y`) to be set at these addresses before the task is started. Both breakpoints will be automatically deleted when the Debugger regains control. In other respects these two breakpoints are identical to normal soft breakpoints. `$0X` or `$0Y` is displayed when these breakpoints are reached.

After a GO command in monitor mode the interrupted program, eg, an RMOS driver, is continued according to the contents in register pair CS:EIP. If the MONITOR command was used to switch the Debugger to monitor mode, the GO command can be used to switch back to task mode.

By modifying the CS:EIP register contents program execution can be resumed at a defined entry point, or the system can be restarted.

Example

Continue the task halted by soft breakpoint (`$02`) with GO and at the same time set a new soft breakpoint at address `0034:0000323A`.

```
$2, TASK: 0002
DEBUG_T>GO $0034:323A<CR>
```

C.18 HALT

Function Halt task

Syntax HALT <task_id>

Description

HALT halts the task identified by <task_id> and puts it in a WAITING state. In addition, the task is flagged as HALTED BY THE DEBUGGER (status 26).

The HALT command can only be applied to tasks in the READY state.

Note

If the ID number specifies its own task or a task which cannot be halted (set during creation of the task), the message NO SUCH TASK! is output.

This command is available in task mode only.

Example

Halt task 3

```
DEBUG_T>HALT 3 <CR>
DEBUG_T>
```

C.19 HELP**Function** Help command**Syntax** **HELP <command>[<SVC>|<command>]****Description**

HELP <SVC> lists the name of all system calls which can be invoked with the SVC command.

HELP alone provides an overview of all commands.

HELP <command> responds with the syntax of the desired command. HELP by itself lists a summary of all commands. The upper case letters in the command names indicate the number of characters necessary to reference a command unambiguously. YES or NO following on the command name indicates whether the command is configured or not.

Example

What is the syntax of HELP ?

```
DEBUG_T>HELP HELP <CR>
SYNTAX: HELP <command> <CR>
DEBUG_T>
```

Which commands are configured?

```
DEBUG_T>HELP <CR>
RMOS3 DYNAMIC DEBUGGER, Vm.n
DEBUG-CMD INC DEBUG-CMD INC DEBUG-CMD INC ...
-----
ASm      YES  BAse      NO   BREaks  YES  ...
...
HElp     YES  ...
...
DEBUG_T>
```

C.20 IN

Function Read I/O port

Syntax IN [{byte|word|dword}] <port_address> <port_address> <expr>

Description

A value of the specified format is read from I/O port <port_address>. If the format specification is omitted, the default byte format is used.

Example

Read byte value from I/O port 0EAH.

```
DEBUG_T>IN BYTE 0EA <CR>
INPUT 00EAH=41H 'A'
DEBUG_T>
```


C.21 INHIB**Function** Enable/inhibit task processing**Syntax** INHIB {0|1}**Description**

INHIB enables task processing with INHIB=0 and inhibits processing with INHIB=1. All task states are retained. SVCs which were requested by a task are completed, if they do not involve further task processing.

Example

```
DEBUG_T>INHIB 1 <CR>
DEBUG_T>
.
.
.
DEBUG_T>INHIB 0 <CR>
DEBUG_T>
```

C.22 KILL

Function Kill breakpoint(s)

Syntax KILL <breakpoint>

Description

KILL deletes the specified breakpoint, ie, the breakpoint is removed from the list of set breakpoints. When the Debugger is exited with EXITK all set breakpoints are deleted.

Example

Delete hard breakpoint @3

```
DEBUG_T>KILL @3 <CR>
DEBUG_T>
```

C.23 LINES

Function Page-by-page output on/off

Syntax LINES <nr>

Description

You can use the `LINES` command to halt the display of commands after each full screen page and resume it with <Return>. The <nr> parameter tells the debugger how many lines your screen has. This number must be no less than 2, and must be entered in decimal, without regard to the `BASE`.

`LINES 0` switches off page-by-page output.

When the debugger is initially started, page-by-page output is OFF.

Note

The information output by the `REPORT` command is not affected by the `LINES` option.

An abort with <CTRL>C does not go into force until output is resumed with <Return>.

C.24 LOADTASK

Function Load task

Syntax **LOADTASK** <filename> [<priority> [<pool_id>]] [RUN] [DIS]

<filename>	File name, path specified according to RMOS conventions
<pool_id>	Memory pool containing the necessary memory areas to be called up. Default: -1H (HEAP)
<priority>	Priority of tasks 0 to 255. Default: 80H
RUN	The task is to be started automatically after loading.
DIS	DISMOUNT call for logging off the data carrier

Description

This command loads a task dynamically and starts it, if necessary.

The task's program code and related data areas are loaded by the function `stl_load` (relocatable taskloader) and cataloged according to its <filename> _<Task-ID> string (without extension). On completion of the load operation a dynamic task is created; its TCD is loaded with the register values from the Loader Result Segment or with the parameters of the command line.

The task ID and the selector for the Loader Result Segment as well as the task registers and the TCD address are displayed on the console. If the RUN was specified, the task is started after loading. The task can also be started separately with the `START` command. The switch DIS for dismounting the volume must be specified, if the volume, eg, a diskette, is removed temporarily from the drive (this ensures that automatically a new MOUNT call is performed before the load operation).

If the loaded task deletes itself (`SVC RmDeleteTask`), the memory areas used by the task must nonetheless be released again with `FREETASK`.

The `START` command can be used for forward parameters on the command line to a program loaded with `LOADTASK`.

Example

```
DEBUG_T>LOADTASK c:rmostask.EXE 0A0 CR
Task-id = 12, Loader result segment = 0180:0
Task entry point = 008C:000099A4,
TCD address = 0030:00000160
DS = 0084, ES = 0084, stack base = 0074:00001000

DEBUG_T>DIR <CR>(
Cataloged resources

Symbolic-name  kind  id          Symbolic-name  kind  id
DEB_0          TASK  0000H      RMOSTASK_0012  TASK  0012H
DEBUG_T>
```

C.25 MONITOR

Function Switch debugger to monitor mode

Syntax MONITOR

Description

If in task mode the debugger is switched to monitor mode. The prompt changes from the task mode prompt

```
DEBUG_T> bzw. DEBUG_TB>
```

to the monitor mode prompt.

```
DEBUG_MB>
```

If the debugger is already in monitor mode an error message is displayed.

C.26 OUT

Function Write I/O port

Syntax OUT[*{byte|word|dword}*]*<port_address>**<expr>**<port_address>*
<expr>

Description

The data element *<expr>* of the specified format is written to I/O port *<port_address>*. If the format specification is omitted, the default byte format is used.

Example

Write 1234H to port 5678H.

```
DEBUG_T>OUT WORD 5678, 1234<CR>
DEBUG_T>
```

C.27 QUALIFY

Function Parameterize breakpoint

Syntax **QUALIFY** <breakpoint>,<count>[<task_id>] [{MON|TASK}]

<breakpoint>	{\$ @ E {M W}{B W D}}{1...0F 40...07F} Breakpoint IDs 40..07FH are used by Organon XDB
<count>	<expr>, value for passcounter
<task_id>	ID of task for which the breakpoint is valid
MON	Switch to monitor mode on reaching the breakpoint
TASK	Switch to task mode on reaching the breakpoint

Description

QUALIFY sets the pass counter for a breakpoint, ie, the breakpoint is executed only after <count> passes and then displayed. The optional <task_id> restricts the breakpoint to a single task.

The breakpoint is valid for all tasks, if the task ID is ANY (= 0FFFFH, default). Task-specific breakpoints are used when a shared code area is used by several tasks.

Example

Set the pass counter of hard breakpoint @4 to 7. In addition, restrict the breakpoint to task 3.

```
DEBUG_T>QUALIFY @1 7 3<CR>
```

```
DEBUG_T>BREAKS <CR>
```

```
@ 01: Addr: 2000:0002300F pass count: 0007,task: 003, taskmode
@ 02: Addr: 2000:00000002 pass count: 0001,task: any, taskmode
E 03: Addr: 2000:0002345F pass count: 0001,task: any, taskmode
MB04: Addr: 2000:00023450 pass count: 0001,task: any, taskmode
MW05: Addr: 2000:00023450 pass count: 0001,task: any, taskmode
MD06: Addr: 2000:00023450 pass count: 0001,task: any, taskmode
WB07: Addr: 2000:00023450 pass count: 0001,task: any, mon.mode
WW08: Addr: 2000:00023450 pass count: 0001,task: any, mon.mode
WD40: Addr: 2000:00023450 pass count: 0001,task: any, taskmode
E 41: Addr: 2000:0002345F pass count: 0001,task: any, mon.mode
```

```
DEBUG_T>
```


C.28 QUERY

Function Query task status

Syntax QUERY <task_id>

Description

QUERY displays the status of the task identified by <task_id> on the console, together with the priority.

The possible task states are TASK DORMANT, TASK READY, TASK BLOCKED or TASK ACTIVE. In addition, the reason why a BLOCKED task is waiting is reported. If a task has never entered the ACTIVE state, the priority and task state both contain the value 00H.

Example

Query the task status of the task with ID=2

```
DEBUG_T>QUERY 2 <CR>
Task dormant
State byte: 00, current priority: FC.
DEBUG_T>
```

The current state of a task is encoded as follows in Bit0..1 of the status byte:

- 0 - DORMANT (suspended)
- 1 - READY (ready)
- 2 - BLOCKED (waiting)
- 3 - ACTIVE (running)

Table C-1 Status of a BLOCKED Task

06H	Waiting for event flag
0AH	Waiting for semaphore/program with controlled access
0EH	Waiting for target task to be loaded
12H	Waiting for target task start
16H	Waiting for target task termination
1AH	Waiting for message
1EH	Waiting for a sent message to be received
22H	Waiting for memory allocation from a memory pool
26H	Halted by debugger or task in suspended state
2AH	Interrupted at debugger breakpoint
2EH	Waiting for time interval to elapse (pause)
32H	Error: Invalid task stack selector

Table C-1 Status of a BLOCKED Task

36H	Waiting for completion of I/O operation
3EH	Waiting for memory enable (FREEALL)
42H	Waiting for time interval to elapse
46H	Runtime error, type 0 (Division by 0 Interrupt)
4AH	Runtime error, type 1 (Single Step Interrupt)
4EH	Runtime error, type 3 (Breakpoint Interrupt)
52H	Runtime error, type 4 (Overflow Interrupt)
56H	Runtime error, type 5 (Array Bound Interrupt)
5AH	Runtime error, type 6 (Unused Opcode)
5EH	Runtime error, type 7 (Escape Opcode)
62H	Runtime error, type 8 (Double Fault)
66H	Runtime error, type 9 (NDP Segment Overrun)
6AH	Runtime error, type 13 (General Protection)
6EH	Runtime error, type 16 (Floating Point Error)
72H	Runtime error, type 10 (Invalid TSS)
76H	Runtime error, type 11 (Segment Not Present)
7AH	Runtime error, type 12 (Stack Fault)
7EH	Runtime error, type 14 (Page Fault)
82H	Runtime error, type 17 (Alignment Check)
C6H	Waiting for a catalog string to be entered
CAH	Task is terminated by KILLTSK (after I/O operation)
CEH	Task is deleted by KILLTSK (after I/O operation)

C.29 REGS

Function Display register contents

Syntax REGS [<task_id>]

Description

In **breakpoint context**:

REGS displays the contents of 8086/80186/80286/80386/80486/Pentium registers in Real Mode, or of the used registers in Protected Mode.

In **escape context**:

REGS displays the task registers after a task ID is entered. The displayed values are only meaningful, if the specified task is in the WAITING state.

Register output in Real Mode:

```
AX: xxxx  CS: xxxx  IP: xxxx
BX: xxxx  SS: xxxx  SP: xxxx  BP: xxxx
CX: xxxx  DS: xxxx  SI: xxxx
DX: xxxx  ES: xxxx  DI: xxxx
FL: xxxx
```

80386 register output in Protected Mode:

```
CS = ssss  ppppppppL  Limit: 11111111  EIP = xxxxxxxx
SS = ssss  ppppppppL  Limit: 11111111  EAX = xxxxxxxx
DS = ssss  ppppppppL  Limit: 11111111  EBX = xxxxxxxx
ES = ssss  ppppppppL  Limit: 11111111  ECX = xxxxxxxx
FS = ssss  ppppppppL  Limit: 11111111  EDX = xxxxxxxx
GS = ssss  ppppppppL  Limit: 11111111  EDI = xxxxxxxx
TR = ssss  ppppppppL  Limit: 11111111  ESI = xxxxxxxx
LDT = ssss  ppppppppL  Limit: 11111111  ESP = xxxxxxxx
GDT = ssss  ppppppppL  Limit: 11111111  EBP = xxxxxxxx
IDT = ssss  ppppppppL  Limit: 11111111  EFL = xxxxxxxx
                                CR0 = xxxxxxxx
```

ssss	Selector
ppppppppL	Linear (physical) 32-bit address
11111111	Segment limit
xxxxxxxx	General register contents

All values are displayed in hexadecimal format.

Example

A soft breakpoint \$2 is set at address 9C:6C in the code area of the task with ID=2. The task is started and then terminated by the soft breakpoint \$2. Afterwards, the registers are displayed.

```

DEBUG_T>tcd 2
Task entry point = 009C:0000006C, TCD address = 0038:00091168,
DS = 0000, ES = 0000, stack base = 00E0:00001000
DEBUG_T>set $2 9c:6c
DEBUG_T>start 2 0 0
DEBUG_T>
Breakpoint $02 reached in task 'ERRLOG' (02H).
009C:0000006C  1E                               PUSH  DS
DEBUG_TB>regs

CS = 009C  Linear: 00083580  Limit: 00000110  ER N   EIP = 0000006C
SS = 00E0  Linear: FFC05000  Limit: 00000FFF  RW N   ESP = 00000FF0
DS = 0000  (invalid)
ES = 0000  (invalid)
FS = 00E0  Linear: FFC05000  Limit: 00000FFF  RW N   ECX = 00000000
GS = 0000  (invalid)
TR = 0018  Linear: 0001A3C0  Limit: 00000067
LDT = 0020  Linear: 0001A200  Limit: 000000D7
GDT =      Linear: 0000A000  Limit: 0000F9FF
IDT =      Linear: 00019A00  Limit: 000007FF
                                CR0 = 8000001B

DEBUG_TB>go
End of task 'ERRLOG' (02H) detected.
DEBUG_T>

```

Note

After starting task 2, the debugger waits after prompt output for input from the console. It is blocked in this state by the console driver and can therefore not yet signal the breakpoint reached by task 2. Any input (a space, for example) ensures the signaling of breakpoints reached in the meantime as well as the change from the escape context to the breakpoint context.

C.30 REPORT

Function Resource Report

Syntax REPORT [<resource> [<resource-id>]] [LONG]

<resource>	[{TASK SEMA FLAG LMBX}]
TASK	Task report
SEMA	Output of semaphore report
FLAG	Report on event flags
LMBX	Mailbox report
MSGQ	Message Queue
<resource-id>	Resource identifier
[LONG]	Long form, detailed output

Description

REPORT executes Resource Report functions. The Resource Report lists information about the resources used by RMOS. The default setting is for short form reports. The [Long] option is used for long form reports. If the type is omitted all possible resources are evaluated. The resource type can optionally be specified by <resource-id>. The resource reporter functions are not performed by a separate Resource Report task, but are executed in Debugger context. The evaluation is performed just once, without periodic restart. Output is routed to the device and unit of the debugger, not as specified in the Resource Report configuration.

Note

This command is available in task mode only.

The information output by the REPORT command is not affected by the LINES command.

Caution

The Resource Reporter must not be called in more than one debugger at one time, because this may cause the debugger to break down.

Example

Task list command.

All READY, ACTIVE or BLOCKED tasks are listed.

```
DEBUG_T>rep task
```

```
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:28:44
```

TASK REPORT:

TASK_ID	STATE	CUR_PRI	INH_PRI	TASK_ID	STATE	CUR_PRI	INH_PRI
18	ready	1	1	1E	i/o oper	40	40
21	active	FF	FF				

```
DEBUG_T>rep task lo
```

```
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:29:44
```

TASK REPORT:

TASK_ID	18	STATE	ready	ATTR	dyn				
CUR_PRI	1	EAX	0 DS	0	START	84:000002DC			
INH_PRI	1	EBX	0 ES	0	STACK	208:000003AA	TCD	38:000026A4	
TASK_ID	1E	STATE	i/o oper	ATTR	dyn				
CUR_PRI	40	EAX	0 DS	240	START	44:00004820			
INH_PRI	40	EBX	0 ES	240	STACK	240:00001AB4	TCD	38:000027B4	
TASK_ID	21	STATE	active	ATTR	nhlt dyn				
CUR_PRI	FF	EAX	0 DS	270	START	94:00003D24			
INH_PRI	FF	EBX	6 ES	0	STACK	268:00000ECC	TCD	38:00002908	

Description

The various items of information in the list have the following meanings:

TASK_ID:	Task identifier
STATE:	Task status
CUR_PRI:	Current priority
INH_PRI:	Inherent priority
ATTR:	Task attributes
START:	Start address of the task
STACK:	Current pointer to the current stack
TCD:	Address of the TCD
EAX,EBX,DS,ES:	Start value of the relevant register

Example

Semaphore list command.

```
DEBUG_T>rep sema
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:31:20
```

SEMAPHORE REPORT:

SEMA_ID	IN_USE	TASK_WAIT	SEMA_ID	IN_USE	TASK_WAIT
0	no	no	1	no	no
2	no	no	3	yes	yes
4	no	no	5	no	no
6	no	no	7	no	no
8	no	no	9	no	no
A	no	no	B	no	no
C	no	no	D	no	no

```
DEBUG_T>rep sema lo
```

```
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:31:23
```

SEMAPHORE REPORT:

SEMA_ID	OWNER_TASK	REQ_TASK	REQ_PRI
0			
1			
2			
3	21	26	FF
		29	FF
4			
...			
C			
D			

Description

The various items of information in the list have the following meanings:

SEMA_ID: Semaphore identifier
 IN_USE: Semaphore in use (yes/no)
 TASK_WAIT: Tasks waiting for semaphore (yes/no)
 OWNER_TASK: ID of the task using the semaphore
 REQ_TASK: Task IDs of waiting tasks
 REQ_PRI: Priority of waiting tasks

Example

Flag group list command.

```
DEBUG_T>rep flag
```

```
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:31:56
```

```
EVENT_FLAG REPORT:
```

EVENT_FLG	OWNER	FLAGS	TASK_WAIT	EVENT_FLG	OWNER	FLAGS	TASK_WAIT
local	18	0	no	local	1E	0	no
local	21	1	no	1		0	no
	2	0	no	3		0	no
	4	0	no	5		0	no
	A	0	no				

```
DEBUG_T>rep flag lo
```

```
RMOS3 RESOURCE REPORTER, V3.8 01-FEB-1996 07:31:59
```

```
EVENT_FLAG REPORT:
```

EVENT_FLG	OWNER	FLAGS	TASK_WAIT	PRI	TEST_MASK	TYPE
local	18	0				
local	1E	0				
local	21	1				
	1	0				
	2	0				
	...	0				
	9	0				
	A	0				

Description

The various items of information in the list have the following meanings:

EVENT_FLG: ID of the event flag group or "local" for local event flags

OWNER: Owner of the local event flag groups

FLAGS: Status of the flags

TASK_WAIT: Tasks waiting for semaphores (yes/no)

PRI: Priority of waiting tasks

TEST_MASK: Flag mask of the waiting tasks

TYPE: Logic operation to be used to combine the test mask with the flag group (and/or)

Example

Mailbox list command.

```
DEBUG_T>rep lmbx
RMOS3 RESOURCE REPORTER, V3.8                      01-FEB-1996 07:32:23
LOCAL MAILBOX REPORT:
MBOX_ID  TASK_WAIT  MSG_AVAIL          MBOX_ID  TASK_WAIT  MSG_AVAIL
      0      no        no                1        no        no
      2      no        no                3        no        no
      4      no        no                5        no        no
      6      no        no                7        no        no
      8      no        no                9        no        no

DEBUG_T>rep lmbx lo
RMOS3 RESOURCE REPORTER, V3.8                      01-FEB-1996 07:32:27
LOCAL MAILBOX REPORT:
MBOX_ID  RECVR  SENDER  PRI   COORD  MSG1  MSG2  MSG3
      0
      1
      2
      ....
```

Description

The various items of information in the list have the following meanings:

MBOX_ID: Mailbox identifier

TASK_WAIT: Tasks waiting for semaphores (yes/no)

MSG_AVAIL: Are there any messages in the mailbox (yes/no)

RECVR: Receive task waiting for the message

SENDER: Send task waiting for the message to be retrieved

PRI: Priority of waiting tasks

COORD: Irrelevant

MSG1,MSG2,MSG3: Message contents (3x 32-bit words)

Example

Message queue list command.

```
DEBUG_T>rep msgq
```

```
RMOS3 RESOURCE REPORTER, V4.0 17-MAR-1998 11:16:04
MESSAGE QUEUE REPORT:
TASK_ID  TASK_WAIT  MSG_AVAIL  TASK_ID  TASK_WAIT  MSG_AVAIL
    3         no         5         22         no         0
    23        yes         0         28         yes         0
    2A        yes         0
```

Example for REP MSGQ LONG

```
DEBUG_T>rep msgq long
```

```
RMOS3 RESOURCE REPORTER, V4.0 17-MAR-1998 11:16:06
MESSAGE QUEUE REPORT:
TASK_ID  SENDER  PRI  COORD  MESSAGE_ID  MESSAGE
    3      2C    3   no coord    3  0000:00000003
    23     2C    2   no coord    2  0000:00000002
    2A     2C    1   no coord    1  0000:00000001
    28     2C    0   no coord    0  0000:00000000
    2A     23    0   no coord    64 0000:00005555
    22
    23
    28
    2A
```

Description

TASK_ID	ID of the owner task
TASK_WAIT	Are there any tasks waiting for messages? (yes/no)
MSG_AVAIL	Number of messages in the queue
SENDER	TASK-ID of the sender task
PRI	Priority of the message
COORD	(see REP LMBX LONG)
MESSAGE_ID	ID of the message (message parameter in RmSendMessage)
MESSAGE	Message (pMessageParam parameter in RmSendMessage)

Note

The selector (value on the left of the ':') is ignored by FLAT programs, and it cannot be set in RmSendMessage.

C.31 SET

Function Set breakpoint(s)

Syntax SET <breakpoint>,<address>

<breakpoint> {\$|@|E|{M|W}|{B|W|D}}1...0F

\$ Set soft breakpoint

@ Set hard breakpoint

Set breakpoint in debug register:

E Execution-Breakpoint in the Debug register

MB Modify (Read or Write) Byte Breakpoint

MW Modify (Read or Write) Word Breakpoint

MD Modify (Read or Write) Dword Breakpoint

WB Write Byte Breakpoint

WW Write Word Breakpoint

WD Write Dword Breakpoint

<address> selector:offset or linear address

Description

SET is used to set breakpoints using the INT3 instruction or the processor's debug register.

SET {\$|@} replaces the byte at <address> by an INT3 instruction. The program code must be located in RAM. Soft breakpoints (\$) are temporary, ie, they are deleted automatically after they are processed. By contrast hard breakpoints (@) are retained until they are removed with KILL. When program execution is resumed after reaching a hard breakpoint, the debugger replaces the INT 3 instruction by the original opcode. After this is executed in single-step mode the INT3 instruction is again entered. The task execution is then continued with normal speed.

SET {E|{M|W}|{B|W|D}} sets a breakpoint using the processor's debug register. Up to 4 debugregister breakpoints can be set. This breakpoint type allows both execution breakpoints in EPROM areas and breakpoints for write/read memory access to be defined. A breakpoint defined by SET is valid for all tasks and is executed when encountered for the first time (see QUALIFY for setting pass counters and task restrictions). When a breakpoint is reached the debugger assumes control in **breakpoint context** and displays a message to this effect at the console.

The allocation of breakpoint numbers with SET is immaterial, ie, breakpoint number 8 can be used ahead of breakpoint number 5, for example.

Example

INT3 breakpoint:

Set soft breakpoint at address 2000:0 (\$01),

Set hard breakpoints at addresses 11B5:2 and 2000:0F (@02 and @03).

```
DEBUG_T>SET $01,2000:0 <CR>
DEBUG_T>SET @02,11B5:2 <CR>
DEBUG_T>SET @03,2000:0F <CR>
DEBUG_T>
```

Debug register breakpoint:

Execution breakpoint at address 01A4:0000E49A (E05)

Modify (Read or Write) at address 01A4:000032F5 (MB06)

Modify (Write) at address 01A4:00012A24 (WW07)

```
DEBUG_T>SET E05,01A4:0000E49A <CR>
DEBUG_T>SET MB06,01A4:000032F5 <CR>
DEBUG_T>SET WW07,01A4:00012A24 <CR>
```

C.32 STACK

Function Display stack

Syntax STACK [<count>]

Description

Breakpoint context only:

STACK displays <count> stack entries from address SS:ESP.

In a 32-bit segment stack entries are shown as DWORDs, in a 16-bit segment as WORDs.

Example

```
DEBUG_T>STACK 10<CR>
SS:      0074      Linear: 00174BC  Limit:  00000322  ESP:      000001E0
FFFF006C 00000000 00000000 FFFF006C 000002D0 0000000C 00000308 00000210
00000000 00001456 000023EA FFFF0000 00000383 0000FFFF 0000F0F0 0000AAAA
```

C.33 START

Function Start DORMANT task

Syntax `START <task_id>[<address>|<expr>[<expr>] | ARGS [<arg> ...]]`

Description

START switches a task specified by ID <task_id> from the DORMANT to the READY state, using the values in <address> or in <expr>[<expr>] as start parameters. If <address> is specified as start parameter the offset is transferred to the EAX register and the segment to the EBX register. If <expr> [<expr>] is specified as start parameter the first is transferred EAX register and the second to the EBX register. If the start parameter is omitted, the Debugger takes the start parameter used in the most recent START command (initially zero). If only the first parameter is specified (EAX register), the last valid entry is used for the second parameter.

If the second format with the keyword ARGS is used, all further arguments are edited so that they are available to the started task as "argc/argv". argv[0] argv[0] contains the file name specified in LOADTASK or, if the program was not loaded with LOADTASK, the catalog entry or, if there is none, the string "(UNKNOWN)". The command line, as well as argv and argc, are pushed onto the task's stack. The stack must have sufficient room to accommodate them.

Note

This command is available in task mode only.

Example

The Error logger task has a task-ID 3. Unused RAM starts at address 002C:0. In the following example the string ABCD is loaded into RAM and subsequently output to the console by the Errorlogger task.

```
DEBUG_T>CHANGE BYTE 002C:0 41,42,43,44<CR>
DEBUG_T>START 3 002C:0 <CR>
DEBUG_T>EXIT
ABCD
```

C.34 STEP

Function Single-step mode

Syntax STEP [<count>]

<count> repeat counter, maximum 127

Description

Breakpoint context only:

The halted task is executed in single-step mode.

If the `STEP` command is to process more than one processor instruction, use the `<count>` parameter to specify the number of instructions to be executed for each `STEP` command.

If an interrupt or an exception occurs during single-step mode, interrupt processing is not interrupted. To test an interrupt routine in single-step mode, a breakpoint must be entered in the respective code area.

It is not possible to run into an SVC with `STEP`. SVC calls are executed like a single Assembler command. Termination of a `STEP` can be delayed by, for example, a blocking SVC or by the execution of high-priority tasks.

C.35 SVC

Function Generate SVC

Syntax **SVC** <SVC_name> <param_list> or briefly:
<SVC_name> <param_list>

<SVC_name>	Valid SVC-name (see the <code>HELP SVC</code> command)
<param_list>	List of SVC-parameters

Description

The debugger generates an SVC for processing by M7 RMOS32. The parameter list consists of the full SVC name (or enough of it to avoid ambiguity) and associated arguments (as bytes, words or addresses).

The SVC name is used as substitute for the SVC number, all other arguments must correspond to the SVC HLL interface, ie, the parameters must be entered in the command line as for a high-level language system call in C. The number and type of the various parameters are checked. In the case of invalid data, error messages are issued at the console and the command is terminated. On completion of the SVC a message is output to indicate whether the call was successful or not, followed by the return value.

If an SVC is awaiting a string input, the string may be entered direct instead of a pointer. If an SVC is awaiting entry of a pointer in order to store a return value, the keyword `AUTO` (or, in the case of interactive input, simply `<Return>`) may be entered in place of the pointer when simple data types are involved. The debugger itself then makes space available for the data and forwards a pointer to the SVC. Following this, the debugger outputs the returned value when returning pointers, numbers, strings, mails, doublewords, `MempoolInfoStruct`, `TaskInfoStruct`.

Note

With the call `RmCreateDescriptor`, the address must be specified as a long value (e.g. 28000). This long value specifies the absolute physical segment base address. The address suffix `l` or `p` (28000l/28000p) is not permitted.

This command is available in task mode only.

API calls which cannot be generated with the SVC command: `RmReadMessage`.

Example

```
>svc rmsetflag 0 14  
SVC successful.  
SVC status -259
```

```
>svc rmalloc 0 0 300000 0e0:0  
SVC failed:  
Error code 38 = 'Invalid size'
```

```
or briefly:  
>rmsetflag 0 14  
SVC successful.  
SVC status -259
```

C.36 SWITCH

Function Switch in breakpoint context

Syntax SWITCH <task_id>

Description

If several tasks are halted at breakpoints, this command can be used to switch from the escape context or the current breakpoint context of a task to the breakpoint context of the task identified with `task_id`. Commands such as REGS, GO, STEP now refer to this task.

C.37 TASK**Function** Switch debugger to task mode**Syntax** TASK**Description****In escape context:**

If in monitor mode the debugger is switched to task mode. The prompt changes from the monitor mode prompt:

```
DEBUG_MB>
```

to the task mode prompt:

```
DEBUG_T>
```

If the debugger is already in task mode an error message is displayed.

In breakpoint context:

A direct switch to the task mode is not possible. The monitor mode can only be exited with the `GO/EXIT` command. At the same time this continues execution of the interrupted program.

C.38 TCB

Function Displays data from a task's TCB

Syntax TCB <task_id>

Description

TCB outputs the current, dynamically modifiable data in the task-control block (TCB) of the task with the task ID <task_id> to the console. The data in the TCB are defined during system configuring in the case of static tasks and at system runtime in the case of dynamically created tasks.

The uses of this command include querying of the LOADER segment needed to debug an already executing task with the Organon XDB.

Note

This command is available only in Task mode.

C.39 TCD

Function Display TCD block of a task

Syntax TCD <task_id>

Description

TCD displays some data items of the TCD (task control data) block of the task identified by <task_id> on the console. The TCD contains data of static tasks generated during system generation and of dynamically created tasks.

Note

This command is available in task mode only.

Example

Protected Mode: Display TCD of the task with ID=2

```
DEBUG_T>TCD 2 <CR>
Task entry point = 11B5:0002, TCD Address = 1004:0040,
DS = 0000, ES = 0000, stack base = 23FB:00D0
DEBUG_T>

DEBUG_T>TCD 2 <CR>
Task entry point = 005C:000024F4, TCD Address = 0014:00000362,
DS = 0000, ES = 0000, stack base = 0064:00000320
DEBUG_T>
```

C.40 Debugger Error Messages

The debugger responds to commands not complying with the syntax rules by issuing a general error message and prompting for renewed input.

Error Message	Meaning
] expected	A square right bracket is missing in an expression.
All debugregisters in use!	An attempt was made to set more than 4 breakpoints of type "debugregister breakpoint".
Already a breakpoint!	An attempt was made to set a breakpoint at an address previously allocated to another breakpoint.
Balance error!	Unmatched number of opening and closing brackets.
Breakpoint_id in use!	An attempt was made to overwrite a valid breakpoint number (ID).
Can't allocate memory!	There is insufficient memory to allocate.
Can't monitor end of task!	The debugger could not log onto the operating system for monitoring the end of this task.
Catalog error!	The debugger could not generate catalog entry.
Command not allowed on this unit!	An attempt was made to switch to monitor mode or to set a monitor breakpoint, on a console which does support this operating mode.
Command not configured!	The command is not configured.
Divide by zero!	The expression contains a division by zero.
Error starting task	A task could not be started.
I/O— error!	An I/O error occurred.
Illegal mode!	An attempt was made to execute a command in task mode which is only allowed in monitor mode, or vice versa.
Illegal request!	An attempt was made to execute a command which is invalid in the current state.
Illegal SVC parameter	Invalid parameter with SVC command.
Invalid base!	Invalid number base.
Loader error	Unknown error of the task loader.
Loader result segment not found!	There is no Loader Result Segment for the specified task.
Memory not writeable	An attempt was made to set a soft or hard breakpoint in ROM.
Missing operand(s)!	A valid operand is missing in the expression.
Missing valid SVC_name!	SVC is either incorrect or does not exist.
Nesting exceeded, stack full!	The nesting level is too deep in an integer or floating-point expression.
No linear/physical address for breakpoints!	A linear/physical address cannot be specified for a setting a breakpoint.
No such breakpoint!	An attempt was made to delete a non-existing breakpoint.
No such task!	A task ID number was specified which is not assigned to a task, or the task is DORMANT.
Not a read-write segment!	The segment specified by the selector must be of type READ-WRITE.

Not an execute-read segment!	The segment specified by the selector must be of type EXECUTE-READ.
NPX not allowed!	Coprocessor operation is not allowed.
Offset exceeds segment limit!	The segment limit was exceeded.
Page not present!	There is no entry in the page directory for this memory area, or the associated page does not exist.
Stepcount > 127!	At most 127 instructions can be executed with STEP.
Syntax error!	Syntax error in the most recently entered command.
Task not halted!	<ul style="list-style-type: none"> • Task not in DEBUGGER HALTED or DEBUGGER BREAKPOINT state (switch or cont command) or • Task not in DORMANT state (freetask or start command) or • Debugger not in breakpoint context (step command)
Too many arguments!	At START <task_id> ARGS ... and SVC <SVC_name> too many arguments were indicated.
Type mismatch!	Invalid TYPE specification.
Wrong report table size!	Incorrect size of Resource Report table.
Wrong selector!	An attempt was made to specify an address with selector:offset without the selector part pointing to a valid entry in a descriptor table.

D

System Status List SZL

Chapter Overview

Section	Title	Page
D.1	Overview of the System Status List (SZL)	D-2
D.2	Structure of an SZL Partial List	D-3
D.3	SZL-ID	D-4
D.4	Possible Partial System Status Lists	D-5
D.5	SZL-ID W#16#xy11 - Module identification	D-6
D.6	SZL-ID W#16#xy12 - CPU characteristics	D-7
D.7	SZL-ID W#16#xy13 - User memory areas	D-8
D.8	SZL-ID W#16#xy14 - System areas	D-10
D.9	SZL-ID W#16#xy15 - Block types	D-11
D.10	SZL-ID W#16#xy22 - Interrupt status	D-12
D.11	SZL-ID W#16#xy24 - Operating mode and operating mode transition	D-13
D.12	SZL-ID W#16#xy32 - Communication status data	D-16
	Sections D.13 to D.15 are data records of all W#16#0132 partial list extracts	
D.16	SZL-ID W#16#xy91 - Module status information	D-20
D.17	SZL-ID W#16#xy92 - Rack/station status information	D-23
D.18	SZL-ID W#16#xyA0 - Diagnostic buffer	D-25
D.19	SZL-ID W#16#00B1 - Module diagnostic information	D-26
D.20	SZL-ID W#16#00B2 - Diagnostic data record 1 with geographical address	D-27
D.21	SZL-ID W#16#00B3 - Module diagnostic data with logical base address	D-28
D.22	SZL-ID W#16#00B4 - Diagnostic data of a DP slave	D-29

D.1 Overview of the System Status List (SZL)

Overview of This Appendix

This appendix describes all partial lists of the system status list which relate to

- CPUs or
- modules whose partial lists are not module-specific (such as SZL-IDs W#16#00B1, W#16#00B2, W#16#00B3).

Module-specific partial lists, such as those for CPs and FMs, can be found in the appropriate module description.

Definition of the System Status List

The system status list describes the current status of an automation system. The contents of the SZL can be read using special information functions, but cannot be altered. The partial lists are virtual lists, that is, they are assembled by the CPUs' operating system only on request.

Contents

The system status lists contain information on the following:

- System data
- Diagnostic status data in the CPU
- Diagnostic data on modules
- Diagnostic buffer

System Data

System data are permanent or programmable CPU data describing the following CPU characteristics and features:

- CPU configuration
- Communication

Diagnostic Status Data

Diagnostic status data describe the current status of the components monitored for system diagnostics.

Diagnostic Data on Modules

The modules with diagnostic capabilities assigned to a CPU have diagnostic data that are stored directly on the modules.

Diagnostic Buffer

The diagnostic buffer contains diagnostic entries which are placed in the buffer in the order of their occurrence.

D.2 Structure of an SZL Partial List

Basics

You can read a partial list or partial list extract with the M7 API call `M7SZLRead`.

Structure

A partial list consists of the following components:

- A header
- Data records

Header

The header for a partial list contains the following:

- SZL-ID
- Index
- Length in bytes of a data record in this partial list
- Number of data records in this partial list

Index

Specification of an object type identifier or an object number is required for some partial lists or partial list extracts. The index is used for this purpose. If the index is not needed, its content is irrelevant.

Data Records

A data record in a partial list has a specific length. This length depends on what information is contained in the partial list. The contents of the data words in a data record also depend on the partial list.

D.3 SZL-ID

SZL-ID

Each partial list in the system status list has a number. You can output a complete partial list or only extracts. The extracts are predefined, and each of them is also identified by a number. The SZL-ID is a combination of the number of the partial list, the number of the partial list extract and the module class.

Structure

The SZL-ID comprises one word, and is structured as follows:




Figure D-1 Structure of the SZL-ID

Module Class

Examples of module classes:

Module Class	Coding (binary)
CPU	0000
CP	1100
FM	1000
IM	0100

Number of the Partial List Extract

The number of the partial list extract and its meaning depends on the partial list. The partial list extract number specifies the subset of the partial list you want to read.

Number of the Partial List

The number of the partial list specifies which partial list of the system status list you want to read.

D.4 Possible SZL Partial Lists

Subset

In a given module, only one subset of all possible partial lists is available. Which partial lists are available depends on the module.

Possible SZL Partial Lists

The table below shows all possible partial lists, each with its associated number in the SZL-ID.

Partial List	SZL-ID
Module identification	W#16#xy11
CPU characteristics	W#16#xy12
User memory areas	W#16#xy13
System areas	W#16#xy14
Block types	W#16#xy15
Interrupt status	W#16#xy22
Operating modes	W#16#xy24
Communication status data	W#16#xy32
Module status information	W#16#xy91
Rack / station status information	W#16#xy92
Diagnostic buffer of the CPU	W#16#xyA0
Module diagnostic information (data record 0)	W#16#xyB1
Module diagnostic information (data record 1), geographical address	W#16#xyB2
Module diagnostic information (data record 1), logical address	W#16#xyB3
Diagnostic data of a DP slave	W#16#00B4

D.5 SZL-ID W#16#xy11 - Module Identification

Purpose

The partial list with SZL-ID W#16#xy11 provides the module's identification.

Header

The header of the SZL with SZL-ID W#16#xy11 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0011: all identification data records for a module W#16#0111: a single identification data record only W#16#0F11: only SZL partial list header information
INDEX	SZL-ID W#16#0111 only: Number of a particular data record W#16#0001: Module identification W#16#0002: Firmware identification W#16#0003: Hardware identification
LENGTHHDR	W#16#001C: 1 data record comprises 14 words (28 bytes)
N_DR	Number of data records

Data Record

A data record in the SZL with the SZL-ID W#16#xy11 is structured as follows:

Name	Length in Words	Description
Index	1	Number of an identification data record
Order No.	10	The module's Order No.; a string of 19 characters and one blank (20H), for example.: "6ES7 314-0AE01-0AB0 " for CPU 314
BGTyp	1	Module type identifier (the module type identifier is for internal use only)
Ausbg	1	Release of the module or operating system version
Ausbe	1	Release of the PG description file for offline configuration

Expansions for M7-300/400

The indices greater than 1 are reserved for the M7-300/400 modules. The indices greater than 1 are optional, that is, non-existence of certain indices (with M7-SYS V1.x) is not an error. The expansions have the following meanings:

	Index = 1 Module Identification	Index = 2 Firmware Identification	Index = 3 Hardware Identification
Order No.	Module Order No.	M7-SYS system software Order No.	Module Order No.
BGTyp	Module type ID	Module type ID	Module type ID
Ausbg	M7-SYS system software version (first two digits only, decimal) e.g. 20 for 2.0.	Complete M7-SYS system software version (BCD coded, four digits)	The first two digits contain the firmware version, the last two digits contain the hardware revision level, both BCD coded.
Ausbe	–	–	BIOS version in ASCII.

D.6 SZL-ID W#16#xy12 - CPU Characteristics

Purpose

CPU modules have different characteristics depending on the hardware being used. Each characteristic is assigned an identifier. The partial list with SZL-ID W#16#xy12 lists the characteristics of a module.

Header

The header of the partial list with SZL-ID W#16#xy12 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract: W#16#0012: All Characteristics W#16#0112: Characteristics of a group Use the INDEX parameter to specify which group. W#16#0F12: SZL-partial list header information
INDEX	Group W#16#0100: Timing system W#16#0200: System response
LENGTHDR	W#16#0002: 1 data record comprises 1 word (2 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy12 comprises one word. There is an identifier for each characteristic. Each such identifier comprises one word.

Characteristic Identifier

All characteristic identifiers are listed in the tables below.

Identifier	Description
W#16#0100 - 01FF Time system (group with index 0100)	
W#16#0101	1 ms time resolution
W#16#0102	10 ms time resolution
W#16#0103	No real-time clock
W#16#0104	BCD time-of-day format
W#16#0200 - 02FF System response (group with index 0200)	
W#16#0201	Multiprocessor capability

D.7 SZL-ID W#16#xy13 - User Memory Areas

Purpose

The partial list with SZL-ID W#16#xy13 provides information on the module's memory areas.

Header

The header of the partial list with SZL-ID W#16#xy13 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0013: Data records for all memory areas W#16#0113: Data record for one memory area Use the INDEX parameter to specify the memory area. W#16#0F13: SZL partial list header information only
INDEX	Memory area specification (for SZL-ID W#16#0113 only) W#16#0001: Work memory
LENGTHDR	W#16#0024: 1 data record comprises 18 words (36 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy13 is structured as follows:

Name	Length in Words	Description
Index	1	Index of a memory area W#16#0001: Work memory
Code	1	Memory type: W#16#0001: Volatile (RAM) W#16#0002: Non-volatile (FEPROM) W#16#0003: Mixed (RAM and FEPROM)
Size	2	Total size of the selected memory (sum of Area1 and Area2)
Mode	1	Logical memory mode Bit 0: Volatile memory Bit 1: Non-volatile memory Bit 2: Mixed memory For work memory: Bit 3: Code and data separate Bit 4: Code and data together
Granu	1	Always 0
Ber1	2	Size of the volatile memory area in bytes
Belegt1	2	Size of the volatile memory area being used
Block1	2	Largest free block in the volatile memory area If 0: No information available or information cannot be ascertained
Ber2	2	Size of the non-volatile memory area in bytes
Belegt2	2	Size of the non-volatile memory area being used
Block2	2	Largest free block in the non-volatile memory area If 0: No information available or information cannot be ascertained

D.8 SZL-ID W#16#xy14 - System Areas

Purpose

The partial list with the SZL-ID W#16#xy14 provides information the system areas of the module.

Header

The header of the partial list with SZL-ID W#16#xy14 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0014: All system areas for a module W#16#0114: One system area, use the INDEX parameter to specify the system area. W#16#0F14: SZL-partial list header information only
INDEX	For W#16#0114 only W#16#0001: PII (number in bytes) W#16#0002: PIQ (number in bytes) W#16#0003: Memory (number) W#16#0004: Timers (number) W#16#0005: Counters (number) W#16#0006: Number of bytes in the logical address space W#16#0007: Size of the entire local data area of the CPU in bytes
LENGTHDR	W#16#0008: 1 data record comprises 4 words (8 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy14 is structured as follows:

Name	Length in Words	Description
Index	1	Index for the system area W#16#0001: PII (number in bytes) W#16#0002: PIQ (number in bytes) W#16#0003: Memory (number) W#16#0004: Timers (number) W#16#0005: Counters (number) W#16#0006: Number of bytes in the logical address area W#16#0007: Size of the entire local data area of the module in bytes)
code	1	Memory type W#16#0001: Volatile (RAM) W#16#0002: Non-volatile (FEPROM) W#16#0003: Mixed (RAM and FEPROM)

Name	Length in Words	Description
anzahl	1	Number of elements in the system area
reman	1	Number of retentive elements

D.9 SZL-ID W#16#xy15 - Block Types

Purpose

The partial list with the SZL-ID W#16#xy15 provides information on the block types on the module.

Header

The header of the partial list with SZL-ID W#16#xy15 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0015: Data records for all block types on a module W#16#0115: Data record for one block type Use the INDEX parameter to specify the block type. W#16#0F15: SZL-partial list header information only
INDEX	Only for SZL-ID W#16#0115: W#16#0800: OB W#16#0A00: DB W#16#0B00: SDB W#16#0C00: FC W#16#0E00: FB
LENGTHDR	W#16#000A: 1 data record comprises 5 words (10 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy15 is structured as follows:

Name	Length in Words	Description
Index	1	Block type number W#16#0800: OB W#16#0A00: DB W#16#0B00: SDB W#16#0C00: FC W#16#0E00: FB
MaxAnz	1	Maximum number of blocks of the specified type For OBs: Max. possible number of OBs for one CPU For DBs: Max. possible number of DBs, including DB0 For SDBs: Max. possible number of SDBs, including SDB2 For FCs and FBs: Max. possible number of loadable blocks
MaxLng	1	Maximum total size of the load object in Kbytes
Maxabl	2	Maximum length of a block's work memory in bytes

D.10 SZL-ID W#16#xy22 - Interrupt Status

Purpose

The partial list with the SZL-ID W#16#xy22 provides information on the current status of interrupt processing and the interrupts generated by the module.

Header

The header of the partial list with SZL-ID W#16#xy22 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0222 Data record for the specified interrupt. Use the INDEX parameter to specify the interrupt. W#16#0F22 SZL-partial list header information only
INDEX	Interrupt class or OB No. (for SZL-ID W#16#0222) W#16#0001: Free cycle (OB 1) W#16#5050: Asynchronous fault interrupt (OB 80)
LENGTHDR	W#16#001C: 1 data record comprises 14 words (28 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy22 is structured as follows:

Name	Length	Description
info	10 words	Start information for the relevant OB, with the following exceptions: <ul style="list-style-type: none"> If OB1: Info shows the minimum and maximum cycle times If OB80: Info shows the configured minimum and maximum cycle times
al1 to 3	4 Words	Reserved

D.11 SZL-ID W#16#xy24 - Operating Mode and Operating Mode Transition

Purpose

The partial list with the SZL-ID W#16#xy24 provides information on a module's operating modes.

Header

The header of the partial list with SZL-ID W#16#xy24 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0024 All mode changes saved on the module W#16#0124 Information on the last operating mode transition W#16#0424 Processed operating mode transition W#16#0524 Specified operating mode transition Use the INDEX parameter to specify the operating mode. W#16#0F24 SZL-partial list header information only
INDEX	Use the INDEX parameter to specify the operating mode. W#16#5000: STOP mode W#16#5010: STARTUP mode W#16#5020: RUN mode W#16#5030: HOLD mode W#16#4520: DEFECT mode
LENGTHDR	W#16#0014: 1 data record comprises 10 words (20 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xy24 is structured as follows:

Name	Length in Words	Description
Info	10	Mode or mode transition information

Mode Transition Information

The information provided for an operating mode transition comprises 20 bytes, and is structured as follows:

Name	Length	Description
ereig	1 Word	Possible event-ID W#16#4xy?
ae	1 Byte	B#16#FF
bzü-id	1 Byte	Operating mode transition ID (OMT-ID), divided into 4 bits Bit 0 to 3: Requested operating mode Bit 4 to 7: Previous operating mode IDs of the requested or previous operating modes: 1H: STOP (update) 2H: STOP (memory reset) 3H: STOP (self-initialization) 4H: STOP (internal) 6H: Startup (complete restart) 7H: Restart 8H: RUN AH: HOLD DH: DEFECT
res	2 Words	Reserved
anlinfo 1	1 Byte	Bit 0: Auxiliary start bit = 0: No difference in expected and actual configuration = 1: Difference in expected and actual configuration Bits 5 and 4: Multiprocessor mode = 00B: Single processor mode = 01B: Multiprocessor mode
anlinfo 2	1 Byte	B#16#01: Automatic complete restart in multiprocessor mode B#16#03: Complete restart set at mode selector B#16#04: Complete restart via communication function B#16#0A: Automatic restart in multiprocessor mode B#16#0B: Manual restart set at mode selector B#16#0C: Restart via communications function B#16#10: Automatic complete restart after battery-backed power on B#16#20: Automatic complete restart after non battery backed power on (with memory reset by system) B#16#A0: Automatic restart after battery backed power on according to parameter assignment (only S7-400)

Name	Length	Description
anlinfo 3	1 Byte	Permissibility of certain restart modes B#16#?0: Manual restart not allowed (memory reset requested) B#16#?1: Manual restart not allowed, parameter modification, etc., required B#16#?7: Manual complete restart permitted B#16#?F: Manual complete restart and manual restart permitted B#16#0?: Automatic restart not allowed (memory reset requested) B#16#1?: Automatic restart not allowed, parameter modification, etc., required B#16#7?: Automatic complete restart permitted B#16#F?: Automatic complete restart and automatic restart permitted
anlinfo 4	1 Byte	Last valid operation or setting of the automatic startup type at power on B#16#?0: No startup type B#16#?1: Complete restart in multiprocessor mode B#16#?3: Manual complete restart via mode selector B#16#?4: Complete restart via communications function B#16#?A: Restart in multiprocessor mode B#16#?B: Manual Restart via mode selector B#16#?C: Restart via communications function B#16#0?: No operator entry B#16#1?: Automatic complete restart after battery-backed power on B#16#2?: Automatic complete restart after non battery backed power on (with memory reset by the system) B#16#A?: Automatic restart after battery backed power on according to parameter assignment (only S7-400)
time	4Words	Time stamp

Operating Mode Transition Information

The information on an operating mode transition comprises 20 bytes and is structured as follows:

Name	Length	Description
ereig	1 Word	Possible event ID W#16#5xy?
ae	1 Byte	B#16#FF

Name	Length	Description
bz-id	1 Byte	Operating mode ID: B#16#01: STOP (update) B#16#02: STOP (memory reset) B#16#03: STOP (self-initialization) B#16#04: STOP (internal) B#16#06: Complete restart B#16#07: Restart B#16#08: RUN B#16#0A: HOLD B#16#0D: DEFECT
res	4Words	Reserved
time	4Words	Time stamp

D.12 SZL-ID W#16#xy32 - Communication Status Data

Purpose

The partial list with the SZL-ID W#16#xy32 contains the status data of module communication.

Header

The header of the partial list with SZL-ID W#16#xy32 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0132 Status data for one communication section of the module. Use the INDEX parameter to specify the communication section . W#16#0F32 SZL partial list header information only
INDEX	Only for SZL-ID W#16#0132: Communication section W#16#0001 General communication data W#16#0005 Diagnostics W#16#0008 Time system
LENGTHDR	W#16#00028: 1 data record comprises 20 words (40 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with the SZL-ID W#16#0132 always comprises 20 words. The contents of the data records depend on the INDEX parameter, that is, on the communication component to which a data record belongs.

D.13 Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0001

Contents

The partial list extract with the SZL-ID W#16#0132 and the index W#16#0001 contains general communication status data.

Data Record

A data record of the partial list extract with the SZL-ID W#16#0132 and the index W#16#0001 is structured as follows:

Name	Length in Words	Description
Index	1	W#16#0001: General communication status data
res pg	1	Guaranteed number of PG connections
res os	1	Guaranteed number of OS connections
u pg	1	Current number of PG connections
u os	1	Current number of OS connections
proj	1	Current number of configured connections
auf	1	Current number of connections established by proj
free	1	Number of free connections
used	1	Number of free connections used
last	1	Maximum configured communications load on the CPU in %
res	10	Reserved

D.14 Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0005**Contents**

The partial list extract with the SZL-ID W#16#0132 and the index W#16#0005 contains information on the module's diagnostic status.

Data Record

A data record of the partial list extract SZL-ID W#16#0132 with index W#16#0005 is structured as follows:

Name	Length in Words	Description
Index	1	W#16#0005: Diagnostics
erw	1	Expanded functions 0: No 1: Yes
send	1	Automatic sending 0: No 1: Yes
moeg	1	Sending of user-defined diagnostic messages currently possible 0: No 1: Yes
res	15	Reserved

D.15 Data Record for the Partial List Extract with SZL-ID W#16#0132, Index W#16#0008

Contents

The partial list extract with the SZL-ID W#16#0132 and the index W#16#0008 contains information on the status of the module's time system.

Data Record

A data record of the partial list extract SZL-ID W#16#0132 with index W#16#0008 is structured as follows:

Name	Length in Words	Description
Index	1	W#16#0008: Time system status
zykl	1	Cycle time of the synchronization frames
korr	1	Correction factor for time-of-day
clock 0	1	Run-time meter 0: Time in hours
clock 1	1	Run-time meter 1: Time in hours
clock 2	1	Run-time meter 2: Time in hours
clock 3	1	Run-time meter 3: Time in hours
clock 4	1	Run-time meter 4: Time in hours
clock 5	1	Run-time meter 5: Time in hours
clock 6	1	Run-time meter 6: Time in hours
clock 7	1	Run-time meter 7: Time in hours
time	4	Current date and time (format: date_and_time)
res	5	Reserved

D.16 SZL-ID W#16#xy91 - Module Status Information

Purpose

The partial list with the SZL-ID W#16#xy91 provides module status information.

Header

The header of the partial list with SZL-ID W#16#xy91 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract W#16#0991 Status information of a DP master system W#16#0A91 Status information of all DP master systems W#16#0C91 Status information of a module in the central rack or connected to DP via the logical base address W#16#0D91 Module status information of all modules in the specified rack/in the specified station (DP) W#16#0F91 SZL-partial list header information only
INDEX	<ul style="list-style-type: none"> for the partial list extract with SZL-ID W#16#0C91: Bit 0 to 14: Logical base addresss of the module Bit 15: 0 = input, 1 = output For the partial list extract with SZL-ID W#16#0991: High byte: Subsystem-ID, Low byte: 0 for the partial list extract with SZL-IDs W#16#0D91: W#16#00xxAll modules and submodules in a rack (xx contains the number of the rack)
LENGTHDR	W#16#0010: 1 data record comprises 8 words (16 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with ID W#16#xy91 is structured as follows:

Name	Length in Words	Description
geoadr1	1	Number of the rack for W#16#0A91 (DP master system ID and station number with DP, geographical address)
geoadr2	1	Slot and submodule slot
logadr	1	First assigned logical I/O address (base address)
solltyp	1	Expected module type
isttyp	1	Actual module type
alarm	1	Reserved

Name	Length in Words	Description
eastat	1	I/O status Bit 0 = 1: Module fault (detected via diagnostic interrupt) Bit 1 = 1: Module available Bit 2 = 1: Module not available (detected as access error) Bit 5 = 1: Module can be host module for submodules Bit 6 = 1: Reserved for S7-400 Bit 7 = 1: Module in local bus segment Bit 8 to 15: Data identifier for logical address (Input: B#16#B4, Output: B#16#B5) external DP interface: B#16#FF)
ber_bgbr	1	Area identifier/module width Bit 0 to 2 : Module width Bit 4 to 6 : Area identifier 0 = M7-400 1 = M7-300 2 = ET area 3 = P area 4 = O area 5 = IM3 area 6 = IM4 area

geoadr1

The geoadr1 parameter contains

- when installed centrally, the rack number.




Figure D-2 Contents of the geoadr1 Parameter when Installed Centrally

- with a distributed configuration
 - the DP master system ID
 - the station number.




Figure D-3 Contents of the geoadr1 Parameter in a Distributed Configuration

geoadr2

The geoadr2 parameter contains the slot and the submodule slot




Figure D-4 Contents of the geoadr2 Parameter

D.17 SZL-ID W#16#xy92 - Rack/Station Status Information

Purpose

The partial list with the SZL-ID W#16#xy92 provides information on the expected and the current hardware configuration of centrally installed racks and stations of a DP master system.

Header

The header of the partial list with SZL-ID W#16#xy92 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract: W#16#0092: Expected status of the central racks/stations of a DP master system W#16#0292: Actual status of the central racks/stations of a DP master system W#16#0692: OK state of the expansion racks in the central configuration / of the stations of a DP master system W#16#0F92: SZL partial list header information only
INDEX	=0: Information on the rack in the centralized configuration ≠ 0 (=DP master system ID): Information on stations in the distributed I/O area
LENGTHDR	W#16#0010: Data record comprises 8 words (16 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with ID W#16#xy92 is structured as follows:

Contents	Length	Description
status	8 Words	Rack status/station status or backup status. The bits are allocated as follows to the racks: Bit 0: Central rack Bit 1-21: 1st to 21st expansion unit Bit 22-29: always 0 Bit 30: Expansion unit failure in a SIMATIC S5 Bit 31 to 127: Always 0 If you have selected INDEX not equal to 0, the following assignment of bits to stations (DP master system) applies: Bit 0: Station 1 Bit 1: Station 2 : : Bit 127: Station 128 W#16#0092: Bit=0: Rack/station not configured Bit=1: Rack/station configured W#16#0292: Bit=0: Rack/station failed or not configured Bit=1: Rack/station configured and has not failed Bit=1: Rack/station configured W#16#0692: Bit=0: all modules of the expansion rack/of a station exist, are available and no problems Bit=1: at least 1 module of the expansion rack/of a station is not OK

D.18 SZL-ID W#16#xyA0 - Diagnostic Buffer

Purpose

The partial list with the SZL-ID W#16#xyA0 lists the entries in a module's diagnostic buffer.

Header

The header of the partial list with SZL-ID W#16#xyA0 is structured as follows:

Contents	Description
SZL-ID	SZL-ID of the partial list extract: W#16#00A0: All entries possible in the current mode W#16#01A0: The most recent entries; use the INDEX parameter to specify how many of the most recent entries. W#16#0DA0: All diagnostic entries (in STOP mode only) W#16#0EA0: All user entries (in STOP mode only). With the <i>M7WriteDiagnose</i> call, you can define your own entries in the range A000H to BFFFH. W#16#0FA0: SZL-partial list header information only
INDEX	Only for SZL-ID W#16#01A0: Number of the most recent entries
LENGTHDR	W#16#0014: 1 data record comprises 10 words (20 bytes)
N_DR	Number of data records

Data Record

A data record in the partial list with SZL-ID W#16#xyA0 is structured as follows:

Name	Length in Words	Description
ID	1	Event ID
info	5	Information on the event or its effect
time	4	Time stamp of the event

Diagnostic Buffer

You obtain more information about the events in the diagnostic buffer using STEP 7.

D.19 SZL-ID W#16#00B1 - Module Diagnostic Information

Purpose

The partial list with the SZL-ID W#16#00B1 lists the first four diagnostic bytes (diagnostic data record DS0) for a module with diagnostic capabilities.

Header

The header of the partial list with SZL-ID W#16#00B1 is structured as follows:

	Description
SZL-ID	W#16#00B1
INDEX	Bit 0 to 14: Logical base address Bit 15: 0 for input, 1 for output
LENGTHDR	W#16#0004: 1 data record comprises 2 words (4 bytes)
N_DR	1

Data Record

A data record in the partial list with SZL-ID W#16#00B1 is structured as follows:

Name	Length	Description
byte1	1 Byte	Bit 0: Module malfunction/OK (group fault signal) Bit 1: Internal fault Bit 2: External fault Bit 3: Channel fault Bit 4: No external auxiliary power source Bit 5: No front connector Bit 6: Module not assigned parameters Bit 7: Invalid parameters on module
byte2	1 Byte	Bit 0 to Bit 3: Module class (CPU, FM, CP, IM, SM, etc.) Bit 4: Channel information available Bit 5: User information available Bit 6: Diagnostic interrupt from standby Bit 7: Reserve (initialized with 0)

Name	Length	Description
byte3	1 Byte	Bit 0: No user module/wrong user module Bit 1: Communication fault Bit 2: RUN/STOP mode (0 = RUN, 1 = STOP) Bit 3: Response from watchdog Bit 4: Internal module power supply failure Bit 5: Battery exhausted (BFS) Bit 6: Complete backup failure Bit 7: Reserve (initialized with 0)
byte4	1 Byte	Bit 0: Expansion rack failure (detected by IM) Bit 1: Processor failure Bit 2: EPROM error Bit 3: RAM error Bit 4: ADC/DAC error Bit 5: Fuse blown Bit 6: Hardware interrupt lost Bit 7: Reserve (initialized with 0)

D.20 SZL-ID W#16#00B2 - Diagnostic Data Record 1 with Geographical Address

Purpose

The partial list with the SZL-ID W#16#00B2 provides the diagnostic data record 1 of a module in a central (not for DP submodules.) The module is specified by its rack and slot number.

Header

The header of the partial list with SZL-ID W#16#00B2 is structured as follows:

Contents	Description
SZL-ID	W#16#00B2
INDEX	W#16#xyy: xx contains the rack number yy contains the slot number
LENGTHDR	The length of the data record depends on the module
N_DR	1

Data Record

The size of a data record in the partial list with the SZL-ID W#16#00B2 and its contents depend on the module in question.

For further information, please refer to Appendix E or to the module manual.

D.21 SZL-ID W#16#00B3 - Module Diagnostic Data via Logical Base Address**Purpose**

The partial list with the SZL-ID W#16#00B3 supplies all diagnostic data (diagnostic data record DS1) of a module. This inquiry function is also possible with distributed I/O and submodules. The module can be selected via its logical base address.

Header

The header of the partial list with SZL-ID W#16#00B3 is structured as follows:

Contents	Description
SZL-ID	W#16#00B3
INDEX	Bit 0 to 14: Logical base address Bit 15: 0 for input, 1 for output
LENGTHDR	Length of a data record (module-dependent)
N_DR	1

Data Record

The size of a data record for the partial list with the SZL-ID W#16#00B3 and its contents depend on the module in question. For further information, please refer to Appendix E or to the module manual.

D.22 SZL-ID W#16#00B4 – Diagnostic Data of a DP Slave

Purpose

The partial list with the SZL-ID W#16#00B4 supplies all diagnostic data of a DP slave. These diagnostic data are structured in accordance with EN50170 Volume 2, PROFIBUS. You select the module via its configured diagnostic address.

Header

The header of the partial list with the SZL-ID W#16#00B4 is structured as follows:

Contents	Description
SZL-ID	W#16#00B4
INDEX	Configured diagnostic address of the DP slave
LENGTHDR	Length of a data record. The maximum length is 240 bytes. For standard slaves which have a diagnostic data length of more than 240 bytes up to a maximum of 244 bytes, the first 240 bytes are read and the overflow bit is set in the data.
N_DR	1

Data Record

A data record of the partial list with the SZL-ID W#16#00B4 is structured as follows:

Name	Length	Meaning
status1	1 Byte	Station status 1
status2	1 Byte	Station status 2
status3	1 Byte	Station status 3
stat_nr	1 Byte	Master station number
ken_hi	1 Byte	Vendor ID (high byte)
ken_lo	1 Byte	Vendor ID (low byte)
....	Further slave-specific diagnostics

Diagnostic Data

This appendix describes the structure and contents of the diagnostic data for M7-300/400 modules.

Data Records 0 and 1 of the System Data

The diagnostic data of a module are found in the data records 0 and 1 of the system data area:

- Data record 0 contains 4 bytes of diagnostic data which describe the current status of a signal module or a function module.
- Data record 1 contains
 - The 4 bytes of diagnostic data which are also in data record 0 and
 - The module-specific diagnostic data

Structure and Content of the Diagnostic Data

This section describes the structure and content of the individual bytes of the diagnostic data.

In general, the following applies: if an error occurs, the corresponding bit is set to "1".

Table E-1 Structure and Content of the Diagnostic Data

Byte	Bit	Meaning	Comment		
0	0	Module fault			
	1	Internal fault			
	2	External fault			
	3	Channel fault			
	4	External auxiliary voltage missing			
	5	Front connector missing			
	6	Parameter assignment error			
	7	Wrong parameters in module			
1	0 to 3	Module class	0101 0000 1000 1100 1111	Analog module CPU Function module CP Digital module	
	4	Channel information available			
	5	User information available			
	6	Diagnostic interrupt from deputy			
	7	0			
	2	0	Memory module incorrect or missing		
		1	Communication fault		
		2	Operating mode	0 1	RUN STOP
3		Cycle time monitoring addressed			
4		Module-internal supply voltage failed			
5		Battery exhausted			
6		All backup failed			
7		0			
3	0	Rack failure			
	1	Processor failure			
	2	EPROM fault			
	3	RAM fault			
	4	ADC/DAC fault			
	5	Fuse blown			
	6	Hardware interrupt lost			
	7	0			

Table E-1 Structure and Content of the Diagnostic Data, continued

Byte	Bit	Meaning	Comment	
4	0 to 6	Channel type	B#16#70 B#16#71 B#16#72 B#16#73 B#16#74 B#16#75 B#16#76 B#16#77 B#16#78 B#16#79 to B#16#7D B#16#7E B#16#7F	Digital input Analog input Digital output Analog output FM-POS FM-REG FM-ZAEHL FM-TECHNO FM-NCU Reserved US300 Reserved
	7	Other channel type?	0 1	No Yes
5	0 to 7	Number of diagnostic bits output by a module per channel		
6	0 to 7	Number of module channels of the same type	If different channel types exist on a module, the structure from byte 4 onwards is repeated for each channel type in data record 1	
7	0	Channel fault channel 0/channel group 0		First byte of the channel fault vector. (The length of the channel fault vector depends on the number of channels and is rounded up to a byte boundary.)
	1	Channel fault channel 1/channel group 1		
	2	Channel fault channel 2/channel group 2		
	3	Channel fault channel 3/channel group 3		
	4	Channel fault channel 4/channel group 4		
	5	Channel fault channel 5/channel group 5		
	6	Channel fault channel 6/channel group 6		
	7	Channel fault channel 7/channel group 7		
...	–	Channel-specific fault		

Channel-Specific Faults

From the byte immediately behind the channel fault vector onwards, the channel-specific faults are displayed for each channel of the module. The following bit assignments apply:

- 1 = fault
- 0 = no fault

You will find the structure of the channel-specific diagnostics for the different channel types in Appendix A, "Diagnostic Data" in the "System Software for S7-300 and S7-400, System and Standard Functions" manual.

Channel Type for M7 FMs

For the application modules FM 356-4 and FM 456-4 the channel type (bit 0 to 6 of byte 4) must be set to equal 0x77 (FM-TECHNO).

Glossary

Client Server Principle

In data interchange based on the client-server principle, the client always submits the requests and the server carries them out.

Device

RMOS handles input/output operations using special programs called driver programs, or just called drivers for short, and their subsets, which are called units. Which drivers are available to an operating system is determined when the system is configured. The operating system identifies the drivers by a number referred to as the device ID.

Dummy

Also called a wildcard or joker. A symbol used as spaceholder: “*” stands for a group of letters or digits, “?” stands for a single alphanumeric character.

Job

Programs and commands started by the CLI (RMOS's **Command Line Interpreter**).

Main Directory

In the HSFS, files are stored in directories. These directories form a hierarchical structure in the HSFS. The main directory, also referred to as the root directory, is a volume's highest directory. A volume (partition) has only one root directory.

MS-DOS System Memory

RAM memory from 0 to 640 Kbytes which can be under the control of MS-DOS.

PIC

Programmable **I**nterrupt **C**ontroller.

SMR

System **M**emory **R**esource, a system memory block provided by the nucleus for internal management purposes.

Subdirectory

All directory on a volume which are not root directories are subdirectories. Each subdirectory must be given a name which is unique in the directory in which they were created.

SVC

Supervisor **C**all.

TCB

Task **C**ontrol **B**lock, a table containing the current dynamic data for controlling a task.

TCD

Task **C**ontrol **D**ata, a table containing default values, is created during configuring for a static task and by the loader for a dynamic task.

Unit

Input/output device. Drivers address one or more units. Which units can be addressed by a given driver is defined when the driver is configured. The operating system identifies units by a number called the unit ID.

Index

Numbers

3964 Driver, 7-4

A

Address, C-3
Argument, C-3
ASM, C-7

B

BASE, 6-7, C-9
Block Types, D-11
Boot Medium, 3-6
Boot Procedure, A-7
 RMOS3-DOS, A-12
bootfile, B-33
Breakpoint, C-6, C-47, C-51
Breakpoint Context, 6-5, C-3, C-15, C-21,
 C-25, C-39, C-47, C-49, C-51, C-55
Breakpoint Number, C-47
BREAKS, C-10

C

CALCULATE, C-11
CALL, C-12
CANCEL, B-5, B-8, B-10
CATALOG, C-16
CD, B-6
CFC Program, 1-1
CHANGE, C-13
Channel Fault, E-2
CHGKBD, B-7
CLI Error Messages, B-43
Communication, Status Data, D-16
configuration files, 3-19
Constant, C-4
CONT, C-14
Context, 6-3, 6-5
CPU Characteristics, D-7
CPU Events, M7-300/400, 4-16
CPU's own SZL, D-28
CPUREG, C-15

D

DATE, B-11
Debug Register, 6-5, C-47
Debug Register Breakpoint, C-6, C-47
DEL, B-12
Delimiter, C-5
DEVICE, B-13
Device Command, 3-24
Device Names, 4-9
Diagnostic Buffer, D-2, D-23, D-25
Diagnostic Data, E-1
 Content, E-1
 of CPU, D-2
 on Modules, D-2
 Structure, E-1
DIR, B-16, C-16
DISMOUNT, B-17
DISPLAY, C-19
Driver, 7-1
 3964, 7-4
 Loading, 7-2
 Removing, 7-3
 SER8250, 7-4

E

ECHO, B-18
ERROR, B-19
Error Handling of RMOS DOS, 1-9
Error Messages, C-58
Escape Context, 6-5, C-39, C-40, C-55
EVALUATE, C-20
Execution Breakpoint, C-6, C-47
EXIT, B-20, C-21
EXITK, 6-5, C-22, C-30
Expression, C-4
External Auxiliary Voltage, Missing, E-2

F

Fault
 Channel, E-2
 External, E-2
 Internal, E-2

File Management System, 1-7, A-8
 RMOS3-DOS, A-13
FILL, C-23
Floating Point Number, 6-8
FORMAT, B-21
Format, C-5
Formatting, M7 PLC Medium, 3-6
FREETASK, C-24
Front Connector, Missing, E-2
FTLFORM, M7 RMOS32, B-22

G

GO, 6-5, C-25

H

HALT, C-26
Hard Breakpoint, C-6, C-47
Hard Disk, Capacity, 5-3
HELP, B-24, C-27
HSFS, 1-7

I

IN, C-28
In-line Commands, 4-4
INHIB, 6-5, C-29
INITTAB file, 3-26
Installation, 2-1
 Hardware Prerequisites, 2-1
 Setup, 2-1
 Software Prerequisites, 2-2
Installation on PC or PG, 2-1
Interrupt Satus, D-12

J

Job, 4-6

K

KILL, C-30

L

LINES, C-31
Loadable Driver, File RMOS.INI, 3-24
Loader Result Segment, C-32

LOADTASK, C-32

M

M7 Operating System
 Installation, 3-2
 Selection, 3-4
M7 PLC System
 Boot Medium, 3-6
 Target Medium, 3-2, 3-4
M7 Program
 Deleting, 4-14
 Starting, 4-15
 Transferring to the M7 programmable
 controller, 4-10
 Transferring via Data Carrier, 4-13
 Transferring via MPI, 4-12
M7 RMOS32, Installing on Memory Card, 3-8
M7-300/400, Operating Systems, 1-4
MD, B-25
Memory Areas, D-8
Memory Format, C-4, C-13, C-23
Module Diagnostic Data, D-27
Module Diagnostic Info, D-26
Module Fault, E-2
Module Identification, D-6
Module Status, M7-300/400, 4-16
Module Status Information, D-20
Module Type Class, D-4
MONITOR, C-34
Monitor Mode, 6-2
Monitor/modify Variable, M7-300/400, 4-17
MOUNT, B-26

N

NPX, B-27
Number Notation, 6-8
Numerical Base, 6-7, 6-8

O

Operating Mode, D-13
Operating Mode Transition, D-13
Optional Packages, 1-2
OUT, C-35

P

Parameter, Wrong Parameters in the Module, E-2
 Parameter Assignment, Error, E-2
 Partitioning, 5-5
 Pass Counter, C-36, C-47
 PATH, B-28
 Performance Features, A-2
 PING, B-30
 Privilege Violations, RMOS DOS, 1-9
 PROMPT, B-31

Q

QUALIFY, C-36
 QUERY, C-37

R

RD, B-32
 RDISK, B-33
 Read-after-write Control, C-13, C-23
 Redirection, 4-8
 REGS, C-39
 Reloadable Commands, 4-4
 REMAP_A, 5-11
 RENAME, B-34
 Repetition Factor, 6-7
 REPORT, C-41
 Resource Reporter, C-41
 Resources, RMOS3-DOS, A-12
 Restart, RMOS DOS, 1-9
 RM3PMEM.SYS, A-16
 RM3RESET.SYS, A-13, A-17
 RMOS.INI file, 3-23
 Runtime Environment, under CLI, 4-4

S

Segment Descriptor, C-3
 Segment Register, C-3
 Segment/Selector, C-19
 Selector, C-3

SER8250 Driver, 7-4
 SESSION, B-37
 SET, B-38, C-47
 Single-step Interrupt, 6-4
 Single-step Mode, C-47, C-51
 Soft Breakpoint, C-6, C-25, C-47
 STACK, C-49
 START, B-39, C-50
 STEP, C-51
 stl_load, C-32
 SVC, C-52
 SWITCH, C-54
 SYSTAT, B-40
 System Areas, D-10
 System Console, File RMOS.INI, 3-24
 System Data, D-2
 System Status List, D-2
 Sublists, D-5
 SZL, D-2, D-3
 Sublists, D-5
 SZL-ID, D-4

T

TASK, C-55
 Task Control Block, C-56, C-57
 Task ID, C-6
 Task Management, M7 RMOS32-DOS, A-13
 Task Mode, 6-2
 TCB, C-56
 TCD, C-57
 TIME, B-41
 Transfer, M7 Program, 4-12
 Transfer Medium, 4-11
 Type Class, Modules, D-4

V

VER, B-42

W

Watchdog, A-8

Siemens AG
A&D AS E48
Postfach 4848
D-90327 Nürnberg
Federal Republic of Germany

From:

Your Name: -----

Your Title: -----

Company Name: -----

Street: -----

City, Zip Code -----

Country: -----

Phone: -----

Please check any industry that applies to you:

- | | |
|--|---|
| <input type="checkbox"/> Automotive | <input type="checkbox"/> Pharmaceutical |
| <input type="checkbox"/> Chemical | <input type="checkbox"/> Plastic |
| <input type="checkbox"/> Electrical Machinery | <input type="checkbox"/> Pulp and Paper |
| <input type="checkbox"/> Food | <input type="checkbox"/> Textiles |
| <input type="checkbox"/> Instrument and Control | <input type="checkbox"/> Transportation |
| <input type="checkbox"/> Nonelectrical Machinery | <input type="checkbox"/> Other ----- |
| <input type="checkbox"/> Petrochemical | |

Remarks Form

Your comments and recommendations will help us to improve the quality and usefulness of our publications. Please take the first available opportunity to fill out this questionnaire and return it to Siemens.

Please give each of the following questions your own personal mark within the range from 1 (very good) to 5 (poor).

- 1. Do the contents meet your requirements?
- 2. Is the information you need easy to find?
- 3. Is the text easy to understand?
- 4. Does the level of technical detail meet your requirements?
- 5. Please rate the quality of the graphics/tables:
- 6.
- 7.
- 8.

Additional comments:

