SIEMENS

Low Voltage Power Circuit Breaker

UL 1066 Circuit Breaker

WL Circuit Breaker

Operating Instructions

Catalog No.: CBIM-02000-0119





NOTE

These instructions do not purport to cover all details or variations in equipment, or to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise, which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Siemens sales office. The contents of this instruction manual shall not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligation of Siemens. The warranty contained in the contract between the parties is the sole warranty of Siemens. Any statements contained herein do not create new warranties or modify the existing warranty.

TRADEMARKS

Unless otherwise noted, all names identified by (b) are registered trademarks of Siemens AG or Siemens Industry, Inc. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Symbols

	Visual examination
S	Hook
	Slotted-type screwdriver
	Cruciform screwdriver Philips (PH), PoziDriv (PZ)
	Torx screwdriver (T)
	Hex socket screwdriver
V	Open end wrench
ک ک 10 Nm 89 lb-in	Tightening torque
Ô	Cable tie
×	Add in writing
1	First step of action sequence

Contents

1	Overview 1-1 Circuit Breaker 1-1 Cradle 1-2
2	Labels2-1Circuit breaker frame accessory label2-1Circuit breaker frame type label2-1Frame designation2-2Trip unit designation2-2Rating Plug label2-3Cradle type label2-3
3	Standard specifications 3-1
4	Packing and Lifting4-1Unpacking4-1Weights4-1Lifting with a crane4-2Lifting with a Lifting Bar Assembly4-3Lifting bar assembly (3-pole)4-3Lifting bar assembly (4-pole)4-3Lifting the circuit breaker4-4Lifting the fuse carriage (frame size III)4-4
5	Installation5-1Mounting5-2Mounting position5-2Mounting on horizontal surface -Mounting tolerances5-3Cubicle and ventilation5-4Main terminal connections5-5Cradle connections5-5Horizontal connections for 4-pole fixed mount breakers5-5Bus connections to the cradle5-6Application and configuration of fused circuit breakers5-8Secondary wiring5-10Breaker Secondary Disconnects5-11Cradle Secondary Disconnect Blocks5-12Secondary disconnect terminal blocks5-13Wiring in cradle5-14Catalog numbers5-15
6	Commissioning6-1Preparation of draw-out circuit breaker6-1Inserting the circuit breaker into the cradle6-1Positions of the circuit breaker in the cradle6-2Unlocking the racking handle /6-3Withdrawing the racking handle6-3Racking circuit breaker into connected position6-3Inserting racking handle6-3Charge the closing spring6-4Check list for commissioning6-6Closing the circuit breaker6-7Opening the circuit breaker6-7Tripping6-8Reclosing a circuit breaker tripped by the trip unit6-9Re-commissioning after fused tripping (Not applicable for 4-6-11

Measures	11
Replacing the fuses6-	13
Removing from service6-	18
Troubleshooting6-	19
Frame sizes / dimension drawings	7_1
Frame size II Drawout (3-Pole and 4-Pole)	7_1
Frame size II fused	7-5
Frame size II fixed-mounted version	7-8
Frame size II, door cut-outs	7_0
Frame size III, fixed-mounted version	10
Frame size III, fixed-mounted version	11
Frame size III fuse carriage	14
Frame size III. door out-outs	16
External sensor for neutral conductor	18
External sensor for neutral conductor	20
	20
Circuit diagrams	3-1
Terminal assignment	3-1
Auxiliary switches	3-2
Signaling switches	3-3
Shunt Trip, Undervoltage Trip / Electrical closing lockout .8	3-4
Closing Coil / Electrical CLOSE	3-5
Motor-operated mechanism	3-6
Remote Bell Alarm Reset	3-6
Trip unit circuitry for ETU745-776	3-7
With Breaker Status Sensor (BSS)	
and metering module	3-7
Metering module only	3-8
Breaker Status Sensor (BSS) only	3-9
Electronic components	9-1
Trip units	9-1
Overview of function	9-1
Trip unit ETU745	9-2
Trip unit ETU776	9-7
Indicators	9-9
Protective functions9-	11
ETU displays9-	17
Rating Plug9-	43
Ground-fault protection modules	44
Replace the trip unit	49
Internal trip unit self-test on	
the overcurrent tripping function	51
Sealing and locking device9-	53
CubicleBUS Modules9-	54
System architecture9-	54
Internal modules9-	55
External CublicleBUS modules9-	83
External sensor for neutral conductor9-	97
External voltage supply9-	98
Handheld test device9-	99
View	99
Preparations9-	99
Connecting	00
Voltage supply	00
Operation	00
Einiching	02

7

8

9

10	Reset the reclosing lockout and the Bell Alarm Resetting the Bell Alarm Resetting the Bell Alarm with reclosing lockout (optional) Field Installation of a reclosing lockout Removing the automatic reset mechanism Installing the remote Bell Alarm reset Mounting remote reset coil and cut-off switch Connecting wires Function test Updating the options label	10-1 10-2 10-3 10-4 10-5 10-5 10-6 10-7 10-7
11	Shunt Trip / Closing Coil / Undervoltage release Overview Installing shunt trips, closing coils, and undervoltage dev 11-2 Installing optional signaling switches on shunt trips, closi coils, and undervoltage devices Setting delay times on undervoltage release Field Installation of a cut-off switch for shunt trips and closing coils Mechanical function test Connecting wires Final tasks Electrical function test Updating the options label	11-1 11-1 ices 11-3 11-3 11-3 11-4 11-6 11-6 11-7 11-7 11-7
12	Auxiliary and control switches Installing internal auxiliary switches S1 - S4 Installing the "Ready-to-close" switch S20 Trip Signaling Switches Trip Signaling Switches S13, S24, and S26 Control switches - Connecting wires Communication switches Connecting secondary wiring Updating the options label Mechanism Operated Contacts (MOC) MOC Versions Order numbers Order numbers 1 Combination of MOC and mechanical interlocking module 1 Mounting of MOC and mechanical interlocking module on the cradle	12-1 12-2 12-3 12-4 12-5 12-6 12-6 12-6 12-6 12-7 12-8 12-8 2-13 2-14 2-14
13	Motor-operated mechanism Installing the motor operator Optional motor disconnect switch on the front panel Updating the options label	13-1 13-1 13-3 13-4
14	Indicators and operating elements Limiting Access to OPEN/CLOSE Buttons EMERGENCY OPEN button Operations counter	14-1 14-1 14-3 14-4
15	Locking devices	15-1 15-1

	Breaker mounted key lock 15-2 Cradle mounted key lock 15-4 Installing racking handle key lock 15-11 Installing a Bell Alarm cover key lock 15-15 Padlocking provisions 15-16 Padlock locking the breaker OPEN 15-17 Optional: Intalling padlocks 15-19 Padlock Locking device for guide rails 15-20 Padlock Locking device for spring charging lever 15-20 Padlock Locking device for spring charging lever 15-20 CLOSE/OPEN padlock kit 15-20
16	Sealing covers16-1
17	Mechanical interlocks 17-1 Field installation of CLOSE / OPEN buttons blocking device 17-2 Cubicle door interlock 17-3 Installing the interlock mechanism to the cradle 17-4 Cubicle door interlock drill pattern 17-4 Installing catch on the cubicle door 17-5
	Function check
	Coding between circuit breaker and cradle
18	Additional options for the cradle 18-1 Shutter 18-1 Field installation 18-2 Catalog numbers 18-4 Truck Operated Contacts - TOC (Cradle Accessory) 18-5
19	Mechanical circuit breaker interlocking 19-1 Configurations 19-1 General notes 19-2 Mechanical interlocking two sources (open transition) 19-3 Mechanical interlocking two sources with a tie circuit breaker (open transition) 19-4 Mechanical interlocking feeder circuit breakers (single load, open transition) 19-5 Mechanical interlocking three sources (open transition to standby system) 19-6 Mechanical interlocking source and tie circuit breaker 19-7 Installing interlocking module 19-8 Fitting interlocking module 19-11 Mounting the Bowden cables 19-12 Evention check 19-14
20	Arc chute covers .20-1 Field installation .20-1 Catalog numbers .20-3
21	Door sealing frame
22	Plexiglas breaker cover

23	Maintenance 23-1 Preparation for maintenance 23-2 Opening the circuit breaker and
	discharging the closing spring
	Removing the circuit breaker from the cradle 23-3
	Changing front panel 23-4
	Removing front panel 23-4
	Reinstalling the front panel 23-4
	Checking arc chutes
	Removing arc chutes 23-6
	Visual inspection 23-6
	Installing arc chutes 23-7
	Catalog numbers 23-8
	Inspection of arc chute covers 23-9
	Checking contact erosion 23-10
	Replacing the internal current sensors 23-11
	Removing vertical adapter 23-13
	Replacing the circuit breaker internal
	contact assemblies 23-21
	Removing front panel 23-22
	Removing arc chutes 23-22
	Removing vertical adapter 23-22
	Removing pole assemblies 23-22
	Installing pole assemblies 23-27
	Adjusting the contact wear indicator 23-32
	Attaching the vertical adapter 23-33

	Order numbers	23-36
	Attaching the front panel	23-37
	Installing the arc chutes	23-37
	Mechanical function test	23-37
	Exchanging the primary disconnects	23-38
	Exchanging the finger cluster	23-38
	Catalog numbers	23-39
	Exchanging the stab tip	23-40
	Catalog numbers	23-41
	Cleaning and greasing the circuit breaker	23-42
	Cleaning and greasing the cradle	23-42
24	Primary injection testingGeneral NotesPrimary Injection Phase Current TestingPrimary Injection Ground Fault Current TestingAchieving Correct External Neutral Sensor Polarity	24-1 24-2 24-4 24-5 24-7
25	Disposal Low-voltage circuit breakers disposal	25-1 25-1
26	Technical Data	26-1
27	Abbreviations	27-1
28	Glossary	28-1
29	Index	29-1

1 Overview

1.1 Circuit Breaker



- (1) Arc chute \rightarrow (page 23-5)
- (2) Carrying handle
- (3) Identification tags
- (4) Motor disconnect switch (option) \rightarrow (page 13-3)
- (5) Circuit breaker type label \rightarrow (page 2-1)
- (6) Spring charge indicator \rightarrow (page 6-7)
- (7) Mechanical "CLOSE" button
- (8) Rated current value
- (9) Racking pictogram
- (10) Make-break operations counter (option)
- (11) Spring charging lever \rightarrow (page 6-4)
- (12) Racking handle
- (13) Racking shaft
- (14) Options label \rightarrow (page 2-1)
- (15) Grounding terminal
- (16) Position indicator \rightarrow (page 6-2)
- (17) Table for ground-fault protection \rightarrow (page 9-12)
- (18) Key lock for racking handle
- (19) Mechanical release of racking handle
- (20) Trip unit \rightarrow (page 9-1)
- (21) Rating Plug
- (22) "OPEN" button or
- "EMERGENCY OPEN" mushroom pushbutton (option)
- (23) "Ready-to-close" indicator \rightarrow (page 6-7)
- (24) Circuit breaker OPEN / CLOSED indicator \rightarrow (page 6-7)
- (25) Tripped indicator (reset button) \rightarrow (page 6-9)
- (26) Locking device "lock OPEN" (option)
- (27) Front panel
- (28) Secondary Disconnects

1.1 Cradle

(with optional accessories)



- (1) Arc chute cover (option)
- (2) Hole for crane hook
- (3) Arc vent openings
- (4) Shutter (option)
- (5) Locking device shutter (standard for shutters)
- (6) Mutual mechanical circuit breaker interlocking (option)
- (7) Locking provision for guide rail
- (8) Door interlock (option)
- (9) Locking device in OPEN position (option)
- (10) Cradle mounted locking device against closing the circuit breaker in disconnect position (option)
- (11) Shutter operating device
- (12) Rejection feature
- (13) Option-related coding
- (14) Secondary disconnects

2 Labels

2.1 Circuit breaker frame accessory label

(with terminal designations)



2.2 Circuit breaker frame type label



- Maximum rated current (1)
- (2) Max. rated operating voltages
- (3) Rated short-circuit breaking capacity
- (4) (5) Manufacturing date
- Instruction book & outline drawings
- (6) Max. rated short-time withstand current
- Rated frequency (7)
- (8) Certifications

2.3 Frame designation



- (1) Type of circuit breaker (WL)
- (2) Siemens interrupting class
- (3) Frame size
- (4) No. of poles(5) Maximum ratio
- (5) Maximum rated continuous current.

2.4 Trip unit designation



- (1) Type
- (2) Catalog number(3) Can be used in t
- (3) Can be used in the following types of circuit breakers
- (4) Regulatory approvals on a separate label

2.5 Rating Plug label



- (1) Catalog number
- (2) Rated current of the circuit breaker
- (3) Regulatory approvals on a separate label

2.6 Cradle type label



- (1) Catalog number
- (2) Rated current and voltage of the cradle
- (3) UL listing mark
 (4) Circuit breakers
- (4) Circuit breakers that can be used with this cradle
- (5) Sales order, production order, cradle identification number

A second type label is attached to the baseplate inside the cradle or on one of its side walls.

3 Standard specifications

	DANGER
	Hazardous voltage.
	Will cause death, serious personal injury, or equipment/property damage.
7.110	Turn off and lock out all power supplying this equipment before working on this device.
* 72	Only qualified personnel should work on this equipment, after becoming thoroughly familiar with all warnings, safety notices, and maintenance procedures contained herein and on the devices.
	The successful and safe operation of this equipment is dependent on proper handling, installation, operation and maintenance.

Qualified Personnel

For the purpose of this instruction manual and these product labels, a "qualified person" is one who is familiar with the installation, construction and operation of the equipment and the hazards involved and who, in addition, has the following qualifications:

a) Is trained and authorized to energize, de-energize, clear, ground and tag circuits and equipment in accordance with established safety practices.

b) Is trained in the proper care and use of protective equipment in accordance with established safety practices.

c) Is trained in rendering first aid.

The circuit breakers are suited for operation in enclosed spaces not subject to operating conditions aggravated by dust, corrosive vapors or gases. Circuit breakers to be installed in dusty or damp locations must be appropriately enclosed.

The circuit breakers are in conformity with the following standards:

- ANSI C37.13
- ANSI C37.16
- ANSI C37.50
- UL 1066

The electronic trip units are in conformity with the following standards:

- ANSI C37.17
- UL 1066

The cradles are in conformity with the following standards:

- ANSI C37.20.1
- ANSI C37.51
- UL 1066

4 Packing and Lifting

4.1 Unpacking

Unpack the circuit breaker and inspect it for damage.

If the circuit breaker or cradle is to be installed at a later date: they may only be stored and redispatched in the original packing.



NOTICE

Equipment Damage.

Placing the circuit breaker on its rear side may cause damage to the finger cluster assemblies.

When handling circuit breakers, do not place them on their rear side.

4.2 Weights

	Weight									
Frame Size	Draw-out ci	rcuit breaker	Fixed Mounted Circuit Breaker	Cra	Circuit Breaker + Cradle					
	3-pole	4-pole	4-pole	3-pole	4-pole	3-pole	4-pole			
II 800 A	159 lb / 72 kg	210 lb / 95 kg	185 lb / 84 kg	112 lb / 51 kg	161 lb / 73 kg	Only lift sepa	arately			
II 1600 A	159 lb / 72 kg	210 lb / 95 kg	185 lb / 84 kg	112 lb / 51 kg	161 lb / 73 kg	Only lift sepa	arately			
II 2000 A	177 lb / 80 kg	227 lb / 103 kg	203 lb / 92 kg	128 lb / 58kg	181 lb / 82 kg	Only lift sepa	arately			
II 3200 A	209 lb / 95 kg	258 lb / 117 kg	229 lb / 104 kg	152 lb / 69 kg	212 lb / 96 kg	Only lift sepa	arately			
II Fused	258 lb / 117 kg	not available	not available	150 lb / 68 kg	not available	Only lift sepa	arately			
III	360 lb / 163 kg	434 lb / 197 kg	426 lb / 193 kg	306 lb / 139 kg	410 lb / 186 kg	Only lift sepa	arately			
III Fuse Carriage	325 lb / 147 kg	not available	not available	306 lb / 139 kg	not available	Only lift sepa	arately			





NOTICE

Lifting a frame size III or frame size II 4-pole cradle with a breaker inside may result in distortion of the cradle.

Remove the frame size III breaker from the cradle before lifting.



4.4.1 Lifting bar assembly (3-pole)



- (1) Locking position for circuit breaker in frame size II
- (2) Locking position for circuit breaker in frame size III
- (3) Receptacle for circuit breaker carrying handle FS II / III
- (4) Receptacle for circuit breaker carrying handle
- (5) Hook for fuse carriage

4.4.2 Lifting bar assembly (4-pole)



- (1) Locking position for circuit breaker in frame size II
- (2) Locking position for circuit breaker in frame size III
- (3) Receptacle for circuit breaker carrying handle FS II / III

NOTE

Always lock the lifting bar assembly symmetrically on both sides.









4.4.4 Lifting the fuse carriage (frame size III)





	Catalog No
Lifting beam for circuit breaker and cradle (3-pole)	WLLFT
Lifting beam for circuit breaker and cradle (4-pole)	WLLFT4
Portable hoist for use with the lifting beam	WLHOIST

5 Installation



A DANGER

Hazardous voltage.

Will cause death, serious personal injury, or equipment damage.

Turn off and lock out all power supplying this equipment before working on this device.



Heavy Equipment.

Improper lifting will cause death, serious personal injury, or equipment/property damage.

Never lift a circuit breaker, fuse carriage, or cradle above personnel. Follow instructions for use of lifting bar assembly. Use OSHA/NIOSH approved crane equipment and personal protection equipment for lifting/moving the circuit breakers and cradles.



High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

5.1 Mounting

5.1.1 Mounting position







5.1.2 Mounting on horizontal surface -Mounting tolerances

The circuit breaker must be mounted on a rigid, level surface, capable of supporting the weight of the breaker, cradle, and associated busbar components. The maximum amount of offset in the mounting plane is 3/64" (1mm).





(1) 4 bolts (5/16" diameter) + belleville washers + nuts

NOTICE

Damage to finger clusters.

Improperly aligned bussing at the terminal connections may affect the position of the bus stabs. Misaligned bus stabs may result in damage to the finger clusters during circuit breaker rack-in.

Do not distort the cradle terminal connections when connecting to the main bus.

5.1.3 **Cubicle and ventilation**



(1) (2) Upper ventilation opening Insulating liner use NEMA GPO-3, min. 0.094" thick or comparable material

(3) Lower ventilation opening

Eramo	Frame	Interrupting Class	Minimal cubicle dimensions			Insulating liner dimensions		Cubicle ventilation		
size	rating (A)		Width W1 (inch)	Height H (inch)	Depth D1 (inch)	Width W2 (inch)	Depth D2 (inch)	Top (square inch)	Bottom (square inch)	
	800									
	1600	N, S, H, L	22	22 .5 ¹⁾	19.5	18.5	10.5	not required		
	2000									
	3200	N, S, H, L	22	22 .5 ¹⁾	19.5	18.5	10.5	55	55 ²⁾	
	800								137 ²⁾	
II Fused	1600	F	22	22.5 ¹⁾	25	18.5	10.5	143		
	2000									
	4000	H, L	шт	20	22 5 ¹)	10.5	00 5	10 5	48	99 ²)
	5000		52	22.0	19.5	20.5	10.5	(2 x 24)	00 /	
III	3200	М	32	30	19.5	28.5	10.5			
	4000							48 (2 x 24)	88 ²⁾	
	5000									
	3200									
III Fused	4000	F	32	22.5 ¹⁾	19.5	28.5	10.5	88	88 ²⁾	
	5000	-								
II 4-pole	1600	N, S, H		22.5 ¹⁾						
	2000		32		19.5	28.5	10.5	not re	quirea	
	3200							55	55 ²⁾	
III 4-pole	5000	H, L	42	22.5 ¹⁾	19.5	39	10.5	48 (2 x 24)	88 ²⁾	

1) Cubicle height given for use with insulating liner on cubicle top or cradles equipped with optional cover

2) Provided by cradle holes

5.2 Main terminal connections

For main terminal dimensions of individual frame sizes, refer to: → Frame sizes / dimension drawings (page 7-1)

The main terminals and connectors are intended for busbar connection with NEMA hole patterns. The number and size of the busbars connected to the circuit breaker must be selected per ANSI C.37.20.1 in order to meet the test requirements according to ANSI C.37.51 depending on the rated current, defined by the Rating Plug. Different bussing in a given frame size may be applicable.



5.2.1 Cradle connections

Drawout Circuit breaker		Connections to Line/Load side cradle connectors				
Frame Size	I _{n max}	Number of Available Busbar Mounting Positions	Busbar cross-section	Number of holes		
II	800 A / 1600 A	1 - 3				
	2000 A	2 - 4	4" x ¼" ¹)	4		
	3200 A	3 - 5				
III	4000 A / 5000 A	5 - 7	5" x ¼" ²)	6		

1) The terminal permits the use of $2^{\text{"}} x \frac{1}{4}$ " busbars is possible.

2) The terminal permits the use of $4^{\text{``}} x \frac{1}{4}^{\text{``}}$ busbars is possible.

5.2.2 Horizontal connections for 4-pole fixed mount breakers

Fixed mount Circuit Breaker		Connection to Line/Load side horizontal terminals		
Frame Size	I _{n max}	Number of Available Busbar Mounting Positions	Busbar cross-section	Number of holes
II	800 A / 1600 A / 2000 A	1 - 4	4" x ¼" ¹)	2

1) The terminal permits the use of 2" x ¼" busbars is possible.

5.2.3 Vertical connections for 4-pole fixed mount breakers

Fixed mount Circuit Breaker		Connection to Line/Load side terminals with vertical connectors		
Frame Size	I _{n max}	Number of Available Busbar Mounting Positions	Busbar cross-section	Number of holes
II	800 A / 1600 A / 2000 A	1 - 4	4" x ¼" ¹)	2
II	3200 A ³⁾	1 - 4	4" x ¼" ¹)	2
	4000 A / 5000 A ³⁾	5 - 7	5" x ¼" ²⁾	6

1) The terminal permits the use of 2" x 1/4" busbars is possible.

2) The terminal permits the use of 4" x 1/4" busbars is possible.

3) The FSII 3200 A and FSIII 4000 A, 5000A require vertical connectors. (4)



A DANGER

Hazardous voltage.

Will cause death, serious personal injury, or equipment damage.

Turn off and lock out all power supplying this equipment before working on this device.

5.3 Bus connections to the cradle

Clean the main conductor connection (plated busbars)



Securing line and load-side busbars



Use grade 5 bolts $^{1}\!/_{2}{}^{\scriptscriptstyle \rm "}$ and Belleville washers. Tighten to a torque of 70 Nm / 50 lb-ft.

Recommended support for bus connections to the cradle



The bus connections to all poles should be braced together, line and load side separately.

Eromo oizo	Rated breaking current	Dimension	ı x
Traine Size	(kA)	(mm)	(inch)
	50 / 65	250	10
П	85	85 200	
	100	200	8
II fused	200	200	8
	85 /100	200	8
	130 / 150	100	4
III fused	200	200	8

These distances are recommendations and are not construction specifications. All designs should be type tested according to ANSI C37.20.1 and ANSI C37.51 for design validation.

5.3.1 Application and configuration of fused circuit breakers

5.3.1.1 Integrally fused and non-integrally fused circuit breakers

Frame size II (800 A through 2000 A) circuit breakers are equipped with fuses, which are fitted directly to the circuit breaker.

Due to size and heat constraints, the frame size III (3200 A through 5000 A frames) are not integrally fused. The fuses are mounted in a separate fuse carriage which has the same outer dimensions as the circuit breaker and are connected in series with the associated circuit breaker. The fuse carriage and frame size III fuse switch breaker system can be mounted in the same vertical section, or adjacent to one another, but it is important that the interconnecting bus be kept as short as possible. The suitability of the design must be verified by type testing.

Siemens fused circuit breakers are not sensitive to the infeed direction. The circuit breakers (or the combination of circuit breaker and fuse carriage) can be fed from either the upper or the lower terminals.

5.3.1.2 Open fuse lockout

Every Siemens fused circuit breakers (or fused switch) is equipped with an open fuse lockout (OFLO). The purpose of the OFLO device is to open the circuit breaker (or switch) and hold the device in the trip-free position until after the primary fuses have been replaced.

For frame size III fused devices, additional control wiring is required to interconnect the OFLO device within the fuse carriage and the OFLO device within the circuit breaker (switch).

NOTICE

Equipment damage.

Incorrect connection of the open-fuse lockout will prevent the circuit breaker from tripping when a fuse in the fuse carriage responds. Polarity must be observed.

Connect the OFLO as shown below.



Fuse carriage



Fused circuit breaker

5.3.1.3 Key interlocking of fuse carriage and FS III fused circuit breaker

The racking mechanism for the fuse carriage is interlocked with the associated fused circuit breaker. In order to rack the fuse carriage, the associated fused circuit breaker must be open, and the KIRK key must be removed from the circuit breaker, which unlocks the racking mechanism of the fuse carriage.



- Fuse carriage FS III (1)
- Circuit breaker FS III
- (2) (3) Interconnenction between cradles, according to the rated current of the circuit breaker.

Secondary wiring 5.4

Terminal assignment

\rightarrow (page 8-1)

Cross-sections

Connection type	Strip conductors	1 x	2 x
Screw clamp terminal (SIGUT system)	900 7 mm 1/4"	20 -14 AWG 1) 0.5 - 2.5 mm ² 1)	20 -14 AWG 1) 0.5 - 1.5 mm ^{2 1)}
Spring clamp terminal	000 7 mm 1/4"	20 -14 AWG ¹⁾ 0.5 - 2.5 mm ^{2 1)}	20 -14 AWG ²⁾ 0.5 - 2.5 mm ^{2 2)}
Ring terminal system		14 - 16 AWG Recommendation: AMP, PIDG series Catalog No. 50881 10 AWG Recommendation: Siemens part Catalog No. WL10RL max. 7 mm / 1/4"	

Use of wire end ferrules (crimp style) is possible
 1 x up to14 AWG tube-type without insulating sleeve
 1 x up to 16 AWG tube-type with insulating sleeve
 2 x up to 16 AWG tube-type with insulating sleeve, twin wire end ferrule

2) 2 x up to 14 AWG tube-type without insulating sleeve 2 x up to 16 AWG tube-type with insulating sleeve

5.4.1 **Breaker Secondary Disconnects**

Arrangement



(1) (2) Arc chute

Secondary disconnect block







(1) (2) Dummy block

Secondary disconnect block



(3) Secondary disconnect adapter block for high arc chutes.

Connecting secondary wiring

Spring clamp terminal



5.4.2 Cradle Secondary Disconnect Blocks

Field installation



- (1) Cradle with sliding contact modules
- (2) Secondary disconnect blocks

Disassembly



(1) Secondary disconnect block

For the screw clamp terminal, a low profile, one-piece, sliding disconnect module is also available.



5.4.3 Secondary disconnect terminal blocks

Versions



- Screw clamp terminal system (1)
- (2) (3) Ring terminal system
- Insulated ring terminal Screws ANSI B 18.6.3 #4 (4)



(5) Spring clamp terminal system 2 terminals per contact

Attaching the secondary disconnect blocks





- Secondary disconnect blocks
- (1) (2) Draw-out circuit breaker: Cradle secondary disconnect block

5.4.4 Wiring in cradle





- ${\rm Arcing\ space}^{*)}$ (1)
- (2) Arcing openings
- (3) Mounting location for mechanical interlock

*) If arc chute covers are installed, the wires of the secondary disconnect blocks must not be laid on these covers.

5.4.5 Catalog numbers

	Catalog No.
Circuit breakers secondary disconnect block	WLCNMD
Secondary disconnect extension	WLCNMDA
Screw clamp terminal (SIGUT) system	WLGAUXPLUGP
Spring clamp terminal	WLGAUXPLUGT
Ring terminal system	WLGAUXPLUGR
Cradle secondary disconnect block	WLGDSCN
Blanking cover	WLGDAUXPLUG
Ring terminal crimp lug for AWG 10 wire	WL10RL
Cradle secondary disconnect block with integrated low profile screw clamp terminal block	WLGAUXPLUGL

6 Commissioning

6.1 Preparation of draw-out circuit breaker

6.1.1 Inserting the circuit breaker into the cradle

NOTE

Remove padlocks from the shutter and place the locking device in the stowed position \rightarrow (page 15-19).

Check circuit breaker position indicator/ Draw out guide rails



- 1) The circuit breaker can only be pushed in when the indicator displays "DISCON".
- 2) Pull out guide rails to the end-stop.

Place the circuit breaker into the guide rails and push it into the cradle up to the disconnected position. Close cubicle door.





	Diagram	Positon indicator	Primary Circuit	Secondary Circuit	Cubicle Door	Shutter
Withdrawn position		green	disconnected	disconnected	open	closed
Disconnected position		green	disconnected	disconnected	closed	closed
Test position		blue TEST	disconnected	connected	closed	closed
Connected position		red CONNECT TEST Ro OB DISCON	connected	connected	closed	open

Secondary circuit (1)

Primary circuit Cubicle door

(1) (2) (3) (4) Shutter

6.1.3 Unlocking the racking handle / withdrawing the racking handle

0067-01



- 1 OPEN circuit breaker
- 2 Push the crank inwards
- 3 Pull out the handle
- 4 Lift and hold the control lever
- 5 Pull out the crank

6.1.4 Racking circuit breaker into connected position









NOTICE

Racking Handle Damage.

Turning the racking handle beyond the stop will cause damage to the racking mechanism.

When the stop is reached, rotate the racking handle counter-clockwise until it can be pushed inwards.

6.2 Charge the closing spring

Charging manually

Ŕ	
	Heavy equipment
	May result in serious injury and/or property damage.
4	Secure the circuit breaker before charging it manually (e.g. during service on the work bench).



- F Handle force
- n Number of strokes
- (1) Spring charged

NOTE

To charge the spring mechanism, grip the handle firmly and carry out each stroke evenly, moving the lever down as far as it will go. Despite a significant increase in the required actuating force, the lever must be moved as far in the ninth stroke as in the first eight. When the closing spring is fully charged, the lever can be moved without resistance.


(1) ince (2) cor

Charging with a motor-operated mechanism



The motor-operated mechanism starts automatically when the control voltage is applied. The motor switches off automatically when the charging process is completed.

The motor will re-engage immediately following spring discharge (closing operation). \rightarrow Installing the motor operator (page 13-1)



🛕 DANGER

Hazardous voltage.

Will cause death, serious personal injury, or equipment damage.

Turn off and lock out all power supplying this equipment before working on this device.

Action required		✓
Verify the circuit breaker is OPEN		
Verify the Rating Plug is installed → Rating Plug (page 9-43)		
Verify the TRIP indicator is reset		
Set the trip unit to appropriate values → Trip units (page 9-1)		
Apply secondary and control voltages		
Close the cubicle door		
Rack circuit breaker into connected position		
Push in the racking handle		
Charge closing spring		
Ensure the following conditions exist		
Undervoltage release energized		
Locking devices not activated		
Indicators		
OPEN CONTACTS READY SPRING	0024gB	



6.5 Opening the circuit breaker



NOTE

The minimum time interval between ON- and OFF-signal of the Low-Voltage Power Circuit Breakers 3WL shall not be shorter than 100 ms.

6.6 Tripping

Tripped by		Trip unit			
Bell Alarm (tripped) indicator					
Bell Alarm	S24* X9 - 12 X9 - 14 $\downarrow \downarrow \downarrow \downarrow$ RESET TRIPPED X9 - 13 (BELL ALARM SHOWN TRIPPED)				
	Indicators	Without motor-operated mechanism	OPEN CONTACTS	READY	DISCHARGED SPRING
Breaker indicators		With motor-operated mechanism	OPEN CONTACTS	READY	CHARGED SPRING

* The breaker is untripped, and the Bell Alarm is shown reset

6.7 Reclosing a circuit breaker tripped by the trip unit

NOTE

The reason for tripping can be displayed using the "QUERY" button on the trip unit. This is stored for at least two days, provided that the trip unit was activated for at least 10 minutes before tripping.

1 Find reason for tripping			TEST OF AV CLEAR		
2			S	5	GFM AT 745-748
Indicator	Overload in main conductor	Overload in neutral conductor	Short circuit: short-time-delay trip	Short circuit: instantaneous trip	Ground fault trip
3 Find and rem- edy cause	- Check downstream load - Check trip unit settings		- Inspect switchgear - Check downstream load		
4 Inspect circuit breaker			Inspect contact system for possible damage → Maintenance (page 23-1)		
5 Clear trip cause			TEST QUERY CLEAR 0075-01-04		

		With mechanical reclosing lockout (optional)
6 Reset Bell Alarm	Electric remote reset of Bell Alarm → (page 10-5) (optional)	BREAKER THIPPED FUSE TRIPPED FOR FUSE TRIPPED FOR FUSE TRIPPED FOR FUSE TRIPPED FOR FUSE TRIPPED FOR FUSE TRI
7 Indicators	Without motor-operated mechanism	TS READY SPRING
	With motor-operated mechanism	TS READY SPRING
	→Charge the closing spring (pa	age 6-4)
	→Closing the circuit breaker (p	age 6-7)

6.8 Re-commissioning after fused tripping (Not applicable for 4-pole)

6.8.1 Measures

	Frame size II	Frame size III	
1 Remove fused circuit breaker/ fuse carriage			
2 Identify and remedy cause of tripping	Check dowr Check s	nstream loads witchgear	
3 Inspect main contacts of fused circuit breaker → Checking contact erosion (page 23-10)			
4 Replace fuses			
5 Insert fused circuit breaker/ fuse carriage	Patrice		



Replacing the fuses 6.8.2

Frame size II

- Remove draw-out circuit breaker from cradle
- Replace all fuses.



Remove all fuses

5

PH 1







0630-1



Install fuse



- M12 socket head cap screw Belleville washer
- (1) (2) (3) (4) (5)
- Ring terminal
- Threaded plate
- 2 x self-tapping collar screws M4

Ш Size 5 ر

8 Nm 71 Ib-in









Frame size III



- Circuit breaker in cubicle
 Fuse carriage in cubicle
 - Rack out and remove the fuse carriage.



- (1) Socket head cap screw M14x50
- (2) Washer
- (3) Fuse
- (4) Socket head cap screw M5x12 (6 ± 0,5 Nm)
 (5) Countersunk screw M6x16 (8 ± 1 Nm)

 - 1 Loosen 2 screws, remove the cover
 - 2 Remove crank with retaining ring from racking shaft
 - 3 Pull out racking shaft on the other side
 - 4 Remove 6 screws securing the racking assembly
 - 5 Take out the complete racking assembly
 - 6 Replace the fuses

Re-assembly is carried out in the opposite order.

- Insert the fuse carriage and rack it into the connected position





Frame Size	Fuse Rating	Fuse Kit (3 fuses)
	400 A	WLCLF0400
	600 A	WLCLF0600
	800 A	WLCLF0800
	900 A	WLCLF0900
ES II	1000 A	WLCLF1000
F3 II	1200 A	WLCLF1200
	1600 A	WLCLF1600
	2000 A	WLCLF2000
	2500 A	WLCLF2500
	3000 A	WLCLF3000
FS III	6000 A	WLCLF6000

6.9 Removing from service



6.10 Troubleshooting

Draw-out breaker	Disturbance	Possible Cause(s)	Remedy
x	Circuit breaker cannot be closed. Circuit breaker not ready to close.	1. Spring not charged	Charge spring SPRING CHARGED
x	"Ready-to-close" indicator shows:	 Undervoltage release not energized. 	Energize undervoltage release
x	ready	3. Mechanical open fuse lock-out effective	For fused circuit breakers: Replace defective fuses and press reset button
x	0024-04	 Key lock engaged (optional accessory) 	Unlock
x		5. Padlocks installed	Remove padlocks
x		6. "EMERGENCY OPEN" button engaged in operating position (accessories)	Release "EMERGENCY OPEN" button by rotating it
x		 Lockout effective against closing when cubicle door is open (accessories) 	Close cubicle door
х		8. Electronic trip unit missing or incorrectly installed	Install electronic trip unit properly
x		9. Racking handle withdrawn	Rack circuit breaker into disconnected, test or connect position, unlatch crank and push crank fully in
x		10. Mutual mechanical circuit breaker interlocks effective (accessories)	Open second circuit breaker or rack into disconnected position

Fixed-mounted breaker	Draw-out circuit breaker	Disturbance	Possible cause(s)	Remedy
x	Х	Circuit breaker cannot be closed. Circuit breaker ready to close	1. Closing coil not energized or incorrectly energized	Check or apply correct voltage
x		"Ready-to-close" indicator: ready	2. The secondary disconnects have been removed	Plug in the secondary disconnects
	х	Circuit breaker cannot be moved from the withdrawn position into the disconnected position	 Racking mechanism of circuit breaker not in disconnected (DISCON) position (Check circuit breaker position indica- tor) 	Rack the mechanism into disconnected position (green position indicator)
			I	I
	x	Circuit breaker cannot be fitted in the guide rails	 Factory mounted coding of circuit breaker and cradle does not match. 	The circuit breaker is not rated for use in this cradle. Replace with the proper circuit breaker (permissible circuit breakers are listed on the cradle type label).
			·	·
	x	When racking from the discon- nected into the test position, the circuit breaker does not move during the first 6 rotations (approximately)	 Not a fault (functional property) 	Continue racking
		I	I	I
	x		1. Circuit breaker is closed	Press "OPEN" button and pull racking handle block out
	х	drawn out	2. Cubicle door not completely closed (Locking device as accessory)	Close cubicle door
	х	Racking handle cannot be pushed in	1. Racking handle is interlocked	Rack circuit breaker into discon- nected, test or connected position, unlatch crank and push it fully in
x		Cubicle door cannot be opened (door interlock as	1. Closed circuit breaker is preventing opening of cubicle door	Open the circuit breaker
	x	accessory)	2. Circuit breaker in connected position	Rack circuit breaker into test or disconnected position

7 Frame sizes / dimension drawings

















VERTICAL MAIN

BUS CONNECTORS

ē

18.62 [473.0]

[58.7 6.97 _____ [177.1] _____

NOTE: ROTATABLE MAIN BUS CONNECTORS ARE ONLY AVAILABLE UNDER THE FOLLOWING CONDITIONS:

6.97 [177.1]

ŀ

(1) ONLY ACCEPTABLE FOR 3-POLE VERSIONS (2) ONLY ACCEPTABLE FOR FS2 800A-2000A

HORIZONTAL MAIN

BUS CONNECTORS

(3) ONLY ACCEPTABLE FOR SHORT-CIRCUIT RATINGS OF 85kAIC OR LESS







7.2 Frame size II fused













Minimum free space _/ for circuit-breaker racking





Door cut-out and mounting holes for edge protector (door sealing frame)

Door cut-out (with edge protector)



Additional information on: Cut-outs for "through-door racking" with Door sealing frame (page 21-1) is given in Chapter 21. Cut-outs for attaching the Plexiglas cover are shown in Chapter 22.

7.5 Frame size III, fixed-mounted version

Fixed-mounted versions are only available as 4-pole with vertical connections.



Top view vertical connection



າແອັກເ ດເຈົົາ

























Door cut-out (with edge protector)

5.63 [143.1] 13.39 [340.2]

2.74 [69.5]

> 10.99 [279.1]

4.79 [121.6]

0.83 [21.1]

Door cut-out and mounting holes for edge protector (door sealing frame)

10.40 [264.1]



Additional information on: Cut-outs for "through-door racking" with Door sealing frame (page 21-1) are shown in Chapter 21. Cut-outs for attaching the plexiglass cover are shown in Chapter 22

7.9 External sensor for neutral conductor

WLNCT2







7 – 18

WLNCT3



Iron Core: WLG800NMCT23, WLG1200NMCT23, WLG1600NMCT23, WLG2000NMCT23, WLG2500NMCT23, WLG3000NMCT23, WLG3200NMCT23, WLG4000NMCT23, WLG5000NMCT23, WLG6000NMCT23, WLGNMDGCT23





7.10 Further dimension drawings

- Door sealing frame \rightarrow (page 21-1)
- Shrouding cover \rightarrow (page 22-2)

Additional information on: Cut-outs for "through-door racking" with Door sealing frame (page 21-1) are shown in Chapter 21. Cut-outs for attaching the plexiglass cover are shown in Chapter 22
8 Circuit diagrams

8.1 Terminal assignment



0053-07_nu

1) The breaker is untripped, and the bell alarm is shown reset



		S1, S2 Option	2 nal auxiliary	switch	nes	S3, S4 Optiona	al additiona	auxiliar	y switches
	Terminals		, X6.12 X6.2	X6.4	x	X5.8	, X5.10	, X5.4 Ve e	0.00
	Wire no.	X6-10	X6-12 X6-2	X6-4		X5-8	X5-10	X5-4 ve e	0.00
	Internal	1 b S1 2	3 1 a 4	3 b S2 2 4	a	1	3 5a 33 4	1 5 	3 4
	Wire no.	6-9X	X6-11 X6-1	X6-3		X5-7	X5-9	X5-3 ve e	P. CV
0136-01_u	Terminals	X6.9	X6.11 c- X6.1	X6.3	,	X5.7	X5.9	X5.3 (-	C.OV



	S20 "Ready to close" signal	S22 ¹⁾ 1st shunt trip signal switch	S23 ¹⁾ 2nd shunt trip signal switch	S24 Bell alarm switch	S26 Open Fuse Indication
Terminals	\$X6.6	*X9.8	¥8.10	×9.14	\$79.6
Wire no.	X6-6	ON	9	N N	ON NO
color		bl / blue	bl/blue	"Trip" bn or gr "Reset" bl / blue	bn or gr
Internal	4 		4 TC/UVR	<u></u>	
00		sw / blk	sw / bik	sw / blk	sw / blk
Wire no.	X6-5	COM	W OO	COM	X9-5 COM
Terminals	X6.5 *	X9.7 *	X9.11 *	X9.13	X9.5 *

*) Same installation location as S43

Contact closed means that the undervoltage release is energized or shunt trip is not energized - circuit breaker is possibly "Ready-to-close".
 Contact open means that the undervoltage release is not energized or shunt trip is energized - circuit breaker is not "Ready-to-close".

0136-02_u

8.4 Shunt Trip, Undervoltage Trip / Electrical closing lockout



*) EMERGENCY OPEN or short terminals

**) Same installation location

1) For circuit breaker equipped with shunt trip and closing coil, the combined cutoff- switch S14 / S15 will be used. (One switch NO + NC is serving both coils.)





*) Same installation location as S12

1) For circuit breaker equipped with shunt trip and closing coil, the combined cutoff- switch S14 / S15 will be used. (One switch NO + NC is serving both coils.)

2) Use twin wire end ferrule Crimping tool e.g.: Weidmüller PZ3 to PZ6, WAGO Variocrimp 4

8.6 Motor-operated mechanism





*) Same installation location as S10

8.7 Remote Bell Alarm Reset





8.8 Trip unit circuitry for ETU745-776

8.8.1 With Breaker Status Sensor (BSS) and metering module



1) Jumper X8.9-X8.10 if there is no external N sensor

 $^{2)}$ Terminating resistor 120 Ω , 0.5 W on X8-1 / X8-2, if no external <code>CubicleBUS</code> - module is connected

³⁾ If no metering module and no BSS module is used: Direct connection X8 to ETU

4) Connection to external voltage transformers

- BSS module: Breaker Status Sensor
- CubicleBUS : Bus system for interconnection of circuit breaker components and COM modules
- ETU: Electronic Trip Unit
- S40 signaling switch "Ready-to-close"
- S41 signaling switch for spring charge level
- S43 signaling switch 2nd shunt trip F3 or F4
- S44 signaling switch for main contacts OPEN / CLOSE position
- S45 Bell Alarm signaling switch



*) same installation location as S23



1) Jumper X8.9-X8.10 if there is no external N sensor

- ²⁾ Terminating resistor 120 Ω , 0.5 W on X8-1 / X8-2, if no external **Cubicle**BUS module is connected
- ³⁾ If no metering module and no BSS module is used: Direct connection X8 to ETU
- 4) Connection to external voltage transformers



 $^{1)}\,$ Jumper X8.9-X8.10 if there is no external N sensor

 $^{2)}~$ Terminating resistor 120 Ω , 0.5 W on X8-1 / X8-2, if no external $\mbox{CubicleBUS}$ - module is connected

9 **Electronic components**

9.1 Trip units

9.1.1 Overview of function

	Trip Units	
Functions	ETU745 → (9-2)	ETU776 → (9-7)
Basic protective functions \rightarrow (page 9-11)		
Overload protection (L-tripping)	✓	✓ ✓
Short-time-delayed short-circuit protection (S-tripping)	✓	1
Instantaneous short-circuit protection (I-tripping)	✓	1
Neutral conductor protection (N-tripping)	✓	1
ground-fault tripping	0	0
Additional functions \rightarrow (page 9-13)		
Load monitoring	✓	1
Pre-trip signal for long-time trip	✓	1
Thermal memory can be switched on/off	✓	1
Zone selective interlocking	0	0
Neutral conductor protection can be switched on/off	✓	1
Short-time delayed short-circuit protection can be switched on/off	✓	1
Instantaneous short-circuit protection can be switched on/off	✓	1
Short-time delayed short-circuit protection switchable to I ² t	✓	1
Overload protection switchable to I ⁴ t	✓	1
Changeable parameter sets	-	✓
Ground-fault protection to I ² t	0	0
Ground-fault alarm	0	0
Display \rightarrow (page 9-17)		
Alphanumeric display	0	-
Graphical display (fixed-mounted)	-	✓ ✓
Communication		
Communication via CubicleBUS	✓	✓
Communication via PROFIBUS DP	0	0
Communication via Modbus RTU	0	0
Communication via Modbus TCP	0	0
Communication via PROFINET IO	0	0
Metering function \rightarrow (page 9-77)		
Metering function PLUS	0	0
Parameterization		
Parameterization via rotary coding switches	\checkmark	-
Parameterization via communication (absolute values)	-	✓
Parameterization via menu (absolute values)	-	
Remote parameterization of basic protective functions	-	✓
Remote parameterization of additional functions	✓	✓
Other		
Option for connecting to an external 24 V DC power supply	✓	1

✓ standard

optional 0

not available -1

fixed

9.1.2 Trip unit ETU745

Overview



1) The trip cause is stored internally for at least two days if the trip unit has been activated for at least 10 min before tripping (for unlimited time with auxiliary power).

2) Changeover switch only accessible with removed module.

NOTICE

Electrostatic Discharge

Trip unit may become inoperative.

Before the protective cover is removed, ensure that the equipment to be connected, and also the operating personnel, are at the same potential.

Overcurrent protection settings

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.

The parameters for the basic functions are adjusted with rotary coding switches.



The value 0.1 is set if the rotary switch is positioned in this **zone**



Various additional functions are adjusted with slide switches.

	ME OFF	MORY ON
T.U.	OFF	ON ON
	.5×In	1x / _n
ERROR	l ² t	$\int \frac{1^4}{t}$

The settings for the additional function "load monitoring" can be adjusted via:

- the alphanumeric display \rightarrow (page 9-17)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)

These settings can only be adjusted if the trip unit is activated, i.e. it must be connected to an external 24 V DC voltage supply (UL Listed Class 2).

Protective functions

- \rightarrow Overload protection L-tripping (page 9-11)
- \rightarrow Short-time delayed short-circuit tripping S-tripping (page 9-11)
- \rightarrow Instantaneous short-circuit tripping I-tripping (page 9-12)
- \rightarrow Ground-fault tripping G-tripping (page 9-12)
- \rightarrow Neutral conductor protection N-tripping (page 9-13)
- \rightarrow Load monitoring (load restore / load shedding) (page 9-13)
- \rightarrow Leading signal for L-tripping (page 9-13)
- \rightarrow Thermal memory can be switched On/Off (page 9-14)
- \rightarrow Ground-fault protection modules (page 9-44)

Characteristics

The ranges shown in the following are only setting ranges of the respective parameters. Possible tolerance ranges are not included here. Tolerance ranges are shown in the Easy TCC Time Current Curve Software.

The characteristics apply to the circuit breaker version H-class, 480 V, frame size II, with ground-fault protection module.

L-tripping



S-tripping



I-tripping



Ground-fault tripping



NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.

The parameters for the basic functions are adjusted with rotary coding switches.



The value 0.1 is set if the rotary switch is positioned in this **zone**



Various additional functions are adjusted with slide switches.



The settings for the additional function "load monitoring" can be adjusted via:

- the alphanumeric display \rightarrow (page 9-17)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)

These settings can only be adjusted if the trip unit is activated, i.e. it must be connected to an external 24 V DC voltage supply (UL Listed Class 2).

Protective functions

- \rightarrow Overload protection L-tripping (page 9-11)
- → Short-time delayed short-circuit tripping S-tripping (page 9-11)
- → Instantaneous short-circuit tripping I-tripping (page 9-12)
- \rightarrow Ground-fault tripping G-tripping (page 9-12)
- \rightarrow Neutral conductor protection N-tripping (page 9-13)
- \rightarrow Load monitoring (load restore / load shedding) (page 9-13)
- \rightarrow Leading signal for L-tripping (page 9-13)
- \rightarrow Thermal memory can be switched On/Off (page 9-14)
- \rightarrow Ground-fault protection modules (page 9-44)

Characteristics

The ranges shown in the following are only setting ranges of the respective parameters. Possible tolerance ranges are not included here. Tolerance ranges are shown in the Easy TCC Time Current Curve Software. The characteristics apply to the circuit breaker version H-class, 480 V, frame size II, with ground-fault protection module.

```
L-tripping

→ (page 9-4)

S-tripping

→ (page 9-4)

Ground-fault tripping

→ (page 9-5)
```

9.1.3 Trip unit ETU776

Overview



1) The trip cause is stored internally for at least two days if the trip unit has been activated for at least 10 min before tripping (for unlimited time with auxiliary power).

NOTICE

Trip unit may become inoperative.

Electrostatic Discharge

Before the protective cover is removed, ensure that the equipment to be connected, and also the operating personnel, are at the same potential.

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.

All parameters for the basic and the additional functions can be adjusted via:

- the graphical display \rightarrow (page 9-28)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)

To do this, the trip unit must be activated, i.e. it must be connected to an external 24 V DC voltage supply (UL Listed Class 2).

Protective functions

- \rightarrow Overload protection L-tripping (page 9-11)
- \rightarrow Short-time delayed short-circuit tripping S-tripping (page 9-11)
- \rightarrow Instantaneous short-circuit tripping I-tripping (page 9-12)
- \rightarrow Ground-fault tripping G-tripping (page 9-12)
- \rightarrow Neutral conductor protection N-tripping (page 9-13)
- → Load monitoring (load restore / load shedding) (page 9-13)
- \rightarrow Leading signal for L-tripping (page 9-13)
- \rightarrow Thermal memory can be switched On/Off (page 9-14)
- \rightarrow Ground-fault protection modules (page 9-44)

Characteristics

The ranges shown in the following are only setting ranges of the respective parameters. Possible tolerance ranges are not included here. Tolerance ranges are shown in the Easy TCC Time Current Curve Software.

The characteristics apply to the circuit breaker version H-class, 480 V, frame size II, with ground-fault protection module.

L-tripping

 \rightarrow (page 9-4)

I-tripping

 \rightarrow (page 9-5)

Ground-fault tripping

 \rightarrow (page 9-5)

9.1.4 Indicators

Scope of indications depends on the type of trip unit.





- Trip unit defective
- I rip unit defective

9.1.5 Protective functions

9.1.5.1 Basic protective functions

The basic protective functions of the trip unit are ensured without additional auxiliary voltage. The required energy is supplied by the circuit breaker's internal energy transformers.

To evaluate the currents, the electronic system of the trip unit calculates the r.m.s value.

The individual functions are parameterized according to the types via:

- rotary coding switch (ETU745)
 - electronic data transfer (ETU776) via:
 - TD400 and the software "powerconfig"
 - the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)
- the control board (ETU776)

Overload protection – L-tripping

The current setting I_B defines the maximum continuous current the circuit breaker can carry without tripping. The long-time delay t_B determines the maximum duration of an overload without tripping.

Setting values for I _R			
ETU745	$I_{R} = (0.4 / 0.45 / 0.5 / 0.55 / 0.6 / 0.65 / 0.7 / 0.8 / 0.9 / 1.0) \times I_{n}$		
ETU776	I _R = (0.4 - 1.0) x I _n (given in Amps)		
Setting values for t			

Setting values for t _R		
ETU745	$t_{\rm R}$ = 2 / 3.5 / 5.5 / 8 / 10 / 14 / 17 / 21 / 25 / 30 sec. (at 6 x ${\rm I}_{\rm R})$	
ETU776	t _R = 2 - 30 sec. (at 6 x I _R)	

The tripping characteristic is an I²t characteristic. Some trip units can be switched over to an I⁴t characteristic. \rightarrow (page 9-14)

Short-time delayed short-circuit tripping – S-tripping

On trip units ETU745 - 776, tripping due to the short-circuit current I_{sd} can be delayed by the time t_{sd}.

This provides selectivity for short-circuit protection in switchgear with several grading levels.

Setting values for I _{sd}			
ETU745	$I_{sd} = (1.25 / 1.5 / 2 / 2.5 / 3 / 4 / 6 / 8 / 10 / 12) \times I_n$		
ETU776	I _{sd} = 1.25 x I _n - 0.8 x I _{CW} (given in Amps)		

Setting values for tea

5 · · · · · · · · · · · · · · · · · · ·	
ETU745	t_{sd} = 0.02(M)^1/ 0.1 / 0.2 / 0.3 / 0.4 sec.; OFF
ETU776	$t_{sd} = 0.02(M)^{1)} / 0.08 - 4 \text{ sec.}^{2)}; \text{ OFF}$

 $^{1)}\;$ The delay time 0.02 sec. is not an I^2t function.

The motor protection function is activated in this position.

 $^{2)}$ For settings t_{sd} >0.4 sec., the maximum possible setting I_{sd} is reduced automatically according to the frame size: Frame size II $_{-}$: 20 kA Frame size III $_{-}$: 30 kA

The setting "OFF" for trip units ETU745 and ETU776 is provided to deactivate the short-time delayed short-circuit protection.

If the zone selective interlocking (ZSI) \rightarrow (page 9-14) is used and the ZSI module is set to "S" or "S+G" the adjusted delay time t_{sd} is automatically set to 50 ms provided that in the event of short-circuit the circuit breaker does not receive a blocking signal from a downstream circuit breaker. In this case regardless of the adjusted t_{sd} value the circuit breaker will trip after 50 ms.

If a blocking signal exists the adjusted delay time tsd is valid. For safety reasons after 3 s the blocking signal is terminated.

Some trip units can be switched over to an l^2 t-characteristic. \rightarrow (page 9-15)

Motor protection function

When the short-time delay is set to 20ms ($t_{sd} = (M) 0.02 \text{ sec.}$), a special motor protective function is enabled which prevents short-time tripping during the turn-on inrush for motors. At the same time, a phase loss sensing function is enabled \rightarrow (page 9-13) and the thermal time constant used for long-time protection is changed from one suitable for bus protection to one suitable for motor protection.

Instantaneous short-circuit tripping - I-tripping

If the current setting I_i is exceeded, the circuit breaker is tripped instantaneously.

Setting values for I _i	
ETU745	OFF: $I_i = I_{CW}$ $I_i = (1.5 / 2.2 / 3 / 4 / 6 / 8 / 10 / 12 \times I_n$ MAX = 0.8 x I_{CW}
ETU776	$I_i = 1.5 \text{ x } I_n \text{ - } 0.8 \text{ x } I_{cs} \text{ ; OFF : } I_i = I_{CW}$

Ground-fault tripping – G-tripping

If the trip unit is equipped with a ground-fault protection module, loads can be protected against impermissibly high ground-fault currents.

Trip units ETU745 - 776 can be equipped with it optionally. \rightarrow Ground-fault protection modules (page 9-44)

The response value I_{q} , together with the setting for the delay time t_{q} , determines the shutdown of ground-fault currents.

Setting values for I _g				
	Frame size			
	II	III		
А	100 A	400 A		
В	300 A	600 A		
С	600 A	800 A		
D	900 A	1000 A		
E	1200 A	1200 A		

Setting values for t _g		
ETU745	$t_g = 0.1 / 0.2 / 0.3 / 0.4 / 0.5$ sec.	
ETU776	t _g = 0.1 - 2.0 sec.	

If the zone selective interlocking (ZSI) \rightarrow (page 9-14) is used and the ZSI module is set to "S" or "S+G" the adjusted delay time t_g is automatically set to 100 ms provided that in the event of ground-fault the circuit breaker does not receive a blocking signal from a downstream circuit breaker. In this case regardless of the adjusted t_g value the circuit breaker will trip after 100 ms.

If a blocking signal exists the adjusted delay time t_g is valid. For safety reasons after 3 s the blocking signal is terminated. Some trip units can be switched over to an l^2 t-characteristic.

Neutral conductor protection – N-tripping

Trip units ETU745 - 776 also make it possible to protect the neutral conductor against overload. This requires a current transformer for the neutral conductor, which can be retrofitted if necessary. \rightarrow (page 9-97)

For tripping, the same long-time delay t_R applies as for overload tripping.

Setting values for I _N	
ETU745	$I_N = (0.5 / 1.0) \times I_n; OFF$
ETU776	$I_N = (0.2 - 2.0) \times I_n; OFF$

NOTICE

Neutral Conductor Overheating.

Neutral conductor or insulation may be damaged.

Settings $I_N > 1 \times I_n$ should only be used if the neutral conductor has been properly sized.

9.1.5.2 Additional functions

Load monitoring (load restore / load shedding)

Trip units ETU745 - ETU776 offer the possibility of additional load monitoring. Two current values, "load shedding" and "load restore", as well as a delay time t_x, can be set.

If the setting value "load restore" is undershot, and the lower limit value for current transmission is exceeded at the same time, a signal is output by the **Cublicle**BUS after the set delay time t_x has elapsed. If the setting value "load shedding" is exceeded, a signal is output by the **Cublicle**BUS after the set delay time t_x has elapsed. These signals can be used to connect or disconnect loads, thereby preventing an overload tripping of incoming circuit breakers.

Setting values for load monitoring			
"Load shedding" and "load restore"	40 A - 1.5 x I _n		
Delay time	t _x = 1 - 15 sec.		

Load monitoring can be adjusted via:

- the alphanumeric display (ETU745)
- the graphical display (ETU776)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)

Leading signal for L-tripping

Trip units ETU745 - 776 provide a leading signal for "L-tripping", which is transmitted via the **Cublicle**BUS 100 milliseconds before overload tripping. In this way it is possible e.g. to disconnect thyristor controllers.

Phase loss sensing

When phase loss sensing is active and the load current on the least-loaded phase is at least 50% below that of the highest loaded phase, the long-time pickup value I_R is automatically reduced to 80% of its set value. This is designed to prevent overheating conditions in motor loads when a single phase of voltage is lost and the motor is operating on 2 phases. If the highest and lowest load phase currents return to differing by less than 50%, I_R returns to its set value.

In the trip unit ETU776, phase loss sensing can be activated independently from the motor protection t_{sd} setting of 20ms.

Thermal memory can be switched On/Off

Trip units ETU745 - 776 make it possible to continue with the internally calculated reproduction of the thermal processes in downstream switchgear and consumers even if the circuit breaker is open and the electronic system has no external supply. In this way, an effective protection against thermal overload can also be guaranteed for frequent closing and opening processes.

The thermal memory can be activated via:

- a slide switch (ETU745)



- the graphical display (ETU776)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2).

Zone selective interlocking

If the circuit breaker is combined with a ZSI module \rightarrow (page 9-87), a short-circuit occurring in systems with several grading levels can be precisely localized.

For this purpose, all circuit breakers are interconnected through their ZSI-modules.

When a short-circuit occurs, each circuit breaker affected by the short-circuit current queries its downstream circuit breaker to determine whether the short-circuit is also present in the next downstream grading level. In the direction of the energy flow, only the circuit breaker nearest to the short-circuit is tripped. A delay time which may have been set for the short-circuit tripping is deactivated. However, tripping takes place after 50 milliseconds at the earliest.

Overload protection switchable to I4t

The trip units ETU776 and ETU745 can be set to perform long-time protection using either l^2 t or l^4 t. l^4 t will yield faster tripping times and will improve coordination with many types of fuses. The ETU745 can be switched between the two modes via a slide switch and the ETU776 via a menu setting.

In this case, the setting options for the long delay time t_R change as follows:

Setting values for t _R	
ETU745	$t_{\rm R}$ = 1 / 2 / 3 / 4 / 5 sec. (at 6 x I _R)
ETU776	$t_{R} = 1-5$ sec. (at 6 x I_{R})



Short-time delayed short-circuit protection switchable to I²t

Trip units ETU745 - 776 make it possible to switch over from a constant delay time to an l^2t -characteristic. In this way, the delay time depends on the short-circuit current, but with a constant l^2t_{sd} -value, providing better coordination with downstream fuses.

In this case, the setting options for the short-time delay $t_{\rm R}$ are as follows:

Settings for t _{sd}	
ETU745	t_{sd} = 0.1 / 0.2 / 0.3 / 0.4 sec. (at 12 x $I_{n})$
ETU776	t _{sd} = 0.1 - 0.4 sec. (at 12 x I _n)

Switchover to the I^2t_{sd} characteristic can be made via:

- the t_{sd} rotary coding switch (ETU745); this must be set to a value in the white area.



- the graphical display (ETU776)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2).

Changeable parameter sets

The trip unit ETU776 contains two complete sets of protective parameters and can be switched between them locally or remotely. This enables lowering instantaneous and short-time settings for arc flash mitigation as well as changing parameters when the source of supply changes between utility and generator.

Switching between parameter sets can be made manually via:

- the graphical display (ETU776)

or remotely via:

- the CublicleBUS with an input signal at the digital input module.
- the PROFIBUS DP
- the PROFINET IO, Modbus TCP and Modbus RTU.

Ground-fault protection switchable to I²t characteristic

The ground-fault protection modules for trip units ETU745 - 776 make it possible to switch over from a constant delay time to an $I^{2}t$ characteristic.

This provides an inverse-time tripping characteristic with a constant I^2t_g value, providing better selectivity of the ground-fault protection in systems with several grading levels.

The setting options for the delay time remain unchanged.

Switchover to the I²t_a characteristic can be made via:

- the t_g rotary coding switch (ETU745); this must be set to a value in the white area.



- the graphical display (ETU776)
- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2).

Ground-fault alarm

 \rightarrow Ground-fault protection modules (page 9-44)

ETU displays 9.1.6

9.1.6.1 Alphanumeric display

Trip units ETU745 can be fitted with an alphanumeric display.

Overview



- Screen (4 lines with 20 characters each) (1)
- (2) (3) Up key
- Down key

Field installation

The trip units ETU745 can be field installed with an alphanumeric display.



- OPEN circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Disconnect external 24 V DC voltage supply, if applicable
- Remove sealing cap of trip unit, if applicable \rightarrow (page 9-53)

Removing dummy flange





Installing display and latching it tight



- Fit and seal trip unit sealing cap, if applicable \rightarrow (page 9-53)

- Reconnect external 24 V DC voltage supply, if applicable



Modifying the angle of the display

At the factory, the alphanumeric display is installed with a downward inclination. However, it can be turned in a vertical direction by 180°, the display is then inclined upwards.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Disconnect external 24 V DC voltage supply, if applicable
- Remove trip unit sealing cap, if applicable \rightarrow (page 9-53)

Removing the display







- Fit and seal the trip unit sealing cap, if applicable → (page 9-53)
 Reconnect external 24 V DC voltage supply, if applicable

Catalog number

	Catalog No.
Alphanumeric display for ETU745	WLLCD48

Menu structure ETU745

After the supply voltage has been applied, the display changes from "Power-up screen" to "Autoscroll" mode after about 5 sec. Thereafter, further modes can be accessed by means of the two buttons.

Overview



"Autoscroll" mode

During normal operation, the display is in "Autoscroll" mode



In this mode, the display automatically changes to the next screen every 5 seconds.

If there is no metering module installed, the display changes continuously back and forth between screens 1 and 2.

If there is a metering module installed, a total of five screens are displayed in "Autoscroll" mode.

Screens displayed in "Autoscroll" mode		
without metering module		
Screen 1		
I1=00000.A I2=00000.A I3=00000.A IN=00000.A	Current I ₁ Current I ₂ Current I ₃ Current I _N	
Screen 2		
Ig=00000.A	Ground-fault current I _g (A value is only displayed if a ground-fault protection mod- ule is fitted.)	
with metering module installed, add	itionally	
Screen 3 KW=.±00000.kW KVA=00000.kVA KVAR.=.±00000.kVAR PF=.±0,000.xxxx	Active power P Apparent power S Reactive power Q Power factor	
Screen 4 V12.=0000.V V23.=0000.V V31.=0000.V	Voltage V ₁₂ Voltage V ₂₃ Voltage V ₃₁	
Screen 5		
W.↑.=00000,00.MWh W.↓.=00000,00.MWh PowerFlowDir↑ f=00,0 Hz	Energy (positive direction) Energy (negative direction) Present direction of energy flow Frequency	

NOTE

The data to be displayed are updated every time the screen page is set up again. No updates take place when a screen page is being displayed.

Button functions in "Autoscroll" mode			
0	Display is frozen; Switchover to "Fixed screen display" mode		
\mathbb{V}	Change to "Parameter setting" mode		
∇ () + () ∧	Change to "Contrast setting" mode		

Mode "Fixed screen display"

To access "Fixed screen display" mode, press the following button:

In "Autoscroll" mode

In this mode, maintenance information is provided with the number of circuit breaker trips and electrical open/close operations as well as with maintenance instructions. The information displayed depends on the number of circuit breaker trips operations.

Num.of.Trips00000 Num.of.Ops00000	Number of trips Number of open/close operations
Num.of.Trips00000	Number of trips
Num.of.Ops00000	Number of open/close
Prepare for contact	operations
maintenance	Maintenance instructions

Button functions in "Fixed screen display" mode			
$\bigcirc \mathbb{A}$	Change to next higher screen level		
$\overline{\mathbb{Q}}$	Change to "Autoscroll" mode		
∇ ○ + ○ Δ	Change to "Tripping counter reset" mode		

"Tripping counter reset" submode

This mode makes it possible to reset the counter for the trips and the open/close operations to zero.

NOTE
The counter should only be reset after contact maintenance. If the counter is reset without contact maintenance having been performed, the maintenance information displayed will not corre- spond to the actual condition of the contacts.

To access "Tripping counter reset mode", press the following button(s)				
In the "Fixed screen display" mode	VO)	+	$\bigcirc \mathbb{A}$
Screens displayed in "Tripping counter reset" mode				
Screen 1				
Reset.Trips.and.Ops Counter? yes:.↑+↓ no:.↑.or.↓		This screen is used for safety queries. Reset the counter after contact maintenance only.		

Screens displayed in "Tripping counter reset" mode

Screen 2

Trips.and.Ops Counter.reset continue:.↑.or. Counter reset for trips and open/close operations confirmed.

Button functions in "Tripping counter reset" mode			
If screen 1	is displa	ayed	
\mathbb{V}	or	$\bigcirc \mathbb{A}$	Canceling, no counter reset to zero Change to "Autoscroll" mode
\mathbb{V}	+	$\bigcirc \mathbb{A}$	Counter reset to zero Change to screen 2
If screen 2 is displayed			
\mathbb{V}	or	$\bigcirc \mathbb{A}$	Change to "Autoscroll" mode

"Parameter setting" mode

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.

In this mode, the following parameters can be adjusted:

- load shedding
- load restore
- delay time for load shedding/load restore
- language setting for display

To access "Parameter setting" mode, press the following button(s):

In "Autoscroll" mode

Screens displayed in "Parameter setting" mode		
Screen 1 Change Parameters Load.Shed=.0000.A ↑=+ ↓=- ↑.und.↓=Confirm	Setting Load shedding	
Screen 2 Change Parameters Load.Restore=.0000.A ↑=+ ↓=- ↑.und.↓=Confirm	Setting Load restore	
Screen 3 Change Parameters tx00.s ↑=+ ↓=- ↑.und.↓=Confirm	Setting Delay time Load shedding/load restore	
Screen 4 Change Parameters Sprache/Lang=XXXX ↑=+ ↓=- ↑.und.↓=Confirm	Setting Display language XXXX may be ENGL or GERM	
Screen 5 Changed.Parameter being.saved, wait.10s	Parameter settings are being changed, switches to "Auto- scroll" mode after 10 seconds	

NOTE

When screen 1, 2, 3 or 4 is displayed and no key is pressed within 10 seconds, "Parameter setting" mode is canceled. Any parameter changes performed are not accepted. Display switches back to "Autoscroll" mode

"Contrast setting" mode

In this mode, the contrast of the display can be adjusted.

To access "Contrast setting" mode, press the following button(s):		
In "Autoscroll" mode	\mathbb{Z}	+ 🔘 🛽
Screens displayed in "Contrast setting" mode		

Sereen 1	
Screen	
Contrast Adjust ■■■■■■■ 0 50 100 % ↑ + ↓ - ↑↓ Enter	Contrast setting The longer the bar, the higher the contrast

Button functions in "Contrast setting" mode			
$\bigcirc \mathbb{A}$	Increases the contrast		
\mathbb{Z}	Reduces the contrast		
∇ ○ + ○ Δ	Accept the contrast, switch to the "Autoscroll" mode		

"Tripping info" screen

This mode will automatically be activated as soon as a trip occurs, provided an external 24 V DC voltage supply has been connected.

Screens displayed in "Tripping info" mode		
Trip.CauseXX Tripped.PhaseYY TripCurrnt.000000.A	Tripping type Phase affected XX may be: L, S, I, G, N, M ¹⁾ YY may be: L1, L2, L3,	

1) Metering function

Button functions in "Tripping info" mode			
♥	Display of maintenance instructions If pressed again: Switches back to "Tripping info" mode		
TEST OUERY CLEAR 0075-01-04	Press CLEAR button Switches to "Autoscroll" mode		

"Display parameter changes" screen

The display automatically switches to this mode when a parameter has been changed via the rotary coding switches, provided an external 24 V DC voltage supply has been connected.

Screens displayed in "Display parameter changes" mode		
Parameter changed: XXXXXX.=000000.YY	Display of the changed value	

Displayed technical data and units

		Changed data	Unit	
		IR=00000.YY	A	
		ISD=00000.YY	A	
		Ii=00000.YY	A	
		IN=00000.YY	A	
		Ig=0000.YY	A	
		Ig.alarm.=0000.YY	A	
		tg=000.YY	ms	
		I^2tg=000.YY	ms	
		I^2tR=000.YY	S	
		I^4tR=0.YY	S	
		tSD=000.YY	ms	
		I^2tSD.=000.YY	ms	
		th.mem.=YYY	••	
ID	Current for overload tripping	1		
	Current for overload tripping			
150	Current for short-time delay			
11	Current for instantaneous short-circuit tripping			
IN	Current for overload protection of the N conductor			
lg	Current for ground-fault protection tripping			
	(this is only displayed if ground-fault protection module is available)			
lg.alarm	Response current for ground-fault protection alarm indicator			
0	(this is only displayed if a gr	ound-fault protection module is instal	led)	
ta	Delay time for ground-fault r	protection (this is only displayed if a o	round-fault protectio	on module is installed)
.9			· · · · · · · · · · · · · · · · · · ·	
l∆2ta	Inverse-time delay (1 ² t-dene	ndent) of around-fault protection (this	is only displayed if	a ground-fault protection module is installed)
rzig	g Inverse-time delay (I ⁻ t-dependent) of ground-fault protection (this is only displayed if a ground-fault protection module is installed)			
	Invorce time delay (1 ² t dans	ndant) for overland tripping		
	inverse-time delay (I ⁻ t-dependent) for overload tripping			
I''4tK	inverse-time delay (l't-depe	ndent) for overload tripping		
tSD	Delay time for short-circuit tripping			
I^2tSD	Inverse-time delay (I ² t-depe	ndent) for short-circuit tripping		
th.mem	Indicates whether thermal n	nemory is On/Off		

Button functions in "Display parameter changes" mode

The changed value is displayed for 4 seconds. The display then switches back to the previous mode.
9.1.6.2 Graphical display

The ETU776 trip unit equipped with a fixed-mounted graphical display as standard. This display enables a text output with a maximum of 8 lines or the graphical representation of characteristics.

It is used both to display data as well as to parameterize the trip unit and the metering function. The display is operated via the operating keys provided on the trip unit.



- (1) Graphical display
- (2) Operating keys

Display overview



- (1) Menu title
- (2) 8-line alphanumeric display or graphical representation of characteristics
- (3) Status line

Status line

The status line shows, by means of bold symbols, which actions the operator can carry out and which settings are currently active at this moment.



- (1) Access with password only
- (2) Maintenance required
- (3) Set parameter set for protective functions
- (4) Editing option
- (5) Set trigger
- (6) Possible actions by the operator

Representation of bar diagrams

The measured values for some parameters are displayed both as numerical values and graphically in the form of a bar diagram.



- (1) Lowest measured value
- (2) Present measured value
- (3) Current measured valuee
- (4) 100% of the measured parameter
- (5) Width of display

The markings for the lowest and highest measured value are automatically updated during the measurement.

Display during operation

After the supply voltage is applied, the display switches from the "power up screen" to the operational screen after approximately 5 seconds. It shows the currents in the three phases and in the neutral conductor as numerical values and in the form of a bar diagram. The background illumination of the display is automatically switched off after approximately 1 minute. It can be switched on again by pressing any button.



Polling the main menu



Navigating in the menu structure

Use the operating keys to navigate in the menu structure.

Button functions				
	Shift the marking			
ENTER	Select the marked menu item			
ESC	Switch back to the previous menu			

Selection of a menu item



Displaying measured values

Example 1: Displaying the currents



Example 2: Displaying the frequency



Example 3: Displaying harmonics



	ΗA	R	М	0	NI	сs	
2 :	2	0		0	%	0.	0 %
2 :	3	0		0	%	0.	0 %
2	4	0		0	%	0.	0 %
2	5	0		0	%	0.	0 %
2	6	0		0	%	0.	0 %
2	7	0		0	%	0.	0 %
2	8	0		0	%	0.	0 %
2	9	0		0	%	0.	0 %
) S	F		R	J	> TRIG	

Displaying parameters

Example 4: Displaying parameters parameter settings





Calling up diagnostic information

Example 6: Querying maintenance information



Example 7: Adjusting representation of characteristics





Example 8: Selecting event for displaying characteristics





Example 9: Displaying characteristics





Changing parameters

Example 10: Setting protection parameters



Settings the display

Example 11: Entering password







Identifications

Example 12: Identifications



Resetting

Example 13: Resetting the measured minimum and maximum values





The Rating Plug defines the rated current In within a certain range for a given circuit breaker frame size.

If a rating plug with a higher current than the maximum permissible circuit breaker rated continuous current is plugged in, the electronic system of the trip unit recognizes this error and signals it with a flashing T.U. ERROR indicator.

The trip unit ignores the rated current value specified by the incorrect Rating Plug and sets it to the value of the smallest Rating Plug for the frame size of the relevant circuit breaker.

The same happens if a circuit breaker with frame size III is equipped with a Rating Plug smaller than 800 A. All set protection parameters are adjusted accordingly.

It is not permitted to operate the trip unit without a Rating Plug. If a circuit breaker is nevertheless started up without a Rating Plug, the T.U. ERROR indicator will light up and the trip unit settings will default to the lowest possible settings for that frame rating.

Frame size		Rating Plug	Catalog No.	
II	III			
1		200 A	WLRP200	
1		225 A	WLRP225	
1		250 A	WLRP250	
1		300 A	WLRP300	
1		315 A	WLRP315	
1		350 A	WLRP350	
1		400 A	WLRP400	
1		450 A	WLRP450	
1		500 A	WLRP500	
1		600 A	WLRP600	
1		630 A	WLRP630	
1		700 A	WLRP700	
1	1	800 A	WLRP800	
1	1	1000 A	WLRP1000	
1	1	1200 A	WLRP1200	
1	1	1250 A	WLRP1250	
1	1	1600 A	WLRP1600	
1	1	2000 A	WLRP2000	
1	1	2500 A	WLRP2500	
1	1	3000 A	WLRP3000	
1	1	3200 A	WLRP3200	
	1	4000 A	WLRP4000	
	~	5000 A	WLRP5000	

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.



9.1.8 Ground-fault protection modules

WL trip units can be optionally equipped with modules that add ground fault protection. The modules provide either an alarm-only function or alarm-and-trip functionality.

The modules can be added or removed as necessary in the field.

Settings are found on \rightarrow (page 9-12)

The following combinations are possible:

Trip unit	Ground-fault protection module
ETU745	GFM A 745 (alarm only) GFM AT 745 (alarm and trip)
ETU776	GFM A 776 (alarm only) GFM AT 776 (alarm and trip)

The following options exist for ground-fault detection:

- Vector sum of the three phase currents plus neutral, if a neutral sensor is connected (residual sensing).
- Direct measurement of the ground-fault current using a separate 1200 A : 1 A iron-core ground fault sensor.

The direct-sense input to the trip unit has the following current-carrying capability:

- max. 1 A continuous
- max. 5 A for 0.5 sec.

Note

If the circuit breaker is applied in a 4-wire system, and residual ground fault protection is desired, it is strongly recommended that a WL neutral sensor (WLNCT2, WLNCT3) be used on the neutral to facilitate the correct vector-summation of the phase currents with the neutral. Failure to apply a neutral sensor may result in erroneous GF alarm and trips.

Note

Output of alarms and messages is possible via COM and $\ensuremath{\textbf{CubicleBUS}}$ modules.

Module GFM A 745



- Alarm only, circuit breaker does not trip
- The changeover switch for ground-fault detection is only accessible when the control panel or the trip unit itself is removed.

Module GFM AT 745



- Ground-fault protection by circuit breaker tripping and alarm signal

- Changeover switch for ground-fault protection accessible only when the control panel or the trip unit itself is removed



- Alarm only, circuit breaker does not trip
- Module programmable via:
 - the graphical display (ETU776)
 - TD400 and the software "powerconfig"
 - the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2).

Module GFM AT 776



- Ground-fault protection by circuit breaker tripping and alarm signal
- Module programmable via:
 - the graphical display (ETU776)
 - TD400 and the software "powerconfig"
 - the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2).
- Ground-fault detection selectable:
 - vector sum $\Sigma I = L1+L2+L3+N$
 - external iron core ground-fault current sensor 1200 A : 1 A

Field installation



High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

Removing dummy module





Installing and snapping the ground-fault protection module into place





- Switch on external 24 V DC voltage supply, if planned
- Adjust settings for ground-fault protection
- -Test the tripping function with the handheld test device \rightarrow (page 9-99)
- Install and seal sealing cap of trip unit, if applicable \rightarrow (page 9-53)

Catalog numbers

Ground-fault protection module	Catalog No.
GFM A 745	WLGFA48
GFM AT 745	WLGFM48
GFM A 776	WLGFA76
GFM AT 776	WLGFM76



 WARNING

 High speed moving parts.

 Can cause serious personal injury.

 Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

Removing

- OPEN circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Remove front panel \rightarrow (page 23-4)













Installation is carried out in the reverse order.

After replacing the trip unit, always test with the handheld test device \rightarrow (page 9-99)

For ordering trip units, please refer to the latest version of the "Selection and Application Guide" WL Low Voltage Power Circuit Breaker catalog.

If a trip unit with another configuration than the existing one is installed, the Catalog No. on the options label of the circuit breaker must be changed according to the catalog data.

Please contact the technical assistance hotline if you have any queries.

9.1.10 Internal trip unit self-test on the overcurrent tripping function

For commissioning and function testing.

Conditions

- Trip unit is activated by: operating current external 24 V DC voltage supply
 Current not in overload range
 - \rightarrow Indicators (page 9-9)

	Internal circuit breaker self-test without tripping					
	Normal operation of the circuit breaker is not impaired					
	The test can be canceled at any time by pressing CLEAR					
1	TEST QUERY QLEAR					
2	Running light All indicators will light up one after other (from left to right or from top to bottom)					
3	The flashing time corresponds to the long-time delay t _R The flashing time deviates more than 10% from the set long-t delay t _R					
4	The L-tripping indicator lights up Test OK	T.U. ERROR indicator lights up Test not OK	Test not OK Trip unit is defective, even if the L-tripping indicator lights up			
5	 LED goes out after 30 sec. End of internal self-test Premature ending of test by pressing CLEAR 					
6	Trip unit OK	Testing with handheld test device \rightarrow Handheld test device (page 9-99)				

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.







NOTE

Keep sealing wire as short as possible.

	Catalog No.
ETU745	WLTUSC55
ETU776	WLTUSC76

9.2 CubicleBUS Modules

9.2.1 System architecture



¹⁾ See communication manual for relay details.

- AO: Analog output module
- **BSS**: Breaker Status Sensor for acquisition of signals about the circuit breaker status (always combined with COM module)
- CubicleBUS : Internal bus system for interconnection of circuit breaker components and for connection of external CubicleBUS modules
- **COM15/16/35**: Communications modules to connect breaker-internal CubicleBUS to external supervisory systems via PROFIBUS-DP, Modbus RTU, PROFINET IO or Modbus TCP. Always combined with the BSS (Breaker Status Sensor).
- **DI**: Digital input module for capturing the status of ungrounded (potential-free) status signals for the purpose of communicating them or switching active parameter set (ETU776). A maximum of 2 modules in different configurations can be connected.
- DO: Digital output modules with 6 outputs each; a maximum of three modules with different configurations or versions can be connected
- ETU: Electronic trip unit
- Metering: Metering function or metering function PLUS
- Modbus TCP: Fieldbus for connection of energy management systems and automation systems
- Open / Close: Opening coil and closing coil for opening and closing the circuit breaker via communication
- PROFIBUS DP/PROFINET IO: Field bus for connection of automation components
- Protection: Protection module
- TD400: Test Device; adapter for parameterizing, operating and monitoring the circuit breaker via powerconfig
- VT: Voltage transformer
- ZSI: Module for zone selective interlocking, must always be connected as the first module

NOTE

The basic functions of the electronic trip units do not require an auxiliary power supply. To use extended functions of the trip units requiring data exchange via the **Cubicle**BUS, an external 24 V DC voltage supply must be connected. \rightarrow (page 9-98)

9.2.2 Internal modules

9.2.2.1 Breaker Status Sensor (BSS)

For collecting circuit breaker status information via signaling switches and transmitting these data to the CubicleBUS.



Signaling switches for BSS



- (1)
- Spring charge signaling switch Signaling switch OPEN / CLOSE position S44
- (2) (3) "Ready-to-close" signaling switch
- (4) S45 Bell Alarm signaling switch
- (5) Signaling switch for connected position S46
- Signaling switch for test position S47 (6)
- Signaling switch for disconnected position S48 (7)
- Signaling switch S43 UVR or 2nd shunt trip (8)

Installing the BSS module



 WARNING

 High speed moving parts.

 Can cause serious personal injury.

 Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

(2)

Always discharge the closing spring before removing any covers or the front panel of the circuit breaker (page 23-2). Move the circuit breaker into the withdrawn position in the cradle (page 23-3) and Removing front panel (page 23-4).

Replace the trip unit (page 9-49).



(3)

(4)

- (1) BSS
- (2) Actuating shaft
- (3) BSS
- (4) "Ready-to-close" indicator
- (5) Drive shaft
- (6) Carrier

Attaching signaling switch S43 to the 2nd shunt trip / UVR



- (1) Rocker
- Signaling switch Guide
- (2) (3) (4) Groove

Attaching signaling switch S45 to the ETU carriage



(1) black wiring

Connecting BSS module

The first CubicleBUS connection leads to the secondary disconnect block X8. The second CubicleBUS connection is made according to the circuit breaker equipment.

 \rightarrow Circuit diagrams (page 8-1)



- (1) (2) ETU745 - 776 without metering function ETU745 - 776 with metering function
- (3) X51-X52 External conducted cubicle bus link does only exist in release 1. release 2 uses an internal link

9.2.2.2 COM module

General

The communication modules permit access to the circuit breaker via their respective fieldbus interface:

- Reading and writing parameters
- Reading circuit breaker states
- Reading measured values
- Transmitting messages and alarms
- Transmitting maintenance information
- Sensing the position of the circuit breaker in the guide frame
- Additional functions via internal inputs and outputs
- Closing and opening the circuit breaker via fieldbus
- Implementing circuit breaker-internal CubicleBUS information

Further information can be found in the system manuals of the respective communication modules:

3WL circuit breakers with communication capability via the COM35 communication module - PROFINET IO, Modbus TCP https://support.industry.siemens.com/cs/ww/en/view/109757987

System manual for 3WL/3VL circuit breakers with communication capability - Modbus https://support.industry.siemens.com/cs/ww/en/view/39850157

System manual for 3WL/3VL circuit breakers with communication capability - PROFIBUS https://support.industry.siemens.com/cs/ww/en/view/12560390

IT Security

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept. For more information about industrial security, please visit https://www.siemens.com/industrialsecurity

Note

This product is intended for industrial environments (Environment A, in accordance with IEC 60947-1/-2). In residential environments, this device can cause unwanted radio interferences. In this case, it is the user's responsibility to address accordingly.

Fitting COM module on the guide frame

- Switch off and discharge the storage spring
 → (page 23-2)
- Pull the breaker into maintenance position \rightarrow (page 23-3)



S46, S47 und S48:

Signaling switch for sensing the position of the circuitbreaker in the guide frame for forwarding to the respective fieldbus and the **Cubicle**BUS

Attaching the position indicating module to the withdrawable circuit breaker

For actuating signaling switches S46, S47 and S48.



For frame size II and frame size III, L & C-class:



Fitting COM module on the fixed-mounted breaker





Connecting wires

→ Circuit diagrams (page 8-1)

Note

If necessary, missing auxiliary terminals may be added (receptacle, auxiliary connectors and sliding contact module for guide frames). \rightarrow (page 5-11)





- (1) Secondary connector X8
- (2) Connecting cable to first external **Cubicle**BUS -module or terminating resistor
- (3) Connecting cable to secondary connector X8

Designation	Assignment	Terminal
X8-1	CubicleBUS -	X8.1
X8-2	CubicleBUS +	X8.2
X8-3	24 V DC +	X8.3
X8-4	24 V DC GND	X8.4

NOTICE

If no external **Cubicle**BUS -modules are connected to the COM module, the terminating resistor must be plugged into the **Cubicle**BUS terminal. Absence of the terminating resistor can cause errors and potentially loss of communications.

Connections for additional inputs and outputs



IEC 61558 SELV/PELV – UL 1310 Class 2 Power Supply Only				
	Voltage	Max. Current		
		COM15/16	COM35	
Power Supply:	- 24 V DC	125 mA	125 mA	
Write Enable:		10 mA	10 mA	
Free IN:		10 mA	10 mA	
Free OUT:		400 mA	400 mA (1A@T _{amb} < 40°C)	
Close:		400 mA	400 mA	
Open		400 mA	400 mA	

Ratings at T_{ambient} < 70°C

More detailed information about the use of these inputs and outputs can be found in the relevant system manuals
9.2.2.3 COM35 module

The COM35 communications module permits access to the circuit breaker via the fieldbus protocols PROFINET IO and Modbus TCP.

The COM35 also features:

- Ethernet switch functionality
- Both protocols may be used simultaneously on both ports
- Dynamic Arc Sentry (DAS) via the COM35 inputs and outputs
- Signed firmware update
- Tripped signal (bell alarm) via the COM35 output





- (1) Input/output terminals for user connection to additional functions
- (2) RJ45 sockets for PROFINET IO and Modbus TCP connection
- (3) Function-select button
- (4) Activity LED PROFINET IO
- (5) Activity LED Modbus TCP
- (6) Activity LED CubicleBUS
- (7) Connections to the secondary disconnect contact system X8
- (8) **Cubicle**BUS connection for connecting external **Cubicle**BUS modules or a **Cubicle**BUS terminating resistor

Note

The COM35 module can be specified as part of the circuit breaker catalog number or ordered separately: WLCOM35: Includes COM35 module and mounting hardware. WLCOM35RET: Retrofit kit including COM35, BSS and all required components to retrofit communications into a breaker.

Indicators

LED	Indication	Meaning	
	green	Normal PROFINET IO communcation	
PROFINET IO	green flashing	Communication with PROFINET IO Controller, no communication with PROFINET IO Supervisor	
	red	No communication with PROFINET IO Controller, no communication with PROFINET IO Supervisor	
Modbus TCP	green	At least one opened Modbus TCP connection	
	green flashing	Ethernet link available but no Modbus TCP connection	
	off	No Ethernet link	
	off	No CubicleBUS participant active	
	green	CubicleBUS communication operating	
Cubicle BUS	green flashing	No ETU installed (e.g: non-automatic/ disconnect switch application)	
	red	CubicleBUS error	

Utilizing the programmable DAS function of the COM35:



The COM35, exclusively, provides the ability to activate the DAS function of the WLETU776 directly via the COM35's programmable I/O. When the COM35 is programmed to enable this function, opening the connection between terminals 1 and 3 will cause the trip unit to switch to Parameter Set B. When contact is made between these two terminals, the trip unit will utilize Parameter Set A. The programmable output can then be used to activate a local status indicator (as illustrated). This COM35 I/O functionality must be programmed by the user via Siemens powerconfig software.

The programable output can carry a load of 1A, up to an ambient temperature of 45C (113F). Above that, the current–carrying capability of the output should be de-rated to 400mA at 70C (158F). The length of the wires connecting the activation switch to the input of the COM35 should be less than 50m (165ft) and be AWG18. Twisted/shielded-pair wiring is recommended for cable runs approaching this length.

9.2.2.4 COM15 module

The COM15 communication module allows access to the circuit breaker via the PROFIBUS DP fieldbus interface.

Overview



- Connection terminals for additional inputs and outputs to provide special functions SUB-D plug, 9-pole, for PROFIBUS DP connection (1)
- (2)
- CubicleBUS LED (3)
- (4) PROFIBUS DP-LED
- (5) Connecting cables to secondary connector X8
- CubicleBUS connection for connecting external CubicleBUS -modules or for the terminating resistor (6)

Indicators

LED	Indication	Significance		
	off	No 24v dc power connected		
PROFIBUS DP	green	PROFIBUS DP communication active		
	red	Bus fault or bus not responding		
	off	No Cubicle BUS -modules found or no 24v dc power connected		
CuhicleBUS	green	CubicleBUS communication active		
	green flashing	Cubicle BUS device found, but no connection to ETU or metering function		
	red	CubicleBUS error		

9.2.2.5 COM16 module

The COM16 communication module permits access to the circuit breaker via the Modbus RTU fieldbus interface.

Overview



- (1) Connection terminals for additional inputs and outputs to provide special functions
- (2) SUB-D plug, 9-pole, for Modbus RTU connection
- (3) **Cubicle**BUSLED
- (4) Modbus RTU LED
- (5) Connecting cables to secondary connector X8
- (6) **Cubicle**BUS connection for connecting external **Cubicle**BUS modules or for the terminating resistor

Installation and operation

Assembly is done as for the COM35 module: for the guide frame \rightarrow (page 9-60) for fixed-mounted breakers \rightarrow (page 9-62)

Installation and operating is described in the system handbook with document order number 3ZX1012-0WL10-1AC1. It can be downloaded free of charge from: http://support.automation.siemens.com/WW/view/en/39850157

Indicators

LED	Indication	Significance		
	off	No 24v dc power connected		
PROFIBUS DP	green	Modbus communication functioning		
	red	No Modbus communication or timeout		
	off	No Cubicle BUS -modules found or no 24v dc power connected		
CubicleBUS	green	CubicleBUS communication active		
Ganciedoo	green flashing	Cubicle BUS device found, but no connection to ETU or metering function		
	red	CubicleBUS error		

Modbus RTU interface

The COM16 module is equipped with a 3-wire RS485 interface. The Modbus RTU connector is a 9-pin female Sub-D connector with the following pinout:

Pin	
1	RS485 Reference
5	Transceiver Terminal 1, V1 voltage
9	Transceiver Terminal 0, V0 voltage
2-4, 6-8	Not connected

Cables connecting COM16 modules via RS485 must contain three insulated conductors and a shield. The three isolated conductors connect to Pins 1, 5 & 9. The RS485 Reference must only be grounded at one end, preferably at the master. Grounding the RS485 Reference in multiple locations can allow common mode voltages to be imposed on the RS485 Transceiver terminals which can prevent communication and potentially damage the device.

The cable shield must only be grounded at one end, preferably at the master. Grounding the shield in multiple locations can allow circulating ground currents in the shield which can prevent successful communication.

Write Enable input

The COM16 Module is equipped with an input that must be activated to allow the module to accept remote control commands as well as remote parameterization. When this input is not active, the module will reject all incoming packets that would normally change the state of an output (open/close circuit breaker) or change protective parameters. Normal polling and communication of data are not affected.

The following commands are blocked if the Write Enable input is inactive:

- opening/closing circuit breaker
- resetting after a trip
- Changing any protective function parameters and extended protective function parameters
- changing any communications parameter (e.g. address)
- changing any parameter of the metering function (e.g. demand period length)
- resetting any diagnostic or service-related counter or indicator
- setting/resetting outputs of the digital output modules

The following commands are always allowed, independent of the state of the Write Enable input:

- changing and setting the trigger settings of the waveform capture function
- reading the contents of the waveform buffer
- changing alarm and setpoint function settings
- changing any of the customer-changeable text strings
- resetting the min/max log
- setting/resetting the "Free Output" of the COM16 module
- setting system time

Modbus RTU Functionality

Transmission Protocol

The COM16 module operates in the RTU transmission mode. ASCII transmission mode is not supported.

Overview of supported Functions

The COM16 module provides the following Modbus RTU function codes for accessing the data contained in the WL circuit breaker.

FC	Name	Description	
02:	Read Discrete Inputs	Reads the state of the Bits in the Status Register	
01:	Read Coils	Reads the state of multiple Control Bits and Extra Flags	
05:	Write Single Coil	Sets the state of a single Control Bit or Extra Flag	
15:	Write Multiple Coils	Sets the state of multiple Control Bits and Extra Flags	
04:	Read Input Registers	Reads the Basic Data Registers. Three Basic Types (1, 2 and 3) are supported.	
03:	Read Holding Registers	Reads a complete data set.	
16:	Write Multiple Registers	Writes a complete data set.	
07:	Read Exception Status	Reads the state of eight Exception Status bits	
08:	Diagnostics	Function provides a method for checking the communication between the master and the slave	
11:	Get Comm Event Counter	Returns a status word and an event count from the communications event counter	
12:	Get Comm Event Log	Returns a status word, event count, message count, and a field of event bytes	

Modbus RTU Communication settings

For Modbus RTU communication, the following settings must be made in the COM16 module: baud rate, serial transmission configuration, Modbus RTU address.

Modbus RTU Slave Address

The Modbus RTU communication address range of the COM16 module is 1 through 126.

Modbus RTU address 0 is used as a broadcast address in Modbus RTU systems.

Modbus RTU address 0xF1(hex) is defined as a broadcast address for COM16 modules.

The Modbus RTU slave address is assigned to data point 5 and may be changed by writing a new address value to high-byte of register 40962 (0xA002). If the COM16 module receives an invalid slave address value, the invalid value will be ignored.

Baud Rate

Baud rate settings of 1200, 2400, 4800, 9600 and 19200 are supported. 19200 baud is the default setting. The baud rate is assigned to data point 427 and may be changed by writing a new baud rate value to high-byte of register 40984 (0xA022). The following numbers are used to identify the selected baud rate. If the COM16 module receives an invalid baud rate, the invalid baud rate will be ignored.

Number	Baud rate
0	1200
1	2400
2	4800
3	9600
4	19200

Parity

Parity settings of "No Parity", "Odd Parity" and "Even Parity" are supported. "Even Parity" is the default setting. The parity is assigned to data point 428 and may be changed by writing a new parity value to the low-byte of register 40994 (0xA022). The following numbers are used to identify the selected parity. If the COM16 module receives an invalid parity, the invalid parity will be ignored.

Number	Parity
0	No Parity
1	Odd Parity
2	Even Parity

Auto configuration of baud rate and parity

The factory settings for baud rate and parity are 19200 baud and "Even Parity". These settings may be changed either by writing from the master to data points 427 and 428 in register 40994 (0xA022) or via the auto configuration process. The auto configuration process only occurs when the supply voltage is switched on.

When the supply voltage is switched on, the COM16 module monitors the bus activity. If the COM16 module detects bus activity but cannot receive any valid data, the auto configuration process is started. The module cycles through all combinations of baud rate and parity until it finds the combination which allows it to receive valid data. This combination is then saved and the auto configuration process ended.

If the COM16 module does not find a combination that allows it to receive valid data after cycling through all combinations, it will adopt the original settings for baud rate and parity, and the auto configuration process will be ended.

The time required to complete the auto configuration process can be several seconds depending on:

- Baud rate
- How often the master transmits a telegram
- The length of the messages transmitted by the master
- The number of tests required to detect a valid baud rate/parity combination

Changing the communication parameters

The communication parameters of the COM16 module can be changed by writing the required parameters (baud rate, serial configuration and Modbus RTU communication address) in data set 160.

		Dataset	160	Commu	inication Pa	arameters				
Address:		Address:	A000	hex, Registers: 36, Access: Read / Write						
Register	Byte	HIGH/ LOW Byte	Description	Data point	Source WL	Source VL ¹	Source VL ²	Format	Length	Scaling
40960	0		Header; value 0x00 00 00 00	_	COM16	COM11	COM21	_	32	_
40962	4	HIGH	Reserved	_	_	_	_	_	8	_
	5	LOW	Modbus RTU address	5	COM16	COM11	COM21	Unsigned char	8	0
40963	6	HIGH	Basic data type (1, 2 or 3)	6	COM16	COM11	COM21	Unsigned char	8	_
	7	LOW	Reserved	_	_	_	_	_	8	_
40964	8		Changeable data points in the basic data	7	COM16	COM11	COM21	Unsigned char	224	_
40984	48	HIGH	Modbus baud rate	427	COM16	COM11	COM21	Unsigned char	8	_
	49	LOW	Modbus parity	428	COM16	COM11	COM21	Unsigned char	8	_
40994	68	HIGH	Property for Byte 49	_	COM16	COM11	COM21	Property byte	8	_
	69	LOW	Property for Byte 48	_	COM16	COM11	COM21	Property byte	8	_
40995	70	HIGH	Reserved	_	_	_	_	Property byte	8	_
	71	LOW	Property for Byte 5	_	COM16	COM11	COM21	Property byte	8	_
40996	72	HIGH	Property for Byte 6	_	COM16	COM11	COM21	Property byte	8	_
	73	LOW	Reserved	_	_	_	_	Property byte	8	_
40997	74	HIGH	Property for Byte 8	-	COM16	COM11	COM21	Property byte	8	_
	75	LOW	Reserved	-	_	_	_	Property byte	8	_
	78		Total Bytes	•						

Note: Registers not listed are reserved.

For details on data formats and properties, see "SENTRON WL VL circuit breakers with communication capability MODBUS" manual.

Modbus RTU function codes

In addition to the Modbus RTU function codes of the COM16 module, described on page 9-68, the following definitions of the Status Register, Control Bits, Extra Flags, Basic Types and Exception Status Bits apply to the COM16 module.

Status Register

The Status Register provides WL status information to the Modbus RTU master. The Status Register is accessed using the following functions:

- 02 Read Input Status Discretes
- 04 Read Input Registers

Bit number	WL	
0, 1	Circuit breaker position 00 = disconnected position 01 = connected position 10 = test position 11 = circuit breaker not present	
2, 3	Circuit breaker status 00 = not ready 01 = circuit breaker open 10 = circuit breaker closed 11 = circuit breaker tripped	
4	Circuit Breaker is "Ready-to-close"	
5	Undervoltage release	
6	Closing spring charged	
7	Overload warning	
8	Setpoints active	
9	Warning(s) active	
10	Modbus RTU "Write enable" input active	
11	User input	
12, 13, 14	Trip 000 = no trip 001 = overload trip 010 = instantaneous short-circuit trip 011 = short time delayed short-circuit trip 100 = ground-fault trip 101 = trip caused by extended protective function 110 = N conductor trip	
15	Load shedding	

Control Bits and Extra Flags

Control Bits and Extra Flags make it possible for the Modbus RTU master to control various WL functions. The Control Bits and Extra Flags are accessed using the following functions:

- 01 Read Coils
- 05 Write Single Coil
- 15 Write Multiple Coils

Bit number		WL		
Control Bits	0, 1	Breaker open / close 00 = no action 01 = open circuit breaker 10 = close circuit breaker 11 = no action		
	2	clear reason for trip		
	3	Not used		
	4	User output 0 = User output Off 1 = User output On		
	5	Not used		
6		Not used		
	7	Not used		
Extra Flags	8, 9	not used		
	10	Clear log book		
	11	Clear all min/max values		
	12	Clear temperature min/max values		
	13	Not used		
	14	Clear maintainance counters		
	15	Synchronize system clock at a rising edge Sets the time to xx:30:00:00		

Byte Order

Data points larger than two bytes transmitted in the Motorola Format (Big-Endian).

Byte Order			Type of Data
Byte 0	Byte 0		char, unsigned char
Byte 1	Byte 1		
Byte 0	High Byte		signed int, unsigned int
Byte 1	Low Byte		
Byte 0	High Byte	High Word	signed long, unsigned long
Byte 1	Low Byte		
Byte 2	High Byte	Low Word	
Byte 3	Low Byte		

Basic Data Types

Basic data types 1, 2 and 3 are supported. Basic data type 1 is the default setting. Basic data type 1 consists of 7 registers, basic data type 2 consists of 13 registers and Basic data type 3 consists of 22 registers.

Basic data is accessed using the function:

04 Read Input Registers - Reads the Basic Data including the Status Register

Basic Data Type 1 Registers and Default Data Points

Register	Byte	Name	Default Data Point – WL		
1	0, 1	Status Register	WL status bits		
2	2, 3	Data Block 1	Phase L1 current		
3	4, 5	Data Block 2	Phase L2 current		
4	6, 7	Data Block 3	Phase L3 current		
5	8, 9	Data Block 4	Current in phase under highest load		
6	10	Block 1 property byte	Property byte of phase L1 current		
	11	Block 2 property byte	Property byte of phase L2 current		
7	12	Block 3 property byte	Property byte of phase L3 current		
	13	Block 4 property byte	Property byte of max current in phase under highest load		

Basic Data Type 2 Registers and Default Data Points

Register	Byte	Name	Default Data Point – WL
1	0, 1	Status Register	WL status bits
2	2, 3	Data Block 1	Phase L1 current
3	4, 5	Data Block 2	Phase L2 current
4	6, 7	Data Block 3	Phase L3 current
5	8, 9	Data Block 4	Current in phase under highest load
6	10, 11	Data Block 5	Current in neutral conductor
7	12, 13	Data Block 6	Average phase-to-phase voltage
8	14, 15	Data Block 7	Average power factors of 3 phases
9	16, 17	Data Block 8	Total active energy of 3 phases ^{a)}
10	18	Block 1 property byte	Property byte of phase L1 current
	19	Block 2 property byte	Property byte of phase L2 current
11	20	Block 3 property byte	Property byte of phase L3 current
	21	Block 4 property byte	Property byte of current in phase under highest load
12	22	Block 5 property byte	Property byte of current in neutral conductor
	23	Block 6 property byte	Property byte of average phase-to-phase voltage
13	24	Block 7 property byte	Property byte of average power factors of 3 phases
	25	Block 8 property byte	Property byte of total active energy of 3 phases

a) Only 2 bytes of the 4 byte data point will be communicated (range: 0 - 65535 MWh)

Basic Data Type 3 Registers and Default Data Points

Register	Byte	Name	Default Data Point – WL
1	0, 1	Status Register	WL status bits
2	2, 3	Data Block 1	Phase L1 current
3	4, 5	Data Block 2	Phase L2 current
4	6, 7	Data Block 3	Phase L3 current
5	8, 9	Data Block 4	Current in phase under highest load
6	10, 11	Data Block 5	Current in neutral conductor
7	12, 13	Data Block 6	Phase-to-phase voltage L1 to L2
8	14, 15	Data Block 7	Phase-to-phase voltage L2 to L3
9	16, 17	Data Block 8	Phase-to-phase voltage L3 to L1
10	18, 19	Data Block 9	Phase-to-neutral voltage L1
11	20, 21	Data Block 10	Phase-to-neutral voltage L2
12	22, 23	Data Block 11	Phase-to-neutral voltage L3
13	24, 25	Data Block 12	Average power factor of 3 phases
14	26, 27	Data Block 13	Total active energy of 3 phases*
15	28, 29	Data Block 14	Total apparent power of 3 phases
16	30	Block 1 property byte	Property byte of phase L1 current
	31	Block 2 property byte	Property byte of phase L2 current
17	32	Block 3 property byte	Property byte of phase L3 current
	33	Block 4 property byte	Property byte of current in phase under highest load
18	34	Block 5 property byte	Property byte of current in neutral conductor
	35	Block 6 property byte	Property byte of phase-to-phase voltage L1 to L2
19	36	Block 7 property byte	Property byte of phase-to-phase voltage L2 to L3
	37	Block 8 property byte	Property byte of phase-to-phase voltage L3 to L1
20	38	Block 9 property byte	Property byte of phase-to-neutral voltage L1
	39	Block 10 property byte	Property byte of phase-to-neutral voltage L2
21	40	Block 11 property byte	Property byte of phase-to-neutral voltage L3
	41	Block 12 property byte	Property byte of average power factors of 3 phases
22	42	Block 13 property byte	Property byte of total active energy of 3 phases ^{a)}
	43	Block 14 property byte	Property byte of total apparent power of 3 phases

* Only 2 bytes of the 4 byte data point will be communicated (range: 0 - 65535 MWh)

Exception Status Bits

The Exception Status Bits are accessed using the following functions:

07 Read Exception Status - Reads the state of the Exception Status Bits

Bit	Description
0	Excessive breaker contact wear
1	Communication with trip unit OK
2	COM16 is OK
3 - 7	Reserved

Further information about the application of these inputs and outputs is given in the "WL Modbus RTU Communication Manual" WL Low Voltage Power Circuit Breaker catalog.

Catalog number

	Catalog No.
WL Breaker Configuration Software	POWERCONFIG

9.2.2.6 Metering function PLUS

Trip units ETU745 - ETU776 can be equipped with a metering function *PLUS*. This, however, requires external voltage transformers providing a three-phase metering voltage (such as the Siemens WL3VT).

This data can be shown on the display of the trip units, transmitted by the COM module via PROFIBUS DP, PROFINET IO, Modbus RTU, or Modbus TCP, and passed on to the outputs of external **Cubicle**BUS modules. Based on this data, conclusions can be drawn about the condition of the power system. To use the metering function without communication, an external 24 V auxiliary voltage supply is required.

NOTICE

High voltages may damage the MeteringPLUS module.

The secondary voltage of the external voltage transformers must not exceed 150 V AC RMS or 300 V AC peak value.

In addition to the values for the currents, the metering function *PLUS* provides data on voltages, powers, energy values, power factors and frequency via the **Cubicle**BUS for further processing.

These data can be shown on the display of the trip units, transmitted to the PROFIBUS DP via the COM15 module or to the Modbus RTU via the COM16 module and transferred to the outputs of external **Cubicle**BUS modules. Based on these data, conclusions can be drawn about the condition of the power system.

Measured parameter	Range	Accuracy ¹⁾	
Currents I_{L1} , I_{L2} , I_{L3} , I_N	30 - 8000 A	± 1 % of measurement range	
Ground current measured per GF mode setting (residual or direct sense).	100 - 1200	± 5 % of measurement range	
Line-to-line voltages U _{L12} , U _{L23} , U _{L31}	15 - 130 V 130 - 1150 V	± 5 % of read value ± 1 % of measurement range	
Line-to-neutral-line voltages U_{L1N} , U_{L2N} , U_{L3N}	10 - 75 V 75 - 700 V	± 5 % of read value ± 1 % of measurement range	
Average line-to-line voltages U _{avgD}	15 - 130 V 130 - 1150 V	± 5 % of read value ± 1 % of measurement range	
Average line-to-neutral-line voltages U _{avgY}	10 - 75 V 75 - 700 V	± 5 % of read value ± 1 % of measurement range	
Apparent power S_{L1} , S_{L2} , S_{L3}	13 - 8000 kVA	± 2 % of measurement range ± 2 % vom Messbereich	
Total apparent power	13 - 24000 kVA	± 2 % of measurement range	
Active power P _{L1} , P _{L2} , P _{L3}	-8000 - +8000 kW	\pm 2 % of apparent power (P.F. > 0.6)	
Total active power	-24000 - +24000 kW	± 2 % of apparent power (P.F. > 0,6)	
Reactive power Q_{L1}, Q_{L2}, Q_{L3}	-6400 - +6400 kVar	± 4 % of apparent power	
Total reactive power	-20000 - +20000 kVar	± 4 % of apparent power	
Power factors $\cos \varphi_{L1}$, $\cos \varphi_{L2}$, $\cos \varphi_{L3}$,	-0,6 - 1 - +0.6 -0.6 - 1 - +0,6	± 0.04 ± 0,04	
Power factor total	-0.6 - 1 - +0.6 -0,6 - 1 - +0,6	± 0.04 ± 0,04	
Ampere demand per phase of currents I_{L1} , I_{L2} , I_{L3}	30 - 8000 A	± 1 % of measurement range	
3-phase ampere demand	30 - 8000 A	± 1 % of measurement range	
Active power demand per phase in L_1 , L_2 , L_3	13 - 8000 kW	± 2 % of apparent power (P.F. > 0.6)	
3-phase active power demand	13 - 8000 kW	± 2 % of measurement range	
Apparent power demand per phase in L_1 , L_2 , L_3	13 - 8000 kVA	± 2 % of measurement range	
3-phase apparent power demand	13 - 8000 kVA	± 2 % of measurement range	
3-phase reactive power demand	-8000 - +8000 kVar	± 4 % of apparent power	
Active energy in the normal direction	1 - 10000 MWh	± 2 %	
Active energy in the reverse direction	1 - 10000 MWh	± 2 %	
Reactive energy in the normal direction	1 - 10000 MVarh	± 2 %	
Reactive energy in the reverse direction	1 - 10000 MVarh	± 2 %	
Frequency	15 - 40 Hz 40 - 70 Hz 70 - 440 Hz	± 0.1 Hz ± 0,1 Hz	
Total harmonic distortion of current and voltage	2 - 100 %	\pm 2 % of measurement range up to 29th harmonic	
Phase unbalance of current and voltage ²⁾	2 - 150 %	± 1 % of displayed value	

¹⁾ The given measured value tolerances are valid for one year based on an average operating temperature of 25 °C. After this period, deviations may occur. The given tolerances for measured values for which the measured voltage is consumed when being determined are only valid if the voltage measurement is carried out with an accuracy of 0.5 %.

 $^{2)}$ ANSI definition: Ratio of the largest difference between the phases and the average of all 3 phases.

Extended metering functions

The metering function PLUS is used to implement extended protective functions beyond the functionality of the trip units.

Parameter	Range	Delay
Undervoltage	100 - 1100 V	0 - 15 sec.
Overvoltage	200 - 1200 V	0 - 15 sec.
Active power in normal direction	1 - 12000 kW	0 - 15 sec.
Active power in reverse direction	1 - 12000 kW	0 - 15 sec.
Overfrequency	40 - 70 Hz	0 - 15 sec.
Underfrequency	40 - 70 Hz	0 - 15 sec.
Phase current unbalance 1)	5 - 50%	0 - 15 sec.
Phase voltage unbalance 1)	5 - 50%	0 - 15 sec.
Phase rotation		
Pickup THD current	3 - 50%	5 - 15 sec.
Pickup THD voltage	3 - 50%	5 - 15 sec.

1) ANSI definition:

Ratio of the largest difference between the phases and the average of all 3 phases.

If one of these parameters exceeds or falls below its default settings, the trip unit is tripped after the adjusted delay via the CubicleBUS.

The parameters can be adjusted via:

- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)
- the graphical display (ETU776)

Setpoints

The setpoint function can be used to signal or record special events in the power system.

Parameter	Range	Delay
Phase overcurrent	30 - 10000 A	0 - 255 sec.
Ground overcurrent	30 - 12000 A	0 - 255 sec.
Neutral overcurrent	30 - 10000 A	0 - 255 sec.
phase current unbalance*	5 - 50%	0 - 255 sec.
current demand	30 - 10000 A	0 - 255 sec.
undervoltage	100 - 1100 V	0 - 255 sec.
phase voltage unbalance*	5 - 50%	0 - 255 sec.
overvoltage	100 - 1100 V	0 - 255 sec.
overpower in normal direction	1 - 12000 kW	0 - 255 sec.
KW reverse	1 - 12000 kW	0 - 255 sec.
KW demand	1 - 12000 kW	0 - 255 sec.
KVA demand	1 - 12000 kVA	0 - 255 sec.
KVAR demand	1 - 12000 kVar	0 - 255 sec.
KVAR consumed	1 - 12000 kVar	0 - 255 sec.
KVAR delivered	1 - 12000 kVar	0 - 255 sec.
KVA	1 - 12000 kVA	0 - 255 sec.
overfrequency	40 - 70 Hz	0 - 255 sec.
underfrequency	40 - 70 Hz	0 - 255 sec.
Under-PF (power factor)	-0.001 - 0.001	0 - 255 sec.
Over-PF (power factor)	-0.001 - 0.001	0 - 255 sec.
current THD	3 - 50%	0 - 255 sec.
voltage THD	3 - 50%	0 - 255 sec.
crest factor	1 - 2.55	0 - 255 sec.
form factor	1 - 2.55	0 - 255 sec.

1) ANSI definition:

Ratio of the largest difference between the phases and the average of all 3 phases.

If one of these parameters exceeds or falls below its default settings, the trip unit is tripped after the adjusted delay via the CubicleBUS.

The parameters can be adjusted via:

- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)
- the graphical display (ETU776).

Additional functions

The metering function Plus offers two additional functions:

- two independent waveform buffers
- harmonic analysis

The two independent waveform buffers can be used to analyze the current and voltage values at the time of the event.

If the waveform buffers are programmed to "recording" (standard setting), continuous recording takes place until a previously defined event occurs. Then, the recording is stopped, and the current or voltage waveforms at the time of the event can be observed on a visual display (graphical LCD, laptop or PC). The time window is one second; the resolution is 1649 values/second.

Settings for waveform buffers		
Currents	$I_{L1}, I_{L2}, I_{L3}, I_{LN}, I_{g}$	
Voltages	U_{L1}, U_{L2}, U_{L3}	

The waveform buffers can also be started or stopped individually via the communication channels (PROFIBUS DP, PROFINET IO, Modbus TCP, Modbus RTU, **Cubicle**BUS).

The waveform buffers can be parameterized via:

- TD400 and the software "powerconfig"
- the COM modules with a PC with the software "powerconfig" installed \rightarrow (page 28-2)
- the graphical display (ETU776)



The metering module ("MeterPLUS Function") can be set to expect 3W or 4W (LL/LG) connections and will correct the amplitude and phase of the signal as necessary.

The parameters on the trip unit must be set as follows:

- (1) VT Primary voltage (100 V ac ... 1200 V ac)
- (2) VT Secondary voltage
- (100 V/110 V/120 V)
- (3) VT Connection
 - (Wye / LG, Delta / LL)

Three VTs must be used at all times.

All three VTs must be rated for the rated LL voltage (e.g. 480 V) and can have either 100 V / 110 V or 120 V secondary rated voltage.







Note: Required primary and secondary overcurrent protection (fusing) not shown for clarity.

9.2.3 External CublicleBUS modules

9.2.3.1 General

Application

External **Cubicle**BUS modules are used for communication between the WL circuit breaker and the secondary equipment in the circuit breaker panel. They are provided to control analog indications, transmit the circuit breaker tripping status and the reason for tripping and to read additional control signals. Furthermore, with one of these modules it is possible to implement a zone selective interlocking for short-circuit protection.



CubicleBUS connections at module: X3-1 = Ground 24V DC X3-2 = CubicleBUS -X3-3 = CubicleBUS + X3-4 = +24V DC

CubicleBUS connections at breaker: X8-1 = CubicleBUS -X8-2 = CubicleBUS + X8-3 = +24V DC X8-4 = Ground 24V DC

- (1) Indicator LED
- (2) Rotary coding switch
- (3) Connection X3: CubicleBUS
- (4) Connection X5: inputs or outputs
- (5) Connection X4: inputs or outputs
- (6) Connection X2: **Cubicle**BUS
- (7) Connection X1: CubicleBUS
- (8) "TEST" button

Installation

The external **Cubicle**BUS modules are snapped onto a standard 35-mm DIN rail inside the switchgear panel. It must be ensured that the length of the connecting cable of the first module to the circuit breaker does not exceed 6.5 ft.

Connection setup

The **Cubicle**BUS modules must only be connected to each other and to the circuit breaker using the pre-assembled cables supplied. These cables are also used for the 24 V DC voltage supply of the **Cubicle**BUS modules.

If more than two CubicleBUS modules are connected, the 24 V DC voltage supply must be fed via a separate cable from module to module.

Only one **Cubicle**BUS module can be connected directly to a circuit breaker. Further modules must be connected from module to module. Radial cables are not permissible.

If provided, the ZSI module is always the first module, and must be connected directly to the circuit breaker.

The CubicleBUS cable must be connected to the X3 connection of the last module with a 120 Ω 0.5 W resistor.

The total length of the **Cubicle**BUS cables must not exceed 30 ft from auxiliary current plug X8 of the circuit breaker to the last **Cubicle**BUS module.



- Connecting cable to 1st module (4-conductor, conductors X8-4/X3-1 twisted with X8-3/X3-4 and X8-1/X3-2 twisted with X8-2/X3-3) Connecting cables between modules (1)
- (2) (3) CubicleBUS modules
- (4)
- Terminating resistor 120 Ω 0.5 W Cable connection for 24 V DC voltage supply (5)

Circuit breaker with COM module



(1) Only if there are more than 2 **Cubicle**BUS modules:

Connecting cables between the X8 and the first CubicleBUS module for 24 V DC voltage supply

- Connecting cables between **Cubicle**BUS modules
- CubicleBUS modules
- (2) (3) (4) Terminating resistor 120 Ω 0.5 W
- (5) Connecting cables between the modules for 24 V DC voltage supply
- Connecting cable between the COM module and the first **Cubicle**BUS module (with two RJ45 plugs) (6)
- COM module (7)



The value 0.1 is set if the rotary switch is positioned in this **segment**



Indicators

LED	Indication	Significance	
	green	Module in operation	
DEVICE	yellow	Module in test mode	
	red	Module faulty	
	green	Connection to CubicleBUS available	
Cubicieboo	off	No connection to CubicleBUS	
All other LEDs	yellow	Option set or signal available	
	off	Option not set or no signal available	

Module test

NOTICE

Unintended operation of the circuit breaker and other devices.

The test circuits of this unit emit real output signals that may cause operation of the circuit breaker and other devices that may be connected to the associated CubicleBUS module.

During the test, the circuit breaker and downstream devices shoud be isolated to prevent unintended device operations.

The correct operation of the **Cubicle**BUS modules can be verified in the test mode. The test mode is started by pushing the "TEST" button once. All outputs and the associated LEDs are switched off. The color of the DEVICE LED changes from green to yellow.

Testing inputs and outputs

Pressing the "TEST" Button	Reaction
Twice quickly	- LED 1 on - Input/output 1 on
After a pause, twice quickly	- LED 1 and input/output 1 off, LED 2 on - Input/output 2 on
After a pause, twice quickly	- LED 2 and input/output 2 off, LED 3 on - Input/output 3 on
After a pause, twice quickly	- LED 5 and input/output 5 off, LED 6 on - Input/output 6 on
After a pause, once	Input/output 6 off, all LEDs on
Once	Test mode starts again, all inputs/outputs and the associated LEDs are off

Pushing the "TEST" button several times in quick succession when an LED is on switches the respective input/output on and off alternately.

Testing LEDs only

Pushing the "Test" button several times with pauses in between switches the LEDs on successively. After the last LED, all LEDs are switched on.

Repeated pushing the "TEST" button starts the test mode again, and all LEDs, inputs and outputs are switched off.

Leaving the test mode

Do not press the "TEST" button for approximately 30 sec.

If all LEDs are on, the test mode will already be quitted after about 4 sec.

9.2.3.2 ZSI module

Function

When circuit breakers are combined with ZSI modules, a short-circuit occurring in systems with several grading levels can be precisely localized.

For this purpose, all circuit breakers are interconnected via their ZSI modules.

When a short-circuit or ground-fault occurs, each circuit breaker affected by the short-circuit current queries its downstream circuit breaker to determine whether the short-circuit is present in the next downstream device. Only the circuit breaker nearest the short-circuit, in the upstream direction, is tripped. If "S" or "S+G" is selected on the ZSI module and the circuit breaker does not receive a blocking signal - ZSI-IN - from its downstream circuit breaker, in the event of short-circuit, the delay time setting for the short-circuit trip is set to 50 ms. If a short-circuit is detected, a blocking signal - ZSI-OUT - will be sent to the upstream circuit breakers. The trip takes place after 50 ms. It typically delays between 80 and 90 ms.

If "S" or "S+G" is selected on the ZSI module and the circuit breaker does not receive a blocking signal - ZSI-IN - from its downstream circuit breaker, in the event of ground-fault, the delay time setting for the ground-fault trip is set to 100 ms.

If a ground-fault is detected, a blocking signal - ZSI-OUT - will be sent to the upstream circuit breakers. The trip takes place after 100 ms. It typically delays between 130 and 140 ms.

After a maximum delay time of 3 s, a given blocking signal ZSI-OUT is terminated.

Installation

\rightarrow (page 9-83)

Connection

 \rightarrow Connection setup (page 9-83)

Only one ZSI module can be connected per circuit breaker.

If the ZSI module is used together with other **Cubicle**BUS modules, the ZSI module must be connected directly to the COM module or secondary terminal block X8.

SIEMENS	WLZSIMD
ZONE SELECTIVE INTERLOCKING	(ZSI)
OEVICE G IN CubicleBUS S OUT	
TEST OFF G S+G TEST	
CubicleBUS X1 X2 X3	-10 20 30 40
TIE ZSI ZSI MV BRKR IN OUT OUT X4-10 20 30 40 50 60 70 80 90	9

0531

Terminal	Connection
TIE BRKR	Only for Tie Breakers; Allows complete ZSI functionality in systems with tie breakers
ZSI IN	ZSI modules of downstream circuit breakers
ZSI OUT	ZSI modules of upstream circuit breakers
MV OUT	Signal to the medium-voltage level

Observe the specified polarity when connecting: plus to plus and minus to minus.

The maximum wire length of the ZSI wiring is 400 m for a wire diameter of AWG 18 (2-wire conductor).

For ZSI connections between only WL circuit breakers, wire lengths of up to 1000 m are permissible if the conductor diameter is increased to AWG 13.

The ZSI connections must consist of twisted pair cables or shielded cables.

The ZSI module allows connection of up to:

- 8 circuit breakers at the ZSI IN input and
- 20 circuit breakers at the ZSI OUT output

Note: Prior to testing the circuit breaker via primary injection and while 24v dc is applied to the trip unit and ZSI module, turn the rotary switch to OFF. If this is not done, the trip unit will "remember" being part of the ZSI system and will always trip according to its ZSI time (80ms) during a short-time overcurrent test instead of in its set delay.

Be sure to turn ZSI back on prior to re-energizing the system.

\rightarrow Changing settings (page 9-86)

Settings ZSI module	
OFF	ZSI function deactivated
S	ZSI module effective for short-time delayed short-circuits only
G	ZSI-module effective for ground-fault protection only
S+G	ZSI-module effective for short-time delayed short-circuits and ground-fault protection
TEST	Test position for checking the ZSI functionality

Indicators

 \rightarrow (page 9-86)

Testing

\rightarrow (page 9-86)

In addition, a special test feature of the ZSI module (rotary coding switch in TEST position) makes it possible to check the ZSI wiring and the operativeness of the ZSI electronics.

9.2.3.3 Digital input module

Function

With the digital input module, up to 6 additional binary signals (DC 24 V) can be connected to the system.

These input signals are transferred to the PROFIBUS DP, PROFINET IO, Modbus RTU and Modbus TCP via the **Cubicle**BUS, and can be evaluated accordingly.

For trip units ETU776, it is possible as an alternative to use an input signal of this type at input 1 to switch between two different sets of protection parameters (if provided).

Installation

 \rightarrow (page 9-83)

Connection

 \rightarrow Connection setup (page 9-83)

A maximum of two digital input modules can be operated on the CubicleBUS at the same time

- 1 module with the "BUS INPUT" setting
- 1 module with the "PARAMETER SWITCH" setting

SIEMENS	WLDGNCUB
DIGITAL INPUT (24 V)	
DEVICE 1 2 3 CubicleBUS 4 5 6	
TEST 16 BUS PARA Input SW	METER ITCH 1
CubicleBUS X1 X2 X3	-10203040
X5-10 20 30 40 50 6 X4-10 20 30 40 50 60 70 80 90 X4-10 20 30 40 50 60 70 80 90	3 70 80 90 3

Terminal assignment of digital input module	
X4	Inputs 4-6
X5	Inputs 1-3

Settings

\rightarrow Changing settings (page 9-86)

Settings of digital input module		
PROFIBUS DP INPUT	Inputs 1-6 are active. If an input signal is present, a corresponding message is output via the COM module to the respective fieldbus.	
PARAMETER SWITCH	Input 1 is used for parameter switchover. All other inputs have no function. No input signal (LED 1 not lights up): Parameter set A activated Input signal available (LED 1 lights up): Parameter set B activated	

NOTE

The parameter switchover query can be overruled by a query via the PROFIBUS DP, Modbus RTU and Modbus TCP / PROFINET IO-communication, the TD400 or the graphical display. For further details please refer to "SENTRON 3WL / 3VL Circuit Breakers with communication capability - PROFIBUS DP".

Indicators

→ (page 9-86)

Testing

→ (page 9-86)

9.2.3.4 Digital output modules

Function

With digital output modules, up to 6 signals can be transmitted.

If the trip unit signals an event, the corresponding LED lights up after the adjusted delay time has elapsed, and the module sets a signal at the corresponding output.

Digital output modules are available in the following versions:

- with rotary coding switch and relay outputs
- configurable and with relay outputs

Installation

 \rightarrow (page 9-83)

Connection

 \rightarrow Connection setup (page 9-83)

If a combination of digital output modules with rotary switch and configurable digital outputs is to be connected to a circuit breaker, the following can be connected per circuit breaker:

- 1 digital output module with rotary coding switch and output assignment 1
- 1 digital output module with rotary coding switch and output assignment 2
- 1 configurable digital output module

Terminal assignment

Digital output modules with rotary switch



- (1) Output assignment 1
- (2) Delay time setting
- (3) Output assignment 2

Configurable digital output modules

SIEMENS	WLRLYCCUB	
CONFIGURABLE RELAY OUTPUT		
 ○ DEVICE ○ 1 ○ 2 ○ 3 ○ CubicleBUS ○ 4 ○ 5 ○ 6 		
TEST		
CubicleBUS X1 X2 X3	-10 20 30 40	
X5-10 20 30 40 50 60 X4-10 20 30 40 50 60 70 80 90	5 76 86 90 5	0560 U

Terminal assignment of digital output module X4 Outputs 4-6

X5	Outputs 1-3

Digital output modules with relay output provide changeover contacts at their outputs.

Current carrying capacity of the outputs	
Relay output	250 V AC, 12 A 25 V DC, 12 A

Settings

Digital output modules with rotary coding switch

 \rightarrow Changing settings (page 9-86)

Terminal assignment 1 (TRIP)		
L	Signaling contact overload tripping	
S	Signaling contact short-time delayed short-circuit tripping	
I	Signaling contact instantaneous short-circuit tripping	
G	Signaling contact ground-fault tripping	
G ALARM	Signaling contact ground-fault alarm	
Ν	Signaling contact neutral conductor tripping	

Delay time setting	
TRIP	0 - 2 sec.
ALARM	0 - 2 sec.

The delay time setting determines how long a signal of the trip unit must be present until the corresponding LED lights up and the signal is set at the corresponding output.

Output assignment 2 (ALARM)		
PRE TRIP	Signaling contact leading signal overload tripping (delay time 0 sec.)	
TU ERR	Signaling contact ETU error	
LD SHED	Signaling contact load shedding (delay time 0 sec.)	
LD REST	Signaling contact load restore (delay time 0 sec.)	
TEMP	Signaling contact temperature alarm	
I UNBAL	Signaling contact phase unbalance current	

Configurable digital output modules

The configurable output module is pre-programmed with the most frequently-used events assigned to the outputs. The configuration can be changed using:

- the with the TD400 through the test connector of the trip unit
- through a COM module using the PC software "powerconfig" \rightarrow (page 28-2).

Default Event Settings	
1:	Parameter Set B Active
2:	Load Shed Alarm Active
3:	Circuit Breaker Open
4:	Circuit Breaker Tripped
5:	Parameter Set B Active
6:	Circuit Breaker Closed

Indicators

 \rightarrow (page 9-86)

Testing

 \rightarrow (page 9-86)

9.2.3.5 Analog output module

Function

With the analog output module, analog measured values can be transmitted, which can be shown on the cubicle door by means of moving-coil instruments. A total of 4 outputs is available.

For the output signal, two different formats can be selected:

- 4 20 mA, output via terminal strip X5
- 0 10 V, output via terminal strip X4

Installation

 \rightarrow (page 9-83)

Connection

 \rightarrow Connection setup (page 9-83)

A maximum of 2 analog output modules can be connected; the rotary coding switches of these modules must, however, have different settings.

Terminal assignment

SIEMENS	١	WLANLGOUT
ANALOG OUTPL	JΤ	
ODEVICE CubicleBUS	()A01()A02 ()A03()A04	
TEST	420mA 010 COS Φ f U P U f L COS Φ	v
CubicleBUS X1	X2 X3	-10203040
420mA X5- 010V X4-	20 30 40 50 60 D 00 00	7 8 8 9 9 9 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Settings

\rightarrow Changing settings (page 9-86)

The measured values to be signaled are adjusted using the rotary switch. They are always present on the two terminal strips in the corresponding format.

The following values are available at the outputs:

Output assignment							
Position	AO 1	AO 2	AO 3	AO 4			
I	I _{L1}	I _{L2}	I _{L3}	I _N			
U	U _{L12}	U _{L23}	U _{L31}	U _{L1N}			
Р	P _{L1}	P _{L2}	P _{L3}	S _{total}			
f	f	U _{LLavg}	P _{total}	P.F. _{avg}			
P.F.	P.F. _{L1}	P.F. _{L2}	P.F. _{L3}	Phase unbalance current in%			

Indicators

→ (page 9-86)

Testing

 \rightarrow (page 9-86)

9.2.3.6 Catalog numbers

Each CubicleBUS module is supplied with a 0.2 m (7.8") connecting cable for the CubicleBUS connection.

CubicleBUS module	Catalog No.
ZSI module	WLZSIMD
Analog output module	WLANLGCUB
Digital output module with relay output	WLRLYCUB
Digital output module with relay output, parameterizable	WLRLYCCUB
Digital input module	WLDGNCUB
CubicleBUS cable (1 m)	WLCBUSCABLE1
CubicleBUS cable (2 m)	WLCBUSCABLE2
CubicleBUS cable (0.2 m)	WLCBUSCABLE02
CubicleBUS cable (4 m)	WLCBUSCABLE4
CubicleBUS cable (9 m)	WLCBUSCABLE9

9.2.4 External sensor for neutral conductor





- Version for copper bar on switchgear side Mounting bracket
- (1) (2) (3) (4) (5)
- Screw M6 with washers and nut
- Version with copper connectors
- Connector P2
- (6) Connector P1

\rightarrow Dimension drawings (page 7-18)

Terminal assignment

Remove bridge X8.9 - X8.10



This arrangement ensures the same direction of the current flow for the circuit breaker and the external neutral sensor.

9.3 External voltage supply

The basic protective functions (L, S, I, & G) of the electronic trip units do not require an auxiliary power supply.

To use the extended functions of trip units ETU745 - 776 requiring data exchange via the **Cubicle**BUS, an external 24 V DC (class 2) voltage supply must be connected.

Connection

Version A: Connection to secondary terminal block X8 (preferred version) Version B: Connection to any **Cubicle**BUS module



Requirements

The external voltage supply with 24 V DC must fulfill at least the requirements of UL class 2.

The Siemens power supply listed below may be used to supply power to a single circuit breaker. A second circuit breaker requires its own power supply.

The external power supply used for electronic components must not be used to supply the motor-operated mechanism.

When using voltage supply units from other manufacturers, the following conditions must be fulfilled:

- Primary-switched-mode power supply unit
- 24 V DC, \pm 3 %
- Current rating: minimum 3.7A per circuit breaker
- EMC according to: IEC 61000-4-4, 4kV on main side; IEC 61000-4-5, 4kV line-to-earth, 2kV line-to-line.

Catalog number

Power supply	Catalog No.	MLFB
120/230 VAC / 24 VDC, 3.8A SITOP PSU100C NEC CLASS 2	WLSITOP1	6EP1332-5BA20

9.4 Handheld test device

The handheld test device is used to check that the trip unit, the energy and current transformers, the F5 tripping coil and the measured value display are functioning properly.

9.4.1 View



- (1) LED for operating voltage indication
- (2) Control buttons
- (3) 6 LEDs to show test results

9.4.2 Preparations

- Open and isolate the circuit breaker
- Document the trip unit setting values of the overload release
- Setting value $I_R = 1.0 I_n$
- Interrupt external voltage supply for the electronic system, if present
- Remove the cap from test connector X25 of the trip unit

NOTICE

Circuit breaker may trip.

If the trip settings are changed while the breaker is closed (and under load) the breaker may trip.

Adjust parameters only when the circuit breaker is in the open position.
9.4.3 Connecting

NOTE Observe the connecting sequence. Malfunctions and incorrect test results may result if the sequence is not observed.



(2) 40-pole ribbon c(3) Voltage supply

(1)

(4) Handheld test device

9.4.4 Voltage supply

The handheld test device is supplied by a 110 - 125 V AC network.

9.4.5 Operation

The status test begins after the voltage supply has been connected. The various components and parameters of the trip unit are queried. If the status test has been completed successfully, the "ETU STATUS" LED will light up continuously.

If it has not been completed successfully, the "ETU STATUS" LED will flash. The type of flashing indicates what type of fault is present.

Indicator	Significance
1 x briefly, pause	Handheld test device defective
2 x briefly, pause	Trip unit defective
4 x briefly, pause	 Parameters not set correctly Current sensor not properly connected Wrong Rating Plug Missing Rating Plug
5 x briefly, pause	 Tripping coil F5 not properly connected Coil defective

The status test can be repeated any time by pressing the "START" button for at least three seconds.

It is also possible to test a trip unit that is already activated, i.e. one that is supplied by an external voltage source. However, it must be taken into account that the "ETU STATUS" LED may briefly flash twice when the status test result is displayed, even if there have not been any faults. As a precaution, the status test should be repeated without external voltage supply.

Testing the current and energy sensors

To test the current sensors and energy transducers, press the "START" button.

START

A lit-up LED confirms the proper operation of the corresponding sensor/converter. If an LED flashes, the corresponding sensor/converter is not present, not properly connected, nonconforming, or a transformer without power supply is connected.

Testing the tripping function

To test the tripping function, press one of the buttons "L", "S", "I", "N" or "G".



Long-time delayed tripping Test

The long-time delayed short-circuit tripping function and the trip unit circuitry can be tested using the test device.



- 1 Charge the circuit breaker
- 2 Close the circuit breaker
- 3 Press the [L] button

The circuit breaker will trip after the set long-time delay time, plus approx. 2 seconds processing time, has elapsed. If the test device has completed a test without faults, the "ETU STATUS" LED will light up continuously green. If a fault is detected, the LED will flash. The type of flashing indicates what type of fault is present (fault codes are listed on page 9-104).

Short-time delayed tripping Test

The short-time delayed short-circuit tripping function and the trip unit circuitry can be tested using the test device.



- 1 Charge the circuit breaker
- 2 Close the circuit breaker
- 3 Press the [S] button

The circuit breaker will trip after the set short-time delay time, plus approx. 2 seconds processing time, has elapsed. If the test device has completed a test without faults, the "ETU STATUS" LED will light up continuously green. If a fault is detected, the LED will flash. The type of flashing indicates what type of fault is present (fault codes are listed on page 9-104).

Instantaneous tripping test

The instantaneous tripping function and the trip unit circuitry can be tested using the test device.



- 1 Charge the circuit breaker
- 2 Close the circuit breaker
- 3 Press the [I] button

The circuit breaker will trip after approx. 2 seconds processing time. If the test device has completed a test without faults, the "ETU STATUS" LED will light up continuously green. If a fault is detected, the LED will flash. The type of flashing indicates what type of fault is present (fault codes are listed on page 9-104).

Neutral conductor tripping test

The long-time delayed short-circuit tripping function for the neutral conductor and the trip unit circuitry for ETU type 776 can be tested using the test device. The current sensor for the neutral conductor must be attached (page 9-97) and the "Neutral conductor protection" function must be switched on (page 9-13).



- 1 Charge the circuit breaker
- 2 Close the circuit breaker
- 3 Press the [N] button

The circuit breaker will trip after the set long-time delay time, plus approx. 2 seconds processing time, has elapsed. If the test device has completed a test without faults, the "ETU STATUS" LED will light up continuously green. If a fault is detected, the LED will flash. The type of flashing indicates what type of fault is present (fault codes are listed on page 9-104).

Ground-fault tripping test

The ground-fault tripping function and the trip unit circuitry of ETU types 745-746 with an installed ground-fault protection module (with tripping function WLGFM48 or WLGFM76) can be tested using the test device. The current sensor for the neutral conductor (page 9-97) and/or the iron-core ground-fault sensor (page 9-44) must be attached.



- 1 Charge the circuit breaker
- 2 Close the circuit breaker
- 3 Press the [G] button

The circuit breaker will trip after the set ground-fault tripping delay time, plus approx. 2 seconds processing time, has elapsed. If the test device has completed a test without faults, the "ETU STATUS" LED will light up continuously green. If a fault is detected, the LED will flash. The type of flashing indicates what type of fault is present (fault codes are listed on page 9-104).

Testing the measured value display

This function works by inputting a signal into the trip unit. The signal is displayed as a single-phase current on the trip unit's display, and the current's measured value is also transmitted via the communication interface to the connected **Cublicle**BUS modules and the connected Modbus RTU / PROFIBUS DP networks.

This feature only works with an integrated display (WLETU745 with WLLCD48, WLETU776), and communicates test signals when a communication interface and/or a **Cublicle**BUS module is installed on the trip unit. This feature does not work when a MeteringPLUS (WLMETERP) module is installed.



- 1 Connect 24 V DC to power the trip unit.
- 2 Press the [I] and [N] buttons simultaneously

A single-phase test signal is fed into the trip unit, which simulates a single-phase load current for the ETU. The local display, the connected communications and connected **Cublicle**BUS modules output this current value. The test signal will specify the simulated value to the first phase for 30 seconds, before changing to the next phase. The cycle runs in the order L1, L2, L3, N, G. The test cycle is completed when all phases have been tested.

Activation the trip unit

To activate the trip unit, press the "N" and "G" buttons simultaneously.



The trip unit will remain activated until another button on the handheld test device (WLTS) is depressed.

With this function, the "T.U.-Error"-LED can be checked if the status test had finished with the error "Trip unit defective".

9.4.6 Finishing

- Restore the documented settingsMount the cover on X25

9.4.7 Catalog numbers

	Catalog No.
Handheld test device	WLTS
Replacement cables	WLTSC

10 Reset the reclosing lockout and the Bell Alarm

10.1 Resetting the Bell Alarm



10.2 Resetting the Bell Alarm with reclosing lockout (optional)

WL circuit breakers are normally configured to be immediately "Ready-to-close" again following a trip. With the automatic reset of the Bell Alarm, the tripping coil is automatic resetting after the trip unit has tripped. The circuit breaker is immediately "Ready-to-close" again. For confirmation, the tripped indicator must be reset, either manually on the trip unit or via the remote reset coil.

When the WL breaker is configured with option WLNOAUTRSET, the tripping coil must be manually reset before the circuit breaker is capable of closing. The following instruction details the resetting of the Bell Alarm, and the tripping coil.



10.3 Field Installation of a reclosing lockout

To activate the Bell Alarm lockout, the automatic reset must be removed. The tripping coil, the tripped indicator and the tripped signal must be reset manually at the breaker. Reclosing of the circuit breaker is blocked until the trip indicator has been reset.

\mathbf{A}	DANGER
$\sqrt{\eta}$	Hazardous voltage.
	Will cause death, serious personal injury, or equipment damage.
	Turn off and lock out all power supplying this equipment before working on this device.



High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2).
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3).
- Remove front panel \rightarrow (page 23-4).
- Remove the trip unit \rightarrow (page 9-49).

10.3.1 Removing the automatic reset mechanism





- Remove lock washer 1
- Remove bolt 2
- Remove reset spring 3

Then

- Install trip unit → (page 9-49)
 Install front panel → (page 23-4)

NOTICE

Can only be used with automatic reclosing lockout reset. The remote reset coil will otherwise be overloaded and damaged.

10.4.1 Mounting remote reset coil and cut-off switch

DANGER Hazardous voltage.
Will cause death, serious personal injury, or equipment damage. Turn off and lock out all power supplying this equipment before working on this device.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2).
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3).
- Remove front panel \rightarrow (page 23-4).
- Remove the trip unit \rightarrow (page 9-49).

NOTICE

When routing the wires, care must be taken to ensure that wires are not damaged when reinstalling the ETU carriage.









10.4.2 Connecting wires





Terminals

X8.13 X8.14



Then

- Install trip unit \rightarrow (page 9-49)
- Install front panel \rightarrow (page 23-4)

10.4.4 Updating the options label

NOTE

After installing additional electrical components, add the following data and mark with a "x", using an indelible ink pen.

Charging Motor X5-1 (-) 240 VAC	1st Shunt Trip X6-13 (-) 240 VAC	2nd Shunt Trip X9-1 (-) VAC	Ready to Close Switch	UVR Switch X9-10 240 VAC	52a 1st Aux. SW. 52b X6-3 <u>X6-11</u> X6-1 <u>X6-9</u>	Bell Alarm 240 VAC
X5-2 (+) 250 VDC Remote Close Coll X6-7 (+) 120 VAC X8-6 (-) 135 VDC X6	X6-14 (+) 250 VDC UVR X5-11 (-) 120 VAC V5 12 (4) 125 VDC	X9-2 (+) VDC Remote Reset X8-13 (-) 120 VAC X8 14 (+) 125 VDC	X6-6 4 A 1st Shunt Trip Switch X9-7 240 VAC V0.9 2A	X9-11 3 A Open Fuse Switch X9-5 ⊥ 240 VAC	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	5A X9-12 X9-14
Siemens Industry, Inc., Fort	Worth, TX 76155 USA	* X8-14 (*) . 125 VDC	Assembled	in USA	X5-0 I X5-10 X5-4 I X5-8 240 VAC 10 A/ 125 VDC 0.5 A/ 24 VDC 3A	0131-FW

	Voltage	Catalog No.
	24 V DC	WLRSET24
Electric Boll Alarm reset coil	48 V DC	WLRSET48
	110 - 125 V AC / DC	WLRSET120
	208 - 250 V AC / DC	WLRSET240

Overview 11.1

Mounting locations



- (1) (2)
- 1st shunt trip F1 Signaling switch S22 Closing coil CC
- (3)
- 2nd shunt trip F2 or undervoltage release (instantaneous) F3 or undervoltage release (time-delayed) F4 (4)
- Signaling switch S23 or S43 (5)
- Cut-off switch S14 for shunt trip 5% duty cycle (6)
- Cut-off switch S15 for closing coil CC 5% duty cycle (7)





High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)



/ Retaining bracket



4 Replace retaining bracket and screw down.

11.3 Installing optional signaling switches on shunt trips, closing coils, and undervoltage devices

Signals the the operating status of the shunt trip, closing coil, or undervoltage device to the BSS.





- Snap in place А
- В Disassembly
- (1) Rocker
- Signaling switch Guide
- (2) (3)
- (4) Groove
- Snap-fit (5)
 - 1 Disengage the snap-fit
 - Pull out the signaling switch 2

11.4 Setting delay times on undervoltage release

Instantaneous release



 $t_{\rm d} < 200$ milliseconds short-time delayed:

instantaneous:

 $t_d < 80$ milliseconds



11.5 Field Installation of a cut-off switch for shunt trips and closing coils



pre-wired









С



- A Shunt trip with cut-off switch S14
 B Closing coil with cut-off switch S15
 C Combination of shunt trip and closing coil with combined cut-off switch S14/S15





11.7 Connecting wires

 \rightarrow Circuit diagrams (page 8-4)



11.8 Final tasks

- Install front panel \rightarrow (page 23-4)
- Attach secondary disconnect blocks \rightarrow (page 5-15)
- Connect wires to secondary disconnect block \rightarrow (page 5-14)
- Move the draw-out circuit breaker into the test position \rightarrow (page 6-2)
- Ensure control voltage is connected

11.9 Electrical function test

NOTE

Make sure that the closing coil with 5% operating time is only activated when the circuit breaker is ready for closing. Otherwise the closing coil will be damaged.





11.10 Updating the options label

NOTE

After installing additional electrical components, mark with a "x", using an indelible ink pen. The voltage must also be noted in the box.



0131-FW

Closing coil	VAC 50/60 Hz	VDC	Catalog No.
	_	24	WLRCS24
	_	48	WLRCS48
	110-127	110-125	WLRCS120
	208-240	220-250	WLRCS240

Signaling switches	Catalog No.
Signaling switch for 1st shunt trip	WLSTC
Signaling switch for 2nd shunt trip or undervoltage release	WLUVRC

1st Shunt Trip	VAC 50/60 Hz	VDC	Catalog No.
	_	24	WLST24
Shupt trip E1	_	48	WLST48
	110-127	110-125	WLST120
	208-240	220-250	WLST240

2nd Shunt Trip or UVR	VAC 50/60 Hz	VDC	Catalog No.
	_	24	WLST24
Shunt trip F2	—	48	WLST48
	110-127	110-125	WLST120
	208-240	220-250	WLST240
	_	24	WLUV24
Undervoltage release F3 (instantaneous)	_	48	WLUV48
	110-127	110-125	WLUV120
	208-240	220-250	WLUV240
	_	48	WLUVD48
Undervoltage release F4 (time-delayed)	110-127	110-125	WLUVD120
	208-240	220-250	WLUVD240

12 Auxiliary and control switches



- Bell Alarm S24 (1)
- (2) Cut off switch for remote reset coil S13 \rightarrow (page 10-5)
- (3) Signaling switch blown fuse S26
- (4)
- (5)
- Signaling switch blown use 520 Signaling switch S22 for 1st shunt trip \rightarrow (page 11-3) Signaling switch for "Ready-to-close" S20 Signaling switch S23 for 2nd shunt trip or under-voltage release \rightarrow (page 11-3) (6)
- Contact position-driven auxiliary switch S1 (7)
- (8) Contact position-driven auxiliary switch S2
- (9) Contact position-driven auxiliary switch S4
- (10) Contact position-driven auxiliary switch S3



High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)



The connecting wires from the auxiliary switches must be connected to terminals X5 and X6 according to the wiring plan (page 8-2).

Contact position-driven auxiliary switches	Catalog No.
S1 + S2 (2 "a" + 2 "b" contacts)	WLAS2
S1 + S2 + S3 + S4 (4 "a" + 4 "b" contacts)	WLAS4



Snap-in mounting



The connecting wires from the "Ready-to-close" signaling switch must be connected to terminal X6 according to the wiring plan (page 8-3).

Signaling switches	Catalog No.
"Ready-to-close" signaling switch S20	WLRTCS



Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- Remove trip unit \rightarrow (page 9-49)

NOTICE

Over-tightening the mounting screws may deform the signaling switch and could lead to an incorrect indication of breaker status.

Hardware shall be tightened carefully until the underside of the screw head is flush with the mounting surface.



- (1) S26 assembled with snap-in pins
- (2) S13 snap in assembly
- (3) S25 / S45 assembled with self-tapping screws
- (4) S24 assembled with snap-in pins

The connecting wires from the signaling switches must be connected to secondary disconnects X8 and X9 according to the wiring plan (page 8-3) and (page 8-6).

Signaling switches	Catalog No.
Bell Alarm S24 (1 form C contact)	WLBA

12.4 Control switches - Connecting wires



- (1) Cut-off switch S13 for remote reset
- (2) Cut-off switch S14 for shunt trip $F1 \rightarrow$ (page 11-4)
- (3) Cut-off switch S15 for closing coil CC \rightarrow (page 11-4)
- (4) Motor disconnecting switch $S12 \rightarrow (page 13-3)$

12.5 Communication switches

 \rightarrow Signaling switches for BSS (page 9-55)

12.6 Connecting secondary wiring

 \rightarrow Circuit diagrams (page 8-4)



12.7 Updating the options label

NOTE

After installing additional components, mark the following data with a "x", using an indelible ink pen.



12.8 Mechanism Operated Contacts (MOC)

The circuit breaker may be equipped with an external auxiliary switch assembly. These external auxiliary switches are known as Mechanism Operated Contacts. In short, the assembly is also referred to as the MOC.

The MOC assembly is mounted within the circuit breaker compartment (cradle) and is connected to the main breaker-driveshaft via a coupler, which is added to the circuit breaker during the MOC installation.

The circuit breaker, itself, may be optionally ordered with either no internal auxiliary switches, a set of four internal auxiliary switches (2 a + 2 b contacts), or eight internal auxiliary switches (4 a + 4 b contacts).

With the addition of a MOC device, an additional eight auxiliary switches (4 a + 4 b contacts) may be added to a circuit breaker.

Note referencing ANSI C37.100:

"a" contact: A secondary contact that is open when the circuit breaker is open, and closed when the circuit breaker is closed "b" contact: A secondary contact that is closed when the circuit breaker is open, and open when the circuit breaker is closed



Cradle



- (1) MOC
- (2) 4 signaling switches
- (3) Driver for connected position
- (4) Driver for test position
- (5) Warning label

12.8.1 MOC Versions

The MOC device may be ordered in two versions for drawout circuit breakers:

The auxiliary contacts, in the "Connect Only" version of the MOC, only change state when the circuit breaker is opened/closed while it is in the "CONNECTED" position within the circuit breaker compartment. There are two distinct models of the "Connect Only" MOC, one for circuit breaker frame size 2 (WLMOCC) and a second for circuit breaker frame size 3 (WLMOCC3).

The second version is known as the "Test and Connect" version. In the "Test and Connect" version, the auxiliary contacts change state when the circuit breaker is opened/closed while it is in the "TEST" or "CONNECTED" positions within the circuit breaker compartment. Like the "Connect Only" version, there are two distinct models of the "connect only" MOC, one for circuit breaker frame size 2 (WLMOC) and a second for circuit breaker frame size 3 (WLMOC3).

12.8.2 MOC Installation Instructions

There are two MOC versions available: with and without a driver for the test position. The version with only one drive is generally used for fixed-mounted circuit breakers.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Remove circuit breaker from cradle \rightarrow (page 23-3)

12.8.2.1 Installing the coupler

In order to interface the MOC assembly (mounted in the circuit breaker compartment), the circuit breaker must be outfitted with a coupler (see Figure 1).



Figure 1

In order to install the coupler, the clear plastic plug in the sidewall of the circuit breaker (see Figure 2) must first be removed. Facing the breaker, the plug is on right sidewall. This is easily accomplished by levering with a small screwdriver.



Figure 2

The coupler snaps onto the end of the steel mainshaft. The steel band should not be removed when installing the coupler. Also ensure that the coupler is oriented properly when installed. Figure 3 illustrates the proper installed orientation of a shaft extension (circuit breaker shown in the OPEN position), with the tampered flange facing the rear of the circuit breaker.







NOTE

The tapered flange of the coupler must point towards the rear side of the circuit breaker.

12.8.2.2 Installing the MOC Baseplate Assembly

The MOC baseplate assembly is secured to the circuit breaker compartment (cradle) by two tabs in the rear and two screws in the front. With the screws inserted from the inside of the cubicle, and the nuts and lockwashers on the outside, the nuts must be torqued to 71 lbin (8 Nm).





NOTICE

MOC Reliability

May cause intermittent signaling.

All four contact blocks, whether wired or not, must be installed into the MOC assembly to ensure reliable operation.

The contact blocks must be removed in order to access the terminals for wiring. The contact blocks should be removed by applying a small amount of outward pressure with a thin blade screwdriver, in the area shown in Figure 6.



Figure 6

NOTICE

Contact block damage.

May cause loss of signaling.

Do not over-extend the feet of the contact block when reinstalling into the MOC assembly.

12.8.2.4 Wiring the Contact Blocks

The contact blocks are designated (front of cradle to rear of cradle) S50, S51, S52, and S53. Each contact block contains one "a" and one "b" contact, with the terminal designations as shown below. Each terminal accepts a maximum of one wire, 14 AWG (or smaller), and shall be tightened to 7 lbin (0.8 Nm).



12.8.2.5 Installing the Contact Blocks

NOTICE

MOC Reliability

May cause intermittent signaling.

All four contact blocks, whether wired or not, must be installed into the MOC assembly to ensure reliable operation.

The contact blocks must be firmly seated, with the feet of the contact block latched into the MOC assembly housing. If there is damage to the contact block assembly, a replacement contact block must be used. Replacement contact blocks may be purchased per catalog number WLMOCSWK (includes four replacement contact block assemblies).

NOTICE

Contact block damage.

May cause loss of signaling.

Do not over-extend the feet of the contact block when reinstalling into the MOC assembly.

12.8.2.6 Contact Ratings

Voltaga	Maximum Current		
voltage	Continuous	Making	Breaking
120 VAC	10 A	30 A	3 A
240 VAC	10 A	30 A	3 A
24 VDC	5 A	1.1 A	1.1 A
48 VDC	5 A	1.1 A	1.1 A
125 VDC	5 A	1.1 A	1.1 A
250 VDC	5 A	0.55 A	0.55 A

12.8.3 Order numbers

мос	Catalog No.
Mechanism Operated Auxiliary Contacts, cradle-mounted, 4 NO + 4 NC, Test and connected position, for draw-out circuit breaker only, FS II	WLMOC
Mechanism Operated Auxiliary Contacts, cradle-mounted, 4 NO + 4 NC, Connected position only, for draw-out circuit breaker only, FS II	WLMOCC
Mechanism Operated Auxiliary Contacts, cradle-mounted, 4 NO + 4 NC, Test and connected position, for draw-out circuit breaker only, FS III	WLMOC3
Mechanism Operated Auxiliary Contacts, cradle-mounted, 4 NO + 4 NC, Connected position only, for draw-out circuit breaker only, FS III	WLMOCC3

12.8.4 Combination of MOC and mechanical interlocking module

For the MOC to be combined and operated with the mutual mechanical interlocking module, a special clutch shaft must be used in place of the normal one.



- (1) (2) Clutch shaft
- Lock-nut

12.8.5 Mounting of MOC and mechanical interlocking module on the cradle





Mechanical interlocking module

13 Motor-operated mechanism

For charging the closing spring automatically.

It is switched on if the closing spring is discharged and control voltage is applied.

The motor-operated mechanism is automatically switched off after the closing spring has been fully charged.

13.1 Installing the motor operator





- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)



Mounting the motor on the operating shaft



Fixing the motor-operated mechanism & connecting wires





3,0 x 0,6

Terminals X5.1 (-) X5.2 (+)
13.2 Optional motor disconnect switch on the front panel

Option.

For switching off the motor-operated mechanism control voltage. Supplied pre-assembled with one wire to be soldered .



Installing motor disconnect switch



Connecting motor disconnect switch

- Disconnect the brown wire from the motor-operated mechanism from terminal X5.2.
- Connect wire X5-2 of the disconnect switch S12 to terminal X5.2.
- Solder the brown wire from the motor-operated mechanism to terminal 4 of the disconnect switch S12.



- Factory installed accessory only. Available as replacement kit

 \rightarrow Circuit diagrams (page 8-6)

13.3 Updating the options label

NOTE

After installing additional components, mark the following data with a "x", using an indelible ink pen.



Voltage **Power consumption** Catalog No. 24 V DC / 30 V DC 110 W WLELCMTR24 48 V DC / 60 V DC 120 W WLELCMTR48 Motor-operated mechanism 110-127 V AC / 110-125 V DC 150 W WLELCMTR120 208-240 V AC / 220-250 V DC 130 W WLELCMTR240 24 V DC / 30 V DC 110 W WLELCMTR24S 48 V DC / 60 V DC 120 W WLELCMTR48S Motor-operated mechanism with motor disconnect switch 110-127 V AC / 110-125 V DC 150 W WLELCMTR120S 208-240 V AC / 220-250 V DC 130 W WLELCMTR240S

14 Indicators and operating elements

There are additional indicators and operating elements available for field installation.

14.1 Limiting Access to OPEN/CLOSE Buttons

This accessory kit allows the access to the OPEN and CLOSE buttons of the circuit breaker to be limited in any combination of the supplied components.





High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)

Supplied Components:

- (1) 2x access blocks. Button is only accessible with a 1/8" pin (or smaller) \rightarrow (page 17-2)
- (2) 2x sealing caps for sealing or attaching a padlock to block the button \rightarrow (page 15-22)
- (3) Shield to prevent inadvertent operation
- (4) Mounting plate

NOTICE

Damage to accessory.

Over-tightening the mounting screws may strip the plastic frame, or damage components, rendering the accessory unusable.

Hardware shall be tightened carefully until the underside of the screw head is flush with the mounting surface.



Catalog No.

	Catalog No.
Locking set	WLLKKT

14.2 EMERGENCY OPEN button

This accessory kit allows the installation of an EMERGENCY STOP mushroom pushbutton above the OPEN button. When depressed, the breaker is opened, and the breaker is held in a trip-free condition until the EMERGENCY STOP mushroom pushbutton is released.





NOTE

Install the EMERGENCY OFF mushroom pushbutton as shown (arrow on the right side).

Catalog No.

	Catalog No.
EMERGENCY OFF mushroom pushbutton	WLEPEN

14.3 Operations counter

The operations counter is incremented when the circuit breaker completes the charging cycle (manual or electrically operated). The mechanical operations counter can be installed only if the circuit breaker is equipped with a motor-operated mechanism.



Knocking out the fields on the front panel



Catalog No.

	Catalog No.
Mechanical operations counter	WLNUMCNT

15 Locking devices

15.1 Key Locks

 \rightarrow Padlocking provisions (page 15-16)



	Key lock	Manufacturer	Application
1	Breaker-mounted key lock	kirk Superior	To activate the locking device, the circuit breaker must be opened. If the circuit breaker is closed, the locking device is blocked. The block is only effective when the key is removed. The key can only be removed in "OPEN" position. \rightarrow (page 15-2)
2	Cradle-mounted key lock	KIRK SUPERIOR	This cradle-mounted key lock prevents the closing of any circuit breaker installed in the cell which this lock is installed. Up to two independent Kirk or Superior key locks may be installed. To activate the lock, the circuit breaker must be open. If the circuit breaker is closed, the locking device is blocked. The block is only effective if the key is withdrawn. The key can only be removed in the "OPEN" position. \rightarrow (page 15-4)
3	Racking handle key lock	KIRK SUPERIOR	Prevents drawing out of the racking handle. The circuit breaker is protected from being moved. The block is only effective when the key is removed. \rightarrow (page 15-11)
4	Bell Alarm and open fuse lockout key lock		A lockable cover prevents resetting the Bell Alarm or open fuse lockout after the breaker trips. \rightarrow (page 15-15)



	High speed moving parts.
V	Can cause serious personal injury.
	Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

When the key is removed, the circuit breaker is locked in the open position.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)
- Remove trip unit \rightarrow (page 9-49)

Installing the locking mechanism

For key lock types: KIRK, Superior



NOTE

When removing the screws (1), ensure that the cylinder does not slip out of the lock. If this happens, the lock cannot be re-assembled.

Knocking out the fields on the front panel



Then

- Install trip unit → (page 9-49)
 Install front panel → (page 23-4)

Key lock	Manufacturer	Catalog No.
Breaker mounted key lock	KIRK	WLLKOFFKRK
	SUPERIOR	WLLKOFFSUP



When a key is removed, all circuit breakers racked into this cradle will be locked in the open position.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)





- (1) Countersunk head screw M6 with belleville washer and nut
- (2) M4 socket head cap screw (must not be used in FS II, fused)
- (3) Pre-assembled skid with guide
- (4) Lever
- (5) Spacer
- (6) Kirk key, supplied separately including fixing screws
- (7) Bolt with washer size 5 mm and clip (for 4 mm inner diameter
- groove; (for 4 mm groove; for FS II only)
 (8) 3x M4 socket-head cap screws with lock waschers and nuts (for FS III only)
- (9) Extension (for FS III only)
- (10) Bolt with washer size 5 mm and clip (for 4 mm inner diameter groove; (for 4 mm groove; for FS II only)
- (11) Ramp extension (for FS III only)
- (12) 2x M4 flat-head screw (for FS III only)

- (13) Small attachment angle
- (14) 2x M4 socket-head cap screws
- (15) Spacer (for FS II only)(16) Plastic slider (slotted)
- FS II / III: short slot FS II fused: long slot
- (17) 2x spring lock washers
- (18) Mounting plate
- (19) Pre-assembled lever mechanism
- (20) Attachment angle low
- (21) 2X Thread-forming screws M4x8 and washers
- (22) Bolt (long) with washers size 5 and 6 mm and clip size 4mm
- (23) Bolt (short) with washers size 5 and 6 mm and clip size 4mm
- (24) 2X Clip for 4mm inner diameter groove





Installing the locks

The way in which the locking module unit is installed is the same whether the unit consists of one lock or two locks. Do not use the spacer which may be provided with the key lock. The spacer (5) supplied with the mounting must be used in place of the spacers supplied with the lock.

NOTE

Attach the lever (4) to the KIRK / Superior locks (6) with the screws supplied with the lock. Attach the KIRK / Superior locks (6) together with the spacer (5) to the lock mechanism using the supplied screws.



NOTE

Omit Step 2 for FS II fused circuit breakers

For FS II 4-pole and FS III 3-pole only:



Mounting the skid with guide to the base plate of the cradle





(1) Base plate of the cradle

Mounting the guide on the guide rail



- A Frame size II
- B Frame size III and Frame size II 4-pole
- (1) Guide rail on left side
- (2) Spacer for FS II must be mounted between angle and guide rail
- (3) Attachment angle
- (4) Guide for FS II
- (5) Guide for ANSI FS II fused

Step 3: For FS II fused insert the bolt in to the hole for the long slot.



- Step 1. Mounting the plate with lever mechanism to the base plate of the cradle
- Step 2. Mounting the guide to the attachment angle
- Step 3. Mounting the attachment angle to the guide rail
- Step 4. To connect the lever with the short slot of guide use the long bolt
- Step 5. To connect the lever with the skid, use the short bolt



- (1) Lower edge of door cutout
- (2) Center of front panel
- (3) Mounting surface of cradle
- (4) Hole for first key cylinder
- (5) Hole for second key cylinder (only if planned)

Knocking out the fields on the front panel





- 1 Knock out the fields on the front panel using a suitable base
- 2 Deburr the edges

Then:

- Install front panel \rightarrow (page 23-4)

Function test

- Check that the locking mechanism on the locks can rotate freely when the keys are turned.
- Check that the spring turns the locking mechanism back to the starting position when it is unlocked.
- By repeatedly drawing out and re-inserting the left guide rail, check that the carriage is also actuated and can move freely.

Catalog Numbers

Lock & Key for Cradle Mounting	Manufacturer	Catalog No.
Single lock	Kirk	WLDLKRK
	Superior	WLDSUP
Double lock	Kirk	WLDLDKRK
	Superior	WLDLDSUP

Provision-only for Cradle Lock	Catalog No.
Single Lock Provision	WLDLPR
Double Lock Provision	WLDLDPR

Lock & Key for Cradle Mounting FSII 4-pole	Manufacturer	Catalog No.
Single lock	Kirk	WL4DLKRK2
	Superior	WL4DLSUP2
Double lock	Kirk	WL4DLDKRK2
	Superior	WL4DLDSUP2

Provision-only for Cradle Lock FSII 4-pole	Catalog No.
Lock Provision	WL4DLPR2

Lock & Key for Cradle Mounting FSIII 4-pole	Manufacturer	Catalog No.
Single lock	Kirk	WL4DLKRK3
	Superior	WL4DLSUP3
Double lock	Kirk	WL4DLDKRK3
	Superior	WL4DLDSUP3

Provision-only for Cradle Lock FSIII 4-pole	Catalog No.
Lock Provision	WL4DLPR3

15.1.3 Installing racking handle key lock

When the key is removed, the circuit breaker's racking handle cannot be drawn out, meaning that the circuit breaker cannot be moved into another position.

The key lock for the WL Fuse Carriage racking handle cannot be replaced. If damaged, please consult Technical Support.





High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)

Pre-assembling the locking module



Installing

 \rightarrow









(1) Socket head cap screw M5 with washer and nut

Knocking out the field on the front panel



- 1 Knock out the fields on the front panel using a suitable base
- 2 Deburr the edges

Then:

- Install front panel \rightarrow (page 23-4)

Key lock	Manufacturer	Catalog No.
Circuit-breaker racking bandle key lock	KIRK	WLLKCLKRK
	SUPERIOR	WLLKCLSUP

15.1.4 Installing a Bell Alarm cover key lock

When the key is removed, the cover cannot be removed and the Bell Alarm cannot be reset.



- Cover with safety lock Trip unit (1)
- (2)

Locking



Key lock	Manufacturer	Catalog No.
Bell Alarm and open fuse lockout key lock		WLTUSC55

15.2 Padlocking provisions

 \rightarrow Key Locks (page 15-1)



	Padlock locking device	Application
1	Padlock locking bracket for "OPEN"	The locking bracket for "OPEN" can be locked with up to 4 padlocks 1/4" diameter. The circuit breaker cannot be closed.
2	Shutter	If the circuit breaker has been removed, the shutter can be locked with padlocks. \rightarrow (page 15-19)
3	Guide rails	The guide rails can be locked with 2 padlocks so that they cannot be drawn out. The circuit breaker is either in the connected position or has been removed. It is not possible to insert a circuit breaker into the cradle. \rightarrow (page 15-20)
4	Racking handle	Up to 3 padlocks can be used to prevent the racking handle being drawn out. The circuit breaker is then locked against being moved. \rightarrow (page 15-20)
5	Spring charging lever	The spring charging lever can be locked with a padlock. This prevents manual charging of the closing spring. \rightarrow (page 15-20)
6	CLOSE	Actuation of the CLOSE button can be prevented by locking the sealing cap with up to 3 padlocks. CLOSING via the "electrical CLOSE" button and remote closing remain possible. \rightarrow (page 15-22)
7	OPEN button	Actuation of the OPEN button can be prevented by locking the sealing cap with up to 3 padlocks. Remote closing remains possible.

15.2.1 Padlock locking the breaker OPEN

This padlock provision is a standard feature. When the control gate is raised (step 1), the padlock provision can be extended, and padlocks installed. With padlocks installed, this circuit breaker cannot be closed. This provision will support up to four 1/4" diameter padlocks at one time.

Locking with a padlock



Field installation

$\mathbf{\Lambda}$	DANGER
<u>_4</u>	Hazardous voltage.
Sult	Will cause death, serious personal injury, or equipment damage.
* ZE	
	High speed moving parts.
	Can cause serious personal injury.
	Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)
- Install the control gate if not already present.

Mounting padlock locking bracket





Latching plate in control gate





Then:

- Install front panel \rightarrow (page 23-4)

Padlock locking device	Catalog No.
Padlock locking breaker/OPEN	WLLKNP

15.2.2 Optional: Intalling padlocks

The WL shutter prevents incidental contact with primary conductors when the circuit breaker is removed from the cradle. At the user's option, padlocks may be installed through the arms of the shutter assembly, as a means of locking out direct access to the primary conductors. One padlock through each arm is required to lock out primary conductor direct access.

NOTICE

Remove padlocks before inserting breaker into the cradle.

Frame size 2 shown



15.2.3 Padlock Locking device for guide rails

The cradle is equipped with this locking device as standard. Up to two padlocks can be applied on each side. This prevents a circuit breaker from being inserted into an empty cradle.



15.2.4 Padlock Locking device for racking handle

Draw-out circuit breakers are equipped with this locking device as standard. Up to three padlocks can be applied to prevent the circuit breaker from being racked into another position.



15.2.5 Padlock Locking device for spring charging lever



This locking device is an optional accessory for preventing manual charging of the circuit breaker closing spring mechanism. It does not prevent charging via the motor-operated mechanism.



K

High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- Open the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Remove front panel \rightarrow (page 23-4).





Then:

- Install front panel \rightarrow (page 23-4)

Padlock Locking device	Catalog No.
Locking device for spring charging lever	WLHANDLC

15.2.6 CLOSE/OPEN padlock kit

The manual closing and/or opening of this circuit breaker can be prevented, when this optional accessory is installed. The covers for the CLOSE button and the OPEN button can be fitted with up to three padlocks. With padlocks applied, it is still possible to electrically open and close this circuit breaker.







\Lambda WARNING

High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)

See also → Limiting Access to OPEN/CLOSE Buttons (page 14-1)

NOTICE

Damage to accessory.

Over-tightening the mounting screws may strip the plastic frame, or damage components, rendering the accessory unusable.

Hardware shall be tightened carefully until the underside of the screw head is flush with the mounting surface.





Then:

- Install front panel \rightarrow (page 23-4)

Padlock Locking device	Catalog No.
CLOSE/OPEN Padlock Kit	WLLKKT



- (1) (2) (3)
- Sealing cover for CLOSE button Sealing cover for ETU (electronic trip unit)
- Sealing cover for OPEN button

Sealing cover for CLOSE/OPEN buttons

 \rightarrow Field installation of sealing cover (page 15-23)

Sealing cover for ETU (electronic trip unit)

 \rightarrow Sealing and locking device (page 9-53)

17 Mechanical interlocks



	Mechanical interlock	Application
1	Access block via CLOSE/OPEN button (locking set)	The CLOSE/OPEN buttons are each covered in such a way that operation is only possible with a tool. \rightarrow (page 17-2)
2	Cubicle door locking mechanism	The cubicle door cannot be opened - if the circuit breaker is in the CONNECTED position. \rightarrow (page 17-3)
3	Interlock against racking when cubicle door is open	The racking handle cannot be withdrawn if the cubicle door is open.

17.1 Field installation of CLOSE / OPEN buttons blocking device

This interlock limits access to the circuit breaker's manual CLOSE and/or OPEN buttons. The blocking device only allows access to the manual CLOSE and/or OPEN buttons via a small tool (1/8" diameter rod).

DANGER Hazardous voltage.
Will cause death, serious personal injury, or equipment damage. Turn off and lock out all power supplying this equipment before working on this device.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Remove front panel \rightarrow (page 23-4)

NOTICE

Damage to accessory.

Over-tightening the mounting screws may strip the plastic frame, or damage components, rendering the accessory unusable.

Hardware shall be tightened carefully until the underside of the screw head is flush with the mounting surface.



Then:

- Fit front panel \rightarrow (page 23-4)

Mechanical interlock	Order No.
Access block via CLOSE button (locking set)	WLLKKT

17.2 Cubicle door interlock

ł

This interlock prevents the cubicle door being opened if the circuit breaker is in the CONNECT position.

\wedge	DANGER
<u>_</u> 4	Hazardous voltage.
	Will cause death, serious personal injury, or equipment damage.
	Turn off and lock out all power supplying this equipment before working on this device.
	WARNING
N/C	High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.



Then:

- Insert the draw-out circuit breaker into the cradle and push it into the disconnected position \rightarrow (page 6-1)

17.2.2 Cubicle door interlock drill pattern



- (1) Centerline of breaker front panel
- (2) Door cutout for breaker front panel
- Inner side of cubicle door (3)
- (4)
- (5)
- Hole for manual defeat \emptyset ⁷/₃₂ inches Hole for manual defeat \emptyset ⁷/₃₂ inches Drill this hole only if a manual defeat is required.
- (6) Mounting surface

17.2.3 Installing catch on the cubicle door



- (1) Clip with hole for manual defeat
- (2) Inner side of cubicle door
- (3) Catch
- (4) 2 washers ISO7089 5
- (5) 2 hex nuts M5

17.2.4 Function check

- Rack the circuit breaker into the connected position
- Close the cubicle door

Checking the manual defeat function:



- (1) Lock position with circuit breaker closed
- (2) Device in normal position
- (3) Device in bypassed position

Interlock	Order No.
Door locking mechanism for cradle	WLDRLC



- Open and discharge the closing spring \rightarrow (page 23-2)
- Remove the circuit breaker from the cradle \rightarrow (page 23-3)



Installing the mechanical interlock


Function check

- Insert the circuit breaker into the cradle and push it into the disconnected position \rightarrow (page 6-1)
- It must not be possible to draw out the racking handle

Mechanical interlock	Order No.
Locking device against moving the circuit breaker if the cubicle door is open	WLDRLC5UL

17.4 Coding between circuit breaker and cradle

Draw-out circuit breakers and cradles are equiped with a factory coding.

This coding ensures that only circuit breakers can be inserted whose blade contacts match the contacts of the cradle and whose instantaneous interrupting capacity and rated current correspond to those of the cradle.

18 Additional options for the cradle

18.1 Shutter

The shutter is closed when the draw-out circuit breaker is in disconnect position or outside the cradle.

The shutter can be fixed in a closed position and protected against unauthorized opening by means of padlocks. \rightarrow (page 15-19)



18.1.1 Field installation



Install Shutter Mounts

Shutter mounting assemblies are used to support the shutter assembly. There are four shutter mounts per shutter (as noted by the arrows below).



Place each shutter mounting assembly into the cradle locking holes – first by inserting the rear tines (1A) and then rotating the assembly towards the cradle sidewall (1B). Ensure that the locating dowel pins are seated. The front tines will pass through the rectangular opening in the cradle sidewall.



Use the screwdriver blade to spread the front tines by inserting the screwdriver between the tines, and rotating the blade in clockwise and counter-clockwise motions. This will lock the shutter mounts to the cradle.







Install Shutter to Mounts

The shutter assembly (Item 1) is secured to the shutter mounting assemblies (Item 2) with four M6 x 10mm patch screws (Item 3) as shown below.

Torque each screw to 30 lb-in (four places).

Frame size 2 shown



18.1.2 Catalog numbers

No. of Poles	Frame size	Interrupting class	Catalog No.
	П	N, S, H, L	WLG3SHUT2L
		F	WLG3SHUT2F
3	3	H, L, F	WLG3SHUT3L
	Ш	М	WLG3SHUT3M
		Fuse Carriage	WLG3SHUT3FC
4	II	S, H, L	WLG4SHUT2L
4		H, L	WLG4SHUT3L



Truck-operated contacts (TOC) can be installed in the cradle. These enable the signaling of the horizontal position of the breaker in the cradle.



(1) TOC signaling switch module

Three versions are available (Order numbers \rightarrow (page 18-7).

WLGSGSW111 (Version 1):

- One form C contact for DISCONNECT position (S30)
- One form C contact for TEST position (S31)
- One form C contact for CONNECT position (S34)

WLGSGSW321 (Version 2):

- One form C contact for DISCONNECT position (S30)
- Two form C contacts for TEST position (S31 and S32)
- Three form C contacts for CONNECT position (S33, S34, and S35)

WLGSGSW6 (Version 3):

- Six form C contacts for CONNECT position (S30, S31, S32, S33, S34, and S35)

Terminals

The TOC accessory is equipped with an integrated terminal block. The integrated terminal block is of spring clamp design, and will accept 1xAWG 20 – 1xAWG 14 for each point

Circuit breaker postion and TOC contact state

Switch	Terminal		Circuit breaker position	
Designation	Points	Disconnect position	Test position	Connected position
S30	12			
	└── 4			
S31 / S32	12			
0017002				
S33 / S34 / S35				
33373347333				
TOC Config.3	12			
S33 / S34 /S35				
		Contact open		

Contact closed

Installation

Depending on the amount of room space around the cradle in the apparatus, it may be necessary to wire the TOC prior to installation.









Then:

- Insert the circuit breaker into the cradle and rack it into the connected position \rightarrow (page 6-1)

Catalog numbers

TOC Version	Catalog No.
1 CONNECT, 1 TEST, 1 DISCONNECT	WLGSGSW111
3 CONNECT, 2 TEST, 1 DISCONNECT	WLGSGSW321
6 CONNECT	WLGSGSW6

19 Mechanical circuit breaker interlocking

NOTE

For proper function of the interlocking device, the following minimum prerequisites have to be met:

- 1 Bowden cables are to be laid out as straight and as unbowed as possible.
- **2** Bending radii of the Bowden cables must exceed > 20" (500 mm).
- **3** The total curvature of the Bowden cable must not exceed 540 degrees.
- 4 When stacking interlocked circuit breakers vertically, the interlocking devices shall be vertically aligned with each other.
- 5 Circuit breakers intended to be interlocked must be positioned so that Bowden cables of 6 ft or 15 ft (2 m or 4.5 m) length can be laid out per the above requirements 1-4.
- 6 Before adjusting the interlocking device, the Bowden cables must be secured, e.g. using cable ties.
- 7 Adequate spacing is required to provide enough room for adjustment of the interlocking device.

Mechanical interlocking module



(1) Cradle

(2) Fixed-mounted breaker

19.1 Configurations

A maximum of three circuit breakers may be interlocked.

7

19.1.1 General notes





- (1) Output 1
- (2) Holes with press nut for socket head cap screw M6 with washer for the configuration of the mechanical circuit breaker interlocking
- (2) Holes with press nut for socket(3) Non-interchangeable brackets
- (4) Input 1
- (5) Input 2
- (6) Output 2

In the following configuration instructions, the following designations apply:

- A 1 : Output signal 1
- E₁ : Input signal 1
- S₁ : Circuit breaker 1

For example, in order to couple the output signal 1 of circuit breaker 1 with the input signal 2 of circuit breaker 2, the abbreviation $S_1 A_1 - S_2 E_2$ is used.

The states of the circuit breaker are shown at the front panel:

CONTACTS READY	Circuit breaker closed
O CONTACTS READY	Circuit breaker open and not ready to close (interlocked)
O CONTACTS OK READY	Circuit breaker open and ready to close (not interlocked)

19.1.2 Mechanical interlocking two sources (open transition)

The two sources are interlocked to prevent paralleling (open transition).



Description:

A circuit breaker can be closed only if the other is open.

Materials required:

Each circuit breaker has an interlocking module and a Bowden cable.

Order no. \rightarrow (page 19-3)

1st Bowden cable:	$S_1 A_1$	-	$S_2 E_1$
2nd Bowden cable:	$S_2 A_1$	-	$S_1 E_1$

19.1.3 Mechanical interlocking two sources with a tie circuit breaker (open transition)





Description:

Any two circuit breakers can be closed, with the third being interlocked.

Materials required:

Each circuit breaker has an interlocking module and a Bowden cables. Three additional Bowden cables must be ordered separately.

Order no. \rightarrow (page 19-4)

1st Bowden cable:	S ₁ A ₁ - S ₂ E ₁
2nd Bowden cable:	S ₁ A ₂ - S ₃ E ₁
3rd Bowden cable:	S ₂ A ₁ - S ₁ E ₁
4th Bowden cable:	$S_2 A_2 - S_3 E_2$
5th Bowden cable:	$S_3 A_1 - S_1 E_2$
6th Bowden cable:	$S_3 A_2 - S_2 E_2$

19.1.4 Mechanical interlocking feeder circuit breakers (single load, open transition)



The feeder breakers are interlocked so that only one feeder may be closed at a time.

Description:

When one circuit breaker is closed, the other two cannot be closed.

Materials required:

Each circuit breaker has an interlocking module and a Bowden cable. Three additional Bowden cables must be ordered separately.

Order no. \rightarrow (page 19-5)

1st Bowden cable:	$S_1 A_1$	-	$S_2 E_1$
2nd Bowden cable:	$S_1 A_2$	-	$S_3 E_1$
3rd Bowden cable:	$S_2 A_1$	-	$S_1 E_1$
4th Bowden cable:	$S_2 A_2$	-	$S_3 E_2$
5th Bowden cable:	$S_3 A_1$	-	$S_1 E_2$
6th Bowden cable:	$S_3 A_2$	-	$S_2 E_2$

19.1.5 Mechanical interlocking three sources (open transition to standby system)

The standby system is mechanically interlocked with the two source circuit breakers to prevent paralleling the standby system with either or both primary source(s).



Description:

Two circuit breakers (S_1, S_3) can be independently opened and closed, the third (S_2) being "Ready-to-close" only if the other two are open. If the third is closed, the other two cannot be closed.

Materials required:

Each circuit breaker has an interlocking module and a Bowden cable. A Bowden cable must be ordered separately.

Order no. \rightarrow (page 19-6)

1st Bowden cable:	S ₁ A ₁	-	$S_2 E_1$
2nd Bowden cable:	S ₂ A ₁	-	$S_1 E_1$
3rd Bowden cable:	S ₂ A ₂	-	$S_3 E_1$
4th Bowden cable:	S ₃ A ₁	-	$S_2 E_2$

19.1.6 Mechanical interlocking source and tie circuit breaker (open transition to standby system)

The standby system is mechanically interlocked with the tie circuit breaker to prevent paralleling with primary source.



Description:

One circuit breaker (S_1) can be opened and closed independently of the two others. The two others cancel each other out, i.e. one can only be closed if the other is open.

Materials required:

Two of the three circuit breakers (S_2, S_3) each have an interlocking module and a Bowden cable.

Order no. \rightarrow (page 19-7)

1st Bowden cable:	$S_2 A_1$	-	$S_3 E_1$
2nd Bowden cable:	$S_3 A_1$	-	$S_2 E_1$



- Switch off and discharge the closing spring \rightarrow (page 23-2)
- Remove the breaker from the cradle \rightarrow (page 23-3)
- or remove the fixed-mounted breaker if necessary \rightarrow (page 5-2)
- Remove front panel and side cover on the right, if required
 - \rightarrow (page 23-4)

19.2.1 Installing intermediate shaft and coupling



For frame size I & II, and frame size III fixed mount



Frame size	Hexagon shaft length L ₁ (mm)	Length of assembly L ₂ (mm)
I	48	59
II	118	129
III (fixed mount only)	232	243



NOTE

Working through step **9**, the intermediate shaft must engage in a hole inside the circuit breaker. Only then it will be possible - working through step **10** - to fit the support for the intermediate shaft in the guide of the side wall.





Short lever outside

Function check



Then:

- Replace front panel and side cover on the right, if it was removed \rightarrow (page 23-4)

19.2.2 Fitting interlocking module

Note

If there isn't enough free space for installation on the right side of the circuit breaker inside the cubicle, it may be advantageous to pre-assemble the Bowden cables on the output side before fitting the interlocking module. \rightarrow (page 19-12)

Mechanical interlocking module



- (1) Cradle
- (2) Fixed-mounted breaker
- (3) 2x socket head cap screw M6x12 with strain washer
- (4) 1x socket head cap screw M6x25 with strain washer and square nut
- (5) 2x socket head cap screw M6x35 with strain washer
- (6) 2x jam nut; penetrates into mounting foot by tightening; if necessary, prevent jam nut from rotating
- (7) 1x washer with large outside diameter

Then:

- Install back the breaker \rightarrow (page 5-2)

Fitting Bowden cable on output site



Installing the Bowden cable at the input of the circuit breaker to be interlocked





(1) Steel index clip

Adjusting the Bowden cable



Then:

- According to the planned configuration of the circuit breaker interlocking, screw socket head cap screws with toothed lock
 washers, respectively plastite-screws with lock washers into the associated index clips if applicable →Configurations (page 19-1)
 leager the draw out circuit breaker into the aradia push into disconnected position, along the cubicle doer if required and rack it.
- Insert the draw-out circuit breaker into the cradle, push into disconnected position, close the cubicle door if required and rack it into connected position → (page 6-1)

19.2.4 Function check

- Close the cubicle doors
- Charge closing spring of circuit breakers to be interlocked \rightarrow (page 6-4)
- Test the various possibilities of the planned interlocking configuration one after the other
- Re-adjust Bowden cables if necessary

Then:

- Discharge the closing spring of the circuit breakers to be interlocked \rightarrow (page 23-2)

Note

The following maintenance points must be followed:

- 1 The adjustment of the Bowden cables needs to be checked after the first 100 breaker operations and must be readjusted if necessary.
- 2 The adjustment of the interlocking device needs to be checked and, if necessary, readjusted every 1000 operations or at least once every year.
- 3 During the inspection, the Bowden cables have to be checked against kinks and abrasions, split wires of the exposed steel cable, damage to the cable housing and the adjustment unit (tube setting with thread and nut) and have to be readjusted if necessary. In addition, the movability of movable parts of the interlocking device in their bearings needs to be examined.
- 4 In extreme environmental conditions (e.g. increased environmental temperature or exposure to chemicals) maintenance checks needs to be performed more frequently.
- 5 When maintaining the circuit breaker, check the operation of the interlock device and replace as necessary. See table (page -14).

Catalog Numbers

Mechanical Interlocking	Catlog number
Mechanical interlock assembly	WLNTLK
Qty.(1) Bowden Cable - 2m	WLNTLWIRE2
Qty.(1) Bowden Cable - 4.5m	WLNTLWIRE4

20 Arc chute covers

The arc chute cover is available as an optional accessory for cradles.

The cover is provided to protect the breaker from larger foreign objects (e.g. tools).



20.1 Field installation



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Remove the circuit breaker from the cradle \rightarrow (page 23-3)





Frame size III

For frame size III, installation is essentially the same, but the steps 6 to 9 can be omitted, since the related part is already installed.

20.2 Catalog numbers

	Frame size	Catalog No.
Arc chute cover for cradle (3-pole)	II *)	WLGARC2
	III ^{**)}	WLGARC3
Arc chute cover for cradle (4-pole)	II	WL4GARC2
	Ш	WL4GARC3

*) Not available for FS II fused circuit breakers

**) Not available for FS III M-class

Dimension drawing of door cutout

Front view of the cubicle door



(1) (2) (3)

- Mounting surface of the cradle Center of breaker front panel
- Eight mounting holes for the door sealing frame



	Catalog No.
Door sealing frame	WLDSF

Not for use with fuse carriages.

NOTE

Following a short circuit interruption, check that the Plexiglas breaker cover is firmly in place and the seal is maintained.

Dimension drawing for door cutout and mounting holes



(1) (2) Center of breaker front panel

4 mounting holes for hinges

(3) Mounting surface of circuit breaker or cradle

Attaching the Plexiglas cover



- (1) Cubicle door with door cutout
- Plexiglas cover
- Hinge pin
- (2) (3) (4) 2 hinges with opening function (right and left)
- 8 x Socket head cap screws M5 with washer and lock nuts (5)

Installation of the right side hinge in the same fashion.

Handling:

To open the Plexiglas cover, push the hinge pins on the left or right hinge together or, to remove the Plexiglas cover, unlock both hinges.

Catalog number

	Catalog No.
Plexiglas cover	WLPGC





High speed moving parts.

Can cause serious personal injury.

Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

Qualified Personnel

For the purpose of this instruction manual and these product labels, a "qualified person" is one who is familiar with the installation, construction and operation of the equipment and the hazards involved and who, in addition, has the following qualifications:

- d) Is trained and authorized to energize, de-energize, clear, ground and label circuits and equipment in accordance with established safety practices.
- e) Is trained in the proper care and use of protective equipment in accordance with established safety practices.

f) Is trained in administering first aid.

The WL circuit breaker is designed and constructed to the highest standard of quality, using the best materials available. Design tests and experience have shown that the circuit breakers can withstand and perform greater than the minimum requirements of the associated design and performance standards. Because of the variability possible due to ambient conditions, it is recommended that these circuit breakers be placed on a regular inspection and maintenance cycle.

Contact assemblies need to be changed depending on their condition, but no later than

- 12,500 operations in FS II up to 1600 A; (3- and 4-pole)
- 10,000 operations in FS II 3200 A; (3- and 4-pole)
- 10,000 operations in FS III; (3- and 4-pole)

The switchgear operator must determine the inspection intervals depending on the conditions under which the circuit breaker is used:

- minimum 1 time per year
- after breaking heavy current

After 1000 open/close operations, it is recommended to inspect:

- arc chutes and contact systems
- mechanical functionality
- main and auxiliary circuits, function, condition, and continuity

verify all trip unit settings and adjust, if necessary

23.1 Preparation for maintenance

23.1.1 Opening the circuit breaker and discharging the closing spring



23.1.2 Removing the circuit breaker from the cradle

Crank the circuit breaker into the disconnected position

- Unlock racking handle / withdraw racking handle \rightarrow (page 6-3)



NOTICE

Turning the racking handle beyond the stop will cause damage to the racking mechanism.

When the stop is reached, rotate the handle counter-clockwise until it can be stowed.

Pull circuit breaker into withdrawn position and remove

Racking Handle Damage.





4



 WARNING

 High speed moving parts.

 Can cause serious personal injury.

 Discharge the closing spring before inspection and before carrying out any work on the circuit breaker.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)

23.2.1 Removing front panel



23.2.2 Reinstalling the front panel



23.3 Checking arc chutes

It is recommended that the arc chutes be inspected on a regular basis. The arc splitter plates erode as the result of load breaking. This constitutes normal wear. The erosion of the arc splitter plates can manifest itself as wear of the plates, a layer of soot, or small spots of collections of molten metal. In case of heavy wear (severe erosion, large deposits of molten metal, etc), the circuit breaker should be replaced.

It is also necessary to replace the arc chutes when the circuit breaker's internal contacts are replaced. See Checking contact erosion (page 23-10) for evaluation of contact wear, and Replacing the circuit breaker internal contact assemblies (page 23-21) for internal contact replacement.



- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)

23.3.1 Removing arc chutes

For Frame Size II:





- 1 Loosen screw by approx. 15 mm; do not remove it; FS III and FS II, class C: remove screw completely
- 2 Push the cover back; FS III: lift the cover carefully
- **3** Remove the cover
- 4 Take out the arc chute

Damage to arc chute components.

Mishandling may lead to broken insulation plates of the arc chute housing, and compromised insulation capacity.

Do not stand arc chutes up, when placing them on a table, or any other surface outside of the circuit breaker. The arc chutes should be placed on their side to prevent breakage of the insulation plates.

23.3.2 Visual inspection

In the case of heavy wear (burnout on arc splitter plates), replace the arc chutes.


Frame size II and frame size III



- Insert arc chute, push cover back if necessary
 Slide the cover into place

- 3 Check position of the 2 screens, FS III only
 4 Hook the cover carefully into place and fold it down, FS III only
 5 Insert the screw and tighten to the specified torque

23.3.4 Catalog numbers

Interrupting class	Frame size	Catalog No.
all	II	WLARC2
H, L, F	III	WLARC3
М	111	WLARCM3

The arc chute cover is available as an optional accessory for cradles.



🛕 DANGER

Hazardous voltage.

Will cause death, serious personal injury, or equipment damage.

Turn off and lock out all power supplying this equipment before working on this device.



In addition to the arc chute inspection, an inspection of the arc chute covers is also recommended. The powder-coated inner sides of the covers which face the arc chutes must not be burned.

A layer of soot or small spots of collections of molten metal are normal.

If the powder-coating on the inner side of the cover has burned through or damaged, this must be replaced Arc chute covers (page 20-1) in the opposite order

23.5 Checking contact erosion

It is strongly recommended that the breaker's internal contacts be inspected on a regular basis. Load breaking and short-circuit trips cause contact erosion. The WL circuit breaker is equipped with a contact erosion indicator for monitoring wear of the circuit breaker's internal contacts.

4	DANGER Hazardous voltage.
<u>ک</u>	Will cause death, serious personal injury, or equipment damage. Turn off and lock out all power supplying this equipment before working on this device.

High speed moving parts.

Will cause serious personal injury.

Do not place hands or objects within the arc chamber.

- OPEN circuit breaker the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Move the circuit breaker into the withdrawn position in the cradle \rightarrow (page 23-3)
- Manually charge the closing spring \rightarrow (page 6-4)
- Close the circuit breaker \rightarrow (page 6-7)
- Remove the arc chutes \rightarrow (page 23-6).

View with the circuit breaker closed





- (1) Indicator pin
- (2) Indicator pin is visible in the big recess
- (3) Indicator pin is no longer visible
- (4) Arcing tip
- (5) Arc Chamber

If the indicator pin is no longer visible, the contact system must be replaced.

The contact system must also be replaced if:

- the end of the circuit breaker's mechanical service life according to its technical data has been reached (due to wear on the copper braids).
- heavy wear of the arcing tip is visible (triangular tips have lost approx. 5/16" of their original length)





Preparation for installation

	Fixed-mounted circuit breaker	Draw-out circuit breaker
A OPEN		
B Disconnect auxiliary circuits		Secondary circuit Position indicator
C CLOSE		
D OPEN		
E Indicators	OPEN CONTACTS REAL	DISCHARGED

Current Sensor Calibration

In order to maintain optimal sensing accuracy, replace current sensors with current sensors with identical calibration markings. The calibration mark (A, B, C, or D) is marked on the face of the current sensor. Please consult the factory for ordering information.



Remove Finger Cluster Assemblies (Drawout Only)

23.6.1 Removing vertical adapter





Remove Bus Brace Assemblies

For frame size II only:

Fit support for the lower contacts together with the sensor covers

0524





- (1) Frame size II, 3200 A
- (2) Frame size II, 800 2000 A

Removing current sensors

Lay circuit breaker on its side





- 1 Remove cover of cable duct
- 2 Detach connectors







- 3 4 Remove current sensor covers
- Remove current sensors

Installing current sensors





- Lay circuit breaker on its side, insert connecting wire 1
- 2 Insert current sensors
- 3 Reposition sensor covers
- and attach 4

NOTICE

Damage to circuit breaker housing.

Turning in self-tapping screws not in the existing threads will damage the breaker housing and prevent the sensor cover from beeing secured.

- Tighten the screw as follows: Insert the screw by hand with slight inward pressure
 - Rotate the screw counter-clockwise by hand until the thread fits
 - Tighten
 - Tighten to a torque of 45 lb-in

Reinstall Bus Brace Assemblies

For frame size II only:

Fit support for the lower contacts together with the sensor covers





- (1) Frame size II, 3200 A
- (2) Frame size II, 800 2000 A

Reconnect Current Sensors



6

0526

5 Establish plug connections

Loss of overcurrent protection.

Incomplete connections of the sensor to the sensor wire harness may result in loss of overcurrent protection.

Make sure that the connectors are fully inserted and latched when connecting the sensor cable harness to the sensor.

Reinstall Finger Cluster Assemblies (Drawout Only)





*) For frame size II, 800 - 2000 A only

- A Version A
- B Version B

NOTICE

Damage to finger clusters.

Incorrect adjustment of the vertical connections on the circuit breaker may cause damage to the finger cluster assemblies when the circuit breaker is racked into the cradle.

Adjust the vertical connections according to the dimension drawings on the following pages.

NOTE

To achieve correct finger cluster position in frame size II, center the vertical adapter of the center pole (phase B) on the copper connector of the frame and tighten it. Shift the vertical adapters (7) of the outer poles (phase A & B) outwards until the specified distance of 5 1/4" is reached, and tighten them.







- (1) Spacer
- Hex-head screw
 800 A, 1600 A: M12 x 45,
 2000 A: M12 x 55,
 3200 A: M12 x 80,
 3200 A: 4-pole version, N-pole bottom M12 x 80
- (3) Belleville washer
- (4) Threaded plate
- (5) Washer
- (6) 800 A, 1600 A, 2000 A: M12 nut 3200 A: threaded plate
- (7) Vertical adapter
- (8) Finger cluster
- (9) Carriage bolt M12 with belleville washer and nut *4-pole versions:* 1600, 2000 A N-pole top and bottom: M12 x 60 3200 A, N-pole top: M12 x 75
- A Construction Style A
- B Construction Style B



For the noted finger clusters, the finger cluster guard should be oriented away from the center pole(s) of the circuit breaker. For interior pole (i.e. B-phase, and 4-pole A-phase), the orientation is insignificant.

Functional Test

Test and document the EMC filter installation with the WLTS Hand-held Trip Unit Test Set, in accordance with Slemens instruction "WLTS Hand-Held Test Set Application Guide," (document number CBBR-WLTSA-0716).

23.7 Replacing the circuit breaker internal contact assemblies

If the circuit breaker's internal contacts need to be replaced following an inspection, this can be done using the following procedure.

When replacing the circuit breaker's internal contacts, it is recommended that all three poles be replaced at the same time. It is also required that the arc chutes be replaced when the breaker internal contacts be replaced at the same time. See Checking arc chutes (page 23-5) for replacement arc chutes.





NOTE

Pole assemblies are not field-replaceable for frame size III, M-class circuit breakers.

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)

- Remove the circuit breaker from the cradle \rightarrow (page 23-3)



23.7.2 Removing arc chutes

 \rightarrow (page 23-6)

23.7.3 Removing vertical adapter



Removing lower contact supports in FS II \rightarrow (page 23-30).

23.7.4 Removing pole assemblies

Mounting actuating shaft retainer

NOTICE

Damage to the operator mechanism.

Failure to install the actuating shaft retainer will cause the closing spring to discharge and will result in the operator mechanism being misaligned and damaged.

Follow steps 1 through 5 closely to ensure that the actuating shaft retainer is properly installed.



- 1 Remove hole plug
- 2 Press contacts together and hold them while completing steps 3, 4 and 5



3 4 5 Mount and fix main shaft retainer

Removing racking shaft

Strip off the driving collar of the spring dump mechanism when extracting the racking shaft \rightarrow (page 23-31).



1820

- **1** Remove retaining ring
- 2 Remove crank
- 3 Pull out racking shaft on the other side

Removing current sensors

Lay circuit breaker on its side





- 1 Remove cover of cable duct
- 2 Detach connectors



Size 5 mm



- 3 Remove current sensor covers
- 4 Remove current sensors

Frame size II: unhook the circuit breaker feet



- 1 Place circuit breaker in upright position, remove both circuit breaker feet, remove screw
- 2 Only loosen these screws

NOTE

Before removing the screws, support circuit breaker in such a way that the circuit breaker feet are not supporting the weight of the circuit breaker.





- (1) Leave this area open
- (2) Suitable support circuit breaker here
- (3) Circuit breaker feet
 - 1 Remove screws
 - 2 Remove circuit breaker feet

Removing rear wall



- 3 Remove upper screws
- 4 Remove lower screws
- 5 Support circuit breaker
- 6 Rearwall carefully draw off to view the end position retaining springs
- 7 Note the position of the end position retaining springs
- 8 Separate and remove rearwall
- **9** Remove end position retaining springs

Removing upper fixed contacts

- 1 Remove three bolts and associated nuts
- 2 Remove fixed contact





Size 5 mm





0513

Removing lower moving contacts

Clean and grease bearings and coupling bolts before assembly. (Grease: Isoflex Topas NB 52, Fa. Klüber Lubrication München KG)



- 1 Support connecting bars
- 1 Push out coupling bolt
- 1 Remove coupling bolt
- 1 Remove pole assemblies

23.7.5 Installing pole assemblies

Installing upper fixed contacts in rear wall



- 2 Mount contact and insert square nut in recess3 Fix contacts
 - Fix contacts Re-tighten screws of guide horns with 89 lb-ft; Installing lower moving contacts

Clean and grease bearings and coupling bolts before assembly. (Grease: Isoflex Topas NB 52, Fa. Klüber Lubrication München KG)

Installing lower moving contacts



- 1 Mount supports for connecting bars
- 2 Mount central pole assembly
- 3 Insert coupling bolt
- 4 Mount external pole assemblies



Installing rear wall

(First remove supports for pole assemblies)

Loss of overcurrent protection.

Pinching or crimping of the current sensor cable harness may result in loss of overcurrent protection.

Lay the cable harness carefully and do not pinch or crimp the wires.



- 1 Insert end position retaining springs
- 2 Inspect to ensure that the coupling bolts are centered
- 3 Attach rear wall
- 4 Insert connecting bars through the rear wall



5 Screw tight of the bottom first, starting in the middle; short screws on the bottom, long screws on the top.

Reduction of current carrying capacity.

Incorrect assembly may result in a reduction of contact force, which may reduce the current carrying capabilities of the circuit breaker.

After re-assembling the circuit breaker housing, the contacts should be inspected to make sure that they are aligned and mobile. This is accomplished by closing the circuit breaker, and observing the main contacts from above (looking down through the breaker's arc chambers).

Function test:

It must be possible to press the contacts completely together, and they must return independently to their original position. If this is not the case, loosen the rear wall and check that the end position retaining springs are properly in place.

Attaching the circuit breaker feet



Installing current sensors



- 1 Lay circuit breaker on its side, insert connecting wire
- 2 Insert current sensors
- 3 Reposition sensor covers
- 4 and attach

NOTICE

Damage to circuit breaker housing.

Turning in self-tapping screws not in the existing threads will damage the breaker housing and prevent the sensor cover from beeing secured.

Tighten the screw as follows:

- Insert the screw by hand with slight inward pressure
- Rotate the screw counter-clockwise by hand until the thread fits
- Tighten
- Tighten to a torque of 45 lb-in

For frame size II only: Fit support for the lower contacts together with the sensor covers





Frame size II, 3200 A
 Frame size II, 800 - 2000 A





5 Establish plug connections

Loss of overcurrent protection.

Incomplete connections of the sensor to the sensor wire harness may result in loss of overcurrent protection.

Make sure that the connectors are fully inserted and latched when connecting the sensor cable harness to the sensor.



6 Attach cable chanel cover

Removing the main shaft retainer



- 1 Place circuit breaker in an upright position, press and hold the contacts together, through steps 2 and 3
- 2 Unscrew the main shaft retainer
- **3** Remove the main shaft retainer
- 4 Remove the actuator



5 Attach the cover

Installing the racking shaft

When inserting the racking shaft slide on the driving collar for the spring dump mechanism. Position both flanges of the driving collar in the groove of the circuit breaker housing.





- 1 Insert racking shaft
- 2 Mount crank
- 3 Secure crank

23.7.6 Adjusting the contact wear indicator

- Charge the closing spring manually → (page 6-4)
 Close → (page 6-7))



Indicator pin

(1) (2) Indicator pin before adjustment

(3) Indicator pin adjusted

Using a screwdriver, cut the plastic indicator pin along the upper edge of the large recess.

If the indicator pin is no longer visible, the contact system must be replaced.

23.7.7 Attaching the vertical adapter





*) For frame size II, 800 - 2000 A only

- A Version A
- B Version B

NOTICE

Damage to finger clusters.

Incorrect adjustment of the vertical connections on the circuit breaker may cause damage to the finger cluster assemblies when the circuit breaker is racked into the cradle.

Adjust the vertical connections according to the dimension drawings on the following pages.

NOTE

To achieve correct finger cluster position in frame size II, center the vertical adapter of the center pole (phase B) on the copper connector of the frame and tighten it. Shift the vertical adapters (7) of the outer poles (phase A & B) outwards until the specified distance of 5 1/4" is reached, and tighten them.







- (1) Spacer
- (2) Hex-head screw
 800 A, 1600 A: M12 x 45,
 2000 A: M12 x 55,
 3200 A: M12 x 80,
 3200 A: 4-pole version, N-pole bottom M12 x 80
- (3) Belleville washer
- (4) Threaded plate
- (5) Washer
- (6) 800 A, 1600 A, 2000 A: M12 nut 3200 A: threaded plate
- (7) Vertical adapter
- (8) Finger cluster
- (9) Carriage bolt M12 with belleville washer and nut *4-pole versions:* 1600, 2000 A N-pole top and bottom: M12 x 60 3200 A, N-pole top: M12 x 75
- A Construction Style A
- B Construction Style B

NOTE

To achieve correct finger cluster position in frame size III, center the vertical adapter of all poles on the copper connector of the frame.





- (1) Hex-head screw M12 x 80
- (2) Belleville washer
- (3)
 (4)
 (5)
 (6) Washer
- M12 nut
- Vertical adapter
- Finger cluster



(1) Reinforced bend of the inner finger clusters can be adjusted as desired.

Reinforced bend of the inner finger clusters can be adjusted as desired.



(1) For the noted finger clusters, the finger cluster edge guard should be oriented away from the center pole(s) of the circuit breaker. For interior poles (i.e. B-phase, and 4-pole A-phase), the orientation is insignificant.

Adjustment of reinforced bend of internal fingerclusters open

Breaker internal contact assembly: (one required for each phase)

Frame size	Max. circuit breaker rated current I _{n max} (A)	Suitable for circuit breaker types	Order No.
	800 / 1600 2000	WLN2A308, WLN2A316	RCS2N10
		WLS2A308, WLS2A316	RCS2S10
		WLH2A308, WLF2A308, WLH2A316, WLF2A316, WLF2S308, WLF2S316	RCS2H10
		WLL2A308, WLL2A316, WLL2S308, WLL2S316	RCS2L10
П		WLS2A320	RCS2S15
		WLH2A320, WLF2A320, WLF2S320	RCS2HF15
		WLL2A320, WLL2S320	RCS2L15
	3200	WLS2A332	RCS2S30
		WLH2A332	RCS2H30
		WLL2A332, WLL2S332	RCS2L30
Ш	4000 / 5000	WLH3A340, WLF3A340, WLH3A350, WLF3A350, WLF3S340, WLF3S350, WLF3A332, WLF3S332	RCS3HF30
		WLL3A340, WLL3A350, WLL3S340, WLL3S350	RCS3L30
	M-class: 3200 / 4000 / 5000	WLM3A332, WLM3A340, WLM3A350	RCS3M30
all	all	Grease used for assembly	WLBGREASE



23.7.10 Installing the arc chutes

When the breaker internal contacts are replaced, it is also necessary to replace the arc chutes. See Installing arc chutes (page 23-7).

23.7.11 Mechanical function test

- Charge the closing spring manually \rightarrow (page 6-4)
- Close \rightarrow (page 6-7)
- Open \rightarrow (page 6-7)
- Check again the wear indicator \rightarrow (page 23-10)







- (1) Finger cluster
- (2) Stab tip

23.8.1 Exchanging the finger cluster

- OPEN the circuit breaker and discharge the closing spring \rightarrow (page 23-2)
- Remove the circuit breaker from the cradle \rightarrow (page 23-3)





(1) Self-tapping M4 screw

NOTE

Ensure, that the shoulder bolt has free play in the slotted holes of the brass bracket of the finger cluster.



Lubricating the finger clusters

Clean and grease finger contacts on both ends (between stab tip and finger cluster, and between vertical adapter and finger cluster) before assembly. (Grease: Isoflex Topas NB 52 by Klüber Lubrication)

Attaching vertical adapter with finger cluster \rightarrow (page 23-33)

23.8.2 Catalog numbers

	Frame size	Max. circuit breaker rated current I _{n max} (A)	Catalog No.
Replacement Finger Cluster Kit	11	800 / 1600	WLFNGR10
		2000	WLFNGR15
		3200	WLFNGR30
		4000 / 5000	WLFCK3
Grease used for assemlby	all	all	WLBGREASE



Size

Size

Size 8 mm

- (1) Stab tip
- (2) (3) Socket head cap screw M6
- Hex-head screw M12





FS III only:





(1) 6x Socket head cap screw M10x40 (40Nm /28ft-lb) and belleville washer

- (2) (3) Stab tip bridge
- Vertical bus connector

23.8.4 Catalog numbers

	Frame size	Max. circuit breaker rated current I _{n max} (A)	Catalog No.
		800 / 1600	WLGST10163LL
Stab tip line	П	2000	WLGST15203LL
		3200	WLGST30323LL
Stab tip load	II	800 / 1600 (2 bolt hole pattern)	WLGST10163LL
		800 / 1600 (4 bolt hole pattern)	WLGST10163LD
		2000 (2 bolt hole pattern)	WLGST15203LL
		2000 (4 bolt hole pattern)	WLGST15203LD
		3200	WLGST30323LL
Stab tip load and line	Ш	4000 / 5000	WLGST30503LL
Grease for contact fingers	all	all	WLBGREASE

23.9 Cleaning and greasing the circuit breaker

Finger cluster



(1) Greasing points

- Wipe away old grease and 1
- 2 apply new grease

23.10 Cleaning and greasing the cradle



- (1) Greasing points

 - Clean the track of the rails and
 relubricate the designated points

Grease	Catalog No.
Isoflex Topas NB52 manufactured by Klüber Lubrication München KG	WLBGREASE

\bigwedge	DANGER
$\overline{7}$	Hazardous voltage.
	Will cause death, serious personal injury, or equipment/property damage.
7.10	Turn off and lock out all power supplying this equipment before working on this device.
* 72	Only qualified personnel should work on this equipment, after becoming thoroughly familiar with all warnings, safety notices, and maintenance procedures contained herein and on the devices.
	The successful and safe operation of this equipment is dependent on proper handling, installation, operation and maintenance.

Qualified Personnel

For the purpose of this instruction manual and these product labels, a "qualified person" is one who is familiar with the installation, construction and operation of the equipment and the hazards involved and who, in addition, has the following gualifications:

- a) Is trained and authorized to energize, de-energize, clear, ground and label circuits and equipment in accordance with established safety practices.
- b) Is trained in the proper care and use of protective equipment in accordance with established safety practices.
- c) Is trained in administering first aid.

Observe Circuit Breaker Settings

The WL circuit breaker ships from the factory with the lowest possible settings. For exisiting circuit breaker installations, it is important to notice and take record of all customer settings of the circuit breaker before performing any testing. These settings should be restored at the conclusion of all inspection and testing.

Proper handling of WL Circuit Breakers

It is important to adhere to all rigging and transportation requirements for Siemens type WL circuit breakers (page 4-1).

CAUTION

Fragile Assembly

Finger Clusters may become damaged or disassembled. Connection may overheat and cause property damage.

Do not rest breaker on finger clusters; avoid impact to finger clusters.

Do not insert busbars wider than 0.40 inch [10 mm] into the finger clusters for the following circuit breaker frames:

WLN2A308, WLN2A316, WLS2A308, WLS2A316, WLS2D308, WLS2D312, WLS2D316, WLH2A308, WLH2A316, WLH2S308, WLH2S316, WLH2Z308, WLH2Z316, WLL2A308, WLL2A316, WLL2D308, WLL2D312, WLL2D316

Do not insert busbars wider than 0.59 inch [15 mm] into the finger clusters for the following circuit breaker frames:

WLS1D308, WLS1D312, WLS1D316, WLS1D320, WLL1D308, WLL1D312, WLL1D316, WLL1D320, WLL1Z308, WLL1Z312, WLL1Z316, WLL1Z320, WLN2A320, WLS2A320, WLS2D320, WLH2A320, WLH2A320, WLH2Z320, WLL2A320, WLL2D320, WLF2A308, WLF2A316, WLF2A316, WLF2A320, WLF2S308, WLF2S316, WLF2S320

Do not insert busbars wider than 1.18 inch [30 mm] into the finger clusters for the following circuit breaker frames:

WLN2A332, WLS2A332, WLS2D330, WLH2A332, WLH2S332, WLH2Z325, WLH2Z330, WLL2A332, WLL2D330, WLC2D308, WLC2D312, WLC2D316, WLC2D320, WLC2D325, WLC2D330, WLL3A340, WLL3A350, WLL3S340, WLL3S350, WLL3D340, WLL3D350, WLL3Z340, WLL3Z350, WLF3A332, WLF3A340, WLF3A350, WLF3S332, WLF3S340, WLF3S350, WLF3S350, WLM3A340, WLM3A350, WLC3D340, WLC3D350.

Visually inspect all finger clusters prior to installing drawout circuit breakers.

Do not energize a circuit breaker with a damaged finger cluster assembly.
24.1 General Notes

A few facts about WL trip units and breakers will help the tester understand how best to accomplish the required testing quickly and easily.

Air Core Sensor Technology

WL Breakers are equipped with air-core current sensors (Rogowsky coils, also known as linear couplers) and, as such, the ETUs cannot be tested by conventional secondary injection techniques.

Ground Fault Protection

WL Breaker trip units can be equipped with ground fault protection according to the table below. Ground fault protection cannot be disabled if it has been installed at the factory. Setting the Ground Fault Mode is either done via switch (see below) or via menu (page 9-44).

ЕТИ Туре	Available Ground Fault Modes
ETU 745	Optional: 3 or 4 wire residual, and direct sensing, are both available with additional ground fault protection module. Mode is set by switch.
ETU 755 / 776	Optional: 3 or 4 wire residual, and direct sensing, are both available with additional ground fault protection module. Mode is set by soft setting.

Figure 1



The ground fault pick-up points for the Ground Fault Alarm and Ground Fault Trip settings are independently configurable. The definitions of the A - E dial settings are described below:

Pick-up Setting	Frame Size 1	Frame Size 2	Frame Size 3	
А	100 A	100 A	400 A	
В	300 A	300 A	600 A	
С	600 A	600 A	800 A	
D	900 A	900 A	1000 A	
E	1200 A	1200 A	1200 A	

Ground Fault Mode Selection (Setting)

Before beginning to test, the Ground Fault Mode setting should be verified.

- a. If connected to a 3- or 4-wire residual system, the mode switch must be in the summation position. In this mode, the ETU will perform a vector summation of phases A, B, C and if connected, N (Neutral). If this sum is not zero, a ground fault is present and the ETU behaves according to the pickup and delay settings.
- b. If connected in system where an external iron-core sensor detects the ground current (such as an MDGF scheme), the switch must be in the Direct Sense position (down). If the switch is in this position, the trip unit will not do a residual calculation and will only respond to a signal from an external iron-core sensor.
- c. On an ETU776, these settings are done via the LCD and keypad as there is no physical switch.

Phase Loss Sensing

When single-phase testing, make sure that the short-time delay is not set to the 20ms setting. In this position, a phase-loss sensitivity function is enabled. This function is designed to protect motors from heavy imbalances and loss of one or more phases. When active, and the trip unit detects that the least heavily loaded phase is 50% lower than the most heavily loaded phase, the long-time pickup setting(IR) is reduced to 80% of setting indicated on the display or dial. When this unbalance condition no longer exists, the setting is returned to normal. Single-phase testing will be recognized as a phase unbalance and the long-time pickup will be reduced to 80% of its set value. The resulting trip timing will be faster than indicated in the trip curves. For an ETU776, the phase-loss sensing is controlled by the "PhaseSen" menu item under the protective parameters. When short-time delay is set to 20ms, phase-loss sensing cannot be turned off.

External Ground Fault Sensor Inputs

There are three types of connections for ground fault protection:

- a. If applied in a 4-wire system, there will be an external air-core sensor connected to the second ary wiring points X8.9 & 10.
- b. If applied in a direct sensed scheme, there will be an external iron-core 1200:1 CT connected to secondary wiring points X8.11 & 12.
- c. If applied in a 3-wire system, secondary wiring points X8.9 & 10 must be shorted together.

Activating the WL Trip Unit

The external neutral sensor does not provide power to the trip unit when current is flowing through it. The trip unit must be activated by an auxiliary power source or phase current in order to detect and react to current flowing though the external neutral sensor.

The WL trip units will become active and begin protecting at approximately 80A in a single phase in Frame Size 1 & 2 breakers and approximately 100A in a single phase in a FS3 breaker.

24.2 Primary Injection Phase Current Testing

Circuit Breakers Without Ground Fault Protection

WL Breakers equipped with trip units without ground fault protection can be easily single phase tested by injecting current into either the line or load connection of any phase and out the opposite connection.

Figure 2



Circuit Breakers With 3- or 4-Wire Residual Ground Fault Protection

WL Breakers equipped with trip units with residual ground fault protection must be phase injected such that the ETU sees two active phases which cancel each other out. This cancellation prevents the ground fault function from tripping. This cancellation is accomplished by injecting current into the line side of one phase, out the load side, back into another load side and back out the line side.

Figure 3



If it is not possible to inject phase current into the breaker as shown in the figure above, the Ground Fault Mode switch can be used to tell the ETU to look for a ground fault signal on a different set of terminals. As stated above, putting the Ground Fault Mode switch in the Direct Sense position will cause the ETU to look for ground fault current on terminals X8.11 and X8.12 and not do the residual calculation. This method can only be used if it is possible to remove the front cover of the breaker to access the switch on the side of the ETU. The switch must be returned to its original position after testing is complete. On an ETU776, these settings are done via the LCD and keypad as there is no physical switch.

24.3 Primary Injection Ground Fault Current Testing

Circuit Breakers With 3-Wire Residual Ground Fault Protection

Testing is accomplished by routing current through one phase of the breaker. The Ground Fault Mode switch must be in the up position (summation symbol) in order for the residual ground fault detection to be tested.

Circuit Breakers using 4-Wire Residual Ground Fault Protection via the External Neutral Sensor (air core)

To test a WL breaker equipped with trip 4-wire residual ground fault protection, the ETU must first be activated by injecting 80-100A through the breaker itself (Source A). Once the ETU is active, the test current can be injected through the external neutral sensor to verify its connection and polarity (Source B). The external neutral sensor does not provide energy to the ETU to activate it.

Figure 4



The same test can be conducted using a single power source. The ETU must be activated by injecting a minimum of 100A through the breaker itself. The external neutral sensor does not provide energy to the ETU to activate it. Multiple windings through the external sensor can be added to create greater imbalances.

Figure 5



Also using a single source, the system can be tested to verify that the circuit breaker will not trip.

Figure 6



Circuit Breakers using Direct Sensing Ground Fault Protection via the External GF Sensor (iron core)

The WL trip units can be connected to an external 1200:1 iron core sensor to provide indication of a ground fault. This configuration requires that the Ground Fault Mode switch be in the down (g) position. The ETU is activated by injecting 80-100A through the breaker itself (Source A). Once the ETU is active, the test current can be injected through the external ground fault sensor to verify its connection and polarity (Source B). The external ground fault sensor does not provide energy to the ETU to activate it.

Figure 7



The same test can be conducted using a single power source. The ETU must be activated by injecting a minimum of 100A through the breaker itself. The external neutral sensor does not provide energy to the ETU to activate it. Multiple windings through the external sensor can be added to simulate greater neutral currents.

Figure 8



24.4 Achieving Correct External Neutral Sensor Polarity

(for air-core sensors WLNCT2 and WLNCT3)

The polarity of the neutral sensor must be observed when installing the neutral sensors in the apparatus. The "dot" side of the sensor, identified as P2 in the drawing below, must face in the same direction as the bottom stabs on the breaker. The schematics and elevation drawing identify the P2 side with a "dot" because that is the label side of the sensor, and most installers and service technicians are accustomed to the label side of the sensor being the 'dot' side. There is also a P2 in a circle on the face of the sensor.

For a top-fed breaker (line on top and load on bottom), the P2 must go towards the load (away from the neutral bus).

For a bottom-fed breaker (line on the bottom and load on the top), the P2 must go towards the neutral bus (away from the load).

As long as the X8-9 and X8-10 leads are connected to the correct terminals on the breaker, the polarity relationship between the internal breaker sensors and the external neutral sensor will be correct for the rules given above.

Figure 9



The correct neutral sensor polarization is achieved when the P1 mark on the neutral sensor is oriented on the neutral bus so that it matches the upper stabs of the breaker (normally the line side). Even if the breaker is bottom fed, the load flow must be such that the lower stabs of the breaker and the P2 mark on the neutral sensor are matched (both line or both load).

The wires from the neutral sensor are color coded as follows:

- BLACK => X8.9 = P1
- BLUE => X8.10 = P2

These wires terminate in a plastic 2-pin connector which is usually connected to a black twisted pair. At the far end of the twisted pair, the two wires are labeled. These wires are usually connected to a shielded, twisted pair which brings the signal to the secondary disconnects (X8.9 & X8.10). If incorrect polarity is detected at the ETU in spite of what appears to be a correctly mounted neutral sensor, then the wires crossing between shipping splits should be inspected carefully.

Sample Circuit Breaker Test Record

The following form is an example of a typical report for recording results of a circuit breaker or ground fault system conformance test. This form may be used in abscence of a preferred document (copies may be required, based on the number of circuit breakers.

CIRCUIT BREAKER TEST RECORD							
Date Tested:	Circuit Breaker ID:						
Tested By:							
Results:							

CIRCUIT BREAKER TEST RECORD						
Date Tested:	Circuit Breaker ID:					
Tested By:						
Results:						

25 Disposal

25.1 Low-voltage circuit breakers disposal

Siemens circuit breakers are environmentally friendly products, predominantly consisting of recyclable materials. For disposal, some disassembly, separation, and professional-services handling may be required.

Stored energy.
Can cause death or serious injury.
Mechanisms contain stored energy, which may be released during disassembly.
Wear suitable protection and take appropriate precautions when disconnecting and removing parts.



Materials to be handled include but are not limited to:

- Metals: Should be transferred and recycled as mixed scrap metals.
- Plastics: Plastic containing a recycle symbol should be recycled. Plastic lacking the recycle symbol should be discarded as industrial waste.
- Small electronics, insulated cables, and motors: Should be recycled via electronics scrap disposal companies specialized in separating and sorting as described above.

Disposal regulations vary from locality to locality and may be modified over time. Specific regulations and guidelines should be verified at the time of waste processing to ensure that current requirements are being fulfilled. For specific assistance in understanding and applying regional regulations and policies, or manufacturer's recommendations, refer to the local Siemens service representative for additional information.

26 Technical Data

WL Power Circuit Breaker

Ratings for UL 1066 Listed (ANSI C37) Breakers

WL frame ratings – Frame size 2		800A					1600A				
Rating Class		N	S	н	L	F	N	S	н	L	F
Interrupting current frame Ics (kAIC RMS) 50/60 Hz	254VAC	50	65	85	100	200	50	65	85	100	200
	508VAC	50	65	85	100	200	50	65	85	100	200
	600VAC	—	—	—	—	200	—	—	—	—	200
	635VAC	50	65	65	85	—	50	65	65	85	—
Short-time current /cw (kA RMS)	1 sec.	50	65	65	85	—	50	65	65	85	—
Close and latch rating (kA RMS)		50	65	65	85	—	50	65	65	85	—
Applicable rating plug range		200 - 800A					200 - 1600A				
Mechanical make-time (ms)		35					35				
Mechanical break-time (ms)		34					34				
Electric close make-time (ms)		50					50				
Electric trip/ UV break-time (ms)		40/73					40/73				
Electric trip and reclose interval (ms)		80					80				
Mechanical duty cycles (with maint. ¹)		15,000					15,000				
Electrical duty cycles (with maint.1)		15,000					15,000				
Draw-out breaker efficiency (Watts loss at rated In)		85					320				
Draw-out fused breaker efficiency (Watts loss at rated In)		Consult factory					Consult factory				
Ambient operating temperature (°C)		-25 to 40					-25 to 40				
Weights (Fused Breaker/Breaker/Cradle) lbs.		227/159/112				227/159/112					

WL frame ratings – Frame size 2			2000A				3200A			
Rating Class		S	Н	L	F	S	н	L		
Interrupting current frame Ics	254VAC	65	85	100	200	65	85	100		
(kAIC RMS) 50/60 Hz	508VAC	65	85	100	200	65	85	100		
	600VAC	—	—	—	200	—	—			
	635VAC	65	65	85	—	65	65	85		
Short-time current Icw (kA RMS)	1 sec.	65	65	85	—	65	65	85		
Close and latch rating (kA RMS)		65	65	85	—	65	65	85		
Applicable rating plug range		200 - 2000/	4			200 - 3200A				
Mechanical make-time (ms)		35				35				
Mechanical break-time (ms)		34				34				
Electric close make-time (ms)		50				50				
Electric trip/ UV break-time (ms)		40/73				40/73				
Electric trip and reclose interval (ms)		80				80				
Mechanical duty cycles (with maint.1)		15,000				15,000				
Electrical duty cycles (with maint.1)		15,000				15,000				
Draw-out breaker efficiency (Watts loss at rated In)		700				1650				
Draw-out fused breaker efficiency (Watts loss at rated In)		Consult factory				Consult factory				
Ambient operating temperature (°C)		-25 to 40				-25 to 40				
Weights (Fused Breaker/Breaker/Cradle) lbs.		227/209/152				227/209/152				

 Maintenance means: replacing main contacts and arc chutes (see operating instructions) M-Class main contacts can be replaced by Siemens personnel only.

2) Short-time Withstand Current $\rm I_{CW}$ at 635VAC is 85 kAIC RMS

3) max. 600 V AC

WL Power Circuit Breaker

Ratings for UL 1066 Listed (ANSI C37) Breakers

WL frame ratings – Frame size 3		3200A		4000A				5000A			
Rating Class		М	F	н	L	М	F	н	L	М	F
Interrupting current frame Ics	254VAC	150	200	85	100	150	200	85	100	150	200
(kAIC RMS) 50/60 Hz	508VAC	150	200	85	100	150	200	85	100	150	200
	600VAC	—	200	—		—	200	—	—	—	200
	635VAC	85	—	85	85	85	—	85	85	85	—
Short-time current Icw (kA RMS)	1 sec.	100 ²	_	85	100 ²	100 ²	—	85	100 ²	100 ²	—
Close and latch rating (kA RMS)		100 ²	—	85	100 ²	100 ²	—	85	100 ²	100 ²	_
Applicable rating plug range		800 - 3200A		800 - 4000A			800 - 5000 A				
Mechanical make-time (ms)		35		35			35				
Mechanical break-time (ms)		34		34			24				
Electric close make-time (ms)		50		50			50				
Electric trip/ UV break-time (ms)		40/73		40/73				40/73			
Electric trip and reclose interval (ms)		80		80			80				
Mechanical duty cycles (with maint.1)		10,000		10,000			10,000				
Electrical duty cycles (with maint.1)		10,000		10,000				10,000			
Draw-out breaker efficiency (Watts loss at rat	ed In)	700		1100				1650			
Draw-out fused breaker efficiency (Watts loss at rated In)		Consult factory		Consult factory				Consult Factory			
Ambient operating temperature (°C)		-25 to 40		-25 to 40				-25 to 40			
Weights (Fused Carriage/Breaker/Cradle) lbs.		225/260/306	5	225/260/306				225/260/306			

WL frame ratings	Frame size 2 800 - 2000A		Frame size 3 3200 - 5000A		
Rating Class		F ³	L	F ³	L
Breaking capacity with external relay (kA RMS)	254VAC	20	100	40	100
50/60 Hz, instantaneous trip	508VAC	20	100	40	100
	635VAC	20	85	40	85
Short-time current Icw (kA RMS)	1 sec.	20	65	40	100 2

 Maintenance means: replacing main contacts and arc chutes (see operating instructions) M-Class main contacts can be replaced by Siemens personnel only.

2) Short-time Withstand Current $\rm I_{CW}$ at 635VAC is 85 kAIC RMS

3) max. 600 V AC

WL Circuit Breakers

		Frame Size II			Frame Size III			
Frame Rating		800	1600	2000	3200	3200	4000	5000
Endurance								
Mechanical	operating							
(without maintenance)	cycles	12,500	12,500	10,000	10,000	5,000	5,000	5,000
Mechanical	operating							
(with maintenance) \bigcirc	cycles	15,000	15,000	15,000	15,000	10,000	10,000	10,000
Electrical	operating			·	· ·			
(without maintenance)	cycles	7,500	7,500	4.000	4.000	2.000	2.000	2.000
Electrical	operating	.,	.,	.,	.,	_,	_,	_,
(with maintenance) ^①	cvcles	15 000	15 000	15 000	15 000	10 000	10 000	10 000
Switching frequency	1/h	60	60	60	60	60	60	60
Minimum interval								
between circuit breaker								
trip and next closing of the								
circuit breaker (when								
used with the automatic								
mechanical reset of the								
reclosing lockout	ms	80	80	80	80	80	80	80
	1113	301-301	201320	00	00	00	00	00
			SFA 4		2			
Mounting position		N/A S			8			
Secondary disconnect	SCR0W-		* pr					
wire sizes (Cu)	typo	$1 \times AWG 14$	$1 \times AWG 14$	1 × AWG 14	$1 \times AWG 14$	$1 \times \Delta WG 14$	$1 \times \Delta WG 1/$	$1 \times \Delta WG 1/$
max # of aux	torminal	or		or		or		
connecting leads x cross	terminar							
section (solid or stranded)		2 X AWG 10	2 X AVIG 10	2 X AWG 10	2 X AWG 10	2 X AWG 10	2 X AWG 10	2 X AWG 10
Section (Solid of Stidhaed)	spring							
	ciamp							
	terminal	2 X AWG 14	2 x AWG 14	2 x AWG 14	2 X AWG 14	2 X AWG 14	2 x AWG 14	2 X AWG 14
	Ring	2 X AVVG 14	2 X AVVG 14	2 X AWG 14	2 X AVVG 14	2 X AVVG 14	$2 \times AVVG 14$	2 X AVVG 14
	terminal	T X AVVG TU	T X AVVG TU	T X AVVG TU	TX AVVG 10	T X AWG TU	T X AVVG TU	T X AWG TU
TOC wine composition size	system	2 X AVVG TO	2 X AWG 16	2 X AWG 16	2 X AVVG 16	2 X AWG 16	2 X AWG TO	2 X AVVG 10
	spring							
(Cu) max # or aux.	ciamp							
connecting leads x cross	terminai	1	1 ANAC 1.4	1 ANNO 14	1 AVAIC 1.4	1 ANAC 14	1 AVAIC 1.4	1 ANA/C 1.4
section (solid or stranded)		TX AWG 14	T X AWG 14	T X AWG 14	T X AWG 14	T X AWG 14	T X AWG 14	TX AWG 14
weight ©	1 41	72/450	72/450	75465	05/200	110/200	440/260	110/200
Circuit Breaker	kg/lb	72/159	72/159	/5/165	95/209	118/260	118/260	118/260
	kg/lb	51/112	51/112	60/132	69/152	139/306	139/306	139/306
WOL wire connection	Bare							
size (Cu) max # of aux.	wire							
connecting leads x cross	pressure							
section (solid or stranded)	terminal	1 x AWG 14	1 x AWG 14	1 x AWG 14	1 x AWG 14	1 x AWG 14	1 x AWG 14	1 x AWG 14

 ① Maintenance consists of replacing main contacts and arc chutes (see operating instructions.)

 M-Class main contacts can be replaced by Siemens personnel only.

 ② For use only with ring terminals supplied by Siemens (WL10RL).

 ③ Fused circuit breaker weights
 (kg/lb)

 Frame size II (fused)
 Frame

(kg/lb)	Frame size II (fused)	Frame size III (fused)
cirucuit-breaker	103/227	same as table above
Cradle	68/150	130/275
Fuse carriage	-	102/225

WL Circuit Breaker Accessory Ratings

Manual-operating mechanism with Mecha	anical Closing			
Closing/charging the closing spring				
	Maximum actuating force required on hand lever			52 lbs
	Number of hand lever strokes required			9
Motor-operating mechanism with Mechan	nical and Electrical Closing			
Charging the closing spring				
Closing coil and Shunt Trip	Coil voltage tolerance		24V DC	14 - 28V DC
			48V DC	28 - 56V DC
			120V AC /	70 - 140V DC
			125V DC	104 - 127V AC
			240V AC / 250V DC	140 - 280V DC 208 - 254V AC 180Y / 104V AC 220Y / 127V AC
	Power consumption (5% duty cycle)			120 W for 50 ms
	Minimum closing coil actuation signal required (5% duty cycle)			50 ms
Motor-operating mechanism with Mechanica	al and Electrical Closing			
Motor for charging closing spring				
	Motor voltage tolerance at 120V AC, 240V AC			85 - 110%
	Extended tolerance for battery operation at 24 V DC, 48 V DC, 125 V DC, 250 V DC			70 - 126%
	Power consumption of the motor			110 W
	Time required for charging the closing spring			≤ 10s
For motor and closing coil short-circuit protection				
	Short-circuit protection Standard slow-blow cartridge		24 - 60 V	6A
Associations Data as a			110 - 250 V	3A
		> 050/ (sinesi	lease lease see the set	
Undervoltage release (UVR)	Operating values	≥ 85% (Circuit	breaker can be c	iosea)
		35 - 70% (Circ	cuit breaker opens)
	AC Coll voltage tolerance at 120 V AC, 240 V AC			85 - 110%
	DC Extended tolerance for battery operation at 24 V DC, 48 V DC, 125 V DC, 250 V DC			85 - 126%
	Rated control supply voltage	AC 50/60 Hz	V	120, 240
		DC	V	24, 48, 125, 250
	Power consumption (inrush / contiuous)	AC	VA	200 / 5
		DC	W	200 / 5
	Opening time of the circuit breaker for AC / DC		ms	200
	UVR (no delay time), 2 settings			
	Setting 1		ms	80
	Setting 2		ms	200
	UVR (with delay time)			
	Adjustable delay		S	0.2 to 3.2
	Reset by additional NC direct opening		ms	≤ 100

WL Circuit Breaker Accessory Ratings

Auxiliary Contac	ts and Mechanism Op	erated Contacts (MOC)		
Contact rating	Alternating current 50/60 Hz	Rated operational voltage	240 V	
		Rated operational current, continuous	10A	
		Rated operational current, making	30A	
		Rated operational current, breaking	3A	
	Direct current	Rated operational voltage	24 V, 125 V, 250 V	
		Rated operational current, continuous	5A	
		Rated operational current, making	1.1A at 24 V, 1.1A at 125 V, 0	.55 A at 250 V
		Rated operational current, breaking	1.1A at 24 V, 1.1 A at 125 V, (0.55 A at 250 V
Bell Alarm Switc	h and "Ready-to-close	" Signal Contact		
Contact rating	Alternating current 50/60 Hz	Rated operational voltage	240 V	
		Rated operational current, continuous	5A	
		Rated operational current, making	8A	
		Rated operational current, breaking	5A	
	Direct current	Rated operational voltage	24 V, 48 V, 125 V	250 V DC ¹⁾
		Rated operational current, continuous	0.4 A	0.2 A
		Rated operational current, making	0.4 A	0.2 A
		Rated operational current, breaking	0.4 A	0.2 A
Shunt release, U	VR and tripped signali	ng contacts		
Contact rating	Alternating current 50/60 Hz	Rated operational voltage	127 V, 240 V	
		Rated operational current, continuous	3 A	
		Rated operational current, making	5 A	
		Rated operational current, breaking	3 A	
	Direct current	Rated operational voltage	24 V, 48 V, 125 V, 48 V DC	125 V DC (IEC rating only)
		Rated operational current, making	1.0 A	0.4 A
		Rated operational current, breaking	1.0 A	0.4 A

1) 250 V DC rating available since October 2005.

WL Circuit Breaker Accessory Ratings

Truck Operated Contacts (TOC)					
Contact rating	Alternating current 50/60 Hz	Rated operational voltage	120 V		
		Rated operational current, continuous	10 A		
		Rated operational current, making	6 A		
		Rated operational current, breaking	6 A		
	Direct current	Rated operational voltage	24 V	24 V, 48 V, 125 V	250 V
		Rated operational current, continuous	6 A	1 A	1 A
		Rated operational current, making	6 A	0.22 A	0.11 A
		Rated operational current, breaking	6 A	0.22 A	0.11 A

WL Circuit Breaker

Function overview of the electronic trip units

Basic Functions			ETU745	ETU776
		Long-time overcurrent protection	V	V
		Function can be switched ON/OFF	-	-
		Setting range $I_{R} = I_{n} \times$	0.4, 0.45, 0.5, 0.55, 0.6, 0.65, 0.7, 0.8, 0.9, 1	40-100% of In (Adjustable in Amps ^①)
′n ↔	L	Switch-selectable overload protection $(I^2 t \text{ or } I^4 t \text{ dependent function})$	V	V
\ \↑		Setting range of delay time class $t_{\rm R}$ at ${\it I}^2 {\rm t}$ (seconds)	2, 3.5, 5.5, 8, 10, 14, 17, 21, 25, 30	2 30 (step: 0.1s)
		Setting range of delay time t _R at I ⁴ t (seconds)	1, 2, 3, 4, 5	1 5 (step: 0.1s)
· · · · · · · · · · · · · · · · · · ·		Thermal memor	✔ (via slide switch)	 (on/off via key pad or communications)
\downarrow \backslash		Phase loss sensitivity	at t _{sd} =20ms (M)	✔ (on/off via key pad or communications)
		N-conductor protection	V	V
	Ν	Function can be switched ON/OFF	✓ (via slide switch)	✓ (via key pad or communications)
		N-conductor setting range $l_N = l_n x$	0.5 1	0.5 2, OFF
		Short-time delayed overcurrent protection	V	V
		Function can be switched ON/OFF	✓ (via rotary switch)	(via key pad or communications)
		Setting range I _{sd} = I _n x	1.25, 1.5, 2, 2.5,	$1.25 0.8 \text{ x l}_{mu} = \text{max}$
			3, 4, 6, 8, 10, 12	(step: 10A)
	S	Setting range of delay time <i>t_{sd},</i> fixed (seconds)	0.02 (M), 0.1, 0.2, 0.3, 0.4, OFF	M, 0.080.4, OFF (step: 0.001s)
		Switch-selectable short-time delayed short-circuit protection (/ ² t dependent function)	✓ (via rotary coding switch)	✓ (via key pad or communications)
* + *		Setting range of delay time t_{sd} at $l^2 t$ (seconds)	0.1, 0.2, 0.3, 0.4	0.1 0.4 (step: 0.001s)
I ↑		Zone Selective Interlocking (ZSI) function	per CubicleBUS module	per CubicleBUS module
		Instantaneous overcurrent protection	v	V
	1	Function can be switched ON/OFF, Extended Instantaneous Protection is enabled when OFF	✔ (via rotary coding switch)	$m{\prime}$ (via key pad or communications)
		Setting range $I_i = I_n \times$	1.5, 2.2, 3, 4, 6, 8, 10, 12 0.8 x / _{cw} = max, OFF=/ _{cw} =EIP ^②	$1.5 \times l_{\rm n} \dots 0.8 \times l_{\rm cs} = {\rm max}, {\rm OFF} = l_{\rm CW} = {\rm EIP}$
•	•	Ground fault protection ③	o (field installable module)	o (field installable module)
		Trip and alarm function	V	✓ (via key pad or communications)
		by residual summing method	v	V
		Detection of the ground fault current by direct summing method	V	V
	G	Setting range of the I _a for trip	A, B, C, D, E (100 1200A)	A E (step: 1A)
	G	Setting range of the $I_{\mathbf{q}}^{\vec{r}}$ for alarm	A, B, C, D, E (100 1200A)	A E (step: 1A)
		Setting range of the delay time t _g (seconds)	0.1, 0.2, 0.3, 0.4, 0.5	0.1 2.0 (step: 0.001s)
[₽Ţ		Switch-selectable ground fault protection (l^2t) fixed)	V	v
		Setting range delay time t_{a} at $l^{2}t$	0.1, 0.2, 0.3, 0.4, 0.5	0.1 2.0 (step: 0.001s)
		ZSI ground function	per CubicleBUS module	per CubicleBUS module

① Note: ETU776 settings via communications: 10A steps for Instantaneous and Short Time pickup, all others 1A steps. Via ETU Keypad: Below 1000A: 10A steps 1000A-1600A: 50A steps

Wa ETO Keybad. Below Todoka. Todo Steps
 1600A-10000A: 100A Steps
 2 Extended Instantaneous Protection (EIP) allows the WL circuit breaker to be applied at the withstand rating of the circuit breaker with minus 0% tolerance; this means there is no instantaneous override at all. EIP further enables the circuit breaker to be applied up to the full instantaneous rating of the circuit breaker in systems where the available fault current exceeds the withstand rating.

✓ available

_ not available

o optional

Notes: M = Motor protection setting indicates phase loss sensitivity is enabled. LT pick-up reduced 80% when phase unbalance > 50%. ST = 20 ms Communications = Setting the parameters of the trip unit via the Breaker Data Adapter, MODBUS, or PROFIBUS Key pad = Direct input on the trip unit

WL Circuit Breaker

Function overview of the electronic trip units

Basic Functions		ETU745	ETU776
Parameter sets			
	Selectable between		
	parameter set A and B	_	V
LCD			
	LCD, alphanumeric (4-line)	0	-
	LCD, graphic	_	V
Communication	. 5 1		
	CubicleBUS integrated	V	V
	Communication capability via MODBUS or PROFIBUS	v	J
Metering function		•	•
Metering function	Metering function canability with		
	Metering Function or		
	Metering Function PLUS		
Display by LED	Metering Function (200	•	•
	Trip unit active	4	<i>J</i>
	Alarm		
	ETH orror		
N /2			
	L trip		
\rightarrow	5 trip		
	l trip		
	N trip	Contracting the second factor of the later.	
	G thp	(only with ground fault module)	(only with ground fault module)
	G alarm	(only with ground fault module)	 (only with ground fault module)
	protective relay function	V	V
	Communication	V	V
Signal contacts with	external CubicleBUS modules		
(opto or relay)			
	Overcurrent warning	V	V
	Load shedding OFF ON	V	v
	Early signal of long- time trip (200ms)	V	V
	Temperature alarm	V	V
	Phase unbalance	V	V
	Instantaneous trip	V	V
1 $($	Short-time trip	V	V
	Long-time trip	V	V
	Neutral conductor trip	v	 ✓
	Ground fault protection trip	✓ (only with ground fault module)	 (only with ground fault module)
1 1	Ground fault alarm	✓ (only with ground fault module)	 (only with ground fault module)
	Auxiliary relay	V	V
	ETU error	V	V

✔ available

not available

o optional

27 Abbreviations

Α	Set current for ground fault protection
A _{1/2}	Output signal 1/2 (mechanical interlocking module)
AC	Alternating current
AMP	AMP Incorporated, Harrisburg
ANSI	American National Standard Institute
AWG	American Wire Gauge
В	Set current for ground-fault protection
BSS	Breaker Status Sensor
С	Set current for ground-fault protection
СС	Closing coil
COM15	Communication interface
СОММ.	Communication
CONNECT	Connected position
CUB -	CubicleBUS -
CUB +	CubicleBUS +
D	Set current for ground-fault protection
DC	Direct current
DIN	German Engineering Standard
DISCON	Disconnected position
E	Set current for ground-fault protection
E _{1/2}	Input signal 1/2 (mechanical interlocking)
ED	Duty cycle
ESD	Electrostatic-sensitive device
EN	European Standard
ETU	Trip unit (electronic trip unit)
EXTEND.	Extended (additional) protection function
F1	1st shunt trip
F2	2nd shunt trip
F3	Undervoltage release
F4	Undervoltage release with delay time
F5	Tripping coil
F7	Remote reset coil
G-alarm	Ground-fault alarm
G-tripping	Ground-fault tripping
1/0	Input / Output module
l ² t	Delay time-current relationship based on formula $I^2t\text{=}constant$
l ² t _g	Delay time for ground-fault based on formula ${\rm I}^2 {\rm t}_g = {\rm constant}$
l ² t _{sd}	Delay time for S tripping based on formula I^2t_{sd} = constant
l ⁴ t	Delay time-current relationship based on formula I^4t = constant

I-tripping	Instantaneous tripping (short-circuit)
l _{ab}	Operating value for load shedding
l _{an}	Operating value for load restore
I _{cs}	Rated operational short-circuit breaking capacity
I _{cu}	Rated ultimate short-circuit breaking capacity
I _{cw}	Rated short-time withstand current
ID	Identification number
IEC	International Electrotechnical Commission
lg	Current setting value for G-tripping
l _i	Current setting value for I-tripping
I _{IT}	Single-pole short-circuit test current (IT systems)
I _N	Current setting value for N-tripping
I _n	Rated current (value of Rating Plug)
I _{n max}	Max. possible rated current
I _R	Current setting value for L-tripping
I _{sd}	Current setting value for S-tripping
L1	Phase 1
L2	Phase 2
L3	Phase 3
L-tripping	Long-time delayed tripping (overload)
LED	Light emitting diode
Μ	Motor
MOC	Mechanism Operated Auxiliary Conntacts
Ν	Neutral pole
NC	Normally closed contact
NO	Normally open contact
N-tripping	Neutral (overload) tripping
PIDG	Ring lug style (Trademark of AMP)
PZ 36	Crimping tool (Weidmüller GmbH)
S _{1/2/3}	Circuit breaker $_{\rm 1/2/3} (mechanical interlocking module)$
S1	Contact position-driven auxiliary switch
S10	Switch Electrical Closed
S11	Motor cut-off switch
S12	
	Motor disconnect switch
S13	Motor disconnect switch Cut-off switch for remote reset
S13 S14	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation)
S13 S14 S15	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation) Cut-off switch for closing coil CC (fast operation)
S13 S14 S15 S2	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation) Cut-off switch for closing coil CC (fast operation) Contact position-driven auxiliary switch
S13 S14 S15 S2 S20	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation) Cut-off switch for closing coil CC (fast operation) Contact position-driven auxiliary switch Signaling switch for "ready-to-close"
S13 S14 S15 S2 S20 S21	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation) Cut-off switch for closing coil CC (fast operation) Contact position-driven auxiliary switch Signaling switch for "ready-to-close" Signaling switch for "closing spring charged"
 S13 S14 S15 S2 S20 S21 S22 	Motor disconnect switch Cut-off switch for remote reset Cut-off switch for shunt trip F1 (fast operation) Cut-off switch for closing coil CC (fast operation) Contact position-driven auxiliary switch Signaling switch for "ready-to-close" Signaling switch for "closing spring charged" Signaling switch for 1st shunt trip

S24	Bell Alarm signaling switch
S3	Contact position-driven auxiliary switch
S30	Signaling switch for disconnected position (TOC)
S31	Signaling switch for test position (TOC)
S32	Signaling switch for test position (TOC)
S33	Signaling switch for connected position (TOC)
S34	Signaling switch for connected position (TOC)
S35	Signaling switch for connected position (TOC)
S4	Contact position-driven auxiliary switch
S40	CubicleBUS signaling switch for "ready-to-close"
S41	CubicleBUS signaling switch for "closing spring charged"
S43	CubicleBUS signaling switch for 2nd shunt trip
S44	$\label{eq:cubicleBUS} \textbf{CubicleBUS} \ \text{signaling switch for "main contacts OPEN / CLOSED"}$
S45	CubicleBUS tripped signaling switch
S46	CubicleBUS signaling switch for connected position
S47	CubicleBUS signaling switch for test position
S48	CubicleBUS signaling switch for disconnected position
S50 S53	MOC (external auxiliary switches)
S7	Contact position-driven auxiliary switch
S8	Contact position-driven auxiliary switch
S-tripping	Short-time delayed tripping
SIGUT	Siemens trademark for aux. termination technique
ST	Shunt trip
T.U. ERROR	Trip unit error
TEST	Test position
t _g	Delay time for G-tripping
тос	Truck operated cell switch (S30 S35)
t _R	Delay time for L-tripping (defined at $6 \times I_R$)
TRIP G	Trip cause was ground fault
TRIP I	Trip cause was short-circuit (instantaneous)
TRIP L	Trip cause was overload
TRIP N	Trip cause was neutral pole overload
TRIP S	Trip cause was short-circuit (short-time delayed)
t _{sd}	Delay time for S-tripping
t _x	Delay time for load monitoring
U _c	Rated control voltage
U _e	Rated operational voltage
Ui	Rated insulation voltage
U _{Imp}	Rated impulse withstand voltage
UVR	
	Undervoltage release (instantaneous)
UVR td	Undervoltage release (instantaneous) Undervoltage release (delayed)

WAGO	WAGO Kontakttechnik, München
x	Terminal designation according to DIN
ZSI	Zone Selective Interlocking
l _{avg}	Present average of current
l _{avglt}	Long term average of current
I _{THD}	Distortion factor of current
U _{THD}	Distortion factor of voltage

28 Glossary

Automatic reset

Circuit breakers feature an automatic reset of the tripping coil. No manual resetting of the Trip Unit is required to place the circuit breaker in a "Ready-to-close" state. UL 1066 circuit breakers are factory-fitted with this automatic reset feature as standard. The automatic reset feature can be removed as a customer option.

Auxiliary releases

Both undervoltage releases and shunt trips are available.

BSS module

Breaker Status Sensor - for collecting circuit breaker status information via signaling switches and transmitting these data to the **Cubicle**BUS.

Closing coil

A coil used for electrically closing the circuit breaker.

Closing spring

Module containing a spring as an energy store. The spring is charged by means of a hand-operated lever or a motor, and is latched in its charged state. When the latches are released, the stored energy is transmitted to the pole and the circuit breaker closes.

Coding of auxiliary connectors

The auxiliary connectors are coded to prevent accidental interchanging of the auxiliary wiring connections.

COM modules

Communication modules with access to the circuit breaker:

- Reading and writing parameters
- Reading circuit breaker states/measured values
- Closing and opening the circuit breaker via fieldbus
- Additional functions via floating outputs or inputs
- Implementing breaker-internal CubicleBUS information

Additional functions when a draw-out breaker is used:

- Sensing position of circuit breaker in guide frame

COM15 module

COM15 communication module with access to the circuit breaker via the PROFIBUS DP fieldbus interface.

COM16 module

COM16 communication module with access to the circuit breaker via the Modbus RTU fieldbus interface.

COM35 module

COM35 communication module with access to the circuit breaker via the two fieldbus interfaces PROFINET IO and Modbus TCP.

Additional functions:

- Ethernet switch functionality
- Both protocols are available simultaneously on both ports
- Dynamic Arc Sentry (DAS)
- Firmware update

CubicleBUS

Bus system in the vicinity of the circuit breaker and to the FieldBus (PROFIBUS DP, PROFINET IO, Modbus RTU and Modbus TCP.)

Electrical closing lockout

For electrical interlocking of two or more circuit breakers (closing interlock). The electrical closing lockout can block the circuit breaker from closing via a sustained signal.

Electrical Closed

Electrical activation of the stored energy through the closing coil.

Energy transformer

Power supply for the trip unit.

Guide rail

Used for placing the circuit breaker in the cradle.

Finger clusters

Connect the main terminals of the circuit breaker with the main terminals of the cradle.

Mechanical reclosing lockout and Bell Alarm

After tripping, the circuit breaker cannot be reclosed until the mechanical reclosing lockout has been reset by hand.

Mechanism Operated Auxiliary Contacts (MOC)

A switching module for signaling the circuit breakers switch position, which is mounted in the cradle and activated by the actuating shaft of the circuit breaker.

Motor-operated mechanism

The geared motor charges the closing spring automatically as soon as voltage is applied to the auxiliary connections. After closing, the closing spring is automatically charged for the next closing operation.

Position indicator

To show the circuit breaker position in the cradle.

Powerconfig

Software for commissioning and service, free of charge available at:<u>www.siemens.com/powerconfig-download</u> *powerconfig* (from Version 2.2) is used as a shared commissioning and maintenance tool for the circuit breakers with communication capability. It offers a standardized interface and a uniform operator control concept for the activities to be carried out, such as

- Parameterizing
- Operating
- Monitoring, and
- Diagnosing.

powerconfig currently supports German and English. "SENTRON communication handbook"
— http://support.automation.siemens.com

Rated current coding

The rated current is coded at the factory, i.e. each and every circuit breaker can only be inserted into a cradle if they have the same rated current.

Rating Plug

This module defines e.g. the setting range of the overload protection.

Remote reset

The electrical signal of the tripped signaling switch and the red reset button are reset by the optional remote reset coil.

Lock OPEN

This additional function prevents closing the circuit breaker and fulfils the disconnecting condition in OFF position as per IEC 60947-2:

- "Mechanical Off" button pressed
- main contacts OPEN
- crank handle of draw-out circuit breakers removed
- the various interlocking conditions are fulfilled.

Shunt trip

For remote circuit breaker tripping and locking against closing.

Shutter

Shutters are insulation plates for covering live main circuits in the cradle (shock protection).

Signaling switch for circuit breaker position (TOC)

These auxiliary switches operate according to the circuit breaker position in the cradle (-> Truck-operated contact).

Spring charging lever

The closing spring is charged by several pumping operations.

Tool operation

A cover with a hole (Ø 0,25") means that buttons can only be pressed using a rod.

TOC - Truck operated Cell Switch

For remote signaling of the circuit breaker position in the cradle.

Truck-operated contact (TOC)

A circuit breaker truck-operated auxiliary switch which is mounted in the compartment of a removable circuit breaker and is operated by the circuit breaker frame (-> Signaling switch for breaker position).

Undervoltage release

For remote tripping and interlocking of the circuit breaker. Circuit breaker application in EMERGENCY OPEN circuits together with an EMERGENCY OPEN facility to be arranged separately. The circuit breaker shall not be tripped by short-time voltage drops (e.g. motor start-up).

Undervoltage release (time delayed)

For remote tripping and interlocking of the circuit breaker. The circuit breaker shall not be tripped by voltage drops (e.g. system transfers).

29	Index
A Abbrevi Access Arc chu Auxiliar	ations
B Basic p Breaker	rotective functions
C Closing Closing Coding COM m COM16 Connec Contact Crank t Cubicle	diagrams .8-1
D Dimens Disconr Door se	ion drawings
E Electror EMERC	nic components9-1 GENCY OPEN button14-3
F Frame s	sizes
Glossar Ground	ry
I Indicato Insertin Insertin Installat Interloc	ors and operating elements
L Labels Lock Ol Locking Locking	

Μ

141		
Maintenance	 	 23-1
Maintenance position	 	 6-2
Make-break operations counter	 	 14-4
Manual reset	 	 10-2
Mechanism-operated contacts .	 	 12-7
MOC	 	 12-7
Motor disconnect switch	 	 13-3
Motor-operated mechanism	 	 13-1
Mounting position	 	 5-2
Mutual mechanical interlocking	 	 19-1

0

Opening the circuit breaker
P Decking 4.1
Padiocking facilities
Positions of the circuit breaker in the guide frame
Powerconfig
Q
Qualified Personnel
D
Packing circuit brocker into connected position 6.2
Pating circuit breaker into connected position
Reclearing a given it breaker tripped by an trip unit
Re-closing a circuit breaker tripped by an trip unit
Removing from service
Removing the circuit breaker from the guide frame
Replacing pole assembly
Replacing the internal current sensors
Replacing the trip unit9-49
Resetting the Bell Alarm10-1
Ring terminal system5-13
S
Safety locks 15-1
Sarewloss terminal evetem 5.12
Secondary disconnect terminal blocks
Shunt Irip
Shutter
Standard specifications
Storage spring
т
Test position
Transport 4-1
Trin unit FTI 1745 9-2
Trip unit ETU776 9-7
Troubleshooting 6-10
Troubleshooting
U
Undervoltage release11-1, 11-3
W
Wiring in guido fromo
Z
7SI module 9-87



Siemens Industry, Inc. Norcross, GA 30092

Technical assistance: 1-800-241-3138 www.usa.siemens.com/powerdistribution