

SINUMERIK

SINUMERIK 840D sl Monitoring and compensating

Function Manual

Valid for

control system
SINUMERIK 840D sl / 840DE sl

CNC software Version 4.94

10/2020
6FC5397-7GP40-0BA1

Preface

Introduction

1

Fundamental safety instructions

2

Geometric machine modeling

3

Collision avoidance, internal

4

Collision avoidance, external

5

Protection areas

6

Axis monitoring functions

7

Contour tunnel monitoring

8

Compensations

9

Appendix

A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.
--

WARNING
--

indicates that death or severe personal injury may result if proper precautions are not taken.

CAUTION
--

indicates that minor personal injury can result if proper precautions are not taken.
--

NOTICE

indicates that property damage can result if proper precautions are not taken.
--

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

WARNING
--

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.
--

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

SINUMERIK documentation

The SINUMERIK documentation is organized into the following categories:

- General documentation/catalogs
- User documentation
- Manufacturer/service documentation

Additional information

You can find information on the following topics at the following address (<https://support.industry.siemens.com/cs/de/en/view/108464614>):

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

If you have any questions regarding the technical documentation (e.g. suggestions, corrections), please send an e-mail to the following address (<mailto:docu.motioncontrol@siemens.com>).

mySupport/Documentation

At the following address (<https://support.industry.siemens.com/My/ww/en/documentation>), you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation.

Training

At the following address (<http://www.siemens.com/sitrain>), you can find information about SITRAIN (Siemens training on products, systems and solutions for automation and drives).

FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support (<https://support.industry.siemens.com/cs/de/en/ps/faq>).

SINUMERIK

You can find information about SINUMERIK at the following address (<http://www.siemens.com/sinumerik>).

Target group

This publication is intended for:

- Project engineers
- Technologists (from machine manufacturers)
- System startup engineers (Systems/Machines)
- Programmers

Benefits

The function manual describes the functions so that the target group knows them and can select them. It provides the target group with the information required to implement the functions.

Standard version

This documentation only describes the functionality of the standard version. Extensions or changes made by the machine tool manufacturer are documented by the machine tool manufacturer.

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

Further, for the sake of simplicity, this documentation does not contain all detailed information about all types of the product and cannot cover every conceivable case of installation, operation or maintenance.

Note regarding the General Data Protection Regulation

Siemens observes standard data protection principles, in particular the principle of privacy by design. That means that

this product does not process / store any personal data, only technical functional data (e.g. time stamps). If a user links this data with other data (e.g. a shift schedule) or stores personal data on the same storage medium (e.g. hard drive) and thus establishes a link to a person or persons, then the user is responsible for ensuring compliance with the relevant data protection regulations.

Technical Support

Country-specific telephone numbers for technical support are provided on the Internet at the following address (<https://support.industry.siemens.com/cs/ww/en/sc/2090>) in the "Contact" area.

If you have any technical questions, use the online form in the "Support Request" area.

Table of contents

	Preface	3
1	Introduction	13
1.1	About this documentation	13
2	Fundamental safety instructions	15
2.1	General safety instructions	15
2.2	Warranty and liability for application examples	15
2.3	Security information	15
3	Geometric machine modeling	17
3.1	Function description	17
3.1.1	Features	17
3.1.2	Automatic tool protection areas	20
3.2	Commissioning	23
3.2.1	General	23
3.2.1.1	Overview	23
3.2.1.2	Structure of the system variables	23
3.2.1.3	Color chart	24
3.2.2	Machine data	25
3.2.2.1	Maximum number of protection areas	25
3.2.2.2	Maximum number of protection area elements for machine protection areas	26
3.2.2.3	Maximum number of protection area elements for automatic tool protection areas	26
3.2.2.4	Maximum number of NC/PLC interface signals for the preactivation of protection areas	26
3.2.2.5	Maximum number of triangles for machine protection areas	26
3.2.2.6	Maximum number of triangles for automatic tool protection areas	26
3.2.2.7	Creation mode for automatic tool protection areas	27
3.2.3	System variables: Protection areas	27
3.2.3.1	Overview	27
3.2.3.2	\$NP_PROT_NAME	28
3.2.3.3	\$NP_CHAIN_ELEM	29
3.2.3.4	\$NP_PROT_TYPE	30
3.2.3.5	\$NP_1ST_PROT	31
3.2.3.6	\$NP_PROT_COLOR	32
3.2.3.7	\$NP_PROT_D_LEVEL	33
3.2.3.8	\$NP_BIT_NO	34
3.2.3.9	\$NP_INIT_STAT	36
3.2.3.10	\$NP_INDEX	37
3.2.4	System variables: Protection area elements for machine protection areas	39
3.2.4.1	Overview	39
3.2.4.2	\$NP_NAME	40
3.2.4.3	\$NP_NEXT	41
3.2.4.4	\$NP_NEXTP	42
3.2.4.5	\$NP_COLOR	43
3.2.4.6	\$NP_D_LEVEL	44

3.2.4.7	\$NP_USAGE	45
3.2.4.8	\$NP_TYPE	46
3.2.4.9	\$NP_FILENAME	51
3.2.4.10	\$NP_PARA	56
3.2.4.11	\$NP_OFF	57
3.2.4.12	\$NP_DIR	58
3.2.4.13	\$NP_ANG	60
3.2.5	System variables: Protection area elements for automatic tool protection areas	61
3.2.6	Boundary conditions	62
3.3	Data lists	63
3.3.1	Machine data	63
3.3.1.1	NC-specific machine data	63
3.3.2	System variables	63
4	Collision avoidance, internal	65
4.1	Function description	65
4.1.1	Options	65
4.1.2	Characteristics	65
4.1.3	Reaction of the control to a risk of collision	67
4.1.4	State diagram: Protection area	70
4.1.5	Tools	71
4.1.6	Boundary conditions	73
4.2	Commissioning	75
4.2.1	General	75
4.2.1.1	Overview	75
4.2.1.2	Structure of the system variables	75
4.2.2	Machine data	77
4.2.2.1	Collision tolerance	77
4.2.2.2	Safety clearance	77
4.2.2.3	Maximum memory space	78
4.2.2.4	Maximum number of collision pairs	78
4.2.2.5	Protection levels for collision avoidance On/Off	79
4.2.3	System variables	79
4.2.3.1	Overview	79
4.2.3.2	\$NP_COLL_PAIR	80
4.2.3.3	\$NP_SAFETY_DIST	81
4.2.4	Extend system variables	82
4.2.4.1	Overview	82
4.2.4.2	State data	83
4.2.4.3	Memory requirement	83
4.2.4.4	Braking distance estimations	84
4.3	Programming	85
4.3.1	Check for collision pair (COLLPAIR)	85
4.3.2	Request recalculation of the machine model of the collision avoidance (PROTA)	86
4.3.3	Setting the protection zone status (PROTS)	87
4.3.4	Determining the clearance of two protection zones (PROTD)	88
4.4	Example	90
4.4.1	Specifications	90
4.4.2	Part program of the machine model	96
4.5	Data lists	104

4.5.1	Machine data	104
4.5.1.1	NC-specific machine data	104
4.5.2	System variables	104
5	Collision avoidance, external.....	107
5.1	Function description	107
5.1.1	Options	107
5.1.2	Characteristics	107
5.2	Commissioning	107
5.2.1	Machine data	107
5.2.1.1	Functions of external collision avoidance.....	107
5.2.1.2	Preview time	108
5.2.1.3	Preview time step.....	108
5.2.1.4	Timeout time	108
6	Protection areas	109
6.1	Function	109
6.2	Commissioning	116
6.2.1	Machine data	116
6.3	Programming	117
6.3.1	Defining protection zones (CPROTDEF, NPROTDEF).....	117
6.3.2	Activating/deactivating protection zones (CPROT, NPROT)	120
6.3.3	Checking for protection zone violation, working area limitation and software limit switches (CALCPOSI)	123
6.4	Special situations	132
6.4.1	Temporary enabling of protection zones.....	132
6.4.2	Behavior in the AUTOMATIC and MDA modes.....	133
6.4.3	Behavior in JOG mode	134
6.5	Boundary conditions	137
6.6	Example	138
6.6.1	Protection zone on a lathe.....	138
6.6.2	Protection zone definition in the part program.....	139
6.6.3	Protection zone definition with system variables	139
6.6.4	Activating protection zones	147
6.7	Data lists.....	147
6.7.1	Machine data	147
6.7.1.1	NC-specific machine data	147
6.7.1.2	Channelspecific machine data	147
7	Axis monitoring functions	149
7.1	Contour monitoring	149
7.1.1	Contour error	149
7.1.2	Following-error monitoring	150
7.2	Positioning, zero speed and clamping monitoring	152
7.2.1	Correlation between positioning, zero-speed and clamping monitoring	152
7.2.2	Positioning monitoring.....	152
7.2.3	Zero-speed monitoring.....	154
7.2.4	Parameter set-dependent exact stop and standstill tolerance	154

7.2.5	Clamping monitoring	155
7.2.5.1	Function	155
7.2.5.2	Machine data	155
7.2.5.3	NC/PLC interface signals	156
7.2.5.4	Fault responses	156
7.2.5.5	"Automatic stop to release the clamping" clamping function	157
7.2.5.6	"Time-optimized release of the clamping" clamping function	158
7.2.5.7	"Automatic stop to set the clamping" clamping function	159
7.2.5.8	Supplementary conditions	161
7.3	Speed-setpoint monitoring	163
7.4	Actual-velocity monitoring	165
7.5	Measuring system monitoring	165
7.5.1	Encoder-limit-frequency monitoring	167
7.5.2	Plausibility check for absolute encoders	168
7.5.3	Customized error reactions	170
7.6	Limit switch monitoring	173
7.6.1	Hardware limit switch	173
7.6.2	Software limit switch	174
7.7	Working area limitation monitoring	176
7.7.1	General	176
7.7.2	Working area limitation in BCS	178
7.7.3	Working area limitation in WCS/SZS	180
7.7.4	Example: Working area limitation in WCS/SZS	183
7.8	Parking a machine axis	186
7.9	Parking the passive position measuring system	188
7.9.1	Function	188
7.9.2	Supplementary conditions	191
7.9.3	Example: Changing an attachment head for a direct position measuring system	192
7.9.4	Example: Changing an attachment head for two direct position measuring systems	197
7.9.5	Example: Measuring system switchover when encoders are missing in certain parts of the range	201
7.10	Switching over encoder data sets	204
7.11	Data lists	206
7.11.1	Machine data	206
7.11.1.1	NC-specific machine data	206
7.11.1.2	Channelspecific machine data	207
7.11.1.3	Axis/spindlespecific machine data	207
7.11.2	Setting data	209
7.11.2.1	Axis/spindlespecific setting data	209
8	Contour tunnel monitoring	211
8.1	Brief description	211
8.1.1	Contour tunnel monitoring	211
8.1.2	Programmable contour accuracy	212
8.2	Contour tunnel monitoring	213
8.3	Programmable contour accuracy	214

8.4	Constraints	217
8.5	Data lists.....	218
8.5.1	Machine data.....	218
8.5.1.1	Channelspecific machine data	218
8.5.1.2	Axis/spindlespecific machine data.....	218
8.5.2	Setting data	218
8.5.2.1	Channelspecific setting data.....	218
9	Compensations	219
9.1	Introduction.....	219
9.2	Temperature compensation.....	220
9.2.1	Function	220
9.2.2	Commissioning	223
9.2.3	Example	224
9.2.3.1	Commissioning the temperature compensation for the Z axis of a lathe	224
9.3	Backlash compensation.....	226
9.3.1	Mechanical backlash compensation.....	226
9.3.1.1	Function	226
9.3.1.2	Commissioning: Axis-specific machine data	228
9.3.2	Dynamic backlash compensation.....	229
9.3.2.1	Function	229
9.3.2.2	Commissioning: Axis-specific machine data	230
9.3.3	Dual position feedback.....	231
9.3.3.1	Commissioning: Axis-specific machine data	232
9.3.3.2	Supplementary conditions	232
9.4	Nodding compensation.....	233
9.4.1	Description of the function.....	233
9.4.1.1	Options	233
9.4.1.2	Features	233
9.4.1.3	Position-dependent compliance factor.....	235
9.4.1.4	Compensation relationships.....	236
9.4.2	Commissioning: Machine data	236
9.4.2.1	Overview	236
9.4.2.2	Time constant for smoothing nodding compensation values.....	237
9.4.2.3	Accelerating axis.....	238
9.4.2.4	Adaptation axis.....	238
9.4.2.5	Number of positions of the adaptation characteristic	239
9.4.2.6	Positions of the adaptation characteristic.....	240
9.4.2.7	Compliance factors	241
9.4.2.8	Function diagram.....	243
9.5	Interpolatory compensation	244
9.5.1	General properties	244
9.5.2	Leadscrew error and measuring system error compensation	246
9.5.2.1	Measuring system error compensation (MSEC)	246
9.5.2.2	Commissioning	247
9.5.2.3	Example	250
9.5.3	Sag and angularity error compensation	251
9.5.3.1	General information.....	251
9.5.3.2	Commissioning: Machine data	253

9.5.3.3	Commissioning: Setting data.....	254
9.5.3.4	Commissioning: System variable	255
9.5.3.5	Commissioning: Basic procedure	259
9.5.3.6	Commissioning: Overview diagram	261
9.5.3.7	Example 1: Sag compensation.....	262
9.5.3.8	Example 2: Compensation with table multiplication.....	263
9.5.3.9	Example 3: 2-dimensional array of compensation values	264
9.5.4	Extension of the sag compensation with NCU link	270
9.5.4.1	General parameter assignment	270
9.5.4.2	Parameterization with channel names	270
9.5.4.3	Parameterization with machine axis names	271
9.5.4.4	Axis container	271
9.5.4.5	Configuration example 1: NCU link with rigid coupling.....	272
9.5.4.6	Configuration example 2 NCU link with axis container	274
9.5.5	Direction-dependent leadscrew error compensation	278
9.5.5.1	Description of functions	278
9.5.5.2	Commissioning	279
9.5.5.3	Example	282
9.5.6	Cylinder error compensation	285
9.5.6.1	Options	285
9.5.6.2	Function	285
9.5.6.3	Commissioning	285
9.5.6.4	Examples	290
9.5.7	Supplementary conditions	293
9.6	Dynamic feedforward control (following error compensation)	295
9.6.1	General properties	295
9.6.2	Speed feedforward control	297
9.6.3	Torque feedforward control.....	298
9.6.4	Dynamic response adaptation	300
9.6.5	Forward feed control for command- and PLC axes.....	301
9.6.6	Secondary conditions.....	303
9.7	Friction compensation overview.....	304
9.8	Friction compensation with a constant compensation value	304
9.8.1	Description of functions	304
9.8.2	Commissioning	305
9.8.2.1	Circularity test.....	306
9.8.3	Supplementary conditions	309
9.9	Friction compensation with adaptive characteristic.....	310
9.9.1	Description of functions	310
9.9.2	commissioning	311
9.9.3	Supplementary conditions	313
9.10	Friction compensation with adaptive characteristics	313
9.10.1	Description of the function.....	313
9.10.2	Commissioning	315
9.10.2.1	Activating the function	315
9.10.2.2	Commissioning functions of the SINUMERIK Operate user interface	315
9.10.2.3	Parameterization of the acceleration at the characteristic interpolation points.....	317
9.10.2.4	Velocity setpoint pulse	319
9.10.2.5	Torque setpoint pulse.....	321

9.11	Compensation functions for suspended axes	325
9.11.1	Electronic counterweight	325
9.11.2	Special function: Reboot delay	326
9.12	Data lists.....	328
9.12.1	Machine data.....	328
9.12.1.1	General machine data	328
9.12.1.2	Channelspecific machine data	328
9.12.1.3	Axis/spindlespecific machine data.....	329
9.12.2	Setting data	331
9.12.2.1	General setting data.....	331
9.12.2.2	Axis/spindle-specific setting data	331
A	Appendix.....	333
A.1	List of abbreviations.....	333
A.2	Documentation overview	338
	Index.....	339

Introduction

1.1 About this documentation

This documentation is part of the documentation category of SINUMERIK Function Manuals.

SINUMERIK Function Manuals

The SINUMERIK Function Manuals describe the NC functions of a SINUMERIK control.

The target group are configuring engineers, technologists, commissioning engineers and programmers.

Each Function Manual covers a specific topic and contains all the function descriptions for this topic.

The following table shows which Function Manuals are available for your SINUMERIK control and which topics a Function Manual covers:

Function Manual	Topic
Basic functions	Basic functions of a CNC control
Axes and spindles	Axis and spindle functions, axis couplings
Transformations	Transformation functions
Monitoring and compensating	Axis monitoring and compensation functions, collision avoidance
Tools	Functions for selection, correction and monitoring of tools
Synchronized actions	Functionality of synchronized actions
PLC	Structure and functions of the PLC
Tool management	Function, commissioning and programming of tool management
Technologies (for SINUMERIK ONE and SINUMERIK 840D sl only)	Extended technological functionalities

Overview of contents

You will find an overview of the main chapters of the descriptions of functions that are contained in a Function Manual on the title page.

Validity

The title page also contains all data about the validity of a document, i.e. for which SINUMERIK control and for which software version this edition of the Function Manual is valid.

System data

In the descriptions of functions, the system data relevant for a function (machine data, setting data, system variables, interface signals and alarms) are only described with the level of detail that is strictly necessary to understand the function. You will find detailed information on this data in the relevant List Manuals and for alarms in the Diagnostics Manual.

PLC blocks

The descriptions of functions often refer to the PLC function blocks (FB) and functions (FC). The descriptions of these blocks apply to the SINUMERIK 840D sl and can only be applied in part to other SINUMERIK controls.

Interface signals

In this document, only the absolute address valid for the SINUMERIK 840D sl is used to address interface signals.

General graphical conventions	Examples
<signal address> (<signal name>)	DB31, ... DBX16.0-2 (actual gear stage A to C) DB31, ... DBX16.3 (gear is changed)

Note

Quantity structure

Explanations concerning the NC/PLC interface are based on the absolute maximum number of the following components:

- Mode groups (DB11)
 - Channels (DB21, etc.)
 - Axes/spindles (DB31, etc.)
-

Fundamental safety instructions

2.1 General safety instructions

 WARNING
Danger to life if the safety instructions and residual risks are not observed If the safety instructions and residual risks in the associated hardware documentation are not observed, accidents involving severe injuries or death can occur. • Observe the safety instructions given in the hardware documentation. • Consider the residual risks for the risk evaluation.

 WARNING
Malfunctions of the machine as a result of incorrect or changed parameter settings As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death. • Protect the parameterization against unauthorized access. • Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

2.2 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment or any eventuality which may arise. Application examples do not represent specific customer solutions, but are only intended to provide support for typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

2.3 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to

2.3 Security information

an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit

<https://www.siemens.com/industrialsecurity> (<https://www.siemens.com/industrialsecurity>).

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

<https://www.siemens.com/industrialsecurity> (<https://new.siemens.com/global/en/products/services/cert.html#Subscriptions>).

Further information is provided on the Internet:

Industrial Security Configuration Manual (<https://support.industry.siemens.com/cs/ww/en/view/108862708>)



WARNING

Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
- Make sure that you include all installed products into the holistic industrial security concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- On completion of commissioning, check all security-related settings.

Geometric machine modeling

3.1 Function description

3.1.1 Features

This section describes how the geometry of machine parts can be mapped based on protection areas and parameterized in the control using system variables for NC functions such as "collision avoidance".

The system variables are retentively saved in the NC and can be archived and/or read as "NC data" via SINUMERIK Operate using the commissioning archive.

By assigning a protective area to an element of the kinematic chain described in the previous section, the position and motion of the machine part can be clearly described within the machine space.

Note

Graphical editor

As an alternative to writing the system variables in a part program, the machine can be modeled from the SINUMERIK Operate user interface:

Operating area: "Commissioning" > "NC" > "Machine model"

Changes to the machine model

The direct changes to the machine model at the system variables only become visible at the user interface after explicitly requesting that the machine model is recalculated by calling the PROTA() (Page 86) or PROTS() (Page 87) function.

Changes to the machine model made at the user interface are immediately accepted in the system variables of the NC. The changes only become active after explicitly requesting that the machine model is recalculated by calling the PROTA() (Page 86) or PROTS() (Page 87) function.

Protection area

The protection areas are the central element when geometrically modeling a machine. The geometric dimensions of a machine part, its reference to the kinematic chain and additional general features are described by a protection area.

A protection area has the following parameters:

- Name of the protection area
- Name of the kinematic element to which the protection area is assigned
- Type of the protection area
- Name of the first protection area element

3.1 Function description

- Color and transparency of the protection area
- Detail level for the protection area
- Number of NC/PLC interface bits of the protection area
- Initialization status of the protection area
- Address of the geometric data of the machine element to the protected (only relevant for automatic protection areas)

Each parameter is mapped by a system variable. The individual parameters and/or system variables are described in detail in Chapter "System variables: Protection areas (Page 27)".

Kinematic chain

The corresponding protection area is assigned to an element of the kinematic chain in order to map the position and motion of a machine part. The geometric data of the protection area relates then to the local coordinate system of this kinematic element.

Type of the protection area

The following types of protection areas are available:

- Machine protection areas (type: "MACHINE")
Machine protection areas are used for general machine modeling. They are used to map stationary and moving machine parts whose geometry is defined once upon commissioning and no longer changes when the machine is in operation.
- Automatic tool protection areas (type: "TOOL")
Automatic tool protection areas are used to map tools. The geometry of the tool is not provided directly with this but is produced automatically by the control when the tool is activated.
See Chapter "Automatic tool protection areas (Page 20)".

Protection area element

Using a protection area element, the geometrical element used is described regarding its geometrical and general properties.

A protection area element has the following parameters:

- Name of the protection area element
- Name of the following protection area element
- Name of the following protection area element parallel to \$NP_NEXT
- Color and transparency of the protection area element
- Detail level for the protection area element
- Usage of the protection area element
- Type of the protection area element
- File name of the STL file that contains the geometric data of the protection area element (only relevant for type "FILE")
- Geometrical parameters of the protection area body (only relevant for types, "BOX", "SPHERE" or "CYLINDER")


- Offset vector of the protection area element local coordinate system
- Direction vector for the rotation of the protection area element local coordinate system
- Angle for the rotation of the protection area element local coordinate system

Each parameter is mapped by a system variable. The individual parameters or system variables are described in detail in:

- Chapter "System variables: Protection area elements for machine protection areas (Page 39)"
- Chapter "System variables: Protection area elements for automatic tool protection areas (Page 61)"

Protection area, protection area elements and kinematic chain

Using an example of a protection area with two protection area elements, the following diagram shows the interrelationship between the protection area, its protection area elements and the assignment to an element of the kinematic chain.



- e_1 Kinematic element 1, type "OFFSET", continuous offset
- e_2 Kinematic element 2, type "AXIS_LIN", machine axis AX1
- s_1 Protection area
- se_1 Protection area element 1, type "FRAME", offset
- se_2 Protection area element 2, type "BOX"
- se_3 Protection area element 3, type "CYLINDER"

Figure 3-1 Protection area, protection area elements and kinematic chain

3.1.2 Automatic tool protection areas

Unlike machine protection areas whose geometry is defined once during the machine modeling and then no longer changes, the geometry of a tool protection area can change with every tool change. As a result the geometry of an automatic tool protection area is not described directly when the machine model is created, and instead the address (magazine number, magazine location, etc.) is provided under which the tool data is stored. The following actions are then carried out automatically by the control.

1. The tool modeling (see "Tool modeling" section below) produces an STL file.
2. A protection area element of the "FILE" type is produced and assigns the STL file.
3. The protection area element is assigned to the protection area (type "TOOL").

Tool definition independent of the tool mounting position

Normally the parameter "\$NP_1ST_PROT (Page 31)" remains empty for the definition of a tool protection area. The name of the protection area element is only entered when the tool is activated by the control (see above).

In order for there to be a tool definition independently of the tool mounting position, a protection area element of the "FRAME (Page 46)" type can be assigned via the parameter "\$NP_1ST_PROT" (transformation element). The transformations to align the tool can be carried out via this additional element. When a tool is activated the name of the internal protection area element is entered in the parameter "\$NP_NEXT (Page 41)" of the transformation element by the control.

The following rules must be observed:

- The transformation element may only be of the "FRAME" type.
- Only one transformation element may be used for each tool protection area.
- The parameter "\$NP_NEXTP" of the transformation element is not evaluated.

Tool reference point

The position of the tool reference point in the machine model is determined by the kinematic element to which the tool protection area is assigned. In addition the tool reference point can be offset within the tool protection area by an optional transformation element.

Kinematic transformations

The tool reference point may only be determined via the kinematic chain when defining a kinematic transformation. Offsets by the transformation element of the tool protection area are not taken into account.

NOTICE

Determination of the tool reference point for kinematic transformations

Offsets of the tool reference point by the transformation element of the tool protection area are not taken into account by kinematic transformations.

Tool modeling

The model of a tool is created by the control heuristically from the tool data. The tool data used for this (L1, L2, L3, R) is always the the overall dimensions resulting from the individual components, e.g. length plus wear, as is also entered in the program processing for tool offset.

Programmable tool offsets

Programmable tool offsets such as `OFFN` (offset to the programmed contour) are not taken into account as they may change in any block, even without a tool change.

3.1 Function description

Tool type-dependent model generation

The following tool types are distinguished for the model generation:

- Milling tool and all other tools that are neither turning tools or grinding tools
 - Modeling
The tool is modeled by a cylinder with the height L1 and radius R. If the length L1 is negative the absolute value of L1 is used for the cylinder height. The sign L1 is taken into account when positioning the cylinder in the machine model. The cylinder axis is parallel to L1.
Tool type 110 (ball end mill cutter) and 111 (face cutter) are modeled using half a sphere or sphere segments.
If the radius is negative the absolute value of the radius is used. If the value for the radius is less than 1/3 mm, a radius of 1/3 mm is used.
 - Positioning
The cylinder is positioned in the machine model using the tool length components L2 and L3.
For milling tools (tool type 100 ... 199) and drilling tools (tool type 200 ... 299) on turning machines, the cylinder is positioned using the cutting edge position.
Precondition: Cutting edge position == 5 ... 8
- Grinding tools
 - Modeling
Grinding tools (grinding wheel, tool type 400 ... 499) are modeled by a cylinder with the tool length as the radius and double the tool radius as the height.
 - Positioning
The cylinder is positioned in the machine model using the tool lengths L1, L2 and L3.
- Turning tools
In the case of turning tools only the cutting tips are taken into account in the machine model but not their connection to the tool reference point.
The following data is taken into account when modeling a cutting tip:
 - Tool type
 - Cutting edge position
 - Cutting edge radius
 - Clearance angle
 - Holder angle
 - Cutting tip length
 - Cutting tip width
 - Tip thickness (assumption: tip thickness = 10% tip length)

Tool model

A tool is modeled as standard with an accuracy of one third of the collision tolerance (Page 77). The geometric data of the modeled tool is stored in an internal file in STL format:

- Directory: `_N_PROT3D_DIR/_N_TOOL_DIR`
- Identifiers: Name of the associated protection area with prefix `_N_` and ending with `_STL`

The coordinate system of the geometric data always has its origin at the point from which the tool length offsets point to the tip of the tool.

System variable

All parameters for an automatic tool protection area can be read via System variable (Page 39).

3.2 Commissioning

3.2.1 General

3.2.1.1 Overview

The commissioning of the "Collision avoidance" function is performed using:

- Machine data
 - Specifications for the quantity structure of protection areas, protection area elements, NC/PLC interface signals, triangles for the geometry modelling
 - Creation mode of the machine model
 - Creation mode for automatic tool protection areas
- System variables
 - Parameterization of the protection areas
 - Parameterization of the protection area elements of a protection area

3.2.1.2 Structure of the system variables

The system variables are structured according to the following scheme:

- **\$NP_<name>[<index_1>]**
- **\$NP_<name>[<index_1>, <index_2>]**

General

The system variables to describe the protection areas or protection area elements have the following properties:

- Prefix: **\$NP_** (N for NC, P for protection).
- They can be read and written via NC programs.
- They can be stored in archives and loaded to the NC again.

Data type

STRING

All system variables of the STRING data type have the following properties:

- Maximum string length: 31 characters
- No distinction is made between upper and lower case
Example: "Axis1" is identical to "AXIS1"
- Spaces and special characters are permitted
Example: "Axis1" is not identical to "Axis 1"
- Names that **start** with **two** underscores "__" are reserved for system purposes and must **not** be used for user-defined names.

Note

Leading space

Since spaces are valid and distinct characters, names that **start** with a **space** followed by **two** underscores "__" can, in principle, be used for user-defined names. However, because they can be easily mistaken for system names, this procedure is **not** recommended.

Index_1

System variables for protection areas

The individual protection areas are addressed via index_1. Index 0 → 1st protection area, index 1 → 2nd protection area, ... m → (m+1) protection area, where m = (\$MN_MM_MAXNUM_3D_PROT_AREAS - 1)

All system variables of a protection area have the same index.

System variables for protection areas elements

The individual protection area elements are addressed via index_1. Index 0 → 1st protection area element, index 1 → 2nd protection area element, ... n → (n+1)th protection area element, where n = (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)

All system variables of a protection area element have the same index.

Index_2

Depending on the respective system variables, index_2 has different meanings.

3.2.1.3 Color chart

The following color chart provides an overview of the RGB color values and the associated colors. A RGB color value comprises three bytes. One byte per color:

3rd byte	2nd byte	1st byte
Color value for red	Color value for green	Color value for blue
0 - 255 _D or 0 - FF _H	0 - 255 _D or 0 - FF _H	0 - 255 _D or 0 - FF _H

330000	333300	336600	339900	33CC00	33FF00	66FF00	66CC00	669900	666600	663300	660000	FF0000	FF3300	FF6600	FF9900	FFCC00	FFFF00
330033	333333	336633	339933	33CC33	33FF33	66FF33	66CC33	669933	666633	663333	660033	FF0033	FF3333	FF6633	FF9933	FFCC33	FFFF33
330066	333366	336666	339966	33CC66	33FF66	66FF66	66CC66	669966	666666	663366	660066	FF0066	FF3366	FF6666	FF9966	FFCC66	FFFF66
330099	333399	336699	339999	33CC99	33FF99	66FF99	66CC99	669999	666699	663399	660099	FF0099	FF3399	FF6699	FF9999	FFCC99	FFFF99
3300CC	3333CC	3366CC	3399CC	33CCCC	33FFCC	66FFCC	66CCCC	6699CC	6666CC	6633CC	6600CC	FF00CC	FF33CC	FF66CC	FF99CC	FFCCCC	FFFFCC
3300FF	3333FF	3366FF	3399FF	33CCFF	33FFFF	66FFFF	66CCFF	6699FF	6666FF	6633FF	6600FF	FF00FF	FF33FF	FF66FF	FF99FF	FFCCFF	FFFFFF
0000FF	0033FF	0066FF	0099FF	00CCFF	00FFFF	99FFFF	99CCFF	9999FF	9966FF	9933FF	9900FF	CC00FF	CC33FF	CC66FF	CC99FF	CCCCFF	CCFFFF
0000CC	0033CC	0066CC	0099CC	00CCCC	00FFCC	99FFCC	99CCCC	9999CC	9966CC	9933CC	9900CC	CC00CC	CC33CC	CC66CC	CC99CC	CCCCCC	CCFFCC
000099	003399	006699	009999	00CC99	00FF99	99FF99	99CC99	999999	996699	993399	990099	CC0099	CC3399	CC6699	CC9999	CCCC99	CCFF99
000066	003366	006666	009966	00CC66	00FF66	99FF66	99CC66	999966	996666	993366	990066	CC0066	CC3366	CC6666	CC9966	CCCC66	CCFF66
000033	003333	006633	009933	00CC33	00FF33	99FF33	99CC33	999933	996633	993333	990033	CC0033	CC3333	CC6633	CC9933	CCCC33	CCFF33
000000	003300	006600	009900	00CC00	00FF00	99FF00	99CC00	999900	996600	993300	990000	CC0000	CC3300	CC6600	CC9900	CCCC00	CCFF00

3.2.2 Machine data

3.2.2.1 Maximum number of protection areas

The maximum number of all types of parameterizable protection areas (Page 30) is specified with the machine data.

MD18890 \$MN_MM_MAXNUM_3D_PROT_AREAS = <number>

3.2.2.2 Maximum number of protection area elements for machine protection areas

The maximum number of parameterizable protection area elements for machine protection areas is specified using machine data (\$NP_PROT_TYPE == "MACHINE" (Page 30)).

MD18892 \$MN_MM_MAXNUM_3D_PROT_AREA_ELEM = <number>

3.2.2.3 Maximum number of protection area elements for automatic tool protection areas

The maximum number of protection area elements for automatic tool protection areas is specified with the machine data. For each automatic tool protection area the control precisely creates one protection area element. As a consequence, using the value parameterized here, the maximum possible number of parameterizable automatic tool protection areas (\$NP_PROT_TYPE == "TOOL" (Page 30)) is also simultaneously defined.

MD18893 \$MN_MM_MAXNUM_3D_T_PROT_ELEM = <number>

3.2.2.4 Maximum number of NC/PLC interface signals for the preactivation of protection areas

The machine data communicates to the control the number of NC/PLC interface signals of interface DB10, DBX234.0 - DBX241.7 actually used (collision avoidance: activate protection area) with the machine data. The number of interface signals used increases the memory space required for each part program block. Counting the number of used NC/PLC interface signal starts at DB10, DBX234.0

MD18897 \$MN_MM_MAXNUM_3D_INTERFACE_IN = <number>

Further information:

A detailed description of the interface signals is provided in the Function Manual PLC.

3.2.2.5 Maximum number of triangles for machine protection areas

With the machine data, the maximum number of triangles for protection area bodies (\$NP_TYPE == "FILE" (Page 46)) of machine protection areas (\$NP_PROT_TYPE == "MACHINE" (Page 30)) to be provided by the control is defined.

MD18895 \$MN_MM_MAXNUM_3D_FACETS = <number>

3.2.2.6 Maximum number of triangles for automatic tool protection areas

With the machine data, the maximum number of triangles for protection area bodies of automatic tool protection areas to be provided by the control is defined.

MD18894 \$MN_MM_MAXNUM_3D_FACETS_INTERN = <number>

The control system automatically models the protection area bodies based on the geometric data of the tool active at the time of creation. The number of triangles correspondingly increases:

- as the geometric complexity of the tool increases.
- as the parameterized collision tolerance decreases.

Note**Protection area bodies and collision tolerance**

The protection area bodies of automatic tool protection areas are, as standard, created by the control with a precision of 1/3 of the collision tolerance (Page 77).

3.2.2.7 Creation mode for automatic tool protection areas

The machine data defines how the control creates protection area bodies of automatic tool protection areas.

MD18899 \$MN_PROT_AREA_TOOL_MASK = <mode>

<Mode>		
Bit	Value	Meaning
0	0	Do not apply heuristic model generation
	1	Heuristic model generation using tool data

3.2.3 System variables: Protection areas

3.2.3.1 Overview

A protection area is parameterized with the following system variables:

Name	Meaning
\$NP_PROT_NAME	Name of the protection area
\$NP_CHAIN_ELEM	Name of the kinematic element to which the protection area is assigned
\$NP_PROT_TYPE	Type of the protection area
\$NP_1ST_PROT	Name of the first protection area element
\$NP_PROT_COLOR	Color and transparency of the protection area.
\$NP_PROT_D_LEVEL	Detail level for the protection area
\$NP_BIT_NO	Number of NC/PLC interface bits of the protection area
\$NP_INIT_STAT	Initialization status of the protection area
\$NP_INDEX	Address of the geometric data of the machine element to be protected (only relevant for automatic protection areas)

The system variables are described in detail in the following sections.

Note

Establish a defined initial state

It is recommended that a defined initial state be generated before parameterizing the protection areas. To do this, set the system variables of the protection areas to their default values with the DELOBJ() function.

Change system variable values

If the value of one of the system variables listed above is changed, the change becomes immediately visible at the user interface, e.g. SINUMERIK Operate. The machine model of the NC is only updated after explicitly requesting that the machine model is recalculated by calling the PROTA() (Page 86) or PROTS() (Page 87) function.

3.2.3.2 \$NP_PROT_NAME

Function

Enter the NC-wide unique protection area name in the system variable. The protection area is referenced via this name, e.g. by a protection area element. The name is also displayed in the graphical editor of SINUMERIK Operate.

Syntax

```
$NP_PROT_NAME [<m>] = "<name>"
```

Meaning

\$NP_PROT_NAME:	Name of the protection area	
	Data type:	STRING
	Default value:	"" (empty string)
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<name>:	Name of the protection area	
	Data type:	STRING

Example

The 6th protection area is assigned the name "Spindle":

Program code	Comment
N100 \$NP_PROT_NAME[5] = "Spindle"	; 6. Protection area, ; name = "Spindle"

3.2.3.3 \$NP_CHAIN_ELEM

Function

Enter the name of the kinematic element to which the protection area will be connected in the system variable.

Note

Reference coordinate system

The geometric data of the protection area, starting from the first protection area element (\$NP_1ST_PROT (Page 31)), refer to the local coordinate system of the kinematic element, with which the protection area is connected.

Syntax

```
$NP_CHAIN_ELEM[<m>] = "<Name>"
```

Meaning

\$NP_CHAIN_ELEM:	Name of the kinematic element to which the protection area will be connected	
	Data type:	STRING
	Default value:	"" (empty string)
<m>:	System variable or protection area index	
	Data type:	INT
	Value range:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<name>:	Name of the kinematic element	
	Data type:	STRING
	Value range:	For names parameterized in \$NK_NAME, refer to the Function Manual "Basic Functions", Section "Kinematic chain".

Example

The 6th protection area is connected to the kinematic element with the name "Z axis":

Program code	Comment
N100 \$NP_CHAIN_ELEM[5] = "Z ax- is"	; 6. Protection area, ; name of the kin. element: "Z axis"

3.2.3.4 \$NP_PROT_TYPE

Function

The protection area type should be entered in the system variable:

- Machine protection area: "MACHINE"
The protection area body is defined using one or several protection area elements.
\$NP_1ST_PROT (Page 31) refers to the first protection area element.
- Automatic tool protection area: "TOOL"
The control calculates the dimensions of the protection area body from the tool data.
\$NP_INDEX (Page 37) refers to the tool.
- Workholder protection area: "FIXTURE"
- Workpiece protection area: "WORKPIECE"

Syntax

```
$NP_PROT_TYPE [<m>] = "<type>"
```

Meaning

\$NP_PROT_TYPE:	Type of the protection area	
	Data type:	STRING
	Range of values:	"MACHINE", "TOOL", "FIXTURE", "WORKPIECE"
	Default value:	"" (empty string)
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<Type>:	Type	
	Data type:	STRING

Example


The 6th protection area is a machine protection area:

Program code	Comment
N100 \$NP_PROT_TYPE[5] = "MACHINE"	; 6. Protection area, ; type = "MACHINE"

3.2.3.5 \$NP_1ST_PROT

Function

Enter the name of the first protection area element (Page 40) in the system variable.



Syntax

`$NP_1ST_PROT [<m>] = "<name>"`

Meaning

\$NP_1ST_PROT:	Name of the first protection area element of the protection area	
	Data type:	STRING
	Range of values:	Names parameterized in \$NP_NAME (Page 40)
	Default value:	"" (empty string)
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<name>:	Protection area name	
	Data type:	STRING

Automatic tool protection areas, \$NP_PROT_TYPE == "TOOL"

For automatic tool protection areas, only the following values are permissible for \$NP_1ST_PROT:

- "" (empty string)
- Name of a protection area element, type "FRAME"

Behavior for value == "" (empty string)

When activating the associated tool, the control creates a protection area element for the tool with a unique, internal name and protection area body generated from the geometric data of the tool. The name is assigned system variable \$NP_1ST_PROT.

- Protection area "TOOL" : \$NP_1ST_PROT = "<internal name>"

The coordinates of the tool protection area refer to the local coordinate system of the kinematic element to which it is assigned.

Behavior for value == name of a protection area element, type "FRAME"

When activating the associated tool, the control creates a protection area element for the tool with a unique, internal name and protection area body generated from the geometric data of the tool. The name is assigned a system variable \$NP_NEXT of the protection area element, type "FRAME", to which \$NP_1ST_PROT refers.

- Protection area "TOOL" : \$NP_1ST_PROT = "WKZ_Frame" →
 - Protection area element "WKZ_Frame" : \$NP_NEXT = "<internal name>"

The coordinates of the tool protection area refer to the local coordinate system of the protection area element, type "FRAME".

Possible applications: Tool definition independent of the position where it is mounted on the machine.

Example

The 1st protection area element which makes up the 6th protection area has the name "Spindle head":

Program code	Comment
N100 \$NP_1ST_PROT[5] = "Spindle head"	; 6. Protection area, ; 1. Protection area element = "spindle box"

3.2.3.6 \$NP_PROT_COLOR**Function**

Enter the protection area element-specific value for alpha/transparency and color (ARGB) in the system variable. This value is used for the display of the protection area or protection area element on the user interface. If a separate value is entered for a protection area element in \$NP_COLOR (Page 43), this is used for the display of the protection area element.

Structure

Alpha/transparency and color are specified as a double word in hexadecimal format:

AARRGGBB_H

- 1. - 3. Byte: RGB color value. See Chapter "Color chart (Page 24)".
- 4. Byte: Alpha channel or transparency value

	Byte	Meaning	Range of values
OC	1	Blue	0 - 255 _D or 0 - FF _H
GG	2	Green	
RR	3	Red	
AA	4	Alpha channel or transparency ¹⁾	
1) 0 = transparent or not visible, 255 _D = FF _H = not transparent or filled			

Syntax

`$NP_PROT_COLOR[<m>] = <value>`

Meaning

\$NP_PROT_COLOR:	Alpha/transparency and color value of the protection area	
	Data type:	DWORD
	Range of values:	00000000 _H - FFFFFFFF _H
	Default value:	00000000 _H (black, not visible)
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<value>:	Transparency and color value	
	Data type:	DWORD

Example

The 6th protection area is to be displayed half transparent and in a green-blue color on the user interface:

- AA = 7F_H = 127_D $\triangleq$ 50% transparency
- RR (red) = 00 $\triangleq$ no red component
- GG (green) = FF_H = 255_D $\triangleq$ 100% green color component
- BB (blue) = 33_H = 51_D $\triangleq$ 20% blue color component

Program code	Comment
N100 \$NP_PROT_COLOR[5] = 'H7F00FF33'	; 6. Protection area, ; alpha/transparency and color value = H7F00FF33

3.2.3.7 \$NP_PROT_D_LEVEL

Function

The detail level as of which the protection area or the protection area elements are displayed on the user interface is specified via the system variable. If a separate value is entered for a protection area element in \$NP_D_LEVEL (Page 44), this is used for the display of the protection area element.

Detail level

- Lowest detail level: 0
- Highest detail level: 3

If the detail level x is selected for the display on the HMI, all protection areas and protection area elements are displayed for which the following applies for the detail level D: $D \leq x$

Syntax

```
$NP_PROT_D_LEVEL[<m>] = <value>
```

Meaning

\$NP_PROT_D_LEVEL:	Detail level for the protection area	
	Data type:	INT
	Range of values:	$0 \leq D \leq 3$
	Default value:	0
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<value>:	Detail level	
	Data type:	INT

Example

The 6th protection area is to be displayed as of detail level 3:

Program code	Comment
N100 \$NP_PROT_D_LEVEL[5] = 3	; 6. Protection area, ; detail level = 3

3.2.3.8 \$NP_BIT_NO**Function**

Enter the bit number (0, 1, 2, 63) of the NC/PLC interface signal with which the protection area is to be connected in system variable \$NP_BIT_NO. If the protection area is not to be connected to an NC/PLC interface signal, enter the value -1.

NC/PLC interface

Activation / deactivation of the protection area can be requested via NC/PLC interface signals from the PLC user program or this can be used for feedback on the current status to the PLC user program:

- Requirement: DB10, DBX234.0 - DBX241.7
- Feedback: DB10, DBX226.0 - DBX233.7

Requirement

The status of the protection area must be "preactivated" or "PLC-controlled" in order that the assigned NC/PLC interface signal of the protection area is taken into account:

```
$NP_INIT_STAT (Page 36) == "P" (preactivated or PLC-controlled)
```

Syntax

```
$NP_BIT_NO[<m>] = <bit number>
```

Meaning

\$NP_BIT_NO:	Bit number of the interface signal to activate/deactivate the protection area	
	Data type:	INT
	Value range:	-1, 0, 1, 2, ... (\$MN_MM_MAXNUM_3D_INTERFACE_IN - 1)
	Default value:	-1 (no interface signal selected)
<m>:	System variable or protection area index	
	Data type:	INT
	Value range:	0, 1, 2, ... (\$MN_MM_3D_MAXNUM_PROT_AREAS - 1)
<Bit number>:	Bit number (0, 1, 2, ... 63) of the 64-bit interface	
	Data type:	INT

Example

The 6th protection area is assigned to the 18th bit of interface (DB10.DBX236.1):

Program code	Comment
N100 \$NP_BIT_NO[5] = 17	; 6. Protection area, ; DB10.DBX236.1

Assignment: Bit number to the interface signal

Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)
0	DBX234.0	DBX226.0	8	DBX235.0	DBX227.0	16	DBX236.0	DBX228.0	24	DBX237.0	DBX229.0
1	DBX234.1	DBX226.1	9	DBX235.1	DBX227.1	17	DBX236.1	DBX228.1	25	DBX237.1	DBX229.1
2	DBX234.2	DBX226.2	10	DBX235.2	DBX227.2	18	DBX236.2	DBX228.2	26	DBX237.2	DBX229.2
3	DBX234.3	DBX226.3	11	DBX235.3	DBX227.3	19	DBX236.3	DBX228.3	27	DBX237.3	DBX229.3
4	DBX234.4	DBX226.4	12	DBX235.4	DBX227.4	20	DBX236.4	DBX228.4	28	DBX237.4	DBX229.4
5	DBX234.5	DBX226.5	13	DBX235.5	DBX227.5	21	DBX236.5	DBX228.5	29	DBX237.5	DBX229.5
6	DBX234.6	DBX226.6	14	DBX235.6	DBX227.6	22	DBX236.6	DBX228.6	30	DBX237.6	DBX229.6
7	DBX234.7	DBX226.7	15	DBX235.7	DBX227.7	23	DBX236.7	DBX228.7	31	DBX237.7	DBX229.7

Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)
32	DBX238.0	DBX230.0	40	DBX239.0	DBX231.0	48	DBX240.0	DBX232.0	56	DBX241.0	DBX233.0
33	DBX238.1	DBX230.1	41	DBX239.1	DBX231.1	49	DBX240.1	DBX232.1	57	DBX241.1	DBX233.1
34	DBX238.2	DBX230.2	42	DBX239.2	DBX231.2	50	DBX240.2	DBX232.2	58	DBX241.2	DBX233.2

Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)	Bit →	DB10 (PLC → NC)	DB10 (NC → PLC)
35	DBX238.3	DBX230.3	43	DBX239.3	DBX231.3	51	DBX240.3	DBX232.3	59	DBX241.3	DBX233.3
36	DBX238.4	DBX230.4	44	DBX239.4	DBX231.4	52	DBX240.4	DBX232.4	60	DBX241.4	DBX233.4
37	DBX238.5	DBX230.5	45	DBX239.5	DBX231.5	53	DBX240.5	DBX232.5	61	DBX241.5	DBX233.5
38	DBX238.6	DBX230.6	46	DBX239.6	DBX231.6	54	DBX240.6	DBX232.6	62	DBX241.6	DBX233.6
39	DBX238.7	DBX230.7	47	DBX239.7	DBX231.7	55	DBX240.7	DBX232.7	63	DBX241.7	DBX233.7

Further information

A detailed description of the interface signals is provided in the Function Manual PLC.

3.2.3.9 \$NP_INIT_STAT

Function

Enter the protection area initialization status in the system variable.

The status of a protection area is set to the parameterized initialization status in the following situations:

- When the control ramps up
- When calling the PROTA (Page 86) function after the protection area has been recreated during operation by writing the protection-area-specific system variables
- When calling the PROTA (Page 86) function with parameter "R"
- When calling the PROTS (Page 87) function with parameter "R"

Syntax

```
$NP_INIT_STAT[<m>] = "<status>"
```

Meaning

\$NP_INIT_STAT:	Initialization status of the protection area	
	Data type:	STRING
	Range of values:	"A", "a", "I", "i", "P", "p"
	Value	Protection area status
	"A" or "a"	Activated
	"I" or "i"	Inactive
	"P" or "p"	Preactivated or PLC-controlled ¹⁾
	Default value:	"I" (inactive)
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREAS - 1)

<Status>:	Initialization status	
	Data type:	STRING
1) The activation/deactivation is performed via: DB10.DBX234.0 - DBX241.7		

Example

The initialization status of the 6th protection area is set to "P" (preactivated or PLC-controlled):

Program code	Comment
N100 \$NP_INIT_STAT[5] = "P"	; 6. Protection area, ; initialization status = "P"

The current status depends on the state of the interface signal parameterized in \$NP_BIT_NO (Page 34).

3.2.3.10 \$NP_INDEX

Function

For automatic protection areas (\$NP_PROT_TYPE (Page 30)), the address, under which the geometric data of the machine part, tool, etc. to be protected is saved, should be entered in the system variable. The control then automatically creates the geometrical dimensions of the protection area from the geometric data.

Example

For example, for an automatic tool protection area (\$NP_PROT_TYPE == "TOOL") the geometrical dimensions of the protection area are created based on the tool data.

Syntax

`$NP_INDEX[<m>,<i>] = <value>`

Meaning

\$NP_INDEX:	Address of the geometric data for the automatic protection areas	
	Data type:	INT[3]
<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREAS - 1)
<i>:	Index	
	The meaning of the system variables \$NP_INDEX[<m>,<i>], with i = 0, 1, 2, ... is dependent on the type (\$NP_PROT_TYPE) of the automatic protection area. See type-specific tables.	
	Data type:	INT
	Range of values:	0, 1, 2

<value>:	Address	
	Data type:	INT

Type: Automatic tool protection area (\$NP_PROT_TYPE == "TOOL")

<i>	<value>	
	When tool management is active	Without tool management
0	Circular magazine: Tool location number	Spindle number
	No circular magazine: Spindle number	
1	Magazine number	---
2	TOA area ¹⁾	

1) TOA area "1" can be addressed with 0 as well as also with 1.

Example

The 6th protection area is an automatic tool protection area (\$NP_PROT_TYPE == "TOOL"). The geometrical dimensions of the protection area should be generated from the geometric data of the tool at the following tool location:

- Tool location number: 1
- Magazine number: 9998 (spindle 1)
- TOA area: 1

Tool management is active.

Program code	Comment
; The dimensions of the 6th protection area are based on the tool data	
; of the tool located at the following position:	
N100 \$NP_INDEX[5,0] = 1	; Tool location number = 1
N110 \$NP_INDEX[5,1] = 9998	; magazine number = 9998 (spindle 1)
N120 \$NP_INDEX[5,2] = 1	; TOA area = 1

See also

\$NP_PROT_TYPE (Page 30)

3.2.4 System variables: Protection area elements for machine protection areas

3.2.4.1 Overview

A protection area element of a machine protection area is parameterized with the following system variables:

Name	Meaning
\$NP_NAME	Name of the protection area element
\$NP_NEXT	Name of the following protection area element
\$NP_NEXTP	Name of the following protection area element parallel to \$NP_NEXT
\$NP_COLOR	Color and transparency of the protection area element.
\$NP_D_LEVEL	Detail level for the protection area element
\$NP_USAGE	Usage of the protection area element
\$NP_TYPE	Type of the protection area element
\$NP_FILENAME	File name of the STL file that contains the geometric data of the protection area element (only relevant for \$NP_TYPE == "FILE")
\$NP_PARA	Geometric parameters of the protection area body (only relevant for \$NP_TYPE == "BOX" or "SPHERE" or "CYLINDER")
\$NP_OFF	Offset vector of the protection area element local coordinate system
\$NP_DIR	Direction vector for the rotation of the protection area element local coordinate system
\$NP_ANG	Angle for the rotation of the protection area element local coordinate system

The system variables are described in detail in the following sections.

Note

Establish a defined initial state

It is recommended that a defined initial state be generated before parameterizing the protection area elements. To do this, set the system variables of the protection area elements to their default values with the DELOBJ() function.

Change system variable values

If the value of one of the system variables listed above is changed, the change becomes immediately visible at the user interface, e.g. SINUMERIK Operate. The machine model of the NC is only updated after explicitly requesting that the machine model is recalculated by calling the PROTA() (Page 86) or PROTS() (Page 87) function.

3.2.4.2 \$NP_NAME

Function

Enter the NC-wide unique protection area element name in the system variable. The protection area element is referenced via this name. The name is also displayed in the graphical editor of SINUMERIK Operate.

Syntax

```
$NP_NAME [<n>] = "<name>"
```

Meaning

\$NP_NAME:	Name of the protection area element	
	Data type:	STRING
	Default value:	"" (empty string)
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<name>:	Name of the protection area element	
	Data type:	STRING

Example


The 19th protection area element is assigned the name "Spindle head":

Program code	Comment
N100 \$NP_NAME[18] = "Spindle head"	; 19th protection area element, ; name = "Spindle head"

3.2.4.3 \$NP_NEXT

Function

If a protection area is made up of several protection area elements, they must be linked. To do this, the name of the following protection area element must be entered in the system variable \$NP_NEXT in every protection area element.



If there is no following protection area element, the name must be entered as an empty string "".

Offset and rotation

An offset and/or rotation in the current protection area element (\$NP_OFF (Page 57), \$NP_DIR (Page 58) and \$NP_ANG (Page 60)) affects the following protection area element specified in \$NP_NEXT. This means that the specification of the spatial position and orientation of the following protection area element is relative to the current protection area element.

Syntax

```
$NP_NEXT [<n>] = "<name>"
```

Meaning

\$NP_NEXT:	Name of the following protection area element	
	Data type:	STRING
	Range of values:	All names contained in \$NP_NAME (Page 40)
	Default value:	"" (empty string)
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<name>:	Protection area name	
	Data type:	STRING

Example


The following protection area element with the name "Coolant nozzle 1" is attached to the 19th protection area element:

Program code	Comment
N100 \$NP_NAME[18] = "Coolant nozzle 1"	; 19th protection area element, ; name of the following element: "Coolant nozzle 1"

3.2.4.4 \$NP_NEXTP

Function

The protection area element chain can be branched via the system variable \$NP_NEXTP. To do this, the following protection area elements must be specified in the system variables \$NP_NEXT and \$NP_NEXTP in a protection area element. These protection area elements are then parallel to one another in two separate subchains.



- ① Following parallel protection area element
- ② Following protection area element of the same subchain

Figure 3-2 Protection area elements in parallel subchains

Application example

The separate subchains can be used, for example, to model different machine parts of a protection area for visualization or collision avoidance. Typically "C" (collision avoidance) is specified for the protection area element referred to by \$NP_NEXT for use in \$NP_USAGE (Page 45), and for the protection area element referred to in \$NP_NEXTP, the value "V" (visualization).

Offset and rotation

An offset and/or rotation in the current protection area element (\$NP_OFF (Page 57), \$NP_DIR (Page 58) and \$NP_ANG (Page 60)) affects the following protection area element specified in \$NP_NEXTP. This means that the specification of the spatial position and orientation of the following protection area element is relative to the current protection area element.

Syntax

```
$NP_NEXTP[<n>] = "<name>"
```

Meaning

\$NP_NEXTP:	Name of the branching protection area element	
	Data type:	STRING
	Range of values:	All names contained in \$NP_NAME (Page 40)
	Default value:	"" (empty string)
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<name>:	Protection area name	
	Data type:	STRING

Example

The following parallel protection area element with the name "Coolant nozzle 2" is attached to the 19th protection area element:

Program code	Comment
N100 \$NP_NEXTP[18] = "Coolant nozzle 2"	; 19. Protection area element, ; name of the parallel following element: "Coolant nozzle 2"

3.2.4.5 \$NP_COLOR

Function

Enter the protection area element-specific value for alpha/transparency and color (ARGB) in the system variable. This value is used for the display of the protection area element on the user interface. If a specific value is not parameterized for a protection area element, the protection area-specific value from \$NP_PROT_COLOR (Page 32) applies.

Structure

Alpha/transparency and color are specified as a double word in hexadecimal format:

AARRGGBB_H

- 1. - 3. Byte: RGB color value. See Chapter "Color chart (Page 24)".
- 4. Byte: Alpha channel or transparency value

	Byte	Meaning	Range of values
OC	1	Blue	0 - 255 _D or 0 - FF _H
GG	2	Green	
RR	3	Red	
AA	4	Alpha channel or transparency ¹⁾	
1) 0 = transparent or not visible, 255 _D = FF _H = not transparent or filled			

Syntax

```
$NP_COLOR[<n>] = <name>
```

Meaning

\$NP_COLOR:	Alpha/transparency and color value of the protection area element	
	Data type:	DWORD
	Range of values:	00000000 _H - FFFFFFFF _H
	Default value:	00000000 _H (black, not visible)
<m>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<value>:	Transparency and color value	
	Data type:	DWORD

Example

The 19th protection area is to be displayed half transparent and in a green-blue color on the user interface:

- AA = 7F_H = 127_D ≙ 50% transparency
- RR (red) = 00 ≙ no red component
- GG (green) = FF_H = 255_D ≙ 100% green color component
- BB (blue) = 33_H = 51_D ≙ 20% blue color component

Program code	Comment
N100 \$NP_COLOR[18] = 'H7F00FF33'	; 19. Protection area, ; alpha/transparency and color value = 'H7F00FF33'

3.2.4.6 \$NP_D_LEVEL**Function**

The detail level as of which the protection area element is displayed on the user interface is specified via the system variable. If no value different from the default value is assigned for a protection area element the protection area-specific value takes effect \$NP_PROT_D_LEVEL (Page 33).

Detail level

- Lowest detail level: 0
- Highest detail level: 3

If the detail level x is selected for the visualization of the machine model, all protection areas and protection area elements are displayed for which the following applies for the detail level D : $D \leq x$

Syntax

`$NP_D_LEVEL[<n>] = <value>`

Meaning

<code>\$NP_PROT_D_LEVEL:</code>	Detail level for the protection area element	
	Data type:	INT
	Range of values:	$0 \leq D \leq 3$
	Default value:	0
<code><m>:</code>	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (<code>\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM</code> - 1)
<code><value>:</code>	Detail level	
	Data type:	INT

Example

The 19th protection area is always to be displayed $\Rightarrow$ detail level 0:

Program code	Comment
N100 <code>\$NP_PROT_D_LEVEL[18] = 0</code>	; 19. Protection area, ; detail level = 0

3.2.4.7 \$NP_USAGE

Function

Enter the protection area element usage in the system variable. The usage specifies how the protection area element is to be considered for the collision avoidance.

- Only visualization, no collision calculation
- Only collision calculation, no visualization
- Visualization and collision calculation

Usage	Meaning
Visualization	The protection area element is displayed in the machine model on the SINUMERIK Operate user interface
Collision calculation	The protection area element is also taken into account for the collision calculation

Syntax

```
$NP_USAGE [<n>] = "<value>"
```

Meaning

\$NP_USAGE:	Use of the protection area element	
	Data type:	CHAR
	Range of values:	"V", "v", "C", "c", "A", "a"
	Value	Meaning
	"V" or "v"	Only visualization, no collision calculation
	"C" or "c"	Only collision calculation, no visualization
	"A" or "a"	Visualization and collision calculation
	Default value:	"A"
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<value>:	Usage	
	Data type:	CHAR

Example

The 19th protection area element is to be displayed at the user interface and included in the collision calculation:

Program code	Comment
N100 \$NP_USAGE[18] = "A"	; 19. Protection area, ; usage = "A"

3.2.4.8 \$NP_TYPE**Function**


Enter the protection area element type in the system variable.

Type: "FRAME"

A protection area element of the "FRAME" type does not contain any bodies, but defines a coordinate transformation of the local coordinate system. The coordinate transformation affects all the following (\$NP_NEXT (Page 41)) and/or parallel (\$NP_NEXTP (Page 42)) protection area elements. The values of the coordinate transformation are set via:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

No parameters are specified in \$NP_PARA (Page 56) for the "FRAME" type.


Type: "BOX"

- L Length in the X direction
- B Width in the Y direction
- H Height in the Z direction

A protection area element of the "BOX" type defines a paraxial box in the local coordinate system of the protection area element. The mid-point of the box is at the origin of the local coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

The parameters length, width and height are to be entered in \$NP_PARA (Page 56)

Type: "SPHERE"

- R Radius of the sphere:

A protection area element of the "SPHERE" type defines a sphere in the local coordinate system of the protection area element. The mid-point of the sphere is at the origin of the local


coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

The parameter radius is to be entered in \$NP_PARA (Page 56)

Note**Rotation**

As the center point of the sphere and the starting point of the direction vector are in the coordinate origin of the local coordinate system of the protection area element, a rotation using the direction vector \$NP_DIR (Page 58) and angle of rotation \$NP_ANG (Page 60) has no effect on the position of the sphere.

Type: "CYLINDER"


H Height in the Z direction

R Radius in the X/Y plane

A protection area element of the "CYLINDER" type defines a cylinder in the local coordinate system of the protection area element. The mid-point of the cylinder is at the origin of the local coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

The parameters height and radius are to be entered in \$NP_PARA (Page 56)


Type: "CONE"

- H Height in the Z direction
R1 Radius 1 in the X/Y plane
R2 Radius 2 in the X/Y plane

A protection area element of the "CONE" type defines a cone in the local coordinate system of the protection area element. The mid-point of the cone (half cone height on the line of symmetry of the cone) is at the origin of the local coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

The parameters height, radius 1, and radius 2 must be entered in \$NP_PARA (Page 56)

Type: "TORUS"

R1 Major radius (= distance from the center of the circle to the center of the torus in the X/Y plane)

R2 Minor radius (= radius of the circle)

A protection area element of the "TORUS" type defines a filled torus in the local coordinate system of the protection area element. The shape of a torus can most easily be described by a circle revolved around an axis that lies in its plane. In contrast to a normal torus, however, the hole in the middle of a filled torus is filled in. The center of the filled torus lies at the origin of the local coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: `$NP_OFF` (Page 57)
- Rotation direction vector: `$NP_DIR` (Page 58)
- Angle of rotation: `$NP_ANG` (Page 60)

The parameters radius 1 and radius 2 must be entered in `$NP_PARA` (Page 56)


Type: "FILE"

Figure 3-3 Example bodies in STL format

A protection area element of the "FILE" type defines a body whose geometry data is contained in the specified file in STL format (triangular areas), in the local coordinate system of the protection area element. The zero point of the body is at the origin of the local coordinate system. At the same time as the definition of the body, the local coordinate system can be transformed via the following system variables:

- Offset: \$NP_OFF (Page 57)
- Rotation direction vector: \$NP_DIR (Page 58)
- Angle of rotation: \$NP_ANG (Page 60)

The parameter is to be entered in \$NP_FILENAME (Page 51):

Syntax

```
$NP_TYPE[<n>] = "<type>"
```

Meaning

\$NP_TYPE:	Type of the protection area element	
	Data type:	STRING
	Range of values:	"FRAME", "BOX", "SPHERE", "CYLINDER", "CONE", "TORUS", "FILE"
	Default value:	"" (empty string)
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<Type>:	Type designation	
	Data type:	STRING

Example

The 19th protection area element is a cube:

Program code	Comment
N100 \$NP_TYPE[18] = "BOX"	; 19. Protection area element, ; type = "Box"

3.2.4.9 \$NP_FILENAME

Function

For protection area elements of the "FILE" type (\$NP_TYPE (Page 46)), enter the name of the file that describes the geometry data of the protection area element in the system variable.

The following file types are currently possible:

- STL files
- NPP files

STL files

An STL file (file extension .STL) must contain a description of the geometry data of a 3D body using triangles in the STL format (**Standard Tessellation Language**).

Search path

A search is made in the directories predefined on the CF card for the file entered in the system variables in the following sequence:

1. /oem/sinumerik/nck/prot_data/machine/3d_data/mm
2. /oem/sinumerik/nck/prot_data/machine/3d_data/inch

Interpretation of the length specifications

Depending on the storage directory, the length specifications contained in the STL file are interpreted in mm or inches:

- <path>/**mm**: Interpretation of the length specifications in millimeters
- <path>/**inch**: Interpretation of the length specifications in inches

Note

Maximum length of the file name

The maximum file name length, including point and the file extension is 49 characters. For more than 49 characters, an alarm is displayed when generating an archive.

NPP files

An NPP file (file extension .NPP) must contain a description of the geometry data of one or several protection area elements using NPP system variables (**NC Protection Area Primitives**). All geometrical primitives available in the NC can be defined as protection area elements using an NPP file (see \$NP_TYPE (Page 46)).

Search path

A search is made in the directories predefined on the CF card for the file entered in the system variables in the following sequence:

1. /oem/sinumerik/nck/prot_data/machine/3d_data/mm
2. /oem/sinumerik/nck/prot_data/machine/3d_data/inch

Interpretation of the length specifications

Depending on the storage directory, the length specifications contained in the NPP file are interpreted in mm or inches:

- `<path>/mm`: Interpretation of the length specifications in millimeters
- `<path>/inch`: Interpretation of the length specifications in inches

NPP file properties

- An NPP file must start with the following comments lines:

```
;COLLISION AVOIDANCE DATA
;LOC_NP_ROOT_NAME="<root_name>"
```
- As `<root_name>`, the name of the first protection area element contained in the NPP file, specified there under `$NP_NAME`, must be entered.
- Comment line are lines that start with the `;` character
- NPP files are allowed to contain empty lines

Properties of NPP system variables

NPP system variables contained in the NPP file have the following properties:

- Same name, significance and syntax as the corresponding system variables used in NC programs
- The system variables of the NC are **not** overwritten by the NPP system variables.
- **Within** an NPP file, the indices of NPP system variables must be **unique**.
- The indices of NPP system variables can be the **same** in **various** NPP files.
- The indices and the values assigned in the NPP system variables must be constants.

Supplementary conditions

- The values for `$NP_COLOR` (Page 43), `$NP_D_LEVEL` (Page 44), `$NP_USAGE` (Page 45) are, for the protection area elements defined in the NPP file, inherited from the protection area element in which they are integrated. As a consequence, all protection area elements of an NPP file have the same values for these properties.
- For positioning the protection area elements of an NPP file, the same conditions apply as for positioning the protection area elements with the system variables of the NC (`$NP_TYPE` (Page 46): "BOX", "SPHERE" and "CYLINDER").
- No additional STL or NPP files are embedded in an NPP file.

Note

Maximum length of the file name

The maximum file name length, including point and the file extension is 49 characters. For more than 49 characters, an alarm is displayed when generating an archive.

Syntax

```
$NP_FILENAME [<n>] = "<name>"
```

Meaning

\$NP_FILENAME:	Name of the STL or NPP file	
	Data type:	STRING
	Default value:	"" (empty string)
<n>:	System variable or protection area element index	
	Data type:	INT
	Value range:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<name>:	Name of the STL or NPP file	
	Data type:	STRING

Examples

Using an STL file

The geometry data for the 19th protection area element are stored in file KUEHLDU-1.STL:

Program code	Comment
N100 \$NP_FILENAME[18] = "KUEHLDU-1.STL"	; 19th protection area element, ; file name = "KUEHLDU-1.STL"

Using an NPP file

The NPP file "Kopf_A.NPP" file is loaded into the system variables of the NC for the 19th protection area element. This contains the following three protection area elements "Box-1", "Sphere-1" and "Cylinder-1".

Program code	Comment
\$NP_NAME[18] = "Head"	; 19th protection area element
\$NP_NEXT[18] = ""	
\$NP_NEXTP[18] = ""	
\$NP_TYPE[18] = "FILE"	
\$NP_OFF[18,0] = 80.0	
\$NP_OFF[18,1] = 100.0	
\$NP_OFF[18,2] = -50.0	
\$NP_DIR[18,0] = 0.0	
\$NP_DIR[18,1] = 0.0	
\$NP_DIR[18,2] = 0.0	
\$NP_ANG[18] = 0.0	
\$NP_COLOR[18] = 0	; 1)
\$NP_D_LEVEL[18] = 0	; 1)
\$NP_USAGE[18] = "A"	; 1)
\$NP_FILENAME[18] = "Kopf_A.npp"	
; 1) Active for all protection area elements loaded from file Kopf_A.NPP	

Content of file "Kopf_A.NPP"

Program code	Comment
;COLLISION AVOIDANCE DATA	; 1st header
;LOC_NP_ROOT_NAME = "Box-1"	; 2nd header
\$NP_NAME[0] = "Box-1"	; 1st protection area element
\$NP_NEXT[0] = "Sphere-1"	
\$NP_NEXTP[0] = "Cylinder-1"	
\$NP_TYPE[0] = "BOX"	
\$NP_PARA[0,0] = 340	
\$NP_PARA[0,1] = 340	
\$NP_PARA[0,2] = 340	
\$NP_OFF[0,0] = 42	
\$NP_OFF[0,1] = 73	
\$NP_OFF[0,2] = -100	
\$NP_DIR[0,0] = 0	
\$NP_DIR[0,1] = 0	
\$NP_DIR[0,2] = 1	
\$NP_ANG[0] = 30	
\$NP_NAME[1] = "Sphere-1"	; 2nd protection area element
\$NP_NEXT[1] = ""	
\$NP_NEXTP[1] = ""	
\$NP_TYPE[1] = "SPHERE"	
\$NP_PARA[1,0] = 20	
\$NP_PARA[1,1] = 0	
\$NP_PARA[1,2] = 0	
\$NP_OFF[1,0] = 170	
\$NP_OFF[1,1] = 170	
\$NP_OFF[1,2] = 170	
\$NP_DIR[1,0] = 0	
\$NP_DIR[1,1] = 0	
\$NP_DIR[1,2] = 0	
\$NP_ANG[1] = 0	
\$NP_NAME[2] = "Cylinder-1"	; 3rd protection area element
\$NP_NEXT[2] = ""	
\$NP_NEXTP[2] = ""	
\$NP_TYPE[2] = "CYLINDER"	
\$NP_PARA[2,0] = 20	
\$NP_PARA[2,1] = 20	
\$NP_PARA[2,2] = 0	
\$NP_OFF[2,0] = 170	
\$NP_OFF[2,1] = 170	
\$NP_OFF[2,2] = 170	

Program code	Comment
\$NP_DIR[2,0] = 1	
\$NP_DIR[2,1] = 2	
\$NP_DIR[2,2] = 3	
\$NP_ANG[2] = 73	

3.2.4.10 \$NP_PARA

Function

Enter the dimensions of the protection area body according to the type of the protection area element (\$NP_TYPE (Page 46)) in the system variable.

Coordinate system

The local coordinate system in which the position of the protection area body is specified, is defined by the system variables \$NP_OFF (Page 57), \$NP_DIR (Page 58), \$NP_ANG (Page 60).

Syntax

\$NP_PARA[<n>,<i>] = <value>

Meaning

\$NP_PARA:	Parameter values corresponding to the type of the protection area element					
	Data type:	REAL				
	Default value:	0.0				
<n>:	System variable or protection area element index					
	Data type:	INT				
	Value range:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)				
<i>:	Parameter index					
	Data type:	INT				
	Value range:	0, 1, 2				
	Parameter index	Type of the protection area element				
		BOX	SPHERE	CYLINDER	CONE	TORUS
	0	Length in X	Radius	Height in Z	Height in Z	Radius 1 ¹⁾
	1	Width in Y	---	Radius ¹⁾	Radius 1 ¹⁾	Radius 2
	2	Height in Z	---	---	Radius 2 ^{1) 2)}	---

<value>:	Parameter value	
	Data type:	REAL
	Value range:	$0.0 < x \leq \text{max. REAL value}$

1) Radius in the X/Y plane

2) Parameter value 0.0 is permissible.

---: Parameters that are not evaluated

Example

The 19th protection area element is a cube with the dimensions:

- Length: 50.0 in the X axis
- Width: 100.0 in the Y axis
- Height: 75.5 in the Z axis

Program code	Comment
; 19. protection area element	
N100 \$NP_TYPE[18] = "BOX"	; type = "BOX"
N120 \$NP_PARA[18,0] = 50.0	; length in X = 50.0
N130 \$NP_PARA[18,1] = 100.0	; width in Y = 100.0
N140 \$NP_PARA[18,2] = 75.5	; height in Z = 75.5

3.2.4.11 \$NP_OFF

Function

The offset vector by which the local coordinate system of the protection area element is moved compared to the coordinate system of the previous protection area element should be entered in the system variable.

Syntax

`$NP_OFF[<n>,<i>] = <value>`

Meaning


\$NP_OFF:	Offset vector	
	Data type:	REAL
	Value range:	$-\text{max. REAL value} \leq x \leq +\text{max. REAL value}$
	Default value:	(0.0, 0.0, 0.0)
<m>:	System variable or protection area element index	
	Data type:	INT
	Value range:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)

<i>:</i>	Coordinate index	
	Data type:	INT
	Value range:	0: X coordinate (abscissa) 1: Y coordinate (ordinate) 2: Z coordinate (applicator)
<value>:	Coordinate value	
	Data type:	REAL
	Value range:	- max. REAL value ≤ x ≤ + max. REAL value

Example

The local coordinate system of the 19th The local coordinate system of the protection area element is moved by the following vector compared to the coordinate system of the previous protection area element:

- X direction: 25.0
- Y direction: 50.0
- Z direction: 37.25



X, Y, Z Coordinate system of the previous protection area element

X', Y', Z' Coordinate system of the current protection area element

Program code	Comment
; 19. protection area element, offset vector	
N100 \$NP_OFF[18,0] = 25.0	X = 25.0
N110 \$NP_OFF[18,1] = 50.0	Y = 50.0
N120 \$NP_OFF[18,2] = 37.25	Z = 37.25

3.2.4.12 \$NP_DIR

Function

The direction vector through which the local coordinate system of the protection area element is rotated compared to the coordinate system of the previous protection area element should be entered in the system variable. The angle of rotation should be entered in \$NP_ANG (Page 60).

Boundary conditions

- The absolute value of the direction vector must be greater than: $1 \cdot 10^{-6}$
- A work offset parameterized in \$NP_OFF (Page 57) is performed **before** the rotation.

Syntax

\$NP_DIR[<n>,<i>] = <value>


Meaning

\$NP_DIR:	Direction vector	
	Data type:	REAL
	Range of values:	- max. REAL value $\leq x \leq \pm$ max. REAL value
	Default value:	(0.0, 0.0, 0.0)
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<i>:	Coordinate index	
	Data type:	INT
	Range of values:	0 $\rightarrow$ X; 1 $\rightarrow$ Y; 2 $\rightarrow$ Z
<value>:	Coordinate value	
	Data type:	REAL
	Range of values:	- max. REAL value $\leq x \leq \pm$ max. REAL value

Example

The local coordinate system of the 19th protection area element is rotated around the direction vector compared to the coordinate system of the previous protection area element. The direction vector is the unit vector (1; 0; 0), rotated through $\alpha=90^\circ$ in the X/Y plane and $\beta=10^\circ$ in the Y/Z plane, in relation to the world coordinate system. The following values result from this for the individual components of the direction vector:

- X component = $\cos(\alpha) \cdot \cos(\beta) = \cos(90) \cdot \cos(10) = 0.0$
- Y component = $\sin(\alpha) \cdot \cos(\beta) = \sin(90) \cdot \cos(10) \approx 0.985$
- Z component = $\sin(\beta) = \sin(10) \approx 0.174$



Program code	Comment
; 19. protection area element, direction vector	
N100 \$NP_DIR[18.0] = COS(90) * COS(10)	; 0 = X component
N110 \$NP_DIR[18.1] = SIN(90) * COS(10)	; 1 = Y component
N120 \$NP_DIR[18.2] = SIN(10)	; 2 = Z component

3.2.4.13 \$NP_ANG

Function

The angle through which the local coordinate system of the protection area element is rotated around the direction vector (\$NP_DIR (Page 58)) compared to the coordinate system of the previous protection area element should be entered in the system variable.

Syntax

\$NP_ANG[<n>] = <value>


Meaning

\$NP_ANG:	Angle of rotation	
	Data type:	REAL
	Range of values:	$-360^\circ < x \leq 360^\circ$
	Default value:	0.0
<n>:	System variable or protection area element index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - 1)
<value>:	Angle	
	Data type:	REAL

Example

The local coordinate system of the 19th protection area element is rotated by the angle by $\delta=45.0^\circ$ around the direction vector compared to the coordinate system of the previous protection area element. The direction vector is the unit vector (1; 0; 0), rotated through $\alpha=90^\circ$ in the X/Y plane and $\beta=10^\circ$ in the Y/Z plane, in relation to the world coordinate system. The following values result from this for the individual components of the direction vector:

- X component = $\cos(\alpha) * \cos(\beta) = \cos(90) * \cos(10) = 0.0$
- Y component = $\sin(\alpha) * \cos(\beta) = \sin(90) * \cos(10) \approx 0.985$
- Z component = $\sin(\beta) = \sin(10) \approx 0.174$
- Angle $\delta = 45.0^\circ$



Program code	Comment
; 19. Protection area element, direction vector and angle of rotation	
N100 \$NP_DIR[18.0] = COS(90)*COS(10)	; 0 = X component
N110 \$NP_DIR[18.1] = SIN(90)*COS(10)	; 1 = Y component
N120 \$NP_DIR[18.2] = SIN(10)	; 2 = Z component
N130 \$NP_ANG[18] = 45.0	; Angle of rotation $\delta = 45^\circ$

3.2.5 System variables: Protection area elements for automatic tool protection areas

The protection area element of an automatic tool protection area is defined using the subsequent system variables. The control automatically generates the values of the system variables from the geometric data of the associated tool, and these can only be read.

Name ¹⁾	Meaning	Analog to ²⁾
\$NP_T_NAME[<n>]	Name of the protection area element	\$NP_NAME (Page 40)
\$NP_T_TYPE[<n>]	Type of the protection area element	\$NP_TYPE (Page 46)
\$NP_T_FILENAME[<n>]	File name of the STL file that contains the geometric data of the protection area element (only relevant for \$NP_T_TYPE == "FILE")	\$NP_FILENAME (Page 51)
\$NP_T_PARA[<n>,<i>]	Geometric parameters of the protection area body (only relevant for \$NP_T_TYPE == "BOX" or "SPHERE" or "CYLINDER")	\$NP_PARA (Page 56)
\$NP_T_OFF[<n>,<i>]	Offset vector of the protection area element local coordinate system	\$NP_OFF (Page 57)
\$NP_T_DIR[<n>,<i>]	Direction vector for the rotation of the protection area element local coordinate system	\$NP_DIR (Page 58)
\$NP_T_ANG[<n>]	Angle for the rotation of the protection area element local coordinate system	\$NP_ANG (Page 60)
1) n = 0, 1, ... (\$MN_MM_MAXNUM_3D_T_PROT_ELEM - 1)		
2) The system variables of the automatic tool protection areas correspond to those of the machine protection areas.		

3.2.6 Boundary conditions

Protection area bodies for spindles

For spindles that are not in position-controlled operation, the associated protection area bodies are only modeled statically. As a result the following boundary conditions must be met when modeling protection area bodies connected with a spindle as a kinematic element:

- The protection area body **must be symmetrical around its axis of rotation**.
- The symmetrical axis of the protection area body must lie on the axis of rotation of the spindle (**collinear**)

This should be taken into account for all types of protection area bodies:

- The protection area body is a basic geometrical body (sphere, cylinder).
- The protection area body comprises several, geometrical basic bodies.
- The protection area body comprises triangles (STL file).
- The protection area body for an automatic tool protection area is created from the geometric tool data.

Note

Automatic tool protection areas

Only using tools that are symmetrical around the axis of rotation is recommended for automatic tool protection areas in connection with spindles.

Following protection areas

The rotational symmetry and collinearity of the protection area body in respect of the axis of rotation of the spindle must also be complied with for all protection areas that are connected with elements of the kinematic chain (\$NP_NEXT, \$NP_NEXTP) following on from the spindle.

Schematic example of such a kinematic chain: ... → (rotary axis/spindle) → (offset) → (linear axis) → (offset) → ...

Rotary axes

The boundary conditions stated above must also be observed in connection with rotary axes where these are also operated as spindles.

Tool reference point and kinematic transformation

The position of the associated tool reference point is determined in principle through the assignment of an automatic tool protection area to an element in the kinematic chain. However, the position of the tool reference point can be changed through offsets within the automatic tool protection area via the system variables \$NP_T_OFF, \$NP_T_DIR and \$NP_T_ANG (Page 61). A change in position for the tool reference point of this type is not captured by the kinematic transformations. In the context of kinematic transformation it is therefore highly recommended that no offsets are used for the geometric machine modeling which move the tool reference point.

3.3 Data lists

3.3.1 Machine data

3.3.1.1 NC-specific machine data

Number	Identifier: \$MN_	Description
MD18890	\$MN_MM_MAXNUM_3D_PROT_AREAS	Maximum number of protection areas
MD18892	\$MN_MM_MAXNUM_3D_PROT_AREA_ELEM	Maximum number of protection area elements
MD18893	\$MN_MM_MAXNUM_3D_T_PROT_ELEM	Maximum number of tool protection area elements
MD18897	\$MN_MM_MAXNUM_3D_INTERFACE_IN	Maximum number of NC/PLC interface signals for the preactivation of protection areas
MD18895	\$MN_MM_MAXNUM_3D_FACETS	Maximum number of triangles for protection areas
MD18894	\$MN_MM_MAXNUM_3D_FACETS_INTERN	Maximum number of triangles for automatic tool protection areas
MD18899	\$MN_PROT_AREA_TOOL_MASK	Creation mode for automatic tool protection areas

3.3.2 System variables

Identifier	Description
\$NP_PROT_NAME	Name of the protection area
\$NP_CHAIN_ELEM	Name of the kinematic element to which the protection area will be connected
\$NP_PROT_TYPE	Type of the protection area
\$NP_1ST_PROT	Name of the first protection area element of the protection area
\$NP_PROT_COLOR	Transparency and color value of the protection area
\$NP_PROT_D_LEVEL	Detail level for the protection area
\$NP_BIT_NO	Bit number of the interface signal to activate/deactivate the protection area
\$NP_INIT_STAT	Initialization status of the protection area
\$NP_INDEX	Array for addressing the effective geometry data
\$NP_NAME	Name of the protection area element
\$NP_NEXT	Name of the following protection area element
\$NP_NEXTP	Name of the branching protection area element
\$NP_COLOR	Transparency and color value of the protection area element
\$NP_D_LEVEL	Detail level for the protection area element
\$NP_USAGE	Usage of the protection area element
\$NP_TYPE	Type of the protection area element
\$NP_FILENAME	Name of the STL file with the geometry data of the protection area element body
\$NP_PARA	Parameter values corresponding to the type of the protection area element

3.3 Data lists

Identifier	Description
\$NP_OFF	Offset vector
\$NP_DIR	Direction vector
\$NP_ANG	Angle of rotation

Collision avoidance, internal

4.1 Function description

4.1.1 Options

The function "Collision avoidance" is an option that requires a license. The following versions are available:

- **Protect MyMachine /3D Primitives**
Properties:
 - Protection: Machine - Machine
 - HMI visualization
 - Only for single-channel control configurations
 - Protection area elements: geometric primitives
- **Protect MyMachine /3D STL**
Properties:
 - such as Protect MyMachine /3D Primitives
 - Protection area elements: Files in STL and NPP format

4.1.2 Characteristics

The "Collision avoidance" function is used to prevent collisions of machine parts and tool cutting edges while the machine axes are being traversed. To do this, the function cyclically calculates the clearance to the protection areas enveloping the bodies to be protected. If two protection areas approach one another to within a configurable safety clearance, an alarm is displayed and the NC program stopped before the relevant traversing block (AUTOMATIC, MDI mode) or the traversing motion is stopped (JOG mode).

Sequence

The collision avoidance is set up in the following sequence:

1. Enabling of the "Collision avoidance" function by setting the corresponding option (Page 65).
2. Setting the machine data for the basic parameterization of the functions:
 - Kinematic chain, Function Manual "Basic Functions", chapter "Kinematic chain"
 - Geometric machine modeling, chapter "Machine data (Page 25)"
 - Collision avoidance, chapter "Machine data (Page 77)"

4.1 Function description

3. Description of the kinematic structure of the machine with kinematic elements.
Refer to Function Manual "Basic Functions", chapter "Kinematic chain".
4. Writing of the protection areas and protection area elements as enveloping geometry of the machine parts, tools and workpieces to be protected. Assignment of the protection area to elements of the kinematic chain.
See chapter "Geometric machine modeling (Page 17)".
5. Definition of collision pairs, i.e. of two protection areas that are to be monitored for collision.
See chapter "\$NP_COLL_PAIR (Page 80)".
6. Triggering a recalculation of the kinematic and geometric model.
See chapter "Request recalculation of the machine model of the collision avoidance (PROTA) (Page 86)".
7. Activation of the protection areas to be monitored.
See chapter "Setting the protection zone status (PROTS) (Page 87)".
8. Optional: Use of the extended functions and system variables

Limits of the collision avoidance

The function cannot guarantee complete protection against a collision when traversing machine parts, tools or workpieces. On the one hand, the collision protection can only be as good as the parameterized kinematic and geometric model or the machine and the protection areas. On the other hand, bodies that have not been modeled cannot be monitored at all. For this reason, it remains the responsibility of the machine operator to ensure that a traversing motion is executed collision-free even when the collision protection is activated.

States of protection areas

Whether a protection area is taken into account for collisions depends on the state of the protection area:

State	Meaning
Active	The protection area is taken into account for collisions.
Inactive	The protection area is not taken into account for collisions.
Preactivated	The protection area is taken into account for collisions. A collision alarm is only issued when it has also been activated by a protection area-specific NC/PLC interface signal.

State after control ramp-up

After the control has powered up, all protection areas are in the state corresponding to their respective setting in \$NP_INIT_STAT. See chapter "\$NP_INIT_STAT (Page 36)".

State change

The state of a protection areas can be changed by:

- The PROTS() (Page 87) procedure
- Change of the initialization state to \$NP_INIT_STAT followed by recalculation of the machine model through the PROTA() (Page 86) procedure.

Requirements


The following requirements must be satisfied so that the protection areas of a collision pair can be monitored:

- **Axes or spindles: referenced/synchronized**
The position measurement system for the axes or spindles which move a protection area must be referenced or synchronized. If this has not been done the corresponding protection area is in an "inactive" state.
- **External motion**
With traversing motions that are not performed by the NC, e.g. PLC axis or manually moved axis, the current axis position must be known in the NC.

4.1.3 Reaction of the control to a risk of collision

The collision avoidance takes the following parameterizable limit values into account for the collision detection:

- Collision tolerance
- Safety clearance



- ① Protection area 1 (static)
- ② Protection area 2 (can be moved in X and Y direction)
- ③ Current clearance
- ④ Safety clearance
- ⑤ Collision tolerance / 2
- ⑥ Collision clearance = safety clearance + collision tolerance

Figure 4-1 Current clearance, collision tolerance and safety clearance

Collision tolerance and safety clearance

Safety clearance

The safety clearance defines a clearance up to which two active protection areas, monitored for collision, can approach one another. The collision avoidance ensures that this clearance is not violated and that the collision is displayed.

The safety clearance can be set specifically for each collision pair via a system variable (Page 81).

4.1 Function description

For all collision pairs for which no specific safety clearance is set via a system variable, the general value that can be set via MD10622 \$MN_COLLISION_SAFETY_DIST (Page 77) applies.

Collision tolerance

The collision tolerance defines an NC-wide additional clearance valid to the safety clearance. Two active protection areas monitored for collision may therefore approach each other up to the collision clearance (safety clearance + collision tolerance). Ideally, the collision avoidance stops the traversing motion of the protection areas exactly at the collision clearance and displays the collision. However, it is permissible that the collision tolerance is not complied with exactly or that a brief violation does not result in collision detection and the traversing motion is not stopped.

The collision tolerance is set the same for all collision pairs via MD10619 \$MN_COLLISION_TOLERANCE (Page 77).

Note

Difference between collision tolerance and safety clearance

The collision tolerance can be violated and is permissible. The safety clearance is always maintained.

Responses in the AUTOMATIC operating mode

Collision detection during preprocessing

In automatic mode, the traversing blocks of the active program are already checked during the preprocessing. If a collision is already detected there, this results in the following reactions:

- Stop of the traversing motions in the channel
- NC/PLC interface signal: DB21,... .DBX377.0 = 1 (collision avoidance: stop)
- Display of alarm 26260 with the block number of the relevant traversing block
- Cancellation of the program processing

Critical approach

Even in automatic mode, superimposed or asynchronous motions can occur that cannot be considered in advance. For this reason, the traversing velocity is reduced or the traversing motion is totally stopped at a critical approach of protection areas:

- Axes-specific NC/PLC interface signal when the traversing velocity is reduced:
DB31,DBX77.0 == 1 (collision avoidance: velocity reduction)
- Channel-specific NC/PLC interface signal at a stop of the traversing motion:
DB21,DBX377.0 == 1 (collision avoidance: stop)

Preactivated protection areas

If during the block processing in the **preprocessing**, it is determined in a traversing block that two protection areas, of which at least one is only **preactivated**, would collide if they were active, this does not yet produce the same reactions as described above in the "Collision detection during preprocessing". The reactions only occur when both protection areas are active.

If the block at the activation time is already being traversed in the main run, a collision is detected based on the collision calculation during preprocessing and the above reactions triggered. The collision is detected irrespective of whether the protection areas are actually colliding at the activation time.

Responses in the JOG operating mode

If two protection areas approach one another when traversing in the JOG mode, the traversing velocity is continuously braked down to standstill when the collision clearance is reached. Alarm 26280 is output when the collision clearance is reached.

If the collision location is exited in the opposite direction, a continuously higher traversing velocity is possible depending on the clearance of the protection areas.


Traversing motion is always **canceled** when the collision clearance is reached. Continuation of the traversing motion always requires a new travel request (e.g. by pressing a traversing key), irrespective of the traversing direction.

Responses in the MDI operating mode

If two protection areas approach one another when traversing in the MDI mode, the traversing velocity is continuously braked down to standstill when the collision clearance is reached. Alarm 26260 is output when the collision clearance is reached.

4.1 Function description

4.1.4 State diagram: Protection area



SB Protection area

BA Operating mode

① UpdateAllCaSysVar(SB) function

All system variables of the collision avoidance are read into NC-internal variables:

int... = \$N...

- ② UpdateAllCaSysVarExeptInitStat(SB) function
As with the UpdateAllCaSysVar(SB) function, but the \$NP_INIT_STAT system variable is not read in. Internally in the NC, the last value of the intInitStat initialization status is therefore retained.
- ③ CheckIntNckCaSysVarImages(SB) function
The NC-internal variables read in from the system variables are checked for consistency.
Return value when an error is detected: FALSE; if error-free: TRUE.
- ④ UpdateCaSysVarInitStat(SB) function
Only the system variable \$NP_INIT_STAT is read into the NC-internal variable intInitStat.
- ⑤ The internal structure of the "Tool protection area" state is the same as the "Machine protection area" state.
- ⑥ The internal structure of the "JOG mode" state is the same as the "AUTO/MDA mode" state.

4.1.5 Tools

Modeling

Protection areas for tools can be modeled automatically from the collision avoidance and be updated automatically following a tool change with some limitations. The following conditions must be fulfilled for this purpose:

- The protection area for the tool is modeled as an automatic tool protection area (type: TOOL). See system variable \$NP_PROT_TYPE (Page 30)
- The tool is managed by the control tool management.
- The tool data stored in the tool management matches the actual geometric dimensions of the tool.
- The collision avoidance recognizes the completion of the tool change. Normally, by programming the corresponding tool offset number D_x, with x = 0, 1, 2, 3, ...
- The collision avoidance recognizes the automatic tool protection area for which the tool was changed.
- If the tool path refers to a normalized tool, the tool radius of the actual tool is specified as either positive or negative deviations referred to the normalized tool. In this case, collision avoidance calculates with the following values:
 - Positive value: Tool radius = specified value, however, as a minimum, the value of the parameterized collision tolerance
 - Negative value: Tool radius = value of the parameterized collision tolerance

Change to the machine model

If a tool which is located in a magazine or tool adapter modeled in the active machine model of the collision avoidance is changed in the machine then the machine model must be updated. This is the case where one of the following actions is carried out, for example:

- A tool is loaded / unloaded in a tool magazine modeled in the machine model.
Example: Tool change in a revolver (circular) magazine.
Update: The machine model update must be explicitly requested by the user using PROTA once the tool change has completed.
- The tool that is in a tool holder is changed.
Example: Tool change in the tool holder of the main spindle.
Update: The machine model is automatically updated following the tool change (standard: M6) with output of the programmed tool offset number D_x in the main run.

Tool changes

The collision avoidance only updates the active machine model after a tool change without an explicit request by PROTA if a tool offset is selected (output of the programmed tool offset number D_x at the NC/PLC interface).

However, at the control, tool changes can be made, which are not associated with a tool offset selection. However, for these changes the active machine model is not updated. These types of tool changes include, for example:

- Loading/unloading a tool at the user interface.
 SINUMERIK Operate: Operating area "Parameter" > "Tool list" > Vertical softkey: "Loading" or "Unloading"
- Carrying out a tool change via the PLC user program
- Directly writing to the tool buffer memory using the system variable $\$TC_MPP6[9998, \langle \text{location} \rangle]$
- $SETMS(\langle \text{spindle number} \rangle)$: Changing the master spindle in the channel
- $TMMVTL$: PI service "Prepare magazine location for loading, unload tool"
Further information: Function Manual PLC; PI services > PI service: $TMMVTL$
- $MVTOOL$: Command for movement of a tool
Further information: Function Manual Tool Management; NC programming > NC language commands > $MVTOOL$ - Language command for movement of a tool

If such a change is carried out, then the machine manufacturer must be requested to update the machine module via the PLC user program. Examples of options include:

- A new channel reset is requested if the channel is in the "reset" state. When the reset response is appropriately set ($MD20110 \$MC_RESET_MODE_MASK$), then the actual tool offset number D_x is output again.
- Starting an ASUB or manufacturer's cycle, which includes the output of the tool offset number D_x and the request to update the machine model (PROTA).

Tool wear

Minimal tool changes do not have to be taken into account in the machine model, as generally they are far less than the collision clearance.

If a tool change occurs, which is relevant for collision avoidance, e.g. diameter changes for grinding tools, then these must be taken into account by explicitly requesting that the machine model is updated (PROTA).

No change to the machine model

The active machine model does **not** change if a fully modeled machine part with tools, e.g. a tool magazine, is moved in the machine.

Example: Revolver magazine on a lathe

The revolver magazine on a lathe is fully modeled in the machine model of the collision avoidance:

- The geometry of the magazine and the tools located inside it
- The motions of the magazine through the machine axes

A rotation of the revolver magazine then does not represent a change to the machine model:

- since no tools are changed inside the machine model the geometries of all the protection areas remain unchanged.
- As the motions of the protection areas by the machine axes are fully captured by the collision avoidance via the kinematic chain.

Boundary conditions

Several spindles in the channel

For configurations with several spindles in the channel, the collision avoidance function assumes that a tool change takes place in the master spindle of the channel (S1). As a result only the automatic tool protection area of the master spindle is updated through the collision avoidance once the tool change has taken place.

Unsupported tool configurations

Tool configurations in accordance with ISO modes 4 and 5 (H numbers) along with "flat D numbers" are not supported by the collision avoidance.

4.1.6 Boundary conditions

Channel assignment

All of the machine components relevant for collision avoidance must be located in the **first channel** of the NC:

- All **axes** and **spindles** of the kinematic chain.
See Function Manual "Basic Functions", Section "Kinematic chain"
- All **tools** of the automatic tool protection areas of the geometric machine modeling.
See Chapter "Geometric machine modeling (Page 17)"

4.1 Function description

Allowance for the following error

The collision avoidance uses the position setpoints of the relevant machine axes for the clearance calculation of the protection areas. However, the actual positions of the machine axes differ from the position setpoint by the following error. For this reason, there is also a difference between the position setpoint and the actual position for the protection areas. This difference must be taken into account by the user through configuration of a suitably large safety clearance or enlargement of the protection area.

Compensations

The various compensation functions of the NC – for instance, temperature, spindle and pitch error and sag compensation – ensure that positions programmed in the workpiece coordinate system are actually assumed in the machine coordinate system. The collision avoidance takes into account the position corrections made by the compensation functions.



WARNING

Risk of collision

If compensations are used for other purposes, e.g. in order to implement axis couplings in the machine coordinate system, the collision avoidance working with position setpoints can no longer be performed reliably. There is a risk of collision.

Actual value offset in the machine coordinate system with PRESETON

With active collision avoidance and use of an actual value offset in the machine coordinate system with PRESETON, it is the sole responsibility of the user to ensure that the geometric model of the collision avoidance remains consistent.



WARNING

Risk of collision

If an actual value offset is made in the machine coordinate system with PRESETON and the geometric model of the collision avoidance not adapted accordingly, the collision avoidance working with position setpoints can no longer be performed reliably. There is a risk of collision.

Block search

For the following types of block search there are **no** collision calculations carried out:

- Type 1: Block search without calculation
- Type 2: Block search with calculation at contour
- Type 4: Block search with calculation at block end point

With the following type of block search collision calculations are carried out (in the preprocessing) for:

- Type 5: Block search with calculation in "Program test" (SERUPRO) mode

AUTOMATIC modes: Incomplete protection area data for collision

When a large number of protection areas have been configured, in exceptional cases, the following behavior can occur:

- Several protection areas have approached one another, down to the collision tolerance
- Only two protection areas are specified in Alarm 26260 "Collision **two** protection areas" that is displayed.
- The collision of the other protection areas is only displayed when manually traversing the axes after changing into the JOG mode.

Unsupported tool configurations

Collision avoidance does not support multitools. Only the selected tool of the multitool is monitored.

4.2 Commissioning

4.2.1 General

4.2.1.1 Overview

The commissioning of the "Collision avoidance" function is performed using:

- Machine data
 - Specification of the quantity structure
 - Specification of general properties of the collision pairs
- System variables
 - Parameterization of the collision pairs and their properties

4.2.1.2 Structure of the system variables

The system variables are structured according to the following scheme:

\$NP_<name>[<index_1>,<index_2>]

Note

Index_2 is not available for all system variables.

General

The system variables to describe the protection areas have the following properties:

- Prefix: **\$NP_**, (N for NC, P for protection).
- They can be read and written via NC programs.
- They can be stored in archives and loaded to the NC again.

Data type

STRING

All system variables of the STRING data type have the following properties:

- Maximum string length: 31 characters
- No distinction is made between upper and lower case
Example: "Axis1" is identical to "AXIS1"
- Spaces and special characters are permitted
Example: "Axis1" is not identical to "Axis 1"
- Names that **start** with **two** underscores "__" are reserved for system purposes and must **not** be used for user-defined names.

Note

Leading space

Since spaces are valid and distinct characters, names that **start** with a **space** followed by **two** underscores "__" can, in principle, be used for user-defined names. However, because they can be easily mistaken for system names, this procedure is **not** recommended.

Index_1

The individual protection areas are addressed via index_1. Index 0 → 1st protection area, index 1 → 2nd protection area, ... n → (n+1) protection area, where n = (\$MN_MM_MAXNUM_3D_PROT_AREAS - 1)

All system variables of a protection area have the same index.

Index_2

For system variables that define a collision pair, the protection areas of the collision pair are addressed via index_2.

- 0 → 1. Protection area
- 1 → 2. Protection area

4.2.2 Machine data

4.2.2.1 Collision tolerance

The collision tolerance (accuracy of the collision check) for all protection areas of the NC monitored for collision is set with the machine data. If the clearance of two safety areas is less than the collision clearance, i.e. the sum of safety clearance (Page 77) and collision tolerance, then there is a collision.

MD10619 \$MN_COLLISION_TOLERANCE = <collision tolerance>

Accuracy of automatic generated protection areas

The collision tolerance also determines the accuracy of the protection area bodies of protection areas produced automatically, e.g. automatic tool protection areas. The accuracy of the protection area bodies approached using triangle areas is 1/3 of the collision tolerance.

Effects

The smaller the collision tolerance is set, the greater the number of triangular areas required for the modelling of the automatically generated protection areas and the computation time required for the collision detection.

Recommended setting

Collision tolerance $\approx$ 1 mm

See also

Reaction of the control to a risk of collision (Page 67)

4.2.2.2 Safety clearance

The safety clearance for all protection areas of the NC monitored for collision is set with the machine data. The collision avoidance ensures that the safety clearance is not violated.

MD10622 \$MN_COLLISION_SAFETY_DIST = <safety clearance>

Note

Collision pair-specific safety clearance

If a specific safety clearance has been set for a collision pair via the system variable \$NP_SAFETY_DIST (Page 81), this has priority over the NC-specific safety clearance set in the machine data.

See also

Reaction of the control to a risk of collision (Page 67)

4.2 Commissioning

4.2.2.3 Maximum memory space

The maximum value of the memory space in KB that can be allocated to the collision avoidance is set with the machine data.

MD18896 \$MN_MM_MAXNUM_3D_COLLISION = <value>

Value	Meaning
0	The maximum value of the memory space is determined automatically by the control using the following machine data: - MD18890 \$MN_MM_MAXNUM_3D_PROT_AREAS - MD18892 \$MN_MM_MAXNUM_3D_PROT_AREA_ELEM - MD18894 \$MN_MM_MAXNUM_3D_FACETS_INTERN - MD18895 \$MN_MM_MAXNUM_3D_FACETS
> 0	Maximum value = parameterized value [KB]

Note

Only one > 0 value must be entered in the machine data when one of the following alarms is displayed:

- Alarm 26262 "Insufficient memory space for the collision check of two protection areas"
- Alarm 26263 "Insufficient memory space for determining the clearance of two protection areas"

Used memory space

Various system variables are available to determine the memory space used by the collision avoidance. See section "Memory requirement (Page 83)".

4.2.2.4 Maximum number of collision pairs

The maximum number of possible collision pairs has an impact on:

- Length m of the system variable fields (e.g. \$NP_COLL_PAIR[m, ...])
- The user memory required for collision avoidance
- The size of the commissioning archive

The maximum number of collision pairs can be restricted with machine data:

MD18898 \$MN_MM_MAXNUM_3D_COLL_PAIRS = <value>

<Value>	Meaning
0	The following applies to the maximum number of possible collision pairs MCP: MCP = maximum value of the machine data
x > 0	The following applies to the maximum number of possible collision pairs MCP: MCP = x, with $0 < x \leq$ maximum value of the machine data
A value greater than the maximum permissible value of the machine data is limited internally to the maximum value. No feedback regarding this is sent to the user.	

4.2.2.5 Protection levels for collision avoidance On/Off

The protection level for switching the collision avoidance On/Off is set with the machine data via the user interface. The protection level can be specified according to operating mode and protection area type.

Machine data = <protection level>

Number	Identifier: \$MN_	Meaning: Protection level for switching the collision avoidance On/Off
MD51160	ACCESS_WRITE_CA_MACH_JOG	Machine protection areas, JOG/MDI operating mode
MD51161	ACCESS_WRITE_CA_MACH_AUTO	Machine protection areas, AUTOMATIC mode,
MD51162	ACCESS_WRITE_CA_TOOL	Tool protection areas

Further information

A detailed description of protection levels can be found in:

Function Manual Basic Functions; Various NC/PLC interface signals and functions > Functions > Access protection via password and keyswitch

4.2.3 System variables

4.2.3.1 Overview

A collision pair is parameterized with the following system variables:

Name	Meaning
\$NP_COLL_PAIR	Name of a collision pair protection area
\$NP_SAFETY_DIST	Safety clearance of the protection area pair

The system variables are described in detail in the following sections.

Note

Establish a defined initial state

It is recommended that a defined initial state be generated before parameterizing the collision avoidance. To do this, set the system variables of the collision avoidance to their default values with the DELOBJ() function.

Change system variable values

If the value of one of the system variables listed above is changed, the change becomes immediately visible at the user interface, e.g. SINUMERIK Operate. The machine model of the NC is only updated after explicitly requesting that the machine model is recalculated by calling the PROTA() (Page 86) or PROTS() (Page 87) function.

4.2.3.2 \$NP_COLL_PAIR

Function

The names of the two protection areas, which form a collision pair, is entered in a system variable. The two protection areas can be in any sequence.

Collision pairs

As the collision check requires a lot of computation time, it does not make sense to monitor all parameterized protection areas for collision with one another through the collision avoidance. Examples in which a collision check does not make sense:

- Protection areas that cannot collide because of the construction
- Protection areas that have been defined without anchoring to the kinematic chain

The user must define which parameterized protection areas can actually collide on the machine and define them as collision pairs. Only these protection areas are monitored by the collision avoidance.

To define a collision pair, the names of the two protection areas must be entered in two system variables with the same collision pair index. One protection area under the protection area index 0, the other under the protection area index 1.

Part of a collision pair

Using the COLLPAIR() (Page 85) function, a check can be made as to whether two protection areas are parameterized as collision pair.

Syntax

```
$NP_COLL_PAIR[<m>,<i>] = "<name>"
```

Meaning

\$NP_COLL_PAIR:	Name of the first or second protection area of a collision pair	
	Data type:	STRING
	Default value:	"" (empty string)
<m>:	System variable or collision pair index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (M - 1) ¹⁾
<i>:	Protection area index	
	Data type:	INT
	Range of values:	0 (first protection area), 1 (second protection area)
<name>:	Protection area name	
	Data type:	STRING
¹⁾ $M = n * (n - 1) / 2$ where $n = \$MN_MM_MAXNUM_3D_PROT_AREAS$		

Example

Two protection areas defined with the names "Rotary table" and "Tool in spindle" are to be checked for collision. The two protection areas are to be mutually monitored for collision. The definition for this is in the seventh collision pair:

Program code	Comment
N100 \$NP_COLL_PAIR[6,0] = "Rotary table"	; 7th collision pair, ; 1st Protection area
N110 \$NP_COLL_PAIR[6,1] = "Tool in spindle"	; 7th collision pair, ; 2nd Protection area

Supplementary conditions

- When forming a collision pair, it should be observed that every protection area of this pair has at least one protection area element that is marked with \$NP_USAGE (Page 45) = "C" or "A". Otherwise, with the protection area, it is not permissible to perform a collision or clearance calculation (Page 88).
- The protection areas of a collision pair are only checked for collision when both protection areas are in the "Protection area monitored" state. See Chapter "State diagram: Protection area (Page 70)".

4.2.3.3 \$NP_SAFETY_DIST

Function

The collision pair-specific safety clearance is entered in the system variable. The collision avoidance ensures that this safety clearance is not violated.

If a value not equal to 0.0 is entered in the system variable, the general safety clearance from MD10622 \$MN_COLLISION_SAFETY_DIST (Page 77) is not taken into account for this collision pair.

If the value 0.0 is entered in the system variable, the safety clearance set in the machine data applies.

Syntax

```
$NP_SAFETY_DIST[<m>] = <value>
```

Meaning

\$NP_SAFETY_DIST:	Safety clearance of the collision pair	
	Data type:	REAL
	Default value:	0.0

4.2 Commissioning

<m>:	System variable or protection area index	
	Data type:	INT
	Range of values:	0, 1, 2, ... (M - 1) ¹⁾
<value>:	Safety clearance	
	Data type:	REAL
	Range of values:	$0.0 \leq x \leq +\text{max. REAL value}$
	Unit:	mm or inch depending on the current dimensions setting
1) $M = n * (n - 1) / 2$ where n = \$MN_MM_MAXNUM_3D_PROT_AREAS		

Example

The safety clearance for the protection areas of the seventh collision pair should be 1.0 mm (input system: metric).

Program code	Comment
N100 \$NP_SAFETY_DIST[6] = 1.0	; 7. collision pair, ; safety clearance = 1.0

See also

Reaction of the control to a risk of collision (Page 67)

4.2.4 Extend system variables

4.2.4.1 Overview

Further information on the internal states and values of the collision avoidance can be read via the following system variables:

- State data (Page 83)
- Memory requirement (Page 83)
- Braking distance estimations (Page 84)

4.2.4.2 State data

The state data of the collision avoidance can be read via the following system variables (OPI variables)

System variable	OPI variable	Meaning
\$AN_COLL_STATE[<m>]	anCollState[<m>]	Current state of a protection area (active/inactive) with regard to the collision avoidance
\$AN_COLL_STATE_COND[<m>]	anCollStateCond[<m>]	Monitoring state (bit-coded) of a protection area
\$AN_COLL_IPO_ACTIVE	anCollIpoActive	Activation state of the collision avoidance in the main run (active/inactive)
\$AN_COLL_IPO_LIMIT	anCollIpoLimit	Velocity reduction through collision avoidance in the main run (active/inactive)
\$AN_COLL_LOAD[<i>] ¹⁾	anCollLoad[<i>] ¹⁾	Computation time requirement for the collision avoidance function <i>
\$AN_ACTIVATE_COLL_CHECK[<j>]	anActivateColl-Check[<j>]	Current state of the NC/PLC interface with index <j> for each 8 bytes: DB10, DBX234.0 - DBX.241.7 (activate protection areas)
\$AN_COLL_CHECK_OFF	anCollCheckOff	Current state of the NC/PLC interface: DB10 DBX58.0 - 7 (disable protection area group)
\$AA_COLLPOS[<a>]	aaCollPos	Position of axis <a> in the machine coordinate system (MCS) when the last collision alarm occurred
\$AC_COLLPOS[<k>]	acCollPos	Vector <k> for the collision position in the world coordinate system when the last collision alarm occurred
a: Axis name i: 0 = function 1, 1 = function 2, 2 = function 3, ... j: Index 0, 1, 2, ... for one bit field each of 8 bytes. k: Coordinate index k = 1, 2, 3 for X, Y, Z coordinates m: System variable or protection area index 0, 1, 2, ... (MD18890 \$MN_MM_MAXNUM_3D_PROT_AREAS - 1)		
1) The system variable can be reset by writing the value 0. Every other value is rejected with an error message.		

Further information

- For a detailed description of the system variables, refer to:
List Manual, System Variables
- A detailed description of the interface signals can be found in:
Function Manual PLC

4.2.4.3 Memory requirement

The data for the memory requirement of the collision avoidance can be read via the following system variables (OPI variables):

System variable	OPI variable	Meaning
\$AN_COLL_MEM_AVAILABLE	anCollMemAvailable	Size of the memory space in KB reserved for the collision avoidance.
\$AN_COLL_MEM_USE_MIN ¹⁾	anCollMemUseMin ¹⁾	Minimum value of the memory space used for the collision avoidance as a percentage of the reserved memory.

4.2 Commissioning

System variable	OPI variable	Meaning
\$AN_COLL_MEM_USE_MAX ¹⁾	anCollMemUseMax ¹⁾	Maximum value of the memory space used for the collision avoidance as a percentage of the reserved memory
\$AN_COLL_MEM_USE_ACT ¹⁾	anCollMemUseAct ¹⁾	Actual value of the memory space used for the collision avoidance as a percentage of the reserved memory.
1) The system variable can be reset by writing the value 0. Every other value is rejected with an error message.		

Further information

For a detailed description of the system variables, refer to:

List Manual, System Variables

4.2.4.4 Braking distance estimations

The estimated total braking distance (linear approximation) and the proportional braking distances of superimposed motions for an axis can be read via the following system variables (OPI variables). The estimation only takes the current state of the axis into account. It returns, e.g. the braking distance 0.0 for an axis that is just at the reversal point as part of a circular path.

Note

The system variables are used for support in the development of user-specific functions as part of the collision avoidance, and similar functions.

Table 4-1 Basic coordinate system (BCS)

System variable	OPI variable	Meaning
Total braking distance		
\$AA_DTBREB[<a>]	aaDtbreb	Estimated, linearly approximated total braking distance
Proportional braking distances for superimposed motions		
\$AA_DTBREB_CMD[<a>]	aaDtbrebCmd	Command component
\$AA_DTBREB_CORR[<a>]	aaDtbrebCorr	Correction component
\$AA_DTBREB_DEP[<a>]	aaDtbrebDep	Coupling component
<a>: Axis name		

Table 4-2 Machine coordinate system (MCS)

System variable	OPI variable	Meaning
Total braking distance		
\$AA_DTBREM[<a>]	aaDtbrem	Estimated, linearly approximated total braking distance
Proportional braking distances for superimposed motions		
\$AA_DTBREM_CMD[<a>]	aaDtbremCmd	Command component
\$AA_DTBREM_CORR[<a>]	aaDtbremCorr	Correction component

System variable	OPI variable	Meaning
\$AA_DTBREM_DEP[<a>]	aaDtbremDep	Coupling component
<a>: Axis name		

Further information

For a detailed description of the system variables, refer to:

List Manual, System Variables

4.3 Programming

4.3.1 Check for collision pair (COLLPAIR)

The `COLLPAIR()` function determines whether two protection areas form a collision pair.

Syntax

```
[<RetVal> =] COLLPAIR(<Name_1>,<Name_2>[,<NoAlarm>])
```

Meaning

COLLPAIR:	Check whether part of a collision pair		
<RetVal>:	Function return value		
	Data type:	INT	
	Value:	≥ 0	The two protection zones form a collision pair. Return value == collision pair index m (see \$NP_COLL_PAIR (Page 80))
		-1	Either two strings have not been specified or at least one of the two is the zero string.
		-2	The protection zone specified in the first parameter has not been found.
		-3	The protection zone specified in the second parameter has not been found.
		-4	Neither of the two specified protection zones has been found.
		-5	Both specified protection zones have been found, but not together in a collision pair.
<Name_1>:	Name of the first protection zone		
	Data type:	STRING	
	Range of values:	Parameterized protection zone names	

4.3 Programming

<Name_2>:	Name of the second protection area		
	Data type:	STRING	
	Range of values:	Parameterized protection zone names	
<NoAlarm>:	Alarm suppression (optional)		
	Data type:	BOOL	
	Value:	FALSE (Default)	In the event of an error (<RetVal> < 0), the program processing is stopped and an alarm displayed.
		TRUE	In the event of an error, the program processing is not stopped and no alarm displayed. Application: User-specific reaction corresponding to the return value

See also

State diagram: Protection area (Page 70)

4.3.2 Request recalculation of the machine model of the collision avoidance (PROTA)

If system variables of the kinematic chain \$NK_..., the geometric machine modeling or the collision avoidance \$NP_... are written in the part program, the PROTA procedure must subsequently be called so that the change becomes effective in the NC-internal machine model of the collision avoidance.

Syntax

```
PROTA [ (<Par>) ]
```

Meaning

PROTA:	Request recalculation of the machine model of the collision avoidance		
	- Triggers a preprocessing stop. - Must be alone in the block.		
<Par>:	Parameter (optional)		
	Data type:	STRING	
	Value:	---	No parameters. The machine model is recalculated. The states of the protection areas are retained.
		"R"	The machine model is recalculated. The protection areas are set to their initialization status corresponding to \$NP_INIT_STAT (Page 36).

Supplementary conditions

Simulation

The `PROTA` procedure must not be used in part programs in conjunction with the simulation (`simNC`).

Example: Avoiding the `PROTA` call while the simulation is active.

Program code	Comment
...	
IF \$P_SIM == FALSE	; IF simulation not active
PROTA	THEN recalculate collision model
ENDIF	; ENDIF
...	

See also

Setting the protection zone status (`PROTS`) (Page 87)

4.3.3 Setting the protection zone status (`PROTS`)

The `PROTS ( )` procedure sets the state of protection areas to the specified value.

Syntax

`PROTS (<State>[, <Name_1>, ..., <Name_n>])`

Meaning

<code>PROTS:</code>	Sets the state of protection areas		
	Must be alone in the block.		
<code><State>:</code>	Status to which the specified protection zones are to be set		
	Data type:	CHAR	
	Value:	"A" or "a"	Status: Active
		"I" or "i"	Status: Inactive
		"P" or "p"	Status: Preactivated or PLC-controlled ¹⁾
		"R" or "r"	Status: NC-internal value of the initialization status ²⁾

4.3 Programming

<Name_1> ... <Name_n>:	Name of one or more protection areas that are to be set to the specified status (optional)	
	If no name is specified, the specified status is set for all defined protection zones.	
	Data type:	STRING
	Range of values:	Parameterized protection zone names
	Note The maximum number of protection areas that can be specified as parameters depends only on the maximum possible number of characters per program line.	
1) The activation/deactivation is performed via: DB10.DBX234.0 - DBX241.7		
2) The status is set to the NC-internal value of the initialization status, i.e. to the value that the system variable \$NP_INIT_STAT (Page 36) had at the time of the last PROTA() (Page 86) call.		

4.3.4 Determining the clearance of two protection zones (PROTD)

The `PROTD()` function calculates the clearance of two protection areas.

Function properties:

- The clearance calculation is performed independent of the protection area status (activated, deactivated, preactivated).
- To calculate the clearance of two protection areas, only protection area elements are used, which are marked with \$NP_USAGE (Page 45) = "C" or "A". Protection area elements of the protection area, which are marked with \$NP_USAGE = "V", are not taken into consideration.
- Protection areas, where all protection area elements of the protection area are marked with \$NP_USAGE = "V", cannot be used for the clearance calculation.
- The clearance calculation is performed with the positions valid at the end of the previous block.
- Overlays that are included in the main run calculation (e.g. DRF offset or external zero offset) are included in the clearance calculation with the values valid at the function **interpretation time**.

Note**Synchronization**

When using the `PROTD()` function, it is the sole responsibility of the user to synchronize the main run and preprocessing, if required, with the `STOPRE` preprocessing stop.

Collision

If there is a collision between the specified protection areas, the function returns a clearance of 0.0. There is a collision if both the protection areas touch or intersect each other.

The safety clearance for the collision check (MD10622 \$MN_COLLISION_SAFETY_DIST) is not taken into account in the clearance calculation.

Syntax

```
[<RetVal> =] PROTD([<Name_1>],[<Name_2>],VAR <Vector>[,<System>])
```

Meaning

PROTD:	Calculates the clearance of the two specified protection areas.		
	Must be alone in the block.		
<RetVal>:	Function return value: Absolute clearance value of the two protection areas or 0.0 with collision (see above: Collision paragraph)		
	Data type:	REAL	
	Range of values:	0.0 ≤ x ≤ +max. REAL value	
<Name_1>, <Name_2>:	Names of the two protection areas whose clearance is to be calculated (optional)		
	Data type:	STRING	
	Range of values:	Parameterized protection area names	
	Default value:	"" (empty string) If no protection areas have been specified, the function calculates the current smallest clearance from all the activated and preactivated protection areas in the collision model.	
<Vector>:	Return value: 3-dimensional clearance vector from protection area <Name_2> to protection area <Name_1> with: <Vector>[0]: X coordinate in the world coordinate system <Vector>[1]: Y coordinate in the world coordinate system <Vector>[2]: Z coordinate in the world coordinate system For collision: <Vector> == zero vector		
	Data type:	VAR REAL [3]	
	Range of values:	<Vector> [n]: 0.0 ≤ x ≤ ±max. REAL value	
<System>:	Measuring system (inch/metric) for clearance and clearance vector (optional)		
	Data type:	BOOL	
	Value:	FALSE (Default)	Measuring system corresponding to the currently active G command from G group 13 (G70, G71, G700, G710).
		TRUE	Measuring system corresponding to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM

4.4 Example

4.4.1 Specifications

General Information

The basic procedure when parameterizing collision avoidance using a part program is shown using a simplified 3-axis milling machine as example. All of the system variables relevant for collision avoidance are written to the part program:

- Kinematic chain \$NK_...
- Geometric machine modeling \$NP_...
- Collision avoidance \$NP_...

The machine model is subsequently activated in the part program, so that after executing the part program, the collision avoidance has been completely parameterized in the 3-axis milling machine and is active.

Option and machine data


The following option and machine data must be set for the example:

No.	Option data: \$ON_	Value
MD19830	COLLISION_MASK	1

No.	Machine data: \$MN_	Value
MD10619	COLLISION_TOLERANCE	1
MD18880	MM_MAXNUM_KIN_CHAIN_ELEM	10
MD18890	MM_MAXNUM_3D_PROT_AREAS	10
MD18892	MM_MAXNUM_3D_PROT_AREA_ELEM	10
MD18893	MM_MAXNUM_3D_T_PROT_ELEM	1
MD18894	MM_MAXNUM_3D_FACETS_INTERN	1000
MD18895	MM_MAXNUM_3D_FACETS	3000
MD18896	MM_MAXNUM_3D_COLLISION	0
MD18897	MM_MAXNUM_3D_INTERFACE_IN	16
MD18899	PROT_AREA_TOOL_MASK	1

Principle design of the 3-axis milling machine

The principle machine design is shown in the following diagram.



- ① Z axis
- ② Stand
- ③ Table
- ④ Machine zero = reference point
- ⑤ Tool
- ⑥ Tool holder


The machine parts and/or protection areas are assigned to the following machine axes.

Machine parts and/or protection areas	Machine axis
Table	X1, Y1
Z axis	Z1
Column	---
Tool holder	Z1
Tool	Z1

4.4 Example

Dimension drawing

The dimensions of the protection area elements as well as their position (vectors to the center point of the protection area element) referred to the machine zero point are specified in the following dimension drawing.



4.4 Example

Vectors to the center point of the protection area elements

V_{tool}	Tool adapter (0;0;25)
V_{ZA}	Z axis (0;200;130)
V_{S}	Column (0;570;350)
V_{T}	Table (0;0;-50)


Kinematic chain

The kinematic chain (see next diagram) starts with an "Offset" type element. These are assigned to all static protection areas of the machine. In the example, this is only the "Column" protection area.

The kinematic elements of the machine axes follow the offset element:

- Z axis and X axis traverse independently of one another $\Rightarrow$ \$NK_PARALLEL
- The Y axis traverses dependent on the X axis $\Rightarrow$ \$NK_NEXT

The various protection areas of the geometric machine modeling are assigned the kinematic elements of the machine axes



Collision pairs

For the example, it is assumed that only the following collision pairs are to be taken into account:

- Tool adapter - table
- Tool - table

4.4 Example

4.4.2 Part program of the machine model

Program code

```

;*****
;***** Example *****
; milling machine: 3 linear axes, 1 spindle
;   table   => X1, Y1
;   Z axis, tool adapter, tool => Z1
;*****
; status: February 11, 2013, 15:34
;
;=====
; Collision machine data used
;=====
; MD10619 $MN_COLLISION_TOLERANCE = 1
;
; MD18880 $MN_MM_MAXNUM_KIN_CHAIN_ELEM   = 100
; MD18890 $MN_MM_MAXNUM_3D_PROT_AREAS    = 10
; MD18892 $MN_MM_MAXNUM_3D_PROT_AREA_ELEM = 10
; MD18893 $MN_MM_MAXNUM_3D_T_PROT_ELEM   = 100
; MD18894 $MN_MM_MAXNUM_3D_FACETS_INTERN = 1000
; MD18895 $MN_MM_MAXNUM_3D_FACETS        = 3000
; MD18896 $MN_MM_MAXNUM_3D_COLLISION     = 0
; MD18897 $MN_MM_MAXNUM_3D_INTERFACE_IN  = 16
; MD18899 $MN_PROT_AREA_TOOL_MASK        = 1
;
; MD19830 $ON_COLLISION_MASK = 1   ; option
;
;
;=====
; Definitions
;=====
DEF INT RETVAL = 0      ; return value of the delete function
;
DEF INT C_NKE = 0       ; index for kinematic elements
DEF INT C_NPC = 0       ; index for protection areas
DEF INT C_NPE = 0       ; index for protection area elements
DEF INT C_NPP = 0       ; index for collision pairs
;
;

```

Program code

```

;=====
; initialization of the collision data
;=====
MSG("protection areas")
G4 F3
; reset all parameters to their initial setting
;
RETVAl = DELOBJ("KIN_CHAIN_ELEM")
IF (RETVAl <> 0)
    MSG("error: DELOBJ KIN_CHAIN_ELEM")
    G4 F5
ENDIF
;
RETVAl = DELOBJ("PROT_AREA_ALL")
IF RETVAl <> 0
    MSG("error: DELOBJ PROT_AREA_ALL")
    G4 F5
ENDIF
;
RETVAl = DELOBJ("PROT_AREA_COLL_PAIRS")
IF RETVAl <> 0
    MSG("error: DELOBJ PROT_AREA_COLL_PAIRS")
    G4 F5
ENDIF
;
;
;=====
; kinematic chain
;=====
; KE1: ROOT
; -----
$NK_NAME[C_NKE]      = "ROOT"
$NK_NEXT[C_NKE]      = "X axis"
$NK_PARALLEL[C_NKE]  = ""
$NK_TYPE[C_NKE]      = "OFFSET"
;
$NK_OFF_DIR[C_NKE, 0] = 0.0      ; X
$NK_OFF_DIR[C_NKE, 1] = 0.0      ; Y
$NK_OFF_DIR[C_NKE, 2] = 0.0      ; Z
;
$NK_AXIS[C_NKE]      = ""
$NK_A_OFF[C_NKE]      = 0.0
;
C_NKE = C_NKE + 1          ; next kinematic element
;

```

4.4 Example

Program code

```

; -----
; kinematic element: X axis
; -----
$NK_NAME[C_NKE]      = "X axis"
$NK_NEXT[C_NKE]      = "Y axis"
$NK_PARALLEL[C_NKE]  = "Z axis"
$NK_TYPE[C_NKE]      = "AXIS_LIN"
;
$NK_OFF_DIR[C_NKE, 0] = 1.0      ; X
$NK_OFF_DIR[C_NKE, 1] = 0.0      ; Y
$NK_OFF_DIR[C_NKE, 2] = 0.0      ; Z
;
$NK_AXIS[C_NKE]       = "X1"
$NK_A_OFF[C_NKE]      = 0.0
;
C_NKE = C_NKE + 1      ; next kinematic element
;
; -----
; kinematic element: Y axis
; -----
$NK_NAME[C_NKE]      = "Y axis"
$NK_NEXT[C_NKE]      = ""
$NK_PARALLEL[C_NKE]  = ""
$NK_TYPE[C_NKE]      = "AXIS_LIN"
;
$NK_OFF_DIR[C_NKE, 0] = 0.0      ; X
$NK_OFF_DIR[C_NKE, 1] = 1.0      ; Y
$NK_OFF_DIR[C_NKE, 2] = 0.0      ; Z
;
$NK_AXIS[C_NKE]       = "Y1"
$NK_A_OFF[C_NKE]      = 0.0
;
C_NKE = C_NKE + 1      ; next kinematic element
;
; -----
; kinematic element: Z axis
; -----
$NK_NAME[C_NKE]      = "Z axis"
$NK_NEXT[C_NKE]      = ""
$NK_PARALLEL[C_NKE]  = ""
$NK_TYPE[C_NKE]      = "AXIS_LIN"
;
$NK_OFF_DIR[C_NKE, 0] = 0.0      ; X
$NK_OFF_DIR[C_NKE, 1] = 0.0      ; Y
$NK_OFF_DIR[C_NKE, 2] = 1.0      ; Z
;
$NK_AXIS[C_NKE]       = "Z1"
$NK_A_OFF[C_NKE]      = 0.0
;
C_NKE = C_NKE + 1      ; next kinematic element
;
;

```

Program code

```

;=====
; protection areas with protection area elements
;=====
; protection area 1: Column
; -----
$NP_PROT_NAME[C_NPC] = "Column"
$NP_PROT_TYPE[C_NPC] = "MACHINE"
$NP_CHAIN_ELEM[C_NPC] = "ROOT"
$NP_1ST_PROT[C_NPC] = "SBE column"
$NP_PROT_COLOR[C_NPC] = 'HFFA0A0A4' ; AARRGGBB
$NP_BIT_NO[C_NPC] = -1
$NP_INIT_STAT[C_NPC] = "A"
;
C_NPC = C_NPC + 1 ; next protection area
;
; -----
; protection area element 1.1: SBE column
; -----
$NP_NAME[C_NPE] = "SBE column"
$NP_NEXT[C_NPE] = ""
$NP_NEXTP[C_NPE] = ""
$NP_TYPE[C_NPE] = "BOX"
;
$NP_PARA[C_NPE,0] = 160.0 ; cube dimensions
                        ; length
$NP_PARA[C_NPE,1] = 140.0 ; width
$NP_PARA[C_NPE,2] = 800.0 ; height
;
$NP_OFF[C_NPE,0] = 0.0 ; center point
                        ; X
$NP_OFF[C_NPE,1] = 570.0 ; Y: xxx rear table edge
$NP_OFF[C_NPE,2] = 350.0 ; Z: Lower edge equal to lower edge table
;
$NP_DIR[C_NPE,0] = 0.0
$NP_DIR[C_NPE,1] = 0.0
$NP_DIR[C_NPE,2] = 0.0
;
$NP_ANG[C_NPE] = 0.0
;
$NP_COLOR[C_NPE] = 0
$NP_D_LEVEL[C_NPE] = 0
$NP_USAGE[C_NPE] = "V" ; V = visualize only
$NP_FILENAME[C_NPE] = ""
;
C_NPE = C_NPE + 1 ; next protection area element
;

```

4.4 Example

Program code

```

;+++++
; protection area 2: Tool adapter
; -----
$NP_PROT_NAME[C_NPC] = "Tool adapter"
$NP_PROT_TYPE[C_NPC] = "MACHINE"
$NP_CHAIN_ELEM[C_NPC] = "Z axis"
$NP_1ST_PROT[C_NPC] = "SBE tool adapter"
$NP_PROT_COLOR[C_NPC] = 'HFF0000FF' ; AARRGGBB
$NP_BIT_NO[C_NPC] = -1
$NP_INIT_STAT[C_NPC] = "A"
;
C_NPC = C_NPC + 1 ; next protection area
;
; -----
; protection area element 2.1: SBE tool adapter
; -----
$NP_NAME[C_NPE] = "SBE tool adapter"
$NP_NEXT[C_NPE] = ""
$NP_NEXTP[C_NPE] = ""
$NP_TYPE[C_NPE] = "CYLINDER"
;
; cylinder dimensions
$NP_PARA[C_NPE,0] = 50.0 ; height
$NP_PARA[C_NPE,1] = 60.0 ; radius
$NP_PARA[C_NPE,2] = 0.0
;
; center point
$NP_OFF[C_NPE,0] = 0.0 ; X
$NP_OFF[C_NPE,1] = 0.0 ; Y
$NP_OFF[C_NPE,2] = 25.0 ; Z: Half height
;
$NP_DIR[C_NPE,0] = 0.0
$NP_DIR[C_NPE,1] = 0.0
$NP_DIR[C_NPE,2] = 0.0
;
$NP_ANG[C_NPE] = 0.0
;
$NP_COLOR[C_NPE] = 0
$NP_D_LEVEL[C_NPE] = 0
$NP_USAGE[C_NPE] = "A"
$NP_FILENAME[C_NPE] = ""
;
C_NPE = C_NPE + 1 ; next protection area element
;

```

Program code

```

; ++++++
; protection area 3: Tool
; -----
$NP_PROT_NAME[C_NPC] = "Tool"
$NP_PROT_TYPE[C_NPC] = "TOOL"
$NP_CHAIN_ELEM[C_NPC] = "Z axis"
$NP_1ST_PROT[C_NPC] = ""
$NP_PROT_COLOR[C_NPC] = 'HFFFF0000' ; AARRGGBB
$NP_BIT_NO[C_NPC] = -1
$NP_INIT_STAT[C_NPC] = "A"
;
$NP_INDEX[C_NPC,0] = 1 ; only relevant for type "TOOL"
$NP_INDEX[C_NPC,1] = 9998 ; tool location No. / spindle No.
$NP_INDEX[C_NPC,2] = 1 ; magazine No. / -
;
C_NPC = C_NPC + 1 ; TOA area
;
; next protection area
;

```

4.4 Example

Program code

```

; ++++++
; protection area 4: Z axis
; -----
$NP_PROT_NAME[C_NPC] = "Z axis"
$NP_PROT_TYPE[C_NPC] = "MACHINE"
$NP_CHAIN_ELEM[C_NPC] = "Z axis"
$NP_1ST_PROT[C_NPC] = "SBE Z axis"
$NP_PROT_COLOR[C_NPC] = 'HFFA0A0A4' ; AARRGGBB
$NP_BIT_NO[C_NPC] = -1
$NP_INIT_STAT[C_NPC] = "A"
;
C_NPC = C_NPC + 1 ; next protection area
;
; -----
; protection area element 4.1: SBE horizontal column
; -----
$NP_NAME[C_NPE] = "SBE Z axis"
$NP_NEXT[C_NPE] = ""
$NP_NEXTP[C_NPE] = ""

$NP_TYPE[C_NPE] = "BOX"
;
$NP_PARA[C_NPE,0] = 160.0
$NP_PARA[C_NPE,1] = 600.0
$NP_PARA[C_NPE,2] = 160.0
;
$NP_OFF[C_NPE,0] = 0.0
$NP_OFF[C_NPE,1] = 200.0
$NP_OFF[C_NPE,2] = 130.0
;
$NP_DIR[C_NPE,0] = 0.0
$NP_DIR[C_NPE,1] = 0.0
$NP_DIR[C_NPE,2] = 0.0
;
$NP_ANG[C_NPE] = 0.0
;
$NP_COLOR[C_NPE] = 0
$NP_D_LEVEL[C_NPE] = 0
$NP_USAGE[C_NPE] = "A"
$NP_FILENAME[C_NPE] = ""
;
C_NPE = C_NPE + 1 ; next protection area element
;

```

Program code

```

; ++++++
; protection area 5: Table
; -----
$NP_PROT_NAME[C_NPC] = "Table"
$NP_PROT_TYPE[C_NPC] = "MACHINE"
$NP_CHAIN_ELEM[C_NPC] = "Y axis"
$NP_1ST_PROT[C_NPC] = "SBE table"
$NP_PROT_COLOR[C_NPC] = 'HFF00FF00' ; AARRGGBB
$NP_BIT_NO[C_NPC] = -1
$NP_INIT_STAT[C_NPC] = "A"
;
C_NPC = C_NPC + 1 ; next protection area
;
; -----
; protection area element 5.1: SBE table
; -----
$NP_NAME[C_NPE] = "SBE table"
$NP_NEXT[C_NPE] = ""
$NP_NEXTP[C_NPE] = ""
$NP_TYPE[C_NPE] = "BOX"
;
$NP_PARA[C_NPE,0] = 1000.0
$NP_PARA[C_NPE,1] = 500.0
$NP_PARA[C_NPE,2] = 100.0
;
$NP_OFF[C_NPE,0] = 0.0
$NP_OFF[C_NPE,1] = 0.0
$NP_OFF[C_NPE,2] = -50.0
;
$NP_DIR[C_NPE,0] = 0.0
$NP_DIR[C_NPE,1] = 0.0
$NP_DIR[C_NPE,2] = 0.0
;
$NP_ANG[C_NPE] = 0.0
;
$NP_COLOR[C_NPE] = 0
$NP_D_LEVEL[C_NPE] = 0
$NP_USAGE[C_NPE] = "A"
$NP_FILENAME[C_NPE] = ""
;
C_NPE = C_NPE + 1 ; next protection area element
;
;

```

4.5 Data lists

Program code

```

;=====
; collision pairs
;=====
$NP_COLL_PAIR[C_NPP, 0] = "Tool adapter"
$NP_COLL_PAIR[C_NPP, 1] = "Table"
;
C_NPP = C_NPP + 1                ; next collision pair
;
$NP_COLL_PAIR[C_NPP, 0] = "Tool"
$NP_COLL_PAIR[C_NPP, 1] = "Table"
;
C_NPP = C_NPP + 1                ; next collision pair
;
;
;=====
; activating the machine model
;=====
PROTA
PROTS("A")
;
M2
;===== ENDE =====

```

4.5 Data lists

4.5.1 Machine data

4.5.1.1 NC-specific machine data

Number	Identifier: \$MN_	Description
MD10619	COLLISION_TOLERANCE	Collision tolerance
MD10622	COLLISION_SAFETY_DIST	Safety clearance
MD18896	MM_MAXNUM_3D_COLLISION	Memory location for the collision avoidance

4.5.2 System variables

Identifier	Description
\$NP_COLL_PAIR	Name of the first or second protection area of a collision pair
\$NP_SAFETY_DIST	Safety clearance of the collision pair
\$AN_COLL_STATE	Current state of a protection area with regard to the collision avoidance
\$AN_COLL_STATE_COND	Monitoring state (bit-coded) of a protection area

Identifier	Description
\$AN_COLL_IPO_ACTIVE	Activation state of the collision avoidance in the main run
\$AN_COLL_IPO_LIMIT	Velocity reduction through collision avoidance in the main run
\$AN_COLL_LOAD	Computation time requirement for the collision avoidance function
\$AN_ACTIVATE_COLL_CHECK	Current state of the NC/PLC interface DB10, DBX234.0 - DBX.241.7 (activate protection areas)
\$AN_COLL_CHECK_OFF	Current state of the NC/PLC interface DB10, DBB58 (switch off protection area groups depending on the operating mode)
\$AA_COLLPOS	Position of an axis in the MCS when the last collision alarm occurred
\$AC_COLLPOS	Vector for the collision position in the world coordinate system when the last collision alarm occurred
\$AN_COLL_MEM_AVAILABLE	Size of the memory space in KB reserved for the collision avoidance.
\$AN_COLL_MEM_USE_MIN	Minimum value of the memory space used for the collision avoidance as a percentage of the reserved memory.
\$AN_COLL_MEM_USE_MAX	Maximum value of the memory space used for the collision avoidance as a percentage of the reserved memory.
\$AN_COLL_MEM_USE_ACT	Actual value of the memory space used for the collision avoidance as a percentage of the reserved memory.
\$AA_DTBREB	Estimated, linearly approximated total braking distance (BCS)
\$AA_DTBREB_CMD	Command component (BCS)
\$AA_DTBREB_CORR	Correction component (BCS)
\$AA_DTBREB_DEP	Coupling component (BCS)
\$AA_DTBREM	Estimated, linearly approximated total braking distance (MCS)
\$AA_DTBREM_CMD	Command component (MCS)
\$AA_DTBREM_CORR	Correction component (MCS)
\$AA_DTBREM_DEP	Coupling component (MCS)

4.5 Data lists

Collision avoidance, external

5.1 Function description

5.1.1 Options

The function "Collision avoidance, external" is an option that requires a license: **Protect MyMachine /Open**

5.1.2 Characteristics

The function "Collision avoidance, external" provides a proprietary data interface at the Industrial Ethernet interface X120 of the NCU module. The following data are transferred in real time via this interface:

- Setpoint and actual values of the machine axes for monitoring and visualizing machine movements
- Status data and input data for influencing traversing movements
- Signals for monitoring the external application

Based on these data, an independent application for machine visualization and collision avoidance can be implemented by a SINUMERIK product partner on an external computer.

5.2 Commissioning

5.2.1 Machine data

5.2.1.1 Functions of external collision avoidance

The functions of external collision avoidance are enabled with machine data:

MD16900 \$MN_COLLISION_EXT_FUNKTION_MASK.Bit x = 1

Bit	Meaning
0	Activate UDP interface
1 - 31	reserved

5.2 Commissioning

5.2.1.2 Preview time

The preview time is set with machine data:

MD16901 \$MN_COLLISION_EXT_PREVIEW_TIME = <preview time>

5.2.1.3 Preview time step

The size of a time step for calculating the movement preview is set in machine data:

MD16902 \$MN_COLLISION_EXT_PREVIEW_STEP = <preview time>

5.2.1.4 Timeout time

The time within which the external application must have reported back to the control for sign-of-life monitoring is set in machine data:

MD16903 \$MN_COLLISION_EXT_TIMEOUT = <timeout time>

If the external application does not report back within the set time, alarm 26300 "Sign of life failure of the external collision avoidance" is displayed.

Protection areas

6.1 Function

Protection zones are static or moveable in 2- or 3-dimensional ranges within a machine to protect machine elements against collisions - and must be defined by the user.

The following elements can be protected:


- Fixed machine elements (e.g. tool magazine, probe that can be swiveled).
- Moving machine elements that belong to the tool (e.g. tool, tool holder)
- Moving machine elements that belong to the workpiece (e.g. parts of the workpiece, clamping table, clamping shoe, spindle chuck, tailstock).

In order that it is guaranteed that the machine element is protected, the protection zones must be defined so that they completely envelope the element to be protected.

Protection zone monitoring is channel-specific, i.e. all the active protection zones of a channel monitor one another for collisions.

During automatic execution of part programs in the AUTOMATIC or MDA mode, the NC checks at the start of every part program block whether a collision between protection zones can occur upon moving along the programmed path.

After manual deactivation of an active protection zone, traversing can be performed in this zone. After leaving the protection zone, the protection zone automatically becomes active again.



- ① **Tool-related protection zone**
 ② **Workpiece-related protection zone**

Figure 6-1 Example of protection zones on a milling machine

Defining protection zones

A protection zone can be 2 or 3 dimensional, and defined using polylines with a maximum of 10 corner points and arcs as contour elements. The definition can be made using commands in the part program (see "Defining protection zones (CPROTDEF, NPROTDEF) (Page 117)") or using system variables. All of the contour elements lie in the plane that can be selected with G17, G18 or G19.

3rd dimension

Extending the protection zone in the 3rd dimension can be limited between $-\infty$ and $+\infty$:

- $-\infty$ to $+\infty$
- $-\infty$ up to the upper limit
- Lower limit to $+\infty$
- Lower limit to upper limit

Coordinate system

The definition of a protection zone takes place with reference to the geometry axis of a channel and therefore in the basic coordinate system (BCS).

Reference

- Tool-related protection zones
Coordinates for **tool**-related protection zones must be specified as absolute values referred to the **tool holder reference point F**.
- Workpiece-related protection zones
Coordinates for **workpiece**-related protection zones must be specified as absolute values referred to the zero point of the **basic coordinate system (BCS)**.

Note

If no tool-related protection zone is active, the tool path is checked against the workpiece-related protection zones.

If no workpiece-oriented protection area is active, then there is no protection zone monitoring.

Orientation

The orientation of the protection zones is determined by the plane definition (abscissa/ordinate), in which the contour is described, and the axis perpendicular to the contour (vertical axis).

The orientation of the protection zones must be the same for the tool- and workpiece-related protection zones.

Machine/channel-specific protection zones

- Machine-specific protection zones
Data for machine specific protection zones are defined once in the control. These protection zones can be activated by all channels.
- Channel-specific protection zones
Data for channel-specific protection zones are defined in a channel. These protection zones can be activated only by this channel.

System variable

When the protection zones are defined using commands in the part program, the protection zone data is stored in system variables. The system variables can also be written directly so that the definition of protection areas can also be performed directly in the system variables. The same supplementary conditions apply for the definition of the contour of a protection zone as for a protection zone definition using commands in the part program (see "Defining protection zones (CPROTDEF, NPROTDEF) (Page 117)").

The protection zone definitions cover following system variables:

System variable	Type	Meaning
\$SN_PA_ACTIV_IMMED[<n> \$SC_PA_ACTIV_IMMED[<n>]	BOOL	Activation type The protection zone is active / not active immediately after the control system has been powered up and the axes referenced.
		FALSE Not immediately active
		TRUE Immediately active

6.1 Function

System variable	Type	Meaning
\$SN_PA_T_W[<n>] \$SC_PA_T_W[<n>]	INT	Protection zone type
		0 Workpiece-related protection zone
		1 Reserved
		2 Reserved
		3 Tool-related protection zone
\$SN_PA_ORI[<n>] \$SC_PA_ORI[<n>]	INT	Orientation of the protection zone, i.e. polygon definition in the plane of:
		0 1st and 2nd geometry axis
		1 3rd and 1st geometry axis
		2 2nd and 3rd geometry axis
\$SN_PA_LIM_3DIM[<n>] \$SC_PA_LIM_3DIM[<n>]	INT	Type of limitation in the 3rd dimension
		0 No limitation
		1 Limitation in plus direction
		2 Limitation in minus direction
		3 Limitation in positive and negative directions
\$SN_PA_PLUS_LIM[<n>] \$SC_PA_PLUS_LIM[<n>]	REAL	Value of the limit in the positive direction in the 3rd dimension
\$SN_PA_MINUS_LIM[<n>] \$SC_PA_MINUS_LIM[<n>]	REAL	Value of the limit in the minus direction in the 3rd dimension
\$SN_PA_CONT_NUM[<n>] \$SC_PA_CONT_NUM[<n>]	INT	Number of valid contour elements
\$SN_PA_CONT_TYP[<n>, <i>] \$SC_PA_CONT_TYP[<n>, <i>]	INT	Contour type[<i>], contour type (G1, G2, G3) of the <i>th contour element
\$SN_PA_CONT_ABS[<n>, <i>] \$SC_PA_CONT_ABS[<n>, <i>]	REAL	End point of the contour[<i>], abscissa value
\$SN_PA_CONT_ORD[<n>, <i>] \$SC_PA_CONT_ORD[<n>, <i>]	REAL	End point of the contour[<i>], ordinate value
\$SN_PA_CENT_ABS[<n>, <i>] \$SC_PA_CENT_ABS[<n>, <i>]	REAL	Center point of the circular contour[<i>], absolute abscissa value
\$SN_PA_CENT_ORD[<n>, <i>] \$SC_PA_CENT_ORD[<n>, <i>]	REAL	Center point of the circular contour[<i>], absolute ordinate value
\$SN_... are system variables for NC and machine-specific protection zones. \$SC_... are system variables for channel-specific protection zones. The index "<n>" corresponds to the number of the protection zone: 0 = 1st protection zone The index "<i>" corresponds to the number of the contour element: 0 = 1st contour element The contour elements must be defined in ascending order.		

Note

The system variables of the protection zone definitions are not restored with REORG!

Data of the protection zone definitions**Data storage**

The protection zone definitions are stored in the following files:

File	Blocks
_N_NCK_PRO	Data block for machine-specific protection zones
_N_CHAN1_PRO	Data block for channel-specific protection zones in channel 1
_N_CHAN2_PRO	Data block for channel-specific protection zones in channel 2

Data backup

The protection zone definitions are saved in the following files:

File	Blocks
_N_INITIAL_INI	All data blocks of the protection zones
_N_COMPLETE_PRO	All data blocks of the protection zones
_N_CHAN_PRO	All data blocks of the channel-specific protection zones

Activating, preactivating and deactivating protection zones

Activation state

The activation state of a protection zone can have the following values:

- Activated
- Preactivated
- Preactivated with conditional stop
- Deactivated

The activation state is always channel-specific even for machine specific protection zones.

Activating, preactivating and deactivating in the part program

The activation state of a protection zone can be changed in the part program at any time using commands (see "Activating/deactivating protection zones (CPROT, NPROT) (Page 120)").

Note

A protection zone is only taken into account after the referencing of all geometry axes of the channel in which it has been activated.

Protection zones that are to be activated at a later time from the PLC user program (see below) must be preactivated in the part program:

Preactivated protection zones are displayed via the following NC/PLC interface signals:

- DB21, ... DBX272.0 - 273.1 (machine-specific protection zone 1 - 10 preactivated) == 1
- DB21, ... DBX274.0 - 275.1 (channel-specific protection zone 1 - 10 preactivated) ==== 1

Preactivated with conditional stop**NOTICE****Protection zone violation possible**

If a preactivated protection zone with conditional stop is not activated in good time, the NC may no longer be able to stop before the protection zone in good time because the braking distance after the activation point has not been taken into account.

In the case of a preactivated protection zone with conditional stop, a traversing motion is **not** stopped before this if the traversing motion goes into the protection zone. A stop is only performed when the protection zone has been activated. This behavior is to enable uninterrupted machining controlled by the user when the protection zone is only required temporarily.

Activating using NC/PLC interface signals

Only protection zones that have been **preactivated** via the part program can be activated in the PLC user program via the NC/PLC interface signals:

- DB21, ... DBX8.0 - 9.1 (activate machine-specific protection zone 1 - 10) = 1
- DB21, ... DBX10.0 - 11.1 (activate channel-specific protection zone 1 - 10) = 1

The activation of preactivated protection zones must be performed prior to the traversing motion of the geometry axes! If the activation is performed during the traversing motion, these protection zones are not taken into account in the current traversing motion. Response:

- Alarm "10704 "Protection zone monitoring is not guaranteed"
- DB21, ... DBX39.0 (protection-zone monitoring not guaranteed) = 1

Note

The activation of preactivated protection zones must be performed prior to the traversing motion of the geometry axes!

Deactivating using NC/PLC interface signals

Only protection zones that have been **preactivated** via a part program and activated via the NC/PLC interface signals, can be deactivated again via the NC/PLC interface signals:

- DB21, ... DBX8.0 to DBX9.1 (activate machine-specific protection zone 1 - 10) = 0
- DB21, ... DBX10.0 to DBX11.1 (activate channel-specific protection zone 1 - 10) = 0

Protection zones that have been **activated** directly via a part program **cannot** be deactivated from the PLC user program.

Automatic deactivation for transformation change/geometry axis interchange

In the default setting, when changing a transformation, or for a geometry axis interchange, the active protection zones are automatically deactivated. On the other hand, if active protection zones should remain active, then the bit-coded machine data MD10618

\$MN_PROTAREA_GEOAX_CHANGE_MODE must be correspondingly adapted (see "Machine data (Page 116)").

Activation state in special system states

Block search with calculation

For block search with calculation, the last programmed activation state of a protection zone is always taken into account.

Program test

In the AUTOMATIC and MDI modes, activated and preactivated protection zones are also monitored in the "Program test" state.

NC RESET and end of program

The activation state of a protection zone is retained even after NC-RESET and program end.

Display of protection zone violations

Violations of activated protection zones or possible violations of preactivated protection zones, if they would be activated, are displayed using the following NC/PLC interface signals:

- DB21, ... DBX276.0 - 277.1 (machine-specific protection zone 1 - 10 violated) == 1
- DB21, ... DBX278.0 - 279.1 (channel-specific protection zone 1 - 10 violated) == 1

Checking for protection zone violation

Function CALCPOSI can be used to check whether geometry axes can traverse a specified path without violating a protection zone (see "Checking for protection zone violation, working area limitation and software limit switches (CALCPOSI) (Page 123)").

6.2 Commissioning

6.2.1 Machine data

Memory requirements

The memory required for protection zones is parameterized via the following machine data:

- Persistent memory
 - MD18190 \$MN_MM_NUM_PROTECT_AREA_NCK (number of available machine-specific protection zones)
 - MD28200 \$MC_MM_NUM_PROTECT_AREA_CHAN (number of available channel-specific protection zones)
- Dynamic memory
 - MD28210 \$MC_MM_NUM_PROTECT_AREA_ACTIVE (maximum number of protection zones that can be activated simultaneously in the channel)
 - MD28212 \$MC_MM_NUM_PROTECT_AREA_CONTUR (maximum number of definable contour elements per protection zone)

Response for a transformation change/geometry axis interchange

The following machine data can be used to define as to whether, when changing a transformation or for a geometry axis interchange, active protection zones should be kept or deactivated:

MD10618 \$MN_PROTAREA_GEOAX_CHANGE_MODE

Bit	Value	Meaning
0	0	The active protection zones are deactivated during the transformation change.
	1	The active protection zones remain active during the transformation change.
1	0	The active protection zones are deactivated during the geometry axis change.
	1	The active protection zones remain active during the geometry axis change.

6.3 Programming

6.3.1 Defining protection zones (CPROTDEF, NPROTDEF)

Protection zones, which protect machine elements against collisions, are defined in the part program in blocks. These contain the following elements:

1. Definition of the machining plane
Before the actual protection zone definition, the machining plane must be selected, to which the contour description of the protection zone refers.
2. Start of the definition
Depending on the particular NC command, either a channel-specific or machine-specific protection zone is created.
3. Contour description of the protection zone
The contour of a protection zone is defined with traversing motion. These are not executed and have no connection to previous or subsequent geometry descriptions. They only define the protection zone.
4. End of definition

Syntax

```
DEF INT <Var>
G17/G18/G19
CPROTDEF/NPROTDEF (<n>, <t>, <AppLim>, <AppPlus>, <AppMinus>)
G0/G1/... X/Y/Z...
...
EXECUTE (<Var>)
```

Meaning

DEF INT <Var>:	Definition of a local help variable, of the INTEGER data type	
<Var>:	Name of the Help variable	
G17/G18/G19:	Machining plane Note: It is not permissible to change the machining plane before the end of the definition. Programming the applicator is not permitted between start and end of the definition.	
CPROTDEF () :	Predefined procedure to define a channel -specific protection zone	
NPROTDEF () :	Predefined procedure to define a machine -specific protection zone	
<n>:	Number of defined protection zone	
	Data type:	INT

<t>:	Type of protection zone	
	Data type:	BOOL
	Value:	TRUE Tool -related protection zone
		FALSE Workpiece -related protection zone
<AppLim>:	Type of limitation in the third dimension	
	Data type:	INT
	Value:	0 No limitation
		1 Limit in plus direction
		2 Limit in minus direction
		3 Limit in positive and negative direction
<AppPlus>:	Value of the limit in the positive direction in the 3rd dimension	
	Data type:	REAL
<AppMinus>:	Value of the limit in the negative direction in the 3rd dimension	
	Data type:	REAL
G0/G1/... X/Y/Z... :	The contour of a protection zone is specified with up to 11 traversing movements in the selected machining plane. The first traversing movement is the movement to the contour. The last point in the contour description must always coincide with the first point of the contour description. The valid protection zone is the zone left of the contour: - Internal protection zone The contour of an internal protection zone must be described in the counterclockwise direction. - External protection zones (permitted only for workpiece-related protection zones) The contour for an external protection zone must be described in the clockwise direction. The following contour elements are permissible: - G0, G1 for straight contour elements - G2 for circle segments in the clockwise direction Permissible only for workpiece-related protection zones. Not permissible for tool-related protection zones because they must be convex. - G3 for circular segments in the counter-clockwise direction Note: A protection zone cannot be described by a complete circle. A complete circle must be divided into two semicircles. Note: The sequence G2 → G3 or G3 → G2 is not permissible! A short G1 block must be inserted between the two circular blocks.	
EXECUTE(<Var>):	Predefined procedure that marks the end of the definition A switch is made back to normal program processing with EXECUTE.	

Example

See example under "Activating/deactivating protection zones (CPROT, NPROT) (Page 120)".

Additional information

Machine-specific protection zones

A machine-specific protection zone or its contour is defined using the geometry axis, i.e. referenced to the basic coordinate system (BCS) of a channel. In order that correct protection-zone monitoring can take place in all channels in which the machine-specific protection zone is active, the basic coordinate system (BCS) of all of the channels involved must be identical:

- position of the coordinate origin referred to the machine zero
- Orientation of the coordinate axes

Reference point for contour description


- Tool-related protection zones
Coordinates for **tool**-related protection zones must be specified as absolute values referred to the **tool holder reference point F**.
- Workpiece-related protection zones
Coordinates for **workpiece**-related protection zones must be specified as absolute values referred to the zero point of the **basic coordinate system (BCS)**.

Protection zones symmetrical around the center of rotation

For protection zones symmetrical around the axis or rotation (e.g. spindle chuck), you must describe the complete contour and not only the contour up to the center of rotation.

Tool-related protection zones

Tool-related protection zones must always be convex. If a concave protected zone is desired, this should be subdivided into several convex protection zones.



- ① Convex protection zones
- ② Concave protection zones (**not permissible!**)
- F Toolholder reference point

General conditions

During the definition of a protection zone, the following functions must not be active or used:

- Tool radius compensation (cutter radius compensation, tool nose radius compensation)
- Transformation
- Reference point approach (G74)
- Fixed point approach (G75)

- Dwell time (G4)
- Block search stop (STOPRE)
- End of program (M17, M30)
- M functions: M0, M1, M2

6.3.2 Activating/deactivating protection zones (CPROT, NPROT)

Protection zones previously defined in the part program can be activated at any time – or can be preactivated for subsequent activation by the PLC user program. Active protection zones can be deactivated at any time.

When activating or preactivating, it is also possible to relatively shift the reference point of the protection zone.

Note

A protection zone is only taken into account after the referencing of all geometry axes of the channel in which it has been activated.

Note

Monitoring protection zones

If a tool-related protection area is not active, the tool path is checked against the workpiece-related protection zones.

If no workpiece-oriented protection zone is active, then there is no protection zone monitoring.

Syntax

CPROT (<n>, <Status>, <XMov>, <YMov>, <ZMov>)

NPROT (<n>, <Status>, <XMov>, <YMov>, <ZMov>)

Meaning

CPROT:	Predefined procedure to activate a channel -specific protection zone		
NPROT:	Predefined procedure to activate a machine -specific protection zone		
<n>:	Number of the protection zone		
	Data type:	INT	
<Status>:	The channel-specific activation status is set using this parameter		
	Data type:	INT	
	Value:	0	Deactivate protection zone
		1	Preactivate protection zone
		2	Activate protection zone
		3	Preactivate protection zone with conditional stop

<XMov>, <YMov>, <ZMov>:	Additive offset values in the X/Y/Z direction The offset can take place in 1, 2, or 3 dimensions. The offset values refer to: • The machine zero for a workpiece-related protection zone • The tool carrier reference point F for a tool-specific protection zone
	Data type: REAL

Example


Possible collision of a milling cutter with the measuring probe is to be monitored on a milling machine. The position of the measuring probe is to be defined by an offset when the function is activated.

The following protection zones are defined for this:

- A machine-specific and a workpiece-related protection zone for both the measuring probe holder (n-PZ1) and the measuring probe itself (n-PZ2).
- A channel-specific and a tool-related protection zone for the milling cutter holder (c-PZ1), the cutter shank (c-PZ2) and the milling cutter itself (c-PZ3).

The orientation of all protection zones is in the Z direction.

The position of the reference point of the measuring probe on activation of the function must be X = -120, Y = 60 and Z = 80.



- ① Name for the protection zone of the probe
 F Toolholder reference point

Program code	Comment
DEF INT PROTZONE	; Definition of a Help variable
G17	; machining plane XY

6.3 Programming

Program code	Comment
; defining protection zones:	
NPROTDEF(1,FALSE,3,10,-10)	; protection zone n-PZ1
G01 X0 Y-10	
X40	
Y10	
X0	
Y-10	
EXECUTE(PROTZONE)	
NPROTDEF(2,FALSE,3,5,-5)	; protection zone n-PZ2
G01 X40 Y-5	
X70	
Y5	
X40	
Y-5	
EXECUTE(PROTZONE)	
CPROTDEF(1,TRUE,3,0,-100)	; protection zone c-PZ1
G01 X-20 Y-20	
X20	
Y20	
X-20	
Y-20	
EXECUTE(PROTZONE)	
CPROTDEF(2,TRUE,3,-100,-150)	; protection zone c-PZ2
G01 X0 Y-10	
G03 X0 Y10 J10	
X0 Y-10 J-10	
EXECUTE(PROTZONE)	
CPROTDEF(3,TRUE,3,-150,-170)	; protection zone c-PZ3
G01 X0 Y-27.5	
G03 X0 Y27.5 J27.5	
X0 Y27.5 J-27.5	
EXECUTE(PROTZONE)	
; activating protection zones:	
NPROT(1,2,-120,60,80)	; activate protection zone n-PZ1 with offset
NPROT(2,2,-120,60,80)	; activate protection zone n-PZ2 with offset
CPROT(1,2,0,0,0)	; activate protection zone c-PZ1
CPROT(2,2,0,0,0)	; activate protection zone c-PZ2
CPROT(3,2,0,0,0)	; activate protection zone c-PZ3

Further information

Activation status after the control powers up

A protection zone can already be active after the control system powers up and the axes have been referenced. This is the case if, for the protection zone, the following system variable is set to TRUE:

- \$SN_PA_ACTIV_IMMED[<n>] (for machine-specific protection zone) or
- \$SC_PA_ACTIV_IMMED[<n>] (for channel-specific protection zone)
Index "<n>" corresponds to the number of the protection zone: 0 = 1. Protection zone

The protection zone is activated with status = 2 – and without offset.

Multiple activation of a protection zone

A machine-specific protection zone can be active simultaneously in several channels (e.g. protection zone of a tailstock where there are two opposite sides). The protection zones are only monitored if all geometry axes have been referenced.

A protection zone cannot be activated simultaneously with different offsets in a single channel.

Protection zone monitoring for active tool radius compensation

For active tool radius compensation, a functioning protection zone monitoring is only possible if the plane of the tool radius compensation is identical to the plane of the protection zone definitions.

6.3.3 Checking for protection zone violation, working area limitation and software limit switches (CALCPOSI)

Function

In the workpiece coordinate system (WCS), the CALCPOSI function checks whether, starting from the starting position, the **geometry axes** can be traversed a specified distance without violating active limits. For the case that the distance cannot be fully traversed because of limits, a positive, decimal-coded status value and the maximum possible traversing distance are returned.

Definition

```
INT CALCPOSI (VAR REAL[3] <Start>, VAR REAL[3] <Dist>, VAR REAL[5]  
<Limit>, VAR REAL[3] <MaxDist>, BOOL <MeasSys>, INT <TestLim>)
```

Syntax

```
<Status> = CALCPOSI (VAR <Start>, VAR <Dist>, VAR <Limit>, VAR  
<MaxDist>, <MeasSys>, <TestLim>)
```

Meaning

CALCPOSI (. . .) :		Predefined function for testing limit violations regarding the geometry axes	
		Preprocessing stop:	No
		Alone in the block:	Yes
<status>: (Part 1)	Function return value. Negative values indicate error states.		
	Data type:		INT
	Value range:		$-8 \leq x \leq 100000$
	Value:	0	The distance can be traversed completely.
		-1	At least one component is negative in <Limit>.
		-2	Error in a transformation calculation. Example: The traversing distance passes through a singularity so that the axis positions cannot be defined.
		-3	The specified traversing distance <Dist> and the maximum possible traversing distance <MaxDist> are linearly dependent. Note Can only occur in conjunction with <TestLim>, bit 4 == 1.
		-4	The projection of the traversing direction contained in <Dist> on to the limitation surface is the zero vector, or the traversing direction is perpendicular to the violated limitation surface. Note Can only occur in conjunction with <TestLim>, bit 5 == 1.
		-5	In <TestLim>, bit 4 == 1 AND bit 5 == 1
		-6	At least one machine axis that has to be considered for checking the traversing limits has not been referenced.
		-7	Collision avoidance function: Invalid definition of the kinematic chain or the protection zones.
		-8	Collision avoidance function: This command cannot be executed because of insufficient memory.
<status>: (Part 2)	Units digit		
	Note If several limits are violated simultaneously, the limit with the greatest restriction on the specified traversing distance is signaled.		
	Value:	1	Software limit switches are limiting the traversing distance
		2	Working area limits are limiting the traversing distance
		3	Protection zones are limiting the traversing distance
		4	Collision avoidance function: Protection zones are limiting the traversing path
	Tens digit		
	Value:	1x	The initial value violates the limit
		2x	The specified straight line violates the limit. This value is returned even if the end point does not violate any limit itself, but the path from the starting point to the end point would cause a limit value to be violated (e.g. by passing through a protection zone, curved software limit switches in the WCS for non-linear transformations, e.g. transmit).

<status>: (Part 3)	Hundreds digit		
	Value:	1xx	AND units digit == 1 or 2: The positive limit value has been violated.
			AND units digit == 3 ¹⁾ : An NC-specific protection zone has been violated.
	2xx		AND units digit == 1 or 2: The negative limit value has been violated.
			AND units digit == 3 ¹⁾ : A channel-specific protection zone is violated.
<status>: (Part 4)	Thousands digit		
	Value:	1xxx	AND units digit == 1 or 2: Factor with which the axis number is multiplied that violates the limit. Numbering of the axes begins with 1. Reference: • Software limit switches: Machine axes • Working area limitation: Geometry axes AND units digit == 3 ¹⁾ : Factor with which the number of the violated protection zone is multiplied.
<status>: (Part 5)	Hundred thousands digit		
	Value:	0xxxxx	Hundred thousands digit == 0: <Dist> remains unchanged
		1xxxxx	A direction vector is returned in <Dist>, which defines the further motion direction on the limitation surface. Can only occur with the following supplementary conditions: • Software limit switch or working area limit violated (not in the starting point) • A transformation is not active • <TestID>, bit 4 or bit 5 == 1
<Start>:	Reference to a vector with the start positions: • <Start> [0]: 1st geometry axis • <Start> [1]: 2nd geometry axis • <Start> [2]: 3rd geometry axis		
	Parameter type:		Input
	Data type:		VAR REAL [3]
	Value range:		-max. REAL value ≤ x[<n>] ≤ +max. REAL value


<Dist>:	Reference to a vector.	
	Input: Incremental traversing distance • <Dist> [0]: 1st geometry axis • <Dist> [1]: 2nd geometry axis • <Dist> [2]: 3rd geometry axis	
	Output (only for set hundred thousands digit in <Status>):	
	<Dist> contains a unit vector v as output value which defines the further traversing direction in the WCS.	
	Case 1: Formation of vector v for <TestID>, bit 4 == 1 The input vectors <Dist> and <MaxDist> span the motion plane. This plane is cut by the violated limitation surface. The intersecting line of the two planes defines the direction of vector v . The orientation (sign) is selected so that the angle between the input vector <MaxDist> and v is not greater than 90 degrees.	
	Case 2: Formation of vector v for <TestID>, bit 5 == 1 Vector v is the unit vector in the projection direction of the traversing vector contained in <Dist> on the limitation surface. If the projection of the traversing vector on the limitation surface is the zero vector, an error is returned.	
	Parameter type:	Input/output
<Limit>:	Data type:	VAR REAL [3]
	Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value
	Reference to an array of length 5.	
	• <Limit> [0 - 2]: Minimum clearance of the geometry axes to the limits: – <Limit> [0]: 1st geometry axis – <Limit> [1]: 2nd geometry axis – <Limit> [2]: 3rd geometry axis The minimum clearances are observed with: – Working area limitation: No restrictions – Software limit switches: If no transformation is active, or a transformation is active in which a clear assignment of the geometry axes to the linear machine axes is possible, e.g. 5-axis transformations. • <Limit> [3]: Contains the minimum clearance for linear machine axes which, for example, cannot be assigned a geometry axis because of a non-linear transformation. This value is also used as limit value for the monitoring of the conventional protection zones and the collision avoidance protection zones. • <Limit> [4]: Contains the minimum clearance for rotary machine axes which, for example, cannot be assigned a geometry axis because of a non-linear transformation. Note This value is only active for the monitoring of the software limit switches for special transformations.	
	Parameter type:	Input
	Data type:	VAR REAL [5]
	Value range:	-max. REAL value ≤ x[n] ≤ +max. REAL value

<MaxDist>:	Reference to a vector with the incremental traversing distance in which the specified minimum clearance of an axis limit is not violated by any of the relevant machine axes:		
	• <Dist> [0]: 1st geometry axis • <Dist> [1]: 2nd geometry axis • <Dist> [2]: 3rd geometry axis		
	If the traversing distance is not restricted, the contents of this return parameter are the same as the contents of <Dist>.		
	For <TestID>, bit 4 == 1: <Dist> and <MaxDist>		
	<MaxDist> and <Dist> must contain vectors as input values that span a motion plane. The two vectors must be mutually linearly independent. The absolute value of <MaxDist> is arbitrary. For the calculation of the motion direction, see the description for <Dist>.		
	Parameter type:	Output	
	Data type:	VAR REAL [3]	
	Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value	
<MeasSys>:	Measuring system (inch/metric) for position and distance specifications (optional)		
	Data type:		BOOL
	Value:	FALSE (Default)	System of units corresponding to the currently active G command from the G group 13 (G70, G71, G700, G710). Note If G70 is active and the basic system is metric (or G71 is active and the basic system is inch), the system variables \$AA_IW and \$AA_MW are provided in the basic system and, if used, must be converted for CALCP0SI.
		TRUE	System of units according to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM
<TestLim>:	Bit-coded selection of the limits to be monitored (optional)		
	Data type:		INT
	Default value:		Bits 0, 1, 2, 3, 6, 7 == 1 (207)
	Bit	Decimal	Meaning
	0	1	Software limit switch
	1	2	Working area limitation
	2	4	Activated conventional protection zones
	3	8	Preactivated conventional protection zones
	4	16	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 1 (see above).
	5	32	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 2 (see above).
	6	64	Activated collision avoidance protection zones
	7	128	Preactivated collision avoidance protection zones
	8	256	Pairs of activated and preactivated collision avoidance protection zones

¹⁾ If several protection zones are violated, the protection zone with the greatest restriction on the specified traversing distance is returned.

Example

Limitations



In the example, the active software limit switches and working area limits in the X-Y plane and the following three protection zones are displayed:

- C2: Tool-related, channel-specific protection zone, active, circular, radius = 2 mm
- C4: Workpiece-related, channel-specific protection zone, preactivated, square, side length = 10 mm
- N3: Machine-specific protection zone, active, rectangular, side length = 10 mm x 15 mm

NC program

The protection zones and working area limits are defined first in the NC program. The `CALCPOSI()` function is then called with different parameter assignments.

Program code

```

N10 DEF REAL _START[3]
N20 DEF REAL _DIST[3]
N30 DEF REAL _LIMIT[5]
N40 DEF REAL _MAXDIST[3]
N50 DEF INT _PA
N60 DEF INT _STATUS

```

Program code

```
: toolrelated protection zone C2
N70 CPROTDEF(2, TRUE, 0)
N80 G17 G1 X-2 Y0
N90 G3 I2 X2
N100 I-2 X-2
N110 EXECUTE(_PA)

; workpiece-related protection zone C4
N120 CPROTDEF(4, FALSE, 0)
N130 G17 G1 X0 Y15
N140 X10
N150 Y25
N160 X0
N170 Y15
N180 EXECUTE(_PA)

; machine-specific protection zone N3
N190 NPROTDEF(3, FALSE, 0)
N200 G17 G1 X10 Y5
N210 X25
N220 Y15
N230 X10
N240 Y5
N250 EXECUTE(_PA)

; activate or preactivate protection zones
N260 CPROT(2, 2, 0, 0, 0)
N270 CPROT(4, 1, 0, 0, 0)
N280 NPROT(3, 2, 0, 0, 0)

; define working area limits
N290 G25 XX=-10 YY=-10
N300 G26 XX=20 YY=21
N310 _START[0] = 0.
N320 _START[1] = 0.
N330 _START[2] = 0.
N340 _DIST[0] = 35.
N350 _DIST[1] = 20.
N360 _DIST[2] = 0.
N370 _LIMIT[0] = 0.
N380 _LIMIT[1] = 0.
N390 _LIMIT[2] = 0.
N400 _LIMIT[3] = 0.
N410 _LIMIT[4] = 0.
N420 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST)
N430 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,3)
N440 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,1)
N450 _START[0] = 5.
N460 _START[1] = 17.
N470 _START[2] = 0.
N480 _DIST[0] = 0.
N490 _DIST[1] = -27.
N500 _DIST[2] = 0.
N510 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,14)
N520 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 6)
N530 _LIMIT[1] = 2.
```

Program code

```

N540 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 6)
N550 _START[0] = 27.
N560 _START[1] = 17.1
N570 _START[2] = 0.
N580 _DIST[0] = -27.
N590 _DIST[1] = 0.
N600 _DIST[2] = 0.
N610 _LIMIT[3] = 2.
N620 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,12)
N630 _START[0] = 0.
N640 _START[1] = 0.
N650 _START[2] = 0.
N660 _DIST[0] = 0.
N670 _DIST[1] = 30.
N680 _DIST[2] = 0.
N690 TRANS X10
N700 AROT Z45
N710 _STATUS = CALCPOSI(_START,_DIST, _LIMIT, _MAXDIST)
; delete frames from N690 and N700 again
N720 TRANS
N730 _START[0] = 0.
N740 _START[1] = 10.
N750 _START[2] = 0.
; vectors _DIST and _MAXDIST define the motion plane
N760 _DIST[0] = 30.
N770 _DIST[1] = 30.
N780 _DIST[2] = 0.
N790 _MAXDIST[0] = 1.
N800 _MAXDIST[1] = 0.
N810 _MAXDIST[2] = 1.
N820 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,17)
N830 M30

```

Results of CALCPOSI()

N...	<status>	<MaxDist>[0] $\triangleq$ X	<MaxDist>[1] $\triangleq$ Y	Remarks
420	3123	8.040	4.594	N3 is violated.
430	1122	20.000	11.429	No protection zone monitoring, working area limitation is violated.
440	1121	30.000	17.143	Only software limit monitoring is still active.
510	4213	0.000	0.000	Starting point violates C4
520	0000	0.000	-27.000	Preactivated C4 is not monitored. The specified distance can be traversed completely.
540	2222	0.000	-25.000	Because _LIMIT[1] = 2, the traversing distance is restricted by the working area limitation.

N...	<status>	<MaxDist>[0] $\triangleq$ X	<MaxDist>[1] $\triangleq$ Y	Remarks
620	4223	-13.000	0.000	Clearance to C4 is a total of 4 mm due to C2 and <code>_LIMIT[3]</code> . Clearance C2 $\rightarrow$ N3 of 0.1 mm does not result in limitation of the traversing distance.
710	1221	0.000	21.213	Frame with translation and rotation active. The permissible traversing distance in <code>_DIST</code> applies in the shifted and rotated WCS.
820	102121	18.000	18.000	The software limit switch of the Y axis is violated. The calculation of a further traversing direction is requested with <code><_TESTLIM> = 17</code> . This direction is in <code>_DIST</code> (0.707, 0.0, 0.707). It is valid because the hundred thousands digit is set in <code><_STATUS></code> .

Additional information

"Referenced" axis status

All machine axes considered by `CALCPOSI()` must be homed.

Circle-related distance specifications

All circle-related distance specifications are **always** interpreted as radius specifications. This must be taken into account particularly for transverse axes with activated diameter programming (`DIAMON/DIAM90`).

Traversing distance reduction

If the specified traversing distance of an axis is limited, the traversing distance of the other axes is also reduced proportionally in the `<MaxDist>` return value. The resulting end point is therefore still on the specified path.

Rotary axes

Rotary axes are only monitored when they are not modulo rotary axes.

It is permissible that no software limit switches, working area limits or protection zones are defined for one or more of the relevant axes.

Software limit switch and working area limitation status

Software limit switches and working area limits are only taken into account if they are active during the execution of `CALCPOSI()`. The status can be influenced, for example, via:

- Machine data: MD21020 `$MC_WORKAREA_WITH_TOOL_RADIUS`
- Setting data: `$AC_WORKAREA_CS_...`
- NC/PLC interface signals DB31, ... DBX12.2 / 3
- Commands: `WALIMON` / `WALIMOF`

Software limit switches and transformations

With `CALCPOSI()`, the positions of the machine axes (MCS) cannot always be uniquely determined from the positions of the geometry axes (WCS) during various kinematic transformations (e.g. `TRANSMIT`) because of ambiguities at certain positions of the traversing

distance. In normal traversing operation, the uniqueness generally results from the history and the condition that a continuous motion in the WCS must correspond to a continuous motion in the MCS. Therefore, when monitoring the software limit switches, the machine position at the time when `CALCPOSI ()` is executed is used to resolve the ambiguity in such cases.

Note**Preprocessing stop**

When using `CALCPOSI ()` in conjunction with transformations, it is the sole responsibility of the user to program a preprocessing stop (`STOPRE`) with the preprocessing before `CALCPOSI ()` for the synchronization of the machine axis positions.

Protection zone clearance and conventional protection zones

With conventional protection zones, there is **no** guarantee that the safety clearance set in parameter `<Limit>[3]` is maintained for all protection zones during a traversing movement on the specified path. It is only guaranteed that no protection zone will be violated when the end point returned in `<Dist>` is extended by the safety clearance in the traversing direction. However, the straight line can pass very close to a protection zone.

Protection zone clearance and collision avoidance protection zones

With collision avoidance protection zones, there is a guarantee that the safety clearance set in parameter `<Limit>[3]` is maintained for all protection zones during a traversing movement on the specified traversing path.

The safety clearance specified in parameter `<Limit>[3]` only takes effect when the following applies:

`<Limit>[3] > (MD10619 $MN_COLLISION_TOLERANCE)`

If bit 4 is set in parameter `<TestLim>` (calculation of the ongoing traversing direction), then the direction vector received in `<DIST>` is only valid when the hundred thousands digit is set in the function return value (`<status>`). If a direction such as this cannot be determined, either because protection zones were violated, or because a transformation is active, then the input value in `<DIST>` remains unchanged. An additional error message is not output.

6.4 Special situations

6.4.1 Temporary enabling of protection zones

If a protection zone violation occurs when starting or during a traversing motion, under certain circumstances, the protection zone can be enabled, i.e. for temporary traversing. In AUTOMATIC and MDA mode as well as in JOG mode, the temporary enabling of protection zones is performed via operator actions.

See also:

- Behavior in the AUTOMATIC and MDA modes (Page 133)
- Behavior in JOG mode (Page 134)

Note

Temporarily enabling protection zones is **only** possible for **workpiece**-related protection zones. **Tool**-related protection zones must either be deactivated in the part program or via the NC/PLC interface in the "Preactivated" state.

Temporary enabling of a protection zone is terminated after the following events:

- When the control system powers up
- AUTOMATIC or MDA mode: The end of the block is outside the protection zone
- JOG mode: The end of the traversing motion is outside the protection zone
- The protection zone is activated

6.4.2 Behavior in the AUTOMATIC and MDA modes

In AUTOMATIC and MDA mode, no traversing motion is enabled into or through active protection zones:

- A traversing motion that would lead from outside into an active protection zone, is stopped at the end of the last block located outside the protection zone.
- A traversing motion that begins within an active protection zone is not started.

Temporary enabling of protection zones

If a traversing motion is stopped in AUTOMATIC or MDA mode because of a protection zone violation, this is indicated to the operator by an alarm. If the operator decides that the traversing motion can be continued, the crossing of protection zones can be enabled.

The enabling is only temporarily and is performed by triggering NC start:

DB21, ... DBX7.1 (NC start) = 1

An alarm is displayed for each violated protection zone. An NC start signal must be triggered by the operator for each protection zone to be enabled.

The traversing motion is continued when all protection zones that have resulted in the stopping of the traversing motion, have been enabled.

Continuation of a traversing motion without temporary enabling

A traversing motion was stopped with an alarm because of a protection zone violation. If the relevant protection zone is set to the "Preactivated" state via the NC/PLC interface, the traversing motion can be continued with NC start, without the protection zone being temporarily enabled.

Increased protection against the enabling of protection zones

If the enabling of a protection zone is to be protected better than just by using an NC start, then this must be realized by the machine manufacturer or user in the PLC user program.

6.4.3 Behavior in JOG mode

Simultaneous traversing of several geometry axes

In JOG mode, traversing motions can be performed simultaneously in several geometry axes. The traversing range of every participating geometry axis is limited axis-specifically at the start of the traversing motion with regard to the traversing range limits (software limit switches, working area limitation, etc.) and active protection zones. However, safe monitoring of all active protection zones cannot be guaranteed. The following is provided as feedback to the user:

- Alarm 10704 "Protection zone monitoring is not guaranteed"
- DB31, ... DBX39.0 (protection-zone monitoring not guaranteed) = 1

After the end of the traversing motion, the alarm is cleared automatically.

If the current position is within an activated or preactivated protection zone, then the following actions are triggered:

- Alarm message 10702 "NC protection zone violated during manual mode" or 10703 "Channel-specific protection zone violated during manual mode" is output – specifying the violated protection zone and the traversing axis.
- Further traversing motion is disabled.
- The following NC/PLC interface signal is set for the protection zone involved:
DB21, ... DBX276.0 – 277.1 (machine-specific protection zone 1 - 10 violated) == 1
or
DB21, ... DBX278.0 – 279.1 (channel-specific protection zone 1 - 10 violated) == 1

To continue, see paragraph "Temporary enabling of protection zones".

Example:

Three activated protection zones and simultaneous traversing of two geometry axes:




Figure 6-2 Motion range of the geometry axes at the start time

At the start time of traversing motion of axes X and Y, the axis-specific traversing range limits are determined from the start time:

- X axis
 - Positive traversing direction: Protection zone 2
 - Negative traversing direction: Absolute traversing range limit (e.g. software limit switches)
- Y axis
 - Positive traversing direction: Protection zone 1
 - Negative traversing direction: Absolute traversing range limit (e.g. working area limitation)

The resulting maximum traversing range at the start time does not take protection zone 3 into account. As a consequence, protection zone 3 could be violated.

Note

Activated and preactivated protection zones are also monitored in the manual operating modes JOG, INC and DRF.

Limiting the traversing motion of an axis

If the traversing motion of an axis is limited as a protection zone has been reached, then alarm 10706 "NC protection zone reached during manual mode" or 10707 "Channel-specific protection zone reached during manual mode" is output, specifying the protection zone reached and the traversing axis. It is assured that no protection zone will be violated when an axis is traversing in JOG. (This response is analogous to approaching software limit switches or a working area limitation.)

The alarm is reset:

- When an axis is traversed that does not lead into the protection zone.
- When the protection zone is enabled.
- When the control powers up.

If an axis starts to move towards a protection zone when it is at a protection zone limit, then alarm 10706 or 10707 is output, and motion is not started.

Temporary enabling of protection zones

If traversing motion is started within an activated protection zone, or at the limit of an activated protection zone, then alarm 10702 "NC protection zone violated during manual mode" or 10703 "Channel-specific protection zone violated during manual mode" is output – specifying the violated protection zone and the traversing axis – and motion is not started. The traversing motion can be performed when the relevant protection zone is temporarily enabled. The following actions must be performed for this:

- Generate a positive edge at the NC/PLC interface signal:
DB21, ... DBX1.1 (enable protection zone)
- Start the same traversing motion again

Note

The NC/PLC interface signal "Protection zone violated" is set when the temporarily enabled protection zone is traversed:

DB21, ... DBX276.0 – 277.1 (machine-specific protection zone 1 - 10 violated) == 1

or

DB21, ... DBX278.0 – 279.1 (channel-specific protection zone 1 - 10 violated) == 1

The enable signal is reset if a motion is started that does not lead into the enabled protection zone.

If further protection zones are affected by the traversing motion, additional alarms 10702 or 10703 are displayed for each protection zone. The protection zones displayed in the alarms can be enabled by creating further positive edges on the NC/PLC interface signal DB21, ... DBX1.1:

Behavior at change of operating mode

The protection zones temporarily enabled in JOG mode are retained after a change to AUTOMATIC or MDI mode. The temporary enable signals set in the AUTOMATIC or MDI mode are also retained after a change to JOG mode.

Reset of an enable

The enable signal is reset internally and on the NC/PLC interface at the next standstill of a geometry axis for which the temporarily enabled protection zone has been completely exited:

DB21, ... DBX276.0 – 277.1 (machine-specific protection zone 1 - 10 violated) == 0

or

DB21, ... DBX278.0 – 279.1 (channel-specific protection zone 1 - 10 violated) == 0

6.5 Boundary conditions

Restrictions in protection-zone monitoring

In the following cases, protection area monitoring is **not** possible:

- Traversing motion of orientation axes
- **Fixed machine**-specific protection zones for face transformation (TRANSMIT) or cylindrical surface transformation (TRACYL).
Exception: Protection areas that are symmetrical around the axis of rotation of the spindle axis. Here, no DRF offset must be active.
- Mutual monitoring of **tool**-related protection areas

Positioning axes

For positioning axes, only the programmed block end point is monitored. Alarm 10704 "Protection zone monitoring is not guaranteed" is output while a positioning axis traverses:

Axis interchange

With regard to the protection zones after an axis replacement, the starting position is the last position approached in the relinquishing channel. Traversing motion in the channel taking over is not taken into account. For this reason, you must ensure that an axis replacement is not performed from a position with protection zone violation.

If an axis intended for the axis interchange is not active in a channel, the position of the axis last approached in the channel is taken as the current position. If this axis has not yet been traversed in the channel, 0.0 is taken as the position.

Behavior for superimposed motions

Superimposed motions that are included in the main run, cannot be taken into account by the block preparation with regard to the active protection zones.

This results in the following reactions:

- Alarm 10704 "Protection zone monitoring is not guaranteed"
- DB31, ... DBX39.0 = 1 (protection area monitoring not guaranteed)

6.6 Example


6.6.1 Protection zone on a lathe

The following internal protection zones are to be defined for a turning machine:

- one machine-specific and workpiece-related protection zone for the spindle chuck, without limitation in the 3rd dimension
- one channel-specific protection zone for the workpiece, without limitation in the 3rd dimension
- one channel-specific, tool-related protection zone for the tool carrier, without limitation in the 3rd dimension

The workpiece zero is placed at machine zero to define the protection zone for the workpiece.

When activated, the protection zone is then offset by 100 mm in the Z axis in the positive direction.



6.6.2 Protection zone definition in the part program

Part program excerpt for protection zone definition:

Program code	Comment
DEF INT AB	
G18	; Working plane ZX
NPROTDEF(1,FALSE,0,0,0)	; Start of definition: Protection zone for spindle chuck
G01 X100 Z0	; Contour description: Traversing motion along the contour
G01 X-100 Z0	; Contour description: 1st Contour element
G01 X-100 Z110	; Contour description: 2nd Contour element
G01 X100 Z110	; Contour description: 3rd Contour element
G01 X100 Z0	; Contour description: 4th Contour element
EXECUTE(AB)	; End of definition: Protection zone for spindle chuck
CPROTDEF(1,FALSE,0,0,0)	; Start of definition: Protection zone for workpiece
G01 X80 Z0	; Contour description: Traversing motion along the contour
G01 X-80 Z0	; Contour description: 1st Contour element
G01 X-80 Z40	; Contour description: 2nd Contour element
G01 X80 Z40	; Contour description: 3rd Contour element
G01 X80 Z0	; Contour description: 4th Contour element
EXECUTE(AB)	; End of definition: Protection zone for workpiece
CPROTDEF(2,TRUE,0,0,0)	; Start of definition: Protection zone for toolholder
G01 X0 Z-50	; Contour description: Traversing motion along the contour
G01 X-190 Z-50	; Contour description: 1st Contour element
G03 X-210 Z-30 I-20	; Contour description: 2nd Contour element
G01 X-210 Z20	; Contour description: 3rd Contour element
G01 X0 Z50	; Contour description: 4th Contour element
G01 X0 Z-50	; Contour description: 5th Contour element
EXECUTE(AB)	; End of definition: Protection zone for toolholder

6.6.3 Protection zone definition with system variables

Machine-specific protection zone for the spindle chuck

System variable	Value	Description
\$SN_PA_ACTIV_IMMED[0]	0	Protection zone for spindle chuck not immediately active
\$SN_PA_T_W[0]	0	The protection zone for the spindle chuck is workpiece-related
\$SN_PA_ORI[0]	1	Orientation of the protection zone: 1 = 3rd and 1st geometry axis

6.6 Example

System variable	Value	Description
\$SN_PA_LIM_3DIM[0]	0	Type of limitation in the 3rd dimension: 0 = No limit
\$SN_PA_PLUS_LIM[0]	0	Value of the limit in the positive direction in the 3rd dimension
\$SN_PA_MINUS_LIM[0]	0	Value of the limit in the minus direction in the 3rd dimension
\$SN_PA_CONT_NUM[0]	4	Number of valid contour elements
\$SN_PA_CONT_TYP[0,0]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for spindle chuck, contour element 1
\$SN_PA_CONT_TYP[0,1]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for spindle chuck, contour element 2
\$SN_PA_CONT_TYP[0,2]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for spindle chuck, contour element 3
\$SN_PA_CONT_TYP[0,3]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for spindle chuck, contour element 4
\$SN_PA_CONT_TYP[0,4]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for spindle chuck, contour element 5
\$SN_PA_CONT_TYP[0,5]	0	Contour type[<i>] : 0 = not defined, protection zone for spindle chuck, contour element 6
\$SN_PA_CONT_TYP[0,6]	0	Contour type[<i>] : 0 = not defined, protection zone for spindle chuck, contour element 7
\$SN_PA_CONT_TYP[0,7]	0	Contour type[<i>] : 0 = not defined, protection zone for spindle chuck, contour element 8
\$SN_PA_CONT_TYP[0,8]	0	Contour type[<i>] : 0 = not defined, protection zone for spindle chuck, contour element 9
\$SN_PA_CONT_TYP[0,9]	0	Contour type[<i>] : 0 = not defined, protection zone for spindle chuck, contour element 10
\$SN_PA_CONT_ORD[0,0]	-100	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 1
\$SN_PA_CONT_ORD[0,1]	-100	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 2
\$SN_PA_CONT_ORD[0,2]	100	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 3
\$SN_PA_CONT_ORD[0,3]	100	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 4
\$SN_PA_CONT_ORD[0,4]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 5
\$SN_PA_CONT_ORD[0,5]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 6
\$SN_PA_CONT_ORD[0,6]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 7
\$SN_PA_CONT_ORD[0,7]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 8
\$SN_PA_CONT_ORD[0,8]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 9
\$SN_PA_CONT_ORD[0,9]	0	End point of contour[<i>], ordinate value protection zone for spindle chuck, contour element 10
\$SN_PA_CONT_ABS[0,0]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 1

System variable	Value	Description
\$SN_PA_CONT_ABS[0,1]	110	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 2
\$SN_PA_CONT_ABS[0,2]	110	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 3
\$SN_PA_CONT_ABS[0,3]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 4
\$SN_PA_CONT_ABS[0,4]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 5
\$SN_PA_CONT_ABS[0,5]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 6
\$SN_PA_CONT_ABS[0,6]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 7
\$SN_PA_CONT_ABS[0,7]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 8
\$SN_PA_CONT_ABS[0,8]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 9
\$SN_PA_CONT_ABS[0,9]	0	End point of contour[<i>], abscissa value protection zone for spindle chuck, contour element 10
\$SN_PA_CENT_ORD[0,0]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 1
\$SN_PA_CENT_ORD[0,1]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 2
\$SN_PA_CENT_ORD[0,2]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 3
\$SN_PA_CENT_ORD[0,3]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 4
\$SN_PA_CENT_ORD[0,4]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 5
\$SN_PA_CENT_ORD[0,5]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 6
\$SN_PA_CENT_ORD[0,6]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 7
\$SN_PA_CENT_ORD[0,7]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 8
\$SN_PA_CENT_ORD[0,8]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 9
\$SN_PA_CENT_ORD[0,9]	0	Center point of circular contour[<i>], ordinate value protection zone for spindle chuck, contour element 10
\$SN_PA_CENT_ABS[0,0]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 1
\$SN_PA_CENT_ABS[0,1]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 2
\$SN_PA_CENT_ABS[0,2]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 3
\$SN_PA_CENT_ABS[0,3]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 4

6.6 Example

System variable	Value	Description
\$SN_PA_CENT_ABS[0,4]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 5
\$SN_PA_CENT_ABS[0,5]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 6
\$SN_PA_CENT_ABS[0,6]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 7
\$SN_PA_CENT_ABS[0,7]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 8
\$SN_PA_CENT_ABS[0,8]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 9
\$SN_PA_CENT_ABS[0,9]	0	Center point of circular contour[<i>], abscissa value protection zone for spindle chuck, contour element 10

Channel-specific protection zone for the workpiece

System variable	Value	Remark
\$SC_PA_ACTIV_IMMED[0]	0	Protection zone for workpiece not immediately active
\$SC_PA_TW[0]	0	Protection zone for workpiece is workpiece-related
\$SC_PA_ORI[0]	1	Orientation of the protection zone: 1 = 3rd and 1st geometry axis
\$SC_PA_LIM_3DIM[0]	0	Type of limitation in the 3rd dimension: 0 = no limitation
\$SC_PA_PLUS_LIM[0]	0	Value of the limit in the positive direction in the 3rd dimension
\$SC_PA_MINUS_LIM[0]	0	Value of the limit in the minus direction in the 3rd dimension
\$SC_PA_CONT_NUM[0]	4	Number of valid contour elements
\$SC_PA_CONT_TYP[0,0]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone workpiece, contour element 1
\$SC_PA_CONT_TYP[0,1]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone workpiece, contour element 2
\$SC_PA_CONT_TYP[0,2]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone workpiece, contour element 3
\$SC_PA_CONT_TYP[0,3]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone workpiece, contour element 4
\$SC_PA_CONT_TYP[0,4]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone workpiece, contour element 5
\$SC_PA_CONT_TYP[0,5]	0	Contour type[<i>] : 0 = not defined, protection zone for workpiece, contour element 6
\$SC_PA_CONT_TYP[0,6]	0	Contour type[<i>] : 0 = not defined, protection zone for workpiece, contour element 7
\$SC_PA_CONT_TYP[0,7]	0	Contour type[<i>] : 0 = not defined, protection zone for workpiece, contour element 8
\$SC_PA_CONT_TYP[0,8]	0	Contour type[<i>] : 0 = not defined, protection zone for workpiece, contour element 9
\$SC_PA_CONT_TYP[0,9]	0	Contour type[<i>] : 0 = not defined, protection zone for workpiece, contour element 10
\$SC_PA_CONT_ORD[0,0]	-80	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 1

System variable	Value	Remark
\$SC_PA_CONT_ORD[0,1]	-80	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 2
\$SC_PA_CONT_ORD[0,2]	80	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 3
\$SC_PA_CONT_ORD[0,3]	80	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 4
\$SC_PA_CONT_ORD[0,4]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 5
\$SC_PA_CONT_ORD[0,5]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 6
\$SC_PA_CONT_ORD[0,6]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 7
\$SC_PA_CONT_ORD[0,7]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 8
\$SC_PA_CONT_ORD[0,8]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 9
\$SC_PA_CONT_ORD[0,9]	0	End point of contour[<i>], ordinate value protection zone for workpiece, contour element 10
\$SC_PA_CONT_ABS[0,0]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 1
\$SC_PA_CONT_ABS[0,1]	40	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 2
\$SC_PA_CONT_ABS[0,2]	40	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 3
\$SC_PA_CONT_ABS[0,3]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 4
\$SC_PA_CONT_ABS[0,4]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 5
\$SC_PA_CONT_ABS[0,5]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 6
\$SC_PA_CONT_ABS[0,6]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 7
\$SC_PA_CONT_ABS[0,7]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 8
\$SC_PA_CONT_ABS[0,8]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 9
\$SC_PA_CONT_ABS[0,9]	0	End point of contour[<i>], abscissa value protection zone for workpiece, contour element 10
\$SC_PA_CENT_ORD[0,0]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 1
\$SC_PA_CENT_ORD[0,1]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 2
\$SC_PA_CENT_ORD[0,2]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 3
\$SC_PA_CENT_ORD[0,3]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 4

6.6 Example

System variable	Value	Remark
\$SC_PA_CENT_ORD[0,4]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 5
\$SC_PA_CENT_ORD[0,5]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 6
\$SC_PA_CENT_ORD[0,6]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 7
\$SC_PA_CENT_ORD[0,7]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 8
\$SC_PA_CENT_ORD[0,8]	0	Center point of circular contour[<i>], ordinate value protection zone for workpiece, contour element 9
\$SC_PA_CENT_ORD[0,9]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 10
\$SC_PA_CENT_ABS[0,0]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 1
\$SC_PA_CENT_ABS[0,1]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 2
\$SC_PA_CENT_ABS[0,2]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 3
\$SC_PA_CENT_ABS[0,3]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 4
\$SC_PA_CENT_ABS[0,4]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 5
\$SC_PA_CENT_ABS[0,5]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 6
\$SC_PA_CENT_ABS[0,6]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 7
\$SC_PA_CENT_ABS[0,7]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 8
\$SC_PA_CENT_ABS[0,8]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 9
\$SC_PA_CENT_ABS[0,9]	0	Center point of circular contour[<i>], abscissa value protection zone for workpiece, contour element 10

Channel-specific protection zone for the tool holder

System variable	Value	Remark
\$SC_PA_ACTIV_IMMED[1]	0	Protection zone for tool holder not immediately active
\$SC_PA_TW[1]	3	Protection zone for the tool holder is tool-related
\$SC_PA_ORI[1]	1	Orientation of the protection zone: 1 = 3rd and 1st geometry axis
\$SC_PA_LIM_3DIM[1]	0	Type of limitation in the 3rd dimension: 0 = no limitation
\$SC_PA_PLUS_LIM[1]	0	Value of the limit in the positive direction in the 3rd dimension
\$SC_PA_MINUS_LIM[1]	0	Value of the limit in the minus direction in the 3rd dimension
\$SC_PA_CONT_NUM[1]	5	Number of valid contour elements
\$SC_PA_CONT_TYP[1,0]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone tool holder, contour element 1

System variable	Value	Remark
\$SC_PA_CONT_TYP[1,1]	3	Contour type[<i>] : 3 = G3 for circle element, counter clockwise, protection zone for tool holder, contour element 2
\$SC_PA_CONT_TYP[1,2]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for tool holder, contour element 3
\$SC_PA_CONT_TYP[1,3]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for tool holder, contour element 4
\$SC_PA_CONT_TYP[1,4]	1	Contour type[<i>] : 1 = G1 for straight line, protection zone for tool holder, contour element 5
\$SC_PA_CONT_TYP[1,5]	0	Contour type[<i>] : 0 = not defined, protection zone for tool holder, contour element 6
\$SC_PA_CONT_TYP[1,6]	0	Contour type[<i>] : 0 = not defined, protection zone for tool holder, contour element 7
\$SC_PA_CONT_TYP[1,7]	0	Contour type[<i>] : 0 = not defined, protection zone for tool holder, contour element 8
\$SC_PA_CONT_TYP[1,8]	0	Contour type[<i>] : 0 = not defined, protection zone for tool holder, contour element 9
\$SC_PA_CONT_TYP[1,9]	0	Contour type[<i>] : 0 = not defined, protection zone for tool holder, contour element 10
\$SC_PA_CONT_ORD[1,0]	-190	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 1
\$SC_PA_CONT_ORD[1,1]	-210	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 2
\$SC_PA_CONT_ORD[1,2]	-210	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 3
\$SC_PA_CONT_ORD[1,3]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 4
\$SC_PA_CONT_ORD[1,4]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 5
\$SC_PA_CONT_ORD[1,5]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 6
\$SC_PA_CONT_ORD[1,6]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 7
\$SC_PA_CONT_ORD[1,7]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 8
\$SC_PA_CONT_ORD[1,8]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 9
\$SC_PA_CONT_ORD[1,9]	0	End point of contour[<i>], ordinate value protection zone for tool holder, contour element 10
\$SC_PA_CONT_ABS[1,0]	-50	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 1
\$SC_PA_CONT_ABS[1,1]	-30	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 2
\$SC_PA_CONT_ABS[1,2]	20	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 3
\$SC_PA_CONT_ABS[1,3]	50	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 4

6.6 Example

System variable	Value	Remark
\$SC_PA_CONT_ABS[1,4]	-50	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 5
\$SC_PA_CONT_ABS[1,5]	0	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 6
\$SC_PA_CONT_ABS[1,6]	0	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 7
\$SC_PA_CONT_ABS[1,7]	0	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 8
\$SC_PA_CONT_ABS[1,8]	0	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 9
\$SC_PA_CONT_ABS[1,9]	0	End point of contour[<i>], abscissa value protection zone for tool holder, contour element 10
\$SC_PA_CENT_ORD[1,0]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 1
\$SC_PA_CENT_ORD[1,1]	-190	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 2
\$SC_PA_CENT_ORD[1,2]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 3
\$SC_PA_CENT_ORD[1,3]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 4
\$SC_PA_CENT_ORD[1,4]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 5
\$SC_PA_CENT_ORD[1,5]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 6
\$SC_PA_CENT_ORD[1,6]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 7
\$SC_PA_CENT_ORD[1,7]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 8
\$SC_PA_CENT_ORD[1,8]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 9
\$SC_PA_CENT_ORD[1,9]	0	Center point of circular contour[<i>], ordinate value protection zone for tool holder, contour element 10
\$SC_PA_CENT_ABS[1,0]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 1
\$SC_PA_CENT_ABS[1,1]	-30	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 2
\$SC_PA_CENT_ABS[1,2]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 3
\$SC_PA_CENT_ABS[1,3]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 4
\$SC_PA_CENT_ABS[1,4]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 5
\$SC_PA_CENT_ABS[1,5]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 6
\$SC_PA_CENT_ABS[1,6]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 7

System variable	Value	Remark
\$SC_PA_CENT_ABS[1,7]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 8
\$SC_PA_CENT_ABS[1,8]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 9
\$SC_PA_CENT_ABS[1,9]	0	Center point of circular contour[<i>], abscissa value protection zone for tool holder, contour element 10

6.6.4 Activating protection zones

Part program excerpt for activating protection zones for spindle chuck, workpiece, and tool holder:

Program code	Comment
NPROT(1,2,0,0,0)	; Protection zone: Spindle chuck
CPROT(1,2,0,0,100)	; Protection zone: Workpiece with 100 mm offset in the Z axis
CPROT(2,2,0,0,0)	; Protection zone: Toolholder

6.7 Data lists

6.7.1 Machine data

6.7.1.1 NC-specific machine data

Number	Identifier: \$MN_	Description
10618	PROTAREA_GEOAX_CHANGE_MODE	Response for a transformation change and geometry axis interchange
18190	MM_NUM_PROTECT_AREA_NCK	Number of available machine-specific protection zones

6.7.1.2 Channelspecific machine data

Number	Identifier: \$MC_	Description
28200	MM_NUM_PROTECT_AREA_CHAN (SRAM)	Number of available channel-specific protection zones
28210	MM_NUM_PROTECT_AREA_ACTIVE	Maximum number of protection zones that can be activated simultaneously in the channel
28212	MM_NUM_PROTECT_AREA_CONTUR	Maximum number of definable contour elements in the channel

Axis monitoring functions

7.1 Contour monitoring

7.1.1 Contour error

Contour errors are caused by signal distortions in the position control loop.

Signal distortions can be linear or non-linear.

Linear signal distortions

Linear signal distortions are caused by:

- Speed and position controller not being set optimally
- Unequal following errors of the axes involved in the path
In this regard, the feedforward control types, DSC setting and equivalent time constants of the feedforward control should usually be set the same. Additional checks should include: Position setpoint filter (e.g. AX_JERK_MODE and AX_JERK_TIME), as well as Kv (in particular for FFWOF, FFW_MODE=0 or FFW_MODE=3).
- Unequal dynamic response of the feed drives
Unequal drive dynamic responses lead to path deviations especially on contour changes. Circles are distorted into ellipses by unequal dynamic responses of the two feed drives.

Non-linear signal distortions

Non-linear signal distortions are caused by:

- Activation of the current limitation within the machining area
- Activation of the limitation of the speed setpoint
- Range of inversion within and/or outside of the position control loop
When traversing a circular path, contour errors occur primarily due to the reversal error and friction.
During motion along straight lines, a contour error arises due to a reversal error outside the position control loop, e.g. due to a tilting milling spindle. This causes a parallel offset between the actual and the set contour. The shallower the gradient of the straight line, the larger the offset.
- Nonlinear friction behavior of slide guides

7.1.2 Following-error monitoring

Function

In control engineering terms, traversing along a machine axis always produces a certain following error, i.e. a difference between the set and actual position.

The following error that arises depends on:

- Position control loop gain
MD32200 \$MA_POSCTRL_GAIN (servo gain factor)
- Maximum acceleration
MD32300 \$MA_MAX_AX_ACCEL (maximum axis acceleration)
- Maximum velocity
MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)
- With activated feedforward control:
Precision of the path model and the parameters:
MD32610 \$MA_VELO_FFW_WEIGHT (factor for the velocity feedforward control)
MD32620 \$MA_FFW_MODE (feedforward control mode)
MD32800 \$MA_EQUIV_CURRCTRL_TIME (equivalent time constant current control loop for feedforward control)
MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant speed control loop for feedforward control)
- Position setpoint filter
MD32402 \$MA_AX_JERK_MODE (filter type for axial jerk limitation)
MD32410 \$MA_AX_JERK_TIME (time constant for the axial jerk filter)
MD32910 4ma_dyn_match_TIME (time constant for dynamic response adaptation)

In the acceleration phase, the following error initially increases when traversing along a machine axis. After a time depending on the parameterization of the position control loop, the following error then remains constant in the ideal case. Due to external influences, more or less large fluctuations in the following error always arise during a machining process. To prevent these fluctuations in the following error from triggering an alarm, a tolerance range within which the following error may change must be defined for the following-error monitoring:

MD36400 \$MA_CONTOUR_TOL (Contour monitoring tolerance range)




Figure 7-1 Following-error monitoring

Effectiveness

The following-error monitoring only operates with active position control and the following axis types:

- Linear axes with and without feedforward control
- Rotary axes with and without feedforward control
- Position-controlled spindles

Fault

If the configured tolerance limit is exceeded, the following alarm appears:

25050 "Axis <Axis name> Contour monitoring"

The affected axis/spindle is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME


(maximum time for braking ramp when an error occurs)

7.2 Positioning, zero speed and clamping monitoring

7.2.1 Correlation between positioning, zero-speed and clamping monitoring

Overview

The following overview shows the correlation between the positioning, zero speed and clamping monitoring functions:



7.2.2 Positioning monitoring

Function

At the end of a positioning operation:

- Set velocity = 0 **AND**
- DB31, ... DBX64.6/7 (motion command minus/plus) = 0

checks the position monitoring to ensure that the following error of every participating machine axis is smaller than the exact-stop fine tolerance during the delay time.

MD36010 \$MA_STOP_LIMIT_FINE (exact stop fine)

MD36020 \$MA_POSITIONING_TIME (delay time exact stop fine)

After reaching "Exact stop fine", the position monitoring is deactivated.

Note

The smaller the exact stop fine tolerance is, the longer the positioning operation takes and the longer the time until block change.

Rules for MD setting

MD36010 \$MA_STOP_LIMIT_FINE	MD36020 \$MA_POSITIONING_TIME
Large	Can be selected relatively short
Small	Must be selected relatively long

MD32200 \$MA_POSCTRL_GAIN (servo gain factor)	MD36020 \$MA_POSITIONING_TIME
Small	Must be selected relatively long
Large	Can be selected relatively short

Effectiveness

The position monitoring only operates with active position control and the following axis types:

- Linear axes
- Rotary axes
- Position-controlled spindles

Fault

If the configured position-monitoring time is exceeded, the following alarm appears:

25080 "Axis <Axis name> Position monitoring"

The affected axis is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME

(maximum time for braking ramp when an error occurs)

7.2.3 Zero-speed monitoring

Function

At the end of a positioning operation:

- Set velocity = 0 **AND**
- DB31, ... DBX64.6/7 (motion command minus/plus) = 0

checks the zero-speed monitoring to ensure that the following error of every participating machine axis is smaller than the standstill tolerance during the delay time.

MD36040 \$MA_STANDSTILL_DELAY_TIME (zero-speed monitoring delay time)

MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance)

After reaching the required exact-stop state, the positioning operation is completed:

DB31, ... DBX60.6/7 (position reached with exact stop coarse/fine) = 1

The position-monitoring function is deactivated and is replaced by the zero-speed monitoring.

Zero-speed monitoring monitors the adherence to the standstill tolerance. If no new travel request is received, the machine axis must not depart from the standstill tolerance.

Effectiveness

The zero-speed monitoring only operates with active position control and the following axis types:

- Linear axes
- Rotary axes
- Position-controlled spindles

Fault

If the delay time and/or the standstill tolerance is exceeded, the following alarm appears:

25040 "Axis <Axis name> Zero-speed monitoring"

The affected axis is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME

(maximum time for braking ramp when an error occurs)

7.2.4 Parameter set-dependent exact stop and standstill tolerance

For adaptation to different machining situations and/or axis dynamics, e.g.:

- Operating state A: High precision, long machining time
- Operating state B: Lower precision, shorter machining time
- Changing of the mass relationships after gear change

the positioning tolerances:

- MD36000 \$MA_STOP_LIMIT_COARSE (exact stop coarse)
- MD36010 \$MA_STOP_LIMIT_FINE (exact stop fine)
- MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance)

can be weighted with a common factor depending on the parameter set:

MD36012 \$MA_STOP_LIMIT_FACTOR (exact stop coarse/fine and standstill factor)

Because the factor applies in common for all three position tolerances, the relationship between the values remains constant.

7.2.5 Clamping monitoring

7.2.5.1 Function

For machine axes that are mechanically clamped upon completion of a positioning operation, a displacement of the axis from the position setpoint can result from the clamping process. Setting the NC/PLC interface signal DB31, ... DBX2.3 (clamping in progress) causes the clamping tolerance (MD36050 \$MA_CLAMP_POS_TOL) rather than the standstill tolerance (MD36030 \$MA_STANDSTILL_POS_TOL) to be monitored for the duration of the clamping process. Alarm 26000 "clamping monitoring" is issued if the clamping tolerance is overshoot.

Alarm delay time

If a time-limited overshooting of the clamping tolerance is permitted, an alarm delay time must be specified via machine data MD36051 \$MA_CLAMP_POS_TOL_TIME. The alarm is then output only after expiration of the parameterized time when the clamping tolerance is overshoot. No alarm is output when the clamping tolerance is undershot again after expiration of the time. The time is restarted when the clamping tolerance is overshoot again.

To permit a response to overshooting the clamping tolerance prior to expiration of the alarm delay time, the axis-specific NC/PLC interface signal DB31, ... DBX102.3 (clamping tolerance overshoot) is set. The signal is reset again when the clamping tolerance is undershot.

7.2.5.2 Machine data

Clamping tolerance

The clamping tolerance, which is higher than the standstill tolerance, is entered in machine data:

MD36050 \$MA_CLAMP_POS_TOL[<axis>] = <clamping tolerance>

Alarm delay time

If a time-limited overshooting of the clamping tolerance is tolerated, the maximum permissible alarm delay time must be specified in the machine data.

MD36051 \$MA_CLAMP_POS_TOL_TIME[<axis>] = <alarm delay time>

When the clamping tolerance is exceeded, alarm 26000 "Clamping monitoring" is only displayed after the alarm delay time has elapsed.

An alarm is not output, if the clamping tolerance is fallen below again before the alarm delay time lapses.

The alarm delay time is restarted when the clamping tolerance is exceeded again.

Special clamping functions

The special clamping functions that automate the release and set of the part program execution sequence are activated bit-by-bit using machine data:

MD36052 \$MA_STOP_ON_CLAMPING[<Achse>], <bit> = <value>

<Bit>	<Value>	Meaning
0	Automatic stop to release the clamping	
	0	Not active
	1	Active
1	Optimized clamping release	
	0	Not active
	1	Active, precondition: Bit 0 == 1
2	Automatic stop to set the clamping	
	0	Not active
	1	Active

7.2.5.3 NC/PLC interface signals

Activating the clamping monitoring

The clamping monitoring is activated by setting the NC/PLC interface signal:

DB31, ... DBX2.3 = 1 (clamping in progress)

Overshooting the clamping tolerance

Overshooting the clamping tolerance is indicated with the NC/PLC interface signal:

DB31, ... DBX102.3 == 1 (clamping tolerance overshoot)

The signal is **set** when the clamping tolerance is overshoot within the alarm delay time.

The signal is **reset** when the clamping tolerance is undershot within the alarm delay time or the follow-up mode is activated for the axis.

7.2.5.4 Fault responses

Fault responses when the clamping tolerance is exceeded:

- Alarm 26000 "Clamping monitoring" is indicated
- The axis is brought to a standstill with the parameterized maximum acceleration:
MD32300 \$MA_MAX_AX_ACCEL
Whereby, the maximum duration of the braking ramp for error states is monitored:
MD36610 \$MA_AX_EMERGENCY_STOP_TIME

- Follow-up mode is activated for the axis:
DB31, ... DBX61.3 == 1
- The "clamping tolerance exceeded" signal is reset:
DB31, ... DBX102.3 == 0

7.2.5.5 "Automatic stop to release the clamping" clamping function

The "Automatic stop to release the clamping" clamping function adds an NC-internal stop before the traversing block of the clamping axis for continuous-path mode.

The stop is not effective or the continuous-path mode is not interrupted if the controller enable signal (DB31, ... DBX2.1) of the clamping axis is set prior to the block change.

If the controller enable signal of the clamping axis is **not** set prior to the block change, the stop acts.

Parameterization

MD36052 \$MA_STOP_ON_CLAMPING[<clamping axis>] = 'H01'

Requirements/assumptions


- If, for the clamping axis there is a **traversing command** (DB31, ... DBX64.6 / .7), then the clamping is **released** by the PLC user program.
- The following relationship must exist between the controller enable signal (DB31, ... DBX2.1) and the clamping of the clamping axis:

Controller enable	⇒	Clamping axis
not set	⇒	Clamped
Set	⇒	Not clamped

Example:

Program code	Comment
N100 G0 X0 Y0 Z0 A0 G90 G54 F500	; Approach initial state
N101 G641 ADIS=.1 ADISPOS=5	; Activate continuous-path mode
N210 G1 X10	; Traversing block
N220 G1 X5 Y20	; "
N310 G0 Z50	; Positioning block
N410 G0 A90	; " (clamping axis)
N510 G0 X100	; "
N520 G0 Z2	; "
N610 G1 Z-4	; Traversing block
N620 G1 X0 Y-20	; "

Schematic change of the NC/PLC interface signals and states for the N310 and N410 blocks:



- ① NC: The automatically inserted stop causes a stop at the N310 block end.
- ② NC → PLC: After the block change, the travel command for the clamping axis is set.
PLC: The clamping is released based on the travel command.
- ③ PLC → NC: The clamping pressure is removed appropriately. The clamping axis is enabled for traversal.

7.2.5.6 "Time-optimized release of the clamping" clamping function

The "Time-optimized release of the clamping" clamping function in conjunction with the "Automatic stop to release the clamping" clamping function for continuous-path mode requests the release of the clamping NC-internal by the Look Ahead setting of the travel command for the clamping axis. The travel command is set only when until the traversal of the clamping axis, positioning (G0 blocks) but no processing (G1 blocks) is performed.

To obtain the reference to the traversing block of the clamping axis, the travel command prefixes a maximum of two rapid traverse blocks (G0), including any internally generated intermediate blocks, to the traversing block.

Activation

MD36052 \$MA_STOP_ON_CLAMPING[<clamping axis>] = 'H03'


Requirements/assumptions

- If, for the clamping axis there is a **traversing command** (DB31, ... DBX64.6 / .7), then the clamping is **released** by the PLC user program.
- While other axes are traversing with rapid traverse (G0), the clamping axis must **not** be clamped.

Example:

Program code	Comment
N100 G0 X0 Y0 Z0 A0 G90 G54 F500	; Approach initial state
N101 G641 ADIS=.1 ADISPOS=5	; Activate continuous-path mode
N210 G1 X10	; Machining block
N220 G1 X5 Y20	; "
N310 G0 Z50	; Positioning block
N410 G0 A90	; " (clamping axis)
N510 G0 X100	; "
N520 G0 Z2	; "
N610 G1 Z-4	; Machining block
N620 G1 X0 Y-20	; "

Schematic change of the NC/PLC interface signals and states for the N220 to N410 blocks:



- ① NC → PLC: The travel command for the clamping axis is set because of the block change.
PLC: The clamping is released based on the travel command.
- ② PLC → NC: The clamping pressure is removed appropriately. The clamping axis is enabled for traversal.

7.2.5.7 "Automatic stop to set the clamping" clamping function

The clamping process takes a while. In continuous-path mode, an explicit stop of the traversing must be provided by programming, e.g. G09, G60 or auxiliary function output, so that the clamping is reliably active before machining started.

The "Automatic stop to set the clamping" clamping function stops the traversing automatically in continuous-path mode. Clamping motion is stopped **before** or **in the** next machining block (traversing block without rapid traverse G0), if the clamping axis has not clamped up until then. The criterion that clamping has taken place and additional traversing motion has been enabled is the setting of the channel-specific feedrate override by the PLC user program not equal to 0% (DB21, ... DBB4 ≠ 0%)

Activation

MD36052 \$MA_STOP_ON_CLAMPING[<clamping axis>] = 'H04'


Requirements/assumptions

- If, for the clamping axis, there is **no** traversing command (DB31, ... DBX64.6 / .7), then the clamping is **closed** by the PLC user program.
- While other axes are traversing with rapid traverse (G0), the clamping axis must **not** be clamped.
- If the channel-specific feedrate override **is not equal to 0%** (DB21, ... DBB4 ≠ 0%), then the clamping axis is **clamped**.

Example

Program code	Comment
N100 G0 X0 Y0 Z0 A0 G90 G54 F500	; Approach initial state
N101 G641 ADIS=.1 ADISPOS=5	; Activate continuous-path mode
N210 G1 X10	; Machining block
N220 G1 X5 Y20	; "
N310 G0 Z50	; Positioning block
N410 G0 A90	; " (clamping axis)
N510 G0 X100	; "
N520 G0 Z2	; "
N610 G1 Z-4	; Machining block
N620 G1 X0 Y-20	; "

Schematic change of the NC/PLC interface signals and states for the N410 to N610 blocks:



- ① NC → PLC: The travel command for the clamping axis is reset because of the block change.
- ② PLC: The clamping is initiated
- ③ PLC → NC: The clamping pressure is sufficiently large to reset the controller enable
- ④ PLC → NC: Enable the N610 machining by setting the channel-specific feedrate override not 0%.

7.2.5.8 Supplementary conditions

Interrupted continuous-path mode

If during the above-described clamping functions, the continuous-path mode and thus also the "LookAhead" function is interrupted by blocks without traversing (e.g. output of an M function M82/M83), the functions behave as follows:

- Clamping function: "Time-optimized release of the axis clamping"**
 (MD36052 \$MA_STOP_ON_CLAMPING[<axis>] = 'B011')
 The function no longer acts because the travel command is set in Look Ahead mode only for blocks with active continuous-path mode. The output of the M function M82 in block N320 of the sample program below stops the traversing and so interrupts the continuous-path mode.
 The Look Ahead stopping on N410 by the function is not necessary because stopping occurs anyway by N320.
- Clamping function: "Automatic stop to set the clamping":**
 (MD36052 \$MA_STOP_ON_CLAMPING[<axis>] = 'B100')
 The function generates a stop irrespective of M83 that is executed as a function of "feedrate override 0%". The axis is thus stopped before the first machining block.

Note**Using clamping functions without clamping**

The following clamping functions can also be used independent of clamping the axis:

- "Automatic stop to release the clamping":
MD36052 \$MA_STOP_ON_CLAMPING[<axis>] = 'B001'
Behavior: A stop is made in the current block on the path when the controller enable (DB31, ... DBX2.1) for the parameterized <axis> is **not** set, but it is traversed in one of the following blocks.
- "Automatic stop to set the clamping":
MD36052 \$MA_STOP_ON_CLAMPING[<axis>] = 'B100'
Behavior: A stop is made in the current block on the path when at the transition from rapid traverse blocks (G0) to traversing blocks (G1), the channel-specific feedrate override (DB21, ... DBB4) is 0%.

In both cases it is ensured that the path motion in continuous-path mode is already stopped before the start of the relevant part program block and not just within the block.

Table 7-1 Sample program: Interrupted continuous-path mode

Program code	Comment
N100 G0 X0 Y0 Z0 A0 G90 G54 F500	; Approach initial state
N101 G641 ADIS=.1 ADISPOS=5	; Activate continuous-path mode
N210 G1 X10	; Traversing block
N220 G1 X5 Y20	; "
N310 G0 Z50	; Rapid traverse block
N320 M82	; Interrupt continuous-path mode
N410 G0 A90	; Rapid traverse block
N420 M83	; Interrupt continuous-path mode
N510 G0 X100	; Rapid traverse block
N520 G0 Z2	; "
N610 G1 Z-4	; Traversing block
N620 G1 X0 Y-20	; "

Block change criterion: Clamping tolerance

After activation of clamping monitoring (DB31, ... DBX2.3), the block change criterion for traversing blocks in which the stop is made at the end of the block, the clamping tolerance rather than the exact stop condition acts for the clamping axis:

MD36050 \$MA_CLAMP_POS_TOL (clamping tolerance with interface signal "Clamping active")

Behavior for releasing the clamping

If the clamping axis was moved by the clamping process from the position setpoint, it is returned by the NC to the position setpoint after releasing the clamping and setting the (DB31, ... DBX2.1)

controller enable signal. Repositioning depends on whether "Follow-up mode" was activated for the axis during the clamping process:

- DB31, ... DBX1.4 == 0 (follow-up mode not active) ⇒ Abrupt by the position controller
- DB31, ... DBX1.4 == 1 (follow-up mode active) ⇒ interpolatory method

Note

The following data can be evaluated by the PLC user program as the criterion for activating the follow-up mode (DB31, ... DBX1.4):

- DB31, ... DBX60.6/7 (position reached with coarse/fine exact stop)
 - Actual position of the clamping axis
-

Follow-up mode

The clamping monitoring is not active in follow-up mode

DB31, ... DBX1.4 == 1 (follow-up mode).

7.3 Speed-setpoint monitoring

Function

The speed setpoint comprises:

- Speed setpoint of the position controller
- Speed setpoint portion of the feedforward control (with active feedforward control only)
- Drift compensation (only for drives with analog setpoint interface)




Figure 7-2 Speed setpoint calculation

The speed-setpoint monitoring ensures by limiting the control or output signal (10 V for analog setpoint interface or rated speed for digital drives) that the physical limitations of the drives are not exceeded:

MD36210 \$MA_CTRLOUT_LIMIT (maximum speed setpoint)




Figure 7-3 Speed setpoint limitation

Speed-setpoint monitoring delay

To prevent an error reaction from occurring in every speed-limitation instance, a delay time can be configured:

MD36220 \$MA_CTRLLOUT_LIMIT_TIME (speed-setpoint monitoring delay)

Only if the speed limitation is required for longer than the configured time does the corresponding error reaction occur.

Effectiveness

The speed-setpoint monitoring is only active for closed-loop position-controlled axes and cannot be deactivated.

Fault

If the configured delay time is exceeded, the following alarm appears:

25060 "Axis <Axis name> Speed-setpoint limitation"

The affected axis is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME
(maximum time for braking ramp when an error occurs)

Note

Upon reaching the speed-setpoint monitoring, the position feedback loop of the axis becomes non-linear due to the limitation. Contour errors result if the axis is involved in generating the contour.

7.4 Actual-velocity monitoring

Function

The actual-velocity monitoring checks that the actual velocity of a machine axis/spindle does not exceed the configured threshold:

MD36200 \$MA_AX_VELO_LIMIT (velocity-monitoring threshold)

The threshold should be 10-15% above the configured maximum velocity.

- For axes:
MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)
- For spindles:
MD35110 \$MA_GEAR_STEP_MAX_VELO_LIMIT[n] (maximum speed of gear stage)

If you use this setting the speed will not normally exceed the velocity-monitoring threshold (exception: Drive error).

Activation

The actual-velocity monitoring is activated as soon as the active measuring system returns valid actual values (encoder limit frequency not exceeded).

Effectiveness

The actual-velocity monitoring only operates with active position control and the following axis types:

- Linear axes
- Rotary axes
- Open-loop-controlled and position-controlled spindles

Fault

If the threshold is exceeded, the following alarm is displayed:

25030 "Axis <Axis name> Actual-velocity alarm limit"

The affected axis is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME
(maximum time for braking ramp when an error occurs)

7.5 Measuring system monitoring

The NC has no direct access to the measuring system hardware, therefore measuring system monitoring is mainly performed by the drive software.

Monitoring functions in the drive

- Monitoring of hardware faults (e.g. measuring system failure, wire breakage)
- Zero mark monitoring

Further information:

Function Manual Drive Functions SINAMICS S120

Measuring system monitoring functions carried out in the drive are mapped on the NC alarms (alarm 25000 and following) or NC reactions (e.g. abort of referencing or on-the-fly measuring). The exact behavior of the NC depends on the setting in the machine data:

MD36310 \$MA_ENC_ZERO_MONITORING

Value	Meaning	
= 0	Monitoring of HW faults:	ON If a hardware fault is detected in the active measuring system, POWER ON alarm 25000 is displayed: "Axis <Axis name> Hardware fault active encoder" The affected axis is stopped via the configured braking ramp in follow-up mode: MD36610 \$MA_AX_EMERGENCY_STOP_TIME (maximum time for braking ramp when a fault occurs) If a hardware fault is detected in the passive measuring system, alarm 25001 is displayed: "Axis <Axis name> Hardware fault passive encoder" There is no further alarm response.
	Zero-mark monitoring:	OFF Alarms 25020 and 25021 (see below) are suppressed.
= 100	No zero-mark monitoring as well as hiding of all encoder monitoring functions, i.e. in addition to alarm 25020 (25021), alarms 25000 (25001) and 25010 (25011) are suppressed.	
> 0 but < 100	Monitoring of HW faults:	ON (see above)
	Zero-mark monitoring:	ON If zero-mark monitoring is tripped in the active measuring system, alarm 25020 is displayed: "Axis <Axis name> Zero-mark monitoring active encoder" The affected axis is stopped via the configured braking ramp in follow-up mode: MD36610 \$MA_AX_EMERGENCY_STOP_TIME (maximum time for braking ramp when a fault occurs) If zero-mark monitoring is tripped in the passive measuring system, alarm 25021 is displayed: "Axis <Axis name> Zero-mark monitoring passive encoder" There is no further alarm response.
> 100	Monitoring of HW faults:	ON with attenuated error message: The POWER ON alarm 25000 is replaced by the reset alarm 25010 and the reset alarm 25001 replaced by the cancel alarm 25011.
	Zero-mark monitoring:	ON (see above)

For details on the alarms, see:

Further information:
Diagnostics Manual

Note

For hardware faults, the referencing status of the machine axis is reset:

DB31, ... DBX60.4/5 (referenced/synchronized 1/2) = 0

Monitoring functions in the NC

- Encoder-limit-frequency monitoring
- Plausibility check for absolute encoders

7.5.1 Encoder-limit-frequency monitoring

Function

The NC encoder-limit-frequency monitoring is based on the configuration and telegram information of the drive. It monitors that the encoder frequency does not exceed the configured encoder limit frequency:

MD36300 \$MA_ENC_FREQ_LIMIT (encoder limit frequency)

Encoder-limit-frequency monitoring always refers to the active measuring system selected in the NC/PLC interface:

DB31, ... DBX1.5/1.6 (position measuring system 1/2)

Effectiveness

The encoder limit frequency is operative for:

- Linear axes
- Rotary axes
- Open-loop-controlled and position-controlled spindles

Fault

Upon exceeding of the encoder limit frequency, the following occurs:

- Message to the PLC:
DB31, ... DBX60.2 or 60.3 = 1 (encoder limit frequency exceeded 1 or 2)
- Spindles
Spindles are not stopped but continue to turn with speed control.
If the spindle speed is reduced so much that the encoder frequency passes below the encoder limit frequency, the actual value system of the spindle is automatically resynchronized.
- Axes
The following alarm is displayed:
21610 "Channel <Channel number> Axis <Axis name> Encoder <Encoder number >
Frequency exceeded"
The affected axis is stopped via the configured braking ramp in follow-up mode:
MD36610 \$MA_AX_EMERGENCY_STOP_TIME
(maximum time for braking ramp when an error occurs)

Note

If the encoder limit frequency is exceeded, a position-controlled machine axis must be re-referenced (see Function Manual "Axes and Spindles", Section "R1: Referencing").

7.5.2 Plausibility check for absolute encoders

Function

With absolute encoders (MD30240 \$MA_ENC_TYPE = 4), absolute values supplied by the measuring system are used to check the plausibility of the actual value.

During the check, the NC compares the cyclic position value held in the position control cycle clock based on the incremental information from the encoder with a new position value generated directly from the absolute and incremental information and checks that the calculated position difference does not exceed the permissible deviation.

MD36310 \$MA_ENC_ZERO_MONITORING (permissible deviation in 1/2 coarse increments between the absolute and the incremental encoder track)

Note

The plausibility check of absolute encoders specifically detects all deviations caused by dirt on the absolute track or by faults when transferring the absolute value. However, small errors in the incremental track (burst interference, impulse errors) are not detected. In such instances the plausibility check only responds to deviations in the millimeter range. This form of monitoring should therefore serve as additional monitoring to assist the diagnosis of absolute-position faults.

Note**Rotary absolute encoders**

If the plausibility check is to be used for a rotary absolute encoder, the SINAMICS parameter p0979 must be taken into account when setting the modulo range (MD34220 \$MA_ENC_ABS_TURNS_MODULO).

Note**Upgrading the NC software**

If the plausibility check is activated in absolute encoders (MD36310 > 0), the existing MD36310 settings must be checked and, if necessary, increased during an upgrade of the NC software.

Zero mark diagnostics

With absolute encoders, the permissible deviation must be determined for the plausibility check during commissioning. This can be performed via the machine data:

MD36312 \$MA_ENC_ABS_ZEROMON_WARNING (zero-mark monitoring warning threshold)

Value	Meaning
0	No zero mark diagnostics
> 0	Permissible deviation in 1/2 coarse increments between the absolute and the incremental encoder track

Procedure when commissioning the system:

1. Deactivate zero-mark monitoring:
MD36310 \$MA_ENC_ZERO_MONITORING = 0
2. Activate zero-mark diagnostics:
MD36312 \$MA_ENC_ABS_ZEROMON_WARNING = 1
3. Move axis and monitor system variable \$VA_ENC_ZERO_MON_ERR_CNT (number of detected limit value violations).
4. If \$VA_ENC_ZERO_MON_ERR_CNT ≠ 0:
Increase MD36312 value and repeat step 3.
5. If \$VA_ENC_ZERO_MON_ERR_CNT = 0 (over a longer period of time!):
The correct value for MD36310 is located! Apply the value from MD36312 to MD36310 and then set MD36312 to "0".

Note

Depending on the rigidity of the machine (minimal load masses / moments of inertia are optimum) and the controller settings, the control play "oscillates" with varying degrees of intensity. Account must be taken of this by entering machine-specific limit values in MD36310.

Fault

Alarm 25020

If the plausibility check is tripped in the **active** measuring system, alarm 25020 is displayed:

"Axis <Axis name> Zero-mark monitoring active encoder"

The affected axis is stopped via the configured braking ramp in follow-up mode:

MD36610 \$MA_AX_EMERGENCY_STOP_TIME

(maximum time for braking ramp when an error occurs)

Alarm 25021

If the plausibility check is tripped in the **passive** measuring system, alarm 25021 is displayed:

"Axis <Axis name> Zero-mark monitoring passive encoder"

There is no further alarm response.

Note

In the event of a fault, the adjustment of the absolute encoder is lost and the axis is no longer referenced. The absolute encoder must be readjusted (see Function Manual "Axes and Spindles, Section "Referencing for absolute encoders").

Note

Errors in the incremental track that cannot be detected with amplitude monitoring can cause position deviations in the millimeter range. The deviation depends on the lattice pitch/line count and the traversing velocity of the axis when the error occurs.

Complete position monitoring is only possible through redundancy, i.e. through comparison with an independent second measuring system.

7.5.3 Customized error reactions

Customized zero-mark monitoring

The default alarm and reaction behavior of the zero-mark monitoring can be adapted in absolute measuring systems (MD30240 \$MA_ENC_TYPE = 4) with the aid of system variables. This allows you to perform your own monitoring using a synchronized action or OEM application and to use all of the reaction options available in this application, e.g.:

- Transmit alarm
- Use cycles (e.g. approach tool-change position)
- ...

Example:

Users can adjust the alarm and reaction behavior so that when machining an expensive workpiece, which could be damaged if the axis is stopped as a result of an alarm, machining

stops before the machining quality of the workpiece is assessed using appropriate synchronized action commands.

Effectiveness

Customized monitoring can be activated in parallel to or as an alternative to standard zero-mark monitoring, depending on the setting in machine data:

MD36310 \$MA_ENC_ZERO_MONITORING

Value	Meaning
0	If only user-specific monitoring is to be implemented, the default zero-mark monitoring must be deactivated: MD36310 = 0 and MD36312 = 0
> 0	Customized monitoring and standard zero-mark monitoring operate in parallel.
100	All encoder monitoring functions are deactivated.

If both monitoring functions are active (MD36310 > 0), you can perform **cascaded monitoring**.

Example:

If a value falls below the threshold specified in MD36310, customized monitoring triggers a prewarning; standard zero-marking monitoring will only detect a fault if the threshold is exceeded and will then deactivate automatically.

System variables

You can implement customized error reactions using the following system variables:


System variable	Meaning
\$VA_ENC_ZERO_MON_ERR_CNT[<n>,<axis>]	Number of detected limit value violations. Contains the current number of detected limit value violations when comparing the absolute and the incremental encoder tracks. The value is reset to 0 at: • POWER ON • Selection/deselection of parking Reset does not cause a reset.
\$VA_ABSOLUTE_ENC_DELTA_INIT[<n>,<axis>]	Initial difference for absolute encoders. Contains the initial difference between the last buffered absolute position in the static NC memory and the current absolute position. Format of the difference value: Number of internal increments (see MD10200 \$MN_INT_INCR_PER_MM or MD10210 \$MN_INT_INCR_PER_DEG) The value is updated at: • POWER ON • Warm restart • Deselection of parking • Return below the encoder limit frequency There is no reset at reset.

<n>: Encoder number

<axis>: Axis name

7.6 Limit switch monitoring

Overview of the end stops and possible limit-switch monitoring:



7.6.1 Hardware limit switch

Function

A hardware limit switch is normally installed at the end of the traversing range of a machine axis. It serves to protect against accidental overtravelling of the maximum traversing range of the machine axis while the machine axis is not yet referenced.

If the hardware limit switch is triggered, the PLC user program created by the machine manufacturer sets the corresponding interface signal:

DB31, ... DBX12.0/1 = 1 (hardware limit switch minus/plus)

Parameterization

The braking behavior of the machine axis upon reaching the hardware limit switch is configurable via the machine data:

MD36600 \$MA_BRAKE_MODE_CHOICE (braking behavior on hardware limit switch)

Value	Meaning
0	Braking with the configured axial acceleration
1	Rapid stop (set velocity = 0)

Effectiveness

The hardware limit-switch monitoring is active after the controller has ramped up in all modes.

Effect

Upon reaching the hardware limit switch, the following occurs:

- Alarm 21614 "Channel <channel number> axis <axis name> hardware limit switch <direction>"
- The machine axis is braked according to the configured braking behavior.
- If the axis/spindle is involved in interpolation with other axes/spindles, these are also braked according to their configured braking behavior.
- The traversing keys of the affected machine axis are blocked based on the direction.

7.6.2 Software limit switch

Function

Software limit switches serve to limit the traversing range of a machine axis. Per machine axis and per traversing direction, two (1st and 2nd) software limit switches are available:

MD36100 POS_LIMIT_MINUS (1st software limit switch minus)

MD36110 POS_LIMIT_PLUS (1st software limit switch plus)

MD36120 POS_LIMIT_MINUS2 (2nd software limit switch minus)

MD36130 POS_LIMIT_PLUS2 (2nd software limit switch plus)

By default, the 1st software limit switch is active. The 2nd software limit switch can be activated for a specific direction with the PLC user program:

DB31, ... DBX12.2 / 12.3 (2nd software limit switch minus/plus)

Effectiveness

The software limit switches are active:

- Immediately after the successful referencing of the machine axis.
- In all operating modes.

Supplementary conditions

- The software limit switches refer to the machine coordinate system.
- The software limit switches must be inside the range of the hardware limit switches.
- The machine axis can be moved to the position of the active software limit switch.

- **PRESET**
After use of the function **PRESET**, the software limit-switch monitoring is no longer active. The machine must first be re-referenced.
- **Endlessly rotating rotary axes**
No software limit-switch monitoring takes place for endlessly rotating rotary axes:
MD30310 \$MA_ROT_IS_MODULO == 1 (modulo conversion for rotary axis and spindle)
Exception: Setup-rotary axes

Effects

Automatic operating modes (AUTOMATIC, MDI)

- Without transformation, without overlaid motion, unchanged software limit switch:
A part program block with a programmed traversing motion that would lead to overrunning of the software limit switch is not started.
- With transformation:
Different reactions occur depending on the transformation type:
 - Behavior as above.
or
 - The part program block with a programmed traversing motion that would lead to overrunning of the software limit switch is started. The affected machine axis stops at the active software limit switch. The other machine axes participating in the traversing motion are braked. The programmed contour is left during this process.
- With overlaid motion
The part program block with a programmed traversing motion that would lead to overrunning of the software limit switch is started. Machine axes that are traveling with overlaid motion or have traveled with overlaid motion stop at the active software limit switch in question. The other machine axes participating in the traversing motion are braked. The programmed contour is left during this process.

Manual operating modes

- JOG without transformation
The machine axis stops at the software limit switch position.
- JOG with transformation
The machine axis stops at the software limit switch position. Other machine axes participating in the traversing motion are braked. The preset path is left during this process.

General

- Changing of the software limit switch (1st ↔ 2nd software limit switch)
If the actual position of the machine axis after changing lies behind the software limit switch, it is stopped with the maximum permissible acceleration.
- Overrunning the software limit switch in JOG mode
If the position of the software limit switch is reached and renewed pressing of the traversing button should cause further travel in this direction, an alarm is displayed and the axis is not traversed farther:
Alarm 10621 "Channel <channel number> axis <axis name> is at software limit switch <direction>"

7.7 Working area limitation monitoring

7.7.1 General

Function

The "working area limitation" function can be used to limit the traversing range of a channel's geometry and special axes to a permissible operating range. The function monitors compliance with working area limits both in AUTOMATIC mode and in JOG mode.

The following versions are available:

- Working area limitation in the Basic Coordinate System (BCS)
The traversing range limits are specified relative to the Basic Coordinate System.
- Working area limitation in the workpiece coordinate system (WCS) or adjustable zero system (AZS)
The traversing range limits are specified relative to the workpiece coordinate system or to the adjustable zero system.

The two types of monitoring are independent of each other. If they are both active at the same time, the traversing range limit which most restricts the access will take effect, depending on the direction of travel.

Reference point at the tool

Taking into account the tool data (tool length and tool radius) and therefore the reference point at the tool when monitoring the working area limitation depends on the status of the transformation in the channel:

- **Transformation inactive**

Without transformations during traversing motion with an active tool the position of the tool tip P is monitored, i.e. during the monitoring the tool length is considered automatically. Consideration of the tool radius must be activated separately:

MD21020 \$MC_WORKAREA_WITH_TOOL_RADIUS (Consideration of the tool radius in the working area limitation)

- **Transformation active**

In the case of certain transformations the monitoring of the working area limitation may differ from the behavior without transformation:

- The tool length is a component of the transformation (\$MC_TRAFO_INCLUDES_TOOL_X = TRUE):
In this case the tool length is not considered, i.e. the monitoring refers to the tool carrier reference point.
- Transformation with change in orientation:
In the case of transformations with changes in orientation, monitoring is always based on the tool center point. MD21020 has no influence.

Note

The machine data \$MC_TRAFO_INCLUDES_TOOL_... is analyzed only in certain transformations. Condition for a possible evaluation is that the orientation of the tool with respect to the base coordinate system cannot be changed by the transformation. With standard transformations, the condition is only fulfilled for the "inclined axis" type of transformation.

Response

Automatic operating modes

- With / without transformation
The parts program block with a programmed traversing motion that would lead to overrunning of the working area limits is not executed.
- With superimposed motion
The axis, which would violate the working area limitation due to a superimposed motion, is braked with maximum acceleration and without jerk limits (BRISK), and will come to a stop in the position of the working area limitation. Other axes involved in the movement are braked according to current acceleration behavior (e.g. SOFT). The path correlation may be lost due to different braking accelerations (contour violation).

Manual operating modes

- JOG with / without transformation
The axis is positioned at the working area limitation and then stopped.

Powerup response

If an axis moves outside the permissible working area when activating the working area limits, it will be immediately stopped with the maximum permissible acceleration.

Overrunning of the working area limitation in JOG mode

In JOG mode, an axis is moved to no further than its working area limit by the control system. When the traverse button is pressed again, an alarm is displayed and the axis does not traverse any further.

Geo-axis replacement

Through the following machine data it is adjustable, whether during geometry axis change the active working area limitation is retained or deactivated:

MD10604 \$MN_WALIM_GEOAX_CHANGE_MODE = <value>

<value>	Meaning
0	The working area limitation is deactivated during the geometry axis change.
1	The working area limitation remains activated during the geometry axis change.

7.7.2 Working area limitation in BCS**Application**

Using the "working area limitation in BCS", the working area of a machine tool is limited so that the surrounding devices (e.g. tool revolver, measuring stations) are protected against damage.

Working area limits

The lower and upper working area limits of each axes are adjusted through setting data or programmed through part program commands:

Working area limitation through setting data

The adjustments are done through the immediately effective axis-specific setting data:

SD43420 \$SA_WORKAREA_LIMIT_PLUS (working area limitation plus)

SD43430 \$SA_WORKAREA_LIMIT_MINUS (working area limitation minus)

Programmed working area limitation

The programming is done using the G commands:

G25 X... Y... Z... lower working area limitation

G26 X... Y... Z... upper working area limitation




Figure 7-4 Programmed working area limitation

The programmed working area limitation has priority and overwrites the values entered in SD43420 and SD43430.

Activation/Deactivation

Working area limitation through setting data

The activation/deactivation of the working area limitation for each axis takes place in a direction-specific manner via the immediately effective setting data:

SD43400 \$SA_WORKAREA_PLUS_ENABLE (working area limitation active in the positive direction)

SD43410 \$SA_WORKAREA_MINUS_ENABLE (working area limitation active in the negative direction)

Value	Meaning
0	The working area limitation in positive or negative direction is switched off .
1	The working area limitation in positive or negative direction is active .

Programmed working area limitation

Activation or deactivation of the overall "working area limitation in the BCS" is arranged via part program commands:

WALIMON Working area limitation ON

or

WALIMOF Working area limitation OFF

Changing the working area limitation

Working area limitation through setting data

HMI user interface: Operating area "Parameter"

- Automatic modes:
 - Changes: Possible only in the RESET state
 - Effectiveness: Immediately
- Manual operating modes:
 - Changes: Always possible
 - Effectiveness: At the start of the next traversing motion

Programmed working area limitation

The working area limitation can be changed in the part program via G25 or G26 <Axis name> <value>. The change takes effect immediately.

The new working area limitation value is retained after NC RESET and POWER ON if the back-up process has been activated in the NC's retentive data storage for SD43420 and SD43430:

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB[0] = 43420

MD10710 \$MN_PROG_SD_RESET_SAVE_TAB[1] = 43430

Reset position

The reset position for the working area limitation (WALIMON or WALIMOF) is configurable via:

MD20150 \$MC_GCODE_RESET_VALUES (reset setting of the G groups)

7.7.3 Working area limitation in WCS/SZS

Application

The "working area limitation" in the WCS/SZS enables a flexible workpiece-specific limitation of the traversing range of the channel axes in the workpiece coordinate system (WCS) or settable zero system (SZS). It is intended mainly for use in conventional lathes.

Requirement

The channel axes must be referenced.

Working area limitation group

In order that the axis-specific working area limits do not have to be rewritten for all channel axes when switching axis assignments, e.g. when switching transformations or the active frame on/off, working area limitation groups are available.

A working area limitation group comprises the following data:

- Working area limits for all channel axes
- Reference system of the working area limitation

The number of the working area limitation groups is set channel-specific in the machine data:

MD28600 \$MC_MM_NUM_WORKAREA_CS_GROUPS

Maximum 10 working area limitation groups are possible per channel.

Set working area limits

The working area limits within a channel are set for each channel axis via the following system variables:

- \$P_WORKAREA_CS_LIMIT_PLUS[<WALimNo>, <Ax>]
- \$P_WORKAREA_CS_LIMIT_MINUS[<WALimNo>, <Ax>]

wit <WALimNo> = Working area limitation group
h:

Value range: 0 (group 1) ... 9 (group 10)
<Ax> = Channel axis name

Enable working area limits

The working area limits within a channel are enabled for each channel axis via the following system variables:

- \$P_WORKAREA_CS_PLUS_ENABLE[<WALimNo>, <Ax>]
- \$P_WORKAREA_CS_MINUS_ENABLE[<WALimNo>, <Ax>]

wit <WALimNo> = Working area limitation group
h:

Value range: 0 (group 1) ... 9 (group 10)
<Ax> = Channel axis name

Using the direction-specific enable, it is possible to limit the working range for an axis in just one direction.

There is no activation through the enable.

Select reference system

The reference system for a working area limitation group within a channel is set via the following system variable:

\$P_WORKAREA_CS_COORD_SYSTEM[<WALimNo>] = <value>

wit <WALimNo> = Working area limitation group
h:

Value range: 0 (group 1) ... 9 (group 10)

<value>	Meaning
1	The reference system is the WCS.
3	The reference system is the SZS.

Activation of working area limits

The working area limits of a working area limitation group are activated in the part program with the G command `WALCS<n>`.

wit <n> = Number of the working area limitation group
h:

Value range: 1 ... 10

Deactivation of working area limits

The working area limits of a working area limitation group active in the channel are deactivated in the part program with the G command `WALCS0`.

Change working area limits

The working area limits can be changed at any time via the system variables mentioned above. Changes take effect with the next activation of the working area limitation group (`WALCSn`).

Data storage

The system variables of the working area limits are stored retentively in the static memory of the NC.

Note

For the storage of the limiting values for the linear axes, the default setting is considered for the system of units (MD10240 \$MN_SCALING_SYSTEM_IS_METRIC).

Data backup

The system variables of the working area limits can be backed up in separate files:

- `_N_CHx_WAL`
To save the system variable values for channel x.
- `_N_COMPLETE_WAL`
To save the system variable values for all channels.

Note

The system variables of the working area limits are part of the "`_N_INITIAL_INI`" file.

Behavior in JOG mode

Initial situation:

- In JOG mode, **several** geometry axes traverse simultaneously (e.g. using several handwheels).
- A **rotating** frame is active between the basic coordinate system (BCS) and the reference coordinate system of the working area limitation (WCS or SZS).

Behavior when a working area limitation responds:

- The traversing motions of the geometry axes that are not affected are continued.
- The affected geometry axis is stopped at the working area limit.

Setting the initial setting

The working area limitation group that is to take effect at ramp up, reset or part program end and part program start is predefined channel-specifically via the machine data:

MD20150 \$MC_GCODE_RESET_VALUE[59] = <n>

with <n> = Number of the working area limitation group
h:

Value range: 1 ... 10

The following setting determines whether the pre-selected working area limitation acts for ramp up and reset or part program end:

MD20152 \$MC_GCODE_RESET_MODE[59] = <value>

<value>	Meaning
0	The working area group takes effect in accordance with MD20150 (default setting).
1	The last active working area group remains active.

7.7.4 Example: Working area limitation in WCS/SZS

Assumption

Channel axes

Four axes are defined in the channel:

- Linear axes: X, Y, Z
- Rotary axis: A (not modulo)

Requirements

Channel axes

Four axes are defined in the channel:

- Linear axes: X, Y, Z
- Rotary axis: A (not modulo)

Working area limitation groups

Three working area limitation groups should be available in the channel:

MD28600 \$MC_MM_NUM_WORKAREA_CS_GROUP = 3

From these three working area limitation groups, two groups are defined in the following.

Coordinate systems

- Working area limitation group 1: Working area limitation in the adjustable zero system (**AZS**).
- Working area limitation group 2: Working area limitation in the workpiece coordinate system (**WCS**).

Working area limitation group 1

- X axis in the plus direction: 10 mm
- X axis in the minus direction: No limitation
- Y axis in the plus direction: No limitation
- Y axis in the minus direction: 25 mm
- Z axis in the plus direction: No limitation
- Z axis in the minus direction: No limitation
- A axis in the plus direction: 10 degrees
- A axis in the minus direction: -40 degrees

Definitions via system variables in the NC program.

Program code

```

; Working area limitation group 1
$P_WORKAREA_CS_COORD_SYSTEM[1] = 3          ; working area limitation in
the SZS
$P_WORKAREA_CS_PLUS_ENABLE[1,X] = TRUE
$P_WORKAREA_CS_LIMIT_PLUS[1,X] = 10
$P_WORKAREA_CS_MINUS_ENABLE[1,X] = FALSE
$P_WORKAREA_CS_PLUS_ENABLE[1,Y] = FALSE
$P_WORKAREA_CS_MINUS_ENABLE[1,Y] = TRUE
$P_WORKAREA_CS_LIMIT_MINUS[1,Y] = 25
$P_WORKAREA_CS_PLUS_ENABLE[1,Z] = FALSE
$P_WORKAREA_CS_MINUS_ENABLE[1,Z] = FALSE
$P_WORKAREA_CS_PLUS_ENABLE[1,A] = TRUE

```

Program code

```
$P_WORKAREA_CS_LIMIT_PLUS[1,A] = 10
$P_WORKAREA_CS_MINUS_ENABLE[1,A] = TRUE
$P_WORKAREA_CS_LIMIT_MINUS[1,A] = -40
```

Working area limitation group 2

- X axis in the plus direction: 10 mm
- X axis in the minus direction: No limitation
- Y axis in the plus direction: 34 mm
- Y axis in the minus direction: -25 mm
- Z axis in the plus direction: No limitation
- Z axis in the minus direction: -600 mm
- A axis in the plus direction: No limitation
- A axis in the minus direction: No limitation

Definitions via system variables in the NC program.**Program code**

```
; Working area limitation group 2
$P_WORKAREA_CS_COORD_SYSTEM[2] = 1          ; working area limitation in
the WCS
$P_WORKAREA_CS_PLUS_ENABLE[2,X] = TRUE
$P_WORKAREA_CS_LIMIT_PLUS[2,X] = 10
$P_WORKAREA_CS_MINUS_ENABLE[2,X] = FALSE
$P_WORKAREA_CS_PLUS_ENABLE[2,Y] = TRUE
$P_WORKAREA_CS_LIMIT_PLUS[2,Y] = 34
$P_WORKAREA_CS_MINUS_ENABLE[2,Y] = TRUE
$P_WORKAREA_CS_LIMIT_MINUS[2,Y] = -25
$P_WORKAREA_CS_PLUS_ENABLE[2,Z] = FALSE
$P_WORKAREA_CS_MINUS_ENABLE[2,Z] = TRUE
$P_WORKAREA_CS_LIMIT_PLUS[2,Z] = -600
$P_WORKAREA_CS_PLUS_ENABLE[2,A] = FALSE
$P_WORKAREA_CS_MINUS_ENABLE[2,A] = FALSE
```

Activation

The working area limitation groups are activated in the NC program using command `WALCS<x>`, with x: Number of the working area limitation group

7.8 Parking a machine axis

If a machine axis is brought into the "Parking" state, then for this particular axis, no encoder actual values are acquired, and all of the monitoring functions described in the preceding sections (measuring system, standstill, clamping monitoring, etc.) are deactivated.

Activation / deactivation

Activate parking

The "Parking" function is **activated** for a machine axis by **resetting** the axis-specific NC/PLC interface signals for the position measuring systems and the controller enable:

- DB31, ... DBX1.5 = 0 (position measuring system 1)
- DB31, ... DBX1.6 = 0 (position measuring system 2)
- DB31, ... DBX2.1 = 0 (controller enable)

The encoder status of the position measuring system of the axis is then set to "Not referenced":

- DB31, ... DBX60.4 = 0 (referenced / synchronized, position measuring system 1)
- DB31, ... DBX60.5 = 0 (referenced/synchronized, position measuring system 2)

The following further NC/PLC interface signals are also reset:

- DB31, ... DBX61.5 = 0 (position controller active)
- DB31, ... DBX61.6 = 0 (speed controller active)
- DB31, ... DBX61.7 = 0 (current controller active)
- DB31, ... DBX93.7 = 0 (pulses enabled)
- DB31, ... DBX102.5 = 0 (position measuring system 1 activated)
- DB31, ... DBX102.6 = 0 (position measuring system 2 activated)

Deactivate parking

The "Parking" function is **deactivated** for a machine axis by **setting** the axis-specific NC/PLC interface signals for the position measuring system to be activated and the controller enable:

- DB31, ... DBX1.5 = 1 (position measuring system 1)
or
DB31, ... DBX1.6 = 1 (position measuring system 2) = 1
- DB31, ... DBX2.1 = 1 (controller enable) = 1

The position control for the machine axis becomes active again at the current position.

The encoder state of the position measuring systems depends on the measuring system type:

- Incremental position measuring system $\Rightarrow$ "not referenced" state
 - DB31, ... DBX60.4 = 0 (referenced / synchronized, position measuring system 1)
 - DB31, ... DBX60.5 = 0 (referenced/synchronized, position measuring system 2)
- Absolute position measuring system $\Rightarrow$ "referenced/synchronized" state
 - DB31, ... DBX60.4 = 1 (referenced / synchronized, position measuring system 1)
 - DB31, ... DBX60.5 = 1 (referenced/synchronized, position measuring system 2)

The following NC/PLC interface signals are also set again:

- DB31, ... DBX61.5 = 1 (position controller active)
- DB31, ... DBX61.6 = 1 (speed controller active)
- DB31, ... DBX61.7 = 1 (current controller active)
- DB31, ... DBX93.7 = 1 (pulses enabled)
- DB31, ... DBX102.5 = 1 (position measuring system 1 activated)
- DB31, ... DBX102.6 = 1 (position measuring system 2 activated)

Incremental position measuring systems

After deactivation of the "parking" state, incremental position measuring systems have to be referenced before they have "referenced" encoder status.



WARNING

Incorrect synchronization of the position measuring system caused by offset of the actual machine axis position

If changes have been made to the position measuring system during "parking" that require a change to the parameterized machine data, for example, another encoder has been mounted, the position measuring system must be completely remeasured and referenced. See Function Manual "Axes and Spindles", Section "R1: Referencing".

Machine axis without position measuring system

For a machine axis without a position measuring system (speed-controlled spindle), a status equivalent to "parking" is activated by canceling the controller enable:

- DB31, ... DBX2.1 = 0 (controller enable)

7.9 Parking the passive position measuring system

7.9.1 Function

Contrary to the "Parking a machine axis (Page 186)" function, for which all position measuring systems of a machine axis are deactivated, using the "Park the passive position measuring system" function, users have the option, of only "parking" the passive position measuring system of a machine axis (i.e. to deactivate the encoder evaluation and monitoring in the drive and in the control), while the active position measuring system can remain operational.

Note

For explanations regarding active/passive measuring system, see Function Manual "Axes and Spindles", Section "Setpoint/actual value system".

Application

The "Park passive measuring system" function can, for example, be used in the following cases:

- Changing attachment heads with and without integrated encoder
Using the "Park passive position measuring system" function, it is possible to mount attachment heads alternating with and without integrated encoder for different machining tasks on the main spindle, without the missing encoder signals initiating drive and control faults.
See also:
 - Example: Changing an attachment head for a direct position measuring system (Page 192)
 - Example: Changing an attachment head for two direct position measuring systems (Page 197)
- Using linear position measuring systems, which are not available over the complete traversing range of a machine axis
Using the "Park passive position measuring system" function, it is possible to pass through the range outside the linear position measuring system, without the missing encoder signals initiating drive and control faults.
See also:
 - "Example: Measuring system switchover when encoders are missing in certain parts of the range (Page 201)".

Activation / deactivation

Activation

The passive position measuring system of a machine axis is parked under the following conditions:

- "Park passive position measuring system" function is active for the measuring system:
MD31046 \$MA_ENC_PASSIVE_PARKING[<n>] = 1
with <n> = 0 (position measuring system 1) or 1 (position measuring system 2)

Note

MD31046 is **not active**:

- for axes with fewer than two encoders:
MD30200 \$MA_NUM_ENCS < 2
 - for simulated encoders:
MD30240 \$MA_ENC_TYPE = 0
-

Note

For position measuring systems, which are used as motor measuring systems, the "Park passive position measuring system" function should be deactivated (MD31046 = 0)!

and

- The user sets the following NC/PLC interface signal to "0":
DB31, ... DBX1.5 (position measuring system 1) = 0
or
DB31, ... DBX1.6 (position measuring system 2) = 0

The controller then sets the status for the activation state of the position measuring system to "0":

DB31, ... DBX102.5 (position measuring system 1 activated) == 0

or

DB31, ... DBX102.6 (position measuring system 2 activated) == 0

The position measuring system is now no longer monitored and updated.

Deactivation

"Park" is deactivated if the user activates the position measuring system:

DB31, ... DBX1.5 (position measuring system 1) = 1

or

DB31, ... DBX1.6 (position measuring system 2) = 1

The controller then sets the status for the activation state of the position measuring system back to "1":

DB31, ... DBX102.5 (position measuring system 1 activated) == 1

or

DB31, ... DBX102.6 (position measuring system 2 activated) == 1

Note

Switching over to a parked position measuring system takes longer than to a non-parked position measuring system. Because of the time taken, we recommend switching over while the axes are stationary.

Position of the position measuring system

Absolute position measuring systems

For absolute position measuring systems, the position after deactivating "park" corresponds to the actual absolute encoder position.

The position measuring system is referenced:

DB31, ... DBX60.4 (referenced/synchronized, position measuring system 1) == 1

or

DB31, ... DBX60.5 (referenced/synchronized, position measuring system 2) == 1

Incremental position measuring systems

For incremental position measuring systems, the position after deactivating "park" always corresponds to the last deactivation position of the position measuring system.

Switching over to the parked position measuring system is only realized if the parameterized permissible deviation between the actual values of the two position measuring systems (see MD36500 \$MA_ENC_CHANGE_TOL) is not exceeded. Otherwise, users must apply the "Park a machine axis" function, in which case such a check is not made.

The position measuring system is **not** referenced:

DB31, ... DBX60.4 (referenced/synchronized, position measuring system 1) == 0

or

DB31, ... DBX60.5 (referenced/synchronized, position measuring system 2) == 0

Incremental position measuring systems with position transfer

Alternatively, for incremental position measuring systems, when the "Park passive position measuring system" is active (MD31046 \$MA_ENC_PASSIVE_PARKING[<n>] = 1) it is possible, after deactivating "Park" to transfer the position, and where relevant, also the "Referenced" status, from the previously active position measuring system.

For every position measuring system of a machine axis, this function can be activated using machine data:

MD34210 \$MA_ENC_REFP_STATE[<n>]

with $\langle n \rangle = 0$ (position measuring system 1) or 1 (position measuring system 2)

Value	Meaning
1	Only the position from the previous active position measuring system is transferred. The position measuring system is not referenced: DB31, ... DBX60.4 (referenced/synchronized, position measuring system 1) == 0 or DB31, ... DBX60.5 (referenced/synchronized, position measuring system 2) == 0
2	Position and "Referenced" status are transferred from the previously active position measuring system. The position measuring system is referenced: DB31, ... DBX60.4 (referenced/synchronized, position measuring system 1) == 1 or DB31, ... DBX60.5 (referenced/synchronized, position measuring system 2) == 1

Note

Position and "Referenced" status of the previously active position measuring system are only transferred for incremental position measuring systems, depending on MD34210 \$MA_ENC_REFP_STATE[$\langle n \rangle$] – and only when the "Park passive position measuring system" function is active (MD31046 \$MA_ENC_PASSIVE_PARKING[$\langle n \rangle$] = 1).

The transferred position has the accuracy of the previous active position measuring system. The position measuring system should be referenced if this accuracy is not adequate.



WARNING

Incorrect synchronization of the position measuring system caused by offset of the actual machine axis position

If changes have been made to the position measuring system during "parking" that require a change to the parameterized machine data, for example, another encoder has been mounted, the position measuring system must be completely remeasured and referenced. See Function Manual "Axes and Spindles", Section "R1: Referencing".

7.9.2 Supplementary conditions

Interaction with "dual position feedback"

The "Park passive position measuring system" function **cannot** be used in conjunction with the "dual position feedback" function (MD32960 \$MA_POSCTRL_DUAL_FEEDBACK_TIME > 0).

Interaction with "position difference input"

The "Park passive position measuring system" function **cannot** be used in conjunction with the "position difference input" function (MD32950 \$MA_POSCTRL_DAMPING > 0).

Interaction with APC (optional)

The "Park passive measuring system" function **cannot** be used in conjunction with the "Advanced positioning control (APC)" drive function.

Interaction with encoder safety protection concept

Only the 1 encoder safety protection concept can be used in conjunction with the "Park passive position measuring system" function.

Interaction when connecting and disconnecting at the DRIVE-CLiQ

If, instead of the encoder cable, the DRIVE-CLiQ cables, e.g. between the SMC and Motor Module are unplugged and plugged, such encoders can only be unparked without fault via the "Parking a machine axis (Page 186)" function.

7.9.3 Example: Changing an attachment head for a direct position measuring system


Initial situation

- Attachment head "A" has an encoder E2.
- Attachment head "B" does not have an encoder.
- Spindle "SP" has an encoder E1.
- One of the following two telegram types is configured in MD13060 \$MN_DRIVE_TELEGRAM_TYPE (standard telegram type for PROFIdrive):
 - Telegram 116 (motor encoder + an external encoder)
or
 - Telegram 136 (motor encoder + an external encoder, and torque precontrol)
- The following position measuring systems are configured in the spindle "SP":
 - Motor encoder E1 as position measuring system 1
 - Direct encoder E2 as position measuring system 2
- Attachment head "A" with encoder E2 is currently mounted on the spindle.
- Position measuring system 2 is the active measuring system:
DB31, ... DBX1.6 = 1
Position measuring system 1 is passive.
- The "Park passive position measuring system" function is:
 - Not active for position measuring system 1:
MD31046 \$MA_ENC_PASSIVE_PARKING [0] = 0
 - Active for position measuring system 2:
MD31046 \$MA_ENC_PASSIVE_PARKING [1] = 1

Objective

The user would like to change from attachment head "A" to attachment head "B."

Execution




- ① Before changing an attachment head, the user must deactivate all position measuring systems of the machine axis using the "Parking a machine axis (Page 186)" function:
 DB31, ... DBX1.5 (position measuring system 1) = 0
 DB31, ... DBX1.6 (position measuring system 2) = 0
 The controller then resets the status signals for the position measuring systems:
 DB31, ... DBX102.5 (position measuring system 1 activated) == 0
 DB31, ... DBX102.6 (position measuring system 2 activated) == 0
- ② The user waits for the status signals and only now removes the attachment head "A" from the spindle. This electrically disconnects the encoder cable between the attachment head "A" and coupling. The absence of encoder E2 does not generate any NC or drive faults.

- ③ Attachment head "B" is now mounted on the spindle.
- ④ The user only activates position measuring system 1:
DB31, ... DBX1.5 (position measuring system 1) = 1
The control then sets the status signal:
DB31, ... DBX102.5 (position measuring system 1 activated) == 1
The "Park passive position measuring system" function is active for position measuring system 2.
This means that position measuring system 2 does not become passive, but remains in the "Park" state.

Objective

The user now wishes to remount attachment head "A" again.

Execution



- ① Using the "Park machine axis" function, the user deactivates position measuring system 1:
 $\text{DB31, ... DBX1.5 (position measuring system 1)} = 0$
 The controller then resets the status signal for the position measuring system:
 $\text{DB31, ... DBX102.5 (position measuring system 1 activated)} == 0$
- ② The user waits for the status signal and only now removes the attachment head "B" from the spindle.
- ③ Attachment head "A" is now mounted on the spindle.
- ④ The user activates position measuring system 2:
 $\text{DB31, ... DBX1.6 (position measuring system 2)} = 1$
 As a consequence, position measuring system 1 is also simultaneously activated; This is because the "Park passive position measuring system" function is not active for position measuring system 1 (motor measuring system!). Position measuring system 1 becomes a passive position measuring system.
 The controller then sets the status signals for the position measuring systems:
 $\text{DB31, ... DBX102.5 (position measuring system 1 activated)} == 1$
 $\text{DB31, ... DBX102.6 (position measuring system 2 activated)} == 1$

7.9.4 Example: Changing an attachment head for two direct position measuring systems

Initial situation

- Attachment head "A" has an encoder E3.
- Attachment head "B" does not have an encoder.
- Spindle "SP" has two encoders E1 and E2.
- One of the following two telegram types is configured in MD13060 \$MN_DRIVE_TELEGRAM_TYPE (standard telegram type for PROFIdrive):
 - Telegram 118 (two external encoders)
or
 - Telegram 138 (two external encoders, plus torque precontrol)

Further information:

Information regarding encoder assignment, see:


Commissioning Manual CNC Commissioning: NC, PLC, drive; Communication between NC and drive > Drives: Assign axis

- The following position measuring systems are configured in the spindle "SP":
 - Direct encoder E2 as position measuring system 1
 - Direct encoder E3 as position measuring system 2
- Attachment head "A" with encoder E3 is currently mounted on the spindle.
- Position measuring system 2 is the active measuring system:
DB31, ... DBX1.6 = 1
Position measuring system 1 is passive.
- The "Park passive position measuring system" function is:
 - Not active for position measuring system 1:
MD31046 \$MA_ENC_PASSIVE_PARKING [0] = 0
 - Active for position measuring system 2:
MD31046 \$MA_ENC_PASSIVE_PARKING [1] = 1

Objective

The user would like to change from attachment head "A" to attachment head "B."

Execution



- Before changing an attachment head, the user must deactivate all position measuring systems of the machine axis using the "Parking a machine axis (Page 186)" function:

DB31, ... DBX1.5 (position measuring system 1) = 0

DB31, ... DBX1.6 (position measuring system 2) = 0

The controller then resets the status signals for the position measuring systems:

DB31, ... DBX102.5 (position measuring system 1 activated) == 0


DB31, ... DBX102.6 (position measuring system 2 activated) == 0
- The user waits for the status signals and only now removes the attachment head "A" from the spindle. This electrically disconnects the encoder cable between the attachment head "A" and coupling. The absence of encoder E3 does not generate any NC or drive faults.

- ③ Attachment head "B" is now mounted on the spindle.
- ④ The user only activates position measuring system 1:
DB31, ... DBX1.5 (position measuring system 1) = 1
The control sets the status signal:
DB31, ... DBX102.5 (position measuring system 1 activated) == 1
The "Park passive position measuring system" function is active for position measuring system 2.
This means that position measuring system 2 does not become passive, but remains in the "Park" state.

Objective

The user now wishes to remount attachment head "A" again.

Execution



- ① Using the "Park machine axis" function, the user deactivates position measuring system 1:
DB31, ... DBX1.5 (position measuring system 1) = 0
The controller then resets the status signal for the position measuring system:
DB31, ... DBX102.5 (position measuring system 1 activated) == 0
- ② The user waits for the status signal and only now removes the attachment head "B" from the spindle.
- ③ Attachment head "A" is now mounted on the spindle.
- ④ The user activates position measuring system 2:
DB31, ... DBX1.6 (position measuring system 2) = 1
As a consequence, position measuring system 1 is also simultaneously activated; This is because the "Park passive position measuring system" function is not active for position measuring system 1. Position measuring system 1 becomes a passive position measuring system.
The controller then sets the status signals for the position measuring systems:
DB31, ... DBX102.5 (position measuring system 1 activated) == 1
DB31, ... DBX102.6 (position measuring system 2 activated) == 1

7.9.5 Example: Measuring system switchover when encoders are missing in certain parts of the range

In the following example, the direct linear position measuring system is only available in the machining zones, while only the motor measuring system is available outside the machining zones.

Initial situation

- Linear axis "X" has two incremental encoders:
 - Motor encoder E1
 - Direct linear encoder E2
- Direct linear encoder E2 is only available in the machining range.
- One of the following two telegram types is configured in MD13060 \$MN_DRIVE_TELEGRAM_TYPE (standard telegram type for PROFIdrive):
 - Telegram 116 (motor encoder + an external encoder)
 - or
 - Telegram 136 (motor encoder + an external encoder, and torque precontrol)
- The following position measuring systems are configured for the machine axis:
 - Motor encoder E1 as position measuring system 1
 - Direct linear encoder E2 as position measuring system 2
- When the machine is switched on, the user activates both position measuring systems:
 - DB31, ... DBX1.5 (position measuring system 1) = 1
 - DB31, ... DBX1.6 (position measuring system 2) = 1


When both position measuring systems are simultaneously activated, then the control selects position measuring system 1 as active position measuring system.

- Position measuring system 2 is selected for machining:
 - DB31, ... DBX1.5 (position measuring system 1) = 0
 - DB31, ... DBX1.6 (position measuring system 2) = 1
- The "Park passive position measuring system" function is:
 - Not active for position measuring system 1:
MD31046 \$MA_ENC_PASSIVE_PARKING [0] = 0
 - Active for position measuring system 2:
MD31046 \$MA_ENC_PASSIVE_PARKING [1] = 1
- Transfer of the position and the "referenced" status is activated for position measuring system 2:
MD34210 \$MA_ENC_REFP_STATE[1] = 2

Objective

When passing through the range outside linear position measuring system E2, the missing encoder signals should not initiate any faults in the drive and in the control.

Execution



- ① Before the table reaches the end of the linear position measuring system, a switchover must be made to the motor measuring system. The user does this by activating both position measuring systems:
 DB31, ... DBX1.5 (position measuring system 1) = 1
 DB31, ... DBX1.6 (position measuring system 2) = 1
 Using the "Park passive position measuring system" function, the linear position measuring system, which is passive after the measuring system switchover, is parked by the control.
 The control resets the status signal:
 DB31, ... DBX102.6 (position measuring system 2 activated) == 0
 The user waits for the status signal before continuing to traverse in the range outside the linear position measuring system.
- ② Traversing through the range outside the linear position measuring system with the motor measuring system.

7.10 Switching over encoder data sets

- ③ If the table returns to the linear position measuring system range, at standstill, the user switches from the motor measuring system to the linear position measuring system:
- DB31, ... DBX1.5 (position measuring system 1) = 0
- DB31, ... DBX1.6 (position measuring system 2) = 1
- The control sets the status signal:
- DB31, ... DBX102.6 (position measuring system 2 activated) == 1
- The motor measuring system becomes a passive position measuring system.

Result

Both position measuring systems are referenced. The position of the linear position measuring system corresponds to the position of the motor measuring system at the switchover instant. The linear position measuring system must be rereferenced if the position accuracy is not sufficient.

7.10 Switching over encoder data sets

Application

Different attachment heads may be used in succession on one and the same power unit in order to perform different machining tasks.

One motor data set (MDS) and one encoder data set (EDS) must be programmed for each attachment head that is equipped with a motor or an encoder. These data sets must be switched over in the PLC program whenever the attachment head is changed. An MDS/EDS switchover can only be implemented indirectly in this regard via switchover of the drive data set (DDS).

Function

NOTICE

Machine damage

If the following drive parameters and machine data have different settings, the axis might not traverse at the programmed speed or to the programmed position.

The machine data must be changed simultaneously and consistently with encoder data switchover in the parked state.

Encoder data switchover in the control is limited to the following SINAMICS drive parameters.

- p0408 (rotary encoder pulse number)
- p0418 (fine resolution of encoder emulation Gx_XIST1 (in bits))
- p0419 (fine resolution absolute value Gx_XIST2 (in bits))

With these parameters, it is possible to switch over encoder data sets with the same encoder type but a different number of encoder pulses.

Switchover in the control is activated in the following machine data:

MD31700 \$MA_ENC_EDS_ACTIVE (activate EDS use)

Value	Meaning
0	Encoder data set switchover EDS is not used.
1.	Encoder data set switchover EDS is used.

A machine data item is provided for each of the drive parameters p0408, p0418, and p0419, which must be parameterized in accordance with the active encoder data set:

- MD31710 \$MA_ENC_RESOL_EDS (encoder pulses per revolution for EDS use)
- MD31720 \$MA_ENC_PULSE_MULT_EDS (encoder multiplication (high resolution) for EDS use)
- MD31730 \$MA_ABS_INC_RATIO_EDS (absolute encoder: ratio between absolute resolution and incremental resolution for EDS use)

Effectiveness

If MD31700 \$MA_ENC_EDS_ACTIVE = 1, the following machine data no longer take effect:

- MD30260 \$MA_ABS_INC_RATIO (absolute encoder: ratio between absolute resolution and incremental resolution)
- MD31020 \$MA_ENC_RESOL (encoder pulses per revolution)
- MD31025 \$MA_ENC_PULSE_MULT (encoder multiplication (high resolution))

The drive data switchover in DB3x.DBX21.0 - 4 also switches over the encoder data sets. Switchover is performed in the parked state (see chapters "Parking a machine axis (Page 186)" and "Parking the passive position measuring system (Page 188)").

Note

If MD31700 \$MA_ENC_EDS_ACTIVE = 1, no plausibility check between the values set in the drive and control is performed.

NC/PLC interface signal:

- DB31, ... DBX21.7 (pulse enable)
- DB31, ... DBX21.6 (integrator inhibit, speed controller)
- DB31, ... DBX21.5 (motor selection)
- DB31, ... DBX21.0 - 4 (request for switchover of a motor and/or drive data set)
The interface can be flexibly parameterized using: DB31,DBX130.0 - 4

Supplementary conditions

SINUMERIK supplementary conditions:

- Only machine data for rotary encoders are available.
- Traversing range extension for absolute-value encoders
MD30270 \$MA_ENC_ABS_BUFFERING = 0 is not permissible.

Further information

Function Manual SINAMICS S120 Drive Functions;
Basic information about the drive system > Data sets

- DDS: Drive data set
- EDS: Encoder data set

Other machine data

In addition to the machine data of the axis monitoring function, the following additional machine data should be set or checked:

All machine axes

- MD31030 \$MA_LEADSCREW_PITCH (leadscrew pitch)
- MD31050 \$MA_DRIVE_AX_RATIO_DENOM (denominator load gearbox)
- MD31060 \$MA_DRIVE_AX_RATIO_NUMERA (numerator load gearbox)
- MD31070 \$MA_DRIVE_ENC_RATIO_DENOM (denominator measuring gearbox)
- MD31080 \$MA_DRIVE_ENC_RATIO_NUMERA (numerator measuring gearbox)
- MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant speed control loop for feedforward control)
- Encoder resolution: see Function Manual "Axes and Spindles", Section "G2: Velocities, setpoint/actual value systems, closed-loop control".

Machine axes with analog speed setpoint interface

- MD32260 \$MA_RATED_VELO (rated motor speed)
- MD32250 \$MA_RATED_OUTVAL (rated output voltage)

7.11 Data lists**7.11.1 Machine data****7.11.1.1 NC-specific machine data**

Number	Identifier: \$MN_	Description
10604	WALIM_GEOAX_CHANGE_MODE	Working area limitation during switchover of geometry axes
10710	PROG_SD_RESET_SAVE_TAB	Setting data to be updated

7.11.1.2 Channelspecific machine data

Number	Identifier: \$MC_	Description
20150	GCODE_RESET_VALUES	Initial setting of the G groups
21020	WORKAREA_WITH_TOOL_RADIUS	Allowance for tool radius with working area limitation
24130	TRAFO_INCLUDES_TOOL_1	Tool handling with active 1st transformation
24230	TRAFO_INCLUDES_TOOL_2	Tool handling with active 2nd transformation
24330	TRAFO_INCLUDES_TOOL_3	Tool handling with active 3rd transformation
24426	TRAFO_INCLUDES_TOOL_4	Tool handling with active 4th transformation
24436	TRAFO_INCLUDES_TOOL_5	Tool handling with active 5th transformation
24446	TRAFO_INCLUDES_TOOL_6	Tool handling with active 6th transformation
24456	TRAFO_INCLUDES_TOOL_7	Tool handling with active 7th transformation
24466	TRAFO_INCLUDES_TOOL_8	Tool handling with active 8th transformation
24476	TRAFO_INCLUDES_TOOL_9	Tool handling with active 9th transformation
24486	TRAFO_INCLUDES_TOOL_10	Tool handling with active 10th transformation
25106	TRAFO_INCLUDES_TOOL_11	Tool handling with active 11th transformation
25116	TRAFO_INCLUDES_TOOL_12	Tool handling with active 12th transformation
25126	TRAFO_INCLUDES_TOOL_13	Tool handling with active 13th transformation
25136	TRAFO_INCLUDES_TOOL_14	Tool handling with active 14th transformation
25146	TRAFO_INCLUDES_TOOL_15	Tool handling with active 15th transformation
25156	TRAFO_INCLUDES_TOOL_16	Tool handling with active 16th transformation
25166	TRAFO_INCLUDES_TOOL_17	Tool handling with active 17th transformation
25176	TRAFO_INCLUDES_TOOL_18	Tool handling with active 18th transformation
25186	TRAFO_INCLUDES_TOOL_19	Tool handling with active 19th transformation
25196	TRAFO_INCLUDES_TOOL_20	Tool handling with active 20th transformation
28600	MM_NUM_WORKAREA_CS_GROUPS	Number of coordinate system-specific working area limitations

7.11.1.3 Axis/spindlespecific machine data

Number	Identifier: \$MA_	Description
30200	NUM_ENCS	Number of encoders
30240	ENC_TYPE	Encoder type of the actual value acquisition (actual position value)
30260	ABS_INC_RATIO	Absolute encoder: ratio between absolute value and incremental value resolution
30270	ENC_ABS_BUFFERING	Absolute encoder: Traversing range extension
30310	ROT_IS_MODULO	Modulo conversion for rotary axis / spindle
30800	WORK_AREA_CHECK_TYPE	Type of checking of working area limits
31020	ENC_RESOL	Encoder pulses per revolution
31025	ENC_PULSE_MULT	Encoder multiplication (high resolution)
31046	ENC_PASSIVE_PARKING	Parking the passive position measuring system
31700	ENC_EDS_ACTIVE	Activate EDS use

7.11 Data lists

Number	Identifier: \$MA_	Description
31710	ENC_RESOL_EDS	Encoder pulses per revolution for EDS use
31720	ENC_PULSE_MULT_EDS	Encoder multiplication (high resolution) for EDS use
31730	ABS_INC_RATIO_EDS	Absolute encoder: Ratio between the absolute resolution and the incremental resolution for EDS use
32200	POSCTRL_GAIN [n]	K_v factor
32250	RATED_OUTVAL	Rated output voltage
32260	RATED_VELO	Rated motor speed
32300	MAX_AX_ACCEL	Maximum axis acceleration
32800	EQUIV_CURRCTRL_TIME	Equivalent time constant current control loop for feedforward control
32810	EQUIV_SPEEDCTRL_TIME	Equivalent time constant speed control loop for feedforward control
32910	DYN_MATCH_TIME [n]	Time constant for dynamic response adaptation
34210	ENC_REFP_STATE	Encoder status
35160	SPIND_EXTERN_VELO_LIMIT	Spindle speed limitation via PLCC
36000	STOP_LIMIT_COARSE	Exact stop coarse
36010	STOP_LIMIT_FINE	Exact stop fine
36020	POSITIONING_TIME	Delay time exact stop fine
36030	STANDSTILL_POS_TOL	Zero speed tolerance
36040	STANDSTILL_DELAY_TIME	Delay time zero-speed monitoring
36050	CLAMP_POS_TOL	Clamping tolerance with IS "Clamping active"
36052	STOP_ON_CLAMPING	Special functions for clamped axis
36060	STANDSTILL_VELO_TOL	Maximum velocity/speed "Axis/spindle stationary"
36100	POS_LIMIT_MINUS	1st software limit switch minus
36110	POS_LIMIT_PLUS	1st software limit switch plus
36120	POS_LIMIT_MINUS2	2nd software limit switch minus
36130	POS_LIMIT_PLUS2	2nd software limit switch plus
36200	AX_VELO_LIMIT	Threshold value for velocity monitoring
36210	CTRLOUT_LIMIT	Maximum speed setpoint
36220	CTRLOUT_LIMIT_TIME	Delay time for speed-setpoint monitoring
36300	ENC_FREQ_LIMIT	Encoder limit frequency
36302	ENC_FREQ_LIMIT_LOW	Encoder limit frequency for encoder resynchronization
36310	ENC_ZERO_MONITORING	Zero mark monitoring
36312	ENC_ABS_ZEROMON_WARNING	Zero-mark monitoring warning threshold
36400	CONTOUR_TOL	Tolerance band contour monitoring
36500	ENC_CHANGE_TOL	Maximum tolerance for position actual value switchover
36510	ENC_DIFF_TOL	Measuring system synchronism tolerance
36600	BRAKE_MODE_CHOICE	Braking behavior at hardware limit switch
36610	AX_EMERGENCY_STOP_TIME	Maximum duration of the braking ramp for faults
36620	SERVO_DISABLE_DELAY_TIME	Cutout delay controller enable

7.11.2 Setting data

7.11.2.1 Axis/spindlespecific setting data

Number	Identifier: \$SA_	Description
43400	WORKAREA_PLUS_ENABLE	Working area limitation active in positive direction
43410	WORKAREA_MINUS_ENABLE	Working area limitation active in negative direction
43420	WORKAREA_LIMIT_PLUS	Working area limitation plus
43430	WORKAREA_LIMIT_MINUS	Working area limitation minus

Contour tunnel monitoring

8.1 Brief description

8.1.1 Contour tunnel monitoring

Function

The absolute movement of the tool tip in space is monitored. The function operates channel specific.

Model

A round tunnel with a definable diameter is defined around the programmed path of a machining operation. Axis movements are stopped as an option if the path deviation of the tool tip is greater than the defined tunnel as the result of axis errors.

Response

In the event of a recognized deviation, the system reacts as quick as possible. However, at least one interpolator clock cycle will pass, before one of the following reactions will occur:

- An alarm is triggered when the tunnel is violated and the axes continue to traverse.
- Violation of the tunnel triggers an alarm and the axis movements are decelerated.

Braking methods

If the monitoring tunnel is violated, one of the following methods can be used to decelerate:

- Deceleration ramp
- Speed setpoint zero and follow-up mode

Use

The function can be used for 2D and 3D paths. For 2D the monitoring surface is defined by parallel lines to the programmed path. The monitoring area is defined by 2 or 3 geometry axis.

Monitoring of synchronized axes, positioning axes, etc. that are not geometry axes is performed directly on the machine axis plane with the "Contour monitoring".

Example

The following figure is a diagram of the monitoring area shown by way of a simple example.




Figure 8-1 Position of the contour tunnel around the programmed path

As long as the calculated actual position of the tool tip remains inside the sketched tunnel, motion continues in the normal way. If the calculated actual position violates the tunnel, an alarm is triggered (in the default setting) and the axes are stopped by "Ramp Stop". This response to the violation of the tunnel can be disabled (alarm triggered but movement continued) or intensified (rapid stop) by means of a machine data setting.

Analysis

The calculated distance between the programmed path and the actual values can be routed to an analog output to analyze the progression of the contour errors during normal operation (quality control).

8.1.2 Programmable contour accuracy

Function

As an alternative to the function described in "Contour tunnel monitoring", i.e. monitoring of the machining accuracy and stopping machining if excessive deviations occur, another function is offered. With this function, the selected accuracy is always achieved with the path velocity being reduced if necessary. Detailed information about this function can be found under the subject "Programmable contour accuracy".

8.2 Contour tunnel monitoring

Aim of the monitoring function

The aim of the monitoring function is to stop the movement of the axes if axis deviation causes the distance between the tool tip (actual value) and the programmed path (setpoint) to exceed a defined value (tunnel radius).

Tunnel size

The radius of the contour tunnel being monitored around the programmed path must be defined to implement the monitoring function:

MD21050 \$MC_CONTOUR_TUNNEL_TOL (Response threshold for Contour tunnel monitoring)

If the machine data is set to 0.0, monitoring is not performed. The value of the machine data is transferred to the control for new configurations.

Parameterizable deceleration behavior

The deceleration behavior for the monitoring response can be set via the following machine data:

MD21060 \$MC_CONTOUR_TUNNEL_REACTION (Reaction upon response of contour tunnel monitoring)

Value	Meaning
0	Display alarm and continue machining
1	Deceleration according to the deceleration ramps (default setting)
2	Rapid stop (speed setpoint = 0)

Encoder switchover

Switching between two encoder systems usually causes a sudden change in the actual position of the tool tip. This change resulting from encoder switchover must not be so large as to cause the tool tip to violate the monitoring tunnel. The radius defined in MD21050 must be higher than the allowed tolerance on actual value switchover:

MD36500 \$MA_ENC_CHANGE_TOL (Max. tolerance for position actual value switchover)

Activation

The monitoring will only become active if the following conditions are met:

- MD21050 is higher than 0.0.
- At least two geometry axes have been defined.

Shutting down

Monitoring can be stopped by enabling the machine data setting:

MD21050 = 0.0.

Analysis output

The values of deviation of the actual value of the tool tip from the programmed path can – for analysis purposes – be output on a fast analog output (accuracy monitoring).

The assignment of an analog output to output the contour error is programmed in machine data:

MD21070 \$MC_CONTOUR_ASSIGN_FASTOUT

Value	Meaning
0	No output (default setting)
1	Output to output 1
2	Output to output 2
...	...
8	Output to output 8

Scale

The tunnel radius set in MD21050 corresponds to a voltage of 10 V at the output.

8.3 Programmable contour accuracy

Function

The function "Programmable contour accuracy" limits the contour errors caused by control behavior and jerk filter to a specified value by reducing the path velocity on curved contours by the necessary amount. It allows the user to set a compromise between accuracy and productivity of a machining.

Note

The "LookAhead" function ensures that the velocity necessary for maintaining the required contour accuracy is not exceeded at any point along the path.

Configuration

The mode of operation and parameterization of the function is determined by the machine data:

MD20470 \$MC_CPREC_WITH_FFW (programmable contour accuracy)

Value	Meaning
0	The "Programmable contour accuracy" function has no effect when feedforward control is also active.
1	The "Programmable contour accuracy" function also acts for feedforward control. With active feedforward control, the reduction of the path velocity is calculated on the basis of the effective K_v factor with feedforward control.
2	Like 1, the function, however, is parameterized with MD32415 \$MA_EQUIV_CPREC_TIME (time constant for the programmable contour accuracy). The jerk filter is correctly taken into account. The SD42450 \$SC_CONTPREC setting data determines the permissible contour errors (see "Parameterization").
3	Like for 2, but any contour accuracy programmed with CTOL has priority over SD42450 \$SC_CONTPREC. The jerk filter is correctly taken into account. The programmed CTOL contour tolerance determines the permissible contour errors (see "Parameterization"). \$SC_CONTPREC is only relevant if CTOL was not programmed.
4	The "Programmable contour accuracy" function is active irrespective of the feedforward control and jerk filter. Only MD32415 \$MA_EQUIV_CPREC_TIME is considered in the calculation of the contour error. All time constants that affect the contour error must be added together and entered in MD32415 \$MA_EQUIV_CPREC_TIME.
5	Like for 4, but any programmed contour accuracy with CTOL has priority over SD42450 \$SC_CONTPREC.

For the MD20470 = 2 or 3 functional versions, the control assumes that there is a jerk filter time constant (MD32410 \$MA_AX_JERK_TIME) for which the setting of the control section with feedforward control produces a negligible contour error. This value must be entered in the machine data MD32415 \$MA_EQUIV_CPREC_TIME (see "Parameterization").

To calculate the contour error based on the set jerk filter type (MD32402 \$MA_AX_JERK_MODE), the following value is used:

- For active feedforward control, the difference:
MD32410 \$MA_AX_JERK_TIME - MD32415 \$MA_EQUIV_CPREC_TIME
- Without feedforward control, the complete value from MD32410 \$MA_AX_JERK_TIME

This procedure allows the commissioning engineer to first change from an initially precise, but possibly excessively hard, setting by increasing the jerk filter time constants to a softer setting with a controlled loss of accuracy.

If function "Programmable contour accuracy" is used in combination with jerk filter type "FIR low pass" (MD32402 \$MA_AX_JERK_MODE = 5), memory space must be made available for the characteristic curve approximation of FIR filters during commissioning with the memory-configuring machine data MD38020 \$MA_MM_CPREC_FIR_POINTS. If no memory is made available (MD38020 = 0), the function cannot be executed and alarm 10990 is output.

Restrictions:

- The function does not use the "band stop" jerk filter type (MD32402 \$MA_AX_JERK_MODE = 3).
- The MD20470 = 2 or 3 functional versions are primarily intended for use with feedforward control. If one of the two functional versions is active for switched off feedforward control, a contour error that results from the K_v factor is added. This reduces the path velocity significantly faster.

Note

The MD20470 = 0 or 1 functional versions are no longer recommended. They only provide compatibility with older software versions.

Parameterization**Contour accuracy**

The maximum contour error for the path of the geometry axes on curved contours is determined by:

- For MD20470 \$MC_CPREC_WITH_FFW = 2 with the setting data:
SD42450 \$SC_CONTPREC (contour accuracy)
- For MD20470 \$MC_CPREC_WITH_FFW = 3 with the contour tolerance programmed with CTOL.

The smaller the value and the lower the K_v factor of the geometry axes, the greater the path feedrate on curved contours is lowered.

Minimum path feedrate

The user can use the following setting data to specify a minimum path feedrate for the "Programmable contour accuracy" function:

SD42460 \$SC_MINFEED (minimum path feed with CPRECON)

The feedrate will not be limited below this value, unless a lower F value has been programmed or the dynamic limitations of the axes force a lower path velocity.

Time constant for the programmable contour accuracy

The equivalent time constant for the MD20470 = 2 or 3 functional versions (see "Configuration") is entered in the machine data:

MD32415 \$MA_EQUIV_CPREC_TIME (time constant for the programmable contour accuracy)

MD32415 must contain that jerk filter time constant (MD32410 \$MA_AX_JERK_TIME) for which the contour error for active feedforward control is negligibly small.

Programming

The "programmable contour accuracy" can be activated and deactivated in the part program with the CPRECON and CPRECOF modal G commands.

Example:

Program code	Comment
N10 G0 X0 Y0	
N20 CPRECON	; Activate the "programmable contour accuracy".
N30 G1 G64 X100 F10000	; Machining with 10 m/min in the continuous-path mode.
N40 G3 Y20 J10	; Automatic feed limitation in circular block.
N50 G1 X0	; Feedrate again without limitation (10 m/min).

Program code	Comment
...	
N100 CPRECOF	; Deactivate the "programmable contour accuracy".
N110 G0 ...	

The two CPRECON and CPRECOF modal G commands form G group 39 (programmable contour accuracy).

Behavior for part program start and after reset / part program end

For part program start and after reset / part program end, the configured control initial setting acts for the G group 39:

MD20110 \$MC_RESET_MODE_MASK (definition of initial control settings after RESET / TP End)

MD20112 \$MC_START_MODE_MASK (definition of the basic setting of the control after part program start)

Supplementary conditions

Positioning axes

The function considers only the geometry axes of the path. It does not have any effect of the velocities for the positioning axes.

Additional information

For information about MD32402 \$MA_AX_JERK_MODE (filter type for axial jerk limitation) and MD32410 \$MA_AX_JERK_TIME (time constant for the axial jerk filter), see:

- Function Manual Axes and Spindles

For information about CTOL, see:

- Function Manual Basic Functions

8.4 Constraints

Availability of the "Contour tunnel monitoring" function

The function is an option ("Contour monitoring with tunnel function"), which must be assigned to the hardware via the license management.

Coupled motion

If coupled motion between two geometry axes is programmed with contour tunnel monitoring, this always results in activation of the contour tunnel monitoring. In this case, the contour tunnel monitoring must be switched off before programming the coupled motion:

MD21050 \$MC_CONTOUR_TUNNEL_TOL = 0.0

8.5 Data lists

8.5.1 Machine data

8.5.1.1 Channelspecific machine data

Number	Identifier: \$MC_	Description
20110	RESET_MODE_MASK	Determination of basic control settings after Reset / TP End
20112	START_MODE_MASK	Definition of the initial control settings after part program start
20470	CPREC_WITH_FFW	Programmable contour accuracy
21050	CONTOUR_TUNNEL_TOL	Response threshold for contour tunnel monitoring
21060	CONTOUR_TUNNEL_REACTION	Reaction to response of contour tunnel monitoring
21070	CONTOUR_ASSIGN_FASTOUT	Assignment of an analog output for output of the contour error

8.5.1.2 Axis/spindlespecific machine data

Number	Identifier: \$MA_	Description
32402	AX_JERK_MODE	Filter type for axial jerk limitation
32410	AX_JERK_TIME	Time constant for axial jerk filter
32415	EQUIV_CPREC_TIME	Time constant for the programmable contour accuracy
36500	ENC_CHANGE_TOL	Maximum tolerance for position actual value switchover

8.5.2 Setting data

8.5.2.1 Channelspecific setting data

Number	Identifier: \$SC_	Description
42450	CONTPREC	Contour accuracy
42460	MINFEED	Minimum path feed for CPRECON

Compensations

9.1 Introduction

Accuracy errors

The accuracy of machine tools is impaired as a result of deviations from the ideal geometry, power transmission faults and measuring system errors. Temperature differences and mechanical forces often result in great reductions in precision when large workpieces are machined.

Compensation functions

Some of these deviations can usually be measured during commissioning and then compensated for during operation on the basis of values read by the positional actual-value encoder and other sensory devices. State-of-the-art CNC controls have compensation functions that are active on an axis for axis basis.

Parameterization

These compensation functions can be set for each machine individually with axis-specific machine data.

Activation

The compensations are active in all operating modes of the control as soon as the input data are available. Any compensations that require the position actual value are not activated until the axis reaches the reference point.

Position display

The normal actual-value and setpoint position displays ignore the compensation values and show the position values of an ideal machine. The compensation values are output in the "Diagnosis" operating area of the "Axis/Spindle Service" window.

9.2 Temperature compensation

9.2.1 Function

Deformation due to temperature effects

Heat generated by the drive equipment or high ambient temperatures (e.g. caused by sunlight, drafts) cause the machine base and parts of the machinery to expand. This expansion depends, among other things, on the temperature and on the thermal conductivity of the machine parts.

Effects

Due to the thermal expansion of the machinery, the actual positions of the axes change depending on temperature. This has a negative impact on the precision of the workpieces being machined.

Temperature compensation

By activating the "temperature compensation" function, actual value changes due to temperature effects can be compensated on an axis-by-axis basis.

Sensor equipment

To provide effective temperature compensation, a number of temperature sensors for acquiring a temperature profile are needed in addition to the actual position data from existing encoders.

Since temperature-dependent changes occur relatively slowly, the PLC can acquire and preprocess the temperature profile in a minutes cycle, for example.


Error curves

In order to implement temperature compensation, the actual-value offsets over the positioning range of the axis must be measured at a given temperature (T) and plotted. This produces an error curve for this temperature value. Error curves must be produced for different temperatures.

Error curve characteristic

If an axis position reference point P_0 is selected, an offset in the reference point (corresponds to the "position-independent component" of the temperature compensation) can be observed as the temperature changes, and because of the change in length an additional offset in the other position points, which increases with the distance to the reference point (corresponds to the "position-dependent component" of the temperature compensation).

The error curve for a given temperature T can generally be represented with sufficient accuracy by a straight line with a temperature dependent gradient and reference position:



Compensation equation

The compensation value ΔK_x is calculated on the basis of current actual position P_x of this axis and temperature T according to the following equation:

$$\Delta K_x = K_0 (T) + \tan\beta (T) * (P_x - P_0)$$

The meaning is as follows:

- ΔK_x : Temperature compensation value of axis at position P_x
- K_0 : Position-independent temperature compensation value of axis
- P_x : Actual position of axis
- P_0 : Reference position of axis
- $\tan\beta$: Coefficient for the position-dependent temperature compensation (corresponds to the gradient of the approximated error line)




Figure 9-1 Approximated error line for temperature compensation

Effectiveness

The following conditions must be fulfilled so that the temperature compensation can be activated:

1. The compensation type is selected (MD32750, see "Commissioning (Page 223)").
2. The parameters for the compensation type are defined (see "Commissioning (Page 223)").
3. The axis is referenced.
DB31, ... DBX60.4 or 60.5 =1 (referenced/synchronized 1 or 2)

As soon as these conditions are fulfilled, the temperature compensation value for the position actual value is added to the setpoint in all modes and the machine axis traverses through this distance. If the compensation value ΔK_x is positive, the axis moves in the negative direction.

If the reference position is then lost, e.g. because the encoder frequency has been exceeded (DB31, ... DBX60.4 or 60.5 = 0), compensation processing is deactivated.

Clock cycle

The compensation values are determined in the interpolator clock cycle.

Display

The total compensation value calculated from the temperature and sag compensation functions belonging to the actual position is output in the "Diagnosis" operating area of the "Axis/Spindle Service" window.

Parameter adaptation for temperature changes

Since the approximated error line applies only to the instantaneous temperature value, the parameters of the error lines that are newly generated when the temperature rises or falls must be sent to the NC again. Only in this way can expansion due to heat always be correctly compensated.

When temperature T changes, the parameters which are temperature-dependent, i.e. (K_0 , $\tan\beta$ and P_0) also change and can thus always be overwritten by the PLC or by means of a synchronized action.

It is thus possible for the machine-tool manufacturer to emulate the mathematical and technological relationship between the axis positions and temperature values via the PLC user program and thus calculate the various parameters for the temperature compensation. The temperature parameters are transferred to the NC using the variable services (FB2 (GET) "Read data" and FB3 (PUT) "Write data").

For more detailed information regarding handling and supplying FB2 and FB3, see:

Further information:

Function Manual PLC

Smooth the compensation value

To prevent overloading of the machine or tripping of monitoring functions in response to step changes in the temperature compensation parameters, the compensation values are distributed over several IPO cycles by an internal control function as soon as they exceed the maximum compensation value specified for each IPO cycle (MD32760, see "Commissioning (Page 223)").

9.2.2 Commissioning

Temperature-dependent parameters

Error curves for different temperatures can be defined for each axis. For each error curve the following parameters must be determined and then entered in the setting data:

- Position-independent temperature compensation value K_0 :
SD43900 \$SA_TEMP_COMP_ABS_VALUE
- Reference position P_0 for position-dependent temperature compensation:
SD43920 \$SA_TEMP_COMP_REF_POSITION
- Gradient $\tan\beta$ for position-dependent temperature compensation:
SD43910 \$SA_TEMP_COMP_SLOPE

Temperature compensation type and activation

The temperature compensation type is selected and the temperature compensation activated using the axis-specific machine data:

MD32750 \$MA_TEMP_COMP_TYPE (temperature compensation type)

Bit	Value	Meaning	Associated parameters
0		Position independent temperature compensation	SD43900
	0	Not active	
	1	Active	
1		Position-dependent temperature compensation	SD43920, SD43910
	0	Not active	
	1	Active	
2		Temperature compensation in tool direction	MD20390 \$MC_TOOL_TEMP_COMP_ON (Activate temperature compensation tool length)
	0	Not active	
	1	Active	

Maximum compensation value per IPO clock cycle

The maximum possible compensation value per IPO cycle, i.e. the maximum distance that can be traversed in an IPO cycle as a result of the temperature compensation, is limited using machine data:

MD32760 \$MA_COMP_ADD_VELO_FACTOR (velocity increase as a result of compensation)

The specified value acts as a factor and is referred to the maximum axis velocity (MD32000 \$MA_MAX_AX_VELO).

MD32760 also limits the maximum gradient of the error line ($\tan \beta$) of the temperature compensation.

9.2.3 Example

9.2.3.1 Commissioning the temperature compensation for the Z axis of a lathe

Commissioning of temperature compensation is described below using the example of a Z axis on a lathe.

Determining the error characteristic of the Z axis

In order to determine the temperature-dependent error characteristic of the Z axis, proceed as follows:

- Uniform temperature increase by traversing the axis across the whole Z axis traversing range (in the example: from 500 mm to 1500 mm)
- Measuring the axis position in increments of 100 mm
- Measuring the actual temperature at the leadscrew
- Executing a traversing measuring cycle every 20 minutes

The mathematical and technological relationships and the resulting parameters for temperature compensation are derived from the recorded data. The calculated deviation errors for a specific temperature, which refer to the actual position of the Z axis displayed by the NC, are represented in graphic form in the diagram below.




Figure 9-2 Error curves determined for the Z axis

Specifying parameters

The temperature compensation parameters must now be determined on the basis of the measurement results (see diagram above).

Reference position P_0

As the diagram above illustrates, there are basically two methods of parameterizing reference position P_0 :

1. $P_0 = 0$ with position-independent temperature compensation value $K_0 \neq 0$
2. $P_0 \neq 0$ with position-independent temperature compensation value $K_0 = 0$

In this case, version 2 is chosen, which means that the position-independent temperature compensation value is always 0. The temperature compensation value therefore only consists of the position-dependent component.

The following parameters are obtained:

- MD32750 \$MA_TEMP_COMP_TYPE = 2
(only position-dependent temperature compensation active)
- $P_0 = 320 \text{ mm} \rightarrow \text{SD43920 } \$SA_TEMP_COMP_REF_POSITION = 320$
(reference position for position-dependent temperature compensation)

Coefficient $\tan\beta$ (T)

In order to determine the dependency of coefficient $\tan\beta$ of the position-dependent temperature compensation on the temperature, the error curve gradient is plotted against the measured temperature:




Figure 9-3 Characteristic of coefficient $\tan\beta$ as a function of measured temperature T

With the appropriate linearization, coefficient $\tan\beta$ depends on T as follows:

$$\tan\beta(T) = (T - T_0) * TK_{\max} * 10^{-6} / (T_{\max} - T_0)$$

with

T_0 = temperature at which position-dependent error = 0; [degrees]

$T_{\max}$ = maximum measured temperature; [degrees]

$TK_{\max}$ = temperature coefficient at $T_{\max}$; [$\mu\text{m}/1000 \text{ mm}$]

Therefore, based on the values from the above diagram:

$$T_0 = 23^\circ$$

$$T_{\max} = 42^\circ$$

$$TK_{\max} = 270 \text{ } \mu\text{m}/1000 \text{ mm}$$

and $\tan\beta$ (T) is therefore:

$$\begin{aligned}\tan\beta(T) &= (T - 23) [\text{degrees}] * 270 [\mu\text{m}/1000 \text{ mm}] * 10^{-6} / (42 - 23) [\text{degrees}] \\ &= (T - 23) [\text{degrees}] * 14.21 [\mu\text{m}/1000 \text{ mm}] * 10^{-6}\end{aligned}$$

Example:

At a temperature of $T = 32.3$ degrees, therefore: $\tan\beta = 0.000132$

PLC user program

The formula given above must be used in the PLC user program to calculate the coefficient $\tan\beta$ (T) which corresponds to the measured temperature; this must then be written to the following NC setting data:

SD43910 \$SA_TEMP_COMP_SLOPE (gradient for position-dependent temperature compensation)

According to the example above:

SD43910 \$SA_TEMP_COMP_SLOPE = 0.000132

9.3 Backlash compensation

9.3.1 Mechanical backlash compensation


9.3.1.1 Function

Mechanical backlash can occur in moving machine parts in the drive train (machine axes), e.g. at a ballscrew or in the connection to the measuring system.

Effects

For a machine axis with indirect measuring system, mechanical backlash results in a difference between the actual position of the NC determined using the measuring system and the actual

position of the machine part. When the direction reverses, the machine axis traverses through a distance that is incorrect by the amount of the backlash:



Compensation

To compensate for the mechanical backlash, the actual value of the machine axis is corrected every time the axis reverses by the axis-specific compensation value set during commissioning (Page 228).

Effectiveness

The mechanical backlash compensation of a machine axis is active in all operating modes.
Requirement:

- Incremental measuring system: Encoder state == "referenced"
- Absolute encoder: Encoder state == "synchronized"

Displaying the compensation values

The compensation values active at the actual position of the machine axis are displayed on the user interface for each individual axis.

SINUMERIK Operate: "Diagnostics" operating area > ETC key (">") > "Axis diagnostics" > "Service axis" >

- "Absolute compensation value measuring system 1"
- "Absolute compensation value measuring system 2"
- "Compensation value from LEC"

9.3.1.2 Commissioning: Axis-specific machine data

Compensation value

The compensation value of the mechanical backlash is entered in the machine data.

MD32450 \$MA_BACKLASH[<active measuring system>] = <compensation value>

Measurement

- Traversing the machine axis and/or the machine part to any measurement position at a high velocity.
- Measuring the actual position of the machine part
- Calculating the backlash compensation value K_L
 $K_L = \text{"displayed actual position of the machine axis"} - \text{"measured actual position of the machine part"}$
 - $K_L > 0$ (**positive backlash**) $\Rightarrow$ **positive** compensation value
 - $K_L < 0$ (**negative backlash**) $\Rightarrow$ **negative** compensation value

Checking

To check the effect of the compensation, we recommend that the mechanical backlash is measured after the machine data has been activated.

Circularity test

The circularity test integrated in the user interface can be used to visualize the mechanical backlash.

SINUMERIK Operate: "Commissioning" operating area > "Optimization/Test" > "Circularity test"

Second measuring system

If an axis has a second measuring system, the compensation value must also be determined for this and entered in the machine data:

MD32450 \$MA_BACKLASH[<measuring system 2>]

When the measuring system is switched over, the associated compensation value is automatically used.

Evaluation factor dependent on the parameter set

For a mechanical backlash dependent on the parameter set, the parameter set-specific factor is entered into the following machine data, which is then applied to the compensation value of the backlash (MD32450 \$MA_BACKLASH).

MD32452 \$MA_BACKLASH_FACTOR[<parameter set 1 ... n>] = <factor>

Effective compensation value

The effective compensation value K_p of a parameter set is calculated as follows:

$K_p = (\text{MD32450 } \$MA_BACKLASH[\text{ <active measuring system> }]) * (\text{MD32452 } \$MA_BACKLASH_FACTOR[\text{ <parameter set> }])$

Backlash compensation mode

The response of mechanical backlash compensation of a machine axis is set using machine data:

MD32454 \$MA_BACKLASH_MODE

Bit	Meaning
0	Restores the last effective backlash compensation after the control system has powered up
	= 0 The backlash compensation value is not restored (default setting)
	= 1 The backlash compensation is restored.
	Precondition The measuring system active after the control powers up must be adjusted and synchronized: • MD34210 \$MA_ENC_REFP_STATE[<active measuring system>] == 2 • DB31,DBX60.4 - 5 == 1 (measuring system 1 / 2: Referenced, synchronized)
1	Effect of other compensation functions (temperature compensation, sag or angularity error compensation)
	= 0 The backlash compensation responds to other compensatory motion (default setting).
	= 1 The backlash compensation does not respond to other compensatory motion (default setting).

9.3.2 Dynamic backlash compensation

9.3.2.1 Function

Dynamic backlash

A dynamic backlash can occur for machine types with sliding guides. Depending on the axial dynamic response (velocity, jerk, etc.) used to approach an end position, the machine slide reaches the programmed end position or stops earlier because of the static friction. The resulting position error is direction-symmetric.

Compensation

To compensate for the dynamic backlash, half the signed compensation value (MD32456 Commissioning: Axis-specific machine data (Page 230), see "") is applied in accordance with the relevant traversing direction of the axis. Compensation value is applied as ramp.

Activation

The dynamic backlash compensation is activated by the PLC only in required the situations:

DB31, ... DBX25.0 (activate dynamic backlash compensation)

Note

The machine tool manufacturer specifies in the PLC user program the "required" situations for the activation of the dynamic backlash compensation. Such situations result with traversal of the axes with G1, in the JOG mode or with the handwheel.

The NC uses the following interface to return the required activation to the PLC:

DB31, ... DBX102.0 (active dynamic backlash compensation)

Requirement

The axes to be compensated must be homed.

Display

The compensation value that belongs to the current actual position is displayed in the "Diagnostics" operator area of the "Axis/Spindle Service" window as the total compensation calculated from LEC, mechanical and dynamic backlash compensation.

9.3.2.2 Commissioning: Axis-specific machine data**Compensation value**

As precondition to commission the dynamic backlash compensation, the mechanical backlash compensation must have already been commissioned (see Chapter "Commissioning: Axis-specific machine data (Page 228)"). To determine the compensation value for the dynamic backlash compensation, the measurement described there should be repeated with **low** traversing velocity. The compensation value determined in this way is entered in the machine data for the corresponding measuring system:

MD32456 \$MA_BACKLASH_DYN[<active measuring system>] = <compensation value for dynamic backlash compensation>

Maximum tolerance for position actual value switchover

You are provided the option of applying the backlash compensation value gradually in several increments when the relevant axis changes direction. This prevents a setpoint step change on the axes from causing corresponding errors. The contents of the axis-specific machine data determine the increment with which the backlash compensation value (MD32450) is applied:

MD36500 \$MA_ENC_CHANGE_TOL (max. tolerance on actual position value switchover)

Please note that the backlash compensation is only fully calculated after <n> servo cycles (<n> = MD32450 / MD36500). An excessive time span can cause the triggering of standstill monitoring alarms. If MD36500 > MD32450, then the compensation is performed in one servo cycle.

Compensation value change

Using the machine data, the velocity with which the compensation value is traversed through is set as a percentage of the maximum axis velocity (MD32000 \$MA_MAX_AX_VELO):

MD32457 \$MA_BACKLASH_DYN_MAX_VELO = <percentage of the maximum axis velocity>

9.3.3 Dual position feedback

For the "Dual position feedback" function, contrary to conventional (mechanical or dynamic) backlash compensation, two measuring systems, which are mechanically coupled through a gearbox without backlash, are used for the closed-loop position control. The advantages of a direct measuring system are combined with the advantages of an indirect measuring system:

- Direct measuring system: The closed-loop position control with direct, i.e. encoder on the load side, "automatically" corrects the backlash.
- Indirect measuring system: The closed-loop position control with indirect, i.e. encoder on the motor side, is "rugged" and "stable" regarding discontinuous backlash.

Each time the setpoint changes, initially only the encoder data from the indirect measuring system is used for rugged control without oscillation. With a parameterizable delay time, the closed-loop control smoothly transitions to monitor the direct measuring system, therefore, achieving the required accuracy on the load side. The control operations should, at this point in time, only involve short distances. This is because in the meantime the tooth flanks are in contact with one another, and the backlash has been moved through.

When using the "Dual position feedback" function, it is not necessary to measure and mathematically compensate the backlash.

Requirements

The following preconditions must be satisfied for an axis to be compensated:

- Direct and indirect measuring system, mechanically coupled:
 - MD30200 \$MA_NUM_ENCS = 2
 - MD31040 \$MA_ENC_IS_DIRECT[0] = 0 or 1
 - MD31040 \$MA_ENC_IS_DIRECT[1] = 1 or 0
- Measuring system calibration has been released:
 - MD34102 \$MA_REFP_SYNC_ENCS = 1
- Both measuring systems are referenced:
 - DB31, ... DBX60.4 (referenced/synchronized 1 / 2) = 1
 - DB31, ... DBX60.5 (referenced/synchronized 1 / 2) = 1

Application

Typical applications include main spindles on turning machines which feature a mechanical system without backlash between motor and main spindle (e.g. gear). Nevertheless, these axes require a direct measuring system for precision in C-axis operation (on the load side).

9.3 Backlash compensation

Due to mechanical factors such as backlash and rigidity, however, the axis cannot traverse with the same position control dynamic with encoder on the load side (in comparison to position control with motor encoder). The solution here is provided by the dual position feedback.

The servo gain factor does not have to be reduced and it can nevertheless be positioned on the direct encoder.

9.3.3.1 Commissioning: Axis-specific machine data

Delay time

The delay time, during which the closed-loop control smoothly transitions from the indirect to the direct measuring system, is entered in the machine data.

MD32960 \$MA_POSCTRL_DUAL_FEEDBACK_TIME = <delay time>

If the delay time is zero, then the function is inactive, and only the active measuring system (DB31,DBX1.5 / .6 (position measuring system 1 / 2)) is active for the position control.

Note

After activating the "Dual position feedback" function, all of the existing measuring system compensations and monitoring functions remain unchanged and active; this means that they may have to be deactivated by the user (e.g. backlash compensation values deleted).

9.3.3.2 Supplementary conditions

Referencing and flying measurement

Also when the "Dual position feedback" function is active, the "Referencing" and "Measuring" functions refer to the active measuring system (DB31,DBX1.5 / .6 (position measuring system 1 / 2)).

Further information

- Function Manual Axes and Spindles; Referencing
- Function Manual Technologies, Measuring

9.4 Nodding compensation

9.4.1 Description of the function

9.4.1.1 Options

The "Nodding compensation" function is an option subject to license. The following versions are available:

- **Nodding compensation ECO:** 6FC5800-0AS20-0YB0
Nodding compensation in **one** machine axis with **one** accelerating axis:
- **Nodding compensation ADVANCED:** 6FC5800-0AS21-0YB0
Nodding compensation in **any arbitrary number** of machine axes

9.4.1.2 Features

Nodding compensation is used to compensate dynamic position deviations in a machine axis due to this or another machine axis accelerating. The position deviations are obtained as a result of the mechanical compliance within the machine.

This is demonstrated in the following schematic of a 3-axis traveling column machine, as example. If the Y axis is accelerated with a_y , as a result of the mechanical compliance in the machine, position deviations Δ_z occur in the Z axis.




Figure 9-4 3-axis traveling column machine

Definition of terms

- Nodding compensation axes
The machine axes involved in the nodding compensation are designated as follows: //////
 - **Compensating axis**
A machine axis, resulting from other machine axes accelerating, results in position deviations, which can be compensated by nodding compensation. In the diagram: Compensating axis $\Rightarrow$ Z axis
 - **Accelerating axis**
Machine axis, whose acceleration as a result of compliance in the machine, results in a position deviation in the compensating axis. In the diagram: Accelerating axis $\Rightarrow$ Y axis
 - **Adaptation axis**
Machine axis, whose position when traversing the accelerating axis influences the magnitude of the position deviation in the compensating axis. In the diagram: Adaptation axis $\Rightarrow$ X axis
 - Compliance factor
Compliance factor N defines the magnitude of the position deviation Δ of the compensating axis for traversing motion of the accelerating axis with acceleration a. Compliance factor N is the quotient of position deviation Δ of the compensating axis and the acceleration a of the accelerating axis that actually causes the deviation: $N = \Delta / a$
-

Note**Further information**

Determining the compliance factor is described in detail in

- Commissioning Manual, CNC Commissioning: NC, PLC, drive; Commissioning NC > Nodding compensation
 - Online help
The online help for nodding compensation is called from the SINUMERIK Operate user interface via: Commissioning > NC > Nodding compensation > Help button on the operator panel front
-


- Compensation value
The actual compensation value Δ is obtained by multiplying the actual compliance factor N with the actual acceleration a of the axis causing the deviation

Boundary conditions

- **Rotary axes**
It is not permissible for the compensating, the accelerating or the adaptation axis to be a rotary axis.
- **Differences to the compile cycle "RMCC/NOCO nodding compensation"**
(6FC5800-0AN63-0YB0)
 - The functionality of system function "Nodding compensation" is, contrary to compile cycle "RMCC/NOCO", exclusively limited to compensating nodding motion. The functions provided beyond this in the compile cycle, such as compensating centrifugal forces, taking into account rotary axis positions as well as comprehensive position tables, are not available with the system function.
 - Either system function "Nodding compensation" can be used – or compile cycle "RMCC/NOCO", but not together.
 - It is not possible to use the parameterizing data of compile cycle "RMCC/NOCO" to parameterize the "Nodding compensation" system function.

9.4.1.3 Position-dependent compliance factor

If the machine compliance depends on the position of another machine axis (adaptation axis), then up to three different positions of the adaptation axis can be selected as interpolation points of the adaptation characteristic; the effective compliance factors can then be determined from the characteristic. Positions (P_1 , P_2 , P_3) and the compliance factors effective there (N_1 , N_2 , N_3) must be saved in the machine data of the compensating axis. When traversing the accelerating axis, the effective compliance factor is calculated depending on the position of the adaptation axis by linearly interpolating between the interpolation points.



- ① Traversing range of the adaptation axis with $P_1 < P_2 < P_3$
- ② Compliance factor of the compensating axis
- ③ Traversing range limit -
- ④ Traversing range limit +

Figure 9-5 Compensation characteristic

Actual position: P	Compliance factor: N
P less than P_1 up to traversing range limit minus	$N = N_1$
P between P_1 and P_2	$N = \text{linear interpolation between } N_1 \text{ and } N_2$
P equal to P_2	$N = N_2$
P between P_2 and P_3	$N = \text{linear interpolation between } N_2 \text{ and } N_3$
P greater than or equal to P_3 - up to the traversing range limit plus	$N = N_3$

9.4.1.4 Compensation relationships

A compensation relationship defines the following dependencies of the compensation value:

- On the acceleration of the accelerating axis
- On the position of the adaptation axis
- On the machine compliance

Up to three compensation relationships can be parameterized in the machine data of a compensating axis. The following data can be set for each compensation relationship:

- Accelerating axis
- Adaptation axis
- Number of positions of the adaptation axis
- Positioning the adaptation axis
- Compliance factors at the positions

Accelerating axes or adaptation axes

Any **linear** machine axis of the NC can be used as accelerating axis or adaptation axis. Even the compensating axis itself.

Total compensation value

The total compensation value acting on the compensating axis is the sum of the compensation values of the individual compensation relationships.

9.4.2 Commissioning: Machine data

9.4.2.1 Overview

The following table provides an overview with which machine data the nodding compensation is parameterized.

Number	Name: \$MA_	Meaning
MD37302	NOCO_FILTER_TIME	Time constant for smoothing nodding compensation values (Page 237)
Compensation relationship 1		

Number	Name: \$MA_	Meaning
MD37310	NOCO_INPUT_AX_1	Machine axis that causes nodding motion (Page 238)
MD37312	NOCO_ADAPT_AX_1	Machine axis, whose position influences nodding motion (Page 238)
MD37314	NOCO_ADAPT_NUM_1	Number of positions, adaptation characteristic of the nodding compensation (Page 239)
MD37316	NOCO_ADAPT_POS_1	Positions, adaptation characteristic of the nodding compensation (Page 240)
MD37318	NOCO_COMPLIANCE_1	Compliance factors for nodding compensation (Page 241)
Compensation relationship 2		
MD37320	NOCO_INPUT_AX_2	See MD37310
MD37322	NOCO_ADAPT_AX_2	See MD37312
MD37324	NOCO_ADAPT_NUM_2	See MD37314
MD37326	NOCO_ADAPT_POS_2	See MD37316
MD37328	NOCO_COMPLIANCE_2	See MD37318
Compensation relationship 3		
MD37330	NOCO_INPUT_AX_3	See MD37310
MD37332	NOCO_ADAPT_AX_3	See MD37312
MD37334	NOCO_ADAPT_NUM_3	See MD37314
MD37336	NOCO_ADAPT_POS_3	See MD37316
MD37338	NOCO_COMPLIANCE_3	See MD37318

9.4.2.2 Time constant for smoothing nodding compensation values

Using the machine data, the time constant is set with which the total nodding compensation value is smoothed when it is entered.



- ① Position deviation
- Blue: Setpoint
 - Red: Actual value

MD37302 \$MA_NOCO_FILTER_TIME[<comp. axis>] = <time constant>

Note

Deactivating smoothing

Smoothing is deactivated - or is not active - if the time constant is set to less than 10 % of the position controller clock cycle:

Time constant < 0,1 * MD10061 \$MN_POSCTRL_CYCLE_TIME

9.4.2.3 Accelerating axis

The number of the machine axis, whose acceleration causes position deviations in the compensating axis, must be entered in the machine data.

The number of the accelerating axis refers to the machine axes of the NC parameterized in machine data MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB. The machine axis number is the corresponding machine data index + 1.

MD37310 \$MA_NOCO_INPUT_AX_1[<comp. Achse>] = <machine axis number>

Example

As a result of the machine compliance, when the Y axis accelerates, a position deviation occurs in the Z axis.

- Compensating axis: AX3 (Z axis)
- Accelerating axis: AX2 (Y axis)




Figure 9-6 Accelerating axis AX2 (Y axis)

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 0 ] = "AX1" ; X axis
```

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 1 ] = "AX2" ; Y axis
```

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 2 ] = "AX3" ; Z axis
```

```
MD37310 $MA_NOCO_INPUT_AX_1[ AX3 ] = 2 ; accelerating axis = Y axis
```

9.4.2.4 Adaptation axis

The number of the machine axis, whose actual position influences the position deviation in the compensating axis, must be entered in the machine data.

The machine axis number refers to the machine axes of the NC parameterized in machine data MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB. The machine axis number is the corresponding machine data index + 1.

MD37312 \$MA_NOCO_ADAPT_AX_1[<comp. Achse>] = <machine axis number>

Note


Activating the position-dependent adaptation

The position-dependent adaptation only becomes active if one adaptation axis and more than one position (MD37314 \$MA_NOCO_ADAPT_NUM_1 (Page 239)) are parameterized.

Example

As a result of the machine compliance, when the Y axis accelerates, a position deviation occurs in the Z axis. Further, the position deviation depends on the position of the X axis.

- Compensating axis: AX3 (Z axis)
- Accelerating axis: AX2 (Y axis)
- Adaptation axis: AX1 (X axis)



①, ②, ③ Axis positions of the adaptation axis AX1 (X axis)

Figure 9-7 Adaptation axis AX1 (X axis)

MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB[0] = "AX1" ; X axis

MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB[1] = "AX2" ; Y axis

MD10002 \$MN_AXCONF_LOGIC_MACHAX_TAB[2] = "AX3" ; Z axis

MD37312 \$MA_NOCO_ADAPT_AX_1[**AX3**] = **1** ; adaptation axis = X axis

9.4.2.5 Number of positions of the adaptation characteristic

The number of axis positions, for which another compliance is effective, must be entered in the machine data for the position-dependent adaptation.

MD37314 \$MA_NOCO_ADAPT_NUM_1[<comp. Axis>] = <number>

Note


Activating the position-dependent adaptation

The position-dependent adaptation only becomes active if more than one position and one adaptation axis (MD37312 \$MA_NOCO_ADAPT_AX_1 (Page 238)) are parameterized.

Example

Interpolation points of the adaptation characteristic are to be parameterized at three positions along the traversing range of the adaptation axis (X axis).

- Compensating axis: AX3 (Z axis)
- Accelerating axis: AX2 (Y axis)
- Adaptation axis: AX1 (X axis)



①, ②, ③ Axis positions of the adaptation axis AX1 (X axis)

Figure 9-8 Number of axis positions of the adaptation axis AX1 (X axis)

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 0 ] = "AX1"    ; X axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 1 ] = "AX2"    ; Y axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 2 ] = "AX3"    ; Z axis
```

```
MD37314 $MA_NOCO_ADAPT_NUM_1[ AX3 ] = 3      ; number of axis positions
```

See also:

- Axis positions: MD37316 \$MA_NOCO_ADAPT_POS_1 (Page 240)
- Compliance factors: MD37318 \$MA_NOCO_COMPLIANCE_1 (Page 241)

9.4.2.6 Positions of the adaptation characteristic


The positions of the adaptation axis, at which a dedicated compliance factor is parameterized, must be entered in the machine data for the interpolation points of the adaptation characteristic:

MD37316 \$MA_NOCO_ADAPT_POS_1[<index>, <comp. Axis>] = <position>

Example

Interpolation points are parameterized at positions -100.0, 0.0, and 120.0 of adaptation axis AX1 (X axis) for the adaptation characteristic.

- Compensating axis: AX3 (Z axis)
- Accelerating axis: AX2 (Y axis)
- Adaptation axis: AX1 (X axis)



- ① Position 1: -100.0
- ② Position 2: 0.0
- ③ Position 3: 120.0

Figure 9-9 Axis positions of the adaptation axis AX1 (X axis)

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 0 ] = "AX1" ; X axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 1 ] = "AX2" ; Y axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 2 ] = "AX3" ; Z axis
```

```
MD37316 $MA_NOCO_ADAPT_POS_1[ 0, AX3 ] = -100.0
MD37316 $MA_NOCO_ADAPT_POS_1[ 1, AX3 ] = 0.0
MD37316 $MA_NOCO_ADAPT_POS_1[ 2, AX3 ] = 120.0
```

See also:

- Number of axis positions: MD37314 \$MA_NOCO_ADAPT_NUM_1 (Page 239)
- Compliance factors: MD37318 \$MA_NOCO_COMPLIANCE_1 (Page 241)

9.4.2.7**Compliance factors**

The compliance factors associated with the particular positions of the adaptation characteristic (MD37316 \$MA_NOCO_ADAPT_POS_1 (Page 240)) must be entered in the machine data.

MD37318 \$MA_NOCO_COMPLIANCE_1[<index>, <comp. Achse>] = <compliance factor>

Without position-dependent adaptation


If no position-dependent adaptation is parameterized (MD37312 \$MA_NOCO_ADAPT_AX_1 (Page 238) == 0), then the compliance factor must be entered into index 0:

MD37318 \$MA_NOCO_COMPLIANCE_1[0, <comp. Achse>] = <compliance factor>

Example

At positions -100.0, 0.0, and 120.0 of the traversing range of the adaptation axis (X axis), for the compensating axis AX3 (Z axis) compliance factors -12 , -25 and $-10 \mu\text{m} / \text{m/s}^2$ are determined.

- Compensating axis: AX3 (Z axis)
- Accelerating axis: AX2 (Y axis)
- Adaptation axis: AX1 (X axis)



- ① Compliance factor at position 1: $-12 \mu\text{m} / \text{m/s}^2$
- ② Compliance factor at position 2: $-25 \mu\text{m} / \text{m/s}^2$
- ③ Compliance factor at position 3: $-10 \mu\text{m} / \text{m/s}^2$

Figure 9-10 Adaptation axis: AX1 (X axis)

```
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 0 ] = "AX1"    ; X axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 1 ] = "AX2"    ; Y axis
MD10002 $MN_AXCONF_LOGIC_MACHAX_TAB[ 2 ] = "AX3"    ; Z axis
```

```
MD37318 $MA_NOCO_COMPLIANCE_1[ 0, AX3 ] = -0.000012
MD37318 $MA_NOCO_COMPLIANCE_1[ 1, AX3 ] = -0.000025
MD37318 $MA_NOCO_COMPLIANCE_1[ 2, AX3 ] = -0.000010
```

See also:

- Number of axis positions: MD37314 \$MA_NOCO_ADAPT_NUM_1 (Page 239)

9.4.2.8 Function diagram




Figure 9-11 Function diagram of a compensating axis

9.5 Interpolatory compensation

9.5.1 General properties

Function

With "interpolating compensation," deviations between the desired and the actual position of an axis can be compensated by leadscrew, measuring system, sag and angularity errors. This is done by determining the deviation by measurement and storing the corresponding compensation values in one or more compensation tables in the NC. During operation, the relevant compensation value is then determined from the compensation table or tables for a compensation axis based on its current set position. Linear interpolation is performed between the interpolation points of the compensation tables.

Within "interpolating compensation", a distinction is made between the two following compensation methods:

- Compensation of leadscrew errors and measuring system errors
- Compensation of sag and angularity errors

Terms

- Compensation value
Additional setpoint that is applied to the compensation axis so that the difference between the desired and actual axis position is zero.
- Basic axis
Axis, via whose set and actual position, the compensation value is determined from the compensation value.
- Compensation axis
Axis, to whose set or actual position the compensation value is applied.
- Interpolation point
Value pair in a compensation table, consisting of a set and actual position of the basic axis (interpolation point) and the associated compensation value (interpolation value).
- Compensation table
Defined number of interpolation points for a defined traversing range of the basic axis.
- Compensation relation
Unit comprising the basic axis, compensation axis, and compensation table.

Entering compensation tables

The size of the compensation table, i.e. the number of interpolation points, must first be defined in a machine data. After the next POWER ON, the compensation tables are generated by the NC and preassigned a value of "0".

The compensation values and additional table parameters are entered in the compensation tables using special system variables. Data can be loaded in two different ways:

- By starting an NC program with the parameter values.
- By transferring the compensation tables from an external computer to the control.

Note

The respective compensation tables can only be loaded if the corresponding compensation function is **not** active for **all** axes:

- MD32700 \$MA_ENC_COMP_ENABLE[<axis>] == 0
 - MD32710 \$MA_CEC_ENABLE[<axis>] == 0
-

The compensation data is also retained when the control system is switched off.

Note


When changing machine data:

- MD18342 \$MN_MM_CEC_MAX_POINTS
- MD38000 \$MA_MM_ENC_COMP_MAX_POINTS

the static user memory is formatted the next time the system is booted (see Function Manual "Basic Functions", Chapter "S7: Memory configuration").

Interim value calculation

The traversing distance defined via the start and end position within which compensation is to apply, is divided into several sub-paths of equal size. The number of sub-paths is defined depending on the error curve and the desired precision. The positions that limit these sub-paths are referred to as interpolation points below. An interpolation and a compensation value must be assigned to each interpolation point. Between two interpolation points, the effective compensation value is determined by **linear interpolation**.



- ① Compensation values of the compensation axis
 ② Position of basic axis

Figure 9-12 Intermediate value calculation by linear interpolation

Boundary conditions

Compensation value at reference point

It is recommended that a compensation table be structured in such a way that the compensation value has the value "0" at the reference point of the axis.

9.5.2 Leadscrew error and measuring system error compensation

9.5.2.1 Measuring system error compensation (MSEC)

Leadscrew and measuring system errors

The measuring principle of "indirect measurement" on NC-controlled machines is based on the assumption that the lead of the ball screw is constant at any point within the traversing range, so that the actual position of the axis can be derived from the position of the drive spindle (ideal case). However, manufacturing tolerances result in dimensional deviations of varying degrees of severity on spindles (so-called leadscrew errors).

Added to this are the dimensional deviations (differences in reference division) caused by the measuring system as well as its mounting on the machine (so-called measuring system errors), plus any machine-dependent error sources.

Compensation

With "measuring system error compensation" (referred to below as **MSEC**), the base and compensation axes are always identical. It is therefore an **axial compensation** for which a definition of the base axis and compensation axis in the compensation table is not necessary.

Note

The leadscrew error compensation (**LEC**) is part of the measuring system error compensation.

The principle of the MSEC is to modify the axis-specific position actual value by the assigned compensation value in the interpolator clock cycle and to apply this value to the machine axis for immediate traversal. A positive compensation value causes the corresponding machine axis to move in the negative direction.

The magnitude of the compensation value is not limited and is not monitored. In order to avoid impermissibly high velocities and accelerations caused by compensation, small compensation values must be selected. Large compensation values can cause other axis monitoring functions to output alarms (e.g. contour monitoring, speed setpoint limitation).

If the axis to be compensated has a 2nd position measuring system, a separate compensation table must be created and activated for each measuring system. The correct table is automatically used when switching between measuring systems.

Preconditions / activation

The MSEC is only active until the following pre-conditions:

- The compensation values are stored in the static user memory and are active (after POWER ON).
- The function has been activated for the relevant machine axis:
MD32700 \$MA_ENC_COMP_ENABLE [<e>] = 1

with: <e> = Position measuring system

<e> = 0 Measuring system 1

<e> = 1 Measuring system 2

- The axis has been referenced:
DB31, ... DBX60.4 or 60.5 = 1 (referenced/synchronized 1 or 2)

As soon as these conditions have been fulfilled, the axis-specific actual value is modified by the compensation value in all modes and traversed by the machine axis immediately.

If the reference is then lost, e.g. because the encoder frequency has been exceeded (DB31, ... DBX60.4 or 60.5 = 0), compensation processing is deactivated.

9.5.2.2 Commissioning**Machine data****Number of compensation interpolation points**

For each machine axis as well as for each measuring system (if a 2nd measuring system is available), the number of reserved interpolation points must be specified for the compensation table:

MD38000 \$MA_MM_ENC_COMP_MAX_POINTS[<e>,<AXi>]

- <e>: Position measuring system
- <AXi>: axis

The number of interpolation points of a compensation table is calculated from the accompanying system variables (see below):

- End position: \$AA_ENC_COMP_MAX[...]
- Start position: \$AA_ENC_COMP_MIN[...]
- Distance between interpolation points: \$AA_ENC_COMP_STEP[...]

Number of interpolation points = ((end position - start position) / interpolation point distance) + 1

System variables

For each machine axis as well as for each measuring system (if a 2nd measuring system exists), the position-related compensation values as well as additional table parameters should be saved for every compensation relationship in the form of system variables:

- **\$AA_ENC_COMP_MIN[<e>,<AXi>] (initial position)**
 The initial position is the axis position at which the compensation table for the relevant axis begins ($\hat{=}$ interpolation point 0).
 The compensation value for the initial position is \$AA_ENC_COMP[<e>,0,<AXi>].
 The compensation value of interpolation point 0 is used for all positions smaller than the initial position (does not apply for tables with modulo function).
- **\$AA_ENC_COMP_MAX[<e>,<AXi>] (end position)**
 The end position is the axis position at which the compensation table for the relevant axis ends ($\hat{=}$ interpolation point <k>).
 The compensation value for the end position is \$AA_ENC_COMP[<e>,<k>,<AXi>].
 The compensation value of interpolation point is used for all positions larger than the end position (exception for table with modulo function).
 The following supplementary conditions apply to interpolation point <k>:
 - for k = MD38000 - 1:
 The compensation table is fully utilized!
 - for k < MD38000 - 1:
 The compensation table is not fully utilized. Compensation values entered in the table that are greater than k are ignored.
 - for k > MD38000 - 1:
 The compensation table is limited by a control function which reduces the end position. Compensation values that are greater than k are ignored.
- **\$AA_ENC_COMP_STEP[<e>,<AXi>] (distance between interpolation points)**
 The distance between interpolation points defines the distance between the compensation values in the relevant compensation table.

- **\$AA_ENC_COMP[<e>,<N>,<AXi>] (correction value for interpolation point N of the compensation table)**
 <N> = interpolation point (axis position)
 For every individual interpolation point the compensation value must be entered in the table.
 <N> is limited by the maximum number of interpolation points of the particular compensation table (MD38000 \$MA_MM_ENC_COMP_MAX_POINTS):
 $0 \leq N \leq \text{MD38000} - 1$
 The size of the compensation value is not limited.

Note

The first and last compensation values remain active over the entire traversing range; i.e. these values should be set to "0" if the compensation table does not cover the entire traversing range.

- **\$AA_ENC_COMP_IS_MODULO[<e>,<AXi>] (compensation with modulo function)**
 System variable to activate/deactivate the compensation with modulo function:
 - \$AA_ENC_COMP_IS_MODULO[<e>,<AXi>] = 0: Compensation **without** modulo function
 - \$AA_ENC_COMP_IS_MODULO[<e>,<AXi>] = 1: Compensation **with** modulo function
 When compensation with modulo function is activated, the compensation table is repeated cyclically, i.e. the compensation value at position \$AA_ENC_COMP_MAX ($\hat{=}$ interpolation point \$AA_ENC_COMP[<e>,<k>,<AXi>]) is immediately followed by the compensation value at position \$AA_ENC_COMP_MIN ($\hat{=}$ interpolation point \$AA_ENC_COMP[<e>,<0>,<AXi>]). For rotary axes with modulo 360° degrees it is therefore suitable to program 0° (\$AA_ENC_COMP_MIN) as the initial position and 360° (\$AA_ENC_COMP_MAX) as the end position.
 The compensation values entered for these two positions should be the same as otherwise the compensation value jumps from MAX to MIN at the transition point and vice versa.

 CAUTION
Wrong correction values

When writing the correction values for a correction table, it must be ensured that all interpolation points within the parameterized range are assigned a value. Correction values which are not described otherwise contain random values.

Note

Table parameters containing position information are automatically converted when the system of units is changed (change from MD10240 \$MN_SCALING_SYSTEM_IS_METRIC).

The position information is always interpreted in the current measuring system. Conversion must be implemented externally.

Automatic conversion of the position data can be configured as follows:

MD10260 \$MN_CONVERT_SCALING_SYSTEM = 1

External conversion is no longer necessary.

Further information


Function Manual Basic Functions; Velocities, setpoint/actual value systems, closed-loop control

9.5.2.3 Example

Sample parameterization of a compensation table:

- Machine axis: X1
- Measuring system: 1
- Starting position: -200 mm
- End position: 600 mm
- Distance between interpolation points: 1 mm
- Number of interpolation points: MD38000 \$MA_MM_ENC_COMP_MAX_POINTS = ((600 - -200) / 1) + 1 = 801

The memory requirement in the static user memory is: 801 * 8 Byte = 6408 Byte



Program for writing system variables

Program code	Comment
% N_AX_EEC_INI	
CHANDATA (1)	
\$AA_ENC_COMP[0,0,X1]=0.003	1st compensation value (interpolation point 0): +3μm
\$AA_ENC_COMP[0,1,X1]=0.01	2nd compensation value (interpolation point 1): +10μm
\$AA_ENC_COMP[0,2,X1]=0.012	3rd compensation value (interpolation point 2): +12μm
...	
\$AA_ENC_COMP[0,800,X1]=-0.0	Last compensation value (interpolation point 800): 0μm
\$AA_ENC_COMP_STEP[0,X1]=1.0	Distance between interpolation points 1.0 mm
\$AA_ENC_COMP_MIN[0,X1]=-200.0	Compensation starts at -200.0 mm
\$AA_ENC_COMP_MAX[0,X1]=600.0	Compensation ends at +600.0 mm

Program code	Comment
\$AA_ENC_COMP_IS_MODULO[0,X1]=0 M17	Compensation without modulo function


9.5.3 Sag and angularity error compensation

9.5.3.1 General information

Function

The sag and angularity error compensation (cross error compensation, CEC) is an axis-specific compensation, where a correction and/or compensation value is added to the the setpoint position of the **compensation axis**. The compensation value is derived from the current setpoint position of one or several **basic axes**.

- **Sag errors**
In the case of sag errors, the weight of a machine part or workpiece leads to a position-dependent error in the tool center point (TCP).
- **Angularity errors**
For angularity errors, a deviation in the ideal angle in the geometric axes in relation to each other leads to a position-dependent error in the tool center point (TCP).



① Position error in Z1 as a function of the position of Y1

Figure 9-13 Example: Sag errors

Error compensation

For error compensation, at various interpolation points (setpoint positions) of the basic axis (Y1), the particular position error should be determined and entered into the compensation table. When the basic axis (Y1) traverses, in the interpolation clock cycle, the control system calculates the actual compensation value for the compensation axis (Z1) by linearly interpolating between the points. The compensation value is added to the setpoint of the compensation axis (Z1). A positive compensation value causes the compensation axis (Z1) to traverse in the negative direction.




Figure 9-14 Compensation table

Summed compensation value

Compensation values from several compensation tables can be applied to a compensation axis. The resulting summed compensation value is the sum of all of the individual compensation values.

Parameterization options

- **An**axis can be defined as a basic axis for **several** compensation tables.
- **Several** compensation tables can act on **one** compensation axis. The total (summed) compensation value is derived from the sum of the compensation values of the individual compensation tables.
- An axis can be both a base axis and a compensation axis at any one time. The programmed position setpoint is used to calculate the compensation values.
- The scope of action of the compensation (starting and end position of the base axis) and the distance between the interpolation points can be defined for every compensation table.
- The compensation can act **as a function of the direction**.
- Every compensation table has a **modulo function** for cyclic evaluation.
- A **weighting factor** can be taken into account for each compensation table, with which the value in the table is multiplied.
- Using **table multiplication**, the actual compensation value K_A of compensation table A can be multiplied with the actual compensation value K_x of any arbitrary compensation table X, i.e. also with itself. The result of the table multiplication is added to the actual compensation value K_A of compensation table A, and this is then the sum compensation value SK_A , which is then effective in the compensation axis.

$$SK_A = K_A + K_A * K_x$$
- **Axes-specific** activation for all compensation relationships of the axis via the machine data:
MD32710 \$MA_CEC_ENABLE[<axis>]
- **Table-specific** activation via the setting data:
SD41300 \$SN_CEC_TABLE_ENABLE[<table>]
Application example: Processing-dependent change to the compensation ratio by switching the active compensation table via part program/synchronous actions or PLC user program.

Application examples

Compensation of repetitive errors with short wavelength

To compensate for repetitive errors with short wavelength in an axis, a compensation table with modulo function for the repetitive error components (short wavelength) together with a second compensation table without modulo function for the aperiodic error component are parameterized for the same axis.

User-specific leadscrew error compensation

For user-specific leadscrew error compensation, a compensation table with the same axis is parameterized as basic and compensation axis.

However, in this case there is a disadvantage in so much that contrary to the standard function a measuring system switchover cannot be automatically taken into consideration.

9.5.3.2 Commissioning: Machine data

Number	Identifier	Meaning
NC-specific machine data		
MD10240	\$MN_SCALING_SYSTEM_IS_METRIC.	Metric basic system
MD10260	\$MN_CONVERT_SCALING_SYSTEM	Basic system switchover active
MD18342	\$MN_MM_CEC_MAX_POINTS	Number of interpolation points per compensation table
Axis-specific machine data		
MD32710	\$MA_CEC_ENABLE	Enabling sag compensation
MD32711	\$MA_CEC_SCALING_SYSTEM_METRIC	System of units for sag compensation
MD32720	\$MA_CEC_MAX_SUM	Maximum compensation value for sag compensation
MD32730	\$MA_CEC_MAX_VELO	Maximum velocity change for CEC

System of units (MD10240, MD10260, MD32711)

The system of units effective in the control system (metric or inch) is defined using:

MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = <system of units>

System of units switchover without automatic conversion

Table parameters with position data are automatically converted if the system of units changes.

The position data is always interpreted in the actual system of units. Conversion must be implemented externally.

System of units switchover with automatic conversion

The automatic conversion of position data is activated using:

MD10260 \$MN_CONVERT_SCALING_SYSTEM = TRUE

As a consequence, the system of units set in the following machine data is effective for all compensation tables of the axis:

MD32711 \$MA_CEC_SCALING_SYSTEM_METRIC = <system of units>

As a consequence, all position data is interpreted together with the summed compensation value in the configured system of units. External conversion of position data is no longer necessary when the system of units changes.

Axes-specific activation (MD32710)

Axis-specific activation for all compensation relationships of the axis is realized using:

MD32710 \$MA_CEC_ENABLE[<axis>] = TRUE

Number of interpolation points per compensation table (MD18342)

The number of interpolation points per compensation table is parameterized using:

MD18342 \$MN_MM_CEC_MAX_POINTS[<table index>] = <number of interpolation points>

The number of interpolation points required in a compensation table is calculated from the maximum, minimum and step width (increment) set in System variables of table:

<Number of interpolation points> = (\$AN_CEC_MAX - \$AN_CEC_MIN) / \$AN_CEC_STEP + 1

Monitoring (MD32720, MD32730)

Absolute limiting

To avoid inadmissibly high compensation motion of the compensation axis, the summed compensation value is monitored against the maximum value specified in the machine data:

MD32720 \$MA_CEC_MAX_SUM[<compensation axis>] = <maximum value>

When the value is exceeded, the summed compensation value is limited to the maximum value and alarm 20124 "Summed compensation value too high" is displayed.

Limiting the change

To avoid inadmissibly high dynamic loads on the compensation axis, the summed compensation value change is monitored against the maximum value specified in machine data:

MD32730 \$MA_CEC_MAX_VELO[<compensation axis>] = <percentage of the maximum axis velocity (MD32000 \$MA_MAX_AX_VELO)>

When exceeded, the summed compensation value change is limited to the maximum value and alarm 20125 "Compensation value change too fast" is displayed.

The reduced traversing distance as result of the limiting is output as soon as the compensation value is no longer being limited.

9.5.3.3 Commissioning: Setting data

Number	Identifier	Meaning
SD41300	\$SN_CEC_TABLE_ENABLE	Compensation table enable
SD41310	\$SN_CEC_TABLE_WEIGHT	Weighting factor

Compensation table enable (SD41300)

The evaluation of the compensation table is enabled using the setting data:

SD41300 \$SN_CEC_TABLE_ENABLE[<table index>] = TRUE

The compensation value determined using the compensation table is only added to the summed compensation value of the compensation axis when the evaluation is enabled.

Weighting factor (SD41310)

The weighting factor should be entered in the setting data, with which the compensation value determined from the compensation table is multiplied:

SD41310 \$SN_CEC_TABLE_WEIGHT[<table index>] = <weighting factor>

As standard, the weighting factor has a value of 1.0. The compensation table becomes inactive with a weighting factor of 0.0.

9.5.3.4 Commissioning: System variable

Identifier	Meaning
NC-specific system variables	
\$AN_CEC	Compensation values
\$AN_CEC_DIRECTION	Direction dependency
\$AN_CEC_INPUT_AXIS	Basic axis
\$AN_CEC_INPUT_NCU	Basic axis on the NCU:
\$AN_CEC_IS_MODULO	Modulo function
\$AN_CEC_MAX	End position
\$AN_CEC_MIN	Starting position
\$AN_CEC_MULT_BY_TABLE	Multiplication
\$AN_CEC_OUTPUT_AXIS	Compensation axis
\$AN_CEC_OUTPUT_NCU	Compensation axis on the NCU
\$AN_CEC_STEP	Distance between interpolation points
\$AN_CEC_TYPE	Table type
Axis-specific system variables	
\$VA_CEC_COMP_VAL	Actual compensation value

Compensation values (\$AN_CEC)

The compensation values of the compensation table should be entered into system variable:

\$AN_CEC[<table index>, <interpolation point index>] = <compensation value>

$\text{<Interpolation point index>} = 0 \leq x \leq (\text{value of MD18342[<table index>]} - 1)$

Note

Before writing to system variable \$AN_CEC, all of the compensation functions for all of the axes must be deactivated:

- MD32700 \$MA_ENC_COMP_ENABLE[<axis>] = 0
 - MD32710 \$MA_CEC_ENABLE[<axis>] = 0
-

Basic axis (\$AN_CEC_INPUT_AXIS)

The basic axis should be entered into the system variable, i.e. the name of the axis whose position setpoint is to be used as the input for the compensation table.

$\$AN_CEC_INPUT_AXIS[<table\ index>] = "<channel\ axis\ name>"\ or\ "<machine\ axis\ name>"$

Compensation axis (\$AN_CEC_OUTPUT_AXIS)

The compensation axis should be entered in the system variable, i.e. the name of the axis to whose setpoint the compensation value is added.

$\$AN_CEC_OUTPUT_AXIS[<table\ index>] = "<channel\ axis\ name>"\ or\ "<machine\ axis\ name>"$

Note

If the names of channel and machine axes are the same in multi-channel systems, the standard axis names AX1, AX2, etc. must be used.

Distance between interpolation points (\$AN_CEC_STEP)

The distance between two interpolation points should be entered into the system variable (position values of the basic axis) of the compensation table.

$\$AN_CEC_STEP[<table\ index>] = <distance\ between\ interpolation\ points>$

Within a compensation table, the distance between interpolation points remains constant.

Starting position (\$AN_CEC_MIN)

The setpoint position of the basic axis for the first interpolation point or the start of the compensation table should be entered in the system variable.

`$AN_CEC_MIN[<table index>] = <starting position>`

Note

Setpoint position less than the starting position

The compensation value of the first interpolation point is used for all setpoint positions less than the starting position.

Exception: Compensation tables with modulo function

End position (\$AN_CEC_MAX)

The setpoint position of the basic axis for the last interpolation point or the end of the compensation table should be entered in the system variable.

`$AN_CEC_MAX[<table index>] = <end position>`

Note

Setpoint position greater than the end position

The compensation value of the last interpolation point is used for all setpoint positions higher than the starting position.

Exception: Compensation tables with modulo function

Basic or compensation axis on the NCU (\$AN_CEC_INPUT_NCU, \$AN_CEC_OUTPUT_NCU)

For sag compensation with link axes, as basic or compensation axis, the number of the NCU should be entered in the system variable to which the axis is connected.

`$AN_CEC_INPUT_NCU[<table index>] or $AN_CEC_OUTPUT_NCU[<table index>] = <NCU number>`

Direction-dependent compensation (\$AN_CEC_DIRECTION)

The traversing direction of the basic axis, where the compensation should become effective, should be entered into the system variable.

`$AN_CEC_DIRECTION[<table index>] = <direction>`

- 0: in both traversing directions
- 1: in the positive traversing direction only
- -1: in the negative traversing direction only

Table multiplication (\$AN_CEC_MULT_BY_TABLE)

Using table multiplication, the actual compensation value K of the compensation table can be multiplied with the actual compensation value K_x of any arbitrary compensation table X , i.e. also with itself. The result of the table multiplication is added to the actual compensation value K of compensation table, and this is the summed compensation value SK , which is then effective in the compensation axis.

$$SK = K + K * K_x$$

The number of the compensation table should be entered in the system variable, with whose compensation value the actual compensation value should be multiplied.

`$AN_CEC_MULT_BY_TABLE[<table index>] = <table number X>`

`<table number X> = <table index X> + 1`

Modulo function (\$AN_CEC_IS_MODULO)

If the modulo function is activated for a compensation table, then the input value, i.e. the setpoint position of the basic axis, is calculated, modulo with the input range of the compensation table. This means that the compensation value of the end position is followed again by the compensation value of the starting position or for an inverse run-through direction, the compensation value of the starting position is followed again by the compensation value of the end position.

`$AN_CEC_IS_MODULO[<table index>] = <value>`

- 0: Compensation without modulo function
- 1: Compensation with modulo function

Note**Equal compensation values**

When the modulo function is active, we recommend that you set the compensation values of the starting and end positions the same.

Note**Modulo rotary axis**

For a modulo rotary axis, the modulo function of the compensation must be activated.

Example: Parameterization for a modulo rotary axis

```
$MA_IS_ROT_AX[AX1] = 1 ; rotary axis
```

```
$MA_ROT_IS_MODULO[AX1] = 1 ; modulo 360°
```

```
$AN_CEC_INPUT_AXIS[0] = AX1
```

```
$AN_CEC_MIN[0] = 0.0
```

```
$AN_CEC_MAX[0] = 360.0
```

```
$AN_CEC_STEP[0]=1.0
```

```
$AN_CEC_IS_MODULO[0] = 1
```

```
$MN_MM_CEC_MAX_POINTS = 361
$AN_CEC[0, 0] = $AN_CEC[0, 360] = 0.1
```

Table type (\$AN_CEC_TYPE)

The table type, i.e. the compensation type should be entered into the system variable.

\$AN_CEC_TYPE[<table index>] = <Type>

- 0: General interpolating compensation
- 1: Cylinder error compensation

Actual compensation value (\$VA_CEC_COMP_VAL)

The system variable supplies the currently effective compensation value of the axis:

<Actual compensation value> = \$VA_CEC_COMP_VAL[<Axis>]

9.5.3.5 Commissioning: Basic procedure

The compensation tables must be defined in the first commissioning step. To do this, the required number of interpolation points must be set for the particular compensation table. The compensation tables will be created in the control system and populated with default values at the next warm restart.

The second commissioning step involves parameterizing the compensation data using system variables. This can be performed in two different ways:

- Start an NC program in which the system variables will be written.
- Transfer the compensation tables from an external computer to the control.

Note

All compensation functions for all axes must be deactivated before loading the compensation tables:


- MD32700 \$MA_ENC_COMP_ENABLE[<Achse>] == 0
 - MD32710 \$MA_CEC_ENABLE[<axis>] == 0
-

Sequence

1. Parameterize the number of interpolation points for the compensation tables:
MD18342 \$MN_MM_CEC_MAX_POINTS
2. Parameterize the monitoring functions:
 - Absolute limiting: MD32720 \$MA_CEC_MAX_SUM
 - Limiting the change: MD32730 \$MA_CEC_MAX_VELO

3. Parameterize the system of units switchover
 - without automatic conversion:
MD10240 \$MN_SCALING_SYSTEM_IS_METRIC
 - with automatic conversion:
 - MD10240 \$MN_SCALING_SYSTEM_IS_METRIC
 - MD10260 \$MN_CONVERT_SCALING_SYSTEM
 - MD32711 \$MA_CEC_SCALING_SYSTEM_METRIC
4. Initiate a **warm restart** of the NC to activate the machine data changes
5. Parameterize the weighting factors for the compensation tables:
SD41310\$SN_CEC_TABLE_WEIGHT
6. Parameterize the table parameters in system variables \$AN_CEC_...
7. Check or reference the actual measuring system of the basic and compensation axis:
DB31, ... DBX60.4 bzw. 60.5 == 1 (referenced/synchronized 1 or 2)
8. Enable compensation:
 - Table-specific: SD41300 CEC_TABLE_ENABLE
 - Axis-specific: MD32710 \$MA_CEC_ENABLE

9.5.3.6 Commissioning: Overview diagram



9.5.3.7 Example 1: Sag compensation

Depending on the position of the axis Y1, an additional compensation value is applied to the set position of axis Z1.

Compensation table used: Table 1 $\Rightarrow$ Index = 0

Compensation parameters

- Starting position: -400.0
- End position: 400.0
- Distance between interpolation points: 8.0

Number of interpolation points

MD18342 \$MN_MM_CEC_MAX_POINTS[0] = (400.0 - -400.0) / 8.0 + 1 = 101

The memory required in the static user memory is at least 808 bytes (8 bytes per compensation value).

Program code	Comment
%_N_NC_CEC_INI	; Writing the compensation data
CHANDATA(1)	; Compensation table 1, index 0
\$AN_CEC[0,0]=0	; 1st Compensation value = 0 μ m
\$AN_CEC[0,1]=0.01	; 2nd Compensation value = 10 μ m
\$AN_CEC[0,2]=0.012	; 3rd Compensation value = 12 μ m
...	
\$AN_CEC[0,100]=0	; 101st Compensation value = 0 μ m
\$AN_CEC_INPUT_AXIS[0]=AX2	; Basic axis Y1 $\Rightarrow$ machine axis name AX2
\$AN_CEC_OUTPUT_AXIS[0]=AX3	; Compensation axis Z1 $\Rightarrow$ machine axis name AX3
\$AN_CEC_STEP[0]=8.0	; distance between interpolation points 8.0 mm
\$AN_CEC_MIN[0]=-400.0	; Starting position: Y1 = -400mm
\$AN_CEC_MAX[0]=400.0	; End position: Y1 = +400mm
\$AN_CEC_DIRECTION[0]=0	; Compensate in both traversing directions of Y1
\$AN_CEC_MULT_BY_TABLE[0]=0	; No table multiplication
\$AN_CEC_IS_MODULO[0]=0	; No modulo function

9.5.3.8 Example 2: Compensation with table multiplication

Compensation of sag of the foundation of a drilling machine with table multiplication.




Figure 9-15 Sag of the foundation

On large machines, sagging of the foundation can cause inclination of the whole machine.

The compensation in axis X1 depends on:

- The position of axis X1 because it determines the angle of inclination β
- The position of axis Z1, in which the drill is located.

The summed compensation value $\Delta X1_{total}$ is calculated from the compensation values $\Delta X1$ and $\Delta Z1$:

$$\Delta X1_{total} = \Delta Z1 * \Delta X1 = \Delta Z1 * \sin\beta(X1) \approx \Delta Z1 * \beta(X1)$$




Figure 9-16 Table multiplication

Compensation table 1 (table index: 0)

- Basic axis: X1
- Compensation axis: X1
- Compensation values: Sine of the position-dependent tilt angle β , with $\beta = f(\text{position of } X1)$

Compensation table 2 (table index: 1)

- Basic axis: Z1
- Compensation axis: X1
- Compensation values: Reaction of the position of axis Z1 on the measured position of axis X1

Table multiplication

For compensation relationship 1 (table index: 0) the table multiplication should be set with the compensation relationship 2:

`$AN_CEC_MULT_BY_TABLE[ 0 ] = 2`

9.5.3.9 Example 3: 2-dimensional array of compensation values

For flat-bed machines, the use case often arises in practice in which the sag compensation values of the Z-axis depend on the axis positions of the X axis and Y axis. This is why it makes sense to organize compensation values in a 2-dimensional array.

In this example, a possible way of implementing sag compensation using a grid, having a size of 4 x 5 (rows x columns), is explained in more detail. The size of the complete measuring range is 2000 x 900 mm². The compensation values are each determined in increments of 500 mm along the X axis and 300 mm increments along the Y axis. The interpolation points with the relevant compensation values are positioned at the intersections of the grid (X-Y plane). Compensation values between these interpolation points are linearly interpolated.




Figure 9-17 Compensation values of the Z axis

Note**SINUMERIK Operate user interface**

The currently effective compensation value of the Z axis as a result of sag compensation is displayed on the SINUMERIK Operate user interface under:

Operating area: "Diagnostics" > "Axis diagnostics" > "Service axis" > Signal: "Compensation, sag + temperature"

Implementation

For each line of the four-line the grid, a compensation table is set up with five interpolation points. In the first compensation table, starting at interpolation point 1, in ascending sequence, the compensation values 0.1 to 0.5 are entered in the first line. Using the same procedure, in the first compensation table, compensation values 0.6 to 1.0 are entered in the second line, etc.

These compensation tables, relevant for the position of the X axis, are now designated with **f tables** and the table values as **f_i(x)**, with i: Table number.


Additional compensation tables are required to take into account the position of the Y axis. These compensation tables are now designated as **g tables** and the table values as **g_i(y)**. The number of f tables and g tables is equal. In the example, four:

In the g tables, one compensation value is set to 1 - and all the others to 0. The position of compensation value 1 within the table is determined by the table number. In the first g table, compensation value 1 is positioned at the first interpolation point and, in the second g table, at the second interpolation point, etc. By multiplying g tables by f tables, the correct compensation value in each f table is selected by multiplying it by 1. All irrelevant compensation values are concealed through multiplication by 0.

The summed compensation value D_z at position (x/y) is calculated according to the following equation:

$$D_z(x/y) = f_1(x) * g_1(y) + f_2(x) * g_2(y) + f_3(x) * g_3(y) + f_4(x) * g_4(y) = k_1 + k_2 + k_3 + k_4$$

At location $D_z(750/450)$, the summed compensation value of the Z axis is calculated to be:



$$\begin{aligned} D_z(750/450) &= f_1(750) * g_1(450) + f_2(750) * g_2(450) + \\ &\quad f_3(750) * g_3(450) + f_4(750) * g_4(450) \\ &= 0.25 * 1.0 + 0.75 * 0.1 + \\ &\quad 1.25 * 0.0 + 1.75 * 0.0 \\ &= 1.0 \end{aligned}$$

Parameterization

Parameterization of machine data using the NC program

Program code	Comment
; Number of interpolation points for the compensation tables	
\$MN_MM_CEC_MAX_POINTS[0]=5	; Compensation table 1
\$MN_MM_CEC_MAX_POINTS[1]=5	; Compensation table 2
\$MN_MM_CEC_MAX_POINTS[2]=5	; Compensation table 3
\$MN_MM_CEC_MAX_POINTS[3]=5	; Compensation table 4
\$MN_MM_CEC_MAX_POINTS[4]=4	; Compensation table 5
\$MN_MM_CEC_MAX_POINTS[5]=4	; Compensation table 6

Program code	Comment
\$MN_MM_CEC_MAX_POINTS[6]=4	; Compensation table 7
\$MN_MM_CEC_MAX_POINTS[7]=4	; Compensation table 8
; Monitoring functions for axis Z1 corresponding to the 3rd machine axis	
\$MA_CEC_MAX_SUM[AX3]=10.0	; Max. summed compensation value
\$MA_CEC_MAX_VELO[AX3]=100.0	; Max. change

Setting the table parameters (system variables) using the NC program

Program code	Comment
; To write to the compensation tables, the	
; compensation for axis Z1 (compensation axis)	
; must first be deactivated.	
\$MA_CEC_ENABLE[Z1] = FALSE	
NEWCONF	; Activate \$MA_CEC_ENABLE
; Define values f _i (x) in the f tables:	
; Function values f ₁ (x) for table with index [0]	
\$AN_CEC[0,0]=0.1	
\$AN_CEC[0,1]=0.2	
\$AN_CEC[0,2]=0.3	
\$AN_CEC[0,3]=0.4	
\$AN_CEC[0,4]=0.5	
; Function values f ₂ (x) for table with index [1]	
\$AN_CEC[1,0]=0.6	
\$AN_CEC[1,1]=0.7	
\$AN_CEC[1,2]=0.8	
\$AN_CEC[1,3]=0.9	
\$AN_CEC[1,4]=1.0	
; Function values f ₃ (x) for table with index [2]	
\$AN_CEC[2,0]=1.1	
\$AN_CEC[2,1]=1.2	
\$AN_CEC[2,2]=1.3	
\$AN_CEC[2,3]=1.4	
\$AN_CEC[2,4]=1.5	
; Function values f ₄ (x) for table with index [3]	
\$AN_CEC[3,0]=1.6	
\$AN_CEC[3,1]=1.7	
\$AN_CEC[3,2]=1.8	
\$AN_CEC[3,3]=1.9	
\$AN_CEC[3,4]=2.0	

Program code	Comment
<pre> ; Enable evaluation of f tables with compensation values \$SN_CEC_TABLE_ENABLE[0]=TRUE \$SN_CEC_TABLE_ENABLE[1]=TRUE \$SN_CEC_TABLE_ENABLE[2]=TRUE \$SN_CEC_TABLE_ENABLE[3]=TRUE ; Define weighting factor for f tables \$SN_CEC_TABLE_WEIGHT[0]=1.0 \$SN_CEC_TABLE_WEIGHT[1]=1.0 \$SN_CEC_TABLE_WEIGHT[2]=1.0 \$SN_CEC_TABLE_WEIGHT[3]=1.0 ; Changes to the following table parameters do not take effect until ; after a warm restart ; Define basic axis X1 \$AN_CEC_INPUT_AXIS[0]=(X1) \$AN_CEC_INPUT_AXIS[1]=(X1) \$AN_CEC_INPUT_AXIS[2]=(X1) \$AN_CEC_INPUT_AXIS[3]=(X1) ; Define compensation axis Z1 \$AN_CEC_OUTPUT_AXIS[0]=(Z1) \$AN_CEC_OUTPUT_AXIS[1]=(Z1) \$AN_CEC_OUTPUT_AXIS[2]=(Z1) \$AN_CEC_OUTPUT_AXIS[3]=(Z1) ; Define distance between interpolation points for compensation values in f tables \$AN_CEC_STEP[0]=500.0 \$AN_CEC_STEP[1]=500.0 \$AN_CEC_STEP[2]=500.0 \$AN_CEC_STEP[3]=500.0 ; Compensation starts at X1=0 \$AN_CEC_MIN[0]=0.0 \$AN_CEC_MIN[1]=0.0 \$AN_CEC_MIN[2]=0.0 \$AN_CEC_MIN[3]=0.0 ; Compensation ends at X1=2000 \$AN_CEC_MAX[0]=2000.0 \$AN_CEC_MAX[1]=2000.0 \$AN_CEC_MAX[2]=2000.0 \$AN_CEC_MAX[3]=2000.0 </pre>	

Program code	Comment
<pre> ; Values of f tables with index [t1] are multiplied by values in g tables ; by the number [t2] ; in accordance with the equation (algorithm) specified above \$AN_CEC_MULT_BY_TABLE[0] = 5 \$AN_CEC_MULT_BY_TABLE[1] = 6 \$AN_CEC_MULT_BY_TABLE[2] = 7 \$AN_CEC_MULT_BY_TABLE[3] = 8 ; Define the g table values for g_i(y): ; Function values g_1(x) for table with index [4] \$AN_CEC[4,0]=1.0 \$AN_CEC[4,1]=0.0 \$AN_CEC[4,2]=0.0 \$AN_CEC[4,3]=0.0 ; Function values g_2(x) for table with index [5] \$AN_CEC[5,0]=0.0 \$AN_CEC[5,1]=1.0 \$AN_CEC[5,2]=0.0 \$AN_CEC[5,3]=0.0 ; Function values g_3(x) for table with index [6] \$AN_CEC[6,0]=0.0 \$AN_CEC[6,1]=0.0 \$AN_CEC[6,2]=1.0 \$AN_CEC[6,3]=0.0 ; Function values g_4(x) for table with index [7] \$AN_CEC[7,0]=0.0 \$AN_CEC[7,1]=0.0 \$AN_CEC[7,2]=0.0 \$AN_CEC[7,3]=1.0 ; Enable evaluation of g tables with compensation values \$SN_CEC_TABLE_ENABLE[4]=TRUE \$SN_CEC_TABLE_ENABLE[5]=TRUE \$SN_CEC_TABLE_ENABLE[6]=TRUE \$SN_CEC_TABLE_ENABLE[7]=TRUE ; Define weighting factor for g tables \$SN_CEC_TABLE_WEIGHT[4]=1.0 \$SN_CEC_TABLE_WEIGHT[5]=1.0 \$SN_CEC_TABLE_WEIGHT[6]=1.0 \$SN_CEC_TABLE_WEIGHT[7]=1.0 </pre>	

Program code	Comment
<pre> ; Changes to the following table parameters do not take effect until ; a power on is carried out ; Define basic axis Y1 \$AN_CEC_INPUT_AXIS[4]=(Y1) \$AN_CEC_INPUT_AXIS[5]=(Y1) \$AN_CEC_INPUT_AXIS[6]=(Y1) \$AN_CEC_INPUT_AXIS[7]=(Y1) ; Define compensation axis Z1 \$AN_CEC_OUTPUT_AXIS[4]=(Z1) \$AN_CEC_OUTPUT_AXIS[5]=(Z1) \$AN_CEC_OUTPUT_AXIS[6]=(Z1) \$AN_CEC_OUTPUT_AXIS[7]=(Z1) ; Define distance between interpolation points for compensation values in g tables \$AN_CEC_STEP[4]=300.0 \$AN_CEC_STEP[5]=300.0 \$AN_CEC_STEP[6]=300.0 \$AN_CEC_STEP[7]=300.0 ; Compensation starts at Y1=0 \$AN_CEC_MIN[4]=0.0 \$AN_CEC_MIN[5]=0.0 \$AN_CEC_MIN[6]=0.0 \$AN_CEC_MIN[7]=0.0 ; Compensation ends at Y1=900 \$AN_CEC_MAX[4]=900.0 \$AN_CEC_MAX[5]=900.0 \$AN_CEC_MAX[6]=900.0 \$AN_CEC_MAX[7]=900.0 ; Activate compensation again \$MA_CEC_ENABLE[Z1]=TRUE NEWCONF ; Carry out a program test to check that the compensation is active G01 F1000 X0 X0 Z0 G90 R1=0 R2=0 LOOP_Y: LOOP_X: STOPRE X=R1 Y=R2 M0 </pre>	<pre> ; Wait to check the CEC value </pre>

Program code	Comment
R1=R1+500	
IF R1 <=2000 GOTOB LOOP_X	
R1=0	
R2=R2+300	
IF R2<=900 GOTOB LOOP_Y	

9.5.4 Extension of the sag compensation with NCU link

9.5.4.1 General parameter assignment

Basic and compensation axes

Parameterization of the basic axis (input) and compensation axis (output) of a compensation table is implemented in conjunction with link axes (see Function Manual "Basic Functions", Section "Distributed systems") with the following system variables:

- \$AN_CEC_INPUT_NCU
- \$AN_CEC_INPUT_AXIS
- \$AN_CEC_OUTPUT_NCU
- \$AN_CEC_OUTPUT_AXIS

The following supplementary conditions must be observed:

- The basic and compensation axes of the sag compensation must be interpolated as channel axes on the same NCU.
- The corresponding machine axes can be connected to different NCUs.
- The system variables become effective only after a **warm restart** of the NCU.
- Data backup is undertaken with machine axis names.

General commissioning of the sag compensation

For general commissioning of the sag compensation, see Chapter "Commissioning: Basic procedure (Page 259)".

9.5.4.2 Parameterization with channel names

The parameterization of basic and compensation axes with channel axis names takes place with the following system variables:

- Input axis
\$AN_CEC_INPUT_AXIS[<CEC table number>] = <channel axis name>
- Output axis
\$AN_CEC_OUTPUT_AXIS[<CEC table number>] = <channel axis name>

Example: Coupling axis "ZZ" (AX2, NCU 2) to "XR" (AX1, NCU 1)

Two part programs, TP1 for channel 1 and TP2 for channel 2, have to be created. The system variables of the basic and compensation axes of the compensation table are written to these.

Excerpt from TP1, channel 1: `$AN_CEC_INPUT_AXIS[0] = "XR"`

Excerpt from TP2, channel 2: `$AN_CEC_OUTPUT_AXIS[0] = "ZZ"`

9.5.4.3 Parameterization with machine axis names

The parameterization of basic and compensation axes with machine axis names takes place with the following system variables:

- Basic axis
 - `$AN_CEC_INPUT_NCU[<CEC table number>] = <NCU number>`
 - `$AN_CEC_INPUT_AXIS[<CEC table number>] = <machine axis name>`
- Compensation axes
 - `$AN_CEC_OUTPUT_NCU[<CEC table number>] = <NCU number>`
 - `$AN_CEC_OUTPUT_AXIS[<CEC table number>] = <channel axis name>`

Example: Coupling axis "ZZ" (AX2, NCU 2) to "XR" (AX1, NCU 1)

A part program has to be created, which can be started in any channel of the NCU 1. The system variables of the basic and compensation axes of the compensation table with machine axis names and NCU number are written to these.

Part program:

```
$AN_CEC_INPUT_NCU[0] = 1
$AN_CEC_INPUT_AXIS[0] = "AX1"
$AN_CEC_OUTPUT_NCU[0] = 2
$AN_CEC_OUTPUT_AXIS[0] = "AX2"
```

Note

- The NCU number must be written to the NC program before the axis names.
- Sag compensation between NC1_AX1 and NC2_AX2 is not possible.

9.5.4.4 Axis container

The sag compensation can also be used in conjunction with container axes (see Function Manual "Basic Functions", Section "Distributed systems"). It should be noted that when using container axes, after each axis container rotation, other machine axes are coupled regarding sag compensation. In order to maintain the coupling between two specific machine axes, even after an axis container rotation, after each rotation, the system variables to parameterize the basic and compensation axes must be appropriately newly written to the compensation table by the user.

Requirement


The axis container has to be located in the start position ($\$AN_AXCTAS == 0$) when the sag compensation is activated.

NOTICE**Changing the machine axes**

After a axis container rotation, the same channel axes remain coupled. The coupled machine axes can change.

9.5.4.5 Configuration example 1: NCU link with rigid coupling

In configuration example 1, the two channels of NCU 1 - and the channel axis names defined using machine data MD20080 $\$MC_AXCONF_CHANAX_NAME_TAB$ - are shown. The configuration of NCU 2 is not shown.



- ① Assignment of channel axes to machine axes:
MD20070 $\$MC_AXCONF_MACHAX_USED[0 \dots 2]$
- ② Assignment of logical to real machine axes:
MD10002 $\$MN_AXCONF_LOGIC_MACHAX_TAB$
- ③ Machine axis names:
MD10000 $\$MN_AXCONF_MACHAX_NAME_TAB$

Figure 9-18 Configuration 1: NCU link with rigid coupling

Channel axis ZZ (NCU1, channel 2) is connected to machine axis AX2 of NCU 2. This means that in order that machine axis AX2 of NCU 2 traverses, in the 2nd channel of NCU 1, axis ZZ is traversed. For example, using the following commands in an NC program:

```
POS[ZZ]=10 FA[ZZ]=1000
```

Parameterization

The machine data of both NCUs is parameterized using the subsequently listed NC programs NC_P1 and NC_P2.

NC program NC_P1: Parameterization of the machine data for NCU 1

Program code

```
; ##### NCU1 #####
; NC-specific machine data
$MN_NCU_LINKNO = 1
$MN_MM_NCU_LINK_MASK = 1
$MN_MM_LINK_NUM_OF_MODULES= 2
$MN_MM_SERVO_FIFO_SIZE = 3
$MN_ASSIGN_CHAN_TO_MODE_GROUP[1]=1
$MN_AXCONF_LOGIC_MACHAX_TAB[0] = "NC1_AX1"
$MN_AXCONF_LOGIC_MACHAX_TAB[1] = "NC1_AX3"
$MN_AXCONF_LOGIC_MACHAX_TAB[2] = "NC2_AX2"
$MN_AXCONF_LOGIC_MACHAX_TAB[3] = "NC1_AX4"
$MN_AXCONF_LOGIC_MACHAX_TAB[4] = "NC1_AX5"
$MN_AXCONF_LOGIC_MACHAX_TAB[5] = "NC2_AX6"
; Channel-specific machine data: Channel 1
CHANDATA(1)
$MC_AXCONF_MACHAX_USED[0]=1
$MC_AXCONF_MACHAX_USED[1]=5
$MC_AXCONF_MACHAX_USED[2]=4
$MC_AXCONF_MACHAX_USED[3]=0
$MC_AXCONF_MACHAX_USED[4]=0
$MC_AXCONF_MACHAX_USED[5]=0
$MC_AXCONF_CHANAX_NAME_TAB[0] = "XR"
$MC_AXCONF_CHANAX_NAME_TAB[1] = "YR"
$MC_AXCONF_CHANAX_NAME_TAB[2] = "ZR"
; Channel-specific machine data: Channel 2
CHANDATA(2)
$MC_REFP_NC_START_LOCK=0
$MC_AXCONF_MACHAX_USED[0]=2
$MC_AXCONF_MACHAX_USED[1]=6
$MC_AXCONF_MACHAX_USED[2]=3
$MC_AXCONF_MACHAX_USED[3]=0
$MC_AXCONF_MACHAX_USED[4]=0
$MC_AXCONF_MACHAX_USED[5]=0
$MC_AXCONF_CHANAX_NAME_TAB[0] = "XX"
$MC_AXCONF_CHANAX_NAME_TAB[1] = "YY"
$MC_AXCONF_CHANAX_NAME_TAB[2] = "ZZ"
M30
```

NC program NC_P2: Parameterization of machine data for NCU 2**Program code**

```

; ##### NCU-2 #####
; NC-specific machine data
$MN_NCU_LINKNO = 2
$MN_MM_NCU_LINK_MASK = 1
$MN_MM_LINK_NUM_OF_MODULES= 2
$MN_MM_SERVO_FIFO_SIZE = 3
$MN_AXCONF_LOGIC_MACHAX_TAB[0] = "NC2_AX1"
$MN_AXCONF_LOGIC_MACHAX_TAB[1] = "NC1_AX6"
$MN_AXCONF_LOGIC_MACHAX_TAB[2] = "NC2_AX3"
$MN_AXCONF_LOGIC_MACHAX_TAB[3] = "NC2_AX4"
$MN_AXCONF_LOGIC_MACHAX_TAB[4] = "NC2_AX5"
$MN_AXCONF_LOGIC_MACHAX_TAB[5] = "NC1_AX2"
; Channel-specific machine data: Channel 1
CHANDATA(1)
$MC_AXCONF_MACHAX_USED[0]=1
$MC_AXCONF_MACHAX_USED[1]=2
$MC_AXCONF_MACHAX_USED[2]=3
$MC_AXCONF_MACHAX_USED[3]=4
$MC_AXCONF_MACHAX_USED[4]=5
$MC_AXCONF_MACHAX_USED[5]=6
$MC_AXCONF_MACHAX_USED[6]=0
M30

```

9.5.4.6 Configuration example 2 NCU link with axis container

Configuration example 2 includes an axis container CT1 (see Function Manual "Basic Functions", Section "Distributed systems"). The parameterization of the axes contained in the axis container is realized using MD12701 \$MN_AXCT_AXCONF_ASSIGN_TAB1. The axis container is a multi-NCU object that only exists once for all NCUs.


The logical machine axis of channel axis YR refers to slot CT1_SL3 - and channel axis YY to slot CT1_SL4. The channel axes of NCU2 are not shown.

Container axes are assigned to the following machine axes:

- NC1_AX5
- NC1_AX6
- NC2_AX1
- NC2_AX2


Axis constellation in the initial state of the axis container

In the initial state of the axis container, after the NCUs power up, channel axis YR is connected with NC2_AX1 and channel axis YY with NC2_AX2.



Axis constellation after one axis container step

After the axis container rotates through one step (increment), channel axis YR is connected to NC2_AX2, and channel axis YY is connected to NC1_AX5.



NC program NC_P1: Parameterization of the machine data for NCU 1

Program code

```
; ##### NCU1 #####
; NC-specific machine data
$MN_NCU_LINKNO = 1
$MN_MM_NCU_LINK_MASK = 1
$MN_MM_LINK_NUM_OF_MODULES= 2
$MN_MM_SERVO_FIFO_SIZE = 3
$MN_ASSIGN_CHAN_TO_MODE_GROUP[1]=1
$MN_AXCONF_LOGIC_MACHAX_TAB[0] = "NC1_AX1"
$MN_AXCONF_LOGIC_MACHAX_TAB[1] = "NC1_AX3"
$MN_AXCONF_LOGIC_MACHAX_TAB[2] = "NC2_AX2"
$MN_AXCONF_LOGIC_MACHAX_TAB[3] = "NC1_AX4"
$MN_AXCONF_LOGIC_MACHAX_TAB[4] = "CT1_SL3"
$MN_AXCONF_LOGIC_MACHAX_TAB[5] = "CT1_SL4"
$MN_AXCT_AXCONF_ASSIGN_TAB1[0] = "NC1_AX5"
$MN_AXCT_AXCONF_ASSIGN_TAB1[1] = "NC1_AX6"
$MN_AXCT_AXCONF_ASSIGN_TAB1[2] = "NC2_AX1"
$MN_AXCT_AXCONF_ASSIGN_TAB1[3] = "NC2_AX2"
$SN_AXCT_SWWIDTH[0] = 1
; Channel-specific machine data: Channel 1
CHANDATA(1)
```

Program code

```

$MC_AXCONF_MACHAX_USED[0]=1
$MC_AXCONF_MACHAX_USED[1]=5
$MC_AXCONF_MACHAX_USED[2]=4
$MC_AXCONF_MACHAX_USED[3]=0
$MC_AXCONF_MACHAX_USED[4]=0
$MC_AXCONF_MACHAX_USED[5]=0
$MC_AXCONF_CHANAX_NAME_TAB[0] = "XR"
$MC_AXCONF_CHANAX_NAME_TAB[1] = "YR"
$MC_AXCONF_CHANAX_NAME_TAB[2] = "ZR"
; Channel-specific machine data: Channel 1
CHANDATA(2)
$MC_REFP_NC_START_LOCK=0
$MC_AXCONF_MACHAX_USED[0]=2
$MC_AXCONF_MACHAX_USED[1]=6
$MC_AXCONF_MACHAX_USED[2]=3
$MC_AXCONF_MACHAX_USED[3]=0
$MC_AXCONF_MACHAX_USED[4]=0
$MC_AXCONF_MACHAX_USED[5]=0
$MC_AXCONF_CHANAX_NAME_TAB[0] = "XX"
$MC_AXCONF_CHANAX_NAME_TAB[1] = "YY"
$MC_AXCONF_CHANAX_NAME_TAB[2] = "ZZ"
M30

```

NC program NC_P2: Parameterization of machine data for NCU 2**Program code**

```

; ##### NCU-2 #####
; NC-specific machine data
$MN_NCU_LINKNO = 2
$MN_MM_NCU_LINK_MASK = 1
$MN_MM_LINK_NUM_OF_MODULES= 2
$MN_MM_SERVO_FIFO_SIZE = 3
$MN_AXCONF_LOGIC_MACHAX_TAB[0] = "CT1_SL1"
$MN_AXCONF_LOGIC_MACHAX_TAB[1] = "CT1_SL2"
$MN_AXCONF_LOGIC_MACHAX_TAB[2] = "NC2_AX3"
$MN_AXCONF_LOGIC_MACHAX_TAB[3] = "NC2_AX4"
$MN_AXCONF_LOGIC_MACHAX_TAB[4] = "NC2_AX5"
$MN_AXCONF_LOGIC_MACHAX_TAB[5] = "NC2_AX6"
CHANDATA(1)
; Channel-specific machine data: Channel 1
$MC_AXCONF_MACHAX_USED[0]=1
$MC_AXCONF_MACHAX_USED[1]=2
$MC_AXCONF_MACHAX_USED[2]=3
$MC_AXCONF_MACHAX_USED[3]=4

```

9.5 Interpolatory compensation

Program code

```
$MC_AXCONF_MACHAX_USED[4]=5  
$MC_AXCONF_MACHAX_USED[5]=6  
$MC_AXCONF_MACHAX_USED[6]=0  
M30
```

9.5.5 Direction-dependent leadscrew error compensation

9.5.5.1 Description of functions

If the direction-dependent differences at the compensation points are excessively high, for an inconsistent backlash or for extremely high demands placed on the precision, then it may be necessary to apply direction-dependent compensation of the leadscrew error or measuring system error (for direct position sensing).

Direction-dependent leadscrew error compensation

For the "direction-dependent leadscrew error compensation" ("direction-dependent LEC" or also "Bidirectional LEC"), two compensation tables are used for each axis. One compensation table for the positive and one compensation table for the negative traversing direction. The deviation at the particular compensation point is entered as difference between the ideal setpoint and measured actual value in the compensation tables. The control automatically calculates compensation values of intermediate values using linear interpolation.

Preconditions / activation

The "direction-dependent LEC" is implemented in the SINUMERIK control as a special case of "sag compensation". This is the reason that the preconditions and conditions of "sag compensation" apply (see "Sag and angularity error compensation (Page 251)").

The activation of the compensation can be checked using a reference measurement, e.g. using the laser interferometer or in the simplest case, using the service display of the particular axis.

Note

If the "direction-dependent LEC" is used in parallel to the sag compensation and compensation of the angularity, then the secondary conditions of these functions must be taken into consideration together, e.g. the assignment of tables <t> to the particular function.

9.5.5.2 Commissioning

Measuring the error or compensation values

When commissioning the "direction-dependent LEC" - just the same as when commissioning the "direction-dependent LEC" - direction-dependent error curves for each axis are determined using a suitable measuring device (e.g. laser interferometer) (see Section "Leadscrew error and measuring system error compensation (Page 246)"). A part program with measurement points and wait times should be generated in order to perform the measurement (see Section "Example (Page 282)": Program "BI_SSFK_MESS_AX1_X.MPF").

Because the various measuring devices offer different support options for the practical implementation in conjunction with a SINUMERIK control, this process is only generally described in the following referred to a control.

Note

The measurement for determining the leadscrew error should only be carried out during the first commissioning if, in the machine data, the traversing directions of the axes in relation to the machine coordinate system have been correctly set.

Commissioning (principle)

1. Specify the number of compensation interpolation points (also see Section "Compensation for droop and angularity error: Commissioning (Page 259)")
For the directional leadscrew error compensation, a compensation table for the positive and a compensation table for the negative traversing directions must be assigned to each axis.
The number of compensation interpolation points of a table is defined in:
MD18342 \$MN_MM_CEC_MAX_POINTS[<compensation table index>]

**CAUTION****Possible data loss**

A change to the machine data MD18342 \$MN_MM_CEC_MAX_POINTS, which configures memory, reconfigures the NC memory the next time the control starts. This can result in the loss of all user-specific data. See Function Manual "Basic Functions", Section "Memory configuration".

Creating a commissioning archive:

Operating area: "Commissioning" > "ETC" key > "Commissioning archive" > "Create commissioning archive" > "OK" > Selection: "NC data"

Example

- X axis: positive traversing direction, table 1, 11 interpolation points
- X axis: negative traversing direction, table 2, 11 interpolation points

Machine data:

- MD18342 \$MN_MM_CEC_MAX_POINTS[0] = 11
- MD18342 \$MN_MM_CEC_MAX_POINTS[1] = 11

2. Reading in a commissioning archive that has been created:
Operating area: "Commissioning" > "ETC" key > "Commissioning archive" > "Read in commissioning archive" > "OK"
The compensation tables are then available.
3. To simplify commissioning, create an NC program by which the compensation parameters are written into the machine data and system variables (see Section "Example (Page 282)").
4. Run the NC program on the control:
Mode: "AUTOMATIC" > Select program > NC start
5. Power-on (warm restart).
6. Now, comparative measurements can be made using the laser interferometer.
7. To further improve the compensation results, it is also conceivable to correct individual compensation values in the program. A POWER ON is no longer necessary when reading-in the table again.

Note**NC_CEC.INI**

The "NC_CEC.INI" file copied via "Commissioning" > "System data" (from the folder "NC active data" > "sag angularity comp") includes all negotiated sag/angularity and direction-dependent LEC tables.

Note**Backlash**

The backlash should be set to **0**:

- MD32450 \$MA_BACKLASH [<measuring system>] = **0**

Compensation parameters

The compensation parameters are set via the following system variables:

- \$AN_CEC[<table>,<interpolation point>] (compensation value)
- \$AN_CEC_INPUT_AXIS[<table>] (basic axis)
- \$AN_CEC_OUTPUT_AXIS[<table>] (compensation axis)

Note

For the "directional LEC," the basis and compensation axes are **always identical**.

- \$AN_CEC_STEP[<table>] (distance between interpolation points)
- \$AN_CEC_MIN[<table>] (starting position)
- \$AN_CEC_MAX[<table>] (end position)
- \$AN_CEC_DIRECTION[<table>] (direction)

Note

The setting \$AN_CEC_DIRECTION[<t>] = 0 (table is effective for both traversing directions of the basic axis) is **not** relevant for the "direction-dependent LEC".

- \$AN_CEC_IS_MODULO[<table>] (compensation with modulo function)

Note

For a description of these system variables, see Section "Compensation of sag and angularity error: Commissioning (Page 259)".

System of units

See Section "Compensation for droop and angularity error: Commissioning (Page 259)".

Monitoring

See Section "Compensation for droop and angularity error: Commissioning (Page 259)".

9.5.5.3 Example

The following examples shows parameterization of the directional compensation tables for an axis (machine axis AX1). All parameter values of the compensation tables are written by means of a program.

Compensation parameters

- Basic axis = compensation axis = machine axis AX1
- Distance between interpolation points: 58.0 mm
- Starting position: -585.0 mm
- End position: -5.0 mm

Table definition

The 1st and 2nd compensation table are defined with 11 compensation interpolation points each for machine axis AX1 as directional compensation tables:


- MD18342 \$MN_MM_CEC_MAX_POINTS[0] = 11 (table 1: **positive** traversing direction)
- MD18342 \$MN_MM_CEC_MAX_POINTS[1] = 11 (table 2: **negative** traverse direction)

Interpolation points and correction values

Interpolation points		Deviations or correction values		Deviation with compensation	
Index	Position [mm]	pos. Traversing direction [mm]	neg. Traversing direction [mm]	pos. Traversing direction [mm]	neg. Traversing direction [mm]
0	-585 ¹⁾	0.0000	0.0020	0.0000	-0.0008
1	-527	0.0010	0.0017	-0.0005	-0.0001
2	-469	0.0040	0.0053	-0.0001	-0.0009
3	-411	0.0034	0.0061	0.0001	-0.0009
4	-353	0.0013	0.0030	-0.0005	-0.0006
5	-295	0.0004	0.0016	-0.0002	-0.0003
6	-237	0.0016	0.0027	-0.0004	-0.0007
7	-179	0.0026	0.0043	-0.0004	-0.0004
8	-121	-0.0010	0.0026	0.0000	-0.0011
9	-63	-0.0023	0.0000	-0.0011	-0.0003
10	-5 ²⁾	-0.0031	-0.0012	-0.0001	-0.0012

1) Starting position: \$AC_CEC_MIN[<Table>]

2) End position: \$AC_CEC_MAX[<Table>]



Programming

The following actions are performed by program "BI_SSFk_TAB_AX1_X.MPF":

- Deactivation of the compensation
- Deactivation of the compensation tables to be written (active tables cannot be written).
- Writing the compensation values into the compensation tables for the positive and negative traversing direction of the X axis
- Writing the compensation parameters

```
; directional LEC
; 1st axis AX1
; table 1 - positive traversing direction
; table 2 - negative traversing direction
;--- Deaktivierung der Kompensation und der Tabellen
CHANDATA(1)
$MA_CEC_ENABLE[AX1]=0          ; compensation OFF
$SN_CEC_TABLE_ENABLE[0]=0      ; lock Table 1
$SN_CEC_TABLE_ENABLE[1]=0      ; lock Table 2
NEWCONF
;--- 1. Kompensationstabelle, positive Verfahrriichtung
;----- Kompensationswerte
$AN_CEC[0,0]=0                 ; correction value interpolation point 0
$AN_CEC[0,1]=0.001             ; correction value interpolation point 1
$AN_CEC[0,2]=0.004             ; correction value interpolation point 2
$AN_CEC[0,3]=0.0034            ; correction value interpolation point 3
```

9.5 Interpolatory compensation

```

$AN_CEC[0,4]=0.0013          ; correction value interpolation point 4
$AN_CEC[0,5]=0.0004          ; correction value interpolation point 5
$AN_CEC[0,6]=0.0016          ; correction value interpolation point 6
$AN_CEC[0,7]=0.0026          ; correction value interpolation point 7
$AN_CEC[0,8]=-0.001          ; correction value interpolation point 8
$AN_CEC[0,9]=-0.0023         ; correction value interpolation point 9
$AN_CEC[0,10]=-0.0031        ; correction value interpolation point 10
; ----- Kompensationsparame-
ter
$AN_CEC_INPUT_AXIS[0]=(AX1)   ; basic axis
$AN_CEC_OUTPUT_AXIS[0]=(AX1)  ; compensation axis
$AN_CEC_STEP[0]=58.0          ; distance between interpolation points
$AN_CEC_MIN[0]=-585.0         ; starting position
$AN_CEC_MAX[0]=-5.0           ; end position
$AN_CEC_DIRECTION[0]=1        ; table applies to positive traversing directions
$AN_CEC_MULT_BY_TABLE[0]=0     ; no multiplication (not relevant here)
$AN_CEC_IS_MODULO[0]=0        ; compensation without modulo function
;--- 2. Kompensationstabelle, negative Verfahrerrichtung
;----- Kompensationswerte
$AN_CEC[1,0]=0.002           ; correction value interpolation point 0
$AN_CEC[1,1]=0.0017          ; correction value interpolation point 1
$AN_CEC[1,2]=0.0053          ; correction value interpolation point 2
$AN_CEC[1,3]=0.0061          ; correction value interpolation point 3
$AN_CEC[1,4]=0.003           ; correction value interpolation point 4
$AN_CEC[1,5]=0.0016          ; correction value interpolation point 5
$AN_CEC[1,6]=0.0027          ; correction value interpolation point 6
$AN_CEC[1,7]=0.0043          ; correction value interpolation point 7
$AN_CEC[1,8]=0.0026          ; correction value interpolation point 8
$AN_CEC[1,9]=0.000           ; correction value interpolation point 9
$AN_CEC[1,10]=-0.0012         ; correction value interpolation point 10
; ----- Kompensationsparame-
ter
$AN_CEC_INPUT_AXIS[1]=(AX1)   ; basic axis
$AN_CEC_OUTPUT_AXIS[1]=(AX1)  ; compensation axis
$AN_CEC_STEP[1]=58.0          ; distance between interpolation points
$AN_CEC_MIN[1]=-585.0         ; starting position
$AN_CEC_MAX[1]=-5.0           ; end position
$AN_CEC_DIRECTION[1]=-1       ; table applies to negative traversing directions
$AN_CEC_MULT_BY_TABLE[1]=0     ; no multiplication (not relevant here)
$AN_CEC_IS_MODULO[1]=0        ; compensation without modulo function (for rotary
                                axes only)
;--- Aktivierung der Kompensation und der Tabellen
$MA_CEC_ENABLE[AX1]=1         ; compensation ON
$SN_CEC_TABLE_ENABLE[0]=1     ; enable table 1
$SN_CEC_TABLE_ENABLE[1]=1     ; enable table 2
NEWCONF

```

M17

; end of program

9.5.6 Cylinder error compensation

9.5.6.1 Options


The following option is required to use the "Cylindrical error compensation" function:

- SINUMERIK Grinding Advanced (6FC5800-0AS35-0YB0)

9.5.6.2 Function

The cylinder error compensation is used to compensate for clamping errors for cylindrical grinding. In this case, a shift and/or rotation of the workpiece in the machining plane is compensated.

Contrary to Sag and angularity error compensation (Page 251), which is used as basis for cylinder error compensation, only two interpolation points are used to define the compensation function (straight line).



- ① Set position of the cylinder
② Actual position of the cylinder

Figure 9-19 Cylinder error due to incorrect clamping

9.5.6.3 Commissioning

Number	Identifier	Meaning
SD41300	\$SN_CEC_TABLE_ENABLE	Compensation table enable
SD41310	\$SN_CEC_TABLE_WEIGHT	Weighting factor
SD41320	\$SN_CEC_0	Compensation value at the starting position
SD41321	\$SN_CEC_1	Compensation value at the end position
SD41330	\$SN_CEC_BAS_0	Measuring point P1: Basic value
SD41331	\$SN_CEC_BAS_1	Measuring point P2: Basic value
SD41335	\$SN_CEC_BAS_STORE_0	Bit memories for measuring point P1: Basic value

Number	Identifier	Meaning
SD41336	\$SN_CEC_BAS_STORE_1	Bit memories for measuring point P2: Basic value
SD41340	\$SN_CEC_COMP_0	Measuring point P1: Cylinder error
SD41341	\$SN_CEC_COMP_1	Measuring point P2: Cylinder error
SD41350	\$SN_CEC_COMP_STORE_0	Bit memories for measuring point P1: Cylinder error
SD41351	\$SN_CEC_COMP_STORE_1	Bit memories for measuring point P2: Cylinder error
SD41355	\$SN_CEC_CALC	Start of calculation by 0/1 edge
SD41356	\$SN_CEC_CALC_ADD	Absolute or additive compensation values

Note**Table index**

All of the subsequently described machine data, setting data and system variables with the same **index <t>** belong to the same compensation table.

Compensation function

The compensation function of the cylinder error compensation is a straight line with the form:

$$\Delta X = m \cdot Z + b$$

ΔX : Compensation value for the set position of the compensation axis


m : Gradient of the compensation straight lines

Z : Set position of the basic axis

b : Offset of the compensation straight lines

Measuring points

To enable the control to calculate the compensation function, the error in the compensation axis must be measured at two points on the clamped cylindrical workpiece. In the following figure, in accordance with the machining plane G18 (Z/X) that is usual in grinding, the basic axis is designated Z and the compensation axis, X.



① Measuring point P1

② Measuring point P2

--- $\$SN_CEC_BAS_0/_1$: Positions of the measuring points in the basic axis (Z)

--- $\$SN_CEC_COMP_0/_1$: Cylinder error at the measuring points in the compensation axis (X)

--- $\varnothing D_1 == \varnothing D_2$

Figure 9-20 Measuring points of the cylinder error compensation

The measuring points must meet the following condition:

$$Z_{P1} < Z_{P2} \Rightarrow \$SN_CEC_BAS_0 < \$SN_CEC_BAS_1$$

Basic commissioning

Cylinder error compensation is based on sag compensation (CEC) (Page 251). As a consequence, before commissioning the cylinder error compensation, the following compensation parameters must first be set in the system variables of the sag compensation. To this end, the required values are written to the system variables in an NC program.

Program code	Comment
$\$AN_CEC_INPUT_AXIS[<t>] = "<basic axis>"$	; name of the basic axis
$\$AN_CEC_OUTPUT_AXIS[<t>] = "<compensation axis>"$	; name of the compensation axis
$\$AN_CEC_MIN[<t>] = <starting position>$	; starting position of the traversing range in which the compensation should be effective
$\$AN_CEC_MAX[<t>] = <end position>$	; end position of the traversing range in which the compensation should be effective
$\$AN_CEC_STEP[<t>] = <distance between interpolation points>$	; distance between interpolation point = end position - starting position
$\$AN_CEC_DIRECTION[<t>] = 0$	; no dependency on the direction
$\$AN_CEC_IS_MODULO[<t>] = FALSE$	; no modulo functionality

Program code	Comment
\$AN_CEC_MULT_BY_TABLE[<t>] = 0	; no multiplication with another table
\$AN_CEC_TYPE = 1	; compensation type = cylinder error compensation

Distance between interpolation points (\$AN_CEC_STEP[t])

Because the compensation function is a straight line, only two interpolation points are required for the cylinder error compensation. The distance between the interpolation points is therefore the difference between the end and the starting position:

$$\$AN_CEC_STEP[<t>] = \$AN_CEC_MAX[<t>] - \$AN_CEC_MIN[<t>]$$

Setting the cylinder error compensation

The following shows the principle approach when setting cylinder compensation.

1. Definition of whether the actual compensation values take effect absolutely or relatively:

Setting data		Meaning
SD41356	\$SN_CEC_CALC_ADD[<t>]	Absolute or additive compensation values (0: absolute, 1: relative)

2. Definition of the weighting factor to which the compensation values are added:

Setting data		Meaning
SD41310	\$SN_CEC_TABLE_WEIGHT[<t>]	Weighting factor

The characteristic curve can be moved vertically via the weighting factor.

3. Determining the **error** in the direction of the compensation axis (X) at two measuring points.
4. Transfer the measuring points (basic value and error or compensation value) to the compensation data:

	Basic value (Z)	Compensation value (X)
Measuring point P1	SD41330 \$SN_CEC_BAS_0[<t>]	SD41340 \$SN_CEC_COMP_0[<t>]
Measuring point P2	SD41331 \$SN_CEC_BAS_1[<t>]	SD41341 \$SN_CEC_COMP_1[<t>]

5. Triggering a positive edge change (0→1) at the start of calculation of the compensation function:

Setting data		Meaning
SD41355	\$SN_CEC_CALC[<t>]	Start of calculation by 0→1 edge

6. The control calculates the compensation values for the starting and end points of the compensation straight lines, absolute or relative, depending on setting data SD41356 \$SN_CEC_CALC_ADD[<t>]:

Absolute:

- SD41320 \$SN_CEC_0[<t>] = <calculated compensation value at the starting position>
- SD41321 \$SN_CEC_1[<t>] = <calculated compensation value at the end position>

Relative:

- SD41320 \$SN_CEC_0[<t>] = SD41320 \$SN_CEC_0[<t>] + <calculated compensation value at the starting position>
- SD41321 \$SN_CEC_1[<t>] = SD41321 \$SN_CEC_1[<t>] + <calculated compensation value at the end position>

Setting data		Meaning
SD41320	\$SN_CEC_0[<t>]	Compensation value at the starting position
SD41321	\$SN_CEC_1[<t>]	Compensation value at the end position

The measured values are written into bit memories after the calculation and then deleted:

- Bit memory = measured value
- Measured value = 0.0

Setting data		Meaning
Bit memory		
SD41335	\$SN_CEC_BAS_STORE_0[<t>]	Bit memories for measuring point P1: Base value
SD41350	\$SN_CEC_COMP_STORE_0[<t>]	Bit memories for measuring point P1: Cylinder error
SD41336	\$SN_CEC_COMP_STORE_0[<t>]	Bit memories for measuring point P2: Base value
SD41351	\$SN_CEC_COMP_STORE_1[<t>]	Bit memories for measuring point P2: Cylinder error
Deleted measured values		
SD41330	\$SN_CEC_BAS_0[<t>]	Measuring point P1: Base value
SD41340	\$SN_CEC_COMP_0[<t>]	Measuring point P1: Cylinder error
SD41331	\$SN_CEC_BAS_1[<t>]	Measuring point P2: Base value
SD41341	\$SN_CEC_COMP_1[<t>]	Measuring point P2: Cylinder error

7. Set enable for use of the compensation table:

Setting data		Meaning
SD41300	\$SN_CEC_TABLE_ENABLE[<t>]	Compensation table enable

Note

SINUMERIK Toolbox

File CNC_TAB_CONF.MPF is also provided in the SINUMERIK Toolbox. It includes an example how cylinder error compensation can be parameterized within an NC program.


9.5.6.4 Examples

In the following examples, for the cylinder error compensation, the first compensation table (index 0) is used.

Example 1: Cylinder error compensation with absolute compensation values

Overview of the compensation parameters determining the characteristic

For the example, the compensation parameters shown in the following figure are used.



General compensation data

Setting data \$SN_...		Value	Meaning
SD41300	CEC_TABLE_ENABLE[0]	FALSE	Enable
SD41310	CEC_TABLE_WEIGHT[0]	1	Weighting factor
SD41356	CEC_CALC_ADD[0]	FALSE	Absolute compensation values ¹⁾

1) The compensation values calculated below are written into the setting data SD41320 \$SN_CEC_0[0] and SD41321 \$SN_CEC_1[0], i.e. they are applied absolutely. In case of TRUE, they would be added to the existing compensation values.

Axes, compensation range, and table properties

System variable \$AN_...	Value	Meaning
CEC_INPUT_AXIS[0]	(Z)	Basic axis
CEC_OUTPUT_AXIS[0]	(X)	Compensation axis
CEC_MIN[0]	-400,000 mm	Starting position
CEC_MAX[0]	400,000 mm	End position

System variable \$AN_...	Value	Meaning
CEC_STEP[0]	800,000 mm	Distance between interpolation points
CEC_DIRECTION[0]	0	The compensation table applies to both traversing directions of the basic axis.
CEC_IS_MODULO[0]	FALSE	No modulo function is active
CEC_MULT_BY_TABLE[0]	0	No table multiplication is active

Measuring points

Setting data \$SN_...	Value	Meaning
SD41330 CEC_BAS_0[0]	110.0 mm	Measuring point P1: Base value
SD41331 CEC_BAS_1[0]	210.0 mm	Measuring point P2: Base value
SD41340 CEC_COMP_0[0]	0.001 mm	Measuring point P1: Cylinder error
SD41341 CEC_COMP_1[0]	0.002 mm	Measuring point P2: Cylinder error

Calculation of the compensation values

Calculation of the compensation values is performed by the control based on a rising edge (0→1) in setting data SD41355 \$SN_CEC_CALC[0]. The calculations shown below are therefore only for illustration.

- Compensation function $\Delta X = f(Z)$:

$$\Delta X = m * Z + b = \frac{X_{P2} - X_{P1}}{Z_{P2} - Z_{P1}} * Z + b \quad (1)$$

- Calculation of the gradient m:

$$m = \frac{\text{SD41341 } \$SN_CEC_COMP_1[0] - \text{SD41340 } \$SN_CEC_COMP_0[0]}{\text{SD41331 } \$SN_CEC_BAS_1[0] - \text{SD41330 } \$SN_CEC_BAS_0[0]}$$

$$= \frac{0.002 - 0.001}{210.0 - 110.0} = 1 * 10^{-5} \quad (2)$$

- Calculating the offset b → measuring point P1(110.0, 0.001) and (2) used in (1):
 $0.001 = 1 * 10^{-5} * 110.0 + b$
 $b = -1 * 10^{-4} \quad (3)$

- Resulting compensation function → (3) and (2) used in (1):

$$\Delta X = 1 * 10^{-5} * Z - 1 * 10^{-4}$$

- Calculating the compensation values → starting or end position used in (4):
 $\text{SD41320 } \$SN_CEC_0[0] = \Delta X_{\text{COMP}_0} = 1 * 10^{-5} * -400000 - 1 * 10^{-4} = -4.0001$
 $\text{SD41321 } \$SN_CEC_1[0] = \Delta X_{\text{COMP}_1} = 1 * 10^{-5} * 400000 - 1 * 10^{-4} = 3.9999$

Setting data \$SN_...	Value	Meaning
SD41320 CEC_0[0]	-4.0001 mm	Compensation value at the starting position
SD41321 CEC_1[0]	3.9999 mm	Compensation value at the end position
SD41330 CEC_BAS_0[0]	0.0 mm	Measuring point P1: Base value (deleted)
SD41331 CEC_BAS_1[0]	0.0 mm	Measuring point P2: Base value (deleted)

Setting data \$SN_...		Value	Meaning
SD41335	CEC_BAS_STORE_0[0]	110.0 mm	Bit memories for measuring point P1: Base value
SD41336	CEC_BAS_STORE_1[0]	210.0 mm	Bit memories for measuring point P2: Base value
SD41340	CEC_COMP_0[0]	0.0 mm	Measuring point P1: Cylinder error (deleted)
SD41341	CEC_COMP_1[0]	0.0 mm	Measuring point P2: Cylinder error (deleted)
SD41350	CEC_COMP_STORE_0[0]	0.001 mm	Bit memories for measuring point P1: Cylinder error
SD41351	CEC_COMP_STORE_1[0]	0.002 mm	Bit memories for measuring point P2: Cylinder error

Example 2: Cylinder error compensation with relative compensation values

Example 2 based on the compensation data of example 1. The cylinder error compensation is also realized using the first compensation table (index 0).

In example 2, the cylinder error is determined only at two measuring points, unlike example 1. The compensation values are to apply relatively, i.e. they are **added** to the existing compensation values from example 1.

General compensation data

Setting data \$SN_...		Value	Meaning
SD41356	CEC_CALC_ADD[0]	TRUE	Relative compensation values ¹⁾
1) The compensation values calculated below are added to the setting data SD41320 \$SN_CEC_0[0] and SD41321 \$SN_CEC_1[0].			

Measuring points

Setting data \$SN_...		Value	Meaning
SD41330	CEC_BAS_0[0]	10.0 mm	Measuring point P1: Base value
SD41331	CEC_BAS_1[0]	410.0 mm	Measuring point P2: Base value
SD41340	CEC_COMP_0[0]	0.0 mm	Measuring point P1: Cylinder error
SD41341	CEC_COMP_1[0]	-0.003 mm	Measuring point P2: Cylinder error

Calculation of the compensation values

Calculation of the compensation values is performed by the control based on a rising edge (0→1) in setting data SD41355 \$SN_CEC_CALC[0]:

- Compensation function: $\Delta X = m * Z + b = -7.5 * 10^{-6} * Z + 7.5 * 10^{-5}$
- Calculated compensation values:
 - $\Delta X_{\text{COMP}_0} = 3.000075 \text{ mm}$
 - $\Delta X_{\text{COMP}_1} = -2.999925 \text{ mm}$
- Adding the calculated compensation values to the actual compensation values:
 - SD41320 \$SN_CEC_CEC_0[0] = SD41320 \$SN_CEC_CEC_0[0] + $\Delta X_{\text{COMP}_0} = -4.0001 \text{ mm} + 3.000075 = -1.000025 \text{ mm}$
 - SD41321 \$SN_CEC_CEC_1[0] = SD41321 \$SN_CEC_CEC_1[0] + $\Delta X_{\text{COMP}_1} = 3.9999 \text{ mm} - 2.999925 \text{ mm} = 0.999975$

Setting data \$SN_CEC_...		Value	Meaning
SD41320	CEC_0[0]	-1.000025 mm	Compensation value at the starting position
SD41321	CEC_1[0]	0.999975 mm	Compensation value at the end position
SD41330	CEC_BAS_0[0]	0.0 mm	Measuring point P1: Base value (deleted)
SD41331	CEC_BAS_1[0]	0.0 mm	Measuring point P2: Base value (deleted)
SD41335	CEC_BAS_STORE_0[0]	10.0 mm	Bit memories for measuring point P1: Base value
SD41336	CEC_BAS_STORE_1[0]	410.0 mm	Bit memories for measuring point P2: Base value
SD41340	CEC_COMP_0[0]	0.0 mm	Measuring point P1: Cylinder error (deleted)
SD41341	CEC_COMP_1[0]	0.0 mm	Measuring point P2: Cylinder error (deleted)
SD41350	CEC_COMP_STORE_0[0]	0.0 mm	Bit memories for measuring point P1: Cylinder error
SD41351	CEC_COMP_STORE_1[0]	-0.003 mm	Bit memories for measuring point P2: Cylinder error

9.5.7 Supplementary conditions

Compensated actual position

The following functions are based on the compensated actual position:

- Measurement
- Teach In
- Software limit switch

Displaying the actual position

The actual position of the axis without compensation (ideal machine) is displayed in the actual position display in the machine coordinate system.

The actual position of the axis with compensation (MSEC and backlash compensation) is displayed in the service display "Axis/spindle" ("Diagnostics" operating area).

Displaying the compensation values

The following compensation values are also output in the "Axis/spindle" service display (operating area "Diagnosis"):

- "Absolute compensation value measuring system 1" or 2
The value displayed is the sum of the compensation values of MSEC, obtained from the actual position of the basic and compensation axis, and backlash compensation.
- Compensation, sag + temperature
The value displayed is the sum of the compensation values of sag and temperature compensation, obtained from the actual position of the basic and compensation axis.

Loss of the referenced status of the basic axis

If the referenced status of the active measuring system of the basic axis changes from "Referenced/synchronized" to "Not referenced/synchronized" (DB31, ... DBX60.4 or .5: 1→0), then the MSEC and/or sag compensation is deactivated in the corresponding axis (basic/compensation axis).

If the referenced status of the active measuring system of the basic axis then changes from "Not referenced/synchronized" to "Referenced/synchronized" (DB31, ... DBX60.4 or .5: 0→1), then the MSEC and/or sag compensation is reactivated in the corresponding axis (basic/compensation axis).

Controller enable signals

If a compensation relationship is active, then the controller enable (DB31, ... DBX2.1) should always be set the same for the basic and compensation axes.

Traversing signal output

The traversing signals of the compensation axis are only when the compensation function is activated/deactivated and when the number of active compensation tables changes.

Traversing motion of the compensation axis, resulting from motion of the basic axis, does not result in the output of traversing signals in the compensation axis.

9.6 Dynamic feedforward control (following error compensation)

9.6.1 General properties

Axial following error

The remaining system deviation of the position controller when traversing a machining axis is known as axial following error. In other words, the axial following error is the difference between the setpoint position and the actual position of the machine axis with a velocity which is not equal to "0".

Effects

Particularly during acceleration in contour curvatures, e.g. circles and corners, this following error leads to undesirable, velocity-dependent contour violations.

Compensation

The axial following error can be reduced almost to zero with the help of the "dynamic feedforward control". The function is therefore also called "following error compensation". Reduction of the following errors in the interpolating axes also ensures that the contour errors are less velocity-dependent and contour distortions are minimized.

Methods

There are two "dynamic feedforward control" methods:

- Speed feedforward control (velocity-dependent)
- Torque feedforward control (acceleration-dependent)

Activation

The feedforward control method is selected and activated using the machine data:

MD32620 \$MA_FFW_MODE (feedforward control mode)

Setting \$MA_FFW_MODE = 4 is recommended to avoid contour errors.

Value	Meaning
0	No feedforward control
1	Speed feedforward control with PT1 balancing
2	Torque feedforward control with PT1 balancing
3	Speed feedforward control with Tt balancing
4	Torque feedforward control with Tt balancing

Modes 1 and 2 are additionally provided for compatibility purposes.

Activation/deactivation in part program

The following axis-specific machine data can be used to define that the feedforward control for the respective axis/spindle can be activated and deactivated by the part program:

MD32630 \$MA_FFW_ACTIVATION_MODE (activate feedforward control from program)

Value	Meaning
0	The feedforward control cannot be activated and deactivated from the part program. This means that the state specified using MD32620 \$MA_FFW_MODE is always effective for the axis/spindle.
1	The feedforward control can be activated and deactivated from the part program. The operation becomes active immediately.
2	The feedforward control can be activated and deactivated from the part program. The operation only becomes active the next time that the axis comes to a standstill.

The feedforward control is activated/deactivated from the part program using the operations:

FFWON: Feedforward control ON

FFWOF: Feedforward control OFF

The default setting (i.e. M30 even after reset) is entered using the channel-specific machine data:

MD20150 \$MC_GCODE_RESET_VALUES (initial setting of the G groups)

FFWON/FFWOF is active for all axes/spindles in the axis mode, where:

MD32630 \$MA_FFW_ACTIVATION_MODE = 1 (or 2)

and

MD32620 \$MA_FFW_MODE = 1, 2, 3 or 4

The identical MD32630 setting should be used for axes that interpolate with each other.

The feedforward control should only be activated or deactivated while the axis/spindle is stationary in the axis mode, in order to prevent jerky motion. Hence the switchover is delayed automatically up to the next standstill through block search stop.

If the axes are optimized with feedforward control, it is recommended that the feedforward control is not switched off in the part program.

MD32630=0 is recommended in this regard.

Note

A preprocessing stop has no effect for command or PLC axes traversing asynchronously to the part program processing. To ensure that FFWON/FFWOF only has an effect on the axis/spindle when it is next stationary in the axis mode, you must explicitly set MD32630 = 2 for each axis/spindle in the axis mode (see also "Forward feed control for command- and PLC axes (Page 301)").


9.6.2 Speed feedforward control

Function

In the case of speed feedforward control, a velocity setpoint is also applied directly to the input of the speed controller. With this value the following error can be reduced to nearly zero (i.e. system deviation is 0) when the velocity is constant.

Commissioning

The following axis-specific parameters must be defined for the speed feedforward control during commissioning:



Equivalent time constant of the speed control loop (MD32810)

The equivalent time constant of the speed control loop must be determined accurately (e.g. graphically from a speed setpoint step response) and entered into the following machine data to correctly set the speed feedforward control:

MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant speed control loop for feedforward control)

Feedforward control factor for speed feedforward control (MD32610)

The additional velocity setpoint can be weighted using a factor:

MD32610 \$MA_VELO_FFW_WEIGHT

Value range: 0 ... 1

"0" means: no feedforward control. As standard, the factor has a value of 1 ($\hat{=}$ 100%).

The factor should remain set at 100%, as this value is the optimum setting for an optimally set control loop for the axis/spindle as well as a precisely determined equivalent time constant of the speed control loop.

Fine adjustment

The speed feedforward control for the particular axis/spindle can be optimized by making slight changes (fine tuning) to the equivalent time constants of the speed control loop (MD32810).

Fine adjustment (equivalent time constant, moment of inertia) can also be determined automatically via AST (AutoServoTuning). Calibration of the interpolating axes ("Dynamic response adaptation") is likewise performed by the AST.

To make this check, the axis/spindle should be traversed at a constant velocity and in the service display "Axis/spindle", the "System deviation" should be checked.

A small acceleration and a high feedrate should be chosen so that the values can be easily read on the service display. This produces very long acceleration phases from which it is easy to read off the control deviation.

Example:

```
MD32300 $MA_MAX_AX_ACCEL = 0.1      ; Maximum axis acceleration = 0.1 m/s2
MD32000 $MA_MAX_AX_VELO = 20000.0   ; Maximum axis velocity
                                      = 20000.0 mm/min
```

```
; Part program for setting the equivalent time constant
G1 F20000
FFWON
LOOP:
X1000
X0
GOTOB LOOP
M30
```

Further information

For detailed information about setting the equivalent time constants of the speed control loop (MD32810) refer to:

- Function Manual Axes and Spindles; Velocities, setpoint/actual value systems, closed-loop control (G2), optimizing the closed-loop control

9.6.3 Torque feedforward control**Function**


In the case of torque feedforward control, an additional current setpoint proportional to the torque is applied directly to the current controller input. This value is formed using the acceleration and moment of inertia.

Application

Torque feedforward control is required to achieve high contour accuracy where the demands on the dynamic response are very high. If set correctly, the following error can almost be completely compensated even during high acceleration.

Commissioning

The following axis-specific parameters must be defined during commissioning for torque feedforward control:



Equivalent time constant of the current control loop (MD32800)

The equivalent time constant of the current control loop must be determined accurately (e.g. graphically from the step response of the current control loop) and entered in the following machine data in order to correctly set the torque feedforward control:

MD32800 \$MA_EQUIV_CURRCTRL_TIME (equivalent time constant current control loop for feedforward control)

Total moment of inertia of axis (MD32650)

The torque feedforward control already offers advantages over the speed feedforward control - even if the actual moment of inertia is not precisely known. It is recommended for load-dependent axes that the empty axis is measured and the resulting total inertia applied. For fine tuning of the AX_INERTIA::

MD32650 \$MA_AX_INERTIA (inertia for torque feedforward control)

Fine adjustment

The torque feedforward control for the particular axis/spindle can be optimized by making slight changes (fine tuning) to the values in MD32800 and MD32650. Fine adjustment (equivalent time constant, moment of inertia) can be determined automatically via AST (AutoServoTuning). Calibration of the interpolating axes ("Dynamic response adaptation") is likewise performed by the AST.

9.6 Dynamic feedforward control (following error compensation)

The position controller difference can be recorded via the trace functionality as verification. In addition to traversing at a constant velocity, the following error should be monitored especially when the axis/spindle accelerates.

Note

As a result of the extremely fast sequences when accelerating, when commissioning the torque feedforward control, the service display cannot be used to check the fine adjustment.

Further information

For detailed information about setting the equivalent time constants of the current control loop (MD32810) refer to:

- Function Manual Axes and Spindles; Velocities, setpoint/actual value systems, closed-loop control, optimizing the closed-loop control

9.6.4 Dynamic response adaptation

Function

For axes that interpolate with one another, but with different axial control loop response times, dynamic response adaptation can be used to achieve identical time responses of all axes to ensure optimum contour accuracy without loss of control quality.

Commissioning

Time constant for dynamic response adaptation (MD32910)

The difference between the equivalent time constants of the "slowest" speed or current control loop and the particular axis should be entered as time constant for the dynamic response adaptation in the following machine data.

MD32910 \$MA_DYN_MATCH_TIME (time constant of dynamic response adaptation)

Example:

Equivalent time constants of the speed control loop (MD32810) for active speed feedforward control of axes 1, 2 and 3:

- Axis 1: 2 ms
- Axis 2: 4 ms (dynamically the slowest axis)
- Axis 3: 1 ms

This means that the following values are obtained for the time constant of the dynamic response adaptation MD32910:

- Axis 1: 2 ms
- Axis 2: 0 ms
- Axis 3: 3 ms

Activation (MD32900)

The dynamic response adaptation is only active if the following machine data is set:

MD32900 \$MA_DYN_MATCH_ENABLE= 1

Further filters

Additional filters can be used for dynamic response adaptation:

- MD32890 \$MA_DESVAL_DELAY_ENABLE (axial phase filter setpoint)
- MD32895 \$MA_DESVAL_DELAY_TIME (time constant for the axial phase filter setpoint)

Further information

Function Manual Axes and Spindles; Velocities, setpoint/actual value systems, closed-loop control, optimizing the closed-loop control

9.6.5 Forward feed control for command- and PLC axes

Function

For command and PLC axes, it must be prevented that the feedforward control is activated/deactivated at higher velocities as follows:

MD32630 \$MA_FFW_ACTIVATION_MODE = 2

With this setting, the *FFWON*/*FFWOF* operation only becomes active below the stationary velocity (MD36060 \$MA_STANDSTILL_VELO_TOL) configured for this particular axis.

If the switchover instruction coincides with an axis motion, the required switchover is executed only in the next stoppage condition of the axis. This avoids the following error being suddenly established/reduced.

Note

A stoppage velocity set to a very high value can lead to the changeover of the feedforward control in the movement. Controls can be activated depending on the existing following error.

Commissioning

We recommend the following procedure when checking the feedforward control for command and PLC axes:

1. Check the stoppage velocity in MD36060.
2. Check the existing following error of the axis in stoppage condition.
3. Setting the changeover condition and activating it:
MD32630 = 2
4. Traverse axis in the part program using the `POSA` operation.
5. Execute `FFWON` during the axis motion.
6. The K_v factor and following error displayed in the service display "Axis/spindle" must not jump.
7. A higher K_v factor and a lower following error are only obtained for traversing motion following standstill. However, the feedforward control is active only from the stoppage condition.

Essentially the same as when activating the feedforward control, for deactivation, the following applies:

1. Traverse axis in the part program using the `POSA` operation.
2. Execute `FFWOF` during the axis motion.
3. The K_v factor and following error displayed in the service display "Axis/spindle" must not jump.
4. A lower K_v factor and a higher following error are only obtained for traversing motion following standstill. However, the feedforward control is inactive only from the stoppage condition.

Example

In the following program example, axis A is traversed asynchronously to the path. An attempt is made to activate the feedforward control in the channel while traversing. Contrary to the geometry axes X, Y and Z, the feedforward control is not immediately effective for axis A. Here one waits for the stoppage after N60. Axis A then traverses with the feedforward control in N70.

Program code

```
N10 FFWOF
N20 POSA[A]=1000 FA[A]=10000
N30 G4 F1
N40 FFWON
N50 G0 X10 Y10 Z10
N60 WAITP(A)
N70 POSA[A]=1500 FA[A]=10000
N80 WAITP(A)
M30
```

9.6.6 Secondary conditions

Axes that are interpolating axes with one another

Also for axes that interpolate with one another, the feedforward control parameter should be optimally set **for each axis**, i.e. also several axes that are interpolating with one another can have different feedforward control parameters.

Check contour monitoring

As the two equivalent time constants:

- MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant speed control loop for feedforward control)

and

- MD32800 \$MA_EQUIV_CURRCTRL_TIME (equivalent time constant current control loop for feedforward control)

also influence the contour monitoring, this should be subsequently checked.

Further information

Axis monitoring functions (Page 149)

Influence on the servo gain factor (K_v factor)

When the feedforward control is set correctly, the response to setpoint changes in the controlled system under speed feedforward control is as dynamic as that of the speed control loop or, under torque feedforward control, as that of the current control loop, i.e. the servo gain factor (K_v factor) entered into MD32200 \$MA_POS_CTRLGAIN hardly has any effect on the control behavior (e.g. corner errors, overshoots, circle/radius errors).

On the other hand, feedforward control does not affect the response to disturbances (synchronism). In this case, the servo gain factor (K_v factor) entered in MD32200 is the active factor.

Service display " K_v factor"

When a feedforward control is active, the servo gain (K_v factor) of the axis (corresponds to servo gain factor (K_v factor) active as response to setpoint changes) shown in the service display "axis/spindle" is very high.

9.7 Friction compensation overview

In addition to the mass inertia and the machining forces, the friction forces in the gearing and guideways of the machine influence the dynamic behavior of a machine axis. In particular, when accelerating a machine axis from standstill, the transition from static to sliding friction has an adverse effect. The resulting sudden change in the friction force results in a briefly increased following error. With interpolating axes, this results in significant contour violations. For circles, these occur especially at the quadrant transitions where one of the participating axes is stationary as its direction is reversed.

To improve the contour accuracy at these points, an additional setpoint pulse (velocity or torque setpoint pulse) is applied to the friction compensation following a direction reversal by the machine axis (during acceleration).

Friction compensation functions

The following functions are available for friction compensation:

- Friction compensation with a constant compensation value (Page 304)
Depending on the acceleration of the machine axis, the same pulse is always applied to the velocity setpoint.
The amplitude and the decay time of the velocity setpoint pulse can be set.
- Friction compensation with adaptive characteristic (Page 310)
Depending on the acceleration of the machine axis, the velocity setpoint pulse is determined from a parameterizable characteristic.
Three different acceleration values can be set as well as the minimum and maximum amplitude and the decay time of the velocity setpoint pulse.
- Friction compensation with adaptive characteristics (Page 313) (Licensed option: 6FC5800-0AS06-0YB0)
Depending on the acceleration of the machine axis, the velocity setpoint pulse is determined from up to three parameterizable characteristics.
Up to nine different acceleration values can be set. For each acceleration value, weighting factors for the amplitude, the active time, and the decay time of the velocity setpoint pulse can be defined.
If the velocity setpoint pulse is not sufficient to achieve the desired result, an additional torque setpoint pulse can be parameterized.

9.8 Friction compensation with a constant compensation value


9.8.1 Description of functions

The friction compensation described below with constant compensation value is intended for applications in which the following general conditions apply:

- The velocity setpoint pulse required for friction compensation is **independent** of the acceleration.
- An acceleration-**independent** amplitude and an acceleration-**independent** decay time are sufficient to model the velocity setpoint pulse.

- For friction compensation at the positive and negative reversal point, the same velocity setpoint pulse is sufficient.
- The requirement for contour accuracy at the reversal points is relatively low.

The following figure shows an example characteristic that can be set with this function:



Δn_{opt} Amplitude of the velocity setpoint pulse
 a Acceleration at the quadrant transition

9.8.2 Commissioning

To determine the axis-specific compensation value Δn_{opt} , the Circularity test (Page 306) must be used to determine the optimum amplitude of the velocity setpoint pulse Δn_{opt_a} for each of a number of acceleration values. The different acceleration values should cover the entire dynamic range.

Calculation of the acceleration at the quadrant transition

On a circular path, the acceleration a of a machine axis on direction reversal at the quadrant transition is calculated from the radius r of the circle and the path velocity v : $a = v^2 / r$

Note

The path velocity and therefore the axis-specific acceleration a can be varied simply via the feedrate override.

Evaluation of the value pairs determined (a , Δn_{opt_a})

To determine the compensation value Δn_{opt} , we recommend graphically applying the value pairs determined in the circularity test comprising the acceleration a and the associated optimum amplitude of the velocity setpoint pulse Δn_{opt_a} : $\Delta n_{opt_a} = f(a)$




Figure 9-21 Axis-specific characteristic determination

The optimum amplitude of the velocity setpoint pulse Δn_{opt} is obtained by drawing in the straight line G1.

Axis-specific machine data

Activating friction compensation

Friction compensation is activated with:

- MD32500 \$MA_FRICT_COMP_ENABLE[<axis>] = **TRUE (1)**

Activating friction compensation with a constant compensation value

Friction compensation with constant compensation value is activated with:

- MD32490 \$MA_FRICT_COMP_MODE[<axis>] = **1**
- MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE[<axis>] = **FALSE (0)**

Velocity setpoint pulse: Amplitude

The amplitude of the velocity setpoint pulse is set with:

MD32520 \$MA_FRICT_COMP_CONST_MAX[<axis>] = <amplitude>

Velocity setpoint pulse: Decay time

The decay time of the velocity setpoint pulse is set via:

MD32540 \$MA_FRICT_COMP_TIME[<axis>] = <time constant>

9.8.2.1 Circularity test

Commissioning via the circularity test

The easiest way to commission the friction compensation is with the circularity test integrated in the user interface. This involves acquiring the circular contour created on the machine as a circle is traversed based on the actual positions of the participating machine axes. Deviations from the programmed ideal circular contour, in particular, at the quadrant transitions, are visualized graphically.

The circularity test can be found on the user interface under:

- SINUMERIK Operate: "Operating area switchover" > "Commissioning" > "Optimization/test" > "Circularity test"

Sequence

The sequence for commissioning friction compensation for a machine axis is divided into the following steps:

1. Set the acceleration a_1 via path velocity v_n and circle radius r
2. Perform circularity test **without** friction compensation

3. Perform a circularity test **with** friction compensation with small initial values for amplitude and decay time
4. Optimize the circularity test **with** friction compensation by changing the parameter values step by step
5. The optimized parameter values are applied graphically, e.g. $\text{amplitude} = f(a_n)$
6. Setting of the next acceleration a_n and continuation with point 2.

Performing the circularity test without friction compensation

A circularity test without friction compensation should be performed to determine the initial quality of the circular contour at the quadrant transitions. To do this, switch off the friction compensation temporarily:

MD32500 FRICT_COMP_ENABLE[<axis>] = 0

The following figure shows a typical example of quadrant transitions without friction compensation:




Figure 9-22 Quadrant transitions without friction compensation

The friction compensation must then be activated again:

MD32500 FRICT_COMP_ENABLE[<axis>] = 1

Performing circularity test with friction compensation

It is recommended that a small amplitude value and a decay time of just a few position control cycles be set as initial values for the velocity setpoint pulse, e.g.:

- MD32520 \$MA_FRICT_COMP_CONST_MAX[<axis>] = 10 [mm/min]
- MD32540 \$FRICT_COMP_TIME[<axis>] = 0.008 [s]

The circularity test performed with these values provides an initial assessment of the friction compensation.

Amplitude too small

Too small an amplitude value (MD32520) is revealed in the circularity test by insufficient compensation of the contour deviations at the quadrant transitions.




Figure 9-23 Amplitude too small

Amplitude too large

Too large an amplitude value (MD32520) is revealed in the circularity test by overcompensation of the contour deviations at the quadrant transitions.




Figure 9-24 Amplitude too large

Decay time too short

Too short a decay time (MD32540) is revealed in the circularity test when the contour deviations at the quadrant transitions are compensated for for a short time but immediately increase again thereafter.




Figure 9-25 Decay time too short

Decay time too long

Too long a decay time (MD32540) is revealed in the circularity test when the contour deviation at the quadrant transitions is compensated for at first. This assumes that the optimum amplitude

values has already been set. If the decay time is too long, however, the compensation applies for too long and results in overcompensation at the next circular contour.




Figure 9-26 Decay time too long

Good friction compensation setting

With a good friction compensation setting, "no" contour violations can be detected at the quadrant transitions.




Figure 9-27 Good friction compensation setting

See also

Friction compensation with adaptive characteristic (Page 310)

9.8.3 Supplementary conditions

Reaction of setpoint-related compensation functions

The following setpoint-related compensation functions affect the position setpoint and must therefore be deactivated for the axes that perform a circularity test:

- Sag and angularity compensation (CEC)
MD32710 \$MA_CEC_ENABLE[<axis>] = 0
- Directional leadscrew error compensation (LEC):
MD32710 \$MA_CEC_ENABLE[<axis>] = 0
- Temperature compensation:
MD32750 \$MA_TEMP_COMP_TYPE[<axis>] = 0


9.9 Friction compensation with adaptive characteristic

9.9.1 Description of functions

The friction compensation with adaptive characteristic is intended for applications with the following requirements:

- The velocity setpoint pulse required for friction compensation depends on the acceleration.
- It is enough if the characteristic is modeled by three different acceleration interpolation points and a minimum and maximum amplitude of the velocity setpoint pulse.
- An acceleration-**dependent** amplitude and an acceleration-**independent** decay time are sufficient to model the velocity setpoint pulse.
- For friction compensation at the positive and negative reversal point, the same velocity setpoint pulse is sufficient.
- For greater acceleration, a smaller compensation value is required than for smaller acceleration.
- The requirement for contour accuracy at the reversal points is high.

The following figure shows an example characteristic that can be set with this function:



$\Delta n_{\max}$ Maximum amplitude of the velocity setpoint pulse

$\Delta n_{\min}$ Minimum amplitude of the velocity setpoint pulse

$a_1, a_2,$ Acceleration interpolation points 1, 2, and 3

a_3

B1 ... Acceleration range 1 ... 4

B4

The amplitude of the velocity setpoint pulse Δn is calculated in the relevant acceleration range B1 to B4 to form:

Range	Acceleration a	Amplitude of the velocity setpoint pulse Δn
B1	$a < a_1$	$\Delta n = \Delta n_{\max} * a / a_1$
B2	$a_1 \leq a \leq a_2$	$\Delta n = \Delta n_{\max}$
B3	$a_2 < a < a_3$	$\Delta n = \Delta n_{\max} + [(\Delta n_{\min} - \Delta n_{\max}) / (a_3 - a_2)] * (a - a_2)$
B4	$a \geq a_3$	$\Delta n = \Delta n_{\min}$

9.9.2 commissioning

To determine the axis-specific characteristic parameters, the Circularity test (Page 306) must be used to determine the optimum amplitude of the velocity setpoint pulse Δn_{opt_a} each for each of a number of acceleration values. The different acceleration values should cover the entire dynamic range. In particular, a sufficient number of measurements must be ensured for low acceleration values and large circle radii.

Calculation of the acceleration at the quadrant transition

On a circular path, the acceleration a of a machine axis on direction reversal at the quadrant transition is calculated from the radius r of the circle and the path velocity v : $a = v^2 / r$

Note

The path velocity and therefore the axis-specific acceleration a can be varied simply via the feedrate override.

Evaluation of the value pairs determined (a , Δn_{opt_a})

To determine the acceleration interpolation points a_1 , a_2 , and a_3 and the minimum and maximum amplitude of the velocity setpoint pulse $\Delta n_{\min}$ and $\Delta n_{\max}$, we recommend graphically applying the value pairs determined in the circularity test comprising the acceleration a and the associated optimum amplitude of the velocity setpoint pulse Δn_{opt_a} : $\Delta n_{\text{opt}_a} = f(a)$




Figure 9-28 Axis-specific characteristic determination

The acceleration interpolation points a_1 , a_2 , and a_3 and the minimum and maximum amplitude of the velocity setpoint pulse $\Delta n_{\min}$ and $\Delta n_{\max}$ result from drawing in the straight lines G1 ...G4.

Axis-specific machine data

Activating friction compensation

Friction compensation is activated with:

MD32500 \$MA_FRICT_COMP_ENABLE[<axis>] = **TRUE (1)**

Activating friction compensation with adaptive characteristic

Friction compensation with adaptive characteristic is activated with:

- MD32490 \$MA_FRICT_COMP_MODE[<axis>] = **1**
- MD32510 \$MA_FRICT_COMP_ADAPT_ENABLE[<axis>] = **TRUE (1)**

Characteristic parameters: Acceleration a_1 , a_2 , and a_3

The axis-specific acceleration a occurring on a circle path on reversal at the quadrant transitions is calculated from the radius r and the path velocity v as: $a = v^2 / r$

The acceleration values a_1 , a_2 , and a_3 , are entered in the machine data in monotonically ascending order ($a_1 < a_2 < a_3$).

- MD32550 \$MA_FRICT_COMP_ACCEL1[<axis>] = < a_1 >
- MD32560 \$MA_FRICT_COMP_ACCEL2[<axis>] = < a_2 >
- MD32570 \$MA_FRICT_COMP_ACCEL3[<axis>] = < a_3 >

Characteristic parameters: Amplitude $\Delta n_{\min}$ and $\Delta n_{\max}$

The maximum and minimum amplitude of the velocity setpoint pulse ($\Delta n_{\max}$, $\Delta n_{\min}$) must be entered in the following machine data:

- MD32520 \$MA_FRICT_COMP_CONST_MAX[<axis>] = < $\Delta n_{\max}$ >
- MD32530 \$MA_FRICT_COMP_CONST_MIN[<axis>] = < $\Delta n_{\min}$ >

Note

If satisfactory results cannot be obtained for very small path velocities, the computational resolution may have to be increased:

- MD10200 \$MA_INT_INCR_PER_MM (computational resolution for linear positions)
 - MD10210 \$MA_INT_INCR_PER_DEG (computational resolution for angular positions)
-

Velocity setpoint pulse: Decay time

The decay time of the velocity setpoint pulse is set via:

MD32540 \$MA_FRICT_COMP_TIME[<axis>] = <decay time>

9.9.3 Supplementary conditions

Reaction of setpoint-related compensation functions

The following setpoint-related compensation functions affect the position setpoint and must therefore be deactivated for the axes that perform a circularity test:

- Sag and angularity compensation (CEC)
MD32710 \$MA_CEC_ENABLE[<axis>] = 0
- Directional leadscrew error compensation (LEC):
MD32710 \$MA_CEC_ENABLE[<axis>] = 0
- Temperature compensation:
MD32750 \$MA_TEMP_COMP_TYPE[<axis>] = 0

9.10 Friction compensation with adaptive characteristics

9.10.1 Description of the function

Friction compensation with adaptive characteristics has the following properties:

- For fast and simple optimization, commissioning can be performed via the SINUMERIK Operate user interface.
- In guided commissioning, the test movements are optionally generated automatically for one or two axes.
- The compensation values can be set separately for each axis, e.g. for a vertical axis, for each reversal point (direction-dependent).
- In relation to the set position (compensation mode (Page 315) = 3), better results are achieved by early application of the compensation value.
- If the velocity setpoint pulse is insufficient to achieve the desired result, e.g. for gearless drives, a pulse can additionally be applied to the torque setpoint.
- Four compensation characteristics with up to nine acceleration interpolation points can be defined.
- Settable parameters for the velocity setpoint pulse:
 - Delay time
 - Amplitude ¹⁾
 - Action time ¹⁾
 - Rise time
 - Decay time ¹⁾


- Settable parameters for the torque setpoint pulse:
 - Amplitude ¹⁾
 - Delay time
 - Rise time
- A temperature, leadscrew error, and/or sag compensation that is active in parallel has no effect on the friction compensation.

1): Parameters that can be adapted depending on the acceleration

Note

In most applications, compensation by means of velocity setpoint pulse and compensation characteristics for amplitude and decay time are sufficient. Only if no satisfactory results have been achieved should further options be used.

Examples of adapted characteristics



①②③

Velocity setpoint pulse:

- Red: Lower reversal point
- Blue: Upper reversal point

④

Torque setpoint pulse

Compensation values for acceleration between the parameterized interpolation points are interpolated linearly.

9.10.2 Commissioning

9.10.2.1 Activating the function

Activating friction compensation

Friction compensation is activated axis-specifically with:

MD32500 \$MA_FRICT_COMP_ENABLE[<axis>] = TRUE

Activating friction compensation with adaptive characteristics

Friction compensation with adaptive characteristics can be applied to the set or actual position of the machine axis, depending on the dynamics of the axis. The function is activated axis-specifically with:

MD32490 \$MA_FRICT_COMP_MODE = <mode>

<mode>	Meaning
3	For axes with high dynamics and active feedforward control ¹⁾ . The velocity or torque setpoint pulse is applied if the set position of the machine axis has reached the trigger point.
4	For axes with low dynamics and inactive feedforward control ¹⁾ . The velocity or torque setpoint pulse is applied if the actual position of the machine axis has reached the trigger point.
1) Feedforward control: MD32620 FFW_MODE (feedforward control mode)	

Note

Commissioning

We urgently recommend performing guided commissioning using the commissioning functions of the SINUMERIK Operate user interface (Page 315) and not changing the generated values in the machine data subsequently.

9.10.2.2 Commissioning functions of the SINUMERIK Operate user interface

Commissioning of the friction compensation with adaptive characteristics is performed in the "friction compensation" window:

Operating area: "Commissioning" > "NC" > "**Friction compensation**"

Note

Softkey "Friction compensation"

The "friction compensation" softkey is only displayed if the friction compensation with adaptive characteristics is active (Page 315) for at least one machine axis.

The parameters for the axis-specific velocity and torque setpoint pulses are determined and stored retentively in machine data. Friction compensation by means of velocity setpoint pulse is normally sufficient.

Determination of the characteristic parameters for the velocity setpoint pulses is performed with guidance by the operator interface.

The characteristic parameters for the torque setpoint pulse required only in exceptional cases must be determined manually.

Note

Friction compensation - axis selection dialog

For the selection of an axis on an NCU other than the currently selected NCU, a switchover is no longer possible once the "Friction compensation" dialog is opened.

To clear the switchover lock, you must first exit the "Friction compensation" dialog.

Further information

The description of friction compensation with adaptive characteristics via the SINUMERIK Operate user interface can be found in: Commissioning Manual, CNC Commissioning: NC, PLC, drive; commissioning NC > Friction compensation with adaptive characteristics

Function

The characteristic parameters are determined using a **circularity test** for up to nine different acceleration values (Page 317). One or two machine axes are alternately continuously traversed via an circularity test program generated automatically by the control and the result is displayed in a circle diagram.

The traversing movements of the circularity program (radius, path velocity, and direction of rotation) are already set in the following setting data. If necessary, they can be modified via the data list (see below paragraph "Further parameters").

Parameters	Axis type	Setting Data
Radius	Linear axis	SD55820 \$SCS_FRICT_OPT_RADIUS
	Rotary axis	SD55821 \$SCS_FRICT_OPT_RADIUS_ROT
Path velocity	Linear axis	SD55822 \$SCS_FRICT_OPT_FEED[0 ... 8]
	Rotary axis	SD55823 \$SCS_FRICT_OPT_FEED_ROT[0 ... 8]
Direction of rotation ¹⁾	---	SD55828 \$SCS_FRICT_OPT_DIR_MINUS

1) Only effective in the circularity test with two axes

Measuring step

After the start of the circularity test program, in each of the up to nine measuring steps of a measurement series, the axes are traversed with the path velocity that is defined in the setting data or with the corresponding acceleration. The deviations of the actual positions from the ideal path are acquired and displayed as a set or actual circular path. The parameters of the velocity setpoint pulse can be varied by the commissioning engineering while the circularity test continues to be performed constantly. The resulting changes are automatically updated in the result graphics.

If the circularity tests is only performed with a single axis, the result is also displayed as a circle. For this purpose, the determined contour deviations of the axis are displayed one horizontally

and once vertically. If the circularity test is performed with two axes, both axes must be geometry axes of the same channel.

Completion

After optimization of the compensation parameters for the entire measurement series has been completed, the maximum values, characteristics interpolation points, and weighting factors are calculated by the control and written into the following machine data:

Maximum value	Machine data
Amplitude	MD32571 \$MA_FRICT_VELO_STEP
Decay time	MD32574 \$MA_FRICT_V_PULSE_DECAY_TIME
Active time	MD32573 \$MA_FRICT_V_PULSE_CONST_TIME

Characteristic interpolation points	Machine data
Acceleration of the friction compensation characteristics	MD32581 \$MA_FRICT_ADAPT_TABLE_ACCEL[0 ... 9]

Weighting factors	Machine data
Amplitude upper / lower	MD32582 \$MA_FRICT_ADAPT_V_STEP_PLUS[0 ... 9] MD32583 \$MA_FRICT_ADAPT_V_STEP_MINUS[0 ... 9]
Decay time upper / lower	MD32586 \$MA_FRICT_ADAPT_V_DECAY_PLUS[0 ... 9] MD32587 \$MA_FRICT_ADAPT_V_DECAY_MINUS[0 ... 9]
Action time upper / lower	MD32584 \$MA_FRICT_ADAPT_V_CONST_PLUS[0 ... 9] MD32585 \$MA_FRICT_ADAPT_V_CONST_MINUS[0 ... 9]

Additional parameters

With the vertical softkey "Data list," further machine and setting data are displayed for parameterization of the friction compensation with adaptive characteristics, e.g. also the parameters for the torque setpoint pulse. The setting these parameters is described in the following sections.

9.10.2.3 Parameterization of the acceleration at the characteristic interpolation points

From the channel-specific setting data of the circularity test (circle radius and traversing velocity), the control calculates the acceleration values of the characteristic interpolation points.

Channel-specific setting data

The channel-specific setting data for circle radius and velocities apply to all machine axes with active friction compensation with adaptive characteristics that are channel axes of the channel in question. They are already assigned typical values. In necessary, they can be adapted machine-specifically.

Circle radius

A circle is traversed with the parameterized radius in the automatically generated circularity tests program:

- Linear axes
SD55820 \$SCS_FRICT_OPT_RADIUS = <radius>
- Rotary axes
SD55821 \$SCS_FRICT_OPT_RADIUS_ROT = <radius>

Traversing velocities

In the circularity test, the machine axes are traversed in each of the up to nine measurement sections with the velocity parameterized in the setting data:

- Linear axes
SD55822 \$SCS_FRICT_OPT_FEED[0 ... 8] = <velocity 1 ... 9>
- Rotary axes
SD55823 \$SCS_FRICT_OPT_FEED_ROT[0 ... 8] = <velocity 1 ... 9>

Note

- If fewer than nine characteristic interpolation points (1 ... n) are required, the velocity zero must be entered in each of the corresponding array elements for all unneeded characteristic interpolation points ((n+1) ... 9).
 - If the velocity is equal to zero in an array element, no following array element must contain a velocity that is not equal to zero.
-

Direction of rotation

In the circularity test with two axes, the direction of rotation of the circle is defined with:

SD55828 \$SCS_FRICT_OPT_DIR_MINUS = <direction of rotation>

Axis-specific machine data

The acceleration a at the characteristic interpolation point n is calculated by the control from the setting data for the circle radius r and the path velocity v_{n-1} : $a_n = v_{n-1}^2 / r$

$$\text{MD32581 } \$\text{MA_FRICT_ADAPT_TABLE_ACCEL}[n] = \frac{(\text{SD55822 } \$\text{SCS_FRICT_OPT_FEED}[(n-1)])^2}{\text{SD55820 } \$\text{SCS_FRICT_OPT_RADIUS}}$$

where $n = 1, 2, 3, \dots, 9$

For acceleration a at characteristic interpolation point $n = 0$, the value zero is always entered:

MD32581 \$MA_FRICT_ADAPT_TABLE_ACCEL[0] = 0

9.10.2.4 Velocity setpoint pulse

Determination of the characteristic parameters for the velocity setpoint pulses and calculation of the corresponding machine data is fully supported by the user interface (Page 315). We therefore advise **against** determining the characteristic parameters or writing the machine data manually.

Axis-specific machine data

Velocity setpoint pulse




Figure 9-29 Basic pulse shape

The numbers (①, ②, ...) stated in the following tables refer to the figure above.

Acceleration-independent parameters

No.	Machine data	Description
①	-	Trigger time or acceleration of the axes from stand-still
③	MD32572 \$MA_FRICT_V_PULSE_DELAY_TIME	Delay time
④	MD32575 \$MA_FRICT_V_PULSE_SMOOTH_TIME	Time constant T of the rise time, after 5 * T ⇒ output value ≈ input value

Maximum values of the acceleration-dependently adaptable parameters

No.	Machine data	Description
②	MD32571 \$MA_FRICT_VELO_STEP	Amplitude
⑤	MD32573 \$MA_FRICT_V_PULSE_CONST_TIME	Active time
⑥	MD32574 \$MA_FRICT_V_PULSE_DECAY_TIME	Decay time

Weighting factors for acceleration-dependent adaptation of the maximum values

Table 9-1 Lower reversal point

Machine data	Description
MD32582 \$MA_FRICT_ADAPT_V_STEP_PLUS[0 ... 9]	Weighting factor for the amplitude
MD32584 \$MA_FRICT_ADAPT_V_CONST_PLUS[0 ... 9]	Weighting factor for the action time
MD32586 \$MA_FRICT_ADAPT_V_DECAY_PLUS[0 ... 9]	Weighting factor for the decay time

Table 9-2 Upper reversal point

Machine data	Description
MD32583 \$MA_FRICT_ADAPT_V_STEP_MINUS[0 ... 9]	Weighting factor for the amplitude
MD32585 \$MA_FRICT_ADAPT_V_CONST_MINUS[0 ... 9]	Weighting factor for the action time
MD32587 \$MA_FRICT_ADAPT_V_DECAY_MINUS[0 ... 9]	Weighting factor for the decay time

Calculation of the characteristic parameters

The commissioning engineer must determine the optimum values for amplitude, action time, and decay time for the velocity setpoint pulse for different acceleration values during the circularity test (Page 315). On completion of the circularity test, the control will calculate the resulting characteristic parameters (maximum values, characteristic interpolation points, and weighting factors) and write them into the corresponding machine data.

Example: Amplitude characteristic for the lower reversal point

- Maximum value

MD32571

$$\text{\$MA_FRICT_VELO_STEP} = \max\{\text{Amplitude 1, Amplitude 2 ... Amplitude 9}\}$$

- Weighting factors

MD32582

$$\text{\$MA_FRICT_ADAPT_V_STEP_PLUS}[n] = \frac{\text{Amplitude}[n]}{\text{MD32571 } \text{\$MA_FRICT_VELO_STEP}}$$

- Effective interpolation points

The effective interpolation points of the amplitude characteristics are the interpolation points to which the following applies:

- MD32581 $\text{\$MA_FRICT_ADAPT_TABLE_ACCEL}[\text{ <interpolation point>}] \neq 0$ (acceleration)
- MD32582 $\text{\$MA_FRICT_ADAPT_V_STEP_PLUS}[\text{ <interpolation point>}] \neq 0$ (weighting factor)

The amplitude of the velocity setpoint pulse of an effective interpolation point is calculated as:

$$\begin{aligned} \text{Amplitude}[n] &= \text{Maximum value} * \text{weighting factor}[n] = \\ &\text{MD32571 } \text{\$MA_FRICT_VELO_STEP} * \\ &\text{MD32582 } \text{\$MA_FRICT_ADAPT_V_STEP_PLUS}[n] \end{aligned}$$

Note

Vertical offset of a characteristic

Subsequent vertical displacement of a characteristics is most easily achieved by changing the corresponding maximum value in the machine data.

9.10.2.5 Torque setpoint pulse

Determination of the characteristic parameters for the torque setpoint pulses and calculation of the corresponding machine data is not supported directly by the user interface. We therefore advise determining the characteristic parameters or writing the machine data manually

Axis-specific machine data

Torque setpoint pulse




Figure 9-30 Basic pulse shape

The numbers (①, ②, ...) stated in the following tables refer to the figure above.

Acceleration-independent parameters

No.	Machine data	Description
①	-	Trigger time or acceleration of the axes from stand-still
③	MD32577 \$MA_FRICT_T_PULSE_DELAY_TIME	Delay time
④	MD32578 \$MA_FRICT_T_PULSE_SMOOTH_TIME	Rise time

Maximum values of the acceleration-dependently adaptable amplitude

No.	Machine data	Description
②	MD32576 \$MA_FRICT_TORQUE_STEP	Amplitude

Weighting factors for acceleration-dependent adaptation of the maximum value

Machine data	Description
MD32588 \$MA_FRICT_ADAPT_T_STEP[0 ... 9]	Weighting factor for the amplitude

Commissioning (manual)

Requirement

The circularity test (Page 315) for determining the characteristic parameter was already been successfully performed completely or at least for the current measuring step.

Note

Determining the characteristic parameters

- The characteristic parameters for the torque setpoint pulse are most simply determined in the circularity test (Page 315) of the user interface:
- Operating area: "Commissioning" > "NC" > "**Friction compensation**"
- The machine data are most simply set via the data list of the circularity test:
Operating area: "Commissioning" > "NC" > "Friction compensation" > "**Data list**" vertical softkey

Assumption

The circularity tests has been started, measuring step 1 is active.

Recommended procedure

1. Initialization of the weighting factors:
 - MD32588 \$MA_FRICT_ADAPT_T_STEP[0] = 1
 - MD32588 \$MA_FRICT_ADAPT_T_STEP[1 ... 9] = 0

Note: For all measuring steps, the weighting factor with index 0 is used.
2. Setting the amplitude for the current measuring step:
 - MD32576 \$MA_FRICT_TORQUE_STEP = <amplitude>
3. Determining the changed contour deviation in the circle diagram.
4. Optimization of the amplitude value by changing in MD32576 \$MA_FRICT_TORQUE_STEP and checking in the circle diagram.
5. Recording the amplitude value for this measuring step for subsequent determination of the maximum value or the weighting factor of the measuring step.
6. Switching on to the next measuring step and continuing with point 2 until the amplitude values have been determined for all measuring steps.
7. Determining the maximum value from the recorded amplitude values and entering them in the machine data:

$$\text{MD32576 \$MA_FRICT_TORQUE_STEP} = \max\{\text{Amplitude 1, Amplitude 2 ... Amplitude 9}\}$$
8. Calculation of the weighting factors for all active interpolation points from the recorded amplitude values and entering them in the machine data:

$$\text{MD32588 \$MA_FRICT_ADAPT_T_STEP[n]} = \frac{\text{Amplitude[n]}}{\text{MD32576 \$MA_FRICT_TORQUE_STEP}}$$

That completes commissioning of the amplitude characteristic for the torque setpoint pulse.

Optional

Setting the parameters that are independent of acceleration:

- MD32577 \$MA_FRICT_T_PULSE_DELAY_TIME
- MD32578 \$MA_FRICT_T_PULSE_SMOOTH_TIME

Effective interpolation points

The effective interpolation points of the amplitude characteristics are the interpolation points to which the following applies:

- MD32581 \$MA_FRICT_ADAPT_TABLE_ACCEL[<interpolation point>] $\neq 0$ (acceleration)
- MD32583 \$MA_FRICT_ADAPT_T_STEP[<interpolation point>] $\neq 0$ (weighting factor)

The amplitude of the torque setpoint pulse of an effective interpolation point is calculated as:

Amplitude[n] = Maximum value * weighting factor[n] =

$$\begin{array}{cc} \text{MD32576} & \text{MD32588} \\ \$MA_FRICT_TORQUE_STEP & * \$MA_FRICT_ADAPT_T_STEP[n] \end{array}$$

Note

Vertical offset of the characteristic

Subsequent vertical displacement of the amplitude characteristic is most easily achieved by changing the corresponding maximum value in the machine data.

9.11 Compensation functions for suspended axes

9.11.1 Electronic counterweight

Axis without counterweight

For axes that have a weight load without counterweight, then after the brake is released, the hanging (suspended) axis drops and the following response is obtained:




Figure 9-31 Drop of a hanging axis without counterweight

"Electronic counterweight" function

A hanging (suspended) axis can almost be completely prevented from dropping (sagging) using the "electronic counterweight" function.

The electronic counterweight prevents axes with a weight load from sagging when the closed-loop control is switched on. After releasing the brake, the constant counterweight torque maintains the position of the vertical axis.




Figure 9-32 Lowering of a vertical axis with electronic weight compensation

Commissioning

Note

The "electronic counterweight" is commissioned through the drive!

Further information

For additional information, see the following:

Function Manual Drive Functions SINAMICS S120

9.11.2 Special function: Reboot delay

Function

For changes, for example, to machine data values to become effective, the NC must be restarted. This is done, for example, on the user interface by triggering an NC reset. If there are suspended axes on the machine, failure of the closed-loop control while the control is starting will result in the axes failing to maintain height.

With the "Reboot delay" function, the request to reboot the NC (NC reset) is communicated to the NC via the operator interface as previously. Rebooting, during which the closed-loop control of the axes is deactivated, is then delayed on the NC by a time that can be parameterized. During

this time, user-specific actions, such as engaging the holding brakes of the suspended axes, are performed.

Note

The reboot delay is only effective on a request to reboot the NC (NC reset) via the **user interface**.

In the case of a power-on reset by switching the control off and on again, pressing the reset button on the front of the NCU, or power failure, a parameterized reboot delay time will have no effect.

Alarm 2900 "Reboot after a delay"

When a reboot request is detected, alarm 2900 "Reboot after a delay" is triggered.

Alarm responses

The following responses are triggered by the alarm 2900:

- The NC/PLC interface signals are reset:
 - DB11 DBX6.3 = 0 (mode group ready); all mode groups
 - DB21, ... DBX36.5 = 0 (channel ready) for **all** channels
 - DB31, ... DBX61.2 = 0 (axis ready) for **all** axes
- Braking the axis / spindles at the current limit.
For further details, see machine data:
 - MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)
 - MD36620 \$MA_SERVO_DISABLE_DELAY_TIME (OFF delay of the controller enable)

The NC/PLC interface signal "NC ready" remains set:

DB10 DBX108.7 == 1

Alarm suppression

With the machine data, **display** of the alarm 2900 "Reboot after a delay" will be suppressed on the user interface:

MD11410 \$MN_SUPPRESS_ALARM_MASKBit 20 = 1

The alarm responses are not affected by this.

Controlling holding brakes

During the reboot operation of the PLC, the PLC outputs defined as 0 are reset. Control of the holding brakes must therefore be connected on the user side in such a way that the brakes engage or remain engaged on a control signal == 0 and are released or remain released on a control signal == 1.

Parameter assignment

The reboot delay time is set in machine data:

MD10088 \$MN_REBOOT_DELAY_TIME = <reboot delay time>

If the parameterized reboot delay time is 0.0, the function is deactivated.

System variables

The time remaining until the NC is rebooted can be read in the system variable:

`$AN_REBOOT_DELAY_TIME`

While no request for a reboot of the NC (NC reset) has been triggered from the user interface, the system variable has the value 0.0.

A value greater than 0.0 indicates that a reboot request (NC reset) has been triggered from the user interface and also the time remaining in the NC or PLC until the reboot.

Application example

Evaluating the system variables in a static synchronized action

Condition part: Check for a value greater than 0.0 because then a request for a reboot of the NC (NC reset) has been made from the user interface.

Action part: e.g. triggering "safe standstill" as part of the "Safety Integrated" function.

9.12 Data lists

9.12.1 Machine data

9.12.1.1 General machine data

Number	Identifier: \$MN_	Description
10050	SYSCLOCK_CYCLE_TIME	Basic system clock cycle
10070	IPO_SYSCLOCK_TIME_RATIO	Factor for interpolator clock cycle
10082	CTRLOUT_LEAD_TIME	Shift of setpoint transfer time
10083	CTRLOUT_LEAD_TIME_MAX	Maximum permissible setting for shift of setpoint transfer time
10088	REBOOT_DELAY_TIME	Reboot delay
18342	MM_CEC_MAX_POINTS[t]	Maximum number of interpolation points of sag compensation

9.12.1.2 Channelspecific machine data

Number	Identifier: \$MC_	Description
20150	GCODE_RESET_VALUES	Reset G groups

9.12.1.3 Axis/spindlespecific machine data

Number	Identifier: \$MA_	Description
32450	BACKLASH	Backlash
32452	BACKLASH_FACTOR	Weighting factor for backlash
32454	BACKLASH_MODE	Backlash compensation mode
32456	BACKLASH_DYN	Compensation value for the dynamic backlash compensation
32457	BACKLASH_DYN_MAX_VELO	Limitation of the dynamic backlash compensation value change
32490	FRICT_COMP_MODE	Type of friction compensation
32500	FRICT_COMP_ENABLE	Friction compensation active
32510	FRICT_COMP_ADAPT_ENABLE	Friction compensation adaptation active
32520	FRICT_COMP_CONST_MAX	Maximum friction compensation value
32530	FRICT_COMP_CONST_MIN	Minimum friction compensation value
32540	FRICT_COMP_TIME	Friction compensation time constant
32550	FRICT_COMP_ACCEL1	Adaptation acceleration value 1
32560	FRICT_COMP_ACCEL2	Adaptation acceleration value 2
32570	FRICT_COMP_ACCEL3	Adaptation acceleration value 3
32610	VELO_FFW_WEIGHT	Feedforward control factor for velocity/speed feedforward control
32620	FFW_MODE	Feedforward control mode
32630	FFW_ACTIVATION_MODE	Activate feedforward control from program
32650	AX_INERTIA	Inertia for torque feedforward control
32700	ENC_COMP_ENABLE	Interpolatory compensation
32710	CEC_ENABLE	Enabling of sag compensation
32711	CEC_SCALING_SYSTEM_METRIC	System of units for sag compensation
32720	CEC_MAX_SUM	Maximum compensation value for sag compensation
32730	CEC_MAX_VELO	Change of velocity during sag compensation
32750	TEMP_COMP_TYPE	Temperature compensation type
32760	COMP_ADD_VELO_FACTOR	Velocity increase as a result of compensation
32711	CEC_SCALING_SYSTEM_METRIC	System of units for sag compensation
32800	EQUIV_CURRCTRL_TIME	Equivalent time constant current control loop for feedforward control
32810	EQUIV_SPEEDCTRL_TIME	Equivalent time constant speed control loop for feedforward control
32910	DYN_MATCH_TIME	Time constant for dynamic response adaptation
36500	ENC_CHANGE_TOL	Maximum tolerance for position actual value switchover
37302	NOCO_FILTER_TIME	Time constant for smoothing nodding compensation values
37310	NOCO_INPUT_AX_1	Compensation relationship 1: Machine axis that causes nodding motion

Number	Identifier: \$MA_	Description
37312	NOCO_ADAPT_AX_1	Compensation relationship 1: Machine axis, whose position influences nodding motion
37314	NOCO_ADAPT_NUM_1	Compensation relationship 1: Number of positions, adaptation characteristic of the nodding compensation
37316	NOCO_ADAPT_POS_1	Compensation relationship 1: Positions, adaptation characteristic of the nodding compensation
37318	NOCO_COMPLIANCE_1	Compensation relationship 1: Compliance factor for nodding compensation
37320	NOCO_INPUT_AX_2	Compensation relationship 2: Machine axis that causes nodding motion
37322	NOCO_ADAPT_AX_2	Compensation relationship 2: Machine axis, whose position influences nodding motion
37324	NOCO_ADAPT_NUM_2	Compensation relationship 2: Number of positions, adaptation characteristic of the nodding compensation
37326	NOCO_ADAPT_POS_2	Compensation relationship 2: Positions, adaptation characteristic of the nodding compensation
37328	NOCO_COMPLIANCE_2	Compensation relationship 2: Compliance factor for nodding compensation
37330	NOCO_INPUT_AX_3	Compensation relationship 3: Machine axis that causes nodding motion
37332	NOCO_ADAPT_AX_3	Compensation relationship 3: Machine axis, whose position influences nodding motion
37334	NOCO_ADAPT_NUM_3	Compensation relationship 3: Number of positions, adaptation characteristic of the nodding compensation
37336	NOCO_ADAPT_POS_3	Compensation relationship 3: Positions, adaptation characteristic of the nodding compensation
37338	NOCO_COMPLIANCE_3	Compensation relationship 3: Compliance factor for nodding compensation
38000	MM_ENC_COMP_MAX_POINTS	Number of interpolation points with interpolatory compensation

9.12.2 Setting data

9.12.2.1 General setting data

Number	Identifier: \$SN_	Description
41300	CEC_TABLE_ENABLE[t]	Enable evaluation of beam sag compensation table
41310	CEC_TABLE_WEIGHT[t]	Weighting factor for beam sag compensation table

9.12.2.2 Axis/spindle-specific setting data

Number	Identifier: \$SA_	Description
43900	TEMP_COMP_ABS_VALUE	Position-independent temperature compensation value
43910	TEMP_COMP_SLOPE	Gradient for position-dependent temperature compensation
43920	TEMP_COMP_REF_POSITION	Reference position for position-dependent temperature compensation

Appendix

A.1 List of abbreviations

A	
A	Output
ASCII	American Standard Code for Information Interchange: American coding standard for the exchange of information
ASIC	Application Specific Integrated Circuit: User switching circuit
ASUP	Asynchronous subprogram
AUTO	Operating mode "Automatic"
AUXFU	Auxiliary Function: Auxiliary function
AWL	Statement List

B	
BAG	Mode group
BCD	Binary Coded Decimals: Decimal numbers encoded in binary code
BICO	Binector Connector
BIN	Binary Files: Binary files
BKS	Basic Coordinate System
BM	Operating alarm
BO	Binector Output
BTSS	Operator Panel Interface

C	
CLC	Clearance control
CNC	Computerized Numerical Control: Computerunterstützte numerische Steuerung
COM	Communication
CP	Communication Processor
CPU	Central Processing Unit: Central processing unit
CST	Configured Stop: Configured stop

D	
DB	Data Block (PLC)
DBB	Data Block Byte (PLC)
DBD	Data Block Double word (PLC)
DBW	Data Block Word (PLC)
DBX	Data block bit (PLC)
DDS	Drive Data Set: Drive data set

D	
DIR	Directory: Directory
DO	Drive Object
DRF	Differential Resolver Function: Differential revolver function (handwheel)
DRY	Dry Run: Dry run feedrate
DW	Data Word
DWORD	Double Word (currently 32 bits)

E	
E	Input
EES	Execution from External Storage
E/A	Input/Output
ESR	Extended Stop and Retract
ETC	ETC key ">"; Softkey bar extension in the same menu

F	
FB	Function Block (PLC)
FC	Function Call: Function Block (PLC)
FDD	Feed Disable: Feed disable
FdStop	Feed Stop: Feed stop
FIFO	First In First Out: Memory that works without address specification and whose data is read in the same order in which they was stored
FM	Error message
FUP	Function Block Diagram (PLC programming method)
FW	Firmware

G	
GEO	Geometry, e.g. geometry axis
GP	Basic program (PLC)
GUD	Global User Data: Global user data

H	
HEX	Abbreviation for hexadecimal number
HiFu	Auxiliary function
HMI	Human Machine Interface: SINUMERIK user interface
HSA	Main Spindle Drive
HT	Handheld Terminal
HW	Hardware

I	
IBN	Commissioning
INC	Increment: Increment
INI	Initializing Data: Initializing data
IPO	Interpolator

J	
JOG	Jogging: Setup mode

K	
KOP	Ladder Diagram (PLC programming method)

L	
LED	Light Emitting Diode: Light-emitting diode
LMS	Position Measuring System
LR	Position controller

M	
Main	Main program: Main program (OB1, PLC)
MCP	Machine Control Panel: Machine control panel
MD	Machine Data
MDA	Manual Data Automatic: Manual input
MDS	Motor Data Set: Motor data set
MELDW	Message Word
MKS	Machine Coordinate System
MM	Motor Module
MPF	Main Program File: Main program (NC)
MPI	Multi Point Interface
MSTT	Machine control panel

N	
NC	Numerical Control: Numerical control with block preparation, traversing range, etc.
NCU	Numerical Control Unit: NC hardware unit
NCK	Numerical Control Kernel
NCSD	NC Start Disable
NST	Interface Signal
NV	Work offset
NX	Numerical Extension: Axis expansion board

O	
OB	Organization block in the PLC
OEM	Original Equipment Manufacturer
OP	Operation Panel: Operating equipment

P	
PCU	PC Unit: PC box (computer unit)
PG	Programming device
PLC	Programmable Logic Control: Adaptation control
PN	PROFINET
PO	Power On
POS	Position/positioning
PPO	Parameter Process data Object: Cyclic data telegram for PROFIBUS DP transmission and "Variable speed drives" profile
PPU	Panel Processing Unit (central hardware for a panel-based CNC, e.g. SINUMERIK 828D)
PROFIBUS	Process Field Bus: Serial data bus
PRT	Program Test
PTP	Point to Point: Point-To-Point
PZD	Process data: Process data part of a PPO

R	
REF	REference point approach function
REPOS	REPOSition function
RESU	Retrace support
RID	Read In Disable
RP	R Parameter, arithmetic parameter, predefined user variable

S	
SA	Synchronized Action
SBL	Single Block: Single block
SBT	Safe Brake Test
SCC	Safety Control Channel
SCL	Structured Control Language
SD	Settingdatum or setting data
SDI	Safe Direction
SERUPRO	Search-Run by Program Test: Block search, program test
SIC	Safety Info Channel
SKP	Skip: Function for skipping a part program block
SLP	Safe Limited Position
SLS	Safely Limited Speed
SMI	Sensor Module Integrated

S	
SOS	Safe Operating Stop
SPF	Sub Program File: Subprogram (NC)
SS1	Safe Stop 1
SS2	Safe Stop 2
STO	Safe Torque Off
STW	Control word
SUG	Grinding Wheel Peripheral Speed
SW	Software

T	
TCU	Thin Client Unit
TM	Terminal Module (SINAMICS)
TO	Tool Offset: Tool offset
TOA	Tool Offset Active: Identifier (file type) for tool offsets
TOFF	Online tool length offset
TRANSMIT	Transform Milling Into Turning: Coordination transformation for milling operations on a lathe

U	
UP	Subprogram
USB	Universal Serial Bus

V	
VDI	Internal communication interface between NC and PLC

W	
WKS	Workpiece Coordinate System
WPD	Work Piece Directory: Workpiece directory
WZ	Tool
WZV	Tool Management

Z	
ZSW	Status word (of drive)

A.2 Documentation overview

You will find extensive documentation on the functions of SINUMERIK 840D sl from version 4.8 SP4 at 840D sl documentation overview (<https://support.industry.siemens.com/cs/ww/en/view/109766213>).



You can display the documents or download them in PDF or HTML5 format.

The documentation is divided into the following categories:

- User: Operating
- User: Programming
- Manufacturer/Service: Functions
- Manufacturer/Service: Hardware
- Manufacturer/Service: Configuration/Setup
- Manufacturer/Service: Safety Integrated
- Manufacturer/Service: SINUMERIK Integrate/MindApp
- Information and training
- Manufacturer/Service: SINAMICS

Index

\$

\$AA_COLLPOS, 83
\$AA_DTBREB, 84
\$AA_DTBREB_CMD, 84
\$AA_DTBREB_CORR, 84
\$AA_DTBREB_DEP, 84
\$AA_DTBREM, 84
\$AA_DTBREM_CMD, 84
\$AA_DTBREM_CORR, 85
\$AA_DTBREM_DEP, 85
\$AA_ENC_COMP, 249
\$AA_ENC_COMP_IS_MODULO, 249
\$AA_ENC_COMP_MAX, 248
\$AA_ENC_COMP_MIN, 248
\$AA_ENC_COMP_STEP, 248
\$AC_COLLPOS, 83
\$AN_ACTIVATE_COLL_CHECK, 83
\$AN_CEC, 255
\$AN_CEC_DIRECTION, 257
\$AN_CEC_INPUT_AXIS, 256
\$AN_CEC_INPUT_NCU, 257
\$AN_CEC_IS_MODULO, 258
\$AN_CEC_MAX, 257
\$AN_CEC_MIN, 257
\$AN_CEC_MULT_BY_TABLE, 258
\$AN_CEC_OUTPUT_AXIS, 256
\$AN_CEC_STEP, 256
\$AN_COLL_CHECK_OFF, 83
\$AN_COLL_IPO_ACTIVE, 83
\$AN_COLL_IPO_LIMIT, 83
\$AN_COLL_LOAD, 83
\$AN_COLL_MEM_AVAILABLE, 83
\$AN_COLL_MEM_USE_ACT, 84
\$AN_COLL_MEM_USE_MAX, 84
\$AN_COLL_MEM_USE_MIN, 83
\$AN_COLL_STATE, 83
\$AN_COLL_STATE_COND, 83
\$AN_REBOOT_DELAY_TIME, 328
\$NP_1ST_PROT, 31
\$NP_BIT_NO, 35
\$NP_CHAIN_ELEM, 29
\$NP_COLL_PAIR, 60, 80
\$NP_COLOR, 44
\$NP_D_LEVEL, 45
\$NP_DIR, 59
\$NP_FILENAME, 53
\$NP_INDEX, 37

\$NP_INIT_STAT, 34, 36
\$NP_NAME, 40
\$NP_NEXT, 41
\$NP_NEXTP, 42
\$NP_OFF, 57
\$NP_PARA, 56
\$NP_PROT_COLOR, 33
\$NP_PROT_D_LEVEL, 34
\$NP_PROT_NAME, 28
\$NP_PROT_TYPE, 30
\$NP_SAFETY_DIST, 81
\$NP_TYPE, 51
\$NP_USAGE, 46
\$P_WORKAREA_CS_COORD_SYSTEM, 181
\$SC_PA_ACTIV_IMMED, 111, 123
\$SC_PA_CENT_ABS, 112
\$SC_PA_CENT_ORD, 112
\$SC_PA_CONT_ABS, 112
\$SC_PA_CONT_NUM, 112
\$SC_PA_CONT_ORD, 112
\$SC_PA_CONT_TYP, 112
\$SC_PA_LIM_3DIM, 112
\$SC_PA_MINUS_LIM, 112
\$SC_PA_ORI, 112
\$SC_PA_PLUS_LIM, 112
\$SC_PA_T_W, 112
\$SN_PA_ACTIV_IMMED, 111, 123
\$SN_PA_CENT_ABS, 112
\$SN_PA_CENT_ORD, 112
\$SN_PA_CONT_ABS, 112
\$SN_PA_CONT_NUM, 112
\$SN_PA_CONT_ORD, 112
\$SN_PA_CONT_TYP, 112
\$SN_PA_LIM_3DIM, 112
\$SN_PA_MINUS_LIM, 112
\$SN_PA_ORI, 112
\$SN_PA_PLUS_LIM, 112
\$SN_PA_T_W, 112
\$VA_ABSOLUTE_ENC_DELTA_INIT, 172
\$VA_ENC_ZERO_MON_ERR_CNT, 169, 172

A

Accelerating axis, 234
Adaptation axis, 234
axis
 Basic, 244
 Compensation, 244

Axis monitoring functions

- Actual velocity, 165
- Boundary conditions, 206
- Following error, 150
- Speed setpoint, 163
- Zero speed, 154

B

Backlash, 228

- Compensation, dynamic, 229
- Dynamic, 229

C

Collision avoidance

- Fundamentals example, 90

Collision pairs, 80

Collision tolerance, 67

COLLPAIR, 85

Compensating axis, 234

Compensation

- Following error, 295
- Interpolating, 244
- Leadscrew error, 246
- Measuring system error, 246

Compensation value, 234

Compliance factor, 234

Contour accuracy

- Programmable, 214

Contour error, 149

Contour tunnel

- radius, 213

CPRECOF, 216

CPRECON, 216

CPROT, 120

CPROTDEF, 117

CTOL, 216

D

DB10

- DBX226.0 - DBX233.7, 34
- DBX234.0 - DBX241.7, 34

DB10 DBX108.7, 327

DB11

- DBX6.3, 327

DB21, ...

- DBX1.1, 136
- DBX10.0 - DBX11.1, 114
- DBX272.0 - DBX273.1, 113

DBX274.0 - DBX275.1, 113

DBX276.0 - DBX277.1, 115, 134

DBX278.0 - DBX279.1, 115, 134

DBX39.0, 114

DBX8.0 - DBX9.1, 114

DB21, ... DBB4, 160

DB21, ...

DBX36.5, 327

DB31, ...

DBX1.4, 163

DBX1.5, 167, 186

DBX1.6, 167, 186

DBX102.0, 230

DBX102.5, 186, 189

DBX102.6, 186, 189

DBX12.0, 173

DBX12.1, 173

DBX12.2, 174

DBX12.3, 174

DBX2.1, 186, 187

DBX2.3, 162

DBX21.0-4, 205

DBX21.5, 205

DBX21.6, 205

DBX21.7, 205

DBX25.0, 230

DBX39.0, 134, 137

DBX60.2, 168

DBX60.3, 168

DBX60.4, 186

DBX60.4/5, 221

DBX60.5, 186

DBX60.6, 154, 163

DBX60.7, 154, 163

DBX64.6, 154

DBX64.7, 154

DB31, ... DBX60.4 - 5, 229

DB31, ... DBX1.4, 163

DB31, ... DBX102.3, 155, 156, 157

DB31, ... DBX2.3, 155, 156

DB31, ... DBX61.3, 157

DB31, ... DBX64.6, 157, 158, 160

DB31, ...

DBX61.2, 327

Deformation

- due to temperature effects, 220

Dynamic backlash, 229

Dynamic response

- adaptation, 300

E

Encoder monitoring functions, 167
 Encoder frequency, 167
 Error
 Leadscrew, 246
 Measuring system, 246
 -temperature compensation curves, 220

F

Feedforward control, 295
 Speed, 297
 Torque, 298
 Following error, 295

G

G25, 178
 G26, 178

H

Hardware limit switch, 173
 HHH"; "UUU, 156

I

Interpolation point, 244

L

LEC, 246
 Limit-switch monitoring, 173
 Linear signal distortions, 149

M

MD10088, 327
 MD10200, 312
 MD10210, 312
 MD10240, 253
 MD10260, 249, 253
 MD10618, 116
 MD10619, 77
 MD10622, 77
 MD10710, 180
 MD11410, 327

MD16900, 107
 MD16901, 108
 MD16902, 108
 MD16903, 108
 MD18190, 116
 MD18890, 25, 78
 MD18892, 26, 78
 MD18893, 26
 MD18894, 26, 78
 MD18895, 26, 78
 MD18896, 78
 MD18897, 26
 MD18898, 78
 MD18899, 27
 MD20110, 217
 MD20112, 217
 MD20150, 180
 MD20390, 223
 MD20470, 215
 MD21020, 177
 MD21050, 213
 MD21060, 213
 MD21070, 214
 MD28200, 116
 MD28210, 116
 MD28212, 116
 MD28600, 181
 MD30260, 205
 MD30270, 205
 MD30310, 175
 MD31020, 205
 MD31025, 205
 MD31030, 206
 MD31046, 189
 MD31050, 206
 MD31060, 206
 MD31070, 206
 MD31080, 206
 MD31700, 205
 MD31710, 205
 MD31720, 205
 MD31730, 205
 MD32000, 150
 MD32200, 150, 153
 MD32250, 206
 MD32260, 206
 MD32300, 150, 156
 MD32402, 150
 MD32410, 150
 MD32415, 216
 MD32450, 228
 MD32452, 228

MD32454, 229
MD32456, 230
MD32457, 231
MD32490, 306, 312
MD32500, 306, 307, 312
MD32510, 306, 312
MD32520, 307, 312
MD32530, 312
MD32540, 307
MD32550, 312
MD32560, 312
MD32570, 312
MD32610, 150, 297
MD32620, 150, 295
MD32630, 296
MD32650, 299
MD32700, 245, 247, 256, 259
MD32710, 245, 252, 256
MD32711, 253, 254
MD32720, 254
MD32730, 254
MD32750, 223, 225, 309, 313
MD32760, 223
MD32800, 150, 299
MD32810, 150, 206, 297
MD32900, 301
MD32910, 150, 300
MD32960, 232
MD34210, 229
MD36010, 153
MD36012, 155
MD36020, 153
MD36030, 154, 155
MD36040, 154
MD36050, 155, 162
MD36051, 155
MD36052, 156, 157, 158, 160, 161, 162
MD36100, 174
MD36110, 174
MD36120, 174
MD36130, 174
MD36200, 165
MD36210, 163
MD36220, 164
MD36300, 167
MD36310, 166, 168
MD36312, 169
MD36400, 150
MD36500, 213
MD36600, 173
MD36610, 151, 153, 154, 156, 164, 165, 168, 170, 327

MD36620, 327
MD38000, 247
MD38020, 215
MD51160, 79
MD51161, 79
MD51162, 79
MSEC, 246
Multiplication
 Table, 252

N

Non-linear signal distortions, 149
NPROT, 120
NPROTDEF, 117

P

Parking, 186
PROTA, 86
PROTD, 88
Protection zones, 109, 117
 Restrictions, 137
PROTS, 87

S

Safety clearance, 67
SD41300, 252
SD42450, 216
SD42460, 216
SD43400, 179
SD43410, 179
SD43420, 178
SD43430, 178
SD43900, 223
SD43910, 223
SD43920, 223, 225
Setup
 Collision avoidance, 65
Signal distortions, 149
Software limit switch, 174
States
 Protection areas, 66
Switching over the encoder data set, 204

T

table
 Compensation, 244

Temperature
 -compensation, 220
 -influence, 220
Temperature compensation
 Coefficient $\tan\beta(T)$, 225
Time constant
 Dynamic response adaptation, 300

W

WALCS0, 182
WALIMOF, 179
WALIMON, 179
Working area limitation, 176
 in BCS, 178
 in WCS/SZS, 180
Working area limitation group, 180

Z

Zero mark diagnostics, 169

