

SIEMENS

SINUMERIK

SINUMERIK 840D sl, SINAMICS S120 IBN CNC: NCK, PLC, drive

Commissioning Manual

Valid for

Control
SINUMERIK 840D sl / 840DE sl
Drive
SINAMICS S120

Software
CNC software for 840D sl/840DE sl

Version
4.4

09/2011

6FC5397-2AP40-2BA0

Preface	
Introduction	1
Safety information	2
Requirements for commissioning	3
Example configuration	4
Power on and boot up	5
Connect PG/PC with the PLC	6
PLC commissioning	7
Commissioning integrated drives (NCU)	8
Commissioning communication NCK<->Drive	9
NCK start-up	10
Optimize the drive	11
Drive optimization using SINUMERIK Operate	12
Commissioning external drives	13
Data backup and standard commissioning	14
File functions	15
Tips for commissioning SINAMICS drives	16
Licensing	17
Cycle protection	18
New installation/upgrading	19
General tips	20
Fundamentals	21
Appendix	A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.
CAUTION
without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.
NOTICE
indicates that an unintended result or situation can occur if the corresponding information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation for the specific task, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be adhered to. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

SINUMERIK documentation

The SINUMERIK documentation is organized in the following categories:

- General documentation
- User documentation
- Manufacturer/service documentation

Additional information

You can find information on the following topics at www.siemens.com/motioncontrol/docu:

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following address:

docu.motioncontrol@siemens.com

My Documentation Manager (MDM)

Under the following link you will find information to individually compile OEM-specific machine documentation based on the Siemens content:

www.siemens.com/mdm

Training

For information about the range of training courses, refer under:

- www.siemens.com/sitrain
SITRAIN - Siemens training for products, systems and solutions in automation technology
- www.siemens.com/sinustrain
SinuTrain - training software for SINUMERIK

FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support. <http://support.automation.siemens.com>

SINUMERIK

You can find information on SINUMERIK under the following link:

www.siemens.com/sinumerik

Target group

This document is designed for machine tool manufacturers. The document provides detailed information for commissioning engineers that they require to commission the SINUMERIK Operate software.

Standard scope

This documentation describes the functionality of the standard scope. Extensions or changes made by the machine manufacturer are documented by the machine manufacturer.

Other functions not described in this documentation might be executable in the control. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of servicing.

Furthermore, for the sake of clarity, this documentation does not contain all detailed information about all types of the product and cannot cover every conceivable case of installation, operation or maintenance.

Technical Support

You will find telephone numbers for other countries for technical support in the Internet under <http://www.siemens.com/automation/service&support>

EC Declaration of Conformity

The EC Declaration of Conformity for the EMC Directive can be found on the Internet at:

<http://support.automation.siemens.com>

Here, enter the number **15257461** as the search term or contact your local Siemens office.

Table of contents

	Preface	3
1	Introduction.....	13
	1.1 Commissioning manuals for SINUMERIK 840D sl	13
	1.2 Principle representation of SINUMERIK 840D sl components for commissioning.....	15
	1.3 Initial commissioning procedure.....	19
2	Safety information.....	21
	2.1 Danger notices	21
	2.2 ESD notices	23
3	Requirements for commissioning.....	25
	3.1 General prerequisites.....	25
	3.2 Hardware and software preconditions	27
	3.3 Communication interfaces and terminal assignment.....	29
	3.3.1 Communication interfaces	29
	3.3.2 Terminal assignment of the digital inputs/outputs.....	31
	3.3.2.1 NCU 7x0.2 and NCU 7x0.3.....	31
	3.3.2.2 NX 1x.1 and NX 1x.3	34
	3.3.3 Support for terminal assignment at the HMI	35
	3.4 Start-up tool on PG/PC	36
4	Example configuration	37
5	Power on and boot up.....	39
	5.1 Operating and display elements for run-up.....	39
	5.2 NCK and PLC general reset	43
	5.3 Boot completed	45
6	Connect PG/PC with the PLC.....	47
	6.1 Start SIMATIC Manager.....	47
	6.2 Setting up the communication.....	48
7	PLC commissioning	49
	7.1 Creating a SIMATIC S7 project.....	49
	7.1.1 Creating a project.....	50
	7.1.2 Inserting a SIMATIC station 300.....	50
	7.1.3 Insert NCU 7x0 in HW config.....	52
	7.1.4 Configuring the properties of the network interfaces	54
	7.1.5 Insert NX in HW Config.....	58
	7.1.6 End hardware configuration and load to the PLC.....	61
	7.2 Creating a PLC program	62

7.2.1	Insert PLC basic program	62
7.2.2	Modifying Ethernet machine control panel in OB100.....	64
7.3	Loading the project to the PLC	65
7.4	Configuring an Ethernet machine control panel.....	67
7.5	First commissioning of the PLC completed.....	67
8	Commissioning integrated drives (NCU).....	69
8.1	Guided commissioning of SINAMICS drives.....	70
8.1.1	Triggering a reset (warm restart) for NCK and drive system	70
8.1.2	Automatic device configuration	73
8.1.3	Parameterization of infeed	76
8.1.4	Parameterization of the drives	82
8.1.4.1	Commissioning of listed motor and encoder via SMC	83
8.1.4.2	Commissioning of third-party motor and additional second encoder via SMC	90
8.1.5	First commissioning of SINAMICS drive ended	98
8.2	Manual commissioning of SINAMICS drives	98
8.2.1	Introduction to commissioning of SINAMICS drives	99
8.2.2	Activate the factory settings	100
8.2.3	Updating the component firmware	103
8.2.4	Automatic device configuration	106
8.2.5	Commissioning using a drive wizard.....	111
9	Commissioning communication NCK<->Drive	113
9.1	Configuration input/output address and telegram.....	115
9.2	Configuration setpoint/actual value.....	116
9.3	Commissioning communication NCK<->Drive completed.....	119
10	NCK start-up.....	121
10.1	Overview Commissioning NCK.....	121
10.2	System data	121
10.2.1	Resolutions	121
10.2.2	Normalization of phys. units of machine data and setting data	124
10.2.3	Modifying scaling machine data.....	128
10.2.4	Loading default machine data	129
10.2.5	Switching over the measuring system	130
10.2.6	Traversing ranges	132
10.2.7	Positioning accuracy of the control system.....	132
10.2.8	Cycle times.....	133
10.2.9	NCK utilization.....	137
10.2.10	Velocities.....	139
10.3	Memory configuration.....	141
10.4	Parameter sets of axis/spindle.....	143
10.5	Parameterize axis data	145
10.5.1	Incremental measuring system settings.....	145
10.5.2	Parameterization of absolute measuring systems	149
10.5.3	DSC (Dynamic Servo Control)	151
10.5.4	Rotary axes	153

10.5.5	Positioning axes	155
10.5.6	Indexed axes/"Hirth" axes	156
10.5.7	Position controller	158
10.5.8	Speed setpoint matching	163
10.5.9	Drift compensation	165
10.5.10	Velocity matching (axis)	166
10.5.11	Axis monitoring.....	169
10.5.12	Axis homing.....	178
10.5.12.1	Incremental measuring system.....	179
10.5.12.2	Distance-coded reference marks.....	182
10.5.12.3	Absolute encoders	185
10.5.12.4	Interface signals and machine data	188
10.6	Parameterization of spindle data	190
10.6.1	Setpoint/actual value channels of spindle.....	190
10.6.2	Gear stages.....	191
10.6.3	Spindle measuring systems	192
10.6.4	Speeds and setpoint adjustment for spindle	194
10.6.5	Position spindle	197
10.6.6	Synchronizing spindle	199
10.6.7	Spindle monitoring	201
10.6.8	Spindle data	204
10.7	Application example	208
10.7.1	Advanced Surface (AS)	208
10.7.2	Preconditions, G code.....	208
10.7.3	Preconditions, machine data.....	211
11	Optimize the drive.....	215
11.1	Measuring functions	217
11.2	Frequency response measurements	220
11.2.1	Current control loop measurement	220
11.2.2	Speed control loop measurement.....	222
11.2.3	Position control loop measurement	225
11.3	Circularity test measurement	231
11.4	Trace	234
11.4.1	Trace overview.....	234
11.4.2	Servo trace.....	235
11.4.3	Drive trace.....	238
11.5	Further optimization options.....	241
12	Drive optimization using SINUMERIK Operate	243
12.1	Automatic servo optimization	243
12.2	Overview of navigation.....	245
12.3	Setting options	246
12.4	General operating sequences for automatic servo optimization.....	248
12.5	Setting the user-specific strategy.....	255
12.6	Additional optimization stages - commissioning interpolation axes.....	256

13	Commissioning external drives	257
13.1	Introduction (PLC drive <-> NC drive).....	257
13.2	Commissioning PLC drives	262
13.2.1	Example configuration.....	262
13.2.2	Principle procedure when commissioning.....	264
13.2.3	PLC commissioning	264
13.2.4	Generate PLC user program.....	273
13.2.5	Commissioning external drives	276
13.2.6	Commissioning communication NCK<->Drive.....	278
13.3	Configuring safety functions for external drives	280
13.3.1	Configuration with SIMATIC Manager under HW Config.....	280
13.3.2	Embedding in safe programmable logic (SPL) based on the example of an SPL of SINUMERIK 840D sl	283
13.3.3	Configuration of test cases with SinuCom NC SI-ATW that must go through an acceptance procedure.....	284
14	Data backup and standard commissioning	289
14.1	Data backup	290
14.2	User data backup/Series commissioning.....	291
14.3	Preassignments when saving PLC data	292
14.4	Series commissioning	294
15	File functions	297
15.1	Introduction	297
15.2	File functions for SINAMICS parameters	298
15.2.1	Overview	298
15.2.2	Data backup of SINAMICS parameters	298
15.2.3	Loading/copying the SINAMICS parameter file	300
15.2.4	Editing the SINAMICS parameter file.....	302
15.3	Copying data from one HMI to another.....	303
15.3.1	Overview	303
15.3.2	Copying machine data	304
15.3.3	Copying SINAMICS parameters	305
16	Tips for commissioning SINAMICS drives	309
16.1	Changing topology (modular machine)	310
16.1.1	Adding components	311
16.1.2	"Topology" > "Change..." menu	319
16.1.2.1	Changing entry into topology	319
16.1.2.2	Deleting drive objects.....	321
16.1.2.3	Deleting components	322
16.1.2.4	Enabling/disabling drive object	324
16.1.2.5	Changing drive object/component names/numbers	326
16.1.3	Replacing SINAMICS S120 components.....	327
16.1.4	Display options.....	330
16.1.5	Sorting the topology display	332
16.1.6	Check topology	334
16.2	Drive diagnostics.....	335

16.3	Diagnostics for pending alarms.....	337
16.4	Drive (SERVO) parameter RESET, individual	338
16.5	Firmware version display of drive components.....	339
16.6	Checking/setting power supply data settings.....	341
16.7	Identification/Optimization "ALM > Infeed/Configuration"	342
16.8	Configuring motor data sets.....	343
17	Licensing	351
17.1	Import licensing terms.....	351
17.2	Overview	352
17.3	Web License Manager	353
17.4	Automation License Manager	353
17.5	License database	353
17.6	CF Card and hardware serial numbers.....	355
17.7	SINUMERIK License Key	356
17.8	Assigning via Web License Manager.....	356
17.8.1	You can execute an assignment via direct access as follows	356
17.8.2	You can execute an assignment via customer login as follows.....	358
17.9	Assigning via Automation License Manager.....	360
17.9.1	Function Overview	360
17.9.2	Installing the Automation License Manager.....	361
17.9.3	Enabling/disabling SINUMERIK plug-ins	362
17.9.4	Assigning parameters to the TCP/IP communication with a control system	363
17.9.5	How to refresh the navigation view: "Manage"	366
17.9.6	Displaying the license information of a piece of hardware	367
17.9.7	Creating a control image (offline).....	368
17.9.8	Performing a license requirement alignment for a piece of hardware	370
17.9.9	Transferring license information for a control image (offline) to a control system (online)	372
17.10	Internet links.....	373
18	Cycle protection.....	375
18.1	Overview, cycle protection	375
18.2	Sequence	376
18.2.1	Overview, cycle protection sequence	376
18.2.2	Preprocessing	376
18.2.3	File extensions for encrypted cycles	377
18.2.4	Handling encrypted cycles in the control	377
18.2.5	Subprogram calls without extension	378
18.2.6	Subprogram calls with extensions	378
18.2.7	NC language commands with absolute path data	379
18.2.8	Actual block display	379
18.2.9	Basic block display.....	379
18.2.10	Version display.....	379
18.2.11	Simulation	379

18.3	General conditions	380
18.4	Notes	381
19	New installation/upgrading.....	383
19.1	Classic.....	383
19.1.1	Introduction	383
19.1.2	Installing "NCU Service System" on a USB-FlashDrive	384
19.1.2.1	Installing "NCU Service System" on the USB-FlashDrive via DOS-Shell.....	384
19.1.2.2	Installing "NCU Service System" on a USB-FlashDrive via RCS-Commander	385
19.1.3	New installation	385
19.1.3.1	Automatic installation of the CNC software using USB-FlashDrive	386
19.1.3.2	Installation of the CNC software using USB-FlashDrive	387
19.1.3.3	Installation of the CNC software using WinSCP on PC/PG.....	390
19.1.3.4	Installation of the CNC software using VNC Viewer on PC/PG	391
19.1.4	Upgrading.....	392
19.1.4.1	Backup/Restore.....	393
19.1.4.2	Automatic upgrade of the CNC software using USB-FlashDrive	396
19.1.4.3	Upgrading the CNC software using USB-FlashDrive	397
19.1.4.4	Upgrading the CNC software using WinSCP on PC/PG	400
19.1.4.5	Upgrading the CNC software using VNC Viewer on PC/PG	401
19.2	With SinuCom Installer (SCI)	402
19.2.1	Software preconditions and fundamentals on the content of this chapter "New installation/upgrade with SinuCom Installer".....	402
19.2.2	Automatic new installation with SinuCom Installer (SCI)	403
19.2.3	Automatic upgrade with SinuCom Installer (SCI).....	408
20	General tips	413
20.1	Configuration of the properties of the network interface for PROFIBUS	413
20.2	Separate NCK and PLC general reset.....	416
20.2.1	NCK general reset.....	416
20.2.2	PLC general reset	416
20.3	Configuring the communication between the PLC and the drive.....	419
20.4	Integrating PG/PC into the network (NetPro).....	421
20.4.1	Integrating PG/PC into NetPro.....	422
20.4.2	PG/PC interface configuration	424
20.4.3	Assigning interfaces	427
20.4.4	Loading the HW config to NCU.....	430
20.5	Overview - Assignment of SINAMICS and NCK machine data for communication via PROFIBUS	431
20.6	Drive-object assignment for PROFIBUS connection	433
20.7	PROFIBUS machine control panel on the HMI.....	436
20.7.1	Configuration of the properties of the network interface for PROFIBUS	436
20.7.2	Load GSD file (contains machine control panel)	439
20.7.3	Adding a machine control panel and handwheel in HW Config.....	439
20.7.4	Modifying PROFIBUS machine control panel in OB100.....	442
21	Fundamentals.....	443
21.1	Basic information on SINAMICS S120.....	443

21.1.1	Rules for wiring the DRIVE-CLiQ interface	443
21.1.2	Drive Objects (DO's) and Drive components	445
21.1.3	BICO interconnection	447
21.2	Transfer telegrams	448
21.2.1	Structure of the telegram with the process data for SINUMERIK 840D sl.....	451
21.2.2	Process data for receiving and sending.....	452
21.3	Control- and status-word bits for NCK<->drive communication	454
21.3.1	NCK to drive.....	454
21.3.2	Drive to NCK	457
21.4	PLC program.....	460
21.4.1	Fundamentals of creating a PLC user program.....	463
21.5	Machine and setting data.....	464
21.5.1	Machine data fundamentals.....	465
21.5.2	Handling the machine data	467
21.6	Protection levels.....	468
21.6.1	Protection level fundamentals.....	470
21.7	Axis data	471
21.7.1	Axis assignment.....	473
21.7.2	Drive assignment	476
21.7.3	Axis names.....	478
21.7.4	Setpoint/actual value channels	479
21.8	Spindle data	482
21.8.1	Spindle modes	483
21.8.2	Initial spindle state	483
21.8.3	General functionality	484
A	Appendix.....	489
A.1	Abbreviations	489
A.2	Overview	492
	Glossary	493
	Index.....	499

Introduction

1.1 Commissioning manuals for SINUMERIK 840D sl

Introduction

The commissioning manuals for SINUMERIK 840D sl are divided into:

- IBN CNC: NCK, PLC, drive
- Base software and HMI-Advanced
- Base software and operating software
- CNC: ShopMill
- CNC: ShopTurn

Basic steps for commissioning SINUMERIK 840D sl

Commissioning a SINUMERIK 840D sl is performed in 2 basic steps:

1. Step 1 (described in "IBN CNC: NCK, PLC, Drive")
 - PLC commissioning
 - Drive commissioning
 - NCK commissioning
2. Step 2 (described in "Base software and HMI-Advanced", "Base software and operating software", "CNC: ShopMill", "CNC: ShopTurn")
 - Commissioning functions in NCK/PLC

References

The SINUMERIK Safety Integrated Function Manual describes commissioning for SINUMERIK 840D sl/SINAMICS S120 Safety Integrated.

Commissioning overview

The following figure is a schematic representation of the commissioning steps that are described in the first step (1) and in step (2):




Figure 1-1 Commissioning overview

1.2 Principle representation of SINUMERIK 840D sl components for commissioning

Introduction

In principle, an NCU 7x0 contains the following components:

- HMI
- NCK
- PLC
- Drive
- CP

The HMI contained in the NCU is designated as **internal HMI** or as HMI-Embedded/ShopMill/ShopTurn/SINUMERIK Operate.

In addition, a PCU 50.3 can be connected to each NCU, on which the HMI-Advanced then runs (additional optional ShopMill/ShopTurn, SINUMERIK Operate). This HMI is then designated as **external HMI**.

For commissioning, the HMI Advanced Software is required or the commissioning tool derived from it.

A PG/PC with SIMATIC STEP7 Version 5.5 is required to commission the PLC.

A network switch is required to connect several communication partners to plug X120.

Commissioning components for internal HMI's

Commissioning of an internal HMI requires a PG/PC. This PG/PC is connected via Ethernet to socket X120.

The internal HMI displays its user interface via TCU (Thin Client Unit), which is connected via the Ethernet machine control panel (e.g. MCP 310) to socket X120.

Commissioning components for external HMI's

External HMIs are connected to socket X120.

A PC/PG is required for commissioning of the PLC of the external HMI. This PG/PC is connected via Ethernet to socket X127.

Note

To use the external HMI (PCU 50.3) without TCU, the internal HMI must be switched off.

Commissioning NCU 7x0 with internal HMI

The following figure illustrates an example of a hardware and software arrangement for the commissioning of an NCU 7x0 with internal HMI.




Figure 1-2 Principle representation SINUMERIK 840D sl

1.2 Principle representation of SINUMERIK 840D sl components for commissioning

Commissioning NCU 7x0 with external HMI

The following figure illustrates an example of a hardware and software arrangement for the commissioning of an NCU 7x0 with PCU 50.3 with external HMI.




Figure 1-3 Principle representation of SINUMERIK 840D sl with PCU 50.3

Schematic representation of the NCU 7x0

The following figure is a schematic representation of the NCU 7x0:




Figure 1-4 Schematic representation of NCU 7x0

1.3 Initial commissioning procedure

Introduction

The mechanical and electrical installation of the system must be completed.

The following is important when starting commissioning:

- The control with its components boots error-free.
- The EMC guidelines were carefully maintained when configuring the system.

Commissioning options depending on the CNC software on the CompactFlash Card

When commissioning the system for the first time, the following dependencies to the CNC software on the CompactFlash Card are considered:

- CompactFlash Card with the current CNC software.
- CompactFlash Card without CNC software.
- CompactFlash Card with older CNC software.

Commissioning steps

The commissioning steps depending on the CNC software on the CompactFlash Card are listed in the following table. The order is recommended but not mandatory:

Table 1- 1 Commissioning steps

Commissioning steps	With current CNC software (First commissioning)	Without CNC software (Reinstallation and first commissioning)	With older CNC software (upgrade)	See chapter
Install the CNC software on the CompactFlash Card using one of the following media: <ul style="list-style-type: none"> • Bootable USB-FlashDrive • WinSCP on PC/PG • VNC viewer on PC/PG Note: A USB-FlashDrive with installed "NCU Service System" is called a bootable USB-FlashDrive.		1.		Automatic installation of the CNC software using USB-FlashDrive (Page 386) Installation of the CNC software using WinSCP on PC/PG (Page 390) Installation of the CNC software using VNC Viewer on PC/PG (Page 391)
Archive the NCK, PLC, HMI and drive data			1.	Data backup (Page 290)

1.3 Initial commissioning procedure

Commissioning steps	With current CNC software (First commissioning)	Without CNC software (Reinstallation and first commissioning)	With older CNC software (upgrade)	See chapter
Upgrade the CNC software using one of the following media: <ul style="list-style-type: none"> • Bootable USB-FlashDrive • WinSCP on PC/PG • VNC viewer on PC/PG 			2.	Automatic upgrade of the CNC software using USB-FlashDrive (Page 396) Upgrading the CNC software using WinSCP on PC/PG (Page 400) Upgrading the CNC software using VNC Viewer on PC/PG (Page 401)
Load archived NCK, PLC, HMI and drive data			3.	
Boot the SINUMERIK 840D sl with NCK/PLC general reset	1.	2.		NCK and PLC general reset (Page 43)
Making a communication connection to the PLC	2.	3.		Setting up the communication (Page 48)
PLC commissioning	3.	4.		Creating a SIMATIC S7 project (Page 49)
Commission the SINAMICS drive system	4.	5.		Commissioning integrated drives (NCU) (Page 69)
Commissioning communication NCK<->Drive	5.	6.		Commissioning communication NCK<->Drive (Page 113)
NCK commissioning <ul style="list-style-type: none"> • Assigning NCK machine data for communication • Scaling machine data • Parameterizing axis data • Parameterizing spindle data • Parameterizing the measuring systems 	6.	7.		Overview Commissioning NCK (Page 121)
Drive Optimization	7.	8.		Optimize the drive. (Page 215)

See also

New installation/upgrading (Page 383)

Safety information

2.1 Danger notices

The following notices are intended firstly for your personal safety and secondly to prevent damage occurring to the product described or any connected devices and machines. Non-observance of the warnings can result in severe personal injury or property damage.

 DANGER
<p>Only appropriately qualified personnel may commission/start-up SINUMERIK equipment.</p> <p>The personnel must take into account the information provided in the technical customer documentation for the product, and be familiar with and observe the specified danger and warning notices.</p> <p>When electrical equipment and motors are operated, the electrical circuits automatically conduct a dangerous voltage.</p> <p>When the system is operating, dangerous axis movements may occur throughout the entire work area.</p> <p>A potential fire hazard exists due to the energy being transferred in the equipment and the work materials used.</p> <p>All work on the electrical system must be performed after the system has been switched off and disconnected from the power supply.</p>

 DANGER
<p>Proper transportation, expert storage, installation and mounting, as well as careful operation and maintenance are essential for this SINUMERIK device to operate correctly and reliably.</p> <p>The details in the catalogs and proposals also apply to the design of special equipment versions.</p> <p>In addition to the danger and warning information provided in the technical customer documentation, the applicable national, local, and system-specific regulations and requirements must be taken into account.</p> <p>Only protective extra-low voltages (PELVs) that comply with EN 61800-5-1 can be connected to all connections and terminals between 0 and 48 V.</p> <p>Should it be necessary to test or take measurements on live equipment, then the specifications and procedural instructions defined in Accident Prevention Regulation BGV A2 must be adhered to, in particular § 8 "Permissible deviations when working on live components". Suitable electric tools should be used.</p>

 **WARNING**

Power cables and signal lines should be installed in such a way that inductive and capacitive interference does not in any way impair the automation and safety functions.

 **WARNING**

Repairs to devices that have been supplied by our company may only be carried out by Siemens customer service or by repair centers authorized by Siemens. When replacing parts or components, only use those parts that are included in the spare parts list.

Before opening the device, always disconnect the power supply.

Emergency stop/off devices which comply with EN 60204 / IEC 60204 (VDE 0113-1) must remain effective in all automation equipment operating modes. The act of releasing the emergency stop/off device must not cause an uncontrolled or undefined hot restart.

Additional external measures must be taken, or devices must be created that enforce a safe operational state even when there is a fault (e.g. using independent limit value switches, mechanical locks, etc.) at any location in the automation equipment where faults might cause major material damage or even physical injury, in other words, where faults could be dangerous.

2.2 ESD notices

CAUTION

The modules contain electrostatically sensitive devices. Discharge yourself of electrostatic energy before touching the components. The easiest way to do this is to touch a conductive, grounded object immediately beforehand (for example, bare metal parts of control cabinet or the protective ground contact of a socket outlet).

NOTICE

Handling ESD-modules:

- When handling electrostatically sensitive devices, make sure that operator, workplace and packing material are properly grounded.
- Generally, electronic modules must not be touched unless work has to be carried out on them. When handling PCBs make absolutely sure that you do not touch component pins or printed conductors.
- Touch components only if:
 - You are permanently grounded via an ESD armband
 - You are wearing ESD shoes or ESD shoe-grounding-strips, if ESD flooring is available
- Modules may only be placed on electrically conductive surfaces (table with ESD top, conductive ESD foam plastic, ESD packaging bags, ESD transport containers).
- Keep modules away from visual display units, monitors or TV sets (minimum distance from screen 10 cm).
- Do not bring ESD-sensitive modules into contact with chargeable and highly-insulating materials, such as plastic, insulating table tops or clothing made of synthetic materials.
- Measurements on modules are allowed only if:
 - The measuring instrument is properly earthed (e.g., protective conductor) or
 - Before measuring with a floating measuring instrument, the probe is briefly discharged (e.g., touch the bare metal parts of the control housing).

Requirements for commissioning

3.1 General prerequisites

General

All components are dimensioned for defined mechanical, climatic and electrical environmental conditions. No limit value may be exceeded, neither during operation, nor during transportation.

Limit values

In particular, the following must be observed:

- Power supply conditions
- Pollution burden
- Function-impairing gases
- Ambient environmental conditions
- Storage/transport
- Shock stressing
- Vibration stressing
- Ambient temperature

Prerequisites for components involved

The complete system is connected mechanically and electrically, and has been verified in the following points:

- When handling the components, all ESD measures are observed.
- All screws are tightened with their prescribed torque.
- All connectors are plugged correctly and locked/screwed.
- All components are grounded and connected to shields.
- The load capacity of the central power supply is taken into account.

Literature

- All information about the structure of SINAMICS S120 drive components are contained in:
SINAMICS S120 Equipment Manual
- You can find all the instructions on how to connect the Ethernet interface here:
Equipment Manual NCU
- To initialize an Ethernet, see also:
HMI commissioning; TCU commissioning

3.2 Hardware and software preconditions

Preconditions

For the commissioning of SINUMERIK 840D sl, the following points are required:

- Hardware prerequisites
 - CompactFlash Card with CNC software for internal HMI, NCK, PLC and drive inserted in NCU
 - Dual ventilator fan/battery module (MLFB 6FC5348-0AA02-0AA0) to NCU (see following figure)




Figure 3-1 Dual fan/battery module

Note

Please dispose of used batteries in the specially provided collection points on site. This will ensure they are reused in the correct manner or treated as special waste.

- Connection to NCU
 - Network switch or hub to socket X120
 - Ethernet connection of PG/PC to socket X120 or socket X127 when commissioning the HMI PLC external
 - Ethernet machine control panel to socket X120
 - Ethernet connection from TCU for internal HMI internal to Ethernet machine control panel or
 - Ethernet connection from PCU 50.3 for HMI external to Ethernet machine control panel

3.2 Hardware and software preconditions

- Software prerequisites
 - SIMATIC STEP 7 Version 5.5 to PG/PC (SIMATIC Manager)
 - STEP7 package for NCU7x0 on PG/PC (Toolbox)
 - GSD file (Toolbox)
 - CompactFlash Card with CNC software for internal HMI, NCK, PLC and drive
 - External HMI on PCU 50.3 or commissioning tool on PG/PC for the commissioning of internal HMI

Note

The order numbers of the SINAMICS drives, motors and encoders should be at hand. These are used for parameterization.

3.3 Communication interfaces and terminal assignment

3.3.1 Communication interfaces

Introduction

The following diagrams show the interfaces on the NCU that can be used for communication with the components involved in the commissioning phase. They are:

- X120 Ethernet interface for TCU and/or PCU (a network switch or hub enables expansion)
- X130 Ethernet interface for factory network
- for PG/PC
 - currently X120 Ethernet interface, internal for HMI
 - X127 Ethernet interface, external for HMI (PLC commissioning)
- X126 PROFIBUS interface for machine control panel, for example




Figure 3-2 Interfaces on the NCU 7x0.2 for commissioning




Figure 3-3 Interfaces on the NCU 7x0.3 for commissioning

Network configuration characteristics

For the individual, participating components that are connected with the NCU, the following properties are available for the network configuration.

Table 3- 1 Network configuration

Component	socket	Which network?	IP address	Subnet ID
TCU/PCU 50.3 and currently PC/PG for commissioning of internal HMI	X120	Ethernet	192.168.214.1	255.255.255.0
Factory network	X130	Ethernet	Assigned by DHCP server, for example 10.10.255.200	
PG/PC for commissioning of PLC external HMI	X127	Ethernet	192.168.215.1 or DHCP Server	255.255.255.248

3.3.2 Terminal assignment of the digital inputs/outputs

3.3.2.1 NCU 7x0.2 and NCU 7x0.3

Terminal assignment according to the device configuration

With the SINAMICS device configuration (Page 73) the following terminals are preassigned:

- NCU 7x0.2
 - X122
 - X132
- NCU 7x0.3
 - X122
 - X132
 - X142

Note

The terminal assignments of the NCU 7x0.2 and NCU 7x0.3 are different.

When changing over from NCU 7x0.2 to NCU 7x0.3, the terminal wiring must be adapted.

See also SINUMERIK 840D sl NCU manual

For terminal blocks X122, X132 and X142 of the NCUs, the table lists the terminal assignments.

In the column "pre-assigned", the signals for which the HMI sets the associated SINAMICS parameters when configuring a SINAMICS device are marked with "x".

NCU 7x0.2 Terminal	NCU 7x0.3 Terminal	Function	Signal	Pre- assigned
X122 terminal strip				
X122.1	X122.1	DI 0	Input ON/OFF1 infeed (if one infeed with a DRIVE-CLiQ connection is operated at the NCU)	x
			Input infeed operation – "infeed ready signal" (if no infeed with DRIVE-CLiQ connection is operated at the NCU)	x
X122.2	X122.2	DI 1	Input 2nd operating condition OFF3 drives "OFF3 – rapid stop" Function: Braking with a configurable OFF3 ramp (p1135,1136,1137); thereafter, pulse suppression and starting lockout. The drive stops controlled. The braking response can be set separately for each servo.	x

3.3 Communication interfaces and terminal assignment

NCU 7x0.2 Terminal	NCU 7x0.3 Terminal	Function	Signal	Pre-assigned
X122.3	X122.3	DI 2	Selection safe standstill group 1 SH/SBC - Group 1 SINAMICS Safety Integrated (SH = p9601 release)	-
X122.4	X122.4	DI 3	Selection safe standstill group 2 SH/SBC - Group 2 SINAMICS Safety Integrated (SH = p9601 release)	-
-	X122.5	DI16	Freely available	-
-	X122.6	DI17	Freely available	-
X122.5	-	Ground for terminals 1...4		
-	X122.7	Ground for terminals 1...6		
X122.6	-	Ground for terminals 7, 8, 10, 11		
-	X122.8	Ground for terminals 9, 10, 12, 13		
X122.7	X122.9	DI/DO 8	Status safe standstill group 1 SH/SBC - Group 1 SINAMICS Safety Integrated	-
X122.8	X122.10	DI/DO 9	Status safe standstill group 2 SH/SBC - Group 2 SINAMICS Safety Integrated	-
X122.9	-	Ground for terminals 7, 8, 10, 11		
-	X122.11	Ground for terminals 9, 10, 12, 13		
X122.10	X122.12	DI/DO 10	Input, external zero mark Bero 1 – "equivalent zero mark"	-
X122.11	X122.13	DI/DO 11	Input, probe 1 - central measuring (check that MD13210 = 0!)	x
			Input, probe 1 - distributed measurement (check that MD13210 = 1)	-
X122.12	-	Ground for terminals 7, 8, 10, 11		
-	X122.14	Ground for terminals 9, 10, 12, 13		
Terminal strip X132				
X132.1	-	DI 4	Input \$A_IN[1]	x
-	X132.1		Freely available	-
X132.2	-	DI 5	Input \$A_IN[2]	x
-	X132.2		Freely available	-
X132.3	-	DI 6	Input \$A_IN[3]	x
-	X132.3		Freely available	-
X132.4	-	DI 7	Input \$A_IN[4]	x
	X132.4		Infeed line contactor feedback signal (if one infeed is operated with a DRIVE-CLiQ connection at the NCU)	x
-	X132.5	DI20	Freely available	-
	X132.6	DI21	Freely available	-
X132.5		Ground for terminals 1...4		
-	X132.7	Ground for terminals 1...6		
X132.6		Ground for terminals 7, 8, 10, 11		
-	X132.8	Ground for terminals 9, 10, 12, 13		

3.3 Communication interfaces and terminal assignment

NCU 7x0.2 Terminal	NCU 7x0.3 Terminal	Function	Signal	Pre- assigned
X132.7	-	DI/DO 12	Output \$A_OUT[4]	x
	X132.9		Output: Infeed operation (if one infeed is operated with a DRIVE-CLiQ connection at the NCU)	x
			Input 2nd operating condition OFF2 drives	-
X132.8	-	DI/DO 13	Output \$A_OUT[3]	x
	X132.10		Output: Status, infeed ready to start (if one infeed is operated at the NCU with a DRIVE-CLiQ connection)	x
			Input 2nd operating condition OFF2 drives	-
			Input, external zero mark 2	-
			Input probe 2 - central measurement	-
			Input probe 2 - distributed measurement	-
X132.9	-	Ground for terminals 7, 8, 10, 11		
-	X132.11	Ground for terminals 9, 10, 12, 13		
X132.10	-	DI/DO 14	Output \$A_OUT[2]	x
	X132.12		Input 2nd operating condition OFF2 drives	-
			Input, external zero mark 3	-
			Input probe 2 - central measurement	-
			Input probe 2 - distributed measurement	-
Infeed, control line contactor	-			
X132.11	-	DI/DO 15	Output \$A_OUT[1]	x
	X132.13		Input 2nd operating condition OFF2 drives	-
			Input, external zero mark 4	-
			Input probe 2 - distributed measurement	-
X132.12	-	Ground for terminals 7, 8, 10, 11		
-	X132.14	Ground for terminals 9, 10, 12, 13		
Terminal strip X142				
	X142.3	IN/OUT 0	Input \$A_IN[1]	Fixed
	X142.4	IN/OUT 1	Input \$A_IN[2]	Fixed
	X142.5	Ground for terminals X142.3, 4, 6, 7, 9, 10, 12, 13		
	X142.6	IN/OUT 2	Input \$A_IN[3]	Fixed
	X142.7	IN/OUT 3	Input \$A_IN[4]	Fixed
	X142.8	Ground for terminals X142.3, 4, 6, 7, 9, 10, 12, 13		
	X142.9	IN/OUT 4	Output \$A_OUT[1]	Fixed
	X142.10	IN/OUT 5	Output \$A_OUT[2]	Fixed
	X142.11	Ground for terminals X142.3, 4, 6, 7, 9, 10, 12, 13		
	X142.12	IN/OUT 6	Output \$A_OUT[3]	Fixed
	X142.13	IN/OUT 7	Output \$A_OUT[4]	Fixed
	X142.14	Ground for terminals X142.3, 4, 6, 7, 9, 10, 12, 13		

3.3.2.2 NX 1x.1 and NX 1x.3

Terminal assignment according to the device configuration

With the SINAMICS device configuration (Page 73), the following terminals are preassigned:

- NX1x.1
 - X122
- NX 1x.3
 - X122

For the X122 terminal strip of the the NXes, the table lists the assignments of the terminals.

In the column "pre-assigned", the signals for which the HMI sets the associated SINAMICS parameters when configuring a SINAMICS device are marked with "x".

NX 1x.1 Terminal	NX 1x.3 Terminal	Function	Signal	Pre-assigned
X122.1	X122.1	DI 0	Input ON/OFF1 infeed (if one infeed with a DRIVE-CLiQ connection is operated at the NX)	x
			Input infeed operation - "infeed ready signal" (if no infeed with DRIVE-CLiQ connection is operated at the NX)	x
X122.2	X122.2	DI 1	Input 2nd operating condition OFF3 drives	x
			Freely available (from SINAMICS 2.5 and higher)	x
X122.3	X122.3	DI 2	Selection safe standstill group 1 SH/SBC - Group 1 SINAMICS Safety Integrated (SH = p9601 release)	-
X122.4	X122.4	DI 3	Selection safe standstill group 2 SH/SBC - Group 2 SINAMICS Safety Integrated (SH = p9601 release)	-
-	X122.5			
-	X122.6			
X122.5	-	Ground for terminals 1...4		
-	X122.7	Ground for terminals 1...4?		
X122.6	-	Ground for terminals 7, 8, 10, 11		
-	X122.8	Ground for terminals 9, 10, 12, 13		
X122.7	X122.9	DI/DO 8	Status safe standstill group 1 SH/SBC - Group 1 SINAMICS Safety Integrated	-
X122.8	X122.10	DI/DO 9	Status safe standstill group 2 SH/SBC - Group 2 SINAMICS Safety Integrated	-
X122.9	-	Ground for terminals 7, 8, 10, 11		
-	X122.11	Ground for terminals 9, 10, 12, 13		
X122.10	X122.12	DI/DO 10	Input, external zero mark Bero 1 – "equivalent zero mark"	-

NX 1x.1 Terminal	NX 1x.3 Terminal	Function	Signal	Pre-assigned
X122.11	X122.13	DI/DO 11	Input, external zero mark 2/1	-
			Input 2nd operating condition OFF2 drives	-
X122.12	-	Ground for terminals 7, 8, 10, 11		
-	X122.14	Ground for terminals 9, 10, 12, 13		

3.3.3 Support for terminal assignment at the HMI

Support for terminal assignment at the HMI

In the following menu you can perform terminal assignment for the drive units (NCU, NX) of the associated SINAMICS drive group.

- "Commissioning" > "Drive system" > "Drive units" > "Inputs/outputs" menu

Signal	In/Out	0/1	Terminal	Terminal	0/1	In/Out	Signal
Input IN/OUT1 Infeed	In	0	X122.1	X132.1	0	In	Input \$A_IN[1]
Input 2. OUT3 Drives	In	0	X122.2	X132.2	0	In	Input \$A_IN[2]
?-Select Safe Stop (SH) Group 1	In	0	X122.3	X132.3	0	In	Input \$A_IN[3]
?-Select Safe Stop (SH) Group 2	In	0	X122.4	X132.4	0	In	Input \$A_IN[4]
?-Status of Safe Stop Group 1	In	0	X122.7	X132.7	0	Out	Status Infeed ready to operate
?-Status of Safe Stop Group 2	In	0	X122.8	X132.8	0	Out	Status Infeed supply ready
?-Input external zero mark	In	0	X122.10	X132.10	0	Out	?-Output \$A_OUT[2]
Input Probe 1 (central)	In	0	X122.11	X132.11	0	Out	Output \$A_OUT[1]

Figure 3-4 "Inputs/outputs" menu for terminal assignment

3.4 Start-up tool on PG/PC

Precondition

If a SINUMERIK 840D sl (internal HMI), consisting of TCU, NCU 7x0 and SINAMICS S120 drive components is commissioned, you require the commissioning software "Start-up tool" on the PG/PC.

To commission a system with PG/PC using the start-up tool, the following preconditions apply:

- The start-up tool has been installed on the PG/PC and has been started.
- There is an Ethernet connection to NCU (currently X120).
- Since the standard Ethernet IP address is pre-assigned in the commissioning tool for X120 (192.168.214.1), there are no additional requirements.
- If another Ethernet interface is used, e.g. connected to socket X127, then this must be adapted accordingly in the start-up tool under "Commissioning" > "HMI" > "NCU connection" > "Standard address" (for example, 192.168.215.1 for socket X127).

Example configuration

Overview

The commissioning described in this manual orientates itself on an example configuration of the SINAMICS drive line-up.

The following figure roughly shows the components.

- An NCU 720 with:
 - A Single Motor Module for a motor with SMI (Sensor Module Integrated)
 - A Double Motor Module for two motors each with an SMC 20 (Sensor Module Cabinet)
- An NX 15 with:
 - A Single Motor Module for a motor with two SMC 20 for the encoder
- An infeed (Active Line Module)




Figure 4-1 Example configuration

References

For further available DRIVE-CLiQ components of the SINAMICS drive line-up, see Catalog NC 61, Edition 2007/2008, SINUMERIK & SINAMICS; Order No.: E86060-K4461-A101-A2

Power on and boot up

5.1 Operating and display elements for run-up

Introduction

The diagram below shows the operating and display elements of the NCU, which are important for switch-on and boot of the SINUMERIK 840D sl:

- Various fault and status LEDs
- Status display (seven-segment display)
- RESET button
- NCK commissioning switch
- PLC mode selector switch
- CompactFlash slot

5.1 Operating and display elements for run-up




Figure 5-1 Operating and display elements for commissioning at the NCU 7x0.2 and NCU 7x0.3

Note

When you turn the start-up switch or operating mode switch, then the status display indicates the selected number/letters!

LED display

The following LED displays indicate the states at the NCU 7x0.2 and NCU 7x0.3:

Table 5- 1 Fault and status display

LED NCU 7x0.2	LED NCU 7x0.3	Meaning
RDY (red)	RDY (red)	Watchdog (no NCK Ready)
RDY (yellow)	RDY (orange)	Write/read access to the CompactFlash Card
	RDY (flashing red/orange (0.5 Hz))	Error when accessing the CompactFlash Card
	RDY (flashing orange (0.5 Hz))	Updating the firmware of the connected DRIVE-CLiQ components
	RDY (flashing orange (2 Hz))	Component firmware update has been completed. Wait for POWER ON for the components involved.
	RDY (flashing green/orange or red/orange (1 Hz))	LED-based recognition of connected DRIVE-CLiQ component is activated: (p0124[0] = 1).
RDY (green)	RDY (green)	NCK has powered up and is in cyclic operation
RUN (green)	RUN (green)	PLC ready to operate
	RUN (flashing green/orange or red/orange (1 Hz))	LED-based recognition of connected DRIVE-CLiQ component is activated: (p0124[0] = 1).
STOP (yellow)	STOP (orange)	PLC is in the stop state
SU/PF (yellow)	SU/PF (yellow)	PLC FORCE activated
SF (red)	SF (red)	General PLC error, see diagnostics buffer
DP1 (red)	DP (red)	Error on PROFIBUS (X126)
DP2 (red)	DP/MPI (red)	Error on PROFIBUS (X136)
	PN (red)	PROFINET IO group error (X150)
	SY/MT (green)	<ul style="list-style-type: none"> Synchronization status (SY) of the on-board PROFINET IO interface (X150) Maintenance status (MT) of the NCU (presently without function)
OPT (red)		Error on option module
	OPT (off)	The PROFINET system is running error-free; data exchange to all configured IO devices runs.

LED NCU 7x0.2	LED NCU 7x0.3	Meaning
	OPT (red)	<ul style="list-style-type: none">• Bus fault (no physical connection)• Incorrect data transmission rate
	OPT (red flashing (2 Hz))	<ul style="list-style-type: none">• Failure of a connected I/O device Incorrect or no configuration
All yellow		Power up not possible (CompactFlash Card not inserted or empty)

NCK commissioning switch

The following switch settings are assigned:

- 0 -> NCK in the operating mode
- 1 -> NCK in the initial clear mode (standard MD)
- 7 -> NCK is not started during run-up
- 8 -> Display IP address for the factory network at X130
 - Turn the NCK start-up switch to "8"
 - Trigger RESET.
 - The individual values of the IP address are displayed as individual digits with points to separate the individual values. The last digit does not have a point. The IP address is displayed again after a short delay. In this state, no NCK operation is possible.

PLC mode selector switch

The following switch settings are assigned:

- 0 -> NC in operating mode
- 1 -> NC in operating mode, protected
- 2 -> NC in operating mode
- 3 -> PLC general reset

5.2 NCK and PLC general reset

When commissioning the NCU for the first time, in order to achieve a defined initial state of the whole system, a general NCK and PLC reset must be performed. To do this, carry-out the following actions:

1. Turn the commissioning switch on the front of the NCU to the following positions (see Chapter "Operating and display elements for run-up (Page 39)"):
 - NCK commissioning switch: Switch position "1"
 - PLC commissioning switch: Switch position "3"
2. Initiate a power on reset by switching-off the control and switching-on again – or by pressing the Reset button on the front of the NCU. The NCU is terminated and with the request for a general reset is restarted.

Effect:

- LED "STOP" flashes
- LED "SF" is lit

3. Turn the PLC mode selector switch to position "2" and back again to position "3".

Effect:

- LED "STOP" first flashes with about 2Hz and then changes to a steady light
- "RUN" LED is lit

4. After the LED "STOP" again has a steady light condition, turn the PLC mode selector back to position "0".

Effect:

- LED "STOP" goes dark

5. Turn the NCK mode selector switch back to the "0" position.

The NCU has now been generally reset and is in the following state:

- NCK
 - The user data have been deleted
 - The system data are initialized
 - The standard machine data are loaded
- PLC
 - The user data have been deleted (data and program blocks).
 - The system data blocks (SDB) have been deleted.
 - The buffered data have been written back to the RAM area.
 - The time of day and the operating hours counter have not been reset.
 - The diagnostics buffer and the MPI parameters are reset.
 - General reset puts the PLC in a defined initial state by deleting and initializing all system and user data.

Completion

Then initiate a power on reset again by switching-off the control and switching-on again - or by pressing the Reset button on the front of the NCU.

After an error-free boot, the number "6" and a flashing point are output on the status display (7-segment display) on the front of the NCU. The "RUN" LED lights up. NCK and PLC are in cyclic operation.

Note

PLC general reset

If a general PLC reset is performed using a power on reset, then the user data must again be transferred to the PLC, e.g. via a programming device (PG).

If position "3" is selected for less than three seconds, no general reset is requested. Furthermore, the "STOP" LED remains unlit if the sequence "2" → "3" → "2" is not completed within 3 seconds after requesting a general reset.

Note

In the following cases, a general PLC reset must always be performed:

- Initial commissioning
 - Module replacement
 - Battery failure
 - General reset request via the PLC
 - Upgrading the PLC
-

Note

Since no PLC start is executed after PLC general reset, the following alarms are displayed:

- Alarm: "120201 Communication failed"
- Alarm: "380040 PROFIBUS DP: Configuring error 3, parameter"
- Alarm: "2001 PLC not booted"

These alarms have no influence on the next steps.

See also

NCK general reset (Page 416)

PLC general reset (Page 416)

5.3 Boot completed

Introduction

After an error-free boot of the NCU, it displays the following:

- Number "6" and a flashing point
- LED RUN illuminates GREEN continuously

Run-up has been completed.

In the following step, commissioning of the PLC is done with the SIMATIC Manager.

Connect PG/PC with the PLC

6.1 Start SIMATIC Manager

Introduction

SIMATIC Manager is a GUI for online/offline editing of S7 objects (projects, user programs, blocks, hardware stations and tools).

The SIMATIC Manager lets you

- manage projects and libraries,
- call STEP 7 tools,
- access the PLC online.

Start SIMATIC Manager

After installation, the SIMATIC Manager icon appears on the Windows desktop, and in the Start menu a "SIMATIC Manager" program item appears under "SIMATIC".

1. Run SIMATIC Manager by double-clicking the icon, or from the Start menu (same as with all other Windows applications).

User interface

A corresponding editing tool is started up when you open the relevant objects. The program editor starts by double-clicking on a program block. The block can be processed.

Online help

The online help for the active window is always called by pressing F1.

6.2 Setting up the communication

Introduction

To load the configuration into the PLC, the communications connection (Ethernet) from PG/PC to the PLC required for the loading must be secured.

Operating sequence for establishing a communications connection to the PLC

The communications connection to the PLC may be set from PG/PC via SIMATIC Manager with the following operating sequence:

1. Select menu command: "Extras" > "Set PG/PC interface..."
2. Under the "Access Mode" tab, look for the interface used in the "Interface parameterization used" selection field, for instance:
"TCP/IP -> Realtek RTL8139/810x F..."
3. Confirm the parameterization with "OK".

Note

Parameterization of the PG/PC interface can be performed or changed from the SIMATIC Manager at any time.

PLC commissioning

7.1 Creating a SIMATIC S7 project

Introduction

It is necessary to create an S7 project for the basic commissioning of the PLC, the Ethernet and PROFIBUS communication as well as the input/output data areas of the NCK. To do this, perform the following steps:

- Create a project
- Insert a SIMATIC station 300
- Insert NCU 7x0 in HW Config
- Configure the properties of the network interfaces
- Insert machine control panel and hand wheel

Note

The toolbox must have been installed.

What do you need to be aware of?

Loading the PLC via network interface X130 is also possible if the IP address of the Ethernet interface is known.

Loading an archive may always be carried out if the communication HMI-NCK is available.

Note

Loading the PLC (CP840) is essential for the configuration of the data path for saving/restoring the drive data. See Section "Terminating hardware configuration and loading to PLC" (Page 61)

References

The PLC interface signals are described in "List Manual 2".

7.1.1 Creating a project

Introduction

You have started the SIMATIC Manager.

Operating sequence

1. To create a new project, select the "File" > "New" menu command in the SIMATIC Manager.
2. Enter the following project data in the dialog box:
 - Name (for example: PLC-Erst-IBN 840D sl)
 - Storage location (path)
 - Type
3. Confirm the dialog with "OK".

SIMATIC Manager is opened. The project window is displayed showing an empty S7 project structure.

7.1.2 Inserting a SIMATIC station 300

Introduction

Before you introduce required hardware to the S7 project, the following steps are needed:

- Insert a SIMATIC station 300 in the project
- Starting HW-Config

Operating sequence

1. Select <right mouse button> "Insert new object" > "SIMATIC 300-Station" menu.




Figure 7-1 Inserting a SIMATIC station 300

2. Double-click on the symbol <SIMATIC 300 (1)>.

3. Double-click on the symbol <Hardware>.
The HW config for introducing required hardware is started.
4. In the menu, select "View" > "Catalog". The catalog with the modules is displayed (see following picture).




Figure 7-2 HW-Config

7.1.3 Insert NCU 7x0 in HW config

Introduction

The user interface of "HW Config" mostly displays (see the following figure):

- Station window:

The station window is split. The upper part displays the structure of the station graphically, and the lower part provides a detailed view of the selected module.

- Hardware catalog

In this catalog, the NCU 7X0 that you need for configuring the hardware is also included.

Use the operating sequence described below to insert an NCU 720.1 as an example.

Operating sequence

1. Select "View" > "Catalog".
2. Search for the module in the catalog under "SIMATIC 300" > "SINUMERIK" > "840D sl" > "NCU 720.1" (see following figure).




Figure 7-3 NCU 720.1 in the catalog

3. Select NCU 720.1 with the left mouse button, hold the mouse button down and drag to the "Station design" station window.

After you release the mouse button, configure in the dialog box the interface properties of processor CP 840D sl located on NCU 720.1 (see next chapter).

7.1.4 Configuring the properties of the network interfaces

Introduction

In the STEP7 project, configure the following network interfaces you want to use to reach the NCU 7X0:

- PROFIBUS DP, only with machine control panel for PROFIBUS (see PROFIBUS machine control panel on the HMI (Page 436))
- Ethernet
- integrated PROFIBUS

When creating a new project using the catalog, the configuration of the PROFIBUS interface is called automatically.

PROFIBUS DP operating sequence

1. You used the left mouse button to select NCU 720.1 and while holding down the mouse button you dragged it to the "Station design" station window.
2. After you release the mouse button, configure the properties of PROFIBUS DP interface for socket X126 (machine control panel) in the dialog box (see figure below).




Figure 7-4 Properties of PROFIBUS DP

3. This is an Ethernet machine control panel, which does not require configuration. Select "Cancel".
4. Module NCU 720.1 with SINAMICS S120 is inserted into the HW config (see figure below).

Note

With the <F4> key and confirmation of the question regarding "Reorganize", you can reorganize the display in the station window.




Figure 7-5 HW config with NCU 720.1

Next, specify the properties for the Ethernet interface.

Operating sequence for Ethernet interface

Note

Use socket X127 for commissioning of the PLC for the external HMI. No configuration of the Ethernet interface is required for this. This interface is set with IP address 192.168.215.1 as a default.

For the first commissioning of a HMI with a PG/PC, it is necessary to configure an Ethernet interface. In our example, this involves the interface to socket X120.

1. Double-click on "CP 840D s1" in the basic rack of the NCU 720.1. The dialog "Properties - Ethernet Interface CP 840D s1" is opened (see figure below).




Figure 7-6 General properties of the CP 840D s1

2. After clicking on the "Properties" button, a new Ethernet interface can be created.




Figure 7-7 Properties of the Ethernet interface

The interface for socket X120 is used to commission the internal HMI. You will have to change the IP address.

3. For socket X120, enter the IP address "192.168.214.1" and the Subnet screen form "255.255.255.0".

4. Create the Ethernet interface using "New" and then "OK".
5. Click on "OK" twice.

Next, specify the properties for the integrated PROFIBUS.

Operating sequence for integrated PROFIBUS

The integrated PROFIBUS for communication with the SINAMICS S120 requires a common Subnet ID. This Subnet ID has to be introduced to the external HMI in the MMC.ini.

1. In the station window, click on the bus of the integrated PROFIBUS "PROFIBUS Integrated: DP Master System" and use the right mouse button to select the menu item "Object properties".
2. Click on "Properties" on the "General" tab.

Enter the ID "0046-0010" in field "S7 Sub-network ID".




Figure 7-8 Integrated PROFIBUS subnet ID

3. Click on "OK" twice.

Telegram lengths and I/O addresses

The telegram lengths and input/output addresses for communication between the PLC and the drive (can be viewed via the object properties of the integrated SINAMICS) are pre-assigned by default and do not require any configuration.

As the next step insert a NX component.

See also

Configuring the communication between the PLC and the drive (Page 419)

7.1.5 Insert NX in HW Config

Introduction

A NX component is contained in the example configuration, for the axis to control the spindle. This component must also be inserted in the HW Config when creating the SIMATIC-S7 project.

Operating sequence

1. Look for the NX module (NX10, NX15) in the hardware catalog under "PROFIBUS DP" > "SINAMICS" > "SINUMERIK NX...".
2. Click with the left mouse button to select the "SINUMERIK NX ..." module and drag it to the "PROFIBUS Integrated DP master system" bus in the "Station design" station window.
3. The "DP Slave Properties" dialog box opens.



Figure 7-9 DP Slave Properties for NX15

Enter the address for the integrated PROFIBUS in this dialog.

The default value for the first NX15 is "15".

Note

The NX must be wired to the NCU via the DRIVE-CLiQ. A fixed DRIVE-CLiQ socket is provided for the relevant address.

The following table contains the wiring:

Integrated PROFIBUS address	DRIVE-CLiQ Socket NCU720	DRIVE-CLiQ Socket NCU710
10	X100	X100
11	X101	X101
12	X102	X102
13	X103	X103
14	X104	-
15	X105	-

1. Enter the address and press "OK".




Figure 7-10 Insert NX

2. Confirm the wiring notification with "OK".

3. After releasing the mouse button, the NX module is added (see figure below).




Figure 7-11 NX in HW Config

Note

When deleting and re-inserting NX modules in the hardware config., new slot addresses are issued during addressing. In order to create a clear and transparent configuration that is always the same, we would recommend that addresses are allocated as shown in the following table:

Integrated PROFIBUS address	DRIVE-CLiQ socket, e.g.: NCU720	Start address of first control slot	Start address of last control slot
15	X105	4340	4540
14	X104	4580	4780
13	X103	4820	5020
12	X102	5060	5260
11	X101	5300	5500
10	X100	5540	5740

7.1.6 End hardware configuration and load to the PLC

End hardware configuration and load to the PLC

To end the overall configuration and generate the system data for the PLC, the project must be saved and compiled.

1. Select the menu "Station" > "Save and compile".
2. Click on the button "Load in module", to load the configuration to the PLC.

The "Select target module" dialog mask automatically displays both configured communication partners (see figure below).




Figure 7-12 Selecting target module

3. Confirm with OK to load into these two modules.
4. Confirm the dialog boxes displayed subsequently with "OK" or "No" for the query "...Should the module be started now (restart)?".

Note

You can test the communication interface at "Target system > Diagnosis > Operating mode".

5. Close the "HW config" window.
- The next step is to create the PLC program.

7.2 Creating a PLC program

Introduction

The operating sequence for the creation of a PLC program describe how to create a basic program.

The SIMATIC STEP7 documentation describes how to modify and extend an application program.

7.2.1 Insert PLC basic program

Introduction

You have performed hardware configuration, have saved and compiled the project and have created the system data for the PLC.

You have installed the toolbox software, which also contains the libraries for the PLC basic program of an NCU 7x0.

You are on the main screen of the SIMATIC Manager.

Operating sequence to open library and copy sources, symbols and blocks

1. Select the "File" > "Open" menu and then click on the "Libraries" tab (see figure below).




Figure 7-13 Opening the library

2. Select the library of the basic PLC program, e.g. "bp7x0_44" and confirm the dialog with "OK".

You have inserted the library and selected the PLC program under "PLC-Erst-IBN 840D sl" > "SINUMERIK" > "PLC 317 2DP" > "S7 Program" (see figure below).




Figure 7-14 Copy the PLC program

3. Copy the sources, modules and symbols to the PLC program

Overwriting OB 1

Inserting blocks overwrites the existing organization block OB1. Confirm the query as to whether you want to overwrite the block with "Yes".

You have now created the PLC basic program.

In the next section you will modify some of the data for the machine control panel in OB100.

7.2.2 Modifying Ethernet machine control panel in OB100

Introduction

The PLC basic program automatically transfers the machine control panel signals (MCP signals) and the addresses of the MCP in the HW config if the configuration is set up as laid out below.

Operating sequence

- Under "Blocks", double-click on "OB100" to open it.

In OB100, the parameters below have to be preset:

```
MCPNum := 1
```

```
MCP1IN := P#E 0.0
```

```
MCP1OUT := P#E 0.0
```

```
MCP1StatSend := P#E 8.0
```

```
MCP1StatREc := P#E 12.0
```

MCPBusAddress := 192

MCPBusType = B#16#55

You have completed the configuration of the PLC basic program.

In the next step, you will load the project to the PLC.

7.3 Loading the project to the PLC

Introduction

For loading the configured PLC project, the following prerequisites must be fulfilled:

Precondition

- An Ethernet network connection exists between STEP7 and the PLC.
- The configuration to be loaded corresponds to the actual station configuration.
- NCU 7x0 is active
 - NCK is in cyclic mode
 - PLC in RUN or STOP mode

Supplementary condition

The following supplementary conditions regarding the system data blocks must be observed when the configuration is loaded:

- HW Config

When loading the configuration via HW Config, only the system modules and their associated system data blocks selected in HW Config are loaded into the module. However, global data defined in SDB 210 is not loaded from the HW Config, for example.

You have loaded the HW config to the module in the previous chapter "End hardware configuration and load to the PLC".

- SIMATIC Manager

When loading the configuration via the SIMATIC manager all the system data blocks are loaded into the module.

Note

When the PLC program is loaded in the "RUN" mode, each block loaded becomes active immediately. This can result in inconsistencies when executing the active PLC program. It is therefore advised to place the PLC in the "STOP" mode before loading the configuration, if this has not already been done.

Operating sequence for loading system blocks into the module

1. To load the configuration of the system blocks change to the SIMATIC Manager.
2. In the SIMATIC Manager in the PLC directory, select the directory "Blocks" > right mouse button> "Target system" > "Load" (see figure below), or the "Load" symbol.




Figure 7-15 Loading system blocks

3. If there is no connection to the destination system, you must confirm in sequence the following dialog requests with:
 - "OK" for "Check the required sequence of blocks for correct functioning"
 - "Yes" for "Do you want to load system data?"
 - "Yes" for "Must system data be deleted on the module and replaced by off-line system data?"
 - "No" for "The module is in STOP mode. Do you want to start the module (cold restart)?"

You have loaded the PLC program to the PLC; the PLC is in "STOP" mode.

Note

If the PLC is stopped via the SIMATIC Manager, then it also has to be started via the SIMATIC Manager. Starting via the PLC mode selector is also possible.

7.4 Configuring an Ethernet machine control panel

Note

If you have an Ethernet machine control panel with Ethernet hand wheel, a "7" for "Ethernet" must be entered for the hand wheel in the general machine data MD11350[0] \$MN_HANDWHEEL_SEGMENT.

7.5 First commissioning of the PLC completed

First commissioning of the PLC completed

NOTICE
A reset (warm restart) of the NCK is required for the PLC-NCK synchronization. See Chapter Triggering a reset (warm restart) for NCK and drive system (Page 70)

The PLC and NCK are in the following state after a reset (warm restart):

- LED RUN illuminates GREEN continuously.
- Status display shows a "6" with a flashing point.
⇒ PLC and NCK are in cyclic operation.

You have completed the first commissioning of the PLC.

Continue with the steps for "Guided commissioning" of SINAMICS drives.

You start with Reset (warm restart) for the NCK and drive system.

Commissioning integrated drives (NCU)

The closed-loop drive control for SINAMICS S120 is integrated in the NCU.

You have the following options when commissioning SINAMICS drives:

- Guided commissioning

For "Guided commissioning", you are guided through the configuration / parameterization of the units, infeed(s) and drives (SERVOs).

Note

We recommend that "Guided commissioning" is used when commissioning a drive system for the first time.

Additional commissioning steps are possible using "Manual commissioning".

- Manual commissioning

For "Manual commissioning", you can select the steps of "Guided commissioning" in any sequence.

You perform additional optional functions, which are not part of "Guided commissioning" (e.g. PROFIBUS connection).

Note

"Manually commissioning" is recommended for experienced commissioning engineers.

8.1 Guided commissioning of SINAMICS drives

8.1.1 Triggering a reset (warm restart) for NCK and drive system

Introduction

The HMI has booted. You are in the "Machine" operating area.




Figure 8-1 Machine operating area

In the previous step before loading the project to the PLC (Page 65), this was brought into the stop state. The NCK interprets this STOP state, with corresponding alarm response, as failure of the PLC.

Alarm response



- Press the <MENU SELECT> key and select the menu "Diagnostics > Alarms" menu.

The system may display the following alarms on the HMI (see figure below):

No.	Date	Delete	Text
120201	17/03/2010 13:59:51	[HMI]	Communication failure
2000	17/03/2010 14:00:20	[I]	PLC sign-of-life monitoring
3000	17/03/2010 14:00:20	[X]	Emergency stop
2140	17/03/2010 14:00:36	[X]	The actual service switch position forces the SRAM to be clear (general reset active)
4060	17/03/2010 14:00:36	[X]	Standard machine data loaded (00000101H, 00000003H, 0700)
2001	17/03/2010 14:00:36	[I]	PLC has not started up

Figure 8-2 Diagnostics operating area

A "reset" (warm restart) is required for the PLC-NCK synchronization.

Operating sequence for initiating an NCK reset



1. Press the <MENU SELECT> key and select the "Commissioning" menu.

NCK Index	Name	Type	Drive	Drive Identifier	Motor Type	Channel
1	X1	Lin				CHAN1
2	Y1	Lin				CHAN1
3	Z1	Lin				CHAN1
4	A1	Lin				CHAN1

Current access level: Keyswitch position 0

Figure 8-3 Setting the commissioning operating area without password

2. Press "Password...".
3. Press "Set password".

- 4. Enter the manufacturer's password "SUNRISE".
- 5. Press "OK".




Figure 8-4 Commissioning operating area password set

- 6. Press the "Reset..." softkey.
- 7. Answer the question "Do you want to trigger a reset (warm restart) for the NCK and the entire drive system (all drive units)?" with the "Yes" softkey.

The PLC goes to RUN mode.

Guided commissioning of the SINAMICS drives is then started.

Continue with the steps described in the following chapter.

See also

Drive diagnostics (Page 335)

8.1.2 Automatic device configuration

Operating sequence

You have set the password for manufacturer and initiated a reset (warm restart).

During the warm restart, the HMI displays the following dialog box for several seconds.

Alarm "120 402:...First commissioning of SINAMICS required!" is displayed in the area for alarms.




Figure 8-5 Wait until the drive system has powered-up

Note

When commissioning for the first time, wait until the complete drive system has powered-up!

1. After the complete drive system has powered-up, the HMI displays the following dialog box to automatically configure the devices:




Figure 8-6 Query, automatic device configuration

2. Press "OK".

Note:

If you "Cancel", then you can manually perform the commissioning (see Chapter Manual commissioning of SINAMICS drives (Page 98)).

3. The individual steps for automatic device configuration are displayed one after the other in the following dialog box:




Figure 8-7 Note, SINAMICS is commissioning the device

4. The following dialog box is displayed after the device has been configured:




Figure 8-8 NCK Power On Reset (warm restart)

5. Press "Yes".

The following notes are displayed during the NCK power on reset:

- "Wait for communication with NC"
- "Wait for communication to the drive"
- "Wait until communication is restored"

After the automatic device configuration, the HMI checks which infeeds and drives (SERVOs) still have to be parameterized/commissioned.

Commissioning guides you using the following dialog box to the individual drive objects that have still not been commissioned.




Figure 8-9 NCK power on reset completed

Continue with the steps to parameterize the infeed in the following chapter.

Press "Infeeds".

8.1.3 Parameterization of infeed

Introduction

You have pressed "Infeeds".

You are in the "Commissioning" > "Drive system" > "Infeeds" menu.




Figure 8-10 Menu "Infeed" > "Configuration"

Operating sequence

The system detects that the infeed has not been commissioned and that a commissioning is required (see above figure).

The commissioning is performed with the "Change" vertical softkey.

1. Press the vertical softkey "Change".

The screenshot shows a software interface for configuring a drive. At the top, there is a status bar with 'Start-up', 'CHAN1', 'JOG Ref', and 'MPF0'. Below this, there are several buttons: 'Channel reset', 'Program aborted', and 'ROV'. The main area is titled 'Configuration - Names' and shows 'Supply ALM_3.3:2' and 'DP3 SLAVE3-ALM_3.3:2 (?)'. Under 'Enter the drive object name', there is a text field with 'ALM_3.3:2' and a 'Change' icon. Below that is a checkbox labeled 'Accept the drive object name for the Active Line Module.' Under 'Configuration of the Active Line Module', there is a text field for 'Name of Active Line Modules' with 'Line_module_2' and a label 'Operating type: Netzein / -rückspeisung'. At the bottom, there are 'Abort' and 'Next >' buttons.

Figure 8-11 Menu "Infeed" > "Configuration - names" (Change)

2. If required, assign a drive object name or accept the default settings.
3. Follow the drive wizard with the horizontal softkey "Next >".

- The default values in the following dialogs are standard values and can be taken over with "Next >".




Figure 8-12 Menu "Infeeds > "Configuration" with recognized ALM (Next 1)




Figure 8-13 Menu "Infeed" > "Configuration - additional data" (Next 2)




Figure 8-14 Menu "Infeed" > "Configuration - terminal wiring" (Next 3)




Figure 8-15 Menu "Infeed" > "Configuration - summary" (Next 4)

5. This completes the configuration for the infeed. You can check the configuration in the summary.

6. Press the "Finish >" softkey.




Figure 8-16 Saving a configuration

7. Press "Yes".

The data is saved as non-volatile data.

8. After commissioning the infeed, the HMI checks which drives (SERVOs) still have to be commissioned.

If the HMI finds a drive, then the following dialog box is displayed:




Figure 8-17 Drive still not commissioned

9. Press the "OK" softkey to continue with the steps to commission the drives (see Chapter Parameterization of the drives (Page 82)).

Note

The following block diagram of the infeed is displayed if

- "Cancel" was pressed
- When exclusively using motors with SMI, drives no longer have to be commissioned




Figure 8-18 Menu "Infeed" > "Configuration" > "Finish"

Note

In this case, "Guided commissioning" ends here.

Using "Manual commissioning (Page 98)" you can now perform additional commissioning steps.

See also

Checking/setting power supply data settings (Page 341)

8.1.4 Parameterization of the drives

Introduction

The following components are parameterize/configured with the drive wizard:

- Motor
- Encoder
- Interface signals

Parameterizing/configuring

Guided commissioning navigates you through the commissioning of SINAMICS drives with motors without SMI (Sensor Module Integrated).

For motors without SMI, when parameterizing/configuring, a distinction is made between the following motor types:

- Catalog motors (standard motors, listed with associated motor data) (Page 83)
- Third-party motors (Page 90)

Note

Motors with SMI (DRIVE-CLiQ) are automatically configured by the drive unit during the device configuration with a drive data set (DDS), but only with the motor measuring system; i.e. motors with SMI only have to be configured with the drive wizard when more than one drive/motor data set (DDS/MDS) or a second (direct) measuring system is required.

8.1.4.1 Commissioning of listed motor and encoder via SMC

Introduction

In our example a power section is to be configured with a listed motor and encoder. You are in the "Commissioning" > "Drive system" > "Drives" menu:




Figure 8-19 "Drives" > "Configuration" menu

Operating sequence

1. The system detects that a drive object has not been commissioned and that a new commissioning is required (see above figure).

The new commissioning is performed with the "Change" vertical softkey.

2. Press the vertical softkey "Change".




Figure 8-20 Menu "Drives" > "Configuration - motor module" (Change)

3. The drive wizard identifies the power section (Motor module). You can assign a new drive object name or accept the default setting.
4. Follow the drive wizard with the horizontal softkey "Next >".
5. The following dialog boxes are displayed in succession for the configuration:




Figure 8-21 Menu "Drives" > "Configuration - motor" (Next 1)

6. In this dialog box, select the "Select standard motor from list" button.
7. Select the motor with the "Cursor up / Cursor down" keys.
8. Press "Next >".




Figure 8-22 Menu "Drives" > "Configuration - motor holding brake" (Next 2)

9. You can select brake control in the "Configuration - motor holding brake" dialog. If a connected brake is detected during the unit configuration, the system will automatically activate the brake control and will by default display "Brake control according to procedural control" here.

10. Press "Next >".

Start-up CHAN1 JOG Ref MPF0
Channel reset Program aborted
ROV

...\\Drives\\Configuration - Encoder DP3 SLAVE3:SERVO_3.3:3 (3) MDS0

Which encoder would you like to use? Mask out encoders already assigned to other DOs from the select. list

Encoder SM_12.Encoder_13
Connection of the Sensor Module: SMx module sin/cos: SM_12 (12) X500
 Switch the Sensor Module LED to make it flash for recognition
 Encoder

Connection of the Sensor Module:
 Switch the Sensor Module LED to make it flash for recognition
 Encoder

Connection of the Sensor Module:
 Switch the Sensor Module LED to make it flash for recognition
 Encoder

< Back Abort Next >

Figure 8-23 Menu "Drives" > "Configuration - encoder" (Next 3)

11. Press "Next >".

An identification of the selected encoders is triggered (Encoder 1).

The drive unit can identify encoders with EnDat protocol. These encoders are selected in the encoder list in the follow-up dialog boxes ("Configuration - Encoder 1" menu).

The entry "No encoder" is selected in the encoder list for encoders that the drive unit cannot identify.




Figure 8-24 Selecting an encoder (Next 4)

The encoder connected via SMC20 must be configured.




Figure 8-25 Selecting an encoder from the list

12. Select the motor encoder from the list: Select the encoder with the "Cursor up / Cursor down" keys.

Note

You can specify the following data using the "Details..." function:

- Inversion of the actual speed value
- Inversion of the actual position value
- External zero mark

Alternatively, the encoder system can be parameterized manually using the "Enter data" softkey.

13. Press "Enter data".




Figure 8-26 Enter data

Configure the encoder in the following fields:

- Encoder type
- Incremental tracks
- Zero marks
- Synchronization

14. Press "OK".

15. Press "Next >".




Figure 8-27 Menu "Drives" > "Configuration - control type/setpoints" (Next 5)

16. Set the number of required drive data sets (DDS). The default setting is a drive data set.

17. You can change the settings for the control mode and the PROFIBUS telegram type.

The control mode and the PROFIBUS telegram are generally correctly pre-assigned by the drive wizards.

18. Press "Next >".




Figure 8-28 Menu "Drives" > "Configuration - BiCo interconnection" (Next 6)

19. You can select the 2nd operating condition input 2nd OFF2 (Page 31) (external input for pulse cancellation)

20. Press "Next >".




Figure 8-29 Menu "Drives" > "Configuration - summary" (Next 7)

21. The configuration of the drive (SERVO) with listed motor is completed. You can check the configuration in the summary.

22. Press the "Finish >" softkey.




Figure 8-30 Menu "Drives > Configuration - summary" > "...save permanently..." (Finish)

23. Confirm the query with "Yes".

24. The next section describes how you can configure a drive (SERVO) with a third-party motor and a second encoder.

8.1.4.2 Commissioning of third-party motor and additional second encoder via SMC

Introduction

In our example a power section is to be configured with third-party motor and encoder. You are in the "Commissioning" > "Drive system" > "Drives" menu:




Figure 8-31 Menu "Drives" > "Configuration" (external motor)

Operating sequence

1. The system detects that the drive object has not been commissioned and that a new commissioning is required (see above figure).

The new commissioning is performed with the "Change" vertical softkey.

2. Press the vertical softkey "Change".




Figure 8-32 Menu "Drives" > "Configuration - motor module" (Change)

3. The drive wizard identifies the power section (Motor module). You can assign a new drive object name or accept the default setting.

4. Follow the drive wizard with the horizontal softkey "Next >".
5. The following dialog boxes are displayed in succession for the configuration:

Figure 8-33 Menu "Drives" > "Configuration - motor with externally supplied motor" (Next 1)

6. Select "Enter motor data" and the motor type.
7. Press "Next >".

Figure 8-34 Menu "Drives" > "Configuration - motor holding brake" (Next 2)

8. You can select brake control in the "Configuration - motor holding brake" dialog.
If a connected brake is detected during the unit configuration, the system will automatically activate the brake control and will by default display "Brake control according to procedural control" here.

9. Press "Next >".




Figure 8-35 Menu "Drives" > "Configuration - motor data 2" (Next 3)

10. Use the "Cursor Up/Cursor Down" keys to select the parameters that need to be changed from the list of motor data.

11. Enter the motor data.

12. Press "Next >". If you have activated "Replacement circuit diagram data" and you select "Next >", the following dialog will appear:




Figure 8-36 Menu "Drives" > "Configuration - motor" > "Replacement circuit diagram data" (Next 4)

13. You can enter additional motor data.

14. Press "Next >".

If more than one encoder has been selected (see following figure), then the parameterization is run through for each individual encoder in succession with "Next >".




Figure 8-37 Menu "Drives" > "Configuration - encoder" (Next 5)

15. Press "Next >".

An identification of the selected encoders is triggered (Encoder 1/2).

The drive unit can identify encoders with EnDat protocol. These encoders are selected in the encoder list in the follow-up dialog boxes ("Configuration - Encoder" menu).




Figure 8-38 Menu "Drives > Configuration" "Encoder 1" (Next 6)

The encoder has been identified.

Note

You can specify the following data using the "Details..." function:

- Inversion of the actual speed value
- Inversion of the actual position value
- External zero mark

Alternatively, the encoder system can be parameterized manually using the "Enter data" softkey.

16. Press "Next >".




Figure 8-39 Menu "Drives > Configuration" "Encoder 2" (Next 7)

The second encoder has been identified.

Note

If EnDat encoders are detected, no further encoder parameterization need be performed. Parameterizations for the pole position ID/synchronization can be found at "Enter data".

17. Press "Next >".




Figure 8-40 Menu "Drives > Configuration" "Control type..." (Next 8)

18. Set the number of required drive data sets (DDS). The default setting is a drive data set.

19. You can change the settings for the control mode and the PROFIBUS telegram type.

The control mode and the PROFIBUS telegram are generally correctly pre-assigned by the drive wizards.

20. Press "Next >".




Figure 8-41 Menu "Drives > Configuration" "BICO interconnection" (Next 9)

21. You can select the 2nd operating condition input 2nd OFF2 (Page 31) (external input for pulse cancellation)

22. Press "Next >".




Figure 8-42 Menu "Drives > Configuration" "Summary" (Next 9)

23. The configuration of the drive (SERVO) with third-party motor is completed. You can check the configuration in the summary.

24. Press the "Finish >" softkey.




Figure 8-43 Menu "Drives > Configuration" "...save permanently..." (Finish)

25. Confirm the query with "Yes".




Figure 8-44 Menu "Drives > Configuration"

Note

If the system identifies other drives, which have still not been commissioned, then you will still be guided to commission these.

Otherwise, this completes the first commissioning.

8.1.5 First commissioning of SINAMICS drive ended

First commissioning of SINAMICS drive completed

You have completed the first commissioning of the SINAMICS drives.

The unit configuration and parameterization has been completed successfully:

- All upper LEDs of the drives (SERVOs) are GREEN.
- The lower LEDs of the drives (SERVOs) are always YELLOW.

Continue with the steps for commissioning the NCK (see chapter Commissioning communication NCK<->Drive (Page 113)).

8.2 Manual commissioning of SINAMICS drives

Note

"Manually commissioning" is recommended for experienced commissioning engineers.

8.2.1 Introduction to commissioning of SINAMICS drives



1. Press the <MENU SELECT> > "Commissioning".




Figure 8-45 "Commissioning" menu

2. Press the "Drive system" softkey.




Figure 8-46 Drive system has already been commissioned

Among others, you can manually perform the following functions to commission SINAMICS drives:

- Restoring factory settings (Page 100)
- Updating the component firmware (Page 103)
- Configuring/parameterizing the infeed and drives (SERVOs) (Page 111)
- Check and configure the PROFIBUS connection (Page 106)

8.2.2 **Activate the factory settings**

Introduction

If a commissioning has already been performed, then the drive system can be reset to the factory settings with the "Factory settings..." function.

NOTICE

Before restoring the factory settings, ensure that the EP terminal (Enable Pulses) of the infeed (booksize: X21, chassis: X41) is de-energized.

Procedure for activating factory settings

1. You are in the "Commissioning" > "Drive system" menu.




Figure 8-47 "Commissioning > Drive system" menu

2. Press the "Factory settings..." softkey.




Figure 8-48 Question

- Press "Drive system" to restore the factory settings for all drive units used in the system (the NCU and NX modules).




Figure 8-49 Switch factory settings off/on

- Switch the control (NCU and NX) off (de-energized drive system) and then on again. Wait until communication has been established again with the NC.




Figure 8-50 Query, automatic device configuration

A message appears that a first commissioning is required (Alarm 120402).

In the dialog box "...Should a device configuration be performed for all drive devices?" you have the following options:

- If you press "OK", then the "Guided commissioning" (Page 70) of the SINAMICS drives starts.
- If you press "Cancel", then you can perform the "Manual commissioning".

8.2.3 Updating the component firmware

Loading firmware update for SINAMICS V2.5 and higher

Note**SINAMICS V2.5 and higher**

As of SINAMICS V2.5, an automatic firmware update is undertaken when powering up the drive system if required.

Manual updates for the individual components are not needed in such cases.

After powering up and when operating the control, the drive firmware can however always be loaded from the CompactFlash card.

You activate the "Load firmware ..." function from the "Commissioning > Drive system" menu.

Loading firmware update up to SINAMICS V2.4

Prior to initial startup, all SINAMICS components should have the same firmware version. The software required for this forms part of the SINAMICS software and is stored on the CompactFlash card. An update of individual components may become necessary, after component replacement for example, and is required if the drive-specific alarm A01006 "Firmware update required for DRIVE-CLiQ component <No.>" appears.

Note

If a firmware update is run before configuring the device, once this is complete continue with the "First commissioning of drive units (Page 106)" operating sequence.

Precondition

All components of the NCU/NX accessible (connected via DRIVE-CLiQ).

Note

The correct firmware update of the SINAMICS components is ONLY performed, if ALL were inserted in the switched-off state. Subsequently inserting components may ONLY be carried out in the switched-off state.

Operating sequence

1. You are in the "Commissioning" > "Drive system" > "Drive units" > "Configuration" menu.




Figure 8-51 Loading firmware

2. Select the next drive module, the NCU or NX with the vertical softkey "Drive unit+/Drive unit-".
3. Press the vertical softkey "Load firmware ...".
4. The "Load all" softkey loads the firmware from the CompactFlash card to all DRIVE-CLiQ components of the drive unit (NCU or NX).

Note

Depending on the design of the SINAMICS drive group, a complete update of component firmware can take about 30 minutes.

The component, on which a firmware update is performed, is indicated by a flashing LED.

5. Answer the query "Must firmware from the CompactFlash card be loaded to the component?" with "Yes".
6. After the firmware update has been completed, the entire control (NCU, all NX and all DRIVE-CLiQ components (motor modules, encoder interfaces, etc.)) must be switched off (de-energized) and then switched on again so that the firmware update can take effect.

Follow the instructions displayed on the HMI after the firmware update has been completed.

You can now continue with the commissioning of the drive components (infeed, motor modules, encoders).

Loading firmware for the entire drive system

The "Commissioning" > "Drive system" menu contains the option for activating a complete component firmware update for the entire drive system.

Note

Depending on the design of the SINAMICS drive group, a complete update of component firmware can take about 30 minutes.

The component, on which a firmware update is performed, is indicated by a flashing LED.




Figure 8-52 Load firmware using the "Commissioning" > "Drive system" menu

8.2.4 Automatic device configuration

Introduction

The following unit configuration is performed during the first commissioning of the drive units:

- Transfer of the DRIVE-CLiQ topology to the drive unit

With the transfer of the topology, all components connected on the DRIVE-CLiQ are detected and the drive-internal data traffic is initialized.

- Drive-object assignment for PROFIBUS connection.

The PROFIBUS connection via the relevant message frames has been specified with the configuration in the HW Config.

Precondition

- The drive unit is in the first commissioning state.

Note the following:

NOTICE
Up to SINAMICS V2.5
It must be ensured that compatible firmware has been loaded on all components. If necessary, stop the operation and first load the firmware from the CompactFlash card to all components of the drive unit(s).

The operating sequence for loading the firmware is described in chapter "Update of the component firmware".

Note

As of SINAMICS V2.5, an automatic firmware update is undertaken when powering up if required.

Operating sequence

1. Press the "Drive units" softkey in the "Commissioning" > "Drive system" menu.




Figure 8-53 "Commissioning" > "Drive system" > "Drive units" menu

You are reminded once again that the drive unit is in the first commissioning state and that a unit configuration must be performed for the drive system.

In the example for first commissioning it is assumed that compatible firmware has been loaded on all components.

2. Press the "Drive system" vertical softkey.

During the unit configuration there is a succession of messages containing information on the respective configuration of the individual drive components.

Depending on the size of the drive system, this can take several minutes.

Before the configuration is completed, the HMI displays the following query:




Figure 8-54 Unit configuration, warm restart

- Press "Yes" to perform an NCK power on restart (warm restart).




Figure 8-55 Message after the unit configuration has been completed

The unit configuration for the drive units and drive components of the NCU has been completed.

If necessary check and correct the settings in the "PROFIBUS connection" dialog.

- Press "OK".

This means that you continue commissioning in the actual dialog box "Drive system" > "Drive units" > "Configuration".

The associated components of the selected drive units are displayed in brackets (generally, the NCU).




Figure 8-56 Unit configuration completed, NCU unit configuration

5. Press "Drive unit +".

If you have selected the NX, then the components belonging to the NX are displayed.




Figure 8-57 NX unit configuration

If necessary you can correct and/or modify the settings in the "PROFIBUS connection" dialog.

6. Press "PROFIBUS connection" > "Change...".




Figure 8-58 PROFIBUS NX connection




Figure 8-59 PROFIBUS NCU connection

Check and, if required, correct the settings.

7. Press <RECALL>.




Figure 8-60 Overview of drive system

8.2.5 Commissioning using a drive wizard

Introduction

Drive configuration is done with a drive wizard on the HMI. The following drive components are to be configured:

- Active Line Module (infeed)
- Motor module, motor and encoders (drives)

Operating sequence for drive configuration

The drive configuration can be opened by selecting "Commissioning" > "Drive system" in the menu.




Figure 8-61 Overview of drive system

1. Press the corresponding softkey for the drive object to be configured.
 - "Infeeds"
 - "Drives" for drive controls (SERVO)
2. Configuration is performed in the following sequence:
 - You select the component with the vertical softkey "Infeed+/"Infeed-" or "Drive+/"Drive-"
 - Press the vertical softkey "Change" and follow the drive wizard with the horizontal softkey "Next >".
 - Parameterize the appropriate configuration in the dialog box that appears.

The individual dialog boxes are listed in Chapter "Parameterization of infeed (Page 76)" and "Parameterization of the drives (Page 82)".

Note

If required, check the power (line supply) data using the vertical "Power data" softkey function.

See also

Checking/setting power supply data settings (Page 341)

Commissioning communication NCK<->Drive

Introduction

The first commissioning of the PLC and SINAMICS drives is completed.

What will be configured next?

You will configure the NCK machine data, which communicates with the drive. These are:

- General machine data

General machine data required for communication with the drive via PROFIBUS, which have been preset with default values. These values may be taken over during first commissioning. These are:

- The message frame type for transfer
- The logical addresses for the PLC

Note**Up to software 1.5/2.5**

For an NX module, the logical address "6516" for the PLC must be entered in the general machine data MD13120[1] CONTROL_UNIT_LOGIC_ADDRESS.

- Axis-specific machine data

The axis component for transfer of the setpoints and actual values for the relevant axis, is set in the axis machine data.

Assigning general and axis-specific machine data

The following table illustrates using the example of an SINAMICS S120 module structure (one NCU (CU), one ALM, three motor modules (MM)) the assignment of the NCK machine data for input/output address/telegram/message frame/actual value:

SINAMICS S120	STEP7 (HW Config) DP slave properties		NCK machine data General MD			NCK machine data Axis MD ²⁾	
	Message frame type/length ¹⁾	I/O address ¹⁾	MD13120[0] Control Unit I/O address ¹⁾	MD13050 [0-5] Axis I/O address ¹⁾	MD13060 [0-5] Message frame type ¹⁾	MD30110/3 0220 setpoint/actual value assignment	MD30130 Type of output Setpoint
MM1	116. PZD-11/19	4100		4100	116	1	1
MM2	116. PZD-11/19	4140		4140	116	2	1
MM3	116. PZD-11/19	4180		4180	116	3	1
X (not available)	116. PZD-11/19	4220		4220	116	-	0
X (not available)	116. PZD-11/19	4260		4260	116	-	0
X (not available)	116. PZD-11/19	4300		4300	116	-	0
CU	391. PZD-3/7	6500	6500				
ALM	370. PZD-1/1	6514					

¹⁾ Default value, do not change

²⁾ The axis-specific machine data for configuring setpoints and actual values are pre-assigned using the "Assign axis" function (see section "Configuration of setpoint and actual value" (Page 116)).

9.1 Configuration input/output address and telegram

Introduction


The following general machine data are pre-assigned with a standard value for the PROFIBUS connection between the axes and drive (also see previous table).

- MD13050 \$MN_DRIVE_LOGIC_ADDRESS (axis address)
- MD13060 \$MN_DRIVE_TELEGRAM_TYPE (telegram type)
- MD13120 \$MN_CONTROL_UNIT_LOGIC_ADDRESS (CU address)

Note

No adjustment is necessary here since these values correspond to those preassigned values in HW Config.

PROFIBUS connection



The connection between the relevant axes and drive via PROFIBUS can be viewed and sorted on the HMI in the "Commissioning" > "Drive system" > "Drive units" > "PROFIBUS connections" menu.

The following diagram shows an example of the connection between the relevant axes and drive for an NCU.

I-70-addr.	addr.	Slot	Slot Type	Length [byte]	SINAMICS-drive object	SINAMICS-telegram type
6700	4	4	Input	24	SERVO_3.3.3 [3]	SIEMENS 6
6700	4	4	Output	24		
4100	5	5	Act val	38		
4100	6	6	Set val	22		
6724	8	8	Input	24	SERVO_3.3:4(4)	SIEMENS 116
6724	8	8	Output	24		
4140	9	9	Act val	38		
4140	10	10	Set val	22		
6748	12	12	Input	24	SERVO_3.3:5(5)	SIEMENS 116
6748	12	12	Output	24		
4180	13	13	Act val	38		
4180	14	14	Set val	22		
6772	16	16	Input	24	(255)	--
6772	16	16	Output	24		
4220	17	17	Act val	38		
4220	18	18	Set val	22		
6796	20	20	Input	24	(255)	--
6796	20	20	Output	24		
4260	21	21	Act val	38		

Figure 9-1 PROFIBUS NCU connection

9.2 Configuration setpoint/actual value

Introduction

The axis component for transfer of the setpoints and actual values for the relevant axis, is set in the axis machine data. The following axis machine data is to be adjusted for each axis (also see previous table):

- MD30110 \$MA_CTRLOUT_MODULE_NR (setpoint channel)
- MD30220 \$MA_ENC_MODUL_NR (actual value channel)
- MD30130 \$MA_CTRLOUT_TYPE (setpoint type of output)
- MD30240 \$MA_ENC_TYPE (actual value sensing)

These axis/machine data can be automatically adapted using the "Assign axis" function or directly using the "Axis MD" function.

Operating sequence in the "Assign axis" menu

1. Select the "Commissioning" > "Drive system" > "Drives" menu.




Figure 9-2 "Commissioning" > "Drive system" > "Drives" menu

Note

The "Assign axis" function can also be activated in the "Commissioning > Drive system" function using the vertical softkey bar. You must have selected a servo drive before doing this.

2. Press the "Assign axis" horizontal softkey




Figure 9-3 Assignment of setpoints and actual values for axes to drive

3. Use "Drive +"/"Drive -"/"Direct selection" to select the corresponding servo.

4. Press "Change".




Figure 9-4 "Assign axis" > "Change" menu

5. Use the cursor keys to select the selection boxes for the setpoint or actual value.
6. Use the <INPUT> key to open the selection box.
7. Use the cursor keys to select the component.
8. Press "Transfer".

Operating sequence in the "Commissioning" > "Machine data" > "Axis MD" menu

1. Select the "Axis MD" softkey in the "Commissioning > Machine data" in the operating range.
2. Select the corresponding axis using "Axis+".
3. For the setpoint channel, search for MD30110 \$MA_CTRLOUT_MODULE_NR.
4. Enter the drive number.
5. For the actual value channel, search for MD30220 \$MA_ENC_MODUL_NR.
6. Enter the drive number.
7. For the setpoint type of output, search for MD30130 \$MA_CTRLOUT_TYPE.
8. Enter "1".
9. For the actual value sensing, search for MD30240 \$MA_ENC_TYPE.
10. Enter "1" for incremental encoder or "4" for absolute value encoder.
11. Select the next axis in each case with **Axis+** and continue with Step 3 for the next drive.

9.3 Commissioning communication NCK<->Drive completed

Commissioning communication NCK<->PLC completed

You have commissioned the following in operation:

- PLC
- SINAMICS drives
- Communication NCK-PLC

The basic commissioning is completed. Now you can move the axes.

The next chapter, "Commissioning NCK", describes the parameterization of NCK regarding the connected machine by setting system variables.

NCK start-up

10.1 Overview Commissioning NCK

Introduction

The parameterization of NCK regarding the connected machine occurs by setting system variables.

These system variables are called:

- Machine data (MD)
- Setting data (SD).

See also

Machine and setting data (Page 464)

Preconditions, machine data (Page 211)

10.2 System data

10.2.1 Resolutions

The following types of resolution, e.g. resolution of linear and angular positions, velocities, accelerations and jerk, must be differentiated as follows:

- the **input resolution**, i.e. the input of data from the user interface or using the parts programs.
- the **display resolution**, i.e. the display of data on the user interface.
- the **computational resolution**, i.e. the internal representation of the data input through the user interface or the parts program.

Input and display resolution

The input and display resolution is specified via the control panel being used, whereby the display resolution of position values can be changed with MD9004 \$MM_DISPLAY_RESOLUTION (display resolution).

MD9011 \$MM_DISPLAY_RESOLUTION_INCH (INCH measuring system display resolution) can be used to configure the display resolution for position values with inch setting. This allows you to display up to six decimal places with the inch setting.

For the programming of parts programs, the input resolutions listed in the Programming Guide apply.

Computational resolution

The computational resolution defines the maximum number of effective decimal places for all data the physical unit of which is referred to a length or an angle, e.g. position values, velocities, tool offsets, zero offsets, etc.

The desired computational resolution is defined using the machine data

- MD10200 \$MN_INT_INCR_PER_MM (computational resolution for linear positions)
- MD10210 \$MN_INT_INCR_PER_DEG (computational resolution for angular positions).

The default assignment is:

- 1000 increments/mm
- 1000 increments/degrees

The computational resolution thus also determines the maximum achievable precision for positions and selected offsets. However, it is essential that the measuring system is adapted to this degree of precision.

Note

Although the computational resolution is generally independent of the input/display resolution, it should have at least the same resolution.

Rounding

The precision of angle and linear positions is limited to the computational resolution by rounding the product of the programmed value with the computational resolution to an integer number.

Example of rounding:

Computational resolution: 1000 increments/mm
Programmed path: 97.3786 mm
Effective value = 97.379 mm

Note

To keep rounding easily understandable, it is better to use powers of 10 for the computational resolution (100, 1000, 10,000).

Display resolution

In MD9004 \$MM_DISPLAY_RESOLUTION (display resolution), you can set the number of decimal places after the decimal point for the position values on the operator panel.

Input and display limit values

Limitation of the input values depends on the display features and on the input options on the operator panel. The limit is ten digits plus comma and sign.

Example of programming in the $1/10$ - μm range:

All the linear axes of a machine are to be programmed and traversed within the range of values 0.1 to 1000 mm.

In order to position accurately to 0.1 μm , the computational resolution must be set to $\geq 10^4$ incr./mm.

MD10200 \$MN_INT_INCR_PER_MM = 10000 [incr./mm]:

Example of related parts program:

```
N20 G0 X 10000 Y 10000
;Axes move to position X=10000 mm, Y=10000 mm
```

```
N25 G0 X 50002 Y 20003
;Axes move to position X=50002 mm, Y=20003 mm
```

Machine data

Table 10- 1 Resolutions: Machine data

Number	Name of identifier	Name / remarks
General (\$MM_ ...)		
9004	DISPLAY_RESOLUTION	Display resolution
9011	DISPLAY_RESOLUTION_INCH	Display resolution for INCH system of measurement

General (\$MN_ ...)		
10200	INT_INCR_PER_MM	Computational resolution for linear positions
10210	INT_INCR_PER_DEG	Computational resolution for angular positions

Literature

Function Manual Basic Functions; Velocities, traversing ranges, accuracy: Input/display resolution, computational resolution

10.2.2 Normalization of phys. units of machine data and setting data

Standard

Machine and setting data having a physical unit are interpreted in the input/output units listed in the table "Scaling physical units of machine and setting data" by default, depending on the scaling system (metric/inch).

The internally used units which the NC uses are independent and fixed.

Table 10- 2 Normalization of phys. units of machine data and setting data

Physical unit	Input/output units for the standard basic system		Internally used unit
	Metric	Inch	
Linear position	1 mm	1 inch	1 mm
Angular position	1 degree	1 degree	1 degree
Linear velocity	1 mm/min	1 inch/min	1 mm/s
Angular velocity	1 rpm	1 rpm	1 deg./s
Linear acceleration	1 m/s ²	1 inch/s ²	1 mm/s ²
Angular acceleration	1 rev/s ²	1 rev/s ²	1 degree/s ²
Linear jerk	1 m/s ³	1 inch/s ³	1 mm/s ³
Angular jerk	1 rev/s ³	1 rev/s ³	1 degree/s ³
Time	1 sec	1 sec	1 sec
Position controller servo gain	1 s ⁻¹	1 s ⁻¹	1 s ⁻¹
Rev. feedrate	1 mm/rev	1 inch/rev	1 mm/degree
Compensation value linear position	1 mm	1 inch	1 mm
Compensation value angular position	1 degree	1 degree	1 degree


User-defined

The user can define different input/output units for machine and setting data.

For this purpose,

- MD10220 \$MN_SCALING_USER_DEF_MASK (activation of standardizing factors) and
- MD10230 \$MN_SCALING_FACTORS_USER_DEF[n] (standardizing factors of the physical quantities)

allow you to set the adaptation between the newly selected input/output units and the internal units.



The following applies:

Input/output unit selected=

MD10230 \$MN_SCALING_FACTORS_USER_DEF[n] * internal unit

The selected I/O unit, expressed in the internal units 1 mm, 1 degree and 1 s must therefore be entered in MD10230 \$MN_SCALING_FACTORS_USER_DEF[n].

Table 10- 3 Bit number and index for user definition

Physical unit	MD10220 bit number	MD10230 index n
Linear position	0	0
Angular position	1	1
Linear velocity	2	2
Angular velocity	3	3
Linear acceleration	4	4
Angular acceleration	5	5
Linear jerk	6	6
Angular jerk	7	7
Time	8	8
Kv factor	9	9
Rev. feedrate	10	10
Compensation value linear position	11	11
Compensation value angular position	12	12

Example 1:

Machine data input/output of the linear velocities is to be in m/min instead of mm/min (initial state). The internal unit is mm/s.

MD10220 \$MN_SCALING_USER_DEF_MASK Bit2 = 1 is used to enter the scaling factor for linear velocities as a user-defined value.

The scaling factor is calculated using the following formula:

$$\text{MD10230 \$MN_SCALING_FACTORS_USER_DEF}[n] = \frac{\text{Input/output unit selected}}{\text{Internal unit}}$$

$$\text{MD10230 \$MN_SCALING_FACTORS_USER_DEF}[n] = \frac{1 \frac{\text{m}}{\text{min}}}{1 \frac{\text{mm}}{\text{s}}} = \frac{1000 \frac{\text{mm}}{60 \text{ s}}}{1 \frac{\text{mm}}{\text{s}}} = \frac{1000}{60} = 16.667$$

→ MD10230 \$MN_SCALING_FACTORS_USER_DEF[2] = 16.667

Index 2 specifies the "linear velocity" (see above).

Example 2:

In addition to the change in example 1, the machine data input/output of linear accelerations is to be performed in ft/s², instead of m/s² (initial state). (The internal unit is mm/s²).

MD10220 \$MN_SCALING_USER_DEF_MASK = ,H14'; (bit no. 4 and bit no. 2) from example 1 as hex value

$$\text{MD10230 \$MN_SCALING_FACTORS_USER_DEF}[n] = \frac{1 \frac{\text{ft}}{\text{s}^2}}{1 \frac{\text{mm}}{\text{s}^2}} = \frac{12 \cdot 25.4 \frac{\text{mm}}{\text{s}^2}}{1 \frac{\text{mm}}{\text{s}^2}} = \frac{1000}{60} = 304.8$$

→ MD10230 \$MN_SCALING_FACTORS_USER_DEF[4] = 304.8

Index 4 specifies the "linear acceleration" (see above).

Machine data

Table 10- 4 Normalization of phys. units of machine data and setting data: Machine data

Number	Name of identifier	Name / remarks	Reference
General (\$MN_ ...)			
10220	SCALING_USER_DEF_MASK	Activation of scaling factors	
10230	SCALING_FACTORS_USER_DEF[n]	Scaling factors of physical quantities	
10240	SCALING_SYSTEM_IS_METRIC	Basic system metric	
10250	SCALING_VALUE_INCH	Conversion factor for switchover to inch system	
10260	CONVERT_SCALING_SYSTEM	Basic system switchover active	
10270	POS_TAB_SCALING_SYSTEM	System of measurement of position tables	T1
10290	CC_TDA_PARAM_UNIT	Physical units of the tool data for CC	
10292	CC_TOA_PARAM_UNIT	Physical units of the tool edge data for CC	

10.2.3 Modifying scaling machine data

The scaling of machine data having physical units is defined by the following machine data:

- MD10220 \$MN_SCALING_USER_DEF_MASK (activation of standardizing factors)
- MD10230 \$MN_SCALING_FACTORS_USER_DEF (standardizing factors of the physical quantities)
- MD10240 \$MN_SCALING_SYSTEM_IS_METRIC (basic system metric)
- MD10250 \$MN_SCALING_VALUE_INCH (conversion factor for switchover to INCH system)
- MD30300 \$MA_IS_ROT_AX (rotary axis)

When scaling machine data are modified, all machine data affected by this modification due to their physical unit are converted with the next NCK reset.

Example: Redefining an A1 axis from linear to rotary axis.

The control has been started up with default values. Axis A1 is declared as a linear axis.

- MD30300 \$MA_IS_ROT_AX[A1] = 0 (no rotary axis)
- MD32000 \$MA_MAX_AX_VELO [A1] = 1000 [mm/min] (max. axis velocity).

Axis A1 is now declared as a rotary axis containing the following machine data:

- MD30300 \$MA_IS_ROT_AX[A1] = 1 (rotary axis)
- MD32000 \$MA_MAX_AX_VELO [A1] = 1000 [mm/min] (max. axis velocity).

With the next NCK reset, the control system recognizes that axis A1 is defined as a rotary axis and standardizes MD32000 \$MA_MAX_AX_VELO to [rev./min] with reference to a rotary axis.

- MD30300 \$MA_IS_ROT_AX[A1] = 1 (rotary axis)
- MD32000 \$MA_MAX_AX_VELO [A1]= 2.778 [rev./min]

Note

If a scaling machine data item is altered, then the control outputs alarm "4070 Scaling data changed".

Modifying manually

The following procedure is recommended when modifying scaling machine data manually:

1. Set all scaling machine data
2. Carry out NCK reset
3. Set all dependent machine data after the NC has powered up.

10.2.4 Loading default machine data

The default machine data can be loaded in different ways.

HMI startup

HMI startup via the HMI standard user interface: Operating area menu "Diagnostics" > "NC/PLC"

- Button: "Delete NCK Data"
- Button: "NCK RESET"

NOTICE

With deleting the NCK data, all user data are lost.

To avoid data loss, a series commissioning file should be created before the NCK data are deleted. The way to create a series machine start-up file is laid out in the Chapter "Creating a series machine start-up file".

MD11200 \$MN_INIT_MD

Using the entry values listed below in MD11200 \$MN_INIT_MD (loading the standard machine data for the "next" NC boot), you can load various data storage areas with default values at the next NC boot.

After setting the machine data, an NCK reset must be carried out:

1. NCK RESET: The machine data is activated.
2. NCK RESET: Depending on the entry value, the corresponding machine data is set to its standard values and the MD11200 \$MN_INIT_MD is reset to value "0".

Input values

MD11200 \$MN_INIT_MD = 1

At the next NC power-up, all machine data (with the exception of the memory configuring data) are overwritten with default values.

MD11200 \$MN_INIT_MD = 2

At the next NC boot, all memory-configuring machine data are overwritten with default values.

10.2.5 Switching over the measuring system

The measuring system is switched over for the entire machine using a softkey in the "Machine" HMI-Advanced operating area. The switchover is only accepted if:

- MD10260 \$MN_CONVERT_SCALING_SYSTEM=1.
- Bit 0 of MD20110 \$MC_RESET_MODE_MASK is set in every channel.
- All channels are in the Reset state.
- Axes are not traversing with JOG, DRF or PLC control.
- Constant grinding wheel peripheral speed (GWPS) is not active.

Actions such as parts program start or mode change are disabled for the duration of the switchover.

If the switchover cannot be performed, this is indicated by a message in the user interface. These measures ensure that a consistent set of data is always used for a running program with reference to the system of measurement.

The actual switchover of the system of measurement is performed internally by writing all the necessary machine data and subsequently activating them with a Reset.

MD10240 \$MN_SCALING_SYSTEM_IS_METRIC and the corresponding G70/G71/G700/G710 settings in MD20150 \$MC_GCODE_RESET_VALUES are switched over automatically and consistently for all configured channels.

The value of machine data: MD20150 \$MC_GCODE_RESET_VALUES[12] varies between G700 and G710.

This process takes place independently of the protection level currently set.

System data

When changing over the measuring system, from the view of the user, all length-related specifications are converted to the new measuring system automatically. This includes:

- Positions
- Feed rates
- Acceleration rates
- Jerk
- Tool offsets
- Programmable, settable and work offsets external and DRF offsets
- Compensation values
- Protection zones
- Machine data
- Jog and hand wheel factors

After switching, all above mentioned data is available in the physical units according to Chapter "Standardizing of physical units of machine and setting data".

Data for which no unique physical units are defined, such as:

- R parameters
- GUDs (Global User Data)
- LUDs (Local User Data)
- PUDs (Program global User Data)
- Analog inputs/outputs
- Data exchange via FC21

are not converted automatically. The user is prompted to take the current valid measuring system MD10240 \$MN_SCALING_SYSTEM_IS_METRIC into consideration.

The current system of measurement setting can be read at the PLC interface via the "inch system" signal DB10.DBX107.7. DB10.DBB71 can be used to read out the "system of measurement change counter".

Machine data

Table 10- 5 Switching over the unit system: Machine data

Number	Name of identifier	Name / remarks	Reference
General (\$MN_ ...)			
10240	SCALING_SYSTEM_IS_METRIC	Basic system metric	
10250	SCALING_VALUE_INCH	Conversion factor for switch-over to inch system	
10260	CONVERT_SCALING_SYSTEM	Basic system switch-over active	
axis spec. (\$MA_ ...)			
32711	CEC_SCALING_SYSTEM_METRIC	System of measurement of sag compensation	G2

Literature

Function Manual; speed, setpoint/actual-value systems, control: Metric/inch measuring system

10.2.6 Traversing ranges

Computational resolution and traversing ranges

The range of values of the traversing ranges directly depends on the selected computational resolution (see Subsection "Resolutions" (Page 121)).

With the default assignment of the machine data for the computational resolution

- 1000 inc./mm
- 1000 inc./deg.

the following traversing ranges result:

Table 10- 6 Traversing ranges

	Traversing range in the metric system	Traversing range in the inch system
Linear axes	± 999,999.999 [mm; deg.]	± 399,999.999 [inch; deg.]
Rotary axes	± 999,999.999 [mm; deg.]	± 999,999.999 [inch; deg.]
Interpolation parameters I, J, K	± 999,999.999 [mm; deg.]	± 399,999.999 [inch; deg.]

10.2.7 Positioning accuracy of the control system

Computational resolution and traversing ranges

The positioning accuracy depends on:

- the computational accuracy (internal increments/(mm or degrees))
- the actual-value resolution (encoder increments/(mm or degrees)).

The rougher resolution of both determines the positioning accuracy of the NC.

The input resolution, the position control and interpolation clock do not affect the accuracy.

Machine data

Table 10- 7 Positioning accuracy: Machine data

Number	Name of identifier	Name / remarks	Reference
General (\$MN_ ...)			
10200	INT_INCR_PER_MM	Computational resolution for linear positions	G2
10210	INT_INCR_PER_DEG	Computational resolution for angular positions	G2
Axis-specific (\$MA_ ...)			
31020	ENC_RESOL[n]	Encoder pulses per revolution	

10.2.8 Cycle times

On the SINUMERIK 840D sl the system clock cycle, the position controller cycle, and the interpolation cycle of the NC are based on the DP cycle time configured in STEP 7 HW config. See Chapter "SIMATIC create S7 project".

System basic cycle

The system clock cycle is set fixed to the ratio of 1:1 with regard to the DP cycle time. The active value is displayed in the machine data MD10050 \$MN_SYSCLOCK_CYCLE_TIME (system cycle). It cannot be changed.

Position controller cycle

The position controller cycle (MD10061 \$MN_POSCTRL_CYCLE_TIME) is set to the fixed ratio 1:1 with respect to the system clock cycle. It cannot be changed.

Position control cycle offset

The position control cycle offset T_M is automatically determined in the default setting (MD10062 \$MN_POSCTRL_CYCLE_DELAY=0).

The effective position controller offset is displayed in the MD10063[1].

The following values can be read out via the MD10063 \$MN_POSCTRL_CYCLE_DIGNOSIS:

- MD10063[0]= T_{DX}
- MD10063[1]= T_M
- MD10063[2]= $T_M + T_{Lag\ max}$

The following conditions must be met for explicit specification of the position controller cycle offset (MD10062 \$MN_POSCTRL_CYCLE_DELAY!=0):

- The cyclic communication with the DP slaves (drives) must be completed before the position controller is started.
Condition: $T_M > T_{DX}$
- The position controller must be completed before the DP cycle/system clock is completed.
Condition: $T_M + T_{\text{Position control max}} < T_{DP}$




Figure 10-1 Position control cycle offset compared to PROFIBUS DP cycle

Key to Fig. above:

T_{Lag} : CPU time required by position controller

T_{DP} : DP cycle time: DP cycle time

T_{DX} : Data Exchange Time: Total transfer time for all DP slaves

T_M : Master time: Offset of the start time for NCK position controller

GC: Global Control: Broadcast message for cyclic convergence of the equidistance between DP master and DP slaves

R: CPU time

Dx: Useful data exchange between the DP master and DP slaves

MSG: Acyclic services (e.g. DP/V1, pass token)

RES: Reserve: "Active pause" until the isochronous (equidistant) cycle has expired

Error response

- Alarm: "380005 PROFIBUS DP: Bus access conflict, type t, counter z"

Cause of errors/error handling

- $t = 1$

The position-control cycle offset selected is too small. The cyclic PROFIBUS communication with the drives was not yet completed with the start of the position controller.

- Remedy: Increase the position-control cycle offset.

- $t = 2$

The position-control cycle offset selected is too large. The cyclic PROFIBUS communication with the drives started before the position controller had finished. The position controller requires more CPU time than available within the DP cycle.

- Remedy: Decrease the position-control cycle offset

Or

- Remedy: Increase the DP cycle time.

The DP cycle time is set using STEP7 "HW-Config". See Chapter "SIMATIC create S7 project".

Interpolation cycle

The interpolator cycle may be chosen freely as a whole multiple of the position control cycle.

- MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO (factor for the interpolation cycle)

Error response

- Alarm: "4240 CPU time overflow on the IPO or position controller level"

Cause of errors/error handling

The DP cycle time/position controller cycle, the interpolation cycle, or the NC CPU time share is set in such a way that not enough CPU time is available for one of the two cyclic levels of the NCK (position controller or interpolator).

Remedial action:

Calculate the maximum values for $T_{pos\ max}$ and $T_{IPO\ max}$ (see above) and adapt the following machine data:

- MD10185 \$MN_NCK_PCOS_TIME_RATIO (CPU time share NCK)
- MD10070 \$MN_IPO_SYSCLOCK_TIME_RATIO (factor for the interpolation cycle)
- MD10050 \$MN_SYSCLOCK_CYCLE_TIME (system clock cycle)

Note

You must adjust the **system clock cycle** by changing the DP cycle time using STEP7 "HW-Config".

Literature

Function Manual special functions; cycle times

Machine data

Table 10- 8 Cycle times: Machine data

Number	Identifier	Name / remarks	Reference
General (\$MN_ ...)			
10050	SYSCLOCK_CYCLE_TIME	System clock cycle/only display data; is always equal to the equidistant PROFIBUS DP cycle. Note: For SINUMERIK solution line for display only!	
10060	POSCTRL_SYSCLOCK_TIME_RATIO	Factor for the position control cycle/is set fixed to the factor 1.	
10061	POSCTRL_CYCLE__TIME	Position Controller cycle	
10062	POSCTRL_CYCLE_DELAY	Position control cycle offset	
10063	POSCTRL_CYCLE_DIAGNOSIS	[0] = DP cycle time [1] = Position controller cycle offset [2] = Position controller cycle offset + max. computation time needed by the position controller	
10070	IPO_SYSCLOCK_TIME_RATIO	Factor for the interpolator cycle/can be freely selected in integer multiples.	
10185	NCK_PCOS_TIME_RATIO	Computation time ratio NCK	

 CAUTION
If you change the cycle times, check the behavior of the controller in all operating modes before you finish commissioning.

Note

The smaller the cycle times (PROFIBUS DP cycle) chosen, the greater the control quality for the drive and the better the surface quality on the workpiece.

10.2.9 NCK utilization

Introduction

You can view utilization of system resources for the NCK on the HMI under the menu "Diagnostics > Service displays > System resources".

Net runtime (pure calculation time)			
	current	minimum	maximum
Position controller	0.097 ms	0.041 ms	0.241 ms
Interpolator	1.006 ms	0.072 ms	1.526 ms
Forward motion	0.101 ms	0.048 ms	23.089 ms

Gross runtime (stopped time from beginning to end)			
	current	minimum	maximum
Position controller	0.097 ms	0.041 ms	0.241 ms
Interpolator	1.006 ms	0.072 ms	1.526 ms
Forward motion	0.096 ms	0.048 ms	26.331 ms

NCU load by position control and interpolator: 11.62% 1.97% 20.75 %
Filling level of interpolator buffer: 0 %

Figure 10-2 NC utilization

The following machine data is taken into consideration for displayed runtimes (see Chapter Cycle times (Page 133)):

- MD1061 \$MD_POSCTRL_CYCLE_TIME = MD10050 \$MN_SYSCLOCK_CYCLE_TIME (System basic cycle)
- MD1070 \$MD_IPO_SYSCLOCK_TIME_RATIO (factor for the interpolation cycle)
- MD1071 \$MD_IPO_CYCLE_TIME (interpolation cycle)

What will be displayed?

In the display of the "System resources" menu, the values have the following meaning:

- Area "Net runtime (purely CPU time)":
Active times (current, minimum and maximum) are displayed in the net values.
The relation to the machine data can be seen from the displayed values.
- Area "Gross runtime (time from start to end)":
The corresponding total utilization of the system (position controller + interpolator) is displayed, based on the net values.

- Line "NCU load by position controller and interpolator":

Note

The current, minimum and maximum utilization of the NCK is displayed.

In order to have sufficient reserves for program processing, maximum utilization in reset condition when pressing the <Reset> key should be in the range of 60-65%.

- Line "Capacity of interpolator buffer":

The capacity indicator MD28060 \$MC_NUM_IPO_Buffer_SIZE is indicated in %.

This display indicates whether batch preparation for batch processing can commence.

Jerky processing in continuous-path mode, if for instance a number of short traversing blocks have been programmed in succession, is a typical indicator of the IPO buffer idling.

Capacity indication is channel-specific.

10.2.10 Velocities

Max. axis velocity or spindle speed

The maximum possible axis velocities and spindle speeds depend on the machine design, drive dynamics and the encoder limit frequency of the individual drives.

Max. progr. tool path velocity

The maximum programmable tool path velocity results from the maximum axis velocities of the axes involved in the path programmed.

Max. tool path velocity

The maximum tool path velocity at which traversing is possible within a parts program block results as follows:

$$V_{\max.} = \frac{\text{Progr. path length in part program block [mm or degrees]}}{\text{Interpolation cycle [s]}}$$

Upper limit

To guarantee that parts program blocks are executed continuously (control margin), the NC limits the tool path velocity within a parts program block to 90% of the max. possible tool path velocity as follows:

$$V_{\max.} \leq \frac{\text{Progr. path length in part program block [mm or degrees]}}{\text{Interpolation cycle [s]}} * 0.9$$

For example, in the case of parts programs generated by means of CAD system, which contain extremely short blocks, this limiting of the path velocity can result in a strong reduction of the path velocity over several parts program blocks.

The function "Online compressor" can help to avoid such sudden velocity dips.

Literature

Programming Manual Work Preparation: Compressor COMPON/COMP CURVE

Voltage limit

The minimum tool path or axis velocity at which traversing is possible results from:

$$V_{\min} \geq \frac{10^{-9}}{\text{comput. resolution} \left[\frac{\text{incr.}}{\text{mm or degrees}} \right] * \text{IPO cycle [s]}}$$

(for the computational resolution, see Chapter "Resolutions")

If V_{\min} is not reached, no traversing movement is carried out.

Literature

Function Manual Basic Functions; Velocities, traversing ranges, accuracy: Velocities

10.3 Memory configuration

Introduction

On the SINUMERIK 840D sl, the persistent data are divided into various independent areas:

- SIEMENS
- Vendor
- Users

SRAM

For historical reasons, SRAM is still named as the memory medium at various points in relation to persistent data. For SINUMERIK solution line, this only applies insofar as SRAM is also sometimes used in the context of persistent data management. However, when a SINUMERIK solution line control system is in continuous operation, the data are physically stored in the much more powerful DRAM. Only when the control system is switched off are the data saved to a persistent data storage area. SRAM is also used for specific control systems.

Memory division

The figure below shows how NCK persistent data is divided:




Figure 10-3 Memory division

Legend	Description	User
1	Part programs and OEM cycles can be set via MD 18352 \$MN_U_FILE_MEM_SIZE	User
2	In addition to part programs and OEM cycles, can be set via MD 18353 \$MN_M_FILE_MEM_SIZE	User
3	SIEMENS cycles	Siemens AG
4	Reserved	Siemens AG
5	RAM in NCK	User
6	RAM in NCK, contains the system and user data accessed by the NCK during program execution. Numbers for tools, frames, etc., are set by default.	User
7	Additional memory (optional)	Available to users as an option and can be used for RAM in NCK or for part programs and cycles.

Memory display

The memory available in the NCK is displayed on the user interface, e.g., HMI Advanced, under: Operating area "Commissioning" > "NC" > "NC memory".

See also

Import licensing terms (Page 351)

10.4 Parameter sets of axis/spindle

Per machine axis, six parameter sets are available. They are used as follows

- on an axis:
for accommodation of the own dynamic response to another machine axis, e.g. when tapping or thread cutting on the relevant spindle.
- on a spindle:
for accommodation of the position controller to modified properties of the machine during operation, e.g. when switching the gearbox.

Tapping, thread cutting

The following applies to axes:

- For a machine axis that is not involved in tapping or thread cutting, the 1st set of parameters (index=0) is active in all cases.

The further parameter sets need not be considered.

- Machine axes involved in tapping or thread cutting: the parameter set is activated in accordance with the current gear stage.

All parameter sets must be parameterized in accordance with the gear stages of the spindle.

The following applies to spindles:

- With spindles, each gear stage is assigned a parameter set of its own.

For instance Gearbox step 1 - Parameter set 2 (Index 1). Spindles in axis operation (DB31, ... DBX60.0 = 0) use Parameter set 1 (Index 0).

The active gearbox step can be read in the PLC via the signals DB31, ... DBX82.0-2 (Gearbox step setpoint)." The parameter set is selected from the PLC using the interface signal DB31, ... DBX16.0 - 16.2 (actual gear stage).

All parameter sets must be parameterized in accordance with the gear stages of the spindle.

For example, in HMI-Advanced, the active parameter set of a machine axis is displayed in the "Diagnosis" control area in the "Service axis" screen.

The active parameter set can be read in the PLC via the signals DB31, ... DBX69.0-2 (Controller parameter set)."

10.4 Parameter sets of axis/spindle

Parameter set no.	Axis	Spindle	Gear stage The spindle
0	Standard	Axis mode	as specified by manufacturer input
1	Axis interpolated with spindle (G33)	Spindle mode	1.
2	Axis interpolated with spindle (G33)	Spindle mode	2.
3	Axis interpolated with spindle (G33)	Spindle mode	3.
4	Axis interpolated with spindle (G33)	Spindle mode	4.
5	Axis interpolated with spindle (G33)	Spindle mode	5.

Figure 10-4 Validity of parameter sets for axis and spindle modes

Remarks on the "Axis" column: Switch-over applies to G33 as well as for G34, G35, G331 and G332.

Machine data

The following machine data of a machine axis depend on the parameter set:

n = parameter set number (0 ... 5)

Table 10- 9 Parameter-set-dependent machine data

Number	Identifier	Name	Reference
Axis/spindle-specific (\$MA_ ...)			
31050	DRIVE_AX_RATIO_DENOM[n]	Denominator load gearbox	
31060	DRIVE_AX_RATIO_NUMERA[n]	Numerator load gearbox	
32200	POSCTRL_GAIN [n]	Kv factor	
32810	EQUIV_SPEEDCTRL_TIME [n]	Equivalent time constant, of speed control loop for feed forward control	
32910	DYN_MATCH_TIME [n]	Time constant for dynamic matching	
35110	GEAR_STEP_MAX_VELO[n]	Maximum speed for gear change	
35120	GEAR_STEP_MIN_VELO[n]	Minimum speed for gear change	
35130	GEAR_STEP_MAX_VELO_LIMIT[n]	Maximum speed of gear stage	
35140	GEAR_STEP_MIN_VELO_LIMIT[n]	Minimum speed of gear stage	
35200	GEAR_STEP_SPEEDCTRL_ACCEL[n]	Acceleration in speed control mode	
35210	GEAR_STEP_POSCTRL_ACCEL[n]	Acceleration in position control mode	
36200	AX_VELO_LIMIT [n]	Threshold value for velocity monitoring	

10.5 Parameterize axis data

Reference

See also

- Axis data (Page 471)
- Drive assignment (Page 476)
- Axis names (Page 478)

10.5.1 Incremental measuring system settings

Rotary measuring system

The diagrams below show the general possibilities of arranging a rotary incremental measuring system with regard to motor and load, as well as the resulting values for the appropriate machine data.

Figures equally apply to rotary axes, modulo axis and spindles.

Linear axis with encoder on the machine




Figure 10-5 Linear axis with encoder on motor

Linear axis with sensor on load




Figure 10-6 Linear axis with sensor on load

Rotary axis with encoder on motor




Figure 10-7 Rotary axis with encoder on motor

Linear axis with encoder on the machine




Figure 10-8 Linear axis with encoder on the machine

Machine data

Table 10- 10 Incremental measuring systems: Machine data

Number	Identifier	Name / remarks	Reference
Axis-specific (\$MA_ ...)			
30240	ENC_TYPE[n]	Actual value acquisition modes 1=incremental raw signal encoder	
30242	ENC_IS_INDEPENDENT[n]	Encoder is independent	
30300	IS_ROT_AX	Rotary axis	R2
31000	ENC_IS_LINEAR[n]	Direct measuring system (linear scale)	
31020	ENC_RESOL[n]	Encoder pulses per revolution	
31030	LEADSCREW_PITCH	Leadscrew pitch	
31040	ENC_IS_DIRECT[n]	Encoder is connected directly to the machine	
31050	DRIVE_AX_RATIO_DENOM[n]	Denominator load gearbox	
31060	DRIVE_AX_RATIO_NUMERA[n]	Numerator load gearbox	
31070	DRIVE_ENC_RATIO_DENOM[n]	Denominator of resolver gearbox	
31080	DRIVE_ENC_RATIO_NUMERA[n]	Numerator of resolver gearbox	

Linear measuring system

The diagram below shows the general possibilities of arranging a linear incremental measuring system with regard to motor and load, as well as the resulting values for the respective machine data.

Linear axis with linear scale




Figure 10-9 Linear axis with linear scale

Machine data

Table 10- 11 Linear measuring systems: Machine data

Number	Identifier	Name / remarks	Reference
axis-specific (\$MA_ ...)			
30240	ENC_TYPE[n]	Actual value acquisition modes 1=incremental raw signal encoder	
30242	ENC_IS_INDEPENDENT[n]	Encoder is independent	
30300	IS_ROT_AX	Rotary axis	R2
31000	ENC_IS_LINEAR[n]	Direct measuring system (linear scale)	
31010	ENC_GRID_POINT_DIST[n]	Distance between reference marks on linear scales	
31030	LEADSCREW_PITCH	Leadscrew pitch	
31040	ENC_IS_DIRECT[n]	Encoder is connected directly to the machine	
31050	DRIVE_AX_RATIO_DENOM[n]	Denominator load gearbox	
31060	DRIVE_AX_RATIO_NUMERA[n]	Numerator load gearbox	
32110	ENC_FEEDBACK_POL[n]	Sign actual value (feedback polarity)	

10.5.2 Parameterization of absolute measuring systems

Encoder types

The following encoder types are currently supported:

- Single-turn absolute value encoder
- Multi-turn absolute value encoder

with EnDat protocol and incremental sinusoidal encoder signals A and B, e.g. Heidenhain EQN 1325.

EQN 1325

The absolute value encoder EQN 1325 from Heidenhain has the following properties:

- EnDat protocol
- PPR count: 2048 = 2^{11} (encoder fine resolution)
- Positions/revolution: 8192 (13 bits)
- Differentiable revolutions: 4096 (12 bits)
- Encoder signals A/B: 1Vpp sin/cos

Calibration

Convergence of the measuring system with the machine positions is performed by calibration of the absolute value encoder in absolute measuring systems. For calibration of the absolute value encoder, see Chapter "Axis homing" (Page 178).

Linear axis with absolute value encoder on motor




Figure 10-10 Linear axis with absolute value encoder on motor

Rotary axis, modulo axis and spindle with absolute value sensor on motor




Figure 10-11 Rotary axis, modulo axis and spindle with absolute value sensor on motor

Machine data

Table 10- 12 Measuring systems: Machine data

Number	Identifier	Name / remarks	Reference
axis-specific (\$MA_ ...)			
30240	ENC_TYPE[n]	Actual-value acquisition modes	
30242	ENC_IS_INDEPENDENT[n]	Encoder is independent	
30260	ABS_INC_RATION[n]	Encoder fine resolution (absolute value encoder)	
30300	IS_ROT_AX[n]	Rotary axis	R2
31000	ENC_IS_LINEAR[n]	Direct measuring system (linear scale)	
31030	LEADSCREW_PITCH[n]	Leadscrew pitch	
31040	ENC_IS_DIRECT[n]	Encoder is connected directly to the machine	
31050	DRIVE_AX_RATIO_DENOM[n]	Denominator load gearbox	
31060	DRIVE_AX_RATIO_NUMERA[n]	Numerator load gearbox	
31070	DRIVE_ENC_RATIO_DENOM[n]	Measuring gearbox denominator	
31080	DRIVE_ENC_RATIO_NUMERA[n]	Measuring gearbox numerator	
34200	ENC_REFP_MODE[n]	Referencing mode	
34210	ENC_REFP_STATE[n]	Status of absolute value encoder	
34220	ENC_ABS_TURNS_MODULO[n]	Absolute value encoder range for rotary encoders (multi-turn resolution)	R2

10.5.3 DSC (Dynamic Servo Control)

The DSC function eliminates the deadtime that necessarily exists at the speed-setpoint interface normally used between the NCK and drive due to relocation of the position controller into the drive.

This results in the following advantages for an axis operated with DSC:

- Considerably improved fault response/stability of the position control loop
- Improved command behavior (contour precision) if the loop gain (K_v factor) that can be set higher in conjunction with DSC is used.
- A reduction of the cyclic communication load on the PROFIBUS, if the position controller cycle/PROFIBUS cycle is reduced by adjusting the above parameters, even if the control loop performance is the same.

Note

The speed feedforward control can be used in conjunction with DSC.

Requirements

Before you can activate DSC mode, the following preconditions must be fulfilled:

- DSC-capable drive
- A DSC-capable message frame type has been parameterized in the S7 project for the drive.

Switch ON/OFF

The DSC function is switched on via the following axis-specific NCK machine data:

- MD32640 \$MA_STIFFNESS_CONTROL_ENABLE (dyn. Stiffness control)

If DSC operation is switched ON or OFF, it might be necessary to adjust the following machine data:

- MD32200 \$MA_POSCTRL_GAIN (servo gain factor)
- MD32610 \$MA_VELO_FFW_WEIGHT (feedforward control factor)
- MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (substitute time const. of the closed speed control loop)

NOTICE

Before you can switch off DSC operation you might have to adapt (reduce) the K_v factor of the axis. Otherwise, instability of the position control loop might result.
--

Actual value inversion during DSC operation

Note

Actual value inversion during DSC operation (MD32640=1) is undertaken as follows:

- Set the p0410 parameter (encoder inversion actual value) in the drive.
- In the NC in the machine data, set MD32110 \$MA_ENC_FEEDBACK_POL = 0 or 1 (no inversion!).

Actual value inversion via MD32110=-1 is not possible during activated DSC operation.

If MD32110=-1 is to be set, the "26017 axis%1 machine data 32110 value not permitted" alarm is output when DSC operation is activated.

Speed setpoint filter

If you use DSC, a speed setpoint filter for rounding the speed setpoint steps is no longer necessary. The speed setpoint filter is then only of any use with differential connection to support the position controller, for example, to suppress resonance.

Machine data

Table 10- 13 DSC: Machine data

Number	Identifier	Name	Reference
Axis-specific (\$MA_ ...)			
32640	STIFFNESS_CONTROL_ENABLE	Dyn. stiffness control	DD2
32200	POSCRTL_GAIN	Kv factor	G2
32642	STIFFNESS_CONTROL_CONFIG	The dynamic stiffness control is configured. 0->standard case: DSC in drive operates with indirect measuring system 1->DSC in the drive operates using direct measuring system	DD2

10.5.4 Rotary axes

Rotary axes

A machine axis is parameterized as a rotary axis in

- MD30300 \$MA_IS_ROT_AX (rotary axis) = 1

The machine data is a scaling machine data. A change results in a conversion of all machine data of the machine axis with length-related units.

For the recommended procedure with respect to scaling machine data, please refer to Subsection "Modifying Scaling Machine Data".

Modulo display

The display of the rotary axis position modulo 360 degrees is displayed via the following machine data:

- MD30320 \$MA_DISPLAY_IS_MODULO (modulo 360 degrees display for rotary axes)

Endlessly rotating rotary axis/modulo axis

The traversing of the rotary axis modulo 360 degrees is displayed via the following machine data:

- MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis)

The limit switches are not monitored during this process. The rotary axis can thus rotate endlessly.

The limit switch monitoring can be activated by the PLC interface.

Machine data

Table 10- 14 Rotary axes: Machine data

Number	Identifier	Name	Reference
general (\$MN_ ...)			
10210	INT_INCR_PER_DEG	Computational resolution for angular positions	G2
axis-specific (\$MA_ ...)			
30300	IS_ROT_AX	Axis is rotary axis	
30310	ROT_IS_MODULO	Modulo conversion for rotary axis	
30320	DISPLAY_IS_MODULO	Actual value display modulo	
36100	POS_LIMIT_MINUS	Minus software limit switch	A3
36110	POS_LIMIT_PLUS	Plus software limit switch	A3

Setting data

Table 10- 15 Rotary axes: Setting data

Number	Identifier	Name	Reference
General (\$SN_ ...)			
41130	JOG_ROT_AX_SET_VELO	JOG speed for rotary axes	H1
Axis-specific (\$SA_ ...)			
43430	WORKAREA_LIMIT_MINUS	Working area limitation minus	A3
43420	WORKAREA_LIMIT_PLUS	Working area limitation plus	A3

Literature

Function Manual Expanded Functions; Rotary axes

10.5.5 Positioning axes

Positioning axes are channel axes traversing parallel to the path axes without interpolating with them.

Positioning axes can be traversed either from the parts program or from the PLC.

Concurrent machine axes

A channel axis is neutrally defined by default with the following machine data. As a result no REORG takes place if the axis/spindle is traversed by the PLC (FC18) or by synchronous actions.

- MD30450 \$MA_IS_CONCURRENT_POS_AX (concurr. positioning axis) = 1

Positioning axis feedrate

If a positioning axis is programmed in the part program without specifying an axis-specific feedrate, the feedrate entered in the following machine data is automatically applicable to this axis:

- MD32060 \$MA_POS_AX_VELO (initial setting for positioning axis velocity)

This feedrate will apply until an axis-specific feedrate is programmed in the parts program for this axis.

Machine data

Table 10- 16 Positioning axes: Machine data

Number	Identifier	Name	Reference
Channel-specific (\$MC_ ...)			
22240	AUXFU_F_SYNC_TYPE	Output timing of F functions	H2
axis-specific (\$MA_ ...)			
30450	IS_CONCURRENT_POS_AX	Concurrent positioning axis	
32060	POS_AX_VELO	Feedrate for positioning axis	

Interface signals

Table 10- 17 Positioning axes: Interface signals

DB number	Bit, byte	Name	Reference
Axis/spindle-specific		Signals from PLC to axis/spindle	
31,...	0	Feedrate override, axis-specific	
31,...	2.2	Delete distance-to-go, axis-specific	
		Signals from axis/spindle to PLC	
31,...	74.5	Positioning axis	
31,...	78-81	F function (feedrate) for positioning axis	

Literature

Function Manual Expanded Functions; Positioning axes

10.5.6 Indexed axes/"Hirth" axes

Indexed axes are rotary or linear axes, which can be traversed to indexed positions by index program instructions.

These indexed positions are approached in JOG mode.

In "normal" positioning, every position can be approached.

Note

Traversing to indexing positions using the parts program or manually is only effective if the corresponding machine axis has been successfully referenced.

Hirth axes are indexing axes with Hirth tooth system. These axes are rotary or linear axes, which may only be traversed to defined positions, the indexing positions, within the traversing range (MD30505 \$MA_HIRTH_IS_ACTIVE).

The indexing positions are stored in tables.

Indexing axis

The following machine data assigns the machine axis the relevant table of indexing positions and also defines the machine axis as an indexing axis:

- MD30500 \$MA_INDEX_AX_ASSIGN_POS_TAB[n] (axis is indexing axis)

Indexing position tables

The indexing positions are stored in one of the 2 tables.

- MD10900 \$MN_INDEX_AX_LENGTH_POS_TAB_1 (number of positions of indexing table 1)
- MD10910 \$MN_INDEX_AX_POS_TAB_1 [n] (indexing position table 1)
- MD10920 \$MN_INDEX_AX_LENGTH_POS_TAB_2 (number of positions of indexing table 2)
- MD10930 \$MN_INDEX_AX_POS_TAB_2 [n] (indexing position table 2)

Machine data

Table 10- 18 Indexing axes: Machine data

Number	Identifier	Name	Reference
general (\$MN_ ...)			
10260	CONVERT_SCALING_SYSTEM	Basic system switch-over active	G2

Number	Identifier	Name	Reference
10270	POS_TAB_SCALING_SYSTEM	Measuring system of position tables	
10900	INDEX_AX_LENGTH_POS_TAB_1	Number of indexing positions used in Table 1	
10910	INDEX_AX_POS_TAB_1[n]	Indexing position table 1	
10920	INDEX_AX_LENGTH_POS_TAB_2	Number of indexing positions used in Table 2	
10930	INDEX_AX_POS_TAB_2[n]	Indexing position table 2	
Axis/spindle-specific (\$MA_ ...)			
30300	IS_ROT_AX	Rotary axis	R2
30310	ROT_IS_MODULO	Modulo conversion for rotary axis	R2
30320	DISPLAY_IS_MODULO	Position display is modulo 360 degrees	R2
30500	INDEX_AX_ASSIGN_POS_TAB	Axis is indexing axis	
30501	INDEX_AX_NUMERATOR	Numerator for indexing axes with equidistant positions	
30505	HIRTH_IS_ACTIVE	Axis is an indexing axis with Hirth tothing	

Interface signals

Table 10- 19 Indexing axes: Interface signals

DB number	Bit, byte	Name	Reference
Axis/spindle-specific		Signals from axis/spindle to PLC	
31,...	60.4, 60.5	Referenced/synchronized 1, referenced/synchronized 2	R1
31,...	76.6	Indexing axis in position	

Literature

Function Manual Expanded Functions; Indexing axes

10.5.7 Position controller

Control loops

The closed-loop control of a machine axis consists of the cascaded closed-loop control circuits of current controller, speed controller and position controller.




Figure 10-12 Control loops

Traversing direction

If the axis does not traverse into the desired direction, the appropriate adaptation is made in the following machine data:

- MD32100 \$MA_AX_MOTION_DIR (travel direction)

The value "-1" reverses the direction of motion.

Control direction

If the control direction of the position measuring system is incorrect, it can be adjusted with the following machine data:

- MD32110 \$MA_ENC_FEEDBACK_POL (sign of actual value)

Note

When DSC is activated on the incorrect position measuring system, the control direction must also be adjusted in SINAMICS parameter p410.

Servo gain

To obtain high contour accuracy, a high loop gain (K_v factor) of the position controller is required. However, an excessively high K_v factor causes overshoot, instability and impermissibly high machine loads.

The maximum permissible K_v factor is dependent on the dynamic response and the use of the feedforward control or DSC, of the drive and the mechanical system of the machine.

Note

The first commissioning is performed without feedforward control.

A K_v factor of "0" leads to the position controller being cut.

Definition of the K_v factor

The K_v factor is defined as the ratio of velocity in m/min and the resulting following error in mm

$$K_v = \frac{\text{Velocity}}{\text{Following error}} \left[\frac{[\text{m/min}]}{[\text{mm}]} \right]$$

This means for a K_v factor of 1 that at a velocity of 1m/min, a following error of 1mm results.

The K_v factor of the machine axis is entered via the following machine data:

- MD32200 \$MA_POSCTRL_GAIN (servo gain factor)

Note

To adapt the input/output unit of the K_v factor selected by default to the internal unit [1/s], the following machine data is assigned pre-assigned:

- MD10230 \$MN_SCALING_FACTORS_USER_DEF[9] = 16.666667
 - MD10220 \$MN_SCALING_USER_DEF_MASK = 'H200'; (bit no. 9 as hex value)
-

When entering the K_v factor it is important to note that the gain factor of the whole position control loop is still dependent on other parameters of the controlled system (speed setpoint alignment).

These factors include, among others:

- MD32260 \$MA_RATED_VELO
- MD32250 \$MA_RATED_OUTVAL
- Automatic interface alignment (SINAMICS parameter "Reference speed" p2000)

For drive optimization see Further optimization options (Page 241)

<p>NOTICE</p> <p>Machine axes that interpolate one with another must have the same dynamic response at the same velocities.</p> <p>This can be achieved by setting the same K_v factor or dynamic response adaptation in the following machine data:</p> <ul style="list-style-type: none"> • MD32900 \$MA_DYN_MATCH_ENABLE • MD32910 \$MA_DYN_MATCH_TIME <p>The real K_v factor can be checked with the following error in the service display.</p> <ul style="list-style-type: none"> • e.g., HMI Advanced: Operating area "Diagnosis" > "Service displays" > "Service axis"
--

Checking the loop gain

If a K_v factor is already known for a machine type in question, this can be set and checked. To ensure that the drive does not reach its current limit during acceleration and deceleration, the acceleration is reduced for checking via the following machine data:

- MD32300 \$MA_MAX_AX_ACCEL (axis acceleration)

The K_v factor must also be checked for high speeds of the rotary axis and spindle (e.g., for spindle positioning, tapping).

The approach behavior at various speeds can be checked by means of the HMI Advanced servo trace software. The speed setpoint is recorded for this purpose.




Figure 10-13 Speed setpoint characteristic

No overshoots may occur while the drive is approaching the static states; this applies to all speed ranges.

Overshoot in the position control loop

The reasons for an overshoot in the control loop can be:

- Acceleration too high (current limit is reached)
- Rise time too long (re-optimization necessary)
- Mechanical backlash
- Mechanical components canted

For safety reasons, set the K_v factor for each axis to a little less than the maximum possible value.

- MD32900 \$MA_DYN_MATCH_ENABLE[n]
- MD32910 \$MA_DYN_MATCH_TIME[n]

For axes interpolating with each other, the same K_v -factor should be set. Normally it is the K_v -factor of the weakest interpolating axis.

Contour monitoring must be set subsequently (MD36400 \$MA_CONTROL_TOL).

Acceleration

In the following machine data machine axes are accelerated and decelerated with the values entered.

- MD32300 \$MA_MAX_AX_ACCEL (axis acceleration)

This value should allow the axes to be accelerated and positioned fast and accurately, while ensuring that the machine is not loaded unduly.

Checking the acceleration

The sign of a properly adjusted acceleration of a machine axis is acceleration and positioning free from overshoot at rapid traverse rate and maximum load (max. external moment of inertia).

After the acceleration has been entered, the axis is traversed rapidly and the actual current values and current setpoint are recorded.

This recording shows whether the drive reaches the current limit. Here, the current limit can be reached for a short time.

The current must be well below the current limit, however, before the rapid traverse velocity or the final position is reached.

Load changes during the machining should not result in the current limit being reached, as they may result in contour errors. For this reason, the acceleration value should be a little bit less than the maximum acceleration value.

Machine axes can have different acceleration values, even if they interpolate with each other.

Jerk

For jerk, the following should be noted:

- For indexing program instructions (SOFT), the maximum jerk must be set in the following machine data:
 - MD32431 \$MA_MAX_AX_JERK (maximum jerk)
- For JOG and positioning axes the following machine data should be supplemented:
 - MD32420 \$MA_JOG_AND_POS_JERK_ENABLE
 - MD32430 \$MA_JOG_AND_POS_MAX_JERK

Machine data

Table 10- 20 Position control: Machine data

Number	Identifier	Name/remarks	Reference
axis spec. (\$MA_ ...)			
32100	AX_MOTION_DIR[n]	Traversing direction	
32110	ENC_FEEDBACK_POL[n]	Actual value sign	
32200	POSCTRL_GAIN [n]	KV factor	
32300	MAX_AX_ACCEL[n]	Axis acceleration	
32420	JOG_AND_POS_JERK_ENABLE	Enabling jerk limitation	
32430	JOG_AND_POS_MAX_JERK	Axial jerk	
32431	MAX_AX_JERK	Maximum axial jerk when traversing along the path	
32900	DYN_MATCH_ENABLE[n]	Dynamic response adaptation	
32910	DYN_MATCH_TIME [n]	Time constant for dynamic matching	
36400	CONTROL_TOL	Contour monitoring	

Literature

Function Manual; speed, setpoint/actual-value systems, control: Closed-loop control

Function Manual Extended Functions; Compensation, Section "Dynamic feedforward control (following error compensation)"

10.5.8 Speed setpoint matching

In the case of speed setpoint comparison, the NC is informed, which speed setpoint corresponds to which motor speed in the drive, for parameterizing the axial control and monitoring. Speed setpoint matching can be performed automatically or manually.

Automatic adjustment

It is possible to perform automatic speed setpoint adjustment if the drive supports acyclic services on the PROFIBUS-DP (standard for SINAMICS).

Acyclic services on the PROFIBUS-DP are supported

if in the following machine data the value "0" is entered:

- MD32250 \$MA_RATED_OUTVAL (rated output voltage) [%]

During start-up of the NCK, speed setpoint matching between the NCK and the drive is then performed automatically.

 WARNING
--

The SINAMICS parameter "Reference speed" p2000 may not be changed during operation of the control with the drive.

Note

If automatic speed setpoint matching fails for one axis, the following message is output on a traverse request for this axis:

- Message: "Wait, axis enable missing"

This axis and any axes that interpolate with it are not traversed.

Manual comparison

The speed setpoint alignment (interface normalization) is specified in the following machine data:

- MD32250 \$MA_RATED_OUTVAL (rated output voltage) [%]
- MD32260 \$MA_RATED_VELO (rated motor speed)

If a non-zero value is entered into the following machine data, the NCK assumes that speed setpoint matching will be performed manually.

- MD32250 \$MA_RATED_OUTVAL (rated output voltage) [%]

Note

The maximum upper limit for the speed setpoint is set in machine data

- MD36210 \$MA_CTRL_OUT_LIMIT (maximum speed setpoint) [%].
-

Calculation of the motor speed

If the motor speed required for speed setpoint matching is not known directly, it can be calculated as follows with reference to the required axis velocity (linear axis) or load speed (rotary axis/spindle):

Motor speed for linear axis

$$n_{Motor} = \frac{v_{Axis} * \frac{MD31060 \$MA_DRIVE_RATIO_NUMERA}{MD31050 \$MA_DRIVE_RATIO_DENOM}}{MD31030 \$MA_LEADSCREW_PITCH}$$

Motor speed for rotary axis/spindle

$$n_{Motor} = n_{Load} * \frac{MD31060 \$MA_DRIVE_RATIO_NUMERA}{MD31050 \$MA_DRIVE_RATIO_DENOM}$$

- v_{Axis} [mm/min]
- MD31060 \$MA_DRIVE_RATIO_NUMERA (load gearbox numerator)
- MD31050 \$MA_DRIVE_RATIO_DENOM (load gearbox denominator)
- MD31030 \$MA_LEADSCREW_PITCH (leadscrew pitch) [mm/rev]
- n_{Motor} [rpm]
- n_{Load} [rpm]

Checking the trim

Incorrect speed setpoint matching has a negative impact on the real loop gain of the axis.

To check speed setpoint matching it is necessary for a defined traverse velocity to compare the actual following error with the desired following error that should be set if speed setpoint matching is correct.

$$\text{Desired following error} = \frac{\text{Traversing speed}}{MD32200 \$MA_POSCTRL_GAIN}$$

- Desired following error [mm]
- Traversing velocity [m/min]
- MD32200 \$MA_POSCTRL_GAIN (servo gain factor) [(m/min)/mm]

The actual following error is shown in the axis-specific service data:

HMI:

Operating area "Diagnostics" > "Service displays" > "Service axis/spindle"

Machine data

Table 10- 21 Speed setpoint matching: Machine data

Number	Identifier	Name/remarks	Reference
Axis-spec. (\$MA_ ...)			
32250	RATED_OUTVAL	Rated output voltage [%]	G2
32260	RATED_VELO	Rated motor speed	G2

Literature

Function Manual Basic Functions;
Speeds, setpoint/actual value systems, control, Chapter "Speeds, traversing ranges, accuracy"

10.5.9 Drift compensation

Digital drives

Digital drives are not subject to drift or compensate for it automatically.

Machine data

Table 10- 22 Drift compensation: Machine data

Number	Identifier	Name/remarks	Reference
axis spec. (\$MA_ ...)			
36720	DRIFT_VALUE	Basic drift value, always = 0 Note: 0 recommended for digital drive.	G2

10.5.10 Velocity matching (axis)

Max. axis velocity

The value entered in the following machine data is the limit velocity up to which a machine axis can accelerate (rapid traverse limiting). It depends on the machine and drive dynamics and the limit frequency of actual-value acquisition.

- MD32000 \$MA_MAX_AX_VELO[n] (max. axis velocity)

The max. axis velocity is used for traversing in the parts program when rapid traverse (G00) is programmed.

The maximum linear or rotary axis velocity should be entered in the machine data in accordance with MD30300 \$MA_IS_ROT_AX[n].

Rapid traverse in JOG mode

The value entered in the following machine data is the velocity at which the machine axis traverses in JOG mode with the rapid traverse override key actuated and with an axial feedrate override of 100%.

- MD32010 \$MA_JOG_VELO_RAPID[n] (rapid traverse in JOG mode) or
- MD32040 \$MA_JOG_REV_VELO_RAPID[n] (revolutional feedrate in JOG mode with rapid traverse override)

The entered value may not exceed the max. permissible axis velocity.

This machine data will not be used for the programmed rapid traverse G00.

JOG axis velocity

The value entered in this machine data is the velocity at which the machine axis traverses in JOG mode with an axial feedrate override of 100%:

- MD32020 \$MA_JOG_VELO[n] (axis velocity in JOG mode) or
- MD32050 \$MA_JOG_REV_VELO[n] (revolutional feedrate in JOG mode)

The velocity from MD32020 JOG_VELO[n] or MD32050 JOG_REV_VELO[n] is used only if

- for linear axes: SD41110 \$SN_JOG_SET_VELO = 0
- for rotary axes: SD41130 \$SN_JOG_ROT_AX_SET_VELO = 0

or

- for reverse feed: SD41120 \$SN_JOG_REV_SET_VELO = 0

If the above mentioned setting data are unequal to 0, the JOG velocity results as follows:

1. SD41100 \$SN_JOG_REV_IS_ACTIVE (revolutional feedrate in JOG mode) = 0

=> Linear feedrate (G94)

- Linear axes:

JOG velocity = SD41110 \$SN_JOG_SET_VELO (JOG velocity for G94)

- Rotary axes:

JOG velocity = SD41130 \$SN_JOG_ROT_AX_SET_VELO (JOG velocity for rotary axes)

2. SD41100 \$SN_JOG_REV_IS_ACTIVE (revolutional feedrate in JOG mode) = 1

- JOG velocity = SD41120 \$SN_JOG_REV_SET_VELO (JOG velocity for G95)

The entered value may not exceed the max. permissible axis velocity.

NOTICE

Depending on MD30300 \$MA_IS_ROT_AX[n], the velocities have to be entered in mm/min, inch/min, or rpm.

If the velocities are changed, MD36200 \$MA_AX_VELO_LIMIT[n] (threshold value for velocity monitoring) must be adapted accordingly.

Machine data

Table 10- 23 Velocities: Machine data

Number	Identifier	Name / remarks	Reference
axis-spec. (\$MA_ ...)			
30300	IS_ROT_AX[n]	Rotary axis	
32000	MAX_AX_VELO[n]	Maximum axis velocity	G2
32010	JOG_VELO_RAPID[n]	Rapid traverse in JOG mode	
32020	JOG_VELO[n]	JOG axis velocity	
32040	JOG_REV_VELO_RAPID[n]	Revolutions feedrate in JOG mode with rapid traverse override	
32050	JOG_REV_VELO[n]	Revolutional feedrate in JOG mode	
32060	POS_AX_VELO[n]	Initial setting for positioning axis velocity	P2
32250	RATED_OUTVAL	Rated output voltage	
32260	RATED_VELO[n]	Rated motor speed	

Setting data

Table 10- 24 Velocities: Setting data

Number	Identifier	Name / remarks	Reference
General (\$SN_ ...)			
41100	JOG_REV_IS_ACTIVE	Revolutional feedrate in JOG mode active	
41110	JOG_SET_VELO	JOG velocity for linear axes (for G94)	
41120	JOG_REV_SET_VELO	JOG velocity (for G95)	
41130	JOG_ROT_AX_SET_VELO	JOG speed for rotary axes	
41200	JOG_SPIND_SET_VELO	JOG velocity for the spindle	

Literature

Function Manual Basic Functions;
Speeds, setpoint/actual value systems, control, Chapter "Speeds, traversing ranges, accuracy"

Function Manual, Expanded Functions; Manual and Hand Wheel Travel

10.5.11 Axis monitoring

Static monitoring functions

The static monitoring functions with reference to a machine axis are:

Exact stop coarse

Window around the setpoint position within which exact stop coarse is detected.

- MD36000 \$MA_STOP_LIMIT_COARSE (exact stop coarse)
- IS: DB31,... DBX60.6 (position reached with exact stop coarse)

Exact stop fine

Window around the setpoint position within which exact stop fine is detected.

- MD36010 \$MA_STOP_LIMIT_FINE (exact stop fine)
- IS: DB31,... DBX60.7 (position reached with exact stop coarse)

Delay time exact stop fine

Delay time after which the actual value must have reached the tolerance window "Exact stop fine" when the setpoint position is reached.

- MD36020 \$MA_POSITIONING_TIME (delay time exact stop fine)
- Alarm: "25080 Positioning monitoring" and follow-up mode.

Zero speed tolerance

Position tolerance which a standing machine axis may not leave.

- MD36030 \$MA_STANDSTILL_POS_TOL (standstill tolerance)
- Alarm: "25040 Zero speed control" and follow-up mode.

Delay time zero speed monitoring

Delay time after which the actual value must have reached the tolerance window "Zero speed tolerance" when the setpoint position is reached.

- MD36040 \$MA_STANDSTILL_DELAY_TIME (Zero-speed monitoring delay time)
- Alarm: "25040 Zero speed control" and follow-up mode.

Clamping tolerance

Tolerance window for a standing machine axis while the signal "Clamping active" is present at the PLC interface.

- MD36050 \$MA_CLAMP_POS_TOL (clamping tolerance)
- IS: DB31,... DBX2.3 (clamping active)
- Alarm: "26000 Clamping monitoring"




Figure 10-14 Static monitoring functions

Working area limitation

The permissible working area of the machine axes can be adapted to the particular machining situation using the "dynamic" working area limitation.

- SD43400 \$SA_WORKAREA_PLUS_ENABLE (Working area limitation active in the positive direction)
- SD43410 \$SA_WORKAREA_MINUS_ENABLE (Working area limitation active in the negative direction)
- SD43420 \$SA_WORKAREA_LIMIT_PLUS (Working area limitation plus)
- SD43430 \$SA_WORKAREA_LIMIT_MINUS (Working area limitation minus)
- Alarm: "10630 Axis reaching operating range limit +/-"
- Alarm: "10631 Axis is at operating range limit +/- (JOG)"
- Alarm: "10730 Progr. end point is behind working area limitation +/-"

Software limit switches

Two software limit switch pairs are provided per machine axis. The active software limit switch pair is selected in the PLC.

- MD36100 \$MA_POS_LIMIT_MINUS (1st software limit switch minus)
- MD36110 \$MA_POS_LIMIT_PLUS (1st software limit switch plus)
- MD36120 \$MA_POS_LIMIT_MINUS2 (2nd software limit switch minus)
- MD36130 \$MA_POS_LIMIT_PLUS2 (2nd software limit switch plus)
- IS: DB31,... DBX12.2 (2nd software limit switch minus)
- IS: DB31,... DBX12.3 (2nd software limit switch plus)
- Alarm: "10620 Axis reaching software limit switch +/-"
- Alarm: "10621 Axis is at software limit switch +/- (JOG)"
- Alarm: "10720 Progr. end point is behind software limit switch +/-"

NOTICE

All position monitoring functions are only active with valid reference point of the corresponding reference point of the machine axis.

Hardware limit switches

If the PLC signals that a hardware limit switch has been reached, the machine axis is stopped with the parameterized brake response.

- IS: DB31, ... DBX12.1 (hardware limit switch plus)
- IS: DB31, ... DBX12.0 (hardware limit switch minus)
- MD36600 \$MA_BRAKE_MODE_CHOICE (braking behavior on hardware limit switch)
 - 0 = Brake characteristic is complied with
 - 1 = Rapid deceleration with setpoint "0"
- Alarm: "21614 Hardware limit switch [+/-]"




Figure 10-15 Overview of end limitations

Dynamic monitoring functions

The dynamic monitoring functions with reference to a machine axis are:

Speed setpoint monitoring

The speed setpoint monitoring prevents that the max. admissible motor speed is exceeded. It must be set such that the max. velocity (rapid traverse) can be reached and, in addition, a certain control margin remains.

- MD36210 \$MA_CTRLLOUT_LIMIT[n] (maximum speed setpoint as %)




Figure 10-16 Speed setpoint limitation

The following machine data is used to define how long the speed setpoint may remain within the limits before the speed setpoint monitoring responds.

- MD36220 \$MA_CTRLLOUT_LIMIT_TIME[n] (delay time for speed setpoint monitoring)

Error response

- Alarm: "25060 Speed setpoint limiting"

and stopping the machine axis using a speed setpoint ramp whose characteristic is set in

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)

Cause of errors/error handling

- A measuring circuit error or drive error is present.
- Setpoints are too high (accelerations, velocities, reducing factors).
- Obstacle in the machining space (e.g. tool hits working table) => remove obstacle.

The speed setpoint consists of the speed setpoint of the position controller and the feedforward control parameter (if feedforward control is active).




Figure 10-17 Speed setpoint calculation

NOTICE

The limitation of the speed setpoint will turn the control loop into a nonlinear control loop. Generally, this will result in deviations from the contour and longer dwelling of the machine axis within the speed setpoint limitation.

Actual velocity monitoring

Monitoring due to the actual velocity of the machine axis determined based on the encoder values

- MD36020 \$MA_AX_VELO_LIMIT (velocity-monitoring threshold)

Error response

- Alarm: "25030 Alarm limit of actual velocity"

and stopping the machine axis using a speed setpoint ramp whose characteristic is set in

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)

Remedy

- Check actual values
- Check position control direction (control sense)
- Threshold value for velocity monitoring is possibly too low.

Contour monitoring

Monitoring of the difference between the following error measured and the following error calculated from the position setpoint.

- MD36400 CONTOUR_TOL (contour monitoring tolerance range)

Error response

- Alarm: "25050 Contour monitoring"

and stopping the machine axis using a speed setpoint ramp whose characteristic is set in

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur).

Remedy

Contour errors are caused by signal distortions in the position control loop.

Remedy:

- Increase the tolerance band
- Checking the K_v factor:

The real K_v factor must correspond to the desired K_v factor, set via MD32200 \$MA_POSCTRL_GAIN[n] (K_v factor).

HMI-Advanced

Operating area "DIAGNOSTICS" > "Service displays" > "Service axis"

- Check optimization of the speed controller
- Check smooth running of the axes
- Check machine data for traversing motions
(Feedrate override, acceleration, max. velocities, ...)
- For operation with feedforward control:
MD32810 \$MA_EQUIV_SPEEDCTRL_TIME (equivalent time constant of speed control loop for feedforward control) or if the machine data is imprecisely set, the MD36400 \$MA_CONTOUR_TOL must be enlarged.

Encoder limit frequency monitoring

Monitoring of the limit frequency of the encoder of a machine axis.

- MD36300 \$MA_ENC_FREQ_LIMIT (encoder limit frequency)

Error response

- Alarm: "21610 Encoder frequency exceeded"
- IS: DB31, ... DBX60.2 "Encoder limit frequency exceeded 1"
- IS: DB31, ... DBX60.3 "Encoder limit frequency exceeded 2"

and stopping the machine axis using a speed setpoint ramp whose characteristic is set in

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)

Remedy

After the axes have come to a stop, the position control is resumed after the alarm (RESET at the machine control panel) is acknowledged.

NOTICE
The axis affected must be re-referenced.

Encoder zero mark monitoring

The zero mark monitoring of the encoder of a machine axis checks whether pulses were lost between two zero mark passes.

- MD36310 \$MA_ENC_ZERO_MONITORING (zero-mark monitoring)

is used to enter the number of detected zero mark errors at which the monitoring is to respond.

Special situation:

A value of 100 will additionally disable hardware monitoring of the encoder.

Error response

- Alarm: "25020 Zero mark monitoring"

and stopping the machine axes using a speed setpoint ramp whose characteristic is set in

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur).

Error causes

- MD36300 \$MA_ENC_FREQ_LIMIT [n] (encoder limit frequency) set too high.
- Encoder cable damaged.
- Encoder or encoder electronics defective.

Position tolerance when switching over the encoder

It is possible to switch between the two encoders or position measuring systems of a machine axis at any time. The permissible position difference between the two position measuring systems when switching over is monitored.

- MD36500 \$MA_ENC_CHANGE_TOL (max. tolerance on position actual value switchover)

Error response

- Alarm: "25100 Measuring system cannot be switched over"

The requested switchover to another encoder is not carried out.

Error causes

- The specified permissible tolerance is too small.
- The position measuring system to which you want to switch over to is not referenced.

Cyclic monitoring of the encoder position tolerance

The position difference between the two encoders or position measuring systems of a machine axis is monitored with

- MD36510 \$MA_ENC_DIFF_TOL (measuring system synchronism tolerance)

Error response

- Alarm: "25105 Measuring systems are not synchronous"

and stopping the machine axes using a speed setpoint ramp whose characteristic is set in the following machine data:

- MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)




Figure 10-18 Monitoring for SINUMERIK 840D sl:

NOTICE

MD36620 \$MA_SERVO_DISABLE_DELAY_TIME (switch-off delay servo enable)
must always be selected greater than
MD36610 \$MA_AX_EMERGENCY_STOP_TIME (braking ramp time when errors occur)
If this is not the case, the braking ramp cannot be kept.

Literature

Function Manual Basic Functions; Axis monitoring: Protection zones

10.5.12 Axis homing

Referencing

When referencing a machine axis, the actual position value system of the machine axis is synchronized with the machine geometry. Depending on the encoder type used, the machine axis is referenced with or without traversing movements.

Reference point approach

For all machine axes which are not equipped with an encoder providing an absolute actual position value, referencing is carried out by traversing the machine axis to a reference point; this is called the reference point approach.

The reference point approach can be carried out either manually in JOG mode, submode REF, or using a parts program.

With the operating mode JOG and submode REF, reference point approach is started using traverse direction keys PLUS or MINUS (depending on the parameterized reference point approach direction).

10.5.12.1 Incremental measuring system

Incremental measuring systems

With incremental measuring systems, referencing is carried out using a reference point approach divided into three phases:

1. Traversing to the reference cam
2. Synchronizing to the encoder zero marker
3. Approach reference point




Figure 10-19 Signal chart: Referencing with an incremental measuring system (principle)

Phase-independent data

The following **machine data** and **interface signals** are relevant in each of the individual phases of the reference point approach:

- MD11300 \$MN_JOG_INC_MODE_LEVELTRIGGRD (INC/REF in jog mode)
- MD34000 \$MA_REFP_CAM_IS_ACTIVE (axis with reference cam)
- MD34110 \$MA_REFP_CYCLE_NR (axis sequence for channel-specific reference point approach)
- MD30240 \$MA_ENC_TYPE (encoder type)
- MD34200 \$MA_ENC_REFP_MODE (referencing mode)
- IS: DB21, ... DBX1.0 ("Activate referencing")
- IS: DB21, ... DBX33.0 ("Referencing active")

Phase 1: Traversing to the reference cam

The following **machine data** and **interface signals** are relevant:

- MD34010 \$MA_REFP_CAM_DIR_IS_MINUS (approach reference cam in minus direction)
- MD34020 \$MA_REFP_VELO_SEARCH_CAM (reference cam approach velocity)
- MD34030 \$MA_REFP_MAX_CAM_DIST (maximum distance to the reference cam)
- MD34092 \$MA_REFP_CAM_SHIFT (electr. cam offset, incremental measuring systems with equidistant zero markers)
- IS: DB21, ... DBX36.2 ("All axes with obligatory reference point are referenced")
- IS: DB31, ... DBX4.7/DBX4.6 ("Traversing keys plus/minus")
- IS: DB31, ... DBX12.7 ("Reference point approach delay")
- IS: DB31, ... DBX60.4, DBX60.5 ("Referenced/synchronized 1, 2")

Properties of phase 1:

- The feedrate override (feedrate switch) is active.
- The feed stop (channel-specific and axis-specific) is active.
- The machine axis can be stopped and restarted with NC-stop/NC-start.
- The machine axis traverses a distance specified in the following machine data from the starting position in the direction of the reference cam, without reaching the reference cam.
 - MD34030 \$MA_REFP_MAX_CAM_DIST (max. distance to reference cam)
- The following interface signal is set to "0". The axis stops, and alarm 20000 "Reference cam not reached" is output.
 - IS: DB31, ... DBX12.7 ("Reference point approach delay") = 0

 WARNING
<p>If the reference cam is not calibrated exactly, it is possible that a wrong zero mark is evaluated after the reference cam has been left. As a result, the control system will take a wrong machine zero.</p> <p>Software limit switches, protection areas and work area limits will thus also be active for the wrong positions. The difference is equivalent to one encoder revolution in each case.</p> <p>Danger for man and machine exists.</p>

Phase 2: Synchronizing to the encoder zero mark

The following **machine data** and **interface signals** are relevant:

- MD34040 \$MA_REFP_VELO_SEARCH_MARKER (creep velocity)
- MD34050 \$MA_REFP_SEARCH_MARKER_REVERSE (direction reversal on reference cam)
- MD34060 \$MA_REFP_MAX_MARKER_DIST (maximum distance from cam to reference mark)

Properties of phase 2:

- Feed override (the feed override switch) is not active.
If a feed override of 0% is selected via the feed override switch, the traverse movement is stopped.
- Feed stop (channel-specific and axis-specific) is active.
On a feed stop, the traverse movement is stopped and the alarm displayed:
- Alarm 20005 "Reference point approach canceled"
- NC-Stop/NC-Start is inactive.
- With IS: DB31, ... DBX12.7 ("Reference point approach delay") = 0, the machine axis traverses a distance parameterized in the following machine data after leaving the reference cam.
 - MD34060 \$MA_REFP_MAX_MARKER_DIST (max. distance to the reference mark)
Without the zero mark being detected, the machine axis stops and the following alarm is displayed:
Alarm 20002 "Zero mark missing"

Phase 3: Approach reference point

The following **machine data** and **interface signals** are relevant:

- MD34070 \$MA_REFP_VELO_POS (reference point positioning velocity)
- MD34080 \$MA_REFP_MOVE_DIST (reference point distance to zero mark)
- MD34090 \$MA_REFP_MOVE_DIST_CORR (reference point offset, additive)
- MD34100 \$MA_REFP_SET_POS (reference point value)
- IS: DB31, ... DBX2.4, 2.5, 2.6, 2.7 ("Reference point value 1...4")
- IS: DB31, ... DBX60.4, DBX60.5 ("Referenced/synchronized 1, 2")

Properties of phase 3:

- Feed override (the feed override switch) is active.
- Feed stop (channel-specific and axis-specific) is active.
- NC-Stop/NC-Start is active.

Literature

Function Manual Basic Functions; Reference point approach: Referencing with incremental measurement systems

10.5.12.2 Distance-coded reference marks

Distance-coded reference marks

When clearance-coded reference marks are used, referencing is divided into 2 phases:

1. Synchronize by overriding 2 reference marks
2. Traverse to target point




Figure 10-20 Signal chart: Distance-coded reference marks (principle)

Phase-independent data

The following **machine data** and **interface signals** are independent with respect to the individual phases of reference point approach:

- MD11300 \$MN_JOG_INC_MODE_LEVELTRIGGRD (INC/REF in jog mode)
- MD34000 \$MA_REFP_CAM_IS_ACTIVE (axis with reference cam)
- MD34110 \$MA_REFP_CYCLE_NR (axis sequence for channel-specific reference point approach)
- MD30240 \$MA_ENC_TYPE (encoder type)
- MD34200 \$MA_ENC_REFP_MODE (referencing mode)
- MD34310 \$MA_ENC_MARKER_INC (interval between two reference marks)
- MD34320 \$MA_ENC_INVERS (inverse measuring system)
- IS: DB21, ... DBX1.0 ("Activate referencing")
- IS: DB21, ... DBX33.0 ("Referencing active")

Phase 1: Synchronize by overriding 2 reference marks

The following **machine data** and **interface signals** are relevant:

- MD34010 \$MA REFP_CAM_DIR_IS_MINUS (approach reference cam in negative direction)
- MD34040 \$MA REFP_VELO_SEARCH_MARKER (referencing velocity)
- MD34060 \$MA REFP_MAX_MARKER_DIST (maximum distance between 2 reference marks)
- MD34300 \$MA ENC_REFP_MARKER_DIST (reference mark distance)
- IS: DB21 .. 30, DBX36.2 ("All axes to be referenced are referenced")
- IS: DB31, ... DBX4.7/DBX4.6 ("Traversing keys plus/minus")
- IS: DB31, ... DBX12.7 ("Reference point approach delay")
- IS: DB31, ... DBX60.4, DBX60.5 ("Referenced/synchronized 1, 2")

Properties of phase 1:

- If the machine axis travels from the initial position a distance defined in MD34300 \$MA REFP_MARKER_DIST (max. distance to the reference mark) without two reference marks being overridden, then the machine axis stops and the system issues alarm 20004 "Reference mark missing".

Phase 2: Traversing to the target point

The following **machine data** and **interface signals** are relevant:

- MD34070 \$MA REFP_VELO_POS (target point positioning velocity)
- MD34090 \$MA REFP_MOVE_DIST_CORR (absolute offset)
- MD34100 \$MA REFP_SET_POS (target point)
- MD34330 \$MA REFP_STOP_AT_ABS_MARKER (with/without target point)
- IS: DB31, ... DBX60.4, DBX60.5 ("Referenced/synchronized 1, 2")

Properties of phase 2:

- The feed rate override (feed rate switch) is active.
- The feed stop (channel-specific and axis-specific) is active.
- The machine axis can be stopped and restarted with NC stop/NC start.

Determining the absolute offset

To determine the absolute offset between the measuring system zero point and the machine zero, the following procedure is recommended:

1. Determining the actual position of the measuring system

After two reference marks following one after the other (synchronized) have been overtraveled, the actual position of the length measuring system can be read on the user interface at "Actual position".

The absolute offset must be zero at this time:

- MD34090 \$MA REFP_MOVE_DIST_CORR = 0

1. Determine the absolute machine actual position

Determining the absolute machine actual position, e.g., can be performed by traversing the machine axis to a known position (fixed stop). Alternatively, it can be measured at any position (laser interferometer).

2. Calculating the absolute offset

Linear measurement system non-inverse to machine system:

Absolute offset = machine actual position + actual position of the measuring system

Linear measuring system inverse to machine system:

Absolute offset = machine actual position - actual position of the measuring system

- MD34090 \$MA REFP_MOVE_DIST_CORR (reference point/absolute offset)

 WARNING
--

After you have determined the absolute offset and made an entry in
--

- | |
|--|
| <ul style="list-style-type: none">• MD34090 \$MA REFP_MOVE_DIST_CORR (absolute offset) |
|--|

the position measuring system must be re-referenced.
--

Literature

Function Manual Basic Functions; Reference point approach: Referencing with length measuring systems with distance-coded reference marks

10.5.12.3 Absolute encoders

Absolute encoder

Initial referencing of the measuring system of a machine axis with absolute encoder is performed by calibrating the encoder.

Follow-up referencing

Follow-up referencing of a machine axis is performed automatically while the NC starts up without axis movement. The following conditions must be fulfilled:

- The measuring system of the machine axis active after the booting of the NC works with the absolute encoder
- The absolute encoder is calibrated:

MD34210 \$MA_ENC_REFP_STATE[n] = 2 (absolute value encoder is calibrated)

Calibration

To calibrate the absolute encoder, the actual value of the encoder is matched with the machine zero once and then enabled.

The SINUMERIK 840D sl supports the following types of calibration:

- Operator-assisted calibration
- Automatic calibration using probe
- Calibration using BERO

The calibration using the probe and BERO is described in:

Literature

Function Manual Basic Functions; Reference point approach: Automatic adjustment with measuring probe, adjustment with BERO

Operator-assisted calibration

During operator-assisted calibration, the machine axis of the absolute encoder is moved to the known machine position (reference position). The position value of the reference position is taken over by the NC as the reference point value.

Recommended procedure

1. Parameterization of referencing mode

- MD34200 \$MA_ENC_REFP_MODE[n] = 0

2. Approaching referencing position

Traversing the machine axis to the referencing position in JOG mode. Approach direction according to machine data:

- MD34010 \$MA_REFP_CAM_DIR_IS_MINUS (reference point approach in minus direction) (0 = positive, 1 = negative approach direction)

NOTICE
To avoid the actual position of the machine axis being falsified by backlash in the drive train, reference point approach must be performed at low velocity and always from the same direction.

3. Assumption of the reference position in the NC

The reference position is entered in the machine data:

- MD34100 \$MA_REFP_SET_POS[n] (reference point value)

4. Enabling encoder calibration

Encoder calibration is performed in the machine data:

- MD34210 \$MA_ENC_REFP_STATE[n] = 1

5. Activate changed machine data by NCK reset.

6. Completing encoder calibration

When the NC has started up, encoder calibration is completed in mode: JOG > REF for the machine axis by once more pressing the direction key as described in point 2:

- Select JOG > REF mode
- Select machine axis
- Press traverse direction key

Note

Pressing the traverse direction key does not move the machine axis!

The NC then calculates the reference point offset and enters it in the machine data:

- MD34090 \$MA_REFP_MOVE_DIST_CORR[n] (reference point offset)

To indicate that calibration has been completed, the value in the machine data changes from 1 = enable encoder calibration to 2 = encoder calibrated:

- MD34210 \$MA_ENC_REFP_STATE[n] = 2

The value from the machine data is shown as the actual position of the machine axis for the current machine position on the user interface:

- MD34100 \$MA_REFP_SET_POS[n] (reference point value)

Calibrating several absolute encoders

For time-optimized calibration of the absolute encoders of several machine axes, the following procedure is recommended:

1. Depending on the machine design, move all or several machine axes to their reference position. See above: Points 1 to 4.
2. Perform an NCK reset. See above: Point 5.
3. Complete encoder calibration for all machine axes. See above: Point 6.

Recalibration

Recalibration of the absolute encoder is required after:

- Gear change between load and absolute encoder
- Removal/installation of the absolute encoder (encoder replacement)
- Removal/installation of the motor with the absolute encoder (motor replacement)
- SRAM data loss of the NC, battery power failure. In this case, it is necessary to load a series startup file.
- PRESET

NOTICE

The status of the absolute encoder is only automatically reset to 1 = "encoder not calibrated" by the NCK on gear change:

- MD34210 \$MA_ENC_REFP_STATE[n] = 1

In all other cases, it is the sole responsibility of the NCK user to indicate the uncalibrated state of the absolute encoder by manually resetting the status to "encoder not calibrated" and to perform calibration again.

A recalibration of the absolute encoder is also required when machine data MD34210 \$MA_ENC_REFP_STATE[n] is set to zero under the following conditions:

- Alarm 25020 "Zero mark monitoring of the active encoder" has been issued.
- The control has been switched off during the consistency check.
- The encoder number has changed.

Literature

Function Manual Basic Functions; Reference point approach: Referencing with absolute encoders

10.5.12.4 Interface signals and machine data

Interface signals

Table 10- 25 Referencing: Interface signals

DB number	Bit, byte	Name	Reference
Mode-group-specific		Signals from PLC to mode group	
11, ...	0.7	Mode group reset	K1
11, ...	1.2	Machine function REF	K1
Mode-group-specific		Signals from mode group to PLC	
11, ...	5.2	Active machine function REF	K1
Channel-specific		Signals from PLC to channel	
21, ...	1.0	Activate referencing	
Channel-specific		Signals from channel to PLC	
21, ...	28.7	(MMC -> PLC) REF	K1
21, ...	33.0	Referencing active	
21, ...	35.7	Reset	K1
21, ...	36.2	All axes that must have a reference point are referenced	
Axis-specific		Signals from PLC to axis/spindle	
31, ...	1.5/1.6	Position measuring system 1/position measuring system 2	A2
31, ...	2.4-2.7	Reference point value 1 to 4	
31, ...	4.6/4.7	Traversing keys minus/plus	H1
31, ...	12.7	Reference point approach delay	
Axis-specific		Signals from axis/spindle to PLC	
31, ...	60.4/60.5	Referenced, synchronized 1/Referenced, synchronized 2	
31, ...	64.6/64.7	Traverse command minus/plus	H1

Machine data

Table 10- 26 Referencing: Machine data

Number	Name of Identifier	Name	Reference
General (\$MN_ ...)			
11300	JOG_INC_MODE_LEVELTRIGGRD	INC/REF in jog/continuous mode	H1
Channel-specific (\$MC_ ...)			
20700	REFP_NC_START_LOCK	NC start disable without reference point	

Number	Name of Identifier	Name	Reference
axis-specific (\$MA_ ...)			
30200	NUM_ENCS	Number of encoders	G2
30240	ENC_TYP	Actual value encoder type	
30242	ENC_IS_INDEPENDENT	Encoder is independent	G2
31122	BERO_DELAY_TIME_PLUS	BERO delay time in plus direction	S1
31123	BERO_DELAY_TIME_MINUS	BERO delay time in minus direction	S1
34000	REFP_CAM_IS_ACTIVE	Axis with reference cam	
34010	REFP_CAM_DIR_IS_MINUS	Reference point approach in minus direction	
34020	REFP_VELO_SEARCH_CAM	Reference point approach velocity	
34030	REFP_MAX_CAM_DIST	Maximum distance to reference cam	
34040	REFP_VELO_SEARCH_MARKER[n]	Reference point creep speed [encoder number]	
34050	REFP_SEARCH_MARKER_REVERSE[n]	Change of direction on reference cam [encoder number]	
34060	REFP_MAX_MARKER_DIST[n]	Maximum distance to reference mark; Maximum distance to 2 reference marks with distance-coded scales [encoder number]	
34070	REFP_VELO_POS	Reference point positioning velocity	
34080	REFP_MOVE_DIST[n]	Reference point distance/target point with distance-coded system [encoder number]	
34090	REFP_MOVE_DIST_CORR[n]	Reference point/absolute offset, distance-coded [encoder number]	
34092	REFP_CAM_SHIFT	Electronic reference cam shift for incremental measurement systems with equidistant zero marks.	
34100	REFP_SET_POS[n]	Reference point value [reference point number]	
34102	REFP_SYNC_ENCS	Actual value adjustment to the referencing measurement system	
34110	REFP_CYCLE_NR	Axis sequence for channel-specific referencing	
34120	REFP_BERO_LOW_ACTIVE	Polarity change of BERO	
34200	ENC_REFP_MODE[n]	Referencing mode [encoder number]	
34210	ENC_REFP_STATE[n]	Status of absolute value encoder [encoder number]	
34220	ENC_ABS_TURNS_MODULO	Absolute value encoder range for rotary encoders	R2
34300	ENC_REFP_MARKER_DIST[n]	Reference marker distance with distance-coded scales [encoder number]	
34310	ENC_MARKER_INC[n]	Interval between two reference marks with distance-coded scales [encoder no.]	
34320	ENC_INVERS[encoder]	Linear measuring system inverse to machine system [encoder number]	
34330	REFP_STOP_AT_ABS_MARKER[n]	Distance-coded linear measurement system without destination point [encoder number]	

Number	Name of Identifier	Name	Reference
35150	SPIND_DES_VELO_TOL	Spindle speed tolerance	S1
36302	ENC_FREQ_LIMIT_LOW	Encoder limit frequency re-synchronization	
36310	ENC_ZERO_MONITORING	Zero mark monitoring	
30250	ACT_POS_ABS	Absolute encoder position at time of deactivation.	

Literature

Function Manual Basic Functions; Reference point approach

10.6 Parameterization of spindle data

Reference

See also

- Spindle data (Page 482)
- Spindle modes (Page 483)
- Initial spindle state (Page 483)
- General functionality (Page 484)
- General functionality (Page 484)

10.6.1 Setpoint/actual value channels of spindle

Parameterization of the setpoint/actual value channels of a spindle is identical to parameterization of the setpoint and actual value channels of an axis. For this, see Section "Setpoint / actual value channels" (Page 479).

10.6.2 Gear stages

Enabling of

The gear stage change is generally carried out in the following machine data:

- MD35010 \$MA_GEAR_STEP_CHANGE_ENABLE (gear stage change possible, spindle has several gear stages)

If this machine data is not set, the system assumes that the spindle has no gear stages.

Multiple gearbox steps

If more than one gearbox step exists, the number of gearbox steps is entered into MD35090 \$MA_NUM_GEAR_STEPS.

Parameter sets

In **spindle mode** of a spindle, the NC will select the parameter set that suits the current gear stage best.

Gear stage $x \Rightarrow$ parameter set $(x+1) \Rightarrow$ index $[x]$

In **axis mode** of a spindle, the NC always selects the 1st parameter set (index $[0]$), independent of the current gear stage.

The machine data listed in the following are gear stage-dependent machine data of a spindle:

- MD35110 \$MA_GEAR_STEP_MAX_VELO[n] (n_{max} for gear stage change)
- MD35120 \$MA_GEAR_STEP_MIN_VELO[n] (n_{min} for gear stage change)
- MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT[n] (n_{max} for gear stage)
- MD35135 \$MA_GEAR_STEP_PC_MAX_VELO_LIMIT (n_{max} for gearbox step with position control)
- MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT[n] (n_{min} for gear stage)
- MD35200 \$MA_GEAR_STEP_SPEEDCTRL_ACCEL[n] (acceleration in speed-control mode)
- MD35210 \$MA_GEAR_STEP_POSCTRL_ACCEL[n] (acceleration in position control mode)

For further information on parameter sets, see Section "Axis/spindle parameter sets" (Page 143).

Literature

Function Manual Basic Functions; Spindles: Gear stage change

10.6.3 Spindle measuring systems

Encoder matching

When parameterizing the measuring systems of spindles, the same conditions apply as for parameterization of the measuring systems of rotary axes. This multiple is 2048.

For incremental measuring systems see Section "Parameterization of incremental measuring systems" (Page 145).

For absolute measuring systems see Section "Parameterization of absolute measuring systems" (Page 149).

NOTICE
If the motor encoder is used for actual-value sensing, the encoder matching data must be entered in the machine data for each individual gear stage if several gear stages are present.

Pulse multiplication factor

The maximum multiplication of the appropriate drive is always used as the multiplication of the increments.

Examples of encoder adaptation

Example A: encoder on the spindle

Suppose the following conditions are provided:

- The incremental encoder is mounted on the spindle.
- Encoder pulses = 500 [pulses/rev.]
- Pulse multiplication = 128
- Internal precision = 1000 [increment/degree]
- Sensor ratio = 1:1
- Load ratio = 1:1

The machine data are set acc. to the values above:

- MD10210 \$MN_INT_INC_PER_DEG (computational resolution) = 1,000 [incr./degree]
- MD31020 \$MA_ENC_RESOL (encoder resolution) = 500 [pulses/revolution]
- MD31050 \$MA_DRIVE_AX_RATIO_DENOM (load rev. denominator) = 1
- MD31060 \$MA_DRIVE_AX_RATIO_NUMERA (load rev. numerator) = 1

- MD31070 \$MA_DRIVE_ENC_RATIO_DENOM (sensor speed denominator) = 1
- MD31080 \$MA_DRIVE_ENC_RATIO_NUMERA (sensor speed numerator) = 1

$$\text{Internal Resolution} = \frac{360 \text{ degree}}{\text{MD31020} * \text{pulse rev.}} * \frac{\text{MD31080}}{\text{MD31070}} * \frac{\text{MD31050}}{\text{MD31060}} * \text{MD10210}$$

$$\text{Internal Resolution} = \frac{360}{500 * 128} * \frac{1}{1} * \frac{1}{1} * 1000 = 5,625 \frac{\text{int. increments}}{\text{encoder pulse}}$$

One encoder increment corresponds to 5.625 internal increments.

One encoder increment corresponds to 0.005625 degrees (highest possible positioning resolution).

Example B: encoder at motor

Suppose the following conditions are provided:

- The incremental encoder is mounted on the motor.
- Encoder pulses = 2048 [pulses/rev.]
- Pulse multiplication = 128
- Internal precision = 1000 [increment/degree]
- Sensor ratio = 1:1
- Load ratio 1= 2.5:1 [motor speed/spindle speed]
- Load ratio 2= 1:1 [motor speed/spindle speed]

Gear stage 1

$$\text{Internal Resolution} = \frac{360 \text{ degree}}{\text{MD31020} * \text{pulse rev.}} * \frac{\text{MD31080}}{\text{MD31070}} * \frac{\text{MD31050}}{\text{MD31060}} * \text{MD10210}$$

$$\text{Internal Resolution} = \frac{360}{2048 * 128} * \frac{1}{1} * \frac{1}{2,5} * 1000 = 0,54932 \frac{\text{int. increments}}{\text{encoder pulse}}$$

One encoder increment corresponds to 0.54932 internal increments.

One encoder increment corresponds to 0.00054932 degrees (highest possible positioning resolution).

Gear stage 2

$$\text{Internal Resolution} = \frac{360}{2048 * 128} * \frac{1}{1} * \frac{1}{1} * 1000 = 1,3733 \frac{\text{int. increments}}{\text{encoder pulse}}$$

One encoder increment corresponds to 1.3733 internal increments.

One encoder increment corresponds to 0.0013733 degrees (highest possible positioning resolution).

10.6.4 Speeds and setpoint adjustment for spindle

Speeds, gear stages

In SINUMERIK solution line, data for five gear stages are implemented. These stages are defined by a minimum and maximum speed for the stage itself and by a minimum and maximum speed for the automatic gear stage changeover.

A new set gear stage is output only if the new programmed speed cannot be traversed in the current gear stage. For the sake of simplification, the oscillation times for gear stage changeovers can be specified directly in the NC; the oscillation function must otherwise be implemented in the PLC. The oscillation function is initiated via the PLC.




Figure 10-21 Example for speed ranges for automatic gear stage selection (M40)

Speeds for conventional operation

The speeds of the spindle in conventional mode are entered in the machine data:

- MD32010 \$MA_JOG_VELO_RAPID (rapid traverse in jog mode)
- MD32020 \$MA_JOG_VELO (axis velocity in JOG mode)

The direction of rotation is specified via the appropriate directional keys for the spindle on the MCP.

Direction of rotation

The direction of rotation of a spindle corresponds to the traversing direction of an axis.

Setpoint matching

The speeds must be transferred with standardized values for the drive controller. The values are scaled in the NC using the selected load gear and the appropriate drive parameter.

Machine data

Table 10- 27 Speeds and setpoint adjustment for spindle: Machine data

Axis-specific (\$MA_ ...)			
31050	DRIVE_AX_RATIO_DENOM	Denominator load gearbox	
31060	DRIVE_AX_RATIO_NUMERA	Numerator load gearbox	
32010	JOG_VELO_RAPID	Rapid traverse in the JOG mode	
32020	JOG_VELO	JOG axis velocity	
35010	GEAR_STEP_CHANGE_ENABLE	Gear stage change possible	
35020	SPIND_DEFAULT_MODE	Basic spindle setting	
35030	SPIND_DEFAULT_ACT_MASK	Activate initial spindle setting	
35040	SPIND_ACTIVE_AFTER_RESET	Spindle active after reset	
35200	GEAR_STEP_SPEEDCTRL_ACCEL[n]	Acceleration in speed control mode	
35220	ACCEL_REDUCTION_SPEED_POINT	Speed limit for reduced acceleration	
35230	ACCEL_REDUCTION_FACTOR	Reduced acceleration	
35400	SPIND_OSCILL_DES_VELO	Oscillation speed	
35410	SPIND_OSCILL_ACCEL	Oscillation acceleration	
35430	SPIND_OSCILL_START_DIR	Oscillation start direction	
35440	SPIND_OSCILL_TIME_CW	Oscillation time for M3 direction	
35450	SPIND_OSCILL_TIME_CCW	Oscillation time for M4 direction	

Interface signals

Table 10- 28 Speeds and setpoint adjustment for spindle: Interface signals

DB number	Bit, byte	Name	Reference
Axis-specific		Signals from PLC to axis/spindle	
31, ...	4.6	Traversing keys minus	
31, ...	4.7	Traversing keys plus	
31, ...	16.2-16.0	Actual gear stage	
31, ...	16.3	Gear changed	
31, ...	16.6	No speed monitoring when changing the gear	
31, ...	18.4	Oscillation via PLC	
31, ...	18.5	Oscillation speed	

DB number	Bit, byte	Name	Reference
Axis-specific		Signals from axis/spindle to PLC	
31, ...	82.2-82.0	Set gear stage	
31, ...	82.3	Change gear	
31, ...	84.7	Active spindle control mode	
31, ...	84.6	Active spindle mode oscillation mode	

10.6.5 Position spindle

The NC provides an oriented spindle stop function with which the spindle can be moved into a certain position and held there (e.g. for tool changing purposes). Several programming commands are available for this function which define the approach and program processing.

Literature

Function Manual Basic Functions; Spindles

Functionality

- To absolute position (0-360 degrees)
- Incremental position (+/- 999999.99 degrees)
- Positioning without influence of block change (SPOSA)
- Block change when block end position is reached (calculated by interpolation)

The control brakes the spindle down to position control speed at the acceleration rate for speed operation.

If position control speed has been reached, the control branches into position control mode and the acceleration rate for position control mode and the Kv factor become active.

The interface signal "Exact stop fine" is output to indicate that the programmed position has been reached (block change when position reached).

Acceleration rate for position control mode must be set such that the current limit is not reached. Acceleration rate must be entered separately for each gear step.

If the spindle is positioned from zero speed, it is accelerated up to a maximum speed corresponding to position control speed; the direction is defined via machine data. If there is no reference, the direction of actuation is as in MD35350 SPIND_POSITIONING_DIR. When position control mode is switched on, contour monitoring is also activated.

Machine data

Table 10- 29 Spindle positioning: Machine data

axis-specific (\$MA_ ...)			
35300	SPIND_POSCTRL_VELO	position control activation speed	
35350	SPIND_POSITIONING_DIR	Direction of rotation when positioning from the standstill	
35210	GEAR_STEP_POSCTRL_ACCEL	Acceleration in position control mode	
36000	STOP_LIMIT_COARSE	Exact stop coarse	
36010	STOP_LIMIT_FINE	Exact stop fine	
32200	POSCTRL_GAIN	Kv factor	
36400	CONTOUR_TOL	Contour monitoring	

Interface signals

Table 10- 30 Spindle positioning: Interface signals

DB number	Bit, byte	Name	Reference
Axis-specific		Signals from axis/spindle to PLC	
31, ...	60.6	Position reached with exact stop "fine"	
31, ...	60.7	Position reached with exact stop "coarse"	
31, ...	84.5	Positioning mode	

10.6.6 Synchronizing spindle

To allow the spindle to be positioned from the NCK, its position has to be adjusted using the measuring system. This operation is called "synchronization".

As a rule, synchronizing is done to the zero mark of the connected encoder or to a reference cam as zero mark substitute.

The following machine data defines the actual position of the spindle at the zero mark position:

- MD34100 \$MA_REFP_SET_POS (reference point value)

The zero mark offset is entered in the following machine data:

- MD34090 \$MA_REFP_MOVE_DIST_CORR (reference point offset)

The following machine data specifies which signal is used for synchronization:

- MD34200 \$MA_ENC_REFP_MODE (homing mode)
 - 1 = Encoder zero mark
 - 2 = Bero

When is synchronization necessary?

The spindle will be synchronized:

- after the NC has powered up when the spindle is moved using a programming command
- after a request for resynchronization by the PLC
 - NST DB31,... DBX16.4 (resynchronize spindle 1)
 - NST DB31,... DBX16.5 (resynchronize spindle 2)
- after each gear stage change for an indirect measuring system
 - MD31040 \$MA_ENC_IS_DIRECT (direct measuring system) = 0
- when the encoder limit frequency falls below the programmed value after a speed has been programmed which is above the encoder limit frequency.

NOTICE

If the spindle encoder is not mounted directly on the spindle and there are gear ratios between the encoder and spindle (e.g. encoder mounted on motor), then a BERO signal connected to the drive (SERVO) must be used for synchronization. The control system then automatically resynchronizes the spindle after each gear stage change. The user does not have to contribute anything here.

In general, backlash, gearbox elasticity and reference cam hysteresis reduce the accuracy achievable during synchronization.

Machine data

Table 10- 31 Synchronizing spindle: Machine data

Axis-specific (\$MA_ ...)			
34100	REFP_SET_POS	Reference point value	
34090	REFP_MOVE_DIST_CORR	Reference point offset	
34200	REFP_MODE	Referencing mode	

Interface signals

Table 10- 32 Synchronizing spindle: Interface signals

DB number	Bit, byte	Name	Reference
Axis-specific		Signals from PLC to axis/spindle	
31, ...	16.4	Synchronize spindle 1	
31, ...	16.5	Synchronize spindle 2	
Axis-specific		Signals from axis/spindle to PLC	
31, ...	60.4	Referenced/synchronized 1	
31, ...	60.5	Referenced/synchronized 2	

10.6.7 Spindle monitoring

Spindle stationary

The maximum permissible spindle speed up to which spindle standstill is detected, is set using machine data:

- MD36060 \$MA_STANDSTILL_VELO_TOL (max. speed "Spindle stationary")

If the actual speed falls below this speed limit, the NC/PLC interface signal is set:

- DB31,... DBX61.4 = 1 (spindle stationary)

Enabling path feed

Precondition:

- The spindle is in the open-loop control mode
- MD35510 \$MA_SPIND_STOPPED_AT_IPO_START == TRUE (feed enable for "Spindle stationary")

The path feed is enabled when both conditions are fulfilled:

- (actual speed of the spindle) < (MD36060 \$MA_STANDSTILL_VELO_TOL)
- DB31,... DBX61.4 == 1 (spindle stationary)

Spindle in setpoint range

If the spindle reaches the tolerance range specified in the following machine data, then the interface signal IS DB31,... DBX83.5 (spindle in setpoint range) is set:

- MD35150 \$MA_SPIND_DES_VELO_TOL (spindle speed tolerance)

The path feedrate is then released in the following set machine data:

- MD35510 \$MA_SPIND_STOPPED_AT_IPO_START (feed enable for "Spindle stopped")

Maximum spindle speed

The maximum spindle speed can be set using the following system data:

- Machine-dependent maximum speed via machine data
MD35100 \$MA_SPIND_VELO_LIMIT (max. spindle speed)
- Process-dependent maximum speed via immediately effective setting data
SD43235 \$SA_SPIND_USER_VELO_LIMIT (max. spindle speed)

The NC limits the spindle speed to the lower of the two values.

Error reaction:

If the speed is nevertheless exceeded by the speed tolerance (drive error), the following signal is output:

- DB31,... DBX83.0 = 1 (speed limit exceeded)
- Alarm "22150 Maximum number of chucks exceeded"

The following machine data also limits the speed of the spindle:

- MD36200 \$MA_AX_VELO_LIMIT (velocity-monitoring threshold)

When the speed is exceeded, an alarm is generated.

In position-controlled mode (e.g. SPCON), the NC limits the specified maximum speed specified in machine or setting data to 90% of the maximum value (control reserve).

Gear stage speed min./max.

The default of a max./min. gear stage speed is entered in the following machine data:

- MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT (maximum speed for gear stage)
- MD35140 \$MA_GEAR_STEP_MIN_VELO_LIMIT (minimum speed for gear stage)

The speed cannot leave this range when the appropriate gear stage is engaged.

Programmed spindle speed limitations

The following functions can be used to specify a spindle speed limitation in an indexing program:

- G25 S... (min. spindle speed)
- G26 S... (max. spindle speed)

The limitation is active in all operating modes.

The function LIMS=... can be used to specify a spindle speed limit for G96 (constant cutting rate):

- LIMS=... (speed limitation (G96))

This limitation is only effective when G96 is active.

Encoder frequency limit

If the sensor limit frequency in the following machine data is exceeded, synchronization of the spindle is lost and spindle functionality is reduced (thread, G95, G96):


- MD36300 \$MA_ENC_FREQ_LIMIT (encoder limit frequency)

The spindle will be re-synchronized automatically once the sensor frequency falls below the value defined in the following machine data:

- MD36302 \$MA_ENC_FREQ_LIMIT_LOW (encoder limit frequency at which the encoder is turned on again)

The encoder limit frequency value must be such that the mechanical encoder speed limit is not exceeded or else the synchronization from high speeds will be incorrect.

Overview of the speed limit values



Reference

Function Manual Basic Functions; Spindles: Spindle monitoring

10.6.8 Spindle data

Machine data

Table 10- 33 Spindle: Machine data

Number	Name of identifier	Name
General (\$MN_ ...)		
12060	OVR_SPIND_IS_GRAY_CODE	Spindle override with Gray coding
12070	OVR_FACTOR_SPIND_SPEED	Evaluation of spindle speed override switch
12080	OVR_REFERENCE_IS_PROG_FEED	Override reference velocity
Channel-specific (\$MC_ ...)		
20090	SPIND_DEF_MASTER_SPIND	Initial setting for master spindle on channel
20092	SPIND_ASSIGN_TAB_ENABLE	Enabling/disabling of spindle converter
20118	GEOAX_CHANGE_RESET	Allow automatic geometry axis change
22400	S_VALUES_ACTIVE_AFTER_RESET	S function active after RESET
Axis-specific (\$MA_ ...)		
30300	IS_ROT_AX	Rotary axis
30310	ROT_IS_MODULO	Modulo conversion
30320	DISPLAY_IS_MODULO	Position display
31050	DRIVE_AX_RATIO_DENOM	Denominator load gearbox
31060	DRIVE_AX_RATIO_NUMERA	Numerator load gearbox
31122	BERO_DELAY_TIME_PLUS	BERO delay time in plus direction
31123	BERO_DELAY_TIME_MINUS	BERO delay time in minus direction
32200	POSCTRL_GAIN	K _v factor
32810	EQUIV_SPEEDCTRL_TIME	Equivalent time constant speed control loop for feedforward control
32910	DYN_MATCH_TIME	Time constant for dynamic matching
34040	REFP_VELO_SEARCH_MARKER	Reference point creep speed
34060	REFP_MAX_MARKER_DIST	Monitoring of zero mark distance
34080	REFP_MOVE_DIST	Reference point distance/destination point for distance-coded system
34090	REFP_MOVE_DIST_CORR	Reference point offset/absolute offset, distance-coded
34100	REFP_SET_POS	Reference point value
34200	ENC_REFP_MODE	Homing mode
35000	SPIND_ASSIGN_TO_MACHAX	Assignment of spindle to machine axis
35010	GEAR_STEP_CHANGE_ENABLE	Gear stage change possible
35012	GEAR_STEP_CHANGE_POSITION	Gear stage change position
35020	SPIND_DEFAULT_MODE	Basic spindle setting
35030	SPIND_DEFAULT_ACT_MASK	Activate initial spindle setting
35040	SPIND_ACTIVE_AFTER_RESET	Spindle active after reset
35100	SPIND_VELO_LIMIT	Maximum spindle speed
35110	GEAR_STEP_MAX_VELO[n]	Maximum speed for gear change

Number	Name of identifier	Name
35120	GEAR_STEP_MIN_VELO[n]	Minimum speed for gear change
35130	GEAR_STEP_MAX_VELO_LIMIT[n]	Maximum speed of gear stage
35140	GEAR_STEP_MIN_VELO_LIMIT[n]	Minimum speed of gear stage
35150	SPIND_DES_VELO_TOL	Spindle speed tolerance
35160	SPIND_EXTERN_VELO_LIMIT	Spindle speed limitation via PLC
35200	GEAR_STEP_SPEEDCTRL_ACCEL[n]	Acceleration in speed control mode
35210	GEAR_STEP_POSCTRL_ACCEL[n]	Acceleration in position control mode
35220	ACCEL_REDUCTION_SPEED_POINT	Speed limit for reduced acceleration
35230	ACCEL_REDUCTION_FACTOR	Reduced acceleration
35300	SPIND_POSCTRL_VELO	position control activation speed
35350	SPIND_POSITIONING_DIR	Positioning direction of rotation for a non-synchronized spindle
35400	SPIND_OSCILL_DES_VELO	Oscillation speed
35410	SPIND_OSCILL_ACCEL	Oscillation acceleration
35430	SPIND_OSCILL_START_DIR	Oscillation start direction
35440	SPIND_OSCILL_TIME_CW	Oscillation time for M3 direction
35450	SPIND_OSCILL_TIME_CCW	Oscillation time for M4 direction
35500	SPIND_ON_SPEED_AT_IPO_START	Feed enable with spindle in setpoint range
35510	SPIND_STOPPED_AT_IPO_START	Feed enable with stationary spindle
35590	PARAMSET_CHANGE_ENABLE	Parameter set definition possible from PLC
36060	STANDSTILL_VELO_TOL	Threshold velocity "Axis/spindle stationary"
36200	AX_VELO_LIMIT	Threshold value for velocity monitoring

Setting data

Table 10- 34 Spindle: Setting data

Number	Identifier	Name
Spindle-specific (\$SA_ ...)		
42600	JOG_FEED_PER_REF_SOURCE	Revolutional feedrate control in JOG mode
42800	SPIND_ASSIGN_TAB	Spindle number converter
42900	MIRROR_TOOL_LENGTH	Mirror tool length offset
42910	MIRROR_TOOL_WEAR	Mirror wear values of tool length compensation
42920	WEAR_SIGN_CUTPOS	Mirror wear values of machining plane
42930	WEAR_SIGN	Invert sign of all wear values
42940	TOOL_LENGTH_CONST	Retain the assignment of tool length components when changing the machining plane (G17 to G19)
43210	SPIND_MIN_VELO_G25	Progr. Spindle speed limiting G25
43220	SPIND_MAX_VELO_G26	Progr. Spindle speed limiting G26
43230	SPIND_MAX_VELO_LIMS	Progr. spindle speed limitation with G96
43300	ASSIGN_FEED_PER_REF_SOURCE	Rotational feedrate for positioning axes/spindles

Interface signals

Table 10- 35 Spindle: Interface signals

DB number	Bit, byte	Name
Axis-specific		Signals from PLC to axis/spindle
31, ...	0	Feed override
31, ...	1.7	Override active
31, ...	1.6	Position measuring system 2
31, ...	1.5	Position measuring system 1
31, ...	1.4	Follow-up mode
31, ...	1.3	Axis/spindle disable
31, ...	2.2	Spindle reset/delete distance-to-go
31, ...	2.1	Servo enable
31, ...	3.6	Velocity/spindle speed limitation
31, ...	16.7	Delete S value
31, ...	16.5	Resynchronize spindle 2
31, ...	16.4	Resynchronize spindle 1
31, ...	16.3	Gear changed
31, ...	16.2-16.0	Actual gear stage A to C
31, ...	17.6	Invert M3/M4
31, ...	17.5	Resynchronize spindle during positioning 2
31, ...	17.4	Resynchronize spindle during positioning 1
31, ...	18.7	Direction of rotation setpoint left
31, ...	18.6	Direction of rotation setpoint right
31, ...	18.5	Oscillation speed
31, ...	18.4	Oscillation via PLC
31, ...	19.7 - 19.0	Spindle offset H - A
Axis-specific		Signals from axis/spindle to PLC
31, ...	60.7	Position reached with exact stop fine
31, ...	60.6	Position reached with exact stop coarse
31, ...	60.5	Referenced/synchronized 2
31, ...	60.4	Referenced/synchronized 1
31, ...	60.3	Encoder limit frequency exceeded 2
31, ...	60.2	Encoder limit frequency exceeded 1
31, ...	60.0	Axis/no spindle
31, ...	61.7	Current controller active
31, ...	61.6	Speed control loop active
31, ...	61.5	Position controller active
31, ...	61.4	Axis/spindle stationary (n < nmin)
31, ...	82.3	Change gear
31, ...	82.2-82.0	Set gear stage A-C
31, ...	83.7	Actual direction of rotation clockwise
31, ...	83.5	Spindle in setpoint range

DB number	Bit, byte	Name
31, ...	83.2	Setpoint speed increased
31, ...	83.1	Setpoint speed limited
31, ...	83.0	Speed limit exceeded
31, ...	84.7	Active spindle control mode
31, ...	84.6	Active spindle mode oscillation mode
31, ...	84.5	Active spindle positioning mode
31, ...	84.3	Rigid tapping active
31, ...	86 and 87	M function for spindle
31, ...	88-91	S function for spindle

10.7 Application example

10.7.1 Advanced Surface (AS)

Advanced Surface (AS) is a function to machine milled surfaces in the area of tool and mold building.

Advanced Surface is an option (Order No. 6FC5800-0AS07-0YB0).

The machine and setting data, which are influenced by this functionality as well as their contents, are subsequently listed.

The values are recommended settings.

10.7.2 Preconditions, G code

Introduction

Dynamic G groups are used for the Advanced Surface option.

Preconditions

- The machine axes have been optimized.
- The dynamic G groups have been set-up and parameterized for the following machining sections:
 - Roughing (DYNROUGH)
 - Pre-finishing (DYNSEMIFIN)
 - Finishing (DYNFINISH)

Recommendations

- Dynamic G groups

The following classification of dynamic G groups is recommended (G code group 59):

DYNNORM	→ 2.5D machining without AS
DYNPOS	→ Positioning mode (e.g. tool change, thread cutting) without AS
DYNROUGH	→ Milling with AS
DYNSEMIFIN	→ Milling with AS
DYNFINISH	→ Milling with AS

Note

DYNNORM is the initial setting of the G group (default).

For Advanced Surface, the precondition is that jerk limited velocity control is active. Jerk-limited velocity control is selected using the G code SOFT.

- **COMPCAD**

Using COMPCAD, it is possible to combine part programs with short linear blocks, with the associated tolerance, using polynomials.

This path compression technique has been developed so that the surface character, which the milling paths form, is retained.

- **G645**

G645 (G code group 10) switches in the continuous path mode (Look Ahead).

G645 has the ability to insert smoothing elements in existing contour elements so that acceleration steps (jumps) do not occur.

- **FIFOCTRL**

FIFOCTRL (G code group 4) switches in the automatic pre-processing memory control.

The feed is adapted so that the pre-processing memory does not become empty.

- **FFWON**

FFWON (G code group 24) switches in the parameterized precontrol (speed or acceleration precontrol). FFWON can only be used if precontrol is parameterized. This must be ensured by the machine suppliers.

Commands for for 5-axis machining

The following commands are important for 5-axis machining:

- **TRAORI** enables the defined transformation and must be programmed alone in the block.
- **UPATH** (G code group 45) switches in the path parameter, which was developed for 5-axis interpolation.
- **ORIXES** (G code group 51) linearly interpolates the orientation axes in the block up to the end of block.
- **ORIWKS** (G code group 25) defines the workpiece coordinate system for orientation interpolation.

CYCLE832 (High Speed Settings)

Cycle CYCLE832 (High Speed Settings) optimally supports Advanced Surface.

This cycle has been developed for this purpose and sets the above mentioned commands and the tolerance.

Commands CTOL (Chord TOLerance) and OTOL (Orientation TOLerance)

Commands CTOL (Chord TOLerance for chord tolerance) and OTOL (Orientation TOLerance) can be used if the tolerance is programmed without support of CYCLE832.

Activating the G code

Activation can be realized either using "Programming in the part program" or when commissioning machines, by re-configuring the RESET response (see \$MC_GCODE_RESET_VALUES).

Programmable program sequence without CYCLE832

Therefore, the following program sequence for customers to be programmed is obtained, which cannot use CYCLE832 or if the G commands do not correspond to the machine initial setting:

```
SOFT
FFWON
FIFOCTRL
G645
COMPCAD
DYNROUGH or DYNSEMIFIN or DYNFINISH {depending on the machining
phase}
TRAORI (<Transformation number>) {for 5-axis programs and
transformation}
ORIAxes
ORIMKS
```

10.7.3 Preconditions, machine data

User system variables for 3 and 5-axis machining

The subsequently listed machine data should be pre-assigned as follows:

MD	Name	Description	Rec. value	Comment
10200	\$MN_INT_INCR_PER_MM	Internal calculation resolution, linear axis	100000	10000 for export version
10210	\$MN_INT_INCR_PER_DEG	Internal calculation resolution, rotary axis	=MD10200	10000 for export version
18360	\$MN_MM_EXT_PROG_BUFFER_SIZE	Maximum reload memory when executing from external	500	Against jamming
18362	\$MN_MM_EXT_PROG_NUM	Number of ext. programs that can be simultaneously processed	2	
20150	\$MC_GCODE_RESET_VALUES[3]	Initial setting of G group 4	3	FIFOCTRL
20150	\$MC_GCODE_RESET_VALUES[19]	Initial setting of G group 20	2	SOFT
20150	\$MC_GCODE_RESET_VALUES[44]	Initial setting of G group 45	2	UPATH (for 5-axis machining)
20150	\$MC_GCODE_RESET_VALUES[50]	Initial setting of G group 50	2	ORIXES (for 5-axis machining)
20170	\$MC_COMPRESS_BLOCK_PATH_LIMIT	Maximum length of POLY generated by the compressor	20	
20172	\$MC_COMPRESS_VELO_TOL	Max. deviation of the path feed for COMCAD	1000	Default
20443	\$MC_LOOKAH_FFORM[0-1]	Activates the extended LookAhead in the particular technology group (DYNNORM, DYNPOS)	0	Default
20443	\$MC_LOOKAH_FFORM[2-4]	Activates the extended LookAhead in the particular technology group (DYNROUGH, DYNSEMIFIN, DYNFINISH)	1	
20482	\$MC_COMPRESSOR_MODE	Behavior of the compressor tolerance	300	
20490	\$MC_IGNORE_OVL_FACTOR_FOR_ADIS	Control of G642	1	
20560	\$MC_G0_TOLERANCE_FACTOR	Factor for tolerance for COMPCAD, G645, OST, ORISON	3	
20600	\$MC_MAX_PATH_JERK [0-4]	Path jerk	10000	Should not be effective
20602	\$MC_CURV_EFFECT_ON_PATH_ACCEL[0-1]	Ratio, translatory to centripetal acceleration	0	Should not be effective

MD	Name	Description	Rec. value	Comment
20602	\$MC_CURV_EFFECT_ON_PATH_ACCEL[2]	Ratio, translatory to centripetal acceleration for DYNROUGH	0.65	Must be effective so that for active curvature smoothing, the jerk is not quite so significantly exceeded!
20602	\$MC_CURV_EFFECT_ON_PATH_ACCEL[3]	Ratio, translatory to centripetal acceleration for DYNSEMIFIN	0.6	Must be effective so that for active curvature smoothing, the jerk is not quite so significantly exceeded!
20602	\$MC_CURV_EFFECT_ON_PATH_ACCEL[4]	Ratio, translatory to centripetal acceleration for DYNFINISH	0.5 (determine using the circularity test)	Limit rotational acceleration especially for "large" machines!
20606	\$MC_PREPDYN_SMOOTHING_ON[0-1]	Activates curvature smoothing	0	Default
20606	\$MC_PREPDYN_SMOOTHING_ON[2-4]	Activates curvature smoothing	1	
21104	\$MC_ORI_IPO_WITH_G_CODE	G code for orientation interpolation	1	
28060	\$MC_MM_IPO_BUFFER_SIZE	Memory, interpolator for number of G1 blocks	150	
28070	\$MC_MM_NUM_BLOCKS_IN_PREP	Memory, preparation (pre-processing)	80	
28520	\$MC_MM_MAX_AXISPOLY_PER_BLOCK	Maximum number of axis polynomials per block	5	
28530	\$MC_MM_PATH_VELO_SEGMENTS	Number of memory elements for limiting the path velocity	5	
28533	\$MC_MM_LOOKAH_FFORM_UNITS	Memory for extended LookAhead	18	
28540	\$MC_MM_ARCLENGTH_SEGMENTS	Number of memory elements to display the arc length function	10	
28610	\$MC_MM_PREPDYN_BLOCKS	Memory, curvature smoothing	10	
29000	\$OC_LOOKAH_NUM_CHECKED_BLOCKS	Number of Look Ahead blocks (this must be the same as N28060)	150	
42470	\$SC_CRIT_SPLINE_ANGLE	COMP criteria for target point analysis (should be >30°)	36	Default
42471	\$SC_MIN_CURV_RADIUS	Factor for compressor tolerance (should be 0.3-3)	1	

MD	Name	Description	Rec. value	Comment
42500	\$SC_IS_MAX_PATH_ACCEL	Limits the path acceleration via SD	10000	
42502	\$SC_IS_SD_MAX_PATH_ACCEL	Activates path acceleration via SD	0	
42510	\$SC_SD_MAX_PATH_JERK	Limits path jerk via SD	10000	
42512	\$SC_IS_SD_MAX_PATH_JERK	Activates path jerk via SD	0	

Optimize the drive

You can optimize the drives in the "Commissioning" > "Optimization/Test" operating area.




Figure 11-1 Optimization/test

The following functions are available:

- Frequency response measurements for the following control loops:
 - Current controller
 - Speed controller
 - Position controller
- Automatic controller setting
- Function generator
- Circularity test
- Trace
 - Servo trace
 - Drive trace

Measuring functions

The measuring functions make it possible to assess the automatic controller action of the respective control loop (frequency response) by the integrated FFT analysis (Fast Fourier Transformation) without external measuring equipment.

The measurement results are represented graphically as a Bode diagram. HMI file functions can be used to archive the diagrams for documentation purposes and to simplify remote diagnostics.

Circularity test

The circularity test serves to set and assess the dynamic response for interpolating axes or to analyze the contour accuracy on the quadrant transitions (circular contours) achieved by means of friction compensation (conventional or neural quadrant error compensation).

Reference

Function Manual Extended Functions, K3 Compensation, Section "Circularity test"

Servo trace

Servo trace provides a graphically assisted analysis of the time response of position controller and drive data.

Drive trace

Drive trace provides a graphically assisted analysis of the time response of drive signals.

11.1 Measuring functions

Explanation

A range of measuring functions allows the time and/or frequency response of drives and closed-loop controls to be displayed in graphic form on the screen. For this purpose, test signals with an adjustable interval are connected to the drives.

Measurement/signal parameters

The test setpoints are adapted to the application in question by means of measurement or signal parameters, the units of which are determined by the relevant measuring function or operating mode. The measurement or signal parameter units are subject to the following conditions:

Table 11- 1 Quantity and units for measurement or signal parameters

Size	Unit
Velocity	Metric system: Specification in mm/min or rev/min for translatory or rotary movements Inch system: Specification in inch/min or rev/min for translatory or rotary movements
Distance	Metric system: Specification in mm or degrees for translatory or rotary movements Inch system: Specification in inch or degrees for translatory or rotary movements
Time	Specified in ms
Frequency	Specified in Hz

Note

The default setting for all parameters is 0.

Preconditions for starting measuring functions

To ensure that no erroneous traversing movements due to part programs can be carried out, the measuring functions have to be started in <JOG> mode.

CAUTION
When traversing movements are carried out within the framework of measuring functions, no software limit switches and working area limitations are monitored, since these are carried out in follow-up mode.
Prior to starting traversing movements, the user must therefore ensure that the axes are positioned such that the traversing limits specified within the framework of the measuring functions are sufficient to prevent collision with the machine.

Starting measuring functions

Measuring functions initiating a traversing movement are only selected using the specific softkey. The actual start of the measuring function and thus of the traversing movement is always carried out with <NC-START> on the machine control panel.

If the main screen of the measuring function is quitted without the traversing movement being initiated, the selection of the traversing function is canceled.

Once the traversing function has been started, the main screen can be exited without any affect on the traversing movement.

Note

<JOG> mode must be selected when measuring functions are started.

Further safety notices

The user must ensure that when the measuring functions are used:

- The <EMERGENCY STOP> button is always within reach.
- No obstacles are in the traversing range.

Canceling measuring functions

The following events will cancel active measuring functions:

- Hardware limit switch reached
- Traversing range limits exceeded
- Emergency stop
- Reset (mode group, channel)
- NC STOP

- No controller enabling command
- Canceling drive enable
- Canceling traversing enable
- Selection of parking (in position-controlled operation).
- Feed override = 0%
- Spindle override = 50%
- Change in operating mode (JOG) or operating mode JOG not selected
- Actuation of traversing keys
- Actuation of handwheel
- Alarms leading to axis shutdown

11.2 Frequency response measurements

11.2.1 Current control loop measurement

Functionality

The current control loop only needs to be measured for diagnostic purposes if there is a fault or if there is no standard data for the motor / power unit combination (third-party motor).

CAUTION

The user must take special safety measures when measuring the current control loop (e.g. secure drive clamping) for hanging axes without external counterweight.
--

Operating path

Operating path for measuring the current control loop: Operating area switchover > "Commissioning" > "Optimization/Test" > "Current control loop"

Measuring functions

The following measuring functions are available for measuring the current control loop:

Measuring type	Measured variable
Reference frequency response (downstream of the current setpoint filter)	Torque-generating actual current value / torque-generating current setpoint
Setpoint step change (downstream of the current setpoint filter)	Measured variable 1: Torque-generating current setpoint Measured variable 2: Torque-generating actual current value

Measurement

The measurement sequence is divided into the following steps:

1. Setting the traverse range monitoring and the enable logic.
2. Selecting the measurement type
3. Setting the parameters, softkey "Measuring parameters"
4. Displaying the measurement results, softkey "Display"



Figure 11-2 Current controller

Measuring parameters

- Amplitude

Magnitude of the test signal amplitude. Given in percent of the peak torque. Values from 1% to 5% are suitable.

- Bandwidth

The frequency range analyzed with the measurement.

The bandwidth depends on the current controller sampling time.

Example:

125 μ s current controller sampling time, set bandwidth 4000 Hz

11.2.2 Speed control loop measurement

Functionality

The response characteristics for the motor measuring system are analyzed when measuring the speed control loop. Various measurement parameter lists are available depending on the basic measurement setting which has been selected.

Operating path

Operating path for measuring the speed control loop: Operating area switchover > "Commissioning" > "Optimization/Test" > "Speed control loop"

Measuring functions

The following measurement functions are available for measuring the speed control loop:

Measuring type	Measured variable
Reference frequency response (downstream of the speed setpoint filter)	Actual speed value motor encoder/speed setpoint after filter
Reference frequency response (upstream of the speed setpoint filter)	Actual speed value motor encoder/speed setpoint after filter
Setpoint step change (downstream of the speed setpoint filter)	Measured variable 1: <ul style="list-style-type: none"> • Speed setpoint downstream of the filter • Actual torque value Measured variable 2: Actual speed value motor encoder
Interference frequency response (fault downstream of the current setpoint filter)	Actual speed value motor encoder / torque setpoint fct. generator
Disturbance variable step change (fault downstream of the current setpoint filter)	Measured variable 1: <ul style="list-style-type: none"> • Torque setpoint fct. generator • Actual torque value Measured variable 2: Actual speed value motor encoder
Speed-controlled system (excitation downstream of the current setpoint filter)	Actual speed value motor encoder/actual torque value
Frequency response of the mechanical parts ¹⁾	Actual speed value measuring system 1/actual speed value measuring system 2
1) The machine axis in question must have both a direct and an indirect measuring system to determine the frequency response of the mechanical parts.	

Measurement

The measurement sequence is divided into the following steps:

1. Setting the traverse range monitoring and the enable logic
2. Selecting the measuring type and measured variable
3. Setting the parameters, softkey "Measuring parameters"
4. Displaying the measurement results, softkey "Display"



Figure 11-3 Speed controller

In the example shown, the speed control loop has not yet been optimized.

A suitable filter parameterization is used to optimize the dynamic response. This can be called with the "Filter" softkey.

The following figure shows the standard settings for a low-pass filter at 1999 Hz (encoder mounting frequency).




Figure 11-4 Standard settings of the speed control loop filter

11.2 Frequency response measurements




Figure 11-5 Speed control loop filter with rejection band 1190 Hz

The use of a rejection band at 1190 Hz and adaptation of the proportional gain results in the following optimized setting for the speed control loop.



Figure 11-6 Optimized speed control loop

11.2.3 Position control loop measurement

Functionality

This measuring function basically analyzes the response to the active position measuring system. If the function is activated for a spindle without a position measuring system, an alarm is displayed. Depending on the measured variable selected, various measurement parameter lists are displayed.

Operating path

Operating path for measuring the speed control loop: Operating area switchover > "Commissioning" > "Optimization/Test" > "Position control loop"

Measuring functions

The following measuring functions are available for measuring the position control loop:

Measuring type	Measured variable
Reference frequency response	Actual position/position setpoint
Setpoint step change	Measured variable 1: Position setpoint Measured variable 2: <ul style="list-style-type: none"> • Actual position value • System deviation • Following error • Actual speed value
Setpoint ramp	Measured variable 1: Position setpoint Measured variable 2: <ul style="list-style-type: none"> • Actual position value • System deviation • Following error • Actual speed value

Measurement

The measurement sequence is divided into the following steps:

1. Setting the traverse range monitoring and the enable logic
2. Selecting the measuring type and measured variable
3. Setting the parameters, softkey: "Measuring parameters"
4. Displaying the measurement results, softkey: "Display"

The following figure shows an optimized position control loop in which the K_v factor has been adapted via the machine data MD32200 \$MA_POSCTRL_GAIN.



Figure 11-7 Optimized position control loop

Reference frequency response measurement

The reference frequency response measurement determines the transmission ratio of the position controller in the frequency range (active position measuring system).

The setpoint filters, control loop gain (K_v factor) and feedforward control must be parameterized such that resonance is avoided wherever possible over the entire frequency range.

Measuring parameters

- Amplitude

This parameter determines the magnitude of the test signal amplitude. It should be set to the smallest possible value (e.g. 0.01 mm).

- Bandwidth

The bandwidth parameter is used to set the analyzed frequency range. The larger this value, the finer the frequency resolution and the longer the measurement time. The maximum value is specified by the position controller cycle ($T_{\text{position controller}}$):

$$\text{Bandwidth}_{\text{max}} [\text{Hz}] = 1 / (2 * T_{\text{position controller}} [\text{sec}])$$

Example:

Position controller cycle: 2 ms

$$\text{Bandwidth}_{\text{max}} = 1 / (2 * 2 * 10^{-3}) = 250 \text{ Hz}$$

- Averaging

The accuracy of the measurement and measurement duration increase with this value. A value of 20 is normally suitable.

- Settling time

This value represents the delay between recording of the measured data and injection of the test setpoint and offset. A value of between 0.2 and 1 s is recommended. Do not set too low a value for the settling times or the frequency response and phase diagrams will be distorted.

- Offset

The measurement requires a slight speed offset of a few motor revolutions per minute. The offset must be set such that no speed zero crossings occur at the set amplitude.

Measurement: Setpoint step change and setpoint ramp

The transient or positioning response of the position control in the time range, and in particular the effect of setpoint filters, can be assessed with the step and ramp stimulation functions.

Possible measured variables:

- Actual position value (active position measuring system)
- Control deviation (following error)

Measuring parameters

- Amplitude

Determines the magnitude of the specified setpoint step change or ramp.

- Measurement time

This parameter determines the period of time to be recorded (maximum: 2048 position controller cycles).

- Settling time

This value represents the delay between measured data recording / test setpoint output and the injection of the offset.

- Ramp time

With default setting: The position reference value is specified with the "Setpoint ramp" according to the set ramp time. In this case, the acceleration limits which currently apply to the axis or spindle are effective.

- Offset

The step is stimulated from standstill or starting from the constant traverse speed set in this parameter.

If an offset value other than zero is input, the step change is stimulated during traversal. For the sake of clarity, the displayed actual position value does not include this speed offset.




Figure 11-8 Signal chart for position setpoint/ramp measuring function

At maximum axis velocity, there is a (virtual) step change in the velocity (continuous line).

The curves represented by the dashed line correspond to a realistic, finite value. The offset component is excluded from the display graphic in order to emphasize the transient processes.

Measurement: Setpoint step change

To avoid overloading the mechanical system of the machine, the step height is limited to the value specified in the machine data during the "Setpoint step change" measurement:

- MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)

This may result in failure to achieve the desired step height.

Measurement: Setpoint ramp

With measurement "Setpoint ramp", the following machine data influence the measurement result:

- MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)

The maximum axis velocity limits the ramp gradient (velocity limitation). The drive does not reach the programmed end position (amplitude).

- MD32300 \$MA_MAX_AX_ACCEL (maximum axis acceleration)

The maximum axis acceleration limits the velocity change (acceleration limitation). This leads to "rounding" on the transitions at the beginning and end of the ramp.

CAUTION
In normal cases the machine data corresponds exactly with the load capacity of the machine kinematics and should not be changed (increased) as part of the measurements: <ul style="list-style-type: none">• MD32000 \$MA_MAX_AX_VELO (maximum axis velocity)• MD32300 \$MA_MAX_AX_ACCEL (maximum axis acceleration)

11.3 Circularity test measurement

Functionality

The circularity test serves to set and assess the dynamic response for interpolating axes or to analyze the contour accuracy on the quadrant transitions (circular contours) achieved by means of friction compensation (conventional or neural quadrant error compensation).

Operating path

Operating path to circularity test: Operating area switchover > "Commissioning" > "Optimization/Test" > "Circularity test"

Measuring parameters

The parameters are entered in the "Measurement" menu.

- Axis names and axis numbers
- Circle that is to be traversed and the actual position values recorded

The parameter settings in the input fields "Radius" and "Feed" must correspond to the values from the part program that controls the circular motion of the axes, taking account of the feed override switch setting.

- The "Measuring time" display field shows the measuring time calculated from the "Radius" and "Feed" values for recording the actual position values during the circular movement.

If only parts of the circle can be represented (i.e. measuring time too short) the measuring time can be increased in the menu by reducing the feed value. This also applies if the circularity test is started from the stationary condition.

Display mode

The following parameter assignments for programming the mode of representation of measurement results can also be made:

- Display based on mean radius
- Display based on programmed radius
- Scaling of the diagram axes

If the measuring time calculated exceeds the time range that can be displayed from the trace buffers (maximum measuring time = position controller cycle frequency * 2048), a coarser sampling rate is used for recording (n * position controller cycle frequency), so that a complete circle can be displayed.




Figure 11-9 Circularity test measurement parameters

The two drives selected for measurement must describe a circular interpolation (G2/G3) with the parameters shown in the example via a part program:

Radius=100 mm, F=10000 mm/min

Measurement

The measurement sequence is divided into the following steps:

1. Setting the parameters, softkey "Measurement" (see above figure).
2. Start measurement with "Start" softkey.

The selected axes run in the part program.

3. Displaying the measurement results, softkey "Display".

A switchover is made to the graphic illustration of the recorded circular diagram (see following figure).

Note

If required, a QEC / backlash compensation can be performed via MD32200 \$MA POSCTRL_GAIN for the K_V factor optimization.




Figure 11-10 Circularity test measurement

11.4 Trace

11.4.1 Trace overview

Introduction

A trace shows signals over a time interval (signal charts)

The following functions are available:

- Servo trace

Servo trace offers functions for recording and graphically illustrating the temporal characteristics of values for servo signals, e.g. actual position value, following error etc.

- Drive trace

Drive trace offers functions for recording and graphically illustrating the temporal characteristics of values for signals from the drive system, e.g. actual speed value, actual current value etc.

It must be possible for the signals to be recorded to be interconnected via a BICO source.

11.4.2 Servo trace

Basic servo trace display

The basic display of the servo trace function is reached via the operating area "Commissioning" > "Optimization/Test" > "Trace" > "Servo trace".

Figure 11-11 "Servo trace measurement" basic display

Parameterization in the basic display

The following selection is made in the basic display for the servo trace measurement:

- Axis/spindle selection
- Measuring signal
- Measurement time
- Trigger time
- Trigger type
- Trigger threshold

Signal selection

"Axis/spindle name" input field

The cursor must be positioned on the "Axis/spindle name" list box of the trace concerned. You can select it with the softkeys "Axis+" and "Axis-" or by accepting a value from the drop-down list box.

"Signal selection" input field

The cursor must be positioned on the "Signal selection" list box of the trace concerned. The selection is made through acceptance from the drop-down list box.

The available selection options depend on the existing configuration and activated functions.

Measuring parameters

"Measuring duration" input field

The measuring time is written directly into the "Measuring duration" input field.

"Trigger time" input field

Direct entry of pre-triggering or post-triggering. With negative input values (leading sign minus -) recording begins at the set time before the trigger event.

With positive input values (without sign) recording starts the time set after the triggering event.

Condition: Trigger time + measuring duration \geq 0.

"Trigger" input field

The trigger type is displayed in the "Trigger" drop-down list box. The trigger always refers to Trace 1. When the trigger condition is satisfied, Traces 2 to 4 are started simultaneously.

Settable trigger conditions:

- "No trigger", i.e. measurement starts by pressing softkey "Start" (all traces are started time-synchronized)
- "Positive edge"
- "Negative edge"
- "Trigger event from the part program"

The trace can be started via an NC part program in conjunction with the system variable \$AA_SCTRACE [axis identifier].

Reference

SINUMERIK 840D sl / 840Di sl System Variable Manual

"Threshold" input field

Direct input of the trigger threshold.

The threshold is only effective with trigger types "Positive edge" and "Negative edge".

The unit refers to the selected signal.

Softkeys "Axis+" and "Axis-"

Selection of the axis/spindle when the cursor is positioned on the appropriate "Axis/spindle name" list field.

You can also select the axis/spindle directly in the list box from the drop-down list using the cursor.

Softkeys "Start" and "Stop"

Trace function recording is started with the softkey "Start".

With the "Stop" softkey or RESET, you can cancel a running measurement.

11.4.3 Drive trace

Basic drive trace display

The basic display of the drive trace function is reached via the operating area "Commissioning" > "Optimization/Test" > "Trace" > "Drive trace".




Figure 11-12 Basic "drive trace" display

When you are in the field for signal selection for a signal, you can press the <SELECT> button to move to a window in which you can determine the signal for interconnecting.




Figure 11-13 Drive trace interconnections

If you scroll through the basic display, the following parameters are displayed:




Figure 11-14 Basic drive trace display, "Trigger" parameter

Parameterization in the basic display

The following selection is made in the basic display for the drive trace measurement:

- Drive unit selection
- Signal selection
- Record
- Trigger

"Trigger time"/"Delay" entry field

Direct entry of pre-triggering or post-triggering. With negative input values (leading sign minus -) recording begins at the set time before the trigger event.

With positive input values (without sign) recording starts at the time set after the triggering event.

Secondary condition: Trigger time + measuring time \geq 0.

"Trigger type" entry field

The trigger type is displayed in the "Trigger" drop-down list.

Settable trigger conditions:

- "Record immediately"
 - This means no trigger, i.e. measurement starts by pressing the "Start" softkey.
- "Positive edge"
- "Negative edge"

- "Entry in the hysteresis band"
- "Exiting the hysteresis band"
- "Trigger on bit mask"

Reference

SINAMICS S120 List Manual

Signal selection

Signals to be recorded, e.g. actual speed value, actual current value etc.

It must be possible for the signals to be recorded to be interconnected, i.e. a BICO source.

Trigger signal

The trigger (signal) can be used to specify the event with which the recording of values is to start, e.g. the actual speed value is not to be recorded straightaway when the drive trace starts but only when the actual current value is > 10 A (here the actual current value trigger is > 10 A).

"Drive unit+" and "Drive unit-" softkeys

Selection of drive unit in which recording is to take place.

Softkeys "Start" and "Stop"

Trace function recording is started with the softkey "Start".



Figure 11-15 Drive trace recording

You can cancel an active recording with the "Stop" softkey or RESET.

11.5 Further optimization options

Introduction

You can adapt the following parameters in the operating area "Commissioning" > "Machine data" > "Drive MD" for the drive optimization.

Speed adjustment

- Spindle drive:
p500 = 102, speed setpoint in p322 corresponds to setpoint 4000 0000hex
- Feed drive:
p500 = 101, speed setpoint in p311 corresponds to setpoint 4000 0000hex

The speed setpoint can be diagnosed in the corresponding drive in r2050[1+2] or r2060[1].

Brake behavior OFF3

Depending on the requirements, the brake behavior for each drive can be adjusted to the signal 2nd OFF3. Default setting: p1135 = 0, brake with maximum current.

Parameters p1135, p1136, p1137 can be used to set a flatter braking ramp for drive-specific parameterization.

Maximum braking ramp setting: 600 secs

Drive optimization using SINUMERIK Operate

12.1 Automatic servo optimization

Introduction

With the SINUMERIK Operate sl user interface under the "Commissioning" > "Automat. Servo Opt." menu, you have the following options for automatic axis optimization:

- Selection of individual axis for optimization
- Selection of one strategy from many options
- Reconfiguration of measurement conditions
- Chart display and activities protocol for optimization process
- Display of current measurement and at the same time the average of previous measurements
- Checking and processing of optimization results for speed and position controller
- Accept or reject results




Figure 12-1 Basic display for automatic optimization of SERVO axes

The "Optimization" function can be used for all individual axes (SERVO and direct drives).

Note

The master slave axes for automatic optimization are not supported by SINUMERIK Operate Version 2.6 SP1.

Master slave axes can be optimized as individual axes if they are not coupled.

12.2 Overview of navigation

Overview

When optimizing an axis, you navigate via various dialog screens.

The following figure shows the navigation options for optimizing an axis:




Figure 12-2 Navigation for automatic optimization of an individual axis

Note

The following section "General operating sequences for automatic servo optimization" uses the numbers shown in the above diagram (e.g. dialog screen "Strategy selection" ②).

12.3 Setting options

Introduction

The general behavior of the automatic servo optimization can be controlled in the main screen using the "Options" softkey.




Figure 12-3 Options

Options

- Perform all measurements of each measurement series with the first NC start:
All repeats (e.g. motion in the positive and negative axis direction) within a measurement series are automatically started.
- Start measurements automatically:
The start screen of each measurement series is skipped and the measurement process is directly started with the default measurement parameters.
- Automatic confirmation of the measurement:
The final screen of each measurement series (is used to evaluate the measurement results -> if required, adapt measurement parameters and restart measurement series) is skipped. The algorithm changes directly to the next optimization step.
- Automatic acknowledgement of the controller data:
The "controller data overview" display is skipped. The controller data determined by the algorithm are directly activated.
- Automatic data activation using the operator panel reset:
The "Operator panel reset" signal is generated by the algorithm. If this option is deactivated, "Operator panel reset" is requested using a dialog screen.

- Automatically backup drive boot files (ACX format):
After completing the optimization of a machine axis, the drive data are automatically saved on the CompactFlash Card in the ACX format. If this option is deactivated, the query is realized via a dialog screen.
- Permit strategy selection:
The dialog screen to select the optimization strategies for the speed and position controller is displayed.
- Backup measurement data in temporary directory:
The recorded measurement data are saved in a temporary directory.
- Perform preliminary measurement to determine the excitation:
Activate a preceding (additional) measurement for each measurement series to more precisely determine the measurement parameters. This is especially recommended when measuring directly-driven machine axes for the first time.

12.4 General operating sequences for automatic servo optimization

General operating sequences

1. In the "Commissioning" operating area, press the "Automat. servo opt." softkey.

"Axis selection" dialog screen appears ①.




Figure 12-4 Axis selection




Figure 12-5 Axis selection, gantry axis grouping

2. Use the cursor keys to select an axis for optimization.

Note

For "Gantry axis groups", only the leading axis is displayed with the "Gantry" note. Synchronous axes are hidden, but when selecting the leading axis, are measured and optimized.

3. In the "Axis selection" dialog screen ①, press the "Optimize" softkey.
4. In the "Strategy selection" dialog screen ②, select the strategy for optimization.




Figure 12-6 Strategy selection

For example in a typical strategy, the mechanical controlled system of the speed control is measured and gains and filters defined for optimized dynamic behavior.

Note

A user-specific strategy (Page 255) can be set using a vertical "Custom/manufacturer" softkey.

5. Press "OK".

- In the "Axis park position" dialog screen ③, move the axes on the machine into a safe position for optimization.




Figure 12-7 Axis park position

! DANGER

Automatic servo optimization based on analysis of measurements. The measurements require the axis to move. Ensure that all axes are in a safe position and no collisions will occur during the traversing motion that is required.

7. Press "OK".

Optimization is started ⑤.




Figure 12-8 Optimization in progress

If measurement can only be continued after the necessary inputs have been made, then this is signaled using input prompts (screen forms).

This is required because you need to initiate certain machine processes (e.g. measurements which require an <NC START>).

You can abort the coordination process at any stage of automatic servo optimization.

Once optimization has been aborted, all original machine data, which was present in the control and in the drives before optimization was started, is restored.

Note

After the measurement has been completed, you can perform the measurements again. In this case, the quality of the measurement data can be influenced by changing the excitation parameters using the dialog screen "Measurement configuration".




Figure 12-9 Measurement configuration

8. If the optimization process has completed some optimizations for a control loop, a "Controller data overview" dialog screen ⑦ appears.




Figure 12-10 Controller data overview




Figure 12-11 Controller data, overview gantry axis group

You can modify and check the results and either accept or reject the proposed control parameters.

Note

Alternatively the optimized values can also be displayed graphically as a Bode diagram using the "Bode diagram" softkey function.

9. Select "Transfer" to transfer the values calculated.

- If you accept the settings for closed-loop speed control by pressing "Transfer", the drive data is updated, and the strategy then runs the measurements for closed loop position control, "Measurement is running" dialog screen ⑥.




Figure 12-12 Measurement is running




Figure 12-13 Measurement running, gantry axis group

- Once the optimum values for closed loop position control have been selected, the data is transferred to the CNC and drives, and the strategy runs the next stage which may be e.g. to measure for verification.

12.5 Setting the user-specific strategy

Introduction

You can go to the area "Design user-specific strategy" in screen ② "Strategy selection" using the vertical softkey "Custom/manufacturer".

Various settings can be selected or deselected in order to control the behavior of the automatic servo optimization.

For the user-specific strategy, settings of the general axis strategy are handled separately from the settings specifically for the speed or position controller.




Figure 12-14 Setting the user-specific strategy

Setting areas

- Axis
Activating/deactivating individual measurements and optimization steps for the selected machine axis - including entering the measurement parameters.
- n/v controller
Settings exclusively to optimize the speed or velocity controller of the selected machine axis.
- Position controller
Settings exclusively to optimize the position controller of the selected machine axis.

12.6 Additional optimization stages - commissioning interpolation axes

Additional optimization stages

Additional optimization stages should be undertaken for axes which make up a collection of interpolations. These optimization steps should be undertaken manually by the commissioning engineer using the options provided in HMI Advanced or the start-up (commissioning) tool:

e.g.:

- Circularity test measurement (Page 231)
- Adaptation of servo gains (e.g. smallest servo gain in all interpolating axes without DSC see Position control loop measurement (Page 225))
- When using speed feed forward control, transfer equivalent time constants of the slowest axis (highest value) into all interpolating axes (see Speed control loop measurement (Page 222)).

Commissioning external drives

13.1 Introduction (PLC drive <-> NC drive)

Introduction

A distinction is made between integrated and external drives using the physical bus arrangement.

Integrated drive

The drives, which are connected to the internal, virtual PROFIBUS, can only be assigned to NC axes.

The assignment is realized using the axis machine data:

- MD30110 \$MA_CTRLOUT_MODULE_NR (setpoint channel)
- MD30220 \$MA_ENC_MODUL_NR (actual value channel)
- MD30130 \$MA_CTRLOUT_TYPE (setpoint type of output)
- MD30240 \$MA_ENC_TYPE (actual value sensing)

Further, the logical I/O addresses ≥ 4100 are defined in the general machine data:

- MD13050 \$MN_DRIVE_LOGIC_ADDRESS (axis address)

External drive

Drives, which are connected to external buses, e.g. DP1 and/or DP2 - can be assigned to the following drives:

- PLC drives:
 - Data is directly exchanged with the PLC user program
 - Integrated in the part program operations using an H command

- NC drives with NC axes:

The NC axes are assigned using the above mentioned NC machine data with changed logical I/O address ≤ 4095 in the general MD13050 \$MN_DRIVE_LOGIC_ADDRESS.

Note

A drive that can be assigned to an NC axis must be a standard slave according to the PROFIdrive profile version 4.1.

Note

In certain version combinations, the integration functions are checked for compatibility. The following versions are supported:

- SINUMERIK from CNC software 2.6 SP1 up to CNC software 2.7 with:
 - CU320DP from SINAMICS firmware Version 2.6 SP2
 - CU310DP from SINAMICS firmware Version 2.6 SP2
- SINUMERIK from CNC software 4.4 with:
 - CU320-2DP from SINAMICS firmware Version 4.4
 - CU310-2DP from SINAMICS firmware Version 4.4

All other SINAMICS drives can be connected to the PLC as standard slaves in accordance with PROFIdrive profile and are not included in the quantity structure, according to the following table "Quantity structure".

Slight differences between the SINAMICS versions of the integrated and external drives should be taken from the upgrade instructions.

Note

With CNC software 4.4, no SINAMICS drives with PROFINET connection are separately supported.

Operator control options with HMI for an external drive

External drives, type SINAMICS S120 can be e.g. CU320 or CU310. These drives communicate on the external PROFIBUS DP1/DP2 (as PNO Ident 0x80E5).

These external drives are supported by SINUMERIK HMI with the following advanced operator options:

- Automatic device configuration (Page 73)
- Only for HMI Advanced
 - Guided commissioning (Page 70), with the known drive wizards for SERVO DOs.

Note

Other guided commissioning wizards (e.g. vector control) are not provided in SINUMERIK HMI. The appropriate version of STARTER can be used for this purpose.

- Manual commissioning (Page 98) performed by experienced commissioning engineers.
 - All parameters of the drive DOs are shown in the operating area "Start-up"> "Machine data", e.g.
 - "Control Unit MD" for the DO1 drive unit
 - "Infeed MD" for DriveCLiQ Line Module, generally DO2
 - "Drive MD" for drive control DOs
- Parameters of the integrated drives with SINUMERIK view as well as external drives with SINAMICS view are displayed.
- Series commissioning support, where the parameters of these external drives are also handled (backing-up/loading) also in the series commissioning drive archive.
 - Topology views including a list of all of the drive units of this type which have been found.
 - Diagnostics with alarms from these PLC drives whose time stamp is synchronized with the system.

In this case, it is necessary that the following general machine data are pre-assigned:

- MD13120[...] \$MN_CONTROL_UNIT_LOGIC_ADDRESS
I/O address on a DO1 telegram, type SINUMERIK telegram 390
- MD13150 \$MN_SINAMICS_ALARM_MASK
Set bit 2 -> faults of external drives are displayed
Set bit 10 -> alarms of external drives are displayed

General Information

- The number of these drive objects (DOs) is limited on an NCU-for-NCU basis as an additional communication load is obtained as a result of the additional operator control options for these external drives.
 - Alarm 380077 "PROFIBUS/PROFINET: Too many DOs: actual %2, maximum %3 in DO group %1"
 - Quantity structure (see table below)
- Depending on the versions used, the texts displayed for the SINAMICS parameters and alarms can be incomplete.
- The extended operator control options are guaranteed in conjunction with the drive unit, infeed and the axis drive SERVO-DO. This is the reason that a device-granular view is considered. All SERVO-DOs of a drive unit can either be assigned to the NC or PLC.
- In an extreme situation, all NC axis assignments can be realized at axis drives at the external DP1 or DP2.
- If the drives are assigned to the NC and distributed across several buses, such as DP1, DP2 and DP3, it must be ensured that each equidistant bus has the same clock cycle settings.

Note

Observe the following for SINUMERIK 840D sl:

- A DO1 drive unit is required for the internal virtual PROFIBUS DP3 for access to the onboard I/O including probe.

-
- ADI4 can only be assigned to NC axes. The number of ADI4 does not reduce the maximum number of managed DO1 drive units
 - The HMI does not support 611U connected to SINUMERIK solution line; it has not been checked as far as its reactions are concerned - and has therefore not been released.

Note

Please note the following for all drive units connected to an external DP1 or DP2:

- In the configuration, the user must take into account the supply as well as the switch-on and switch-off behavior in interaction with the other axes and their supply.

Note

When wiring terminals, observe the guidelines for the machine configuration Chapter 6. In the simplest case, the feedback of the Line Module is connected to the external PLC drives (see Terminal assignment of the digital inputs/outputs (Page 31))

Quantity structure

Table 13- 1 Quantity structure

Quantity structure-scaling		840D sl NCU type		
		NCU710	NCU720	NCU730
Drives (drive control DOs ¹⁾) in total ³⁾ :		15	40	50
	Of which, assigned to the NC, maximum ³⁾ :	6/8 ⁴⁾	31	31
	Resulting from this, those not assigned to the NC, minimum:	9/7 ⁵⁾	9	19
	Not assigned to the NC, maximum:	15	40	50
Drives units (DO1) with drive control objects, in total ³⁾ :		9	13	15
	Of which, at the virtual, integrated PROFIBUS, maximum ³⁾ :	4	6	6
	Of which, at the virtual, integrated PROFIBUS, minimum:	1	1	1
	Of which, at DP1/DP2 ²⁾ minimum:	5	7	9
	Of which, at DP1/DP2, maximum:	8	12	14

1) Drive control DOs -> with software version 2.6 must be SERVO-DOs

2) DP1 -> 1st PROFIBUS interface of the integrated PLC
DP2 -> 2nd PROFIBUS interface of the integrated PLC

3) Sum is monitored using Alarm 380077

4) "6" for SW 2.7; "8" for SW 4.4

5) "9" for SW 2.7; "7" for SW 4.4

Commissioning external drives

Commissioning PLC drives is described step-by-step in the following Chapters.

13.2 Commissioning PLC drives

13.2.1 Example configuration

Overview

The SINAMICS drive system for PLC drives communicates with the PLC via the external PROFIBUS DP.

The commissioning described in this chapter orientates itself to an example configuration of the SINAMICS drive line-up.

The following figure roughly shows the components.

- Was commissioned:
 - NCU 720 and NX15 with additional components.
- Will be commissioned in this chapter:
 - CU320 with:
 - An infeed (Active Line Module)
 - Three Single Motor Modules
 - CU310DP with:
 - A PM340 Power Module

Note

This example also applies to CU3x0-2 drives.




Figure 13-1 PROFIBUS DP configuration example

13.2.2 Principle procedure when commissioning

Overview

The following commissioning steps are performed when commissioning PLC drives for the first time:

1. PLC commissioning
2. Generating a PLC user program
3. Commissioning external drives
4. Commissioning communication NCK<->Drive

13.2.3 PLC commissioning

Introduction

The PLC must be notified of the PROFIBUS communication interfaces of SINAMICS.

You generate a SIMATIC S7 project using the SIMATIC Manager.

To do this, perform the following steps:

- Insert CU320 in HW Config
- Configure the properties of the PROFIBUS interface
- Insert CU310DP
- Configure the properties of the PROFIBUS interface
- Compile the configuration and then download to the PLC

Also see Chapter PLC commissioning (Page 49) for the integrated drive.

Note

The toolbox must have been installed.

The GSD file for SINAMICS S120 from the SINUMERIK toolbox is required for configuration.

The following preferred telegrams are supported:

- Standard telegram 2
 - SIEMENS telegram 116
 - SIEMENS telegram 390
-

Precondition

- You have connected the PG/PC to the PLC (see Connect PG/PC with the PLC (Page 47)).
- You have started the SIMATIC Manager and created a project (see Creating a project (Page 50)).
- You have inserted a SIMATIC Station-300 in the project (see Inserting a SIMATIC station 300 (Page 50)).
- You have started HW Config.
- You have inserted and configured an NCU 720 and NX 15 at the integrated PROFIBUS (see Insert NCU 7x0 in HW config (Page 52)).

Inserting CU320 operating sequence

1. Search in the catalog under "PROFIBUS DP" > "SINAMICS" > "SINAMICS S120" > "S120 CU320" (see following figure).




Figure 13-2 HW Config S120 CU320

2. Keeping the lefthand mouse key pressed, drag the "S120 CU320" in the station window to PROFIBUS (9): DP master system.

3. After releasing the mouse key, in the dialog box, configure the properties of the PROFIBUS interface SINAMICS.




Figure 13-3 Properties, PROFIBUS interface SINAMICS

4. Press "OK".




Figure 13-4 Properties, SINAMICS CU320

5. In the selection box "Version", select the firmware version of the Control Unit.

Note

The firmware version must match the version of the CompactFlash Card on the CU320. Refer to the upgrade instructions for the versions that have been released for external drives.

6. Press "OK".

7. In the "DP Slave Properties" dialog box, select the "Configuration" tab.




Figure 13-5 DP slave properties, telegrams

8. Select the telegrams required for the individual objects (axes and CU320) (see following figure).
- 3x "Standard telegram 2, PZD-4/4" for e.g. speed axes.
 - "SIEMENS telegram 390, PZD-2/2" for CU320

Note

SIEMENS telegram 390 is required for the time stamp of the PLC alarms.




Figure 13-6 DP slave properties, telegrams CU320 overview

9. Click on the "Details" tab in the "Configuration" window.




Figure 13-7 DP slave properties, configuration details

Note

You can now view the generated input and output addresses on PROFIBUS for the individual objects.

The input and output addresses must be identical to support automatic device commissioning.

These addresses are required for the PLC user program in FB283 (see Generate PLC user program (Page 273)).

10. Press "OK".

Inserting CU310DP operating sequence

1. Search in the catalog under "PROFIBUS DP" > "SINAMICS" > "SINAMICS S120" > "S120 CU310DP" (see following figure).




Figure 13-8 CU320 inserted, CU310DP selected

2. Keeping the lefthand mouse key pressed, drag the "S120 CU310DP" in the station window to PROFIBUS (9): DP master system.
3. After releasing the mouse key, in the dialog box, configure the properties of the PROFIBUS interface SINAMICS.

4. In turn, you configure the properties (see following figures).




Figure 13-9 SINAMICS CU310 properties




Figure 13-10 DP slave properties, telegrams CU310DP overview




Figure 13-11 DP slave properties, telegrams CU310DP details

5. You have inserted and configured the hardware in HW Config.




Figure 13-12 CU310DP inserted

Operating sequence, save/compile/load into the module

1. Select the menu "Station" > "Save and compile"
 2. Click on the button "Load in module", to load the configuration to the PLC.
 See also End hardware configuration and load to the PLC (Page 61).
- The next step is to create the PLC user program.

13.2.4 Generate PLC user program

Introduction

You generate the PLC user program using the SIMATIC Manager.

The SIMATIC STEP7 documentation describes how to modify and extend an application program.

The chapter explains how to program the function blocks for PLC drives using an example.

Precondition

You require the SINAMICS toolbox V1.x for this example.

The SINAMICS toolbox is in the SINUMERIK toolbox in directory BSP_PROG.

The path depends on the version, e.g. ->
\\8x0d\020606\BSP_PROG\Toolbox_S120_V13_HF1.zip.

You can also download the SINAMICS toolbox V1.x under the following link:

<http://support.automation.siemens.com/WW/view/en/25166781>

Operating sequence

1. You are on the main screen of the SIMATIC Manager.
2. You have created a project.
3. Select the "File" > "Open" menu and then click on the "User projects" tab.
4. Open the project example.
5. Copy blocks FB283, FC70, DB70 and DB283 into your existing project.
6. As the DB70 could be used by another program, rename DB70 as DB111!
7. Edits blocks OB1, FC70 and FC73.

Block OB1

```
...  
...  
CALL FC70  
CALL FC73  
...  
...
```

FC70

```
CALL FB 283, DB283
NR_ACHS_DB := 111
LADDR := 300 //Logical I/O address
LADDR_DIAG := 8186 //Diagnostics address
WR_PZD := P#DB111 DBX172.0 Byte 8 //Source range for outputs
RD_PZD := P#DB111 DBX212.0 Byte 8 //Target range for inputs
CONSIST := TRUE
RESTART := FALSE
AXIS_NO := B#16#3 //Drive object number
```

FC73

```
L W#16#47E
T DB111.DBW 172 //Issue all enable signals to drive
//with the exception of ON/OFF1
//RESET
U E 3.7 //RESET MCP
= DB111.DBX 173.7
```

Additional entries

Using the variable table, the missing ON/OFF1 enable signal can now be set:
DB111.DBX173.0

Further, the speed setpoint must be entered into DB111.DBW174.

In our example (standard telegram 2), 4000hex corresponds to the rated speed in drive parameter p2000.

Significance of the signals "WR_PZD" and "RD_PZD"

Table 13- 2 Signals "WR_PZD" and "RD_PZD"

Signal	Type	Type	Range of values	Comment
WR_PZD	I	Any	P#Mm.n byte x.. P#DBnr.dbxm.n byte x	Target range for process data, master → slave (control words/setpoints) Here, generally the axis DB is used, i.e. in the pointer, the same DB-No. must be specified as formal parameter "NR_ACHS_DB" The length of the pointer depends on the telegram. Standard telegram 2: 8 bytes Siemens telegram 116: 22 bytes
RD_PZD	I	Any	P#Mm.n byte x.. P#DBnr.dbxm.n byte x	Target range for process data, master ← slave (status words/actual values) Here, generally the axis DB is used, i.e. in the pointer, the same DB-No. must be specified as formal parameter "NR_ACHS_DB" The length of the pointer depends on the telegram. Standard telegram 2: 8 bytes Siemens telegram 116: 38 bytes

Load project to PLC

You have completed the programming of the user memory
Now load the project to the PLC (Page 65).

Commissioning the PLC has been completed

NOTICE
A reset (warm restart) of the NCK and HMI is required for the HMI-PLC-NCK synchronization. See Chapter Triggering a reset (warm restart) for NCK and drive system (Page 70)

The PLC and NCK are in the following state after a reset (warm restart):

- LED RUN illuminates GREEN continuously.
- Status display shows a "6" with a flashing point.
- ⇒ PLC and NCK are in cyclic operation.

You have completed the first commissioning of the PLC.

You commission the devices, infeed(s) and drives in the next step.

See also Guided commissioning of SINAMICS drives (Page 70).

13.2.5 Commissioning external drives

Introduction

The following description for commissioning briefly discusses the automatic configuration of the devices via the user interface of HMI-Advanced.

Commissioning drive components of an external PROFIBUS corresponds to the SINAMICS commissioning of an integrated drive (Page 70) with SERVO drives.

Preconditions

- You have loaded the PLC project into the PLC.
- To synchronize the PLC-NCK-HMI, you have initiated a reset (warm restart) for the NCK and the drive system.
- The PLC and NCK are in the following state after a reset (warm restart):
 - LED RUN illuminates GREEN continuously.
 - Status display shows a "6" with a flashing point.
 - ⇒ PLC and NCK are in cyclic operation.

Operating sequence

1. At the HMI, select the "Commissioning" > "Drive system" menu.

Alarm "120 402:...First commissioning of SINAMICS required!" is displayed in the area for alarms.




Figure 13-13 "Commissioning" > "Drive system" menu

2. Press the "Drive units" to start the automatic device configuration.




Figure 13-14 Menu "Commissioning" > "Drive system" > "Drive units" > Query

3. Press "OK".

- The individual steps for automatic device configuration are displayed one after the other in the following dialog box:




Figure 13-15 Device configuration running

- You are guided through the automatic device configuration up to commissioning of the individual drive objects that have still not been commissioned.

The commissioning corresponds to the SINAMICS commissioning via an integrated PROFIBUS.

For additional commissioning steps, please refer to Chapter Commissioning integrated drives (NCU) (Page 69) from Chapter Automatic device configuration (Page 73).

13.2.6 Commissioning communication NCK<->Drive

Introduction

The PLC alarms of the drives communicating at the external PROFIBUS, must have an identical time stamp with the NCK.

For the configuration in HW Config, this is the reason that you defined SIEMENS telegram 390 for the CU320 and CU310DP devices.

The corresponding logical input and output addresses of this communication interface must be entered in the general machine data MD13120[...] CONTROL_UNIT_LOGIC_ADDRESS.

NOTICE

You can view these logical addresses in HW Config when configuring the DP Slave properties of SINAMICS components under "Details".

Operating sequence

Please check the following logical addresses in the menu "Commissioning" > "Machine data" > "General machine data" in MD13120[...]:

- MD13120[6] logical address for CU320 -> "324"
- MD13120[7] logical address for CU310DP -> "338"

Setup	CHAN1	JOG Ref	MPFD	
<input checked="" type="checkbox"/>				Channel reset
				Program aborted
				RDV
General MD (\$MN_)				
13114[4]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[5]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[6]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[7]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[8]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[9]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[10]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[11]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[12]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13114[13]	\$MN_PROFIBUS_TRACE_START_EVENT	0H		cf
13120[0]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	6500		po
13120[1]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	6530		po
13120[2]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po
13120[3]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po
13120[4]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po
13120[5]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po
13120[6]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	324		po
13120[7]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	338		po
13120[8]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po
13120[9]	\$MN_CONTROL_UNIT_LOGIC_ADDRESS	0		po

Logical address of SINAMICS CU

General MD	Channel MD	Axis MD	User views	Control unit MD	Supply MD	Drive MD
------------	------------	---------	------------	-----------------	-----------	----------

Figure 13-16 Input and output address in MD13120[...]

- Press "Reset (po)...".

The changed machine data are updated.

This completes the commissioning of the external drive.

13.3 Configuring safety functions for external drives

Introduction

The Chapter "Configuration of Safety functions for external drives" only partially describes how an external drive can be integrated in a safety-related application.

In this case, the published supplement of the PROFIdrive profile that includes drive-based safety functions via the PROFIsafe supplement with telegram 30 is used.

Reference

For the implementation, reference is made to the following function manuals for safety functions, which are binding for the safety-related version:

- Function Manual SINUMERIK 840D sl/SINAMICS S120 "SINUMERIK Safety Integrated" Edition 03/2010.
- SINAMICS S120 Function Manual "Safety Integrated" Edition 01/2011 Chapter "Structure of telegram 30 (Basic Functions)".

Basic procedure

The following steps are necessary to integrate drive-based safety functions:

- Configuration with SIMATIC Manager under HW Config.
- Embedding in safe programmable logic (SPL).
- Configuration of test cases with SinuCom NC ATW that must go through an acceptance procedure.

13.3.1 Configuration with SIMATIC Manager under HW Config

Precondition

The chapter PLC commissioning (Page 264) describes in detail the operating sequence when you create a project with SIMATIC Manager. The chapter goes into detail on the configuration in HW Config.

A CU320 has been inserted and for the operating sequence **8**, in the dialog box of the "DP Slave Properties" the telegrams selected.

Provided that the option package "S7 Configurations Pack" has been installed, the following steps are necessary here for telegram 30:

Operating sequence

1. Select a telegram.




Figure 13-17 Selecting a telegram

2. For this telegram, in the selection field "Option", select the PROFIsafe telegram 30.




Figure 13-18 Selecting PROFIsafe telegram 30

3. Under the "Details" tab, set the input/output addresses.
The PROFIsafe option requires an additional 6 bytes.

4. To do this, press the "PROFIsafe ..." button.




Figure 13-19 Setting the input and output addresses

5. Set the "F_Dest_Add".

- Under "Parameter name", you select "F_Dest_Add".
- You can change the value using the "Change Value.." button.
- Note down the value.




Figure 13-20 "F_Dest_Add" setting

The value of the parameter "F_Dest_Add" must be entered in p9610 and p9810 as a hexadecimal value of the corresponding drive (e.g. 200 decimal corresponds to C8 hexadecimal).

The value of the "F_Source_Add" must match the other PROFIsafe modules and must also be entered in MD 10385 \$MN_PROFISAFE_MASTER_ADRESS.

It must be ensured that the same source address is set for all PROFIsafe modules.

13.3.2 Embedding in safe programmable logic (SPL) based on the example of an SPL of SINUMERIK 840D sl

Introduction

The following machine data and files must be taken into account when embedding telegram 30 in a safe programmable logic:

- NC machine data
- Drive machine data
- "safe.SPF" file
- PLC program expansion

NC machine data

- Not bold: Values already used by PROFIsafe / F-Send/F-Rec.
- **Bold:** Values that have been added as a result of telegram 30.

The SPL PROFIsafe configuration for the basic safety functions STO without SSI are then shown as example:

Archive excerpt	Comment
CHANDATA(1)	
N10385 \$MN_PROFISAFE_MASTER_ADDRESS='H50007d2'	
N10386 \$MN_PROFISAFE_IN_ADDRESS[0]='H50000c8'	;> entry from HW Config
N10387 \$MN_PROFISAFE_OUT_ADDRESS[0]='H50000c8'	;> entry from HW Config
...	
N10390 \$MN_PROFISAFE_IN_ASSIGN[0]=9011	;> INSE[9] for S_STW1.0 No Safe Torque Off
	;> INSE[10] for S_STW1.1 No Safe Stop 1
	;> INSE[11] for S_STW1.7 INTERNAL_EVENT_ACK
	; No extended functions
...	
N10400 \$MN_PROFISAFE_OUT_ASSIGN[0]=9011	;> OUTSE[9] for S_ZSW1.0 Power removed
	;> OUTSE[10] for S_ZSW1.1 Safe Stop 1 not active
	;> OUTSE[11] for S_ZSW1.7 INTERNAL_EVENT
	; No extended functions
...	
N13300 \$MN_PROFISAFE_IN_FILTER[0]='H83'	
...	
N13320 \$MN_PROFISAFE_OUT_FILTER[0]='H83'	
...	

Drive machine data

- Values that have been added as a result of telegram 30:

p9601=p9801=0x8

p9610=p9810=0xC8

"safe.SPF" file

Program example

```
IDS = 40 DO $A_OUTSE[09] = $A_INSE[2]
IDS = 41 DO $A_OUTSE[10] = $A_INSE[2]
```

Comment

```
;If the cover is locked then deselect STO
;If the cover is locked then deselect SS1
```

PLC program expansion

Program example

```
U "SPL".SPL_DATA.INSEP[2];
= "SPL".SPL_DATA.OUTSEP[9];
= "SPL".SPL_DATA.OUTSEP[10];
//Enable signal OFF1 set:
UN "SPL".SPL_DATA.INSEP[9];
UN "SPL".SPL_DATA.INSEP[10];
U E 0.0;
=
"CU320_A".Speed_Control.WR_PZD_DREHZ AHL.STW1
.Aus1 ;
```

Comment

```
// => cover switch locked?
// $A_OUTSE[9] =1 => Deselect STO
// $A_OUTSE[10] =1 => Deselect SS1
// => No STO?
// => No SS1?
// of course, only if OFF1 is also requested
by switch
```

13.3.3 Configuration of test cases with SinuCom NC SI-ATW that must go through an acceptance procedure

Note

SinuCom NC SI-ATW, which can be used for the acceptance of safety-related SINUMERIK Safety Integrated functions, can also be used to accept certain drive-based safety functions.

The following example for STO (Safe Torque Off)/SH (safe standstill) of an external SINAMICS CU3xx device shows these functions.

Note

For safety-related acceptance, the function manuals, as specified in Chapter Configuring safety functions for external drives (Page 280), are binding.

Basic operator input options when ATW is running

The tests for the drives of the CU320 are integrated into the ATW using the "Function inter-relationships". For the parameters there are two options:

1. The contents of the parameter are entered into the result box.
2. The "setpoint/reference" values are located in the condition box and are only confirmed in the result box with "OK" if there is a match.

Test 1: Checking the version parameters




Figure 13-21 Test 1: Checking the version parameters




Figure 13-22 Test 1: Checking the version parameters

Test 2: Checking the SI monitoring clock cycles




Figure 13-23 Test 2: Checking the SI monitoring clock cycles

Test 3: Testing the safety-related shutdown (STO). There is a test for each drive.




Figure 13-24 Testing the safety-related shutdown




Figure 13-25 Testing the safety-related shutdown

Data backup and standard commissioning

Introduction

Once commissioning of the NCK, PLC and drive has been completed, you can manage the modified data using the functions below:

- Save/Archive user data
- Series commissioning
- Upgrading, as series commissioning

User data

The following user data can be managed:

Table 14- 1 User data

NCK/HMI	PLC
Machine data	OB (organization blocks)
Setting data	FB (function blocks)
Option data	SFB (system function blocks)
Global (GUD) and local (LUD) user data	FC (functions)
Tool and magazine data	SFC (system functions)
Protection zone data	DB (data blocks)
R parameters	SDB (system data blocks).
Work offsets	
Compensation data	
Display machine data	
Workpieces, global part programs and subroutines	
Standard and user cycles	
Definitions and macros	

14.1 Data backup

Introduction

Data is backed up by means of the HMI. SINUMERIK solution line components can either be backed up individually or jointly. You can select from:

- NCK (NC)
- PLC
- HMI
- Drives

Operating sequence

1. Selection of Data backup menu
Operating range "Services > ETC key ">" > "Standard commissioning".
2. You can choose which data you want to back up:
 - HMI
 - NC with compensation data
 - PLC
 - PROFIBUS drives
3. Archive name: The suggested archive name depends on the selected area and can be changed if necessary.
4. Create the data backup file by selecting the component to which you wish the file to be output:
 - NC card (CompactFlash card)
 - Archive

Data backup DRIVE-CLiQ motors

Note

We would recommend backing up the DRIVE-CLiQ motor data onto a CompactFlash card (NC card).

The p4692 parameter must be set to "1" in the "Commissioning" > "Machine data" > "Control unit MD" operating range.

14.2 User data backup/Series commissioning

Introduction

Data can be saved and archived in the following ways:

- Reading out the data completely: Series commissioning
- Files are exported/imported area by area.

The following user data can be selected as individual files:

- Machine data
- Setting data
- Tool data
- R parameters
- Zero point offset
- Compensation data (LEC)
- Part programs
- Standard cycles
- User cycles
- PLC programs (binary file)

In the case of a data backup, e.g., following commissioning of the control system, the user data selected via the user interface are written to what is known as a series-commissioning file. Once a series-commissioning file has been imported, the control system returns to its original state, as it was at the time of the data backup.

Time of data backup

Experience has shown that the following times can be recommended for carrying out data backups:

- Following commissioning
- After changing machine-specific settings
- After service, e.g., after replacement of a hardware component, software upgrade, etc.
- Before activation of memory-configuring machine data. A warning prompting you to back up is displayed automatically.

Note

References: Operator's Guides for:

- HMI Advanced
 - HMI-Embedded
 - ShopMill/ShopTurn
-

14.3 Preassignments when saving PLC data

Introduction

When creating a series-commissioning file that contains PLC data, the PLC image that is saved during this process is dependent on the status of the PLC at the time of creation.

Depending on the status of the PLC, the following PLC images result:

- Original image
- Instantaneous image
- Inconsistent image

Operating sequence for original image

The original image of the PLC is represented by the PLC-data state immediately after loading the S7 project into the PLC.

1. Set the PLC to the operating status STOP.
2. Load the appropriate S7 project into the PLC using SIMATIC Manager STEP 7.
3. Create a series-commissioning file with PLC data.
4. Set the PLC to the RUN operating status.

Operating sequence for instantaneous image

If you cannot create an original image, you can save an instantaneous image as an alternative.

1. Set the PLC to the operating status STOP.
2. Archive PLC data.
3. Set the PLC to the RUN operating status.

Operating sequence for inconsistent image

An inconsistent image results if a series-commissioning file with PLC data is created and the PLC is in the RUN state (cyclic operation). The data blocks of the PLC are saved at different times with contents that under certain circumstances may meanwhile have changed. This may result in a data inconsistency that, once the data backup has been copied back to the PLC, may under certain circumstances result in a PLC stop in the user program.

NOTICE
The creation of a series-commissioning file with PLC data while the PLC is in RUN status (cyclic operation) may result in an inconsistent PLC image in the series commissioning archive. After this series-commissioning file has been copied back, this data inconsistency in the PLC user program may under certain circumstances result in a PLC stop.

Changing the PLC operating status

The PLC operating status can be changed using:

- SIMATIC STEP7 Manager
- PLC mode selector on the NCU (position "2" -> STOP, position "0" -> RUN)

14.4 Series commissioning

Introduction

Series commissioning means bringing a series of control systems to the same initial state as regards their data.

You can archive/read in your choice of PLC, NC and HMI data for series commissioning. Compensation data can be saved at the same time if necessary. The drive data are saved as binary data which cannot be modified.

Requirement

The password, e.g., with access level 3 (user) is set.

Note

In order to prevent a topology error, Control Unit parameter p9906 (topology comparison stage of all components) should be set to "Medium" to load Control Unit series commissioning.

Operating sequence

1. Open the menu to create a series-commissioning file:

Operating range "Services" > <ETC> key > > "Series IBN".




Figure 14-1 Series commissioning

2. Create an archive for the series-commissioning file: You can select which data you wish to save as the archive contents:
 - HMI
 - NC with compensation data
 - PLC
 - PROFIBUS drives
3. Archive name: The suggested archive name depends on the selected area and can be changed if necessary.
4. Create the series-commissioning file by selecting the component to which you wish the file to be output:
 - NC-Card
 - Archive

File functions

15.1 Introduction

Functionality

You have the following options when using the "File functions" function:

- SINAMICS parameters of the drive objects:
 - Backing up on SINUMERIK Operate
 - Loading to the drive unit
 - Editing on SINUMERIK Operate
- Back-up all of the machine data and SINAMICS parameters on an HMI drive and from there, move them to another HMI.

The functions are available under "Commissioning" > "Machine data" > <ETC> key > "File functions".

Depending on the machine data area from which the file functions were selected, the corresponding entry is selected from the selection box for selecting data.

The data and parameters available on the control appear in this selection box.

The first three vertical softkeys for "+/-" and "Direct selection" are adapted accordingly and are only visible where there is more than one component.




Figure 15-1 File functions

15.2 File functions for SINAMICS parameters

15.2.1 Overview

SINAMICS parameters

You can use a drop down list box in the "Data" window to back up/load the following SINAMICS parameters from the individual drive objects:

- SINAMICS control unit parameters
- SINAMICS infeed parameters
- SINAMICS drive parameters
- SINAMICS communications parameters




Figure 15-2 Selecting "SINAMICS drive parameters" file functions

Drive objects

Select the respective drive objects using the vertical softkeys.

For example the "Drive +"/"Drive -" vertical softkeys for "SINAMICS drive parameters".

15.2.2 Data backup of SINAMICS parameters

Introduction

Select the "File functions" dialog under "Commissioning" > "Machine data" > <ETC> key.

Operating sequence

Proceed as follows to back up the drive object parameters:

1. In the "Data" window, select the data type you require.
2. Use the "+/-" or "Direct selection" vertical softkeys to select the component if there is more than one component.
3. In the "File" window enter a name or select an existing name from the selection box.
4. In the "Directory" window, select the directory under which you want to save the parameters.
5. Press "Save".

The following screen shots show examples of "SINAMICS drive parameters" and "SINAMICS control unit parameters".




Figure 15-3 Select "File functions" > "SINAMICS drive parameters"




Figure 15-4 Select "File functions" > "SINAMICS control unit parameters"

15.2.3 Loading/copying the SINAMICS parameter file

Introduction

Select the "File functions" dialog under "Commissioning" > "Machine data" > <ETC> key.

Operating sequence

Proceed as follows to load parameters to the individual drive objects:

1. In the "Data" window, select the data type you require.
2. Use the "+/-" or "Direct selection" vertical softkeys to select the component if there is more than one component.
3. Select an existing name from the selection box.




Figure 15-5 Loading/copying SINAMICS drive parameter file functions

4. Press "Load".

The following message will appear if the source and target numbers don't match:




Figure 15-6 Loading/copying SINAMICS drive parameter file functions, "Adapt" query

5. Select "Adapt".

You can now adapt the "Actual values" for the "File" using the "Setpoints".




Figure 15-7 Loading/copying SINAMICS drive parameter file functions, "Adapt"

6. Press "OK".

15.2.4 Editing the SINAMICS parameter file

Introduction

Select the "File functions" dialog under "Commissioning" > "Machine data" > <ETC> key.

Operating sequence

Proceed as follows to display the contents of a file:

1. In the "Data" window, select the data type you require.
2. Use the "+/-" or "Direct selection" vertical softkeys to select the component if there is more than one component.
3. Select an existing name from the selection box.




Figure 15-8 Select "File functions" > "File"

4. Press "Edit..."




Figure 15-9 Editing SINAMICS drive parameter file functions

5. The content of the file is displayed and can be viewed.

15.3 Copying data from one HMI to another

15.3.1 Overview

Functionality

All of the machine data and SINAMICS parameters can be saved at the HMI under a directory and are then written from this directory to a medium. The data can then be copied to another HMI from this medium (e.g. USB-FlashDrive).

You can copy the following data:

- General machine data
- Channel-specific machine data
- Axis-specific machine data
- General display, machine data
- Channel-specific display machine data
- SINAMICS Control Unit parameters
- SINAMICS infeed parameters
- SINAMICS drive parameters

15.3 Copying data from one HMI to another

- SINAMICS I/O parameters
- SINAMICS communication parameters

File names and directory names

Note

At the HMI, all file and directory names are mapped to unique 8.3 file/directory names.

This is the reason that the file and directory names should be a maximum of 8 characters long.

Example: "MYDIR"

This makes it easier to identify file and directory names with more than 8 characters in the file system.

15.3.2 Copying machine data

Introduction

Select the "File functions" dialog under "Commissioning" > "Machine data" > <ETC> key.

Operating sequence

Proceed as follows to copy machine data:

1. In the "Data" window, select the data type you require.
2. In the "File" window, assign a name to the file or select an existing name from the selection box.
3. In the "Directory" window, assign a name to the directory or select an existing name from the selection box.
4. Press "Save".

The files are saved in the HMI file system. Copy the files from there to a USB-FlashDrive and you can then copy them to another HMI.

Only the <file name>.TEA file has to be copied.

Default directory

If you have selected the "default directory", then the files are saved in the HMI file system under the following directory:

- General machine data <HMI installation directory>\dh\dg.dir\MDNC.DIR\<file name.TEA>
- Channel-specific machine data <HMI installation directory>\dh\dg.dir\MDCH.DIR\<file name.TEA>
- Axis-specific machine data <HMI installation directory>\dh\dg.dir\MDAX.DIR\<file name.TEA>
- General and channel-specific display, machine data <HMI installation directory>\dh\dg.dir\MDBT.DIR\<file name.TEA>

New directory, e.g. "MYDIR"

If, for example, you have entered a new directory name, e.g. "MYDIR", then the files are saved in the HMI file system under the following directory:

- General machine data <HMI installation directory>\dh\dg.dir\MYDIR\MDNC.DIR\<file name.TEA>
- Channel-specific machine data <HMI installation directory>\dh\dg.dir\MYDIR\MDCH.DIR\<file name.TEA>
- Axis-specific machine data <HMI installation directory>\dh\dg.dir\MYDIR\MDAX.DIR\<file name.TEA>
- General and channel-specific display, machine data <HMI installation directory>\dh\dg.dir\MYDIR\MDBT.DIR\<file name.TEA>

15.3.3 Copying SINAMICS parameters

Introduction

Select the "File functions" dialog under "Commissioning" > "Machine data" > <ETC> key.

Operating sequence

Proceed as follows to copy SINAMICS parameters:

1. In the "Data" window, select the data type you require.
2. In the "File" window, assign a name to the file or select an existing name from the selection box.

15.3 Copying data from one HMI to another

3. In the "Directory" window, assign a name to the directory or select an existing name from the selection box.
4. Press "Save".

The files are saved in the HMI file system. Copy the files from there to a USB-FlashDrive and you can then copy them to another HMI.

Only the <file name>.TEA file has to be copied.

Note

For HMI-Advanced Version 7.6, the <file name>.TEA file and the <file name>.ACX file must be copied.

Default directory

If you have selected the "default directory", then the files are saved in the HMI file system under the following directory:

- SINAMICS Control Unit parameters <HMI installation directory>\dh\dg.dir\MDSINAMI.DIR\MD_CU.DIR\<file name>.TEA>
- SINAMICS infeed parameters <HMI installation directory>\dh\dg.dir\MDSINAMI.DIR\MD_LM.DIR\<file name>.TEA>
- SINAMICS drive parameters <HMI installation directory>\dh\dg.dir\MDSINAMI.DIR\MD_DC.DIR\<file name>.TEA>
- SINAMICS I/O parameters <HMI installation directory>\dh\dg.dir\MDSINAMI.DIR\MD_IO.DIR\<file name>.TEA>
- SINAMICS communication parameters <HMI installation directory>\dh\dg.dir\MDSINAMI.DIR\MD_COM.DIR\<file name>.TEA>

New directory, e.g. "MYDIR"

If, for example, you have entered a new directory name, e.g. "MYDIR", then the files are saved in the HMI file system under the following directory:

- SINAMICS Control Unit parameters <HMI installation directory>\dh\dg.dir\MYDIR\MDSINAMI.DIR\MD_CU.DIR\<file name.TEA>
- SINAMICS infeed parameters <HMI installation directory>\dh\dg.dir\MYDIR\MDSINAMI.DIR\MD_LM.DIR\<file name.TEA>
- SINAMICS drive parameters <HMI installation directory>\dh\dg.dir\MYDIR\MDSINAMI.DIR\MD_DC.DIR\<file name.TEA>
- SINAMICS I/O parameters <HMI installation directory>\dh\dg.dir\MYDIR\MDSINAMI.DIR\MD_IO.DIR\<file name.TEA>
- SINAMICS communication parameters <HMI installation directory>\dh\dg.dir\MYDIR\MDSINAMI.DIR\MD_COM.DIR\<file name.TEA>

Tips for commissioning SINAMICS drives

Introduction

This chapter describes instructions and tips on:

- Changing topology (modular machine)
- Drive states
- Diagnostics for pending alarms
- Drive (SERVO) parameter RESET, individual
- Version display of the drives (SERVOs)
- Checking/setting power supply data settings
- Identification/Optimization "ALM > Infeed/Configuration"

16.1 Changing topology (modular machine)

Introduction

The topology is changed using the following menus:

- "Commissioning" > "Drive system" > "Drive units" > "Topology".




Figure 16-1 "Drive units" > "Topology" menu

- "Commissioning" > "Drive system" > "Drive units" > "Configuration".




Figure 16-2 "Drive units" > "Configuration" menu

Functions for changing topology

The following functions are provided for changing the topology:

- "Topology" > "Add component..."
- "Topology" > "Change..."
 - Delete drive objects/components
 - Enable/disable drive objects
 - Change drive object name/number
 - Change component name/number
- "Configuration" > "Sort..."
- "Configuration" > "Change..."
 - Change drive object name
 - Change component name
 - Change comparison level

Note

First commissioning is not necessary after changes to the topology.

16.1.1 Adding components

Introduction

If you connect a component (e.g. SMC20) via DRIVE-CLiQ to the drive system for the NCU, SINAMICS detects the change in the actual topology and sends the actual/reference topology difference to the HMI.

The new component must be configured on the HMI and assigned to a drive object (SERVO-DO/Motor Module) via the drive wizard.

Note

Up to version 2.5

A new motor with DRIVE-CLiQ can only be assigned to an existing drive object (SERVO-DO) (see following operating sequence, including "Add component") that has never previously been assigned an encoder interface or another motor with DRIVE-CLiQ and that has not yet ever been commissioned.

Operating sequence

1. Select the "Commissioning" > "Drive system" > "Drive units" menu.




Figure 16-3 "Drive system" > "Configuration" menu

2. Press "Topology".




Figure 16-4 Topology without new component

in the "Topology" menu, you start with the actual status (here an example).

The component has not been connected yet.

3. Connect a new DRIVE-CLiQ component (e.g. SMC20) to a Motor Module.

Note

Only plug in (connect) components when the drive unit is switched off.

Start-up	CHAN1	JOG Ref	MPF0					
<input checked="" type="checkbox"/> Channel reset			Program aborted	ROV				
201416 DP003.Slave003: CU_I_3.3.1 (1) component Control_Unit_1: Topology: Comparison additional component in actual topology. Component				Drive device+				
\Drive devices\Topology - Comp. topol. DP3.SLAVE3:CU_I_3.3.1 (1)				Drive device-				
Drive Object	-No.	Component	-No.	Socket	Socket	-No.	Component	Select drive dev.
CU_I_3.3.1	1	Control_Unit_1	1	X100	X200	2	Line_Module_2	Change...
				X101	X200	4	Motor_Module_3	
				X102	X500	201	<SMx module sin/cos>	
				X103				
				X104				
ALM_3.3.2	2	Line_Module_2	2	X200	X100	1	Control_Unit_1	Configure drive unit
				X201				Add component
SERVO_3.3.3	3	Motor_Module_3	4	X200	X101	1	Control_Unit_1	
				X201				
SERVO_3.3.3	3	SM_5	5	X202	X500	5	SM_5	Display options
		<SMx module sin/...>	201	X500	X202	4	Motor_Module_3	
				X102	X102	1	Control_Unit_1	
from:	CU_I_3.3.1.Control_Unit_1(1)						DS	
to:								
Configuration	Topology	PROFIBUS	Connections	Inputs / Outputs			Control unit MD	

Figure 16-5 Desired state

Start-up	CHAN1	JOG Ref	MPF0					
<input checked="" type="checkbox"/> Channel reset			Program aborted	ROV				
201416 DP003.Slave003: CU_I_3.3.1 (1) component Control_Unit_1: Topology: Comparison additional component in actual topology. Component				Drive device+				
\Drive devices\Topology - Comp. topol. DP3.SLAVE3:CU_I_3.3.1 (1)				Drive device-				
Drive Object	-No.	Component	-No.	Socket	Socket	-No.	Component	Select drive dev.
CU_I_3.3.1	1	Control_Unit_1	1	X100	X200	2	Line_Module_2	Change...
				X101	X200	4	Motor_Module_3	
				X102	X500	201	<SMx module sin/cos>	
				X103				
				X104				
ALM_3.3.2	2	Line_Module_2	2	X200	X100	1	Control_Unit_1	Configure drive unit
				X201				Add component
SERVO_3.3.3	3	Motor_Module_3	4	X200	X101	1	Control_Unit_1	
				X201				
SERVO_3.3.3	3	SM_5	5	X202	X500	5	SM_5	Display options
		<SMx module sin/...>	201	X500	X202	4	Motor_Module_3	
				X102	X102	1	Control_Unit_1	
from:	CU_I_3.3.1.Control_Unit_1(1)						Act. state	
to:	<unassigned>. <SMx module sin/cos>(201)							
Configuration	Topology	PROFIBUS	Connections	Inputs / Outputs			Control unit MD	

Figure 16-6 Actual state

16.1 Changing topology (modular machine)




Figure 16-7 Component not commissioned yet (201)

SINAMICS detects the change in the actual topology and sends the actual/reference topology difference to the HMI.

- GRAYED OUT -> Desired state, drive object/component not plugged in and/or deactivated in drive system

Use the cursor keys to select the required line. The state is indicated in the bottom part of the window.

- RED -> actual state - present in the actual topology

New components which haven't yet been commissioned have a component number > "200", in this example, the number is "201".

The new component must now be configured in the drive system via the vertical softkey "Add component...".

4. Press "Add component...".




Figure 16-8 Menu "Add component"

A new component has been found.

5. Press "OK" to configure and accept this component.




Figure 16-9 Configuration begins

During the unit configuration there are a succession of messages containing information on the configuration.

Determining the device configuration may take several minutes.

Before the configuration is completed, the HMI displays the following query:




Figure 16-10 Power on reset (warm restart)

6. Press "OK" to perform an NCK power on restart (warm restart).




Figure 16-11 Component accepted

The unit configuration is finished. The component has been accepted.

You have the following options to assign this component (e.g. SMC20 with new encoder) to a drive:

- Press "Drives" to open the drive wizard. Select the drive and run through the drive wizard to the encoder configuration (Page 82).
- Press "OK" and assign this component later to a drive.




Figure 16-12 "Topology" menu after "OK"

The actual state is displayed in the topology.

If you select the component with the cursor keys, the HMI informs you in the bottom area of the topology table, which components have been connected to this component via DRIVE-CLiQ.

Note

A non-assigned component must be commissioned with the drive wizard.

You can start the drive wizard via the "Topology" menu with the following operating sequence:

1. Press the <RECALL> key.
 2. Press "Drives".
-

See also

Drive diagnostics (Page 335)

16.1.2 "Topology" > "Change..." menu

16.1.2.1 Changing entry into topology

Introduction

You have the following options in the "Topology" > "Change..." dialog:

- Delete drive objects/components
- Enable/disable drive objects
- Change drive object name/number
- Change component name/number

Operating sequence for "Topology" > "Change" dialog

You have saved the drive data (see "Data backup of SINAMICS parameters" (Page 298))

You are in the "Commissioning" > "Drive system" > "Drive units" > "Topology" menu.

Start-up		RACK800		JOG Ref		MPF0		
Channel reset				Program aborted				
				ROV				
...Drive devices\Topology - Comp. topol.						DP3.SLAVE3:CU_I_3.3:1 (1)		
from		to						
Drive Object	-No.	Component	-No.	Socket	---	Socket	-No.	Component
CU_I_3.3:1	1	Control_Unit_1	1	X100	---	X200	2	Line_Module_2
				X101	---	X202	3	Motor_Modul...
				X102				
				X103				
				X104	---	X100		CU_NX_3.14:1
				X105	---	X500	14	SM_14
ALM_3.3:2	2	Line_Module_2	2	X200	---	X100	1	Control_Unit_1
				X201				
				X202				
SERVO_3.3:3	3	Motor_Modul...	3	X200				
				X201	---	X200	4	Motor_Modul...
				X202	---	X101	1	Control_Unit_1
SERVO_3.3:3	3	SM_14	14	X500	---	X105	1	Control_Unit_1
SERVO_3.3:4	4	Motor_Modul...	4	X200	---	X201	3	Motor_Modul...
				X201	---	X200	5	Motor_Modul...
				X202	---	X500	9	SM_9

from: CU_I_3.3:1.Control_Unit_1(1)
 to: ALM_3.3:2.Line_Module_2(2)

Configuration | **Topology** | PROFIBUS | Connections | Inputs / Outputs | Control unit MD

Figure 16-13 Changing topology (modular machine) SK "Change"

16.1 Changing topology (modular machine)

1. Press "Change...".




Figure 16-14 Changing topology (modular machine) > query

2. Read the query through carefully.

You have saved the data.

Press "OK".




Figure 16-15 Basic display for "Change topology (modular machine)"

3. You are in the basic display for changing the topology (modular machine).

Activate the following functions from this basic display:

- Delete drive objects/components
- Enable/disable drive objects
- Change drive object name/number
- Change component name/number

The sections below describe the operating sequences for these functions.

16.1.2.2 Deleting drive objects

Operating sequence

1. Use the cursor keys to select a drive object.

Once you have selected a drive object, the vertical "Delete drive object" softkey function is displayed.




Figure 16-16 Menu "Topology" > "Change..." > "SERVO_3_3:2 selected" drive object

2. Press "Delete drive object".




Figure 16-17 Menu "Topology" > "Change..." > "Delete drive object" Note for double motor module

A note regarding the drive object appears and you are again asked whether the drive object is to really be deleted.

3. Press "OK".

The drive object is deleted from the reference topology.

16.1.2.3 Deleting components

Operating sequence

1. Use the cursor keys to select a component.

Once you have selected a component, the vertical "Delete component" softkey function is displayed.




Figure 16-18 Menu "Topology" > "Change" > Component SM_2" selected

2. Press "Delete component".




Figure 16-19 Menu "Topology" > "Change" > "Delete component" > Note relating to component

3. A note regarding the component appears and you are again asked whether the component is to really be deleted.

4. Press "OK".

The component is deleted from the reference topology.




Figure 16-20 Menu "Topology" > "Change" > "Component deleted" > Warning relating to component

5. A warning appears above the topology window if the component is still present in the actual topology.

6. Press "OK".




Figure 16-21 Menu "Topology" > "Topology comparison" view

7. You can see in the window with the "Topology comparison" view that the "SMx module" component in the actual topology is still wired (highlighted in red).

8. Remove the module.

16.1.2.4 Enabling/disabling drive object

Introduction

In the "Topology" > "Change..." menu you can disable/enable drive objects directly in the drive system.

Operating sequence

1. Use the cursor keys to select a drive object.

Once you have selected a drive object, the vertical "Enable/disable dr. obj." softkey function is displayed.




Figure 16-22 "Topology" > "Change" menu

2. Press "Enable/disable dr. obj."

Follow the instructions given by the messages.




Figure 16-23 Menu "Topology" > "Change" > SERVO_3.3:2 disabled drive object

3. Once successfully disabled, the drive object and the associated components are grayed out.
4. If you want to reactivate this drive object, press "Enable/disable dr. obj."
Follow the instructions given by the messages.

16.1.2.5 Changing drive object/component names/numbers

Introduction

You have the following options under the menu:

- "Topology" > "Change..."
 - Change drive object name/number
 - Change component name/number




Figure 16-24 Menu "Topology" > "Change..." > "Drive object no. 2" set to 20

- "Configuration" > "Change..."
 - Change drive object name
 - Change component name
 - Change comparison level




Figure 16-25 Menu "Configuration" > "Change..." > Name/comparison level

Note

Changing the names and numbers affects data in the reference and actual topology for the drive software.

Changing the comparison level affects the topology comparison in the drive software.

Operating sequence

1. Position the cursor in the "Change..." menu on the corresponding field. Specify a new "Name/number/comparison level".
2. Press <Input>.

16.1.3 Replacing SINAMICS S120 components

Introduction

The operating sequences describe two procedures for replacing a component:

- Replacing a motor module with a more powerful one.
- Replacing SMI/SMx motor component.

Operating sequence for replacing a motor module with a more powerful one.

The following prerequisites are satisfied:

- The motor modules are of the same type.
- The serial number is different.
- MLFB number differs e.g. instead of 5 A -> 9 A.

Note

DRIVE-CLiQ components simply have different serial numbers

In this case no further configuration is needed.

Note

A permanent change in the drive system should not be undertaken

Before you replace the DRIVE-CLiQ component, change the comparison level.

1. Select the "Commissioning" > "Machine data" > "Control unit MD" dialog.
 2. Change parameters p9907 (component number) and p9908 (comparison level of a component).
 3. Save (Page 298) the changed drive data before switching off (power OFF).
 4. Switch the drive system off (power OFF).
 5. Replace the component.
 6. Switch the drive system on (power ON).
 7. No further configuration is required.
-

You have replaced the motor module with the drive system switched off.

The motor module should be permanently replaced.

1. Select the "Commissioning" > "Machine data" > "Control unit MD" dialog.
2. Set the "Device configuration" parameter to control unit: p0009 = 1
3. Transfer the new component: Control Unit: p9905 = 2
4. Wait until p9905 = 0 is automatically set.
5. Set the "Device configuration" parameter to control unit: p0009 = 0
6. Save "All": set p977 = 1.
7. It is imperative you wait until p977 is automatically written back to "0" this takes about 40 seconds.

The replacement of a single SINAMICS component is automatically acknowledged by the system.

Operating sequence for replacing SMI/SMx motor component

1. You have removed the previous SMI or SMx motor component.

This motor component is missing from the actual topology.

SINAMICS indicates this in the form of a topology error alarm.

The "Commissioning" > "Drive system" > "Drive units" > "Topology" dialog shows the previous motor component awaiting replacement GRAYED OUT (present in reference topology only).

Note

The new SMI/SMx motor component must not yet be inserted!

2. In the "Commissioning" > "Drive system" > "Drive units" > "Topology" > "Change..." dialog, remove the SMI/SMx motor component awaiting replacement from the reference topology using the "Delete component" dialog (Page 322).

Note

Save (Page 298) the changed drive data before switching off (power OFF).

3. Switch the drive system off and on (power OFF/ON).
4. In the "Commissioning" > "Drive system" > "Drive units" > "Topology" dialog box, check whether the SMI/SMx motor component has been removed from the reference topology - and check the following:
 - Topology error alarm no longer active.
 - "Commissioning" > "Drive system" > "Drive units" > "Topology" dialog no longer shows any differences.
5. Switch off the drive system.
6. Plug in the new SMI/SMx motor component.
7. Switch on the drive system.
8. Add the new SMI/SMx motor component using the "Commissioning" > "Drive system" > "Drive units" > "Topology" > "Add component" (Page 311) dialog for the reference topology.
9. Assign the added SMI/SMx motor component via the "Commissioning" > "Drive system" > "Drives" (Page 82) drive wizard.

16.1.4 Display options

Introduction

The "Display options" function allows you to do things like set which drive object and component properties are to be displayed in the "Configuration" and "Topology" windows.

Operating sequences for "Configuration" window

You are in the "Commissioning" > "Drive system" > "Drive units" menu.

1. Select "Configuration" > "Display options".




Figure 16-26 "Configuration" > "Display options" menu.

Define the following properties for the "Configuration" window:

- Topology display
- Columns to be displayed
- Filter for drive objects and components to be displayed

Operating sequences for "Topology" window

You are in the "Commissioning" > "Drive system" > "Drive units" menu.

1. Select "Topology" > "Display options".




Figure 16-27 "Topology" > "Display options" menu.

Define the following properties for the "Topology" window:

- Topology display
- Filter for drive objects and components to be displayed

When you click on filter "off", even components which are not in the DRIVE CLiQ are displayed.




Figure 16-28 "Topology" menu - Filter "off" has been selected for the "Display options".

16.1 Changing topology (modular machine)

The colors used in the topology window have the following meanings for the drive objects and components:

- GRAYED OUT -> Desired state, drive object/component not plugged in and/or deactivated in drive system

Use the cursor keys to select the required line. The state is indicated in the bottom part of the window.

- RED -> actual state - present in the actual topology

16.1.5 Sorting the topology display

Operating sequence

In the "Drive system" > "Drive units" > "Configuration" menu you can call up a sorting function for the topology display.




Figure 16-29 "Drive system" > "Drive units" > "Configuration" menu

1. Press "Sort...".




Figure 16-30 "Configuration" > "Sort..." menu

2. In the "Sort" dialog select from the following sorting options for displays in the topology window:

- Drive object
The display is sorted by drive object number.
- Wiring
The display is sorted by the wiring of the drive components in the drive system.
- Component number
The display is sorted by component number.
- Axis
The display is sorted by axis number.

3. Press "OK".

16.1.6 Check topology

Introduction

After you have parameterized the drive components, you can view the topology on the HMI.

Topology of individual drive components

1. Under "Commissioning", press the "Drive system" > "Drive units" > "Topology" softkeys one after the other.
2. On the HMI, the topology of individual drive components is displayed, including the component number (see figure below).

You can now check whether the topology displayed conforms with the topology of your system.

Start-up	RACK1003	JOG Ref	MPF0
Channel interrupt		Program aborted	
Stop: No NC Ready		ROV	
240003 ↓ DP003.Slave003: ALM_3.3.2 [2]: Fault at DRIVE-CLiQ socket X103. 40799.			
Topology DP3 SLAVE3:CU_1_3.3:1 [1]			
Component	-No.	Connection	Component -No. Connect...
Control_Unit_1	1	X100	Line_module_2 2 X201
		X101	
		X102	Motor_Module_3 3 X200
		X103	CU_NX_3.13:1 X100
		X104	
		X105	SM_14 14 X500
Line_module_2_	2	X200	
		X201	Control_Unit_1 1 X100
		X202	
Motor_Module_3/ Motor_Module_4	3	X200	Control_Unit_1 1 X102
	4	X201	Motor_Module_5 5 X202
	3	X202	SMI20_16 16 X500
	4	X203	SM_9 9 X500
SM_14	14	X500	Control_Unit_1 1 X105
Motor_Module_5	5	X200	
		X201	SMI20_6 6 X500
from: CU_1_3.3:1.Control_Unit_1[1]		to: ALM_3.3:2.Line_module_2_[2]	
Configur- ation	Topology	PROFIBUS link	Conne- ctions
		Inputs / Outputs	Control unit MD
			File functions

Figure 16-31 Topology

You will need the component numbers in order to configure direct measuring systems manually.

See also

Drive diagnostics (Page 335)

16.2 Drive diagnostics

Introduction

You can view the alarms and faults of the drive in the "Diagnostics" > "Drive system" operating area on the HMI.




Figure 16-32 Overview of drive states, "Diagnostics" > "Drive system" menu

Operating sequence

1. Select the relevant drive component with the cursor in the overview of the drive states.
2. Press "Details".




Figure 16-33 "Diagnostics" > "Drive system" > "Details" menu

3. Press "Alarms".




Figure 16-34 "Diagnostics" > "Drive system" > "Details" > "Alarms" menu

4. Press "Faults".




Figure 16-35 "Diagnostics" > "Drive system" > "Details" > "Faults" menu

See also

Adding components (Page 311)

Check topology (Page 334)

16.3 Diagnostics for pending alarms

Introduction

Alarms - these are warnings and faults - can be viewed in SINAMICS S120 via parameters.

Warnings

Pending warnings are indicated by parameter r2122 of the relevant drive components in question.

Deleting the warning buffer may be carried out manually:

- Write r2111 of the drive component with "0".

This results in the deletion of all existing warnings of this component and updates the current warnings still pending.

Faults

Fault messages are indicated by parameter r945.

Display on HMI

If you set the MD13150 \$MN_SINAMICS_ALARM_MASK to the hexadecimal value "D0D" on the HMI, then the HMI automatically displays the pending warnings/faults from SINAMICS S120.

16.4 Drive (SERVO) parameter RESET, individual

Introduction

The factory setting (parameter RESET) may be set for each drive (SERVO) individually.

Note

Not just the motor and encoder data are reset. All the configured Binector-Connector logic operations (releases, probe signals) and message frame type are also deleted.

Operating sequence

1. Set the factory settings on the selected drive: p0010 = 30
2. Activate the factory settings on this drive: p0970 = 1
3. Device automatically carries out RESET of all parameters on this drive.
4. Save drive-specific: set p971 = 1
or
save "All": set p977 = 1
5. It is imperative you wait until p977/p971 is automatically written back to "0"; this takes about 40 seconds.

16.5 Firmware version display of drive components

Introduction

The firmware version of the drive components can be viewed under "Commissioning" > "Drive system" > "Drive units" > Configuration" in the "FW comp" column.

Example: 2603000, -> Firmware version is 02.60.30.00

Axis	Drive Object	Component	-No.	FW comp.	type	C.level
	CU_I_3.3.1	Control_Unit_1	1	2603700	NCU/220	High
	LM_3.3.2	Line_Module_2	2	2603700	LM_ACDC	High
X1	SERVO_3.3.3	Motor_Module_3	4	2603700	MM_1AXIS_DCAC	High
X1	SERVO_3.3.3	SM_5	5	2603700	SMx module sin/cos	High

Figure 16-36 Menu "Drive system > Configuration"

Using certain parameters from individual drive components, it is also possible to view the relevant firmware version for:

- System software SINAMICS S120
- Firmware from:
 - Drive components
 - SMC or SMI modules

System software SINAMICS S120

The version of the SINAMICS S120-SW available in the system is readable in parameter r18 on the TCU/PCU.

Example:

r18 = 2300700, -> firmware version is 02.30.07.00

Firmware version drive components

The firmware version of all individual components is read out individually in parameters r975[2] and r975[10] for each drive component (NCU, ALM, power unit).

Example:

r975[2] = 230, r975[10] = 700 -> "230" & "700" -> firmware version is 02.30.07.00

Firmware version of all SMC or SMI modules

The firmware version of all SMC or SMI modules is read out in parameter r148[0...2] on the relevant motor module.

Example:

r148[0] = 2300700, -> firmware version of the connected encoder module 1 is 02.30.07.00

16.6 Checking/setting power supply data settings

Introduction

The power supply data settings must be checked/set in the SINAMICS during commissioning.

Checking/setting network data when commissioning the infeed

You can use the "Commissioning" > "Drive units" > "Infeed" > "Configuration" > "Network data" menu to view and modify the network data.




Figure 16-37 Network data

See also

Identification/Optimization "ALM > Infeed/Configuration" (Page 342)

16.7 Identification/Optimization "ALM > Infeed/Configuration"

Introduction

On identification of the ALM, control optimization in the ALM is also carried out. Here, the inductance and capacity of the DC link are determined and the optimum control data determined for the set-up converter.

Identification can only be performed after the controller and the drive have been put into operation.

Procedure for automatic identification of the ALM

Identification of the ALM is performed automatically by the system in the current SINAMICS versions as soon as the first drive has been commissioned and enable terminal X122.1 activated. An internal optimization sequence is started automatically; it takes approx. 20 seconds to complete.

During this optimization sequence, enable terminal X122.1 should not be deactivated; otherwise the optimization would be aborted. If optimization is aborted, identification may be carried out manually at a later stage by the user.

Procedure for manual identification of the ALM

Identification of the ALM is carried out as follows:

1. Disconnect release (AUS1) ALM (X122.1) by commissioner.
2. Select machine data for the infeed (ALM) in the "Commissioning" > "Machine data" > "Infeed MD" menu.
3. Initiate identification on the ALM: p3410 = 5.
4. Connect release ALM (release has to remain pending during the execution of the first step of the identification).
5. ALM controller data are reset automatically and power supply identification starts.
6. After identification has occurred, p3410 is automatically written to 0 and the values are saved automatically for the controller data of the ALM. Check: p3402 = 9 (release has to remain during the execution of this step of the identification!).
7. Disconnect release ALM (X122.1) by commissioner.
8. The optimized ALM data are saved automatically. The data does not need to be saved manually (p977 = 1).

16.8 Configuring motor data sets

Introduction

You can configure the following drive data sets:

- Motor data set -> MDSx (max. 4)
- Drive data set -> DDSx (max. 8 pro MDS)
- Encoder data sets -> MDSx (max. 3)

Data sets are configured under the menu "Commissioning" > Drive system" > "Drives" > "Data sets".

Motor	Motor Data Set	Drive Data Set	Encoder1	Encoder2	Encoder3
Motor0	MDS0	DDS0	EDS0		
Motor1					
Motor2					
Motor3					

Figure 16-38 "Drives" > "Data sets" menu

Note

The particular drives must have been already commissioned.

Operating sequence

1. Press "Change".




Figure 16-39 "Drives" > "Data sets" > "Change" menu

2. The following options are now available:
 - "Insert MDS"
 - "Delete MDS", if an additional data set was created.
 - "Change EDS"
 - "Change DDS"

3. Press "Insert MDS".




Figure 16-40 "Insert MDS" menu

The system automatically creates a new motor data set. In the example, "MDS1"
The existing MDS0 is copied to MDS1 here.




Figure 16-41 Empty MDS

Alternatively, the "empty" MDS1 can also be generated, which must then be subsequently commissioned.

Note

Up to three motor data sets can be created with "Insert MDS".

- MDS0 -> DDS0 to DDS7 (is always created as standard)
- MDS1 -> DDS8 to DDS15
- MDS2 -> DDS16 to DDS24
- MDS3 -> DDS25 to DDS32

4. Press "Next >".



Figure 16-42 DDS -> Drive Data Sets

The drive data sets from MDS0 are assigned to MDS1 as copy.

In the example, DDS8 to DDS15.

5. Press "Next".




Figure 16-43 "Summary" dialog box

In the summary, you can again check what the system inserts.

With "Complete", the system creates the new MDS1 as copy of MDS0. The drive data sets DDS0 to DDS7 (MDS0) are also copied into MDS1 (DDS8 to DDS15).

Note

You exit the "Insert MDS" dialog box with "Complete".

If you click on the field "Start drive assistant" then you go directly to the menu "Commissioning" > "Drive units" > "Drive".

6. Press "Complete".




Figure 16-44 "Store in non-volatile manner?" dialog box

7. Respond to the prompt that is displayed with "yes".




Figure 16-45 New motor data set with drive data set and encoder data set

The new motor data set is created.

8. Press <RECALL>.




Figure 16-46 "Drives" > "Configuration" menu

You are in the "Drives" > "Configuration" menu.

9. Press "Select MDS..."




Figure 16-47 "Drives" > "Configuration" > "Select MDS" menu pressed

Now, in the direct selection, you can select the motor data set in the selection box.

10. The new motor data set for the drive is selected with "Accept".




Figure 16-48 New motor data set

The drive can now be commissioned.

11. Press "Change..."

The drive wizard now guides you as you commission the drive.

Licensing

17.1 Import licensing terms

The terms below are important for understanding the license management of SINUMERIK software products.

Term	Description
Software product	"Software product" is generally used to describe a product that is installed on a piece of hardware to process data. Within the license management of SINUMERIK software products, a corresponding license is required to use each software product.
Hardware	In the context of license management of SINUMERIK software products, "hardware" refers to the component of a SINUMERIK control system to which licenses are assigned on the basis of its unique identifier. License information is also saved to remanent memory on this component. Example: <ul style="list-style-type: none"> • SINUMERIK 840D sl: CF card • SINUMERIK 840Di sl: MCI board
License	A license gives the user a legal right to use the software product. Evidence of this right is provided by the following: <ul style="list-style-type: none"> • CoL (Certificate of License) • License key
CoL (Certificate of License)	The CoL is the proof of the license. The product may only be used by the holder of the license or authorized persons. The CoL includes the following data relevant for the license management: <ul style="list-style-type: none"> • Product name • License number • Delivery note number • Hardware serial number <p>Note The hardware serial number is located only on a CoL of the system software or if the license was ordered bundled, in other words the system software came together with options.</p>
License number	The license number is the feature of a license that is used for its unique identification.
CF Card (Compact Flash Card)	The CF Card represents, as the carrier of all the remanent data of a SINUMERIK solution line control system, the identity of this control system. The CF Card includes the following data relevant for the license management: <ul style="list-style-type: none"> • Hardware serial number • License information including the License Key

Term	Description
Hardware serial number	The hardware serial number is a permanent part of the CF Card. It is used to identify a control system uniquely. The hardware serial number can be determined by: <ul style="list-style-type: none"> • CoL (see: Certificate of License > "Note") • HMI user interface • Printing on the CF Card
License key	The License Key is the "technical representative" of the sum of all the licenses that are assigned to one particular piece of hardware, which is uniquely marked by its hardware serial number.
Option	One option is a SINUMERIK software product that is not contained in the basic version and which requires the purchase of a license for its use.
Product	A product is marked by the data below within the license management of SINUMERIK software products: <ul style="list-style-type: none"> • Product designation • Order number • License number

17.2 Overview

The use of the installed system software and the options activated on a SINUMERIK control system require that the licenses purchased for this purpose are assigned to the hardware. In the course of this assignment, a License Key is generated from the license numbers of the system software, the options, as well as the hardware serial number. Here, access occurs to a license database administered by Siemens A&D via the Internet. Finally, the license information including the License Key is transferred to the hardware.

There are two ways to access the license database:

- Web License Manager
- Automation License Manager

Note

Using SINUMERIK software products for testing purposes

SINUMERIK software products may be temporarily activated and used for testing purposes on a SINUMERIK control system, even without the corresponding License Key.

On the SINUMERIK user interface, the license key is displayed as "not sufficient" in the dialog box: "Overview" of the license information. Also the control system will repeatedly display a corresponding message.

17.3 Web License Manager

By using the Web License Manager, you can assign licenses to hardware in a standard Web browser. To conclude the assignment, the License Key must be entered manually at the control system via the HMI user interface.

Internet address

The Internet address of the Web License Managers is:
<http://www.siemens.com/automation/license>

17.4 Automation License Manager

The Automation License Manager can be used to assign all the licenses required for a piece of hardware (license-requirement comparison). The license information, including the License Key, is transferred electronically via an Ethernet link (TCP/IP).

Preconditions:

- The Automation License Manager must be installed on the computer (PC/PG) that is used to assign the licenses to the hardware.
- The computer (PC/PG) must be able to connect to the license database and the SINUMERIK control system via Ethernet link (TCP/IP):
 - License database: Internet connection
 - SINUMERIK control system: Intranet or PTP connection (Ethernet, Peer-To-Peer)

The individual steps for assigning licenses to hardware (license database) and the transfer of license information from/to the SINUMERIK control system can be performed such that only one connection must be available at any one time.

17.5 License database

The license database contains all the customer-specific license information relevant for the license management of SINUMERIK software products. The central management of the license information in the license database ensures that the existing license information regarding a piece of hardware is always up to date.

License database access

License database access occurs via:

- Direct access

The direct access occurs with:

- Delivery note number
- License number

The direct access enables the direct assignment of licenses for which the license numbers are available, e.g., in the form of a CoL.

- Customer login

The customer login occurs with:

- User name
- Password

The customer login enables the assignment of all the licenses available to the user that are delivered at the time of the login and have not yet been assigned to any hardware. Here, the license numbers of licenses that can still be assigned need not be directly at hand, instead these are displayed from within the license database.

Note

Customer login

You can obtain a customer login from Siemens A&D Mall under menu item: "Registration". The Internet address is: <http://mall.automation.siemens.com/>

Currently, access is not yet possible for all countries.

Various license information

As indicated above, only the license information in the license database represents the current status regarding a piece of hardware. Differences may arise between the license information available for a piece of hardware and that of the license database due to:

- loading older archive data into the NCK (data restoration from a series-commissioning file after a service job)
- assigning licenses to hardware without transferring the modified license information for the hardware control system (online)

As a result, a more limited license requirement (possibly no license requirement) may be displayed than indicated on the HMI user interface of the control system for a license requirement alignment by Automation License Manager.

To align the license information, a transfer should be carried out for the current license information of the license database for the hardware control system (online).

17.6 CF Card and hardware serial numbers

The CF card (Compact Flash card) contains, in addition to the system and user software and the retentive system and user data, that data relevant for the license management of SINUMERIK software products of a control system:

- Hardware serial number
- License information including the License Key

The CF card thus represents the identity of a SINUMERIK control system. For this reason, assigning licenses to a control system always occurs using the hardware serial number.

This has the advantage that the CF card can be slotted into a replacement NCU in the event of failure and all data is retained.

Automation License Manager

Thus, the hardware serial number is always decisive during the transfer of license information to a control system in Automation License Manager and not the set IP address of the control system with which Automation License Manager is currently communicating.

Determining the hardware serial number

The hardware serial number is a permanent part of the CF card. It is used to identify a control system uniquely. The hardware serial number can be determined by:

- CoL (Certificate of License) (see note)
- SINUMERIK user interface, e.g. HMI Advanced
- Printing on the CF card
- Display in the Automation License Manager as supplementary information for the elements below:
 - Control system file
 - Control system (online)
 - Control image (offline)

Note

Hardware serial number and CoL

The hardware serial number is located only on a CoL of the system software or if the license was ordered bundled, in other words the system software came together with options.

17.7 SINUMERIK License Key

Basic information on License Keys

If a license is required for a product, then with the purchase of the license the purchaser receives a CoL as proof for the rights to use this product and a corresponding License Key as to the "technical representative" of this license. In conjunction with software products, the License Key usually must be available on the hardware on which the software product executed.

SINUMERIK License Keys

Depending on the software product, there are License Keys with different technical properties. The essential properties of a SINUMERIK License Key are:

- **Hardware reference**
The hardware serial number included in the SINUMERIK License Key provides a direct link between the License Key and the hardware on which it can be used. In other words, a License Key created for the hardware serial number of a specific CF card is only valid for this CF card and will be rejected on other CF cards as invalid.
- **Total number of assigned licenses**
A SINUMERIK License Key not only refers to one single license, instead it is the "technical representative" of all licenses that are assigned to the hardware at the time of its generation.

Copying SINUMERIK License Keys

By the fixed reference to certain hardware, a SINUMERIK License Key may, for example, be copied to various computers (PC/PG) and/or memory media for security or archiving purposes.

17.8 Assigning via Web License Manager

17.8.1 You can execute an assignment via direct access as follows

Background

For the direct access, log on to a computer connected to the Internet (PC/PG) with the delivery note and license number in the Web License Manager. All licenses of the delivery note numbers entered at the login may then be assigned to a piece of hardware. After completing the assignment process, the new License Key is displayed. This must then be entered in the license dialog box of the HMI components used.

Preconditions

The following prerequisites must be met in order to assign a license to a piece of hardware via direct access and HMI user interface:

- The HMI component is connected with the control system (NCU) on which the license should be assigned. Both components have booted.
- A computer (PC/PG) with Internet connection and browser is available.
- The login data for the direct access (e.g., per CoL) are available:
 - License number
 - Delivery note number

Assigning a license to a piece of hardware

1. Determine the HW serial number and the designation of the product (HMI-Advanced / HMI- Embedded: "Type of hardware") using the HMI license dialog box.
HMI-Advanced / HMI-Embedded:

Operating-area switchover: Commissioning > Key: etc. (">") > Licenses > Overview

Note

Ensure that the hardware serial number displayed is also really the one you want to make the assignment for. The assignment of a license to a piece of hardware cannot be reversed via the Web License Manager.

2. Go to the Internet page of the Web License Manager:
<http://www.siemens.com/automation/license>
 3. Login via "Direct access":
 - License number
 - Delivery note number
 4. Follow the additional instructions in the Web License Manager.
-

Note

License Key via e-mail

If you have an e-mail address, you have the option (checkbox) of receiving the License Key by e-mail. Advantage: It is simpler to enter the License Key at the control.

5. After completing the assignment process, enter the License Key displayed on the Web License Manager into the license dialog box of the HMI user interface.
HMI-Advanced / HMI-Embedded:

Operating-area switchover: Commissioning > Key: etc. (">") > Licenses > Overview

6. Confirm the entry of the new License Key by pressing the softkey: "Accept".

17.8.2 You can execute an assignment via customer login as follows

Background

For the customer login, log on to a computer (PC/PG) connected to the Internet with the user name and password in the Web License Manager. All licenses released for this user name in the framework of the license management may then be assigned to a piece of hardware. After completing the assignment process, the new License Key is displayed. This must then be entered in the license dialog box of the HMI components used.

Preconditions

The following prerequisites must be met in order to assign a license to a piece of hardware via customer login and HMI user interface:

- The HMI component is connected with the control system (NCU) on which the license should be assigned. Both components have booted.
- A computer (PC/PG) with Internet connection and browser is available.
- The login data for the customer login is available:
 - User name
 - Password

Assigning a license to a piece of hardware

1. Determine the HW serial number and the designation of the product (HMI-Advanced / HMI- Embedded: "Type of hardware") using the HMI license dialog box.
HMI-Advanced / HMI-Embedded:

Operating-area switchover: Commissioning > Key: etc. (">") > Licenses > Overview

Note

Ensure that the hardware serial number displayed is also really the one you want to make the assignment for. The assignment of a license to a piece of hardware cannot be reversed via the Web License Manager.

2. Go to the Internet page of the Web License Manager:
<http://www.siemens.com/automation/license>
3. Login via "Customer login":
 - User name
 - Password

4. Follow the additional instructions in the Web License Manager.

Note

License Key via e-mail

If you have an e-mail address, you have the option (checkbox) of receiving the License Key by e-mail. Advantage: It is simpler to enter the License Key at the control.

5. After completing the assignment process, enter the License Key displayed on the Web License Manager into the license dialog box of the HMI user interface.

HMI-Advanced / HMI-Embedded:


Operating-area switchover: Commissioning > Key: etc. (">") > Licenses > Overview

6. Confirm the entry of the new License Key by pressing the softkey: "Accept".

17.9 Assigning via Automation License Manager

17.9.1 Function Overview

The following figure provides an overview of the functions available and the sequence in which they should be applied.



17.9.2 Installing the Automation License Manager

Background

The following components need to be installed for the license management of SINUMERIK solution line License Keys:

- Automation License Manager
The Automation License Manager is loaded by the installation routine only if no manager or a manager version with a lower version number is installed on the computer (PC/PG).
- SINUMERIK plug-in
The SINUMERIK plug-in is loaded by the installation routine only if it finds a version of the Automation License Manager installed on the computer (PC/PG).
- HMI basic software
The HMI basic software is loaded by the installation routine only if no HMI software or a version with a lower number is installed on the computer (PC/PG).

Note

The Automation License Manager is used for all Siemens A&D products, e.g. SIMATIC STEP7. As versions of the Automation License Manager are upwards compatible, we always recommend using the version with the highest version number, irrespective of the source of supply (e.g. SINUMERIK or SIMATIC product CD, download via A&D Mall, etc.).

System requirements

Hardware

- Computer: Industrial PC, programming device, etc.
- Work memory: \geq 128 MB
- Free hard-disk storage:
 - 5 MB (SINUMERIK plug-in)
 - + 32 MB (Automation License Manager)
 - + 300 MB (HMI basic software)
- Operating system: Windows XP

Execution

1. Launch the installation program for the Automation License Manager from "SETUP.EXE" and follow the instructions for the installation.
2. Launch the installation program for the SINUMERIK plug-in from "SETUP.EXE" and follow the instructions for the installation.
The HMI basic software can be installed as part of this process.

17.9.3 Enabling/disabling SINUMERIK plug-ins

Background

All of the plug-ins enabled for the Automation License Manager scan the relevant communication interfaces when booting and after specific operator inputs. If there is a large number of enabled plug-ins, this can result in a significantly longer boot and refresh time for the user interface. To prevent this delay, you can disable the plug-in installed for handling the SINUMERIK License Keys in dialog: "Connect to target system".

Procedure

Perform the following actions to enable/disable the SINUMERIK plug-ins:

1. Start the Automation License Manager
2. Open the "Connect to target system" dialog via menu command: **Edit > Connect to target system > SINUMERIK . . .**
3. In the dialog, open tab: **Settings**
4. Enable/disable the plug-in by selecting/deselecting the appropriate checkbox.
5. Close the dialog by pressing the button: **OK**

Result

The Automation License Manager shows the SINUMERIK-specific license information in accordance with the current status of the SINUMERIK plug-in. See Section:

Note

How to refresh the view manually

If the view is not automatically refreshed, you can refresh the view manually. See Section: "How to refresh the view: Manage"

17.9.4 Assigning parameters to the TCP/IP communication with a control system

Background

To be able to read or transfer license information from or to the CF card of a control system, the Automation License Manager must communicate with the control system via TCP/IP.

Requirements:

- The HMI basic software is installed
- The SINUMERIK plug-in is enabled

Note

HMI Advanced

If the SINUMERIK user interface "HMI Advanced" is installed on the same computer (PC/PG) as the Automation License Manager you can set the IP address using the user interface. The IP address for the control system with which both HMI Advanced as well as the Automation License Manager communicate is set via the following dialog:

Operating area switchover > Start-up > HMI > NCU link

This requires at least the password of protection level 2 (manufacturer) to be set.

General communication parameters

The default general communication parameters for the HMI basic software are stored in the following initialization file:

<installation drive>:\Siemens\Sinumerik\HMI-Advanced\mmc2\MMC.INI

User-specific communication parameters

The user-specific communication parameters for the HMI basic software are stored in the following initialization file:

<installation drive>:\Siemens\Sinumerik\HMI-Advanced\user\MMC.INI

During evaluation of the initialization data when booting the HMI basic software, user-specific communication parameters have priority over general communication parameters.

Sections of the initialization file: MMC.INI

The parameters relevant to TCP/IP communication with SINUMERIK control systems are stored in the following sections:

- [GLOBAL]
Section: [GLOBAL] specifies the section (e.g. *AddressParameter*) that contains the communication parameters for the current SINUMERIK control system.
- [*AddressParameter*]
The name of this section can be any unique ASCII string within the file. The specified IP address is crucial for communication with the current SINUMERIK control system: *IP address*.

Table 17- 1 User-specific file: MMC.INI

Statements
<pre>[GLOBAL] NcddeMachineName = AddressParameter NcddeDefaultMachineName = AddressParameter NcddeMachineNames = AddressParameter [AddressParameter] ADDRESS0 = IP address, LINE=10,NAME=/NC, SAP=030d, PROFILE=CLT1__CP_L4_INT ADDRESS1 = IP address, LINE=10,NAME=/PLC, SAP=0201, PROFILE=CLT1__CP_L4_INT ADDRESS2 = IP address, LINE=10, NAME=/DRIVE0, SAP=0900, PROFILE=CLT1__CP_L4_INT ADDRESS3 = IP address, LINE=10, NAME=/DRIVE1, SAP=0a00, PROFILE=CLT1__CP_L4_INT ADDRESS4 = IP address, LINE=10, NAME=/DRIVE2, SAP=0b00, PROFILE=CLT1__CP_L4_INT ADDRESS5 = IP address, LINE=10, NAME=/DRIVE3, SAP=0c00, PROFILE=CLT1__CP_L4_INT ADDRESS6 = IP address, LINE=10, NAME=/DRIVE4, SAP=0d00, PROFILE=CLT1__CP_L4_INT ADDRESS7 = IP address, LINE=10, NAME=/DRIVE5, SAP=0e00, PROFILE=CLT1__CP_L4_INT</pre>

Multiple SINUMERIK control systems

If you require communication with multiple SINUMERIK control systems you must create a section

[*AddressParameter*] with a unique name e.g. [840D_001], [840D_002], etc. for each control system with the relevant IP address.

In the [GLOBAL] section, you must specify the section name for the SINUMERIK control system, e.g. [840D_001], with which communication should occur once the Automation License Manager has booted.

NOTICE

Editing the IP address

The IP address specified in the user-specific initialization file MMC.INI influences not only the Automation License Manager but also all other applications installed on the same computer (PC/PG) that use HMI basic software (e.g. HMI Advanced).

To apply the change to the active IP address, you must close all active applications using HMI basic software (e.g. HMI Advanced). Once you have closed all applications, restart the computer to activate the new IP address.

Requirements

The following conditions must be fulfilled:

- The HMI basic software is installed on the computer (PC/PG) on which the Automation License Manager is running.
- The IP addresses of the SINUMERIK control systems with which the Automation License Manager must communicate are known.

Procedure: Creating parameters for the first time

Perform the following actions when creating user-specific communication parameters for the first time:

1. Create the text file:
<installation drive>\Siemens\Sinumerik\HMI-Advanced\user\MMC.INI if it does not already exist.
2. Open the file MMC.INI with a text editor.
3. Copy the [GLOBAL] section from the table given above: "User-specific file: MMC.INI" to the open file MMC.INI.
4. Copy the [*AddressParameter*] section from the table given above: "User-specific file: MMC.INI" to the open file MMC.INI according to the number of available SINUMERIK control systems.
5. For all [*AddressParameter*] sections replace the string: "AddressParameter" with a unique name.
6. In all [*AddressParameter*] sections replace the string: "IP-Address" with the relevant IP address for the corresponding SINUMERIK control system.
7. In the [GLOBAL] section replace the string: "*AddressParameter*" with the section name for the SINUMERIK control system with which the Automation License Manager must communicate after booting. (See note "Changing the IP address" above.)

Procedure: Changing the active control system (online)

Perform the following actions to change the active control system (online), i.e. the SINUMERIK control system with which the Automation License Manager communicates:

1. Close the Automation License Manager.
(See note "Changing the IP address" above.)
2. Open the file: <installation drive>\Siemens\Sinumerik\HMI-Advanced\user\MMC.INI with a text editor.
3. In the [GLOBAL] section, replace the current address string with the section name for the SINUMERIK control system with which the Automation License Manager should communicate after booting.
4. Start the Automation License Manager.

Result

After booting the Automation License Manager communicates with the SINUMERIK control system defined in the user-specific communication parameters.

The control system to which you have switched is represented by an "online" control system file in the navigation area of the Automation License Manager.

The control system to which the Automation License Manager was connected before switching is represented by an "offline" control system file, if a control image (offline) exists.

17.9.5 How to refresh the navigation view: "Manage"

Background

After actions which add or remove elements in the navigation area of the navigation view: "Manage" of the Automation License Manager (e.g. deletion of a control image (offline), enabling/disabling of plug-ins), the view is normally refreshed automatically. If the view does not refresh automatically after an operation, you can refresh the view manually.

Execution

Perform the following actions to refresh the navigation view: "Manage" manually:

1. Select the following nodes in the navigation area of the Automation License Manager:
My Computer
2. Refresh the view using one of the following options:
 - Menu command: **View > Refresh**
 - Key **F5**
 - Toolbar: 

Result

The navigation view of the Automation License Manager is refreshed. All sub-nodes under the node: **My Computer** are closed.

The object view of the Automation License Manager shows the current nodes and drives of the navigation area.

Note

All directories are closed when the view is refreshed. When you select key: ' * ' on the numeric keypad, you can open all directories with a single key.

17.9.6 Displaying the license information of a piece of hardware

Background

To perform one of the following tasks with the Automation License Manager:

- Check the license information for the hardware
- Ascertain the license requirement for the hardware and align if necessary
- Assign new licenses to hardware and transfer updated license information including License Keys to the hardware

you must display the license information for a hardware item.

Requirements

The license information can only be displayed if the Automation License Manager is communicating with the relevant SINUMERIK control system.

Procedure with current control system (online)

Perform the following actions to display the license information for the control system currently connected to the Automation License Manager:

1. In the navigation area of the Automation License Manager, open: Technology folder:  "SINUMERIK online" > Control folder  and choose the control system (online)  by clicking with the left mouse button.
2. Enable the default object view: "SINUMERIK".

Procedure with control system change over (online)

Perform the following actions to display the license information for a control system not connected to the Automation License Manager:

1. Exit the Automation License Manager and all other applications using HMI basic software (e.g. HMI Advanced).
2. Switch the active communication parameters to the required control system. See Section:
3. Start the Automation License Manager
4. In the navigation area of the Automation License Manager, open: Technology folder:  "SINUMERIK online" > Control folder  and choose the control system (online)  by clicking with the left mouse button.

Result

The license information for the control system (online) is displayed in the object area of the Automation License Manager.

17.9.7 Creating a control image (offline)

Background

It is essential to create a control image (offline) in the following situations:

- The license information must later be transferred to the control system (online).
- The computer (PC/PG) on which the Automation License Manager is installed is not simultaneously connected to the Internet and the control system. This means the license information must be transferred to the control system (online) in three separate steps.
 - Intranet or PTP link to control system: Creating a control image (offline) in the Automation License Manager
 - Internet connection: Transferring license information to the control image (offline) by license requirement alignment
 - Intranet or PTP link to control system: Transferring license information from the control image (offline) to the control system (online) in the Automation License Manager
- The license information for a control system should be saved as an archive file for the purpose of archiving or customer support.

Requirements

A control image (offline) can only be created if the Automation License Manager is communicating with the control system.

Note

A PTP link (Peer-To-Peer) via Ethernet and TCP/IP requires a crossed Ethernet cable (twisted pair crossed 10baseT/100baseTX Ethernet cable).

Procedure using drag-and-drop

Perform the following steps to create a control image (offline) of the control system (online) by drag-and-drop:

1. In the navigation area of the Automation License Manager, open:
Technology folder:  "SINUMERIK online" > Control folder  and choose the control system (online)  by clicking with the left mouse button.
2. Select any line from the license information displayed in the object area by clicking with the left mouse button.
3. Drag the selected line to the desired target and release the mouse button.

The following objects can be selected as the target:

-  Computer
-  Drive
-  Storage folder
-  Control folder "offline"
-  Control image (offline)

Result

A control image (offline) has been created from the license information of the control system (online) in the selected target:

-  <computer> → drive C:\<default storage folder>
-  <drive>:\SINUMERIK\<storage folder>\<control folder "offline">
-  <storage folder>\<control folder "offline">
-  <control folder "offline">
-  Control image (offline): The control image (offline) was overwritten with the license information of the control system (online)

Procedure using menu command: "Upload from target system"

Perform the following actions to create a control image (offline) of the control system (online) using menu command: "Upload from target system":

1. In the navigation area of the Automation License Manager, open: Technology folder:  "SINUMERIK online" > Control folder  and choose the control system (online)  by clicking with the left mouse button.
2. Create the control image (offline)  using menu command: **License Key > Upload from target system**

Result

A control image (offline) has been created from the license information of the control system (online) in the default storage folder:

17.9.8 Performing a license requirement alignment for a piece of hardware

Background

If one or more options are active on a SINUMERIK control system, you must assign each license to the hardware. Next, the updated license information including the new license key is transferred to the hardware.

Via the function: "Align requirement" you can perform the alignment automatically for all required licenses based on the control system (online) or a control image (offline). The following actions are performed:

- Determining the hardware serial number for the control system
- Determining the license requirement for the control system
- Taking the required licenses from the customer-specific licenses and assigning these to the hardware
- Transferring the updated license information including License Key to the control system (online) or the control image (offline)

Requirements

The following requirements must be met for the license requirement alignment:

- The address data for the customer login (personalized login) is available:
 - User name
 - Password
- Control (online) or control image (offline)

An "online" control system file or an "offline" control system file with the relevant control image (offline) is available.

Procedure

Perform the following actions for license requirement alignment with a control system (online) or a control image (offline):

1. In the navigation area of the Automation License Manager, open:
 - For control system (online)
Technology folder:  SINUMERIK online > Control folder "online" 
 - For control image (offline)
Technology folder:  SINUMERIK offline > storage folder  > control folder "offline"  or and choose the control system (online)  or the control image (offline)  or  by clicking with the left mouse button.
2. Select the menu command: **License Key > Align requirement**

3. Login via your customer login.
4. Start the Automation License Manager and perform the following actions: "Align requirement", "Confirm requirement list" and "Transfer licenses". Follow the instructions displayed on the screen.

NOTICE**Suggested license assignment**

Carefully check the suggested license assignment. An adjustment may be required if:

- you wish to use a license number that differs from the number suggested
- you wish to use a license package rather than single licenses
- you wish to assign greater or fewer licenses than suggested for any reason

You can **no** longer undo the assignment independently.

The procedure for transferring the updated license information from a control image (offline) to a control system (online) is described in Subsection:

Result

A new License Key has been generated and loaded to the control (online) or the control image (offline).

17.9.9 Transferring license information for a control image (offline) to a control system (online)

Background

It is essential to transfer the license information for a control image (offline) to a control system (online), i.e. the hardware for a SINUMERIK control, in the following situations:

- The computer (PC/PG) on which the Automation License Manager is installed is not simultaneously connected to the Internet and the control system. License information is initially only updated based on a control image (offline). The computer on which the Automation License Manager is running is then disconnected from the Internet and connected to the relevant SINUMERIK control system to transfer the license information.
- After a service call, the license information should be transferred from an archive file to a SINUMERIK control system.

Requirements

The following conditions must be met for transmission of a control image (offline) to the control system (online):

- The Automation License Manager must be communicating with the control system.
- The hardware serial number of the control image (offline) and the control system (online) must be identical.

Procedure using drag and drop

Perform the following steps to transfer a control image (offline) to the control system (online) by drag-and-drop:

1. In the navigation area of the Automation License Manager, open:
Technology folder:  "SINUMERIK online" > Control folder  and left-click on the control (online)  to select it.
2. In the navigation area of the Automation License Manager, open:
Technology folder:  "SINUMERIK offline" > storage folder:  > control folder  .
Choose the control image (offline)  by clicking with the left mouse button.
3. Select any line from the license information displayed in the object area by clicking with the left mouse button.
4. Drag the selected line to the control system (online)  release the mouse button.

Procedure using menu commands

Perform the following actions to transfer a control image (offline) to the control system (online) using menu command: "Download to target system":

1. In the navigation area of the Automation License Manager, open:
Technology folder  SINUMERIK offline > storage folder:  > control folder:  and choose the control image (offline) by clicking with the left mouse button: .
2. Select the menu command: **License Key > Download to target system**

Result

The license information of the control system (online) is now identical to the information for the control image (offline), including the license key.

17.10 Internet links

Overview of Internet links used:

No.	Topic	Address
1	Web License Manager	http://www.siemens.com/automation/license
2	Siemens A&D Mall: Customer login	http://mall.automation.siemens.com/
3	Download server	http://software-download.automation.siemens.com

Cycle protection

18.1 Overview, cycle protection

Functionality

With cycle protection, cycles can be encrypted and then stored, protected in the control.

For cycles with cycle protection, execution in the NC is possible without any restrictions.

In order to protect the manufacturer's know-how, any type of view is inhibited for cycles with cycle protection.

For encryption, a symmetrical algorithm is used - which does not require embargo authorization - with a key length of 56 bits and a non-symmetrical algorithm with a factorization of integer numbers of 2512.

NOTICE
This type of encryption is in compliance with export restrictions and embargo regulations.

Copying encrypted cycles

The encrypted cycle can be copied and can therefore be used at other machines.

Using encrypted cycles at only one machine

If the cycle must not be used at another machine, then the cycle can be permanently linked to a particular machine.

Machine data MD18030 \$MN_HW_SERIAL_NUMBER can be used for this purpose.

When 840D sl boots, the unique hardware serial number of the CompactFlash Card is saved in this machine data.

If a cycle is to be permanently linked to a machine, then the specific serial number of the control must be queried in the call header of the cycle (MD18030 \$MN_HW_SERIAL_NUMBER).

If the cycle identifies a serial number that does not match, then an alarm can be output in the cycle - therefore preventing further processing. As the code of the cycle is encrypted, there is always a fixed link to a defined hardware.

Using encrypted cycles for several machine data

If a cycle is to be permanently linked to several, defined machines, the cycle must be entered into each hardware serial number.

The cycle must be re-encrypted with these hardware serial numbers.

Preconditions to encrypt cycles

The encrypted cycles can only be decrypted at the machine in the NC with Power On.

For service calls, it is not possible for Siemens service technicians to decrypt an encrypted cycle file locally.

For a service call, the machine manufacturer must provide the unencrypted cycle.

It is also not possible for the Siemens development department to decrypt an encrypted cycle. Also here, the equipment manufacturer must supply the unencrypted cycle for debug purposes.

18.2 Sequence

18.2.1 Overview, cycle protection sequence

The cycle to be protected is encrypted using an external PC and the SINUCOM Protector program.

The encrypted cycle has the extension `_CPF` (Coded Program File).

The `_CPF` files are either loaded to `/_N_CST_DIR`, `/_N_CMA_DIR` or `/_N_CUS_DIR`.

These files can be seen there and can be executed just like the previous part programs (`_MPF`, `_SPF`).

To execute a `_CPF` file, a Power On is required after loading the cycles.

If a Power On is not executed, and a `_CPF` file is run, then this results in a new NC alarm 15176 "Program %3 can only be executed after Power On".

18.2.2 Preprocessing

Encrypted files can be pre-processed just the same as all `_SPF` files.

To activate pre-processing, machine data MD10700 `$MN_PREPROCESSING_LEVEL` must be set.

Pre-processing is always recommended for runtime reasons.

For pre-processing, an NC program (`_MPF`) or cycle (`_SPF`) must be converted from the ASCII format into the binary format (compiled). The following NC alarm is issued if, at the time of execution, the compilation is older than the encrypted cycle file:

15176 "Program%3 can only be executed after Power On".

18.2.3 File extensions for encrypted cycles

Introduction

When considering file extensions, in this conjunction, the following, already existing extensions are relevant:

- `_`.MPF "Main Program File" for unencrypted main programs; ASCII
- `_`.SPF "Sub Program File" for unencrypted subprograms; ASCII
- `_`.CYC "Cycle" for pre-compiled file; binary files

Extensions for encrypted cycles

The following file extensions are available for encrypted cycles:

- `_`.CPF "Coded Program File" for encrypted binary files

18.2.4 Handling encrypted cycles in the control

A `_`CPF file can be deleted or unloaded just like an `_`SPF or `_`MPF file. If an archive is generated, all of the encrypted `_`CPF files are also backed-up.

Note

An encrypted cycle cannot ...

- be directly selected for execution. It can only be called from a program - or directly in MDI.
 - Executed with the "Execute from external" function
-

18.2.5 Subprogram calls without extension

A directory can include an encrypted file file _CPF and also an unencrypted file _SPF with the same name, e.g. CYCYCLE1. If the unencrypted _SPF file is pre-processed, then the following are located in directory:

- CYCLE1.SPF ; unencrypted cycle
- CYCLE1.CYC ; compilation unencrypted cycle
- CYCLE1.CPF ; encrypted cycle

For a call in the part program without extension, N5 CYCLE1(1.2) the call is made with the following priority:

- CYCLE1.CYC
- CYCLE1.SPF
- CYCLE1.CPF

If only the encrypted file (*.CPF) is in a directory, for a call without extension, nothing has to be changed. The encrypted file or its compilation is called.

In the case of service, an unencrypted file (*.SPF) is loaded. As this file has a higher priority, for the same call without extension, this file is called.

Note

An unencrypted file and its compilation have a higher priority than an encrypted file.

18.2.6 Subprogram calls with extensions

Subprogram calls with extension are:

- Direct call N5 CYCLE1_SPF
- Indirect subprogram call (CALL) N5 CALL "CYCLE1_SPF"
- Subprogram call with path data (PCALL) N5 PCALL / _N_CMA_DIR / _N_CYCLE1_SPF

The following extensions are possible

- N3_MPF; calls the unencrypted file.
- N5_SPF ; calls the unencrypted cycle
- N10_CYC ; calls the compilation of the unencrypted cycle.
- N15_CPF ; calls the encrypted or its compilation.

If a previous unencrypted cycle CYCLE1 is called with _SPF and this is now only loaded encrypted as _CPF, then all of the calls must be adapted.

18.2.7 NC language commands with absolute path data

Using the following commands, files can be accessed in the passive file system from the part program. In this case, absolute path data with extensions are used.

- WRITE: Data cannot be attached to a _CPF file, return 4 "incorrect file type".
- READ: Lines cannot be read from a _CPF file, return 4 "incorrect file type".
- DELETE: _CPF files can be deleted.
- ISFILE: A check can be made as to whether a _CPF file is available.
- FILEDATE
- FILETIME
- FILESIZE
- FILESTAT
- FILEINFO

All commands can also be called for _CPF files. The commands then supply the corresponding information.

18.2.8 Actual block display

If an encrypted cycle is executed, then DISPLOF is always active, independent of the programmed PROC attributes. DISPLOF and DISPLON in the block have no effect. If an NC alarm occurs in the cycle, when programming ACTBLOCNO, the block number is not output in the alarm line, but always just the line number.

18.2.9 Basic block display

If a _CPF cycle is executed, for an active basis block display, the absolute end of block is still displayed. In the single block, this information corresponds to the display of the axis actual values and can also be entered there.

18.2.10 Version display

If a version is entered in the header of an encrypted _CPF cycle, then this version is displayed in the contents screen of a cycle directory, just the same as for unencrypted cycles.

18.2.11 Simulation

When executing a _CPF file, the absolute end values are still displayed.

18.3 General conditions

A machine manufacturer cycle can be called from a main program using the cycle name and an extension, for example _SPF. This is possible in the CALL, PCALL command or also directly with the name. If this machine manufacturer cycle is loaded encrypted as _CPF, all sub-program calls with extension must be changed to _CPF.

18.4 Notes

Note

End user

When using encrypted cycles of a machine manufacturer, when problems occur, then only the service department of the machine manufacturer should be contacted.

Note

Machine manufacturer

When using encrypted cycles, the machine manufacturer must ensure that original, unencrypted cycles are archived with the appropriate version management.

New installation/upgrading

19.1 Classic

19.1.1 Introduction

Introduction

The CNC software on the CompactFlash Card can be newly installed or upgraded.

A new installation is required if there is no CNC software on the CompactFlash Card (see Chapter New installation (Page 385)).

An upgrade is required if an older CNC software is available on the CompactFlash Card (see Chapter Upgrading (Page 392)).

Media for new installation/upgrade

Using the following media, you have the option of initiating a new installation/upgrade:

- USB-FlashDrive
- WinSCP on PC/PG
- VNC viewer on PC/PG

Note

A new installation/upgrade always requires a bootable USB-FlashDrive for the control.

In order that this USB-FlashDrive is capable of being booted, an "NCU Service System" must be installed on it.

The procedure to generate a "boot-capable" USB FlashDrive is described in Chapter Installing "NCU Service System" on a USB-FlashDrive (Page 384).

See also

Initial commissioning procedure (Page 19)

19.1.2 Installing "NCU Service System" on a USB-FlashDrive

Introduction

A new installation/upgrade always requires a USB-FlashDrive with "NCU Service System".

19.1.2.1 Installing "NCU Service System" on the USB-FlashDrive via DOS-Shell

Flow diagram




Figure 19-1 Installing "NCU Service System" on a USB-FlashDrive via "Dos shell"

19.1.2.2 Installing "NCU Service System" on a USB-FlashDrive via RCS-Commander

Flow diagram




Figure 19-2 Installing "NCU Service System" on a USB-FlashDrive via RCS-Commander

19.1.3 New installation

Introduction

No CNC software was installed on the CompactFlash Card. The CompactFlash Card is empty.

You have the following options of initiating a new installation of the CNC software:

- Automatic installation using USB-FlashDrive
- Installation using USB-FlashDrive
- Installation using WinSCP on PG/PC
- Installation using VNC Viewer on PG/PC

19.1.3.1 Automatic installation of the CNC software using USB-FlashDrive

Flow diagram




Figure 19-3 Automatic installation using USB-FlashDrive

19.1.3.2 Installation of the CNC software using USB-FlashDrive

Flow diagram




Figure 19-4 Installing the control software using USB-FlashDrive

Flow diagram - installation of the system TCU (1) continued




Figure 19-5 Installing the control software using USB-FlashDrive - continued (TCU system)

Flow diagram - installation of the system PCU (2) continued




Figure 19-6 Installing the control software using USB-FlashDrive - continued (PCU system)

19.1.3.3 Installation of the CNC software using WinSCP on PC/PG

Flow diagram




Figure 19-7 Installation using WinSCP on PG/PC

19.1.3.4 Installation of the CNC software using VNC Viewer on PC/PG

Flow diagram




Figure 19-8 Installation using VNC Viewer on PG/PC

19.1.4 Upgrading

Introduction

Note

Upgrade

An upgrade is possible from CNC software 2.xx and higher.

It is not permissible to upgrade from other software releases. In the case, a new installation is required.

- When the software is upgraded, all user data are kept on the CompactFlash Card in the directories /user, /addon, /oem. The license key is kept as well.
- Backup data before each upgrade:
 - NC/PLC/drive archive
 - Load the PLC project into the PC/PG (STEP7)
 - License key
- Prior to overwriting a licensed CompactFlash Card, a backup of the license key is absolutely necessary.
The key is included in the "keys.txt" file and is located in the path /card/keys/sinumerik
The key can be backed-up e.g. using WinSCP from the PG/PC.
- The licenses are permanently assigned to the CompactFlash Card (card ID) and can only be used on this card.

Note

The license key can be read back via Web License Manager (Page 353) using the card number.

Upgrade options

You have the following options of upgrading the CNC software:

- Automatic upgrade using USB-FlashDrive
- Upgrade using USB-FlashDrive
- Upgrade using WinSCP on PG/PC
- Upgrade using VNC Viewer on PG/PC

Note

Before the upgrade, you can backup the complete CompactFlash Card. Using Restore, you can write back this backup to the CompactFlash Card.

Note

For an automatic upgrade with autoexec.sh from the USB-FlashDrive, the CompactFlash Card is first backed up.

The backup file "card_img.tgz" is saved under the following directory:

/machines/[machine name+serial number of the CompactflashCard]

An existing data backup is not overwritten. In this case, the operation is exited with an error.

The upgrade is made once the backup has been successfully completed.

19.1.4.1 Backup/Restore

Introduction

Before the upgrade, you can backup the complete CompactFlash Card. Using Restore, you can write back this backup to the CompactFlash Card.

Automatic backup of the complete CompactFlash Card

Flow diagram




Figure 19-9 Automatic backup of the complete CompactFlash Card

Automatic restoration of the complete CompactFlash Card

Flow diagram




Figure 19-10 Automatic restoration of the complete CompactFlash Card

19.1.4.2 Automatic upgrade of the CNC software using USB-FlashDrive

Flow diagram




Figure 19-11 Automatic upgrade of the CNC software using USB-FlashDrive

19.1.4.3 Upgrading the CNC software using USB-FlashDrive

Flow diagram




Figure 19-12 Upgrading the CNC software using USB-FlashDrive

Flow diagram - continued system TCU (1)




Figure 19-13 Upgrading the CNC software using USB-FlashDrive - continued (TCU system)

Flow diagram - continued PCU system (2)




Figure 19-14 Upgrading the CNC software using USB-FlashDrive - continued (PCU system)

19.1.4.4 Upgrading the CNC software using WinSCP on PC/PG

Flow diagram




Figure 19-15 Upgrading the CNC software using WinSCP on PG/PC

19.1.4.5 Upgrading the CNC software using VNC Viewer on PC/PG

Flow diagram




Figure 19-16 Upgrading the CNC software using VNC Viewer on PC/PG

19.2 With SinuCom Installer (SCI)

19.2.1 Software preconditions and fundamentals on the content of this chapter "New installation/upgrade with SinuCom Installer"

Software prerequisites

The prerequisite for the configuration of an Installer package for automatic new installation/upgrade is that the engineering software "SinuCom Installer" higher than or equal to Version 2.6 is installed on your PG/PC.

Basic information on the content of the chapter

Note

The descriptions for new installation/upgrading with SinuCom Installer include basic steps for configuring and subsequent automatic new installation/upgrading of an NCU.

Detailed online help is provided in the engineering software "SinuCom Installer Expert".

19.2.2 Automatic new installation with SinuCom Installer (SCI)

Introduction

You configure an Installer package for new installation of the CNC software using the "SinuCom Installer Expert" engineering software.

Precondition

You have installed the "SinuCom Installer" software Version 2.6 on the PG/PC.

The following preconditions must be met for the CompactFlash Card of the NCU:

- The CompactFlash Card of the NCU is empty or contains executable NCU software.
If any CNC software and possibly irrelevant user data are on the CompactFlash Card, then these are lost when the software is newly installed.
- You have a <name>.tgz file (cnc-sw.tgz) with the actual software.
- You want to initiate a new installation of the NCU via a USB FlashDrive.

Note

If the CompactFlash Card is empty or contains CNC software that cannot be executed, then you need a USB-FlashDrive with installed "NCU Service System (Page 384)".

Operating sequence

1. Start the engineering software "SinuCom Installer Expert".
With this software you configure an Installer package, which initiates a new installation from the USB-Flashdrive to the CompactFlash Card of the NCU.
2. Create a new project under "File" > "New" > "New Project".

3. Activate the "NCU" area under the "Package" tab.




Figure 19-17 SinuCom Installer Expert

4. Activate the "NCU system software" window under the "Dialogs" tab.




Figure 19-18 "Dialog" tab

5. In the context menu, select > right mouse button > "edit mode for all dialog boxes" > "Automatic".




Figure 19-19 Automatic edit mode

6. In the "NCU system software" window under "Installation", select the "New installation" mode.
7. For the file "<name>.tgz" you have the following options:

- The file is embedded in the Installer package.

For the automatic new installation insert the "<name>.tgz" file in the project under "TGZ files". To do this, enter the name of the TGZ file in the "Preselection" area.

- Copy the file on the USB FlashDrive into the root directory in which the Installer package is located.

You only enter the name with the prefix "./" in the "Preselection" field under "TGZ files": ./<name>.tgz

The file is automatically selected while the Installer package is running.

8. Create an Installer package "<name>.usz" via the menu "File" > "Transfer" > "Linuxpaket (NCU).

The SinuCom Installer Expert saves the project and performs a check routine.

The Installer package is placed in the root directory on the USB-FlashDrive - and depending on the configuration - also the file "<name>.tgz".

Note

The USB-FlashDrive must only be bootable if the CompactFlash Card of the NCU does not contain executable CNC system software.

9. Insert the USB FlashDrive into a USB socket (X125 or X135) of the NCU.

10. Switch the control system off and on again.

Provided that when configuring you configured the "Edit mode of all dialogs" > "Automatic", then the package is automatically executed when the control system powers-up (boots).

The dialogs are displayed, but require no operator actions.

The CNC software has been installed once the Installer package has been completed.

A logbook about the activities that have been performed can be saved. The logbook documents all activities performed during the new installation.

11. Switch-off the control.

12. Remove the USB-FlashDrive.

13. Commissioning work can continue after the control system has been switched on.

Optional additional functions for CNC software installations

In the same package - after the CNC software installation - the following actions can be optionally configured, which can either run completely automatically or conditionally at the machine:

- Loading an SDB Archive
- SINAMICS device configuration
- Renaming DOs, SINAMICS components and DO numbers
- Assignment of the drives to NC axes
- Manipulation of (standard) data in the NC and drive area
- Manipulation of display machine data
- Loading of PLC user programs
- Installation of user software
- Copying, deleting and manipulating files on the CompactFlash Card.
- Conditional execution of actions, executing, deleting, copying and manipulating
- Messages and interactions to the operator

19.2.3 Automatic upgrade with SinuCom Installer (SCI)

Introduction

Note

An upgrade is possible from CNC software 1.4, 1.5, 2.4, 2.5, 2.6 and higher (precise Version, see "siemens.txt" on the product CD of the SinuCom installer).

When the software is upgraded, all user data is kept on the CompactFlash Card and in the control areas NCK, PLC and drives.

The NCK and drive data are automatically migrated into the new CNC software version. Archives neither have to be created nor imported again.

The "NCK commissioning switch" and "PLC mode selector switch" remain during the update in position "0".

In conjunction with an upgrade, using the same Installer package, the automatic generation of a backup can be configured, which is then stored on the USB FlashDrive. It is not necessary to first generate an archive.

You configure an Installer package for upgrade of the CNC software using the "SinuCom Installer Expert" engineering software.

Note

After the CNC software has been upgraded, adaptations may be required. Using the SinuCom Installer Expert, these adaptations can also be configured and therefore automatically executed.

For information about the necessary adaptations, please refer to the upgrade instructions of the respective CNC software versions.

Operating sequence

1. You have started the engineering software "SinuCom Installer Expert".
Using this software, you configure an Installer package which initiates that the CNC software on the CompactFlash Card of the NCU is updated.
2. You have created a new project under "File" > "New" > "New Project".
3. Activate the "NCU" area under the "Package" tab.




Figure 19-20 SinuCom Installer Expert

4. Activate the "NCU system software" window under the "Dialogs" tab.




Figure 19-21 "Dialog" tab

5. In the context menu, select > right mouse button > "edit mode for all dialog boxes" > "Automatic".
6. In the "NCU system software" window under "Installation", select the "Update" mode.
7. For the <name>.tgz files you have the following options:
 - The file is embedded in the Installer package.
For the automatic new installation insert the "<name>.tgz" file in the project under "TGZ files". To do this, enter the name of the TGZ file in the "Preselection" area.
 - Copy the file on the USB FlashDrive into the root directory in which the Installer package is located.
You only enter the name with the prefix "./" in the "Preselection" field under "TGZ files": ./<name>.tgz
The file is automatically selected while the Installer package is running.

8. Create an Installer package "<name>.usz" via the menu "File" > "Transfer" > "Linuxpaket (NCU).

The SinuCom Installer Expert saves the project and performs a check routine.

The Installer package is placed in the root directory on the USB-FlashDrive - and depending on the configuration - also the file "<name>.tgz".

9. Insert the USB FlashDrive into a USB socket (X125 or X135) of the NCU.
10. Switch the control system off and on again.

Provided that when configuring you configured the "Edit mode of all dialogs" > "Automatic", then the package is automatically executed when the control system powers-up (boots).

The CNC software has been updated and all data is available again after the Installer package has been completed on the NCU.

11. Switch-off the control.
12. Remove the USB-FlashDrive.
13. The machine is ready for operation again after switch-on.

A logbook about the activities that have been performed can be saved. The logbook documents all activities performed during the update.

Optional additional functions for CNC software installations

In the same package - after the CNC software has been updated - the following actions can be optionally configured, which can either run completely automatically or conditionally at the machine:

- SINAMICS device configuration
- Renaming DOs, SINAMICS components and DO numbers
- Assignment of the drives to NC axes
- Manipulation of the NC and drive data
- Manipulation of display machine data
- Loading, deleting and replacing PLC blocks (replacing the basic program)
- Installation of application software on the NCU.
- Copying, deleting and manipulating files on the CompactFlash Card.
- Conditional execution of actions, executing, deleting, copying and manipulating
- Messages and interactions to the operator

General tips

20.1 Configuration of the properties of the network interface for PROFIBUS

Introduction

In the STEP7 project, you configure the network interfaces PROFIBUS DP, via which you want to reach the machine control panel:

PROFIBUS DP operating sequence

1. You used the left mouse button to select NCU 720.1 and while holding down the mouse button you dragged it to the "Station design" station window.
2. After you release the mouse button, configure the properties of PROFIBUS DP interface for socket X126 (machine control panel) in the dialog box (see figure below).




Figure 20-1 Properties of PROFIBUS DP

3. Click on the following one after the other:
 - the "New..." button,
 - the "Network settings" tab in the "Properties new subnet PROFIBUS Subnet" dialog box.

20.1 Configuration of the properties of the network interface for PROFIBUS

- 4. Select the transmission rate "12 Mbps" for the "DP" profile (see figure below).




Figure 20-2 Properties of the PROFIBUS interface

- 5. Click on "Options" and then on the "Equidistance" tab (see figure below).




Figure 20-3 Equidistance

20.1 Configuration of the properties of the network interface for PROFIBUS

6. To enable reproducible access to peripherals (for hand wheel mode), the PROFIBUS DP must have constant bus cycle time. The following entries are necessary under Equidistance:
 - Click on the "Activate equidistance bus cycle" field
 - Enter the cycle, e.g., "2 ms" for the "Equidistance DP cycle" (for integrated PROFIBUS) (see MD10050 \$MN_SYSOCK_CYCLE_TIME).
 - Click on the "Times Ti and To equal for all slaves" field
 - The fields "Time Ti" and "Time To" must contain a value "< 2ms".
7. Click on "OK" three times.
8. Module NCU 720.1 with SINAMICS S120 is inserted into the HW config (see figure below).

Note

With the <F4> key and confirmation of the question regarding "Reorganize", you can reorganize the display in the station window.




Figure 20-4 HW config with NCU 7x0

As the next step configure a machine control panel with hand wheel.

20.2 Separate NCK and PLC general reset

20.2.1 NCK general reset

Carry out the following actions to perform an NCK general reset:

1. Turn the NCK commissioning switch (labeled "SIM/NCK") at the front of the NCU to position "1".
2. Initiate a power on reset by switching-off the control and switching-on again - or by pressing the Reset button on the front of the NCU (labeled "RESET").
The NCU is terminated and with the request for a general NCK reset is restarted.
3. After the NCU has booted, turn the NCK commissioning switch back to the "0" position.

Effect:

- The number "6" and a flashing point are output on the status display (7-segment display) on the front of the NCU.
- "RUN" LED is lit

The NCU is in the following state after an error-free power-up (boot):

- The static memory of the NCU is deleted.
- The machine data are preassigned standard values.
- The NCK is in cyclic operation.

20.2.2 PLC general reset

A PLC general reset can be performed with or without power on reset. Depending on this - and depending on the PLC - different states are obtained for the basic PLC and user program:

PLC general reset without power on reset

Perform the following operator actions for a PLC general reset without power-on reset:

1. Turn the PLC mode selector switch (labeled "SIM/NCK") on the front of the NCU to position "2" (STOP).

Effect:

- The PLC goes into the "STOP" state
- LED "STOP" is lit

2. Turn the PLC mode selector switch to position "3" (MRES)

Effect:

- LED "STOP" goes dark and after approximately 3 seconds is lit again

3. Within approx. 3 seconds, turn the PLC mode selector to the positions "2" → "3" → "2"

Effect:

- LED "STOP" flashes with about 2 Hz and then changes to a steady light.

4. After the LED "STOP" again has a steady light condition, turn the PLC mode selector again back to position "0".

Effect:

- LED "STOP" goes dark
- "RUN" LED is lit

A general reset has now been performed for the PLC and is now in cyclic operation with the following properties:

- The user data have been deleted (data and program blocks).
PLC319-3PN/DP: see the following note
- The system data blocks (SDB) have been deleted.
- The buffered data have been written back to the RAM area.
- The time of day and the operating hours counter have not been reset.
- The **diagnostics buffer** and the MPI parameters **are** not reset.

Note

PLC319-3PN/DP

For a PLC319-3PN/DP, in the case of a PLC general reset without power on reset, the user data is first backed up on the CF Card and is then loaded into the PLC. Therefore, after a PLC general reset, user data are not deleted.

PLC general reset with power on reset

Perform the following operator actions for a PLC general reset with power on reset:

1. Turn the PLC mode selector on the front of the NCU to position "3" (MRES).
2. Initiate a power on reset by switching-off the control and switching-on again - or by pressing the Reset button on the front of the NCU (labeled "RESET").
The NCU is shut down and with the request for a general PLC reset is restarted.

Effect:

- LED "STOP" flashes
- LED "SF" is lit

20.2 Separate NCK and PLC general reset

3. Turn the PLC mode selector switch to position "2" and back again to position "3".

Effect:

- The "STOP" LED flashes approx. 20 seconds with approx. 2 Hz, then:
- LED "STOP" is lit
- "RUN" LED is lit

4. After the LED "STOP" again has a steady light condition, turn the PLC mode selector back to position "0".

Effect:

- LED "STOP" goes dark

A general reset has now been performed for the PLC and is now in cyclic operation with the following properties:

- The user data have been deleted (data and program blocks).
- The system data blocks (SDB) have been deleted.
- The buffered data have been written back to the RAM area.
- The time of day and the operating hours counter have not been reset.
- The **diagnostics buffer** and the MPI parameters **are** reset.

20.3 Configuring the communication between the PLC and the drive

Telegram lengths and I/O addresses

Note

In the HW Config, a telegram length and the associated I/O addresses is preassigned per default.

The pre-assignment for SINAMICS Integrated corresponds to telegram 116 for the axes and 391 for the NCU and 370 for the ALM with the max. possible telegram length.

This default can be used to supply all known telegrams; no modification is necessary.

Operating sequence

1. To view this configuration, click in the HW Config on the module "SINAMICS Integrated" and select "Object properties", using the <right mouse button>.
2. Select the "Configuration" tab and the select the "Overview" tab.

As shown in the figure below, you can view the lengths of the preassigned telegrams.

The figure shows user-defined telegrams for 6 axes.




Figure 20-5 Message length

20.3 Configuring the communication between the PLC and the drive

3. Click "OK" to close the dialog.
4. You can view the address areas in the station window in the detail view by clicking on "SINAMICS Integrated". Here, for example, address 4100 corresponds to the address entered in MD13050 \$MN_DRIVE-LOGIC_ADRESS[0]. The addresses have a gap of 40 bytes. The following figure shows how the default values MD13050 \$MN_DRIVE-LOGIC_ADRESS[0...5] correspond to the input/output addresses for standard configuration of the PLC.




Figure 20-6 SINAMICS Integrated addresses

20.4 Integrating PG/PC into the network (NetPro)

Introduction

To carry out routing functions, it is necessary to integrate a PG/PC in the SIMATIC Manager under NetPro and to configure the interfaces.

Requirements

The following preconditions for integrating a PG/PC in the hardware configuration network must be satisfied:

- inserted NCU 720.1 into the HW config,
- configured the properties of the network interfaces,
- configured the PLC to drive communication,
- inserted the machine control panel (MCP),
- saved and compiled the configuration,
- created a PLC program.

See also

Insert NCU 7x0 in HW config (Page 52)

Configuring the properties of the network interfaces (Page 54)

Adding a machine control panel and handwheel in HW Config (Page 439)

End hardware configuration and load to the PLC (Page 61)

Creating a PLC program (Page 62)

20.4.1 Integrating PG/PC into NetPro

Introduction

To enable the communication between PG/PC <-> HMI via Ethernet, the PG/PC should be included in the network configuration of the system.

To integrate the PG/PC, proceed from the following starting situation in the SIMATIC Manager.

You are in the HW config in the created project "PLC-Erst-IBN 840D sl" (see figure below).




Figure 20-7 HW config project "PLC-Erst-IBN 840D sl"

Operating sequence for integrating PG/PC into NetPro

1. Click on the "NetPro" button (see previous figure).
2. From the catalog under "Stations", insert the PG/PC via Drag&Drop into the network configuration (see figure below).




Figure 20-8 Insert PG/PC

The newly inserted symbol PG/PC does not yet contain any interfaces. Next, configure the interfaces.

20.4.2 PG/PC interface configuration

Introduction

Under NetPro, configure the interfaces required for commissioning at the PG/PC. These may include the following interfaces:

- Ethernet for the communication for NCU socket X127
- PROFIBUS

Operating sequence for configuring interfaces

1. Highlight the symbol "PG/PC" under NetPro.
2. Select "Object properties" <right mouse button >.
3. In the "Properties - PG/PC" dialog box displayed, select the "Interfaces" tab in the dialog (see figure below).

Under this tab, define/configure all the required interfaces.




Figure 20-9 Properties - PG/PC

Operating sequence for configuring interfaces at PG/PC

1. Click on "New..." to configure the Ethernet interface first.
2. In the type selection field, select "Industrial Ethernet" (see figure below).




Figure 20-10 Type Industrial Ethernet

3. Click "OK".
4. In the subsequent dialog box, select the subnet "Ethernet(1)" and enter the IP address and the subnet screen mask of your PG/PC (see figure below). E.g.:
 - IP address, such as, 192.168.0.3
 - Subnet screen form = 255.255.255.0




Figure 20-11 Properties of the Ethernet Interface

5. Click "OK".

- 6. You can configure additional interfaces via "New".
- 7. When you have configured the interfaces, all the configured interfaces are visible under the "Interface" tab (see figure below).




Figure 20-12 Configured interfaces

The configured interfaces must be assigned in a device-specific manner to the available hardware interfaces on the PG/PC.

The sequence steps are laid out in the following section.

20.4.3 Assigning interfaces

Introduction

The interfaces configured in the previous chapter must now be assigned in a device-specific manner to the available hardware interfaces on the PG/PC.

Operating sequence for assigning an Ethernet interface

1. Select the "Assign" tab.
2. Select "Ethernet interface(1)" in the selection field "Configured interfaces".
3. Select the installed network card "TCP/IP -> Realtek RTL8139/810xF..." in the selection field "Interface parameterizations in PG/PC" (see figure below).




Figure 20-13 Selecting

- Click on "Assign" and confirm the subsequent message on processing object properties with "OK".

The assigned interfaces are deleted from the field "Configured interfaces" and these assigned interfaces are displayed in the field "Assigned" (see figure below).




Figure 20-14 Assigning Ethernet interface

- Now assign the remaining configured interfaces (PROFIBUS).
From those interfaces assigned, one must be marked as "active".
- Select "Ethernet interface" in the field "Assigned" and mark the field next to it as "active".

- Click on "OK" to end the dialog "Properties - PG/PC".

In NetPro, the PG/PC interface declared as "active" is highlighted in YELLOW (see figure below).




Figure 20-15 Configured PG/PC in the network configuration

- Select "Save and compile > Save and check all" and confirm the process with "OK".

The next operating sequence described explains how to load this hardware configuration to the NCU.

20.4.4 Loading the HW config to NCU

Introduction

The newly created network configuration PG/PC must be introduced to NCU.

You have established a connection to the Ethernet interface (X120 or X127) and you load this configuration from the PG/PC to the NCU.

Operating sequence for loading HW config to NCU

1. Change from "NetPRO" to "HW Config".
2. Press the "Download to module" button.
The target module interactive screenform automatically displays both configured communication peers.
3. Confirm the load into the module with "OK".
4. Confirm the dialog boxes displayed subsequently with "OK" or "No" for the query "...Should the module be started now (restart)?".

Note

Loading the HW config to NCU is only possible via Ethernet interface.

20.5 Overview - Assignment of SINAMICS and NCK machine data for communication via PROFIBUS

Assignment of SINAMICS and NCK machine data for communication

The table below uses a sample to SINAMICS S120 component configuration to illustrate the assignment of the communication parameters. The SINAMICS S120 drive group comprises the following:

- an NCU (CU),
- an ALM,
- Three Motor Modules (MM)

Note

In the Control Unit Parameter 978, deactivate the process data exchange with the value "0". Cyclic and acyclic data are separated. Components that do not communicate on PROFIBUS are to be preassigned "255".

SINAMICS S120			STEP7 (HW Config) DP slave properties		NCK machine data General machine data			NCK machine data Axis MD		
HW Module	Control Unit Parameter p978[0-9] List of drive objects	Control Unit Parameter p922 Message frame type	Drive parameter p922 Message frame type	Message frame type length 1)	I/O address 1)	MD13120[0] Control Unit I/O address	MD13050[0-5] Axis I/O address 1)	MD13060[0-5] Message frame type)	MD30110/30220 Setpoint/Actual value assignment	MD30130 Type of output setpoint
MM1	3		116	116, PZD-11/19	4100		4100	116	1	1
MM2	4		116	116, PZD-11/19	4140		4140	116	2	1
MM3	5		116	116, PZD-11/19	4180		4180	116	3	1
x	255		x	116, PZD-11/19	4220		4220	116	4	0
x	255		x	116, PZD-11/19	4260		4260	116	5	0
x	255		x	116, PZD-11/19	4300		4300	116	6	0
CU	1	391		391, PZD-3/7	6500	6500				
ALM	255			370, PZD-1/1	6514					
x	0									
x	2									

Process data (PZD) exchange configured
X Does not exist
255 Not active

1) Standard value, do not change

Figure 20-16 Assignment

20.6 Drive-object assignment for PROFIBUS connection

Introduction

PROFIBUS message frames (internal PROFIBUS, HW Config) are used to specify the process data to be exchanged between the NCK and the drives. The sequence of the drive objects (configurable/configured using HW Config) involved in PROFIBUS process-data exchange is defined via a drive-object list.

List of drive objects

You usually configure eight drive objects (DOs). The drive objects have drive-object (DO) numbers and are input in p978[0...9] as a list of drive objects.

You configure the following from parameter p978 in the index:

- **0...5** -> Motor Module (e.g., DO no. 3...8)
- **6** -> Control Unit (e.g., DO no. 1)
- **7** -> Active Line Module (e.g., DO no. 2),

PROFIBUS message frame 370 is not currently available for the Active Line Module (infeed). However, according to the SINAMICS rule, all DOs from parameter p0101 have to be assigned in parameter p0978. The resulting infeed DO number then has to be entered in index **9** (see table below).

Note

The list of DOs involved in process-data exchange is completed by entering a value of "0". Components that are available, but do not communicate on PROFIBUS, must be preset to "255".

The list of drive objects is already pre-assigned in the following order by the system upon initializing the drive (acceptance of topology):

- ALM, first Motor Module ...n., CU; e.g., 2-3-4-5-1.
- The assignment allocated by the drive when the DRIVE-CLiQ topology is accepted must be reviewed and adapted.

Drive-object numbers

The drive-object numbers (DO numbers) can be viewed under "Commissioning > Machine data > Control Unit MD/Infeed MD/Drive MD" in the component name line. For example, the name for a Control Unit could be: "DP3.Slave3:CU_003 (1)". The DO number appears inside the brackets "...".

Drive-object assignment

The table below uses the example of a SINAMICS S120 component configuration to illustrate the drive-object assignment to be made for the drive parameters.

For example, the drive group could be configured as follows:

- One Control Unit (CU)
- One Active Line Module (ALM)
- Three Motor Modules

Table 20- 1 Assignment of p978[0...9] for infeed with DRIVE-CLiQ connection

Component	Index p978	List of drive objects
1st motor module	0	3
2nd motor module	1	4
3rd motor module	2	5
not found	3	255 ¹⁾
not found	4	255 ¹⁾
not found	5	255 ¹⁾
CU	6	1
ALM, only if protocol 370 is available	7	255 ¹⁾
not found	8	0 ²⁾
ALM (Standard for SINUMERIK)	9	2

1) Not active

2) End of exchange of PZD

Note

The following table describes the assignment of the drive objects in the p978[0...9] for an infeed without DRIVE-CLiQ connection. This assignment is also done for a drive group with NX module.

Table 20- 2 Assignment p978[0...9] for infeed without DRIVE-CLiQ connection

Component	Index p978	List of drive objects
1st motor module	0	2
2nd motor module	1	3
3rd motor module	2	4
not found	3	255 ¹⁾
not found	4	255 ¹⁾
not found	5	255 ¹⁾
CU	6	1
ALM, only if protocol 370 is available	7	255 ¹⁾
not found	8	0 ²⁾
not found	9	0

1) Not active

2) End of exchange of PZD

Procedure for assigning the drive objects in parameter p978

You are now in the "Commissioning > Machine data > Control Unit MD" menu.

p978 can be written using the following sequence:

1. Set p9 = 1
2. Set p978 [0...9] to the values outlined in the table below (column ...List of drive objects...), e.g., 3-4-5-255-255-255-1-255-0-2.
 - Motor Module drive objects, ascending order (connected as per DRIVE-CLiQ)
 - Control unit
 - ALM
3. Set p9 = 0
4. Save "All": set p977 = 1

It is imperative you wait until p977 is automatically written back to "0".

See also

Overview - Assignment of SINAMICS and NCK machine data for communication via PROFIBUS (Page 431)

20.7 PROFIBUS machine control panel on the HMI

Configuration of the PROFIBUS machine control panel

The following is required in the HW Config for a PROFIBUS machine control panel on the HMI:

- Configuration of the properties of the network interface for PROFIBUS
- Supplementation of the machine control panel and hand wheel in HW Config
- Modification of the machine control panel in OP100

20.7.1 Configuration of the properties of the network interface for PROFIBUS

Introduction

In the STEP7 project, you configure the network interfaces PROFIBUS DP, via which you want to reach the machine control panel:

PROFIBUS DP operating sequence

1. You used the left mouse button to select NCU 720.1 and while holding down the mouse button you dragged it to the "Station design" station window.
2. After you release the mouse button, configure the properties of PROFIBUS DP interface for socket X126 (machine control panel) in the dialog box (see figure below).




Figure 20-17 Properties of PROFIBUS DP

3. Click on the following one after the other:
 - the "New..." button,
 - the "Network settings" tab in the "Properties new subnet PROFIBUS Subnet" dialog box.

4. Select the transmission rate "12 Mbps" for the "DP" profile (see figure below).




Figure 20-18 Properties of the PROFIBUS interface

5. Click on "Options" and then on the "Equidistance" tab (see figure below).




Figure 20-19 Equidistance

20.7 PROFIBUS machine control panel on the HMI

6. To enable reproducible access to peripherals (for hand wheel mode), the PROFIBUS DP must have constant bus cycle time. The following entries are necessary under Equidistance:
 - Click on the "Activate equidistance bus cycle" field
 - Enter the cycle, e.g., "2 ms" for the "Equidistance DP cycle" (for integrated PROFIBUS) (see MD10050 \$MN_SYSOCK_CYCLE_TIME).
 - Click on the "Times Ti and To equal for all slaves" field
 - The fields "Time Ti" and "Time To" must contain a value "< 2ms".
7. Click on "OK" three times.
8. Module NCU 720.1 with SINAMICS S120 is inserted into the HW config (see figure below).

Note

With the <F4> key and confirmation of the question regarding "Reorganize", you can reorganize the display in the station window.




Figure 20-20 HW config with NCU 7x0

As the next step configure a machine control panel with hand wheel.

20.7.2 Load GSD file (contains machine control panel)

Introduction

To expand the machine control panel, you need the device data (GSD file) with the SINUMERIK MCP. This file contains information that a DP master system requires to link the MCP as DP slave in its PROFIBUS configuration.

This file is a component of the STEP7 package for NCU7x0 (tool box).

Operating sequences

1. Search in the HW config under "Extras" > "Install GSD file..." in the installation directory of the tool box under, for example: C:\temp\tb_sl_1.1.0.0\8x0d\GSD\MCP_310_483 to find the corresponding GSD directory.
2. Choose the corresponding language you want to install.
3. Click "Install".
4. Click "Close".

20.7.3 Adding a machine control panel and handwheel in HW Config

Introduction

The machine control panel (MCP) can be connected via PROFIBUS to the PLC. In later configurations, this will also be possible over the network.

Operating sequence for adding an MCP in HW Config

You have created a NCU and a NX in the HW Config and installed the GSD file for the MCP.

1. Search under "PROFIBUS DP" > "Further field devices" > "NC/RC" > "MOTION CONTROL" for the "SINUMERIK MCP" module.
2. Click with the left mouse button to select the "SINUMERIK MCP" module and drag it to the chain for the "PROFIBUS DP master system" in the "Station design" station window.
3. After releasing the mouse button, the machine control panel is added (see figure below).
4. Select "MCP" and enter the PROFIBUS address 6 under "Object properties" > button "PROFIBUS..." > tab "Parameter" > input field "Address".

5. Click on "OK" twice.

Now you can assign the slots of the machine control panel, e.g., "Standard + Hand wheel".




Figure 20-21 Machine control panel in HW Config

6. In the hardware catalog under "SINUMERIK MCP" click with the left mouse button to select the "Standard+Hand wheel" option and drag it to Slot 1 (see figure below).




Figure 20-22 Standard+Handwheel for slot

You have configured a machine control panel with handwheel in HW Config.

Note

If a handwheel has been configured, equidistance is required. You set this when you configured the PROFIBUS DP. PROFIBUS address for the machine control panel is "6".

Save, compile and load the configuration to the PLC as the next operating sequence.

20.7.4 Modifying PROFIBUS machine control panel in OB100

Introduction

The PLC basic program automatically transfers the machine control panel signals (MCP signals) and the addresses of the MCP in the HW config if the configuration is set up as laid out below.

Operating sequence

- Under "Blocks", double-click on "OB100" to open it.

In OB100, the parameters below have to be preset:

```
MCPNum :=1
MCP1IN := P#E 0.0
MCP1OUT := P#E 0.0
MCP1StatSend := P#E 8.0
MCP1StatREc := P#E 12.0
MCPBusAdresse := 6
MCPBusType = B#16#33
```

Fundamentals

21.1 Basic information on SINAMICS S120

Reference

See also

Small SINAMICS Glossary

21.1.1 Rules for wiring the DRIVE-CLiQ interface

Introduction

When wiring components with DRIVE CLiQ, the following rules apply: The rules are subdivided into **obligatory rules**, which must be observed, and **optional rules**, which enable automatic topology detection if they are adhered to.

Obligatory rules:

- A maximum of 198 DRIVE-CLiQ node components can be connected for each NCU.
- Up to 16 nodes can be connected to a DRIVE-CLiQ socket.
- A maximum of 7 nodes can be connected in one row. A row is always considered from the perspective of the closed-loop control module.
- Ring wiring is not permitted.
- Components must not be double-wired.

Optional rules:

If you follow the optional rules for wiring DRIVE-CLiQ, the components associated with the encoder are automatically assigned to the drives (see figure below) if commissioning is performed via macro 150xxx.




Figure 21-1 Optional rules

- For one motor module, the related motor encoder must also be connected.
- Due to the improved performance utilization, use as many of the DRIVE-CLiQ points on the NCU as possible.
- It is essential you comply with the optional rules when using the macro. This is the only way to achieve a proper assignment of the drive components.

21.1.2 Drive Objects (DO's) and Drive components

Introduction

The components that belong to the drive group are reflected in the parameterization in a drive object.

Each drive object has its own parameter list.

General procedure

The figure below uses the example of a SINAMICS S120 drive group to illustrate the meaning of the drive components and drive objects.

Example

Drive object 3 is made up of the components Single Motor Module (No. 3), Motor (No. 10), Encoder (No. 9) and SMC (No. 8).

The component number is assigned by the drive after DRIVE-CLiQ topology recognition.

The component number in each case can be viewed in the parameter list for the relevant drive object. E.g.: under operating area "Commissioning > Machine data > Drive MD > Axis +".

Table 21- 1 Component numbers in the DO 3

Parameter	Name of the parameter
p121	Component number of power module
p131	Component number of motor
p141	Component number of encoder interface
P142	Component number of encoder




Figure 21-2 Drive group

21.1.3 BICO interconnection

Introduction

Each drive unit contains a large number of interconnectable input and output variables as well as internal control variables.

BICO technology (binector connector technology) allows the drive to be adapted to a wide variety of conditions.

Digital and analog signals, which can be connected freely by means of BICO parameters, are identified by the prefix BI, BO, CI, or CO in their parameter name.

These parameters are identified accordingly in the parameter list or in the function diagrams.

There are:

- Binectors (digital), with
BI: binector input, BO: binector output
- Connectors (analog), with
CI: connector input, CO: connector output

Interconnecting signals using BICO technology

To interconnect two signals, a BICO input parameter (signal sink) must be assigned to the required BICO output parameter (signal source).

Literature

Commissioning Manual or List Manual for SINAMICS S120 Documentation

Visualization of BICO connections on the HMI

Accessing the following menu allows you to perform a BICO connection of the SINAMICS drive group associated components.

- "Commissioning" > "Drive system" > "Drives/Drive units" > "Connections" menu




Figure 21-3 "Connections" menu

21.2 Transfer telegrams

Introduction

The transfer telegrams from NCK to the drive are transferred via an internal PROFIBUS on the NCU. They are:

- Send telegrams (drive->NCK)
- Receive telegrams (drive->NCK)

Telegrams

The telegrams are standard telegrams with pre-defined assignment of the process data. These telegrams are interconnected in the drive object using BICO technology.

The drive objects that can exchange process data include the following:

1. Active line module (A_INF)
2. Basic line module (B_INF)
3. Motor module (SERVO)
4. Control unit (CU)

The order of the drive objects in the telegram is displayed on the drive page via the parameter list in the "Commissioning" > "Machine data" > "Control Unit MD" operating area in p978[0...15] and may also be changed through it.

Literature

SINAMICS S120 Commissioning Manual

Receive words/send words

By selecting a telegram via p922 of the related drive object (operating area "Commissioning" > "Machine data" > "Drive MD"), the process data is determined which is transferred between the master and slave.

From the perspective of the slave, the received process data comprises the receive words and the process data to be sent the send words.

The receive and send words are comprised of the following elements:

- Receive words: Control words or setpoints
- Send words: Status words or actual values

Message frame types

The message frame length for communication with the drive must be defined in the hardware configuration. The message frame length to be chosen depends on the axis functions required, e.g., the number of encoders or DSC, or the functions in the drive used.

Note

If you change the message frame length of a drive component in HW config, you also must adjust the selection of the message frame type in the configuration of the interface in the NCK.

What types of message frames are available?

- Standard telegrams

The standard telegrams are structured in accordance with the PROFIdrive Profile V3.1. The internal process data links are set up automatically in accordance with the message frame number setting.

- Manufacturer-specific telegrams

The manufacturer-specific telegrams are structured in accordance with internal company specifications. The internal process data links are set up automatically in accordance with the message frame number setting.

The following vendor-specific telegrams can be set via p0922:

- For axes (SERVO)

- 116 DSC with torque reduction, 2 position encoders, supplementary data (also parameterization)

- For axes (SERVO)

- 118 DSC with torque reduction, 2 independent position encoders per axis, supplementary data (also parameterization)

- For Control Unit

- 390 telegram without probe (for NX)

- 391 message frame for up to 2 probes (for NCU)

21.2.1 Structure of the telegram with the process data for SINUMERIK 840D sl

Introduction

SINUMERIK 840D sl uses the following preferred message frame types:

- For axes
116 DSC with torque reduction, 2 position encoders, supplementary data (also parameterization)
- For NX
390 message frame without probe (NX)
- For NCU
391 message frame for up to 2 probes (only valid for NCU)

Note

The telegram types 116, 390 and 391 are preset by default via HW Config. It is recommended not to change these.

Telegrams for receiving

The following table contains the structure of the telegrams with the process data for receiving the control words and setpoints (NCK->drive).

Table 21- 2 Telegrams with the process data for receiving (NCK->drive)

PZD Receive word	Telegram 116	Telegram 118	Telegram 390	Telegram 391
PZD 1	STW1	STW1	STW1	STW1
PZD 2	NSOLL_B	NSOLL_B	Digital outputs	Digital outputs
PZD 3				STW_PROBES
PZD 4	STW2	STW2		
PZD 5	M_RED	M_RED		
PZD 6	G1_STW	G2_STW		
PZD 7	G2_STW	G3_STW		
PZD 8	XERR	XERR		
PZD 9				
PZD 10	KPC	KPC		
PZD 11				

Telegrams for sending

The following table contains the structure of the telegrams with the process data for sending the status words and actual values (drive->NCK).

Table 21- 3 Telegrams with the process data for sending (drive->NCK)

PZD Send word	Telegram 116	Telegram 118	Telegram 390	Telegram 391
PZD 1	ZSW1	ZSW1	ZSW1	ZSW1
PZD 2	NIST_B	NIST_B	Digital inputs	Digital inputs
PZD 3				ZSW_PROBES
PZD 4	ZSW2	ZSW2		TIMESTAMP_PROBE_1N
PZD 5	MELDW	MELDW		TIMESTAMP_PROBE_1P
PZD 6	G1_ZSW	G2_ZSW		TIMESTAMP_PROBE_2N
PZD 7	G1_XIST1	G2_XIST1		TIMESTAMP_PROBE_2P
PZD 8				
PZD 9	G1_XIST2	G2_XIST2		
PZD 10				
PZD 11	G2_ZSW	G3_ZSW		
PZD 12	G2_XIST1	G3_XIST1		
PZD 13				
PZD 14	G2_XIST2	G3_XIST2		
PZD 15				
PZD 16	LOAD	LOAD		
PZD 17	TORQUE	TORQUE		
PZD 18	POWER	POWER		
PZD 19	CURR	CURR		

21.2.2 Process data for receiving and sending

Process data for receiving

The process data for the control words and setpoints are interconnected in the receive buffer.

Overview of control words and setpoints

The table below provides an overview of the process data that are interconnected as target at the receive buffer.

References

SINAMICS S120 Commissioning Manual

Abbreviation	Name
STW1	Control word 1
STW2	Control word 2
NSOLL_A	Speed setpoint A (16-bit)
NSOLL_B	Speed setpoint B (32-bit)
G1_STW	Encoder 1 control word
G2_STW	Encoder 2 control word
G3_STW	Encoder 3 control word
XERR	Positional deviation
KPC	Position controller gain factor
M_RED	Torque reduction
A_STW1	Control word for A_INF/B_INF (infeed)
STW_PROBES	Control word probes

Note

The drive signals are interconnected to the PZD automatically when a telegram type is allocated (parameter p922).

Process data for sending

The process data for the control words and setpoints are interconnected in the send buffer.

Overview of status words and actual values

The table below provides an overview of the process data that are interconnected as source at the transmit buffer.

References

SINAMICS S120 Commissioning Manual

Abbreviation	Name
ZSW1	Status word 1
ZSW2	Status word 2
NIST_A	Speed setpoint A (16 bit)
NIST_B	Speed setpoint B (32 bit)
G1_ZSW	Encoder 1 status word
G1_XIST1	Encoder 1 actual position value 1

Abbreviation	Name
G1_XIST2	Encoder 1 actual position value 2
G2_ZSW	Encoder 2 status word
G2_XIST1	Encoder 2 actual position value 1
G2_XIST2	Encoder 2 actual position value 2
G3_ZSW	Encoder 3 status word
G3_XIST1	Encoder 3 actual position value 1
G3_XIST2	Encoder 3 actual position value 2
MELDW	Message word
A_ZSW1	Status word for A_INFEED (infeed)
LOAD	Drive load
TORQUE	Drive torque setpoint
POWER	Drive efficiency
CURR	Drive actual current
ZWS_PROBES	Status word probe
TIMESTAMP_PROBE_1N	Time stamp probe 1 falling edge
TIMESTAMP_PROBE_1P	Time stamp probe 1 rising edge
TIMESTAMP_PROBE_2N	Time stamp probe 2 falling edge
TIMESTAMP_PROBE_2P	Time stamp probe 2 rising edge

21.3 Control- and status-word bits for NCK<->drive communication

21.3.1 NCK to drive

Introduction

The NCK transfers data to the drive using message frames via a PROFIBUS interface (internal PROFIBUS). Setpoints exist for speed control and torque and are preceded by a control word in the message frame.

PLC interface for STW1

Signal provided by NCK	VDI interface (PLC)	Remarks	Bit in STW1	Meaning
Axis controllable from NCK: <ul style="list-style-type: none"> Servo enable Measuring system selected and OK Pulse enable ... 	DB(AX).DBX2.1 DB(AX).DBX1.5/6 DB(AX).DBX21.7		0	OFF1
always "1", "TRUE"	No signal		1	OFF2
always "1", "TRUE"	No signal		2	OFF3
VDI signal pulse enable	DB(AX).DBX21.7		3	Enable inverter
HLGSS	DB(AX).DBX20.1		4	Ramp-function generator enable
HLGSS	DB(AX).DBX20.1		5	Ramp-function generator Start
		NCK controlled in parallel to STW1 bit0	6	Setpoint enable
(DriveReset) is generated by: <ul style="list-style-type: none"> "RESET signal" or CANCEL key, if a drive fault is simultaneously present (ZSW1.bit3 or ZSW1.bit6) 	No signal	Signal "OFF1" is automatically set to FALSE internally, simultaneously to "DriveReset" (user must NOT manipulate the servo enable separately!).	7	Reset fault memory
Selection of NC function generator (via PI service from HMI)	No signal	The user cannot influence the function generator selection via the VDI interface.	8	Activate function generator
always "0", "FALSE"	No signal	Signal not used	9	Reserved
is "1", "TRUE", if the NC can control the associated drive AND the drive requests the control (ZSW1.bit9)	No signal		10	Control requested
"always "0", "FALSE"	No signal	Signal not used	11	Reserved
"Release holding brake"	DB(AX).DBX20.5		12	Open holding brake
always "1", "TRUE"	No signal	Signal is used as the identifier to shut down the drive's ramp-function generator (isochronous Profibus drive)	13	Ramp-up time zero for controller enable
always "1", "FALSE"	No signal	Signal not used	14	Open-loop torque-controlled mode
Customer-specific signal	no Signal for SINAMICS,		15	In conjunction with SINUMERIK the signal is not used, not a PROFIDRIVE standard signal

PLC interface for STW2

Signal provided by NCK	VDI interface (PLC)	Remarks	Bit in STW2	Meaning
Drive-parameter-set switchover	DB(AX).DBX21.0	Bit A	0	Parameter-set switchover, bit0
	DB(AX).DBX21.1	Bit B	1	Parameter-set switchover, bit1
	DB(AX).DBX21.2	Bit C	2	Parameter-set switchover, bit2
1st speed setpoint filter	DB(AX).DBX20.3	Not used for SINUMERIK or SINAMICS (ineffective)	3	1st speed setpoint filter
Ramp-function generator disable	DB(AX).DBX20.4	Not used for SINUMERIK or SINAMICS (ineffective)	4	Ramp-function gen. inactive
Always "FALSE"		not used	5	Reserved
Integrator inhibit, speed controller	DB(AX).DBX21.6		6	Integrator inhibit, speed controller
Selection of "parking axis" by shutting down the encoder bit on the VDI interface	DB(AX).DBX1.5 = FALSE & DB(AX).DBX1.6 = FALSE		7	Selection of "parking axis"
Traversing to fixed endstop	No signal	Drive fault "speed controller at limit" deactivated	8	Suppress fault 608, "speed controller at limit"
Motor changeover/selection	DB(AX).DBX21.3	Bit A	9	Motor changeover, bit0
	DB(AX).DBX21.4	Bit B	10	Motor changeover, bit1
Motor being selected	DB(AX).DBX21.5		11	Motor being selected
Master sign-of-life	No signal		12	Master sign-of-life
			13	
			14	
			15	

21.3.2 Drive to NCK

Introduction

The drive transfers the data to the NCK using message frames via a PROFIBUS interface (internal PROFIBUS). Actual values exist for the speed control and torque and are preceded by a status word in the message frame.

PLC interface for ZSW1

Meaning	Bit in ZSW1	Remarks	VDI interface (PLC)	Signal processing in the NCK
Ready to start	0		No signal	
Ready-to-operate/no fault	1		No signal	
Status, controller enable	2	For a combination bit2 from ZSW1 = 0 and simultaneously bit11 from MeldW = 1, the drive is in an independent state.	DB(AX).DBX92.4	
Fault active	3		No signal	Alarm 25201/25202, is used to activate error deletion on the NCK.
No OFF2 pending.	4		No signal	Not used
No OFF3 is active	5		No signal	Not used
Power-on inhibit	6		No signal	Used on the NCK to generate the "Acknowledge fault memory" signal.
Warning present	7		No signal	No evaluation
nset = nact	8		No signal	No evaluation
Control requested	9	Signal is primarily set by the drive.	No signal	The NCK itself then sets the associated STW1.bit9, if the drive in the NC is known to be "operational" and "ready" (e.g., bus booted, etc.).
Comparison value reached	10		No signal	No evaluation
Reserved	11		No signal	No evaluation
Reserved	12		No signal	No evaluation
Function generator active	13		DB(AX).DBX61.0	Drive test "travel request"
Only used in "positioning mode": Open-loop torque-controlled mode	14	Irrelevant for SINUMERIK	No signal	No evaluation
Only used in "positioning mode": Spindle positioning ON	15	Irrelevant for SINUMERIK	No signal	No evaluation

PLC interface for ZSW2

Meaning	Bit in ZSW2	Remarks	VDI interface (PLC)	Signal processing in the NCK
Parameter set	0	Bit A	DB(AX).DBX93.0	active drive parameter set
	1	Bit B	DB(AX).DBX93.1	
	2	Bit C	DB(AX).DBX93.2	
1st speed-setpoint filter inactive	3	Signal from SINAMICS not used	DB(AX).DBX92.3	as the signal from SINAMICS is not used: signal always "0", ""FALSE"
Ramp-function gen. inactive	4		DB(AX).DBX92.1	Ramp-function-generator disable active
Holding brake open	5		DB(AX).DBX92.5	Holding brake open
Integrator inhibit, speed controller	6		DB(AX).DBX93.6	Speed controller integrator disabled
Status: Parking axis	7	Axis parked via SINAMICS	No signal	NCK cannot respond to the "axis parked" state => alarm 25000, An alarm is output if the drive parks even though parking was not requested.
Suppress "speed controller at limit" fault	8		No signal	
Motor data set	9	Bit A	DB(AX).DBX93.3	Active motor
	10	Bit B	DB(AX).DBX93.4	
Motor being changed over	11		No signal	
Slave sign-of-life	12		No signal	Drive sign-of-life
	13			
	14			
	15			

PLC interface for MeldW

Meaning	Bit in MeldW	Remarks	VDI interface (PLC)	Signal processing in the NCK
Ramp-up function completed	0		DB(AX).DBX94.2	Ramp-up function completed
M<Mx	1		DB(AX).DBX94.3	M<Mx
Nact<Nmin	2		DB(AX).DBX94.4	Nact<Nmin
Nact<Nx	3		DB(AX).DBX94.5	Nact<Nx
DC link overvoltage	4		DB(AX).DBX95.0	Signal not available for SINAMICS 120!
Variable signaling function	5		DB(AX).DBX94.7	Signal not available for SINAMICS 120!
Motor temperature pre-warning	6		DB(AX).DBX94.0	Motor temperature pre-warning
Heatsink-temperature prewarning	7		DB(AX).DBX94.1	Heatsink-temperature prewarning
Nsetp=Nact	8		DB(AX).DBX94.6	
Reserved	9		kein Signal	No evaluation
Power module current not limited	10		DB(AX).DBX95.7	Signal not available for SINAMICS 120!
Reserved	11	Speed controller active	DB(AX).DBX61.6& DB(AX).DBX61.7	
Reserved	12	Drive Ready	DB(AX).DBX93.5	
Pulses enabled	13	Only for SINAMICS S120 with message-frame types 101ff direct on VDI interface	DB(AX).DBX93.7	
Reserved	14	Only in conjunction with positioning mode, irrelevant for SINUMERIK	No signal	No evaluation
Reserved	15	Only in conjunction with positioning mode, irrelevant for SINUMERIK	No signal	No evaluation

21.4 PLC program

Introduction

The PLC program is constructed modularly. It comprises the two parts:

- PLC basic program

The PLC basic program organizes the exchange of signals and data between the PLC user program and the NCK, HMI, and machine control panel components. The PLC basic program is a part of the tool box delivered with the SINUMERIK 840D sl.

- PLC user program

The PLC user program is the user-specific part of the PLC program by which the basic PLC program has been added to or extended.

PLC basic program

For a complete description of the basic PLC program, its structure and all modules including their call parameters, please refer to:

Literature

Function Manual Basic Functions; Basic PLC Program

PLC user program

The organization blocks of the basic machine contain the entry points for the appropriate parts of the PLC user program.

- OB100 (cold restart)
- OB1 (cyclic processing)
- OB40 (process alarm)

The following diagram shows the structure of the PLC program:




Figure 21-4 PLC program structure

PLC status

The PLC always starts up in RESTART mode, i.e. the PLC operating system runs OB100 after initialization and starts cyclic operation at the beginning of OB1. There is no re-entry at the point of interruption (e.g. on power failure).

Start-up behavior of the PLC

There are both remanent and non-remanent areas for the markers, times and counter. The areas are continuous and are divided by a parameterizable limit, where the area with the higher-value address range is defined as the non-remanent area. Data blocks are always remanent.

Start-up mode COLD RESTART (OB 100)

If the remanent area has no battery backup (backup battery is empty) start-up is prevented. The following operations are performed during a cold restart:

- UStack, BStack and non-retentive flags, timers and counters are deleted
- The process output image (POI) is deleted
- Process and diagnostics alarms are cancelled
- The system status list is updated
- Parameterization objects of modules (from SD100 onwards) are evaluated or default parameters are output to all modules in single-processor mode
- Execute cold restart (OB100)
- Read in process input image (PII)
- Cancel command output inhibit (BASP)

Basic program, start-up part (FB1)

FB 1 (start-up block of the PLC program) must be assigned variables.

Parameter FB 1

A precise description of the variables and options for modifying their parameterization is given in:

Literature

Function Manual Basic Functions; Basic PLC Program

Cyclical mode (OB 1)

From a chronological viewpoint, the basic program runs ahead of the PLC user program. The complete processing of the NCK-PLC interface is carried out in cyclic mode.

A cyclic monitoring function is activated between PLC and NCK once power-up and the first OB1 cycle have been completed. A PLC failure produces alarm "2000 Sign-of-life monitoring PLC".

See also

Creating a PLC program (Page 62)

21.4.1 Fundamentals of creating a PLC user program

Introduction

The following points must be observed when generating a PLC user program:

- Software and hardware requirements
- Installing the toolbox (PLC basic program, slave OEM, GSD files)
- Editing the blocks in the PLC basic program

Software and hardware requirements

- SIMATIC STEP 7 as from Version 5.3, Service Pack 3
- SIMATIC STEP 7 is installed on the PG/PC

Installing the PLC basic program library

To be able to use the blocks of the basic PLC program (OBs, FBs, DBs, etc.) in a SIMATIC S7 project, the library must first be installed in the SIMATIC manager.

Editing the blocks in the PLC basic program

The individual blocks in the basic PLC program can be processed as follows in the SIMATIC manager:

- Select the appropriate block, e.g. OB 100 in the folder Blocks of the corresponding Module
- Use the "Edit" > "Open object" menu command to open the block or double-click the block with the left mouse button
- Edit the block using the LAD/STL/CSF editor. Switch over to the block display using the "View" > "LAD" or STL or CSF menu command

See also

Creating a PLC program (Page 62)

21.5 Machine and setting data

Introduction

Adaption of the control at the machine is carried out using the machine and setting data.

Parameter assignment

- Machine data

The machine data (MD) are divided into the following areas:

- General machine data
- Channel-specific machine data
- Axis-specific machine data
- Machine data for control unit
- Machine data for infeed
- Machine data for drives

- Setting data

The setting data (SD) are divided into the following areas:

- General setting data
- Channel-specific setting data
- Axis-specific setting data

- Option data

For enabling options. The option data are included in the scope of delivery.

Overview of machine and setting data

The table below lists the areas for machine and setting data. The List Manual contains a detailed description.

Table 21- 4 Overview of machine and setting data

Range	Name
from 1000 to 1799	Machine data for drives (\$MD_...)
from 9000 to 9999	Machine data for operator panel front (\$MM_...)
from 10000 to 18999	General machine data (\$MN_...)
from 19000 to 19999	Reserved
from 20000 to 28999	Channel-specific machine data (\$MC_...)
from 29000 to 29999	Reserved
from 30000 to 38999	Axis-specific machine data (\$MA_...)
from 39000 to 39999	Reserved

Range	Name
from 41000 to 41999	General setting data (\$SN_...)
from 42000 to 42999	Channel-specific setting data (\$SC_...)
from 43000 to 43999	Axis-specific setting data (\$SA_...)
from 51000 to 61999	General machine data for compile cycles
from 62000 to 62999	Channel-specific machine data for compile cycles
from 63000 to 63999	Axis-specific machine data for compile cycles

See also

Overview Commissioning NCK (Page 121)

21.5.1 Machine data fundamentals

Introduction

Machine and setting data are parameterized via:

- Number and identifier
- Activation
- Protection levels
- Unit
- Default value
- Value range (minimum and maximum)

Number and identifier

Machine data and setting data are identified using the number or the name (identifier). The number and name are displayed at the HMI.

The identifier of a machine data is subject to the scheme:

- **\$ M k _IdentifierString**
 - where the following applies:
 - **\$** System variable
 - **M** Machine data
 - **k** Component
 - k** identifies the components of the NC parameterizing the appropriate machine data:
 - **N** NC
 - **C** Channel
 - **A** Axis

The identifier of a setting data is subject to the scheme:

- **\$ S k**_IdentifierString

where the following applies:

- **\$** System variable
- **S** Setting data
- **k** Component

k identifies the components of the NC parameterizing the appropriate machine data:

- **N** NC
- **C** Channel
- **A** Axis

Activation

Activation when referring to a machine data indicates the NC status in which a change to a machine data becomes active.

The levels of effectiveness have been listed below in order of priority. Modification of the machine data takes effect after:

- POWER ON (po) NCK RESET
- NEWCONF (cf)
 - "Set MD to active" softkey on MMC
 - <RESET> key on the MSTT
 - It is possible to modify block limits during program operation
- RESET (re)
 - at end of program M2/M30 or
 - <RESET> key on the MSTT
- IMMEDIATE (so)
 - After entry of value

Note

Unlike machine data, changes to setting data always become effective **immediately**.

Protection levels

Access level 4 (keyswitch position 3) or more is required to display machine data.

To start up the system, the appropriate protection level must generally be enabled by entering the password "EVENING".

Unit

The unit refers to the standard setting of the machine data:

- MD10220 \$MN_SCALING_FACTOR_USER_DEF_MASK
- MD10230 \$MN_SCALING_FACTOR_USER_DEF
- MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = 1.

If the machine data is not based on an engineering unit, then the field is marked with "-".

Default value

The machine data/setting data is preset to this value.

Note

Inputs via HMI are limited to ten digits plus comma and sign.

Value range (minimum and maximum)

Specifies the input limits. If no range of values is specified, the data type determines the input limits and the field is marked with "***".

21.5.2 Handling the machine data

Introduction

To display and input machine data, appropriate screen forms are provided.

Example

Selection of displays:

When you press the <Area switchover> key on the HMI, the menu bar appears with the following areas: "Machine", "Parameter", "Program", "Services", "Diagnostics" and "Commissioning". Press "Commissioning" > "Machine data".

Note

For the input of machine data, the protection level 2 password "EVENING" has to be set at the least.

Screen editor for HEX machine data

A bit editor has been implemented to simplify the matter of setting certain machine data bits. If the input cursor is on a machine data in HEX format in the MD list, you can call up the bit editor by pressing the <Toggle> key (in the middle of the cursor keys).

You can set or reset single bits by clicking on them with the mouse or by selecting them with the cursor keys and then pressing the <Toggle> key.

- With the "Ok" softkey, you can terminate the bit editor and accept the value set.
- With the "Abort" softkey, you can reject the bit editor and accept the value set. The previous setting is then valid again.

21.6 Protection levels

Introduction

Access to programs, data and functions is user-oriented and controlled via eight hierarchical protection levels. These are divided into

- 4 password levels for Siemens, machine manufacturer, start-up personnel, and end user
- 4 key switch positions for end user

Protection levels

There are protection levels 0 to 7 (see table below), where

- 0 is the highest and
- 7 is the lowest level.

Table 21- 5 Protection level concept

Protection level	Locked by	Range
0	Password	Siemens
1	Password: SUNRISE (default)	Machine manufacturer
2	Password: EVENING (default)	Installation engineer, service
3	Password: CUSTOMER (default)	End user
4	Key switch position 3	Programmer, machine setter
5	Key switch position 2	Qualified operator
6	Key switch position 1	Trained operator
7	Key switch position 0	Semi-skilled operator

Interlock

Protection levels

- 0 to 3 are locked by means of a password and
- 4 to 7 by means of keyswitch positions (see table below).

Table 21- 6 Keyswitch settings

Keyswitch setting	Retraction pos.	NC password level	User group
	0 or 1 or 2 or 3 Red key	4 (highest access level)	Programmer, machine setter
	0 or 1 or 2 Green key	5 (increasing access rights)	Qualified operator
	0 or 1 Black key	6 (increasing access rights)	Trained operator
	-	7 (lowest access level)	Semi-skilled operator

Protection levels for machine data

The machine data is assigned different protection levels by default.

Access level 4 (keyswitch position 3) or more is required to display machine data.

Note

To start up the system the appropriate access level must generally be enabled by entering the password "EVENING".

You can find additional change options of protection levels at:

Literature

Function Manual Basic Functions; Diverse Interface Signals

21.6.1 Protection level fundamentals

Introduction

You can influence the protection levels used with passwords via softkeys.

Press the "HMI" -> "Password" softkey in the "Startup" operating area. The following softkeys are available:

- Setting the password
- Change password
- Delete password

Set password

1. Press the softkey "Set password." The "Please enter password:" input window appears.
2. Enter one of the possible default passwords (see table "Protection levels concept") and confirm the entry with the softkey "OK." A permissible password is set and the valid access level is displayed. Invalid passwords will be rejected.

Change password

For secure access protection, you should change the default passwords

1. Press the "Change password" softkey. The current access level is displayed in the window that opens.
2. Mark the area for which you would like to assign the new password. You can select the following areas here:
 - System
 - Vendor
 - Service
 - User
3. Enter the new password in the input fields "New password" and "Repeat password."
4. Confirm the entry with the softkey "OK." Both entered passwords must match for the modified password to become valid.

Delete password

1. Press the softkey "Delete password" in order to reset the access authorization.

Access authorization is not automatically deleted at POWER ON!

NOTICE
For a system boot in which standard machine data is loaded, the passwords are set to the default values.

21.7 Axis data

Introduction

The term "axis" is often used either as a single term in conjunction with SINUMERIK 840D sl or in compounded form, e.g. machine axis, channel axis, etc. To provide an overview of the philosophy used as the basis, here is a brief explanation of this term.

Definition

Generally, 4 types of axes are distinguished:

1. Machine axes
2. Channel axes
3. Geometry axes
4. Special axes

Machine axes

Machine axes are the motion units existing on a machine, which can also be designated as linear or rotary axes, depending on their usable movement.

Channel axes

The total of all machine, geometry and special axes assigned to a channel is designated as channel axes.

In this context, the geometry and special axes constitute the program-technological part of the machining process, i.e. they are used for programming in the parts program.

The machine axes constitute the physical part of the machining process, i.e. they carry out the programmed traversing movements on the machine.

Geometry axes

The geometry axes constitute the rectangular Cartesian basic coordinate system of a channel.

Generally, (Cartesian arrangement of the machine axes) direct imaging of the geometry axes to the machine axes is possible. If the arrangement of the machine axes, however, is not Cartesian at right angles, the imaging is performed using a kinematic transformation.

Special axes

Additional axes are all other channel axes that are not geometry axes. Unlike for geometry axes (Cartesian coordinate system), no geometric context is defined for additional axes, neither between additional axes nor with respect to geometry axes.

Literature

Function Manual Basic Functions; Axes, Coordinate Systems, Frames, Workpiece numbers
IWS: Axes

21.7.1 Axis assignment

Introduction

The assignment of geometry axes to channel axes and channel axes to machine axes, as well as the definition of the names of the different axis types is realized via machine data. The following diagram illustrates this relationship:




Figure 21-5 Axis assignment

Geometry and special axes

A maximum of 3 channel axes can be declared as geometry axes. The geometry axes must be assigned to the channel axes in ascending order without any gaps.

All channel axes that are not geometry axes are special axes.

Channel axis gaps

Normally, using MD20070, a channel axis is assigned to one machine axis. Not every channel axis must be assigned to a machine axis. Each channel axis that cannot be assigned to a machine axis (MD20070 [n] = 0), represents a channel axis gap.

Application

Channel axis gaps allow the creation of a uniform configuration of the channel axes over different machine versions of a series. Each channel axis of the series has a defined task or function. If the function and therefore the machine axis does not exist at a specific machine, the corresponding channel axis is not assigned to a machine axis:

MD20070 \$MC_AXCONF_MACHAX_USED[<channel axis>] = 0

Advantages:

- Series commissioning file with uniform basic configuration
- Simple post configuration for the specific machine
- Flexible portability of part programs

Enable

The use of channel axis gaps must be enabled using the machine data:

- MD11640 \$MN_ENABLE_CHAN_AX_GAP = 1 (channel axis gap allowed).

If the use of channel axis gaps is not released, the value 0 for channel axis n in the following machine data exits the allocation of additional machine axes to channel axes possibly following channel axis n:

MD20070 \$MC_AXCONF_MACHAX_USED[<channel axis n>]

Supplementary conditions

- Regarding the number of channel axes and the indexing, a channel axis gap counts just the same as axes.
- Ensure that a geometry axis is not assigned to a channel axis that is not assigned to a machine axis (channel axis gap). **No** alarm is displayed!
- Transformation: When configuring a channel axis in the following machine data, which is not assigned a machine axis (channel axis gap), then Alarm 4346 / 4347 displayed:
 - MD24110 ff. \$MC_TRAFO_AXES_IN1...8
 - MD24120 ff. \$MC_TRAFO_GEOAX_ASSIGN_TAB1...8

Example

The 5th channel axis "B" in MD20070 is not assigned to a machine axis.

If channel axis gaps are enabled, 6 machine axes (1 - 4, 5, 6) are available.

If channel axis gaps are not enabled, then there are 4 machine axes (1 - 4) available.




Figure 21-6 Axis configuration with channel axis gap

21.7.2 Drive assignment

Introduction

The assignment of machine axes to the drive objects SERVO is realized using machine data. The following diagram illustrates this relationship.

Drive assignment




Figure 21-7 Drive assignment

- (1) Using the machine data, the NC is informed about the I/O addresses of the SERVO drive objects defined in the S7 project in "HW Config":
MD13050 \$MN_DRIVE_LOGIC_ADDRESS[n] (I/O address of the drive)
- (2) Using the machine data of the setpoint and actual value assignment, the machine axes are assigned to the particular SERVO drive objects:
 - MD30110 \$MA_CTRLOUT_MODULE_NR[0] (setpoint assignment)
 - MD30220 \$MA_ENC_MODULE_NR[0] (actual value assignment)
 The logical drive number **m** to be entered into the two machine data, refers to the I/O address entered in (1) under index $n = (m - 1)$.
- (3) Using machine data, MD10000 \$MN_AXCONF_MACHAX_NAME_TAB, the machine axes are allocated a unique name NC-wide.
Index n addresses the (n+1)th machine axis.

Machine data

The following machine data are relevant for the assignment of channel axes to drives:

No.	Name of identifier	Name/remarks
NC-specific (\$MN_ ...)		
10000	AXCONF_MACHAX_NAME_TAB	Machine axis name
10002	AXCONF_LOGIC_MACHAX_TAB	Logical machine axis image
13050	DRIVE_LOGIC_ADDRESS	I/O address of drive
Channel-specific (\$MC_ ...)		
20050	AXCONF_GEOAX_ASSIGN_TAB	Assignment of geometry axis to channel axis
20060	AXCONF_GEOAX_NAME_TAB	Geometry axis name in channel
20070	AXCONF_MACHAX_USED	Machine axis number valid in channel
20080	AXCONF_CHANAX_NAME_TAB	Name of channel axis in the channel
Axis-specific (\$MA_ ...)		
30110	CTRLOUT_MODULE_NR	Setpoint assignment
30220	ENC_MODULE_NR	Actual-value assignment

See also

Axis assignment (Page 473)

21.7.3 Axis names

Introduction

Each machine, channel and geometry axis can/must be assigned an individual name unambiguously identifying it in its name range.

Machine axes

The name of the machine axes are defined via the following machine date:

MD10000 \$MN_AXCONF_MACHAX_NAME_TAB [n] (machine axis name)

Machine axis names must be unambiguous for the entire NC.

The names and the corresponding index defined in the machine date above is used for:

- Accessing axis-specific machine data (loading, saving, displaying)
- Reference point approach from the parts program G74
- Measuring
- Test point traversing from the parts program G75
- Traversing the machine axis from PLC
- Display of axis-specific alarms
- Display in the actual-value system (machine-related)
- DRF handwheel function

Channel axes

The name of the channel axes are defined via the following machine date:

MD20080 \$MC_AXCONF_CHANAX_NAME_TAB[n] (name of the channel axis in the channel)

Channel axis names must be unambiguous for the entire channel.

Geometry axes

The name of the geometry axes are defined via the following machine data:

MD20060 \$MC_AXCONF_GEOAX_NAME_TAB [n] (geometry axis in the channel)

Geometry axis names must be unambiguous for the entire channel.

The axis names for channel and geometry axes are used in the parts program for programming general traversing movements or to describe the workpiece contour. The axis names are used for

- Path axes
- Synchronized axes
- Positioning axes

- Command axes
- Spindles
- Gantry axes
- Coupled axes
- Guide value coupling axes

Machine data

The following machine data are relevant for the axis names:

Table 21- 7 Axis names: Machine data

Number	Identifier	Name/remarks
General (\$MN_ ...)		
10000	AXCONF_MACHAX_NAME_TAB	Machine axis name
Channel-specific (\$MC_ ...)		
20060	AXCONF_GEOAX_NAME_TAB	Geometry axis name in channel
20080	AXCONF_CHANAX_NAME_TAB	Channel axis name/special axis name in channel

21.7.4 Setpoint/actual value channels

Introduction

The following points must be observed for setpoint/actual value channels:

Note

In order to guarantee that the control runs up reliably, all machine axes are declared as simulation axes (without hardware).

- MD30130 \$MA_CTRLOUT_TYPE (output type of setpoint value) = 0
- MD30240 \$MA_ENC_TYPE (actual value acquisition mode) = 0

Traversing of the axes in servo mode is simulated without speed setpoint output, and no hardware-specific alarms are output.

Machine data

- MD30350 \$MA_SIMU_AX_VDI_OUTPUT (output of axis signals with simulation axes) can be used to select whether the interface signals of a simulation axis are output at the NC/PLC interface (e.g. during program test, if there is no drive hardware, used in FC18 in PLC).
-

Assignment of the setpoint/actual value channels

For each machine axis to which a drive is assigned, the following must be parameterized:

- a setpoint channel and
- at least one actual-value channel

A second actual-value channel can be set up as an option.

NOTICE
The motor measuring system is always used for the speed control function. Motor and motor measuring system must therefore always be connected to the same drive (SERVO).

In the following two axis-specific machine data, the logical drive number *m* of the drive is entered, which represents the machine axis:

- MD30110 \$MA_CTRL_OUT_MODULE_NR[0] (setpoint assignment: logical drive number)
- MD30220 \$MA_ENC_MODUL_NR[n] (actual value assignment: logical drive number)

With the logical drive number *m*, that drive is addressed whose I/O address is entered under the index $n = (m - 1)$ in MD13050 \$MN_DRIVE_LOGIC_ADDRESS[<n>] (see Chapter "Axis assignment (Page 473)").

NCK Reset

Once the drive configuration and setpoint/actual value assignment have been parameterized, an NCK reset must be executed to initiate a warm restart of the NC. After the NC has powered up, the set configuration is effective.

Measuring system switchover

The following interface signals can be used to switch between the two position measuring systems of a machine axis from the PLC.

- DB31, ... DBX1.5 (position measuring system 1 selected)
- DB31, ... DBX1.6 (position measuring system 2 selected)

References

Function Manual Basic Functions; Diverse Interface Signals

Machine data

Table 21- 8 Setpoint/actual value channels: Machine data

Number	Name of identifier	Name/remarks	Reference
Axis-specific (\$MA_ ...)			
30110	CTRLOUT_MODULE_NR	Setpoint assignment: Logical drive number	
30130	CTRLOUT_TYPE	Output of setpoint value 0 = Simulation 1 = Output of speed setpoint	
30200	NUM_ENCS	Number of measuring channels 1 = One position measuring system present 2 = Two position measuring systems present	
30220	ENC_MODULE_NR[0]	Actual value assignment: Logical drive number for position measuring system 1	
30220	ENC_MODULE_NR[1]	Actual value assignment: Logical drive number for position measuring system 2	
30230	ENC_INPUT_NR[0]	Actual value assignment: Position measuring system 1 1 = G1_XIST encoder 1 position actual value 1 2 = G2_XIST encoder 1 position actual value 2	
30230	ENC_INPUT_NR[1]	Actual value assignment: Position measuring system 2 1 = G1_XIST encoder 2 position actual value 1 2 = G2_XIST encoder 2 position actual value 2	
30240	ENC_TYPE[0]	Type of actual value recording 0 = Simulation 1 = Incremental encoder 4 = Absolute encoder with EnDat interface	

Interface signals

Table 21- 9 Switchover of position measuring system: Interface signals

DB number	Bit, byte	Name	Reference
Axis/spindle-specific		Signals from PLC to axis/spindle	
31, ...	1.5	Position measuring system 1	
31, ...	1.6	Position measuring system 2	

References

Function Manual Basic Functions;
Speeds, Setpoint/actual-value systems, Control: Setpoint/actual-value system

Function Manual Basic Functions;
Diverse Interface Signals: Interface signals to axis/spindle

21.8 Spindle data

Introduction

The spindle mode of a machine axis is a subset of the general axis functionality. For this reason, the machine data required to start up an axis have also to be set for a spindle.

The machine data to parameterize a spindle are therefore to be found under the axis-specific machine data (from MD 35000 onwards).

Note

After the default machine data have been loaded, no spindle is defined.

Spindle definition

With the following machine data, a machine axis is declared to be an endlessly rotating rotary axis whose programming and display is carried out modulo 360 degrees.

- MD30300 \$MA_IS_ROT_AX (rotary axis/spindle)
- MD30310 \$MA_ROT_IS_MODULO (modulo conversion for rotary axis/spindle)
- MD30320 \$MA_DISPLAY_IS_MODULO (modulo 360 degrees display for rotary axis/spindle)

The machine axis is converted to a spindle by defining the spindle number x (with x = 1, 2, ...max. number of channel axes) in machine data

- MD35000 \$MA_SPIND_ASSIGN_TO_MACHAX (spindle number)

The spindle number must be unique within the channel axes of the channel to which the spindle is assigned.

21.8.1 Spindle modes

Spindle modes

The spindle can have the following modes:

- Control mode
- Oscillation mode
- Positioning mode
- Synchronous mode, synchronous spindle

References:

Function Manual, Extension Functions, Synchronous Spindle (S3)

- Rigid tapping

References:

Programming Manual, Fundamentals; Chapter: Motion commands

Axis mode

The spindle can be switched from spindle mode to axis mode (rotary axis) if the same motor is used for spindle and axis operation.

21.8.2 Initial spindle state

Spindle basic setting

The following machine data is used to specify a spindle mode as basic setting:

MD35020 \$MA_SPIND_DEFAULT_MODE

Value	Spindle basic setting
0	Speed control mode, position control deselected
1	Speed control mode, position control activated
2	Positioning mode
3	Axis mode

Time when the spindle basic setting takes effect

The time when the spindle basic setting takes effect is set in the machine data:

MD35030 \$MA_SPIND_DEFAULT_ACT_MASK

Value	Effective time
0	POWER ON
1	POWER ON and program start
2	POWER ON and RESET (M2 / M30)

21.8.3 General functionality

Why axis mode?

For certain machining tasks (e.g. on lathes with end-face machining), the spindle not only has to be rotated with M3, M4 and M5 and positioned with SPOS, M19 and SPOSA, but also addressed as an axis with its axis identifier (e.g. "C").

Prerequisites

- The same spindle motor is used for spindle mode and axis mode.
- The same position measurement system or separate position measurement systems can be used for spindle mode and axis mode.
- A position actual-value encoder is a mandatory requirement for axis mode.
- If the axis is not synchronized, e.g. M70 is programmed after POWER ON, the axis must first be referenced with G74. Only then does the mechanical position match the programmed one.

Example:

```
M70
G74 C1=0 Z100
G0 C180 X50
```

Configurable M function

The M function used to switch the spindle to axis mode can be configured in the machine data:

```
MD20094 $MC_SPIND_RIGID_TAPPING_M_NR
```

The value on delivery is 70.

Note

From software version 2.6, the control system detects the transition to axis mode automatically from the program sequence (see ""). Therefore, there is no need at all for the explicit programming in the part program of the configured M function for switching the spindle to axis mode (default: M70). However, the M function can continue to be programmed, e.g. to increase the readability of the part program.

Functionality

If the axis mode is active and the rotary axis homed, all axis functions can be used.

The most important functions are:

- Programming with axis name
- Use of zero offsets (G54, G55, TRANS, etc.)
- G90, G91, IC, AC, DC, ACP, ACN
- Use of kinematic transformations (e.g. TRANSMIT)
- Interpolation with other axes (path interpolation)
- Programming as a positioning axis

References:

Function Manual, Extension Functions; Rotary Axes (R2)

Special points to be noted

- The feed override switch is active.
- NC/PLC IS:
DB21, ... DBX7.7 (Reset)
does not terminate axis mode as standard.
- The NC/PLC interface signals:
DB31, ... DBB16 to DBB19 and DBB82 to DBB91
are not important if:
DB31, ... DBX60.0 (axis / no spindle) = 0
- Axis mode can be activated in all gear steps.

If the position actual value encoder is installed on the motor (indirect measuring system), the positioning and contouring accuracy can vary for the different gear steps.
- The gear step cannot be changed when the axis mode is active.
The spindle must be switched to control mode.
This is done with M41 ... M45 or M5, SPCOF.
- In axis mode, the machine data from the servo parameter set with index zero are effective in order to carry out adaptations in this mode.

Servo parameter set

The relevant machine data from the servo parameter set are:

Machine data	Meaning
MD31050 \$MA_DRIVE_AX_RATIO_DENOM	Measuring gear denominator
MD31060 \$MA_DRIVE_AX_RATIO_NUMERA	Numerator load gearbox
MD32200 \$MA_POSCTRL_GAIN	K _v factor
MD32452 \$MA_BACKLASH_FACTOR	Weighting factor for backlash
MD32610 \$MA_VELO_FFW_WEIGHT	Weighting factor for feedforward control
MD32800 \$MA_EQUIV_CURRCTRL_TIME	Equivalent time constant current control loop for feedforward control
MD32810 \$MA_EQUIV_SPEEDCTRL_TIME	Equivalent time constant speed control loop for feedforward control
MD32910 \$MA_DYN_MATCH_TIME	Time constant for dynamic matching
MD36012 \$MA_STOP_LIMIT_FACTOR	Factor for exact stop coarse/fine and zero speed control
MD36200 \$MA_AX_VELO_LIMIT	Velocity monitoring threshold value

Other notes on the servo parameter set:

References:

Function Manual, Basic Functions; Velocities, Setpoint/Actual-Value System, Closed-Loop Control (G2)

Dynamic response

The dynamic limits of the axis stored in the machine data are applicable in axis operation.

The axis switches to the current feedforward control mode as designated by the MD and the commands `FFWON` and `FFWOF`.

Use of resolution changes

When using resolution changes in (analog) drive actuators, the following NC program steps are required:

1. Changeover to axis mode

Programming	Comment
SPOS=...	
M5	; Controller enable off (by PLC) → is output on PLC
M70	; Switch actuator (by PLC on account of M70) Controller enable on (by PLC)
C=...	; NC traverses with axis parameter set

2. Switch back to spindle mode

Programming	Comment
C=...	
M71	; → Output to PLC Closed-loop controller enable off (by PLC) Switch actuator (by PLC) Switched to spindle parameter set (1-5) internally in the NC, controller enable on (by PLC)
M3/4/5 or SPOS=...	; NC traverses with spindle parameter set

Change to spindle mode

The interpolation parameter (set 1 ... 5) is selected according to the currently valid gear step.

The feedforward control function is always activated, except for tapping with compensating chuck.

Machine data:

MD32620 \$MA_FFW_MODE (feedforward control type)

must always be not equal to 0.

Feedforward control should always be operated with the value 100% to avoid alarms being output during positioning.

Parameter set	Axis mode	Spindle mode
0	Valid	
1		Valid
2		Valid
3		Valid
4		Valid
5		Valid

Depending on gear step

Figure 21-8 Validity of parameter sets for axis and spindle modes

Master spindle

In order to use diverse spindle functions in one channel, like for instance

- Revolutionary feed (G95)
- Tapping with compensation chuck (G63)
- Thread cutting (G33)
- Dwell time in spindle revolutions (G4 S...)

it is necessary to define a master spindle in each channel:

- MD20090 \$MC_SPIND_DEF_MASTER_SPIND (master spindle initial setting in channel)

The spindle number of the channel spindle which is to be the master spindle defined in machine data MD35000 \$MC_SPIND_ASSIGN_TO_MACHAX (spindle number) is entered in this machine data.

Spindle reset

The following machine data defines whether the spindle is to remain active after reset (IS: DB21,... DBX7.7) or end of program (M02/M30).

- MD 35040 \$MC_SPIND_ACTIVE_AFTER_RESET (spindle active after reset)

To cancel spindle movements, an independent spindle reset is required:

- IS: DB31,... DBX2.2 (spindle reset)

Literature

Function Manual Basic Functions; Spindles

Appendix

A.1 Abbreviations

ACX	Compressed format from XML
ALM	Active Line Module
AS	Automation System
BASP	Command output disable
BERO	Proximity limit switch
BI	Binector input
BICO	Binector connector
BO	Binector output
CF	CompactFlash
CI	Connector input
CNC	Computerized Numerical Control
CO	Connector output
CoL	Certificate of License
CP	Communications Processor
CPU	Central Processing Unit
CU	Control unit
DHCP	Dynamic Host Configuration Protocol: Protocol for automatic assignment of IP addresses from a DHCP server to a client computer
DIP	Dual In-Line Package: dual in-line arrangement
DO	Drive objects
DP	Distributed I/O
DRAM	Dynamic Random Access Memory
DRF	Differential resolver function: differential-synchro transmitter function
DRIVE-CLiQ	Drive Component Link with IQ
DSC	Dynamic servo control
DWORD	Doubleword
EMC	Electro-Magnetic Compatibility
EN	European standard
EQN	Designation for an absolute encoder with 2048 sine signals per revolution
ESD	Electrostatic Sensitive Device
GC	Global Control
GSD	Device master file
GUD	Global User Data
GWPS	Grinding wheel peripheral speed
HMI	Human Machine Interface: SINUMERIK operator interface for operating, programming, and simulation
IBN	Start up


Appendix

A.1 Abbreviations

IPO	Interpolator cycle
IS	Interface signal
JOG	JOG mode: manual mode for setting up the machine
LAN	Local Area Network
LED	Light Emitting Diode
LR	Position controller
LUD	Local User Data
MAC	Media Access Control
MCIS	Motion Control Information System
MCP	Machine control panel
MD	Machine data
MELDW	Message word
MLFB	Machine-readable product designation
MM	Motor module
NC	NCK
NCK	Numerical Control Kernel: NC kernel with block preparation, travel range, etc.
NCU	Numerical Control Unit: NCK hardware unit
NX	Numerical Extension (axis extension module)
OB	Organization block
OLP	Optical Link Plug
PCU	PC Unit: computer unit
PD	Process date
PELV	Protective Extra-Low Voltage
PG	Programming device
PII	Process input image
PIO	Process output image
PLC	Programmable Logic Control (component of the CNC controller)
PM	Power Module
PNO	PROFIBUS User Organization (e.v.)
PUD	Global Program User Data
RAM	Random Access Memory (can be read and written)
RDY	Ready
REF	Reference point
RES	Reset
RTCP	Real Time Control Protocol
SBC	Safe brake activation
SD	Setting Data
SH	Safe standstill
SIM	Single Inline Module
SLM	Smart Line Module
SMC	Sensor Module Cabinet-Mounted
SME	Sensor Module Externally Mounted
SMI	Sensor Module Integrated

SRAM	Static RAM (battery-backed)
STW	Control word
TCU	Thin Client Unit (communication with operator panels)
USB	Universal Serial Bus
VDE	Association of Electrical Engineering, Electronics and Information Technology
VO	Voltage output
ZSW	Status Word

A.2 Overview



Glossary

Active Line Module

Controlled, self-commutating feed/feedback unit (with -"IGBT"s in feed/feedback direction), which supplies the DC link voltage for the -> "Motor module".

CompactFlash card

Memory card for non-volatile storage of the drive software and corresponding -> "Parameters". The memory card can be plugged into the -> "Control Unit" from outside.

Control unit

Central control module in which the closed-loop and open-loop control functions for one or more -> "SINAMICS" -> "Line Module"s and/or -> "Motor Module"s are implemented.

There are three types of Control Unit:

- SINAMICS Control Units, e.g. -> "CU320"
- SIMOTION Control Units, e.g. -> "D425" and -> "D435"
- SINUMERIK solution line Control Units, e.g. NCU710, NCU720 and NCU730

Control Word

Bit-coded -"Process data" word, transmitted by -> "PROFIdrive" at cyclic intervals to control the drive states.

Double Motor Module

Two motors can be connected to and operated with a Double Motor Module.

See -> "Motor Module" -> "Single Motor Module"

Former term: -> "Double-axis module"

Drive

The drive includes the motor (electric or hydraulic), the actuator (converter, valve), the control unit, measuring system, and supply components (line infeed module, pressure reservoir).

For electric drives, a distinction is made between a converter system and an inverter system. With a converter system (e.g. -> "MICROMASTER 4"), from the point of view of the user the line infeed, actuator, and control component form a single device; with an inverter system (e.g. -> "SINAMICS S"), the supply is ensured by means of -> "Line Module", thereby realizing a DC line to which the -> "Inverters" (-> "Motor Module"s) are connected.

The (-> "Control unit") is implemented as a separate device and connected to the other components by means of -> "DRIVE-CLiQ".

Drive component

Hardware component connected to a → "Control Unit" via → "DRIVE-CLiQ", for example. Drive units are for instance: → "Motor Module"s, → "Line Module"s, → "Motor"s, → "Sensor Module"s and → "Terminal Module"s. The overall layout of a Control Unit together with the connected drive components is called → "Drive unit".

Drive group

A drive group comprises a → "Control Unit" and the → "Motor Module"s and → "Line Module"s connected via → "DRIVE-CLiQ".

Drive object

A drive object is an autonomous, individual software function with its own → "Parameters" and may also have its own → "Fault"s and → "Alarm"s. Drive objects may exist by default (e.g. On Board I/O) can be created individually (e.g. → "Terminal Board" 30, TB30) or also as multiples (e.g. → "Servo Control"). As a rule, each drive object has its own window for parameterization and diagnostic purposes.

Drive parameters

Parameters of a drive axis that include, for example, the parameters of the corresponding controllers, as well as the motor and encoder data. The parameters of the higher-level technology functions (positioning, ramp-function generator), however, are called → "Application Parameters". See → "Basic Unit System".

Drive system

The drive system includes all the components in a product family (e.g. SINAMICS). A drive system comprises, for example, → "Line Module"s, → "Motor Module"s, → "Sensors", → "Motors", → "Terminal Module"s and → "Sensor Module"s as well as additional components (reactors, filters, cables, etc.). See → "Drive unit".

Drive unit

The drive unit includes all the components connected via → "DRIVE-CLiQ" that are required for carrying out a drive task: → "Motor Module" → "Control Unit" → "Line Module" and the required → "Firmware" and → "Motor"s, but not additional components, such as filters or reactors. Several → "Drive"s can be implemented in a drive unit. See → "Drive System".

DRIVE-CLiQ

Abbreviation of "Drive Component Link with IQ".

Communication system for connecting the different components of a SINAMICS drive system (e.g. -> "Control Unit", -> "Line Module"s, -> "Motor Module"s, -> "Motor"s, and speed/position sensors.

The DRIVE-CLiQ hardware is based on the Industrial Ethernet standard with twisted-pair lines. The DRIVE-CLiQ line provides the transmit and receive signals, as well as the +24 V power supply.

DRIVE-CLiQ Hub Module Cabinet

The DRIVE-CLiQ Hub Module Cabinet (DMC) is a star coupler for multiplying -> "DRIVE-CLiQ sockets. The DMC can be clipped onto a rail. The DMC20 is available, for example:

See -> "Hub"

Encoders

An encoder is a measuring system that captures actual values for the speed and/or angular/position values and makes them available for electronic processing. Depending on the mechanical construction, encoders can be integrated in the -> "Motor" (-> "Motor Sensor") or mounted on the external mechanics (- "External Sensor"). Depending on the type of movement, a distinction is made between rotary sensors ("rotary transducers") and translatory sensors (e.g. - Linear Sensors). In terms of measured value provision, a distinction is made between -> "Absolute Sensor"s (code sensors) and -> "Incremental Sensors"s.

See -> "Incremental Sensor TTL/HTL" -> "Incremental Sensor sin/cos 1 Vpp" -> "Resolver".

External Encoder

Position encoder that is not built in or mounted on the -> "Motor", but fitted instead via a mechanical transmission element or mechanical intermediate element.

The external encoder (see -> "Externally-Mounted Sensor") is used for -> "Direct Position Detection".

Hub

Central connection device in a network with star-shaped topology. A hub distributes incoming data packages to all connected end devices.

See -> "DRIVE-CLiQ Hub Module Cabinet" (DMCxx)

Line Module

A Line Module is a power component that generates the DC link voltage for one or more → "Motor Module"s from a 3-phase mains voltage.

In SINAMICS, the following three types of Line Module are available:

→ "Basic Line Module", → "Smart Line Module" → "Active Line Module".

The overall function of an infeed, including the required additional components like → "Line Reactor", proportional computing power in a → "Control Unit", switching devices, etc., is called → "Basic Infeed", → "Smart Infeed", and → "Active Infeed".

Motor

For the electric motors that can be driven by → "SINAMICS", a basic distinction is made between rotary and linear motors with regard to their direction of motion, and between synchronous and induction motors with regard to their electromagnetic operating principle. In SINAMICS, the motors are connected to a → "Motor Module".

See → "Synchronous Motor" → "Induction Motor" → "Built-In Motor" → "Motor Encoder" → "External Encoder" → "Third-Party Motor".

Motor Encoder

A → "Sensor" (e.g. → "Resolver", → "Incremental Sensor TTL/HTL", or → "Incremental Sensor sin/cos 1 Vpp" that is integrated in or attached to the motor.

The sensor detects the motor speed. In the case of synchronous motors, it can also detect the rotor position angle (of the commutation angle for the motor currents).

For drives without an additional → "Direct Position Measuring System", it is also used as a → "Position Sensor" for position control.

In addition to the motor encoders, → "External Sensor"s for → "Direct Position Sensing" are available.

Motor Module

A Motor Module is a power component (DC-AC inverter) that supplies the power for the connected motor(s).

Power is supplied through the → "DC Link" of the → "Drive Unit".

A Motor Module must be connected to a → "Control Unit" via → "DRIVE-CLiQ". The open-loop and closed-loop control functions for the Motor Module are stored in the Control Unit.

→ "Single Motor Module"s and → "Double Motor Module"s are available.

Option Slot

Slot for an optional module (e.g. in the → "Control Unit").

Parameters

Variable quantity within the drive system that the user can read and, in some cases, write.

For → "SINAMICS", all specifications defined in the → "PROFIdrive" profile are defined by a parameter.

See → "Visualization Parameters" and → "Adjustable Parameters".

PROFIBUS

Field bus to IEC 61158, Sections 2 to 6.

The abbreviation "DP" is no longer included because PROFIBUS FMS is not standardized and PROFIBUS PA (for Process Automation) is now part of the "general" → "PROFIBUS".

Sensor Module

Hardware module for evaluating speed/position encoder signals and providing detected actual values as numerical values at a → DRIVE CLiQ Socket".

Three mechanical Sensor Module variants are available:

- SMCxx = Sensor Module Cabinet-Mounted
- SME = Sensor Module Externally Mounted (with a high degree of protection)

Servo Control

For → "Motor"s equipped with a → "Motor Encoder", this control type allows operation with a high level of → "Accuracy" and → "Dynamic Response".

In addition to speed control, position control can also be implemented.

Servo Drive

An electric servo drive comprises a motor, a → "Motor Module", a → "Servo Control" and, in most cases, a speed and position → "Sensor"

Electric servo drives are normally extremely precise and have a high dynamic response.

They are designed for cycle times to less than 100 ms, and often have a short-time overload capacity, which enables quick acceleration. Servo drives are available as rotary and linear drives and are used for machine tools, handling robots, and packaging machines.

SITOP Power

Components for → "Electronics Power Supply".

Example: 24 V DC

Smart Line Module

Unregulated line infeed/feedback unit with a diode bridge for the infeed and stall-protected, line-commutated feedback via → "IGBT"s.

The Smart Line Module supplies the DC link voltage for the → "Motor Module"s.

Status Word

Bit-coded → "Process data" word, transmitted by → "PROFIdrive" at cyclic intervals to control the drive states.

Supply

Input component of a converter system for generating a DC link voltage to supply one or more -> "Motor module"s, including all the required components (e.g. -> "Line module"s, fuses, reactors, line filters, and firmware, as well as proportional computing power (if required) in a -> "Control unit".

Vector Control

Vector control (field-oriented control) is a high-performance control type for induction machines. It is based on an exact model calculation of the motor and two current components that simulate and accurately control the flux and torque by means of software algorithms, thereby enabling predefined speeds and torques to be observed and limited accurately and with a good dynamic response.

Two vector control types exist:

Frequency control (-> "Sensorless Vector Control") and speed-torque control with speed feedback (-> "Sensor").

Index

8

840Di sl, 351

A

Absolute encoders, 185
 Calibration of multiple axes, 187
 Operator-assisted calibration, 185
 Recalibration, 187
Absolute measuring systems
 Parameterization, 149
Acceleration, 161
 Checking, 161
Actual value inversion, 152
Advanced Surface (AS), 208
Assign axis, 116
Assigning actual-value channels, 480
Assigning setpoint channels, 480
Assignment
 General and axis-specific machine data, 114
Automatic servo optimization, 245
 Axis selection, 245
 Controller data overview, 245
 Measurement, 245
 Options, 245
 Park position, 245
 Reconfigure measurement, 245
 Strategy selection, 245
Automation License Manager, 353, 361
Axis
 Monitoring functions, 169
 Parameter sets, 143
 Reference point approach, 178
 Velocity matching, 166
Axis assignment, 473
Axis selection, 245

B

BICO connections on the HMI, 448
Brake behavior OFF3, 241

C

Catalog motor, 83
CF card, 351, 355
Changing the password, 470
Changing topology, 309
Channel axes, 471
Circularity test, 216
Clamping tolerance, 169
CoL, 351, 355
Cold restart, 480
Communication parameters, 363
CompactFlash card, 355
Computational resolution, 122
Contour monitoring, 173
Control direction, 158
Control image (offline), 372
Control mode, 88
Control system (online), 361, 367, 372
 Switchover, 365, 367
Controller data overview, 245
Copy drive object, 301
Current control loop
 Measurement, 220
Customer login, 354
Cycle times, 133

D

Data backup DRIVE-CLiQ motors, 290
DB 31, ...
 DBB16-19, 485
 DBB82-91, 485
 DBX60.0, 485
DB21, ...
 DBX7.7, 485
DDS, 343
Deleting the password, 470
Detailed view, 52
Device configuration, 74
Diagnostics
 System, 41
Direct access, 354
Display resolution, 121, 122
Distance-coded reference marks, 182
Download to target system, 373

- Drift compensation, 165
- Drive components, 445
- Drive object, 445
- Drive states, 335
- Drive wizard, 82
- DSC, 151
- Dynamic monitoring functions, 172
 - Velocity monitoring, 173
- Dynamic servo control, 151

E

- EDS, 343
- Encoder Monitoring
 - Cut-off frequency, 174
 - Cyclic monitoring of position tolerance, 176
 - Position tolerance when switching over the encoder, 175
 - Zero mark monitoring, 175
- Encoder types
 - Absolute measuring system, 149
- Endlessly rotating rotary axis, 153
- EQN 1325, 149
- Ethernet connection, 353
- Exact stop
 - Coarse, 169
 - Fine, 169
- External drive, 258
- External HMI, 15

F

- Factory settings, 101
- Firmware update, 103
- Firmware version drive components, 340
- Firmware version measuring systems, 340
- Function Overview, 360

G

- GEAR_STEP_PC_MAX_VELO_LIMIT, 191
- Geometry axes, 471

H

- Hardware, 351
- Hardware limit switches, 171
- Hardware reference, 356
- Hardware serial number, 352, 355
- Hirth axes, 156

- HMI Advanced, 17, 355, 363
- HMI basic software, 361, 363
- HMI Embedded, 16
- HW Config, 52

I

- Identification of the ALM, 342
- Incremental measuring systems
 - Parameterization, 145
- Indexing axes, 156
- Indexing position tables, 156
- Infeeds, 76
- Input limits, 123
- Input resolution, 121
- Inputs/outputs (HMI function), 35
- Installed components, 361
- Integrated drive, 257
- Interface signals, 49
- Interlock, 469
- Internal HMI, 15, 16
- Internet, 372
- Internet connection, 368
- Interpolation cycle, 135
- Intranet, 368
- Intranet connection, 353
- IP address, 364

J

- JOG axis velocity, 166

K

- Key
 - *, 366
 - F5, 366
- KV factor
 - Definition, 159

L

- LED
 - Fault and status display, 41
- License, 353, 361
- License database, 353, 354
- License information, 355, 367
- License key, 352
- License Key, 356
 - copying, 356
 - SINUMERIK, 356

License number, 351
 License requirement, 367
 Linear axis
 With linear scale, 147
 With rotary encoder on motor, 145
 With rotary encoder on the machine, 146
 Linear measuring system, 147
 Load drive object, 301

M

M70, 484
 Machine axes, 471
 Machine data
 Changing scaling, 128
 Loading of default data, 129
 Normalization of physical quantities, 124
 Manufacturer-specific telegrams, 450
 Max. axis velocity, 166
 MCI board, 351
 MD10002, 474
 MD10050 \$MN_SYSCLOCK_CYCLE_TIME, 137
 MD1061 \$MD_POSCTRL_CYCLE_TIME, 137
 MD1070 \$MD_IPO_SYSCLOCK_TIME_RATIO, 137
 MD1071 \$MD_IPO_CYCLE_TIME, 137
 MD20070, 474
 MD20080, 474
 MD20094, 484
 MD24110, 474
 MD24120, 474
 MD31050, 486
 MD31060, 486
 MD32200, 486
 MD32452, 486
 MD32610, 486
 MD32620, 487
 MD32800, 486
 MD32810, 486
 MD32910, 486
 MD35020, 483
 MD35030, 483
 MD36012, 486
 MD36200, 486
 MDS, 343
 Measurement of autom. servo optimization, 245
 Measurement of speed control loop, 222
 Measuring functions, 216, 217
 Cancel, 218
 Start, 218
 Measuring system switchover
 Interface signals, 480

Menu command
 Connect to target system, 362
 Download to target system, 373
 Edit, 362
 PlugIn SINUMERIK, 362
 Refresh, 366
 Upload from target system, 369
 View, 366
 MMC.INI, 363
 Modular machine, 309
 Modulo axis, 153
 Modulo display, 153
 My Computer, 366

N

NC utilization, 137
 NCK commissioning switch, 39, 42
 NCU 7x0.2
 Interfaces, 29
 LED fault and status display, 41
 Terminal assignment, 31
 NCU 7x0.3
 Interfaces, 30
 LED fault and status display, 41
 Terminal assignment, 31
 New installation
 Classic, 383
 SinuCom Installer, 403
 NX 1x.1
 Terminal assignment, 34
 NX 1x.3
 Terminal assignment, 34

O

Option, 245
 Options for autom. servo optimization, 245
 Overview of functions, 360

P

Parameter sets of the position controller, 143
 Park position, 245
 Peer-to-Peer, 353
 PLC mode selector switch, 39, 42
 Position control loop
 Measurement, 225
 Overshoots, 160
 Reference frequency response, 227
 Setpoint step change, 228
 Step height, 230

Position controller cycle, 133
Positioning accuracy of the control system, 132
Positioning axes, 155
Power on reset, 75
Process data
 Actual values: G1_XACT1, 453
 Actual values: G1_XACT2, 454
 Actual values: G2_XACT1, 454
 Actual values: G2_XACT2, 454
 Actual values: G3_XACT1, 454
 Actual values: G3_XACT2, 454
 Actual values: NACT_A, 453
 Actual values: NACT_B, 453
 Control words: A_STW1, 453
 Control words: STW1, 453
 Control words: STW2, 453
 Control words:G1_STW, 453
 Control words:G2_STW, 453
 Control words:G3_STW, 453
 Setpoints: NSET_A, 453
 Setpoints: NSET_B, 453
 Setpoints: TRQRED, 453
 Setpoints:KPC, 453
 Setpoints:XERR, 453
 Status words: A_ZSW1, 454
 Status words: G1_ZSW, 453
 Status words: G2_ZSW, 454
 Status words: G3_ZSW, 454
 Status words: MELDW, 454
 Status words: ZSW1, 453
 Status words: ZSW2, 453
Process data for receiving, 452
Process data for sending, 453
Product, 352
PROFIBUS connection, 109, 115
PROFIBUS telegram type, 88
Protection levels, 468
 for machine data, 469
 Influence via softkeys, 470
PTP link, 353, 368
Pulse multiplication factor, 192

Q

Quantity structure, 261

R

Ramp-up time, 362
Rapid traverse in the JOG mode, 166
Reference point approach, 178

Reset (warm restart), 72
Resolutions, 121
Rotary axes
 Drive Optimization, 153
Rotary axis
 With rotary encoder on motor, 146
 With rotary encoder on the machine, 147
Rotary measuring system, 145

S

Safe operation, 21
Safety Integrated, 13
Section, 363
Servo gain, 159
 Checking, 160
Servo trace, 216
Setting data
 Normalization of physical quantities, 124
Setting the axis-specific setpoint parameters, 479
Setting the axis-specific setpoint/actual value parameters, 479
Setting the password, 71, 470
Signal distortion, 174
SIMATIC, 361
SIMATIC Manager, 47
 start, 47
SIMATIC S7 project, 49
SinuCom Installer, 403
SinuCom Update Agent, 290
SINUMERIK 840Di sl, 351
SINUMERIK plug-in, 361, 363
 enable/disable, 362
Software limit switches, 171
Software product, 351
Speed adjustment, 241
Speed setpoint matching, 163
Speed setpoint monitoring, 172
Spindle
 Encoder matching, 192
 Gear stages, 191, 194
 Measuring systems, 192
 modes, 483
 Monitoring functions, 201
 Parameter sets, 143, 191
 Positioning, 197
 Setpoint matching, 195
 setpoint/actual value channels, 190
 Synchronization, 199
 Velocities, 194
Spindle data, 204
Standard telegrams, 450

Static monitoring functions, 169
Strategy selection, 245
Switching over the measuring system, 130
System basic cycle, 133
System data, 121
System requirements, 361
System resources, 137
System software SINAMICS S120, 339

T

TCP/IP, 353
Telegram assignment, 435
Telegrams
 Manufacturer-specific, 450
 Standard, 450
Telegrams for receiving, 451
Telegrams for sending, 452
Terminal assignment
 HMI function, inputs/outputs, 35
 HMI support, 35
 NCU 7x0.2, 31
 NCU 7x0.3, 31
 NX 1x.1, 34
 NX 1x.3, 34
Third-party motor, 90
Thread
 Tapping/thread cutting, 143
Toolbox, 28
Topology of individual drive components, 334
Transfer license information
 Drag-and-drop, 372
 using menu commands, 373
Traversing direction, 158
Traversing ranges, 132

U

Upgrade
 Classic, 383
 SinuCom Installer, 408

V

Velocities, 194
 Max. axis velocity, 139
 Max. tool path velocity, 139
 Maximum spindle speed, 139
 Upper limit, 139
 Voltage limit, 140
Velocity monitoring
 Actual, 173

W

Working area limitation, 170

Z

Zero speed tolerance, 169

