

A man in a light blue shirt is seen from the side, looking at a tablet. The background is a blurred industrial setting with a clock on the wall. Overlaid on the image are various digital icons and text elements, including a '24/7' circular arrow icon, a 'NEWS' icon, a 'Home' icon, and a '2017' icon. The overall theme is industrial technology and online support.

SIEMENS

Ingenuity for life

Signaling and Switching via SMS with S7-1200 and CP 1242-7 GPRS V2

S7-1200, CP, SMS

<https://support.industry.siemens.com/cs/ww/en/view/58638283>

Siemens
Industry
Online
Support



Legal information

Use of application examples

Application examples illustrate the solution of automation tasks through an interaction of several components in the form of text, graphics and/or software modules. The application examples are a free service by Siemens AG and/or a subsidiary of Siemens AG ("Siemens"). They are non-binding and make no claim to completeness or functionality regarding configuration and equipment. The application examples merely offer help with typical tasks; they do not constitute customer-specific solutions. You yourself are responsible for the proper and safe operation of the products in accordance with applicable regulations and must also check the function of the respective application example and customize it for your system.

Siemens grants you the non-exclusive, non-sublicensable and non-transferable right to have the application examples used by technically trained personnel. Any change to the application examples is your responsibility. Sharing the application examples with third parties or copying the application examples or excerpts thereof is permitted only in combination with your own products. The application examples are not required to undergo the customary tests and quality inspections of a chargeable product; they may have functional and performance defects as well as errors. It is your responsibility to use them in such a manner that any malfunctions that may occur do not result in property damage or injury to persons.

Disclaimer of liability

Siemens shall not assume any liability, for any legal reason whatsoever, including, without limitation, liability for the usability, availability, completeness and freedom from defects of the application examples as well as for related information, configuration and performance data and any damage caused thereby. This shall not apply in cases of mandatory liability, for example under the German Product Liability Act, or in cases of intent, gross negligence, or culpable loss of life, bodily injury or damage to health, non-compliance with a guarantee, fraudulent non-disclosure of a defect, or culpable breach of material contractual obligations. Claims for damages arising from a breach of material contractual obligations shall however be limited to the foreseeable damage typical of the type of agreement, unless liability arises from intent or gross negligence or is based on loss of life, bodily injury or damage to health. The foregoing provisions do not imply any change in the burden of proof to your detriment. You shall indemnify Siemens against existing or future claims of third parties in this connection except where Siemens is mandatorily liable.

By using the application examples you acknowledge that Siemens cannot be held liable for any damage beyond the liability provisions described.

Other information

Siemens reserves the right to make changes to the application examples at any time without notice. In case of discrepancies between the suggestions in the application examples and other Siemens publications such as catalogs, the content of the other documentation shall have precedence.

The Siemens terms of use (<https://support.industry.siemens.com>) shall also apply.

Security information

Siemens provides products and solutions with Industrial Security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. For additional information on industrial security measures that may be implemented, please visit <https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at: <https://www.siemens.com/industrialsecurity>.

Table of Contents

Legal information	2
1 Task	5
1.1 Overview	5
1.2 Requirements	6
2 Solution	7
2.1 Overview	7
2.2 Description of the core functionality	8
2.3 Overview and description of the user interface	9
2.4 Hardware and software components	14
2.4.1 Validity	14
2.4.2 Components used	14
3 Mode of Operation	16
3.1 Program overview	17
3.2 System block "TC_CONFIG" (FB169)	19
3.2.1 Call and parameter interface of the "TC_CONFIG" FB	19
3.2.2 System data types (SDTs) for the configuration data of the CP 1242-7 GPRS V2	20
3.3 Global data block "DataTcConfig" (DB7)	21
3.4 Global data block "SmsParamDB" (DB1)	22
3.5 Functionality of "SndSms" FB – sending SMS to a recipient	23
3.5.1 Call and parameter interface of the "SndSms" FB	23
3.5.2 Description of the "Sending SMS to a recipient" function	25
3.5.3 "Type_SndParam" PLC data type	26
3.5.4 "TCON_Phone" connection parameter	26
3.6 Functionality of "RcvSms" FB – receiving SMS from a recipient	27
3.6.1 Call and parameter interface of the "RcvSms" FB	27
3.6.2 Description of the "Receiving SMS from a recipient" function	29
3.6.3 "Type_RcvParam" PLC data type	30
3.7 Functionality of the "BroadcastSms" FB – sending SMS to several recipients	32
3.7.1 Call and parameter interface of the "BroadcastSms" FB	33
3.7.2 Call and parameter interface of the "FunctionBroadcast" FC	34
3.7.3 Description of the "Sending SMS to several recipients" function	35
3.7.4 "Type_BroadcastSms" PLC data type	36
3.7.5 "Type_FCBroadcast" PLC data type	37
3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients	38
3.8.1 Call and parameter interface of the "EscalationSms" FB	39
3.8.2 Call and parameter interface of the "FunctionEscalation" FC	40
3.8.3 Description of the "Sending SMS to several recipients with acknowledgment" function	40
3.8.4 "Type_EscalationSms" PLC data type	42
3.8.5 "Type_FCEscalation" PLC data type	43
3.8.6 Functionality of the "SetGet" FB – control and remote request of values	44
3.8.7 Call and parameter interface of the "SetGet" FB	45
3.8.8 Call and parameter interface of the "FunctionSetGet" FC	46
3.8.9 Description of the "Control and remote request of values" function	46
3.8.10 "Type_SetGet" PLC data type	48
3.8.11 "Type_FCSetGet" PLC data type	49
3.9 Status and error displays	50

4	Configuration and Settings of the CP 1242-7 GPRS V2.....	51
5	Installation and Commissioning	54
5.1	Installing the hardware	54
5.2	Installing the software.....	55
5.3	Commissioning	55
5.3.1	Setting the IP addresses	55
5.3.2	Assigning the IP address to the engineering station	55
5.3.3	Adjusting the configuration of the CP 1242-7 V2	56
5.3.4	Loading the station	60
5.3.5	Changing the configuration data of the CP 1242-7 GPRS V2 with TC_CONFIG	61
6	Operating the Application	63
6.1	Overview.....	63
6.1.1	Menu navigation of the HMI	63
6.1.2	"WT_Sms" watch table.....	64
6.2	Sending SMS to several recipients – Broadcast.....	66
6.2.1	Filling level of the coin box exceeds the limit value	66
6.2.2	Cooling system temperature exceeds the limit value.....	68
6.3	Sending SMS to several recipients with acknowledgment – Escalation	70
6.4	Control and remote request of values – SetGet.....	72
6.4.1	Control of receiving SMS commands and sending an acknowledgment to the recipient.....	73
6.4.2	Receiving a remote request of a value and sending the requested value to the recipient	75
7	Appendix	77
7.1	Service and support	77
7.2	Links and literature	78
7.3	Change documentation	78

1 Task

1.1 Overview

Introduction

The application example shows how to send messages to mobile maintenance staff via the TeleControl CP 1242-7 GPRS V2 by means of a simple SMS-based switching and signaling system.

A beverage vending machine shall serve as an exemplary area of application.

Overview of the automation task

The vending machine regularly checks the following:

- Filling level of the coin box
- Cooling system temperature


In addition, any unauthorized opening of the front door is detected by a sensor.

The vending machine automatically responds to certain events such as limit values being exceeded and informs the maintenance staff.

Regardless of this, the vending machine answers incoming process value requests.

The figure below provides an overview of the automation task.

Figure 1-1



1.2 Requirements

This application example is intended to meet the following requirements:

The S7 station

- sends a message to a configured phone number,
- sends a message to a several users (broadcast),
- sends a message with acknowledgement by one of the configured recipients of the message (escalation),
- receives messages (SetGet). Depending on the message text,
 - requested values are read out of the controller and sent to a cellular phone,
 - received commands are executed in the controller and a confirmation/error message is sent to the cellular phone.

Using visualization software, the simulated process shall be operated and controlled in the S7 station.


2 Solution

2.1 Overview

Schematic layout

The figure below shows a schematic overview of the most important components of the solution:

Figure 2-1



Configuration

A CP 1242-7 V2 is used here to connect the S7-1200 CPU to the GSM network.

The "SndSms" and "RcvSms" user blocks are used to send messages via SMS to a GSM-capable mobile terminal using the CP 1242-7 V2 and to receive messages from this terminal. The underlying blocks are called in the "BroadcastSms", "EscalationSms" and "SetGet" user blocks that coordinate that the message is sent to the maintenance staff.

The application is visualized using WinCC Advanced.

Advantages

The solution presented here offers the following advantages:

- The "SndSms", "RcvSms", "BroadcastSms", "EscalationSMS" and "SetGet" user blocks provide you with immediately usable codes.
- The user blocks can also be used for the CP 1243-7 LTE.
- The "SndSms" and "RcvSms" user blocks can be used for your own developments.

Topics not covered by this application

This application does not contain a description of

- SIMATIC NET S7-1200 - TeleControl CP 1242-7 GPRS V2 (see [\3\](#))
- SIMATIC HMI operator panels
- LAD/ FBD/ STL/ SCL programming languages

Basic knowledge of these topics is assumed.

2.2 Description of the core functionality

Functions realized

The following core functions have been realized in the application example:

Table 2-1


Function	Block	Description
Send a message	"SndSms"	Sending a message to a configured phone number.
Receive a message	"RcvSms"	Receiving a message from an authorized phone number.
Broadcast	"BroadcastSms"	Sending a message to several users.
Escalation	"EscalationSms"	Sending a message with acknowledgement by one of the configured recipients of the message.
SetGet	"SetGet"	Receiving messages. Depending on the message text, <ul style="list-style-type: none"> requested values are read out of the controller and sent to a cellular phone, received commands are executed in the controller and a confirmation/error message is sent to the cellular phone.

Note

For a more detailed description of these functions, please refer to [chapter 3](#) and the following chapters.

NOTE

You can start the SMS text with a defined character string (e. g. "*N#" for Vodafone). You will receive an acknowledgement of receipt from your provider when the SMS has arrived at your partner.



2.3 Overview and description of the user interface

The application example is visualized with WinCC Advanced by means of three configured screens called "Broadcast", "Escalation" and "SetGet". The configuration data of the CP 1242-7 V2 is adjusted via the "Configuration" screen.

"Broadcast"

The "Broadcast" screen visualizes the broadcast process.

Figure 2-2

CP1242-7 GPRS V2: Broadcast

Users	Error	Max. FillLevel	FillLevel	Max. Temperature	Temperature	Broadcast
User1: +491712345678	Error1: 00000000	+25	+0	+4	+0	
User2: +491712345678	Error2: 00000000					
User3: +491712345678	Error3: 00000000					
User4: +491712345678	Error4: 00000000					
User5: +491712345678	Error5: 00000000					
User6:	Error6: 00000000					
User7:	Error7: 00000000					
User8:	Error8: 00000000					
User9:	Error9: 00000000					
User10:	Error10: 00000000					

SMS Text: Over Temperature

Buttons: StartScreen, Escalation, SetGet, Configuration

Table 2-2

No.	Element	Description
1.	"Users"	Input field Number of recipients to whom the alarm SMS message is sent.
2.	"Array of Users"	Input fields <ul style="list-style-type: none"> Recipients configured to whom the alarm SMS message is sent. The recipient to whom the alarm SMS message is currently sent is displayed in green.
3.	"Array of Errors"	Display Indicates whether an error has occurred (flashes red).
4.	"SMS Text"	Input field Alarm SMS message which is sent to the recipients.

2 Solution

2.3 Overview and description of the user interface

No.	Element	Description
5.	"Max. FillLevel"	Limit value of the station's filling level. Entered manually by the user. The start value is set to 25 %.
6.	"FillLevel"	Current fill level value of the station
7.	"Max. Temperature"	Limit value of the station's temperature. Entered manually by the user. The start value is set to +4 C.
8.	"Temperature"	Current temperature of the station.
9.	"Broadcast"	Display Indicates whether the process is active (flashes green).
10.	Change screen	Once click on the buttons changes the display of the appropriate screens.

"Escalation"

The "Escalation" screen visualizes the escalation process.

Figure 2-3

The screenshot shows the "CP1242-7 GPRS V2: Escalation" screen. It features a list of 10 users on the left, each with a corresponding phone number field. To the right of the user list is a column of 10 error status fields, each labeled "Error1" through "Error10". Further right is a "Received Acknowledgment" section with a "User" field, a "Date and Time" field (showing "1/1/1970 12:00:00 AM"), and an "Escalation" status field. At the bottom left is an "Alarm Text" field (showing "Alarm101"). At the bottom right are four navigation buttons: "StartScreen", "Broadcast", "SetGet", and "Configuration". Numbered callouts (1-9) point to specific elements: 1 points to the "Users 3" label, 2 points to the first user's phone number, 3 points to the first error status field, 4 points to the "Alarm Text" label, 5 points to the "Received Acknowledgment" label, 6 points to the "User" field, 7 points to the "Date and Time" field, 8 points to the "Escalation" status field, and 9 points to the "Broadcast" button.

2 Solution

2.3 Overview and description of the user interface

Table 2-3

No.	Element	Description
1.	"Users"	Input field Number of recipients to whom the alarm SMS message is sent.
2.	"Array of Users"	Input fields <ul style="list-style-type: none">Recipients configured to whom the alarm SMS message is sent.The recipient to whom the alarm SMS message is currently sent is displayed in green.
3.	"Array of Errors"	Display Indicates whether an error has occurred (flashes red).
4.	"Alarm Text"	Input field Alarm SMS message which is sent to the recipients.
5.	"Received Acknowledgment"	Display Indicates whether an acknowledgment has been received (green).
6.	"User"	Output field Recipient's phone number from which the acknowledgment has been sent.
7.	"Date and Time"	Output field Time stamp of the received acknowledgment.
8.	"Escalation"	Display Indicates whether the process is active (flashes green).
9.	Change screen	One click on the buttons changes the display of the appropriate screens.

"SetGet"

The "SetGet" screen visualizes the SetGet process.

Figure 2-4

Table 2-4

No.	Element	Description
1.	"Array of Orders"	Input fields List of defined queries and commands.
2.	"Array of Values"	Input fields List of attached coefficients.
3.	"Error"	Display Indicates whether an error has occurred (flashes red).
4.	"Status"	Output field Returns the error message.
5.	"Activate SetGet"	Enables the reception of messages (grayed out).
6.	"Deactivate SetGet"	Disables the reception of messages (grayed out).
7.	Change screen	One click on the buttons changes the display of the appropriate screens.

"Configuration"

Via this screen you can adjust the configuration data of the CP 1242-7 V2.

Figure 2-5

CP1242-7 GPRS V2: Configuration

PIN (1) 1234

AccessPointGPRS (2) web.vodafone.de

AccessPointUser (3) guest

AccessPointPassword (4) guest

SMSProvider (5) +491722270000

AuthorizedPhone1 (6) +491712345678

AuthorizedPhone2

AuthorizedPhone3

AuthorizedPhone4

AuthorizedPhone5

AuthorizedPhone6

AuthorizedPhone7

AuthorizedPhone8

AuthorizedPhone9

AuthorizedPhone10

Start Configuration (7)

Broadcast Escalation (8) SetGet

Table 2-5

No.	Element	Description
1.	"PIN"	Input field PIN number of the SIM card created in the CP.
2.	"AccessPointGPRS"	Input field Name of the access point from cellular network to Internet.
3.	"AccessPointUser"	Input field APN user name
4.	"AccessPointPassword"	Input field APN password
5.	"SMSProvider"	Input field User number of the short message service center (SMSC) of the cellular network provider
6.	"AuthorizedPhones"	Input fields List of authorized phone numbers.
7.	"Start Configuration"	Enables the process for changing the configuration data of the CP 1242-7 GPRS V2.
8.	Change screen	One click on the buttons changes the display of the appropriate screens.

2.4 Hardware and software components

2.4.1 Validity

This application is valid for

- CP 1242-7 GPRS V2
- CP 1243-7 LTE
- STEP 7 V15.1 Update 2
- S7-1200 CPU V4.1 or higher

2.4.2 Components used

The application was created using the following components:

Hardware components

Table 2-6

Component	Qty.	Article number	Note
S7-1200 PM1207	1	6EP1332-1SH71	Power supply
SIMATIC S7-1200 CPU 1217C DC/DC/DC	1	6ES7217-1AG40-0XB0	Any S7-1200 CPU as of V4.1 can be used.
COMMUNICATION PROCESSOR CP 1242-7 V2	1	6GK7242-7KX31-0XE0	Alternatively, a CP 1243-7 LTE can also be used: <ul style="list-style-type: none"> • CP 1243-7 LTE EU (6GK7243-7KX30-0XE0) • CP 1243-7 LTE US (6GK7243-7SX30-0XE0)
ANTENNE ANT794-4MR	1	6NH9860-1AA00	GSM quad band and UMTS
SIMATIC memory card	1	6ES7954-8LF01-0AA0	Memory card for the S7-1200 CPU (optional)
SIM card	1		

Software components

Table 2-7

Component	Qty.	Article number	Note
STEP 7 Professional V15.1 Update 2	1	6ES7822-1AA05-0YA5	STEP 7 Basic can also be used.
WinCC Advanced V15.1 Update 2	1	6AV2102-0AA05-0AA5	WinCC Basic can also be used.

Example files and projects

The following list includes all files and projects that are used in this example.

Table 2-8

Component	Note
58638283_S7_1200_SMS_PROJ_V13.zip	This zip file contains the STEP 7 V15.1/ WinCC Advanced project.
58638283_S7_1200_SMS_DOC_V13_en.pdf	This document.

3 Mode of Operation

This application example includes the following key elements:

- The configuration of the S7 station (S7-1200 and CP 1242-7 V2) for sending and receiving SMS messages
- The communication mechanisms in the S7-CPU for sending and receiving SMS messages via the CP 1242-7 GPRS V2:
 - Sending SMS to a recipient
 - Receiving SMS from a recipient
 - Sending SMS to several recipients
 - Sending SMS to several recipients with acknowledgment
 - Receiving SMS commands and a remote request of a value and sending the requested value to the recipient.

3.1 Program overview

The figure below shows the most important elements of the program of the S7 station.

Figure 3-1




Table 3-1

Element	Symbolic name	Description
OB1	Main	Cyclic OB: Calling the user blocks
FB169	TC_CONFIG	System block for changing the configuration data of the CP 1242-7 GPRS V2.
FC1	FunctionBroadcast	Simulation block that checks the filling level of the coin box as well as the current cooling system temperature of the automatic machine and enables the "BroadcastSms" FB, if limit values are exceeded.

3 Mode of Operation

3.1 Program overview

Element	Symbolic name	Description
FB3	BroadcastSms	User block for sending an SMS message to several recipients
FC2	FunctionEscalation	Simulation block that enables the "EscalationSms" FB, if an unauthorized opening of the front of the automatic machine is detected.
FB4	EscalationSms	User block for sending an SMS message to several recipients and subsequent waiting for acknowledgement by one of the configured recipients of the message.
FC3	FunctionSetGet	Command interpreter. It evaluates the output parameters of the "SetGet" FB and sets/resets the HMI parameters.
FB5	SetGet	User block for receiving <ul style="list-style-type: none">• SMS commands and their evaluation• Remote queries of a value.
FB1	SndSms	Basic block for sending an SMS message
FB2	RcvSms	Basic block for receiving an SMS message
FB1030	TSEND_C	Sending data via Ethernet
FB1031	TRCV_C	Receiving data via Ethernet
DB7	DataTcConfig	Global data block for <ul style="list-style-type: none">• summarizing the configuration data that is to be changed• saving the tags for calling the TC_CONFIG in OB1.
DB1	SmsParamDB	Global data block for saving the data: <ul style="list-style-type: none">• Send data• Receive data• Status tags• Trigger signals• HMI tags

Note

Alternatively to the TSEND_C and TRCV_C function blocks, the TCON, TDISCON, TSEND, TRCV communication blocks can be used.

3.2 System block "TC_CONFIG" (FB169)

With the TC_CONFIG program block you can change the parameters of the CP 1242-7 GPRS V2 that are configured in STEP 7:

- PIN number of the SIM card,
- Short message service center (SMSC) of your provider,
- APN settings of your provider,
- authorized phone number.

3.2.1 Call and parameter interface of the "TC_CONFIG" FB

The following figure and table shows the call interface of the "TC_CONFIG" system block.

Figure 3-2




Table 3-2

Name	Data type	Description
REQ	Bool	If there is a rising edge, the processing of the block is started and the status displays are initialized.
INTERFACE	HW_Interface (Word)	Reference to the interface of the local CP.
CONFIG	Variant	Reference to the memory area of the configuration data.
BUSY	Bool	Display of the processing status of the block.
DONE	Bool	The status parameter indicates whether the order has been processed without errors. Only valid for one cycle.
ERROR	Bool	Error display. Only valid for one cycle.
STATUS	Word	Status display (see STEP 7 online help)

3.2.2 System data types (SDTs) for the configuration data of the CP 1242-7 GPRS V2

The CONFIG parameter of the TC_CONFIG program block references to the memory area with the configuration data of the CP 1242-7 GPRS V2 that is to be changed. The configuration data stored in the "DataTcConfig" data block is summarized via various "IF_CONF_xyz" SDTs:

- IF_CONF_Header: Total number of the blocks included in the structure
- IF_CONF_APN: APN settings
- IF_CONF_SMS_Provider: User number of the short message service center (SMSC)
- IF_CONF_PIN: PIN of the SIM card inserted in the CP
- F_CONF_WakeupList: Phone number of the authorized users.

Note

For more information, please refer to the manual of the CP 1242-7 GPRS V2 [\3\](#) and in the FAQ for programming the TC_CONFIG [\4\](#).

3.3 Global data block "DataTcConfig" (DB7)

The "DataTcConfig" DB contains:

- The "tcConfigParam" structure with the created blocks:
 - IF_CONF_Header
 - IF_CONF_APN
 - IF_CONF_SMS_Provider
 - IF_CONF_PIN
 - F_CONF_WakeupList
- The PLC tags for calling the TC_CONFIG in OB1.

Figure 3-3

DataTcConfig				
	Name	Data type	Offset	Start value
1	Static			
2	tcConfigParam	Struct	0.0	
3	Header	IF_CONF_Header	0.0	
4	APN	IF_CONF_APN	6.0	
5	PIN	IF_CONF_Pin	180.0	
6	SMSC	IF_CONF_SMS_Prov...	196.0	
7	AUT_NUMBERS	IF_CONF_WakeupList	224.0	
8	tcConfigTrigger	Bool	470.0	false
9	tcConfigDone	Bool	470.1	false
10	tcConfigBusy	Bool	470.2	false
11	tcConfigError	Bool	470.3	false
12	tcConfigStatus	Word	472.0	16#0
13	posSignalEdge	Bool	474.0	false

3.4 Global data block "SmsParamDB" (DB1)

The "SmsParamDB" DB contains:

- The "Type_SndParam" PLC data type that contains the parameters for sending an SMS message (see [chapter 3.5.3](#)),
- The "Type_RcvParam" PLC data type containing the parameters for receiving an SMS message (see [chapter 3.6.3](#)),
- the "Type_BroadcastSms" PLC data type that contains the parameters for the broadcast process (see [chapter 3.7.4](#)),
- the "Type_EscalationSms" PLC data type containing the parameters for the escalation process (see [chapter 3.8.4](#)),
- the "Type_SetGet" PLC data type containing the parameters for the SetGet process (see [chapter 3.9.4](#)),
- the PLC tags for calling the functions in OB1:
 - PLC tags for calling the blocks in OB1
 - PLC tags for visualizing the process.

Figure 3-4

SmsParamDB		
	Name	Data type
1	Static	
2	sndSmsParam	"Type_SndParam"
3	sndSmsOB1	Bool
4	doneSndOB1	Bool
5	busySndOB1	Bool
6	errorSndOB1	Bool
7	statusSndOB1	DWord
8	rcvSmsParam	"Type_RcvParam"
9	activateRcvSms	Bool
10	ndrRcvOB1	Bool
11	errorRcvOB1	Bool
12	statusRcvOB1	DWord
13	broadcastSms	"Type_BroadcastSms"
14	broadcastFC	"Type_FCBroadcast"
15	escalationSms	"Type_EscalationSms"
16	escalationFC	"Type_FCEscalation"
17	SetGet	"Type_SetGet"
18	SetGetFC	"Type_FCSetGet"

3.5 Functionality of "SndSms" FB – sending SMS to a recipient

Introduction

For sending an SMS message to a recipient via the CP 1242-7 GPRS V2, the "SndSms" FB is used.

3.5.1 Call and parameter interface of the "SndSms" FB

The figure and table below show the call interface of the "SndSms" basic block.

Figure 3-5




Table 3-3

	Name	Data type	Description
input	sndSms	Bool	Starts the send process. Responds only to a positive edge.
InOut	smsParam	"Type_SndSms" PLC data type	Parameters required for sending an SMS message (see chapter 3.5.3).
Output	done	Bool	Set when the send process has been completed successfully. Only valid for one cycle. Default value: FALSE.
	busy	Bool	If the "SndSms" block is busy sending, busy=TRUE is set. "busy" is set to FALSE as soon as the above process has been completed successfully or with an error.

3 Mode of Operation

3.5 Functionality of "SndSms" FB – sending SMS to a recipient

Name		Data type	Description
	error	Bool	Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see chapter 3.10). Only valid for one cycle.

3.5.2 Description of the "Sending SMS to a recipient" function


The following blocks or system data types are required for transmitting SMS messages:

- TSEND_C: Compact block for sending SMS
- TCON_Phone: Connection parameter for transmitting SMS (see [chapter 3.5.4](#))

The "SndSms" block internally calls these blocks.

The figure below shows the program flow of the "Sending SMS to a recipient" function.

Figure 3-6



3.5.3 "Type_SndParam" PLC data type

The "Type_SndParam" PLC data type contains the parameters for sending an SMS message.

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "smsParam" InOut parameter of the function block.

Figure 3-7

	Name	Datentyp
1	interfaceld	HW_ANY
2	conld	CONN_OUC
3	phoneNumber	String[22]
4	smsText	String[160]

Table 3-4

Name	Data type	Description
interfaceld	HW_ANY	Hardware ID of the CP 1242-7 GPRS V2
conld	CONN_OUC	Connection ID
phoneNumber	String[22]	SMS message recipient's phone number
smsText	String[160]	SMS message text

3.5.4 "TCON_Phone" connection parameter

The "TSEND_C" or "TRCV_C" requires the "TCON_Phone" SDT type to transfer SMS messages. The SDT is called in the "SndSms" or "RcvSms" block. The "Interfaceld", "ID" and "PhoneNumber" parameters are linked to the parameters of the "Type_SndParam" or "Type_RcvParam" PLC data type.

Table 3-5

Name	Data type	Description
Interfaceld	HW_ANY	Hardware ID of the CP 1242-7 GPRS V2
ID	CONN_OUC	Connection ID
ConnectionType	Byte	Connection type 14=TCON_Phone
ActiveEstablished	Bool	Active / passive connection establishment
PhoneNumber	String[22]	SMS message recipient's phone number

3.6 Functionality of "RcvSms" FB – receiving SMS from a recipient

Introduction

For receiving an SMS message from a recipient via the CP 1242-7 GPRS V2, the "RcvSms" FB is used.

3.6.1 Call and parameter interface of the "RcvSms" FB

The figure and table below show the call interface of the "RcvSms" basic block.

Figure 3-8




Table 3-6

	Name	Data type	Description
Input	activateRcvSms	Bool	True: enables the reception of SMS messages False: Disables the reception of SMS messages
	smsParam	"Type_RcvParam" " PLC data type	Parameters required for receiving an SMS message (see chapter 3.6.3).
InOut	rcvData	Variant	Structure containing the received data: <ul style="list-style-type: none"> • dateAndTime • rcvTelNo • rcvSms • statusSms

3 Mode of Operation

3.6 Functionality of "RcvSms" FB – receiving SMS from a recipient

Name		Data type	Description
Output	ndr	Bool	Signals that a new SMS message has been received. Only valid for one cycle.
	error	Bool	Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see chapter 3.10). Only valid for one cycle.

Note

Messages can only be received if the "RcvSms" is enabled upon their arrival. Otherwise, the message will be lost. It is not possible to browse the memory subsequently.

3.6.2 Description of the "Receiving SMS from a recipient" function


The following blocks or system data types are required for receiving SMS messages:

- TRCV_C: Compact block for receiving SMS message
- TCON_Phone: Connection parameter for transmitting SMS (see [chapter 3.5.4](#))

The "RcvSms" block internally calls these blocks.

If SMS reception is enabled with "activateRcvSms = True", the communication connection to the CP will be established once and then maintained until it is disconnected with "activateRcvSms = false". Thus, "RcvSms" is ready to receive further SMS messages. The communication connection is disconnected, if the "activateRcvSms" signal is reset.

Figure 3-9





















3.6.3 "Type_RcvParam" PLC data type

The "Type_RcvParam" PLC data type contains the parameters for receiving an SMS message.

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "smsParam" InOut parameter of the function block.

Figure 3-10

	Name	Datentyp
1	 interfaced	HW_ANY
2	 conId	CONN_OUC
3	 phoneNumber	String[22]
4	 ▼ rcvData	Array[1..10] of Struct
5	 ▼ rcvData[1]	Struct
6	 ▸ dateAndTime	DTL
7	 rcvTelNo	String[22]
8	 rcvSms	String[160]
9	 statusSms	Byte
10	 ▸ rcvData[2]	Struct
11	 ▸ rcvData[3]	Struct
12	 ▸ rcvData[4]	Struct
13	 ▸ rcvData[5]	Struct
14	 ▸ rcvData[6]	Struct
15	 ▸ rcvData[7]	Struct
16	 ▸ rcvData[8]	Struct
17	 ▸ rcvData[9]	Struct
18	 ▸ rcvData[10]	Struct

3 Mode of Operation

3.6 Functionality of "RcvSms" FB – receiving SMS from a recipient

Table 3-7


Name	Data type	Description
interfacelId	HW_ANY	Hardware ID of the CP 1242-7 GPRS V2
conId	CONN_OUC	Connection ID
phoneNumber	String[22]	Phone number of the sender Note: <ul style="list-style-type: none">• If you enter an empty string into this parameter, you will receive SMS messages from all authorized phone numbers.• If you enter an asterisk (*) after the phone number base (for example, +4917*) into this parameter, the asterisk will act as a placeholder for all authorized phone numbers with the same phone number base.• If you enter "SMSSTORE" into this parameter, you can output up to 10 received SMS messages from the "RcvSms". The phone numbers authorized for access to the CP can be configured in STEP 7 in the "Security" parameter group of the CP (see chapter 4).
rcvData	Struct	Structure containing the received data: <ul style="list-style-type: none">• dateAndTime: Time stamp of the received SMS message• rcvTelNo: Phone number of the sender of the received SMS message• rcvSms: Received SMS message• statusSMS: Status of the received SMS message

3.7 Functionality of the "BroadcastSms" FB – sending SMS to several recipients

Introduction

For sending an SMS message to several recipients via the CP 1242-7 GPRS V2, the "BroadcastSms" FB is used.

Figure 3-11



3.7.1 Call and parameter interface of the "BroadcastSms" FB

The figure and table below show the call interface of the "BroadcastSms" basic block.

Figure 3-12




Table 3-8

	Name	Data type	Description
Input	activateBroadcast	Bool	Starts sending the SMS message to several recipients (Broadcast). Responds only to a positive edge.
InOut	smsParam	"Type_BroadcastSms" PLC data type	Parameters required for the broadcast process (see chapter 3.7.4).
Output	done	Bool	Set when the broadcast process has been completed successfully. Only valid for one cycle. Default value: FALSE.
	busy	Bool	If the "BroadcastSms" block is busy sending, busy = TRUE. "busy" is set to FALSE as soon as the above process has been completed successfully or with an error.

3.7 Functionality of the "BroadcastSms" FB – sending SMS to several recipients

Name		Data type	Description
	error	Bool	Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see chapter 3.10). Only valid for one cycle.

3.7.2 Call and parameter interface of the "FunctionBroadcast" FC

The figure and table below show the call interface of the "FunctionBroadcast" simulation block.

Figure 3-13




Table 3-9


Name	Data type	Description
ParamBroadcast	Type_FCBroadcast	Parameters required for the broadcast process (see chapter 3.7.5).
smsText	String[160]	Alarm SMS

3.7.3 Description of the "Sending SMS to several recipients" function

The "FunctionBroadcast" FC checks the current filling level of the coin box as well as the current cooling system temperature of the beverage vending machine and enables the "BroadcastSms" FB, if these values exceed the limit values.

The "BroadcastSms" FB sends the "Over FillLevel" or "Over Temperature" alarm SMS to up to 10 recipients. In the "Broadcast" FB, "SndSms" calls (see [chapter 3.5.2](#)) are executed one after another for each configured recipient.

Figure 3-14



3.7.4 "Type_BroadcastSms" PLC data type

The "Type_BroadcastSms" PLC data type contains the parameters for sending an SMS message to several recipients.

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "smsParam" InOut parameter of the function block.

Figure 3-15





	Name	Datentyp
1	 smsParam	"type_SndParam"
2	 usersNo	Int
3	 phoneNumbers	Array[1..10] of String[22]
4	 errors	Array[1..10] of DWord

Table 3-10

Name	Data type	Description
smsParam	"Type_SndParam" PLC data type	Contains the parameters for sending an alarm SMS (see chapter 3.5.3).
usersNo	Int	Number of recipients to whom the alarm SMS message is sent. The maximum value in this example is "10".
phoneNumbers	Array[1..10] of String[22]	Configured recipients to whom the alarm SMS message is sent. Note: <ul style="list-style-type: none"> The number of configured recipients must match the "usersNo". If the "phoneNumber[i], i<=userNo" parameter contains an empty string, the process will be stopped with an error.
errors	Array[1..10] of DWord	Error result (status DWORD) for each "SndSms" call. Thus, it is possible to determine subsequently which messages have been sent and which errors have occurred. Note: The "errors" parameter keeps the values until the next order is started.











3.7.5 "Type_FCBroadcast" PLC data type

The "Type_FCBroadcast" PLC data type contains

- the parameters required for the "FunctionBroadcast" FC simulation block:
 - current filling level of the coin box
 - maximum filling level value of the coin box
 - current cooling system temperature
 - maximum cooling system temperature
- PLC tags for calling the blocks in OB1

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "paramBroadcast" InOut parameter of the "FunctionBroadcast" simulation block.

Figure 3-16


	Name	Data type
1	 fillLevel	Int
2	 overFillLevel	Int
3	 temperature	Int
4	 overTemp	Int
5	 activateBroadcastOB1	Bool
6	 busyBroadcastOB1	Bool
7	 negativeEdgeBusy	Bool
8	 doneBroadcastOB1	Bool
9	 errorBroadcastOB1	Bool
10	 statusBroadcastOB1	DWord

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

Introduction

For sending an SMS message to several recipients and for receiving an acknowledgment from one of the configured recipients of the SMS message via the CP 1242-7 GPRS V2, the "EscalationSms" FB is used.

Figure 3-17



3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.1 Call and parameter interface of the "EscalationSms" FB

The figure and table below show the call interface of the "EscalationSms" basic block.

Figure 3-18




Table 3-11

Name		Data type	Description
Input	activateEscalation	Bool	Starts the escalation process. Responds only to a positive edge.
	smsParam	"Type_EscalationSms" PLC data type	Parameters required for the escalation process (see chapter 3.8.4)
Output	rcvAck	Bool	Signals that an acknowledgment has been received. Only valid for one cycle.
	busy	Bool	If the "EscalationSms" block is busy sending, busy = TRUE. "busy" is set to FALSE as soon as the above process has been completed successfully or with an error.
	error	Bool	Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see chapter 3.10). Only valid for one cycle.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.2 Call and parameter interface of the "FunctionEscalation" FC

The figure and table below show the call interface of the "FunctionEscalation" simulation block.

Figure 3-19




Table 3-12

Name	Data type	Description
ParamEscalation	Type_FCEscalation	Parameters required for the escalation process (see chapter 3.8.5).

3.8.3 Description of the "Sending SMS to several recipients with acknowledgment" function

The "FunctionEscalation" FC enables the "EscalationSms" FB, if unauthorized opening of the front of the beverage vending machine is detected.

The "EscalationSms" FB


- sends the alarm SMS message to the first recipient,
- waits for a configured time for this recipient's acknowledgment SMS message,
- sends the message to the next recipient if no acknowledgment has been received within this time,
- repeats this procedure with up to 10 recipients,
- saves the information of who has acknowledged the alarm SMS message,
- terminates the process with an error if no recipient has acknowledged the alarm SMS message.

It is possible to configure up to 10 recipients.

In the "EscalationSms" FB, the calls "SndSms" and "RcvSms" (see [chapter 3.5.2](#) and [chapter 3.6.2](#)) are successively executed for each configured recipient.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

Figure 3-20



Note

The acknowledgment SMS message must match the outgoing alarm SMS message.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.4 "Type_EscalationSms" PLC data type

The "Type_EscalationSms" PLC data type contains the parameters for the escalation process.

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "smsParam" InOut parameter of the function block.

Figure 3-21






	Name	Datentyp
1	 smsSndParam	"type_SndParam"
2	 smsRcvParam	"type_RcvParam"
3	 usersNo	Int
4	 phoneNumbers	Array[1..10] of String[22]
5	 errors	Array[1..10] of DWord

Table 3-13

Name	Data type	Description
smsSndParam	"Type_SndParam" PLC data type	Contains the parameters for sending the alarm SMS message (see chapter 3.5.3).
smsRcvParam	"Type_RcvParam" PLC data type	Contains the parameters for sending an alarm SMS message (see chapter 3.6.3).
usersNo	Int	Maximum number of recipients to whom the alarm SMS message is sent. The maximum value in this example is "10".
phoneNumbers	Array[1..10] of String[22]	Configured recipients to whom the alarm SMS message is sent. Note: <ul style="list-style-type: none"> The number of configured recipients must match the "usersNo". If the "phoneNumber[i], i<=usersNo" parameter contains an empty string, the process will be stopped with an error.
errors	Array[1..10] of DWord	Error result (status DWord) for each "SndSms" or "RcvSms" call. Thus, it is possible to determine subsequently which messages have been sent and which errors have occurred. Note: The "errors" parameter keeps the values until the next order is started.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients














3.8.5 "Type_FCEscalation" PLC data type

The "Type_FCEscalation" PLC data type contains

- the parameters required for the "FunctionEscalation" FC simulation block,
- PLC tags for calling the blocks in OB1
- PLC tags for visualizing the process.

For commissioning of the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "paramEscalation" InOut parameter of the "FunctionEscalation" simulation block.

Figure 3-22


		Name	Data type
1		frontOn	Bool
2		possitiveEdgeFrontOn	Bool
3		activateEscalationOB1	Bool
4		positEdgeActivateOB1	Bool
5		busyEcalationOB1	Bool
6		negEdgeBusy	Bool
7		errorEscalationOB1	Bool
8		statusEscalationOB1	DWord
9		rcvAckOB1	Bool
10		positEdgeAckOB1	Bool
11		rcvAckHmi	Bool
12		errorEscalationOB2	Bool
13		statusEscalationOB2	DWord

3.8.6 Functionality of the "SetGet" FB – control and remote request of values

Introduction

In the "SetGet" FB, the "Receive control commands" function and the remote request of values are implemented. The FC3 "FunctionSetGet" block is the command interpreter.

Figure 3-23



3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.7 Call and parameter interface of the "SetGet" FB

The figure and table below show the call interface of the "SetGet" basic block.

Figure 3-24




Table 3-14

Name	Data type	Description
activateSetGet	Bool	True: enables the SetGet process False: disables the SetGet process
smsParam	"Type_SetGet" PLC data type	Parameters required for the SetGet process (see chapter 3.9.4).
ndr	Bool	Signals that a new SMS message has been received. Only valid for one cycle.
done	Bool	Set when the send process has been completed successfully. Only valid for one cycle. Default value: FALSE.
busy	Bool	If the "SetGet" block is busy sending, busy = TRUE is set. "busy" is set to FALSE as soon as the above process has been completed successfully or with an error.
error	Bool	Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see chapter 3.10). Only valid for one cycle.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.8 Call and parameter interface of the "FunctionSetGet" FC

The figure and table below show the call interface of the "FunctionSetGet" simulation block.

Figure 3-25




Table 3-15

Name	Data type	Description
OrderNo	Int	Placeholder for the received command or for the received remote request
paramSetGet	Type_FCSetGet	Parameters required for the SetGet process (see chapter 3.9.5).

3.8.9 Description of the "Control and remote request of values" function

With the "SetGet" FB, you can receive

- Commands for setting and resetting signals and
- Requests of values from the process (filling level, temperature).

In addition, it is possible to send the requested values to the recipient.

Commands

- Commands always end with the "=" symbol, for example, "SetM=".
- Commands are answered with "OK", if no error occurs during processing. Signals are controlled by means of the FC3 "FunctionSetGet".
- Commands are answered with the "Unknown Command" string, if the command is unknown.

Remote request of values

- Requests of values always end with the "?" symbol, for example, "Temp?"
- Requests are always answered with the currently stored values, for example, "Temp: 25 C"
- Requests are answered with the "Unknown Command" string, if the request is unknown.


The "SetGet" FB is provided with 3 additional storage locations for incoming SMS messages. If a new request arrives while the block is busy, this request will be stored in one of the storage locations and will be processed later.

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

Note If the SetGet process is disabled, the received requests (max. 3) are buffered and will only be answered when SetGet is enabled.

Note The commands and requests of values must be known to the system. They are stored in a specific data area.
The text of the incoming SMS message must match the known commands / requests.

Figure 3-26



3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients

3.8.10 "Type_SetGet" PLC data type

The "Type_SetGet" PLC data type contains the parameters for the SetGet process. For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "smsParam" InOut parameter of the function block.

Figure 3-27






	Name	Datentyp
1	 smsSndParam	"type_SndParam"
2	 smsRcvParam	"type_RcvParam"
3	 orders	Array[1..10] of String[10]
4	 reiceivedOrders	Array[1..3] of String[10]
5	 sndValues	Array[1..10] of String[10]

Table 3-16

Name	Data type	Description
smsSndParam	"Type_SndParam" PLC data type	Contains the parameters for sending the alarm SMS message (see chapter 3.5.3).
smsRcvParam	"Type_RcvParam" PLC data type	Contains the parameters for sending an alarm SMS message (see chapter 3.6.3).
orders	Array[1..10] of String[10]	List of known commands/requests
receivedOrders	Array[1..3] of String[10]	Data buffer for incoming SMS messages, if the block is busy
sndValues	Array[1..10] of String[10]	List of currently stored values. The value must have the same index as the request of this value, for example: Orders[3]:=Temp? sndValues[3]:=25 C

3.8 Functionality of the "EscalationSms" FB – sending SMS with acknowledgment to several recipients













3.8.11 "Type_FCSetGet" PLC data type

The "Type_FCSetGet" PLC data type contains

- the parameters required for the "FunctionSetGet" FC simulation block,
- PLC tags for calling the blocks in OB1
- PLC tags for visualizing the process.

For commissioning the application, this data type is used in the "SmsParamDB" global data block, which is linked to the "paramSetGet" InOut parameter of the "FunctionSetGet" simulation block.

Figure 3-28

		Name	Data type
1		activateSetGet	Bool
2		ndrSetGetOB1	Bool
3		busySetGetOB1	Bool
4		doneSetGetOB1	Bool
5		errorSetGetOB1	Bool
6		errorSetGetHmi	Bool
7		statusSetGetOB1	DWord
8		statusSetGetHmi	DWord
9		setResetSignalOB1	Bool
10		posSignalEdgeError	Bool
11		posSignalEdgeNdr	Bool
12		negEdgeSetGet	Bool

3.9 Status and error displays

For error diagnostics, the function blocks have a "status" output. By reading the "status" output of the function block, you are provided with information on logical errors and error messages that may occur during communication.

The error message structure is such that the first word indicates the block that triggered this message. For example, error message 16#000180A3 was triggered by TSEND_C. The following tables provide a list of possible error messages.

Table 3-17

Status	Meaning	Remedy / notes
16#0001xyzx	TSEND_C error messages	For a description of the communication errors, please refer to the STEP 7 Online Help.
16#0011xyzx	TRCV_C error messages	
16#00008101	Previous order not yet completed. (You have started a new send operation, although busy was still active.)	
16#00008102	The timer for establishing the connection has expired.	Check the CP connection.
16#00008103	The list of recipient data is incomplete.	Enter the recipient data into the list. Note: If usersNo=5, enter the data for 5 recipients.
16#00008104	The escalation process is complete without acknowledgment.	
16#00008105	Unknown command has been received.	<ul style="list-style-type: none"> Check the list of commands and adjust it Or Send a command / request that is included in the list. Stop the escalation process and restart the SetGet process.

4 Configuration and Settings of the CP 1242-7 GPRS V2



Note The configuration and settings are fully implemented in the project. This chapter is for information only.


In order to ensure that the CP 1242-7 V2 is able to send or to receive SMS messages, you have to


- set the mobile communication,
- make APN settings,
- enter authorized phone numbers.

The table below shows how to configure a S7-1200 station with the CP 1242-7 GPRS V2 for sending/receiving SMS messages.

Table 4-1

No.	Action
1.	Create a STEP 7 V15.1 project.
2.	Add the S7-1200 CPU (as of V4.1) for the SIMATIC station 1.
3.	<p>Add the CP 1242-7 GPRS V2 to the station.</p> 
4.	<p>Activate the online functions and enable S7 communication:</p> <p>"Properties of the CP 1242-7 GPRS V2 > General > Communication types".</p> 

No.	Action
5.	<p>Make the required mobile communication settings: "Properties of the CP 1242-7 GPRS V2 > Mobile wireless communications settings":</p> <ul style="list-style-type: none"> • Enable the PIN number • Enable data services and SMS • Make APN settings / depending on provider 
6.	<p>Activate the global security settings and create a user with "NET Standard" or "NETAdministrator" rights. Then activate the security functions of the CP 1242-7 GPRS V2. "Properties of the CP 1242-7 GPRS V2 > Security".</p>

No.	Action
7.	<p>Enter the authorized phone number for receiving SMS messages. "Properties of the CP 1242-7 GPRS V2 > Security > Authorized phone numbers".</p> 
8.	Load the project data into the station.

5 Installation and Commissioning

5.1 Installing the hardware

The required hardware components are listed in [chapter 2.4.2](#).

Note

Always observe the installation guidelines for all components.

NOTICE

Before you switch on the power supply, complete and check the installation!

The figure below shows the hardware setup of the station: S7-1200 CPU with the CP 1242-7 GPRS V2.

Figure 5-1




Table 5-1

No.	Action
1.	Insert your SIM card into the CP 1242-7 GPRS V2.
2.	Connect the individual modules to a suitable module rack.
3.	Connect the CPU with the CP 1242-7 GPRS V2.
4.	Connect the antenna to the CP 1242-7 GPRS V2.
5.	Connect the engineering PG to the PROFINET interface of the S7-CPU.
6.	Connect the CPU 1217C and the CP 1242-7 GPRS V2 to a 24 V DC power source.
7.	Connect the DC power source to the power grid (220 / 230 V AC).

5.2 Installing the software

Engineering PC / PG

Table 5-2

No.	Action	Remark
1.	Install STEP 7 V15.1 Update 2	Follow the instructions of the installation program.
2.	Install WinCC Advanced.	

Application software

Unzip the "58638283_S7_1200_SMS_PROJ_V13.zip" file. This folder contains the STEP 7 project with the

- "S7-1200_CP1242-7" project and the
- WinCC project "SMS Application".

5.3 Commissioning

5.3.1 Setting the IP addresses

Table 5-3


Module	IP address	Subnet mask
Station CPU 1217C DC/DC/DC	192.168.0.1	255.255.255.0
Engineering PC/PG	192.168.0.100	255.255.255.0
KTP1000 Basic color PN	192.168.0.3	255.255.255.0

5.3.2 Assigning the IP address to the engineering station

The following table shows the network settings to which you have to change the engineering station.

Table 5-4

No.	Action
1.	Open the Internet Protocol (TCP/IP) Properties: "Start > Settings > Network Connections > Local Connections"
2.	In the open window, select the Internet Protocol (TCP/IP) and open Properties.

No.	Action
3.	<p>Select the option box "Use the following IP address" and fill in the box as shown in the figure. Close the dialog boxes with "OK".</p> 
4.	If your PG has an IWLAN interface, disable it.



5.3.3 Adjusting the configuration of the CP 1242-7 V2



To be able to work with the project, you have to adjust the following parameters:

- PIN number of the SIM card
- Short message service center (SMSC) of your provider
- APN settings of your provider
- authorized phone number.

Table 5-5

No.	Action
1.	Unzip the "58638283_S7_1200_SMS_PROJ_V13.zip" project.
2.	Open the STEP 7 V15.1 project "58638283_CP1242-7_SMS_PROJ_V13.ap15_1".

No	Action
3.	<p>Valid until TIA V14 SP1: Enable the security functions of the CP: "CP1242-7_SMS > Global security settings > User login"</p> <div></div> <p>User name: administrator Password: administrator</p> <p>Valid for TIA V15 and higher: While opening the project the following dialog appears:</p> <div></div> <p>Enter the following User data: User name: administrator Password: administrator</p>

No.	Action
4.	Open the Device configuration of the project.
5.	<p>Open the Properties of the CP 1242-7 V2 by double-clicking the CP 1242-7 V2.</p> <ol style="list-style-type: none"> Open "Properties of the CP 1242-7 GPRS V2 > Mobile wireless communications settings" Enable the PIN number ("Enable PIN") and enter the PIN number of your SIM card. Enable data services and SMS. Enter the short message service center (SMSC) of your provider. Enter the APN settings of your provider. 
6.	<p>Enter the authorized phone number for receiving SMS messages. "Properties of the CP 1242-7 GPRS V2 > Security > Authorized phone numbers".</p> 
7.	Save and compile the project.

NOTICE

If you are using the CP in a different location from the sample project, you must adjust the hardware ID in the project.

To do this, open the DB "SmsParamDB" and adjust the hardware ID at the following locations:

CP1242-7_SMS ▶ S7-1200_CP1242-7 [CPU 1217C DC/DC/DC] ▶ Programmbausteine ▶ SmsParamDB [DB1]


SmsParamDB				Remanenz	Erreichbar a...	Sichtbar i...	Einstellwert	Kommentar
1	Static							
2	▼ sndSmsParam	*Type_SndParam*						
3	interfaceId	HW_ANY	269					Hardware identifier
4	phoneNumber	String[22]	"					Connection ID
5	smsText	String[160]	'491'					Phone numbers
6	smsText	String[160]	'test cp1242-7 ...'					Received Data
7	sndSmsOB1	Bool	false					Bit, which activates Snd Sms block
8	doneSndOB1	Bool	false					Done. Signal for one programm cycle active
9	busySndOB1	Bool	false					Block is active
10	errorSndOB1	Bool	false					Error. Signal for one cycle active
11	statusSndOB1	Bool	false					Error Status for one Program cycle active
12	▼ rcvSmsParam	*Type_RcvParam*						Parameter for receiving Sms
13	interfaceId	HW_ANY	269					Hardware identifier
14	phoneNumber	String[22]	'491'					Connection ID
15	phoneNumber	String[22]	'491'					Phone numbers
16	rcvData	Array[1..10] of Struct						Received Data
17	activateRcvSms	Bool	false					Bit, which activates Rcv Sms block
18	ndrRcvOB1	Bool	false					Received new data. Signal for one programm cycle active
19	errorRcvOB1	Bool	false					Error. Signal for one cycle active
20	statusRcvOB1	Bool	false					Error Status for one Program cycle active
21	▼ broadcastSms	*Type_BroadcastSms*						Parameter Broadcast
22	smsParam	*Type_SndParam*						Parameter for sending sms
23	interfaceId	HW_ANY	269					Hardware identifier
24	phoneNumber	String[22]	"					Connection ID
25	smsText	String[160]	'Over Tempera...					Phone number
26	usersNo	Int	1					Sms Text
27	phoneNumbers	Array[1..10] of String						Number of users
28	errors	Array[1..10] of DWORD						Phone numbers
29	broadcastFC	*Type_FCBroadcast*						Errors
30	▼ escalationSms	*Type_EscalationSms*						Parameter Function Broadcast
31	smsSndParam	*Type_SndParam*						Parameter escalation
32	interfaceId	HW_ANY	269					Parameter for sending sms
33	cond	CONN_OUC	4					Hardware identifier
34	phoneNumber	String[22]	"					Connection ID
35	smsText	String[160]	'491'					Phone number
36	smsRcvParam	*Type_RcvParam*						Sms Text
37	interfaceId	HW_ANY	269					Parameter for receiving sms
38	cond	CONN_OUC	5					Hardware identifier
39	phoneNumber	String[22]	"					Connection ID
40	rcvData	Array[1..10] of Struct						Phone numbers
41	usersNo	Int	3					Received Data
42	phoneNumbers	Array[1..10] of String						User number
43	errors	Array[1..10] of DWORD						Phone Numbers
44	▼ SetGet	*Type_SetGet*						Errors
45	smsSndParam	*Type_SndParam*						Parameter Function Escalation
46	interfaceId	HW_ANY	269					Parameter setGet
47	cond	CONN_OUC	6					Parameter for sending sms
48	phoneNumber	String[22]	"					Hardware identifier
49	smsRcvParam	*Type_RcvParam*						Connection ID
50	interfaceId	HW_ANY	269					Phone number
51	cond	CONN_OUC	7					Sms Text
52	phoneNumber	String[22]	"					Parameter for receiving sms
53	rcvData	Array[1..10] of Struct						Hardware identifier
54	usersNo	Int	4					Connection ID

5.3.4 Loading the station

Prerequisites

- There is a connection between your engineering station and the CPU (for example, via PROFINET interface).
- The CPU must be in a mode that allows loading.
- Prior to loading the user program, a general reset of the CPU should be performed to ensure that none of the "old" blocks still exist on the CPU.

Table 5-6

No.	Action
1.	<p>Select the "S7-1200_CP1242-7" station and load the project to the station.</p> 



5.3.5 Changing the configuration data of the CP 1242-7 GPRS V2 with TC_CONFIG

With the TC_CONFIG program block you can change the parameters of the CP 1242-7 GPRS V2 that are configured in STEP 7:

- PIN number of the SIM card
- Short message service center (SMSC) of your provider
- APN settings of your provider
- authorized phone number.

An instruction can be found in the following table.

Table 5-7

No.	Action	
1.	Open the "StartScreen".	
2.	Start the WinCC Advanced simulation by clicking the "Start simulation" icon.	

5 Installation and Commissioning

5.3 Commissioning

No.	Action																																								
3.	<p>Open the "Configuration" screen and change the configuration data of the CP. Start the process by clicking "Start Configuration".</p> <div><p>CP1242-7 GPRS V2: Configuration</p><table><tr><td>PIN</td><td><input type="text" value="1234"/></td><td>AuthorizedPhone1</td><td><input type="text" value="+491712345678"/></td></tr><tr><td>AccessPointGPRS</td><td><input type="text" value="web.vodafone.de"/></td><td>AuthorizedPhone2</td><td><input type="text"/></td></tr><tr><td>AccessPointUser</td><td><input type="text" value="guest"/></td><td>AuthorizedPhone3</td><td><input type="text"/></td></tr><tr><td>AccessPointPassword</td><td><input type="text" value="guest"/></td><td>AuthorizedPhone4</td><td><input type="text"/></td></tr><tr><td>SMSProvider</td><td><input type="text" value="+491722270000"/></td><td>AuthorizedPhone5</td><td><input type="text"/></td></tr><tr><td></td><td></td><td>AuthorizedPhone6</td><td><input type="text"/></td></tr><tr><td></td><td></td><td>AuthorizedPhone7</td><td><input type="text"/></td></tr><tr><td></td><td></td><td>AuthorizedPhone8</td><td><input type="text"/></td></tr><tr><td></td><td></td><td>AuthorizedPhone9</td><td><input type="text"/></td></tr><tr><td></td><td></td><td>AuthorizedPhone10</td><td><input type="text"/></td></tr></table><p>Start Configuration</p></div>	PIN	<input type="text" value="1234"/>	AuthorizedPhone1	<input type="text" value="+491712345678"/>	AccessPointGPRS	<input type="text" value="web.vodafone.de"/>	AuthorizedPhone2	<input type="text"/>	AccessPointUser	<input type="text" value="guest"/>	AuthorizedPhone3	<input type="text"/>	AccessPointPassword	<input type="text" value="guest"/>	AuthorizedPhone4	<input type="text"/>	SMSProvider	<input type="text" value="+491722270000"/>	AuthorizedPhone5	<input type="text"/>			AuthorizedPhone6	<input type="text"/>			AuthorizedPhone7	<input type="text"/>			AuthorizedPhone8	<input type="text"/>			AuthorizedPhone9	<input type="text"/>			AuthorizedPhone10	<input type="text"/>
PIN	<input type="text" value="1234"/>	AuthorizedPhone1	<input type="text" value="+491712345678"/>																																						
AccessPointGPRS	<input type="text" value="web.vodafone.de"/>	AuthorizedPhone2	<input type="text"/>																																						
AccessPointUser	<input type="text" value="guest"/>	AuthorizedPhone3	<input type="text"/>																																						
AccessPointPassword	<input type="text" value="guest"/>	AuthorizedPhone4	<input type="text"/>																																						
SMSProvider	<input type="text" value="+491722270000"/>	AuthorizedPhone5	<input type="text"/>																																						
		AuthorizedPhone6	<input type="text"/>																																						
		AuthorizedPhone7	<input type="text"/>																																						
		AuthorizedPhone8	<input type="text"/>																																						
		AuthorizedPhone9	<input type="text"/>																																						
		AuthorizedPhone10	<input type="text"/>																																						


6 Operating the Application

6.1 Overview

6.1.1 Menu navigation of the HMI

The application is visualized with WinCC Advanced by means of three configured operating screens called "Broadcast", "Escalation" and "SetGet" (see [chapter 2.3](#)).

Figure 6-1



Main menu

The application can be opened via the main menu and toggled between "Broadcast", "Escalation" and "SetGet".

"Broadcast" screen

The "Broadcast" screen visualizes the broadcast process. It can be toggled between "Main menu", "Escalation" and "SetGet".

"Escalation" screen

The "Escalation" screen visualizes the escalation process. It can be toggled between "Main menu", "Broadcast" and "SetGet".

"SetGet" screen

The "SetGet" screen visualizes the SetGet process. It can be toggled between "Main menu", "Broadcast" and "Escalation".

6.1.2 "WT_Sms" watch table

As an alternative to the HMI, you can use the "WT_Sms" table to monitor or control the tags of the "SmsParamDB" data block.

Figure 6-2

1	// Broadcast				
2	"SmsParamDB".broadcastFC.overFillLevel	DEC+/-	25		
3	"SmsParamDB".broadcastFC.overTemp	DEC+/-	4		
4	"SmsParamDB".broadcastFC.fillLevel	DEC+/-	0		
5	"SmsParamDB".broadcastFC.temperature	DEC+/-	0		
6	"SmsParamDB".broadcastFC.activateBroad.	Bool	<input type="checkbox"/> FALSE		
7	"SmsParamDB".broadcastFC.busyBroadcas.	Bool	<input type="checkbox"/> FALSE		
8	// Escalation				
9	"SmsParamDB".escalationFC.frontOn	Bool	<input type="checkbox"/> FALSE		
10	"SmsParamDB".escalationFC.activateEscal.	Bool	<input type="checkbox"/> FALSE		
11	"SmsParamDB".escalationFC.busyEscalation	Bool	<input type="checkbox"/> FALSE		
12	"SmsParamDB".escalationFC.rcvAckHmi	Bool	<input type="checkbox"/> FALSE		
13	// SetGet				
14	"SmsParamDB".SetGetFC.activateSetGet	Bool	<input type="checkbox"/> FALSE		
15	"SmsParamDB".SetGetFC.errorSetGetHmi	Bool	<input type="checkbox"/> FALSE		
16	"SmsParamDB".SetGetFC.statusSetGetHmi	Hex	16#0000_0000		
17	"SmsParamDB".SetGetFC.setResetSignalOB	Bool	<input type="checkbox"/> FALSE		

Table 6-1

Name	Data type	Description
"SmsParamDB".broadcastFC.overFillLevel	Int	Limit value of the filling level of the coin box. Start value: 25 %
"SmsParamDB".broadcastFC.overTemp	Int	Limit value of the cooling system's temperature. Start value: +4°C
"SmsParamDB".broadcastFC.fillLevel	Int	Current filling level value of the coin box
"SmsParamDB".broadcastFC.temperature	Int	Current cooling system temperature
"SmsParamDB".broadcastFC.activateBroadcastOB1	Bool	The broadcast process is automatically enabled by the "FunctionBroadcast" FC, if the current filling level value or temperature exceeds the limit value.
"SmsParamDB".broadcastFC.busyBroadcastOB1	Bool	True: Broadcast process is active.
"SmsParamDB".escalationFC.frontOn	Bool	True: Unauthorized opening of the front of the automatic machine Note: In this example, it is set by the user and automatically reset by the program when the correct acknowledgment has been received.
"SmsParamDB".escalationFC.activateEscalationOB1	Bool	The escalation process is activated automatically by the "FunctionEscalation" FC, if unauthorized opening of the front of the automatic machine is detected.

6 Operating the Application

6.1 Overview




Name	Data type	Description
"SmsParamDB".escalation FC.busyEscalationOB1	Bool	True: Escalation process is active.
"SmsParamDB".escalation FC.rcvAckHmi	Bool	True: An acknowledgement has been received. It remains set to "true" until the next escalation process is activated.
"SmsParamDB".SetGetFC. activateSetGet	Bool	True: Enables the SetGet process False: Disables the SetGet process
"SmsParamDB".SetGetFC. errorSetGetHmi	Bool	True: An error has occurred during the SetGet process. It remains set to "true" until the next SetGet process is activated.
"SmsParamDB".SetGetFC. statusSetGetHmi	DWord	Returns the status to narrow down the cause of the error. Is reset when a new SetGet process is activated.
"SmsParamDB".SetGetFC. setResetSignalOB1	Bool	True: The command "SetM=" has been received. False: The command "ResetM=" has been received.

6.2 Sending SMS to several recipients – Broadcast

The "FunctionBroadcast" FC checks the current filling level of the coin box as well as the current cooling system temperature of the beverage vending machine and enables the broadcast process, if these values exceed the limit values. The following tables provide instructions for this order.




6.2.1 Filling level of the coin box exceeds the limit value

Table 6-2

No.	Action
1.	Open the "StartScreen". 
2.	Start the WinCC Advanced simulation by clicking the "Start simulation" icon. 
3.	Open the "Broadcast" screen and enter the number of recipients ("Users") to whom the SMS message will be sent. 

6 Operating the Application

6.2 Sending SMS to several recipients – Broadcast





No.	Action
4.	<p>Enter the phone numbers of the recipients into the list of recipients ("Users").</p>  <p>Note: The number of recipients you have to enter into the list depends on the number of "Users".</p>
5.	<p>Enter a filling level value which exceeds the "Max. FillLevel" limit value (for example, 30 %).</p> <p>Note: When starting the simulation, the limit value is set to 25 %. You can change this value as needed.</p> 
6.	<p>The broadcast process will be activated automatically and the "Over FillLevel" SMS message will be sent to all configured recipients.</p> 

Note

If the "User[i], i<=Users" parameter contains an empty string, the process will be stopped with the error 16#00008103.



6.2.2 Cooling system temperature exceeds the limit value

Table 6-3

No.	Action
1.	<p>Open the "StartScreen".</p> 
2.	<p>Start the WinCC Advanced simulation by clicking the "Start simulation" icon.</p> 
3.	<p>Open the "Broadcast" screen and enter the number of recipients ("Users") to whom the SMS message will be sent.</p> 
4.	<p>Enter the phone numbers of the recipients into the list of recipients ("Users").</p>  <p>Note: The number of recipients you have to enter into the list depends on the number of "Users".</p>

6 Operating the Application

6.2 Sending SMS to several recipients – Broadcast

No.	Action
5.	<p>Enter a temperature that exceeds the "Max.Temp" limit value (for example, 10 C).</p> <p>Note: When starting the simulation, the limit value is set to +4. You can change this value as needed.</p> 
6.	<p>The broadcast process will be activated automatically and the "Over Temperature" SMS message will be sent to all configured recipients.</p> 

Note

If the "User[i], i<=Users" parameter contains an empty string, the process will be stopped with the error 16#00008103.

6.3 Sending SMS to several recipients with acknowledgment – Escalation





The "FunctionEscalation" FC enables the escalation process, if unauthorized opening of the front of the beverage vending machine is detected. The following table provides instructions for this order.



Table 6-4

No.	Action
1.	Open the "StartScreen". <div data-bbox="922 577 1375 1025"> </div>
2.	Start the WinCC Advanced simulation by clicking the "Start simulation" icon. <div data-bbox="467 1126 1292 1317"> </div>
3.	Open the "Escalation" screen and enter the number of recipients ("Users") to whom the SMS message will be sent. <div data-bbox="467 1395 1276 1541"> </div>
4.	Enter the phone numbers of the recipients into the list of recipients ("Users"). <div data-bbox="467 1619 1276 1865"> </div> <p>Note: The number of recipients you have to enter into the list depends on the number of "Users".</p>

6 Operating the Application

6.3 Sending SMS to several recipients with acknowledgment – Escalation

No.	Action
5.	<p>Enter any alarm text, for example, "Alarm101".</p> 
6.	<p>In the "WT_Sms" watch table, set "SmsParamDB".escalationFC.frontOn.</p> 
7.	<p>The escalation process will be activated automatically and the SMS message will be sent to the first recipient.</p> 
8.	<p>The SMS message has been sent to the second recipient, because no acknowledgment has been received within the time (1 min).</p> 
9.	<p>From your mobile device with the phone number of the second recipient, send an SMS message with the text "Alarm101".</p> <p>Note: The alarm SMS message ("Alarm101") and the acknowledgment SMS message ("Alarm101") must match.</p>

No.	Action
10.	<p>The station receives the acknowledgment from the second recipient, saves the recipient's data, resets the "SmsParamDB".escalationFC.frontOn" and terminates the process.</p> <div data-bbox="469 394 842 748"> <p>Received Acknowledgement</p>  <p>User</p> <p>+49171</p> <p>Date and Time</p> <p>31.05.2016 12:07:45</p> <p>Escalation</p>  </div> <div data-bbox="469 786 1366 853"> <p>// Escalation</p> <p>"SmsParamDB".escalationFC.frontOn Bool FALSE</p> </div>

Note

If no recipient sends an acknowledgment within the configured time, the escalation process will be stopped with the error 16#00008104.

6.4 Control and remote request of values – SetGet

With the "SetGet" FB, you can receive

- Commands for setting and resetting signals and
- Requests of values from the process (filling level, temperature).

In addition, it is possible to send the requested values to the recipient.





The following tables provide instructions for this order.

Note

The SetGet process must not be started when the escalation process is active. If the SetGet process is already active when an acknowledgment is being received, the process will be stopped with the error 16#00008105.





6.4.1 Control of receiving SMS commands and sending an acknowledgment to the recipient

Table 6-5

No.	Action
1.	<p>Open the "StartScreen".</p> 
2.	<p>Start the WinCC Advanced simulation by clicking the "Start simulation" icon.</p> 
3.	<p>Enter any commands into the "Orders" list.</p>  <p>Note: All commands must end with the "=" symbol. Only these commands will be considered by the system.</p>
4.	<p>Enable the "SetGet" process by clicking "Activate SetGet".</p> 





6 Operating the Application

6.4 Control and remote request of values – SetGet

No.	Action
5.	Use your mobile device to send an SMS with one of the entered commands, for example, "SetM=".
6.	<p>The command will be recognized by the system and confirmed with the "OK" string.</p> 
7.	<p>The "SmsParamDB".SetGetFC.setResetSignalOB1 signal is set.</p> 
8.	Use your mobile device to send an SMS with one of the entered commands, for example, "ResetM=".
9.	<p>The command will be recognized by the system and confirmed with the "OK" string.</p> 
10.	<p>The "SmsParamDB".SetGetFC.setResetSignalOB1 signal is reset.</p> 


6.4.2 Receiving a remote request of a value and sending the requested value to the recipient

Table 6-6

No.	Action
1.	<p>Open the "StartScreen".</p> 
2.	<p>Start the WinCC Advanced simulation by clicking the "Start simulation" icon.</p> 
3.	<p>Enter any requests into the "Orders" list.</p>  <p>Note: All requests must end with the "?" symbol. Only these requests will be considered by the system.</p>
4.	<p>Enter the current values matching each request into the "Values" list.</p> 

6 Operating the Application

6.4 Control and remote request of values – SetGet

No.	Action	
5.	Enable the "SetGet" process by clicking "Activate SetGet".	
6.	Send your mobile device an SMS with one of the entered requests, for example, "Temp?".	
7.	The request will be recognized by the system and the current temperature " Temp: 25 C " will be sent to your mobile device.	

7 Appendix

7.1 Service and support

Industry Online Support

Do you have any questions or need assistance?

Siemens Industry Online Support offers round the clock access to our entire service and support know-how and portfolio.

The Industry Online Support is the central address for information about our products, solutions and services.

Product information, manuals, downloads, FAQs, application examples and videos – all information is accessible with just a few mouse clicks:

<https://support.industry.siemens.com>

Technical Support

The Technical Support of Siemens Industry provides you fast and competent support regarding all technical queries with numerous tailor-made offers – ranging from basic support to individual support contracts. Please send queries to Technical Support via Web form:

www.siemens.com/industry/supportrequest

SITRAIN – Training for Industry

We support you with our globally available training courses for industry with practical experience, innovative learning methods and a concept that's tailored to the customer's specific needs.

For more information on our offered trainings and courses, as well as their locations and dates, refer to our web page:

www.siemens.com/sitrain

Service offer

Our range of services includes the following:

- Plant data services
- Spare parts services
- Repair services
- On-site and maintenance services
- Retrofitting and modernization services
- Service programs and contracts

You can find detailed information on our range of services in the service catalog web page:

<https://support.industry.siemens.com/cs/sc>

Industry Online Support app

You will receive optimum support wherever you are with the "Siemens Industry Online Support" app. The app is available for Apple iOS, Android and Windows Phone:

<https://support.industry.siemens.com/cs/ww/en/sc/2067>

7.2 Links and literature

Table 7-1

	Topic
\1\	Siemens Industry Online Support https://support.industry.siemens.com
\2\	Download page of the entry https://support.industry.siemens.com/cs/ww/en/view/58638283
\3\	SIMATIC NET S7-1200 – TeleControl CP 1242-7 GPRS V2 – Operating Instructions https://support.industry.siemens.com/cs/ww/en/view/109476700
\4\	How do you program the TC_CONFIG instruction to change the parameters of a CP 1242-7 configured in STEP 7? https://support.industry.siemens.com/cs/ww/en/view/67396336

7.3 Change documentation

Table 7-2

Version	Date	Modifications
V1.0	07/2016	First version
V1.1	09/2016	TC_CONFIG was added
V1.2	04/2018	Migration to TIA Portal V15 Bugfixing
V1.3	09/2019	Migration to TIA Portal V15.1