SIEMENS

SINUMERIK

SINUMERIK 840D sl SINUMERIK Integrate Create MyConfig - Diff, Expert, Topo

Operating Manual

Preface	
Safety information	1
Installation	2
Create MyConfig - Diff	3
Create MyConfig - Expert	4
Package execution	5
Create MyConfig - Topo	6
Create MyConfig - NcuShare	7
List of abbreviations	Α

Valid for: CMC software V4.7 SP1

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.



WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.



CAUTION

indicates that minor personal injury can result if proper precautions are not taken.

NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:



WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

Introduction

Target group

This manual is intended for machine manufacturers and service technicians.

Benefits

The Create MyConfig engineering software is used by the machine manufacturer to create and run a project for automated commissioning/production of machines with SINUMERIK 840D sl controllers. Even upgrades of those controllers at the end customer can be configured and executed automatically.

Thanks to the modular concept, Create MyConfig enables the automatic series production and the upgrade of different machines of a series with one package.

In contrast to the conventional procedure, individual operations on the machine can be performed faster and with greater ease and reliability.

- The production time for machines with the 840D sl is significantly reduced.
- The upgrade time for end customers is also reduced.
- A high level of reproducibility is achieved through automatic data loading.
- The quality in production and service is improved significantly.
- Lower demands are placed on the expert knowledge of the commissioning engineer.
- A modular data management for modular machines is supported at the machine manufacturer.
- The modular machines are adapted to the flexible SINAMICS topologies.
- The commissioning process is documented in a log file.

The Create MyConfig engineering software comprises the four components Diff, Expert, Topo and Shield.

- Diff is a comparison software and supports you in the provision of modular data.
- Expert is a configuration software and supports you when creating a project. Deployment
 of a project produces an executable package.
- Topo is a topology software and supports you with displaying and/or creating a comparison and/or target topology for commissioning of the SINAMICS drive system.
 With Topo, the axis-drive assignment can also be displayed or configured.
- Shield is the upgrade software and cannot be installed on its own. Deploying the project
 with Expert creates an executable package containing the software component Shield, a
 script, and data. Shield executes the configured instructions when the package is started.

Training

For information about the range of training courses, refer to:

 SITRAIN (<u>www.siemens.com/sitrain</u>) - training courses from Siemens for automation products, systems and solutions

FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support (www.siemens.com/automation/service&support).

SINUMERIK

You can find information on SINUMERIK under the following link: (http://www.siemens.com/sinumerik)

Technical Support

Country-specific telephone numbers for technical support are provided in the Internet under "Contact" (www.siemens.com/automation/service&support).

Table of contents

	Preface		3
1	Safety inf	ormation	11
	1.1	Fundamental safety instructions	11
	1.1.1	General safety instructions	
	1.1.2	Industrial security	
2	Installatio	on	13
	2.1	Overview	13
	2.2	Installation via command line	13
	2.2.1	Structure of the "OPFILE.txt" control file	
	2.2.2	Command line call	
	2.2.3	Modifying installed program parts	
3	Create M	yConfig - Diff	
_	3.1	Safety instructions	
	3.1.1	Fundamental safety instructions	
	3.1.1	General safety instructions	
	3.1.1.2	Industrial security	
	3.2	Introduction	
	3.3	NC data comparison	
	3.3.1	General information about NC data comparison	
	3.3.2	Overview of user interface	
	3.3.2.1	NC data comparison - toolbar	
	3.3.2.2	NC data comparison - overview window	
	3.3.3	Configuration	
	3.3.4	Copying/exporting data from the NC data comparison	
	3.3.5	Pasting/importing data in the NC data comparison	
	3.3.6	Data jobs in the NC data comparison	
	3.3.6.1	Overview	
	3.3.6.2 3.3.6.3	Configuring data jobs	
	3.3.0.3	Executing data tasks	
	3.4	Folder comparison	47
	3.4.1	General information	47
	3.4.2	Overview of user interface	
	3.4.2.1	Folder comparison - toolbar	48
	3.4.2.2	Folder comparison - overview window	
	3.4.3	Changing the column arrangement	53
	3.4.4	Configuration	55
	3.4.5	Copying from the folder comparison	59
	3.5	File comparison	
	3.5.1	General information	
	3.5.2	Overview of user interface	61
	3.5.2.1	File comparison - toolbar	61

	3.5.2.2 3.5.3	File comparison - overview window	66
	3.5.4	Configuration of the automatic file identification	
	3.5.5	Copying from the file comparison	
	3.5.6	Display modes	75
	3.6	Exporting and importing configurations	75
	3.6.1	General information	
	3.6.2	Exporting	
	3.6.3	Import	
	3.7	Command line call	77
	Α	Use of regular expressions in Diff	79
	A.1	General information on regular expressions	
	A.2	Meta characters in the regular expressions	
	A.3	Examples of regular expressions	
4		yConfig - Expert	
	-		
	4.1	Safety instructions	
	4.1.1	Fundamental safety instructions	
	4.1.1.1	General safety instructions	
	4.1.1.2	Industrial security	80
	4.2	Introduction	86
	4.2.1	Overview of the expert user interface	87
	4.2.2	Main menus and toolbars	88
	4.2.3	Source Explorer	
	4.2.4	Converting projects from older CMC versions	92
	4.3	Project folder	92
	4.3.1	Package	
	4.3.2	Dialogs	
	4.3.2.1	Dialog page: Package configuration	
	4.3.2.2	Dialog page: Notes about acknowledgement	
	4.3.2.3	Dialog: Notes on the package	
	4.3.2.4	Dialog page: Archive access	
	4.3.2.5	Dialog page: PCU access	112
	4.3.2.6	Dialog page: NCU access	115
	4.3.2.7	Dialog page: Notes on the Service Platform Industry (GSP)	119
	4.3.2.8	Dialog page: Service Platform Industry (GSP)	121
	4.3.2.9	Dialog: CNC software	126
	4.3.2.10	Dialog: System configuration	131
	4.3.2.11	Dialog: Notes on the topology	141
	4.3.2.12	Dialog: SINAMICS topology	
	4.3.2.13	Dialog: Version display	
	4.3.2.14	Dialog: Notes on the step tree	
	4.3.2.15	Dialog: Step tree	
	4.3.2.16	Dialog page: NCU result	
	4.3.2.17	Dialog: Finish	
	4.3.3	Steps	
	4.3.3.1	Step tree structure	
	4.3.3.2	Step properties	
	4.3.3.3	Edit step tree	
	4.3.3.4	Linking steps	1/5

4.3.3.5 4.3.3.6	NamespaceCreating a step link	
4.4 4.4.1 4.4.2 4.4.3 4.4.4 4.4.5 4.4.6	Component editor Components Execute Delete Copy Change Manipulate	
4.5 4.5.1 4.5.2 4.5.3 4.5.4 4.5.5	Scripting Introduction to scripting Color coding of program elements. Set channel Cross-area access (read) Package variables	
4.5.5 4.5.5.1 4.5.5.2 4.5.5.3 4.5.6 4.5.7	Script variables DO variables System variables Commenting Scripts under dialogs, steps, and manipulation jobs	
4.5.7.1 4.5.7.2 4.5.7.3 4.5.7.4 4.5.7.5	Sections	
4.5.7.6 4.6 4.6.1	Procedures Conversion Rules for adapting the syntax	233
4.7 4.8 4.8.1 4.8.2 4.8.3 4.8.4	Transferring a project/creating a package Cross references Overview Display cross references Search in cross-references Filter according to identifier or object	236 236 237 238
4.9 4.9.1 4.9.2 4.9.2.1 4.9.2.2 4.9.2.3	Password protection Overview Protecting projects and components Access levels Editing a password list Transferring a password list to existing components	240 241 241 242
4.10 4.10.1 4.10.2 4.10.2.1 4.10.2.2	Create MyConfig packages	
4.10.2.3 4.10.3 4.10.3.1 4.10.3.2	Package execution dialogs Executing the package under Linux Introduction Starting package execution under Linux	249 249

4.10.3.3	Executing the package on NCU from the CompactFlash card	250
4.10.3.4	Executing the package on the NCU from the network	
4.10.3.5	Package execution dialogs	252
4.10.4	Reimporting packages	252
4.10.4.1	Overview	
4.10.4.2	Reimport with password protection	
4.11	Command line call	253
4.11.1	Expert	253
4.11.2	Package	256
4.12	SINAMICS device configuration	257
4.12.1	Production of modular machines	
4.12.2	SINAMICS device configuration with Automatic configuration or user-specified topology	258
4.12.3	Drive data generation via "automatic configuration"	
4.12.4	Drive data generation via "user-specified topology"	
4.12.5	Assignment of the drive data using DO variables	
4.12.6	The advantages of using comparison or user-specified topology	
4.12.7	Configuration of the topology with Topo	
4.12.8	Generation of the comparison topology using external software	
4.13	Interface – Step XML	.269
4.13.1	Description Step XML file	
4.13.2	Step xml (USS file)	
4.14	Reference list, system variables	271
4.14.1	System variables - overview	
4.14.2	Package tab.	
4.14.2.1	System variables for the Package tab	
4.14.2.2	Enumeration runtime system - DeployTargets	
4.14.2.3	Enumeration PCU operating system - PcuSystem	
4.14.2.4	System variables for package properties \$Pack	
4.14.3	Dialogs tab	
4.14.3.1	System variables for the Dialogs tab	
4.14.3.2	Enumeration processing modes - ProcessModes	
4.14.3.3	Enumeration message level - InteractLevels	
4.14.3.4	System variables for the Package configuration dialog	
4.14.3.5	System variables for the Notes about acknowledgement dialog	
4.14.3.6	System variables for the Notes on the package dialog	
4.14.3.7	System variables for the Archive access dialog	
4.14.3.8	System variables for the NCU access dialog	
4.14.3.9	System variables for the PCU access dialog	
4.14.3.10	Enumeration, installation modes - Modes	
4.14.3.11	System variables for the CNC software dialog	276
4.14.3.12	NCSources - enumeration, source of the NC data	
4.14.3.13	PlcSources - enumeration, source of the PLC data	
4.14.3.14	SdbSources - enumeration source of the SDB data	
4.14.3.15	DrvSource - enumeration, source of the DRV data	
4.14.3.16	System variables for the System configuration dialog	
4.14.3.17	System variables for the Notes on the topology dialog	
4.14.3.18	System variables for the SINAMICS topology dialog	
4.14.3.19	System variables for the Version view dialog	279
4.14.3.20	System variables for the Notes on the Service Platform Industry (GSP) dialog	280
4.14.3.21	System variables for the Service Platform Industry (GSP) dialog	280

	4.14.3.22	System variables for the Notes on the step tree dialog	280
	4.14.3.23	System variables for the Step tree dialog	280
	4.14.3.24	System variables for the NCU result dialog	281
	4.14.3.25	System variables for the Finish dialog	
	4.14.4	Steps tab	282
	4.14.5	Environment variables	
	4.14.5.1	Enumeration, runtime environments - runtimes	
	4.14.5.2	Environment variables	289
5	Package ex	xecution	291
	5.1	Package execution	291
6	Create My0	Config - Topo	293
	6.1	Safety instructions	293
	6.1.1	Fundamental safety instructions	
	6.1.1.1	General safety instructions	
	6.1.1.2	Industrial security	
	6.2	Introduction	294
	6.3	Overview of user interface	297
	6.3.1	Topo - overview window	
	6.3.2	Topo - menu functions	
	6.4	Topo - operation	300
	6.4.1	Creating a topology	
	6.4.2	Managing modules	
	6.4.3	Manage DO list	
	6.4.4	Comparing topologies	
	6.4.5	Deploy topology	
	6.5	Command line call	312
	6.6	SINAMICS device configuration	314
	6.6.1	Production of modular machines	
	6.6.2	SINAMICS device configuration with Automatic configuration or user-specified topology.	315
	6.6.3	Drive data generation via "automatic configuration"	
	6.6.4	Drive data generation via "user-specified topology"	
	6.6.5	Assignment of the drive data using DO variables	318
	6.6.6	The advantages of using comparison or user-specified topology	321
	6.6.7	Configuration of the topology with Topo	322
	6.6.8	Generation of the comparison topology using external software	323
	6.7	Extended user-specified topology	325
	6.8	Axis-drive assignment	327
	6.9	Interface Topo XML	331
	6.9.1	Example for displaying the wiring using an XML image	331
	6.9.2	Description of the XML structure	333
	6.9.3	XSD for XML-interface	336
7	Create My0	Config - NcuShare	347
	7.1	Introduction	347
	7.1.1	NcuShareService	347
	7.2	Installation	347

	7.2.1	Installation	347
	7.2.2	"Create MyConfig NcuShare" service	347
	7.3	Error checking	348
Α	List of abbreviations		351
	A.1	Abbreviations	351
	Index		353

Safety information

1.1 Fundamental safety instructions

1.1.1 General safety instructions



Risk of death if the safety instructions and remaining risks are not carefully observed

If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur.

- Observe the safety instructions given in the hardware documentation.
- Consider the residual risks for the risk evaluation.

N WARNING

Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

1.1 Fundamental safety instructions

1.1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (http://www.siemens.com/industrialsecurity).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (http://support.automation.siemens.com).

Æ

WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/ or material damage.

- Keep the software up to date.
 You will find relevant information and newsletters at this address (http://support.automation.siemens.com).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
 You will find further information at this address (http://www.siemens.com/ industrialsecurity).
- Make sure that you include all installed products into the holistic industrial security concept.

Installation

2.1 Overview

You have two options for installing the Create MyConfig engineering software and the NcuShareService application on your PC:

- Installation using the installation wizard
 Installing the Create MyConfig setup as usual by running the setup file and by manually working through the setup dialogs.
- Installation via command line
 From version 4.6, it can also be automatically installed without any user interaction.
 An "OPFILE.txt" control file can be transferred as argument when starting the setup.
 The setup process can be preconfigured in this control file. This means that it is no longer necessary to manually work through the setup dialogs. The following chapter describes the option for installation via the command line.

2.2 Installation via command line

2.2.1 Structure of the "OPFILE.txt" control file

The file contains the section data as first entry [SETUPREQUESTS]. A parameter value is then allocated per line.

Comment lines can be started with the "#" character:

Parameter description

Parameters and their possible values are listed in the following table:

Parameter	Description	Example
SetupMode	The "Batch" value must be allocated to the parameter in order to prevent setup dialogs being displayed.	SetupMode=Batch
DestinationDrive (optional)	The target drive where the software should be installed is specified in this parameter. The system drive is used if a value is not entered.	DestinationDrive=C
	This parameter is ignored if CMC components are already installed.	

2.2 Installation via command line

Parameter	Description	Example
DestinationPath (optional)	A path without a specific drive where the software should be installed can be specified in the parameter. A default installation path is used if a value is not entered.	DestinationPath ="\myTools \Create MyConfig 4.7"
	Under a 32-bit Windows operating system, for example, the path is "\Program Files\Siemens\Create MyConfig 4.7."	
	This parameter is ignored if CMC components are already installed.	
Features (optional)	The components to be installed, separated by commas, are listed in this parameter. Possible values include Expert, Topo, Diff and Samples.	Install all components: Features=Expert,Topo,Di ff, Samples
alog when installing manually.	The components correspond to the selection in the setup dialog when installing manually. All of the components are selected if a value is not entered.	Only install "Diff" components: Features=Diff
DeleteSettings (optional)	With this parameter, it is possible to force deletion of settings from a previous installation.	DeleteSettings=1
	If the optional parameter is omitted, the prior settings from a previous installation will be retained.	

Example of the "OPFILE.txt" control file

```
[SETUPREQUESTS]
# Do not display setup dialogs
SetupMode=Batch
# Target drive for installation
DestinationDrive=C
# Target path for installation
DestinationPath="\Program Files\Siemens\Create MyConfig 4.7"
# Component selection for installation
Features=Expert, Topo, Diff, Samples
# Delete settings from previous installation
# (default: DeleteSettings=0)
# DeleteSettings=1
# Installing the NcuShareService
# (default: NcuShareService=1)
# NcuShareService=1
# Selection of the share folder of the NcuShareService
# NcuShareServiceShareFolder=c:\Siemens\NcuShare
```

Note

In addition to the setup file, the commented template "OPFILE.txt" is also stored, which can be adapted and used accordingly.

Example of the "OPFILE.txt" control file for installation with standard settings

[SETUPREQUESTS]
SetupMode=Batch

2.2.2 Command line call

Syntax for the command line call

setup.exe /W /L<Language ID> /V"commandline=\"\"\"-OF:<absolute path \>OPFILE.txt\"\"\""

Options and arguments

Options	Arguments and description	
L	<language id=""></language>	
	The option L (language) indicates the language ID for displaying the language in the dialogs and messages.	
	The language ID does not influence the installed program language.	
	The following arguments are admissible:	
	1031 for German	
	1033 for English	
W	The option does not include any arguments.	
	Setup.exe waits until the installation has been completed, and only then is it closed.	
V	<msiexec (command="" line="" options)=""></msiexec>	
	Parameters can be specified as arguments to call up the Windows Installer. The argument must be specified in double inverted commas.	
	A description of possible parameters can be found under the topic "Msiexec (command line options)" on theInternet (http://technet.microsoft.com/en-en/library/cc759262(v=ws.10).aspx).	

Note

A list of all of the options and additional information can be viewed at the following link:

Command line parameter for setup.exe (<u>https://flexeracommunity.force.com/customer/articles/en_US/INFO/Setup-exe-Command-Line-Parameters</u>)

Example of a call for an English installation and OPFILE.txt in the setup folder

setup.exe /W /L1033 /V"commandline=\"\"\"-OF:OPFILE.txt\"\"\""

2.2 Installation via command line

Example of a call for a German installation and OPFILE.txt with absolute path data

setup.exe /W /L1031 /V"commandline=\"\"\"-OF:D:\mySetupConfiguration \OPFILE.txt\"\"\""

2.2.3 Modifying installed program parts

The individual installed program parts (Diff, Topo, Expert, Samples) can be easily added or removed afterwards.

There are three versions:

Version 1

- 1. If you have installed $\mbox{\sc Windows}\ \mbox{\sc XP}$, in the start menu, select:
 - "Start > Settings > Control Panel > Software".
 - If you have installed Windows 7, select
 - "Programs and functions".
- 2. Then select Create MyConfig 4.7 and click on "Change" or "Change/add".
- 3. Select the program parts that you wish to add or remove.

Version 2

1. Start the "setup.exe" again on the CD.

You then go to the same dialogs, and you can proceed as in version 1.

Version 3

- Use the "OPFILE.txt" control file described above to subsequently add or delete program parts.
 - If, for Features, you specify another configuration, then it is precisely this one that will be installed.
 - If you have already installed "Topo", and you wish to also install "Diff", then the "Features" parameter looks like this: Features=Topo,Diff
 - If instead of the installed Topo, you only wish to have Diff installed, then the "Features" parameter looks like this: Features=Diff

These three versions can be combined. For example, this means you can first use version 1, for a subsequent change, version 3, and later, for a new change, version 2.

Create MyConfig - Diff

3.1 Safety instructions

3.1.1 Fundamental safety instructions

3.1.1.1 General safety instructions

WARNING

Risk of death if the safety instructions and remaining risks are not carefully observed

If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur.

- Observe the safety instructions given in the hardware documentation.
- Consider the residual risks for the risk evaluation.

/ WARNING

Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

3.1.1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (http://www.siemens.com/industrialsecurity).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (http://support.automation.siemens.com).



WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/ or material damage.

- Keep the software up to date.
 You will find relevant information and newsletters at this address (http://support.automation.siemens.com).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
 You will find further information at this address (http://www.siemens.com/industrialsecurity).
- Make sure that you include all installed products into the holistic industrial security concept.

3.2 Introduction

Note

Setup of documentation: Operating Manual / online help

The contents for the **Diff** section are identical in the operating manual and the online help.

Diff is software for displaying and comparing folders, SINUMERIK archives, general files and special files of the SINUMERIK 840D sl control.

With Diff, SINUMERIK archives can also be modified and stored.

Selected data can be exported from SINUMERIK archives or can be imported into SINUMERIK archives and stored.

For data class archives of the SINUMERIK 828D control, unlimited functionality is available.

Diff comprises the following three components:

- NC data comparison → Display and comparison of NC, drive or display data from SINU-(Page 19)
 MERIK archives or files
- Folder comparison → Display and comparison of folders, SINUMERIK archives and (Page 47) archives in ZIP, TGZ and TAR format.
- File comparison → Display and comparison of files.
 (Page 60)

These three components can be called individually and any number of times in the application and are each displayed as a tab card. Diff can be used to support the configuration of packages with Expert, and independent of Expert, as standard comparison software. In all three components, the opened archive, folder or files can be edited.

The data determined with Diff is provided in such a way that it can be incorporated into a project directly.

The advantage of Diff that makes it so unique is the fact that it can process SINUMERIK archives in the PC or punched tape format and special SINUMERIK files and SINUMERIK data structures.

Diff shows NC and drive data in a structured fashion in an NC data comparison.

3.3 NC data comparison

3.3.1 General information about NC data comparison.

Any number of comparison objects (SINUMERIK archives or Sub files) can be imported, displayed and compared in an NC data comparison.

The comparison is realized at the data level.

The NC data comparison supports the comparison of the following objects:

- SINUMERIK archives in the PC format
- Drive archives in ASCII and ACX format
- NC/drive/display data files (INI, OPT, TEA...) in ASCII format
- Data nodes within a comparison object.

The NC data comparison extracts the NC, drive, and display data from the SINUMERIK archives and displays these in a structured fashion.

Unlike file comparison involving INI files, data is not compared line by line, but according to its identifiers. If the same identifiers occur a multiple number of times, these are only displayed once and the value of the last one that was imported is used.

The data comparison can be performed between different objects opened for comparison, but also within one object (selective).

The comparison result is prepared in a structured fashion.

Data from the objects being compared can be copied to the clipboard and then used in other applications (Expert, ...).

It is possible to remove or insert identifiers and change the values of existing identifiers in the "Selective" comparison mode.

Diff permits the user to resave an open SINUMERIK archive with modified data as SINUMERIK archive.


Note

In an NC data comparison, Diff always displays the data contained in the comparison object if no settings were made in the comparison configuration to exclude data (Expert list or filter).

For SINAMICS drive data, there are parameters (r or p) that can be displayed online on the HMI. However, they are not part of an archive and therefore cannot be displayed by Diff.

3.3.2 Overview of user interface

3.3.2.1 NC data comparison - toolbar



- New NC data comparison
- 2 New folder comparison
- 3 New file comparison
- 4 Update comparison
- 5 Display/save HTML/XML protocol
- 6 Comparison configuration
- 7 Copy / Insert
- 8 Go to the previous or next difference.
- Different / The same / Not available in all comparison objects
- ① Changed only
- (1) Search functions
- ② Select archive or file for NC data comparison / Close archive or file / Save as
- Create archive from control system / read into control system
- (4) List of opened comparison objects
- (5) Switch between opened comparisons via tab

Description of buttons/fields of the toolbar

The buttons of the toolbar are described in more detail below.

① New NC data comparison

Open a new NC data comparison.

② New folder comparison

Open a new folder comparison.

③ New file comparison

Open a new file comparison.

4 Update comparison

The button for updating the comparison is always shown in color if the displayed comparison result is not a current result and the comparison should be restarted using this button.

Note

Depending on the comparison situation, the comparison is automatically started by Diff in some cases.

⑤ Display/save HTML/XML protocol

Using this button, the comparison result of the node selected in the data structure (see NC data comparison - Overview window (Page 23): position numbers ① and ②) is displayed in the standard browser (Internet Explorer).

The result can be saved either as an HTML or XML report.

It can be output complete with expanded fields or as it is shown in the display.

6 Comparison configuration

Using this button, a comparison configuration can be changed or a different comparison configuration can be selected (see sectionConfiguration (Page 26)).

6 Copy / Insert

Buttons for copying and inserting (selective mode) selected values of one or more comparison objects (see section Copying/exporting of data from the NC data comparison).

6 Go to the previous or next difference.

The differences in direction, forward or backward, can be displayed here.

6 Different / The same / Not available in all comparison objects

The differing and identical parts of the comparison result or parts that are not available in all comparison objects can be hidden or displayed via these buttons.

6 Changed only

The display can be reduced to just show the modified values when activated using this button. This selection acts in addition to the display restrictions selected using button group (a) and those defined by the comparison configuration.

6 Search functions

This group contains:

- a button for opening a dialog box in which the search options can be defined
- an edit box for searching for character strings in selected nodes
- buttons for searching upward and downward.
- Search down
- Search up

Selecting comparison objects

- Select archive or file for NC data comparison
- The last opened archives or files are listed.
- x Close archive or file.
- Button to save a modified archive.
- 6 Create online archive from control system / read into control system
- Load archive from the control
- Load archive into the control

6 List of opened comparison objects

As many objects as required can be opened for comparison.

The number at the beginning of the line is used to identify the comparison object, e.g. in the column header (see NC data comparison - overview window (Page 23): the area at position number (8).

Note


Modified archives that have not been saved are assigned an asterisk "*" in list ①.

6 Switch between opened comparisons

Using the tab you can toggle between the opened comparisons with a mouse click or by simultaneously pressing "Ctrl" and "Tab".

3.3.2.2 NC data comparison - overview window

Below is an overview of the functions in the NC data comparison window.



- 1 Normal tab
- Selective tab
- 3 Display result: Different / The same / Not available in all comparison objects
- 4 Expert list and Filter functions
- 5 Display of the comparison configuration
- 6 Context menu
- A brief description of the selected parameter is displayed in the text area with yellow background.
- 8 Result from the Normal tab / Selective tab
- Status bar
- 10 Short designation of data end node:

- (1) Behind the node names "Machine data" and "SINAMICS", the NCK and SINAMICS version is displayed from which the data originate.
- Axis-drive assignment

Description of the areas/functionalities in the NC data comparison window

The individual functionalities of the NC data comparison are described in more detail below:

1 Normal tab

In this area, the data nodes of the comparison objects are shown in a tree structure in the comparison mode "Normal" or in the comparison mode "Selective".

In the "Normal" comparison mode, the data structures of all comparison objects (archives, files) are placed one on top of the other and the comparison result is visualized using special node symbols.

For example, the NC data of axis 1 (AX1) are always compared with the data of axis 1 or the data of drive object 2 (DO2) compared with the data of drive object 2 of another archive.

The data structure is formed from all of the data end nodes involved in the comparison of the objects.

In this mode, the end nodes of all comparison objects that are located within the selected folder are compared with one another.

- The equal character in the area node indicates that the data of the objects being compared is identical below this area node.
- The unequal character in the area node indicates that not all of the data of the objects being compared is identical below this area node.
- The equal character in the end node indicates that the data of the objects being compared is identical within this end node.
- The unequal character in the end node indicates that not all of the data of the objects being compared is identical within this end node.

The values specified in brackets after a data node specify how many identifiers of a node are displayed and how many identifiers there are in a node.

Examples:

➡ MN (1173) This node contains 1173 identifiers and they are all displayed.

This node contains 1173 identifiers, and as a result of the Expert list or the filter, only 1086 identifiers are displayed.

1 Selective tab

In this area, the data nodes of the comparison objects are shown in a tree structure in the comparison mode "Normal" or in the comparison mode "Selective".

In the "Selective" comparison mode, the data structures of all comparison objects (archives, files) are placed one below the other - the structure is separately established for every comparison object.

Contrary to the "Normal" comparison mode, in the "Selective" comparison mode, all data end nodes of the same type can be compared with one another as required.

The data, which should be compared with one another, is selected by activating the end nodes.

① Display result: Different / The same / Not available in all comparison objects

These values provide information as to how many identifiers in the comparison results have unequal (red) or equal (black) values or which values do not exist in all comparison objects (blue/green arrows).

4 Expert list and Filter functions

If the functions "Expert list" and "Filter" are active in the comparison configuration, the relevant symbols will be displayed.

With a double click, the expert list or filter in the comparison configuration is opened.

Note

Using "Expert list" and "Filter," non-relevant identifiers can be excluded from the comparison, so that these are no longer displayed.

① Display of the comparison configuration

The comparison configuration that is being used in the actual comparison is displayed in this field.

The comparison configuration is opened with a double-click.

1) Result from the Normal tab / Selective tab

The data of the nodes selected in areas ① and ② is prepared in a tabular form in this area of the user interface.

The identifiers are listed in the column to the far left, and in all of the additional columns, the associated values of the individual comparison objects (archives, nodes).

The comparison results are color-coded to make it easier to interpret the results:

Identifiers shown in **black** indicate that all values of the comparison object for this particular identifier are the same.

Identifiers shown in **red** indicate that not all values of the comparison object for this particular identifier are the same.


Values shown in **blue** are values that the user changed in the "Selective" mode.

The number as prefix in the column header of the values defines the comparison object (archive, file) to which these values belong.

100 Data end node - short designator


The data end nodes have a code that defines the data area from which the data originated.

For SINAMICS data, the following information is contained in the node designation.



Axis-drive assignment

Axis-drive assignment of the selected drive object or the selected axis.



This information can only be completely displayed for archives that contain both NC data as well as drive data.


3.3.3 Configuration

NC data comparison

You can call the dialog for configuration of the NC data comparison via the "Comparison configuration" button . You can manage the different comparison configurations (i.e. create, edit, delete, etc.) in the dialog box.

In a comparison configuration, all of the criteria that should be taken into account when comparing NC data can be defined.

You can also export or import configurations, for example, to make them available to other users (see Exporting and importing configurations (Page 75)).



- 1 List of the available comparison configurations
- ② Buttons for managing the configurations
- 3 The properties that belong to the selected configuration are saved in this area of the configuration dialog; these properties include display criteria, filter criteria and a comment.
- 4 Background color

① List of the available comparison configurations

The existing comparison configurations are listed in this area of the configuration dialog and can be selected by clicking on them.

Configurations shown in gray are user-specified configurations; these can be changed, but not deleted - and can be restored again at any time.

① Buttons for managing the configurations

Configurations can be managed using these buttons.

Using "Add", a new configuration is generated which can also be adapted.

A copy of the selected comparison configuration is created by clicking "Duplicate".

With "Restore user-specified setting", the changes to the specified comparison configuration are undone.

Note

The "Restore user-specified setting" button is only active if a user-specified configuration has been selected the contents of which are no longer the same as the default setting.

In addition to restoring the default setting, this button can also be used to check whether the contents are identical with those of the default setting.

1 Background color

So that the user can immediately recognize how to select certain comparison configurations, a separate background color can be defined for each comparison configuration.

Display tab

Under the "Display" tab, you can define which main nodes should be displayed in the data structure tree, assuming that data is available in the comparison object (archive or file) for this main node. Further, you can define whether the data should be sorted in alphabetic order or similar to that used in an NC in the data list.


Expert list tab

Using the "Expert list" tab, you can specify a (large) number of identifiers that should either be included or excluded for the comparison.

Contrary to the functionality for filters, the identifiers must be completely specified. The only exception is the field data in the identifier.

Example:

An entry "\$MA_CTRLOUT_NR[0]" in an inclusion list precisely includes this identifier. An entry "\$MA_CTRLOUT_NR" in an inclusion list includes all identifiers that belong to this field, i.e. "\$MA_CTRLOUT_NR[0]" and "\$MA_CTRLOUT_NR[1]".



- ① Using the expert list
- 2 Import... button
- 3 Extracting identifiers button
- 4 Combining indices button
- (5) Including/excluding data with identifiers
- 6 Field listing the identifiers

① Use expert list

The use of an expert list can be activated by selecting "Use expert list".

Note

If an expert list is active, then all of the identifiers that have been filtered-out are not compared and are also no longer displayed. The following symbol a papears in the status bar.

② Import...

Identifiers can be imported from a file using this button.

1 Extracting identifiers

If identifiers were imported via the clipboard or a file, then values or additional information that are not identifiers can be included.

Identifiers can be extracted from the imported characters using this button.

The "Extract identifiers" function also removes the field data at the identifiers and eliminates identifiers that occur more than once in the list.

4 Combining indices

This button can be used to combine indexed machine data to form global machine data:

 $MN_AXCONF_MACHAX_NAME_TAB[3] \rightarrow MN_AXCONF_MACHAX_NAME_TAB$

1) Include/exclude data with identifiers

You can define as to whether the listed identifiers and their data are included or excluded when making the comparison.

6 Field list of the identifiers


The identifiers involved are displayed in this field. There may only be one identifier in each line.

The identifiers can also be imported via the clipboard or using the import function.

Filter tab

Using filters, identifiers can be included or excluded for the comparison by identifying matching characters.

The filters are applied to the identifiers and their (block) number. The function is not casesensitive.



- Activate filter
- ② Define filters, as character string or regular expression
- 3 Filter entries can be created, edited and deleted via the context menu.
- 4 Every filter entry can be individually activated or deactivated.

1 Activate filter

By selecting "Include/exclude data with block numbers or identifiers by way of a filter", the functionality of the inclusion and exclusion filter is activated.

Note

If a filter is active, then all of the identifiers that have been filtered-out are not displayed and are also not compared. The filter symbol γ appears in the status bar.

2 Define filter, as character stringor regular expression

Interpret filter as:

You can define whether the filter should be interpreted as **String** or **Regular expression** (see Use of regular expressions in Diff (Page 79)).

Generally, the filters do not describe complete identifiers, but distinct character strings of the identifier which are sufficient to clearly identify the required quantity of identifiers.

3 Activate or deactivate an exclusion filter

Every filter entry can be individually activated or deactivated.

Example of a filter:


SAFE

This filter describes all identifiers that contain the specified character string.

Generally, these are all of the safety data such as \$MA SAFE IS ROT AX, \$MA SAFE SINGLE ENC, etc.

Value range tab

In the Value range tab, the value-based comparison of floating point numbers is displayed at significant points.



Floating point numbers are saved separately and internally in the computer in mantissa and exponent.

The exponent is adapted in such a way that the mantissa is normalized, i.e. in the range of $1 \le m \le 10$.

The maximum possible number of significant digits is thus 7 for floating values and 15 for double values.

Other inaccuracies can occur as a result of parameter calculations, which can be consciously ignored during the comparison.

When the comparison algorithm is activated, the difference of the values is normalized via the absolute value of the values. If this is then less than the specified significant digit (the mantissa), the values are considered equal.

Comment tab

Any comments on the selected comparison configuration can be saved under the Comment tab.

3.3.4 Copying/exporting data from the NC data comparison

In the NC data comparison, data identifiers and the associated values can be copied to the clipboard or exported to a file.

For instance, the copied or exported data can be used in manipulation jobs of Expert, in Excel for documentation, in another software application or where relevant, also in an NC data comparison in Diff.

In the NC data comparison, depending on the data marking, there are two different copy and/ or export formats "Value assignment" and "Value table".


Copy/export format - "Value assignment"

For the copy/export format "Value assignment", data is extracted in the form "identifier=value". This means that data is extracted with unique, fully qualified identifiers, a value for each identifier as well as information about the source data area - and are saved in a form that can be directly used in manipulation jobs of Expert.

This type of copy and export is the most frequently used type.

To copy or export data, the values must be selected in the value column as shown below.

Example 1: Copying of SINAMICS data



Using the context menu entries "Copy" or "Data Export to File", you can transfer the selected values and their identifiers to the clipboard or to a file.


For the selection shown, the following content is obtained for the clipboard or file:

```
[B3_S3_PS3] ;V2.40.43.00
p45=1
p100=0
p105=1
```

A section with the information about the data source is provided in the first line. This information is saved in a format that is in conformance with Expert, so that it can be used in a manipulation jobs as "Data target" for the following values. The SINAMICS version – from which the following data comes – is saved after the section, separated by a semicolon.

The value assignments in the form identifier=value are located in lines 2 to n.

Example 2: Copying NC axis machine data



For the selection shown, the following content is obtained for the clipboard or file:

```
CHANDATA(1)
N32000 $MA_MAX_AX_VELO[AX6]=8000
N32010 $MA_JOG_VELO_RAPID[AX6]=8000
N32020 $MA_JOG_VELO[AX6]=550
N32060 $MA_POS_AX_VELO[AX6]=8000
```

The identifiers extracted by Diff are fully qualified, i.e. they again include the definition of the axis to which the data belongs.

Note


CHANDATA(1) is also automatically added for channel-independent data as this guarantees that a previous channel assignment greater than 1 is reset again.

Channel-independent data must not be located below a CHANDATA operation greater than 1.

Copy/export format "Value table"

For the copy/export format "Value table", data is extracted in tabular form. This means that all selected identifiers are saved in the first column, and in the additional columns, the value of the particular comparison object (archive, file or node).

To copy or export data in this form, the identifiers in the Identifier column must be selected, as shown in the following example.



For the selection shown, the following content is obtained for the clipboard (to insert in Excel) or file:

Identifier	1 DO3 (3.3.3 SERVO 11)	2 DO3 (3.3.3 SERVO 11)
P125	1	1
p130	1	1
r131 [0]	22	19
p139 [0]	0	0
p139 [1]	0	0
p139 [2]	0	0
p140	2	2
p141 [0]	20	17
p141 [1]	0	0
p142 [0]	21	18
p142 [1]	0	0

3.3.5 Pasting/importing data in the NC data comparison

Introduction


In the NC data comparison, data from the clipboard can be pasted or imported from a file. This function is **only** available in the "Selective" comparison mode and only for SINUMERIK archives (not INI/TEA files...).

The data must be in the clipboard or in a file in the form "identifier=value" (copy/export format, "Value assignment").

Note

The copy/export format "Value table" from Diff is **not** supported for paste/import.

Using the context menu it is possible to paste/import data to a value column ②.



When pasting/importing data, Diff searches the identifiers contained in the clipboard/file in the data nodes ① selected in the value column ② and pastes the "new" value for the identifiers found.


Note

If the number of values ③ selected in value column ② is equal to the value contained in the clipboard/file, then the selected values are overwritten and the identifiers are no longer taken into consideration.

When pasting into data nodes ① the values are always pasted, taking into consideration the identifiers.

"Preview pasting" dialog

To show what the result of pasting or importing values will be before values are actually pasted or imported, Diff displays a "Preview pasting" dialog.



The following information is shown in the dialog:

- This dialog box lists all of the identifiers with the old and new values that are to be pasted. If, as a result of the new value, the value changes with respect to the old value, then the new value is shown in blue.
- If no identifiers (i.e. no old values) could be found for the values to be pasted, or if there are format problems, this is also shown in the dialog.

After pasting or importing values, changed values are identified in Diff in blue and the path of the comparison object (archive) is identified in the list of opened comparison objects using an asterisk "*". The "Save" button is still active for the comparison object.

3.3.6 Data jobs in the NC data comparison

3.3.6.1 Overview

In the NC data comparison, using data tasks, data can be converted, imported and exported. A configuration and an Excel template belong to a data task.

3.3 NC data comparison

Supplementary conditions for data tasks

- Data tasks are only available in the "Selective" comparison mode.
- Data tasks can only be applied to data end nodes.

Application examples for data tasks

- Importing encoder data.
 Encoder data saved in an Excel file (template) can be imported into an archive.
- Exporting optimization data.
 For the identifiers of optimization data saved in an Excel template, values can be added and saved as Excel file.

Principle of operation of import tasks

When executing import tasks, values are imported into the clipboard from the "Import area" of an Excel template.

In Diff, these values can be inserted at a data end node. When inserting values, only the values of existing identifiers can be overwritten. Diff cannot insert any new identifiers in an archive.

Principle of operation of export tasks

When executing export tasks, data identifiers are determined in an "Export area" of an Excel template. These identifiers are searched for in a selected data end node in the data structure of the NC data comparison and their values are transferred into an Excel template.

The "Save As" dialog allows the completed Excel template to be saved.

The "Save As" dialog is displayed, which allows the completed Excel template to be saved.

Principle of operation of conversion tasks

When executing conversion tasks, data identifiers are determined from an "Export area" of an Excel template. These identifiers are searched for in a selected data end node in the data structure of the NC data comparison and their values are transferred to an Excel template. The conversion rule saved in the same Excel template is processed by Excel without any visualization. In so doing, values are generated for the saved import identifiers and these are then imported to Diff from the "Import area". The imported values are saved in the clipboard, and can be inserted into Diff at a data end node.

When inserting values, only the values of existing identifiers can be overwritten. Diff cannot insert any new identifiers in an archive.


The Excel file with the converted data can be saved.

3.3.6.2 Configuring data jobs

You can call the dialog to configure data tasks via the main menu "Tools > NC Data Comparison > Configure Data Task".

The dialog to configure data tasks is equivalent to the dialog for the comparison configuration and should be used in the same way.

You can also export or import configurations, for instance, to provide them to other users (see Exporting and importing configurations (Page 75)).



Task type tab


Under the "Task type" tab, you can define whether a data task involves "Data conversion", "Data export" or "Data import".

3.3 NC data comparison

Template tab

You can store an Excel template under the "Template" tab for the selected data task. This is required for the data conversion, but also for the data import and the data export. Diff saves this template as a fixed component of the configuration.


If a template is not saved under this tab, then when executing the data task, Diff requests a template to be specified via an "Open file" dialog. It makes sense not to save a template, if Diff should not operate with a fixed template, but instead with an external template, which is assigned during the package execution.



- ① This inscription indicates that an Excel template is available in the configuration.
- ② In this field, the name and the date of the file are displayed, which should be used as Excel template.
- 3 Using these buttons, it is possible to
 - Import a file as template in the configuration
 - Export the configuration, contained in the template, as file
 - Remove the template saved in the configuration
 - Display the template contained in the configuration using Excel.

Export tab

The export area of the identifiers and values are specified in the Excel template under the "Export" tab.




Further, a node type in the data structure tree must be specified under this tab. An export or conversion task can only be started at this node type.

The node type should be selected that belongs to the data to be exported.

Import tab

The import area of the identifiers and values are specified in the Excel template under the "Import" tab.



In addition, only a node type in the data structure tree must be specified for an import task under this tab. An import task can only be started at this node type. The node type should be selected that belongs to the data to be imported.

Note


For a conversion task, the selection of the node type under the "Import" tab has no functional significance and cannot be selected. The node type always specifies the node on which a task is started.

Description tab

A description of the configured data task can be saved under the "Description" tab.

3.3 NC data comparison

The description is displayed in the data task wizard when the "Display description when executed" checkbox is activated.



3.3.6.3 Executing data tasks

Configured data tasks can be executed using a data task wizard.


You can start a data task using the context menu at a selected data end node in the selective mode of the NC data comparison.

The data tasks shown in gray in the task list are not permitted at the selected data end node for execution, corresponding to the configuration of the node type (see Configuring data jobs (Page 38)).

The data task wizard starts with the first dialog page after clicking on the required task. The dialogs are subsequently described using a data import task as example.

Dialog page: Description of the data task wizard

The "Description" dialog page of the data task wizard provides the description saved in the configuration and allows users to view notes.



1 Identification of the active step

The current step and the following or processed steps are listed in this line.

The active step is shown in **bold**.

② Display of the description

The description of the data task saved in the configuration is shown in this area.

3 Deselect the dialog page

By checking the checkbox, you can select that the wizard no longer displays this dialog page the next time this data task is started.


Note

If the dialog is to be subsequently reactivated, then this is possible via the data task configuration (see Configuration of data tasks (Page 38)).

3.3 NC data comparison

Dialog page: Import

The "Import" dialog page allows the import values - determined by the wizard from the Excel template - to be viewed.



① List of import designators/values

The import identifiers from the import area of the Excel template and the associated values, which were calculated in the Excel template, are listed in this area.

2 Note on creating missing values

If no values were able to be determined in the Excel template for individual identifiers, then these identifiers are color-coded and an information text is generated.

Values can be manually entered or changed for the identifiers; however, identifiers without value can also be processed.

3 List of placeholders/values

The place holders defined in the Excel template and their (default) values are listed.

4 Change of the values via the context menu


The default value saved for the place holder can be changed via the context menu.

If a place holder was defined in the Excel template, however no default value, then the wizard displays a question mark '?' instead of the value at ③ and in the identifiers at ① and a corresponding information text is displayed in area ③.

The next dialog is selected by clicking the "Next" button.

Dialog page: Summary

The "Summary" dialog shows the exported and imported values on a dialog and therefore provides an overview of the conversion operation.



① Color coding of the values

If, in the Excel template, no values were able to be determined for the individual identifiers, then these identifiers are shown in a bright purple color.

These values are shown in blue if the user manually entered or manipulated the values.

Saving a copy upon completion

By setting a checkmark in the check box, the "Save as" dialog is called when conversion is completed; this allows the used Excel template to be saved as copy together with the values it contains.


Data conversion is completed by clicking the "Finish" button.

A dialog is then called which makes reference to the fact that the import values were transferred into the clipboard and can be pasted at a data node.


3.3 NC data comparison



After clicking the "Yes" button, the converted data can be pasted at a data node via the context menu.



The "Preview pasting" dialog is displayed; this shows the value changes after the pasting.



Pasting can be acknowledged – i.e. executed – by clicking the "OK" button. The "Cancel" button can be used to cancel the operation.

Values which change as a result of the pasting are shown in blue.

Users should take special note of values or elements shown in red – these are also allocated an information text.

3.4 Folder comparison

3.4.1 General information

In a Folder comparison of Diff, you can compare two comparison objects with each other, insert or delete files or folders, and store the modified objects again. The comparison and display of the comparison results is realized at the folders and files level. This means that the contents of the files are compared optionally, but not displayed.

The folder comparison supports comparison and editing of the following objects:

- Folders/directories,
- SINUMERIK archive in the PC format
- SINUMERIK archive in the punched tape format
- ZIP archive
- TGZ archive
- TAR archive

Because unpacked archives usually represent a structure consisting of folders and files, similar rules apply to comparing and editing.


In the folder comparison, files with the same name are compared for size, date, version, and binary contents.

The comparison result is prepared both qualitatively and quantitatively.

From the comparison objects, folders and files can be copied to the clipboard and to other applications (Expert, Windows Explorer, etc.).

3.4.2 Overview of user interface

3.4.2.1 Folder comparison - toolbar



- ① Edit mode Synchronize Copy
- New folder comparisonCalling a folder comparison.
- 3 Switch between opened comparisons
- 4 Update comparison
- 5 Display/save HTML/XML report
- 6 Comparison configuration
- Opy / Insert
- 8 ■5 ■2

Go to the next/previous difference.

- Button group comparison results
- 10 Path of the opened comparison object.
- 10 Toggling between a tree view and list mode.
- Selecting the left-hand comparison object.
- Buttons/input for searching
- (4) Column with the comparison result symbols
- (5) Path of the opened comparison object.
- Selecting the **right-hand** comparison object.⇒ see ②

Description of buttons/fields of the toolbar

The buttons of the toolbar are described in more detail below.

① Edit mode - Synchronize - Copy



The edit mode can be activated and deactivated using the "Edit mode" button.

When the edit mode is activated, using the context menu, the following edit functions can be applied: Files and folders can be cut, copied, pasted, deleted and renamed. New files and folders can also be created.

The changes are saved in an archive using the floppy disk symbol.

Note

Changes become effective immediately

Changes in a folder become effective immediately in the original folder and **cannot** be saved again.

As a consequence, the floppy disk symbol remains deactivated.



The content of the left-hand comparison object can be synchronized with the content of the right-hand comparison object using the "Synchronize" button.

You can select which files and folders should be adapted by changing the comparison symbols (see 4) with a left click or from the short-circuit menu.



With the "Copy to the right," the selected files and folders of the lefthand comparison object are inserted in the right-hand comparison object.



With the "Copy to the left," the selected files and folders of the righthand comparison object are inserted in the left-hand comparison object.

③ Switch between opened comparisons

In the opened tabs, similar to the Window task bar, you can toggle between the opened comparisons with a mouse click or by simultaneously pressing "Ctrl" and "Tab".

4 Update comparison

The update button is always shown in color if the displayed comparison result is not a current result and the comparison should be restarted using this button.

① Display/save HTML/XML report

The comparison result of the nodes selected in the folder structure is shown in the standard browser (Internet Explorer) using this button.

The result can be saved either as HTML or XML protocol.

The comparison result for the selected directory is output completely or, under "...like display", an output depending on the settings made under (9).

3.4 Folder comparison

6 Comparison configuration

Using this button, a comparison configuration is changed or a different comparison configuration is selected (see Configuration (Page 55)).

6 Copy / Insert

Buttons for copying and inserting (only in edit mode) selected folders or files of the left-hand or right-hand comparison object (see Copy from the folder comparison (Page 59)).

The associated lines of the comparison result can be hidden or displayed using this group of buttons.

1 Toggle between a tree view and list mode.

Improved synchronization functionality is obtained by being able to toggle.

② Selecting the left-hand comparison object.

- Selection of the folder to be compared
- Selection of the archive to be compared
- Selection from the objects that were last selected
- Load archive from the control
- Load archive into the control

(3) Buttons/input for searching

This group contains:

- a button for opening a dialog box in which the search options can be defined
- an edit box for searching for character strings in selected nodes
- buttons for searching upward and downward.
- A Search down
- Search up


(4) Column with the comparison result symbols

For separating the left-hand and right-hand comparison objects.

When the edit mode is activated ①, the symbols can be changed for the purpose of synchronization (left click, context menu).

3.4.2.2 Folder comparison - overview window

Below is an overview of the functions in the folder comparison window.



- ① Display of the folders with respective comparison objects in the tree structure
- 2 Colored comparison of the comparison objects
- 3 Column of the comparison result icons
- Assignment of the comparison results icon/value (status line bottom right)
- ⑤ Context menu
- 6 Comparison configuration
- ① Display of the current comparison configuration (status bar)
- 8 Status bar

Description of the areas/functionalities in the Folder comparison window

The individual functionalities of the folder comparison are described in more detail below:

① Display of the folders with the respective comparison objects in the tree structure.

In this area, the folders of the comparison objects are shown in a tree structure arranged one on top of the other. The comparison result is visualized using special folder symbols.

2 Colored comparison of the comparison objects

The content of folder ① selected in the area is displayed next to one another for both comparison objects, whereby the center column ③ with the comparison result symbols is also used as demarcation between the left-hand and right-hand comparison objects.

The comparison results are color-coded to make it easier to interpret the results:

- Objects that are only available on the left-hand side are shown in green.
- Unequal objects or properties available on both sides are shown in red.
- Equal objects or properties available on both sides are shown in black.
- Objects that are only available on the right-hand side are shown in blue.

The contents of the column can be sorted in ascending or descending order by clicking on the column header.

Note

The contents of the files are only compared in the binary notation if this has been preselected in the comparison configuration (see Configuration (Page 55)).

The date for the comparison is not relevant for folders.

1 Column of the comparison result icons

Column with the comparison result symbols, to separate the left-hand and right-hand comparison objects.

When the edit mode is activated, you can change the symbols for synchronization purposes by left-clicking or via the context menu.

Meaning of the comparison symbols:

- A green arrow indicates that the folder is only available in the left-hand comparison object.
- The unequal character indicates that the contents of the folder are not identical.
- **=** The equal character indicates that the contents of both folders are identical.
- A blue arrow indicates that the folder is only available in the right-hand comparison object.

4 Assignment of comparison result icon/value (status bar bottom right)



The value in front of the slash specifies how many of these files can be seen in the selected folder.

The value after the slash shows the total number of these files that are contained in both comparison objects.

Example:

8/14

Specifies that there are 8 unequal files from a total of 14 in the currently selected folder.

Special features context menu

The "Open", "Send to" and "Copy" entries can be used to view and extract files from archives.

The entry "Open with file comparison" or a double-click opens the files contained in the selected line in the data comparison of Diff.

The other entries can be used to edit a selected file or a selected folder.

© Comparison configuration

A filter is used in the comparison configuration (see Configuration (Page 55)).

The comparison configuration is opened with a double-click.

Note

Using inclusion and exclusion filters, it is possible that not all of the files of the folder or archive are displayed any longer.

① Display of the current comparison configuration (status bar)

The comparison configuration that is being used in the actual comparison is displayed in this field (see Configuration (Page 55)).

The comparison configuration is opened with a double-click.


3.4.3 Changing the column arrangement

Changing the column arrangement for folder comparison


The column arrangement when comparing folders can be modified via the menu "View > "Column Arrangement" > "Same Sequence" or "Mirrored".

3.4 Folder comparison

Same sequence



Mirrored




3.4.4 Configuration

Folder comparison

You can call the dialog to configure a folder comparison using the "Comparison configuration" button. You can manage the different comparison configurations (i.e. create, edit, delete, etc.) in the dialog box.

In a comparison configuration, all of the criteria that should be taken into account when comparing folders can be defined.

You can also export or import configurations, for example, to make them available to other users (see Exporting and importing configurations (Page 75)).



- 1 List of the comparison configurations
- ② Buttons for managing the configurations
- 3 Comparison / Filter / Comment tab
- 4 Background color
- 5 Date of the last change option button
- ⑤ Date field/version/drop-down list of regular identification expressions option button
- 7 Checkbox Additional comparison criteria

3.4 Folder comparison

① List of the comparison configurations

The existing comparison configurations are listed in this area of the configuration dialog and can be selected by clicking on them.

Configurations shown in gray are user-specified configurations; these can be changed, but not deleted - and can be restored again at any time.

① Buttons for managing the configurations

Configurations can be managed using these buttons.

Using "Add", a new configuration is generated which can also be adapted.

A copy of the selected comparison configuration is created by clicking "Duplicate".

With "Restore user-specified setting", the changes to the specified comparison configuration are undone.

Note

The "Restore user-specified setting" button is only active if a user-specified configuration has been selected the contents of which are no longer the same as the default setting.

In addition to restoring the default setting, this button can also be used to check whether the contents are identical with those of the default setting.

3 Comparison / Filter / Comment tab

The properties that belong to the selected configuration are stored in this area of the Configuration dialog; these properties include comparison criteria, filter criteria and a comment.

1 Background color

So that the user can immediately recognize how to select certain comparison configurations, a separate background color can be defined for each comparison configuration.

Comparison tab

When making a comparison, the file size is always taken into account and when it is equal, it is shown in black - and when it is unequal, in red.

5 Date of last change to file option button

When the date/version comparison is activated, then for this selection, Diff also takes into account the date that the file was last changed and displays this in either in black or red.

The date is not relevant for folders.

6 Date field/version/drop-down list of regular identification expression option button

SINUMERIK archives can contain cycles.

The cycle version number is specified in the file. When making a comparison, it provides more information than the date and can be used for the comparison.

In order to be able to compare these version numbers, the files in the first ten lines are checked for the character string, which is then described using a regular identification expression.

A regular expression that is generally used is already selected in the specified comparison configuration "SINUMERIK archive".

Some regular expressions can be created in the drop down list box. An introduction to regular expressions can be found at the end of the document (see Use of regular expressions in Diff (Page 79)).


Additional comparison criteria checkbox

The content of the files is only compared byte-by-byte if the additional comparison criterion "Compare content of the files in a binary fashion" is selected.

Otherwise, only the size is compared and possibly the date or the version.

Filter tab

Using filters, files can be hidden and displayed for comparison in screen forms.



1 The functionality of the inclusion and exclusion filter is activated via the "Include/exclude files through filter" checkbox.

NOTE:

The filter symbol is shown in the status bar if this function is activated.

- ② Filter entries can be created, edited and deleted via the context menu.
- 3 Every filter entry can be individually activated or deactivated.

3.4 Folder comparison

Table 3-1 Examples of filters:


.ini	The "" expression (asterisk) stands for any number of any characters. If the entry in the inclusion filter is defined, then only file names with the file extension "ini" are displayed, and all others are hidden. If "*.ini" is in the exclusion filter, then all file names with the "ini" extension are not displayed.
cycle8?.spf	The question mark represents precisely one character (any character). Files with the "cycle8" name plus any character and the "spf" file extension are displayed, and all others are hidden if the entry was defined in the inclusion filter. File names with the designation "cycle8?.spf" can therefore be called as follows: cycle80.spf, cycle81.spf, cycle8a.spf etc.

Comment tab

Any comments on the selected comparison configuration can be saved under the Comment tab.

3.4.5 Copying from the folder comparison

Files, folders or complete folder structures can be copied from the comparison objects of the folder comparison to the clipboard and then, e.g. in Expert, inserted in a component. This means that it is possible to extract files from SINUMERIK, ZIP, TAR or TGZ archives, without having to use a Create MyConfig external software.



In the selected folder ①, in the list of folders and files contained in it ②, the objects ③ to be copied are selected using normal Windows tools (<Ctrl + mouse click>, <Shift + mouse click>, etc.).

Note

It should be noted that the objects to be copied can only be selected on the left-hand side or only on the right-hand side of the comparison objects.

Objects are copied using the normal Windows tools (context menu 4), button, <Ctrl+C>, etc.).

3.5 File comparison

3.5.1 General information

In a file comparison using Diff, you can compare the contents of two files line-by-line.


The comparison result is processed from qualitative and quantitative perspectives. Contents can be copied from the files line-by-line to the clipboard and used in other applications (Expert ...).

In the edit mode, you can delete lines or characters directly in the file comparison, insert them or copy them backwards and forwards between files.

It is also possible to simultaneously and externally process a file opened in the comparison.

3.5.2 Overview of user interface

3.5.2.1 File comparison - toolbar



- 1 Edit mode / Copy
- New file comparisonCalling a file comparison.
- 3 Update comparison
- Display/save HTML/XML report
- (5) Comparison configuration
- 6 Copy
- Go to previous / next difference.
- 8 Group of buttons for displaying and hiding the comparison results.
- 9 Differences in context
- 10 Select file for comparison

Here selection of the left-hand comparison object

- (f) Column with the comparison result symbols, to separate the left-hand and right-hand files.
- ② Switch between opened comparisons
- Input field Search
- (4) Path of the opened file.
- (5) Select file for comparison

Here selection of the right-hand comparison object

Description of buttons/fields of the toolbar

The buttons of the toolbar are described in more detail below.

1 Edit mode / Copy

The edit mode can be activated and deactivated using the "Edit mode" button. Using the "Copy to the right" and "Copy to the left" buttons, all of the selected lines are transferred from one file into the other. When the edit mode is activated, using the context menu, additional edit functions can be applied.

3.5 File comparison

This is how lines can be selected, deleted, copied and reinserted. Further, text in lines can be modified. You can change the display mode using the shortcut menu.

The changes are saved in the file using the floppy disk symbol.

4 Update comparison

The update button is always shown in color if the displayed comparison result is not a current result and the comparison should be restarted using this button.

① Display/save HTML/XML report

The comparison result is shown in the standard browser (Internet Explorer) by clicking this button.

The result can be saved as HTML file or as XML protocol.

The comparison result is output completely or, under "...like display," the output depends on the settings made under \under ...

6 Comparison configuration

Using this button, a comparison configuration can be changed or a different comparison configuration can be selected (see section "Configuration (Page 66)").

Note

An automatic selection of the comparison configuration as a function of the file type identification is the default setting that can be manually changed at any time.

You will find more information about this in section "Configuring automatic file identification (Page 72)."

6 Copy

A button to copy selected lines of the left-hand or right-hand file (see section "Copying from the data comparison (Page 74)").

8 Button group for showing and hiding the comparison results

The associated lines (left only, unequal, equal and right only) of the comparison result can be hidden or displayed using this group of buttons.

Differences in the context

The "Differences in the context" button hides larger blocks with identical lines.

If more than three identical lines are located before or after a different line, then these (up to three lines) are hidden.

Select file for comparison

Here you select the **left** comparison object.

Selection of the file to be compared

→ Selection from the files that were last selected

6 Switch between opened comparisons

In the opened tabs, similar to the Window task bar, you can toggle between the opened comparisons with a mouse click or by simultaneously pressing "Ctrl" and "Tab".

→ Input field Search


Edit box for the "Search" dialog box to search for text within both files

This group contains:

- a button for opening a dialog box in which the search options can be defined
- an edit box for searching for character strings in the display fields
- buttons for searching upward and downward.
- A → Search down

3.5.2.2 File comparison - overview window

Below is an overview of the functions in the file comparison window.



- Overview comparison result
- Column with the comparison result symbols, to separate the left-hand and right-hand files.
- 3 Specified values for lines (status bar bottom right)
- 4 Comparison result symbols and color coding of lines
- 5 Comparison configuration Filter
- 6 Display of the current comparison configuration
- Status bar
- 8 Display of the lines to be compared one on top of the other

Description of the areas/functionalities in the Data comparison window

The individual functionalities of the file comparison are described in more detail below:

① Overview comparison result

The comparison result is shown over the complete content of both files in this bar as an overview.


The colored dashes represent lines that are only available on the left-hand side, only on the right-hand side – or are not equal.

The white bars in the right-hand part of the list indicate which section of the comparison result is displayed in the area ④. The bars and therefore the visible section of the window can be positioned by clicking on the toolbar.

2 Column with comparison result symbols

See description for 4

3 Specified values for lines (status bar bottom right)



These values provide information about how many lines are either available only in the left-hand file (green), where the contents differ (red), are identical in both files (black), are identical in the relevant part of the line (gray) or only exist in the right-hand file (blue).

4 Comparison result icons and color coding of lines

The lines of the files to be compared are displayed next to one another in this area and are color-coded to make it easier to interpret the comparison result.

- → The green arrow and the line number with green background indicate that this line only exists in the left-hand file.
- ≠ The unequal character and the line numbers with red background indicate that the content of the line is not identical.
- **=** The black equal character indicates that both lines are identical.
- The gray equal character indicates matches in the relevant part of the line.

Note

Non-relevant parts of a line (e.g. spaces or comments) can be defined in the comparison configuration (see section Configuration).

← The blue arrow and the line number with blue background indicate that this line only exists in the right-hand file.

Note

Lines or characters shown in gray have been excluded from a comparison by a filter.

3.5 File comparison

6 Comparison configuration - Filter

A filter is active in the comparison configuration. The comparison configuration is opened with a double-click.

Note

Character strings that are not relevant can be excluded from the comparison using the inclusion/exclusion filter.

In the comparison result, these character strings are shown in gray.

① Display of the current comparison configuration

The comparison configuration that is being used in the actual comparison is displayed in this field

The comparison configuration is opened with a double-click.

® Display of the lines to be compared one on top of the other

The two lines below the comparison window represent the lines located side by side in the comparison window, above one another; this simplifies comparing the lines character by character.

With this representation it can be seen whether the characters in the lines are unequal (red), equal (black), only available at the left (green) or only available at the right (blue).

A gray point represents a character that does not exist in this line. In this case, there is a character at this location in the other line (possibly also a space).

See also

Configuration (Page 66)


3.5.3 Configuration

File comparison

You can call the dialog to configure a folder comparison using the "Comparison Configuration" button or via the menu "Comparison > Edit Configuration...". You can manage the comparison configurations (i.e. create, edit, delete, etc.) in the dialog.

In a comparison configuration, all of the criteria that should be taken into account when comparing files can be defined.

You can also export or import configurations, for example, to make them available to other users (see Exporting and importing configurations (Page 75)).



- 1 The existing comparison configurations are listed in this area of the configuration dialog and can be selected by clicking on them. Configurations shown in gray are user-specified configurations; these can be changed, but not deleted and can be restored again at any time.
- Configurations can be managed using these buttons.
 Using "Add," a new configuration is generated, which can also be adapted.
 A copy of the selected comparison configuration is created by clicking "Duplicate."
 "Restore user-specified setting" undoes the changes to the specified comparison configuration.

NOTE::


The "Restore user-specified setting" button is only active if a user-specified configuration has been selected the contents of which are no longer the same as the default setting. In addition to restoring the default setting, this button can also be used to check whether the contents are identical with those of the default setting.

The properties that belong to the selected configuration are stored in this area of the Configuration dialog; these properties include comparison criteria, filter criteria, alignment of the lines and a comment.

Comparison tab

You can define how the file comparison handles upper/lower-case letters and spaces under the "Compare" tab. The background color for comparisons can additionally be defined.

3.5 File comparison



① Background color


So that the user can immediately recognize how to select certain comparison configurations, a separate background color can be defined for each comparison configuration.

Filter tab

Using filters, parts of a line can be included in or excluded from the comparison based on regular expressions.

Characters excluded from the comparison are shown in gray in the comparison results. This means that the contents of a file are always displayed completely, but marked in color.

If only the relevant characters are identical in the line but non-relevant characters are different, the comparison symbol will be a gray equals sign.



1 The functionality of the inclusion and exclusion filter is activated using a check mark for "Parts of a line..."

NOTE:

The filter symbol is shown in the status bar if this function is activated.


- ② Filter entries can be created, edited and deleted via the context menu.
- 3 Every filter entry can be individually activated or deactivated.

Examples of filters:

*. *	The regular expression (see Use of regular expressions in Diff (Page 79)) which is used for ③ comprises the following characters: A space, an asterisk, a semicolon, a period and an asterisk.
	The characters have the following significance: Space stands for itself Asterisk → is a quantifier for any number of leading characters as prefix Semicolon → stands for itself Period → stands for any character
	If this expression is used as exclusion filter, then it excludes all of the semi- colons in the file and the following characters in this line that can be of any type. Comments identified using a semicolon are displayed, but are excluded from the comparison.

Alignment tab

Under the "Alignment" tab, you can define how the individual lines of both files should be aligned with one another after the comparison.



- ① Using this selection, you can define that all lines of the two files are aligned continuously next to one another (line 1 next to line 1, line 2 next to line 2, etc.).

 A search is not made across lines regarding identity or similarity.
- ② As an alternative to ①, in practice, this selection is more frequently used, which defines that identical lines should be aligned next to one another.

 This selection can be further refined or extended by making the appropriate entries for ③, ④ and ⑤.
- In the files to be compared, you can define sections that should be taken into consideration and for identical section identifiers, these should be aligned next to one another as priority. When the option is selected (using the context menu or double-click) a regular expression (see Use of regular expressions in Diff (Page 79)) should be saved in the entry field to describe the section identifier.

NOTE:

The lines found also have a yellow background in the comparison display.

Further, you can define that in the files to be compared, lines with identical partial character strings are aligned next to one another as first priority. When the option is selected, a regular expression to describe the partial character string must be saved in the entry field. For example, this function is used to define that in files which have the structure "identifier= value", only identical identifiers are placed next to one another (compared).

NOTE


The lines that are found also have a light yellow background in the comparison display.

NOTICE:

When selection ③ is activated, lines with identical partial character strings are only placed next to one another (compared) if they are located in the same section.

- (5) In addition, with lines for which the definitions (3) and (4) do not apply, this slider can be used to set how the system handles lines that are not identical, but similar when it comes to aligning them. This means it is defined as to whether similar lines, depending on the degree of similarity, are shown offset to one another (green and blue arrow) or next to one another (red unequal symbol).
- 6 This diagram should symbolically explain how the slider functions.

Two typical comparison configurations for SINUMERIK are subsequently shown and their comparison results as example.



Comment tab


Any comments on the selected comparison configuration can be saved under the Comment tab.

3.5.4 Configuration of the automatic file identification

Automatic file identification in Diff


An automatic file identification function is integrated in Diff for file comparison. This file identification function can identify the file type from the file name or the file content and can select an associated comparison configuration.

You can call the dialog for setting the program options via the menu "Tools > Options".



- The automatic selection of the comparison configuration can be activated or deactivated under the "File comparison" tab.
- ② Further, it can be set as to whether a message should be issued when an automatic comparison configuration is changed as a result of the file identification.
- This button can be used to call the dialog to configure the automatic file identification function.

The dialog to configure the automatic file identification function is equivalent to the dialog for the comparison configuration and should be used in the same way.



① When a file is opened, Diff goes through the saved identification configurations from the top to the bottom - and applies the first appropriate configuration corresponding to what has been configured under the Settings tab.

As a consequence, the sequence in which the configurations were saved is of significance.

For instance, a configuration that only operates with the file identification function using the file names should be located after a configuration that operates with the file identification function using the same file names and in addition, the file content.

Configurations that are to be temporarily not used can be deactivated by removing the checkmark.

Settings tab

- ② A screen form to identify the file (file type) using the file names can be saved in this field.
- If, using the file name, a clear identification is not possible, then a character string in the content of the file typical for the file type can be used to identify it.
- In this field, when activating the content identification via ③, a regular expression that describes a character string typical for the particular file type must be saved. Several regular expressions (one for each line) can also be specified. The comparison configuration is used as soon as one matches, i.e. a defined character string was found in the file.
- (5) This list box is used to specify which comparison configuration will be used if a file described using (2), (3), and (4) is identified. The drop down list box contains all of the file comparison configurations (see Configuration (Page 66)).

3.5 File comparison

Note

For the user-specified configurations, the file identification configuration and the associated file comparison configuration have the same names. It is not mandatory that the names are the same. The configuration names have no significance from a functional perspective.


Comment tab

Any comments on the selected identification configuration can be saved under the Comment tab.

3.5.5 Copying from the file comparison

Contents can be copied line-by-line from the files selected for comparison. You can insert these contents in a component, e.g. in Expert.


The lines to be copied are selected by left-clicking - keeping the <Ctrl> or <Shift> key pressed at the same time.



Objects are copied using the normal Windows tools (context menu, button, <Ctrl+C>, etc.).

3.5.6 Display modes

The display mode for the file to be compared can be selected using the context menu of the file comparison.



3.6 Exporting and importing configurations


3.6.1 General information

The comparison configurations, specified in Diff and those that you configured yourself, file identification configurations and data task configurations can be exported in a file, either individually or in groups, and imported from a file.

This means that you have the possibility of backing up your own configurations outside of Diff and also making these available to other users.

3.6.2 Exporting

The dialog to export configurations can be called via the main menu "Tools > Export Configurations".



The configurations available in Diff are displayed and grouped according to application areas.


- ① By activating the individual configurations, for each configuration you can define whether this should be exported.
- ② Activating/deactivating a group node means that this action is accepted for all configurations of the group.

The "Export" button opens the "Save as" dialog which saves the configurations to a file.

3.6.3 Import

Configurations can be imported via the main menu "Tools > Import Configurations".

After opening a file with exported configurations, you can select the configurations to be imported in the Import dialog.



The configurations available in the file are displayed and grouped according to application areas.

- ① Activating or deactivating a group node means that this action is accepted for all configurations of the group.
- ② By activating the individual configurations, for each configuration you can define whether this should be imported.
- 3 Group nodes are shown in gray if there is no configuration for the group in the file.

The "Import" button transfers the selected configuration to Diff.

If a configuration is to be transferred to Diff, for which a configuration with the same name already exists in Diff, then you are prompted as to whether the existing configuration should be overwritten.

3.7 Command line call

To be able to use Diff via the shortcut menu, e.g. in Windows Explorer, Diff has been provided with option switches which, in turn, allow Diff to be called via the command line.

Call

```
Diff /data <archive path 1> [< archive path 2>] [< archive path n>]
Diff /dir <directory path 1> [< directory path 2>]
Diff /file <file path 1> [< file path 2>]
```

3.7 Command line call

Parameter

Table 3-2 Parameter

Options	Arguments	Description			
/data	<"Archive(s)">	Means that the NC data comparison is opened			
		As argument(s), one or more paths for archives or parameter files can be specified here, which are to be compared			
		The path must be specified in double inverted commas if spaces are included in it (example: "C:\path with spaces\")			
/dir	<"Directory(ies)">	Means that the folder comparison is opened			
		As argument(s), one or two paths can be specified here for directories or archives that are to be compared			
		The path must be specified in double inverted commas if spaces are included in it (example: "C:\path with spaces\")			
/file	<"File(s)">	Means that the file comparison is opened			
		 As argument(s), one or two paths can be specified here for files that are to be compared 			
		The path must be specified in double inverted commas if spaces are included in it (example: "C:\path with spaces\")			
/config	<"Comparison configuration">	A name of a comparison configuration can be specified. If the configuration exists, then this is used.			
		NOTICE Case sensitive.			

Return values

Table 3-3 Return values

-	No evaluation possible

Example

(Requirement: Create MyConfig is installed in the directory "C:\Program Files\SIEMENS \Create MyConfig 4.7" an archive "Archive1.arc" is available in the path "C:\Temp\" and in Diff there is the comparison configuration "myConfig".)

"C:\Program Files\SIEMENS\Create MyConfig 4.7\Diff.exe" /data "C:\Temp\Archivel.arc" /config "myConfig"

A Use of regular expressions in Diff

A.1 General information on regular expressions

Regular expressions represent a general notation to describe text patterns. They are frequently known as a type of programming language to test and manipulate texts.

A regular expression is a character string with syntactic rules which defines significant text patterns or character strings in a general form. Regular expressions are used in Diff to identify a significant character string and if required to filter it (e.g. all block numbers or all comments in a cycle).

A regular expression comprises two types of characters, literal text characters and metacharacters:

Literal characters

Literal characters are characters that only stand for themselves in a regular expression and have no special significance.

A search with a regular expression which only comprises literals, therefore corresponds to a conventional character search.

Meta characters

Meta characters are characters that have a special function within regular expressions. Meta characters are, e.g. the characters \$ ^ { } [] () | . * + ? \ -.

Analogous to natural languages, literals can be considered as vocabulary and the meta characters as the grammar of regular expressions.

Escape sequence

If a meta character is required as literal character to formulate a regular expression, i.e. it must only stand for itself, then the character must be masked with what is called an escape sequence. This is realized by using a backslash \ as prefix.

For example, if an open square bracket [is to be identified with a regular expression, then it must have a backslash \ as prefix; the reason for this is that the square bracket alone is a meta character, i.e. has a special function (see character classes). This means, in this case that \ [must be written in the regular expression.

A.2 Meta characters in the regular expressions

The most important meta characters are shown in the following subsections which are contained in the dialect of the regular expressions of Create MyConfig.

Character classes

In a regular expression, a character class defines *one* character, which may be *one* of the characters contained in the character class.

Meta charac- ters	Description
	Corresponds to any character with the exception of \n (line break).
[]	A character set available for selection can be defined using square brackets. The expression in the square brackets precisely stands for one character from this selection.
[acdb]	Corresponds to <i>one single</i> character which is contained in the specified character string. This means one a, one b, one c or one d. The sequence of the characters within the character class is of no significance.
[^acdb]	Corresponds to any, individual character which is <i>not</i> contained in the specified character string. If a ^ is not located at the beginning of the definition, then it should be considered as literal. For "character negation" the ^ can only be located <i>within the square brackets</i> and here, in turn, may only be used at the <i>beginning!</i> Outside a square bracket, ^ has a different meaning, see below: "Constructs".
Adjacent characters can be specified as a range by using a hyphen. If the hyphen is written at the beginning or at the end of the character backslash, i.e. \- then it stands for itself and is not valid as specifying	
\w	A character which is a letter, a number or an underscore.
\W	A character which is neither a letter, number nor underscore.
\s	Corresponds to any space character, i.e. space character, tabulator, line feed spectrum.
\S	Corresponds to any non-space characters.
\d	Corresponds to any decimal number, corresponds to [0-9].
\D	Corresponds to any non number, corresponds to [^0-9].
\t	Corresponds to a tab stop character.
\n	Corresponds to a line break.
\x20	Corresponds to an ASCII character in the hexadecimal notation (precisely two positions).
\u0020	Corresponds to a unicode character in the hexadecimal notation (precisely four positions).

Constructs

Meta charac- ters	Description			
I	Several regular expressions can be combined to form a single one using alternation (logical OR). Example: cat dog tiger. (cat or dog or tiger) The match to the far left has priority.			
()	The grouping is used to combine parts of regular expressions and to limit the range of validity of an alternation. Example: _(abc xyz)_			

Meta charac- ters	Description			
^	The meta character for the beginning of the line does not describe a character in the actual sense, but instead a position in a line. Example: ^ [aA] requires a lower-case a or upper-case A at the beginning of the line. The ^ character in square brackets has a different meaning, it is used as negation of the character string.			
\$	The meta character for the end of the line does not describe a character in the actual sense, but instead a position in a line. Example: [aA] \$ requires a lower-case a or an upper-case A at the end of the line.			

Quantifier

Using quantifiers, you can specify how many times a specific component of a regular expression must occur in order for a found character string to be considered a match. A quantification expression is valid for the character or character set which is located directly in front of it.

Meta charac- ters	Description			
?	Requires a null or a match. Example: _? or (abc xyz)?.			
+	Requires one or any number of matches. Example: a+ or [0-9]+.			
*	Requires null or any number of matches. Example: \w* or (abc) *.			
{n}	Requires precisely n matches. Example: (abc) {2}.			
{n,}	Requires a minimum of n matches, but there can also be more. Example: (abc) {2,}.			
{n,m}	Requires at least n matches, however a maximum of m matches. Example: $\w \{2,17\}$.			

A.3 Examples of regular expressions

Regular expression	Charac- ter	Description		
^\[[^\]]+\]		Describes a section, e.g. <i>[Version]</i> At the beginning of the line there should be an "open square bracket" [and then there should be at least one character other than a "close square bracket"] followed by a "close square bracket"]. The remainder up to the end of the line is not specified.		
12345		Numbers indicate the position of the character in the regular expression.		
The regular expression	The regular expression is described below from the left to the right:			
^\[[^\]]+\]	① ^	Here, the beginning of the line, i.e. the described expression should be located at the beginning of the line.		

A Use of regular expressions in Diff

Regular expression	Charac- ter	Description	
^[[^\]]+\]	2\	Escape character; the "open square bracket" [should stand for itself as literal and not as meta character of a character set.	
^ \[[^\]]+\]	3 [Character stands for itself, i.e. at the beginning of the line there should be an "open square bracket [.	
^\[[^\]]+\]	4 [Starting definition of a character set (character is a meta character).	
^\[[^ \]]+\]	⑤ ^	Here, a negation character, i.e. the characters specified in the character set, should not occur. The character negation is only possible within square brackets, therefore, brackets are used for characters ④ and ⑧.	
^\[[^ \]]]+\]	6 \	Escape character; the "close square bracket"] should stand for itself as literal and not as meta character of a character set.	
^\[[^\]]+\]	7]	This character stands for itself.	
^\[[^\]] +\]	8]	End definition of a character set	
^\[[^\]]+\]	9 +	Requires one match or as many matches as specified, i.e. there must be at least one character, which is not a "]".	
^\[[^\]]+ \]	10 \	Escape character; the "close square bracket"] should stand for itself as literal and not as meta character of a character set.	
^\[[^\]]+\]	①]	This character stands for itself.	

Regular expression	Charac- ter	Description		
^[^=]+=		Describes a value assignment (identifier = value) e.g. <i>Version</i> = 1.0.3 At the beginning of the line there should be at least one character, which is <i>not</i> an equal sign "=". This expression (^[^=]+) stands for the "identifier" in the value assignment. This should then be followed by an equal sign "=" and the remainder of the line, the value, is not specified.		
102345		Numbers indicate the position of the character in the regular expression.		
The regular expression	is describe	ed below from the left to the right:		
^ [^=]+=	1 ^	Here, the beginning of the line, i.e. the described expression should be located at the beginning of the line.		
^[^=]+=	2 [Start of the definition of a character set (character is a meta character).		
^ [^ =] +=	3 ^	Here, a negation character, i.e. the characters specified in the character set should not occur.		
^ [^=] +=	4 =	Equal sign (literal) stands for itself.		
^ [^=] +=	⑤]	End of the definition of a character set.		
^ [^=] + =	6 +	Requires one match or as many matches as specified, i.e. there must be at least one character, which is not an equal sign.		
^ [^=] + =	7 =	Equal sign (literal) stands for itself.		

Regular expression	Character	Description		
^CHANDATA\(\d+\)		Describes a CHANDATA operation in an NC-INI file, e.g. <i>CHANDATA(1)</i> CHANDATAshould be at the beginning of the line, followed by a "open round bracket", followed by at least one digit, followed by a "close round bracket".		
12345		Numbers indicate the position of the character in the regular expression.		
The regular expression is	described below f	rom the left to the right:		
*CHANDATA\(\d+\)	① ^	Here, the beginning of the line, i.e. the described expression should be located at the beginning of the line.		
^CHANDATA\(\d+\)	② CHANDATA	This literal character stands for itself, i.e. a search is made for a CHANDATA.		
stan		Escape character; the "open round bracket" should stand for itself as literal and not as meta character of a group.		
^CHANDATA\(\d+\)	4 (This character stands for itself.		
^CHANDATA\(\d+\)	5 \d	Corresponds to any decimal number.		
^CHANDATA\(\d+\) 6 +		Requires one match or as many matches as specified, i.e. there must be at least one decimal number.		
^CHANDATA\(\d +\)	⑦ \	Escape character; the "close round bracket" should stand for itself as literal and not as meta character of a group.		
^CHANDATA\(\d+\)	8)	This character stands for itself.		

A Use of regular expressions in Diff

Create MyConfig - Expert

4.1 Safety instructions

4.1.1 Fundamental safety instructions

4.1.1.1 General safety instructions

WARNING

Risk of death if the safety instructions and remaining risks are not carefully observed

If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur.

- Observe the safety instructions given in the hardware documentation.
- Consider the residual risks for the risk evaluation.

/ WARNING

Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

4.1.1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (http://www.siemens.com/industrialsecurity).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (http://support.automation.siemens.com).

Æ

WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/ or material damage.

- Keep the software up to date.
 You will find relevant information and newsletters at this address (http://support.automation.siemens.com).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
 You will find further information at this address (http://www.siemens.com/industrialsecurity).
- Make sure that you include all installed products into the holistic industrial security concept.

4.2 Introduction

Note

Setup of documentation: Operating Manual / online help

The contents for the **Expert** section are identical in the Operating Manual and online help.

Expert is the engineering software for creating a CMC project. An executable package for the production and upgrading of machines can be generated from this project with the "Deployment" function. The package contains a configurable sequence of production or upgrading steps and the associated data.

In Expert, the configuration of the package, the dialog boxes for operator interactions, and the individual upgrade steps in the form of a hierarchical step tree are defined and the data and files that are required or will be manipulated are specified.

The configuration can only be performed by qualified personnel.

The majority of the settings can be easily made via a context-sensitive context menu.

A source explorer (similar to the Windows Explorer) is integrated for the integration of files in the components. Files can be either copied or linked. Linked files are only accepted in the package at the time of transfer.

Before a Verification of package, you will be informed if there are any errors in the configuration.

The "Transfer" function creates a package that can be executed under Linux or Windows depending on the configuration.


An integrated online help (F1), which is identical to this documentation, supports you in the correct configuration.

4.2.1 Overview of the expert user interface

The expert user interface comprises the following areas:

- Main menus and toolbars (Page 88)
- Project folder (Page 92)
- Source explorer (Page 91)
- Component editor (Page 183)
- Cross references (Page 236)
- Verification of package

4.2 Introduction



- Project folder
- Source explorer
- 3 Component editor
- 4 Cross references
- 5 Verification of package

4.2.2 Main menus and toolbars

Table 4-1

Project					
9	New	<ctrl+n></ctrl+n>	Creates a new project under the specified name and storage path.		
<i></i>	Open	<ctrl+o></ctrl+o>	Opens an existing project. Also permits an older project to be selected for conversion.		

7	Save	<ctrl+s></ctrl+s>			ct and all internal or externally linked com-		
	Sava All	Ctrl+Chiff+C>	ponents belonging to this project, if there is a save request for these. Saves all projects and components for which there is a save request.				
Ø	Save All <ctrl+shift+s></ctrl+shift+s>		-	Saves all projects and components for which there is a save request.			
	Save As		Saves all opened projects and components under a different name or location.				
1	Password protection	The project, the components, the package, and the logbook can be protected from unauthorized access with passwords.					
			Enter the password		Log on to the open project using the password (extended rights).		
		Edit password list		Define the passwords with the corresponding rights on the package and project.			
			Transfer password list		Transfer the created passwords to internal or external components.		
×	Display cross references	<ctrl+alt+shift+r></ctrl+alt+shift+r>	Displays the cros	ss referen	ces for the project and all of its components.		
	Verification run	<ctrl+shift+b></ctrl+shift+b>			ing all components. The verification run is one each deployment.		
€	Deployment		Checks the proje	ect and de	eploys it as package.		
_			Deploy Linux package (NCU)	USZ	Can be executed on the NCU		
		Deploy Win- dows package (PC/PCU)	EXE	Can be executed on a PC or the PCU			
		Deploy package without the executable part	UAZ	Cannot be executed			
•	Import Package		Imports all data into a new project from a deployed package such as USZ, EXE, UAZ.				
×	Delete Projects	Allows the deletion of one or several projects of the current project archive that have not been opened. The project file and the project folder with all internal components are deleted.					
	Properties		Shows important project properties, such as path of the project, date of change, changed by, version and comment.				
	CMC Report		CMC report shows the properties of the project and all components in a dialog box.				
	Last Opened		Provides a fast entry to open the last projects used.				
	Close All		Closes the project and all of the components that have been opened.				
	Exit	<alt+f4></alt+f4>	Exits the Expert program.				
Edit							
¥	Cut	<ctrl+x></ctrl+x>	Removes the currently selected objects and copies them to the clip-board.				
	Сору	<ctrl+c></ctrl+c>	Copies the currently selected objects to the clipboard.				
	Paste	<ctrl+v></ctrl+v>	Pastes the objects from the clipboard to the selected position.				
×	Delete		Deletes the currently selected objects.				
2	Refresh	<f5></f5>	Refreshes the step tree completely. This function is particularly for the refreshing of linked steps.				
View	1	1	· '				

4.2 Introduction

	Source explorer		Hides or displays the source explorer at the upper edge of the working area.	
	Cross references		Shows all identifiers, folders, and file objects used in the project on tabs "Identifiers" and "Folders and File objects".	
	Verification run		Hides or displays the verification window.	fication of package at the lower edge of the
Q	Go to error/warning for- ward	<f8></f8>	After a verification run, a ju or alarm entry.	ump can be made to the next/previous error
I	Go to error/warning backward	<shift+f8></shift+f8>		
	Toolbars	Standard	Allows toolbars to be hidd	den or displayed.
		Quick search		
Comp	ponent			
îè	New	<alt+shift+n></alt+shift+n>	Creates a new component created.	t. Internal and external components can be
20	Open	<alt+shift+o></alt+shift+o>	Opens an existing compo	nent.
r _e	Save	<alt+shift+s></alt+shift+s>	Saves the current compo	nent.
	Save As		Saves the current comporor externally.	nent under another name - either internally
	Close	<ctrl+f4></ctrl+f4>	Closes the current compo	onent.
•	Password protection		The current component is protected from unauthorized access by passwords.	
			Enter the password	Log on in the current component (active tab) with another password (extended rights).
			Edit password list	Define passwords with the corresponding rights in the current component.
			Transfer password list	Transfer the created passwords to internal or external components.
	Properties		Shows important component properties, such as path of the component, date of change, changed by, version and comment.	
	CMC Report			
P	Manage (copy, delete, etc.)	<shift+f12></shift+f12>	Opens the "Manage" dialo moved, structured and de	og box in which components can be copied, eleted.
	Display non-linked comp	oonents	Determines all internal components of the currently opened project that are not linked – and allows these to be deleted.	
C	Display cross references	<ctrl+alt+shift+r></ctrl+alt+shift+r>	Shows a list of all identified current component.	ers, folders, and file objects used in the
G _v	Verification of package	<ctrl+shift+b></ctrl+shift+b>	Checks the current component. For an opened project, this is checked against its configuration.	
Comp	onent			
	Store in file		Enables the storing of the current configuration for areas to be selected, in a file.	
	Read from file		Imports configurations for areas to be selected, from a file.	
			The current configuration is overwritten by the imported configuration data.	
Tools	•		1	
	Options		Opens a dialog box in wh	ich the options can be set.

	Adapt links		in the project	Links in the project and components can		
			in component	be adapted.		
			in components of a storage folder			
	Convert		from components of a storage folder	Enables components from an older Expert version to be converted to the current Expert version in a folder.		
			Delete backup files (*.bak)	Deletes the backup files created during the conversion.		
Windo	ow .					
	New horizontal tab group		Displays the selected component in the new horizontal tab group.			
	New vertical tab group		Displays the selected component in the new vertical tab group.			
	Move to previous tab group		Moves the selected component to the previous tab group.			
	Move to next tab group		Moves the selected component to the next tab group.			
	Note Window Layout		Note the layout of the user interface areas for the next start of the program.			
Help						
?	Contents	<f1></f1>	Displays the online help of the Expert program which is identical to this manual.			
	About		Contains information on the version and copyright.			

NOTICE

Data can no longer be found

If projects, components, and associated data are moved more than once without storage in a buffer, automatic path adaptation may no longer be possible. Components or linked data can then no longer be found.

You should therefore run a verification of projects every time after packages or components are moved.

When projects and components are copied with unfavorable conditions for automation path adaptation, the project may access the original components or linked data.

4.2.3 Source Explorer

A source explorer is integrated in Expert which is used similarly to the Windows Explorer. Only read operations are offered for the source explorer in order to avoid unintentional deletion, moving or changing of data.

An external file manager can also be used to copy files and folders to the components, or to link these.

Copy

Folders and files can be dragged from the source explorer and dropped in a component. Copying is performed when the <Ctrl> key is pressed. Linking is performed when the <Ctrl +Shift> keys are pressed. Otherwise you are prompted as to what should be done. Copy & paste is also possible.

Refresh

The <F5> key refreshes the display of the source explorer.

Double-click

A double-click on the title bar minimizes the source explorer or restores it. When a linked file is double-clicked, the source explorer changes to its path.

4.2.4 Converting projects from older CMC versions

When opening a project or a component, Expert checks the existing CMC version. If the CMC version of the project to be opened is earlier than the installed CMC version, Expert converts the project and the internally and externally linked components.

The conversion only takes place after a prompt, which must be confirmed by the user.

The prompt also specifies the CMC version that was used to create the project to be opened and allows the creation of *.bak files before the conversion.

The *.bak files can be subsequently deleted via the main menu "Tools > Convert > Delete backup files (*.bak)".

It is recommended that each project be manually backed up or archived with all of the associated internal and external components before the conversion. It is also recommended that a conversion only be carried out from the previous to the current CMC version, i.e. no CMC versions should be skipped.

4.3 Project folder

4.3.1 Package

The basic settings for the package are made on the Package tab.

After specifying the project properties, all the relevant data for the deployment of the project is configured.

Then the settings for the package and NcuShareService are defined and an executable package is created.

Specifying the configuration for Package

You can configure the following property groups on the "Package" tab:

- General
- Deployment
- Package
- Data areas
- NcuShareService




Figure 4-1 Project / Package tab - project engineer view

Note

Help areas for Project / Package tab

Note the color-coded help area under Project / Package.

Click on a property to display the relevant description.

Display all system variables via a dialog button

Via the button (Display all system variables via a dialog), you can call the "Package system variables" dialog. All system variables that can be used in Package are listed here.

Information on the Package system variables can be found in the System variables for package properties Up.\$Pack (Page 272) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

General

The following settings are available:

Table 4-2 General

Comment	Project-internal information can be entered here.	
	This comment is not displayed during package processing or in the logbook.	
Access	Access rights are displayed and defined here.	
	Click the button to open the "Edit password list [Rights without a password]" dialog.	
	More detailed information is provided at "Editing password protection (Page 240)"	
	General information on the password protection (Page 240).	

Deployment

The following settings are available:

Table 4-3 Deployment

Name	Here, you define the name of the package for this deployment.
Storage location	Here, you define the storage location, i.e. the absolute path under which the package is saved.

Runtime system	LINUX package (NCU) Windows package (PC/PCU)	Here, you select the runtime system on which the package is executed.	
	Package without the executable part		
Exclude data	Yes	Here, you define whether data from unused data	
areas	No	areas Archive, NCU, and PCU is excluded from deployment.	
		The data of the non-selected PCU system is also excluded.	
		The size of the package can be reduced by excluding the data areas.	

Package

The following settings are available:

Table 4-4 Package

Language preselection	German English	Here, you select the user interface language for processing the package.
		The language can be switched for each dialog separately by the user during the package execution.
		The user fields (yellow fields) remain unchanged.
User version	1.0	The package can be versioned by the user via the user version.
		An environment variable of the type Up. \$Pack.ProdVersion = "1.0" can also be entered here.

Data areas

The following settings are available:

Table 4-5 Data areas

Use archive	Yes No	Here, you specify whether the Archive data area is used for package execution.
		This configuration affects the target area nodes in the actions of components (partially also scripts).
		Unused nodes are hidden or highlighted in color if they contain data.
Use PCU	Yes No	Here, you specify whether the PCU data area is used for package execution.
		This configuration affects the target area nodes in the actions of components (partially also scripts).
		Unused nodes are hidden or highlighted in color if they contain data.

PCU system	Windows XP Windows 7	Here, you select the operating system of the PCU.
Use NCU	Yes No	Here, you specify whether the NCU data area is to be used for the package execution. This configuration affects the target area nodes in the actions of components (partially also scripts). Unused nodes are hidden or highlighted in color if they contain data.

NcuShareService

The following settings are available:

Table 4-6 NcuShareService

Installation	Yes No	The NcuShareService is installed on the "NCU access" dialog page if it has not been installed yet or an older versions exists on the PC/PCU.
		The service is only required if a Windows package is to be executed with NCU data area.
Uninstallation	Yes No	The NcuShareService is uninstalled after executing the package.
		The uninstall can only be performed if the installed service has the same service version in the current package.

Further information on the NcuShareService can be found in the Create MyConfig NcuShare (Page 347) section or in the online help of the same name.

See also

Editing a password list (Page 242)

4.3.2 Dialogs

Overview of dialog pages

Below the project map in the "Dialogs" tab, you can activate the dialogs to be executed and configure their contents and behavior.

You can see the dialog list with the dialog pages that are possible to configure in the following:




Figure 4-2 Dialogs tab - Overview

Defining general properties for all dialogs

Generally applicable properties can be defined for all dialogs.

Name

In the table column under "Name", dialog pages with a black checkbox can be activated or deactivated for "Editing" directly in the dialog list or via the property "Edit" in the property field.

Dialog pages with a gray checkbox are **always** required to execute the package, in accordance with the configuration of the areas in the Project/Package tab, and **cannot** be deselected.

Editing mode for all dialogs

By right-clicking on one of the table columns (Name, Mode or Messages) or on a dialog page, you can uniformly define the Mode property for all dialogs: "Editing mode for all dialogs".

The following options are offered and are activated when the package is executed:

Manual	The dialog page is completely displayed, the operator can make changes and must trigger the dialog page advance or execution.
Automatic	The dialog page is completely displayed, however, the operator cannot make any changes and it is executed automatically.
Progress	Processing is analogous to the Automatic mode without the configuration information being displayed.

Display messages for all dialogs

Also by right-clicking on one of the table columns (Name, Mode or Messages) or on a dialog page, you can uniformly define the Messages property for all dialogs: "Display messages for all dialogs".

The following options are available:

Errors	The "Display messages for all dialogs" property allows messages to be sup-
Errors and warnings	pressed during execution.
All	Messages to be suppressed are acknowledged via automatic actuation of the standard button.

The following table shows an overview of when which message is displayed or not displayed.

Message	All	Errors and warnings	Errors
System error	On	On	On
Run error	On	On	On
Run warning	On	On	Off
Message when the step script is fulfilled	On	Off	Off
Warning for activated/ not activated step	On	On	Off
Error function	On	On	On
Warning function	On	On	Off
Msg function	On	Off	Off
Input functions	On	On	On

Using the dialog list, you can centrally view the editing mode and message display for all dialogs, and select individually or for all dialogs (context menu).

Dialog pages for the Dialogs tab

The following dialog pages are run through chronologically during package execution.

In the following sections, the property groups and the setting options for the respective dialog pages are described.

Finally, the configured dialog page is shown how it is displayed for the operator or commissioning engineer during package execution.

All configurable dialog pages have multiple property groups. All dialog pages have the following two property groups:

- Dialog
- Operating instructions

These property groups are described only once in the "Notes about acknowledgement (Page 104)" dialog, but they apply for all dialog pages.

To the dialog pages

Here you can find detailed information about the individual dialog pages:

- Package configuration (Page 99)
- Notes about acknowledgement (Page 104)
- Notes on the package (Page 107)
- Archive access (Page 109)
- PCU access (Page 112)
- NCU access (Page 115)
- Notes on GSP (Service Platform Industry) (Page 119)
- Service Platform Industry (GSP) (Page 121)
- CNC software (Page 126)
- System configuration (Page 131)
- Notes on the topology (Page 141)
- SINAMICS topology (Page 143)
- Version display (Page 150)
- Notes on the step tree (Page 153)
- Step tree (Page 155)
- NCU result (Page 159)
- End (Page 163)

4.3.2.1 Dialog page: Package configuration

Configuration

You can configure the following property groups for the "Package configuration" dialog page:

- Dialog
- Configuration
- Dialog scripts




Figure 4-3 Package configuration - project engineer view

Display all system variables via a dialog button

You open the "Package configuration - System variables" dialog via the button (display all system variables via a dialog).

All system variables to be used under "Package configuration" are listed here.

Information on the system variables can be found in the System variables for the Package configuration dialog (Page 274) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog

More detailed information about the property group "Dialog" can be found under the dialog page: Notes about acknowledgement (Page 104).

Configuration

The following settings are available:

List	The list of all existing package configurations in the package is displayed in the "List of package configurations".
Preselection	Here, you make the preselection for the selected package configuration for package execution.

Operating instructions

The following settings are available:

Text	

Dialog scripts

Under "Dialog scripts", entry "Scripts", via the button you open the dialog page "ScriptEditor dialog - <Name of the opened dialog page> (<Time of execution>)". You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

The dialogs are listed in the following table:

Table 4-7 Assignment dialog - Event

Dialog	Event
Package configuration	OnInit
Archive access	OnNext
PCU access	OnEnd
NCU access	
Service Platform Industry (GSP)	
CNC software	
System configuration	
SINAMICS topology	
Step tree	
NCU result	

Meaning of the events:

Table 4-8 Event - Meaning

Event	Meaning / Time of script execution		
OnInit	The script is executed before the dialog page is displayed.		
	OnInit is used:		
	To skip this dialog page		
	To change settings of this dialog page because of the current sequence (e.g. settings for write access to the system variables can still be changed effectively)		
OnNext	The script is executed in the dialog immediately after clicking the "Next" button.		
	OnNext is used:		
	To check operator inputs after clicking the "Next" key		
	To return to the input		
	At this point in time, set values of the dialog page can be checked by exporting system variables.		
	The dialog execution can be interrupted in the script with the Redo() function. In this case, settings of the dialog page can be corrected.		
	The execution of the dialog page can be restarted. The script "OnNext" is also executed again.		
OnEnd	After successful processing, the script is executed at the end of a dialog page.		
	Here, via write access to system variables for example, you can set which of the following dialogs is to be executed or not.		

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section at:

- Sections (Page 204)
- Area data (Page 206)
- Control structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

Description

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-4 Package configuration dialog - commissioning engineer / operator view

Buttons for the dialogs

Table 4-9 Meaning of buttons

Button	Meaning	
Output	The output window is shown or hidden. Status messages are displayed in the output window while the package is being executed.	
Alarms	The alarm list is shown or hidden. It displays errors and messages from NC, PLC, drive, and HMI. It approximately corresponds to the "Diagnostics" used in SINUMERIK Operate.	
Log	This button opens the CMC logbook for package execution.	
Back / Next	These buttons lead through the dialog pages accordingly.	
Cancel	The execution of the package is canceled. A prompt generally appears. This prompt must be acknowledged. After a dialog is canceled, the "Finish" dialog is always displayed, thus allowing the logbook to be backed up.	
	The cancellation process can take place immediately or after a time delay, depending on the dialog page and the execution status.	

Note

The buttons are identical for all dialog pages and thus have the same meaning.

4.3.2.2 Dialog page: Notes about acknowledgement

Configuration

You can configure the following property groups for the "Notes about acknowledgement" dialog page:

- Dialog
- Operating instructions




Figure 4-5 Notes about acknowledgement - project engineer view

Note

Help area below the Dialogs tab

Note the yellow help area under the Dialogs tab. Click on a property to display the relevant description.

Display all system variables via a dialog button

You open the "Notes about acknowledgement - System variables" dialog via the button display all system variables via a dialog). All system variables to be used under "Notes about acknowledgement" are listed here.

Information on the system variables can be found in the System variables for the Notes on confirmation dialog (Page 274) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog

You have the capability of centrally defining the "Dialog" properties for all of the dialogs together, see the Summary "Defining general properties for all dialogs (Page 96)" section.

However, you can also individually adapt the "Dialog" properties for each dialog page, which should then take effect when the package is executed:

Activation	Yes No	Here, you specify whether the dialog page is to be used for the package execution.
	INO	If this is not activated for the package execution, the following properties have no effect.
Editing mode	Manual	The dialog page is completely displayed, the operator can make changes and must trigger the dialog page advance or execution.
	Automatic	The dialog page is completely displayed and executed automatically.
		The operator cannot make any changes.
	Progress	Processing is analogous to the "Automatic" mode without the configuration information being displayed.
		A progress indicator is displayed in a small display window.
Display messages	Errors	The "Display messages" property allows messages to be suppressed during the package execution.
	Errors and	
	warnings	Messages to be suppressed are acknowledged via automatic actuation of the standard button.
	All	

Operating instructions

User-specific "Operating instructions" can be configured for most dialog pages. The text can be formatted using HTML tags.

When executing, the operating instructions are displayed with a yellow background so that it is easier to distinguish them from fixed user interface texts.

Dialog view during the package execution (for commissioning engineers / operators)

On the "Notes about acknowledgement" dialog page, you can display your license terms from a file in text format or restricted HTML format.

You can also use this page to define that the user must confirm having read the displayed information before the package is executed.

Package execution can only be continued when the user agreement has been accepted.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-6 Notes about acknowledgement dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.3 Dialog: Notes on the package

Configuration

You can configure the following property groups for the "Notes on the package" dialog page:

- Dialog
- Operating instructions




Figure 4-7 Notes on the package dialog - project engineer view

Display all system variables via a dialog button

You open the "Notes on the package - system variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Notes on the package" are listed here.

Information on the system variables can be found in the System variables for the Notes on the package dialog (Page 274) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Dialog view during the package execution (for commissioning engineers / operators)

A file in text format or restricted HTML format can be displayed with notes about executing the package on the "Notes on the package" dialog.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-8 Notes on the package dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.4 Dialog page: Archive access

Configuration

You can configure the following property groups for the "Archive access" dialog page:

- Dialog
- Operating instructions
- Archive path
- Dialog scripts




Figure 4-9 Archive access - project engineer view

The "Archive access" dialog page is activated if "Use archive" was selected in the "Project / Package" tab under Packages > Data areas.

The package configuration is only possible without the areas NCU and PCU.

Display all system variables via a dialog button

You open the "Archive access - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Archive access" are listed here.

Information on the system variables can be found in the System variables for the Archive access dialog (Page 275) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Archive path

Under the specified "Path" there is the folder which contains the archives to be executed and into which the result archive is re-saved.

Dialog scripts

Under "Dialog scripts", entry "Scripts", via the button ... you open the "ScriptEditor dialog - Archive access (<Time of execution>)" dialog page.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section at:

- Sections (Page 204)
- Area data (Page 206)
- Control structures (Page 206)
- Operators (Page 209)

- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

Execution of the "Archive access" dialog page cannot be deactivated. It is always automatically executed when executing a package under Windows that addresses either the "Archive area" or "PCU area".

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-10 Archive access dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.5 Dialog page: PCU access

Configuration

You can configure the following property groups for the "PCU access" dialog page:

- Dialog
- Operating instructions
- Address
- PCU login information
- Dialog scripts




Figure 4-11 PCU access - project engineer view

Display all system variables via a dialog button

You open the "PCU access - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "PCU access" are listed here.

Information on the system variables can be found in the System variables for the PCU access dialog (Page 276) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Address

The "Preselection" is already set to the default address of the "PCU50" 192.168.214.241 during configuration.

Note

If the package is to be executed locally on a PCU, the specified address has no significance.

PCU login information

The following settings are available for the "PCU login information" property:

User name	Neither a user name nor a password is pre-assigned for a new project.
	If the user name and password are not specified, a logon is started with the standard user of the PCU50 XP "auduser" and the appropriate password for the package execution.

Dialog scripts

Under "Dialog scripts", entry "Scripts", the button calls the "ScriptEditor dialog - PCU access (<Time of the execution>)" dialog page.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section at:

- Sections (Page 204)
- Area data (Page 206)
- Control structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

Execution of the "PCU access" dialog page cannot be deactivated.

If at "Package > Data areas > Use PCU" has been selected in the Project / Package tab, this dialog page is executed automatically when executing a package.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-12 PCU access dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.6 Dialog page: NCU access

Configuration

You can configure the following property groups for the "NCU access" dialog page:

- Dialog
- Operating instructions
- Address
- NCU login information
- Data backup CF card
- Archive
- Dialog scripts




Figure 4-13 NCU access - project engineer view

"Display all system variables via a dialog" button

You open the "NCU access - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "NCU access" are listed here.

Information on the system variables can be found in the System variables for the NCU access dialog (Page 275) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Address

The Address of the NCU must be entered for a remote Windows access from a PCU 50 or a PG/PC.

The "Preselection" is preset with the default address 192.168.214.1 during configuration.

Note

If the package is to be executed locally on an NCU, the specified address has no significance.

NCU login information

The following settings are available for the "NCU login information" property:

User name Login information (user name, password) ca		Login information (user name, password) can be stored for access to the NCU.
	Password	In a new package, these are preset to standard user of the NCU "manufact" and
		the appropriate password.

Data backup CF card

The following settings are available for the "Data backup CF card" property:

Perform backup	Yes	A data backup of the NCU can be selected on this dialog page at the start of the package execution.
	No	This backs up the content of the CF card, including the current active archive data (NC, PLC, DRV), in a folder named based on the CF card ID.
		If when starting, a data backup is found next to the package, it can be selected in the package selection for restoration.
		When the backup is restored, the backed-up archive data is reloaded automatically.
		In addition to the data backup *.tgz, this folder also contains an instruction *.txt and a package *.usz for a Linux package or *.exe for a Windows package, for restoring the data backup.
		A confirmation prompt appears if a backup not belonging to this CF card ID is to be restored (see section Creating MyConfig packages (Page 246)).
Setting disabled	Yes	The settings made during the configuration can only be viewed by the
	No	operator during execution, but not changed.

Note

for "Setting disabled"

The setting for selecting the data backup can be disabled for the operating sequence.

The licenses of the controller are also backed up. When restoring a backup, a query appears as to whether the licenses from the backup are to be restored, or the licenses on the control system are to be retained.

Archive

A complete archive can also be created for the diagnostics, with a setting for all data to be backed up.

The complete archive is stored in a folder named based on the CF card ID with the name "Backup_<Date>.arc".

Dialog scripts

Under "Dialog scripts", entry "Scripts", you open the "ScriptEditor dialog - NCU access (<time of execution>)" dialog page via the button.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section at:

- Sections (Page 204)
- Area data (Page 206)
- Control structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

Execution of the "NCU access" dialog page cannot be deactivated.

If at "Package > Data areas > Use NCU" has been selected in the Project / Package tab, this dialog page is executed automatically when executing a package.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-14 NCU access dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.7 Dialog page: Notes on the Service Platform Industry (GSP)

Configuration

You can configure the following property groups for the "Notes on the Service Platform Industry (GSP)" dialog page:

- General
- Operating instructions




Figure 4-15 Notes on the Service Platform Industry (GSP) - Configuration engineer view

General / Operating instructions

More detailed information about the property groups "General" and "Operating instructions" can be found under Dialog page: Notes about acknowledgment (Page 104).

Package execution dialog

A file in text format or restricted HTML format with operating instructions for the following dialog can be displayed on the "Notes on Service Platform Industry (GSP)" dialog.




Figure 4-16 Notes on the Service Platform Industry (GSP) - commissioning engineer/operator view

4.3.2.8 Dialog page: Service Platform Industry (GSP)

Configuration

You can configure the following property groups for the "Service Platform Industry (GSP)" dialog page:

- Dialog
- · Specify machine identity
- Machine information
- Manufacturer data
- Subsidiary data
- Dealer data
- End customer data
- Generate and back up data
- Dialog scripts




Figure 4-17 Service Platform Industry (GSP) - project engineer view

Display all system variables via a dialog button

You open the "Service Platform Industry (GSP) - System variables" dialog via the button display all system variables via a dialog). All system variables to be used under "Service Platform Industry (GSP)" are listed here.

Information on the system variables can be found in the System variables for the Service Platform Industry (GSP) dialog (Page 280) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog

More detailed information about the property group "Dialog" can be found under the dialog page: Notes about acknowledgement (Page 104).

Specify machine identity

The following settings are available for the property "Specify machine identity":

Selection	Yes	Here you specify whether machine identity data is generated and saved
	No	for the GSP data.

Machine information

The following settings are available for the "Machine information" property:

Machine name	Here, you specify the name of the machine.
	Notice
	The machine name is only imported if the "NC archive data (Page 131)" is used on the "System configuration" dialog page.
Machine types (selection file)	The "ma_types.xml" file that contains a list of machine types can be linked or inserted here.
Machine type	Click to display the list of contained machine types and to select a machine type.

Example of file "ma_types.xml" (source: DOC_ON_CD):

```
<?xml version="1.0" encoding="utf-8"?>
<Machine types>
<Type>LC 80</Type>
<Type>LC 82</Type>
<Type>LC 120</Type>
<Type>LC 122</Type>
<type>LC 122</Type>
```

Manufacturer data

The following settings are available for the "Manufacturer data" property:

Manufacturers (selection file)	The "oem.xml" file that contains a list of manufacturers with their addresses can be linked or inserted here.
Manufacturer	The manufacturers contained in the selection file are displayed via the context menu and can be selected.

Subsidiary data

The following settings are available for the "Subsidiary data" property:

Subsidiary (selection file)	The "oemsubs.xml" file that contains a list of branch offices with their addresses can be linked or inserted here.
Subsidiaries	The subsidiaries contained in the selection file are displayed via the context menu and can be selected.

Dealer data

The following settings are available for the "Dealer data" property:

Dealer (selection file)	The "dealer.xml" file that contains a list of dealers with their addresses can be linked or inserted here.
Dealer	The dealers contained in the selection file are displayed via the context menu and can be selected.

Example of file "dealer.xml" (source: DOC_ON_CD)

You can acquire the address data of any number of dealers in file "dealer.xml". If you wish to enter additional dealers, copy the <Dealer> to </Dealer> area for each dealer.

```
<?xml version="1.0" encoding="utf-8"?>
<Addresses>
<Dealer>
<Customer-Id></Customer-Id>
<Name></Name>
<Street></Street>
<ZIP code></ZIP code>
<Location></Location>
<Country></Country>
<State></State>
<Contact></Contact>
<Phone></Phone>
<Fax></Fax>
<E-mail></E-mail>
<URL></URL>
</Dealer>
</Addresses>
```

End customer data

The following settings are available for the "End customer data" property:

End customers (selection file)	The "user.xml" file that contains a list of end customers with their addresses can be linked or inserted here.
End customer	The end customers contained in the selection file are displayed via the context menu and can be selected.

Generate and back up data

The following settings are available for the "Generate and back up data" property:

Selection	Yes	Here, you specify whether the GSP data is to be generated after ex-
	No	ecuting the step and in stored in a folder named based on the CF card ID.

Dialog scripts

Under "Dialog scripts", entry "Scripts", the ... button calls the "ScriptEditor dialog - Service Platform Industry (GSP) (<Time of the execution>)" dialog page.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section at:

- Sections (Page 204)
- Area data (Page 206)
- Control structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

GSP data can be parameterized in this dialog.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).

Note

Templates for the described XML files can be viewed on the NCU under "/card/siemens/sinumerik/hmi/template/identity".




Figure 4-18 Service Platform Industry (GSP) - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.9 Dialog: CNC software

Configuration

You can configure the following property groups for the "CNC software" dialog page:

- Dialog
- Operating instructions
- Installation
- CNC software (*.tgz)
- Dialog scripts




Figure 4-19 CNC software - project engineer view

Display all system variables via a dialog button

You open the "CNC software - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "CNC software" are listed here.

Information on the system variables can be found in the section System variables for the CNC software dialog (Page 276) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Installation

The following settings are available for the "Installation" property:

Mode	None	Here, you select the type of installation.
	New installa- tion	"New installation" means that the CF card is deleted and the system software is reinstalled.
	Upgrade	The subsystems NC, PLC and DRV are overall reset and default data is loaded.
		In the "Upgrade" mode, the NC, PLC and DRV data is migrated immediately after installing the new CNC software, i.e. before the step is executed.
		Note
		Data migration means that the backed-up archive is imported from the old to the new installed software version. Step execution will be performed later based on the archive data of the newly installed software version.
Setting disa-	Yes	Setting for the mode can be disabled for the operation sequence.
bled	No	

CNC software (*.tgz)

The following settings are available for the "CNC software (*.tgz)" property:

List	TGZ files that contain the CNC software are provided by Siemens Support and can be inserted as copy or link in a list.	
	Linked files are not taken into this list until the package is deployed.	
Preselection	A file can be preselected from the list.	
	If no file is preselected, the operator must make the selection on the machine.	
	With the specification of './ <path>/<file>', a file next to the package can be preselected. For example, ./std31a10c_hmi.tgz is then in the preselection.</file></path>	

Note

If the package is started from a service system USB FlashDrive, then generally booting is from the CF card after this dialog.

Dialog scripts

Under "Dialog scripts", entry "Scripts", the button calls the "ScriptEditor dialog - CNC software (*.tgz) (<Time of the execution>)" dialog page.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section under:

- Sections (Page 204)
- Area data (Page 206)
- Check structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

The "CNC software" dialog box is used for installation of new CNC software or for upgrading existing CNC software.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-20 CNC software dialog - commissioning engineer / operator view

Using the "CNC software (*.tgz)" drop-down list, a file that was assigned to the package or a file lying next to the package (prefix: "./") can be selected.

The "Browse" button allows a selection to be made from any location.

After the TGZ file has been loaded, the NCU is automatically restarted.

Note

TGZ files generated using "sc backup xyz.tgz" or backups generated using Create MyConfig can **only** be used for a new installation.

They cannot be used for an upgrade.

If a backup of CMC is used for a new installation, the archive data it contains will be imported.

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.10 Dialog: System configuration

Configuration

You can configure the following property groups for the "System configuration" dialog page:

- Dialog
- Operating instructions
- NC archive data
- PLC archive data
- PLC logic program
- PLC SDB HW Config
- DRV archive data / drive configuration
- Dialog scripts




Figure 4-21 System configuration - project engineer view

The source or output data is provided via the "System configuration" dialog page. This data is then manipulated later on the "SINAMICS topology" and "Step tree" dialog pages. At the end of the execution of the "Step tree" dialog page, the changed data is transferred to the control or the result archive.

On the "System configuration" dialog page, you can define for every archive area (NC, PLC, DRV) whether it should be used.

For "Source of the data", select from where the data of the individual areas should be sourced. This selection can be blocked individually for each area by the project engineer in order to prevent changes by the operator during the package execution.

The PLC area is subdivided into the PLC logic and PLC SDB.

Display all system variables via a dialog button

You open the "System configuration - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "System configuration" are listed here.

Information on the system variables can be found in the System variables for the System configuration dialog (Page 278) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

NC archive data

The following settings are available for the "NC archive data" and are activated when the package is executed:

Table 4-10 NC archive data

Use data	Yes	Here, you specify whether the "NC archive data" is to be used.		
	No			
Origin of data	Note			
		This selection can be blocked by the project engineer in order to prevent changes by the operator during the package execution.		
	Initial state	If the "NCU area" was activated during package configuration, the archive data can be loaded directly from the control with the setting "Initial state".		
		If the initial state is used, the archive is extracted that was located on the control when this dialog box was entered.		
		If the CNC software was installed beforehand, only default data is available in the archive.		
		Note		
		No data is reset when upgrading the CNC software. The archive that is available in the system after data migration is used.		
	Overall reset	If this option is used, default data is loaded and then the archive data is backed up.		
	Offline archive	If this option is used, the output data for the NC area is taken from a stored SINUMERIK archive.		
Setting disabled	No	The selection at "Source of the data" can be blocked by the project engineer		
	Yes	via this option in order to prevent changes by the operator during the package execution.		

List	Under "List", SINUMERIK archives with NC data can be inserted or linked for "Offline Archive". These archives are also saved in the package during deployment and can be selected during package execution.
	Several archives can be linked or inserted via the "List" property, which is available for the preselection or during the package execution for the selection.
Preselection	Under "Preselection", a SINUMERIK archive can be inserted, linked or preselected from the list for "Offline Archive".
	Select an archive from the "List", or enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "./NC-data.arc".</file></path>
	Note
	If data for "Offline Archive" must be entered in the step tree via components, no SINUMERIK archive must be specified in the preselection.

PLC archive data

The following settings are available for the "PLC archive data" and are activated when the package is executed:

Use data	Yes	Here you define whether the archive area "PLC archive data" with the subar-
	No	eas "PLC logic program" and "PLC - SDB HW Config" are used in the package during configuration.
		A change is possible via the package configuration or dialog script.

PLC logic program

The following settings are available for "PLC - Logic program" and are activated when the package is executed:

Origin of data	Note		
	This selection can be blocked by the project engineer in order to prevent changes by the operator during the package execution.		
	Initial state	If the "NCU area" was activated during package configuration, the archive data can be loaded directly from the control with the setting "Initial state".	
		Note	
		No data is reset when upgrading the CNC software. The archive that is available in the system after data migration is used.	
	Overall reset	If this option is used, the PLC memory is overall reset and then the archive data is backed up.	
	Offline archive	If this option is used, the output data for the PLC area is taken from a stored SINUMERIK archive.	
Setting disabled	No	The selection at "Source of the data" can be blocked by the project engineer	
	Yes	via this option in order to prevent changes by the operator during the package execution.	

List	Under "List", SINUMERIK archives with PLC data can be inserted or linked for "Offline Archive". These archives are also saved in the package during deployment and can be selected during package execution.
	Using the "List" property, multiple archives can be transferred, one of which must be selected at runtime.
Preselection	Under "Preselection", a SINUMERIK archive with PLC data (blocks) can be inserted, linked or preselected from the list for "Offline Archive".
	Alternatively, enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "./sdb.arc".</file></path>
	Note
	When data for "Offline Archive" is entered in the step tree via components, an archive from the overall reset state must be saved here or the "Origin of the data" must be set to "Overall reset".

PLC - SDB HW Config

The following settings are available for "PLC - SDB HW Config" and are activated when the package is executed:

Origin of data	Note		
	This selection can be blocked by the project engineer in order to prevent changes by the operator during the package execution.		
	Initial state	If the "NCU area" was activated during package configuration, the archive data can be loaded directly from the control with the setting "Initial state".	
		If the initial state is used, the archive is extracted that was located on the control when this dialog box was entered.	
		If the CNC software was installed beforehand, only default data is available in the archive.	
		Note	
		No data is reset when upgrading the CNC software. The archive that is available in the system after data migration is used.	
	Overall reset	When this option is used, the PLC system data memory is overall reset and then the archive data is backed up.	
		NOTICE	
		Drive configuration is not possible on a PLC-SDB HW configuration on which an overall memory reset has been performed.	
	Offline archive	If this option is used, the output data for the area is taken from a stored SINU-MERIK archive.	
Setting disabled	No	The selection at "Source of the data" can be blocked by the project engineer	
	Yes	via this option in order to prevent changes by the operator during the package execution.	

List	Under "List", SDB archives with system data blocks can be inserted or linked for "Offline Archive". These archives are also saved in the package during deployment and one of them can be selected during package execution.
	Several archives can be linked or inserted via the "List" property, which is available for the preselection or during the package execution for the selection.
Preselection	Under "Preselection", an SDB archive with system data blocks can be inserted, linked or preselected from the list for "Offline Archive". The package specified here is preselected during the package execution.
	An SDB archive can also be saved in addition to the package when the package is being executed.
	Alternatively, enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "./sdb.arc".</file></path>

DRV archive data / drive configuration

In the "DRV archive data / drive configuration" property group, you can define via the "Source of the data" property whether drive commissioning will be performed in the production step by Automatic configuration or User-specified topology.

The following settings are available for the "DRV archive data / drive configuration" and are activated when the package is executed:

Use data	Yes	Here, you define whether the archive area "DRV archive data" is used in the
	No	package during configuration.
		A change is possible via the package configuration or dialog script.

Origin of data	Initial state	If the "NCU area" was activated during package configuration, the archive data can be loaded directly from the control with the setting "Initial state".
		Note
		No data is reset when upgrading the CNC software. The archive that is available in the system after data migration is used.
		During a re-installation of the CNC software, a blank DRV archive would result.
	Automatic configuration	The "Automatic configuration" selection runs through the drive unit configuration during the package execution in the same way as SINUMERIK Operate.
		"Automatic configuration" mode initially restores the SINAMICS factory settings.
		Then automatic HMI device configuration (incl. DO sorting, BICO interconnection, etc) is performed. In this mode, you can work with a "comparison topology (*.ust)", which must be inserted in the "SINAMICS topology" dialog page. This means that the automatically identified SINAMICS target topology can be compared with a comparison topology generated offline.
		In "Automatic configuration", SINAMICS determines the target topology, which determines all modules connected at this time, including their DRIVE-CLiQ wiring.
		In the subsequent package stages, the most recently created online archive is always used. It is only possible to modify the topology by adding, removing, or replacing components via SINUMERIK Operate or configuration must be performed again.
	User-specified top- ology	With the selection "User-specified topology", a SINAMICS offline topology package (*.utz) is loaded during package execution.
		For drive commissioning, a "user-specified topology" can be loaded in a SI-NAMICS offline topology package that also contains modules that will not be attached, wired, and activated until later during commissioning.
		The necessary data objects are created by SINAMICS also for the modules that are not yet present, too, so that the user data can already be loaded during package execution.
		In the subsequent package stages, the most recently created online archive is always used.
		A main application case for this are DQI/SMI motors. The Cu and the NX expansion modules must always be present.
		Note
		When selecting the option "User-specified topology option, the appropriate user-specified topology (*.utz) must also be entered in the "SINAMICS topology" dialog.
	Offline archive	When the "Offline Archive" is set, the data from a SINUMERIK archive is used.
Setting disabled	Yes	The selection at "Source of the data" can be blocked by the project engineer
	No	via this option in order to prevent changes by the operator during the package execution.

List	Under "List", SINUMERIK archives with drive data can be inserted or linked for the "Offline archive". These archives are also saved in the package during deployment and can be selected during package execution.
	Several archives can be linked or inserted via the "List" property, which is available for the preselection or during the package execution for the selection.
Preselection	Under "Preselection", a SINUMERIK archive can be inserted, linked or preselected from the list for "Offline Archive".
	Alternatively, enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "./DRV-data.arc".</file></path>
	Note
	When data for "Offline Archive" is entered in the step tree via components, an archive from the overall reset state must be saved here or the "Origin of the data" must be set to "Overall reset".

Dialog scripts

Under "Dialog scripts", entry "Scripts", the button calls the "ScriptEditor dialog - System configuration (<Time of the execution>)" dialog page.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section under:

- Sections (Page 204)
- Area data (Page 206)
- Check structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Package execution

If the "System configuration" dialog page is executed in editing mode "Manual", the "Origin of data" can be adapted for every area if the project engineer has not locked this.

In the case of "Offline archive", archives must be selected that were either transferred with the package, are located next to the package (prefix "./") or are inserted at any location using the ("Search") button.

To address offline archives from the control or from the archive path, the following prefixes are provided:

- ARC: Archive path that was specified under "Windows access"
- oem: Operate oem/sinumerik/data/archive
- user: Operate user/sinumerik/data/archive
- ADV: HMI-Adv F:\DH\ARC.DIR

Note

If, during package execution, a jump is made to the System configuration dialog page via "Back", then the archives backed up there are reused, and changes that have possibly already been made are rejected.

Examples

Example: Archive next to the package:

./myPath/myArchive.arc

An archive "myArchive.arc" from the folder "myPath", which is located next to the package, is used.

The prefix "./" stands for the current path in which the package file is located at the time of execution.

Example: Archive path as under "Access Windows":

If under "Access Windows", the path "D:\PCU50" has been specified and an archive "myArchive.arc" exists under this path, then this archive can be selected with the entry "ARC:myArchive.arc".

Example: Archive selection of PCU50 Windows 7 (USER)

If an archive "myArchive.arc" exists on PCU50 V5 in the path "C:\Program Files (x86)\Siemens \MotionControl\user\sinumerik\data\archive\", then this archive can be selected in the selection with the entry "user:myArchive.arc".

Example: Archive selection of PCU50 Windows 7 (OEM)

If an archive "myArchive.arc" exists on PCU50 V5 in the path "C:\Program Files (x86)\Siemens \MotionControl\oem\sinumerik\data\archive\", then this archive can be selected in the options with the entry "oem:myArchive.arc".

Example: Archive selection of PCU50 HMI Advanced

If an archive exists on PCU50 with HMI Advanced, it was saved under "F:\dh\arc.dir". This archive can be selected in the options, e.g. with the entry "ADV:MYARCHIV.ARC (MYARCHIVE.ARC)".

Dialog view during the package execution (for commissioning engineers / operators)

In this dialog you set which archive data (NC, PLC, and DRV) will be used later in the subsequent package stages.

Note

If the "Archive area" is activated on the Package tab, the System configuration dialog must be parameterized.

To establish communication between the NCK, the integrated CU, and the NX expansion modules, it is necessary to import an appropriate PLC hardware configuration in the form of an SDB archive. It is not absolutely necessary that the final hardware expansion is included in this SDB archive, but only the information valid for this NCU relating to PROFIBUS, PROFINET, NCU, and NX.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-22 System configuration dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.11 Dialog: Notes on the topology

Configuration

You can configure the following property groups for the "Notes on the topology" dialog page:

- Dialog
- Operating instructions




Figure 4-23 Notes on the topology - project engineer view

Display all system variables via a dialog button

You open the "Notes for the topology - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Notes on the topology" are listed here.

Information on the "Notes on the topology - System variables" can be found in section System variables for Up.\$Dialog.DriveTopologyNotes (Page 278).

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Dialog view during the package execution (for commissioning engineers / operators)

A file in text format or restricted HTML format with operating instructions for the following dialog page can be displayed on the "Notes on the topology" dialog page.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-24 Notes on the topology dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.12 Dialog: SINAMICS topology

Configuration

You can configure the following property groups for the "SINAMICS topology" dialog page:

- Dialog
- Axis-drive assignment
- Comparison topology (*.ust)
- User-specified topology (*.utz)
- DO variables
- Dialog scripts




Figure 4-25 SINAMICS topology - project engineer view

Display all system variables via a dialog button

You open the "SINAMICS topology - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "SINAMICS topology" are listed here.

Information on the system variables can be found in the System variables for the SINAMICS topology dialog (Page 279) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog

More detailed information about the property group "Dialog" can be found under the dialog page: Notes about acknowledgement (Page 104).

Axis-drive assignment

The following options are offered for the "axis-drive assignment", which are activated when the package is executed:

Selection	No Yes	Here, you specify whether the "axis-drive assignment" is to be used.
Setting disabled	No Yes	A change of the "Selection" property by the operator during the package execution can be blocked by the project engineer.

An axis-drive assignment can be performed in both variants, comparison topology and user-specified topology.

The checkbox must be activated to perform the assignment. The condition is that the selected topology contains an axis-drive assignment.

Note

For security reasons, Axis-drive assignment is only permissible with drive configuration "User-defined topology" and "Automatic configuration."

Comparison topology (*.ust)

Note

Prerequisite for comparison topology

On the "SINAMICS topology" dialog page, a comparison topology is always used if, on the System configuration dialog page under DRV archive data / Drive configuration, for "Origin of data" Initial state, Automatic configuration, or Offline archive has been selected.

With the comparison topology, the DRIVE-CLiQ wiring and components are checked based on the SINAMICS target topology from the DRV archive.

The following options are offered for the "comparison topology (*.ust)", which are activated when the package is executed:

List	The button opens the "List of topologies" dialog.		
	Select the desired topology from the list.		
	Comparison topologies can be inserted or linked under "List". These are also saved in the package during deployment and can be selected during package execution.		
Preselection	Select a topology that is to be preselected for the package execution.		
	Alternatively, enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "Comparison-topology.ust".</file></path>		

User-specified topology (*.utz)

Note

Prerequisite for user-specified topology

If, on the System configuration dialog page, User-specified topology has been selected under "Data source", a configured user-specified topology always applies.

If no critical inconsistency with the real topology is found by the drive in the user-defined topology, the user-defined topology is applied as the target topology by SINAMICS.

The following options are offered for the "user-specified topology (*.utz)", which are activated when the package is executed:

List	The button opens the "List of user-specified topologies (*.utz)" dialog.
	Select the desired User-specified topology (*.utz) from the list.
	User-specified topologies can be inserted or linked under "List". These are also saved in the package during deployment and can be selected during package execution.
Preselection	Select a user-specified topology (*.utz) that is to be preselected for the package execution.
	Alternatively, enter the path of a file which is located next to the package "/ <path>/<file>", e.g. "User-specified-topology.utz".</file></path>

Note

The "SINAMICS topology" dialog differs during package execution depending on whether the drive configuration "User-specified topology" or one of the three other variants has been selected in the "System configuration" dialog.

DO variables

The following options are offered for the "DO variables", which are activated when the package is executed:

List	The button opens the "Manage DO variable list" dialog.
	Enter the "DO variable" and its corresponding data here:
	DO type
	DO No.
	DO name
	Description

The following can be defined for a DO variable:

Parameter	Description	Description		
DO variable	Unique name w specifying Up.)	Unique name within the package (without specifying Up.)		
DO type	Type depending	Type depending on the selected category:		
	Category	Туре		
	Control Unit	Integrated (NCU)		
		SINAMICS		
		Extended (NX)		
	Line Module	ACTIVE INFEED CONTROL		
		SMART INFEED CON- TROL		
		BASIC INFEED CONTROL		
	Motion Control	SERVO		
	Terminal Mod- ule	TM31		
	Terminal Board	TB30		
	Hub Module	DMC20 / DME20		
	CULINK	CULINK		
DO No.	NOTE	No number may be assigned for the CU_Link		
DO name	DO name to be	assigned to the drive object.	Characters (max. 24):	
			A-z_0-9	
Description	Additional inform	Additional information for the operator.		

The assignment of the DO number, the DO name and the DO description is optional.

The DO variable list is used in checking manipulation tasks to ensure that only defined objects are accessed.

When a comparison or user-defined topology is applied, this list is mixed with the DO variables it contains if different DO variable lists are used in Expert and Topo.

Both in the comparison topology and in the user-specified topology, DO variables can be assigned to the SINAMICS components, which are declared in the DO variable list of Topo. By assigning a DO variable, all components are identified that belong to a drive object (e.g. a Motor Module, two Sensor Modules).

During package execution, values are assigned to the properties of the DO variables so that, for example, indirect addressing of the DOs for reading and writing parameters can be performed.

If neither a comparison topology nor a target topology is defined, the DO variables from the DO variable list configured in Expert can be assigned manually.

The DO variable list can be exported, imported, or linked. We recommend using the same list in Expert and Topo. The easiest way to accomplish this is to externally save this list and link it in Expert and in Topo. The list can then be viewed and edited by both Expert and Topo.

Note

For DO manipulations using a comparison topology, user-specified topology, or DO list

When changing the DO number, the assigned PS file is renamed and parameters p101 and p978 of the higher-level CU are adapted.

The DO name is entered in parameter p199 of the relevant DO, and the DO variable name in parameter p9489.

BiCos are not automatically adapted. This should be noted particularly for the Line Module.

Note

Conflicts between DO variables as regard type, number, or name result in errors.

Note

The TM31 Terminal Module is not supported by CNC SW 4.4 SP1 with Create MyConfig.

Dialog scripts

Under "Dialog scripts", entry "Scripts", you open the "ScriptEditor dialog - SINAMICS topologyjack (<time of execution>)" dialog page via the button.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section under:

- Sections (Page 204)
- Area data (Page 206)
- Check structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Package execution

Using the "Topology file" drop-down list, a file that was assigned to the package or a file located next to the package (prefix: "./") can be used.

A file from a different location and with another extension (with comparison topology, e.g. XML generated by E-CAD system) can be selected with the "Browse..." button.

Comparison topology

In the interactive assignment of the DO variables to the SINAMICS components, a DO variable must first be assigned to a Motor Module before the DO variable can be assigned to a Sensor Module, so that the association of the sensors to the axes/drives is also defined.

In the comparison topology, additional information can be hidden or displayed for diagnostics in the list and tree view using the "Display additional details" checkbox.

User-specified topology

The three different activation states of the SINAMICS modules "0-inactive," "1-active," and "2-not present" can be adapted interactively. With a click on the relevant cell, the three states are connected.

Keyboard operation is performed with UP/Down in the line and then "-DO" of the "K component".

Dialog view during the package execution (for commissioning engineers / operators)

The "SINAMICS topology" dialog page is displayed here with an example of a **Comparison topology**:

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-26 SINAMICS topology dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.13 Dialog: Version display

Configuration

You can configure the following property groups for the "Version Display" dialog page:

- Dialog
- Operating instructions




Figure 4-27 Version display - project engineer view

Display all system variables via a dialog button

You open the "Version display - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Version display" are listed here.

Information on the system variables can be found in the System variables for the Version display dialog (Page 279) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Dialog view during the package execution (for commissioning engineers / operators)

The applications identified during execution and their determined versions are displayed on the "Version display" dialog.

For the NCU, the information is obtained from the file: "/siemens/versions.xml" and for the PCU from the registry: "HKLM\Software\SIEMENS\AUTSW".

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).

Note

For the version query (see: Steps (Page 166)) for the conditional step execution or in the scripting, the names displayed here should be used as keywords. The names can also be shortened as long as they remain unique.




Figure 4-28 Version Display dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.14 Dialog: Notes on the step tree

Configuration

You can configure the following property groups for the "Notes on the step tree" dialog page:

- Dialog
- Operating instructions




Figure 4-29 Notes on the step tree - project engineer view

Display all system variables via a dialog button

You open the "Notes on the step tree - system variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Notes on the step tree" are listed here.

Information on the "Notes on the step tree - System variables" can be found in section System variables for Up.\$Dialog.StepSelectionNotes (Page 280).

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Dialog view during the package execution (for commissioning engineers / operators)

A file in text format or restricted HTML format with operating instructions for the following dialog can be displayed on the "Notes on the step tree" dialog.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-30 Notes on the step tree dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.15 Dialog: Step tree

Configuration

You can configure the following property groups for the "Step tree" dialog page:

- Dialog
- Step configuration (*.uss)
- Archive
- Dialog scripts




Figure 4-31 Step tree - project engineer view

Display all system variables via a dialog button

You open the "Step tree - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Step tree" are listed here.

Information on the system variables can be found in the System variables for the Step tree dialog (Page 280) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog

More detailed information about the property group "Dialog" can be found under the dialog page: Notes about acknowledgement (Page 104).

Step configuration (*.upcfg)

The following settings are available for the "Step configuration (*.upcfg)" which are activated when the package is executed:

List	The button opens the "List of step configurations (*.upcfg)" dialog.
	Under "List", step configurations (*.upcfg and/or *.uss) can be inserted or linked. These are also saved in the package during deployment and can be selected during package execution.
	Such a list can be exported in the project folder in the Steps tab (Page 166).
Preselection	Select a step configuration that is to be preselected for the package execution.

Further information can be found in the Interface - Step-XML (Page 269) section.

Archive

The settings for the creation of archives before and after execution of the step tree are specified by the project engineer and not displayed during the package execution.

The archives can be used for the diagnostics. They are not required for the production or the upgrade of a machine.

The following settings are available for "Archive":

Create before step tree	Yes	Here, you specify whether an archive with the NC, PLC and DRV areas is to
	No	be created before the execution of the step tree.
		The backup is performed for the NC area with the setting that all data is to be saved.
		With the setting "Yes", the archive is saved with the name 'StepBe-gin_ <date>.arc'.</date>
		The archive is stored in the folder based on the name of the CF card ID which is located next to the package after the package execution.

Create after step tree	Yes No	Here, you specify whether an archive with the NC, PLC and DRV areas is to be created after the execution of the step tree.
		The backup is performed for the NC area with the setting that all data is to be saved.
		With the setting "Yes", the archive is saved with the name 'Ste-pEnd_ <date>.arc'.</date>
		The archive is stored in the folder based on the name of the CF card ID which is located next to the package after the package execution.

Dialog scripts

Under "Dialog scripts", entry "Scripts", you open the "ScriptEditor dialog - Step tree (<time of execution>)" dialog page via the button.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section under:

- Sections (Page 204)
- Area data (Page 206)
- Check structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

On the dialog page, the operator can activate or deactivate interactive steps. The information for the selected step is displayed at the bottom in the yellow field and makes it easier for the operator to understand.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-32 1. Step tree dialog - commissioning engineer / operator view

Using the "Step configuration (*.upcfg)" drop-down list, a file that was assigned to the package or a file located next to the package (prefix: "./") can be used. The "Browse" button allows a selection to be made from any location.

In addition to files of the type *.upcfg, files of the type *.uss can also be used.

The preparation of the execution is confirmed with the "Next" button and it is not possible to return.




Figure 4-33 2. Step tree dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

See also

Steps (Page 166)

4.3.2.16 Dialog page: NCU result

Configuration

You can configure the following property groups for the "NCU result" dialog page:

- Dialog
- Operating instructions
- Data backup CF card
- Archive
- Dialog scripts




Figure 4-34 NCU result - Project engineer view

Display all system variables via a dialog button

You open the "NCU result - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "NCU access" are listed here.

Information on the system variables can be found in the System variables for the NCU result dialog (Page 281) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Data backup CF card

The "NCU result" dialog page is used to back up all of the data of the NCU which runs under the Linux operating system.

The following settings are available for the "Data backup CF card" and are activated when the package is executed:

Perform backup	Yes No	Here, you specify whether a data backup of the CF card including the archive data for the NC, PLC and DRV areas is to be created after the package execution. With the setting "Yes", the data backup is saved with the name ' <cf card="" id="">_result.tgz'.</cf>
		The file is stored in the folder based on the CF card ID which is located next to the package after the package execution.
Setting disabled	Yes	Here, you specify whether the settings made during the configuration are to be
	No	blocked so that they can only be viewed by the operator, but not changed.

Archive

The settings for the archive are defined by the project engineer and are not displayed during package execution.

The archive can be used for the diagnostics. It is not required for the production or the upgrade of a machine.

The following settings are available for the "Archive":

Perform backup	Yes No	Here, you specify whether an archive with the NC, PLC and DRV areas is to be created after the execution of the package.
		The backup is performed for the NC area with the setting that all data is to be saved.
		With the setting "Yes", the archive is saved with the name 'Result_ <date>.arc'.</date>
		The archive is stored in the folder based on the name of the CF card ID which is located next to the package after the package execution.

Dialog scripts

Under "Dialog scripts", entry "Scripts", you open the "ScriptEditor dialog - NCU result (<time of execution>)" dialog page via the \square button.

You can edit scripts here that are to be executed at selectable times during the package execution.

In this dialog, the specified dialog scripts of selected dialogs can be assigned to the desired events (=time) without having to call each individual dialog.

Assignment dialog - Event

The dialogs in which dialog scripts can be assigned to selected times (events), are listed in the Assignment dialog - Event (Page 101) table.

Meaning of the events:

Possible events and their meaning can be found in the Event - Meaning (Page 102) table.

Inserting a script

Information on inserting a script and on the following options can be found in the Scripting (Page 197) section under:

- Sections (Page 204)
- Area data (Page 206)
- Check structures (Page 206)
- Operators (Page 209)
- Functions (Page 212)
- Procedures (Page 231)

Dialog view during the package execution (for commissioning engineers / operators)

A data backup of the CF card including all current control data (NC, PLC, DRV) can be selected on this dialog page.

The data backup is stored with the name '<C cardID>_result.tgz' in the folder based on the CF card ID which is located next to the package after the package execution.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-35 NCU result dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.2.17 Dialog: Finish

Configuration

You can configure the following property groups for the "Finish" dialog page:

- Dialog
- Operating instructions
- Logbook




Figure 4-36 Dialog page: Finish - project engineer view

Display all system variables via a dialog button

You open the "Finish - System variables" dialog via the button (display all system variables via a dialog). All system variables to be used under "Finish" are listed here.

Information on the system variables can be found in the System variables for the Finish dialog (Page 281) section.

Further general information on the system variables can be found in the Reference list system variables (Page 271) section.

Dialog / Operating instructions

More detailed information about the property groups "Dialog" and "Operating instructions" can be found under the dialog page: Notes about acknowledgement (Page 104).

Logbook

The following settings are available for the "Logbook" and are activated when the package is executed:

Path	Here, you define the storage location of the logbook.
Name	Here, you specify the name of the logbook.

Note

Storage location logbook

If a storage path has not been configured, the logbook is stored next to the package.

For the package execution with the **NCU** area, the logbook is also stored on the control under / card/install.

For a package which runs on the **PCU** or Windows PC, it is stored under: d:\UP of the PCU if a PCU is involved.

Dialog view during the package execution (for commissioning engineers / operators)

The "Finish" dialog cannot be deactivated. A file in text format or restricted HTML format can be displayed on this dialog for postprocessing.

The operator can also be prompted to save the logbook when closing the dialog. A logbook that can only be opened after a password has been entered is stored as an *.exe file.

You will find additional information on package execution in the section under Create MyConfig packages (Page 246).




Figure 4-37 Finish dialog - commissioning engineer / operator view

Buttons in dialogs

Information on the general buttons in the dialogs can be found under Meaning of buttons (Page 103).

4.3.3 Steps

On the "Steps" tab, you can create a hierarchically structured step tree.

Structuring of the steps

Because of the structuring of the steps on several levels into main steps and substeps and the possibility of activating/deactivating the individual steps, the different variants of the machines of the series can be modeled by the step tree.

Properties are defined for each step during configuration. The control elements for activation of the steps can be configured both for the \mathbf{m} out of \mathbf{n} selection and for the $\mathbf{1}$ out of \mathbf{n} selection. The step activations that you have specified can also be changed by the operator on the machine during the package execution.

Package execution

When executing the package, the step tree is executed from top to bottom along the **step sequence marked in green**. A step is always executed if its checkbox is green in the display. When a step is executed, any existing step script is first checked. If the step script defines that the step is to be processed further, the components linked to the step will be executed in the configured sequence. Execution then proceeds to the next step.

When generating the step tree using the context menu, steps should be arranged in the sequence that they should be executed when executing the package.

A step name can be freely selected. The numbering has no functional significance and is only used to improve the overall orientation.

The step tree is simultaneously used for navigation when processing/editing components.

Steps can be copied, cut and pasted by means of the context menu. This covers all the properties of a step and its subordinate steps (conditions, component links, notes, etc.).

Note

The external components allocated to the step are linked and are not copied. The link remains.

If steps with internal components are copied between projects, a selection can be made between "Paste" and "Insert as link".

If "Paste" is selected, a copy is inserted as internal component in the target project.

If "Insert as link" is selected, the component remains in the original project and is linked as an external component.

4.3.3.1 Step tree structure

Step tree structure

The step tree has a hierarchical structure encompassing:

- Steps
- Substeps
- Components




Figure 4-38 Example Structure of a step tree

Buttons for the step tree

The display options of the Steps tab are described in the following.



Figure 4-39 Toolbar of the Steps tab

Using the buttons, you can modify the representation of the step tree:

Ф	Expand selection
	Here, you can either display a selected step or the entire step tree with all substeps and components.
= ≡ ▼	Reduce selection
	Here, you can reduce an individually selected step or the entire step tree to the main step. Substeps and components are thus no longer visible.
(a)	Preview for step tree during the package execution
	The project engineer can check the operator view here.
	Collapsed steps are not displayed.
C	Show components
	The components for the displayed steps are displayed or hidden via this button.
.	Display tooltip for steps
	Select this option to display tooltips for steps or substeps.
	Any existing warning messages are also displayed in the tooltip.
—[1] —[2]	Display step ID
	The step IDs are displayed or hidden via this button.
2	Refresh step tree completely (F5)
	Via this button, all of the changes that were made in the entire step tree to steps, substeps and components are refreshed in the display.
	Meaning of the colored display of a link step:
	Blue
	The update was successful.
	Red
	The update could not be performed because the subproject cannot be reached.
	• Purple
	During the update, a difference was found in the main project; the step configuration must be checked. (Purple display only possible for link step that is managed in the main project.)
	Note
	The changes are not saved by the update.
4 û	Down / Up
	Using the arrow keys, you can change the sequence of selected steps, substeps or components which are located on a level.

"Display all system variables via a dialog" button

You open the "System variables" dialog via the button (display all system variables via a dialog).

The "System variables" dialog shows the list of system variables Up.\$Step[<id>] for the currently selected step.

Information on the system variables can be found under the System variables reference list in the Steps tab (Page 282) section.

4.3.3.2 Step properties

Configuration

You can configure the following property groups for each step or substep:

- Step
- Step configuration
- Miscellaneous
- Step scripts

Step

The following settings are available for the property group "Step":

Name	A name can be assigned to each step.				
	This name is not relevant for the functioning, but can help the expert in Expert and the operator on the machine with regard to content and meaning of the step.				
Components	Use the button to open the "Component list" dialog.				
	The available components are listed in the "Component list" dialog. You can change their order using the arrow keys • on the top right.				
	You can link new 📸 or existing 📷 component(s) via the buttons top left.				
	The "Component Explorer" dialog opens for this purpose. Here you can create new components or link existing components.				
	Components can also be deleted from the Component list. You can "Delete the link from the step" ;; this results in the component being retained and it can be linked again via the Component explorer or the component is irrevocably deleted .				
	The components are executed according to the order of their listing from top to bottom when executing the package, provided that the step activation is "green" and the step execution is not skipped due to step scripts.				
	No components must be linked to steps. Steps can also be created for organizational reasons only, e.g. for querying conditions, etc.				
ID namespace	The ID namespace is only displayed if a step from a subproject was linked into a main project.				
	The newly linked step is assigned a unique namespace in the main project. The designation of the namespace can be changed.				
	Further information on the namespace (Page 177).				
ID	When it is created, a step is assigned an ID which is unique in the project.				
	This can be subsequently adapted. Either numeric values or alphanumeric values starting with a letter or '_' are permitted.				
	While executing the step, the activation state of the step can be queried (from other steps or in the scripting) using its ID.				
	Further information on the step activation and ID can be found in the System variables reference list - Steps tab (Page 282) section.				

Step configuration

The following settings are available for the property group "Step configuration":

Management in the	Main project	Specifies where the step configuration is to be managed.	
	Subproject		
Activation	Yes	The "Activation" defines whether a step will be called for execution.	
	No	With "No" this step and all of its substeps are not executed.	
		All steps to be executed according to this logic are identified by a green activation symbol.	
		Note	
		If a step cannot be executed due to the step scripts, the linked components of this step and the substeps will also not be executed.	
		Because this condition can only be evaluated during the package execution, the activation symbols of the associated substeps can still be green.	
Execute Yes No		If "Execute > Yes" is displayed, the step is executed during the package execution, including the stored step scripts.	
		An activated step, which is displayed in green in the step tree, contains the property "Execute > Yes".	
		If "Execute > No" is displayed, a step is either not activated or the green line was interrupted	
		due to the lack of activation in a higher-level step.	
		This step is not considered during package execution.	
Activation disabled	Yes No	If the "Activation is disabled", then when executing the package, the operator can no longer activate or deactivate the step.	
		The context menu allows the selected step to be disabled, including all of the substeps.	
		When executing the package, steps that only contain disabled substeps are collapsed.	
Collapse	Yes No	For the time of package execution, it can be defined for each step whether the step will be collapsed.	
		Substeps can be hidden in this way.	
		The overview for display of the step tree can therefore be configured individually.	
		In the default setting "No", substeps during package execution are displayed.	
		The setting "Yes" hides the substeps.	
		In the configuration view, collapsed steps are displayed in italics.	

Miscellaneous

The following settings are available for the property group "Miscellaneous":

Information text	An information text can be entered for each step; this text is then displayed on the "Step tree" dialog if the particular step is selected or being processed.
Warning message	Optionally, a warning message can be configured which informs the operator that the step is activated or deactivated when clicking the "Finished" button on the "Step tree" dialog page.

None	No warning message is output.
If step activated	A warning message is output if the step is activated.
If step not activated	A warning message is output if the step is not activated.
	The operator then has the option of confirming the setting using "OK" – or after "Cancel" – can correct the step activation before execution is continued.

Step scripts

The following settings are available for the property group "Step scripts":

Scripts	You can call the "ScriptEditor Script - <number and="" name="" of="" step="" the=""> (OnProc)" dialog page here via the <> button.</number>
	A script can be inserted which is executed before the execution of the step.
	For example, a step condition can be programmed in this step script.

4.3.3.3 Edit step tree

Component editor

Double-clicking a component link opens the component in the component editor. Open components are shown in **bold** in the step tree.

A single click on a component that is already open, brings the associated component editor into the foreground.

With the symbol, internal components and with the symbol, external components are displayed.

The content of the function of internal and external components is completely identical. They differ only be their storage location. Internal components are stored in the project folder and external components are stored in any accessible folder. External components can therefore be processed independently of the project.

Context menu

Using the context menu, steps and components can be pasted, copied, deleted and resorted. The following operations are possible:

Conte	Context menu steps			
¥	Cut	Ctrl+X	Cuts the selected step, including the substeps and the links to components.	
	Сору	Ctrl+C	Cuts the selected step into the clipboard, including the substeps and the links to components.	
	Paste	Ctrl+V	Reinserts the step, including the substeps and links to the components, from the clipboard below the selected step.	
×	Delete	Del	Deletes the selected step, including the substeps and the links to components.	

aĵje	Rename		F2	Allows the selected step to be renamed.
	Update link			
	New Step		Ins	Inserts a new step after the currently selected step and selects this.
	New substep		Shift + Ins	Inserts a new substep in the selected step and select this. If a lower level does not exist, then it is created.
•	New step as link			
e -	New substep as link			
	Level Selection Type	multiple (m:n - Check- Box)	Ctrl+T	The steps of a level can either be selected or deselected a multiple number of times (all can be selected/deselected independent of one another) or individually
		normal (1:n - RadioBut- ton)	Ctrl+Shift+T	(selecting one deselects all others).
	Step configuration	Activation	1	
		Activation disabled		The step activation is only disabled for the selected step
	Activation incl. s		bsteps disabled	The step activation of the selected step, including all of the substeps, is disabled.
		Collapse		
		Exporting into file		
		Import from file		
		Load from list		
	Store in list			
	Go to step		Ctrl+G	Selects the step with the ID that should be specified.
	Find		Ctrl+F	
ŵ	Upwards		Alt+Up	Shifts the step in the level upwards in the execution sequence.
4	Downwards		Alt+Down	Shifts the step at its level downwards in the execution sequence.
2	Adapt link			
	Edit link			
<mark>हें</mark> दे	Link new components			Displays the "Component explorer" dialog box, with which a new component can be created. This component is associated with the step.
FG	Link existing component(s)			Displays the "Component explorer" dialog box, with which one or more existing components can be linked with the step.
Conte	xt menu component			
	Edit Component			Opens the selected component for editing in the component editor or brings it to the foreground if it has already been opened.
¥	Cut		Ctrl+X	Cuts the link to the selected component.
	Сору		Ctrl+C	Copies the association with the selected component to the clipboard.

	Paste	Ctrl+V	Pastes the association to the component from the clipboard below the selected component.
×	Remove link	Del	Deletes the selected component, including the association, only after a confirmation query or only removes its association from the higher-level step.
a <u>[</u> e	Rename	F2	Allows the selected component to be renamed.
ŵ	Upwards	Alt+Up	Within the step, shifts the component upwards in the execution sequence.
4	Downwards	Alt+Down	Within the step, shifts the component downwards in the execution sequence.
	Adapt Link		For an external component, it allows the link entry in the component list of the step to be adapted. A new target for the link can be selected in the dialog that opens.
	Edit link		In a dialog, the link path can be manually changed.
æ	Search for components and relink		Opens the "Component explorer" dialog box, with which the selected component can be replaced by another existing component.

Insert a new step

To create a new step, select "New step" via the context menu.




Figure 4-40 Create new step

See also

Dialog: Step tree (Page 155)

4.3.3.4 Linking steps

Introduction

For commissioning machines, sometimes several projects must be managed.

To simplify things for the user, partial or entire step trees from different projects can be linked to one another. As a result of this, recurring step sequences from different projects can be decentrally created and maintained, but centrally managed and executed in one package.

Some examples of this are operator panels, tool magazines, PLC components, etc.

Thanks to this technique of linking the step trees, the commissioning can be reduced to the execution of only one package. The linking of steps allows considerable time savings.


The commissioning engineer sees a complete step tree during project execution. The use of subprojects is no longer visible here.

Due to the linking in step trees, the commissioning of modular machines is supported even more efficiently.

Example

In the following example, the position of a project as the main or subproject is explained and the possible linking depth is shown.

In principle, any project that can run can function as a main project or subproject (an error-free step tree is sufficient in the subproject). A project is designated as a subproject if it serves as a source of the step linking for another project. The main project is thus the project that contains step links from one or more (sub-)projects.



Green connecting line

Permissible step logic operations:

- from subproject Project 2 to the main project Project 1 and
- from subproject Project 3 to the main project Project 2.

Red struck-through connecting line

Impermissible step logic operation:

Step [2] of the subproject Project 2 is already used in the main project Project 1. (Linking depth = 1)

The position of the projects as main project or subproject

Project 1 is the main project and can only run with Project 2 (here: subproject). Prerequisite is that the link to Project 3 shown in red does not exist.

Project 2 is both main project and subproject. From the standpoint of Project 1, it is the subproject. As main project, it can run independently with Project 3 (subproject here).

In this example, **Project 3** is the subproject, but it can also run independently (corresponding to a main project).

Rules

To link steps from one project to another project, one project is defined as the main project (MP) and at least one project is defined as the subproject (SP).

The projects remain independent and no project properties are changed. Each project can thus be used as a main project or a subproject.

The following rules must be observed when linking steps:

 In a main project (MP), several links from the same or different subprojects (SP) can be carried out.

Note

Linking depth with main projects and subprojects

The step trees linked from subprojects must not contain any links to another subproject (linking depth = 1).

- Subprojects are separate projects and can run separately even when linked to a main project.
- The steps are linked by the configuration. When the project is deployed, the configured links are dissolved and the linked steps of the subproject (SP) are inserted into the main project (MP).
- The linked steps retain their step ID from the subproject, in which a namespace is added in the main project for each link, in order to ensure unambiguous identification.
 - The ID namespace is automatically assigned during configuration. This also prevents an ID namespace from being assigned twice.
 - The ID namespace can be changed by the user.
 - The linked steps can be recognized in the logbook by a step ID with namespace.
- Steps with namespace before the step ID cannot be linked and cannot contain any linked steps as substeps.
- The execution of the dialogs (in the project folder) is performed exclusively in the main project (MP) also for the steps inserted in the "Steps" tab.
 Only the step tree is linked or taken over from the subproject(s).

 The system variables used in the linked steps of the subproject (SP) always refer to the main project (MP).

Note

Exceptions are:

- Up.\$Step[ID]
- Up.\$Dialog.StepSelection.CurrentID (see also System variables for the Step tree > Current ID dialog (Page 280))

The system variables can be applied for the main project and subproject.

- The Up script variables are globally applicable in the main project and subproject.
- The same names are permitted for the components in the MP and SP.
- The options of the step configuration ("Activation", "Activation disabled", "Activation disabled including substeps" and "Collapse") can be alternatively managed in the main project or subproject.

Various use cases are thus supported. A subproject can thus be managed independently of the main project if the "subproject" is selected in the main project under "Manage in".

4.3.3.5 Namespace

Requirement

For each link step which is inserted from a subproject into a main project, a namespace, identified as "ID namespace" is created by default.

A defined namespace only applies in a main project for precisely one link step (blue) with the steps located below it (gray). Thus, the step ID does not have to be changed in the main project or subproject.

Identical step IDs in the main project and subproject are thus possible and also permitted.

Existing queries of the step ID in manipulation tasks and step scripts do not have to be adapted in the main project and subproject.

Query steps

The queries in the main project, which concern a linked step in the subproject, are only expanded by the specification of the namespace.

In the subproject, steps of the main project can be queried by specifying the namespace "." (period).

If the subproject runs separately, the specification of the namespace "." is for a return value "Null". This implementation ensures that a step query always refers clearly to one and the same step, in this case for "." in the main project. This must be taken into account in the programming.

Example for step query

The following shows how a query can be made from one project to another project whether the steps are active. The status in the relation of the projects to one another is either a main project (MP) or a subproject (SP).




Figure 4-41 Step guery - example

The query in the figure shown above returns a value of "Null" for an independent execution of the subproject (SP).

Before this query, the existence of the step in the main project (MP) can be checked.

Example:

```
If Up.$Step[.2] != Null
```

- OP.19 is namespace in the main project for linked steps from a subproject
- Instead of Activated, the following may apply:

```
If Up.$Step[2].Processing == true
If Up.$Step[2].Locked == true
If Up.$Step[2].Collapsed == true
If Up.$Step[OP19.2].Processing == true
If Up.$Step[OP19.2].Locked == true
If Up.$Step[OP19.2].Collapsed == true
```

Summary example step query

Within a project (the status of the project can be both a main project and/or subproject), the step query is the following:

• If UP.\$Step[2].Activated ==true

Depending on which direction the query is started in, from MP to SP or vice versa, the condition for the step query must be formulated as follows:

- In the main project to the step of the subproject: If UP.\$Step[OP 19.2].Activated == true
- In the subproject to the step of the main project:
 If UP.\$Step[.2].Activated == true

Logbook entry

In the logbook, the namespace with a period "." is displayed for steps of the subproject separately from the step ID, e.g. **OP19.1**.

Reserved identifiers

Alphanumerical characters are permissible for the namespace. Reserved identifiers such as UP, Main, True, False, Null are excluded.

Note

Do **not** use any reserved identifiers of the script language, e.g. "True", "False", "Up", "Main", "Null", in the name space.

4.3.3.6 Creating a step link

Procedure

The following shows how a step is copied from a subproject (SP) and inserted into a main project (MP).

1. In the Steps tab in a project of your choice, which you use as a subproject (SP), select a step and copy it via Ctrl+C or the context menu.




Figure 4-42 Copy link step

Note

Drag and drop is not supported when linking steps.

2. Open the main project (MP) and insert the step via Ctrl+V or via the context menu as shown in the following.





Figure 4-43 Insert link step

3. In the newly inserted step, you can now read that an "ID namespace" has also been assigned in addition to the step ID.

The "Management in" property is also new; per default the subproject is specified from which the step was copied.

4.3 Project folder



Step properties of linked steps

For the step link and all substeps, all step properties are taken into the main project. The step properties are displayed and saved in the project.

The step properties shown in gray cannot be changed in the main project. The ID namespace produced by the step link can be changed at any time in the link step marked in blue.

The management of the step configuration is set on the subproject when creating a step link. This setting can be changed to the management in the main project.

The "Management in" property specifies whether the step configuration of the gray link step below the blue link step is to be managed in the main project or the in the subproject. The management of the step configuration for the blue link step is always performed in the main project.

4.4 Component editor

4.4.1 Components

So that a component is executed when executing the package, it must be linked with a step and the step must be selected for execution (green symbol). An existing step script can permit or prevent the execution of the components.

The component contains actions. All the relevant operations and data are inserted in the respective actions under the relevant tab during configuration.

The actions to be performed by the component can be activated in the "Actions" tab.

The following actions can be created:

- Execute (Page 184)
- Delete (Page 187)
- Copy (Page 189)
- Change (Page 192)
- Manipulate (Page 194)

During the execution of a component by the package, the activated actions are executed in the order of their listing from top to bottom. If in practice, another order is desired, the order of the actions in the list can be adapted using the toolbar or context menu "Up (Alt+up)" or "Dwon (Alt+down)".

In order to edit an action, it must first be opened by double-clicking or via the context menu. A tab is displayed for this action on which various tasks can be configured.

Files and folders can be inserted below the "Execute" and "Copy" actions both as a copy and a link. A mixture of copied and linked objects is also possible.

In the "Delete", "Change" and "Manipulate" actions, tasks can be directly created using the appropriate operations, imported from a file or linked to an external file. In all cases, it is possible to directly edit the tasks with the task editor integrated in Expert. This has the advantage that the support from Expert is always offered.

All links are only cancelled when the package has been deployed and the data has been accepted in the package. In this case, the advantage of the link is that the source data can be updated independently of the project until deployment.

A version can be assigned to the component. This version is noted in the logbook when executing the package.

Information about the components can be stored in the "Comment" field. The text is not displayed during execution and is also not taken into the logbook.

4.4.2 Execute

Execute action

The "Execute" action allows a program, command or script to be executed. For instance, software components from SIEMENS or other suppliers can be installed or special manipulations made in the archive or other target areas.

The following target areas are supported:

- NCU
- PCU (Windows XP) and PCU (Windows 7)
- Linux (runtime system)
- Windows (runtime system)

All the files and folders required for execution can be inserted as a copy or link under the respective target area. When deployed, the links are cancelled and the folders and files are accepted in the component.

Target areas that do not contain any data or operations are shown in gray.

You can specify a command or an executable file in the "Execution of:" text field. It is also possible to transfer arguments, separated by spaces, such as file names, switches, etc. In this case, it must be observed that commands or file names that have a space must be written in inverted commas.

The Special operators (Page 211) can be used at any place in the text field.

Note

The name of the selected file can be transferred to the "Execute" text field using the associated button (4).

Execute - NCU

When executing, all folders and files are unzipped into a temporary folder. This folder is used as work directory when executing and is then deleted.

The script outputs are transferred to the logbook. In this case, the error messages (stderr) of the programs called in the script are entered in *italics*.

The return value of the script is evaluated as terminating error code, i.e. a return code not equal to 0 results in an error message and the user must decide whether the package should be cancelled or continued.

See also the section below: "Additional useful notes"

Execute - PCU - Windows XP or Windows 7

When executing, all folders and files on the PCU are unzipped in a temporary folder. When executing, this folder is used as a work directory and is then deleted.

For an installation, additional operator actions may be required on the PCU.

Execution on the PCU is controlled via the PCU handler that runs as a setup application on the PCU.

When a communication error occurs, the PCU can be exited by pressing the key combination Shift+Esc (Shift+ ALARM CANCEL).

Examples of "Execution of"

```
Setup.exe -OF:opfile.sl
Cmd.exe "my start.cmd" /x /y /z
```

PCU handler yields return to Shield

As of Create MyConfig Version V4.7, the following function expansion applies:

The return value of programs which were executed by the PCU handler is returned to the package execution and logged in the logbook.

Example with return value 0

The return value of the script is evaluated as terminating error code, i.e. a return code not equal to 0 results in an error message and the user must decide whether the package should be canceled or continued.

Execute:

```
cmd /c echo "Examle using exit 0" && exit 0
```

The entry in the logbook that results from this is:

```
Execute
[execute] installations, scripts
Execute PcuWinXP
PcuWinXP
cmd /c echo "Examle using exit 0" && exit 0 started
cmd /c echo "Examle using exit 0" && exit 0 ended 0
```

Example with return value 1

Execute:

```
cmd /c echo "Examle using exit 1" && exit 1
```

The entry in the logbook that results from this is:

See also the section below: "Additional useful notes"

4.4 Component editor

Execute - runtime system

A package can be deployed for various runtime systems. In order to now also be able to deploy a package for Linux and for Windows that makes special changes via "Execute" in the "Archive" area, two scripts must be written. Depending on the runtime system, Windows or Linux, the corresponding node is automatically executed and the other skipped during execution. All folders and files are unzipped in a temporary folder; this folder is then used as work directory and subsequently deleted.

The script outputs are transferred to the logbook. In this case, the error messages (stderr) of the programs called in the script are entered in *italics*.

The return value of the script is evaluated as terminating error code, i.e. a return code not equal to 0 results in an error message and the user must decide whether the package should be canceled or continued.

Example

All of the files – with the exception of OEM001.SPF – are to be deleted from the CMA.DIR directory of the NC. As there is no special delete instruction for this purpose, a script is generated which saves the file to be obtained, subsequently deletes the folder and then returns the file. The particular script file is copied to the component and when executing, entered as command.

Windows

```
Md .\Save
Move %UP_ARC%\NC\CMA.DIR\OEM001.SPF .\Save\
Del /Q %UP_ARC%\NC\CMA.DIR\*.*
Move .\Save\OEM001.SPF %UP_ARC%\NC\CMA.DIR\
Linux
mkdir ./Save
mv $UP_ARC/NC/CMA.DIR/OEM001.SPF ./Save/
rm -r $UP_ARC/NC/CMA.DIR/*
```

mv ./Save/OEM001.SPF \$UP ARC/NC/CMA.DIR/

Additional useful notes

Environment variables

UP_PACK	Location from where the package was started. Therefore, points to the same path, as "./" - next to the package.
UP_ARC	Temporary storage location of the archive tree with the subfolders NC, PLC, CP, and DRV
UP_CFID	ID of the CompactFlash card Only available for packages with the NCU area.
UP_SHARE	Folder for exchange release between the PCU and NCU Only available for Windows packages with the NCU area. This environment variable points to the shared folder under Windows and to the mount point under Linux.
UP_PCU_ROOT	Computer name of the PCU Only available for packages with the PCU area.

UP ARC ROOT Folder of the archives to be processed

Only available for packages that solely address the ARC area.

General

A script should preferably always be exited with exit 0 if no internal script error handling is performed.

PCU/Windows

Under Windows, the command interpreter should be used as prefix for command line scripts.

For example:

Cmd.exe /c test.cmd.

NCU/Linux

With shell scripts (sh) for Linux, it must be ensured that data is saved in the Unix file format, only LF not CR/LF.

The shell ID (e.g. #!/bin/sh) must be located in the first line – or the script should be started using a shell command (e.g. sh my script.sh).

A shell should be used as a prefix if you wish to specify commands directly with place holder or environment variables (e.g.: sh rm /user/*.log). If a file is specified for execution, './' should be used as a prefix (e.g.: ./test.sh).

4.4.3 Delete

Deleting action

The "Delete" action allows files and folders to be deleted in the target area.

You can create the paths in which the files and folders to be deleted are located on the nodes in the target area. This is supported by the context menu entry "Known folder".

Target areas, that do not contain any delete tasks, are shown in gray, inserted folders that are not permissible, in red.

The following target areas are supported:

Archive Archive image NC, MMC, PLC, CP, DRV NCU Root of the NCU card, user, oem, addon

PCU (Windows XP) Drives/enables of the PCU C:, D:, E:, F:

PCU (Windows 7) " C:, D:

HMI Adv HMI Advanced drive DH (data management), USER,

OEM, ADD ON

Operate Folder of SINUMERIK Operate hmisl or card

Note

Delete instructions in the target area: Archive/MMC are only applied to the archive and do not affect the data management of HMI Advanced F: DH.

4.4 Component editor

A "Task" must be created using the context menu in order to be able to enter delete operations. The operations can be sub-divided into several tasks in order to improve the structure. The task name can be freely selected.

When executing, the specified files are deleted without any prior confirmation prompt.

Tasks can be created in the following ways:

- New task
 - Enter the operations directly into the operation editor. You can choose any name for the task
- Importing a task
 - Import the operations that are saved in an external file. The task name is allocated the name of the imported file. After importing, the task name and the operations in the operation editor can be edited without changing the original file.
- Linking a task
 - An external file that contains operations is linked as task. The task name is allocated
 the name of the linked file and can be subsequently changed. The linked file can still be
 edited either externally or in the operation editor, whereby the supporting context menu
 is available in the operation editor.
 - When transferring, the task is accepted in the package.

Task editor

The names of the files and folders to be deleted are specified under "Operations". The place holders "*" (none or one or several characters) and "?" (any character) are permissible in the file names.

On the other hand, *no* place holders are permitted in the folder names. Folders are deleted with all of their contents.

Only one delete operation is permissible per line.

If a line starts with the ";" comment character, it is not evaluated.

Examples:

Cycle*.spf	All cycles in the current folder are deleted.
* . *	All files in the current folder are deleted, subfolders are kept!
4711.WPD	Folder 4711.WPD with all of its contents is deleted.
0C00022	The FC22 is deleted.

Additional useful notes

HMI Adv / DH

An error tolerant procedure is used for delete operations as well as when navigating.

A check is first made as to whether the name corresponds to a data management name. If this is the case, then the system uses the information from the data management. Otherwise, a check is made as to whether this name exists at the operating system level and is not assigned to another data management entry. If this is the case, then the system uses the information from the operating system.

Archive/PLC

To delete PLC blocks, these must be specified in the archive name convention.

The naming convention has the format: ${\tt TTNNNNN}$, whereby ${\tt TT}$ stands for the hexadecimal type, and ${\tt NNNNN}$ for the decimal number of the block. When necessary, both should be filled up with leading zeros to obtain 2 or 5 positions respectively.

PLC block types:

08 - OB Organization block

OA - DB Data block

OB - SDB System data block

OC - FCFunctionOE - FBFunction block

NCU

Operate

In contrast to Windows, the file system used on the NCU differentiates between upper and lower case.

For the "Operate" target area, create the "All", "NCU" or "PCU" folders using known folders. This folder is used to define for which SINUMERIK Operate the tasks are to be processed.

Under this folder, you define the path to the files to be deleted.

The tasks stored under "All" are processed on the NCU and on the PCU. The tasks stored under the other two folders are only processed on the associated system.

4.4.4 Copy

Copy action

The "Copy" action enables folders and files in the target area to be copied. You can insert folders and files in the component as a copy or link under the target areas.

Note

Possible via the context menu "Linking to the folder content"

Link to folder contents means that the link is to a folder, the contents of which are completely copied into the folder of the target area.

The name of the linked folder does not appear in the package.

4.4 Component editor

When you transfer the package, links are canceled and the objects transferred into the component.

The tree view already contains the possible "target areas" as root nodes.

You can create folders below the root nodes using the shortcut menu. The "Known folder" menu item makes entry simpler.

During execution, existing files are overwritten without a confirmation query.

The following color conventions are used to support the operator:

- gray target areas that do not contain any data to be copied
- red folder of file is not permitted in the current path
- black target areas and folders that contain data to be copied

The following target areas are supported:

Archive Archive image NC, MMC, NC_MMC, PLC, CP, DRV

NCU Root of the NCU card, user, oem, addon

PCU (Windows XP) Drives/enables of the PCU C:, D:, E:, F:

PCU (Windows 7) " C:, D:

HMI Adv HMI Advanced drive DH (data management), USER,

OEM, ADD_ON

Operate Folder of SINUMERIK Operate hmisl or card

Copying in the data management (HMI Adv, archive)

For folders and files in the data management, names with characters: $A-Z_0-9$ and a maximum length of 24 characters are permissible.

Further, especially folders are subject to the data management schematic regarding their names.

The "Known folder" context menu entry makes it easier for you to create folders; this lists all of the permissible subfolders of the selected node.

The following options are available when copying in the data management:

HMI Adv / DH Copies to the PCU in the F:\DH folder - and at the same time adapts the

necessary entries in the HMI Advanced data management (saved in the files: __dhinf.000). This is the preferred procedure in order to transfer large

data volumes (bmp, pdf, hlp, ...) to the controller.

NOTE:

When copying files, files with the same name in archive/NC or archive/

MMC are deleted.

Archive/NC Copies to the NC area of the archive. When loading the archive, all the

data contained therein is transferred directly to the NC.

NOTE:

When copying files, files with the same name in archive/MMC or

HMI Adv / DH are deleted.

Archive/MMC Copies to the MMC area of the archive. When loading the archive, all the

data contained therein is transferred directly to the HMI (MMC).

Using the archive/NC_MMC, the functionality of an MMC archive can be implemented to replace data there where it was already located.

NOTE:

When copying files, files with the same name in archive/NC or

HMI Adv/DH are deleted.

Archive/NC_MMC Copies to the NC area of the archive, if the file is already available there.

Otherwise the file is copied to the MMC area. Regarding loading the ar-

chive, the statements made above apply.

NOTE:

When copying files, files with the same name in archive/NC, archive/MMC

or HMI Adv/DH are deleted.

The sequence when executing is specified:

 ${\tt HMI-Adv/DH} \rightarrow {\tt Archive/NC} \rightarrow {\tt Archive/MMC} \rightarrow {\tt Archive/NC} \ {\tt MMC}$

Additional useful notes

HMI Adv / DH When copying and navigating, an error-tolerant procedure is used. A check

is first made as to whether the name corresponds to a data management name. If this is the case, then the system uses the information from the data management. Otherwise, a check is made as to whether this name exists at the operating system level and is not assigned to another data management entry. If this is the case, then the system uses the information from

the operating system.

Archive/PLC To copy PLC blocks, they must be specified in the archive naming conven-

tion.

The naming convention has the following format: TTNNNNN, whereby TT stands for the hexadecimal type, and NNNNN for the decimal number of the block. When necessary, both should be filled up with leading zeros to obtain 2 or 5 positions respectively.

PLC block types:

08 - OB Organization block

0A - DB Data block

OB - SDB System data block

OC - FC Function

OE - FB Function block

For easier identification of the function block types, the plaintext names in parentheses are shown behind each of

the naming conventions.

The blocks must be stored in TTNNNNN format.

4.4 Component editor

NCU In contrast to Windows, the file system used on the NCU differentiates be-

tween upper and lower case.

Operate For the "Operate" target area, create the "All", "NCU" or "PCU" folders using

known folders. This folder is used to define for which SINUMERIK Operate

the files are to be copied.

Below these folders, you now create the path for the files to be copied.

The files stored under "All" are stored on the NCU, and when a SINUMERIK Operate is available on the PCU, also saved there. The files stored under

the other two folders are only stored on the associated system.

4.4.5 Change

Change action

The "Change" action allows data in the configuration files to be adapted. Configuration files are text files comprising one or more sections including value assignments:

[Section]

Identifier=value

Generally, the ini extension is used for configuration files. However, all files that have the structure of an ini file can be changed.

The possible target areas are specified in the tree view. Using the context menu, additional folders below this can be created, whereby the "Known folder" menu entry simplifies entry.

The following target areas are supported:

Archive Archive image NC, MMC, NC_MMC, PLC, CP, DRV

NCU CompactFlash card of the NCU user, oem, addon PCU (Windows XP) Drives/enables of the PCU C:, D:, E:, F: PCU (Windows 7) " C:, D:

HMI Adv HMI-Advanced drive DH (data management), USER,

OEM, ADD ON

Operate Folder of SINUMERIK Operate hmisl or card

To enter change operations, use the context menu to create a "task" in the folder that contains the file to be changed.

The name and path of a task specify the file to be changed.

Tasks can be created in the following ways:

New task

 Enter the operations directly into the operation editor. You can choose any name for the task.

Importing a task

 Import the operations that are saved in an external file. The task name is allocated the name of the imported file. After importing, the task name and the operations in the operation editor can be edited without changing the original file.

Linking a task

An external file that contains operations is linked as task.
 The task name is assigned the name of the linked file and can be subsequently changed.
 The linked file can be either edited externally or in the operation editor, whereby the supporting context menu is available in the operation editor.
 When deploying, the task is accepted in the package.

Task editor

Based on the structure of the configuration files, change operations should be specified specifying the section. They comprise an identifier, operator and possibly the value. Enter these line-by-line. The context menu supports inserting operators.

Lines that start with a semicolon ";" are not evaluated and can be used for *comments*. The Special operators (Page 211) can be inserted at any place within a line in order to insert the contents of UP variables to be changed.

Note

If folder, file, section or identifier are not available, then the package itself generates these in order to implement a value assignment.

Operators

=	Assignment of a new value	
~	Deleting data, i.e. identifier and value are removed	
?=	?= Assigning a (new) value, if no (old) value is available	

Example:

```
[LANGUAGE]
FontList=Europe, Europe, Europe, Europe
[Local]
ADRESS0=0,NAME=/NC,LINE=11
ADRESS1~
[Function]
Del. Dir query1?=111
```

4.4 Component editor

Additional useful notes

Operate

For the "Operate" target area, create the "All", "NCU" or "PCU" folders using known folders.

This folder defines for which SINUMERIK Operate the tasks are to be processed.

Under this folder, you define the path to the files to be modified.

The tasks stored under "All" are processed on the NCU and on the PCU. The tasks stored under the other two folders are only processed on the associated system.

Changes of display data of the SINUMERIK Operate are possible via the actions "Change" and "Manipulate" in CMC. It makes sense to use only one of the two methods (preferably "Manipulate"), because they affect one another.

4.4.6 Manipulate

Manipulate action

The "Manipulate" action allows machine data to be accessed, essentially independent of the data storage in the control system.

The data to be manipulated can be stored in the archive (e.g. NC data, drive data) as well as in the HMI (display data).

Data manipulation operations are supported in the following "target areas":

- NC data
- SINAMICS data
- Display data

Additional information on the possibilities associated with manipulation tasks is provided in the description of the script language (see: Introduction to scripting (Page 197)).

A "Task" must be generated using the context menu in order to be able to enter manipulation operations. The operations can be sub-divided into several tasks in order to improve the structure. The task names can be freely selected.

Tasks can be created in the following ways:

New task

 Enter the operations directly into the operation editor. You can choose any name for the task

Importing a task

 Import the operations that are saved in an external file. The task name is allocated the name of the imported file. After importing, the task name and the operations in the operation editor can be edited without changing the original file.

Linking a task

An external file that contains operations is linked as task.
 The task name is assigned the name of the linked file and can be subsequently changed.
 The linked file can be either edited externally or in the operation editor, whereby the supporting context menu is available in the operation editor.
 When deploying, the task is accepted in the package.

Task editor

Manipulation tasks are executed by the package and **not** by the NC or the HMI. Processing is line-oriented up to the end of the line or the comment character ';'. Except for string values, upper/lower-case and spaces are not relevant for the notation. Example: "ID = 0" corresponds to "id=0"

Note

Exception

String values form an exception as upper/lower-case and spaces are relevant.

In a simple case, data manipulation operations comprise consecutive assignments: Block number (optional), identifier, operator and value. A section should be set first, such as the channel number or the drive object path.

The context menu provides support when inserting sections, control structures, functions, procedures, operators and system variables. A catalog is also available listing all the identifiers specified by SIEMENS.

The operation editor marks the syntax of faulty entries with a red wavy line. Syntax errors in the task can be easily found using the "Go to next error" context menu entry.

The formatting (simplified Qt-html) within your texts for the functions and procedures can be checked via the "Message preview" context menu entry. To do this, mark the entire text within the quotation marks and click "Show preview" in the context menu.

Example of an operation

4.4 Component editor

Additional useful notes

NC data

NC data is manipulated, based on the NC archive area.

If a context is not set using CHANDATA(n), then channel 1 is assumed.

NOTICE:

With multi-channel assignments, make sure that CHANDATA(1) is set in front of data that is **not** channel-dependent!

If NC data is to be manipulated, in relation or depending on its old value (e.g.: operators +=, *= etc.), then it must be ensured that this data is also in the NC offline archive (take into account machine data: 11210 UP-

LOAD_MD_CHANGES_ONLY and 11212 UPLOAD_CHANGES_ONLY).

In the case of "Source of the data," "Initial state," or "Overallreset," all NC data is always provided.

When loading an archive to organize the memory, the NC requires certain machine data that is in the *upload files* (NC.OPT, GLOBAL.IN, SCALING.INI and CHAN.INI) located in front of INITIAL.INI. Before manipulation, the package loads all data from the INITIAL.INI to the memory, completes the manipulation operations and then writes back all the data. All previously existing data is written back to its old position, both in the INITIAL.INI and in the upload files. Additional data is attached to the data of the INITIAL.INI - and according to the following rule - also to the data of the upload files:

- NC.OPT, if the identifier starts with \$ON
- GLOBAL.INI, if the identifier starts with \$MN or \$MA
- SCALING.INI, if the identifier starts with \$MN or \$MA
- CHAN.INI, if the identifier starts with \$MN or \$MC

If NC data is manipulated, then the *line checksum* is generated and attached to all data.

SINAMICS data

Drive data is manipulated, based on the DRV archive area.

Display data

Display machine data is saved differently for HMI-Advanced and SINUMERIK Operate.

For $\mathit{HMI-Advanced}$, data is read from the section: <code>[OPI settings]</code> of the file: "MMC.INI" in the search sequence: <code>HMI_ADV \rightarrow MMC2 \rightarrow ADD_ON \rightarrow OEM \rightarrow USER</code> but is only written back to <code>MMC.INI</code> under <code>USER</code>. When deleting data, this results in a reset to a user-specified value of preceding files in the search sequence.

For SINUMERIK Operate, data is read from the section: [OPI settings] of the file: "hmi_md.ini" in the search sequence: $siemens \rightarrow addon \rightarrow oem \rightarrow user$, but is only written back to $hmi_md.ini$ under user. When deleting data, this results in a reset to a user-specified value of preceding files in the search sequence.

4.5.1 Introduction to scripting

In the Scripting section you will find general information on script instructions:

- Color coding of program elements (Page 199)
- Set channel (Page 199)
- Cross-area access (read) (Page 200)
- Package variables (Page 201)
- Comments (Page 204)

Call scripting

Scripting an be used in:

- Dialogs
- Steps
- Manipulation jobs

Further information on scripting and "Inserting a script" can be found in the section Scripts under Dialogs, Steps, and Manipulation jobs (Page 204).

Dialogs

On selected dialog pages, scripts can be executed before displaying the pages, when clicking the "Next" button, and at the end. The processing of the current and subsequent dialogs can be controlled with these scripts.

Proceed as follows to call scripting in dialogs:

- 1. In the Dialogs tab, choose Dialog scripts > Scripts.
- 2. Use the button to open the ScriptEditor dialog.
- 3. Right-click in the dialog to select via the Insert Script context menu.
- 4. Select from the available options:
 - Section
 - Identifier
 - Check structure
 - Operator
 - Function
 - Procedure

Steps

Under every step in the step tree, scripts can be executed before the step is processed. The current and all subsequent steps can be controlled from these scripts.

Proceed as follows to call scripting in the Steps tab:

- 1. Choose Step scripts > Scripts.
- 2. Click to open the ScriptEditor Step dialog.
- 3. Right-click in the dialog to select via the Insert Script context menu.
- 4. Select from the available options (see dialogs).

Manipulation jobs

In the Component Editor, scripts can be added under actions of the type "Manipulate".

Proceed as follows to use scripting for manipulation jobs:

- 1. Select the Manipulate tab in the Component editor.
- 2. In the Instructions window, right-click to open the Insert Script context menu.
- 3. Here you can select between available options (see dialogs).

Section Scripting describes a simple programming language based on known elements of other programming languages. Scripts can be created for dialogs, steps, and manipulation tasks.

The task editor supports creation of scripts with syntax checking, syntax emphasis, automatic completion, and with an extensive shortcut menu.

Overview of the script language

Fundamentals		Control structures	
→ Set channel (Page 199)	CHANDATA(1)		If
→ Sections (Page 204)	[B3_S3_PS1]	while control structure (Page 208)	While
→ Area data (Page 206)	R[1], p105	↓ Logic operators / comparison operators (Page 211)	true != false
Package variable		Procedures and functions	
→ Package variables (Page 201)	Up.name	→ Procedures (Page 231)	Msg()
→ Script variables (Page 202)	Up.myVar	→ Exists (Page 229)	Input()
→ DO variables (Page 203)	Up.doVar.doNr	Miscellaneous	
→ Step activation	Up.\$Step[1]	↓ Commenting (Page 204)	;
↓ Querying package properties (Page 272)	Up.\$Pack	-	-
→ Querying dialog properties	Up.\$Dialog	-	-
Assignment and calculation		↓ Special operators (Page 211)	\$(Up.ax)
→ Assignment operators (Page 209)	= ~ ?=	-	-
→ Arithmetic operators (Page 210)	+ - * / &	-	-

4.5.2 Color coding of program elements

For better orientation, important program elements are color coded in the task editor and in the step condition editor. The remaining program elements are displayed black and unformatted.

The meaning of the colors is shown in the following:

Program element	Color	Formatting	Example
Comment	Dark green	Italic	; Kommentar OK
Keyword	Blue	Bold	#include "Datei.txt"
Sections	Black	Bold	Chandata(1) [C1] [B3_S3_DO1]
Decimal numbers	Blue	-	DEZ = 123 ; DEZ_GP = 123.45 DEZ_EX = 123ex-1 VER = 2.6.1
Binary numbers Hexadecimal numbers Binector/connector (BiCo)	Violet	-	HEX_NC = 'H123' HEX_0x = 0x123 BIN_NC = 'B0101' BICO = 3:1.23
String	Chestnut brown	-	STR = "text"
Procedures	Dark cyan	Bold	<pre>Msg("Text") ; Warning("Text") Error("Text")</pre>
Functions	Violet	Bold	BOOL = Exists(NCU, "test") VER = Version(NCU, "test") VAR = Input("trala")
User frames (variables that have not been interpreted)	Yellow/orange	-	<pre>\$P_UIFR[1] = CTRANS(x, 0.5, y 0.2)</pre>

4.5.3 Set channel

Set channel - CHANDATA (?)

For NC data with the same name that comes a multiple number of times (e.g. channel data) before value assignments, the channel to which it belongs must be specified. This channel specification is effective as long as no other channel setting is made via CHANDATA() operation. Data accesses between areas are unaffected by this.

When the channel is not specified, then channel 1 is automatically used.

Examples

CHANDATA(1)

```
;channel 1 is set as an area as of here
$MC_CHAN_NAME = "Channel 1"
Up.NAME_CHAN_3 = NC[C3].$MC_CHAN_NAME; access across areas
to channel 3
Up.NAME_CHAN_1 = $MC_CHAN_NAME; access to channel 1
CHANDATA(2)
;Channel 2 is set as of here
$MC_CHAN_NAME = "Channel 2"
[C3] ;alternative abbreviation
;Channel 3 is set as of here
```

NC data

Syntax	Description
NC[Ci]. <nc-variable></nc-variable>	The value of the NC machine data "NC variable" in the "i" channel within the NC archive. If the data is not found, the null value is returned. The channel specification "i" must be assigned a value between 1 and 10.
	Example:
	NC[C5].\$MC_CHAN_NAME

4.5.4 Cross-area access (read)

As an alternative to setting the channel for NC data, the channel can also be specified directly during access (local). This channel specification has a higher priority compared to the last setting for the channel (CHANDATA() operation).

As an alternative to setting a section, the section can also be specified directly during access (local). This section specification has a higher priority compared to the last setting for the section (section setting [B? S? PS??], [ADV], [SL]).

In order to be able to access channels or sections from step scripts, cross-area access must be used.

Syntax

The syntax for cross-area access is generally:

Namespace[section].variable

Namespaces

The following namespaces are defined:

Namespace / target area	Channel / section input	Format example
BD (display data)	HMI of the target system	BD[ADV].\$MM_LCD
	ADV - HMI-Advanced	BD[SL].\$MM_LCD
	• SL - SINUMERIK Operate	
NC (NC data)	Channel C1, C2 C10	NC[C2]. \$MC_MM_NUM_AC_PARAM
PS (SINAMICS data)	Subpath within the drive system B3_S3_PS3, B3_S15_PS99	PS[B3_S3_PS1].p105

Example: Cross-area access in step script

Example: Cross-area access in the NC data manipulation task

```
[C1] ; Global channel setting, as an alternative to CHANDATA(1)

; Test whether channel name is missing for channel 1 and is available for channel 2

If $MC_CHAN_NAME == null && NC[C2].$MC_CHAN_NAME != null

; Copy channel name from channel 2 to channel 1

$MC_CHAN_NAME = NC[C2].$MC_CHAN_NAME
EndIf
```

4.5.5 Package variables

Package variables - Up. name

Package variables are variables that only have meaning within the package. The controller does not know these variables and they are not transferred to the controller.

Variable	Syntax	Description
Script variable	Up. <variable></variable>	Value of a UP variable
DO variable	Up. <variable>.<property></property></variable>	Property value a DO variable
System variable	Up. <variable></variable>	Value of a system variable

Package variables are identified by the prefix "Up.". Depending on their definition location, package variables are classified according to the following categories:

Category	Defined by	Value allocation by
Script	User in manipulation tasks	User
DO (drive object)	User on the "SINAMICS Topology" dialog page	System
System	The system using the package configuration	System

All package variables are defined in the same namespace. Consequently unique names must be used throughout all categories. Package variables are addressed using the prefix Up. They can be used throughout the package, in step scripts, tasks, etc.

They can be used as follows:

- In manipulation tasks for reading as well as writing using Up.name
- In step-scripts (see Steps (Page 166)) reading via Up.name
- In connection with the replacement operator: \$ (Up.name) (see Special operators (Page 211))

A variable name "name" that can be entered by the user must start with a letter or an underscore and comprises the characters $A-Z_0-9$. Upper/lower-case is not relevant. Package variables that receive their value from the system can only be accessed in read-only mode.

4.5.5.1 Script variables

Script variables - Up.myVar

Users create script variables using operations with the form:

```
Up.name = value
```

using a unique name and immediate value initialization.

Examples

4.5.5.2 DO variables

DO variables - Up. doVar

The DO variables (drive object variables) that can be used in the package are managed in the package design on the "Dialog: SINAMICS topology (Page 143)." This DO variable list can be exported as an XML file and linked again. To achieve data consistency, the same DO variable list can be associated with a topology project in Topo as a file. The variables are instantiated and the property values allocated when executing on this dialog by assigning to the existing drive components.

In manipulation tasks, DO variable properties can be read-accessed via:

```
Up. Variable. Property
```

The following properties are available for a DO variable with the name doVar:

Up.doVar != null

Supplies "true" if the DO variable was assigned to a drive component at runtime.

Up.doVar.doNr

Supplies the number of the drive object

Note:

A configured renumbering of the drive objects is performed before the variable assignment.

Up.doVar.slaveNr

Supplies the number of the higher-level slave object

Up.doVar.busNr

Supplies the number of the higher-level bus object

Up.doVar.psPath

Supplies the path to the PS file

Up.doVar.dpSlot

Supplies the PROFIBUS location number, starting with 1 (only for SERVO of the NCU and NX).

4.5.5.3 System variables

Note

When the password variables are used, the password that is used appears in the logbook during the package execution.

System variables - Up. \$sysname

System variables are package variables that provide information on the package configuration and runtime environment. System variables are identified by a name ("sysname") preceded by a '\$'.

System variables of the following type exist:

- Up. \$Pack System variables for the Package tab (Page 271)
- Up.\$Dialog System variables for the Dialogs tab (Page 273)
- Up.\$Step[ID] Steps tab (Page 282)
- UP.\$Env Environment variables (Page 289)

Note

You can find a reference list on the system variables in the last section of Create MyConfig - Expert under Reference list system variables (Page 271).

4.5.6 Commenting

Commenting - ; Comment

Comments are identified by a semicolon as prefix. As a consequence, all of the characters up to the end of the line are no longer evaluated.

In order to comment out several lines simultaneously, select the corresponding lines and use Ctrl+K+C.

To undo commenting out, use Ctrl+K+U.

Example

```
; Comment across complete line
N20000 $MC_CHAN_NAME="Machine" ; Comment in line
```

4.5.7 Scripts under dialogs, steps, and manipulation jobs

4.5.7.1 Sections

```
Set section - [B? S? PS?], [ADV], [SL]
```

For data with the same name, which occur in various files, before assigning a value, a specifying section must be specified. This section is effective as long as no other section is specified.

Depending on the target area, the following applies:

Target area	Explanation	Format
SINAMICS data	Subpath within the	[B3_S3_PS3]
	drive system	Notice
		No leading zeroes must be used
		No leading zeroes must be used for the figures. These are not detected during the validation run for replacement operators.
Display data	HMI of the target sys-	[ADV] - HMI Advanced
	tem	[SL] - SINUMERIK Operate

Examples

Display data

Syntax	Description
BD[<section>].<bd variable=""></bd></section>	Value of the display machine data "BD variable" from the "section" section. Values for "section":
	ADV for HMI Advanced
	SL for SINUMERIK Operate
	If the data is not found, null is returned.
	Note:
	EMB - HMI Embedded is no longer supported.
	Example:
	BD[ADV].\$MM_TECHNOLOGY

Drive data

Syntax	Description
PS[B <bnr>_S<snr>_PS<psnr>].<drvdata></drvdata></psnr></snr></bnr>	Value of the SINAMICS drive parameter "drvData" of the specified section:
	Bus with the bus number "bNr"
	Slave with the slave number "sNr"
	Drive object with number "psNr"
	Values from 1 to 99 are valid for "psNr". Leading zeros are not permitted!
	Example:
	PS[B3_S3_PS1].p105

4.5.7.2 Area data

All variables/identifiers without the package prefix \mathtt{Up} . are interpreted as area data. They can be written (left-hand side of an assignment) as well as also read (right-hand side of an assignment).

Note

Cross-area variable access is only supported for read access. In order to transfer the value of a data item from one area to another area, this can be assigned in the target area, whereby values can be read from different source areas (see Cross-area access (read) (Page 200)).

4.5.7.3 Check structures

Control structures - context menu

The following variants of the control structures are available:

- if control structure (Page 206)
- if-else control structure (Page 206)
- if-elslf control structure (Page 207)
- if-elslf-else control structure (Page 207)
- while control structure (Page 208)

if control structure / if-else control structure

Conditional execution - If ... Else ... EndIf

```
If exp
block1
Else
block2
EndIf
```

The control structure allows the conditional execution of two different operation blocks dependent on whether the "exp" condition is fulfilled or not. If this is fulfilled (true), then the first operation block "block1" is executed, otherwise, the second execution "block2".

Each of the two operation blocks can, in turn, contain control structures; this means that any nesting depth is possible.

Note

Before using machine or drive data in control structures, it is necessary to specify a section.

Example

```
CHANDATA(1)
If Up.Velo_X != null
   If Up.Velo_X > $MA_MAX_AX_VELO[AX1]
     $MA_MAX_AX_VELO[AX1] = Up.Velo_X
   Else
     $MA_MAX_AX_VELO[AX1] = 1000
   EndIf
EndIf
```

if-elslf control structure / if-elslf-else control structure

The IF-ELSE control structure was expanded in Create MyConfig V4.7. After the IF condition, alternative conditions can be checked by specifying ELSIF or ELIF.

The operation block is executed after the first fulfilled condition.

Conditional execution - If ... ElsIf... Else... EndIf

```
If exp
block_1
ElsIf exp_2
block_2
ElsIf exp_3
block_3
...
Else
block_E
EndIf
```

Note

For the alternative conditions, the keywords "ElsIf" and "ElIf" are used as equivalents.

The control structure allows the conditional execution of different operation blocks dependent on whether the "exp" condition is fulfilled or not.

If this is fulfilled (true), then the first operation block "block_1" is executed, otherwise it is checked whether the second alternative condition "exp 2" is fulfilled or not.

If this is fulfilled (true), then the second operation block "block_2" is executed, otherwise it is checked whether the next alternative condition "exp 3" is fulfilled or not.

If this is fulfilled (true), then the third operation block "block 3" is executed, and so on.

Once a condition or alternative condition is fulfilled, the associated operation block is executed and then the execution continues after the associated keyword "EndIf".

As long as the condition or alternative condition is not fulfilled, the subsequent alternative condition is checked.

If no alternative condition is fulfilled, the operation block "block_ ${\tt E}$ " in the alternative branch is executed after the keyword " ${\tt Else}$ ".

If no alternative branch "Else" was specified, then processing is continued after the keyword "EndIf" without executing an operation block.

Each operation block can, in turn, contain control structures; this means that any nesting depth is possible.

Example 1

```
CHANDATA(1)
If Up.Velo_X != null
   If Up.Velo_X > $MA_MAX_AX_VELO[AX1]
      $MA_MAX_AX_VELO[AX1] = Up.Velo_X
   Else
      $MA_MAX_AX_VELO[AX1] = 1000
   EndIf
EndIf
```

Example 2 - Alternative condition

```
IF (up.selection == 1)
Log("selection 1")
; ...
ELSIF (up.selection == 2)
Log("selection 2")
; ...
ELIF (up.selection == 3)
Log("selection 3")
; ...
ELSE Log("selection was not 1, 2 or 3")
; ...
ENDIF
```

while control structure

Repeated execution - While ... EndWhile

```
While exp
block
EndWhile
```

The control structure allows the repeated execution of the operation block "block" as long as the "exp" condition is fulfilled.

The operation block can, in turn, contain control structures; this means that any nesting depth is possible.

Example

```
[B3_S3_PS99]
Up.i = 0
Up.CU_Hat_Servo = false
While Up.i < 6 && !Up.CU_Hat_Servo
   If p978[$(Up.i)] != 255
        Up.CU_Hat_Servo = true
   EndIf
   Up.i += 1
EndWhile</pre>
```

4.5.7.4 Operators

Overview operators

The following operator groups are available for scripting in dialogs, step scripts, and manipulation jobs:

- Assignment operators (Page 209)
- Arithmetic operators (Page 210)
- Logic operators (Page 211)
- Comparison operators (Page 211)
- Special operators (Page 211)

Assignment operators

Assignment operators - VAR = 123

The assignment operators constitute the core function of manipulation jobs, because control data is written with them. All assignment operators can also be applied to script variables.

The following assignment operators are available:

?=	Assign if blank or not available
	Assign the specified value if no value is available.
=	Assign
	Assignment of a new value
	An assignment of "null" leads to the deletion of the variables or to the reset of the value to the default, see deletion operator ~.
~	Delete
	Delete data, i.e. reset to the default value
+=	Add
	Addition of the specified value to the existing value.

-=	Subtract
	Subtraction of the specified value from the existing value
*=	Multiply
	Multiplication of the specified value and the existing value.
/=	Divide
	Division of the existing value by the specified value.
 =	OR operation
	OR operation of the specified and existing value (setting of bits).
&=	AND operation
	AND operation of the specified and existing value (resetting of bits).
:=	Assignment without evaluation
	Assignment without evaluation to the right of the operator. The value is transferred to the controller as specified.

If no old value exists for compiled operators: += -= *= /= &= |=, then an error message is output.

Examples

```
N20000 $MC_CHAN_NAME="TUTORIAL"
$ON_AXIS_FUNCTION_MASK~
$MA_AX_VELO_LIMIT[0,AX1]?=2300
R[0]+=10
$MN_MM_TOOL_MANAGEMENT_MASK|='B10000'
GUD_2=$MA_MAX_AX_VELO[AX1]
Up.myVar ~ ; delete variable
Up.myVar = null ; delete variable (alternative)
```

Arithmetic operators

Arithmetic operators - VAR = 1 + 2 - 3

Arithmetic operators permit the assignment of a term comprising several constants and variables.

The following arithmetic operations are supported:

Table 4-11 Arithmetic operators

+	Add
-	Subtract
*	Multiply
1	Divide
1	OR operation
&	AND operation

The calculation is made for + - * / in double format (15-digit accuracy) and for & | in UInt64 format.

Calculations must be set in brackets in order to define a clear sequence.

Examples

```
UP.Index=UP.Index +1
$MA_MAX_AX_VELO[AX1] = $MA_MAX_AX_VELO[AX2]*1.3
GUD_1=(100-50)/3
$MN_MM_TOOL_MANAGEMENT_MASK = $MN_MM_TOOL_MANAGEMENT_MASK |
'B10000'
```

Logic operators / comparison operators

Condition-true != false

The following logical operations and comparison operators are available to form Boolean expressions:

Table 4-12 Logic operators

&&	Logical AND operation
II	Logical OR operation
!	Negation operator

Table 4-13 Comparison operators

==	equal to
!=	not equal to
<	less than
>	greater than
<=	less than or equal to
>=	greater than or equal to

Logic operations must be set in brackets in order to define a clear sequence.

Example

```
(UP.$Step[HMI_Adv]&&Version(PCU, "HMI-Advanced")>=7.6)||
(Version(NCU, "InternalVersion")!=2.7)
```

Special operators

Special operator Replace - \$ (up.?)

With the aid of the special operator **Replace**, it is possible to replace parts of an operation, an identifier, a value or a (message) text flexibly with the value of an Up.name variable.

The following rules must be observed when using the special operator Replace:

- It can only be used with package variables (see Package variables (Page 201)).
- During replacement, inverted commas are removed from string values.
- It can be nested.

The special operator Replace can be used in the following:

- in sections, e.g.: [\$(up.doX.pspath)] or [B3 S\$(Up.slave) PS\$(Up.doNr)]
- in operations under Manipulate and Change, e.g.: \$MA_MAX_AX_VELO[AX\$ (UP.AXNr)]=1000
- in control structures under Manipulate, e.g.: If p107[\$(Up.i)] == 254
- in step scripts, e.g.: Version (PCU, "HMI Advanced") >= \$ (Up.HMI)
- in functions and procedures under Manipulate, e.g.:
 MSG("Machine number: \$(Up.Masch_Nr)")
- in command lines for "Execution of:", e.g.: Setup.exe > Log \$(Up.Masch Nr).txt
- in message texts of the steps, e.g.: "The machine number is: \$ (Up.Masch Nr)"

Note

Instruction lines in which a special operator Replace is used cannot be checked for correct syntax in a verification run.

4.5.7.5 Functions

Note

Please note that variables are permissible as arguments for functions.

Functions for dialogs, steps, and manipulation jobs

The following functions can be used in scripts for dialogs, steps, and manipulation jobs.

The functions are called via the context menu Insert Script > Function.

- Input(..) (Page 218)
- InputChoice(..) (Page 219)
- InputEnum(..) (Page 223)
- InputText(..) (Page 224)
- InputInt(..) (Page 225)
- InputUInt(..) (Page 226)
- InputReal(..) (Page 227)
- Round(..) (Page 228)
- Match(..) (Page 228)

- Exists(..) (Page 229)
- Version(..) (Page 229)
- DateTime(..) (Page 230)

Input functions

Two types of Input functions are available for expert:

- Input functions that are not linked to a particular type
- · Input functions that are linked to a particular type

Input functions linked to the particular type return a typical value, contrary to input functions that are not linked to a particular type:

- "string"
- "integer"
- "real"
- Enumerator value as "string"
- "unsigned integer"

The type-bound input functions are assigned a user-specified value. The user-specified value can be entered directly or only applied at runtime via variables and replacement operators.

Independent of the selection "Display message", for the "Step tree" dialog, all Input functions are displayed.

Note

Double quotation marks

If the message text <msg> or another string should contain double quotation marks, they must be written with single quotation marks ('"') so that they are not interpreted by CMC.

Example: Msg("Component ' " ' HMI Install ' " ' ... ")

This procedure must be used for all double quotation marks within strings, just as is typically seen in the NC.

Note

Inserting line breaks

Line breaks can also be inserted in texts using '
'.

Example:

Input("line
 new line")

In tasks, a preview dialog box can be called to check the formatting after selection of the line or the text via shortcut menu item "Message preview."

Extended programming notes on input functions

Programming options

Examples are listed below that you can program for the input functions.

This is demonstrated with the InputReal function as an example. However, you can use any other input function.

Example of the representation of a line break

For a clearer arrangement, insert a line break between the header and the text.

up.wrap=InputReal("Notice!
 Please enter a number.",3.0)




Figure 4-44 Example of the representation of a line break

Example of the representation of a header with underscore

up.underline=InputReal("<u> Notice! </u> Please enter a number.",3.0)




Figure 4-45 Example of a header with underscore

Example of the representation of a bold font

up.bold=InputReal(" Notice! Please enter a number.", 3.0)




Figure 4-46 Example of a header, bold

Example of the representation of an italic header

up.cursive=InputReal("<i> Notice! </i> Please enter a number.",3.0)




Figure 4-47 Example of a header, italic

Example of the representation of a larger header

up.big=InputReal("<big> Notice! </big> Please enter a number.",3.0)

Example of a header, large

up.header=InputReal("<h1> Notice! </h1> Please enter a number.",3.0)



Figure 4-48 Example of a large header in a separate line

Example of a header in another font

up.type=InputReal("<tt> Notice! </tt> Please enter a number.",3.0)

Example of a header, small

up.small=InputReal("<small> Notice! </small> Please enter a number.",
3.0)

Example of a header, strikethrough

up.scratch=InputReal("<s> Notice! </s> Please enter a number.",3.0)




Figure 4-49 Example of the representation of a header, strikethrough

Example of an empty line between the header and the text

In order to display a warning, for example, a better representation can be achieved via an empty line.

up.lines=InputReal(" Notice! Please enter a number.",3.0)




Figure 4-50 Example of empty lines between the header and the text

Example of a header in superscript

up.sup=InputReal("^{Notice!} Please enter a number.",3.0)

Example of a header in subscript

up.sub=InputReal("_{Notice!} Please enter a number.",3.0)

Examples of colored headers

Some examples of colored texts are shown below.

Red header

```
up.red=InputReal("<b style='color:red'> Notice! </b
style='color:red'> Please enter a number.",3.0)
```

Green header

up.green=InputReal("<b style='color:green'> Notice! </b
style='color:green'> Please enter a number.",3.0)

Header and text in different colors

up.green_red=InputReal("<b style='color:red'> Notice! </b
style='color:red'> <b style='color:green'>Please enter a number.</b
style='color:green'>",3.0)



Figure 4-51 Example of the representation of the header and text in different colors

Example of background color

Header and text have different background colors, e.g. red and green

up.background=InputReal("<b style='background-color:red'> Notice! </b style='background-color:red'> <b style='background-color:green'>Please enter a number.</b style='background-color:green'>",3.0)




Figure 4-52 Example of the representation of text with a background color

Example of an invisible table

You can layout your texts using and invisible table.

up.table=InputReal("
 Notice! Please note!!! align='right'>Your data will be lost (please perform a backup please confirm!",3.0)



Figure 4-53 Example of an invisible table

Example of special characters

Use the HTML code special characters for the representation.

The special characters "less than" and "greater than" are used in the example: up.special=InputReal("Notice! Please enter a number that is <5 and >2.",3.0)




Figure 4-54 Example of special characters

More detailed information on HTML code can be found in the relevant documents and on the Internet, e.g. at HTML code (http://www.html-seminar.de/referenz-sonderzeichen.htm).

Input

Input("<msg>")

The Input function is a non-type-specific function.

Using the Input ("<msg>") function, the operator can query a value while the script is being executed.

If the operator does not specify a value, the function returns null. This can then be intercepted in the script code using an appropriate IF condition.

Example input

```
Up.in = null
While Up.in == null
   Up.in = Input("Make an entry. <br> (new line)")
EndWhile
```




Figure 4-55 Example input

InputChoice

If the function InputChoice (<icon_label>, <buttons>) is called, a dialog is shown with an icon during package execution in which the user can choose directly by pressing individual buttons.

The selection made is returned as a string.

InputChoice(<icon_label>,<buttons>)

The entry can be described using the "icon_label" argument. An icon can optionally be chosen at the beginning of the argument "icon_label", separated by a semicolon, which is displayed during package processing.

You can choose between the following icons "icon label":

- Selection without icon
- *I; selection with information icon
- *Q; selection with question mark icon (InputChoice icon)
- *W; selection with warning icon
- *E; selection with error icon

The "buttons" argument can be used to specify the identifiers for multiple buttons, separated by semicolons. The freely selectable identifiers simultaneously define the possible return values of the function.

Control characters in the argument "buttons":

- * Accept / Input
- ^ Reject / Cancel with ESC
- & Alt-Shortcut

The control characters '*' and '^' can be used to specify the default button for confirming or for cancelling with ESC at the beginning of a identifier.

The control character '&' in the identifier for buttons defines the subsequent letters as "Altshortcut" (key combination Alt+<letter>).

On package execution, each button can then also be operated via the keyboard, using the uniquely assigned key combination. Ensure an unambiguous letter assignment across all buttons.

The Alt-shortcuts are not case-sensitive.

Example Selection without icon

```
Up.ret = InputChoice ("Beispiel ohne Symbol", "*&OK")
Up.ret = InputChoice ("Example without icon", "*&OK")
```




Figure 4-56 Example without icon

Example Selection with information icon

```
Up.retI = InputChoice("*I;Beispiel für Symbol '"'Information'"'",
"*&OK")
Up.retI = InputChoice("*I;Example for Icon '"'Information'"'",
"*&OK")
```




Figure 4-57 Example for "Information" icon

Example Selection with question mark icon

```
Up.retQ = InputChoice("*Q; Beispiel für Symbol '"'Frage'"'
(InputChoice)", "*&Ja; &Nein")
Up.retQ = InputChoice("*Q; Example for Icon '"'InputChoice'"'",
"*&Yes; &No")
```



Figure 4-58 Example for "InputChoice" icon

Example Selection with warning icon

```
Up.retW = InputChoice("*W; Beispiel für Symbol '"'Warnung'"'",
"*&OK; &Abbruch")
Up.retW = InputChoice("*W; Example for Icon '"'Warning'"'",
"*&OK; &Cancel")
```



Figure 4-59 Example for "Warning" icon

Example Selection with error icon

```
Up.retE = InputChoice("*E;Beispiel für Symbol '"'Fehler'"' (error)",
"*&Abbruch;&Fortsetzen")
Up.retE = InputChoice("*E;Example for Icon '"'Error'"',
"*&Abort;&Continue")
```




Figure 4-60 Example for "Error" icon

Example Pushbutton operation

Up.example = InputChoice("*Q;Beispiel für Schaltflächenbedienung
mit
br> * Alt-Tastenkombination
br> * Eingabe
br> * ESC", "*Alt+&A
oder Eingabe;Alt+&B;^Alt+&C oder ESC")
Up.example = InputChoice("*Q;Example for push-button operation
using
br> * Alt + control character
br> * Enter key
br> * ESC (escape key)", "*Alt+&A or Enter;Alt+&B;^Alt+&C or ESC")




Figure 4-61 Example for Pushbutton operation

Example Technology selection

```
Up.MaschineType = InputChoice("Wählen Sie die Technologie!",
"&Fräsen; &Drehen; &Schleifen")
Up.MaschineType = InputChoice("Please select technology!",
"&Milling; &Turning; &Grinding")
```



Figure 4-62 Example "Technology selection"

InputEnum

InputEnum(label,enums)

When the InputEnum(label, enums) function is called, when the package is executed, a dialog box is displayed and the operator can make a selection.

This chosen string is assigned to an Up variable.

- The entry can be described using the "label" argument.
- You can define the selection text sequence using the "enums" argument, separated with semicolon.
- You can define this as preselection with a "*" at the beginning of a selection text sequence. If this is not done, then the first listed is preselected.
- The return value is the text that the user had selected as string.

Example with defined preselection (*)

```
Up.in = InputEnum("Please select input type:", "Magazine A;
*Magazine B; Magazine C")
```




Figure 4-63 Example with defined preselection

Example Preselection with replacement operator

Note the use of a replacement operator in the selection string.

```
Up.Typ1 = "Milling machine"
Up.Typ2 = "Drilling machine"
Up.Auswahl = "$(up.Type1); $(Up.Type2); turning machine"
Up.Maschinentyp = InputEnum("Which machine type?", "$(Up.Auswahl)")
```




Figure 4-64 Example Preselection with replacement operator

InputText

InputText(label,text)

Mit Aufruf der Funktion InputText (label, text) wird bei der Paketabarbeitung eine Dialogbox angezeigt und der Bediener kann einen Text eingeben. Dieser String wird einer Up-Variablen zugewiesen.

- The entry can be described using the "label" argument.
- A text can be preselected using the "text" argument.
- The dialog box is changed over to hidden password entry using the "*" user-specified value.
- The return value is the text that the user had entered.
- For an empty input field and when pressing "OK", an empty string " " is returned.

Example Input text with and without replacement operators

Up.Name = InputText("Enter the machine name.", "'Machine XY'")



Figure 4-65 Example Input text without replacement operator

```
Up.FA = "Siemens"
Up.Name = "Machine XY"
Up.Hersteller = InputText("$(up.Name) is manufactured by which company?",up.FA)
```




Figure 4-66 Example of input text with replacement operator

Example of input text for password entry

Up.Kennwort = InputText("Enter your password", "*")



Figure 4-67 Example of using input text for password entry

InputInt

InputInt(label,int)

By calling the InputInt (label, int) function, a dialog is shown during package processing in which the user can enter an integer.

This integer value is assigned to an Up variable.

- The entry can be described using the "label" argument.
- The "int" argument must contain a default value. This can be changed while the package is being executed.
- The return value is the number that the user had entered.

Example of entering an integer

Up.GanzeZahl = InputInt("Enter an integer number", 1234)



Figure 4-68 Example of entering an integer

Example of replacement from string, e.g. from an Enum

```
Up.n = "1500"
Up.Drehzahl = InputInt("Confirm the speed.", $(Up.n))
```



Figure 4-69 Example of replacement from string, e.g. Enum (enumeration)

InputUInt

InputUInt(label,uint)

By calling the InputInt(label, uint) function, a dialog is shown during package processing in which the user must enter an unsigned integer.

This unsigned integer value is assigned to an Up variable.

The value can be entered in various formats.

```
DEC = 123

HEX_NC = 'H9F'

HEX_0x = 0x9F

BIN_NC = 'B1101'

BiCo = 3:1.23
```

- The entry can be described using the "label" argument.
- The "uint" argument must contain a default value. This can be changed while the package is being executed.
- The return value is the number that the user had entered.

Example

```
Up.Uint = InputUInt("Enter an unsigned integer number", 'H9F')
```



Figure 4-70 Example of InputUInt entry unsigned integer number

Example of specification with replacement operator

```
Up.Vorgabe = 0x9F
Up.Uint = InputUInt("Enter an unsigned integer number", $
(Up.Vorgabe))
```




Figure 4-71 Example of specification with replacement operator

InputReal

InputReal(label,real)

When the InputReal (label, real) function is called, when the package is executed, a dialog box is displayed and the operator can enter a real number. This real string is assigned to an Up variable.

- The entry can be described using the "label" argument.
- The "real" argument must contain a default value. This can be changed while the package is being executed. The following entries are permitted:

Decimal:	-15	= -15
	1.5	= 1.5
Exponential:	1.5e2	= 150
	1.5ex+2	= 150
	-1.5ex-2	= -0.015

• The return value is the number that the user had entered.

Example of real-number entry

```
Up.RealZahl = InputReal("Enter a real number", 567.890)
```




Figure 4-72 Example of real-number entry

Example of specification with variables

```
Up.Exp = 12eX-3 ; = 0.012
Up.RealZahl = InputReal("Input as exponential:", Up.Exp)
```




Figure 4-73 Example of specification with variables

Round

Match

Match

The Match function searches in the <string> character string according to the search pattern <regular expression>.

Regular expressions are used as search pattern.

Match(<string>, <regular expression>)

Example

```
Up.NCU = match("NCU720.3 PN", "NCU([0-9]+)") -> "720"
```

```
Up.NCU = match(Up.\$Env.NCU, "NCU([0-9.]+)") -> "720.3"
```

Exists

Exists() function - Exists (<area>, "<path>")

The Exists (<area>, "<path>") function returns "true" if the folder or the "path" file exists with the absolute path in the "area" area.

Note

Only absolute paths are permitted, relative paths cause errors in the verification run.

The following values are permitted for "area":

- NCU for access to the file system of the NCU (e.g. the CompactFlash card /card/)
 Example: EXISTS(NCU, "/siemens/versions.xml").
 Upper/lower-case must be taken into account in the path. Please note that only areas can be addressed, which have also been activated in the project folder when configuring the package.
- PCU for access to the hard disk of the PCU 50, the path must start with the drive letter,
 e.g. "D:\" or "D\$\"

Example: EXISTS(PCU, "F:\DH")

 ARC - for access to data in the archive image, the path must start with NC\, MMC\, PLC\, CP\ or DRV\

Example: Exists(ARC, "NC\CST.DIR\Test.SPF")

Example Output of a message and entry in the log file

Output of a message and entry in the log file if the "/siemens/versions.xml" file has been found on the NCU.

```
IF EXISTS(NCU, "/siemens/versions.xml")
   Msg("The versions.xml file exists on the NCU.")
ENDIF
```

Example Package variable UP. DHexists

Package variable "UP.DHexists" has the value "true" if the data management "F: \DH" has been found on the PCU.

```
Up.DHexists = EXISTS(PCU, "F:\DH")
```

Version() function - Version (<area>, "app")

The Version (<area>, "app") function supplies the version of an application "app". Please note that only versions that have also been activated in the project folder when configuring the package can be queried in the areas. For example, when querying versions on the NCU, then the NCU area must be activated, etc.

If the version of the specified "<app>" application can be determined, then the function returns the null value. In this way, it is possible to react when a version cannot be found.

For the package area <area> = "PCU", all of the SIEMENS applications installed on the PCU are determined, which are entered in the PCU registry under the key:

```
HKEY LOCAL MACHINE\SOFTWARE\Siemens\AUTSW
```

For the package area <area> = "NCU", the versions are determined from the /siemens/versions.xml file.

For the name of the application "app", an abbreviated, unique entry is sufficient, e.g.:

"SINUMERIK CNC" instead of "SINUMERIK CNC-SW 31-5".

Note

All applications that are found are displayed on the Version Display dialog.

Example of query as to whether a version is larger/smaller

Query whether the version of the NCK is less than or equal to 83.03:

```
Version(NCU, "NCK") <= 83.03</pre>
```

Version of HMI Advanced greater than or equal to 6 and ShopMill is installed:

```
Version(PCU, "HMI-Advanced") >= 6 && Version(PCU, "ShopMill") != null
```

For the entry SINUMERIK Operate: 04.07.02.00 from Version.xml

Version of HMI Advanced greater than or equal to 4.7 and ShopMill is installed:

```
Version(PCU, "SINUMERIK Operate") >= 04.07 && Version(PCU,
"ShopMill") != null
```

For instance, the queries can be used in control structures (If, While).

DateTime

DateTime

If the function DateTime("") is transferred with an empty string "", it is formatted according to ISO 8601 "yyyy-MM-ddThh:mm:ss".

The following script code must be used to get the previous name of the logbook. Script_201412031651

```
Up.dt = DateTime("yyyyMMddhhmm")
Up.$Dialog.PackageEnd.LogName = "$(Up.Pack.Name)_$(Up.dt)"; extension
by Shield correspond to password protection
Up.$Dialog.PackageEnd.LogDir = "./"; is default ==> only explicitly
written down once more
```

Examples of units of time

```
Up.year = DateTime("yyyy"); the year as four digit number
Up.month = DateTime("MM"); the month as number with a leading zero
(01-12)
Up.day = DateTime("dd"); the day as number with a leading zero (01
to 31)
Up.hour = DateTime("hh"); the hour with a leading zero (00 to 23)
Up.minute = DateTime("mm"); the minute with a leading zero (00 to 59)
Up.second = DateTime("ss"); the second with a leading zero (00 to 59)
Up.milliseconds = DateTime("zzz"); the milliseconds with leading zeroes (000 to 999)
Up.dt = DateTime("yyyy-MM-dd hh:mm:ss.zzz"); previous examles in combination
```

4.5.7.6 Procedures

Various procedures exist in order to be able to interactively influence script editing. These should be coded in a dedicated line.

Table 4-14 Overview of procedures:

Procedure	Description
Msg("?")	Message output,
	which must be confirmed with "OK." <msg> contains an arbitrary message text that is also written to the logbook.</msg>
Error("?")	Message output,
	which must be confirmed with "OK" and results in termination of the package. <msg>contains an arbitrary message text that is also written to the logbook.</msg>
Warning("?")	Message output
	and prompt for cancellation of the package. <msg> contains an arbitrary message text that is also written to the logbook.</msg>
Log("?")	Logbook entry
	<msg> contains an arbitrary message text that is only written to the logbook.</msg>
Logging(On Off)	Logging on/off
	Logging in the logbook can be activated and reactivated.
ExtCall(" <path>")</path>	External call
	Call of an external manipulation task. There is no verification run for this task in Expert, and therefore no syntax check. The file must be stored in ANSI code. The path can be specified as an absolute path or relative path.
	A relative path refers to the folder from which the package is executed. An absolute path must correspond to the conventions of the runtime system.

Procedure	Description
#Include " <path>"</path>	Deployment directive
	Preprocessor operation that includes an external file (manipulation task) when checking or deploying.
	 When a package is deployed, the contents of the external file are taken over in the manipulation task instead of the #include operation.
	 Included files are also checked by the verification run.
	 The path can be specified as an absolute path or relative path. With internal tasks, the relative path refers to the storage folder of the component. With external tasks, the relative path refers to the storage folder of the external task. The path can contain environment variables of the type %SUB_PATH%.
Return()	Function Return()
	This function can be used in the script of the dialog pages.
	With Onlnit , after the dialog page is displayed and processed, a switch to the next dialog page takes place.
	With OnNext , the dialog page is processed.
	With OnEnd , the dialog page is terminated.
Skip()	Function Skip()
	This function can be used in the script of the dialog pages.
	A dialog page is skipped with the function Skip().
	Exception:
	The dialog pages Archive access, NCU access, PCU access and System configuration are not skipped if "Yes" is set in the Project / Package tab under Package > Data areas > Use archive.
	An error message is displayed during package processing in Shield or during verification in Expert.
Redo()	Function Redo()
	This function can be used in the script of the dialog pages.
	With Onlnit, an error message is displayed in Expert during the verification run.
	With OnNext , a return is made to the operator input of the dialog page.
	With OnEnd , only after successful execution is the script executed at the end of the dialog page.

Note

Double quotation marks

If the message text <msg> or another string should contain double quotation marks, they must be written with single quotation marks ('"') so that they are not interpreted by CMC.

Example: Msg("Component'"' HMI Install'"'...")

This procedure must be used for all double quotation marks within strings, just as is typically seen in the NC.

Note

Inserting line breaks

Line breaks can also be inserted in the <msg> texts via '
'.

Example:

Msg("line
 new line")

In tasks, a preview dialog box can be called to check the formatting after selection of the line or the text via shortcut menu item "Message preview".

Example

```
If Up.doX == null
Warning("X drive was not assigned!")
Else
Log("assignment, X drive checked.")
EndIf
```

4.6 Conversion

Projects that were created with the versions SCI 2.6, CMC 4.4 / 4.5 or CMC 4.6 are automatically converted on calling.

Packages that were created with these versions cannot be converted during direct import.

Pay attention to the procedure for converting packages from older versions of Expert.

Procedure

- 1. Import the packages with the corresponding older version of Export.
- 2. Open and convert the project that has been created using the actual CMC Expert.
- 3. Store the project and forward it as package with the current version (*.exe, *uaz, *usz).

4.6.1 Rules for adapting the syntax

If you open a project SinuCom Installer SCI 2.6, CMC V4.4 / 4.5 or CMC V4.6 with the current version, the majority of the syntax from scripts and step scripts is converted automatically. However, there are a few expressions where an automatic conversion is not possible. These must by adapted manually to the correct syntax.

This section provides an overview of which expressions can be converted automatically and which must be manually adapted. Syntax errors (syntax that has become invalid) are displayed through the verification of package by Expert. Especially extensive conversions are necessary in projects of SCI 2.6.

4.6 Conversion

Adaptation of logic operators in projects from Version 2.6

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
&	Yes	&&
	Yes	II

Adaptation of values in projects from Version 2.6

Replace the **UP()** function with a value query.

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
Up(\$Step[id])	Yes	Up.\$Step[id]
UP(data)	Yes	UP.data
UP(doX) != null &	Yes	UP.doX != null &&
<pre>UP(doX.slaveNr) == 3</pre>		<pre>UP.doX.slaveNr == 3</pre>

Adaptation of functions in projects from Version 2.6

Adapt the Version() function. Enter the range to determine the version.

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
Version(NCK) <= 4.4.18	Only in part:	Version(NCU, "NCK") <= 4.4.18
	Example:	
	Version(NCK) → Version(?NCU PCU, "NCK")	
Version(HMI Advanced) >= 6	Only in part:	Version(PCU, "HMI Advanced")
	Example:	>= 6
	Version(HMI Advanced) → Version(? NCU PCU, "HMI Advanced")	
Version(ShopMill) != null	Only in part:	<pre>Version(PCU, "ShopMill") !=</pre>
	Example:	null
	Version(ShopMill) → Version(?NCU PCU, "ShopMill")	
Exists(<area/> , <path>)</path>	Only in part:	Exists(<area/> , " <path>")</path>
	Set in "", but only the ARC, NCU, PCU areas are still possible.	

Replace the **NC()** function with a value query.

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
NC(\$MC_CHAN_NAME, 5) ==	Yes	NC[C5].\$MC_CHAN_NAME ==
"CHAN5"	Special case:	"CHAN5"
	NC(\$MC_CHAN_NAME) → NC[C1]. \$MC_CHAN_NAME	

Replace the BD() function with a value query.

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
BD(\$MM_TECHNOLOGY, ADV) == 2	Only in part:	BD[ADV].\$MM_TECHNOLOGY == 2
	Set in "", but only the ADV, SL sections are still possible. (EMB not applicable)	

Querying SINAMICS drive parameters

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
Not directly possible	-	PS[B3_S3_PS1].p105

Sections in tasks of SINAMICS data

The sections in tasks of SINAMICS data are converted from the long notation still tolerated in SCI into a new shorthand notation, if the section does not contain a replacement operator.

Syntax Version 2.6	Conversion possible?	Syntax as of Version 4.6:
[BUS3.DIR/SLAVE3.DIR/ PS000099.ACX]	Partially: Only if a replacement operator is not contained.	[B3_S3_PS99]

4.7 Transferring a project/creating a package

Transmission of a CMC package to a third party

Note

Legal information on Open Source Software and Commercial off-the-shelf

If a CMC package in which Shield with Open Source Software or Commercial off-the-shelf is integrated, is transmitted to a third party, the CMC package must contain explicit information on the legal conditions.


In order not to violate the licensing agreement, include the "Notes for conformation" dialog page in the file on the CD. This file is located in the root directory of the CD.

Procedure

The generated Expert projects can be deployed as Windows or Linux packages. These can then be executed under the particular operating system.

To create a package, proceed as follows:

4.8 Cross references



- 1. Select "Project > Deployment" and select whether you want to create a Windows package or a Linux package.
- 2. Select a name and a target directory for the package.

 An automatic verification is started which checks the package for inconsistencies and errors. You can also perform the verification manually via the "Verification run" button.

4.8 Cross references

4.8.1 Overview

Cross reference objects

Projects generated in CMC Expert can be very complex, and generally contain a large number of cross-reference objects.

Cross-reference objects are identifiers of machine data, user and system variables, linked files and folders. These cross-reference objects are configured at various positions of use within the project and the linked components. In the form of a table, the cross-reference function shows you where all of the cross-reference objects are used.

This table can be exported using the context menu.

4.8.2 Display cross references

Display options

There are several ways of displaying cross references. Cross references can be displayed for a project with all linked components, for an individual component or for a cross-reference object (e.g. an identifier in a manipulation task).

For the project with all linked components, select "Project > Display cross-references" and for individual components "Component > Display cross-references."


Optionally you can display the corresponding cross references using the symbol bar.

To display individual cross-reference objects, put the cursor on the object in the editor and select "Go to position of use" from the shortcut menu. The cross-references are then filtered according to the object name. The object name of part of it can also be entered in the filter field manually.

Overview of the user interface

The list of locations where cross reference objects are used is grouped using the two "Identifier" and "Folder and file objects" tabs:

"Identifier" tab



Identifier Identifier is the unique identification of the cross reference object within the list.

Operator The operator specifies how the cross reference object is processed at the position where it is used.

Project/ Indicates in which project or in which component the cross-reference object is located.

Component


Step/ Indicates in which step or task the cross-reference object is located.

task

Line Indicates in which line, the cross-reference object is located.

4.8 Cross references

"Folder and file object" tab



Object Indicates which file or which folder is involved.

Project/compo-

Area/action

Indicates in which project or in which component the cross-reference object is located.

nent

Indicates in which area of the project folder or in which action of the component the cross-reference

object is located.

Target Indicates where the cross-reference object target is located.

Source Indicates where the origin of the cross-reference object target is located.

Size Indicates how big the cross reference object is (in bytes).

4.8.3 Search in cross-references

Search options


There are two ways of searching for cross-references: The specified character string is searched for in all columns and rows.

Quick search



By entering in the search field and clicking the "Search up/search down" button or pressing Enter.

Extended search using the search dialog



The extended search dialog is opened by clicking on the binoculars located to the left of the search field

Under Conditions / Direction, you can define the various search properties.

4.8.4 Filter according to identifier or object

A partial string can be entered in the input field by which the column "Identifier" or "Object" is filtered. All objects are listed that contain this character string at any position in the name.

Filtering is reset by entering an empty string.

Procedure

If you want to filter the cross-references according to a certain string, proceed as follows:




Enter the desired string in the field using the keyboard or select "Go to position of use" from the shortcut menu in the instruction editor to filter a selected identifier.



Filtering is applied to the "identifier" or "object" column.

4.9 Password protection

Example:



4.9 Password protection

4.9.1 Overview

Create MyConfig offers password protection for projects, components, packages and logbooks. Using this password protection function, you can protect your own know-how from being viewed and changed by unauthorized personnel.

You can use the password list to define various access levels. You can then execute the following activities only by entering the correct password:

- Opening or saving a project or a component.
- Executing a package at the machine or reimporting this package as project.
- Viewing a protected logbook.

Project structure with access levels

The project and package structure with the possible access levels is shown in the following overview diagram:




Figure 4-74 Systematically displaying the project structure with the associated access levels

4.9.2 Protecting projects and components

4.9.2.1 Access levels

In Expert, a CMC project is protected using three access levels with different authorization levels. The same access levels are also applied for components. It is necessary to specifically protect components, because components can be opened and processed independently of projects.

You can only view protected CMC projects or protected components if you have a password with one of these access levels.

Converted projects from older versions or newly created projects are unprotected and can be edited as previously. You can subsequently provide projects with protection at any time.

To enter a password that permits defined processing permissions, use "Project > Password protection > Enter password...."

4.9 Password protection

Access levels

Access level	Authorizations	
"Read project"	Opening a project/component for reading	
"Change project"	Opening a project/component for reading	
	Changing and saving a project/component	
"Full access to project"	Opening a project/component for reading	
	Changing and saving a project/component	
	Editing a project/component password list - transfer password list to components	

4.9.2.2 Editing a password list

Requirement

You define the password protection already during the creation of a project in the Configuration tab under Project - General > Access.

To make changes at a later time, e.g. activate password protection or manage the password list, use the main menu in Expert: "Project > Password protection > Edit password list...". The dialog "Edit password list [Rights without a password]" is opened.

If there is already password protection, then you will be initially asked to enter the password for "Full access".


By default, when creating a new project or an external component, an entry <Right without password> will be created with the following authorizations.

Placeholder screenshot - Edit password list [Rights without a password] (by default with 4 authorizations)

You can select the maximum authorizations via the Extended access protection button.

If, when opening the password list, other passwords exist with the access level "Full access," these cannot be viewed or modified, however they can be deleted.

Overview of user interface



1 Add new password"

You can add any number of entries to the list using this button. Passwords must be unique.

The new entries that are added are allocated default passwords: the first entry is 001, the second 002 etc.

These passwords should be changed in order to guarantee the appropriate level of security.

② Remove password"

You can remove the selected entries using this button.

3 Display password"

You can display the password in plain text using this button. All passwords with "full access" are displayed encrypted so that other project engineers cannot see these passwords.

4 Import password list:

You can import the password list of another project using this button.

In the window that opens, you must then search and open the corresponding project.

The current password list is deleted on importing.

⑤ Comment field:

You can add any text to the particular entry in the comment field. Here, we recommend that you describe the role or the person who is using this password with the appropriate access levels. Comments must be unique.

6 Selecting access rights:

Using the option boxes, you can activate or deactivate access rights for certain passwords.

The reduced view only offers access levels for the package. The extended view (see ⑦) allows you to allocate access rights for the project.

Better access protection:

If you wish to protect your project/your component within the company, then you can extend the access rights.

There must always be at least one password with full access. Expert checks that this really is the case. This means that it is not possible to completely lock a project / a component as a result of an incorrectly configured dialog.

8 Allocating a password:

Here, you can assign a password with up to 24 characters for specific access permissions.

4.9 Password protection

Options

- Password list is always transferred to new internal components:
 If a new, internal component is created within the project, the password list of the project for this new component will automatically be transferred.
- Password list is always transferred to new, external components:
 If a new, external component is created in the project, the password list of the project for this new component will automatically be transferred.

See also

Package (Page 92)

4.9.2.3 Transferring a password list to existing components


Applications

The relevant dialog for transferring the password list is started via the main menu "Project / Component > Password protection > Transfer the password list > To project components... / to components of an archive folder...".

There are various applications, where it makes sense that you manually transfer your password list to your components, for example, if you have:

- Created a project with a lot of internal linked, internal unlinked as well as external linked components.
- Created a new password list to protect the project or have changed it. You want to transfer this password list to all of the components of your project.
- Created many unlinked components. You want to transfer subsequent changes to the password list to these components.

Overview of the user interface



1 Display password

If this is activated, the passwords are displayed in plain text. Passwords permitting full access are an exception to this.

- Selecting the target components.
- Option Delete target password lists in the components completely before transfer If this option is selected, the password list will be deleted completely in the target components and then the selected passwords will be transferred with the associated rights.
- (4) Password list

Displays the passwords and the associated comments from the password list of the project or the source component.

Here, you select the passwords that are to be transferred.

The selected passwords are transferred to the target components, depending on the selected action.

4.10 Create MyConfig packages

(5) Action

The desired actions are defined via the checkboxes:

Add

The password is added to the target component with the associated rights. If the password already exists, the rights are overwritten additively.

Replace

If an identical password is found in the target component, only the rights of the source password are applied.

If a password to be transferred to the target component does not exist, no action will be performed.

Delete

The password is deleted in the target components.

The first line "Rights without password" cannot be deleted.

- 6 With the **OK** button, transfer of the selected passwords ② to the selected components is performed according to the selected action ④.
- (7) With the **Cancel** button, you discard the settings and close the dialog box.

Note

Also observe the transfer of rights for "Rights without password"

If you have also changed the rights of the "Default password" for the "Rights without password" in your source for the transfer (project or component) and also want to transfer this change, you must also activate this password for the transfer. Generally, "Replace" makes sense as action.

This means that if you create new passwords in your password lists and transfer rights from "Rights without password" to them, you remove these rights from the "Rights without password".

Make sure during the transfer that you not only transfer your new passwords, but also the "Rights without password" as otherwise this would still retain all rights and your components would not be protected.

4.10 Create MyConfig packages

4.10.1 Introduction

How can Create MyConfig packages be processed or executed?

Create MyConfig packages can be created for Windows and Linux systems with Expert. For the Linux operating system on the NCU, Expert generates a file with the extension "usz" (Linux package) and for the Windows operating system on the PCU, PG or PC, a file (Windows package) with the extension "exe".

The following sections describes the procedure for the Windows and Linux operating systems.

4.10.2 Executing the package under Windows

4.10.2.1 Executing a standard package

Precondition

If the package to be executed under Windows should also access the data of the NCU (the "NCU" area is activated in the package), then the NCU must access a shared folder on the Windows computer (PCU/PG/PC) on which the package is executed.

Note

If an active firewall prevents access from the NCU to the PG/PC, then the package cannot be executed from the PG/PC.

In this case, the package can be executed on the PCU50 or the package must be transferred as a Linux package (see Executing the package under Linux (Page 249)).

The following is required for the execution of (Windows) packages that also access data of the NCU:

- A network connection to the NCU / PCU
- Create MyConfig NcuShareService

For package execution, prior to establishing the connection to the NCU, it is checked if Create MyConfig NcuShareService is available on the Windows system with a sufficiently up-to-date version.

If an insufficient version is found, the package execution installs a current version. (This is part of the package).

During the package execution, the folder C:\ProgramData\Siemens\UpNcuShare is released as an exchange release by Create MyConfig NcuShareService.

When package execution is finished, the release is canceled by the service.

NcuShareService

The NcuShareService service is required for executing CMC packages with NCU share by Windows PC or by PCU50. The service activates an exchange release (share) on the Windows system for the duration of the package execution. There are three possible ways to install the service NcuShareService on the Windows PC (PG or PCU):

- 1. Automatically during installation of CMC 4.7
- 2. Manual installation NcuShareService
- 3. After enabling of the service by configuration.

In Expert, the service is installed by Shield at the start of a CMC package if it does not already exist and it can be configured and even uninstalled later.

Starting to execute the package under Windows

Establish a network connection between the PC and the control devices (NCU7x0, PCU) that is to be processed with the package.

4.10 Create MyConfig packages

The package generated by Expert for Windows with the file extension "exe" can be started on the PCU, the PG or the PC using standard Windows resources ("Run...", double-click, etc.).

If the file is the only exe file in the folder "Install" of a USB medium inserted in the PCU (USB FlashDrive, hard disk, CD), then the file is automatically started when the PCU is booted.

Note

Unknown USB medium

For older PCU-base systems, ensure that the USB medium is known to the PCU, as a new medium is installed after the start routine for the package. This means that it may be necessary to insert the USB medium and then switch-off and switch-on the PCU again after approximately 30 seconds.

Note

In a PCU with Windows 7, various settings are required to permit package execution for automated commissioning.

Expert provides support with generating a configuration file for initial startup of the PCU (asdelivered state).

In project in which you select the PCU area and Windows 7 operating system, this support will be provided automatically.

The necessary settings are stored in the file unattend.xml. The file must be transferred to a USB medium and plugged in before initial startup of the PCU.

Note

To be considered during initial startup of the PCU50 with Windows 7

If no configuration file unattend.xml was used during the commissioning for the first boot-up of the PCU50 with Windows 7, no update packages will be executed later from USB media from the Install folder.

Packages can only be executed locally from the PCU from the service desktop.

4.10.2.2 Executing the package on the PCU 50 from the network

Windows packages can be executed on the PCU 50. The package is on a network drive.

Preconditions

The following requirements apply:

- There must be a connection to the network drive.
- The folder containing the Windows package must be released for a user of the PCU 50 (default user "auduser") for read and write access.
- If the Windows package contains a restart of the PCU 50 (e.g. due to an installation), then the PCU-local default user "auduser" and the password "SUNRISE" must be used.

Procedure

- 1. Transfer the project in Expert as Windows package.
- 2. Save the Windows package in a folder of the network drive.
- 3. Release the folder of the network drive for users of the PCU 50 (preferred default user "auduser").
- 4. Let the PCU 50 start up in the Service Desktop.

Note

Do not start HMI Advanced or SINUMERIK Operate.

- 5. In the Windows Start menu, select "Start > Run".
- 6. Enter the following command: "\\<IP address or UNC name>\<share name>\<package name>.
 - e.g.: \\10.8.6.16\Package folder\Machine 1.exe
- 7. Follow the instructions of the package dialogs.

See also

Executing a standard package (Page 247)

4.10.2.3 Package execution dialogs

A representation of the package execution dialogs can be found at Dialogs (Page 96).

4.10.3 Executing the package under Linux

4.10.3.1 Introduction

Expert can deploy the package to a "normal USB FlashDrive" (or hard disk or CD) or a service USB FlashDrive from Siemens. Both versions result in a different system behavior which is subsequently explained.

4.10 Create MyConfig packages

Package execution from "normal USB FlashDrive":

If the package was transferred to a "normal USB-FlashDrive" (or hard disk or CD) which cannot be booted because it does not contain a Linux boot system from Siemens, then the NCU starts Linux from the CompactFlash card and then starts the package on the USB medium. For this version, a Linux system that can be run (system software SW) must be available on the CompactFlash card. The system software can be upgraded or reinstalled by the package.

Package execution from the service USB FlashDrive:

If the package has been transferred to a service USB flash drive (from Siemens) that is bootable because it contains a Linux boot system from Siemens, the NCU will start the Linux from this USB flash drive and then start the package on the USB flash drive.

In this variant, the CompactFlash card does not have to contain an executable Linux system (system software SW), i.e. the CompactFlash card can also be empty.

Note

In this case, reinstallation of the system software is a precondition for package execution.

As soon as installation on the CompactFlash card has been completed, the package will restart the NCU and force Linux to start from the compact flash card.

If "None" or "Upgrade" is selected in the "NCU system software" dialog box and there is a system on the CF card, starting is performed from the CF card during execution of this dialog box.

Package execution then continues the same as for a "normal USB FlashDrive".

4.10.3.2 Starting package execution under Linux

The package generated by Expert for Linux with the file extension "usz" should be transferred into the root directory of a USB medium (USB FlashDrive, hard disk) – and this medium should be inserted into a direct USB interface (X125 or X135) of the NCU 7x0. The package is automatically started when the NCU boots.

If there are several packages in the start folder, they will be provided on the Package selection dialog page.

If you select a package other than the default package for execution, clicking the Next button ends the default package and starts the newly selected package.

The result of this procedure is that the VNC server of the NCU is restarted. In this context, there is a loss of connection to all VNC viewers.

The VNC viewer running on the TCU is then automatically ended and restarted.

An external VNC viewer running under Windows on your PC/PG or the PCU might possibly have to be restarted if no automatic connection attempts were set for this.

4.10.3.3 Executing the package on NCU from the CompactFlash card

Linux packages can be executed from the CompactFlash card of the NCU that contains the CNC software under certain circumstances.

Preconditions

The following requirements apply:

- The CompactFlash card must contain a bootable CNC system.
- Fresh installation or upgrading is not permissible.
- The Linux package <name> can be stored under any path <path> on the CompactFlash card. We recommend storage according to the responsibility below "/card/oem" or "/card/user".

Procedure

- 1. Create an "sci.ini" file with the entry: "Start=<path>/<name>". Example: Start=/card/user/Test.usz
- 2. Save this file in the "/<responsible>/system/etc" folder of the CompactFlash card. <Responsible> can be "siemens", "addon", "oem" or "user".
- 3. Click on main switch "Off/On".
- 4. Follow the instructions of the package dialogs.

Note

The "sci.ini" file is deleted from the package as soon as it has been started. This will ensure that a package is not unintentionally executed several times.

4.10.3.4 Executing the package on the NCU from the network

Linux packages can also be executed from a network drive.

Procedure

1. Create an "sci.ini" file with the entry: "Start=//<domain>/<user>%<password>@<Server>/ <release>/<package name>.usz".

The specification of the domain is optional.

Example: Start=//wwprod/user%pass@192.168.100.2/Share/NCU_Pack.usz

- 2. Save this file in the "/<responsible>/system/etc" folder of the CompactFlash card. <Responsible> can be "siemens", "addon", "oem" or "user".
- 3. Click on main switch "Off/On".
- 4. Follow the instructions of the package dialogs.

Note

The "sci.ini" file is deleted from the package as soon as it has been started. This will ensure that a package is not unintentionally executed several times.

Note

The most important mechanisms for creating a user and performing a share under Windows are described in Sections Auto-Hotspot and Auto-Hotspot. You can use these or any other releases/users for the package execution from the network.

4.10 Create MyConfig packages

4.10.3.5 Package execution dialogs

A representation of the package execution dialogs can be found at Dialogs (Page 96).

4.10.4 Reimporting packages

4.10.4.1 Overview

With Expert, packages can be reimported via "Project > Import...", i.e. the project used as basis is regenerated. The complete know-how of the project engineer is in this project. To protect this know-how and prevent unauthorized use of a transferred package, three access levels can be assigned with different authorizations.

Therefore, a project development engineer can make the know-how of his package accessible to a group of previously defined people.

The procedure is described in Section "Password protection (Page 240)".

You can only execute or view (reimport) protected CMC packages if you have a password with one of these access levels.

Access levels

Access level	Authorizations	
"Execute package"	Execute package	
"Read package reimport"	Only open project for reading after a reimport	
"Full access to package reimport"	Open a project for reading	
	Change or save project	
	Edit password list of project	

4.10.4.2 Reimport with password protection

Preconditions

In principle, it is always possible to reimport a package of the same version. However, to open the project that has been created, you require a password which gives you the permission "Read reimported package" or "Full access to reimported package."

Rules for a reimport

 When opening a reimported project or a reimported component, all passwords are removed that are not identical to the password used for opening.

The entry <permissions without password> remains unchanged with its configured rights. In the result, in the password list, there are a maximum of 2 entries; the entry <rights without password> and the entry of the password used.

Note

This point is only implemented, if you logged on with a password for "Package reimport full access" and the project was subsequently saved.

- If the password used has the permission "Package reimport full access," in addition to this
 permission, after the reimport, all of the other permissions to the project/component will
 also be assigned to it.
- If the password used only has the permission "Package reimport read," no other additional permissions are allocated.
 - The project or the component cannot be stored and any passwords with "Full access to reimport" are therefore retained.
- No permissions for reimporting a component have been granted, it can be deployed but not viewed or modified.

Reimported components that have permissions for the project password used are opened with this permissions without an additional query.

Otherwise, the password protection behaves in the same way as for reimported components.

4.11 Command line call

4.11.1 Expert

Create MyConfig Expert can be started in the command line mode for the package deployment. This is designed for the automated deployment of finished packages.

A project configuration can be optionally specified during the deployment.

Expert can import a project configuration before the deployment of a project. The project will then be deployed with the imported settings.

Call options

Import project configuration

In order to be able to import a configuration before the deployment, the following minimum syntax must be adhered to in the command line:

/pack <Expert project path> /config <Absolute file path of the
configuration file> /deploy /silent

4.11 Command line call

The settings imported by the configuration file can be replaced again by arguments of the respective switch, where the current switch comes into effect:

- /deploydir
- /deploy
- /target

Automated forwarding of the project to the package

Expert	<pre><pre><pre><pre>project path></pre></pre></pre></pre>				
Expert	Expert [/pack] <project path=""> /deploy [<deployment name="">]</deployment></project>				
	/deploydir <deployment directory=""></deployment>				
	/silent /target (NCU PCU UAZ) [/protect] [/log <log file="">]</log>				
	[/tgz <tgz file="">] [/sdb <path file="" of="" sdb="" the="">] [/ust <path file="" of="" the="" ust="">] [/utz <path file="" of="" the="" utz="">]</path></path></path></tgz>				
	[/uss <path file="" of="" uss="">]</path>				

Note

Umlauts and special characters

Avoid the use of umlauts and special characters in path names.

If special characters or umlauts are to be correctly processed in specified paths, batch files with command line calls must be saved with the same character set as used by the region-specific command line interpreter (cmd.exe).

For example, Codepage 850, also known as DOS Latin 1, applies for the region Western Europe. The Notepad editor integrated in Windows does not support saving files with this character set.

Parameter

Switch	Arguments	Optional	Description	
/pack	<"Project path">	No	The path must be specified with the switch /pack.	
			The switch specifies the path of the package file – either absolute or relative.	
			The path must be specified in double inverted commas if spaces are included in it (example: "C:\Path with spaces \package file.upz").	
/deploy	<"Deploy name">	Yes	A name of the package for the deployment can be specified.	
			The switch causes the opened package to be checked and deployed.	
			No parameters are required for this switch.	
/deploydir	<"Deploy directory">	Yes	The switch specifies the path of the deploy folder – absolute or relative – in which the package should be deployed. The path is the path without the name of the deployed package.	
			The path must be specified in double inverted commas if spaces are included in it (example: "C:\path with spaces").	

Switch	Arguments	Optional	Description		
/log	<"Log file">	Yes	The switch specifies the path of a log file – either absolute or relative.		
			 Alarms and faults are written to the log file (XML format) when checking and deploying the package. 		
			 The path must be specified in double inverted commas if spaces are included in it (example: "C:\Path with spaces \Expert_Logfile.log"). 		
			If the switch is not specified, the log file with the name of the package in the path for deployment is automatically saved.		
/silent	-	No	The graphical user interface of Create MyConfig Expert is hidden.		
/config	<pre><"absolute path to the project configuration file"></pre>	Yes	The switch /config specifies the configuration file (with extension) under an absolute path.		
			The configuration file can have any file extension. Expert then attempts to import the file and apply the project settings. Note Project and package configuration files are normally exported/saved as *.upcfg via Expert.		
/target	< NCU PCU UAZ >	No	The switch defines the target system where the package will be deployed.		
			If UAZ or no value is specified, then the package is automatically deployed without executable part.		
/uss	<"Path of the USS file">	Yes	The switch specifies a USS file that is added and selected during deployment.		
/ust	<"Path of the UST file">	Yes	The switch specifies a ust file that is added and selected for deployment.		
/tgz	<"Path of the TGZ file">	Yes	The switch specifies a tgz file that is added and selected during deployment.		
/sdb	<"Path of the SDB file">	Yes	The switch specifies an SDB file that is added and selected during deployment.		
/utz	<"Path of the UTZ file">	Yes	The switch specifies a UTZ file that is added and selected during deployment.		
/protect	-	Yes	Automated "always reimport protected" deployment of packages.		

Return values

Note

The return values for the Expert command line call only apply if Expert is executed in /silent mode without the user interface.

4.11 Command line call

Value	Description
0	No faults or alarms occurred when checking/deploying the package.
1	Alarms, but no faults occurred when checking/deploying the package.
2	Faults (and possibly alarms) occurred when checking/deploying the package.
3	Incorrect command line call.

Example

(Requirement: Create MyConfig is installed in the directory "C:\Program Files\SIEMENS \Create MyConfig 4.7" and a package "Pack_1.upz" is available in the path "C:\Packages\".)

```
Set PATH=%PATH%;"C:\Program Files\SIEMENS\Create MyConfig 4.7"

Expert.exe /silent /pack "C:\Packages\Pack_1.upz" /deploy /deploydir "D:\Deploying" /target PCU

if %ERRORLEVEL% EQU 3 (
    @echo "Error when calling Expert.exe!"
    pause
)

if %ERRORLEVEL% EQU 2 (
    @echo "Faults during deployment!"
    pause
)

if %ERRORLEVEL% EQU 1 (
    @echo "Alarms during deployment!"
    pause
)

if %ERRORLEVEL% EQU 0 (
    @echo "Deploy executed without error!"
    pause
)
```

4.11.2 Package

Call

```
<package> [-hide] [-batch] [-pw:<pass>]
```

Parameter

Options	Arguments	Description	
-hide	-	This causes the package to be processed without being displayed.	
		Implies in the "-batch" option.	
-batch	-	This causes the package selection and the completion message to be bypassed for packages with NCU configuration.	
-pw	<pass></pass>	Uses the password "pass," forwarded in plaintext, as input for "Execute package."	

Return values

Value	Description
0	No faults have occurred.
1	Cancellation by user
2	Abort through step script or script function.
3	Incorrect command line call.
11xx	Dialog xx could not be advanced in automatic or progress mode because a fault occurred.
12xx	Dialog xx could not be advanced in automatic or progress mode because there is a configuration error on the dialog.
13xx	The dialog page xx could not be manually activated further during package start using the option -hide.
	There is a configuration error on the dialog page.

Example

package.exe -batch

4.12 SINAMICS device configuration

4.12.1 Production of modular machines

The Create MyConfig (CMC) engineering software supports both the automated production of modular machines for the machine manufacturer as well as the upgrade of machines for end customers, which requires only a limited number of operator actions.

The production of machines with 840D sl requires a basic commissioning of the SINAMICS, generally designated as "System configuration". The system configuration can be performed with CMC either as "Automatic configuration" or as "User-specified topology."

When the system configuration is configured in the CMC package, all the data sets and optimization data in the step tree required within a series of modular machines in the maximum machine configuration can be specified. The package is adapted to the specific version of a

4.12 SINAMICS device configuration

modular machine either initially during the configuring or when the package is being executed on the machine – either manually or using configuration files.

4.12.2 SINAMICS device configuration with Automatic configuration or user-specified topology

Applications

A differentiation is made between three applications that CMC supports when configuring SINAMICS:

- The SINAMICS was commissioned previously with SINUMERIK Operate or with a different commissioning software. The existing drive data can be checked with a CMC package via "Initial state" (online access) on the dialog page "System configuration" under "DRV..." in the drive archive data, including the topology. In addition, a further configuration or optimization of the SINAMICS can be made.
- 2. The maximum configuration of the SINAMICS is wired on the machine, but the SINAMICS has not yet been commissioned or configured. Using a CMC package, the "Automatic configuration" under "DRV archive data/drive configuration" is selected from the "System configuration" dialog page. The checks, configurations or optimizations listed in item 1 in the same package are then performed.
- 3. Not all the SINAMICS components provided for the maximum configuration of the machine have already been wired on the machine. For example, DQI/SMI motors are still missing. The SINAMICS has not yet been commissioned and configured. Using a CMC package, the "User-specified topology" under "DRV archive data/drive configuration" is executed from the "System configuration" dialog page. The user-defined topology file is a SINAMICS offline topology package (SOT) that contains the topology in the final configuration of the machine. The checks, configurations or optimizations listed in item 1 in the same package are then performed.

Differences between "Automatic configuration" and "User-specified topology"

The table below shows the major differences between "Automatic configuration" and "User-specified topology." In the same way as the automatic device configuration via SINUMERIK Operate, the PROFIBUS assignment (p978), the message frames and the BICO links are also entered automatically in both CMC variants.

Table 4-15

Automatic configuration	User-specified topology
Execution via SINUMERIK Operate or CMC (identical result).	Execution only via CMC.
The SINAMICS performs an automatic configuration and determines its own actual topology.	A user-specified topology is transferred to the SINAMICS in the CMC package that is applied as the target topology.
Only those SINAMICS modules wired at the time of the automatic configuration are acquired.	The user-specified topology can also include SINAMICS modules that have not yet been wired and deactivated, exception: NCU, NX, CU320.

Automatic configuration	User-specified topology
The DRV archive data also contains the DOs and components that have been wired after the automatic configuration was performed.	After importing the user-specified topology, the DRV archive data contains all DOs and components that were specified in the user-specified topology.
The step-by-step commissioning is possible only to a limited extent (e.g. the addition of DQI/SMI motors).	The step-by-step commissioning is possible almost without limitation (e.g. the addition of DQI/SMI motors).
The specification of the comparison topology file allows the DRIVE-CLiQ wiring to be checked.	The SINAMICS reports an error if the topology specified in the user-specified topology cannot be implemented.

Configuring in Expert

When configuring in Expert, on the "System configuration" dialog page in section "DRV..." under "Origin of data", you can define which of the four applications "Initial state," "Automatic configuration," "User-specified topology," or "Offline archive" is applicable.

By selecting the "User-specified topology" mode, it is necessary to generate with Topo a file with the user-specified topology and make it available to the package for execution on the "SINAMICS topology" dialog page. The user-specified topology file has a binary format with the file extension "utz."

If "automatic configuration" is performed, as an option, you can use on the "SINAMICS topology" dialog page a file with the comparison topology in XML format and the file extension "ust" or "xml". This is used for comparison with the automatically detected topology.

The two topology files can be configured in one package. During execution, the setting Origin of data" under "DRV archive data/drive configuration on the "System configuration" page determines which of the two settings will be used on the following "SINAMICS topology" page.

Both the user-specified topology and the comparison topology contain the topology of the SINAMICS and other properties of the DOs and the components.

4.12 SINAMICS device configuration




Figure 4-75 CMC package structure

4.12.3 Drive data generation via "automatic configuration"

Basic procedure

The "automatic configuration" via SINUMERIK Operate or via CMC uses the same functions internally. In both cases, the SINAMICS determines its actual topology and saves it as target topology (p9903). This also includes the creation of drive objects (DOs) and their assignment in a folder structure according to bus number and slave number. Each DO is represented as a PS file either in ACX or ASCII format (*.TEA). The file PS000000 is used for the consistence monitoring and the file PS000099 contains configuration data of the internal PROFIBUS. This structure can be saved as drive archive and imported later.




Figure 4-76 Drive data storage

SINAMICS specifies for the "Automatic configuration" DO names, DO numbers, component names, component numbers, etc., and acquires component properties such as article number, component category and component type. The parameters for the DOs are read out of the components, calculated or assigned with factory settings.

The complete data is backed up in the drive data archive.

4.12.4 Drive data generation via "user-specified topology"

Basic procedure

If the SINAMICS device configuration is made with the "User-specified topology," the SINAMICS is assigned a SINAMICS offline topology package corresponding to the maximum configuration of the machine in the form of a user-specified topology file (*.utz) from the CMC package. In other words, components, such as DQI/SMI motors, still may be missing because commissioning has been performed step by step.

In addition to the topology, the user-specified topology file also specifies the DO names, DO numbers, component names and component numbers as well as component properties such

4.12 SINAMICS device configuration

as article number and component type. The structure with generalized drive data is also specified.

Finally, the package processing requests the SINAMICS to check this data based on the currently available configuration and to customize it appropriately, i.e. define the DO or component status. SINAMICS has in the result a customized target topology (p9903) and customized DOs for the specified components.

The DO parameters are customized by SINAMICS with the factory settings, values exported from the components or calculated values. All this data is backed up in the drive data archive.

Because at this time components not yet present in the structure have already been created, the associated user data can be added to the step tree using manipulation tasks. As an alternative, for example with DQI/SMI motors, export of the data from the electronic rating plate with the motor type or encoder type selection can be forced after activation.

4.12.5 Assignment of the drive data using DO variables

Immediately after the "Automatic configuration" or after the "User-specified topology", the physical drives have been assigned to the data in the archive structure. The DOs, however, are not yet assigned to the technological drive and thus to the correct NC axis.

If optimized drive, motor or encoder data has been configured in a CMC package for a DO, it must be known to which physical DO this technological data must be assigned. This means that the path address of this DO must be known. The data is assigned using DO variables.

Diff

When configuring a package in production preparation, SINAMICS data of the modular modules is extracted once as master data to ASCII files from drive archives of one or more commissioned base machines with the comparison component Diff (e.g. drive data, motor data, encoder data of the various axes, line module data, etc.). Appropriate filter settings mean this data no longer contains any topology-specific component numbers when exported.

When exporting, Diff writes a section in front of the data that provides a reference to a topology-specific PS file in the drive data archive. This reference in the section is a short form of the path, e.g. [B3_S3_PS5] instead of [BUS3.DIR\SLAVE3.DIR\PS000005.TEA]. These modular data sets can be maintained and managed in freely selectable folder structures.

Expert

When configuring in Expert , the topology-specific path data can be replaced by symbolic, topology-independent path data using a DO variable, e.g. [\$(Up.doVar.psPath)]. By assigning the drive-specific DO variables to a SINAMICS-DO and the associated simultaneous value assignment of the DO variables using the package during runtime, the DO variable has a defined value and thus also a defined path. The assignment of the DO variables to a SINAMICS-DO can be done manually at runtime in a dialog or in advance during the configuration of the comparison or user-specified topology. With this method, topology-independent SINAMICS parameters (master data) can be flexibly and easily assigned to each DO, regardless of where the drive-specific DO was placed in the SINAMICS group for the current machine.

As a result of the value assignment during the execution of the package, the symbolic path data is replaced with absolute paths and the topology-independent SINAMICS data that do not contain any component numbers are assigned to the drive-specific components in the current topology.

Example

Execution step		Result		
		[B3_S3_PS5] (corresponds to the path of the data storage		
		[BUS3.DIR\SLAVE3.DIR\PS000005.TEA])		
Replacement of the reference with a symbolic path.		X.psPath)]		
	[]	Section for path details in the data storage		
		Replacement operator		
		Identification of a package variable		
		DO variable		
		Property that specifies the path in the data storage		
Assignment of the DO variables to a DO in the topology.	Manual assignment at runtime on the "SINAMICS topology dialog page or during the configuration of the topology			
Use of the path property after assignment of the doX variables to the DO at runtime.	[\$(Up.doX.psPath)] becomes [B3_S15_PS10] if the DO is or the first NX and has the DO number 10 (BUS3.DIR \SLAVE15.DIR\PS000010.TEA)			

If DO variables are assigned as reference sensor modules of a second encoder, an assignment of this encoder to the associated servo drive can be performed while executing the package by entering the component numbers specified by SINAMICS during the package processing of CMC automatically into the parameters for the sensor module and encoder module p141[1] or p142[1] of the DO.

Other properties of DO variables are used to obtain the current topology information and optionally further process this information, e.g. the assignment of the PROFIBUS.

Properties of DO variables

The following properties are available for a DO variable with the name "doVar". The DO variable name "doVar" can be freely selected, for example "doX", "X drive", etc.

Table 4-16 Properties of DO variables

Property	Description
Up.doVar != null	Supplies "true" if the DO variable was assigned to a drive component at runtime.
Up.doVar.doNr	Supplies the number of the DO (NOTICE: The renumbering is performed beforehand).
Up.doVar.slaveNr	Supplies the number of the higher-level slave object.
Up.doVar.busNr	Supplies the number of the higher-level bus object.
Up.doVar.psPath	Replaces in a section the path to the PS file in the archive.
Up.doVar.dpSlot	Supplies the PROFIBUS location number, starting with 1 (only for servo of the NCU and NX).

The "Assignment of the DO variables to SINAMICS components" figure shows an example how the properties of the DO variables are assigned after the assignment for the package

4.12 SINAMICS device configuration

processing. The properties of the DO variables can only be read in the manipulation tasks and step scripts.




Figure 4-77 Assigning DO variables to SINAMICS components

Note

We recommend that the drive data is assigned to the drive objects via the assignment of DO variables. Although a direct assignment via a path specification is possible in short form, this limits the flexibility and can easily result in errors.

Assignment options

There are two ways of assigning the DO variables to the SINAMICS components:

- 1. When processing the package, you need to manually assign the DO variables to the SINAMICS components on the "SINAMICS topology" dialog page.
- 2. The DO variables are assigned to the SINAMICS components as a property during the configuration of a comparison topology or user-specified topology. The two topologies are linked into the project on the "SINAMICS topology" dialog page. Which topology is used during the runtime depends on the configuration of the DRV area on the "System configuration" dialog page.

4.12.6 The advantages of using comparison or user-specified topology

The configuration of a comparison or user-specified topology with Topo and the use of the file in the package, offer a number of additional advantages:

Advantages for the configuration of the topology with Topo

- Understandable topology creation thanks to a graphical wiring diagram
- Support with component box, context menu, verification run and graphic / color-coded visualization
- Printing the wiring diagram of the SINAMICS components with legend for documentation purposes
- · Comparison of topologies
- Import of topologies from drive archives
- Management of DO variables

Advantages of the topology file during the package execution

- The actual wiring of the SINAMICS in the control cabinet can be checked using the machine topology exported from SINAMICS. Warning or error messages are issued should deviations occur.
- You can check the properties of the components wired via DRIVE-CLiQ (DO type, article number, etc.). Wildcards are allowed when specifying the article number, e.g. 1FK7042 xAF7x xFxx.
- Sensor Modules not directly wired to a Motor Module, but rather to a hub or a CU, can be uniquely assigned to a DO.
- The specification of an OEM-ID is used to assign the SINAMICS-CU local component number to a particular OEM global unique identifier. When processing the package, the OEM component number in the DO1 is written to the parameter p7859 [component number].
- For the comparison topology, the DO names, DO numbers and component names specified by SINAMICS for the "Automatic configuration" can be replaced by user-specific data.

DO names

If a change of the DO name is configured, then this is automatically entered into the ${\sf SINAMICS}$ parameter p199 .

DO number

With the drive device configuration, SINAMICS assigns the DO numbers for all DOs at the CU and the NXs, i.e. on the particular CU starting at 1. For a machine series, it is more understandable, for example, if the X-drive, irrespective of its positioning in the SINAMICS group, always has the same number and that the DO numbers in the SINAMICS group are unique. The value range for the DO numbers lies between 2 and 54.

Component names

The component names can be freely assigned. The names of the SINAMICS components are displayed on the dialogs and in the screen forms and messages of SINUMERIK Operate.

4.12 SINAMICS device configuration

- When a user-specified topology is used, the component numbers must also be specified in addition to the DO names, DO numbers and component names. The use of the DO names, DO numbers and component names corresponds to the above explanations for the comparison topology. When the user-specified topology is used, the component numbers must also be specified. The CU and the NX must contain 1; the numbers on the CU or NX must not be assigned more than once and must be in the range 2 to 199. In Topo, the component numbers can also be automatically assigned via the shortcut menu.
- When configuring a user-specified topology, the activation status of the DOs and components can still be specified.
 The following is true:
 - 0 inactive and present
 - 1 active and present
 - 2 not present

The status is entered in the following parameters:

- p105 DO activation/deactivation
- p125 Motor Module activation/deactivation
- p145 Sensor Module activation/deactivation

DO list - comparison topology - user-specified topology

The mentioned properties and their specification are summarized in the following table:

Properties	Set	Check	DO list in the package [*.uvd]	Reference topology *.ust	User-specified topology *.utz
DO variable	[x]		package [.uvu]		Expanded
DO type		х			user-specified
DO number	Х		Creation in		topology *.uptz
DO name	х		Expert/Topo		
Wiring	SOT	SOT/VT			
Article number	SOT	SOT/VT		Creation in	
Component names	Х		Topo		
Component number	х				
DO activation	х				Creation in
Component activation	х				Торо

Figure 4-78 DO list - comparison topology (VT) - user-specified topology (SOT)

4.12.7 Configuration of the topology with Topo

CMC Topo can be used to configure not only a comparison topology but also a user-defined topology. The operation of CMC Topo is described in detail in Section Create MyConfig – Topo (Page 294).

The wiring diagram for the DRIVE-CLiQ connections and some of the properties are identical for both topologies.

With the changeover from comparison topology to user-defined topology, the additional properties DO activation, component activation and component number must also be specified.

On switchover to comparison topology, the data remain stored for when switch-back to user-defined topology is performed. These data have no effect in the comparison topology.

For the deployment as user-defined topology, other necessary data is added internally and output as binary user-defined topology file.

To deploy a user-defined topology, it is necessary to specify a CNC software version.




Figure 4-79 Variants of the topology generation with CMC Topo

See also

Generation of the comparison topology using external software (Page 267)

4.12.8 Generation of the comparison topology using external software

The structure and the contents of the comparison topology for a package is an open and documented interface, the Topo XML interface. The file format is XML.

You will find more information on this in Section Interface - Topo-XML (Page 331).

This means that it is also possible to generate the comparison topology using external software, which is integrated in the PLM process of the machine manufacturer, e.g. ePlan, ELCAD or similar. When required, the externally generated comparison topologies can also be read-in in Topo as part of the production preparation for control purposes or adaptations, before they are linked into the project when configuring with Expert or placed next to the package as configuration file. A comparison configuration file, which is located in or next to the package, can also be selected manually on the dialog of the "SINAMICS topology" during the runtime. Normally, a special topology must be created for each machine version, whereas one package can be sufficient for all machines.

4.12 SINAMICS device configuration




Figure 4-80 Configuration of a CMC package with comparison topology or user-specified topology

Compatibility of CMC versions and CNC software releases

The Topo XML interface is available in the version SCI 2.6, CMC V4.4/4.5 and CMC V4.6. For transfer, CMC Topo V4.6 no longer supports the Topo XML interfaces SCI 2.6 and CMC V4.4/4.5.

Note

CMC Topo 4.6 can only generate comparison or user-specified topology for CMC packages 4.6.

For deployment of a user-defined topology, the CNC system software version must be defined to which this will be applied.

CMC Topo V4.6 supports the CNC software versions V2.6, V2.7, V4.4, V4.5, and V4.6.

4.13 Interface – Step XML

4.13.1 Description Step XML file

Functions of a Step XML file

For an existing package, properties of steps are stored in an XML file (designation: Step XML file or USS file). The assignment of the properties to the particular step is realized using the step ID. When executing the package, a Step XML file in the package or next to the package can be accessed.

The Step XML file can either be output via the shortcut menu in the Expert software or according to the interface description via an external system.

The file must have the extension "<name>.XML" or "<name>.uss".

Property	XML attribute name	Description		
Step selection (step activation/deactivation)	checked	 Defines whether the step is to be activated/deactivated. The activation does not mean that it is shown in green and actually executed (see the example below: "4.1 Step is activated and not locked [5]"). Further, it is of no significance as to whether a possibly configured step condition is fulfilled or not fulfilled Possible values: "True", "False" 		
Step selection can be changed	locked	 Defines whether the step selection for the operator of the package is blocked or enabled Possible values: "True", "False" 		
Expanded/collapsed status	collapsed	 For the time of package execution, it can be defined for each step whether the step will be collapsed. Substeps can be hidden in this way. The overview for display of the step tree can therefore be configured individually. Possible values: "True," "False" 		

4.13 Interface - Step XML

Step tree configuration file



Figure 4-81 Step tree example

```
<upstep packname="MyMachine" version="4.6.0.0">
<step id="1" checked="True" locked="False" collapsed="False" />
<step id="2" checked="False" locked="False" collapsed="False" />
<step id="3" checked="True" locked="True" collapsed="False" />
<step id="4" checked="False" locked="True" collapsed="True" />
<step id="5" checked="True" locked="False" collapsed="False" />
</Upstep>
```

Explanation

<element></element>	Upstep, step	Tag element
attr=""	id="x"	Attribute required for a unique assignment to the step
attr=""	checked="True", checked="False" locked="True", locked="False" collapsed="True", col- lapsed="False"	Optional attributes for a step property
attr=""	packname="Parameter test" version="4.6.0.0"	Optional attributes for assignment to the package, version

Note

The configuration file must not contain properties for each step of the package.

When applying the configuration file to the step tree of the package, only ID-identifiable step properties are accepted.

Additional steps are ignored.

For missing steps, the properties from the step tree in the package are used.

4.13.2 Step xml (USS file)

The "namespace" attribute is designated in the Step xml.

...

4.14.1 System variables - overview

System variables for Expert

To provide a simple overview, the system variables that you require for the Project folder are listed according to the Package (Page 92), Dialogs (Page 96) and Steps (Page 166) tabs. In addition there is a list for the Environment variables that cannot be changed.

Entry of the system variable is supported by the shortcut menu or by automatic completion function (IntelliSense).

The values of most system variables are provided with values for the first time during configuration. These can be overwritten by using project configuration files during the deployment. Some variables are only available during the package execution.

This is specified for the relevant system variables in the "Description" column.

During the package execution, all of the system variables that are relevant for the package can be overwritten by using a package configuration file. During the package execution as well, system variables can be changed in dialog scripts, step scripts or manipulation tasks by write accesses before the system variables come into effect in the sequence.

For all of the system variables, the time until which a change of the system variables makes sense and is still effective for the package execution is then specified in the respective "Change effective until" column.

The system variables with the entry "ReadOnly" cannot be changed in the script.

4.14.2 Package tab

4.14.2.1 System variables for the Package tab

Package tab

The following system variables are assigned to the Package (Page 92) tab.

• Package properties Up.\$Pack

The enumerations are marked with the icon = and the elements of the enumerations with the icon =.

Conventions

Take the following conventions into account:

- Upper/lower-case is not relevant.
- In compound names, the beginnings of words are written in uppercase for better legibility.
- Values of enumerations are written in uppercase throughout.

4.14.2.2 Enumeration runtime system - DeployTargets

Rang	Range System variable / enumeration		Туре	Change effective until	Description
	Enumeration runtime system - DeployTargets				
	22	Up.\$Pack.DeployTargets.ADDON	Enumerator value	readOnly	Package without the executable part
	22	Up.\$Pack.DeployTargets.LINUX	Enumerator value	readOnly	LINUX package (NCU)
	22	Up.\$Pack.DeployTargets.WINDOWS	Enumerator value	readOnly	Windows package (PC/PCU)

4.14.2.3 Enumeration PCU operating system - PcuSystem

Ran	ige	System variables/enumeration	Туре	Change effective until	Description	
	Enumeration PCU operating system - PcuSystem					
	22	Up.\$Pack.PcuSystems.WINXP	Enumerator value	readOnly	Windows XP operating system	
	22	Up.\$Pack.PcuSystems.WIN7	Enumerator value	readOnly	Windows 7 operating system	

4.14.2.4 System variables for package properties \$Pack

System variables	Туре	Change effective until	Description	Example
Up.\$Pack.DeployDir	STRING	readOnly	Storage location	-
Up.\$Pack.DeployExclude	BOOL	readOnly	Exclude data storage areas for the project deployment.	false / true
Up.\$Pack.DeployName	STRING	readOnly	Name of the executed package. The name is different to the deployment name if the package has been renamed.	-
Up.\$Pack.DeployTarget	Enumeration DeployTargets (Page 272)	readOnly	Runtime system	-
Up.\$Pack.Language	STRING	readOnly	Language setting	"de"/"en"
Up.\$Pack.ARC	BOOL	Package configura- tion dialog page	Configuration archive selected.	false / true
Up.\$Pack.NCU	BOOL	Package configura- tion dialog page	Configuration NCU selected.	false / true
Up.\$Pack.PCU	BOOL	Package configura- tion dialog page	Configuration PCU selected.	false / true
Up.\$Pack.PcuSystem	Enumeration Pcu- Systems (Page 272)	Package configura- tion dialog page	PcuSystems	-
Up.\$Pack.ProdVersion	VERSION	readOnly	Display of the CMC system version.	"4.7.0.1"

BOOL	NCU access dialog page	NcuShareService is installed.	false / true
BOOL	End dialog page	NcuShareService is uninstalled.	false / true
STRING / VER- SION	readOnly	User version. The type can be a string or version; this depends on the specified value. The default for a blank string is "STRING":	"V1.0" or 1.0.0.2
30	OOL TRING / VER-	page OOL End dialog page TRING / VER- readOnly	page DOL End dialog page NcuShareService is uninstalled. TRING / VER-ON The type can be a string or version; this depends on the specified value. The default for a blank string is "STRING":

4.14.3 Dialogs tab

4.14.3.1 System variables for the Dialogs tab

Dialog properties \$Dialog

The subsequent system variables are assigned to the Dialogs tab (Page 96) within the project folder. To facilitate a better overview, the system variables are chronologically listed for the particular dialog pages and according to the structure of the context menu.

The enumerations are identified with the symbol ____, the elements of the enumerations with _____.

4.14.3.2 Enumeration processing modes - ProcessModes

Ran	Range System variable/enumeration		Туре	Change effective	Description	
	Enumeration processing modes - ProcessModes					
	22	Up.\$Dialog.ProcessModes.AUTO- MATIC	Enumerator value	readOnly	Automatic editing mode	
	22	Up.\$Dialog.ProcessModes.MANUAL	Enumerator value	readOnly	Manual editing mode	
	22	Up.\$Dialog.ProcessModes.PRO-GRESS	Enumerator value	readOnly	Editing mode progress	

4.14.3.3 Enumeration message level - InteractLevels

Rang	Range System variable/enumeration		Туре	Change effective	Description
	Enumeration message level - InteractLevels				
	22	Up.\$Dialog.InteractLevels.ALL	Enumerator value	readOnly	Message level, display all messages
	22	Up.\$Dialog.InteractLevels.ERROR	Enumerator value	readOnly	Message level, only error messages
	22	Up.\$Dialog.InteractLevels.WARNING	Enumerator value	readOnly	Message level, error and warning mes-
					sages

4.14.3.4 System variables for the Package configuration dialog

Table 4-17 Package configuration dialog - PackageConfig

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.Packag	eConfig.			
Activated	BOOL	readOnly	Activating the dialog processing	false / true
ConfigFile	STRING	Current dialog → OnInit	Configuration preselection	-
InteractLevel	Enumeration InteractLevels (Page 274)	Current dialog → OnInit	Enumeration message level	-
ProcessMode	Enumeration ProcessModes (Page 273)	Current dialog → OnInit	Enumeration processing mode	-

4.14.3.5 System variables for the Notes about acknowledgement dialog

Table 4-18 Notes about acknowledgement - ConfirmNotes dialog

System variables	Туре	Change effective until	Description	Example		
Up.\$Dialog.ConfirmNotes.						
Activated	BOOL	Last script before dialog	Activating the dialog processing	false / true		
InteractLevel	Enumeration InteractLevels (Page 274)	Last script before dialog	Enumeration message level	-		
ProcessMode	Enumeration ProcessModes (Page 273)	Last script before dialog	Enumeration processing mode	-		

4.14.3.6 System variables for the Notes on the package dialog

Table 4-19 Dialog, Notes on the package - PackageNotes

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.Package				
Activated	BOOL	Last script before dialog	Activating the dialog processing	false / true

System variables	Туре	Change effective until	Description	Example
InteractLevel	Enumeration InteractLevels (Page 274)	Last script before dialog	Enumeration message level	-
ProcessMode	Enumeration ProcessModes (Page 273)	Last script before dialog	Enumeration processing mode	-

4.14.3.7 System variables for the Archive access dialog

Table 4-20 Archive access - ArcAccess dialog

System variables	Туре	Change effective until	Description	Example			
Up.\$Dialog.ArcAccess.							
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true			
InteractLevel	Enumeration InteractLevels (Page 274)	Current dialog → OnInit	Enumeration message level	-			
Location	STRING	Current dialog → OnInit	Archive path - Specify path	-			
ProcessMode	Enumeration ProcessModes (Page 273)	Current dialog → OnInit	Enumeration processing mode	-			

4.14.3.8 System variables for the NCU access dialog

Table 4-21 Dialog, NCU access - NcuAccess

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.NcuAco	cess.			
Activated	BOOL	Last script before dialog	Activating the dialog processing	false / true
Address	STRING	Current dialog → OnInit	Address or IP address of NCU	"NCU720"
				"194.168.2.1"
Archives	BOOL		NCPLCDP archive "Backup.arc" before package run	false / true
Backup	BOOL		Complete data backup (TGZ) before package run	false / true
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-
Password	STRING	Current dialog → OnNext	NCU login information: Password	"SUNRISE"
ProcessMode	Enumeration ProcessModes (Page 273)	Current dialog → OnInit	Enumeration processing mode	-
UserName	STRING	Current dialog → OnNext	NCU login information: User Name	"manufact"

4.14.3.9 System variables for the PCU access dialog

Table 4-22 PCU access dialog - PcuAccess

System variables	Туре	Change effective until	Description	Example				
Up.\$Dialog.PcuAco	Up.\$Dialog.PcuAccess.							
Activated	BOOL	Last script before dialog	Activating the dialog processing	false / true				
Address	STRING	Current dialog → OnInit	UNC name / IP of the PCU or archive path	"192,167,140,210"				
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-				
Password	STRING		PCU login information: Password	-				
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-				
UserName	STRING		PCU login information: User name	-				

4.14.3.10 Enumeration, installation modes - Modes

Ran	Range System variable/enumeration		Туре	Change effective	Description
CNC	softw	are dialog - NcuSetup			
	Enumeration installation modes - Modes				
	22	Up.\$Dialog.NcuSetup.Modes.IN- STALL	Enumerator value	readOnly	Installations mode, new installation
	22	Up.\$Dialog.NcuSetup.Modes.NONE	Enumerator value	readOnly	Installation mode without installation
	0.00	Up.\$Dialog.NcuSetup.Modes.UP- DATE	Enumerator value	readOnly	Installation mode upgrade

4.14.3.11 System variables for the CNC software dialog

Table 4-23 CNC software dialog - NcuSetup

System variables	Туре	Change effective until	Description	Example				
Up.\$Dialog.NcuSet	Up.\$Dialog.NcuSetup.							
Activated	BOOL	Script of the previous ac-	Activating the dialog processing	false / true				
InteractLevel	Enumeration InteractLevels (Page 274)	tive dialog	Enumeration message level	-				
Mode	Enumeration modes (Page 276)		Enumeration installation mode	-				
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-				
TgzFile	STRING		CNC system software (*.tgz) - pre- selection	"./sw/ 04.05.02.00.007.tgz				

4.14.3.12 NCSources - enumeration, source of the NC data

Ran	Range System variable/enumeration		Туре	Change effective	Description		
Syst	System configuration dialog - SystemConfig						
	NcSources - enumeration source of the NC data						
	20	Up.\$Dialog.SystemConfig.NcSources.ARCHIVE	Enumerator value	readOnly	Data are taken from an archive.		
	20	Up.\$Dialog.SystemConfig.NcSources.FACTORY	Enumerator value	readOnly	Memory reset state of the NC.		
	22	Up.\$Dialog.SystemConfig.NcSources.ORIGIN	Enumerator value	readOnly	Actual state of the NC (initial state).		

4.14.3.13 PlcSources - enumeration, source of the PLC data

Ran	Range System variable/enumeration		Туре	Change effective	Description		
Syst	System configuration dialog - SystemConfig						
	PlcSources - enumeration source of the PLC data						
	0.00	Up.\$Dialog.SystemConfig.PlcSources.ARCHIVE	Enumerator value	readOnly	Data are taken from an archive.		
	88	Up.\$Dialog.SystemConfig.PlcSources.FACTORY	Enumerator value	readOnly	Memory reset state of the PLC.		
	88	Up.\$Dialog.SystemConfig.PlcSources.ORIGIN	Enumerator value	readOnly	Actual state of the PLC (initial state).		

4.14.3.14 SdbSources - enumeration source of the SDB data

Ran	ge	System variable/enumeration	Туре	Change effective	Description		
Diale	Dialog, system configuration - SystemConfig						
	SdbSources - enumeration source of the SDB data						
	22	Up.\$Dialog.SystemConfig.SdbSources.ARCHIVE	Enumerator value	readOnly	Data are taken from an archive.		
	22	Up.\$Dialog.SystemConfig.SdbSources.FACTORY	Enumerator value	readOnly	Memory reset state of the SDB data.		
	88	Up.\$Dialog.SystemConfig.SdbSources.ORIGIN	Enumerator value	readOnly	Actual state of the SDB data.		

4.14.3.15 DrvSource - enumeration, source of the DRV data

Rang	ge System variable/enumeration	Туре	Change effective	Description		
System configuration dialog - SystemConfig						
	DrvSources - enumeration source of the DRV	lata				

Ran	ge	System variable/enumeration	Туре	Change effective	Description
	88	Up.\$Dialog.SystemConfig.DrvSources.ARCHIVE	Enumerator value	readOnly	Data are taken from an archive.
	22	Up.\$Dialog.SystemConfig.DrvSources.AUTOMATIC	Enumerator value	readOnly	Automatic configuration is used.
	22	Up.\$Dialog.SystemConfig.DrvSources.ORIGIN	Enumerator value	readOnly	The actual topology is used
	22	Up.\$Dialog.SystemConfig.DrvSources.TARGET	Enumerator value	readOnly	A user-specified topology is used

4.14.3.16 System variables for the System configuration dialog

Table 4-24 System configuration dialog - SystemConfig

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.System	Config.			
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true
DrvFile	STRING	Current dialog → OnInit	Path of the DRV data	"DRV-Daten.arc"
DrvProcess	BOOL	Current dialog → OnInit	Use data	false / true
DrvSource	Enumeration DrvSources (Page 277)	Current dialog → OnInit	Enumeration source of the DRV data	-
InteractLevel	Enumeration InteractLevels (Page 274)	Current dialog → OnInit	Enumeration message level	-
NcFile	STRING	Current dialog → OnInit	Path of the NC data.	"NC-Daten.arc"
NcProcess	BOOL	Current dialog → OnInit	Use data	-
NCSource	Enumeration NcSour- ces (Page 277)	Current dialog → OnInit	Enumeration source of the NC data	-
PlcFile	STRING	Current dialog → OnInit	Path of the PLC data.	"PLC-Daten.arc"
PlcProcess	BOOL	Current dialog → OnInit	Use data	false / true
PlcSource	Enumeration PlcSource (Page 277)	Current dialog → OnInit	Enumeration source of the PLC data	-
ProcessMode	Enumeration ProcessModes (Page 273)	Current dialog → OnInit	Enumeration processing mode	-
SdbFile	STRING	Current dialog → OnInit	Path of the SDB data.	"./hw/SDB- Daten.arc"
SdbSource	Enumeration Sdb_Sources (Page 277)	Current dialog → OnInit	Enumeration source of the SDB data.	-

4.14.3.17 System variables for the Notes on the topology dialog

Table 4-25 Notes on the topology dialog - DriveTopologyNotes

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.DriveTopologyNotes.				
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true

System variables	Туре	Change effective until	Description	Example
InteractLevel	Enumeration InteractLevels (Page 274)	Script of the previous active dialog	Enumeration message level	-
ProcessMode	Enumeration ProcessModes (Page 273)	Script of the previous active dialog	Enumeration processing mode	-

4.14.3.18 System variables for the SINAMICS topology dialog

Table 4-26 SINAMICS topology dialog - DriveTopology

System variables	Туре	Change effective until	Description	Example			
Up.\$Dialog.DriveTo	Up.\$Dialog.DriveTopology.						
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true			
AxisDriveAssign- ment	BOOL	Current dialog → OnInit	Axis-drive assignment - selection	false / true			
InteractLevel	Enumeration InteractLevels (Page 274)	Current dialog → OnInit	Enumeration message level	-			
ProcessMode	Enumeration ProcessModes (Page 273)	Current dialog → OnInit	Enumeration processing mode	-			
UstFile	STRING	Current dialog → OnInit	Name of the Ust file	"C:\Data \ust_file.ust"			
UtzFile	STRING	Current dialog → OnInit	Name of the Utz file	"Utz_File.utz"			

4.14.3.19 System variables for the Version view dialog

Table 4-27 Version Display dialog - VersionView

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.Version	ıView.			
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true
ProcessMode	Enumeration ProcessModes (Page 273)	Script of the previous active dialog	Enumeration processing mode	-
InteractLevel	Enumeration InteractLevels (Page 274)	Script of the previous active dialog	Enumeration message level	-

4.14.3.20 System variables for the Notes on the Service Platform Industry (GSP) dialog

Table 4-28 Notes on the Service Platform Industry (GSP) dialog - ServiceDataNotes

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.ServiceDataNotes				
Activated	BOOL	Script of the previous ac-	Activating the dialog processing	false / true
InteractLevel	Enumeration InteractLevels (Page 274)	tive dialog	Enumeration message level	-
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-

4.14.3.21 System variables for the Service Platform Industry (GSP) dialog

Table 4-29 Service Platform Industry (GSP) dialog - ServiceData

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.ServiceData				
Activated	BOOL	Script of the previous ac-	Activating the dialog processing	false / true
ProcessMode	Enumeration ProcessModes (Page 273)	tive dialog	Enumeration processing mode	-
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-

4.14.3.22 System variables for the Notes on the step tree dialog

Table 4-30 Notes on the step tree dialog - StepSelectionNotes

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.StepSelectionNotes				
Activated	BOOL	Last script before dialog.	Activating the dialog processing	false / true
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-

4.14.3.23 System variables for the Step tree dialog

Table 4-31 Step tree dialog - StepSelection

System variables	Туре	Change effective until	Description	Example
Up.\$Dialog.StepSelection.				
Activated	BOOL	Script of the previous active dialog	Activating the dialog processing	false / true

System variables	Туре	Change effective until	Description	Example
ArchiveBeg	BOOL	Current dialog → OnInit	NCPLCDP archive "StepBeg.arc" before step tree	false / true
ArchiveEnd	BOOL	Current dialog → OnEnd	NCPLCDP archive "StepEnd.arc" after step tree	false / true
InteractLevel	Enumeration InteractLevels (Page 274)	Current dialog → OnInit	Enumeration message level	-
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-
CfgFile	STRING		Name of the Cfg file for step properties	"Properties.cfg

4.14.3.24 System variables for the NCU result dialog

Table 4-32 NCU result dialog - NcuResult

System variables	Туре	Change effective until	Description	Example		
Up.\$Dialog.NcuResult.						
Activated	BOOL		Activating the dialog processing	false / true		
Archives	BOOL		NCPLCDP archive "Result.arc" after package run			
Backup	BOOL		Complete data backup (TGZ) after package run.			
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-		
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-		

4.14.3.25 System variables for the Finish dialog

Table 4-33 Finish dialog - PackageEnd

System variables	Type Change effective until Description		Example	
Up.\$Dialog.Packag	geEnd.	•		
Activated	BOOL	Last script before dialog	Activating the dialog processing	false / true
InteractLevel	Enumeration InteractLevels (Page 274)		Enumeration message level	-
LogDir	STRING		Path to storage location of the logbook.	<pre>Up. \$Dialog.Package End.LogDir = "D:\Install"</pre>
LogName	STRING		File name of the logbook	Up. \$Dialog.Package End.LogName = "CMC_Package_Lo g"
ProcessMode	Enumeration ProcessModes (Page 273)		Enumeration processing mode	-

4.14.4 Steps tab

Up.\$Step[?]

The subsequent system variables are assigned to the Steps (Page 166) tab.

Table 4-34 Steps tab

System variable	Туре	Query as of	Change effective until	Description	Example
Up.\$Step[?]	•	•	•		

System variable	Туре	Query as of	Change effective until	Description	Example
Up.\$Step[?].	OBJECT	Dialog Package configuration	readOnly	Step query whether the step with the specified ID exists. If the specified step ID is not available, "0" is returned.	<pre>If Up.\$Step[1337] ! = null</pre>
		Event Onlnit		The properties .Activated or .Processing must be used for determining the activation or processing status.	
				Note	
				For compatibility reasons, a query for "true" or "false" returns the same result as the new notation Up.\$Step[].Processing.	
				The use of the old notation Up. \$Step[] of the BOOL type is marked as deprecated in the veri- fication run.	
Activated	BOOL		Last script be- fore current	The activation status of the specified step is returned.	If Up. \$Step[1337].Activa
			step.	"true" is signaled when the step is activated, i.e. the checkbox or the option button is set.	ted == true
				Note	
				This information is returned irrespective of whether the step has a green background (green track) or not.	
Collapsed	BOOL			"true" is signaled when the sub- steps below the queried step have been collapsed, i.e. are not visible for the operator.	Up. \$Step[1337].Collap sed = true
Locked	BOOL			Status activation disabled.	<pre>If Up. \$Step[1337].Locked == true</pre>
Processing	BOOL		readOnly	The execution status of the specified step is returned.	If Up. \$Step[1337].Proces
				"true" is signaled when the step is activated and has a green background.	sing == true
				Note	
				Only the green steps (green track) are executed.	

Query step - Up.\$Step[id]

The ${\tt Up.\$Step[id]}$ system variable can be used to query whether a specific step is available in manipulation tasks, dialog scripts or step scripts.

Example

CHANDATA (1)

Activate step - Up.\$Step[id].Activated

Using the system variable Up.\$Step[id]. Activated, the activation status of a specific step is defined in the step tree.

The system variable **Up.\$Step[id].Activated** supplies the value "true" for all steps whose step symbol (option button or checkbox) are displayed in white or green **with** checkmark and the value "false" for all other step symbols without a checkmark.

The step is activated now, but it is not considered during package execution as long as the step is additionally assigned the "Execute" status and displayed in **green**.

Example activate step




Figure 4-82 Display activate step

The step configuration is configured for each step individually, either via the context menu or via the settings of the property field.

Note

Step activation

The step activation can also be configured direct in the step tree and becomes effective immediately.

Execute step(s) - Up.\$Step[id].Processing

Using the system variable Up.\$Step[id].Processing, the execution status for package execution is defined in the step tree.

The system variable **Up.\$Step[id].Processing** supplies the value "true" for all steps whose step symbol (option button or checkbox) has already been activated and are displayed in green. The selected step in green and all of its higher-level steps are performed during package execution. Activated substeps are marked in green and are thus executed if the higher-level step is activated. The step in the first level is always assigned the execution status during activation.

The value "false" is returned for all other step symbols with a white background.

Example execute step




Figure 4-83 Display execute step

Via the button (Display all system variables via a dialog), you can display the current status of the system variables for each step.

Note

Executing steps

The "Execute" status can also be configured directly in the step tree and becomes effective immediately.

Step activation locked - Up.\$Step[id].Locked

Using the system variable Up.\$Step[id]. Locked, the activation status of a step is locked for package execution.

The system variable **Up.\$Step[id].Locked** supplies the value "true" for all steps whose step symbol (option button or checkbox) is displayed with a gray background, including the step. This step is not performed during package execution.

Observe the type of blocking during step configuration:

- · Activation disabled
- Activation disabled including substeps

Example activation disabled




Figure 4-84 View step - Activation disabled

Collapse step(s) - Up.\$Step[id].Collapsed

Using the system variable Up.\$Step[id].Collapsed, the selected step is collapsed in the step tree. The operator cannot see the step.

The system variable **Up.\$Step[id].Collapsed** supplies the value "true" for all steps whose font of the step is italic.

Example collapsing steps




Figure 4-85 Display collapse step

Note

Collapse steps

When configuring in the step tree, you can continue to have all steps with "Collapsed" status displayed. The steps are identified by the italic font.

The "Collapsed" status only becomes effective during package execution in Shield. The user cannot have these steps displayed.

4.14.5 Environment variables

The environment variables for Expert are listed below. Environment variables are only read accessed (read only).

The enumerations are identified with the symbol $_{\blacksquare}$, the elements of the enumerations with $_{\blacksquare}$.

4.14.5.1 Enumeration, runtime environments - runtimes

Range)	Variable/enumeration	Туре	Description	Example
	Enur	neration runtime environments -	Runtimes		
	22	Up.\$Env.RunTimes.LINUX	Enumerator value	Executing the package under LINUX	
	000	Up.\$Env.RunTimes.WIN- DOWS	Enumerator value	Executing the package under WIN-DOWS	

4.14.5.2 Environment variables

Range	Variable/enumeration	Туре	Description	Example
	Up.\$Env.RunTime	Enumeration Run- Times	RunTimes (Page 289)	
	Up.\$Env.CFID	STRING	CF card ID (string from hwversion.xml)	"2009123709B2A62AA61A"
	Up.\$Env.NCU	STRING	Type from NCU (string from hwversion.xml)	"SIEMENS SINUMERIK 840D sI NCU730.3 PN"
	Up.\$Env.PLC	STRING	Type from PLC (string from hwversion.xml)	"SIEMENS SINUMERIK PLC317-3PN/DP"

hwversions.xml on CF card under user/system/etc

4.14 Reference list, system variables

Package execution

5.1 Package execution

Information about projects which have been created in Expert, which are forwarded as Linux or Windows packages, is provided under Create MyConfig packages (Page 246).

5.1 Package execution

Create MyConfig - Topo

6

6.1 Safety instructions

6.1.1 Fundamental safety instructions

6.1.1.1 General safety instructions

/ WARNING

Risk of death if the safety instructions and remaining risks are not carefully observed

If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur.

- Observe the safety instructions given in the hardware documentation.
- Consider the residual risks for the risk evaluation.

/ WARNING

Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

6.1.1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (http://www.siemens.com/industrialsecurity).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (http://support.automation.siemens.com).

Æ

WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/ or material damage.

- Keep the software up to date.
 You will find relevant information and newsletters at this address (http://support.automation.siemens.com).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
 You will find further information at this address (http://www.siemens.com/industrialsecurity).
- Make sure that you include all installed products into the holistic industrial security concept.

6.2 Introduction

Note

Setup of documentation: Operating Manual / Online Help

The contents for the section **Topo** are identical in the operating manual and online help.

What is Topo?

The Topo software is used in Create MyConfig to configure, display, print, and compare SINAMICS topologies.

Comparison topology

An image of the SINAMICS topology can be used, for example, to check the topology (wiring) of the SINAMICS on the machine, to monitor module/component properties, to change the module/component names, to change DO numbers and DO names and to assign DO variables to the SINAMICS modules. SINAMICS modules or components are, for example, sensor and motor modules.

User-specified topology

In addition, it is also possible instead of the use of the automatic configuration to specify a SINAMICS Offline (reference) Topology package (SOT). This variant of the device commissioning supports a step-by-step production, because modules/components and data can be introduced into the controller that physically do not exist.

During series production of modular machines, generally a special version of the axis-drive assignment is specified for each machine variant to be manufactured. The objective is to split the axis-drive assignment into several modular objects to be able to handle their parameterization flexibly, irrespective of the physical design and wiring of the machine. The functional interaction of the individual axis/drive configurations must be ensured beforehand.

Extended user-specified topology

As a new function in Topo - Create MyConfig V4.7 or higher, the extended user-specified topology is available in addition to the comparison and user-specified topology. In addition to the SINAMICS wiring diagram, it also contains NC and DRV data.

The starting basis for the extended user-specified topology is the archive import of a functioning machine. After changing the topology or NC or DRV data, the result can be loaded directly in NC.

An Expert project with subsequent Shield package in not required in this case.

Functions of Topo

Topo provides the following functions that are necessary for:

- Creation of topologies via a graphical user interface using the context menu and additional standard Windows tools.
- Import of topologies from SINUMERIK archives, from deployed topologies (ECAD XML files)
- Verification of package for created topologies
- Comparison of topologies
- Assignment of module/component properties such as component name, OEM ID, etc.
- Specification of criteria (Article No.), which the package compares with the actual properties
 of the SINAMICS modules on the machine to be produced (read-out TARGET topology of
 the SINAMICS), and reports any impermissible deviations.
- Assignment of the DO variables to modules/components.
- Creation of a user-defined topology based on generic modules. This user-defined topology can be downloaded directly to the SINAMICS when executing the package.

6.2 Introduction

- Support of a step-by-step commissioning for missing components through deactivation of these components.
- Use the axis-drive assignment (AAZ) to assign the configured axes to the drives that are actually being used.

Assignment of DO variables and DO properties

DO variables can be assigned to the modules in Topo. These DO variables provide properties that can be used for the configuration in Expert when executing the package. In this way, it is possible to work flexibly in Expert with defined DO variables whose absolute values only apply during the package runtime on the machine.

SINAMICS modules that do not generate their own DO can be assigned the DO-generating modules via DO variables (e.g. Sensor Module to Motor Module).


The drive-specific parameters can therefore be stored modularly in a package without reference to a particular DO number, module number, or slave. The assignment of the parameters to the topology-specific DOs on the machine is controlled flexibly via the DO variables, manipulation tasks and step scripts defined in the configuration of the package.

The DRIVE-CLiQ wiring created in Topo and the assignments made for DO variables, DO names and DO numbers are saved via a deploy function to a comparison (*.ust) or user-defined topology file (*.utz) which is accessed when a package is executed.

6.3 Overview of user interface

6.3.1 Topo - overview window

The following shows the various operating areas of the Topo software user interface:



- 1 "Topologies"
- 2 Topology tree
- Topology graph

Topology tree/topology graph:

Both of these display forms offer the same functionality with regard to creating and editing a topology. As a consequence, you can work with one or both of these display types.

The topology tree or the topology graph are shown or hidden via the menu "View > Topology tree" and "View > Topology graph"

- 4 "Modules"
- (5) "Verification of package"
- 6 "Properties"
- (7) "Modules used"

6.3.2 Topo - menu functions

Designation			Meaning
Proje	ect		<u> </u>
*	New	<ctrl+n></ctrl+n>	Create a new project.
<i></i>	Open	<ctrl+o></ctrl+o>	Open an existing project (*.uptz).
	Save	<ctrl+s></ctrl+s>	Saves the current project as uptz file. If components are changed, they are marked in the topology tree with an asterisk at the component. The diskette symbol is active so that the changes can be saved.
N	Save as		Saves the current project under another path or file name.
	Verification of package		Checks an opened topology regarding the correct allocation of DO variables, component numbers, errors in the axis-drive assignment (AAZ).
			A check is not made as to whether the wiring is permissible according to SINAMICS guidelines.
()	Deployment		Deploys an open topology in a .ust (reference topology) or .utz file (target topology), which can be used by the package. The topology is first checked.
T	Load topology in controller		The finished project can be loaded into the controller via a network connection. A configured Shield package is being executed in the background. This is not an archive.
			The topology can only be loaded into the controller with the extended user-specific topology.
			It must be ensured that source data (archives or ASCI datasets) is not generated from a software version that is newer than the target software version.
	Displaying/importing topology		Displays a previously exported topology (*.ust) created by an
T		From topology	electrical engineering design system (*.xml), a topology extracted from a drive archive or directly from a topology taken from
		From archive	a control. In this case, the external topology is opened, write-protected and is not imported into the actual project. When closing the topology, this can be imported into the project.
\$		From control	For this purpose, a network connection must be established, specifying the IP address.
<i>\rightarrow</i>	Print Topology		Prints either the topology tree or the topology graph.
	Properties		Shows important project properties, such as path of the project, date of change, changed by, version and comment.
	Last Opened		The projects opened last can be selected.
	Displayed last		The projects displayed last can be selected.
	Close all		Closes the open project.
	Exit	<alt+f4></alt+f4>	Ends the Topo program.
Edit			
¥	Cut	<ctrl+x></ctrl+x>	Removes the selected components and copies them to the clipboard.
	Сору	<ctrl+c></ctrl+c>	Copies the selected components to the clipboard.

Designation			Meaning	
	Paste	<ctrl+v></ctrl+v>	Pastes the components from the clipboard to the selected position.	
×	Delete		Deletes the selected components and any following components connected to the component.	
View				
	Topology tree		Shows or hides the topology tree. The topology tree and graphic representation can never be hidden simultaneously.	
Ē	Topology graph		Shows or hides the graphic topology view. The topology tree and graphic representation can never be hidden simultaneously.	
	Display modules used		For the various device classes, shows group titles for the modules used or hides these.	
	Groups in modules used		For the various device classes, shows group titles in the "Modules used" window or hides these.	
	Toolbars	Standard	Allows toolbars to be hidden or displayed.	
		Quick search		
B	Go to error/warning forward	<f8></f8>	Errors or warnings can be displayed in succession.	
₽	Go to error/warning backward	<shift+f8></shift+f8>	Preceding errors or warnings can be displayed.	
Data		·		
	Manage DO list	Ctrl+Alt+D	Opens the "DO list" dialog for the administration of DO variables, i.e. DO variables can be newly added, imported, exported, or linked. You can find additional information under Manage DO list	
			(Page 307).	
A _D	Administrate axis-drive assignment	Ctrl+Alt+A	Opens the "Axis-drive assignment - Topo project" dialog, in which the axis-drive assignment table is shown and an axis-drive assignment can be performed.	
			A special feature is the display of the automatically generated DO variables, which can also be assigned manually.	
			When moving drive objects (DO), the required calculations are performed automatically.	
			It is possible to perform the desired axis-drive assignment manually.	
			You can find additional information under Axis-drive assignment (Page 327).	
	Manage NC data	Ctrl+Alt+N	Opens the "NC data - Topo project" dialog.	
			The view of the dialog is identical to the view under Diff. Machine data or parameters are displayed for processing.	
			Light gray parameters with the identifier "calculated" are automatically processed by Topo and cannot be changed.	
			If the drive data is deleted, the DO is empty.	
			It is not possible to add parameters.	
Comp	Comparison			
₩.	Refresh	Ctrl+D		

6.4 Topo - operation

Desig	gnation		Meaning
T	Compare with External Topology	From topology From archive	Compares the currently displayed topology with a previously exported topology (*.ust), a topology from an electrical engineering design system (*.xml) or with a topology from a drive archive. In this case, the external topology is opened, write-protected and is not imported into the actual project. You can find additional information under Topology comparison (Page 309).
*	Edit configuration	Ctrl+M	Opens the dialog "Configuration - Topology comparison", in which you can manage the comparison configurations (i.e. create, edit, delete, etc.).
	Select configuration	Topology comparison	Compares the currently displayed topologies and switches over into the compare mode.
		Complete comparison	You can find additional information under Topology comparison (Page 309).
			To display several topologies, select these in the list of topologies using the <ctrl> key and a mouse click. A maximum of two topologies can be compared simultaneously.</ctrl>
Tools	} }	1	
	Options		Opens the "Options" dialog, which offers the option of making basic settings, such as language and color changes to the graphical representation, in the following tabs:
			Topology graph
			Axis-drive assignment
			Messages
			Language
Help			
Ŷ	Contents	<f1></f1>	Calls the online help of the Topo program.
	About		Contains information on the version and copyright.

6.4 Topo - operation

6.4.1 Creating a topology

Topo offers the option of creating a new topology from the module window. Furthermore, it is possible to import and edit a topology from an electrical design system or directly from a control via an archive.


The topology can also be displayed from a drive archive, imported, or directly imported from a control and subsequently edited. In this case, the original component numbers and article numbers determined by SINAMICS are entered in the properties of the components. During the import, it can also be selected as to whether the DO properties should be taken over from the archive. In so doing, new DO variables are automatically generated and assigned to the imported components.

As from a newer CNC software version, the DO variables used for CNC commissioning are stored in the control and can be assigned and displayed again.

A topology is displayed in two ways in Topo. On the one hand, in a structurally hierarchic tree, and on the other hand, in a systematic graphic form which allows the wiring to be more easily understood and individual components to be simply identified.

Both of these display types offer the same functionality regarding creating and editing a topology. As a consequence, you can work with one or both of these display types. The topology tree or the topology graph can be shown or hidden via the menu "View > Topology Tree" = and "View > Topology Graph."

To display and edit several topologies, they can be selected in the list of topologies by making a multiple selection. Just the same as for Comparing topologies (Page 309), both technologies are displayed next to one another.



Procedure for creating a topology

- 1. Start Topo.
- In the "Project" main menu, select the "New" entry to create a new project.
 A new topology is now automatically created with the default name "Topology" and a "Bus 3" inserted.
- 3. You can now modify the name of the topology and wire the "Bus 3" directly to an NCU. The slave is created automatically.

Note

Wiring of external CU, e.g. CU320

Note that these cannot be connected to the internal "Bus 3." To do this, first insert the relevant bus 1, 2, 4 ... into the topology.

6.4 Topo - operation

4. The components are wired either from the selected structure node of the tree view or directly from the wiring diagram via the "Connect component" context menu entry. The components that can be used at this point of the topology can be selected from the module window and inserted and wired in the list of the used components. In this way, it is ensured that a valid topology is created and that components are not connected twice. Alternatively, you can drag and drop the components from the module window to the "topology configurator" and connect them (save).




Figure 6-1 Creating a topology

5. The DO variables are assigned to the components in the component properties in the "DO variables" field. Before you can make this assignment, you must have created or imported the DO variables. Refer to the section Manage DO list (Page 307).




Figure 6-2 Assigning DO variables

Additional functions

In addition to the standard functions such as "Cut", "Copy", "Paste", etc., the context menu of the topology configurator provides further functions:

Function	Description
Edit	If a topology has been read in via an archive, it will be displayed write-protected on a gray background. By editing or by clicking on the Import button, it is included in the topology list and can be processed.
Replace component	Replaces an already connected component with an equivalent component from a different topology of the opened topology project. Only components from the same device class and that have the same number of DRIVE-CLiQ ports are listed. When replacing components, all of the components wired to the original component are kept.

Function	Description
Convert Component	Converts the selected component and directly connected lower-level components into another module. SMI, SMC and DQE modules can be converted in this way.
Rewire	Downlink port:
	In Topo, a component is always generally wired to the lower-level component with its first DRIVE-CLiQ port (X100, X200,). If the wiring is to be made to another port, then any free DRIVE-CLiQ port can be selected here.
	Uplink port:.
	In Topo, as a standard, a component is always wired to the higher-level component using its first DRIVE-CLiQ port (X100, X200, etc.). If the wiring is to be made to another port, then any free DRIVE-CLiQ port can be selected here. Rewiring is also possible by means of drag-and-drop
Search	Lets you search for character strings within the topology tree.
Print	Allows a topology tree or a topology graph to be printed out. For a topology graph, in addition, a legend of all properties can also be printed out at the same time.
Zoom	Only in the topology graph Allows the size of the display to either be increased or decreased (zoom in/zoom out) in the topology graph. The size can also be changed as required by holding down "Ctrl" and turning the mouse wheel.

See also

Managing modules (Page 303)

Topo - menu functions (Page 298)

6.4.2 Managing modules

Modules

The module window integrated in Topo contains templates of modules for each supported device class. The module window is structured according to specific groups of topics.

These modules can be dragged to the topology configurator and connected to a free DRIVE-CLiQ port.

6.4 Topo - operation






Figure 6-3 Modules

Component properties

Each component can be assigned various properties, depending on the device class:

Component properties of user-defined topolo- Component properties of comparison topology gy (*.utz) (*.ust)





Property	Description	Note
Component grou	ıp	
Name	Name of the component.	Component names must be unique and have a maximum of 50 ASCII characters.
Article no.	Order number of the component.	You can specify the article number so that in addition to the wiring, the package also checks the use of the correct components based on the article number.
		If a position in the article number should not be checked, you can do this by specifying an 'x' (e.g.: 6SL3120-1TE23-0Axx).
		If an article number differs when executing the package, the package generates an alarm that the operator can ignore.
		If a "?" is in a position, this position will be specified by the SINAMICS on importing the user-defined topology.

6.4 Topo - operation

Prope	erty	Description	Note
K no.	-	The CU-related SINAMICS component number is displayed or specified.	 The component number can be edited. The following rules apply: The SINAMICS component number range is between 1 and 199. Component number 1 is assigned automatically for control units and cannot be edited. In relation to a control unit, the component number must be unique. For all other components, the component number can be in the range from 2 to 193 in relation to a control unit (CU320, NCU or NX) (6 K numbers are reserved for CU-LINK DOs).
			 In the topology configurator, the component numbers can be automatically reassigned or added via the context menu when selecting a bus or slave.
K sta	tus	Setting options:	The default value is "HW available, active."
		HW available, inactive (p1x5=0)	Cannot be changed for CU320 and NCU control
		HW available, active (p1x5=1)	units.
		HW not available, inactive (p1x5=2)	Also cannot be changed for DOs that only consist of one component.
OEM	ID	Identifier of the component in the catalog of the machine manufacturer.	Only numbers can be used.
DO st	tatus		
DO variable		The specified DO variable is assigned to this component. The drop-down list lists all DO variables available in the DO variable list (see Topo - menu functions (Page 298)) that are permitted on this component in accordance with their type.	Not available for device classes that do not constitute a drive object, e.g. motor, encoder. A DO variable name must start with a letter or an underscore and comprises the characters A-Z_0-9.
	DO type	Assignment of a DO to a component type.	Is a property of the DO variable and can only be modified via the DO variable list (Page 307).
	DO number	DO number via which a drive object is addressed.	Is a property of the DO variable and can only be modified via the DO variable list (Page 307).
	DO name	Freely selectable name for a drive object.	Is a property of the DO variable and can only be modified via the DO variable list (Page 307). DO names can have a maximum of 24 ASCII characters.
DO status		Setting options:	The default value is "1 active, available".
		0 inactive, available	The "Active" status cannot be changed for the
		1 active, available	DO types "Integrated (NCU)" and "SINAMICS
		2 not available	S".
Encoder number		Specifies the number of the Encoder Data Set (EDS) to which this encoder evaluation with its associated encoder data set is assigned in the referenced DO.	Only permissible in conjunction with a DO variable reference. Only for device class "Sensor Module".

6.4.3 Manage DO list

The DO list that you can call via the main menu "Data > Manage DO list" is used to manage the DO variables used in the topology project.

DO variables can either be created manually or imported from an existing UVD file and then edited. The UVD file serves as an interface between the Expert and Topo configuring tools. DO variables can be exported from Topo as well as from Expert in a UVD file () or imported from this (). It is also possible to link a UVD file ().

We recommend linking the same DO list in Topo and Expert.




Figure 6-4 Manage DO list

Assigning properties to variables

You can assign the following properties to each DO variable:

Property	Description	Note
DO variable	Name of the DO variable used in the package for assignment to a drive object.	Valid characters are: a-z, A-Z, 1-9, _ (no numbers at the beginning, min. 2, max. 24 characters)
DO type	Defining the DO type.	-

6.4 Topo - operation

Property	Description	Note
DO No.	DO number via which a drive object is addressed.	Only numbers between 2 and 54 as well as 61 and 62 are permitted.
		For Control Units (CU_I, NX) only a "1" is permissible.
		The DO number 63 is reserved for DO number-independent BICO connections within a DO.
		The numbers 55 to 60 are reserved for "CU-LINK" DOs.
DO name	Freely selectable name for a drive object.	Max. 25 characters.
Description	Freely selectable description text for the DO variable.	-

DO type

DO type	Module assignment
SINAMICS S Integrated (NCU) Extended (NX)	Control Unit
Determine INFEED from HW ACTIVE INFEED CONTROL SMART INFEED CONTROL BASIC INFEED CONTROL	Line module
SERVO	Servo, Servo HF
Determine TM from HW TM31 TM41 TM15 TM120	Terminal module
TB30	Terminal Board
DMC20 / DME20	Hub Module
CU-LINK	-

Number of components

Restrictions with regard to the number of components that can be assigned a DO also apply. Only the following assignments are permitted:

DO type	Component type	Permitted number
SINAMICS S (CU320)	CU320, all variants	1
Integrated (NCU)	NCU, all variants	1
Extended (NX)	NX, all variants	1
	Line module	1
	Voltage sensor module	1

DO type	Component type	Permitted number
	Motor module	1
	Motor	1
	Sensor module	2
	Encoder	2
	Terminal Module	1
	Terminal Board	1
	Hub Module	2
	NX10 or NX15	1

Note

You can recognize which components are assigned to which DOs.

If you select a wired component, the remaining components that are assigned to the same DO are highlighted.

Display of the DO variables

The properties of the DO variables assigned to a component are displayed in the "Properties" dialog box.




Figure 6-5 Component properties

6.4.4 Comparing topologies

The topology comparison offers the option of comparing two topologies as well as components - or to synchronize the individual properties of a component.

Two topologies in the current project that have been selected can be compared via the menu "Compare > Refresh" !!

It is also possible to compare a topology in the project with one from an archive or from a .ust or .utz file via the menu "Comparison > Compare with External Topology".

6.4 Topo - operation




Figure 6-6 Comparing topologies

Marking the differences in the component properties


The Properties table displays differences in the properties of the components and at the same time offers the option of editing the properties. In addition, it is also possible to synchronize individual properties of the component or also complete components between two topologies via the context menu. Differences in the properties of the two components that have been selected are shown in color.

For the article number, differences at the individual positions are also shown in color. The colors have the following meanings:

Red	Property is available in both components, but is different
Blue	Property is only available in the component selected in the right-hand topology
Green	Property is only available in the component selected in the left-hand topology
Gray	Digit of the article number irrelevant (x)

Identifying the differences in the topologies


After the topologies have been compared, then the result of the comparison is shown in the lower section. You can jump directly to the location in the topologies where the differences were identified via the context menu "Go to Difference" or by double-clicking the message line.



6.4.5 Deploy topology

Procedure

To deploy the topology in Topo, proceed as follows:



- 1. Select the topology that is to be deployed.
- 2. Set the mode of the topology to deploy this as user-defined topology (*.utz) or comparison topology (*.ust).
- 3. Set the correct CNC version.
- 4. Start the deployment.

6.5 Command line call

Create MyConfig Topo can be executed in command line mode for the automated deployment.

Call

Note

Note the following rules for the command line call:

- The /silent option must always be specified first.
- Path specifications may not end with '\'.

Parameter

Options / switches	Arguments	Description		
-	<topology path=""></topology>	Specifies the path of the project file – either absolute or relative.		
		The path must be specified in double inverted commas if spaces are included in it. Example: "C:\Path with spaces\package file"		
		 For topology projects (*.uptz), the name of the topology to be compared must be specified separately behind the path with a colon. If no name is specified, the first topology contained in the project is selected. 		
		 uptz, ust, utz, and xml files according to the Topo interface description as well as SINUMERIK archives are permitted. 		
/diff	<file1></file1>	Two paths to uptz, ust, utz, arc files.		
	<file2></file2>	 For topology projects (*.upt), the name of the topology to be compared must be specified separately behind the path with a colon. 		
/silent	-	The graphical user interface of Create MyConfig Topo is hidden.		
		The following options are only effective with this switch.		
/deploy	<deploy name=""></deploy>	Causes the topology selected in the project to be checked and deployed.		
		 If the parameter is omitted, Topo will generate the name from the <topology path="">.</topology> 		
/deploydir	<deploy directory=""></deploy>	 Specifies the deployment path, absolute or relative, in which the topology is to be deployed. 		
		The path must be specified in double inverted commas if spaces are included in it. Example: "C:\path with spaces"		
		If the switch is omitted, Topo uses the folder of <topology path="">.</topology>		

Options / switches	Arguments	Description
/log	<log file=""></log>	Specifies the path of a log file – either absolute or relative.
		 Alarms and faults are written to the log file (XML format) when checking and deploying the package.
		Specification of this switch with its parameter is optional.
/target	UST UTZ27 UTZ44 UTZ45 UTZ47	Deployment type and CNC software version of the NCU on which the specified topology is used.
/autocomplete	-	Automatically adds missing component numbers and DO properties and sets up standard encoder assignments if none have been specified.

Return values

Note

The return values for the Topo command line call only apply if Topo is executed in /silent mode without the user interface.

Value	Description
0	No faults or alarms occurred when checking/deploying the project.
1	Alarms but no faults occurred when checking/deploying the project.
2	Faults (and possibly alarms) occurred when checking/deploying the project.
3	Incorrect command line call

6.6 SINAMICS device configuration

Example

Precondition: Create MyConfig is installed in the directory "C:\Program Files\SIEMENS\Create MyConfig 4.7" and a project "TopoProj_1.upt" that contains the "Topo1" and "Topo2" topologies is available in the path "C:\Topologie."

```
Set PATH=%PATH%; "C:\Program Files\SIEMENS\Create MyConfig 4.7"
Topo.exe /silent "C:\Topologies\TopoProj 1.upt:Topo1" /deploy xyz /
deploydir "D:" /target UTZ44
if %ERRORLEVEL% EQU 3 (
@echo "command line call errors!"
pause
)
if %ERRORLEVEL% EOU 2 (
    @echo "Faults during deployment!"
    pause
if %ERRORLEVEL% EQU 1 (
    @echo "Alarms during deployment!"
    pause
if %ERRORLEVEL% EQU 0 (
    @echo "Deploy executed without error!"
    pause
)
```

6.6 SINAMICS device configuration

6.6.1 Production of modular machines

The Create MyConfig (CMC) engineering software supports both the automated production of modular machines for the machine manufacturer as well as the upgrade of machines for end customers, which requires only a limited number of operator actions.

The production of machines with 840D sl requires a basic commissioning of the SINAMICS, generally designated as "System configuration". The system configuration can be performed with CMC either as "Automatic configuration" or as "User-specified topology."

When the system configuration is configured in the CMC package, all the data sets and optimization data in the step tree required within a series of modular machines in the maximum machine configuration can be specified. The package is adapted to the specific version of a modular machine either initially during the configuring or when the package is being executed on the machine – either manually or using configuration files.

6.6.2 SINAMICS device configuration with Automatic configuration or user-specified topology

Applications

A differentiation is made between three applications that CMC supports when configuring SINAMICS:

- The SINAMICS was commissioned previously with SINUMERIK Operate or with a different commissioning software. The existing drive data can be checked with a CMC package via "Initial state" (online access) on the dialog page "System configuration" under "DRV..." in the drive archive data, including the topology. In addition, a further configuration or optimization of the SINAMICS can be made.
- 2. The maximum configuration of the SINAMICS is wired on the machine, but the SINAMICS has not yet been commissioned or configured. Using a CMC package, the "Automatic configuration" under "DRV archive data/drive configuration" is selected from the "System configuration" dialog page. The checks, configurations or optimizations listed in item 1 in the same package are then performed.
- 3. Not all the SINAMICS components provided for the maximum configuration of the machine have already been wired on the machine. For example, DQI/SMI motors are still missing. The SINAMICS has not yet been commissioned and configured. Using a CMC package, the "User-specified topology" under "DRV archive data/drive configuration" is executed from the "System configuration" dialog page. The user-defined topology file is a SINAMICS offline topology package (SOT) that contains the topology in the final configuration of the machine. The checks, configurations or optimizations listed in item 1 in the same package are then performed.

Differences between "Automatic configuration" and "User-specified topology"

The table below shows the major differences between "Automatic configuration" and "User-specified topology." In the same way as the automatic device configuration via SINUMERIK Operate, the PROFIBUS assignment (p978), the message frames and the BICO links are also entered automatically in both CMC variants.

Table 6-1

Automatic configuration	User-specified topology
Execution via SINUMERIK Operate or CMC (identical result).	Execution only via CMC.
The SINAMICS performs an automatic configuration and determines its own actual topology.	A user-specified topology is transferred to the SINAMICS in the CMC package that is applied as the target topology.
Only those SINAMICS modules wired at the time of the automatic configuration are acquired.	The user-specified topology can also include SINAMICS modules that have not yet been wired and deactivated, exception: NCU, NX, CU320.
The DRV archive data also contains the DOs and components that have been wired after the automatic configuration was performed.	After importing the user-specified topology, the DRV archive data contains all DOs and components that were specified in the user-specified topology.

Automatic configuration	User-specified topology
The step-by-step commissioning is possible only to a limited extent (e.g. the addition of DQI/SMI motors).	The step-by-step commissioning is possible almost without limitation (e.g. the addition of DQI/SMI motors).
The specification of the comparison topology file allows the DRIVE-CLiQ wiring to be checked.	The SINAMICS reports an error if the topology specified in the user-specified topology cannot be implemented.

Configuring in Expert

When configuring in Expert, on the "System configuration" dialog page in section "DRV..." under "Origin of data", you can define which of the four applications "Initial state," "Automatic configuration," "User-specified topology," or "Offline archive" is applicable.

By selecting the "User-specified topology" mode, it is necessary to generate with Topo a file with the user-specified topology and make it available to the package for execution on the "SINAMICS topology" dialog page. The user-specified topology file has a binary format with the file extension "utz."

If "automatic configuration" is performed, as an option, you can use on the "SINAMICS topology" dialog page a file with the comparison topology in XML format and the file extension "ust" or "xml". This is used for comparison with the automatically detected topology.

The two topology files can be configured in one package. During execution, the setting Origin of data" under "DRV archive data/drive configuration on the "System configuration" page determines which of the two settings will be used on the following "SINAMICS topology" page.

Both the user-specified topology and the comparison topology contain the topology of the SINAMICS and other properties of the DOs and the components.




Figure 6-7 CMC package structure

6.6.3 Drive data generation via "automatic configuration"

Basic procedure

The "automatic configuration" via SINUMERIK Operate or via CMC uses the same functions internally. In both cases, the SINAMICS determines its actual topology and saves it as target topology (p9903). This also includes the creation of drive objects (DOs) and their assignment in a folder structure according to bus number and slave number. Each DO is represented as a PS file either in ACX or ASCII format (*.TEA). The file PS000000 is used for the consistence monitoring and the file PS000099 contains configuration data of the internal PROFIBUS. This structure can be saved as drive archive and imported later.




Figure 6-8 Drive data storage

SINAMICS specifies for the "Automatic configuration" DO names, DO numbers, component names, component numbers, etc., and acquires component properties such as article number, component category and component type. The parameters for the DOs are read out of the components, calculated or assigned with factory settings.

The complete data is backed up in the drive data archive.

6.6.4 Drive data generation via "user-specified topology"

Basic procedure

If the SINAMICS device configuration is made with the "User-specified topology," the SINAMICS is assigned a SINAMICS offline topology package corresponding to the maximum configuration of the machine in the form of a user-specified topology file (*.utz) from the CMC package. In other words, components, such as DQI/SMI motors, still may be missing because commissioning has been performed step by step.

In addition to the topology, the user-specified topology file also specifies the DO names, DO numbers, component names and component numbers as well as component properties such

6.6 SINAMICS device configuration

as article number and component type. The structure with generalized drive data is also specified.

Finally, the package processing requests the SINAMICS to check this data based on the currently available configuration and to customize it appropriately, i.e. define the DO or component status. SINAMICS has in the result a customized target topology (p9903) and customized DOs for the specified components.

The DO parameters are customized by SINAMICS with the factory settings, values exported from the components or calculated values. All this data is backed up in the drive data archive.

Because at this time components not yet present in the structure have already been created, the associated user data can be added to the step tree using manipulation tasks. As an alternative, for example with DQI/SMI motors, export of the data from the electronic rating plate with the motor type or encoder type selection can be forced after activation.

6.6.5 Assignment of the drive data using DO variables

Immediately after the "Automatic configuration" or after the "User-specified topology", the physical drives have been assigned to the data in the archive structure. The DOs, however, are not yet assigned to the technological drive and thus to the correct NC axis.

If optimized drive, motor or encoder data has been configured in a CMC package for a DO, it must be known to which physical DO this technological data must be assigned. This means that the path address of this DO must be known. The data is assigned using DO variables.

Diff

When configuring a package in production preparation, SINAMICS data of the modular modules is extracted once as master data to ASCII files from drive archives of one or more commissioned base machines with the comparison component Diff (e.g. drive data, motor data, encoder data of the various axes, line module data, etc.). Appropriate filter settings mean this data no longer contains any topology-specific component numbers when exported.

When exporting, Diff writes a section in front of the data that provides a reference to a topology-specific PS file in the drive data archive. This reference in the section is a short form of the path, e.g. [B3_S3_PS5] instead of [BUS3.DIR\SLAVE3.DIR\PS000005.TEA]. These modular data sets can be maintained and managed in freely selectable folder structures.

Expert

When configuring in Expert , the topology-specific path data can be replaced by symbolic, topology-independent path data using a DO variable, e.g. [\$(Up.doVar.psPath)]. By assigning the drive-specific DO variables to a SINAMICS-DO and the associated simultaneous value assignment of the DO variables using the package during runtime, the DO variable has a defined value and thus also a defined path. The assignment of the DO variables to a SINAMICS-DO can be done manually at runtime in a dialog or in advance during the configuration of the comparison or user-specified topology. With this method, topology-independent SINAMICS parameters (master data) can be flexibly and easily assigned to each DO, regardless of where the drive-specific DO was placed in the SINAMICS group for the current machine.

As a result of the value assignment during the execution of the package, the symbolic path data is replaced with absolute paths and the topology-independent SINAMICS data that do not contain any component numbers are assigned to the drive-specific components in the current topology.

Example

Execution step	Result			
metallia po in the data at an an		[B3_S3_PS5] (corresponds to the path of the data storage		
		IR\SLAVE3.DIR\PS000005.TEA])		
Replacement of the reference with a symbolic path.		X.psPath)]		
	[]	Section for path details in the data storage		
		Replacement operator		
		Identification of a package variable		
		DO variable		
	psPath	Property that specifies the path in the data storage		
Assignment of the DO variables to a DO in the topology.	Manual assignment at runtime on the "SINAMICS topology" dialog page or during the configuration of the topology			
Use of the path property after assignment of the doX variables to the DO at runtime.	[\$(Up.doX.psPath)] becomes [B3_S15_PS10] if the DO is on the first NX and has the DO number 10 (BUS3.DIR \SLAVE15.DIR\PS000010.TEA)			

If DO variables are assigned as reference sensor modules of a second encoder, an assignment of this encoder to the associated servo drive can be performed while executing the package by entering the component numbers specified by SINAMICS during the package processing of CMC automatically into the parameters for the sensor module and encoder module p141[1] or p142[1] of the DO.

Other properties of DO variables are used to obtain the current topology information and optionally further process this information, e.g. the assignment of the PROFIBUS.

Properties of DO variables

The following properties are available for a DO variable with the name "doVar". The DO variable name "doVar" can be freely selected, for example "doX", "X drive", etc.

Table 6-2 Properties of DO variables

Property	Description
Up.doVar != null	Supplies "true" if the DO variable was assigned to a drive component at runtime.
Up.doVar.doNr	Supplies the number of the DO (NOTICE: The renumbering is performed beforehand).
Up.doVar.slaveNr	Supplies the number of the higher-level slave object.
Up.doVar.busNr	Supplies the number of the higher-level bus object.
Up.doVar.psPath	Replaces in a section the path to the PS file in the archive.
Up.doVar.dpSlot	Supplies the PROFIBUS location number, starting with 1 (only for servo of the NCU and NX).

The "Assignment of the DO variables to SINAMICS components" figure shows an example how the properties of the DO variables are assigned after the assignment for the package

6.6 SINAMICS device configuration

processing. The properties of the DO variables can only be read in the manipulation tasks and step scripts.




Figure 6-9 Assigning DO variables to SINAMICS components

Note

We recommend that the drive data is assigned to the drive objects via the assignment of DO variables. Although a direct assignment via a path specification is possible in short form, this limits the flexibility and can easily result in errors.

Assignment options

There are two ways of assigning the DO variables to the SINAMICS components:

- 1. When processing the package, you need to manually assign the DO variables to the SINAMICS components on the "SINAMICS topology" dialog page.
- 2. The DO variables are assigned to the SINAMICS components as a property during the configuration of a comparison topology or user-specified topology. The two topologies are linked into the project on the "SINAMICS topology" dialog page. Which topology is used during the runtime depends on the configuration of the DRV area on the "System configuration" dialog page.

6.6.6 The advantages of using comparison or user-specified topology

The configuration of a comparison or user-specified topology with Topo and the use of the file in the package, offer a number of additional advantages:

Advantages for the configuration of the topology with Topo

- Understandable topology creation thanks to a graphical wiring diagram
- Support with component box, context menu, verification run and graphic / color-coded visualization
- Printing the wiring diagram of the SINAMICS components with legend for documentation purposes
- · Comparison of topologies
- Import of topologies from drive archives
- Management of DO variables

Advantages of the topology file during the package execution

- The actual wiring of the SINAMICS in the control cabinet can be checked using the machine topology exported from SINAMICS. Warning or error messages are issued should deviations occur.
- You can check the properties of the components wired via DRIVE-CLiQ (DO type, article number, etc.). Wildcards are allowed when specifying the article number, e.g. 1FK7042 xAF7x xFxx.
- Sensor Modules not directly wired to a Motor Module, but rather to a hub or a CU, can be uniquely assigned to a DO.
- The specification of an OEM-ID is used to assign the SINAMICS-CU local component number to a particular OEM global unique identifier. When processing the package, the OEM component number in the DO1 is written to the parameter p7859 [component number].
- For the comparison topology, the DO names, DO numbers and component names specified by SINAMICS for the "Automatic configuration" can be replaced by user-specific data.

DO names

If a change of the DO name is configured, then this is automatically entered into the ${\sf SINAMICS}$ parameter p199 .

DO number

With the drive device configuration, SINAMICS assigns the DO numbers for all DOs at the CU and the NXs, i.e. on the particular CU starting at 1. For a machine series, it is more understandable, for example, if the X-drive, irrespective of its positioning in the SINAMICS group, always has the same number and that the DO numbers in the SINAMICS group are unique. The value range for the DO numbers lies between 2 and 54.

Component names

The component names can be freely assigned. The names of the SINAMICS components are displayed on the dialogs and in the screen forms and messages of SINUMERIK Operate.

6.6 SINAMICS device configuration

- When a user-specified topology is used, the component numbers must also be specified in addition to the DO names, DO numbers and component names. The use of the DO names, DO numbers and component names corresponds to the above explanations for the comparison topology. When the user-specified topology is used, the component numbers must also be specified. The CU and the NX must contain 1; the numbers on the CU or NX must not be assigned more than once and must be in the range 2 to 199. In Topo, the component numbers can also be automatically assigned via the shortcut menu.
- When configuring a user-specified topology, the activation status of the DOs and components can still be specified.
 The following is true:
 - 0 inactive and present
 - 1 active and present
 - 2 not present

The status is entered in the following parameters:

- p105 DO activation/deactivation
- p125 Motor Module activation/deactivation
- p145 Sensor Module activation/deactivation

DO list - comparison topology - user-specified topology

The mentioned properties and their specification are summarized in the following table:

Properties	Set	Check	DO list in the package [*.uvd]	Reference topology *.ust	User-specified topology *.utz
DO variable	[x]		package [.uvu]		Expanded
DO type		х			user-specified
DO number	Х		Creation in		topology *.uptz
DO name	х		Expert/Topo		
Wiring	SOT	SOT/VT			
Article number	SOT	SOT/VT		Creation in	
Component names	Х			Торо	
Component number	Х				'
DO activation	х				Creation in
Component activation	Х				Торо

Figure 6-10 DO list - comparison topology (VT) - user-specified topology (SOT)

6.6.7 Configuration of the topology with Topo

CMC Topo can be used to configure not only a comparison topology but also a user-defined topology. The operation of CMC Topo is described in detail in Section Create MyConfig – Topo (Page 294).

The wiring diagram for the DRIVE-CLiQ connections and some of the properties are identical for both topologies.

With the changeover from comparison topology to user-defined topology, the additional properties DO activation, component activation and component number must also be specified.

On switchover to comparison topology, the data remain stored for when switch-back to user-defined topology is performed. These data have no effect in the comparison topology.

For the deployment as user-defined topology, other necessary data is added internally and output as binary user-defined topology file.

To deploy a user-defined topology, it is necessary to specify a CNC software version.




Figure 6-11 Variants of the topology generation with CMC Topo

See also

Generation of the comparison topology using external software (Page 267)

6.6.8 Generation of the comparison topology using external software

The structure and the contents of the comparison topology for a package is an open and documented interface, the Topo XML interface. The file format is XML.

You will find more information on this in Section Interface - Topo-XML (Page 331).

This means that it is also possible to generate the comparison topology using external software, which is integrated in the PLM process of the machine manufacturer, e.g. ePlan, ELCAD or similar. When required, the externally generated comparison topologies can also be read-in in Topo as part of the production preparation for control purposes or adaptations, before they are linked into the project when configuring with Expert or placed next to the package as configuration file. A comparison configuration file, which is located in or next to the package, can also be selected manually on the dialog of the "SINAMICS topology" during the runtime. Normally, a special topology must be created for each machine version, whereas one package can be sufficient for all machines.




Figure 6-12 Configuration of a CMC package with comparison topology or user-specified topology

Compatibility of CMC versions and CNC software releases

The Topo XML interface is available in the version SCI 2.6, CMC V4.4/4.5 and CMC V4.6. For transfer, CMC Topo V4.6 no longer supports the Topo XML interfaces SCI 2.6 and CMC V4.4/4.5.

Note

CMC Topo 4.6 can only generate comparison or user-specified topology for CMC packages 4.6.

For deployment of a user-defined topology, the CNC system software version must be defined to which this will be applied.

CMC Topo V4.6 supports the CNC software versions V2.6, V2.7, V4.4, V4.5, and V4.6.

6.7 Extended user-specified topology

Requirement

As of the Create MyConfig version V4.7 there is also the extended user-specified topology as a third mode in addition to the comparison and user-specified topology.




Figure 6-13 Extended user-specified topology

In addition to the SINAMICS wiring diagram, there is also NC and DRV data in the extended user-specified topology.

The starting basis for the extended user-specified topology is the archive import of a functioning machine.

After the import, the wiring diagram is displayed as for V4.6. In addition, additional NC and DRV data are available in the background for a manipulation.

All of the data remain available until it is deleted and can be saved as Topo project <Name>.uptz.

During the import, DO variables are automatically assigned to the drive objects (DO). These are needed for the drive or encoder assignment.

Components can be deleted, added or moved using the known mechanisms such as drag and drop, copy and paste.

Drive objects

The extended user-specified topology works only with complete drive objects.

This means that

- when a DO is moved, the complete dataset is always moved, including all of the components used in it.
- all of the data of the DO is symbolically displayed by the "Motor module" component (TM, hub).
- the complete DO is always considered when adding/deleting a motor module.

6.7 Extended user-specified topology

If individual measuring systems are processed, these must be changed via the data view (see below).

Note

Measuring system / Motor data

Note that it is not possible to assign a measuring system or motor data to a different DO by moving a component.

Example: moving a dual axis module from Slave 12 to Slave 13

In the following example, the selected dual motor module is moved from NX Slave 12 X103 to NX Slave 13 X102. During the move

a prompt appears, asking whether attached components, NC or drive data should also be moved or deleted.

The colored highlighting denotes the attached data.




Figure 6-14 Moving a dual axis module from Slave 12 to Slave 13

Note

No more than 6 motor modules (MM) can be connected to one slave:

6.8 Axis-drive assignment

After the drives have been configured in SINAMICS, there is no assignment yet between the NC axes and servo drive objects. The desired assignment must to be explicitly written into a number of NC machine data.

Configuration is possible with CMC. After automatic device configuration or user-defined topology, a service drive object (DO) of a topology is automatically assigned to each NC axis. Configuration takes place in Topo. The necessary NC data are written during execution of the package.

if an axis-drive assignment has been performed on a machine, Topo can perform a diagnosis using the NC-DRV archive.

Configuration

First of all, the topology must be available as a comparison or user-defined topology and DO variables must be assigned to the component of the servo drive objects.

The table for configuring the axis-drive assignment is called using the **Tools** menu or the icon. Only under **Display: Standard** is configuration possible.



The data are displayed that are relevant for configuration. Assignment of the machine data, e.g. I/O address, will not be performed until during runtime of the package and cannot be displayed at the time of configuration.

Axis-drive assignment - Maschine 1 - - X Display: Standard - *} 🝍 Calculation using I/O address Calculation using drive number Axis Axis Setpoint/actual value type Input NC drive DO Variable DO No. DO Name name DR1 ▼ AXX_00_3_3_11 11 AXX 00 AX1 $\times 1$ 1: Setpoint output active • • AXX_00_3_3_11 11 MS 1 x1 l: Raw signal encoder 1 DR1 AXX 00 2 MS 2 x1 4: Absolute encoder, gen. DR1 AXX 00 3 3 11 11 AXX 00 12 AX2 yl 1: Setpoint output active • DR2 ▼ AXY_00_3_3_12 AXY 00 • MS 1 v1 l: Raw signal encoder 1 DR2 AXY_00_3_3_12 12 AXY 00 4: Absolute encoder, gen. 2 MS 2 12 v1 DR2 AXY_00_3_3_12 AXY 00 ✓ DR3 ▼ AXZ_00_3_3_13 АХЗ zl 1: Setpoint output active 13 AXZ 00 13 l: Raw signal encoder **▼** 1 ✓ DR3 AXZ_00_3_3_13 AXZ_00 MS 1 zl • MS 2 21 0: Simulation **▼** 2 ✓ DR3 AXZ_00_3_3_13 13 AXZ 00 ✓ DR4 - AXC_00_3_3_14 AX4 1: Setpoint output active • 14 AXC 00 c1MS 1 cl l: Raw signal encoder **▼** 1 DR4 AXC_00_3_3_14 14 AXC 00 • MS 2 cl 0: Simulation ▼ 2 DR4 AXC_00_3_3_14 14 AXC 00 DR5 ▼ AXA_00_3_13_17 17 AX5 Al 1: Setpoint output active • AXA 00 • DR5 17 MS 1 Al l: Raw signal encoder **▼** 1 AXA_00_3_13_17 AXA 00 MS 2 A1 0: Simulation ▼ 2 DR5 17 • AXA_00_3_13_17 AXA_00 AX6 spl 1: Setpoint output active DR6 - AXSPI1_00_3_13_16 16 AXSPI1 00 **▼** 1 16 MS 1 spl l: Raw signal encoder DR6 AXSPI1_00_3_13_16 AXSPI1_00 MS 2 spl 0: Simulation ▼ 2 DR6 AXSPI1 00 3 13 16 AXSPI1 00 • Axis-drive assignment using the I/O address Axis-drive assignment using the drive number Axis-drive assignment using the I/O address and the drive number Close User-defined axis-drive assignment

Example of a tabular view for configuration

Figure 6-15 Table axis-drive assignment - representation standard

The table for configuration of the axis-drive assignment is composed of the following table columns:

Display of the axes AX1 to AX31, including the two possible measurement systems MS1 and MS2. For configuration, the name of the axis that is written into the NC machine data
For configuration, the name of the axis that is written into the NC machine data
VIOOOO \$MN_AXCONF_MACHAX_NAME_TAB during package execution must be entered here.
n this column, the Setpoint output can be activated via a list box and the encoder type can be specified. These data are entered in the following NC machine data:
N30130 \$MA_CTRLOUT_TYPE N30240 \$MA_ENC_TYPE N30200 \$MA_NUM_ENCS Activated axes and measurement systems are displayed on a white background.
13 13 13 υ t

Table column	Meaning
Input	In this column, the input can be modified for the measurement systems. This states whether it is the first or the second encoder.
NC Drive	The "NC drive" column is not activated by Topo until after assignment of the DO variable and contains the drive number.
	This assignment can be influenced if no automatic assignment is possible.
DO variable	The columns "DO variable," "DO No.," and "DO name" are coupled to each other to form a drive object.
DO No.	A DO variable must be assigned to the NC axis via a list box.
DO name	All the drive objects are available that have been assigned to the motor modules or sensor modules in the topology.
	Note
	Selection is only possible if the DO variable table is correctly filled out.

Assigning axes to the drive

There are two ways of assigning the axes to the drive:

1. Axis-drive assignment by adaptation of the I/O addresses - Calculation using I/O address
In this setting, the drive number is set to be equal to the axis number and the NC address machine data are adapted.

```
N13050 $MN_DRIVE_LOGIC_ADDRESS
N10393 $MN SAFE DRIVE LOGIC ADDRESS
```

2. Axis-drive assignment by adaptation of the drive number - Calculation using drive number With this setting, an attempt is made to adapt the drive number in he NC axis machine data in such a way that the I/O addresses remain at the default values.

```
N30110 $MA_CTRLOUT_MODULE_NR..
N30220 $MA_ENC_MODULE_NR
N36906 $MA_SAFE_CTRLOUT_MODULE_NR
N10000 $MN AXCONF MACHAX NAME TAB[?]
```

Note

In special cases, such as CU320, setpoint switchover etc., no automatic assignment can be made. In this case, it is up to the configurer to select the NC drive. This is the configurer's own responsibility. A manual selection is always marked with yellow in the "NC drive" column.

In the bottom status area/legend, the assigned colors are explained and the most important axis-drive assignment is highlighted.

The table corresponds to the topology representation, i.e. if an assignment has occurred and an axis has been clicked, the associated drive object will be selected in the topology image.

Diagnostics

If you import an NC/DRC archive via the Project > Display/import topology... menu, the topology will be shown on a gray background.

When you open the "Axis-drive assignment" dialog box, you see the "Display: Diagnosis". This contains all consistent information required to represent the exact assignment of the relevant machine data as they have been set on the machine by automatic axis-drive assignment or manually.

6.8 Axis-drive assignment

This table is used for diagnostics and checking the axis-drive assignment. If, with the "Import" button, you take over the topology on a gray background into the topology list of Topo, you can perform another configuration and the displayed list under "Diagnostics" becomes invalid.

When you open the "Axis-drive assignment" dialog, after importing in the "Axis-drive assignment" dialog, you will see the "Display: Standard". You can change the configuration. The axis drive dialog with "Display: Diagnostics" is not available for the topologies in the topology list.

Example of a tabular view for diagnostics





Figure 6-16 Table axis-drive assignment - representation diagnostics

Configuration Dialog

A configuration dialog box is opened with the notice it is it is it is it. In the dialog box, the "standard" and "diagnostics" variants offered in the display can be changed with regard to the columns shown and new user-defined display variants can be added.

6.9.1 Example for displaying the wiring using an XML image



```
<?xml version="1.0" encoding="UTF-8"?>
<dp preliminary="true" build="008" appVersion="4.7.0.2"</pre>
version="4.7.0.0">
  <bus subsystem="3">
    <slave address="3">
      <control unit ncu doname="NCU XY" donr="1" dotype="3"</pre>
dovar="doCU" name="NCU" compnr="1">
        <cliq index="0">
          <line module doname="ALM XY" donr="2" dotype="3003"</pre>
dovar="doLM" name="ALM" compnr="2">
            <cli>q index="0" uplink="true"/>
            <cliq index="1"/>
            <cliq index="2"/>
          </line module>
        </cliq>
        <cliq index="1">
          <motor module doname="X-drive" donr="3" dotype="11"</pre>
dovar="doX" name="MM X" compnr="3">
            <cli>q index="0" uplink="true"/>
             <cliq index="1">
               <motor module doname="Y-drive" donr="4" dotype="11"</pre>
dovar="doY" name="MM Y" compnr="7">
                 <cli>q index="0" uplink="true"/>
                 <cliq index="1">
                   <sensor module name="SM1 Y" compnr="9" sm="1"</pre>
doref="doY" group="DQI Y">
                     <cli>q index="0" uplink="true"/>
                     <encoder name="Enc1 Y" compnr="10" group="DQI Y"/</pre>
>
```

```
<motor name="Motor Y" compnr="11" group="DQI Y"/</pre>
>
                  </sensor module>
                </cliq>
                <cliq index="2"/>
              </motor module>
            </cliq>
            <cliq index="2">
            <sensor module name="SM X" compnr="5" sm="1" doref="doX">
                <cli>q index="0" uplink="true"/>
                <encoder name="Encoder X" compnr="6"/>
              </sensor module>
            </cliq>
            <motor name="Motor X" compnr="4"/>
          </motor module>
        </cliq>
        <cliq index="2">
          <sensor module name="SM2 Y" compnr="8" sm="2" doref="doY">
            <cli>q index="0" uplink="true"/>
            <encoder name="Enc2 Y" compnr="12"/>
          </sensor module>
        </cliq>
        <cliq index="3"/>
      </control unit ncu>
    </slave>
  </bus>
</dp>
```

Explanation

<element></element>	black, bold	Tag element
attr=""	black, normal	Required attribute
attr=""	gray, normal	An attribute that is only required in a certain constellation
attr=""	blue, italics	Optional attributes for the parameterization of the package (variables)
attr=""	brown, italics	Optional attributes to change the component name
attr=""	green, italics	Optional attributes to restrict to certain components when checking

6.9.2 Description of the XML structure

SINAMICS components


SINAMICS components should be specified in the structure as XML elements based on their device class. To further reduce the recognition tolerance level, restrictive attributes can be specified (order number).


Device classes:

control_unit_ncu, control_unit_nx, control_unit_cu, line_module, voltage_sensing_module, motor_module, sensor_module, motor, encoder, motor_module_hf, damping_module, sine_filter_module hub_module, terminal_module, terminal_board motor_module_hf, damping_module, sine_filter_module

Composite modules

For composite modules, such as Double Motor Modules and 120 combi modules, their internal structure must be mapped in the XML structure. To ensure the correct display as composite module in Topo, all the internal components belonging to such a module must be identified with the attribute group="<name of the composite component>". In addition, the "index" attribute with the position inside the module must be specified (MM1 → index=1, etc.) for components of the same device class (here Motor Module).





Analog connection type

Power connection type

Figure 6-17 S120 Combi topological modeling

Automatically created DOs for DRIVE-CLiQ components

SINAMICS automatically creates DOs for specific DRIVE-CLiQ components.

Automatically created DOs for DRIVE-CLiQ components:

control unit ncu,

motor module hf control unit nx, control unit cu, line module, motor module, hub module, terminal module.

terminal board.

SINAMICS components for which a DO is created, can be assigned a "dovar" attribute. Using the "dovar" attribute, the component is assigned a DO variable. This DO variable contains the properties of the DO that can be used subsequently by the package when executing the package.

If such a component was assigned a DO variable manually or via the Topo XML file, this DO

variable can also be used to specify the user-specific DO name and DO number. For each component that is assigned a DO variable, an appropriate type must also be specified via the "dotype" attribute.

The possible DO types are:

- SINAMICS S
- Integrated (NCU)
- Extended (NX)
- ACTIVE INFEED CONTROL
- SERVO
- SMART INFEED CONTROL
- BASIC INFEED CONTROL
- TB30
- DMC20 / DME20
- TM31
- TM41
- TM15
- TM120
- CULINK
- Determine INFEED from hardware
- Determine TM from hardware

DOs not created automatically for DRIVE-CLiQ components

DRIVE-CLiQ components for which no DO was generated by SINAMICS can be assigned existing DOs.

DOs not created automatically for DRIVE-CLiQ components:

sensor_module,

damping_module voltage_sensing_module

This is realized by specifying "doref". "doref" references a DO and thus specifies the association of the component to the DO. To do this, the same DO variable is used as that specified for the required DO via the "dovar" attribute. This allows, for example, Sensor Modules on a hub to be assigned to a SERVO-DO.

The "sm" attribute of the "sensor_module" element designates the encoder as 1st or 2nd encoder of the DO. It must then be used if the encoder cannot be assigned uniquely.

For modeling DQI/SMI motors, a **motor** must be specified on the **sensor_module** along with the **encoder**. The motor must also be removed from the associated **motor_module**. The associated components must be identified with the attribute **group=**"<name of the composite component>".

Non-DRIVE-CLiQ components (motor, encoder, sine_filter_module) must be adequately defined using their subordinate hierarchical position.

The "cliq" element designates a port of a DRIVE-CLiQ component. The "index" attribute specifies the last position of the terminal designation (for $X104 \rightarrow 4$, for $X501 \rightarrow 1$, etc.).

The "uplink=true" attribute in the "CLiQ" element specifies that it involves an "incoming connection" from a higher-level component.

Each component can be assigned an ID using the "oemid" attribute.

This ID is written to SINAMICS parameter p7859[component number] in DO1. Using this parameter, the machine manufacturer can address additional information, such as additional error texts, spare part numbers, etc.

In order to use a comparison topology to generate a user-specified topology without further manual processing in Topo, a unique name as well as a unique component number for each slave ("compnr/compnr2" attribute) must be assigned for each component.

To deactivate individual components of a DO or whole DOs, the "compstate" and "dostate" attributes with appropriate valid values can be assigned to the corresponding components.

6.9.3 XSD for XML-interface

```
<?xml version="1.0" encoding="utf-8"?>
<xs:schema xmlns:xs="http://www.w3.org/2001/XMLSchema"</pre>
elementFormDefault="qualified" attributeFormDefault="unqualified">
  <xs:annotation>
    <xs:documentation>
      Content:
                      Topo XML interface
      Version: 4.7
      Date: 01.09.2014
    </xs:documentation>
  </xs:annotation>
  <xs:simpleType name="uInt">
    <xs:union>
      <xs:simpleType>
        <xs:restriction base="xs:unsignedInt"/>
      </xs:simpleType>
```

```
<xs:simpleType>
       <xs:restriction base="xs:token">
          <xs:enumeration value=""/>
       </xs:restriction>
     </xs:simpleType>
   </xs:union>
 </xs:simpleType>
 <xs:simpleType name="uShort">
   <xs:union>
     <xs:simpleType>
       <xs:restriction base="xs:unsignedShort"/>
     </xs:simpleType>
     <xs:simpleType>
       <xs:restriction base="xs:token">
          <xs:enumeration value=""/>
       </xs:restriction>
     </xs:simpleType>
   </xs:union>
 </xs:simpleType>
 <xs:simpleType name ="smnr">
   <xs:restriction base="xs:unsignedShort">
     <xs:enumeration value="1"/>
     <xs:enumeration value="2"/>
   </xs:restriction>
 </xs:simpleType>
 <xs:simpleType name="state">
   <xs:restriction base="xs:unsignedShort">
     <xs:enumeration value="0"/>
     <!--inactive-->
     <xs:enumeration value="1"/>
     <!--active-->
     <xs:enumeration value="2"/>
     <!--inactive / not available-->
   </xs:restriction>
 </xs:simpleType>
 <xs:simpleType name="dotype">
   <xs:restriction base="xs:unsignedInt">
     <xs:enumeration value="1"/> <!--CU (CU320/CU310)-->
     <xs:enumeration value="3"/> <!--NCU-->
     <xs:enumeration value="4"/> <!--NX-->
     <xs:enumeration value="10"/> <!--ALM-->
     <xs:enumeration value="20"/> <!--SLM-->
     <xs:enumeration value="30"/> <!--BLM-->
     <xs:enumeration value="3003"/> <!--Determine DOType LM from HW</pre>
(only SOT as of 4.6)-->
     <xs:enumeration value="11"/> <!--SERVO-->
```

```
<xs:enumeration value="70"/><!--SERVO HLA-->
      <xs:enumeration value="200"/> <!--TM31-->
      <xs:enumeration value="201"/> <!--TM41-->
      <xs:enumeration value="204"/> <!--TM15-->
      <xs:enumeration value="207"/> <!--TM120-->
      <xs:enumeration value="3006"/> <!--Determoine DOType TM from</pre>
HW (only SOT as of 4.6)-->
      <xs:enumeration value="100"/> <!--TB30-->
      <xs:enumeration value="150"/> <!--HUB-->
      <xs:enumeration value="254"/> <!--CULINK-->
    </xs:restriction>
  </xs:simpleType>
  <xs:simpleType name ="adamode">
    <xs:restriction base="xs:string">
      <xs:enumeration value="ONLINE"/>
      <xs:enumeration value="NONE"/>
    </xs:restriction>
  </xs:simpleType>
  <xs:simpleType name ="axdrnr">
    <xs:restriction base="xs:unsignedInt">
      <xs:minInclusive value="1"/>
      <xs:maxInclusive value="31"/>
    </xs:restriction>
  </xs:simpleType>
  <xs:simpleType name ="encidx">
    <xs:restriction base="xs:unsignedInt">
      <xs:minInclusive value="0"/>
      <xs:maxInclusive value="1"/>
    </xs:restriction>
  </xs:simpleType>
  <xs:simpleType name ="ctrltype">
    <xs:restriction base="xs:unsignedInt">
      <xs:minInclusive value="0"/>
      <xs:maxInclusive value="4"/>
    </xs:restriction>
  </xs:simpleType>
  <xs:simpleType name ="enctype">
    <xs:restriction base="xs:unsignedInt">
      <xs:minInclusive value="0"/>
      <xs:maxInclusive value="5"/>
    </xs:restriction>
  </xs:simpleType>
```

```
<!--
  <xs:simpleType name ="slotnr">
    <xs:restriction base="xs:unsignedInt">
      <xs:minInclusive value="1"/>
      <xs:maxInclusive value="6"/>
    </xs:restriction>
  </xs:simpleType>
  -->
  <xs:element name="dp">
    <xs:complexType>
      <xs:sequence>
        <xs:element name="bus" type="bus" minOccurs="1"</pre>
maxOccurs="unbounded"/>
        <xs:element name="ada" type="ada" minOccurs="0"</pre>
maxOccurs="1" />
      </xs:sequence>
      <xs:attribute name="version" type="xs:string" use="required"</pre>
fixed="4.7.0.0"/>
      <xs:attribute name="utzversion" type="xs:string"</pre>
use="optional" />
      <xs:attribute name="mode" type="xs:string" use="optional" />
      <!--only CMC!!! (not permitted for externals) -->
      <xs:attribute name="appVersion" type="xs:string"</pre>
use="optional" />
      <xs:attribute name="sciVersion" type="xs:string"</pre>
use="optional" />
      <xs:attribute name="build" type="xs:string" use="optional" />
      <xs:attribute name="preliminary" type="xs:boolean"</pre>
use="optional" />
      <!--only CMC!!! (not permitted for externals) -->
    </xs:complexType>
  </xs:element>
  <xs:complexType name="bus">
    <xs:sequence>
      <xs:element name="slave" type="slave" minOccurs="0"</pre>
maxOccurs="unbounded"/>
    </xs:sequence>
    <xs:attribute name="subsystem" type="xs:unsignedInt"</pre>
use="required" />
  </xs:complexType>
  <xs:complexType name="slave">
    <xs:choice minOccurs="1" maxOccurs="1">
      <xs:element name="control unit ncu" type="control unit ncu"</pre>
minOccurs="1" maxOccurs="1" />
      <xs:element name="control_unit_cu" type="control_unit_cu"</pre>
minOccurs="1" maxOccurs="1" />
      <xs:element name="control unit nx" type="control unit nx"</pre>
minOccurs="1" maxOccurs="1" />
```

```
</xs:choice>
    <xs:attribute name="address" type="xs:unsignedInt"</pre>
use="required"/>
  </xs:complexType>
  <xs:complexType name="cliq">
    <xs:choice minOccurs="0" maxOccurs="1">
     <xs:element name="line module" type="line module" minOccurs="0"</pre>
maxOccurs="1" />
      <xs:element name="motor module" type="motor module"</pre>
minOccurs="0" maxOccurs="1" />
      <xs:element name="sensor module" type="sensor module"</pre>
minOccurs="0" maxOccurs="1" />
      <xs:element name="voltage sensing module"</pre>
type="voltage sensing module" minOccurs="0" maxOccurs="1" />
      <xs:element name="cu link" type="cu link" minOccurs="0"</pre>
maxOccurs="1" />
      <xs:element name="hub_module" type="hub_module" minOccurs="0"</pre>
maxOccurs="1" />
      <xs:element name="terminal_module" type="terminal_module"</pre>
minOccurs="0" maxOccurs="1" />
      <xs:element name="motor module hf" type="motor module hf"</pre>
minOccurs="0" maxOccurs="1" />
      <xs:element name="damping module" type="damping module"</pre>
minOccurs="0" maxOccurs="1" />
      <xs:element name="motor module hla" type="motor module hla"</pre>
minOccurs="0" maxOccurs="1" />
    </xs:choice>
    <xs:attribute name="index" type="xs:unsignedInt" use="required" /</pre>
    <xs:attribute name="uplink" type="xs:boolean" use="optional"</pre>
default="false" />
  </xs:complexType>
  <xs:complexType name="compbase" abstract="true">
    <xs:attribute name="name" type="xs:string" use="optional" />
    <xs:attribute name="compnr" type="uShort" use="optional" />
    <xs:attribute name="mlfb" type="xs:string" use="optional" />
    <xs:attribute name="oemid" type="uInt" use="optional" />
    <xs:attribute name="rds" type="xs:string" use="optional" />
    <xs:attribute name="group" type="xs:string" use="optional" />
   <xs:attribute name="index" type="xs:unsignedInt" use="optional" /</pre>
  </xs:complexType>
  <xs:complexType name="docomp" abstract="true">
    <xs:complexContent>
      <xs:extension base="compbase">
        <xs:attribute name="dovar" type="xs:string" use="optional" /</pre>
        <xs:attribute name="dotype" type="dotype" use="optional" />
        <xs:attribute name="donr" type="uShort" use="optional" />
```

```
<xs:attribute name="doname" type="xs:string" use="optional" /</pre>
        <xs:attribute name="dodesc" type="xs:string" use="optional" /</pre>
      </xs:extension>
   </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="dostatecomp" abstract="true">
    <xs:complexContent>
      <xs:extension base="docomp">
        <xs:attribute name="dostate" type="state" use="optional" />
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="dorefcomp" abstract="true">
    <xs:complexContent>
      <xs:extension base="compbase">
        <xs:attribute name="doref" type="xs:string" use="optional" /</pre>
        <xs:attribute name="compstate" type="state" use="optional" /</pre>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="control unit ncu">
    <xs:complexContent>
      <xs:extension base="docomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="4"</pre>
maxOccurs="6" />
          <xs:choice minOccurs="1" maxOccurs="1">
            <xs:element name="terminal board" type="terminal board"</pre>
minOccurs="0" maxOccurs="1" />
            <xs:element name="comm board" type="comm board"</pre>
minOccurs="0" maxOccurs="1" />
          </xs:choice>
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="control unit ncu 828">
    <xs:complexContent>
      <xs:extension base="docomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="3"</pre>
maxOccurs="3" />
        </xs:sequence>
      </xs:extension>
```

```
</xs:complexContent>
  </xs:complexType>
  <xs:complexType name="control unit cu">
    <xs:complexContent>
      <xs:extension base="docomp">
        <xs:sequence>
           <xs:element name="cliq" type="cliq" minOccurs="1"</pre>
maxOccurs="4" />
          <xs:choice minOccurs="1" maxOccurs="1">
            <xs:element name="terminal board" type="terminal board"</pre>
minOccurs="0" maxOccurs="1" />
            <xs:element name="comm board" type="comm board"</pre>
minOccurs="0" maxOccurs="1" />
          </xs:choice>
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="control unit nx">
    <xs:complexContent>
      <xs:extension base="docomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="4"</pre>
maxOccurs="4" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="line module">
    <xs:complexContent> <xs:extension base="dostatecomp">
     <xs:sequence> <xs:element name="cliq" type="cliq" minOccurs="3"</pre>
maxOccurs="3" />
        </xs:sequence>
        <xs:attribute name="compstate" type="state" use="optional" /</pre>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="motor module base" abstract ="true">
    <xs:complexContent>
      <xs:extension base="dostatecomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="3"</pre>
maxOccurs="3" />
        </xs:sequence>
        <xs:attribute name="compstate" type="state" use="optional" /</pre>
      </xs:extension>
```

```
</xs:complexContent>
  </xs:complexType>
  <xs:complexType name="motor module">
    <xs:complexContent>
      <xs:extension base="motor module base">
        <xs:sequence>
          <xs:element name="motor" type="motor" minOccurs="0"</pre>
maxOccurs="1" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="motor module hf">
    <xs:complexContent>
      <xs:extension base="motor module base">
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="damping module">
    <xs:complexContent>
      <xs:extension base="dorefcomp">
        <xs:choice maxOccurs="2">
          <xs:element name="cliq" type="cliq" minOccurs="3"</pre>
maxOccurs="3" />
          <xs:element name="sine filter module"</pre>
type="sine filter module" minOccurs="0" maxOccurs="1" />
        </xs:choice>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="motor module hla">
    <xs:complexContent>
      <xs:extension base="dostatecomp">
        <xs:choice maxOccurs="2">
          <xs:element name="cliq" type="cliq" minOccurs="4"</pre>
maxOccurs="4" />
          <xs:element name="valve" type="valve" minOccurs="0"</pre>
maxOccurs="1" />
        </xs:choice> <xs:attribute name="compstate" type="state"</pre>
use="optional" />
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="sensor module">
    <xs:complexContent>
      <xs:extension base="dorefcomp">
        <xs:sequence>
```

```
<xs:element name="cliq" type="cliq" minOccurs="1"</pre>
maxOccurs="1" />
          <xs:element name="encoder" type="encoder" minOccurs="0"</pre>
maxOccurs="1" />
          <!--only for SMI-->
          <xs:element name="motor" type="motor" minOccurs="0"</pre>
maxOccurs="1" />
          <!--only for SMI-->
        </xs:sequence>
        <xs:attribute name="sm" type="smnr" use="optional"/>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="voltage sensing module">
    <xs:complexContent>
      <xs:extension base="dorefcomp">
       <xs:sequence>
         <xs:element name="cliq" type="cliq" minOccurs="1"</pre>
maxOccurs="1" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="sine filter module">
    <xs:complexContent>
      <xs:extension base="compbase">
        <xs:sequence>
          <xs:element name="motor" type="motor" minOccurs="0"</pre>
maxOccurs="1" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="motor">
    <xs:complexContent>
      <xs:extension base="compbase"/>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="encoder">
    <xs:complexContent>
      <xs:extension base="compbase"/>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="valve">
    <!--Valve for HLAModule-->
    <xs:complexContent>
      <xs:extension base="compbase">
```

```
<xs:sequence>
          <xs:element name="actuator" type="actuator" minOccurs="0"</pre>
maxOccurs="1" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="actuator">
    <!--Actuator for HLAModule-->
    <xs:complexContent>
      <xs:extension base="compbase"/>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="hub module">
    <xs:complexContent>
      <xs:extension base="dostatecomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="6"</pre>
maxOccurs="6" />
        </xs:sequence>
        <xs:attribute name="compnr2" type="uShort" use="optional" />
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="terminal module">
    <xs:complexContent>
      <xs:extension base="dostatecomp">
        <xs:sequence>
          <xs:element name="cliq" type="cliq" minOccurs="2"</pre>
maxOccurs="2" />
        </xs:sequence>
      </xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="terminal board">
    <xs:complexContent>
      <xs:extension base="dostatecomp"/>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="comm board">
  </xs:complexType>
  <xs:complexType name="cu link">
    <xs:complexContent>
      <xs:extension base="dostatecomp">
        <xs:attribute name="address" type="xs:unsignedInt"</pre>
use="optional" />
```

```
</xs:extension>
    </xs:complexContent>
  </xs:complexType>
  <xs:complexType name="ada">
    <xs:sequence>
      <xs:element name="ada ctrl" type="ada ctrl" minOccurs="0"</pre>
maxOccurs="unbounded"/>
    </xs:sequence>
    <xs:attribute name="mode" type="adamode" />
  </xs:complexType>
  <xs:complexType name="ada ctrl">
    <xs:sequence>
      <xs:element name="ada enc" type="ada enc" minOccurs="0"</pre>
maxOccurs="2"/>
   </xs:sequence>
    <xs:attribute name="axnr" type="axdrnr" use="required" />
    <xs:attribute name="axname" type="xs:string" use="optional" />
    <xs:attribute name="drnr" type="axdrnr" use="optional"/>
    <xs:attribute name="ctrltype" type="ctrltype" use="optional"/>
    <xs:attribute name="dovar" type="xs:string" use="optional"/>
  </xs:complexType>
  <xs:complexType name="ada enc">
    <xs:attribute name="idx" type="encidx" use ="required"/>
    <xs:attribute name="enctype" type="enctype" use="optional"/>
    <xs:attribute name="encinputnr" type="smnr" use="optional"/>
    <xs:attribute name="doref" type="xs:string" use="optional"/>
  </xs:complexType>
</xs:schema>
```

Create MyConfig - NcuShare

7.1 Introduction

7.1.1 NcuShareService

An exchange release is required for processing Windows packages with NCU share. The previous configuration of the exchange release is replaced with the NcuShareService "Create MyConfig NcuShare".

A setup is available for the installation of the service.

7.2 Installation

7.2.1 Installation

There are three possible options for installing the service "Create MyConfig NcuShare".

- 1. Installation with the setup of Create MyConfig
- Manual installation by executing NcuShareServiceSetup.msi
 After installing Create MyConfig, the setup file is available in the installation folder under / Shield.
- 3. Installation for package execution. (Reference to Expert)

When the service is installed, a folder can be configured for the installation types 1 and 2, which is used as the exchange folder.

7.2.2 "Create MyConfig NcuShare" service

The service is installed during the installation on the Windows computer under the program name "Create MyConfig NcuShareService" with the specified service version and entered under the name "Create MyConfig NcuShare" in the list of services.

The service is in the service status "Finished" after installation.

The service is started with the execution of Windows packages with NCU share for the duration of the package execution and is then closed again.

When the service is started, it automatically activates the exchange release for the NCU access.

This permits the exchange of data between NCU and PC/PCU during package execution.

7.3 Error checking

What must be checked in the event of an error?

Use of virtual machines (VMWare)

In connection with virtual machines (VMWare), problems may occur when establishing a connection, because the release of the NCU cannot be achieved.

To ensure the NcuShareService functions properly, the virtual machine must be operated in "Bridged Mode". In "Bridged Mode", the release can be achieved by another computer while the service is running.

Utilization of the service on Windows XP (PCU)

To use the NcuShareService in Windows XP, it is necessary to deactivate the "simple file release" in order to allow authentication of the NCU.

The following link has a description of how you can deactivate a simple file release: http://support.microsoft.com/kb/307874 (http://support.microsoft.com/kb/307874)

Created user

During installation, the user "UpNcuUser" is created and the password is automatically assigned.

For security reasons, the password is changed each time the "UpNcuShareService" is started.

Note

If no user is available when the "UpNcuShareService" is started, a new one is automatically created.

Configuration of the service

The service automatically ends and deletes the release if no shield is carried out.

Observe the following when setting the properties of the Create MyConfig NcuShare:

1. In the General tab, select the Type of start "Manually".




Figure 7-1 Create MyConfig NcuShare - General tab

2. In the Login tab, select the option "Local system account".

7.3 Error checking




Figure 7-2 Create MyConfig NcuShare - Login tab

Changing the release folder

The release folder is defined during the installation of the "UpNcuShareService".

In case of an installation with Create MyConfig or manual setups, the user can change the path during the installation.

If the "UpNcuShareService" is installed during the package execution, the default path is always used.

To subsequently change the exchange folder, the "UpNcuShareService" must first be uninstalled and then re-installed.

List of abbreviations



A.1 Abbreviations

AAZ	Axis-drive assignment
AGK	Automatic device configuration (per HMI)
CMC	Create MyConfig
CNC	Computerized Numerical Control
CU	Control Unit
DB	Data Block
DO	Drive Object
DRV	Drive Data
EUNA	End User Notification Administration; is replaced as from Version V4.7 by the Service Platform Industry (GSP).
FB	Function Block
FC	Function
GSP	Global Service Platform; is officially designated as Service Platform Industry (GSP)
HW Config	Hardware Configuration (Step 7)
NC	Numerical Control
NCK	Numerical Control Kernel
NCU	Numerical Control Unit (example: NCU 720.2)
ОВ	Organization Block
PC	Personal Computer
PCU	Personal Computer Unit (display device; example: PCU 50: Windows-based display device)
PG	Programming device
PLC	Programmable Logic Controller
SDB	System Data Block
COT	SINAMICS offline topology package
SOT	1 671 6
TCU	Thin Client Unit

Table A-1 File extensions for the file formats used in CMC

*.arc	NC, PLC, SDB, or DRV archive
*.tgz	
*.ucz	Expert component
*.upt	Topology project; designation up to CNC Version V4.6
*.uptz	Topology project; the designation applies as from CMC Version V4.7
*.upz	Expert project

A.1 Abbreviations

*.uss	Step XML, step properties
*.ust	Comparison topology
*.usz	Executable Linux package
*.utz	User-specified topology

Index

	CMC package
"	Configuration, 260, 316
	CNC software, 126
"Create MyConfig NcuShare" service, 347	Collapse step
3	Example, 288
	Up.\$Step[id].Collapsed, 287
\$	Column arrangement
	Mirrored, 54
\$Pack, 273	Same sequence, 54
	Command line
	DeleteSettings, 14
A	DestinationDrive, 13
Administrating an axis-drive assignment	DestinationPath, 13
Topo menu, 299	Features, 13
Advantage	Parameter, 13
Diff, 19	SetupMode, 13
Advantages	Comment characters, 195
Configuration of the topology with Topo, 265, 321	Commenting, 193, 198
Topology file during the package execution, 265,	commissioning
321	Step-by-step, 296
ArcAccess, 275	Comparing topologies, 301
Archive	Comparison configuration
Step tree, 156	Manage, 55, 66
Archive access, 109	Comparison menu
Area data, 198	Topo, 299
	Comparison objects, 47
Article po 305	Compatibility of CMC versions and CNC software
Article no., 305	releases
Assignment	Topo XML interface, 268, 324
Dialog - Event, 101	Component names, 295
Assignment operators, 198	Component number, 306
Automatic configuration	Component status, 306
Basic procedure, 261, 317	Component type, 295
Comparison user-specified topology, 258, 315	Components
	Convert, 303
D	Differences, 310
В	Properties, 305, 310
Buttons	Reassign, 303
for dialogs, 103	Replace, 302
Step tree, 168	Components used, 295
•	Condition, 198
	Conditional execution, 198
C	Configuration
	Alignment, 70
Call scripting, 197	Archive access, 109
CHANDATA(1), 34, 83, 196, 198	CNC software, 126
Change operations, 192	Comment, 32, 58, 71, 74
Character classes, 80	Comparison, 56, 67
Check	Default setting, 67
Topology, 298	_ siddit sotting, or

Dialog Finish, 163 Display, 28 Expert list, 28 Filter, 30, 57, 68 NCU access, 115 NCU result, 159 Notes about acknowledgement, 104 Notes on the package, 107	Created user Create MyConfig NcuShare, 348 Cross reference objects, 237 Cross references Displaying, 237 Search, 239
Notes on the Service Platform Industry	D
(GSP), 119	
Notes on the step tree, 153	Data menu
Notes on the topology, 141	Topo, 299 Data structure tree
Package configuration, 99	Main nodes, 28
PCU access, 112	Data task wizard, 42
Service Platform Industry (GSP), 121	Data task wizard, 42
Settings, 73	Application examples, 38
SINAMICS topology, 143	Supplementary conditions, 38
Step tree, 155, 170	Default setting, 28, 56
System configuration, 131	Delete operations
Value range, 31	Target area, 187
Version display, 150	DeployTargets, 272
Configuration - Data task	Dialog
Description, 41	Archive access, 111
Export, 41 Import, 41	CNC software, 129
Task type, 39	Finish, 165
Template, 40	NCU access, 119
Configuration of the topology with Topo	NCU result, 162
Advantages, 265, 321	Notes about acknowledgement, 106
Configuration service	Notes on the package, 108
Create MyConfig NcuShare, 348	Notes on the Service Platform Industry
ConfirmNotes, 274	(GSP), 120
Constructs, 80	Notes on the step tree, 154
Conversion	Notes on the topology, 142
Import, 44	Package configuration, 102 PCU access, 114
Overview, 45	Service Platform Industry (GSP), 125
Package, 233	SINAMICS topology, 146, 149
Conversion tasks, 38	Step tree, 157
Сору	System configuration, 140
Archive, 190	Version display, 152
Clipboard, 59	Dialog pages, 97
HMI Adv, 190	General properties, 97
NC axis machine data, 34	Operating instructions, 106
SINAMICS data, 33	Dialog scripts, 101, 118
Create Project 88	Dialogs tab
Project, 88 Create MyConfig NcuShare	Overview, 99
Configuration service, 348	Diff
Created user, 348	Command line call, 77
Installation, 347	Introduction, 18
Release folder, 350	Parameter, 78
,	Return values, 78

Differences	Edit menu
Components, 310	Topo, 298
Directories, 47	Editing mode for all dialogs, 97
Display all system variables via a dialog	Enable step
Archive access, 110	Example, 285
CNC software, 127	Up.\$Step[id].Activated, 284
Finish (dialog), 164	Encoder
NCU access, 116	Number, 306
NCU result, 160	Escape sequence, 79
Notes about acknowledgement, 105	Event
Notes on the package, 107	Meaning, 102
Notes on the step tree, 153	OnEnd, 102
Notes on the topology, 141	OnInit, 102
Package configuration, 100	OnNext, 102
Package tab, 94	Execute
PCU access, 113	NCU, 184
Service Platform Industry (GSP), 122	PCU, 184
SINAMICS topology, 144	Runtime system, 186
Step tree, 156	Execute step
System configuration, 133	Example, 286
Version display, 151	Up.\$Step[id].Processing, 285
Display data, 196, 205	Expert
Display messages for all dialogs, 98	Command line mode, 253
Displaying	Import project configuration, 253
Cross references, 237	Main menus / toolbars, 88
Displaying/importing topology	Overview window, 87
Project, 298	Parameter, 254
DO	Return values, 255
Name, 296, 306	Expert configuring, 259, 316
Number, 296, 306	Export tasks, 38
Properties, 301, 307	Expression
Variable, 296, 301, 302, 306	Asterisk, 58
DO list	Question marks, 58
Managing, 307	Question marks, 50
DO status, 306	
DO status, 300 DO type, 306	F
DO type, 300 DO variable, 198	Г
DO variable, 190 DO variables	File comparison
Assignment options, 264, 320	Automatic file identification, 72
Properties, 263, 319	Configuration, 66
	Overview, 60
Double quotation marks, 232	Overview window, 64
Downlink port:	Toolbar, 61
Rewire, 303	Filter
Drive data, 205	_SAFE_, 31
DriveTopology, 279	Folder comparison
DriveTopologyNotes, 279	Configuration, 55
	Overview, 47
_	Overview window, 51
E	Toolbar, 48
Edit	Functions, 198
Filter entries, 57	

•	Tools, 88
G	View, 88 Window, 88
General properties	Main nodes
Specify for all dialogs, 97	Data structure tree, 28
	Manage DO list
П	Topo menu, 299
Н	Manage NC data
Help menu	Topo menu, 299
Topo, 300	Meta characters, 79
	Alternation, 80
	any character, 80
I	ASCII character, 80
Import tasks, 38	Decimal number, 80
Input function, 213	Hyphen, 80 Letter, 80
Input functions	Number, 80
Programming examples, 214	Space characters, 80
InputReal	Square bracket, 80
Examples, 227	Tab stop character, 80
Installation	Tabulator, 80
Command line, 13	Underscore, 80
Create MyConfig NcuShare, 347	Unicode character, 80
	Modes, 276
K	
K no., 306	N
K no., 306	Name, 305
K no., 306	
K no., 306	Name, 305 Namespace
K no., 306 K status, 306 L Line breaks, 233	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251 Literal characters, 79	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277 NCU Network connection, 247 NCU access, 115
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277 NCU Network connection, 247 NCU access, 115 NCU result, 159
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251 Literal characters, 79	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277 NCU Network connection, 247 NCU access, 115 NCU result, 159 NcuAccess, 276
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251 Literal characters, 79	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277 NCU Network connection, 247 NCU access, 115 NCU result, 159 NcuAccess, 276 NcuResult, 281
K no., 306 K status, 306 L Line breaks, 233 Line checksum, 196 Link step copy, 180 ID namespace, 182 Inserting, 181 Linux, 186 Linux package, 89 CompactFlash card, 250 NCU, 250 Network drive, 251 Literal characters, 79	Name, 305 Namespace Logbook entry, 179 Query steps, 177 Requirement, 177 NC data, 196, 200 Diff, 19 NC data comparison Configuration, 26 Copying/exporting data, 32 Data task wizard, 42 Functionality, 19 Toolbar, 21 Window, 24 NcSources, 277 NCU Network connection, 247 NCU access, 115 NCU result, 159 NcuAccess, 276

Network connection	Package processing
NCU, 247	USB FlashDrive, 249
PCU, 247	Package variable, 198
Notes about acknowledgement, 104	PackageConfig, 274
Notes on the package, 107	PackageEnd, 282
Notes on the Service Platform Industry (GSP), 119	PackageNotes, 275
Notes on the step tree, 153, 154	Password protection, 240
Notes on the topology, 141	Components, 240
	Logbook, 240
_	Overview, 240
0	Project that can be executed, 240
OEM ID, 306	Projects, 240
OnEnd, 102	PCU
Onlnit, 102	Network connection, 247
OnNext, 102	PCU access, 112
Operators, 193	PcuAccess, 276
Options menu	PlcSources, 277
Topo, 300	Print
Τορο, 300	Topology graph, 303
	Topology tree, 303
P	Procedure, 231, 232
	Procedures, 198
Package	ProcessModes, 274
Conversion, 233	Program elements
Export, 233	Color coding, 199
Import, 233	Project
Parameter, 257	Displaying/importing topology, 298
Return values, 257	Verification of Package, 298
Package configuration, 99	Project Menu
Package execution	Topo, 298
Archive access, 111	Properties
CNC software, 129	Component number, 306
CompactFlash card, 250	DO status, 306
Dialog Finish, 165	DO type, 306
NCU, 250, 251	K no., 306
NCU access, 119	Property
NCU result, 162	Article no., 305
Network drive, 248	Component status, 306
Notes about acknowledgement, 106	K status, 306
Notes on the package, 108	Name, 305
Notes on the Service Platform Industry	OEM ID, 306
(GSP), 120	Step XML, 269
Notes on the step tree, 154	
Notes on the topology, 142	
Package configuration, 102	Q
PCU access, 114	
Service Platform Industry (GSP), 125	Quantifier, 81
SINAMICS topology, 149	Query step
Step tree, 157	Example, 284
System configuration, 140	Querying dialog properties, 198
Version display, 152	Querying package properties, 198
Volument display, 102	

	Step configuration, 156, 171
	Step ID, 269
R	Step query
Pogular expressions	Example, 178
Regular expressions	Step scripts, 172
Examples, 81	Step tree, 155
Release folder	Archive, 156
Create MyConfig NcuShare, 350	Buttons, 168
Repeated execution, 198	Configuration, 170
Replacing, 198	Step tree configuration file
Reserved identifiers, 179	Step XML, 270
Rewire, 303	Step XML
Downlink port:, 303	Property, 269
Uplink port, 303	Step tree configuration file, 270
	Step-by-step commissioning, 296
_	Steps
S	Activation, 171
Script	Activation disabled, 171
Inserting, 102	Collapse, 171
Script variable, 198	Component editor, 172
Scripting	Components, 170
Call, 197	Context menu, 172
Dialogs, 197	ID, 170
Manipulation jobs, 198	Information text, 171
Steps, 197	Name, 170
SdbSources, 277	Scripts, 172
	•
Service Platform Industry (GSP), 120, 121	Warning message, 171
ServiceData, 280	Steps tab
ServiceDataNotes, 280	Toolbar, 168
Set channel, 198	Steps tab
Set section, 198	Up.Step[?], 282
SINAMICS, 295	StepSelection, 281
SINAMICS data, 196	StepSelectionNotes, 280
SINAMICS topology, 143	System configuration, 131, 258, 315
SINUMERIK archive, 47, 59	Automatic configuration, 258, 315
Source explorer	User-specified topology, 258, 315
Copy, 92	System variables
Double-click, 92	\$Pack, 273
Refresh, 92	ArcAccess, 275
Standard comparison software, 19	CNC software dialog - NcuSetup, 277
Step	ConfirmNotes, 274
Configuring, 170	DeployTargets, 272
Step activation, 198	DriveTopology, 279
Step activation disabled	DriveTopologyNotes, 279
Example, 287	Enumeration installation modes - Modes, 276
Step activation locked	Enumeration message level - InteractLevels, 274
Up.\$Step[id].Locked, 287	Enumeration operating systems - Operation
Step condition	system, 272
Display data, 205	Enumeration processing modes -
Drive data, 205	ProcessModes, 274
NC data, 200	Enumeration runtime environments -
Package variables, 201	Runtimes, 289

	Enumeration runtime system -	SystemConfig, 278
	DeployTargets, 272	
	Environment variables, 289	
	Expert, 271	T
	for dialog Archive access - ArcAccess, 275	TAR archive, 47, 59
	for dialog Finish - PackageEnd, 282	Task
	for dialog NCU access - NcuAccess, 276	
	for dialog Notes about acknowledgement -	Import, 188, 193, 195
	ConfirmNotes, 274	Link, 188, 193, 195
	for dialog Notes on the Service Platform Industry	New, 188, 193, 195
	(GSP) - ServiceDataNotes, 280	Task editor, 188, 193, 195
	for dialog Package configuration -	TGZ archive, 47, 59
	PackageConfig, 274	Toolbar
	for dialog PCU access - PcuAccess, 276	File comparison, 61
	for dialog Version view - VersionView, 280	Folder comparison, 48
	for dialog, package notes - PackageNotes, 275	NC data comparison, 21
	for dialog, system configuration -	Steps tab, 168
	SystemConfig, 277, 278	Toolbars
	for DriveTopologyNotes - Notes on the topology	Topo menu, 299
	dialog, 279	Торо
	for the dialog NCU result - NcuResult, 281	Command line mode, 312
	for the dialog Notes on the step tree -	Comparison menu, 299
	StepSelectionNotes, 280	Data menu, 299
	for the dialog Service Platform Industry (GSP) -	Edit menu, 298
	ServiceData, 280	Help menu, 300
	for the dialog SINAMICS topology -	Options menu, 300
	DriveTopology, 279	Parameter, 312
	for the dialog Step tree - StepSelection, 281	Project Menu, 298
	Modes, 276	Return values, 313
	NcSources, 277	View menu, 299
	NcuAccess, 276	Topo XML interface
	NcuResult, 281	Compatibility of CMC versions and CNC software
	NcuSetup, 277	releases, 268, 324
	Package properties \$Pack, 271, 273	Topology
	PackageConfig, 274	Check, 298
	PackageEnd, 282	SINAMICS, 146
	PackageNotes, 275	Topology file during the package execution
	PcuAccess, 276	Advantages, 265, 321
	PlcSource - enumeration source of the PLC	Topology graph
	data, 277	Topo menu, 299
	PlcSources, 277	Topology tree
	ProcessModes, 274	Topo menu, 299
	SDB Source - enumeration source of the SDB	
	data, 277	
	SdbSources, 277	U
	ServiceData, 280	Up.\$Dialog.ArcAccess, 275
	ServiceDataNotes, 280	Up.\$Dialog.ConfirmNotes, 274
	StepSelection, 281	Up.\$Dialog.Commindes, 274 Up.\$Dialog.DriveTopology, 279
	StepSelectionNotes, 280	Up.\$Dialog.DriveTopologyNotes, 279
	SystemConfig, 278	Up.\$Dialog.NcuAccess, 276
Sv	stem variables "	Up.\$Dialog.NcuResult, 281
Οу	VersionView, 280	Up.\$Dialog.NcuSetup, 277
	V CIGICITY ICVV, ZOO	op. polalog. Nouoctup, 211

Up.\$Dialog.PackageConfig. 274 Up.\$Dialog.PackageEnd, 282 W Up.\$Dialog.PackageNotes, 275 Up.\$Dialog.PcuAccess, 276 Window Up.\$Dialog.ServiceData, 280 NC data comparison, 24 Up.\$Dialog.ServiceDataNotes, 280 Windows, 186 Up.\$Dialog.StepSelection, 281 Windows package, 89 Up.\$Dialog.StepSelectionNotes, 280 Network drive, 248, 251 Up.\$Dialog.SystemConfig, 278 PCU 50, 248 Up.\$Dialog.VersionView, 280 Up.\$Pack.ARC, 272 Up.\$Pack.DeployDir, 272 X Up.\$Pack.DeployExclude, 272 Up.\$Pack.DeployName, 272 XML structure Up.\$Pack.DeployTarget, 272 cliq, 336 Up.\$Pack.Language, 272 doref, 335 Up.\$Pack.NCU, 272 dovar, 335 Up.\$Pack.PCU, 272 index. 336 Up.\$Pack.PcuSystem, 272 oemid, 336 Up.\$Pack.ProdVersion, 272 sm. 335 uplink =true, 336 Up.\$Pack.ServiceDeinstall, 273 Up.\$Pack.ServiceInstall, 273 Up.\$Pack.UserVersion, 273 Ζ Up.\$Step[?], 282 Up.\$Step[id].Activated, 284 ZIP archive, 47, 59 Up.\$Step[id].Collapsed, 287 Up.\$Step[id].Locked, 287 Up.\$Step[id].Processing, 285 Uplink port Rewire, 303 **USB FlashDrive** Package processing, 249 User-specified topology, 295 Basic procedure, 261, 317 Comparison automatic configuration, 258, 315 V Value assignment, 32 Value table, 34 Verification of Package Project, 298 Verification run, 89 Version display, 150 VersionView, 280 View menu

Topo, 299