



Application description • 09/2014

SINAMICS G/S: HMI direct access

SINAMICS G120 SINAMICS S120

Warranty and liability

Note

The application examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The application examples do not represent specific customer solutions; they are intended only as support for typical tasks. You are responsible for the proper operation of the described products. These application examples do not relieve you of the responsibility in safely and professionally using, installing, operating and servicing equipment. By using these application examples, you agree that Siemens cannot be made liable for possible damage beyond the liability clause described. We reserve the right to make changes to these application examples at any time and without prior notice. If there are any differences between the suggestions made in these application examples and other Siemens publications, such as catalogs, the contents of the other document(s) take priority.

We give no guarantee that the information contained in this document is complete, accurate, or up-to-date.

We accept no liability for any damage or loss caused by the examples, information, programs, planning data, or performance data described in this application example, irrespective of the legal basis for claims arising from such damage or loss, unless liability is mandatory. For example, according to the product liability law, in cases of malfeasance, gross negligence, due to endangerment of life, body or health, due to assumption of a guarantee for the properties of a product, due to malicious concealment of a defect or due to violation of basic contractual obligations. Any compensation for violation of basic contractual obligations, however, shall be limited to the foreseeable damage or loss which is typically envisaged in contracts unless there has been gross negligence or unless liability is mandatory due to endangerment of life, body, or health. Any change to the burden of proof to your disadvantage is not covered hereby.

Any form of duplication of these application examples or excerpts hereof is not permitted without the express consent of Siemens Industry Sector.

Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, devices, and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Any third-party products that may be in use must also be taken into account. For more information about industrial security, visit <http://www.siemens.com/industrialsecurity>

To receive information about product updates on a regular basis, register for our product newsletter. For more information, visit <http://support.automation.siemens.com>.


Table of contents

Warranty and liability.....	2
1 Task.....	4
1.1 Using the application	4
1.2 Core content of the application	4
1.3 Demarcation	5
2 Preconditions.....	6
2.1 HMI direct access via PROFINET	6
2.2 HMI direct access via PROFIBUS.....	6
3 Technical background.....	7
3.1 Acyclic communication.....	7
3.2 Drive object number G120 / S120.....	7
3.3 Creating the HMI connection.....	8
3.4 Establishing the DB access.....	10
3.4.1 Creating HMI variables.....	10
3.4.2 Examples for various parameters	12
4 Examples	13
4.1 Output of display parameters	13
Display of the motor temperature.....	13
Display of faults and alarms in plain text.....	14
4.2 Reading and writing adjustable parameters.....	15
Reading and writing parameters, e.g. ramp-up time, RAM to ROM ..	15
4.3 Reading and writing BICO parameters	16
Reading and writing BICO parameters	16
4.4 Indirect parameter access	17
Indirect access via variable	17
5 Downloading projects	18
6 References	19
7 Contact person	19
8 History.....	19

1 Task

1.1 Using the application

Fig. 1-1



This application example shows how communication can be established between a SIMATIC HMI and a SINAMICS G120 or a SINAMICS S120 without using a SIMATIC S7 PLC.

You can operate a SIMATIC HMI together with a SINAMICS drive unit independently of a SIMATIC PLC.

Note

HMI direct access is also possible if a SIMATIC controller is connected to the bus.

1.2 Core content of the application

This application deals with the following key points:

- Configuring the communication in the TIA Portal V13
- Description of the communication

1.3 Demarcation

Note HMI direct access from a SIMATIC HMI to a drive is not possible via a network transition. (No HMI direct access via routing)

This application only contains a description of the communication configuration.

Configuring a SINAMICS drive is not discussed here. It is assumed that readers have a basic knowledge about parameterizing SINAMICS drives.

It is not explained how to configure the SIMATIC HMI. It is assumed that readers have basic knowledge about WinCC V12 or higher.

2 Preconditions

2.1 HMI direct access via PROFINET

Precondition, SIMATIC HMI:

- HMI with PROFINET interface

Precondition, SINAMICS drive:

- SINAMICS G120 FW >= V4.7
- SINAMICS S120

2.2 HMI direct access via PROFIBUS

Precondition, SIMATIC HMI:

- HMI with PROFIBUS interface FW >= 13.0.0


Precondition, SINAMICS drive:

- SINAMICS G120 FW >= V4.7
- SINAMICS S120

3 Technical background

3.1 Acyclic communication

Acyclic (non-cyclic) communication is used to access drive parameters directly via the SIMATIC-HMI.



3.2 Drive object number G120 / S120

The drive object number (DO number) is required to address parameter access operations.

SINAMICS G120

For SINAMICS G120, the DO number is always 1.

SINAMICS S120

For SINAMICS S120, the Control Unit has the number 1; the DO numbers of additional drive objects can be found in the STARTER project for the drive device under telegram configuration.

Fig. 3-1 DO number of the SINAMICS S120

IF1: PROFldrive PZD telegrams | IF2: PZD telegrams |

Communication interface: PROFINET - Control Unit onboard (isochronous)
The PROFlsafe communication is performed via this interface

The PROFldrive telegrams of the drive objects are transferred in the following order:
The input data corresponds to the send and the output data of the receive direction of the drive object.
Master view:

Object	Drive object	-No.	Telegram type	Input data Length	Output data Length
1	SERVO_02	2	Free telegram configuration with BICO	0	0
2	SERVO_03	3	Free telegram configuration with BICO	0	0
3	TB30_04	4	Free telegram configuration with BICO	0	0
4	Control_Unit	1	Free telegram configuration with BICO	0	0

Without PZDs (no cyclic data exchange)

DO numbers

Adapt telegram configuration | Interconnections/diagnostics


The screenshot shows the SIMATIC Manager interface for configuring a SINAMICS S120. On the left, a tree view shows the project structure with nodes like 'HMI_direct_S120PN', 'Antriebsgeraet_1', 'Control_Unit', and various drive components. The 'Control_Unit' node is expanded, showing its internal structure. On the right, a detailed configuration window is open for the 'Control_Unit'. At the top, it specifies 'IF1: PROFldrive PZD telegrams | IF2: PZD telegrams |'. Below this, text describes the communication interface as PROFINET - Control Unit onboard (isochronous) and notes that PROFlsafe communication is performed via this interface. It also states that PROFldrive telegrams of drive objects are transferred in a specific order. A table titled 'Master view:' lists the objects and their corresponding drive objects and telegram types. The 'Control_Unit' is listed with a drive object number of 1. A red box highlights this entry. A callout box labeled 'DO numbers' points to the 'Object' column of the table. At the bottom of the configuration window, there are buttons for 'Adapt telegram configuration' and 'Interconnections/diagnostics'.

3.3 Creating the HMI connection

- Create a new HMI, or open the configuration of an existing HMI.
- In the project navigation, open the "Connections" window
- Add a new connection using "Add new".
- Select "SIMATIC S7 300/400" as communication driver

Communication via PROFINET

Fig. 3-2




- Select the Ethernet interface of your HMI
- For the HMI device, enter the IP address of your HMI
- For the control, enter the IP address of your SINAMICS drive
- Expansion slots and racks are not relevant to this case

3 Technical background

Communication via PROFIBUS

Fig. 3-3



- Select the PROFIBUS interface of your HMI.
- For the HMI device, set the PROFIBUS address of your HMI as well as the baud rate of the Profibus line.
- For the control, enter the PROFIBUS address of your SINAMICS drive Expansion slots and racks can be left at their standard values.

3.4 Establishing the DB access

Parameters are accessed in the SINAMICS drive via HMI variables using S7 communication.

All parameters can be accessed.

Whether a parameter can be written to via HMI direct access depends on whether it is a display parameter (rxxxx) or an adjustable parameter (pxxxx) – and in which operating state the SINAMICS drive is in. For more detailed information, please consult the parameter description. See **Fehler! Verweisquelle konnte nicht gefunden werden.**

3.4.1 Creating HMI variables

- Create a variable for parameter access. Use the connection from chapter 3.3

Fig. 3-4

HMI tags				
Name	Data type	Connection	Address	Tag table
Motortemperatur_DO_02	Real	S120_DP	%DB35.DB2048	Standard-Variablenliste
<Add new>				

- Use the data types that match the particular parameter. See Table 3-1
- The address comprises parameter number, index and DO number:

$$\text{DB<} \text{parameter number} \text{>.DB<} \text{a} \text{>data block offset} \quad \text{a=B|W|D}$$
 1. The data block number corresponds to the parameter number.
 2. The data block offset is formed from the DO number and the parameter index:

Data block offset (binary): $x_{15}x\ x\ x\ x\ x_{10}x\ x\ x\ x\ x\ x\ x\ x\ x\ x$.

Drive object number, bits 10-15 Parameter index bit 0-9

Note Data block offset = 1024*drive object No. + parameter index

For variables, data type byte, the data block offset is specified as DBB, for integer, as DBW and for variables, type double integer or real, as DBD.

Note It is important that the data type of the variable matches the parameter data type.

Table 3-1

Data type parameter	Data type HMI variable	Offset
Integer8	Byte	B
Integer16	Int / Word	W
Unsigned8	Byte	B
Unsigned16	Int / Word	W
Unsigned32	DInt / DWord	D
FloatingPoint32	Real	D

You can find the data types of the drive parameters in the parameter description in the List Manual for the drive. Here, a description is also provided regarding in which operating states, adjustable parameters can be changed.

Fig. 3-5

r0002 Control Unit operating display / CU op_display			
CU_I, CU_I_D410,	Can be changed: -	Calculated: -	Access level: 1
CU_NX_CX,	Data type: Integer16	Dyn. index: -	Func. diagram: -
CU_S_AC_DP,	P-Group: -	Units group: -	Unit selection: -
CU_S_AC_PN,	Not for motor type: -	Scaling: -	Expert list: 1
CU_S120_DP,	Min	Max	Factory setting
CU_S120_PN,	0	117	-
CU_S150_DP,			
CU_S150_PN			
Description:	Operating display for the Control Unit (CU).		

Data type: Integer16





Fig. 3-6

p1120[0...n] Ramp-function generator ramp-up time / RFG ramp-up time			
VECTOR,	Can be changed: C2(1), U, T	Calculated: -	Access level: 1
VECTOR_AC,	Data type: FloatingPoint32	Dyn. index: DDS, p0180	Func. diagram: 3060, 3070
VECTOR_I_AC	P-Group: Setpoints	Units group: -	Unit selection: -
	Not for motor type: -	Scaling: -	Expert list: 1
	Min	Max	Factory setting
	0.000 [s]	999999.000 [s]	10.000 [s]
Description:	The ramp-function generator ramps-up the speed setpoint from standstill (setpoint = 0) up to the maximum speed (p1082) in this time.		

Data type: FloatingPoint32

Can be changed: C2(1) = commissioning, U = operation, T = ready

3.4.2 Examples for various parameters



4 Examples


The access to several parameters is shown in the project examples.

The following applications are shown:

4.1 Output of display parameters

Display of the motor temperature


Fig. 4-1 Motor temperature



Parameter r0035 is shown in the "Motor temperature" screen.

Display of faults and alarms in plain text

Fig. 4-2 Faults and alarms



An active fault and alarm are displayed in plain text in the "Faults and alarms" screen.

You can find fault texts in the XML format at the following link:

<http://support.automation.siemens.com/WW/view/en/10804921/133100>


You can convert the XML files to the required Excel format using the SINAMICS XML parser. You can find the SINAMICS XML parser at the following link:

<http://support.automation.siemens.com/WW/view/en/77467239>

4.2 Reading and writing adjustable parameters

Reading and writing parameters, e.g. ramp-up time, RAM to ROM

Fig. 4-3 Ramp-function generator / RAM to ROM




In the "Ramp-function generator / RAM to ROM" screen, the ramp-up and ramp-down times of the ramp-function generator is displayed in an input/output field – and can also be changed.

The parameters can be backed up to ROM using parameter p0977 (SINAMICS G120 p0971). To do this, a value of 1 is written to parameter p0977 (p0971). After the operation has been completed. The parameter of the drive is set to 0. Parameter p0977 (p0971) is also visualized in color in an input/output field.

4.3 Reading and writing BICO parameters

Reading and writing BICO parameters

Fig. 4-4



In the screen "BICO parameter", parameter p2103 "BI: Acknowledge faults" can be interconnected to other parameters, 0 or 1, for example.

The value of parameter p2103[is] shown in the hexadecimal and binary formats.

Note

In the SINAMICS drive, parameters can be logically combined using BICO parameters.

The parameter contains the following information:

Parameter index:	Bits 0 - 9
DO number:	Bits 10 - 15
Parameter number:	Bits 16 - 31

Note


Interconnection within the drive object:

For interconnections within the DO (always for SINAMICS G120), bits 10 – 15 can be set to "true" (decimal 63).

4.4 Indirect parameter access

Indirect access via variable

Fig. 4-5



Parameters can be displayed and values changed in the "Indirect access" screen. Without creating the parameters directly as HMI variable. HMI variables were created for the parameter number, DO number and index as well as for the data type.

The data type must be selected so that it matches the required parameter, so that the value can always be correctly displayed.

Note

If the correct parameter data type is not set, then either no value (#####) or an incorrect value is displayed.

5 Downloading projects

The following TIA Portal projects can be downloaded:

- SINAMICS G120 via PROFINET connected to HMI TP 700
- SINAMICS G120 via PROFIBUS connected to HMI TP 700
- SINAMICS S120 via PROFINET connected to HMI TP 700
- SINAMICS S120 via PROFIBUS connected to HMI TP 700

In the projects, the HMI configuration has the functions described in Chapter 4.
There is no drive configuration included in the projects.

6 References

Table 6-1

	Topic	Title
\1\	Siemens Industry Online Support	http://support.automation.siemens.com
\2\	Download page of the article	http://support.automation.siemens.com/WW/view/en/97550333
\3\	Fault texts in the XML format	http://support.automation.siemens.com/WW/view/en/10804921/13310_0
\4\	XML parser	http://support.automation.siemens.com/WW/view/en/77467239

7 Contact person

Siemens AG
Industry Sector
I DT MC PMA APC
Frauenauracher Strasse 80
D - 91056 Erlangen, Germany
mailto: tech.team.motioncontrol@siemens.com

8 History

Table 8-1

Version	Date	Revision
V1.0	09/2014	First Edition