

Frequently Asked Questions

usa.siemens.com/inhabLM

Q. Can multiple Load Managers be installed in a property?

A. Yes, multiple load managers can be installed in each property. Each Load Manager will require Mains CTs to be installed. Installers should review space available around mains wiring to determine how many CTs can be stacked around the load center mains.

Q. If I install multiple Load Managers, how can I prevent all of them turning off at once when my panel load reaches 80%?

A. A time delay can be set for either ON or OFF operation. This is detailed in installation instructions.

Q. How to prevent relay settings from being changed? Are there any passwords?

A. The relays do not include a password setting. A padlock can be installed in the door to prevent adjustment to settings.

Q. Can the Load Manager be used with a single pole breaker, for example a 30A/120V RV receptacle application. Or is it only compatible with 2-pole 240V breaker loads?

A. This application is not documented. The Load Manager was designed with the intended use in single phase 240V loads.

Q. What limits CTs to have maximum wire length of 500ft?

A. CT accuracy is not guaranteed beyond 500ft. CT wiring should be kept to 500ft or less for proper system operation.

Q. Are there other CT types offered for meter combos which don't have wires between the meter and LC?

A. The Load Manager is currently only offered with the included split core CTs.

Q. I'm installing a new HVAC and don't have enough electrical capacity. I want to use the Load Manager to prevent service upgrade but don't want my HVAC to turn off if the weather outside is 100+°F. How can I take advantage of the Load Manager benefits to prevent service upgrade?

A. Inhab Load Manager should be installed with non-critical loads that can be turned off as needed to prevent service/mains overloads. If HVAC should always be powered, a recommendation would be to install an existing non-critical load (ex. electric water heater) to the Load Manager instead of HVAC. This frees up capacity for the new critical load.

Legal Manufacturer

Siemens Industry, Inc.
3617 Parkway Ln
Peachtree Corners, GA 30092
United States of America
Telephone: +1 (800) 333-7421
www.usa.siemens.com/inhabLM

Order No.
© 10.2024, Siemens Industry, Inc.

This document contains a general description of available technical options only, and its effectiveness will be subject to specific variables including field conditions and project parameters. Siemens does not make representations, warranties, or assurances as to the accuracy or completeness of the content contained herein. Siemens reserves the right to modify the technology and product specifications in its sole discretion without advance notice.

The Siemens logo, consisting of the word "SIEMENS" in a bold, teal, sans-serif typeface.