




Edition

11/2024

EQUIPMENT MANUAL

SIMATIC

ET 200SP

F-TM StepDrive ST 1x24..48V 5A
6BK1136-6SB01-0BU0

www.siemens.com/drives

SIEMENS

SIMATIC

ET 200SP F-TM StepDrive ST 1x24..48V 5A

Equipment Manual

Introduction	1
Fundamental safety instructions	2
Product overview	3
Wiring	4
Safety functions integrated in the drive	5
Configuring	6
Commissioning	7
Programming	8
Maintenance	9
Interrupts, error messages and diagnostics and system alarms	10
Technical specifications	11
Appendix	A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.
--

WARNING
--

indicates that death or severe personal injury may result if proper precautions are not taken.

CAUTION
--

indicates that minor personal injury can result if proper precautions are not taken.
--

NOTICE

indicates that property damage can result if proper precautions are not taken.
--

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

WARNING
--

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.
--

Trademarks

All names identified by ® are registered trademarks of Siemens Aktiengesellschaft. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	7
1.1	About SIMATIC Micro-Drive.....	7
1.2	About this information for use.....	7
1.2.1	Contents.....	7
1.2.2	Target group	8
1.2.3	What's new?	9
1.2.4	Standard scope	9
1.2.5	Use of third-party products in this documentation	9
1.2.6	Websites of third-party companies.....	9
1.3	SIMATIC documentation.....	10
1.3.1	ET 200SP Documentation Guide.....	10
1.3.2	SIMATIC Technical Documentation	12
1.4	Service & Support	13
1.4.1	FAQ	13
1.4.2	ID link and Siemens Online Support.....	13
1.4.3	Spare parts services	14
1.5	Important product information	14
1.5.1	Intended use.....	14
1.6	Safety Evaluation Tool (SET)	15
2	Fundamental safety instructions.....	17
2.1	General safety instructions.....	17
2.2	Equipment damage due to electric fields or electrostatic discharge	23
2.3	Warranty and liability for application examples	23
2.4	Cybersecurity information	23
2.5	Residual risks of power drive systems	25
3	Product overview	27
3.1	Area of application.....	27
3.2	Properties	28
3.3	Supported functions	30
4	Wiring	31
4.1	Pin assignment	31
4.2	Block diagram	33
4.3	Connecting the motor	36
4.3.1	Wiring the motor phases (stepper motor)	36
4.4	Connecting an encoder	37
4.4.1	Connecting an incremental encoder	37

4.4.2	Connecting safe torque off (Hardware STO)	38
4.4.3	Connecting the 24 V digital input	40
4.5	Wiring of multiple TM Drives	40
5	Safety functions integrated in the drive.....	43
5.1	Basic safety information	43
5.1.1	General safety information	43
5.1.2	Warranty and liability for application examples	43
5.1.3	Fundamental safety instructions for Safety Integrated.....	44
5.1.4	Safety Integrated functions	45
5.1.4.1	Safe Torque Off (STO)	47
5.1.5	Overview of the Safety Integrated functions	49
5.1.6	Supported safety functions	50
5.1.7	Examples of using the safety functions	50
5.1.8	Safety concept	50
5.2	Acceptance of the safety functions	51
5.2.1	General information on acceptance.....	51
5.2.2	Content of an acceptance test	54
5.2.3	Documentation of acceptance.....	55
5.2.4	Acceptance test for Safe Torque Off (STO).....	56
5.2.5	Report completion	57
5.3	System features	58
5.3.1	Current information	58
5.3.2	Certifications	58
5.3.3	Failure probability of the safety functions	59
5.3.4	Response times	59
5.4	Safety Integrated	60
5.5	EMERGENCY OFF and EMERGENCY STOP	60
6	Configuring	63
6.1	Communication telegrams	64
6.2	Structure of the encoder position actual value	65
6.2.1	Incremental encoder	66
6.2.2	Encoderless / calculated	67
7	Commissioning	69
7.1	Basics	70
7.1.1	Engineering	70
7.1.2	Drive parameters	72
7.1.3	Calling help information.....	74
7.2	Requirements for the commissioning	74
7.3	Procedure for commissioning the ET 200SP TM Drive	76
7.4	Operating modes	77
7.4.1	General operating modes of a stepper motor.....	77
7.4.2	Operating modes for stepper motors of the TM Drive	78
7.4.2.1	Controlled - encoderless.....	79
7.4.2.2	Controlled - with incremental encoder.....	79
7.4.2.3	Closed-loop control	79

7.5	Drive data sets	80
7.5.1	Using the drive data set.....	81
7.5.2	Drive data export / import	81
7.5.3	Using a user-defined drive data set	83
7.5.4	Drive parameters stepper motor	83
7.5.5	Motor encoder	84
7.5.5.1	Encoder parameters incremental encoder and encoderless / calculated	85
7.5.5.2	Assign encoder counting direction parameters	86
7.5.5.3	Automatic encoder / pole position identification	87
7.6	Controller structure.....	89
7.6.1	Setpoint channel.....	89
7.6.1.1	Reference values.....	90
7.6.1.2	Application limits	91
7.6.1.3	Ramp generator and speed setpoint filter.....	92
7.6.2	Cascade controller	93
7.6.2.1	Cascade controller	96
7.7	Controller settings	97
7.7.1	Speed control (cascade)	97
7.7.2	Manual controller tuning Speed controller (cascade)	100
7.7.3	Controlled (I = const.)	101
7.8	OFF responses	103
7.9	DC-link voltage	105
7.10	Brake module	106
7.10.1	External motor holding brake	106
7.11	Messages/monitoring.....	110
7.11.1	Motor	111
7.11.2	Power end stage	112
7.12	Isochronous mode	113
7.13	Dynamic Servo Control (DSC)	113
8	Programming	115
8.1	Controlling TM Drive via the process image	115
8.2	Controlling a TM Drive via the instruction SINA_SPEED.....	125
8.3	Controlling TM Drive with a technology object.....	125
9	Maintenance.....	127
10	Interrupts, error messages and diagnostics and system alarms	129
10.1	Status and error displays	129
10.2	Diagnostics	132
10.2.1	Diagnostics overview of the TM Drive	132
10.2.2	Active messages	133
10.2.3	Drive diagnostics	135
11	Technical specifications	141
11.1	Technical specifications	141

11.2 Derating of the TM Drive 144

A Appendix..... 147

A.1 Response times..... 147

A.2 Device disposal 148

A.3 Directives and standards 148

Index..... 151

Introduction

1.1 About SIMATIC Micro-Drive

SIMATIC MICRO-DRIVE

SIMATIC MICRO-DRIVE is the drive system for safety extra-low voltages of 24 V to 48 V. Comprising SIMATIC MICRO-DRIVE, versatile motors and connecting cables from selected product partners, it extends the SIEMENS portfolio in the safety extra-low voltage area.

Suitable controllers from the SIMATIC range round out the motion control functionalities.

SIMATIC MICRO-DRIVE TM Drives

TM Drives is a technology module for SIMATIC ET 200SP. It can be controlled by a SIMATIC S7-1500/1200, including via technology objects (TO). TM Drives can be used in combination with a Distributed Controller or the SIMATIC ET 200SP Open Controller in decentralized system concepts.

1.2 About this information for use

1.2.1 Contents

To illustrate possible application areas for our products, typical use cases are listed in this product documentation and in the online help. These are purely exemplary and do not constitute a statement on the suitability of the respective product for applications in specific individual cases. Unless explicitly contractually agreed, Siemens assumes no liability for such suitability. Suitability for a particular application in specific individual cases must be assessed by the user, taking into account all technical, legal, and other requirements on a case-by-case basis. Always observe the descriptions of the technical properties and the relevant constraints of the respective product contained in the product documentation.

Purpose of the documentation

This Equipment Manual supplements the ET 200SP System Manual (<https://support.industry.siemens.com/cs/ww/en/view/58649293>).

Functions that generally relate to the system are described in the System Manual.

The information provided in this Equipment Manual and in the System/Function Manuals supports you in commissioning the system.

Firmware versions

This manual is valid for firmware version FW 2.1 and current HSP versions from V18 and for the corresponding GSDML version.

Note

The current firmware versions can be found in Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/view/109807362>).

Conventions

CPU: When the term "CPU" is used in the following, it applies to the central modules of the S7-1500 automation system, the S7-1200 automation system, as well as to the CPUs/interface modules of the ET 200SP distributed I/O system.

STEP 7: In this documentation, "STEP 7" is used as a synonym for all versions of the configuration and programming software "STEP 7 (TIA Portal)".

Also observe notes marked as follows:

Note

A note contains important information on the product described in the documentation, on the handling of the product or on the section of the documentation to which particular attention should be paid.

This documentation should be kept in a location where it can be easily accessed and made available to the personnel responsible.

Information regarding third-party products

Note

Recommendation relating to third-party products

This document contains recommendations relating to third-party products. Siemens accepts the fundamental suitability of these third-party products.

You can use equivalent products from other manufacturers.

Siemens does not accept any warranty for the properties of third-party products.

1.2.2 Target group

The Equipment Manual is intended for:

- Assemblers
- Commissioning engineers
- Operators

- Service personnel
- Project engineers

1.2.3 What's new?

Equipment Manual revision level	Change/new functions
03/2023	Regulated operation of stepper motors

1.2.4 Standard scope

The functions of the system as delivered can only be found in the order documents.

Further functions may be executable in the system, which are not explained in this documentation. However, there is no entitlement to these functions in the case of a new delivery or service.

This documentation does not contain all detailed information on all types of the product. Furthermore, this documentation cannot take into consideration every conceivable type of installation, operation and service/maintenance.

The machine manufacturer must document any additions or modifications they make to the product themselves.

1.2.5 Use of third-party products in this documentation

This documentation contains recommendations relating to third-party products. Siemens accepts the fundamental suitability of these third-party products. You can use equivalent products from other manufacturers.

Siemens does not accept any warranty for the use of third-party products.

1.2.6 Websites of third-party companies

This document may contain hyperlinks to third-party websites. Siemens is not responsible for and shall not be liable for these websites and their content. Siemens has no control over the information which appears on these websites and is not responsible for the content and information provided there. The user bears the risk for their use.

1.3 SIMATIC documentation

1.3.1 ET 200SP Documentation Guide



The documentation for the SIMATIC ET 200SP distributed I/O system is arranged into three areas.

This arrangement enables you to access the specific content you require.

You can download the documentation free of charge from the Internet (<https://support.industry.siemens.com/cs/ww/en/view/109742709>).

Basic information



The System Manual describes in detail the configuration, installation, wiring and commissioning of the SIMATIC ET 200SP distributed I/O system.

The STEP 7 online help supports you in the configuration and programming.

Examples:

- ET 200SP System Manual
- System Manual ET 200SP HA/ET 200SP modules for devices used in a hazardous area
- Online help TIA Portal

Device information



Figure 1-1 Icon for device information

Equipment manuals contain a compact description of the module-specific information, such as properties, wiring diagrams, characteristics and technical specifications.

Examples:

- Equipment Manuals CPUs
- Equipment Manuals Interface Modules
- Equipment Manuals Digital Modules
- Equipment Manuals Analog Modules
- Equipment Manuals Motor Starter
- BaseUnits Equipment Manuals
- Equipment Manual Server Module
- Equipment Manuals Communications Modules
- Equipment Manuals Technology Modules

General information



The function manuals contain detailed descriptions on general topics relating to the SIMATIC ET 200SP distributed I/O system.

Examples:

- Function Manual ET 200AL/ET 200SP Mixed Configuration
- Function Manual Diagnostics
- Function Manual Communication
- PROFINET Function Manual
- PROFIBUS Function Manual
- Function Manual Designing Interference-free Controllers
- MultiFieldbus Function Manual

Product Information

Changes and supplements to the manuals are documented in a Product Information. The Product Information takes precedence over the device and system manuals.

You can find the latest Product Information on the ET 200SP distributed I/O system on the Internet. (<https://support.industry.siemens.com/cs/ww/en/view/73021864>)

Manual Collection ET 200SP

The Manual Collection contains the complete documentation on the SIMATIC ET 200SP distributed I/O system gathered together in one file.

You can find the Manual Collection on the Internet. (<https://support.automation.siemens.com/WW/view/en/84133942>)

Manual Collection fail-safe modules

The Manual Collection contains the complete documentation on the fail-safe SIMATIC modules, gathered together in one file.

You can find the Manual Collection on the Internet. (<https://support.industry.siemens.com/cs/ww/en/view/109806400>)

1.3.2 SIMATIC Technical Documentation

Additional SIMATIC documents will complete your information. You can find these documents and their use at the following links and QR codes.

The Industry Online Support gives you the option to get information on all topics. Application examples support you in solving your automation tasks.

Overview of the SIMATIC Technical Documentation

Here you will find an overview of the SIMATIC documentation available in Siemens Industry Online Support:



Industry Online Support International (<https://support.industry.siemens.com/cs/ww/en/view/109742705>)

Watch this short video to find out where you can find the overview directly in Siemens Industry Online Support and how to use Siemens Industry Online Support on your mobile device:



Quick introduction to the technical documentation of automation products per video (<https://support.industry.siemens.com/cs/us/en/view/109780491>)



YouTube video: Siemens Automation Products - Technical Documentation at a Glance (<https://youtu.be/TwLSxxRQQsA>)

Application examples

The application examples support you with various tools and examples for solving your automation tasks. Solutions are shown in interplay with multiple components in the system - separated from the focus on individual products.

You can find the application examples on the Internet. (<https://support.industry.siemens.com/cs/ww/en/ps/ae>)

1.4 Service & Support

1.4.1 FAQ

You will find FAQs on TM Drive on the Internet (<https://support.industry.siemens.com/cs/ww/en/ps/26085/faq>).

1.4.2 ID link and Siemens Online Support

You can find additional information about the product:

- via ID link
- using the Siemens Industry Online Support
 - Website: SIOS
 - App Industry Online Support (for Apple iOS and Android)

Product-specific information via ID link

The QR code on your product and on the product packaging contains the ID link.

ID link is a globally unique identifier according to IEC 61406-1.

You can use the ID link to access product data, manuals, Declarations of Conformity, certificates and other information about your product.



Figure 1-2 QR code with ID link included

The ID link is characterized by a frame with a black corner at the bottom right.

Content of Siemens Online Support

- Product support
- Global forum for information and best practice sharing between users and specialists
- Local contact persons via the contact person database (→ Contact)

1.5 Important product information

- Product information
- FAQs (frequently asked questions)
- Application examples
- Manuals
- Downloads
- Compatibility tool
- Newsletter with product selection
- Catalogs/brochures
- Certificates

See also

SIOS (<https://support.industry.siemens.com/cs/ww/en/>)

1.4.3 Spare parts services

The online spare part service "Spares on Web (<https://www.sow.siemens.com/>)" offers spare parts for the product.

1.5 Important product information

1.5.1 Intended use

This equipment is used for the open-loop and closed-loop control of EC and stepper motors for safety extra-low voltages up to 48 V DC.



WARNING

**Hazardous Voltage
Can Cause Death, Serious Injury, or Property Damage.**

Intended use of hardware products

This equipment is only allowed to be used for the applications described in the catalog and in the technical description, and only in conjunction with non-Siemens equipment and components recommended by Siemens.

Correct transport, storage, installation and assembly, as well as careful operation and maintenance, are required to ensure that the product operates safely and without faults.

EU note: Start-up/commissioning is absolutely prohibited until it has been ensured that the machine in which the component described here is to be installed fulfills the regulations/specifications of Directive 2006/42/EC.

1.6 Safety Evaluation Tool (SET)

You can quickly and easily evaluate the safety functions of your machine using the Safety Evaluation Tool (SET) for the IEC 62061 and ISO 13849-1 standards. You receive the results as a standard-compliant report that can be integrated in the machine documentation as proof of safety.

The free Safety Evaluation Tool is available on the Internet (<https://new.siemens.com/global/en/products/automation/topic-areas/safety-integrated/factory-automation/support/safety-evaluation-tool.html>).

Fundamental safety instructions

2.1 General safety instructions



WARNING

Electric shock and danger to life due to other energy sources

Touching live components can result in death or severe injury.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Generally, the following steps apply when establishing safety:

1. Prepare for disconnection. Notify all those who will be affected by the procedure.
2. Isolate the drive system from the power supply and take measures to prevent it being switched back on again.
3. Wait until the discharge time specified on the warning labels has elapsed.
4. Check that there is no voltage between any of the power connections, and between any of the power connections and the protective conductor connection.
5. Check whether the existing auxiliary supply circuits are de-energized.
6. Ensure that the motors cannot move.
7. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water. Switch the energy sources to a safe state.
8. Check that the correct drive system is completely locked.

After you have completed the work, restore the operational readiness in the inverse sequence.



WARNING

Risk of electric shock and fire from supply networks with an excessively high impedance

Excessively low short-circuit currents can lead to the protective devices not tripping or tripping too late, and thus causing electric shock or a fire.

- In the case of a conductor-conductor or conductor-ground short-circuit, ensure that the short-circuit current at the point where the converter is connected to the line supply at least meets the minimum requirements for the response of the protective device used.
- You must use an additional residual-current device (RCD) if a conductor-ground short circuit does not reach the short-circuit current required for the protective device to respond. The required short-circuit current can be too low, especially for TT supply systems.



WARNING

Risk of electric shock and fire from supply networks with an excessively low impedance

Excessively high short-circuit currents can lead to the protective devices not being able to interrupt these short-circuit currents and being destroyed, and thus causing electric shock or a fire.

- Ensure that the prospective short-circuit current at the line terminal of the converter does not exceed the breaking capacity (SCCR or I_{cc}) of the protective device used.



WARNING

Electric shock if there is no ground connection

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

- Ground the device in compliance with the applicable regulations.



WARNING

Electric shock due to connection to an unsuitable power supply

When equipment is connected to an unsuitable power supply, exposed components may carry a hazardous voltage. Contact with hazardous voltage can result in severe injury or death.

- Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV- (Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.



WARNING

Electric shock due to equipment damage

Improper handling may cause damage to equipment. For damaged devices, hazardous voltages can be present at the enclosure or at exposed components; if touched, this can result in death or severe injury.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- Do not use any damaged devices.


! WARNING
Electric shock due to unconnected cable shield

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

- As a minimum, connect cable shields and the conductors of power cables that are not used (e.g. brake cores) at one end at the grounded housing potential.


! WARNING
Arcing when a plug connection is opened during operation

Opening a plug connection when a system is in operation can result in arcing that may cause serious injury or death.

- Only open plug connections when the equipment is in a voltage-free state, unless it has been explicitly stated that they can be opened in operation.

NOTICE
Material damage caused by an incorrect power connection

An incorrect power connection can result in damage due to fire, device defects or malfunctions.

- Check all power connections at regular intervals, particularly after equipment has been transported.

! WARNING
Electromagnetic interference due to inadequate shield support

A lack of adequate shield support for the power cables can cause malfunctions and impermissibly high levels of interference.

- Use the shield connection plates supplied or recommended.
- Use the shield connection clips recommended.

! WARNING
Active implant malfunctions due to electromagnetic fields

Converters generate electromagnetic fields (EMF) in operation. Electromagnetic fields may interfere with active implants, e.g. pacemakers. People with active implants in the immediate vicinity of a converter are at risk.

- As the operator of an EMF-emitting installation, assess the individual risks of persons with active implants.
- Observe the data on EMF emission provided in the product documentation.

 CAUTION

Symptomatic respiratory and skin reaction to chemicals

A newly purchased product might contain traces of substances that are identified as sensitizers. Sensitizers are substances which can cause sensitization in the lungs and skin after exposure to them.

Once sensitized, individuals can have severe reactions to further exposure, even in small amounts. In the most extreme cases, individuals might develop asthma or dermatitis respectively.

- If the product has a strong smell, keep it in a well-ventilated area for 14 days.

 WARNING

Unexpected machine movement caused by radio devices or cellphones

Using radio devices, cellphones, or mobile WLAN devices in the immediate vicinity of the components can result in equipment malfunction or faults and damage to the devices. Malfunctions may impair the functional safety of machines and can therefore put people in danger or lead to property damage.

- Avoid operating radio devices, cellphones and mobile WLAN devices in the direct vicinity of converters and operating units.
- Scan the machine readable code, e.g. a QR code, from a greater distance or switch off the converter power supply before scanning.
- Only operate built-in devices with the control cabinet doors closed.
- When control cabinet doors are open, only qualified electrical personnel are allowed to carry out service and maintenance work.

 CAUTION

Radio frequency interference in residential areas

When you operate EMC category C2 devices in residential areas, the devices can cause radio frequency interference.

When you operate EMC category C3 or C4 devices in residential areas, it is to be expected that the devices will cause radio frequency interference.

- Do not operate EMC category C2 devices in residential areas.
- Do not operate EMC category C3 or C4 devices in public low-voltage networks supplying residential buildings.

Note

It cannot be guaranteed that EMC emission limits are complied with if the products are connected to an isolated line supply, a line supply grounded through a high ohmic connection or a line supply with a grounded line conductor.

- Draw-up an EMC plan to comply with the EMC requirements of the planned application.

**WARNING****Fire due to inadequate ventilation clearances**

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

- Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

NOTICE**Overheating due to inadmissible mounting position**

The device may overheat and therefore be damaged if mounted in an inadmissible position.

- Only operate the device in admissible mounting positions.

NOTICE**Device damage caused by incorrect insulation resistance tests**

High test voltages can damage the device.

- Measure the insulation resistance of low voltage circuits of machines or systems only with ≤ 500 V DC.
- Measure the insulation resistance of SELV circuits of machines or systems only with ≤ 250 V DC.

NOTICE**Device damage caused by incorrect voltage tests**

High test voltages can damage the device. Capacitive leakage currents can distort the test results.

- Disconnect the components before carrying out a voltage test on the machine.¹⁾

¹⁾ The components are voltage tested in accordance with the IEC 61800-5-1 product standard and must be disconnected during testing in accordance with IEC 60204-1:2021 Section 18.4.



WARNING

Unexpected movement of machines caused by inactive safety functions

Inactive or non-adapted safety functions can trigger unexpected machine movements that may result in serious injury or death.

- Observe the information in the appropriate product documentation before commissioning.
- Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.
- Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.
- Perform a function test.
- Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.



WARNING

Malfunctions of the machine as a result of incorrect or changed parameter settings

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization against unauthorized access.
- Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

2.2 Equipment damage due to electric fields or electrostatic discharge

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



NOTICE

Equipment damage due to electric fields or electrostatic discharge

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g. conductive foam rubber or aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
 - Wearing an ESD wrist strap
 - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

2.3 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment, or any eventuality which may arise. Application examples do not represent customer-specific solutions, but merely serve to provide assistance with typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

2.4 Cybersecurity information

Siemens provides products and solutions with industrial cybersecurity functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial cybersecurity concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

2.4 Cybersecurity information

For additional information on industrial cybersecurity measures that may be implemented, please visit
<https://www.siemens.com/cybersecurity-industry>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Cybersecurity RSS Feed under
<https://new.siemens.com/cert>.

Further information is provided on the Internet:

Configuration Manual Industrial Cybersecurity (<https://support.industry.siemens.com/cs/ww/en/view/109975311>)



WARNING

Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a state-of-the-art, integrated industrial cybersecurity concept for the installation or machine.
- Make sure that you include all installed products in the integrated industrial cybersecurity concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- Carefully check all cybersecurity-related settings once commissioning has been completed.

2.5 Residual risks of power drive systems

When assessing the machine or system-related risk in accordance with the respective local regulations (e.g. EC Machinery Directive), the machine manufacturer or system integrator must take into account the following residual risks emanating from the control and drive components of a drive system:

1. Unintentional movements of driven machine or system components during commissioning, operation, maintenance, and repairs caused by, for example,
 - Hardware faults and/or software errors in the sensors, control system, actuators, and connections
 - Response times of the control system and of the drive
 - Operation and/or environmental conditions outside the specification
 - Condensation/conductive contamination
 - Parameterization, programming, cabling, and installation errors
 - Use of wireless devices/mobile phones in the immediate vicinity of electronic components
 - External influences/damage
 - X-ray, ionizing radiation and cosmic radiation
2. Unusually high temperatures inside and outside the components, including open flames, as well as emissions of light, noise, particles, gases, etc. due to fault conditions, e.g.:
 - Component failure
 - Software errors
 - Operation and/or environmental conditions outside the specification
 - External influences/damage
 - Short circuits or ground faults in the intermediate DC circuit of the converter
3. Hazardous shock voltages caused by, for example:
 - Component failure
 - Influence during electrostatic charging
 - Induction of voltages in moving motors
 - Operation and/or environmental conditions outside the specification
 - Condensation/conductive contamination
 - External influences/damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly

2.5 Residual risks of power drive systems

6. Influence of network-connected and wireless communications systems, e.g. ripple-control transmitters or data communication via the network or mobile radio, WLAN or Bluetooth.
7. Motors for use in potentially explosive areas:
When moving components such as bearings become worn, this can cause enclosure components to exhibit unexpectedly high temperatures during operation, creating a hazard in areas with a potentially explosive atmosphere.

For more information about the residual risks of the drive system components, see the relevant sections in the technical user documentation.

Product overview

3.1 Area of application

Broad range of control applications

The SIMATIC ET 200SP distributed I/O system provides the flexibility and power required for a wide range of control applications.

The F-TM StepDrive ST is a product from the range of TM Drive modules in the ET 200SP network. In this manual, the term TM Drive is used as a synonym for F-TM StepDrive ST.

The TM Drive technology module offers you the following possible applications:

- Variable speed control
- Positioning tasks in combination with higher-level control and technology objects
- In the area of safety extra-low voltage ≤ 60 V DC with integrated hardware Safety function Safe Torque Off (STO)

Areas of application

The TM Drives have proven to be an ideal and compact drive in many applications.

Examples of applications:

- Packaging machines
- Automatic assembly machines
- Electronics and battery production
- Printing and labeling machines
- Winders/unwinders, e.g. in the textile, packing and printing and solar industries
- Driving of shuttles for storage and retrieval machines and storage rack systems
- Automated guided vehicle systems
- Battery-powered applications

S7-1500




Figure 3-1 Overview of standard variant with standard CPU

3.2 Properties

Article number

6BK1136-6SB01-0BU0

View of the module




Figure 3-2 View of the F-TM StepDrive ST module

Properties

The F-TM StepDrive ST has the following properties:

- Operation on ET 200SP PROFINET IMs as of V4.0
- Operation on CPU 151x as of V2.0, S7-1200, OpenController and CPU 151xSP
- Speed-controlled single-axis drive with PROFIdrive profile
- Rated voltage of the drive module: 24 to 48 V DC (safety extra-low voltage)
- Support of incremental encoders (with A, B, Z track)

- 24 V digital input
- Support of individually configurable bipolar stepper motors
- Support of incremental encoders with (A, B track)
- Controller parameter determination possible using HSP
- Thermal monitoring of the motor and the power end stage
- Cyclic overload capability
- Safety function STO hardwired
- Motor holding brake external via the process image
- Integrated engineering in STEP 7 (TIA Portal) via Hardware Support Package HSP0311 V16 or higher

Accessories

The following accessories that are not included in the module's scope of delivery can be used with the module:

Designation	Article number
Feed BaseUnit (light)*	6ES7193-6BP00-0DU0
Expansion BaseUnit (dark)*	6ES7193-6BP00-0BU0
MCB, B, 6 A	5SY6106-6
MCB, B, 10 A	5SY6110-6
MCB, B, 6 A for UL markets	5SJ4106-6HG40
MCB, B, 10 A for UL markets	5SJ4110-6HG40
Shield connection	6ES7193-6SC00-1AM0

A type U0 BaseUnit (light or dark) is needed for operation of the TM Drive. You can find an overview of the BaseUnits that you can use with the technology module in the Equipment Manual SIMATIC ET 200SP BaseUnits (<https://support.industry.siemens.com/cs/ww/en/view/109751716>).

For additional information on accessories such as:

- Labeling strips
- Color-coded labels
- Reference identification labels
- Shield connection

refer to the System Manual SIMATIC ET200SP distributed I/O system (<https://support.industry.siemens.com/cs/ww/en/view/58649293>).

Note

Unsuitable electronic fuses

Electronic fuses that disconnect the output voltage briefly in case of an overload and are not capable of power feedback (e.g. SITOP SEL1200) are not suitable for fuse protection.

3.3 Supported functions

System functions

The TM Drive supports the following PROFINET IO function:

- Firmware update via PROFINET IO

The TM Drive supports the function:

- Identification data I&M 0 to 3

PROFIdrive communication types

The TM Drive supports the following communication types:

- Cyclic data exchange via a cyclic data channel
Motion control systems require cyclically updated data during operation for open-loop and closed-loop control. This data must be sent as setpoints to the drive devices or read as actual values from the drive devices via the communication system. The transfer of this data is normally time-critical.
- Acyclic data exchange via an acyclic data channel
An acyclic parameter channel for exchange of parameters between the CPU or supervisor and the drive devices is additionally available. Access to this data is not time-critical.
- Isochronous real-time communication from firmware version 2.1
- Alarm channel
Alarms are output event-triggered and indicate incoming and outgoing error states.

PROFIdrive application classes

The TM Drive supports Application Classes 1 and 4 of the PROFIdrive profile from V4.2.

- Class 1 (AC1)
The drive is controlled via a speed setpoint using PROFINET.
The closed-loop speed control takes place entirely in the drive.
Typical applications are, for example, simple frequency converters for pump and fan control.
- Class 3 (from firmware version 2.1): Synchronous operation with multiple axes
 - Purpose: Applications that require synchronous coordination of multiple axes, such as robotics or printing machines.
 - Functionality: Extended synchronization and coordination functions for multiple drive axes.
 - Communication: Fast and deterministic communication mechanisms for synchronous control jobs

Class 4 (AC4)

This PROFIdrive application class defines a speed setpoint interface with the closed-loop speed control taking place in the drive and the closed-loop position control taking place in the CPU, as is required for robot and machine tool applications with coordinated motion sequences on multiple drives.

Wiring

4.1 Pin assignment

Specific application

Observe the safety and accident prevention regulations applicable for specific applications, e.g. "Safety of Machinery EN ISO 13849-1".

During wiring and maintenance work, the TM Drive must be disconnected from the power supply.

EMERGENCY OFF equipment

EMERGENCY OFF devices according to IEC 60204 (corresponds to DIN VDE 0113) must remain in effect in all operating modes of the plant or system.

The drive-integrated safety function STO of the TM Drive does not replace the EMERGENCY OFF mechanism of the plant.

Excluding hazardous plant states

Hazardous operating states must not occur when

- The plant restarts up after a voltage dip or voltage failure
- Bus communication resumes after a fault

If necessary, the EMERGENCY OFF must be forced!

An uncontrolled or undefined startup must not occur after the EMERGENCY OFF is unlocked.

You can find a description on how to prevent uncontrolled startup in the section Safety Integrated functions (Page 45).

Potential group

Up to a continuous input current of up to max. 10 A for each potential group, several TM Drive can be connected together to form a drive group.

No other ET 200SP components may be located within a potential group consisting of one or more TM Drive.

A TM Drive potential group can be supplied as follows:

- With a separate power supply unit
- With a common power supply that also supplies other components. In this case, use a DC line filter (e.g. EPCOS B84113C0000B110) before the TM Drive potential group.

If you are using a power supply unit with a rated current of more than 10 A or batteries/ rechargeable batteries, it is imperative to connect a circuit breaker of characteristic B with

4.1 Pin assignment

max. 10 A rated current, approved for direct current and the corresponding SELV / PELV voltage, upstream of the TM Drive potential group. For a potential group with only one TM Drive, we recommend using an appropriate miniature circuit breaker with 6 A rated current and characteristic B.

Note

No voltage sources with low impedance

You must not use voltage sources with low impedance, such as supercaps, without adequate current-limiting protective measures.

Note

Unsuitable electronic fuses

Electronic fuses that disconnect the output voltage briefly in case of an overload and are not capable of power feedback (e.g. SITOP SEL1200) are not suitable for fuse protection.

Short circuits

The power outputs of the TM Drive are short-circuit proof. If the module detects a short circuit, it is still imperative to rectify the fault before switching it on again. Otherwise the module can be damaged.

Disturbance of radio communication services due to radio-frequency interferences in residential environments

The TM Drive can cause radio frequency interference which requires measures for interference suppression. This system is not designed for liberal use in the first environment (residential area) and must not be used there without appropriate radio interference suppression measures. Have the installation and commissioning performed with appropriate radio interference suppression measures by experts.

Protection from external electrical effects

You can find information on interference-proof design in the Function Manual Designing interference-free controllers (<https://support.industry.siemens.com/cs/ww/en/view/59193566>).

Overload

The TM Drive is overload-capable. The load of the power end stage is automatically limited by the drive.

With automatic overload limiting, the output current is automatically reduced on reaching the rated load of the power end stage to effectively prevent an overload of the power unit.


SCCR (short circuit current rating)

Suitable For Use On A Circuit Capable Of Delivering Not More Than 5kA DC Symmetrical Amperes, 48 Volts DC Maximum.

4.2 Block diagram**WARNING****Fuse for the load circuit**

In general, use a suitable overcurrent protection device to protect the TM Drive.

Schematic circuit diagram



- ① Backplane bus
- ② Backplane bus interface module of the technology controller
- ③ Electrical isolation
- ④ Technology controller
- ⑤ Safe Torque Off circuitry
- ⑥ Digital input circuit
- ⑦ Power supply/Preparation
- ⑧ Reverse polarity protection
- ⑨ Power electronics

Stepper motor

A-
A+
B-
B+

Encoder supply

ENC+ Power supply encoder 5 V
ENC- Power supply encoder, negative connection

Incremental encoder

a+ Differential encoder signal a+
a- Differential encoder signal a-
b+ Differential encoder signal b+

⑩	Encoder power supply	b-	Differential encoder signal b-
Power supply			
L+	Power supply 24 - 48 V	z+	Differential encoder signal z+
M	Power supply GND	z-	Differential encoder signal z-
Inputs			
STO+	STO+ input (24 V)		
M	Negative terminal		
STO-	Negative STO input		
DI	Digital input		

Figure 4-1 Schematic circuit diagram


Cable lengths and cable types

If you do not use an "all-in-one" plug-in cable, the following cable lengths and cable types are permitted for the interfaces:

Table 4-1 Wiring rules for the interfaces

Pins	Function	Maximum cable length	Cable type
ENC+/ENC-	Incremental encoder signals and supply	10 m	Shielded For differential wiring, one twisted pair per signal pair
A+/A-/B+/B-	Motor phases	10 m	Shielded
DI, M	Input	10 m	≥ 2 m shielded
	Ground	10 m	-
L+/M	Power supply, power unit	10 m	-
a, b, z	Encoder connectors	10 m	Shielded For differential wiring, one twisted pair per signal pair
STO	Safe Torque Off	10 m	-

Permissible cable cross-sections depend on the BaseUnit used. See ET 200SP BaseUnits Equipment Manual (<https://support.industry.siemens.com/cs/ww/en/view/59753521>).



CABLE SPEC.

Note that connected power lines must be designed according to the expected current value at maximum ambient temperature and installation type in accordance with applicable standards.

Note

In addition to the shield connection on the ET 200SP, the cable shield must also be grounded with a suitable fastening, for example with a metal clip on the control cabinet rear panel. The cable shield must be applied on the motor/encoder side.

4.3 Connecting the motor

Overview

The F-TM StepDrive supports bipolar interconnected stepper motors.

4.3.1 Wiring the motor phases (stepper motor)

The following figure shows the connection of the motor phases to the BaseUnit:




Figure 4-2 Connecting the motor

Note

In addition to the shield connection on the ET 200SP, the cable shield must also be grounded with a suitable fastening, for example with a metal clip on the control cabinet rear panel. The cable shield must be applied on the motor side.

Pin assignment

Pin	Designation	Function
1	A-	Motor phase A-
2	A+	Motor phase A+
3	B-	Motor phase B-
4	B+	Motor phase B+

4.4 Connecting an encoder

4.4.1 Connecting an incremental encoder

You have the following options for connection to the TM Drive:

- Motors with a three-channel incremental encoder (A, B and Z track)
- Motors with a two-channel incremental encoder (A, B track)

The A and B tracks and a reference track Z are required for evaluation in regulated operation.

It is also possible to use a two-channel incremental encoder in combination with a stepper motor in regulated operation.

You connect all signals as "single-ended" or "differential".

The following figure shows the connection of an incremental encoder to the BaseUnit.




Figure 4-3 Connection of incremental encoder with differential signals

Pin assignment of incremental encoder

Pin	Designation	Function
9	ENC+	Power supply encoder 5 V
10	ENC-	Power supply encoder, negative connection
11	a+	Differential encoder signal a+
12	a-	Differential encoder signal a-
13	b+	Differential encoder signal b+
14	b-	Differential encoder signal b-
15	z+	Differential encoder signal z+
16	z-	Differential encoder signal z-

4.4 Connecting an encoder

Table 4-2 Power supply and signal processing conditions of the incremental encoder

Encoder property	Range/Value
TTL bipolar 5 V or differential	High 2 V .. 5.5 V
	Low -5.5 V ... -2 V
TTL unipolar 5 V	High 4 V .. 5.5 V
	Low 0 V .. 1 V
Encoder supply voltage	5 V ... 5.3 V
Maximum current consumption of the encoder	150 mA
Encoder output	Push Pull
Maximum signal frequency that can be processed (per signal A and B)*	500 kHz

*The quadrature interface results in a maximum step resolution of 2000 kHz.

Note

In addition to the shield connection on the ET 200SP, the cable shield must also be grounded with a suitable fastening, for example with a metal clip on the control cabinet rear panel. The cable shield must be applied on the encoder side.

4.4.2 Connecting safe torque off (Hardware STO)

Safe Torque Off (STO)

The safety function Hardware STO is activated via an exclusive safe input (STO+ and STO-). The TM Drive safely switches off the control of the motor. As long as Hardware STO is active, the motor does not generate any torque.

The safe state "Safe Torque Off" corresponds to the de-energized state at STO+/STO- (closed-circuit current principle).

The Hardware STO function meets the specification of a digital input according to EN 61131-2 Type 1 without limitation. In addition, this input has an increased leakage current resistance of 5 mA. That is, at leakage currents below 5 mA, the safe state is always selected.


! WARNING

Danger to life due to coasting down of the drive with STO

The Category 0 stop function according to EN 60204-1 (STO according to Safety Integrated) means that the drives are not braked but instead coast down for an amount of time corresponding to the kinetic energy.

- You must take this behavior into account, for example, in the logic for the protective door interlock.

Wiring the Hardware STO



STO+ STO input 24 V

STO- STO input, negative connection

Figure 4-4 Connection of Hardware STO

Note

The supply voltage for the STO inputs must be different from that of the power supply.

Table 4-3 Pin assignment

Pin	Designation	Function
5	STO+	STO input 24 V
7	STO-	STO input, negative connection


The cables of the hardware STO (STO+/STO-) must be routed separately from other cables, especially power cables.

The risk of crushing and short-circuits against earth connections must be minimized by appropriate routing.

Premature aging of the cables due to continuous UV radiation must be ruled out.

4.4.3 Connecting the 24 V digital input

Connecting a 24 V digital input



DI 24 V digital input

M Ground

Figure 4-5 24 V digital input connection

Table 4-4 Pin assignment

Pin	Designation	Function
6	M	Ground, internally connected to ground of 24 - 48 V power supply
8	DI	24 V digital input

4.5 Wiring of multiple TM Drives

Wiring of multiple TM Drives to form a drive line-up

You can connect multiple TM Drives to form a potential group (drive line-up). The following figure shows multiple TM Drives in a potential group with different motors. The common potential group means that the drives share a DC link that is protected by the same protective device.




Figure 4-6 Load distribution in a drive line-up

Observe the following points when connecting up a common potential group:

1. The permitted total current of a BaseUnit is no more than 10 A, so the average current consumption of all the devices in a potential group must also not exceed this value. Make sure that corresponding line protection is provided. See potential group (Page 31).

Note

Note in this connection that the motor current does not equate to the DC input current, so it is not permissible to set the current based on the motor current. The total current must therefore be set based on the ratings of the individual drives/motors.

2. If you have multiple drives for distribution, note the following points:
 - Use the potential group for distribution for more highly loaded modules to avoid modules affecting each other thermally and consequent derating.
 - Position the most highly loaded modules close to the infeed.
3. Regenerative feedback into the DC power supply is not suppressed by the TM Drive. The use of the common DC link means that energy can thus be exchanged, which results in greater system energy efficiency.
4. The inrush current when switching in the DC supply voltage increases with every additional TM Drive connected in parallel. This can result in the power supply being shut off. If this happens, you should use current-limited protective measures such as current-limited voltage sources, a pre-charging input circuit or line reactors.

Safety functions integrated in the drive

5.1 Basic safety information

5.1.1 General safety information

 WARNING
Danger to life if the safety instructions and residual risks are not taken into consideration
The non-observance of the safety instructions and residual risks stated in the associated F-TM StepDrive documentation can result in accidents causing severe injuries or death.
• Observe the safety instructions given in the F-TM StepDrive documentation. • Consider the residual risks for the risk evaluation.

 WARNING
Malfunctions of the machine as a result of incorrect or changed parameter settings
As a result of incorrect or changed parameter settings, machines can malfunction, which in turn can lead to injuries or death.
• Protect the parameter assignment against unauthorized access. • Respond to possible malfunctions by implementing suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

 WARNING
Validity of safety features
The safety features of the product are guaranteed only for intended use within the intended ambient conditions (see section Technical specifications (Page 141)).
The safety features only apply when operating with a BaseUnit of the U0 type (6ES7193-6BP00-0DU0 or 6ES7193-6BP00-0BU0).

5.1.2 Warranty and liability for application examples

Application examples are non-binding and do not claim to be complete regarding configuration and equipment as well as all eventualities. Application examples do not represent customer-specific solutions. They are only intended to provide support for typical tasks.

As user, you are responsible for ensuring that the products described are used correctly. Application examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance.

5.1.3 Fundamental safety instructions for Safety Integrated

Additional safety instructions and residual risks are provided outside of this section at the relevant points of this system manual.

DANGER

Risk minimization through Safety Integrated

Safety Integrated can be used to minimize the risk associated with machines and plants. However, safe operation of the machine or system with Safety Integrated is only possible if the machine manufacturer:

- Knows and complies with this technical user documentation, including the documented constraints, safety instructions and residual risks
- Carefully constructs and configures the machine/plant and verifies it through a carefully implemented and documented acceptance test by qualified personnel
- Implements and validates all the measures required in accordance with the system/machine risk analysis by means of the programmed and configured Safety Integrated functions or by other means

The use of Safety Integrated does not replace the machine/plant risk assessment carried out by the machine manufacturer as required by the CE Machinery Directive.
In addition to using Safety Integrated functions, further risk reduction measures must be implemented.

WARNING

Danger to life as a result of undesirable motor movement when automatically restarting

An emergency stop must be performed according to Stop Category 0 (STO) (EN 60204-1). The emergency stop must be ensured by external measures.

It is not permissible that the motor automatically restarts after an Emergency Stop, as this represents danger to life as a result of the associated undesirable motor motion.

If individual safety functions are deactivated, an automatic restart is permitted under certain circumstances depending on the risk analysis (except when Emergency Stop is reset). An automatic start is possible when a protective door is closed, for example.

- Ensure that no automatic restart takes place in the indicated cases.

**WARNING****Danger to life as a result of undesirable motor motion when the system powers up and the drives are activated after hardware and/or software is changed or replaced**

After hardware and/or software components have been modified or replaced, or after drive parameters are changed or parameter backups are loaded, it is only permissible for the system to run up and the drives to be activated with the protective devices closed. Personnel shall not be present within the danger zone during this time.

- It may be necessary to carry out a partial or complete acceptance test or a simplified functional test after making certain changes or replacements.
- Before personnel may re-enter the hazardous area, all of the drives should be tested to ensure that they exhibit stable control behavior by briefly moving them in both the plus and minus directions (+/-).

5.1.4 Safety Integrated functions

This section gives you a quick insight into the functioning of the safety functions.

The description of the safety functions starts in each case with the definition in IEC/EN 61800-5-2 and simple examples of the use of the function.

The description of the functions is simplified as far as possible so that the essential properties and setting options are made clear.

Response time

You can find additional information on the response time of the listed safety functions in section Response times (Page 147).

Examples of safety devices and 3 TM Drives

Note

The supply voltage for the STO inputs must be different from that of the power supply.

The following figure shows various safety devices that are connected to 3 TM Drives.

5.1 Basic safety information




Figure 5-1 Safety devices and 3 TM Drives

Note

The F-TM StepDrive does not support startup protection.

Measure:

Startup protection via additional safety relay or in higher-level controller, depending on the safety requirements.

Input voltage range STO

Operate input STO+ as intended with 19.2 to 28.8 V DC to keep the enable active or lower than 5 V DC for disabling.

Connect the input STO- for enabling or disabling the connection to ground.

Operating voltage range

Operate input STO+ as intended with 19.2 to 28.8 V DC to keep the enable active or lower than 5 V DC for disabling.

Connect the input STO- for enabling or disabling the connection to ground.


Reclosing delay of the 24 V DC to 48 V DC power supply

Note

STO self-diagnosis when the power supply is switched off and on too fast

Between switching the 24 V DC to 48 V DC power supply off and on, an ON delay greater than 2 s must be complied with. Otherwise the module can register an internal STO error and the module switches off in a safety-oriented manner.

5.1.4.1 Safe Torque Off (STO)



Safe Torque Off (STO) is a safety function that directly stops torque- or force-producing energy from being supplied to the motor. This function corresponds to Stop Category 0 according to EN 60204-1.

The TM Drive complies with the definition of the STO function in IEC/EN 61800-5-2: "The STO function prevents torque-producing energy from being supplied to the motor."

If the motor is still rotating when STO is selected, the motor will coast to a standstill.




Figure 5-2 Functioning of STO (A) when motor is at stopped and (B) when motor is rotating

Functional characteristics



WARNING

Danger to life due to coasting down of the drive with STO

The Category 0 stop function according to EN 60204-1 (STO according to Safety Integrated) means that the drives are not braked but instead coast down for an amount of time corresponding to the kinetic energy.

- You must take this behavior into account, for example, in the logic for the protective door interlock.

STO is a drive-specific function and must be wired individually for each drive.

5.1 Basic safety information

The following applies when the "Safe Torque Off" function is selected:

- An unwanted startup of the motor cannot take place.
- The torque-producing energy supply to the motor is safely interrupted.
- An electrical isolation between the power unit and motor does not occur.

The stop function category 0 (selection of STO according to Safety Integrated) is only active when selected at the STO terminals. In order to meet the requirements of an EMERGENCY STOP in accordance with EN 60204-1, you need to ensure that the STO function at the STO terminals in the system can only be deselected by means of conscious manual operation. This prevents electrically driven machine components from restarting unintentionally.

Selection

The STO safety function is always enabled and cannot be disabled via parameter assignment.

You can select the STO function via the fail-safe digital input at STO+ and STO- terminals. The selection of the STO function is enabled directly as a response to safety messages (e.g. when a defect is detected in a monitoring channel).

Range of application

You can use the STO safety function without restrictions for a bipolar connected two-phase stepper motor. A special encoder concept suitable for safety is not required.

Applications

Application areas are all machines or systems with moving axes (e.g. conveyor systems, handling systems).

STO can be used in which the motor is already at a standstill or comes to a standstill safely due to friction in a short time.

STO allows safe working while a protective door is open. A conventional Emergency Stop with electromechanical unlocking is not required. The converter remains connected to the supply system and has full diagnostics capability.

Note

Difference between EMERGENCY OFF and EMERGENCY STOP

EMERGENCY OFF and EMERGENCY STOP are commands that mitigate different risks in the machine or plant. The STO function is suitable for implementing an EMERGENCY STOP, but not an EMERGENCY OFF.

Hardware STO

The F-TM StepDrive internally monitors the fail-safe digital input at STO+ and STO- terminals for discrepancies.

Discrepancy monitoring

Due to the design of the Hardware STO circuit, a discrepancy cannot occur at STO+ and STO- terminals. As long as the STO terminal is de-energized, STO is selected. The Hardware STO signal is read in internally via two channels.

To comply with the requirements for timely error detection from EN 61800-5-2, the switch-off signal paths of the end stage in both monitoring channels are also cyclically tested. Errors when testing the shutdown paths trigger STO. A manual forced checking procedure (test stop) for testing the shutdown paths of the F-TM StepDrive is therefore not needed.

WARNING
Forced checking procedure
You should nevertheless examine its necessity for diagnosing the utilized sensors or for performing a test stop in the context of the overall system.

5.1.5 Overview of the Safety Integrated functions

Compared to standard drive functions, safety functions have an especially low error rate. Performance Level (PL) and Safety Integrity Level (SIL) as defined in the corresponding standards are a measure for the error rate.

For this reason, safety functions are suitable for use and for risk reduction in safety-related applications. An application is safety-related when the risk analysis of the machine or plant has identified a particular risk potential in the application.

Safety Integrated means that the safety functions are integrated in the drive and can be executed without additional external components.

Conformity of Safety Integrated functions

The Safety Integrated functions comply with:

- Safety Integrity Level (SIL) 3 according to IEC 61508 Part 1-3
- Category 3 according to ISO 13849-1
- Performance Level (PL) d according to ISO 13849-1

For functional safety of variable-speed drives, the standard IEC 61800-5-2, in which the Safety Integrated functions are defined, applies.

Function groups

The safety functions are divided into the following function groups for the F-TM StepDrive:

- Safety Integrated stop function (hardware STO)

5.1.6 Supported safety functions

The supported safety functions are included in the standard scope of the TM Drive and can be used without an additional license.

Stop functions

The stop functions do not pose any special requirements on the utilized encoder and do not need actual value acquisition. The stop functions include the following Safety Integrated functions:

- **Safe Torque Off (hardware STO)**
Safe Torque Off is a safety function for prevention of unexpected startup according to EN 60204-1. STO prevents torque-producing energy from being supplied to the motor and corresponds to Stop Category 0.

5.1.7 Examples of using the safety functions

Table 5-1 Examples of using the safety functions

Safety function	Application examples	Possible solution
Safe Torque Off (STO)	It is only permissible to open a protective door if the motor torque has been switched off.	Activate STO in the F-TM StepDrive via the STO inputs. The pulses are suppressed and the motor coasts to a standstill.
	A central Emergency Stop button ensures that multiple drives cannot start unintentionally.	Evaluate the emergency stop button in a central controller. Use a two-channel connection to the STO inputs on the F-TM StepDrive.

5.1.8 Safety concept

The safety concept of the drive controller is based on a 2-channel system structure. Each channel has the possibility of bringing about the safe state, and the two channels monitor each other through a corresponding cross-comparison and cyclic diagnostics.

Safe state

The safe state of the system exists when the motor bridge is **de-energized**.

The safe state is reached in the following cases:

- Switch-off or failure of the external power supply to L+/M
- Missing enable signal at STO+ and STO- (at least one signal interrupted)
- Detection of an internal hardware fault

Safe state of Safety Integrated functions

The safe state of the STO input terminal is reached when at least one of the two STO supply terminals is disconnected from the energy supply.

Note

The safe state means the absence of torque in the sense of functional safety, but not necessarily the absence of voltage in the sense of electrical safety.

5.2 Acceptance of the safety functions

Responsibilities

The machine manufacturer is responsible for the performance and documentation of the acceptance test. In this section, you will find a recommendation for how to perform and document the acceptance tests for the individual safety functions.

Note

The performance and documentation of the acceptance tests are plant-specific and must be adapted appropriately and performed.

5.2.1 General information on acceptance

Why is acceptance required?

The EU machinery directive and ISO 13849-1 stipulate:

- You must test safety-relevant functions and machine parts after commissioning.
See "Acceptance test" below in this section.
For the F-TM StepDrive Safety Integrated functions (SI functions), this means:
The acceptance test is used to check the functionality of the safety functions used in the drive. Correct implementation of the defined safety functions is examined for this.
- You must create an "acceptance report" that describes the test results.
See "Documentation" further on in this section.

Note

Purpose of the acceptance test

The measured values (e.g. speed, time) and the system behavior identified (e.g. initiation of a specific stop) serve to check the plausibility of the configured safety functions. The objective of an acceptance test is to identify potential configuration errors and/or to document the correct function of the configuration. The measured values are typical values (not worst case values). They represent the behavior of the machine at the time of measurement. These measurements cannot serve as the basis for deriving real values (e.g. maximum values for over-travel distances).

Requirements

The requirements for an acceptance test (configuration test) for safety functions of electric drives come from EN 61800-5-2, section 7.1, paragraph f). The acceptance test is called "configuration test" in this standard.

- Description of the application including an image
- Description of the safety-related components (including software versions) that are used in the application
- List of the utilized safety functions of the PDS(SR) [Power Drive System(Safety Related)]
- Results of all tests of these safety functions using the specified test procedure

Necessity of an acceptance test

An acceptance test is required (again) when the Safety Integrated functionality of a machine is commissioned or changed. The acceptance tests must be performed for each individual drive. Safety-related function extensions, transfer of commissioning to other series machines, hardware changes, software upgrades and the like may allow a partial performance test to be performed.

The conditions determining the necessity and recommendations for the test depth required in each case are summarized below.

Requirements for the acceptance test

- The machine is correctly wired.
- All safety equipment (e.g. protective door monitoring devices, light barriers, emergency limit switches) are connected and ready for operation.
- The commissioning of open-loop and closed-loop control must be complete; otherwise, the over-travel distance may be changed due to a changed dynamic response of the drive control, for example. This includes:
 - Settings of the setpoint channel
 - Position control in the higher-level CPU
 - Drive control

Acceptance test

The acceptance test comprises two parts:

- You test whether the safety functions are set correctly in the drive:
 - Does the configured safety function sufficiently reduce the residual risk at the machine/plant?
 - Do the set interfaces, timers and monitoring functions match the configuration of the machine?
- You test whether the safety-relevant functions in the machine or system function correctly. This part of the acceptance test goes beyond the acceptance test of the drive:
 - Is all safety equipment, such as protective door monitoring, light barriers and emergency limit switches, connected and ready for operation?
 - Do the drive settings match the configured safety-relevant function in the machine?

Documentation

The documentation consists of the following parts:

- Description of safety-relevant components and functions of the machine or system, including the program versions.
- Report of the acceptance test results.
- Report of the safety function wiring.
- The documentation must be signed off by the person who performed the acceptance test.

Authorized persons

Persons authorized by the **machine manufacturer** who, on account of their technical training and knowledge of the safety-relevant functions, can carry out the acceptance in an appropriate manner are entitled to perform the acceptance.



WARNING

Unwanted movement due to faulty wiring

Incorrect wiring for Safety Integrated functions can cause unwanted motion resulting in severe injury or death.

- For Safety Integrated functions, always carry out an acceptance test for the affected function after changing the wiring.
- Record the results of the acceptance test in an acceptance report.



WARNING

Unsafe operating states due to manipulation of the hardware configuration after the acceptance test

Changes to the wiring of the Safety Integrated functions after an acceptance test can cause unwanted motion resulting in severe injury or death.

- To prevent access to your machines and systems by unauthorized persons, implement access restrictions and take the precautions described in the security instructions in the preface.
- To prevent improper wiring of the Safety Integrated functions, take the precautions described in this manual.
- Review the safety change tracking of the drive at regular intervals. Make certain that no changes have been made to the wiring after the last successfully completed acceptance test.
- If intentional changes have been made, repeat the acceptance test for the Safety Integrated functions affected. The purpose of the acceptance test is to ensure and document safe operation of the system. Correct any unintentional changes back to the original values and repeat the acceptance test.

5.2.2 Content of an acceptance test

Documentation

Documentation of the machine including safety functions

- Machine description (with overview image)
- Information on controller (if available)
- Function table:
 - Active monitoring functions depending on operating mode and protective door
 - Additional sensors with protection functions
 - The table is an object or result of the configuration work.
- SI functions for each drive
- Information on the safety equipment

Function test of diagnostic/safety functions

Value-based function check of the SI functions used. You can use trace records of individual parameters, for example, to do this.

- Acceptance test for Safe Torque Off (STO)

Report completion

Reporting of the tested state of commissioning and countersignatures

- Control of the STO function as enable signal of the STO+ and STO- terminals
- Enable to control the motor is removed as soon as a connection (STO+ or STO-) is not connected
- Counter signature

5.2.3 Documentation of acceptance

Machine or system description

Describe your machine or plant using the following table. Insert a diagram of the plant, for example.

Table 5-2 Machine description and overview image

Designation	
Type	
Serial number	
Manufacturer	
End customer	
Overview image of the machine	

Drive data

In the following table, enter information on the drive components used and add additional components as required.

Table 5-3 Hardware components

Component	Designation	Article number	Hardware version	Type
Drive controller				
Motor				
Encoders				
Brake module				
Gearbox				

Utilized Safety Integrated functions

In the following table, describe the use of the Safety Integrated drive functions in relation to your plant or machine.

Table 5-4 Utilized SI functions of the drive

SI function	Status/Description
Safe Torque Off (STO)	

5.2.4 Acceptance test for Safe Torque Off (STO)**Procedure**

Test each configured activation of the STO function.

This test consists of the following steps:

Table 5-5 Acceptance test for "Safe Torque Off" (STO) function

No.	Description	Status
1.	Drive is ready for operation	
	• No faults	
	• The enable signal is present (STO is deselected).	
2.	Switch on motor	
	2.1 Set speed setpoint $\neq 0$	
	2.2 Switch on motor (ON command)	
	2.3 Check that the intended motor is rotating	
3.	Select STO	
	3.1 Selecting STO means interrupting the wire, supplying the STO from STO+ and short-circuiting STO- (if the source is current-limited)	
	3.2 Check the following points:	
	• Motor coasts down to a standstill	
	Message is implemented, but is not safety-relevant	
4.	Deselect STO	
	4.1 Deselection of STO (HW STO terminal)	
	4.2 Check the following points:	
	• Enable is active, motor must allow switch-on	

5.2.5 Report completion

SI change tracking (Safety logbook)

Ensure that changes to the safety function (wiring) can be traced.

Countersignatures

Commissioning engineer

Professional execution of the above-stated tests and checks is confirmed.

Table 5-6 Report completion - Countersignature of commissioning engineer

Date	Name	Company/Department	Signature

5.3 System features

Machine manufacturer

The correctness of the parameter assignment documented above is confirmed.

Table 5-7 Report completion - Countersignature of machine manufacturer

Date	Name	Company/Department	Signature

5.3 System features

5.3.1 Current information

Important note for maintaining the operational safety of your system:

NOTICE
Operational safety risk from unwanted motions Systems with safety-oriented variants are subject to special operational safety requirements on the part of the operator. If information becomes known in the course of product monitoring indicating insufficient product safety, this information will be disclosed in various ways. For this reason, our website provides information on product developments and features that are (or could be) relevant to operation of systems from a safety perspective.

5.3.2 Certifications

The safety functions of the TM Drive drive system meet the following requirements:

- Safety Integrity Level (SIL) 3 according to IEC 61508 Part 1-3 and IEC 61800-5-2
- Category 3 according to ISO 13849-1
- Performance Level (PL) d according to ISO 13849-1

In addition, the safety functions of the drive are generally certified by independent institutes. A list of the components that are currently already certified in each case is available on request from your sales partner.

5.3.3 Failure probability of the safety functions

The probability of failure of safety functions must be specified in the form of a PFH value (Probability of Failure per Hour) according to DIN EN 61800-5-2 and ISO 13849-1. The PFH value of a safety function depends on the safety concept of the drive device, its hardware configuration and the PFH values of the other components used for the safety function. For the F-TM StepDrive drive system, PFH values are provided as a function of the hardware configuration.

Note**PFH values**

The PFH value of the integrated safety function STO is 30 FIT ($10^{-9}/h$) and refers to a service life of 20 years.

The underlying assumption for the calculation is an average operating temperature of 40°C, an average repair time of 8 hours and an average time to recovery of 8 hours. A proof test is not necessary.

5.3.4 Response times

The response time is the time between the detection of an input signal and the change of a linked output signal. Below you will find information on the response times of the F-TM StepDrive drive system.

Note

The actual response time falls between a minimum and maximum response time. You must always assume the maximum response time when configuring your system.

The drive system is the component that provides the safety functions. The description "error-free drive system" means that the component providing the safety functions itself has no defect:

- Maximum response time in error-free drive system
When the enable is removed at the STO+ or STO- terminals, the maximum response time in an error-free drive system is guaranteed.

Stop function (via terminals)

The following table specifies the response times for the indicated stop functions from the time of activation until occurrence of the response.

Function	Maximum response time
STOP_STO	Max. 20 ms

5.4 Safety Integrated

Important notes on the Safety Integrated system are provided in this section.

Diagnostics hardware fault

If an internally diagnosed hardware fault occurs, you can only reset the module by restarting it. Nevertheless, the replacement of the F-TM StepDrive is strongly recommended. Unwanted activation of the safety function can be an indication of a hardware fault.

Wiring the F-TM StepDrive

For information on how to perform the electrical wiring for the F-TM StepDrive, refer to section Wiring (Page 31)

STO inputs

The STO inputs are described in the section Connecting safe torque off (Hardware STO) (Page 38).

5.5 EMERGENCY OFF and EMERGENCY STOP

Difference between EMERGENCY OFF and EMERGENCY STOP

EMERGENCY OFF and EMERGENCY STOP are commands that mitigate different risks in the machine or plant.






EMERGENCY OFF Risk of electric shock 	EMERGENCY STOP Risk of unexpected movement 
---	---

Table 5-8 Measures and solutions

Command	EMERGENCY OFF	EMERGENCY STOP
Measure to minimize risk	Safe switch off Switching off the electric power supply for the installation, either completely or partially.	Safely stop and safely prevent re-starting Stopping or preventing the dangerous movement
Classic solution	Switch off the power supply. 	Switch off the drive power supply. 
Solution with the STO safety function integrated in the drive	STO is not suitable for safely switching off a voltage.	Select STO.  You may also switch off the power supply of the drive controller. However, switching off the voltage is not required as a risk-reduction measure.

Configuring

Configuration and parameter assignment

STEP 7 (TIA Portal) is available for configuring a ET 200SP TM Drive.

You perform the following tasks with STEP 7 (TIA Portal), for example:

- You configure the TM Drive (insert into the project and configure the input addresses).
- You specify the desired hardware parameters for operation of the TM Drive.

Requirements

Hardware

- Supported interface modules: See Properties (Page 28)
- You have completed installation and wiring of the hardware. Take the potential group into account, see section Pin assignment (Page 31).
- You have connected the PG/PC via the PROFINET interface of the CPU.

Software

- You have installed the HSP0311. You can find the support packages for the hardware catalog in the TIA Portal (HSP) on the Internet (<https://support.industry.siemens.com/cs/ww/en/view/72341852>).

As soon as the configuration and hardware parameter assignment have been successfully completed, you can create your user program and commission the drive.



WARNING

Safety Integrated

As soon as a safety program has been created, you must perform a complete function test based on your automation task.

To accept the plant, you must use the safety summary created in accordance with this manual.

Configuring a TM Drive (minimal configuration)

To configure a TM Drive , follow these steps:

1. Create a new project.
2. Add a CPU S7-1200 or S7-1500 as a new device.
3. Add a PROFINET interface module to the project under "Devices & networks" from the ET200SP system, e.g. IM 155-6PN ST.

4. Assign the inserted IO device to the configured IO controller.
5. Switch to the device view of the interface module.
6. Add the TM Drive module from the hardware catalog to the IO device.
7. Add a server module.

6.1 Communication telegrams

Selection of a communication telegram

The selection of a communication telegram determines the process data of the drive that will be transmitted between the drive and CPU.

The following table shows the supported telegram types for the drive and sensor assignment.

Table 6-1 Supported communication telegrams

Supported PROFIdrive telegrams	Brief description	User data
Standard telegram 1 PZD-2/2	Speed setpoint 16 bits, without sensor	- Control word STW1, status word ZSW1 - Speed setpoint 16 bits (NSET), actual speed value 16 bits (NACT)
Standard telegram 2 PZD-4/4	Speed setpoint 32 bits, without position encoder	- Control words STW1 and STW2, status words ZSW1 and ZSW2 - Speed setpoint 32 bits (NSET), actual speed value 32 bits (NACT)
Standard telegram 3 PZD-9/5	Speed setpoint, 32 bits with one position encoder	- Control words STW1 and STW2, status words ZSW1 and ZSW2 - Speed setpoint 32 bits (NSET), actual speed value 32 bits (NACT) - Encoder control word 1 (Gx_STW), encoder status word 1 (Gx_ZSW) - Actual encoder position value 1 (Gx_XIST1, Gx_XIST2)
Standard telegram 5 PZD-9/9	Speed setpoint 32 bits with a position encoder, position controller interface for DSC	- Control words STW1 and STW2, status words ZSW1 and ZSW2 - Speed setpoint 32 bits (NSET), actual speed value 32 bits (NACT) - Encoder control word 1 (Gx_STW), encoder status word 1 (Gx_ZSW) - Actual encoder position value 1 (Gx_XIST1, Gx_XIST2) - Positional deviation (Xerr) - Position controller gain (KPC)

Supported PROFIdrive telegrams	Brief description	User data
Extension word	Status bits of the inputs	• Bit 0: DI • Bit 1: STO
Process data extension PII	Extension for transmission of process data in the PII (6/0)	• 3 x 2 bytes (parameter configuration with data set 242)

A PZD (process data word) corresponds to a 16-bit word.

Selecting a telegram in STEP 7

To select the telegram for the TM Drive in STEP 7, follow these steps:

1. Select the TM Drive in the device view.
2. Navigate to the properties of the module in the "General" tab under "TM Drive" > "Basic parameters".
3. Under "Telegram" in the drop-down list, select the desired telegram, e.g. "Standard telegram 3 (PZD length 9/5 words)".

Note

The extension word for the telegram is always also transmitted in the process image by default; here you can read out the state of the digital input and the STO.

You can define an input delay in the integer ms range for the digital input.

The input is only switched when the signal is applied throughout the entire time of the input delay without interruption (maximum parameter of 20 ms can be assigned).

4. If needed, activate the extension word by selecting the "Telegram extension active" check box.
5. Configure the process data that you want to transmit online in the dialog box "Online & Diagnostics" or by writing data set 242

6.2 Structure of the encoder position actual value

Starting with standard telegram 3, the encoder position actual value is transmitted as a 32-bit value via the user data Gx_XIST1 and Gx_XIST2. These value provide the current **actual incremental position** of the encoder system and are read cyclically, for example by the "Positioning axis" technology object and further processed accordingly (see also section 8.3 (Page 125)). The layout of the encoder position actual value mainly depends on the following factors:

- Type of the encoder
- Resolution of the encoder

Regardless of the type of encoder, the actual position value is structured as follows:

- G1_XIST1 and Gx_XIST2 are right-aligned
- After it is switched on, a 32-bit counter is loaded with the current position value. Depending on the direction of rotation, this value is then only incremented or decremented. After reaching the max. position value, it starts again at 0.

Note

Dependence on the configured encoder resolution

The singleturn value ("increments / revolution") in G1_XIST1 is directly dependent on the configured encoder resolution (p408).

6.2.1 Incremental encoder

If you are using a motor with an incremental encoder and you have configured this for the type of motor encoder (p404), then the structure of the encoder position actual value is as follows:

Table 6-2 Structure of the encoder position actual value

User data	Contents	
Actual encoder position value 1 (Gx_XIST1)	Increments per revolution	Depends on the parameter assignment of the encoder resolution. You can read this back under "Drive diagnostics section 10.2.3 Encoders (Page 135)".
	Bits in Gx_XIST1 "Shift factor"	2
	Encoder type	Rotary incremental

Example of an incremental encoder with 4096 "steps per revolution", this corresponds to 1024 "steps per revolution" with a fine resolution of 2:

Table 6-3 Structure Gx_XIST1

3	3	2	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	9	8	7	6	5	4	3	2	1	0
1	0	9	8	7	6	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0									
M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	S	S	S	S	S	S	S	S	S	F	F

M: Multiturn value (number of distinguishable revolutions)

S: Singleturn value (singleturn "steps per revolution")

F: Fine resolution

Table 6-4 Structure Gx_XIST2

3	3	2	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	1	9	8	7	6	5	4	3	2	1	0
1	0	9	8	7	6	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0										

Error code: See PROFIdrive specification (<https://mall.industry.siemens.com/mall/en/WW/Catalog/Products/10293158>)

6.2.2 Encoderless / calculated

If you have set encoder (0) encoderless / calculated as encoder type, the encoder position actual value is calculated. Actual encoder position value is structured as follows.

Table 6-5 Structure of the encoder position actual value

User data	Contents	
Encoder position actual value 1 (Gx_XIST1)	Increments per revolution	Depends on the parameter assignment of the encoder resolution. You can read this back under "Drive diagnostics section 10.2.3 Encoders (Page 135)".
	Bits in Gx_XIST1 "Shift factor"	2
	Encoder type	Rotary incremental

Example of a "simulated encoder" with 4096 "steps per revolution", this corresponds to 1024 "steps per revolution" with a shift factor of 2:

Table 6-6 Structure Gx_XIST1

3	3	2	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	1	9	8	7	6	5	4	3	2	1	0
1	0	9	8	7	6	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0										
M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	S	S	S	S	S	S	S	S	S	F	F

M: Multiturn value (number of distinguishable revolutions)

S: Singleturn value (singleturn "steps per revolution")

F: Fine resolution

Table 6-7 Structure Gx_XIST2

3	3	2	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	1	9	8	7	6	5	4	3	2	1	0
1	0	9	8	7	6	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0										
																															error

Error code: See PROFIdrive specification (<https://mall.industry.siemens.com/mall/en/WW/Catalog/Products/10293158>)

Commissioning

The engineering of the TM Drive drive controller is integrated in STEP 7 (TIA Portal). You install it with the Hardware Support Package HSP0311. The graphic user interface supports you in the configuration, parameter assignment and commissioning of the drive functions of the TM Drive.

In this section you will find information on various topics including:

- Check before powering on for the first time
- Commissioning an TM Drive drive



CAUTION

Failure to comply with the instructions for Safety Integrated poses a risk of injury

Failure to comply with the instructions may result in serious injuries. Carefully read through the safety instructions in section Safety functions integrated in the drive (Page 43) before commissioning and before operation.



WARNING

Personal injury and property damage from the collapse of a suspended axis

If the drive system is used as suspended axis, the axis will fall down if the positive and negative poles of the power supply are interchanged during connection. An unexpected collapse of a suspended axis can result in personal injury and property damage.

Before commissioning, it must be ensured that a cross brace is fitted to hold the suspended axis in place and prevent it from collapsing unexpectedly. Also ensure that the power supply is connected properly.



WARNING

Personal injury and property damage from the collapse of a suspended axis

An unexpected collapse of a suspended axis can result in personal injury and property damage.

- When using the STO function in conjunction with suspended axes, the axis may fall down unexpectedly and cause property damage and personal injury.

Note

Performing tests

You must ensure the safety of your plant. You therefore need to perform a complete functional test and the necessary safety checks before the final commissioning of a plant.

Also allow for any possible foreseeable errors in the tests. This avoids endangering persons or equipment during operation.

7.1 Basics

7.1.1 Engineering

You perform configuration as well as diagnostics of a TM Drive with a PG/PC or notebook (commissioning device) using the TIA Portal (Hardware Support Package HSP0311 needed).

The settings can be found in STEP 7 in the device navigation under "Ungrouped devices" > "<Name of the interface module>" > "<Name of the TM Drive>".

Overview

This drive engineering is divided into the following areas:

- Device configuration
- Online & diagnostics
- Parameters

"Device configuration" area

Contents in the "Device configuration" area of the TM Drive engineering.

- Potential group
- Basic parameters
 - Define telegram
 - Define the input delay DI
 - Define sign-of-life tolerance for clock synchronization
- Process data extension PII
 - Activate process data extension in the PII
- I/O addresses
 - Activate/deactivate isochronous mode

"Online & diagnostics" area

Contents in the "Online & diagnostics" area of the TM Drive engineering.

Diagnostics

- General (module information):
 - Order number
 - Firmware and hardware version
 - I&M data
- Diagnostic status (display of status information)

- Active messages:
Pending faults and alarms
- Drive diagnostics
 - Status bits
 - Operating values
 - Encoders
 - Temperatures
 - Inputs
 - Configuration of process data extension PII
- Functions
Firmware update

"Parameters" area

Contents in the "Parameters" area of the TM Drive TM engineering.

- Drive:
 - Drive data set
 - General settings
 - Motor
 - Thermal model
 - DC link voltage
 - Brake control module
- Setpoint channel:
 - Reference values
 - Application limits
 - Speed ramp-function generator
- Open-loop/closed-loop control:
 - Control type
 - Controller settings
 - Speed controller
 - Current controller
- Messages/monitoring
 - Motor (thermal motor type)
 - DC link voltage
 - Power end stage (utilization)

"Commissioning" area

Contents in the "Commissioning" area of the TM Drive TM Engineering.

- Configuration:
Link to the parameter dialog
- Identification:
 - Identification mode
 - Encoder and pole position identification
- Tuning:
 - Calculate speed/current controller values
 - Tuning the speed controller
 - Transfer controller values to drive parameters

7.1.2 Drive parameters

Parameter tooltips

All drive parameters displayed in the STEP 7 engineering of the TM Drive are linked to tooltips. You will find detailed information on the parameter in the tooltips, e.g. parameter name, properties, factory setting, value range, descriptions, notes and dependencies.

Changing a parameter

You can directly change the values of the writable adjustable parameters in STEP 7.

You have the following options for this:


- You overwrite the current parameter value with the new value.
Or
- You select a value via the drop-down list.

Invalid values are rejected.

Note


Parameters cannot be changed online while the drive is in operation. In this case, the corresponding entry field is automatically disabled.

The following overview shows the display of an entry field, depending on the context and the properties of the drive parameter:

	Project (offline)	Parameter value can be changed and stored in the project.
	Project (offline)	The parameter value is write-protected.
	Project (online)	Parameter value is write-protected or disabled due to the drive status.

Parameter symbols and operator controls

The following overview explains additional symbols and operator controls in the TM Drive engineering:

	Drive value (online) could not be determined
	Bit parameter active (1-signal)
	Bit parameter inactive (0-signal)
	
	Binding values to be set by the commissioning engineer

Automatic check of the configured drive parameters

The configured parameters are checked both in STEP 7 and in the drive in order to detect incorrect parameter assignments and possible functional restrictions even before commissioning.

Both warning and error messages are output. In STEP 7, you obtain additional information and corrective measures about the respective message.

The causes of errors in the drive parameterization that prevent the drive from operating are listed below.

Parameter group	Possible causes of error
Motor	Electrical time constants of the connected motor are too low
	Torque constant is not consistent with other motor parameters
Encoders	Motor/encoder combination is not permitted
Speed/current controller	Controller parameters have not yet been set or are not permissible
DC link voltage	DC link voltage limits are prohibited

Loading drive parameters

You can synchronize all p-parameter values of your project (offline) using the "Download to device" function.

Conditions

- When you load parameters into the device, a rotating drive automatically stops.
- After the parameters are loaded, the drive does not restart automatically. You must activate the drive once again using a new drive command.
- If you transmit an invalid parameter to the TM Drive, the module remains in parameter assignment mode. The drive cannot be activated until valid parameters are loaded.

"Download to device" function for drive parameters

You can use the "Download to device" function to transfer parameter values from your project (offline) to the drive (online).

Procedure

1. Select the drive in the project tree.
2. Click on "Download to device"  in the menu bar.

Or

1. Select "Download to device" > "Software" in the shortcut menu.

You have transferred the current parameter values of your project to the drive.

7.1.3 Calling help information

To obtain information on parameters and alarms (messages) of the drive, open the information system via "Help" > "Show help" and search for the article number of the product.

You can also directly open the information system for a parameter or a message. To do so, click the online help link in the tooltip of a parameter or message .

7.2 Requirements for the commissioning

Requirements

- The TM Drive was installed according to the information in the following sections:
 - Wiring (Page 31)
 - Configuring (Page 63)
- The motor is installed in the drive train to be operated in accordance with the plant/device construction planning.

Note**Additional information concerning the requirements**

You can find additional information relating to technology objects and motion control in the online help of STEP 7 under "Using technology functions" > "Motion Control".

Before powering on for the first time

Before the first power-on, check the installation and the wiring of the TM Drive.

Questions for the check

The following questions provide guidance for checking your TM Drive in the form of a checklist.

Racks

- Is the mounting rail securely mounted to the wall, in the frame or in the cabinet?
- Are the cable ducts correctly installed?
- Have the minimum clearances been observed?

Grounding and chassis concept

- Is the mounting rail connected to the protective conductor?
- Is the connection between the ground reference and ground properly established for the mounting rail?
- Has the shielding of the motor/encoder cable been applied over a large area on the device and on the motor/encoder?
- Are the required equipotential bonding cables connected with low impedance to the affected plant units?
- Are the grounding terminals correctly attached and is the motor/encoder cable correctly connected?

Module installation and wiring

- Is the TM StepDrive plugged in/installed and firmly connected or screwed according to the assembly plan and configuration with STEP 7?
- Are all connectors wired according to the circuit diagram?
- Is the PROFINET connection to the CPU and the engineering system of the STEP 7 (TIA Portal) connected?
- Is the input for Hardware STO (STO+/STO-) connected?
- Are the cables (motor connection cable, encoder cable) properly connected between the TM Drive and the motor and installed according to the guidelines?
- Is the optional digital input connected?
- Are the cables from the hardware STO (STO+/STO-) separated from the other cables, in particular from power cables?

- Have you minimized crushing hazards and short-circuits against ground connections by appropriate routing?
- Are the cables fully protected against premature aging due to continuous UV radiation?

Power supply

- Are all power supplies switched off?
- Is the power cable connector correctly wired?
- Has the connection to line voltage been made?

7.3 Procedure for commissioning the ET 200SP TM Drive

Procedure for commissioning with STEP 7

Commissioning is performed according to the steps listed below. The individual commissioning steps are optional and are to be performed as required. We recommend the following procedure for the first commissioning of a TM Drive .

Table 7-1 Commissioning procedure

Step	Procedure	Comments	See section ...
1	Configure drive data set	In the "Import drive data set" dialog under "Parameters > Drive": Import drive data from file system	Drive data sets (Page 80)
2	Define setpoint channel	Under "Setpoint channel" you configure the following: • Reference values • Application limits • Ramp-function generator	Controller structure (Page 89)
3	Set control/closed-loop control	Have the controller parameters automatically calculated using the "Speed/current controller settings" comfort function.	Speed control (cascade) (Page 97)
4	Configure DC link voltage monitoring and optionally the brake control module	• Define limits for DC link voltage • Motor holding brake settings	DC link voltage monitoring
5	Configure messages/monitoring	• Define warning thresholds for thermal monitoring	Messages/monitoring (Page 110)
8	Optional: Perform online optimization	• Tuning the speed controller	Section Manual controller tuning Speed controller (cascade) (Page 100)

See also

Controller settings (Page 97)

7.4 Operating modes

7.4.1 General operating modes of a stepper motor

There are generally the following control methods for operating stepper motors:

- Full step method
- Half step method
- Micro step method

Full step method

Within a pole pitch of the motor, 4 positions can be distinguished. With each step, the rotating field is advanced by 90°. For a stepper motor with 50 pole pairs, this results in a control angle of 1.8°:

$$\frac{360^\circ}{\text{Number of positions of method} \cdot \text{Number of pole pairs}} = \frac{360^\circ}{4 \cdot 50} = 1,8^\circ$$

Half step method

Within a pole pitch of the motor, 8 positions can be distinguished.

With each step, the rotating field is advanced by 45°. For a stepper motor with 50 pole pairs, this results in a control angle of 0.9°:

$$\frac{360^\circ}{\text{Number of positions of method} \cdot \text{Number of pole pairs}} = \frac{360^\circ}{8 \cdot 50} = 0,9^\circ$$

Micro step method

The range of a pole pitch is covered by a large number of steps. This results in an even generation of torque. However, the maximum achievable torque is lower than when the full step or half step control method is used. A smaller control angle and smoother motor running can be achieved with the micro step method than with the full step or half step method.

Example

The following diagram shows the current characteristic produced using the different control methods. In the example illustrated, the stepper motor is controlled with a frequency of 100 Hz. For a stepper motor with 50 pole pairs, this would result in a speed of 120 rpm.




Figure 7-1 Current characteristic of stepper motors using different control methods

7.4.2 Operating modes for stepper motors of the TM Drive

All operating modes of the TM Drive work with control by means of a sinusoidal current. This method is comparable to the micro step method.

The following operating modes are available:

- Controlled - encoderless
- Controlled - with incremental encoder
- Closed-loop control

You can find more detailed information in the following sections.

7.4.2.1 Controlled - encoderless

Controlled - encoderless operation is comparable to the micro step method. Here, a rotating field causes the rotor to rotate with a constant sinusoidal current (running current). At standstill, the current can assume a different value (stop current). The settings for the currents must be configured and correlate to the maximum required torques. In this context, consider maximum loads and maximum accelerations. If the currents are configured with too small a value, this can result in step losses or cause the motor to stall.

In this operating mode, a virtual encoder value is calculated from the sinusoidal control and output via the PROFIdrive telegram, ensuring compatibility with TIA Portal engineering (e.g. technology objects). The resolution of the virtual encoder can be configured via "Parameters" > "Drive" > "Encoder".

This resolution thus determines the steps that can be achieved within a motor revolution or that can be actuated by the position controller.

7.4.2.2 Controlled - with incremental encoder

Controlled operation with an incremental encoder is comparable to encoderless operation of the TM Drive. However, controlled operation differs with regard to the use of a real incremental encoder. The rotor position is thus determined via the real incremental encoder, so that the loss of individual steps can be detected and compensated by the position control or closed-loop speed control. In this case, parameterize the encoder as specified in the data sheet via "Parameters" > "Drive" > "Encoder".

With this operating mode, too, ensure the correct parameterization of the running and stop current. If the running current is parameterized with too small a value, the step error can become so great that following error monitoring is triggered during position control.

7.4.2.3 Closed-loop control

Closed-loop control combines the advantages of the full step method with the advantages of the micro step method. A higher torque can thus be achieved with a minimum control angle and optimized rotational accuracy. In addition, the temperature development of the stepper motor can be reduced, as a result of which energy efficiency is improved.

This operating mode is based on the closed-loop control of servo motors. The stepper motor is not driven with a constant control current, but is instead controlled by means of field-oriented current regulation. In this case, a variable current is impressed in the motor so that the required torque can be generated dynamically. Here, the encoder supplies the information about the rotor position that is evaluated internally in the TM Drive. In order to be able to resolve the rotor position with sufficient accuracy, the encoder must have a sufficiently high resolution. Here, at least 40 increments should be available within an electrical period.

Resolution_{Encoder} = 40 (number of pole pairs of the motor)

This means that an encoder should have a minimum resolution of 2000 steps per revolution on a motor with 50 pole pairs.

If this requirement is not met, an inaccurate detection of the rotor position can result. This can in turn lead to a lower efficiency of the motor or failure to achieve the maximum torque.

7.5 Drive data sets

Introduction

It is possible to connect motors from third-party motor manufacturers, provided that they meet the required conditions regarding motor, encoder system, connection technology, electrical safety, EMC etc., as described in this manual.

With the F-TM StepDrive ST, this also includes stepper motors which can be connected in a bipolar manner and which meet the boundary conditions explained in this manual.

Drive data set

The motor or drive of the TM Drive drive system is configured using a drive data set (DDS). A drive data set contains the settings and information for the following drive components:

- Motor
- Thermal motor model

Note

The description "drive" means the combination of motor, encoder and additional built-on accessories such as a gearbox and holding brake.

Motor

You can find the settings for the motor in the "Parameters" > "Drive" > "Motor" area.

The TM Drive drive system supports stepper motors. You specify important basic data and reference data of the motor.

Observe the information and notes in the help or in the tooltips of the individual parameters.

You can also find detailed information and descriptions for the drive parameters in the Product Information (<https://support.industry.siemens.com/cs/ww/en/view/109773204>).

Motor encoder

The motor encoder is used for the closed-loop speed control of the drive. The encoder values are transferred to the CPU in the PROFIdrive telegram of the TM Drive, independent of the encoder type.

The following combinations are available:

Motor type: Stepper motor

- (0) No encoder / calculated
- (1) Incremental encoder (A, B, Z track)
- (3) Incremental encoder (A, B track)

(0) No encoder / calculated

The setting (0) encoderless / calculated is only supported in connection with a stepper motor. In this case, the rotor position is calculated and transferred to the control depending on the increments per revolution (p0408) or the steps per revolution (p0409).

(1) Incremental encoder (A, B, Z track)

When selecting the encoder type (1) incremental encoder, a 3-channel encoder with Z-track (often also referred to as I-track) can be connected.

(3) Incremental encoder (A, B track)

If you select encoder type (3) "Incremental encoder", a two-channel encoder combined with a stepper motor can be connected in regulated operation.

Thermal model

The motor can be protected from thermal overload. Take section Messages/monitoring (Page 110) into consideration for this.

You define the thermal properties of the motor in the "Parameters" > "Drive" > "Thermal model" area.

7.5.1 Using the drive data set

To configure a drive, create a user-defined drive data set and configure your motor manually.

NOTICE
After a change of the drive data set, you may have to adapt or optimize the parameters for the current and speed controllers. See section Speed control (cascade) (Page 97).

7.5.2 Drive data export / import

In addition to the pre-defined drive data sets, custom drive data sets can also be exported and imported.

The standard CSV format with ',' (comma) as column separator including a line header is used.

The data is stored according to the file header and also read in again on the basis of this line.

The formatting of decimal numbers is region-independent using a '.' (dot) as the decimal separator.

For negative values, the value must be preceded by a '-' (minus).

UTF-8 is defined as the character coding.

The header line is defined as follows:

```
##PNU(mandatory)##,##name##,##value(mandatory)##,##unit##,##dataType##,##group#
#,##ECLASS number##
```

- Motor
- Gearbox
- Encoders
- Thermal model
- Motor holding brake

All parameters contained in the CSV file are included in an import.

The parameters are assigned via the PNU, where the value must be present. Name, unit, data type and ECLASS number are used for better readability and are ignored during import.

Quotation marks and spaces are hidden during import, which is why no further commas are supported except for column separation.

The CSV file can be adjusted retrospectively using an editor.

Export drive data

The existing drive parameter assignments can be exported and saved as a file (*.csv) from STEP 7 Engineering.

1. Open "Parameters" > "Drive".
2. Start the export via the "Export drive data set..." button in the "Drive data set" area.
3. In the "Save" dialog, select a folder and the file name and confirm with "Save".

Import drive data

The drive parameter assignment can be imported as a file (*.csv) in STEP 7 Engineering. A drive data set may contain all or part of the parameters supported by the TM Drive used.

Note

Importing the drive parameter assignments overwrites all parameters with the values contained in the csv file.

Importing resets motor parameters and controller parameters to the relevant default values.

The "Undo" function is not possible for the "Import drive data set" function.

Save your parameter assignments before importing a drive data set.

1. Open "Parameters" > "Drive".
2. Start the configuration wizard via the "Import drive data set..." button in the "Drive data set" area.
3. Select the "Import parameter table from file system" option.
4. Select the drive data set (*.csv) via the file folder button.
5. The drive data set is displayed in the log area and you can check the data.
6. Apply the configuration with "Yes".

Status messages about the import are displayed in the Inspector window in the General tab.

7.5.3 Using a user-defined drive data set

Create a user-defined drive data set and configure your motor manually.

You can also use this function to edit an existing drive data set.

 WARNING
Avoiding incorrect parameter assignments
Note that incorrect or modified parameter assignments can result in drive malfunctions and damage to the drive.

See also

Product Information for TM Drive (<https://support.industry.siemens.com/cs/ww/en/view/109773204>)

7.5.4 Drive parameters stepper motor

Parameter number	Name	Description	Unit
Motor			
p0300	Motor type	Selection of the motor type	
p0305	Rated current	Rated current per coil in full step mode.	A
p0312	Hold torque	Hold torque of the stepper motor in full step mode and rated current.	Nm
p0322	Maximum speed	Maximum speed is the mechanically permissible speed of the machine. If the speed is exceeded, the motor may be damaged.	rpm
p0372	Connection resistance	Connection resistance of a phase	Ohm
p0376	Connection inductance	Connection inductance one phase	mH
p0341	Rotor moment of inertia	The rotor moment of inertia is the mass moment of inertia of the rotor with the connecting shaft.	kgcm ²
P30000	Step angle	Step angle of the stepper motor in full step mode.	°
P30001	Number of steps	The number of steps indicates the number of steps per mechanical revolution in full step mode. The value cannot be edited and is calculated from the step angle. Number of steps = 360° / step angle	-

Parameter number	Name	Description	Unit
P30014	Number of pole pairs	The number of pole pairs indicates the number of pole pairs in the motor. The value cannot be edited and is calculated from the step angle. Number of pole pairs = number of steps / 4	-
Thermal model			
p0611[1]	Time constant winding - environment	Setting of the thermal time constant between the winding and the environment. In rated operation (rated load and the ambient temperatures and installation altitude specified by the manufacturer) the limit temperature of the motor is reached after five times the time constant. Note: If the ambient conditions of the motor do not correspond to the values specified by the manufacturer, the motor must be derated. See 7.7.1 Thermal motor monitoring	s
Motor connection			
p0352	Motor cable line resistance	Input of the motor cable resistance value for outgoing and return conductor.	Ohm
p0353	Motor series inductance (=motor cable inductance)	Input of the line inductance of the outgoing and return conductor. The value can be neglected for motor connection cables < 10 m. If a series reactor is also connected between the motor and the inverter, you need to enter the inductance value as an additive to the line inductance.	mH

The output frequency of the module for stepper motors in open-loop control operation (without clock synchronization) is 4000 Hz and, in closed-loop control operation or with use of the module in an isochronous group, it is 1500 Hz. According to the number of pole pairs, this results in the following calculation for the maximum speed:

Speed [Hz] = 4000 Hz/number of pole pairs

Example:

If there are 50 pole pairs, a stepper motor in open-loop control operation with the TM Drive can rotate at a maximum speed of 4,800 rpm

7.5.5 Motor encoder

Under Encoder type configuration, select the appropriate encoder type for the motor.

Encoder type configuration			
p0404	Motor encoder selection	Selection of the motor encoder	-

7.5.5.1 Encoder parameters incremental encoder and encoderless / calculated

The encoder types incremental encoder and encoderless / calculated use the same settings.

Parameter number	Name	Description	Unit
p0408	Increments per revolution	Setting of the increments per revolution or the pulses per revolution (PPR) of the motor encoder.	-
p0409	Steps per revolution	Display of the steps per revolution or counts per revolution (CPR) of the encoder. The value cannot be edited, results from the quadrature interface and is four times the value of increments per revolution (p0408).	-

Incremental encoder

With the incremental encoder, the increments per revolution must be set.

Encoderless / calculated with stepper motor

With the setting encoderless / calculated with stepper motor, the motor moves at low speeds in the set encoder resolution steps p0408 or p0409. The encoder resolution (increments per revolution (p0408)) must be at least 4 times or a multiple of the number of pole pairs of the motor. If the values are too high, the positioning accuracy can fluctuate depending on the motor quality (ripple).

It is recommended to set every integer multiple of the motor full step angle (p30001); a step division into partial steps ($1/2$, $1/4$, $1/8$...) is not necessary but can improve the positioning accuracy, especially with multi-pole stepper motors. The following table shows how the corresponding step subdivisions are determined for this.

Table 7-2 Determination of the step subdivisions

Step resolution	Steps per revolution (p0409)	Increments per revolution (p0408)	Example: Step angle = 1.8 °; Number of steps = 200; Number of pole pairs = 50	
			Steps per revolution (p0409)	Increments per revolution (p0408)
Full step	1 x number of steps (p30001)	1/4 x number of steps (p30001)	200	50
1/2 half step	2 x number of steps (p30001)	2/4 x number of steps (p30001)	400	100
1/4 quarter step	4 x number of steps (p30001)	4/4 x number of steps (p30001)	800	200
1/8 eighth step	8 x number of steps (p30001)	8/4 x number of steps (p30001)	1600	400
.	.	.	.	.
1/64 sixty-fourth of a step	64 x number of steps (p30001)	64/4 x number of steps (p30001)	12800	3200

7.5.5.2 Assign encoder counting direction parameters

For encoder types [1] incremental encoder (A, B, Z track) or [3] incremental encoder (A, B track), it may be necessary to invert the counting direction of the encoder. This is done by way of the "Invert encoder counting direction" parameter (p0410). With incremental encoders, this may be necessary, for example, if the A and B tracks were swapped when the encoder was connected.

Definition of direction of rotation for incremental encoder:

The positive direction of rotation for an incremental encoder is defined as follows.

If the positive A edge comes before the positive B edge in terms of time, the motor with a view of the motor shaft rotates clockwise in the positive direction of rotation.




Figure 7-2 Direction of rotation for the incremental encoder

Definition of motor speed:

A positive motor speed in TM Drive is defined as follows:

The motor rotates clockwise looking down on the motor shaft. The encoder value increments during this process.

Table 7-3 Additional encoder values

Parameter number	Name	Description	Unit
p0410	Reverse encoder counting direction	This setting negates the counting direction of the encoder.	-

7.5.5.3 Automatic encoder / pole position identification

Automatic encoder/pole position identification is found in the "Commissioning" submenu of the configured TM Drive. It is possible to detect the encoder/motor parameters for incremental encoders, absolute encoders and Hall encoders. Depending on the encoder type, the following encoder / motor parameters are automatically detected:

Absolute encoder (6)

- Commutation angle offset (p0431)
- Number of pole pairs (p0314)

Incremental encoder (1)

- Increments per revolution (p0408)
- Invert encoder counting direction (p0410)

Hall encoder (2)

- Hall pattern (p0420)
- Phase-angle error (p0431)

Proceed as follows for automatic encoder/pole position identification:

Preconditions

- The motor parameters are known and the calculation of the controller parameters under open-loop/closed-loop control has been performed and transferred to the drive.
- The device is in RUN state and the drive is at standstill.
- The drive is not enabled in any other way (e.g. by a technology object or a user program).
- The motor can rotate freely in both directions of rotation and is not loaded with a static load (example: suspended load)

Note

If the motor is loaded with a static load during encoder detection, the commutation offset angle may not be correctly detected. The motor can then only deliver a reduced torque.

Step 1:

Go online and enable commissioning mode under Commissioning, Identification with the 'Start' button and select the encoder / pole position identifier.

Note

In this operating mode, the drive can be controlled only by the TM Drive. A control of the drive by the S7 control via PROFIdrive is not possible in this mode and is locked. This is also signaled by resetting ZSW1 bit 9.

Step 2:

The configured motor type and motor encoder is displayed under Commissioning encoder / Pole position identification. Insert the identification current allowed for the test. This is always automatically set to the rated motor current. However, it can be adjusted if required.

Note

If the motor is already installed in an application, you may need to increase the identification current in steps. The motor maximum current p0323 must not be exceeded. If necessary, observe idle times between the identification cycles to avoid overheating the motor.

Especially for motors with an increased cogging torque, it may be necessary to increase the identification current so that the encoder and pole position information can be accurately detected.

Step 3:

Start the encoder / pole position identification with the selection button "Start encoder detection".

A configured motor holding brake is opened during encoder / pole position identification. This is signaled via ZSW1 bit 12.

NOTICE**Open motor holding brake**

The motor holding brake is opened during encoder / pole position identification. Especially with suspended axes, you must ensure that it is possible to open the motor holding brake.

An unexpected collapse of a suspended axis can result in personal injury and property damage.

Step 4:

If the drive is still in operation, execution of the identification commands is rejected. Stop the operation of the drive before the encoder / pole position identification. Then continue with step 3.

When all conditions are met, the TM Drive starts identification after confirmation of the safety prompt. It is necessary that the drive can be turned safely in both directions.

Step 5:

If the encoder / pole position identification is successfully executed, the determined values are displayed.

Note

Check that the values determined are plausible before you apply them.

Step 6:

You can now select which of the determined values you want to transfer to the offline project. By clicking the "Transfer determined values to offline project" button, the selected values are transferred to the offline project.

Note

The determined settings are stored only temporarily on the module. They are replaced by the permanently stored parameters on the next restart.

If you want to store the settings permanently on the module, change the drive parameters offline and download them again with "Download to device".

Step 7:

When you have transferred the parameters to the offline project, disable commissioning mode under Commissioning, Identification with the 'Exit' button. You must then load the parameters onto the module using "Download to device".

Note

Encoder / pole position identification is completed. The option "Encoder calibration at each start" (p1990) is no longer required for the incremental and absolute encoders and should be deselected.

7.6 Controller structure

Overview




Figure 7-3 Controller structure overview

7.6.1 Setpoint channel

Overview

Setpoints from the respective setpoint source are prepared for the motor control in the setpoint channel of the drive.


You specify the setpoints via the drive function in the S7 controller (technology object or the Sina Speed functions) or the drive telegrams to PROFIdrive.

You can find the settings for the setpoint channel in the context of the drive under "Parameters" > "Setpoint channel".

Under "Setpoint channel" you configure the following:

- Reference values (Page 90)
- Application limits (Page 91)
- Ramp generator and speed setpoint filter (Page 92)

The figure below shows the processing of the speed setpoint in the drive controller.



- ① Release conditions in STW1 of the Profidrive telegram must be satisfied.
Stationary state detection (p1226) must have responded in the case of a restart.

Figure 7-4 Setpoint channel

The speed setpoint from the drive telegram is limited in the setpoint channel according to the specified values, see section Reference values (Page 90).

The output of the ramp-function generator is fed to the speed controller via the speed setpoint filter, see section Ramp generator and speed setpoint filter (Page 92).

7.6.1.1 Reference values

The physical variable speed is transmitted in the drive telegrams as a reference values.

- Speeds are normalized to the reference speed (p2000) in the drive telegram.
- Torques are normalized to the reference torque (p2003) in the drive telegram.

Parameters p2000 and p2003 are definitive as reference values (telegram content = 4000 hex or 4000 0000 hex for double words, if the input value has the value p2000).

Example of the normalization of the speed:




Figure 7-5 Example of normalization of the speed

Note

The speed and torque are specified in the drive telegram as a percentage of the reference speed in the range -200% to 200%.

Therefore, set the reference variables in such a way that the desired maximum value falls within the value range of the control from -200% to +200%.

Procedure

1. Configure the reference value in the context of the drive under:
"Parameters" > "Setpoint channel" > "Reference values".



WARNING

Uncontrolled drive behavior

Note that the specification of reference values in the CPU and the drive must always match. Otherwise, uncontrolled drive behavior and rotating of the motor might occur.

Recommendation: First, complete the commissioning of the drive and thereby the definition of the reference values before you start up the CPU and a technology object, for example.

7.6.1.2 Application limits

In the "Parameters" > "Setpoint channel" > "Application values" area, you can configure limitations for the speed and torque of the drive if required and adapt them to the requirements of your mechanical system.

Speed limitation

If you need a direction-dependent limitation of the speed, define speed limits for each direction using parameters p1083 and p1086.

7.6.1.3 Ramp generator and speed setpoint filter

Speed ramp-function generator

The TM Drive uses the speed ramp generator type "Basic ramp function generator" p1115[0].

The ramp-function generator can be switched off with the setting "No ramp-function generator".

The speed ramp-function generator is used to limit the acceleration at sudden setpoint changes and helps to prevent drive train shock loads.

An acceleration ramp and a deceleration ramp can be set independently with the ramp-up time and ramp-down time. This enables a controlled transition at setpoint changes.

Note

Set the ramp-up and ramp-down times of the ramp-function generator in the setpoint channel of the drive only so fast that, in the case of accelerations and decelerations, the motor speed can track the setpoint without damaging the machine. This ensures optimal functioning of the speed controller precontrol.

Especially with the control type [103] controlled (I = const.), the ramp-up and ramp-down times must not be set too steep, as otherwise the rotor cannot follow the controlled rotating field.

Procedure

Enter the settings for the speed ramp-function generator under "Parameters" > "Setpoint channel" > "Ramp-function generator":

- Rampup time
- Ramp-down time
- Speed

Note

The TM Drive uses the three values entered to form the values "Speed ramp-function generator ramp-up time" (p1120) and "Speed ramp-function generator ramp-down time" (p1121), which refer to 10,000 rpm.

When using the GSD file, directly enter the values relative to 10,000 rpm.

Speed setpoint filter

The drive has a first-order time-delay element (low pass PT1) as a speed setpoint filter. The filter time constant can be set with p1416.

The speed setpoint filter is able to attenuate harmonic components of the setpoint and thus to prevent any overshooting of the higher-level controller.

The speed setpoint filter has no effect on the stability of the speed controller because it is in the setpoint channel before the control loop. The dynamics of the response to setpoint changes is reduced by smoothing.

As a rule, set the speed setpoint filter to a low value, since the upstream ramp-function generator ensures sufficient limitation of the setpoint signal.

7.6.2 Cascade controller

Torque limitation

You can specify the torque limitation p1520 as an absolute value. The limitation acts both when motoring as well as generating.

WARNING

Accuracy of torque limitation

The function of the torque limitation is not safe torque limitation in the sense of functional safety. The torque limitation refers to the calculated internal (air gap) torque of the motor.

The internal torque is a calculated value from the internal motor constant and motor current. The torque output at the shaft is the internal torque minus friction and iron losses.

Due to the following influencing factors, the deviation of the torque calculation can be in the two-digit percentage range:

- Internal motor constant p0316
- Current measurement accuracy
- Temperature dependence
- Speed and load dependence on friction, iron and additional losses of the motor

WARNING

Danger to life due to uncontrolled movement of the drive as a result of incorrect parameter assignment

Incorrect parameterization of the torque limitation can result in uncontrolled movement of the drives if there is no counter-torque, and cause death or serious injury.

Ensure the correct parameterization.

Zero speed detection

Set the speed threshold for the motor standstill detection (p1226). For braking with OFF1 or OFF3, the zero speed is detected when this threshold is fallen below.

Note

A zero point calibration is only started if the speed falls below the speed threshold for standstill detection (p1226).

Note

A switch-on process of the drive via STW1 is always delayed until the speed has fallen below the speed threshold for standstill detection (p1226).

As long as the speed is still above this speed threshold, warning 2007 is issued. This can be the case, for example, if the motor shaft is driven externally.

If the switch-on command is still set despite this warning, the drive is switched on and the specified setpoint speed is adopted as soon as the speed threshold for standstill detection has been undershot.

Speed threshold values for message

Also specify the speed threshold values for the following messages of the drive status word:

- "Speed threshold 1" (p2141)
If the speed exceeds the threshold value, bit 10 is set as feedback in ZSW 1
- "Speed threshold 4" (p2163)
As long as the speed deviation lies within the tolerance range, bit 8 in ZSW1 is set as feedback
- "On delay time" (p2167)
Setting the switch-on delay time for the message "Speed setpoint/actual deviation within tolerance" (see also p2163)




Figure 7-6 Sets the ON-delay time (p2167) and the speed threshold value 4 (p2163)

End stop detection and step loss detection with the stepper motor

When an incremental encoder and the control type [103] controlled ($I = \text{const.}$) are used with a stepper motor, end stop detection or step loss detection can be implemented using bit 8 in the ZSW1. The parameters "speed threshold value 4" (p2163) and "On delay" (p2167) can be used to set the detection tolerance range.

7.6.2.1 Cascade controller




Figure 7-7 Cascade controller

7.7 Controller settings

Under "Parameters" > "Open-loop/closed-loop control", you specify the type of control, the general controller settings and the settings for speed and current controllers.

Control type

The open-loop / closed-loop control type can be selected depending on the motor type.

Motor type: Stepper motor

- [100] Closed-loop speed control (cascade)
- [103] Controlled (I = constant)

7.7.1 Speed control (cascade)

In Speed controller (cascade) mode, the speed difference between the actual and the rated speed is detected using an encoder and the speed deviation is controlled accordingly. Since the speed controller is followed by a current controller, this speed control method is referred to as cascade control.

General controller settings

Speed and current controllers can be optimally tuned if the properties of the load mechanics of your machine and the electrical properties of the drive are specified as correctly as possible.

Enter the general controller settings under "Parameters" > "Control/closed-loop control" > "Controller settings".

- Moment of inertia load p1398
- Precontrol p1496
- Viscous friction p1399
- Additional torque p1511
- Speed actual value filter p1441

Speed stability can be improved using the actual speed filter, depending on the encoder resolution.

Constant loads can be compensated using additional torque p1511. This reduces compensation processes when the drive is switched on using motor holding brakes.

Additional important settings

The values for speed and current controllers can be determined in the best possible way if, in addition to the properties of the electric motor, you also specify the properties of the gearbox and the connecting cable.

- Motor cable line resistance p0352
- Motor cable/series inductance p0353
- Gearbox moment of inertia p2725

Precontrol p1496

Using the precontrol (p1496), the precontrol of the moments of inertia, consisting of Motor (p0341), Gearbox (p2725) and Moment of inertia load (p1496), can be specified as a percentage value. The precontrol allows the drive to be moved more dynamically. The precontrol is switched off with a preset of 0%.

To use this function, the setpoint speed must be preset by a ramp. For this, you can either use the internal ramp-function generator (see section Ramp-function generator and speed setpoint filter) or corresponding acceleration/deceleration functions in technology objects.

Viscous friction p1399

The friction of the system is precontrolled using Viscous friction (p1399). This is specified as a linear friction torque as a function of the speed.

Additional torque p1511

Constant loads can be compensated using additional torque (p1511). This reduces compensation processes when the drive is switched on using motor holding brakes.

Speed actual value filter p1441

The drive has a first-order time-delay element (low pass PT1) as a speed actual value filter. The filter time constant can be set via (p1441).

The parameter is preset depending on the parameter "Increments per revolution" p0408 in the HSP. If you configure the device using a GSDML, you can use the following table as a guide.

Table 7-4 Actual speed filter times as a function of the encoder resolution

Encoder resolution (steps per revolution p0409 or single-turn resolution p0423)	Speed actual value filter p1441 in ms
400	11
512	10
1024	8
2048	6
4096	4
6000	2
10000	1
16000	0

Speed controller and current controller

You can have the speed and current controller parameters calculated via the controller settings of STEP 7. It is also possible to select the controller settings manually.

Having controller settings calculated

To have the controller settings of STEP 7 calculated, proceed as follows:

1. Click the "Calculate speed number/current controller settings" button in the area for the controller settings.
The "Controller calculation" window opens. The window displays the appropriate controller parameters.
2. If needed, you can re-adjust the controller settings via the "Controller behavior" and "Load fluctuation" sliders.
 - "Controller behavior": If the value is increased, the controllers react more strongly to controller differences. At the same time, the controller tends to overshoot. The default setting here is 70%.
 - "Load fluctuation": A larger value allows more oscillation in the stable state. The speed deviations are greater during a load step. The default setting here is 30%.

Note

There is no guarantee that readjustment of the controller calculation will always result in a stable system.

Change the settings for "Controller behavior" and "Load fluctuation" incrementally. Always check the settings with low speed and load profiles.

3. Apply the controller settings by clicking the "Apply" button.

You can then continue to change the calculated controller settings manually.

Setting the controller settings manually

Enter the settings for the speed controller under "Parameters" > "Control/closed-loop control" > "Speed controller".

- Prop. gain
- Integral action time
- Speed actual value filter

Enter the settings for the current controller under "Parameters" > "Control/closed-loop control" > "Current controller".

- Iq proportional gain
- Iq integral action time
- Id proportional gain
- Id integral action time
- Enable overmodulation
- Optimum motor load angle p327

Note

If you manually set the controller parameters to inappropriate values, the drive system can be damaged.

Make changes to the controller settings in small steps. Keep checking the behavior of the drive system until you have found a satisfactory setting.

7.7.2 Manual controller tuning Speed controller (cascade)

You can find the manual controller tuning in STEP 7 under Commissioning. Here, you can optimize the control parameters according to your application and thereby fine-tune the drive.

Procedure

For manual controller tuning, proceed as follows:

Step 1:

Go online to the module with TIA Portal by clicking on the "Connect online" selection button.

Step 2:

If you have not already calculated the controller parameters under Control/closed-loop control, you can do this again here. First, enter the mass moment of inertia of the load.

Use the "Calculate" selection button to calculate the controller parameters.

Step 3:

The calculated controller values are displayed. The online values, i.e. the currently active values, are also displayed on the module.

Step 4:

With the selection "Apply online" button, the new controller values are directly transferred and take effect.

Note

When the axis is in operation, the enable is automatically canceled and the new parameters are applied.

Step 5:

You can now put the drive into operation with a speed or positioning TO, for example, and evaluate the control behavior using a trace recording.

If the control behavior is satisfactory, continue with step 7.

Step 6:

If additional tuning is required, there are 2 options to better adjust the control parameters.

1. You can calculate the controller parameters again as described in step 2 and readjust the parameters accordingly using the sliders. (See section Control/closed-loop control (Page 97) under Speed controller and current controller)
2. You set the controller parameters manually. You can use the old values as a guide and gradually change the proportional gain and/or the integral action time.

Perform the steps starting with step 4 again.

Step 7:

Once you have performed the tuning, you need to transfer the detected controller parameters to the drive parameters using the selection button "Apply controller values".

Terminate the online connection ("Go offline" selection button) and then reload the project onto the module using "Download to device". This ensures that the parameters are still active in the project and on the module after a restart.

Controller tuning is now completed.

7.7.3 Controlled (I = const.)

General controller settings

In the controlled control mode (I = const.), the speed is controlled by an angle adjuster. Depending on the respective speed, the control angle of the motor is switched faster or slower in quantified steps in the desired direction of rotation.

Speed controller

It is advisable to specify speed changes along an up and down ramp, as otherwise the drive is not able to follow the specified speed.

The internal ramp-function generator (section 7.5.3) can be used as speed ramp.

Current controller

With the control mode controlled (I = const.), the current controller applies a constant current value to the motor. The motor current is specified using two current values for travel mode (p1738 run current) and standstill mode (p1739 stop current). The current values are effective values.

- Run current p1738
- Stop current p1739

The stop current is impressed on the motor while it is at a standstill and ensures a corresponding holding torque. If a speed not equal to 0 1/min is specified, the current setpoint is switched from stop current to run current. If the motor comes to a standstill from a movement, the setpoint current is switched from run current to stop current after 1 s.

In many applications, the stop current can be reduced during standstill. As a result, energy can be saved during the stop phases and the motor is subjected to less thermal stress.

For reasons of protection, the run and stop current may not be greater than 1.5 times the rated motor current (p0305).

Note

With the closed-loop control mode ($I = \text{const.}$), no distinction is made between the magnetic longitudinal inductance (for I_d) and transverse inductance (for I_q) of the motor. There are therefore only current controller values for the total current.

Enter the general controller settings under "Parameters" > "Control/closed-loop control" > "Controller settings".

- Moment of inertia load p1398
- Speed setpoint filter p1416

Additional important settings

The speed and current controllers can be determined in the best possible way if, in addition to the properties of the electric motor, you also specify the properties of the gearbox and the connecting cable.

- Motor cable line resistance p0352
- Motor cable/series inductance p0353
- Gearbox moment of inertia p2725

Current controller

You can either set the current controller manually or have the controller settings calculated by STEP 7.

Having controller settings calculated

To have the controller settings of STEP 7 calculated, proceed as follows:

1. Click on the "Calculate current controller settings" button in the Controller settings area. The "Controller calculation" window opens. The window displays the appropriate controller parameters.
2. Apply the controller settings by clicking the "Apply" button.

You can then continue to change the calculated controller settings manually.

Setting the controller settings manually

Enter the settings for the current controller under "Parameters" > "Control/closed-loop control" > "Current controller".

- Proportional gain
- Integral action time
- Enable overmodulation
- Optimum motor load angle

Note

If you manually set the controller parameters to inappropriate values, the drive system can be damaged.

Make changes to the controller settings in small steps. Keep checking the behavior of the drive system until you have found a satisfactory setting.

7.8 OFF responses

OFF1 (Switch off)

By resetting bit 0 in STW1 (On), you activate OFF1 and the drive is braked to 0 in a speed-controlled manner according to the ramp-function generator ramp-down (p1120, p1121). If the actual speed falls below the value of the "Standstill detection" parameter (p1226) or if a timeout is detected, the pulses are blocked after the motor brake closing time p1217 has expired. "Switching on inhibited" is activated.

Timeout

With OFF1, the time is calculated in which the drive should normally stop from twice the reference speed. If the drive does not stop within 2 times of this time, the drive is de-energized and it coasts down.




Figure 7-8 OFF1 sequence diagram

OFF2 (Coast down)

You activate OFF2 by resetting bit 1 in STW1 (NoCoastStop). The pulses are immediately canceled, any parameterized motor holding brake is applied and the drive coasts down. "Switching on inhibited" is activated.




Figure 7-9 OFF2 sequence diagram

OFF3 (QuickStop)

You trigger a quick stop (OFF3) by resetting bit 2 in STW1 (NoQuickStop). The rapid stop takes into account the ramp-down time configured in the HSP ("Parameter" > "Setpoint channel" > "Speed – Ramp-function generator"). After the standstill is detected or the monitoring time has elapsed, any configured motor holding brake is closed and the pulses are deleted after the motor holding brake closing time p1217 has expired. "Switching on inhibited" is activated.

Timeout

The rapid stop is monitored for time and causes the motor to be energized after 6 seconds at the latest.




Figure 7-10 OFF3 sequence diagram

Prioritization

The OFF responses are prioritized as follows:

- OFF2 (coast down) > OFF1 (switch off)
- OFF3 (QuickStop) > OFF1 (Switch off)

7.9 DC-link voltage

The TM Drive system cyclically monitors the DC link voltage. The limit values can be set under "Alarms/Monitoring".

The regenerative feedback into the DC power supply cannot be suppressed. This has several advantages.

When the drive is braked and the brake chopper is not connected and configured, energy is fed back, which results in an increase in the DC link voltage. For this reason, the DC link voltage is monitored by the module.

You can freely set the DC link voltage monitoring limits within the permissible range.

If the limits are exceeded, the module switches off. Before the module switches off, it issues a warning (limit $\pm 5\%$) stating that the limit is almost exceeded.

Procedure

1. Open the "DC link voltage" area in the context of the drive under "Parameters" > "Drive".
2. Configure:
 - Minimum value of the DC link voltage p0390
 - Maximum value of the DC link voltage p0391

**WARNING****Danger due to excessively high voltages with an active load and inactive control**

When the control is inactive, an active load can cause the motor to accelerate to a speed at which a hazardous voltage (greater than 42 V AC) is applied to the motor terminals. In this case, the DC link voltage may increase over 60 V DC when the control is inactive.

- Under the given application conditions, ensure that the motor is not operated above the voltage setting range by selecting the appropriate motor and gearbox.

7.10 Brake module

The drive system TM Drive can externally control a motor holding brake via the process image using a DQ or relay module.

The following options for the stepper motor type can be selected under "Brake module":

- [0] No function
- [4] Motor holding brake externally via the process image

If stepper motors are selected, the brake chopper function cannot be used. Should a brake chopper nevertheless be required, you can install another TM Drive module with brake chopper functionality in the same potential group and connect the brake resistor there and parameterize the brake chopper.

7.10.1 External motor holding brake

The motor holding brake can be used when the drive system is disabled (e.g. when the power supply to the drive system is switched off) to prevent unwanted movements of the suspended load (e.g. falling due to gravity). The motor can move by its own weight or an external force even if the motor power supply is interrupted.

Note

- Use this brake only for "holding", which means to maintain the standstill. Do not use it for "braking", which means to stop the moving load. Use the holding brake only to hold a motor at a standstill.
 - The holding brake is enabled when the motor is switched off.
-

If the motor holding brake function is enabled, you must configure the following settings in the area "Parameters" > "Drive" > "Brake control module".

Adjust the opening and closing times of the motor holding brake:

- Motor holding brake opening time (p1216)
- Motor holding brake closing time (p1217)

For the closing and opening times, delay times of relays may have to be taken into account and added to the times of the motor holding brake.

p1216 = motor brake opening time + relay opening time

p1217 = motor brake closing time + relay closing time

If the motor holding brake is configured, the drive takes the delay times into account and accordingly sets bit 12 in the process image ZSW1. This bit can be used to control a motor holding brake, for example with a DQ module or relay module.

Note

When selecting the additional module, make sure that the current carrying capacity is suitable. This must be dimensionless depending on the current consumption of the motor holding brake.

RC circuit of a TM Drive with DQ module and motor holding brake




Figure 7-11 RC circuit of a TM Drive with DQ module and motor holding brake

Braking sequence

The sequence diagram shows an example of the behavior of the drive with OFF1.




Figure 7-12 Braking sequence

The magnetizing time is calculated automatically depending on the motor parameters.

The influence of the motor holding brake on the OFF reactions is described in section 7.6.4 (Page 103) OFF reaction.

NOTICE

Improper use

Improper use of the motor brake will shorten its service life. The motor brake is only intended for holding purposes. Frequent emergency stops with the motor brake shorten its service life. Unless absolutely necessary, do not use the motor brake as emergency stop.

7.11 Messages/monitoring

Thermal monitoring

The purpose of thermal monitoring is to detect critical states. Parameterizable warning thresholds are available that allow further operation of the drive (e.g. with reduced power) and prevent an immediate shutdown. However, the parameter assignment options are only interventions below the shutdown thresholds.

The following thermal monitoring options are available:

- Motor
 - Motor I^2t model
- Power end stage
 - Overload protection
 - Temperature sensor

When an overload is detected by one of these monitoring functions, a warning is output first. The respective warning thresholds (p0291) are parameterizable. The current status of the monitoring functions is displayed. If an alarm or fault limit is exceeded, the "Temperature monitoring" message is sent.

Note

All alarm and fault limits are provided with a corresponding hysteresis. The corresponding alarm or fault messages therefore remain until the threshold including hysteresis has been fallen below.

Note

Motor monitoring

The thermal motor resistance utilization is a calculated value. The values are not saved.

After a power reset, the values only match again after a sufficiently long cooling time.

Operating temperature

Note that the specified ambient temperature range for the drive must always be adhered to, see section Technical specifications (Page 141).

7.11.1 Motor

Thermal motor monitoring

The thermal motor monitoring is performed using a configurable I^2t temperature model.

WARNING

Risk of injury due to overheating of the motor

The thermal model is reinitialized after changing the drive data set and when switching on the device.

After initialization, the thermal motor utilization cannot be immediately determined as the model must first settle. As a consequence, an initial utilization of 50 % is used as basis. The settling phase duration depends on the given thermal time constants; the accuracy depends on to what extent the specific installation situation deviates from the model.

During the settling time it is possible that the set alarm and/or fault threshold is reached with some delay. For the installation situation simulated in the model, an unfavorable installation was selected so that generally deviations occur on the safe side.

- If the motor has been subjected to a high load for a long time, allow a sufficient cooling time after switching the motor off.
- Avoid direct contact.

You can define the warning threshold under Parameters > Messages/monitoring > Motor relative to the respective shutdown threshold.

Procedure

1. Open the "Motor" area in the context of the drive under "Parameters" > "Messages/monitoring".
2. Configure the warning threshold p0291[1].

Motor I^2t model

The I^2t monitoring operates with the relative motor power loss, and in addition to the rated motor current (p0305) as reference value, only requires the thermal time constant winding - environment (p0611[0]) to calculate the limiting integral. The 100 % shutdown threshold corresponds to the maximum continuous power loss of the motor, i.e. to the square of the rated motor current (p0305).

Motor type PMSM

If the PMSM reaches the 100% threshold, the motor current is limited to the rated motor current to prevent overheating.

Motor type stepper motor

When the stepper motor reaches the 100% utilization threshold, the drive is switched off and an error is set.

**WARNING****Overheating of the motor due to non-compliance with specified ambient conditions**

The motor may only be operated in the ambient conditions such as ambient temperature, installation elevation, etc. specified by the manufacturer.

If the motor is used outside its specification, the thermal model does not provide sufficient protection.

- If the ambient conditions of the motor do not correspond to the values specified by the manufacturer, ensure that the motor is derated.
- Obtain the derating behavior and the resulting lower motor performance data from the motor manufacturer and adjust these accordingly in the motor parameters of the TM Drive.

7.11.2 Power end stage**Thermal monitoring of power end stage**

The power end stage is monitored with a temperature sensor. You can specify the warning threshold (p0291[1]) relative to the shutdown threshold "System maximum temperature power end stage".

Procedure

1. Open the "Power end stage" area in the context of the drive under "Parameters" > "Messages/monitoring".
2. Configure the warning threshold p0291[1].

Besides the temperature monitoring, the current load is also monitored. The current load of the power unit is decisive for the temperature rise. The relative load of the power end stage is calculated based on the square of the output current according to the I^2t method.

Automatic overload limiting

The TM Drive is overload-capable. The load of the power end stage is automatically limited by the drive.

The maximum overload time t_{overload} is calculated depending on the temperature of the power end stage T_{PU} . When operating with cyclic overload, the rated power is not exceeded by the time-averaged power (rms).

Stepper motor

With a stepper motor, a double overload of the rated current I_n cyclic for a duration of $t_{\text{overload}} = 3$ s with a subsequent recovery time of 17 s at $T_{\text{PU}} = 20$ °C is possible. At $T_{\text{PU}} = 80$ °C, the overload time $t_{\text{overload}} \approx 0.75$ s.




Figure 7-13 Overload behavior of TM Drive

Note the information on derating as a function of ambient conditions (e.g. temperature, mounting position) in section Derating of the TM Drive (Page 144).

Note

Overload capability of the power unit

Operation with a peak current of 10 A is possible temporarily if the average RMS value of the output current does not exceed the rated current of the power unit up to 5 A.

7.12 Isochronous mode

In isochronous mode, communication with the isochronous alarm of the S7 program is synchronized to optimize the synchronous operation of multiple axes, for example. If both the CPU (at least 1500) and the ET200SP (HF or HS) support clock synchronization, the TM Drive from firmware version 2.1 or higher can be integrated into an isochronous group.

In this case, the module is synchronized with the synchronized bus clock of the ET200SP, whose cycle time can be parameterized in the sync domain. Due to the cross-module synchronized transmission and receipt of the data, performance is considerably improved where multiple drives interact.

Note

The sign-of-life tolerance for monitoring clock synchronization can be set in the device configuration under "Basic parameters". It specifies how many erroneous isochronous cycles in succession are permissible in communication between the module (slave) and the S7-CPU (master). This monitoring of the clock synchronization can be switched on and off.

7.13 Dynamic Servo Control (DSC)

For the TM Drive from firmware version 2.1, DSC can be parameterized.

7.13 Dynamic Servo Control (DSC)

For this, select SIEMENS telegrams 5 (without torque reduction) or 105 (with torque reduction). The basic precondition is that isochronous operation is activated for the TM drive.

With DSC, position control is performed in the drive module and no longer in the S7-CPU. The positional deviation and the position controller gain are transferred in the drive telegram. That enables, for example, traversing of curved paths with multiple axes.

Programming

The TM Drive does not have its own control panel. A user program is required to control the motion sequences.

You have the following options for controlling the motion sequences in the user program:

- Control via the process image
- Control via the SINA_SPEED (Page 125) instruction
- Control with a technology object (Page 125)

8.1 Controlling TM Drive via the process image

Structure of the I/O addresses

The structure of the input addresses of the TM Drive depends on the configured communication telegram.

The telegrams can be set in the "Properties" area under "General" and further via "Basic parameters".

The status of the digital input and the state of the STO input is available at any time via the process image irrespective of the telegram selection.

For activation of the process data extension in the PII, the process image of the inputs for the transmission of process variables from the module to the S7 program is extended by 6 bytes. This means that up to 3 variables can be transferred concurrently in the cyclic data.

The structure of the output addresses of the TM Drive depends on the configured communication telegram.

Frame	1		2		3		5	
PZD1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1
PZD2	NSET_A	NACT_A	NSET_B	NACT_B	NSET_B	NACT_B	NSET_B	NACT_B
PZD3								
PZD4			STW2	ZSW2	STW2	ZSW2		ZSW2
PZD5					G1_STW	G1_ZSW	STW2	ZSW2
PZD6						G1_XIST1	G1_STW	G1_ZSW
PZD7							XERR	G1_XIST1
PZD8						G1_XIST2		
PZD9							KPC	G1_XIST2
PZD10								

Standard telegram 1 Structure I/O addresses

Inputs

Element	Data type	Offset
Status word ZSW1	Structure	0.0
Bit08_NoSpeedDeviation	Bool	0.0
Bit09_ControlRequested	Bool	0.1
Bit10_SpeedComparisonValueReachedExeed	Bool	0.2
Bit11_TorqueLimitNotReached	Bool	0.3
Bit12_MotorHoldingBrakeOpen	Bool	0.4
Bit13_NoMotorOvertemperature	Bool	0.5
Bit14_ActualSpeedPositive	Bool	0.6
Bit15_NoPowerUnitOvertemperature	Bool	0.7
Bit00_ReadyToSwitchOn	Bool	1.0
Bit01_ReadyToOperate	Bool	1.1
Bit02_OperationEnabled	Bool	1.2
Bit03_FaultPresent	Bool	1.3
Bit04_NoCoastStopActivation	Bool	1.4
Bit05_NoQuickStopActivated	Bool	1.5
Bit06_SwitchingOnInhibited	Bool	1.6
Bit07_AlarmPresent	Bool	1.7
Actual speed value NACT_A	Word	2.0
Telegram extension word	Structure	4.0
Reserved	Byte	4.0
Telegram extension STO_Status	Bool	5.0
Telegram extension DI_Status	Bool	5.1

Outputs

Element	Data type	Offset
Control word STW1	Structure	0.0
Bit08_Reserved	Bool	0.0
Bit09_Reserved	Bool	0.1
Bit10_ControlByPlc	Bool	0.2
Bit11_Reserved	Bool	0.3
Bit12_Reserved	Bool	0.4
Bit13_Reserved	Bool	0.5
Bit14_Reserved	Bool	0.6
Bit15_Reserved	Bool	0.7
Bit00_On	Bool	1.0
Bit01_NoCoastStop	Bool	1.1
Bit02_NoQuickStop	Bool	1.2
Bit03_EnableOperation	Bool	1.3
Bit04_EnableRampGenerator	Bool	1.4

Element	Data type	Offset
Bit05_UnfreezeRampGenerator	Bool	1.5
Bit06_EnableSetpoint	Bool	1.6
Bit07_FaultAcknowledge	Bool	1.7
Speed setpoint NSET_A	Word	2.0

Standard telegram 2 Structure I/O addresses

Inputs

Element	Data type	Offset
Status word ZSW1	Struct	0.0
Bit08_NoSpeedDeviation	Bool	0.0
Bit09_ControlRequested	Bool	0.1
Bit10_SpeedComparisonValueReachedExceed	Bool	0.2
Bit11_TorqueLimitNotReached	Bool	0.3
Bit12_OpenHoldingBrake	Bool	0.4
Bit13_NoMotorOvertemperature	Bool	0.5
Bit14_ActualSpeedPositive	Bool	0.6
Bit15_NoPowerUnitOvertemperature	Bool	0.7
Bit00_ReadyToSwitchOn	Bool	1.0
Bit01_ReadyToOperate	Bool	1.1
Bit02_OperationEnabled	Bool	1.2
Bit03_FaultPresent	Bool	1.3
Bit04_NoCoastStopActivation	Bool	1.4
Bit05_NoQuickStopActivated	Bool	1.5
Bit06_SwitchingOnInhibited	Bool	1.6
Bit07_AlarmPresent	Bool	1.7
Actual speed value NACT_B	DWord	2.0
Status word ZSW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5

8.1 Controlling TM Drive via the process image

Element	Data type	Offset
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7
Telegram extension word	Struct	8.0
Reserved	Byte	8.0
Telegram extension STO_Status	Bool	9.0
Telegram extension DI_Status	Bool	9.1

Outputs

Element	Data type	Offset
Control word STW1	Struct	0.0
Bit08_Reserved	Bool	0.0
Bit09_Reserved	Bool	0.1
Bit10_ControlByPlc	Bool	0.2
Bit11_Reserved	Bool	0.3
Bit12_Reserved	Bool	0.4
Bit13_Reserved	Bool	0.5
Bit14_Reserved	Bool	0.6
Bit15_Reserved	Bool	0.7
Bit00_On	Bool	1.0
Bit01_NoCoastStop	Bool	1.1
Bit02_NoQuickStop	Bool	1.2
Bit03_EnableOperation	Bool	1.3
Bit04_EnableRampGenerator	Bool	1.4
Bit05_UnfreezeRampGenerator	Bool	1.5
Bit06_EnableSetpoint	Bool	1.6
Bit07_FaultAcknowledge	Bool	1.7
Speed setpoint NSET_B	DWord	2.0
Control word STW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5

Element	Data type	Offset
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7

Standard telegram 3 Structure I/O addresses

Inputs

Element	Data type	Offset
Status word ZSW1	Struct	0.0
Bit08_NoSpeedDeviation	Bool	0.0
Bit09_ControlRequested	Bool	0.1
Bit10_SpeedComparisonValueReachedExeed	Bool	0.2
Bit11_TorqueLimitNotReached	Bool	0.3
Bit12_MotorHoldingBrakeOpen	Bool	0.4
Bit13_NoMotorOvertemperature	Bool	0.5
Bit14_ActualSpeedPositive	Bool	0.6
Bit15_NoPowerUnitOvertemperature	Bool	0.7
Bit00_ReadyToSwitchON	Bool	1.0
Bit01_ReadyToOperate	Bool	1.1
Bit02_OperationEnabled	Bool	1.2
Bit03_FaultPresent	Bool	1.3
Bit04_NoCoastStopActivation	Bool	1.4
Bit05_NoQuickStopActivated	Bool	1.5
Bit06_SwitchingOnInhibited	Bool	1.6
Bit07_AlarmPresent	Bool	1.7
Actual speed value NACT_B	DWord	2.0
Status word ZSW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7

8.1 Controlling TM Drive via the process image

Element	Data type	Offset
Encoder status word 1	Struct	8.0
Bit08_Probe1Deflected	Bool	8.0
Bit09_Probe2Deflected	Bool	8.1
Bit10_Reserved	Bool	8.2
Bit11_EncoderFaultAcknowledgeActive	Bool	8.3
Bit12_HomePositionExecuted	Bool	8.4
Bit13_AbsoluteValueCyclicallyExecuted	Bool	8.5
Bit14_ReservedParkingSensorExecuted	Bool	8.6
Bit15_ParkingSensorExecuted	Bool	8.7
Bit00_Function1Active	Bool	9.0
Bit01_Function2Active	Bool	9.1
Bit02_Function3Active	Bool	9.2
Bit03_Function4Active	Bool	9.3
Bit04_Value1Available	Bool	9.4
Bit05_Value2Available	Bool	9.5
Bit06_Value3Available	Bool	9.6
Bit07_Value4Available	Bool	9.7
Encoder position actual value 1 G1_XIST1	DWord	10.0
Encoder position actual value 2 G1_XIST2	DWord	14.0
Telegram extension word	Struct	18.0
Reserved	Byte	18.0
Telegram extension STO_Status	Bool	19.0
Telegram extension DI_Status	Bool	19.1

Outputs

Element	Data type	Offset
Control word STW1	Struct	0.0
Bit08_Reserved	Bool	0.0
Bit09_Reserved	Bool	0.1
Bit10_ControlByPlc	Bool	0.2
Bit11_Reserved	Bool	0.3
Bit12_Reserved	Bool	0.4
Bit13_Reserved	Bool	0.5
Bit14_Reserved	Bool	0.6
Bit15_Reserved	Bool	0.7
Bit00_On	Bool	1.0
Bit01_NoCoastStop	Bool	1.1
Bit02_NoQuickStop	Bool	1.2
Bit03_EnableOperation	Bool	1.3
Bit04_EnableRampGenerator	Bool	1.4
Bit05_UnfreezeRampGenerator	Bool	1.5
Bit06_EnableSetpoint	Bool	1.6

Element	Data type	Offset
Bit07_FaultAcknocklegde	Bool	1.7
Speed setpoint NSET_B	DWord	2.0
Control word STW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7
Encoder control word G1_STW	Struct	8.0
Bit08_Reserved	Bool	8.0
Bit09_Reserved	Bool	8.1
Bit10_Reserved	Bool	8.2
Bit11_Reserved	Bool	8.3
Bit12_Reserved	Bool	8.4
Bit13_AbsoluteValueCyclically	Bool	8.5
Bit14_RequestParkingEncoder	Bool	8.6
Bit15_AcknowledgeError	Bool	8.7
Bit00_Function1Request	Bool	9.0
Bit01_Function2Request	Bool	9.1
Bit02_Function3Request	Bool	9.2
Bit03_Function4Request	Bool	9.3
Bit04_Command0Request	Bool	9.4
Bit05_Command1Request	Bool	9.5
Bit06_Command2Request	Bool	9.6
Bit07_Mode	Bool	9.7

Standard telegram 5: Structure I/O addresses

Table 8-1 Inputs

Element	Data type	Offset
Status word ZSW1	Struct	0.0
Bit08_NoSpeedDeviation	Bool	0.0
Bit09_ControlRequested	Bool	0.1
Bit10_SpeedComparisonValueReachedExeed	Bool	0.2
Bit11_TorqueLimitNotReached	Bool	0.3
Bit12_MotorHoldingBrakeOpen	Bool	0.4
Bit13_NoMotorOvertemperature	Bool	0.5
Bit14_ActualSpeedPositive	Bool	0.6
Bit15_NoPowerUnitOvertemperature	Bool	0.7
Bit00_ReadyToSwitchON	Bool	1.0
Bit01_ReadyToOperate	Bool	1.1
Bit02_OperationEnabled	Bool	1.2
Bit03_FaultPresent	Bool	1.3
Bit04_NoCoastStopActivation	Bool	1.4
Bit05_NoQuickStopActivated	Bool	1.5
Bit06_SwitchingOnInhibited	Bool	1.6
Bit07_AlarmPresent	Bool	1.7
Actual speed value NACT_B	DWord	2.0
Status word ZSW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7
Encoder status word 1	Struct	8.0
Bit08_Probe1Deflected	Bool	8.0
Bit09_Probe2Deflected	Bool	8.1
Bit10_Reserved	Bool	8.2

8.1 Controlling TM Drive via the process image

Element	Data type	Offset
Bit11_EncoderFaultAcknowledgeActive	Bool	8.3
Bit12_HomePositionExecuted	Bool	8.4
Bit13_AbsoluteValueCyclicallyExecuted	Bool	8.5
Bit14_ReservedParkingSensorExecuted	Bool	8.6
Bit15_ParkingSensorExecuted	Bool	8.7
Bit00_Function1Active	Bool	9.0
Bit01_Function2Active	Bool	9.1
Bit02_Function3Active	Bool	9.2
Bit03_Function4Active	Bool	9.3
Bit04_Value1Available	Bool	9.4
Bit05_Value2Available	Bool	9.5
Bit06_Value3Available	Bool	9.6
Bit07_Value4Available	Bool	9.7
Encoder position actual value 1 G1_XIST1	DWord	10.0
Encoder position actual value 2 G1_XIST2	DWord	14.0
Telegram extension word (only with telegram extension)	Struct	18.0
Reserved	Byte	18.0
Telegram extension STO_Status	Bool	19.0
Telegram extension DI_Status	Bool	19.1

Table 8-2 Outputs

Element	Data type	Offset
Control word STW1	Struct	0.0
Bit08_Reserved	Bool	0.0
Bit09_Reserved	Bool	0.1
Bit10_ControlByPlc	Bool	0.2
Bit11_Reserved	Bool	0.3
Bit12_Reserved	Bool	0.4
Bit13_Reserved	Bool	0.5
Bit14_Reserved	Bool	0.6
Bit15_Reserved	Bool	0.7
Bit00_On	Bool	1.0
Bit01_NoCoastStop	Bool	1.1
Bit02_NoQuickStop	Bool	1.2
Bit03_EnableOperation	Bool	1.3
Bit04_EnableRampGenerator	Bool	1.4
Bit05_UnfreezeRampGenerator	Bool	1.5
Bit06_EnableSetpoint	Bool	1.6
Bit07_FaultAcknowledge	Bool	1.7
Speed setpoint NSET_B	DWord	2.0

8.1 Controlling TM Drive via the process image

Element	Data type	Offset
Control word STW2	Struct	6.0
Bit08_Reserved	Bool	6.0
Bit09_Reserved	Bool	6.1
Bit10_Reserved	Bool	6.2
Bit11_Reserved	Bool	6.3
Bit12_Reserved	Bool	6.4
Bit13_Reserved	Bool	6.5
Bit14_Reserved	Bool	6.6
Bit15_Reserved	Bool	6.7
Bit00_Reserved	Bool	7.0
Bit01_Reserved	Bool	7.1
Bit02_Reserved	Bool	7.2
Bit03_Reserved	Bool	7.3
Bit04_Reserved	Bool	7.4
Bit05_Reserved	Bool	7.5
Bit06_Reserved	Bool	7.6
Bit07_Reserved	Bool	7.7
Encoder control word G1_STW	Struct	8.0
Bit08_Reserved	Bool	8.0
Bit09_Reserved	Bool	8.1
Bit10_Reserved	Bool	8.2
Bit11_Reserved	Bool	8.3
Bit12_Reserved	Bool	8.4
Bit13_AbsoluteValueCyclically	Bool	8.5
Bit14_RequestParkingEncoder	Bool	8.6
Bit15_AcknowledgeError	Bool	8.7
Bit00_Function1Request	Bool	9.0
Bit01_Function2Request	Bool	9.1
Bit02_Function3Request	Bool	9.2
Bit03_Function4Request	Bool	9.3
Bit04_Command0Request	Bool	9.4
Bit05_Command1Request	Bool	9.5
Bit06_Command2Request	Bool	9.6
Bit07_Mode	Bool	9.7
XERR positional deviation	DWord	10
Position controller gain KPC	DWord	14

Basic procedure in STEP 7

1. In the project tree, create PLC data types in the CPU 2 with the appropriate structure for your configuration:
 - PLC data type for the structure of the input data (depending on the communication telegram)
 - PLC data type for the structure of the output data (depending on the communication telegram)
2. Create a tag from each type of the PLC data type in a tag table.
3. Assign the addresses for the tag according to the configured I/O addresses of the TM Drive.
4. Control the TM Drive by setting outputs bit-by-bit. A description of how to set the outputs to control the TM Drive can be found in the PROFIdrive standard.
You can find the current PROFIdrive specification under.

8.2 Controlling a TM Drive via the instruction SINA_SPEED

Control with the SINA_SPEED instruction

For controlling the TM Drive, you can also use the SINA-SPEED instruction from the "DriveLib" block library.

The SINA_SPEED block only works with the standard telegram 1. See Communication telegrams.

The "DriveLib" block library can be downloaded from the Internet (<https://support.industry.siemens.com/cs/ww/en/view/109475044>).

See also

Communication telegrams (Page 64)

8.3 Controlling TM Drive with a technology object

Control with a technology object

You can also use a technology object, for example "Speed-controlled axis" or "Positioning axis", to control the TM Drive.

Note that the TM Drive itself does not have integrated positioning functionality and only supports speed operation.

Procedure

1. Create, for example, a "Speed axis" technology object in the CPU in the project tree in STEP 7.
2. Open the technology object.

3. Select "TM Drive" under "Configuration" > "Hardware interface" > "Drive".
4. Reference the technology object in the user program using the Motion Control technology instructions, e.g. "MC-Power".

Note

We do not recommend using the "Encoder calibration at every startup" option in conjunction with positioning technology objects (positioning axis). The calibration process can lead to undesired behavior of the drive axis.

More information

You can find more information about the technology objects and technology instructions in the online help of STEP 7.

Maintenance

Firmware update

A firmware update is possible via PROFINET.

See SIMATIC ET200SP distributed I/O system (<https://support.industry.siemens.com/cs/ww/en/view/58649293>).

Note

After a firmware update, test the parameter assignment (acceptance test – see above) and make any adjustments necessary.

Interrupts, error messages and diagnostics and system alarms

10

10.1 Status and error displays

LED display

The figure below shows the LEDs on the TM Drive.




Figure 10-1 LED display on F-TM StepDrive

Meaning of the LED displays

The following tables contain the meanings of the status and error displays.

10.1 Status and error displays

DIAG LED

Table 10-1 DIAG status and error display

DIAG LED	Meaning	
 Off	Backplane bus supply of the ET 200SP not OK	
 Flashing	Module parameters not assigned	
 On	Module parameters assigned and no module diagnostics	
 Flashing	0.5 Hz (slow)	Module parameters assigned and module diagnostics
	1 Hz (normal)	There is a fault. You can find detailed information via "Online & Diagnostics" > "Diagnostics" > "Active messages" or in the section Active messages (Page 133).
	2 Hz (fast)	

RUN LED

Table 10-2 RUN status and error display

RUN LED	Meaning	
 Off	Device is not yet ready for operation	
 On	Device is ready for operation and error-free	
 Flashing	0.5 Hz (slow)	Device is performing self-test during power-up
	1 Hz (normal)	Device performs a firmware update
	2 Hz (fast)	Device has detected a parameterization error

ERR LED

Table 10-3 ERR status and error display

ERR LED	Meaning
 Off	No fault
 On	Device has a fault and needs to be restarted. This corresponds to a serious device error or the loaded firmware cannot be operated on this device version.

DI LED

Table 10-4 DI status and error display

DI LED	Meaning
 Off	Input is inactive
 On	Input is active

B LED

Table 10-5 B status and error display

B LED	Meaning
 On	The motor holding brake is open / information about the process image was set

STO LED

Table 10-6 STO status and error display

STO LED	Meaning
 On	Drive ready, switch connected correctly and STO not requested
 flashes (0.5 Hz)	STO requested (motor is disconnected from power)

INC LED

Table 10-7 Status and error display INC (encoder)

INC LED	Meaning
 On	Incremental speed encoder was assigned parameters/activated
 Flashes (2 Hz)	Incremental speed encoder has a connection problem (A/B and/or Z track not connected)

24..48V LED

Table 10-8 24..48V status and error display

24..48V LED	Meaning
 Off	DC link voltage outside the configured limits
 On	DC link voltage within the configured limits (is OK)
 flashes (0.5 Hz)	DC link voltage shortly before the interference threshold

PWR LEDs

Table 10-9 PWR status and error display

PWR LED	Meaning
 Off	Logic component supply of the converter is missing
 On	Logic component supply of the converter is OK

10.2 Diagnostics**10.2.1 Diagnostics overview of the TM Drive****Diagnostic view of the CPU and its associated I/O**

If you go online to the CPU and establish an online connection via the CPU to the TM Drive, this occurs within the project context.

Procedure

To display the diagnostic information for the TM Drive, perform these steps.

1. Select the TM Drive in the project tree, for example under "Ungrouped devices":
2. Double-click "Online & diagnostics".
The "Diagnostics - General" window appears.
3. Navigate to the required information.

The diagnostic window is divided into the following diagnostic groups:

- **General**
The general diagnostic information is displayed for:
 - Module
 - Module information
 - Manufacturer information
- **Diagnostics status**
"Diagnostics status" shows the current diagnostics status of the TM Drive.
- **Active messages**
"Active messages" displays the currently pending alarms and faults in the TM Drive module.
- **Drive diagnostics**
The current diagnostic information of the drive is displayed for:
 - Status bits
 - Operating values
 - Encoders
 - Temperatures
 - Inputs

10.2.2 Active messages

Pending faults and alarms

"Active messages" shows the currently pending faults and alarms in the TM Drive. Faults must be acknowledged after the cause has been corrected.

Procedure

To display the active messages, follow these steps:

1. Select the TM Drive in the project tree and go to "Online & diagnostics".
2. In the "Diagnostics" folder, select the "Active messages" area.

Faults and alarms

The TM Drive supports the following faults.

Fault number	Description	S7 diagnostics alarm
1000	Overvoltage in the DC link	Overvoltage
1001	Undervoltage in the DC link	Undervoltage
1003	Shutdown due to overcurrent switch-off of a phase	Overload
1032	Temperature measured values implausible	Error

10.2 Diagnostics

Fault number	Description	S7 diagnostics alarm
1035	Permitted temperature at the motor end stage exceeded	Overtemperature
1042	Fail-safe shutdown path (STO) defective	Safety-related shut-down
1043	Permissible temperature of the motor electronics exceeded	Overtemperature
1045	The connection to the A/B track of the incremental speed encoder is interrupted.	Wire break
1046	The connection to the Z track of the incremental speed encoder is interrupted.	Wire break
1047	An unsupported PROFIdrive speed encoder function was requested.	-
1049	Zero point calibration could not be performed. The rotor may be blocked. The motor holding brake may not be open.	External error
1050	A ramp/quick stop (OFF1/OFF3) could not be performed due to a timeout.	External error
1051	Zero point calibration could not be performed due to a timeout. The system may be oscillating too much.	External error
1052	Multiple step losses were detected.	
1054	Permissible temperature at the motor winding when stepper motor exceeded	Overload
1070	Hardware defect in the power end stage	Error in actuator/sensor
1071	One or more phases of the motor are not properly connected	Wire break
1100	An internal error in the diagnostic module was detected in the area of the fault indications.	-
1300	There is an error in the parameter assignment of the motor type.	Parameterization error
1340	There is an error in the parameter assignment of the encoder.	Parameterization error
1360	There is an error in the parameter assignment of the controller.	Parameterization error
1380	There is an error in the parameter assignment of the braking function.	Parameterization error
1912	Sign-of-life tolerance has been exceeded	Error
1999	General error	Error

Acknowledge faults

To acknowledge all active faults, click the "Acknowledge faults" button.

Alarms

The TM Drive supports the following alarms.

Alarm number	Description
2000	Voltage in the DC link shortly before shutdown
2001	STO shutdown active
2002	Warning threshold when motor end stage temperature is exceeded
2003	Warning threshold when motor winding temperature is exceeded
2004	Thermal overload of the motor end stage
2007	Axis is rotating while it is ready for switching on
2100	An internal error in the diagnostic module was detected in the area of the alarm indications.
35911	Sign-of-life tolerance has been exceeded
36000	Sign-of-life monitoring could not be initialized

10.2.3 Drive diagnostics

You can find online information on important current drive diagnostics data and drive service data in the "Drive diagnostics" area under "Online & diagnostics" in the context of the drive.

Note

All drive diagnostics are only available online. They are automatically updated in the user interface.

You will find diagnostic information on the following points in the "Drive diagnostics" area:

- Status bits
- Operating values
- Encoders
- Temperatures
- Inputs
- Configuration of process data PII

Properties of drive diagnostics

Drive diagnostics

- Show the current values of various parameters
- Are cyclically updated
- Are read-only.

Drive diagnostics: Status bits

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Status bits"

Table 10-10 Drive diagnostics - status bits

Number	Parameter	Display/unit
Status word		
r0899	Status bits Note: Signal corresponds to status word 1 PROFI-drive (r0968).	• Ready for switching on • Ready for operation • Operation • Fault active • Coasting active • Rapid stop active • Switching on inhibited active • Alarm active • Speed setpoint - actual value deviation • Control by controller • n comparison value reached • Control of the motor holding brake is active Note: • Status word 1 is sent cyclically by the drive to the higher-level controller.

Drive diagnostics: Operating values

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Operating values"

Table 10-11 Drive diagnostics - operating values

Number	Parameter	Display/unit
r0063	Speed actual value smoothed	rpm
r0080	Torque actual value	Nm
r1045	Speed setpoint before ramp-function generator	rpm
r0026	DC link voltage	V
r0027	Current actual value	A _{eff}
r0072	Output voltage	V

Note

With a stepper motor and the "controlled (I = const.)" control type, the actual torque value corresponds to the current hold torque.

Drive diagnostics: Encoders

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Encoder"

Table 10-12 Drive diagnostics - encoder

Number	Parameter	Display/unit
r7811	Position	°
r7810[0]	Single-turn steps	-
p979[2]	Increments per revolution	-
p979[3]	Fine resolution bits in actual value Gx_XIST1	Bits

Drive diagnostics: Temperatures

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Temperatures"

Table 10-13 Drive diagnostics -temperatures

Number	Parameter	Display/unit
r0037[0]	Current microcontroller	°C
r0037[1]	Microcontroller max.	
r0037[4]	Power end stage	
r0037[5]	Power end stage max.	

Drive diagnostics: Inputs

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Inputs"

Table 10-14 Drive diagnostics - inputs

Number	Parameter	Display/unit
-	Inputs	- Digital input - STO active

Drive diagnostics: Configuration of the process data extension PII

"Online & diagnostics" > "Diagnostics" > "Drive diagnostics" > "Configuration of process data extension PII"

You can use this dialog box if the process data extension PII is activated (device configuration).

If process data extension PII is activated, three times 2 bytes are transmitted in the process images of the inputs in addition to the telegram data.

10.2 Diagnostics

In this dialog box, you can parameterize which physical variables are transmitted from the module in this address range.

Table 10-15 Drive diagnostics – process data extension PII

Number	Parameter	Value
-	Signal 0	Selection from the table below
-	Signal 1	Selection from the table below
-	Signal 2	Selection from the table below

Enum-index/value	Physical variable	Unit	Value range
0	No selection (default)	-	0...64k
1	DC link voltage	$V \cdot 10^{-1}$	-32k...+32k
2	Setpoint voltage U_dq_set	$V \cdot 10^{-1}$	0...64k
3	Phase current phase U	mA	-32k...+32k
4	Phase current phase V	mA	-32k...+32k
5	Phase current phase W	mA	-32k...+32k
6	Setpoint current d axis I_d_set	mA	-32k...+32k
7	Setpoint current q axis I_q_set	mA	-32k...+32k
8	Actual current d axis I_d_act	mA	-32k...+32k
9	Actual current q axis I_q_act	mA	-32k...+32k
10	DC link current filtered	mA	-32k...+32k
11	Setpoint torque M_set (empty - 0 for stepper motor)	mNm	-32k...+32k
12	Actual torque M_act (empty - 0 for stepper motor)	mNm	-32k...+32k
13	Speed filtered	RPM	-32k...+32k
14	Speed unfiltered	RPM	-32k...+32k
15	Electric rotor angle	DEG	0...64k
16	Mechanical rotor angle	DEG	0...64k

You can make the process variables available using one of the following two options in the TRACE tool of the TIA Portal:

- Create the variables and assign the corresponding address ranges in the PII
- Download the "PII Trace" block from SIOS, import it, and integrate it into your program (assignment via the hardware ID of the drive and linking of the imported data block). All parameters that can be transmitted exist as variables from which the variables parameterized in the drive diagnostics are automatically assigned current values.

Note

The process data extension in the PII can also be parameterized by reading, changing, and writing data set 242. Its structure is described in the relevant SIOS entry for the data sets.

Reference

All displayed parameters have a tooltip that provides you with information and descriptions relating to the parameter as well as access to the online help.

You can find additional information on the parameters in the Product Information (<https://support.industry.siemens.com/cs/ww/en/view/109773204>).

Technical specifications

11.1 Technical specifications

Technical specifications of TM Drive

Article number	6BK1136-6SB01-0BU0
General information	
Product type designation	F-TM StepDrive ST
HW functional status	01
Firmware version	V2.1
• FW update possible	Yes
Product description	control of stepper motors
usable BaseUnits	BU type U0
Product function	
• I&M data	Yes
• Isochronous mode	Yes
• Four-quadrant operation	Yes
• Speed control with encoder	Yes
• Speed control without encoder	No
• Safety Functions	Yes; Drive controller with hardwired STO
Protection function	
• Undervoltage protection	Yes
• Overvoltage protection	Yes
• Overload protection	Yes
• Ground-fault protection	No
• Short-circuit protection	Yes
Installation type/mounting	
Type of ventilation	Convection cooling
Supply voltage	
Design of the power supply	24 ... 48 V DC, SELV / PELV
permissible range, lower limit (DC)	16.8 V
permissible range, upper limit (DC)	57.6 V
Input current	
Current consumption, max.	190 mA
Inrush current, max.	10 A; 40 µs
output voltage / header	
Rated value, min.	24 V
Rated value, max.	48 V
Output current	
Current output (rated value)	5 A

11.1 Technical specifications

Article number	6BK1136-6SB01-0BU0
Output current, max.	10 A
Output frequency	1 500 Hz
Encoder supply	
Number of outputs	1
5 V encoder supply	
• 5 V	Yes
• Short-circuit protection	Yes
• Output current, max.	150 mA
Power	
DC power consumption	300 W; At 50 V
Power loss	
Power loss, typ.	3.5 W
Digital inputs	
Number of digital inputs	1; input for message signal
Number of safety inputs	1; For STO, antivalent (2-pin) - 24 V DC
Encoder	
Connectable encoders	
• Incremental encoder (symmetrical)	Yes; up to 500 Hz per channel
Interrupts/diagnostics/status information	
Alarms	
• Diagnostic alarm	Yes
• Hardware interrupt	No
Diagnoses	
• Monitoring the supply voltage	Yes
• Wire-break	Yes
• Short-circuit	Yes
• Group error	Yes
Diagnostics indication LED	
• RUN LED	Yes
• ERROR LED	Yes
Integrated Functions	
Position detection	
• Incremental acquisition	Yes
• Absolute acquisition	No
• Suitable for S7-1500 Motion Control	Yes
Potential separation	
Potential separation channels	
• between the channels and backplane bus	Yes
Isolation	
Isolation tested with	DC 850 V, type test (between backplane bus, DC input and functional grounding)
Overtoltage category	III
Degree of pollution	2 according to EN 61800-5-1

Article number	6BK1136-6SB01-0BU0
Degree and class of protection	
IP degree of protection	IP20
Standards, approvals, certificates	
CE mark	Yes
UKCA mark	Yes
cULus	Yes
RCM (formerly C-TICK)	Yes
KC approval	Yes
EAC (formerly Gost-R)	Yes
RoHS conformity	Yes
China RoHS compliance	Yes
Standard for EMC according to EN 61800-3	Yes
Standard for drive acc. to EN 61800-5-1	Yes
Standard for drive acc. to EN 61800-5-2	Yes
Highest safety class achievable in safety mode	
Performance level according to ISO 13849-1	Category 3, performance level d, according to EN ISO 13849-1:2015
SIL acc. to IEC 61508	SIL 3
SIL according to DIN EN 61800-5-2	SIL 3
Ambient conditions	
Pollution degree during storage and transport	2
Ambient temperature during operation	
horizontal installation, min.	-30 °C; No condensation, splash water, icing, salt spray or oil mist permitted.
horizontal installation, max.	60 °C; No condensation, splash water, icing, salt spray or oil mist permitted. Note the derating data!
vertical installation, min.	-30 °C; No condensation, splash water, icing, salt spray or oil mist permitted.
vertical installation, max.	50 °C; No condensation, splash water, icing, salt spray or oil mist permitted. Note the derating data!
Ambient temperature during storage/transportation	
Storage, min.	-30 °C
Storage, max.	70 °C
Altitude during operation relating to sea level	
Installation altitude above sea level, max.	3 000 m
Cables	
Cable length for motor, shielded, max.	10 m
Dimensions	
Width	20 mm
Height	73 mm
Depth	58 mm
Weights	
Weight, approx.	55 g
Other	

11.2 Derating of the TM Drive

Article number	6BK1136-6SB01-0BU0
Brake design	holding brake control via the process image
Braking chopper	No

Climatic and mechanical environmental conditions

You can find the climatic and mechanical ambient conditions here SIMATIC ET200SP distributed I/O system (<https://support.industry.siemens.com/cs/ww/en/view/58649293>).

If there are discrepancies between the statements in this document and the system manual, the statements in the this document take priority.

Biological environmental conditions

The standards DIN EN IEC 60721-3-1:2018, DIN EN IEC 60721-3-2:2018, IEC 60721-3-3: Edition 3.0, with the classes 1B1, 2B1 and 3B1 apply for the biological environmental conditions during operation, long-term storage and transport.

Conductive dust and sand

The TM Drive must not be exposed to conductive dust or sand during operation, long-term storage, and transport.

Chemical environmental conditions

The standards DIN EN IEC 60721-3-1:2018, DIN EN IEC 60721-3-2:2018, DIN EN 60721-3-3:1995, with the classes 1C2, 2C2 and 3C2 apply for the chemical environmental conditions during operation, long-term storage and transport.

11.2 Derating of the TM Drive

Maximum permitted output current as a function of installation altitude and ambient temperature

You must take into account the dependency on the ambient temperature and installation altitude.

Derating of the TM Drive depends on the installation elevation

For all permissible mounting types, starting from an installation altitude of 1000 m, a derating of 10% current per additional 1000 m elevation gain applies. In this case, the motor current and the output current of the digital outputs must be reduced.

All other functions do not have to be reduced up to the maximum installation altitude.

The figure below shows the maximum permitted output current as a function of the ambient air temperature for the derating.

Derating of the TM Drive depends on the ambient temperature (horizontal/vertical mounting position)

When mounted horizontally (DIN rail horizontal), the TM Drive can be operated up to the maximum ambient temperature (60 °C). Note the derating curve.

When mounted vertically (DIN rail vertical), the TM Drive may be operated up to a maximum of 50 °C. Note the derating curve.




Figure 11-1 Derating the TM Drive with a stepper motor

Test signal suppression

The STO inputs can be dark tested. The dark test time is up to 1 ms.

11.2 Derating of the TM Drive

Appendix

A.1 Response times

Introduction

Below you can find the response time of the TM Drive in STEP7. The response times of the TM Drive are included in the calculation of the response time of the F-system.

The drive system is the component that provides the safety functions.

Definition of response time

The response time is the time between the detection of an input signal and the change of a linked output signal.

Definition of process safety time of a process

The process safety time of a process is the time between the occurrence of an error within which a process can be left unattended without risk to life and limb of the operating personnel or damage to the environment and the time of the completed reaction.

Any type of F-system control is tolerated within this process safety time, i.e. the F-system can control its processes incorrectly or even not at all. The process safety time of a process depends on the type of process and must be determined on a case-by-case basis.

Check that the process safety time of the process is not exceeded. You may need to reduce the specific monitoring times of the F-system.

Fluctuation width

The actual response time falls between a minimum and maximum response time. You must always assume the maximum response time when configuring your system.

Definition of maximum response time in an error-free scenario (worst case delay time, WCDDT)

In the event of errors outside the drive system (e.g. incorrect setpoint setting by a controller, limit violations due to behavior of the motor, closed-loop control, load, etc.), the "maximum response time in an error-free scenario" is guaranteed.

Definition of maximum response time when an error is present (one fault delay time, OFDDT)

In the event of a single error within the drive system (e.g. defect in a shutdown path of the power unit), the "maximum reaction time in the event of error" is guaranteed.

Times required for the calculation

Function	Maximum response time
STOP_STO via terminal	20 ms

STOP_STO:

With a STOP_STO, the drive safely switches off the torque of the connected motor immediately.

You can find an overview of the data sets for the TM Drive and the structure of the data sets in the Product Information (<https://support.industry.siemens.com/cs/ww/en/view/109773204>).

A.2 Device disposal

Recycling and disposal



For environmentally-friendly recycling and disposal of your old device, please contact a company certified for the disposal of waste electrical and electronic equipment, and dispose of the old device as prescribed in the respective country of use.

Note

The device does not have its own memory. Neither personal data nor project-specific data are stored on it. It is not necessary to reset the memory for data security reasons.

A.3 Directives and standards

Directives and standards that are complied with

TM Drive complies with the requirements of the following directives and standards:



European Machinery Directive

TM Drive meets the requirements of the Machinery Directive, 2006/42/EU through compliance with EN 61800-5-2, insofar as the equipment is used within the area of application of this directive.

TM Drive has been fully evaluated for compliance with the material provisions relating to health and safety in the directive when used in a typical machine application.

European EMC Directive

The compliance of TM Drive with the regulations of Directive 2014/30/EU has been verified through full compliance with EN 61800-3.

Safety Integrated

TM Drive complies with the requirements for functional safety/machine safety.

RoHS

TM Drive complies with Directive 2011/65/EU on the restriction of the use of certain hazardous substances.



Underwriters Laboratories (North American market)

TM Drive equipment bearing any of the test symbols shown to the left complies with the requirements for the North American market as a component of drive applications and is listed accordingly.

- UL file number for DC mains connection: E229808



Eurasian conformity

TM Drive complies with the requirements of the Eurasian Customs Union (EAC).



Australia and New Zealand (RCM formerly C-Tick)

TM Drive equipment bearing the symbol shown complies with the EMC requirements for Australia and New Zealand.



EMC requirements for South Korea

TM Drive equipment bearing the KC symbol on the rating plate complies with the EMC requirements for South Korea.

Certificates for download

- EC declaration of conformity:
- Certificates for the relevant directives, prototype test certificates, manufacturers declarations and test certificates for functions relating to functional safety ("Safety Integrated"): (<https://support.industry.siemens.com/cs/ww/en/ps/26085/cert>)
- Certificates of products that were certified by UL: (<https://iq.ulprospector.com>)

Standards that are not relevant



China Compulsory Certification

TM Drive does not fall within the scope of China Compulsory Certification (CCC).

UKCA - United Kingdom Conformity Assessed



The TM Drive series complies with the conformity requirements for England, Scotland and Wales.

China RoHS

The TM Drive drive series complies with the China RoHS.

You will find more information at:

China RoHS (<https://support.industry.siemens.com/cs/ww/en/ps/26085/cert>)

Index

S

STO hardwired, (see Hardware STO)

More information

SIMOTICS:

www.siemens.com/micro-drive

Industry Mall:

www.siemens.com/industrymall

Industry Online Support:

www.siemens.com/online-support