

SIEMENS

SINUMERIK

SINUMERIK MC NC programming

Programming Manual

Preface

Fundamental safety
instructions

1

Fundamentals

2

Work preparation

3

Tables

4

Appendix

A

Valid for:

Control system
SINUMERIK MC

Software
CNC software version 1.12

06/2019

A5E47437142B AA

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.
--

 WARNING
--

indicates that death or severe personal injury may result if proper precautions are not taken.

 CAUTION
--

indicates that minor personal injury can result if proper precautions are not taken.
--

NOTICE

indicates that property damage can result if proper precautions are not taken.
--

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
--

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.
--

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

SINUMERIK documentation

The SINUMERIK documentation is organized into the following categories:

- General documentation/catalogs
- User documentation
- Manufacturer/service documentation

Additional information

You can find information on the following topics at the following address (<https://support.industry.siemens.com/cs/de/en/view/108464614>):

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

If you have any questions regarding the technical documentation (e.g. suggestions, corrections), please send an e-mail to the following address (<mailto:docu.motioncontrol@siemens.com>).

mySupport/Documentation

At the following address (<https://support.industry.siemens.com/My/ww/en/documentation>), you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation.

Training

At the following address (<http://www.siemens.com/sitrain>), you can find information about SITRAIN (Siemens training on products, systems and solutions for automation and drives).

FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support (<https://support.industry.siemens.com/cs/de/en/ps/fag>).

SINUMERIK

You can find information about SINUMERIK at the following address (<http://www.siemens.com/sinumerik>).

Target group

This publication is intended for:

- Programmers
- Project engineers

Benefits

With the programming manual, the target group can develop, write, test, and debug programs and software user interfaces.

Standard scope

This Programming Manual describes the functionality of the standard scope. Extensions or changes made by the machine tool manufacturer are documented by the machine tool manufacturer.

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

Furthermore, for the sake of clarity, this documentation does not contain all detailed information about all product types and cannot cover every conceivable case of installation, operation or maintenance.

Note regarding the General Data Protection Regulation

Siemens observes standard data protection principles, in particular the principle of privacy by design. That means that

this product does not process / store any personal data, only technical functional data (e.g. time stamps). If a user links this data with other data (e.g. a shift schedule) or stores personal data on the same storage medium (e.g. hard drive) and thus establishes a link to a person or persons, then the user is responsible for ensuring compliance with the relevant data protection regulations.

Technical Support

Country-specific telephone numbers for technical support are provided in the Internet at the following address (<https://support.industry.siemens.com/sc/ww/en/sc/2090>) in the "Contact" area.

Information about the structure and contents of the documentation

The NC programming is described in two manuals:

1. **Fundamentals**

The Programming Manual "Fundamentals" is intended for use by skilled machine operators with the appropriate expertise in drilling, milling and turning operations. Simple programming examples are used to explain the commands and statements, which are also defined according to DIN 66025.

2. **Work preparation**

The Programming Manual "Advanced" is intended for use by technicians with in-depth, comprehensive programming knowledge. By virtue of a special programming language, the SINUMERIK control enables the user to program complex workpiece programs (e.g. for free-form surfaces, channel coordination, ...), and makes the programming of complicated operations easier for technologists.

Table of contents

	Preface	3
1	Fundamental safety instructions	23
1.1	General safety instructions	23
1.2	Warranty and liability for application examples	24
1.3	Industrial security	25
2	Fundamentals	27
2.1	Fundamental Geometrical Principles	27
2.1.1	Workpiece positions	27
2.1.1.1	Reference system of position specifications	27
2.1.1.2	Cartesian coordinates	27
2.1.1.3	Polar coordinates	30
2.1.1.4	Absolute dimensions	31
2.1.1.5	Incremental dimension	33
2.1.2	Working planes	34
2.1.3	Zero points and reference points	35
2.1.4	Coordinate systems	37
2.1.4.1	Machine coordinate system (MCS)	37
2.1.4.2	Basic coordinate system (BCS)	39
2.1.4.3	Basic zero system (BZS)	41
2.1.4.4	Settable zero system (SZS)	42
2.1.4.5	Workpiece coordinate system (WCS)	43
2.1.4.6	What is the relationship between the various coordinate systems?	43
2.2	Fundamental Principles of NC Programming	44
2.2.1	Name of an NC program	44
2.2.2	Structure and contents of an NC program	45
2.2.2.1	Blocks and block components	45
2.2.2.2	Block rules	48
2.2.2.3	Value assignments	49
2.2.2.4	Comments	49
2.2.2.5	Skipping blocks	50
2.3	Creating an NC program	52
2.3.1	Basic procedure	52
2.3.2	Available characters	53
2.3.3	Program header	54
2.3.4	Program examples	55
2.3.4.1	Example 1: First programming steps	55
2.3.4.2	Example 2: NC program for turning	56
2.3.4.3	Example 3: NC program for milling	58
2.4	Tool change	62
2.4.1	Tool change with T command	62
2.4.2	Tool change with M6	64
2.4.3	Tool change with tool management (option)	65

2.4.3.1	Tool change with T command with active tool management (option)	65
2.4.3.2	Tool change with M6 with active tool management (option)	67
2.4.4	Behavior with faulty T programming	69
2.5	Tool offsets	70
2.5.1	Programmed contour and tool path	70
2.5.2	Tool length compensation	70
2.5.3	Tool radius compensation	71
2.5.4	Tool compensation memory	72
2.5.5	Tool types	73
2.5.5.1	Tool type number and tool groups	73
2.5.5.2	Milling tools	74
2.5.5.3	Drills	76
2.5.5.4	Grinding tools	77
2.5.5.5	Turning tools	79
2.5.5.6	Special tools	81
2.5.6	Tool offset call (D)	83
2.5.7	Change in the tool offset data	85
2.5.8	Programmable tool offset (TOFFL, TOFF, TOFFR, TOFFLR)	85
2.6	Spindle motion	91
2.6.1	Spindle speed (S), spindle direction of rotation (M3, M4, M5)	91
2.6.2	Tool cutting speed (SVC)	94
2.6.3	Constant cutting rate (G96/G961/G962, G97/G971/G972, G973, LIMS, SCC)	100
2.6.4	Switching constant grinding wheel peripheral speed (GWPSON, GWPSOF) on/off	105
2.6.5	Programmable spindle speed limitation (G25, G26)	106
2.7	Feed control	107
2.7.1	Feedrate (G93, G94, G95, F, FGROU, FL, FGREF)	107
2.7.2	Traverse positioning axes (POS, POSA, POSP, FA, WAITP, WAITMC)	115
2.7.3	Position-controlled spindle mode (SPCON, SPCOF)	118
2.7.4	Positioning spindles (SPOS, SPOSA, M19, M70, WAITS)	119
2.7.5	Feedrate for positioning axes / spindles (FA, FPR, FPRAON, FPRAOF)	124
2.7.6	Programmable feedrate override (OVR, OVRRAP, OVRA)	127
2.7.7	Programmable acceleration compensation (ACC)	128
2.7.8	Feedrate with handwheel override (FD, FDA)	130
2.7.9	Feedrate optimization for curved path sections (CFTCP, CFC, CFIN)	133
2.7.10	Several feedrate values in one block (F, ST, SR, FMA, STA, SRA)	136
2.7.11	Non-modal feedrate (FB)	139
2.7.12	Tooth feedrate (G95 FZ)	140
2.8	Geometry settings	146
2.8.1	Settable zero offset (G54 to G57, G505 to G599, G53, G500, SUPA, G153)	146
2.8.2	Settable work offset (G54 to G57, G505 to G599, G53, G500, SUPA, G153): Further information	147
2.8.3	Selection of the working plane (G17/G18/G19)	148
2.8.4	Dimensions	151
2.8.4.1	Absolute dimensions (G90, AC)	151
2.8.4.2	Incremental dimensions (G91, IC)	154
2.8.4.3	Absolute and incremental dimensions for turning and milling (G90/G91)	157
2.8.4.4	Absolute dimensions for rotary axes (DC, ACP, ACN)	158
2.8.4.5	Metric/inch dimension system (G70/G71, G700/G710)	160
2.8.4.6	Channel-specific diameter/radius programming (DIAMON, DIAM90, DIAMOF, DIAMCYCOF)	164

2.8.4.7	Axis-specific diameter/radius programming (DIAMONA, DIAM90A, DIAMOFA, DIACYCOFA, DIAMCHANA, DIAMCHAN, DAC, DIC, RAC, RIC).....	166
2.8.5	Position of workpiece for turning	170
2.9	Motion commands.....	172
2.9.1	General information about the travel commands	172
2.9.2	Travel commands with Cartesian coordinates (G0, G1, G2, G3, X..., Y..., Z...).....	173
2.9.3	Travel commands with polar coordinates.....	175
2.9.3.1	Reference point of the polar coordinates (G110, G111, G112)	175
2.9.3.2	Travel commands with polar coordinates (G0, G1, G2, G3, AP, RP)	176
2.9.4	Rapid traverse movements	180
2.9.4.1	Activating rapid traverse (G0)	180
2.9.4.2	Switch on/off linear interpolation for rapid traverse movements (RTLION, RTLIOf)	182
2.9.4.3	Adjust relative G0 tolerance (STOLF)	183
2.9.5	Linear interpolation (G1)	186
2.9.6	Circular interpolation	188
2.9.6.1	Overview	188
2.9.6.2	Circular interpolation with center point and end point (G2/G3, X... Y... Z..., I... J... K...)	189
2.9.6.3	Circular interpolation with radius and end point (G2/G3, X... Y... Z..., CR)	192
2.9.6.4	Circular interpolation with opening angle and end point / center point (G2/G3, X... Y... Z... / I... J... K..., AR).....	194
2.9.6.5	Circular interpolation with polar coordinates (G2/G3, AP, RP)	196
2.9.6.6	Circular interpolation with intermediate point and end point (CIP, X... Y... Z..., I1... J1... K1...).....	198
2.9.6.7	Circular interpolation with tangential transition (CT, X... Y... Z...)	200
2.9.7	Helical interpolation (G2/G3, TURN).....	204
2.9.8	Contour definitions	206
2.9.8.1	Contour definition programming.....	206
2.9.8.2	Contour definitions: One straight line	207
2.9.8.3	Contour definitions: Two straight lines	209
2.9.8.4	Contour definitions: Three straight lines.....	212
2.9.8.5	Contour definitions: End point programming with angle.....	215
2.9.9	Thread cutting	216
2.9.9.1	Thread cutting with constant lead (G33, SF).....	216
2.9.9.2	Thread cutting with increasing or decreasing lead (G34, G35).....	222
2.9.9.3	Programmed run-in and run-out path for G33, G34 and G35 (DITS, DITE)	224
2.9.9.4	Fast retraction during thread cutting (LFON, LFOF, DILF, ALF, LFTXT, LFWP, LFPOS, POLF, POLFMASK, POLFMLIN)	226
2.9.9.5	Convex thread (G335, G336).....	229
2.9.10	Tapping without compensating chuck.....	235
2.9.10.1	Tapping without compensating chuck and retraction motion (G331, G332)	235
2.9.10.2	Example: Tapping with G331 / G332	236
2.9.10.3	Example: Output the programmed drilling speed in the current gear stage.....	236
2.9.10.4	Example: Application of the second gear-stage data block	237
2.9.10.5	Example: Speed is not programmed, the gearbox stage is monitored	237
2.9.10.6	Example: Gearbox stage cannot be changed, gearbox stage monitoring	238
2.9.10.7	Example: Programming without SPOS	238
2.9.11	Tapping with compensating chuck	239
2.9.11.1	Tapping with compensating check and retraction motion (G63)	239
2.9.12	Chamfer, rounding (CHF, CHR, RND, RNDM, FRC, FRCM)	240
2.10	Tool radius compensation	246
2.10.1	Tool radius compensation (G40, G41, G42, OFFN)	246

2.10.2	Approaching and leaving contour (NORM, KONT, KONTC, KONTT)	255
2.10.3	Compensation at the outside corners (G450, G451, DISC).....	263
2.10.4	Smooth approach and retraction.....	266
2.10.4.1	Approach and retraction (G140 to G143, G147, G148, G247, G248, G347, G348, G340, G341, DISR, DISCL, DISRP, FAD, PM, PR)	266
2.10.4.2	Approach and retraction with extended retraction strategies (G460, G461, G462)	277
2.10.5	Activation/deactivation of collision detection ("bottleneck detection") (CDON, CDOF, CDOF2).....	280
2.10.6	2 1/2 D tool offset (CUT2D, CUT2DD, CUT2DF, CUT2DFD)	282
2.10.7	Keep tool radius compensation constant (CUTCONON, CUTCONOF).....	284
2.10.8	Tools with a relevant cutting edge position	286
2.11	Path action	288
2.11.1	Exact stop (G60, G9, G601, G602, G603).....	288
2.11.2	Continuous-path mode (G64, G641, G642, G643, G644, G645, ADIS, ADISPOS)	290
2.12	Coordinate transformations (frames)	300
2.12.1	Frames	300
2.12.2	Frame instructions.....	302
2.12.3	Programmable work offset (TRANS, ATRANS)	305
2.12.4	Programmable work offset (G58, G59)	309
2.12.5	Programmable rotation (ROT, AROT, RPL).....	311
2.12.6	Programmable frame rotations with solid angles (ROTS, AROTS, CROTS).....	317
2.12.7	Programmable scaling factor (SCALE, ASCALE)	320
2.12.8	Programmable mirroring (MIRROR, AMIRROR)	323
2.12.9	Frame generation according to tool orientation (TOFRAME, TOROT, PAROT):.....	328
2.12.10	Deselect frame (G53, G153, SUPA, G500)	330
2.12.11	Programming: Deselecting overlays axis-specifically (CORROF)	331
2.12.12	Deselecting additive work offsets (DRFROF)	334
2.12.13	Grinding-specific work offsets (GFRAME0, GFRAME1 ... GFRAME100).....	335
2.13	Auxiliary function outputs	337
2.13.1	M functions.....	339
2.14	Supplementary commands	343
2.14.1	Output messages (MSG)	343
2.14.2	Writing string in OPI variable (WRTPR).....	344
2.14.3	Working area limitation.....	346
2.14.3.1	Working area limitation in BCS (G25/G26, WALIMON, WALIMOF)	346
2.14.3.2	Working area limitation in WCS/SZS (WALCS0 ... WALCS10)	349
2.14.4	Reference point approach (G74).....	352
2.14.5	Approaching a fixed point (G75)	353
2.14.6	Travel to fixed stop (FXS, FXST, FXSW).....	358
2.14.7	Dwell time (G4)	362
2.14.8	Internal preprocessing stop.....	364
2.15	Other information	365
2.15.1	Axes	365
2.15.1.1	Axes (overview).....	365
2.15.1.2	Main axes/Geometry axes	365
2.15.1.3	Special axes.....	366
2.15.1.4	Main spindle, master spindle.....	367
2.15.1.5	Machine axes.....	367
2.15.1.6	Channel axes	368
2.15.1.7	Path axes	368

2.15.1.8	Positioning axes	368
2.15.1.9	Synchronized axes	369
2.15.1.10	Command axes	369
2.15.1.11	PLC axes	370
2.15.2	From travel command to machine movement	370
2.15.3	Path calculation	370
2.15.4	Addresses	371
2.15.5	Names	373
2.15.6	Constants	375
2.15.7	Operators and arithmetic functions	377
3	Work preparation	381
3.1	Flexible NC programming	381
3.1.1	Variables	381
3.1.1.1	System data	382
3.1.1.2	Predefined user variables: Channel-specific arithmetic parameters (R)	384
3.1.1.3	Predefined user variables: Global arithmetic parameters (RG)	385
3.1.1.4	Definition of user variables (DEF)	387
3.1.1.5	Redefinition of system data, user data, and NC commands (REDEF)	392
3.1.1.6	Attribute: Initialization value	396
3.1.1.7	Attribute: Limit values (LLI, ULI)	398
3.1.1.8	Attribute: Physical unit (PHU)	400
3.1.1.9	Attribute: Access rights (APR, APW, APRP, APWP, APRB, APWB)	402
3.1.1.10	Overview of definable and redefinable attributes	406
3.1.1.11	Definition and initialization of array variables (DEF, SET, REP)	407
3.1.1.12	Definition and initialization of array variables (DEF, SET, REP): Further Information	412
3.1.1.13	Data types	413
3.1.1.14	Variable minimum, maximum and range (MINVAL, MAXVAL and BOUND)	414
3.1.1.15	Check availability of a variable (ISVAR)	415
3.1.1.16	Reading attribute values / data type (GETVARPHU, GETVARAP, GETVARLIM, GETVARDIM, GETVARDFT, GETVARTYP)	417
3.1.1.17	Possible type conversions	422
3.1.2	Indirect programming	423
3.1.2.1	Indirectly programming addresses	423
3.1.2.2	Indirectly programming G commands	425
3.1.2.3	Indirectly programming position attributes (GP)	427
3.1.2.4	Indirectly programming part program lines (EXECSTRING)	429
3.1.3	Instructions	430
3.1.3.1	Arithmetic functions	430
3.1.3.2	Comparison and logic operations	432
3.1.3.3	Priority of the operations	434
3.1.3.4	Precision correction on comparison errors (TRUNC)	435
3.1.3.5	Roundup (ROUNDUP)	436
3.1.4	String operations	437
3.1.4.1	Type conversion to STRING (AXSTRING)	438
3.1.4.2	Type conversion from STRING (NUMBER, ISNUMBER, AXNAME)	438
3.1.4.3	Concatenation of strings (<<)	439
3.1.4.4	Conversion to lower/upper case letters (TOWER, TOWER)	441
3.1.4.5	Determine length of string (STRLEN)	441
3.1.4.6	Search for character/string in the string (INDEX, RINDEX, MINDEX, MATCH)	442
3.1.4.7	Selection of a substring (SUBSTR)	443
3.1.4.8	Reading and writing of individual characters	444

3.1.4.9	Formatting a string (SPRINT).....	445
3.1.5	Program jumps and branches.....	453
3.1.5.1	Return jump to the start of the program (GOTOS).....	453
3.1.5.2	Program jumps to jump markers (GOTOB, GOTOF, GOTO, GOTOC).....	454
3.1.5.3	Program branch (CASE ... OF ... DEFAULT ...)	457
3.1.6	Repeat program section (REPEAT, REPEATB, ENDLABEL, P).....	458
3.1.7	Check structures.....	464
3.1.7.1	Conditional statement and branch (IF, ELSE, ENDIF).....	466
3.1.7.2	Continuous program loop (LOOP, ENDLOOP).....	467
3.1.7.3	Count loop (FOR ... TO ..., ENDFOR).....	468
3.1.7.4	Program loop with condition at start of loop (WHILE, ENDWHILE).....	469
3.1.7.5	Program loop with condition at the end of the loop (REPEAT, UNTIL).....	470
3.1.7.6	Program example with nested check structures.....	471
3.1.8	Cross-channel program coordination (INIT, START, WAITM, WAITMC, WAITE, SETM, CLEARM).....	471
3.1.9	Macro technique (DEFINE ... AS).....	477
3.2	Subprogram technique.....	480
3.2.1	General information.....	480
3.2.1.1	Subprogram.....	480
3.2.1.2	Subprogram names.....	481
3.2.1.3	Nesting of subprograms.....	482
3.2.1.4	Search path.....	483
3.2.1.5	Formal and actual parameters.....	483
3.2.1.6	Parameter transfer.....	484
3.2.2	Definition of a subprogram.....	486
3.2.2.1	Subprogram without parameter transfer.....	486
3.2.2.2	Subprogram with call-by-value parameter transfer (PROC).....	486
3.2.2.3	Subprogram with call-by-reference parameter transfer (PROC, VAR).....	488
3.2.2.4	Save modal G functions (SAVE).....	490
3.2.2.5	Suppress single block execution (SBLOF, SBLON).....	491
3.2.2.6	Suppress current block display (DISPLOF, DISPLON, ACTBLOCNO).....	497
3.2.2.7	Identifying subprograms with preparation (PREPRO).....	500
3.2.2.8	Subprogram return M17.....	500
3.2.2.9	RET subprogram return.....	501
3.2.2.10	Parameterizable subprogram return jump (RET ...)	502
3.2.2.11	Parameterizable subprogram return jump (RETB ...)	508
3.2.3	Subprogram call.....	512
3.2.3.1	Subprogram call without parameter transfer.....	512
3.2.3.2	Subprogram call with parameter transfer (EXTERN).....	514
3.2.3.3	Number of program repetitions (P).....	516
3.2.3.4	Modal subprogram call (MCALL).....	517
3.2.3.5	Indirect subprogram call (CALL).....	519
3.2.3.6	Indirect subprogram call with specification of the calling program part (CALL BLOCK ... TO ...)	520
3.2.3.7	Indirect call of a program programmed in ISO language (ISOCALL).....	521
3.2.3.8	Call subprogram with path specification and parameters (PCALL).....	522
3.2.3.9	Extend search path for subprogram calls (CALLPATH).....	523
3.2.3.10	Execute external subroutine (EXTCALL).....	524
3.3	Interrupt routine (ASUB).....	528
3.3.1	Function of an interrupt routine.....	528
3.3.2	Creating an interrupt routine.....	529

3.3.3	Assign and start interrupt routine (SETINT, PRIO, BLSYNC).....	530
3.3.4	Deactivating/reactivating the assignment of an interrupt routine (DISABLE, ENABLE).....	532
3.3.5	Delete assignment of interrupt routine (CLRINT).....	532
3.3.6	Fast retraction from the contour (SETINT LIFTFAST, ALF).....	533
3.3.7	Traversing direction for fast retraction from the contour	535
3.3.8	Motion sequence for interrupt routines.....	538
3.4	File and Program Management.....	540
3.4.1	Program memory	540
3.4.1.1	Program memory in the NCK.....	540
3.4.1.2	External program memory.....	542
3.4.1.3	Addressing program memory files	544
3.4.1.4	Search path for subprogram call.....	548
3.4.1.5	Interrogating the path and file name	549
3.4.2	Working memory (CHANDATA, COMPLETE, INITIAL).....	550
3.5	File handling.....	554
3.5.1	Write file (WRITE)	554
3.5.2	Delete file (DELETE).....	557
3.5.3	Read lines in the file (READ)	558
3.5.4	Check for presence of file (ISFILE).....	560
3.5.5	Read out file information (FILEDATE, FILETIME, FILESIZE, FILESTAT, FILEINFO).....	561
3.6	Protection zones	564
3.6.1	Defining protection zones (CPROTDEF, NPROTDEF).....	564
3.6.2	Activating/deactivating protection zones (CPROT, NPROT)	567
3.6.3	Checking for protection zone violation, working area limitation and software limit switches (CALCPOSI).....	571
3.7	Special motion commands	581
3.7.1	Approaching coded positions (CAC, CIC, CDC, CACP, CACN).....	581
3.7.2	Activating/deactivating NC block compression (COMPON, COMPCURV, COMPCAD, COMPSURF, COMPOF).....	582
3.7.3	Polynomial interpolation (POLY, POLYPATH, PO, PL)	583
3.7.4	Settable path reference (SPATH, UPATH)	588
3.7.5	Channel-specific measuring (MEAS, MEAW)	590
3.7.6	Axis-specific measurement (MEASA, MEAWA, MEAC) (option)	592
3.7.7	Special functions for OEM users (OMA1 ... OMA5, OEMIPO1, OEMIPO2, G810 ... G829)....	601
3.7.8	Feedrate reduction with corner deceleration (FENDNORM, G62, G621)	602
3.7.9	Programmable end of motion criteria (FINEA, COARSEA, IPOENDA, IPOBRKA, ADISPOSA).....	603
3.8	Coordinate transformations (frames)	606
3.8.1	Coordinate transformation via frame variables	606
3.8.1.1	Predefined frame variable (\$P_CHBFRAME, \$P_IFRAME, \$P_PFRAME, \$P_ACTFRAME)	608
3.8.2	Value assignments to frames.....	611
3.8.2.1	Assigning direct values (axis value, angle, scale).....	611
3.8.2.2	Reading and changing frame components (TR, FI, RT, SC, MI)	613
3.8.2.3	Calculating with frames	614
3.8.2.4	Definition of frame variables (DEF FRAME)	616
3.8.3	Coarse and fine offsets (CTRANS, CFINE)	617
3.8.4	External zero offset (\$AA_ETRANS).....	618
3.8.5	Set actual value with loss of the referencing status (PRESETON).....	619
3.8.6	Set actual value without loss of the referencing status (PRESETONS).....	621

3.8.7	Frame calculation from three measuring points in space (MEAFRAME).....	622
3.8.8	Global frames.....	626
3.8.8.1	Channel-specific frames (\$P_CHBFR, \$P_UBFR).....	627
3.8.8.2	Frames active in the channel.....	627
3.9	Transformations.....	632
3.9.1	General programming of transformation types.....	632
3.9.1.1	General programming of transformation types.....	632
3.9.1.2	Orientation movements for transformations.....	634
3.9.1.3	Overview of orientation transformation TRAORI.....	637
3.9.2	Three, four and five axis transformation (TRAORI).....	639
3.9.2.1	General relationships of universal tool head.....	639
3.9.2.2	Three, four and five axis transformation (TRAORI).....	642
3.9.2.3	Variants of orientation programming and initial setting (ORIRESET).....	643
3.9.2.4	Programming the tool orientation (A..., B..., C..., LEAD, TILT).....	645
3.9.2.5	Face milling (A4, B4, C4, A5, B5, C5).....	651
3.9.2.6	Reference of the orientation axes (ORIWKS, ORIMKS):.....	652
3.9.2.7	Programming orientation axes (ORIAxes, ORIVect, ORIEuler, ORIRPY, ORIRPY2, ORIVIRT1, ORIVIRT2).....	654
3.9.2.8	Orientation programming along the peripheral surface of a taper (ORIPLANE, ORICONCW, ORICONCCW, ORICONTO, ORICONIO).....	656
3.9.2.9	Specification of orientation for two contact points (ORICURVE, PO[XH]=, PO[YH]=, PO[ZH]=).....	659
3.9.3	Orientation polynomials (PO[angle], PO[coordinate]).....	661
3.9.4	Rotations of the tool orientation (ORIROTA, ORIROTR, ORIROTT, ORIROTC, THETA).....	663
3.9.5	Orientations relative to the path.....	665
3.9.5.1	Orientation types relative to the path.....	665
3.9.5.2	Rotation of the tool orientation relative to the path (ORIPATH, ORIPATHS, angle of rotation).....	667
3.9.5.3	Interpolation of the tool rotation relative to the path (ORIROTC, THETA).....	668
3.9.5.4	Smoothing of orientation characteristic (ORIPATHS A8=, B8=, C8=).....	670
3.9.6	Compression of the orientation (COMPON, COMPCURV, COMPCAD, COMPSURF).....	671
3.9.7	Activating/deactivating the orientation characteristic (ORISON, ORISOF).....	674
3.9.8	Kinematic transformation.....	675
3.9.8.1	Activate face end transformation (TRANSMIT).....	675
3.9.8.2	Activate cylinder surface transformation (TRACYL).....	675
3.9.8.3	Oblique plunge-cutting on grinding machines (G5, G7).....	678
3.9.9	Cartesian PTP travel.....	680
3.9.9.1	Activating/deactivating Cartesian PTP travel (PTP, PTPG0, PTPWOC, CP).....	680
3.9.9.2	Specify the position of the joints (STAT).....	681
3.9.9.3	Specify the sign of the axis angle (TU).....	685
3.9.9.4	Example 1: PTP travel of a 6-axis robot with ROBX transformation.....	688
3.9.9.5	Example 2: PTP travel for generic 5-axis transformation.....	689
3.9.9.6	Example 3: PTPG0 and TRANSMIT.....	690
3.9.10	Constraints when selecting a transformation.....	691
3.9.11	Deselecting a transformation (TRAFOOF).....	692
3.10	Kinematic chains.....	694
3.10.1	Deletion of components (DELOBJ).....	694
3.10.2	Index determination by means of names (NAMETOINT).....	697
3.11	Collision avoidance with kinematic chains.....	698
3.11.1	Check for collision pair (COLLPAIR).....	698
3.11.2	Request recalculation of the machine model of the collision avoidance (PROTA).....	699

3.11.3	Setting the protection zone status (PROTS)	700
3.11.4	Determining the clearance of two protection zones (PROTD)	700
3.12	Transformation with kinematic chains	703
3.12.1	Activating a transformation (TRAFOON).....	703
3.12.2	Modifying the orientation transformation after the machine measurement (CORRTRAFO)	704
3.13	Tool offsets.....	712
3.13.1	Offset memory.....	712
3.13.2	Additive offsets	714
3.13.2.1	Selecting additive offsets (DL)	714
3.13.2.2	Specify wear and setup values (\$TC_SCPxy[t,d], \$TC_ECPxy[t,d]).....	716
3.13.2.3	Delete additive offsets (DELDL).....	716
3.13.3	Special handling of tool offsets	717
3.13.3.1	Mirroring of tool lengths.....	719
3.13.3.2	Wear sign evaluation.....	719
3.13.3.3	Coordinate system of the active machining operation (TOWSTD, TOWMCS, TOWWCS, TOWBCS, TOWTCS, TOWKCS).....	720
3.13.3.4	Tool length and plane change	723
3.13.4	Online tool offset	724
3.13.4.1	Defining a polynomial function (FCTDEF).....	724
3.13.4.2	Write online tool offset continuously (PUTFTOCF)	725
3.13.4.3	Write online tool offset, discrete (PUTFTOC).....	726
3.13.4.4	Activate/deactivate online tool offset (FTOCON/FTOCOF)	727
3.13.5	Tool orientation (ORIC, ORID, OSOF, OSC, OSS, OSSE, ORIS, OSD, OST)	728
3.13.6	Free assignment of D numbers, cutting edge numbers	734
3.13.6.1	Free assignment of D numbers, cutting edge numbers (CE address)	734
3.13.6.2	Free assignment of D numbers: Checking D numbers (CHKDNO)	734
3.13.6.3	Free assignment of D numbers: Rename D numbers (GETDNO, SETDNO).....	734
3.13.6.4	Free assignment of D numbers: Determine T number to the specified D number (GETACTTD)	735
3.13.6.5	Free assignment of D numbers: Invalidate D numbers (DZERO).....	736
3.13.7	Toolholder kinematics	736
3.13.8	Tool length compensation for orientable toolholders (TCARR, TCOABS, TCOFR, TCOFRX, TCOFRY, TCOFRZ).....	742
3.13.9	Modifying the orientable tool carrier according to the machine measurement (CORRTC)....	744
3.13.10	Online tool length compensation (TOFFON, TOFFOF)	747
3.13.11	Modification of the offset data for rotatable tools	750
3.13.11.1	Calculating orientations (ORISOLH)	750
3.13.11.2	Activating the modification of the offset data for rotatable tools (CUTMOD, CUTMODK)....	759
3.13.12	Working with tool environments	766
3.13.12.1	Save tool environment (TOOLENV).....	766
3.13.12.2	Delete tool environment (DELTOOLENV).....	769
3.13.12.3	Read T, D and DL number (GETTENV).....	770
3.13.12.4	Read information about the saved tool environments (\$P_TOOLENVN, (\$P_TOOLENV)....	771
3.13.12.5	Read tool lengths and/or tool length components (GETTCOR).....	771
3.13.12.6	Change tool components (SETTCOR).....	777
3.13.13	Read the assignment of the tool lengths L1, L2, L3 to the coordinate axes (LENTOAX)	789
3.14	Path traversing behavior	793
3.14.1	Feedrate characteristic (FNORM, FLIN, FCUB, FPO)	793
3.14.2	Acceleration behavior.....	798
3.14.2.1	Acceleration mode (BRISK, BRISKA, SOFT, SOFTA, DRIVE, DRIVEA).....	798

3.14.2.2	Influence of acceleration on following axes (VELOLIMA, ACCLIMA, JERKLIMA).....	800
3.14.2.3	Activation of technology-specific dynamic values (DYNNORM, DYNPOS, DYNROUGH, DYNSEMIFIN, DYNFINISH, DYNPREC).....	801
3.14.3	Traversing with feedforward control (FFWON, FFWOF).....	803
3.14.4	Programmable contour accuracy (CPRECON, CPRECOF).....	804
3.14.5	Program sequence with preprocessing memory (STOPFIFO, STARTFIFO, FIFOCTRL, STOPRE).....	805
3.14.6	Defining a stop delay range (DELAYFSTON, DELAYFSTOF).....	808
3.14.7	Prevent program position for SERUPRO (IPTRLOCK, IPTRUNLOCK).....	810
3.14.8	Repositioning to the contour (REPOSA, REPOSL, REPOSQ, REPOSQA, REPOSH, REPOSHA, DISR, DISPR, RMIBL, RMBBL, RMEBL, RMNBL).....	812
3.14.9	Influencing the motion control.....	820
3.14.9.1	Percentage jerk correction (JERKLIM).....	820
3.14.9.2	Percentage velocity correction (VELOLIM).....	821
3.14.9.3	Program example for JERKLIM and VELOLIM.....	823
3.14.10	Programming contour/orientation tolerance (CTOL, OTOL, ATOL).....	823
3.14.11	Block change behavior with active coupling (CPBC).....	827
3.15	Axis functions.....	829
3.15.1	Axis replacement, spindle replacement (RELEASE, GET, GETD).....	829
3.15.2	Transfer axis to another channel (AXTOCHAN).....	833
3.15.3	Axis functions (AXNAME, AX, SPI, AXTOSPI, ISAXIS, AXSTRING, MODAXVAL).....	834
3.15.4	Replaceable geometry axes (GEOAX).....	836
3.15.5	Wait for valid axis position (WAITENC).....	841
3.15.6	Programmable parameter set changeover (SCPARA).....	842
3.16	Axis couplings.....	844
3.16.1	Coupled motion (TRAILON, TRAILOF).....	844
3.16.2	Curve tables (CTAB).....	848
3.16.2.1	Define curve tables (CTABDEF, CATBEND).....	848
3.16.2.2	Check for presence of curve table (CTABEXISTS).....	854
3.16.2.3	Delete curve tables (CTABDEL).....	855
3.16.2.4	Locking curve tables to prevent deletion and overwriting (CTABLOCK, CTABUNLOCK)....	856
3.16.2.5	Curve tables: Determine table properties (CTABID, CTABISLOCK, CTABMEMTYP, CTABPERIOD).....	857
3.16.2.6	Read curve table values (CTABTSV, CTABTEV, CTABTSP, CTABTEP, CTABSSV, CTABSEV, CTAB, CTABINV, CTABTMIN, CTABTMAX).....	858
3.16.2.7	Curve tables: Check use of resources (CTABNO, CTABNOMEM, CTABFNO, CTABSEGID, CTABSEG, CTABFSEG, CTABMSEG, CTABPOLID, CTABPOL, CTABFPOL, CTABMPOL).....	863
3.16.3	Axial master value coupling (LEADON, LEADOF).....	864
3.16.4	Electronic gear (EG).....	870
3.16.4.1	Defining an electronic gear (EGDEF).....	870
3.16.4.2	Switch-in the electronic gearbox (EGON, EGONSYN, EGONSYNE).....	871
3.16.4.3	Switching-in the electronic gearbox (EGOFS, EGOFC).....	874
3.16.4.4	Deleting the definition of an electronic gear (EGDEL).....	875
3.16.4.5	Rotational feedrate (G95) / electronic gear (FPR).....	875
3.16.5	Synchronous spindle.....	876
3.16.5.1	Synchronous spindle: Programming (COUPDEF, COUPDEL, COUPON, COUPONC, COUPOF, COUPOFS, COUPRES, WAITC).....	876
3.16.6	Generic coupling (CP...).....	886
3.16.7	Tangential control.....	893
3.16.7.1	Defining coupling (TANG).....	893

3.16.7.2	Activating intermediate block generation (TLIFT)	895
3.16.7.3	Activating the coupling (TANGON)	896
3.16.7.4	Deactivating the coupling (TANGOF).....	898
3.16.7.5	Deleting a coupling (TANGDEL)	898
3.16.8	Master/slave coupling (MASLDEF, MASLDEL, MASLON, MASLOF, MASLOFS)	900
3.17	Synchronized actions	902
3.17.1	Brief description	902
3.17.2	Definition of a synchronized action	903
3.17.3	Components of synchronized actions	905
3.17.3.1	Validity, identification number (ID, IDS)	905
3.17.3.2	Frequency (WHENEVER, FROM, WHEN, EVERY)	906
3.17.3.3	G command (condition).....	907
3.17.3.4	Condition	908
3.17.3.5	G command (action).....	908
3.17.3.6	Actions with condition fulfilled (DO).....	909
3.17.3.7	Actions with condition unfulfilled (ELSE).....	909
3.17.4	System variables for synchronized actions	910
3.17.4.1	Reading and writing	911
3.17.4.2	Operators and arithmetic functions	911
3.17.4.3	Type conversions	914
3.17.4.4	Marker/counter (\$AC_MARKER)	915
3.17.4.5	Parameters (\$AC_PARAM).....	916
3.17.4.6	R parameters (\$R)	917
3.17.4.7	Machine and setting data (\$M, \$\$S)	918
3.17.4.8	Timer (\$AC_TIMER).....	919
3.17.4.9	FIFO variables (\$AC_FIFO)	920
3.17.4.10	Path tangent angle (\$AC_TANEB).....	925
3.17.4.11	Override (\$A...OVR).....	925
3.17.4.12	Capacity evaluation (\$AN_IPO ... , \$AN/AC_SYNC ... , \$AN_SERVO)	927
3.17.4.13	Working-area limitation (\$SA_WORKAREA_ ...).....	929
3.17.4.14	SW cam positions and times (\$\$SN_SW_CAM_ ...)	930
3.17.4.15	Path length evaluation / machine maintenance (\$AA_TRAVEL ... , \$AA_JERK ...).....	930
3.17.4.16	Polynomial coefficients, parameters (\$AC_FCT ...)	932
3.17.4.17	Overlaid movements (\$AA_OFF)	934
3.17.4.18	Online tool length compensation (\$AA_TOFF)	937
3.17.4.19	Current block in the interpolator (\$AC_BLOCKTYPE, \$AC_BLOCKTYPEINFO, \$AC_SPLITBLOCK)	940
3.17.4.20	Initialization of array variables (SET, REP)	943
3.17.4.21	Grinding-specific system variables (\$AC_IN_KEY_G...)	943
3.17.4.22	Status Synchronized action disabled (\$AC_SYNA_STATE).....	946
3.17.5	User-defined variables for synchronized actions	947
3.17.6	Language elements for synchronized actions and technology cycles	949
3.17.7	Language elements for technology cycles only	955
3.17.8	Actions in synchronized actions	955
3.17.8.1	Output of M, S and H auxiliary functions to the PLC	955
3.17.8.2	Reading and writing of system variables.....	957
3.17.8.3	Polynomial evaluation (SYNFCT)	957
3.17.8.4	Online tool offset (FTOC)	962
3.17.8.5	Programmed read-in disable (RDISABLE).....	964
3.17.8.6	Cancel preprocessing stop (STOPREOF)	965
3.17.8.7	Delete distance-to-go (DELDTG).....	965
3.17.8.8	Traversing axes, to position (POS)	967

3.17.8.9	Setting the measuring system (G70, G71, G700, G710)	971
3.17.8.10	Position in specified reference range (POSRANGE)	972
3.17.8.11	Traversing axes, endless (MOV).....	973
3.17.8.12	Axial feedrate (FA)	974
3.17.8.13	Axis replacement (GET, RELEASE, AXTOCHAN)	974
3.17.8.14	Traversing spindles (M, S, SPOS)	980
3.17.8.15	Withdrawing the enable for the axis container rotation (AXCTSWEC)	981
3.17.8.16	Actual value setting with loss of the referencing status (PRESETON)	984
3.17.8.17	Actual value setting without loss of the referencing status (PRESETONS)	989
3.17.8.18	Couplings (CP..., LEAD..., TRAIL..., CTAB...).....	994
3.17.8.19	Measurement (MEAWA, MEAC).....	999
3.17.8.20	Travel to fixed stop (FXS, FXST, FXSW, FOCON, FOCOF, FOC).....	1002
3.17.8.21	Channel synchronization (SETM, CLEARM)	1004
3.17.8.22	User-specific error reactions (SETAL)	1004
3.17.8.23	Cancel the actual subprogram level (CANCELSUB)	1005
3.17.9	Technology cycles.....	1006
3.17.9.1	General	1006
3.17.9.2	Processing mode (ICYCON, ICYCOF)	1008
3.17.9.3	Definitions (DEF, DEFINE).....	1009
3.17.9.4	Parameter transfer	1009
3.17.9.5	Context variable (\$P_TECCYCLE)	1010
3.17.10	Coordination via part program and synchronized action (LOCK, UNLOCK, CANCEL)	1011
3.17.11	Coordination via PLC	1011
3.18	Oscillation.....	1013
3.18.1	Asynchronous oscillation (OS, OSP1, OSP2, OST1, OST2, OSCTRL, OSNSC, OSE, OSB)	1013
3.18.2	Oscillation controlled by synchronized actions (OSCILL)	1017
3.19	Grinding.....	1025
3.19.1	Activate/deactivate grinding-specific tool monitoring (TMON, TMOF)	1025
3.20	Program runtime/part counter	1026
3.20.1	Program runtime	1026
3.20.2	Workpiece counter	1029
3.21	Additional functions	1031
3.21.1	Activate machine data (NEWCONF).....	1031
3.21.2	Check scope of NC language present (STRINGIS)	1032
3.21.3	Interactively call the window from the part program (MMC).....	1035
3.21.4	Process DataShare - Output to an external device/file (EXTOPEN, WRITE, EXTCLOSE):.....	1040
3.21.5	Alarms (SETAL)	1044
3.21.6	Define blank (WORKPIECE).....	1045
3.21.7	Switch language mode (G290, G291).....	1049
3.22	User stock removal programs	1052
3.22.1	Supporting functions for stock removal	1052
3.22.2	Generate contour table (CONTPRON)	1052
3.22.3	Generate coded contour table (CONTDCON)	1058
3.22.4	Determine point of intersection between two contour elements (INTERSEC)	1062
3.22.5	Execute the contour elements of a table block-by-block (EXECTAB).....	1063
3.22.6	Calculate circle data (CALCDAT).....	1064
3.22.7	Deactivate contour preparation (EXECUTE).....	1066


3.23	Programming cycles externally	1067
3.23.1	Technology cycles.....	1067
3.23.1.1	Introduction	1067
3.23.1.2	Technology-specific overview	1068
3.23.1.3	HOLES1 – row position pattern	1070
3.23.1.4	HOLES2 – circle or pitch circle position pattern	1070
3.23.1.5	POCKET3 – rectangular pocket	1072
3.23.1.6	POCKET4 – circular pocket	1075
3.23.1.7	SLOT1 - longitudinal slot.....	1077
3.23.1.8	SLOT2 - circumferential slot.....	1080
3.23.1.9	LONGHOLE - elongated hole	1082
3.23.1.10	CYCLE60 – engraving.....	1084
3.23.1.11	CYCLE61 - Face milling.....	1087
3.23.1.12	CYCLE62 - contour call.....	1089
3.23.1.13	CYCLE63 – contour pocket milling / contour pocket residual material / contour spigot milling / contour spigot residual material	1089
3.23.1.14	CYCLE64 - Predrilling contour pocket	1092
3.23.1.15	CYCLE70 - thread milling.....	1094
3.23.1.16	CYCLE72 - Path milling	1095
3.23.1.17	CYCLE76 – rectangular spigot.....	1098
3.23.1.18	CYCLE77 – circular spigot	1101
3.23.1.19	CYCLE78 - Drill thread milling	1103
3.23.1.20	CYCLE79 - multi-edge	1105
3.23.1.21	CYCLE81 - drilling, centering.....	1107
3.23.1.22	CYCLE82 - drilling, counterboring.....	1108
3.23.1.23	CYCLE83 – deep-hole drilling 1	1111
3.23.1.24	CYCLE84 - tapping without compensating chuck	1114
3.23.1.25	CYCLE85 - reaming	1117
3.23.1.26	CYCLE86 - boring	1118
3.23.1.27	CYCLE92 - cut-off.....	1119
3.23.1.28	CYCLE95 - contour cutting	1121
3.23.1.29	CYCLE98 - thread chain	1123
3.23.1.30	CYCLE99 - thread turning.....	1127
3.23.1.31	CYCLE435 - Set dresser coordinate system	1132
3.23.1.32	CYCLE495 - form-truing.....	1132
3.23.1.33	CYCLE800 – swivel plane / swivel tool / align tool.....	1134
3.23.1.34	CYCLE801 – grid or frame position pattern	1137
3.23.1.35	CYCLE802 - arbitrary positions.....	1139
3.23.1.36	CYCLE830 - deep-hole drilling 2.....	1141
3.23.1.37	CYCLE832 - High-Speed Settings	1147
3.23.1.38	CYCLE840 - tapping with compensating chuck	1150
3.23.1.39	CYCLE899 – open slot.....	1153
3.23.1.40	CYCLE930 - groove	1156
3.23.1.41	CYCLE940 – undercut form E and F / undercut thread	1158
3.23.1.42	CYCLE951 - stock removal.....	1161
3.23.1.43	CYCLE952 – stock removal / residual stock removal / plunge cutting / residual plunge cutting / plunge turning / residual plunge turning	1164
3.23.1.44	CYCLE4071 - longitudinal grinding with infeed at the reversal point	1170
3.23.1.45	CYCLE4072 - longitudinal grinding with infeed at the reversal point and cancel signal	1172
3.23.1.46	CYCLE4073 - longitudinal grinding with continuous infeed	1176
3.23.1.47	CYCLE4074 - longitudinal grinding with continuous infeed and cancel signal.....	1177
3.23.1.48	CYCLE4075 - surface grinding with infeed at the reversal point.....	1180


3.23.1.49	CYCLE4077 - surface grinding with infeed at the reversal point and cancel signal.....	1183
3.23.1.50	CYCLE4078 - surface grinding with continuous infeed.....	1187
3.23.1.51	CYCLE4079 - surface grinding with intermittent infeed	1189
3.23.1.52	GROUP_BEGIN - beginning of program block	1192
3.23.1.53	GROUP_END - end of program block.....	1192
3.23.1.54	GROUP_ADDEND - End of trial cut addition	1193
3.23.1.55	Supplementary conditions.....	1193
3.23.2	Overview of measuring cycle parameters	1195
3.23.2.1	CYCLE973 measuring cycle parameters	1195
3.23.2.2	CYCLE974 measuring cycle parameters	1197
3.23.2.3	CYCLE994 measuring cycle parameters	1200
3.23.2.4	CYCLE976 measuring cycle parameters	1203
3.23.2.5	CYCLE978 measuring cycle parameters	1205
3.23.2.6	CYCLE998 measuring cycle parameters	1208
3.23.2.7	CYCLE977 measuring cycle parameters	1211
3.23.2.8	CYCLE961 measuring cycle parameters	1215
3.23.2.9	CYCLE979 measuring cycle parameters	1217
3.23.2.10	CYCLE997 measuring cycle parameters	1220
3.23.2.11	CYCLE995 measuring cycle parameters	1223
3.23.2.12	CYCLE996 measuring cycle parameters	1225
3.23.2.13	CYCLE9960 measuring cycle parameters	1228
3.23.2.14	CYCLE982 measuring cycle parameters	1230
3.23.2.15	CYCLE971 measuring cycle parameters	1232
3.23.2.16	CYCLE150 measuring cycle parameters	1235
4	Tables.....	1237
4.1	Operations.....	1237
4.2	Addresses	1274
4.2.1	Address letters	1274
4.2.2	Fixed addresses	1275
4.2.3	Settable addresses	1279
4.3	G commands.....	1286
4.3.1	G commands.....	1286
4.3.2	G group 1: Modally valid motion commands	1286
4.3.3	G group 2: Non-modally valid motion, dwell time	1287
4.3.4	G group 3: Programmable frame, working area limitation and pole programming.....	1287
4.3.5	G group 4: FIFO	1288
4.3.6	G group 6: Plane selection	1288
4.3.7	G group 7: Tool radius compensation	1288
4.3.8	G group 8: Settable work offset.....	1289
4.3.9	G group 9: Frame suppression	1289
4.3.10	G group 10: Exact stop - continuous-path mode.....	1289
4.3.11	G group 11: Exact stop, non-modal	1290
4.3.12	G group 12: Block change criteria at exact stop (G60/G9)	1290
4.3.13	G group 13: Workpiece measuring inch/metric	1290
4.3.14	G group 14: Workpiece measuring absolute/incremental	1291
4.3.15	G group 15: Feed type	1291
4.3.16	G group 16: Feedrate override at inside and outside curvature.....	1292
4.3.17	G group 17: Approach and retraction response, tool offset	1292
4.3.18	G group 18: Corner behavior, tool offset.....	1292
4.3.19	G group 19: Curve transition at beginning of spline	1292

4.3.20	G group 20: Curve transition at end of spline.....	1293
4.3.21	G group 21: Acceleration profile.....	1293
4.3.22	G group 22: Tool offset type.....	1293
4.3.23	G group 23: Collision monitoring at inside contours.....	1293
4.3.24	G group 24: Precontrol.....	1294
4.3.25	G group 25: Tool orientation reference	1294
4.3.26	G group 26: Repositioning mode for REPOS (modal)	1294
4.3.27	G group 27: Tool offset for change in orientation at outside corners	1294
4.3.28	G group 28: Working area limitation.....	1295
4.3.29	G group 29: Radius/diameter programming.....	1295
4.3.30	G group 30: NC block compression	1295
4.3.31	G group 31: OEM G commands.....	1296
4.3.32	G group 32: OEM G commands.....	1296
4.3.33	G group 33: Settable fine tool offset.....	1296
4.3.34	G group 34: Tool orientation smoothing.....	1297
4.3.35	G group 37: Feedrate profile	1297
4.3.36	G group 39: Programmable contour accuracy	1297
4.3.37	G group 40: Tool radius compensation constant	1297
4.3.38	G group 41: Interruptible thread cutting	1298
4.3.39	G group 42: Tool carrier	1298
4.3.40	G group 43: SAR approach direction	1298
4.3.41	G group 44: SAR path segmentation	1298
4.3.42	G group 45: Path reference for FGROU P axes	1299
4.3.43	G group 46: Plane selection for fast retraction.....	1299
4.3.44	G group 47: Mode switchover for external NC code	1299
4.3.45	G group 48: Approach and retraction response with tool radius compensation.....	1299
4.3.46	G group 49: Point-to-point motion	1300
4.3.47	G group 50: Orientation programming	1300
4.3.48	G group 51: Interpolation type for orientation programming	1300
4.3.49	G group 52: Frame rotation in relation to workpiece	1301
4.3.50	G group 53: Frame rotation in relation to tool	1301
4.3.51	G group 54: Vector rotation for polynomial programming	1302
4.3.52	G group 55: Rapid traverse with/without linear interpolation.....	1302
4.3.53	G group 56: Taking into account tool wear	1302
4.3.54	G group 57: Corner deceleration.....	1303
4.3.55	G group 59: Dynamic response mode for path interpolation.....	1303
4.3.56	G group 60: Working area limitation.....	1303
4.3.57	G group 61: Tool orientation smoothing.....	1304
4.3.58	G group 62: Repositioning mode for REPOS (non-modal)	1304
4.3.59	G group 64: Grinding frames.....	1304
4.4	Predefined procedures.....	1306
4.5	Predefined procedures in synchronized actions	1327
4.6	Predefined functions	1329
A	Appendix.....	1343
A.1	List of abbreviations	1343
	Index.....	1353

Fundamental safety instructions

1.1 General safety instructions

 WARNING
Danger to life if the safety instructions and residual risks are not observed
If the safety instructions and residual risks in the associated hardware documentation are not observed, accidents involving severe injuries or death can occur.
<ul style="list-style-type: none">• Observe the safety instructions given in the hardware documentation.• Consider the residual risks for the risk evaluation.

 WARNING
Malfunctions of the machine as a result of incorrect or changed parameter settings
As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.
<ul style="list-style-type: none">• Protect the parameterization against unauthorized access.• Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

1.2 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment or any eventuality which may arise. Application examples do not represent specific customer solutions, but are only intended to provide support for typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

1.3 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Products and solutions from Siemens constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. using firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that can be implemented, please visit:

Industrial security (<https://www.siemens.com/industrialsecurity>)

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they become available, and that only the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at:

Industrial security (<https://www.siemens.com/industrialsecurity>)

Further information is provided on the Internet:

Industrial Security Configuration Manual (<https://support.industry.siemens.com/cs/ww/en/view/108862708>)



WARNING

Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
- Make sure that you include all installed products into the holistic industrial security concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- On completion of commissioning, check all security-related settings.
- Protect the drive against unauthorized changes by activating the "Know-how protection" converter function.


Fundamentals

2.1 Fundamental Geometrical Principles

2.1.1 Workpiece positions

2.1.1.1 Reference system of position specifications

In order that the machine or the control can work with the positions specified in the NC program, these position specifications have to be made in a reference system that can be transferred to the directions of motion of the machine axes. Cartesian (i.e. clockwise, perpendicular) coordinate systems in accordance with DIN 66217 are used as workpiece coordinate system for machine tools.




The workpiece zero (W) is the origin of the workpiece coordinate system.

2.1.1.2 Cartesian coordinates

The axes in the coordinate system are assigned dimensions. In this way, it is possible to clearly describe every point in the coordinate system and therefore every workpiece position through the direction (X, Y and Z) and three numerical values. The workpiece zero always has the coordinates X0, Y0, and Z0.

Position specifications in the form of Cartesian coordinates

To simplify things, we will only consider one plane of the coordinate system in the following example, the X/Y plane:




Points P1 to P4 have the following coordinates:

Position	Coordinates
P1	X100 Y50
P2	X-50 Y100
P3	X-105 Y-115
P4	X70 Y-75

Example: Workpiece positions for turning

With lathes, one plane is sufficient to describe the contour:




Points P1 to P4 have the following coordinates:

Position	Coordinates
P1	X25 Z-7.5
P2	X40 Z-15
P3	X40 Z-25
P4	X60 Z-35

Example: Workpiece positions for milling

For milling, the feed depth must also be described, i.e. the third coordinate (in this case Z) must also be assigned a numerical value.



Points P1 to P3 have the following coordinates:

Position	Coordinates
P1	X10 Y45 Z-5
P2	X30 Y60 Z-20
P3	X45 Y20 Z-15

2.1.1.3 Polar coordinates

Polar coordinates can be used instead of Cartesian coordinates to describe workpiece positions. This is useful when a workpiece or part of a workpiece has been dimensioned with radius and angle. The point from which the dimensioning starts is called the "pole".


Position specifications in the form of polar coordinates

Polar coordinates are made up of the **polar radius** and the **polar angle**.

The polar radius is the distance between the pole and the position.

The polar angle is the angle between the polar radius and the horizontal axis of the working plane. Negative polar angles are in the clockwise direction, positive polar angles in the counterclockwise direction.

Example



Points P1 and P2 can then be described – with reference to the pole – as follows:

Position	Polar coordinates
P1	RP=100 AP=30
P2	RP=60 AP=75
RP: Polar radius	
AP: Polar angle	

2.1.1.4 Absolute dimensions


Position specifications in absolute dimensions

With absolute dimensions, all the position specifications refer to the currently valid zero point.

Applied to tool movement this means:

the position, to which the tool is to travel.


Example: Turning



In absolute dimensions, the following position specifications result for points P1 to P4:

Position	Position specification in absolute dimensions
P1	X25 Z-7.5
P2	X40 Z-15
P3	X40 Z-25
P4	X60 Z-35

Example: Milling



In absolute dimensions, the following position specifications result for points P1 to P3:

Position	Position specification in absolute dimensions
P1	X20 Y35
P2	X50 Y60
P3	X70 Y20

2.1.1.5 Incremental dimension


Position specifications in incremental dimensions

In production drawings, the dimensions often do not refer to a zero point, but rather to another workpiece point. So that these dimensions do not have to be converted, they can be specified in incremental dimensions. In this method of dimensional notation, a position specification refers to the previous point.

Applied to tool movement this means:

The incremental dimensions describe the distance the tool is to travel.

Example: Turning



In incremental dimensions, the following position specifications result for points P2 to P4:


Position	Position specification in incremental dimensions	The specification refers to:
P2	X15 Z-7.5	P1
P3	Z-10	P2
P4	X20 Z-10	P3

Note

With DIAMOF or DIAM90 active, the set distance in incremental dimensions (G91) is programmed as a radius dimension.

Example: Milling

The position specifications for points P1 to P3 in incremental dimensions are:



In incremental dimensions, the following position specifications result for points P1 to P3:


Position	Position specification in incremental dimensions	The specification refers to:
P1	X20 Y35	Zero point
P2	X30 Y20	P1
P3	X20 Y -35	P2

2.1.2 Working planes


An NC program requires information about the machining plane, because only then can the control, for example, correct the tool correction values correctly. The specification of the working plane is also required for certain types of circular-path programming and polar coordinates.

The working plane is specified in the base Cartesian workpiece coordinate system with two coordinate axes. The third coordinate axis is perpendicular to this work plane and determines the infeed direction of the tool (e.g. for 2D machining).

Working planes for turning/milling



Working planes for turning



Working planes for milling

Activating a work plane

The working planes are activated defined in the NC program with the G commands G17, G18 and G19. The relationship is defined as follows:

G command	Working plane	Abscissa	Ordinate	Applicate infeed direction
G17	X/Y	X	Y	Z
G18	Z/X	Z	X	Y
G19	Y/Z	Y	Z	X


2.1.3 Zero points and reference points

Various zero points and reference points are defined on an NC machine:


Zero points		
	M	Machine zero The machine zero defines the machine coordinate system (MCS). All other reference points refer to the machine zero.
	W	Workpiece zero = program zero The workpiece zero defines the workpiece coordinate system in relation to the machine zero.
	A	Blocking point Can be the same as the workpiece zero (only for lathes).

Reference points		
	R	Reference point Position defined by output cam and measuring system. The distance to the machine zero M must be known so that the axis position at this point can be set exactly to this value.
	B	Starting point Can be defined by the program. The 1st tool starts machining here.
	T	Toolholder reference point Is on the toolholder. By entering the tool lengths, the control calculates the distance between the tool tip and the toolholder reference point.
	N	Tool change point

Zero points and reference points for turning



Zero points for milling



2.1.4 Coordinate systems


A distinction is made between the following coordinate systems:

- Machine coordinate system (MCS) (Page 37) with the machine zero **M**
- Basic coordinate system (BCS) (Page 39)
- Basic zero system (BZS) (Page 41)
- Settable zero system (SZS) (Page 42)
- Workpiece coordinate system (WCS) (Page 43) with the workpiece zero **W**

2.1.4.1 Machine coordinate system (MCS)

The machine coordinate system comprises all the physically existing machine axes.

Reference points and tool and pallet changing points (fixed machine points) are defined in the machine coordinate system.



If programming is performed directly in the machine coordinate system (possible with some G commands), the physical axes of the machine respond directly. Any workpiece clamping that is present is not taken into account.

Note

If there are various machine coordinate systems (e.g. 5-axis transformation), then an internal transformation is used to map the machine kinematics on the coordinate system in which the programming is performed.

Three-finger rule

The orientation of the coordinate system relative to the machine depends on the machine type. The axis directions follow the so-called "three-finger rule" of the **right** hand (according to DIN 66217).

2.1 Fundamental Geometrical Principles

Seen from in front of the machine, the middle finger of the right hand points in the opposite direction to the infeed of the main spindle. Therefore:

- the thumb points in the +X direction
- the index finger points in the +Y direction
- the middle finger points in the +Z direction






Figure 2-1 "Three-finger rule"

Rotary motions around the coordinate axes X, Y and Z are designated A, B and C. If the rotary motion is in a clockwise direction when looking in the positive direction of the coordinate axis, the direction of rotation is positive:



Position of the coordinate system in different machine types

The position of the coordinate system resulting from the "three-finger rule" can have a different orientation for different machine types. Here are a few examples:



2.1.4.2 Basic coordinate system (BCS)

The basic coordinate system (BCS) consists of three mutually perpendicular axes (geometry axes) as well as other special axes, which are not interrelated geometrically.

Machine tools without kinematics transformation

BCS and MCS always coincide when the BCS can be mapped onto the MCS without kinematics transformation (e.g. 5-axis transformation, TRANSMIT/TRACYL/TRANG).

On such machines, machine axes and geometry axes can have the same names.




Figure 2-2 MCS = BCS without kinematics transformation

Machine tools with kinematics transformation

BCS and MCS do not coincide when the BCS is mapped onto the MCS with kinematics transformation (e.g. 5-axis transformation, TRANSMIT/TRACYL/TRANG).

On such machines the machine axes and geometry axes must have different names.




Figure 2-3 Kinematics transformation between the MCS and BCS

Machine kinematics

The workpiece is always programmed in a two- or three-dimensional, right-angled coordinate system (WCS). However, the production of these workpieces is being programmed ever more frequently on machine tools with rotary axes or linear axes not perpendicular to one another. The kinematics transformation is used to represent coordinates programmed in the WCS (rectangular) in real machine movements.


Further information

Transformations Function Manual; Kinematics Transformation

Transformations Function Manual; Multiple Transformations

2.1.4.3 Basic zero system (BZS)

The basic zero system (BZS) is derived from the basic coordinate system through the basic offset.



Basic offset

The basic offset describes the coordinate transformation between BCS and BZS. It can be used, for example, to define the palette zero.

The basic offset comprises:

- External work offset
- DRF offset
- Overlaid movement

- Chained system frames
- Chained basic frames

Further information


Basic Functions Function Manual; Axes, Coordinate Systems, Frames

2.1.4.4 Settable zero system (SZS)

Settable zero offset

The "settable zero system" (SZS) results from the basic zero system (BZS) through the settable zero offset.

Settable zero offsets are activated in the NC program with the G commands G54...G57 and G505...G599 as follows:



If no programmable coordinate transformations (frames) are active, then the "settable zero system" is the workpiece coordinate system (WCS).

Programmable coordinate transformations (frames)

Sometimes it is useful or necessary within an NC program, to move the originally selected workpiece coordinate system (or the "settable zero system") to another position and, if required, to rotate it, mirror it and/or scale it. This is performed using programmable coordinate transformations (frames).

See Section: "Coordinate transformations (frames)"

Note

Programmable coordinate transformations (frames) always refer to the "settable zero system".


2.1.4.5 Workpiece coordinate system (WCS)

The geometry of a workpiece is described in the workpiece coordinate system (WCS). In other words, the data in the NC program refers to the workpiece coordinate system.

The workpiece coordinate system is always a Cartesian coordinate system and assigned to a specific workpiece.

2.1.4.6 What is the relationship between the various coordinate systems?

The example in the following figure should help clarify the relationships between the various coordinate systems:



- ① A kinematic transformation is not active, i.e. the machine coordinate system and the basic coordinate system coincide.
- ② The basic zero system (BZS) with the pallet zero result from the basic offset.
- ③ The settable work offset G54 or G55 specifies the "settable zero system" (SZS) for workpiece 1 or workpiece 2 respectively.
- ④ The workpiece coordinate system (WCS) results from the programmable coordinate transformation.

2.2 Fundamental Principles of NC Programming

Note

DIN 66025 is the guideline for NC programming.

2.2.1 Name of an NC program

Rules

Each NC program must be assigned a program name (identifier) when it is created. The program name can be chosen freely providing the following rules are observed:

- Permissible characters:
 - Letters: A ... Z, a ... z
 - Numbers: 0 ... 9
 - Underscore: _
- The first two characters should either be two letters or an underscore followed by a letter.

Note

If this condition is satisfied, then an NC program can be called as subprogram from another program just by specifying the program name. However, if the program name starts with digits, the subprogram call is then only possible via the CALL statement.

- Maximum length: 24 characters

Note

Uppercase/lowercase letters

The SINUMERIK NC language does **not** distinguish between uppercase and lowercase letters.

Note

Impermissible program names

To avoid problems with Windows applications, the following program names may **not** be used:

- CON, PRN, AUX, NUL
- COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9
- LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9

Further restrictions, see "Names (Page 373)".

Control-internal extensions

The program name assigned when the program is created is extended within the control with the addition of a prefix and a suffix:

- Prefix: `_N_`
- Suffix:
 - Main programs: `_MPF`
 - Subprograms: `_SPF`

Files in punch tape format

Externally created program files that are read via the RS-232-C must be present in punch tape format.

The following additional rules apply for the program name of a file in punch tape format:

- First character: `%`
- Then a four-character file extension: `_xxx`

Examples:

- `%_N_SHAFT123_MPF`
- `%Flange3_MPF`

Further information

For detailed information on downloading, creating and storing NC programs, see:
Turning, milling and grinding operating manual; "Manage programs" section

2.2.2 Structure and contents of an NC program

2.2.2.1 Blocks and block components

Blocks

An NC program consists of a sequence of NC blocks. Each block contains the data for executing a step in the workpiece machining.

Block components

NC blocks consist of the following components:

- Commands (statements) according to DIN 66025
- Elements of the NC high-level language

Commands according to DIN 66025

The commands according to DIN 66025 consist of an address character and a digit or sequence of digits representing an arithmetic value.

Address character (address)


The address character (generally a letter) defines the meaning of the command.

Examples:

Address character	Meaning
G	G command (preparatory function)
X	Position data for the X axis
S	Spindle speed

Digit sequence

The digit sequence is the value assigned to the address character. The sequence of digits can contain a sign and decimal point. The sign always appears between the address letter and the sequence of digits. Positive signs (+) and leading zeros (0) do not have to be specified.



Elements of the NC high-level language

As the command set according to DIN 66025 is no longer adequate for programming complex machining sequences in modern machine tools, it has been extended by the elements of the NC high-level language.

These include, for example:

- Commands of the NC high-level language
In contrast to the commands according to DIN 66025, the commands of the NC high-level language consist of several address letters, e.g.
 - OVR for speed override
 - SPOS for spindle positioning
- Identifiers (defined names) for:
 - System variables
 - User-defined variables
 - Subprograms
 - Keywords
 - Jump markers
 - Macros

Note

An identifier must be unique and cannot be used for different objects.

- Comparison operators
- Logic operators
- Arithmetic functions
- Control structures

Effectiveness of commands

Commands are either modal or non-modal:

- Modal
Modal commands retain their validity with the programmed value (in all following blocks) until:
 - A new value is programmed under the same command.
 - A command is programmed that revokes the effect of the previously valid command
- Non-modal
Non-modal commands only apply to the block in which they were programmed.

End of program

The last block in the execution sequence contains a special word for the end of program: M2, M17 or M30.

2.2.2.2 Block rules

Start of block

NC blocks can be identified at the start of the block by block numbers. These consist of the character "N" and a positive integer, e.g.

N40 . . .

The order of the block numbers is arbitrary, however, block numbers in rising order are recommended.

Note

Block numbers must be unique within a program in order to achieve an unambiguous result when searching.

End of block

A block ends with the character LF (LINE FEED = new line).

Note

The LF character does not have to be written. It is generated automatically by the line change.

Block length

A block can contain a maximum of **512 characters** (including the comment and end-of-block character LF).

Note

Three blocks of up to 66 characters each are normally displayed in the current block display on the screen. Comments are also displayed. Messages are displayed in a separate message window.

Order of the statements

In order to keep the block structure as clear as possible, the statements in a block should be arranged in the following order:

N... G... X... Y... Z... F... S... T... D... M... H...

Address	Meaning
N	Address of block number
G	Preparatory function
X, Y, Z	Positional data
F	Feedrate
S	Speed

T	Tool
D	Tool offset number
M	Additional function
H	Auxiliary function

Note

Certain addresses can be used repeatedly within a block, e.g.

G..., M..., H...

2.2.2.3 Value assignments

Values can be assigned to the addresses. The following rules apply:

- An "=" sign must be inserted between the address and the value if:
 - The address comprises more than one letter.
 - The value includes more than one constant.

The "=" sign can be omitted if the address is a single letter and the value consists of only one constant.

- Signs are permitted.
- Separators are permitted after the address letter.

Examples:

X10	Value assignment (10) to address X, "=" not required
X1=10	Value assignment (10) to address (X) with numeric extension (1), "=" required
X=10*(5+SIN(37.5))	Value assignment by means of a numeric expression, "=" required

Note

A numeric extension must always be followed by one of the special characters "=", "(", "[", ")", "]", ";", or an operator, in order to distinguish an address with numeric extension from an address letter with a value.

2.2.2.4 Comments

To make an NC program easier to understand, comments can be added to the NC blocks.

A comment is at the end of a block and is separated from the program section of the NC block by a semicolon (";").

Example 1:

Program code	Comment
N10 G1 F100 X10 Y20	; Comment to explain the NC block

Example 2:

Program code	Comment
N10	; Company G&S, order no. 12A71
N20	; Program written by H. Smith, Dept. TV 4 on November 21, 1994
N50	; Section no. 12, housing for submersible pump type TP23A

Note

Comments are stored and appear in the current block display when the program is running.


2.2.2.5 Skipping blocks

NC blocks which are not to be executed in every program pass (e.g. execute a trial program run), can be skipped.

Programming

Blocks which are to be skipped are marked with an oblique "/" in front of the block number. Several consecutive blocks can also be skipped. The statements in the skipped blocks are not executed; the program continues with the next block which is not skipped.

Example:



Program code	Comment
N10	; Is executed
/N20 ...	; Skipped
N30 ...	; Is executed
/N40 ...	; Skipped
N70 ...	; Is executed

Skip levels

Blocks can be assigned to skip levels (max. 10) which can be activated via the user interface.

Programming is performed by assigning a forward slash, followed by the number of the skip level. Only one skip level can be specified for each block.

Example:

Program code	Comment
/ ...	; Block is skipped (1st skip level)
/0 ...	; Block is skipped (1st skip level)
/1 N010...	; Block is skipped (2nd skip level)
/2 N020...	; Block is skipped (3rd skip level)
...	
/7 N100...	; Block is skipped (8th skip level)
/8 N080...	; Block is skipped (9th skip level)
/9 N090...	; Block is skipped (10th skip level)

Note

The number of skip levels that can be used depends on a display machine data item.

Note

System and user variables can also be used in conditional jumps in order to control program execution.

2.3 Creating an NC program

2.3.1 Basic procedure

The programming of the individual operation steps in the NC language generally represents only a small proportion of the work in the development of an NC program.

Programming of the actual instructions should be preceded by the planning and preparation of the operation steps. The more accurately you plan in advance how the NC program is to be structured and organized, the faster and easier it will be to produce a complete program, which is clear and free of errors. Clearly structured programs are especially advantageous when changes have to be made later.

As every part is not identical, it does not make sense to create every program in the same way. However, the following procedure has shown itself to be suitable in the most cases.

Procedure

1. Prepare the workpiece drawing

- Define the workpiece zero
- Draw the coordinate system
- Calculate any missing coordinates

2. Define the machining sequence

- Which tools are used when and for the machining of which contours?
- In which order will the individual elements of the workpiece be machined?
- Which individual elements are repeated (possibly also rotated) and should be stored in a subroutine?
- Are there contour sections in other part programs or subroutines that could be used for the current workpiece?
- Where are zero offsets, rotating, mirroring and scaling useful or necessary (frame concept)?

3. Create a machining plan

Define all machining operations step-by-step, e.g.

- Rapid traverse movements for positioning
- Tool change
- Define the machining plane
- Retraction for checking
- Switch spindle, coolant on/off
- Call up tool data
- Feed
- Path correction
- Approaching the contour
- Retraction from the contour
- etc.

4. Compile machining steps in the programming language

- Write each individual step as an NC block (or NC blocks).

5. Combine the individual steps into a program**2.3.2 Available characters**

The following characters are available for writing NC programs:

- Uppercase characters:
A, B, C, D, E, F, G, H, I, J, K, L, M, N,(O),P, Q, R, S, T, U, V, W, X, Y, Z
- Lowercase characters:
a, b, c, d, e, f, g, h, i, j, k, l, m, n, o, p, q, r, s, t, u, v, w, x, y, z
- Numbers:
0, 1, 2, 3, 4, 5, 6, 7, 8, 9
- Special characters:
See the table below.

Special characters	Meaning
%	Program start character (used only for writing programs on an external PC)
(For bracketing parameters or expressions
)	For bracketing parameters or expressions
[For bracketing addresses or indexes
]	For bracketing addresses or indexes
<	Less than
>	Greater than
:	Main block, end of label, chain operator
=	Assignment, part of equation

Special characters	Meaning
/	Division, block suppression
*	Multiplication
+	Addition
-	Subtraction, minus sign
"	Double quotation marks, identifier for character string
'	Single quotation marks, identifier for special numerical values: hexadecimal, binary
\$	System variable identifiers
s_	Underscore, belonging to letters
?	Reserved
!	Reserved
.	Decimal point
,	Comma, parameter separator
;	Comment start
&	Format character, same effect as space character
LF	End of block
Tab character	Separator
Blank	Separator (blank)

Note

Take care to differentiate between the letter "O" and the digit "0".

Note

No distinction is made between uppercase and lowercase characters (exception: tool call).

Note

Non-printable special characters are treated like blanks.

2.3.3 Program header

The NC blocks that are placed in front of the actual motion blocks for the machining of the workpiece contour are called the program header.

The program header contains information/statements regarding:

- Tool change
- Tool offsets
- Spindle motion
- Feed control
- Geometry settings (zero offset, selection of the working plane)

Program header for turning

The following example shows the typical structure of an NC program header for turning:

Program code	Comment
N10 G0 G153 X200 Z500 T0 D0	; Retract toolholder before tool turret is rotated.
N20 T5	; Swing in tool 5.
N30 D1	; Activate cutting edge data set of the tool.
N40 G96 S300 LIMS=3000 M4 M8	; Constant cutting rate (Vc) = 300 m/min, speed limitation = 3000 rpm, direction of rotation counterclockwise, cooling on.
N50 DIAMON	; X axis will be programmed in the diameter.
N60 G54 G18 G0 X82 Z0.2	; Call zero offset and working plane, approach starting position.
...	

Program header for milling

The following example shows the typical structure of an NC program header for milling:

Program code	Comment
N10 T="SF12"	; Alternative: T123
N20 M6	; Trigger tool change.
N30 D1	; Activate cutting edge data set of the tool.
N40 G54 G17	; Zero offset and working plane.
N50 G0 X0 Y0 Z2 S2000 M3 M8	; Approach to the workpiece, spindle and coolant on.
...	

If tool orientation / coordinate transformation is being used, any transformations still active should be deleted at the start of the program:

Program code	Comment
N10 CYCLE800()	; Resetting of the swiveled plane
N20 TRAFOOF	; Resetting of TRAORI, TRANSMIT, TRACYL, ...
...	

2.3.4 Program examples

2.3.4.1 Example 1: First programming steps

Program example 1 is to be used to perform and test the first programming steps on the NC.

Procedure

1. Create a new part program (name)
2. Edit the part program
3. Select the part program
4. Activate single block
5. Start the part program.

Further information:

Operating Manual for the present user interface

Note

In order that the program can run on the machine, the machine data must have been set appropriately (→ machine manufacturer!).

Note

Alarms can occur during program verification. These alarms first have to be reset.

Program example 1

Program code	Comment
N10 MSG ("THIS IS MY NC PROGRAM")	; Message "THIS IS MY NC PROGRAM" displayed in the alarm line.
N20 F200 S900 T1 D2 M3	; Feedrate, spindle, tool, tool offset, spindle clockwise.
N30 G0 X100 Y100	; Approach position in rapid traverse.
N40 G1 X150	; Rectangle with feedrate, straight line in X.
N50 Y120	; Straight line in Y.
N60 X100	; Straight line in X.
N70 Y100	; Straight line in Y.
N80 G0 X0 Y0	; Retraction in rapid traverse.
N100 M30	; End of block.

2.3.4.2 Example 2: NC program for turning

Program example 2 is intended for the machining of a workpiece on a lathe. It contains radius programming and tool radius compensation.

Note

In order that the program can run on the machine, the machine data must have been set appropriately (→ machine manufacturer!).

Program code	Comment
N85 G1 X46	
N90 X52 Z-63	
N95 G0 G40 G97 X100 Z50 M9	; Deselect tool radius compensation and approach tool change location.
N100 T2 D2	; Call tool and select offset.
N105 G96 S210 M3	; Select constant cutting rate.
N110 G0 G42 X50 Z-60 M8	; Set tool with tool radius compensation.
N115 G1 Z-70 F0.12	; Turn diameter 50.
N120 G2 X50 Z-80 I6.245 K-5	; Turn radius 8.
N125 G0 G40 X100 Z50 M9	; Retract tool and deselect tool radius compensation.
N130 G0 G53 X280 Z380 D0 M5	; Approach tool change location.
N135 M30	; End of program.

2.3.4.3 Example 3: NC program for milling

Program example 3 is intended for the machining of a workpiece on a vertical milling machine. It contains surface and side milling as well as drilling.

Note

In order that the program can run on the machine, the machine data must have been set appropriately (→ machine manufacturer!).

Dimension drawing of the workpiece




Figure 2-5 Side view

2.3 Creating an NC program

Program code	Comment
N100 G1 X40 Y30 CHR=10	
N110 G1 X40 Y-30	
N120 G1 X-41 Y-30	
N130 G1 G40 Y-72 F3000	; Deselection of the milling tool radius compensation.
N140 G0 Z200 M5 M9	; Retraction of the milling tool, spindle + cooling off.
N150 T="SF10"	; Preselection of the tool with name SF10.
N160 M6	; Load the tool into the spindle.
N170 S2800 M3 M8	; Speed, direction of rotation, cooling on.
N180 G90 G64 G54 G17 G0 X0 Y0	; Basic settings for the geometry and approach starting point.
N190 G0 Z2	
N200 POCKET4(2,0,1,-5,15,0,0,0,0,800,1300,0,21,5,,,2,0.5)	; Call of the pocket milling cycle.
N210 G0 Z200 M5 M9	; Retraction of the milling tool, spindle + cooling off.
N220 T="ZB6"	; Call center drill 6 mm.
N230 M6	
N240 S5000 M3 M8	
N250 G90 G60 G54 G17 X25 Y0	; Exact stop G60 for exact positioning.
N260 G0 Z2	
N270 MCALL CYCLE82(2,0,1,-2.6,,0)	; Modal call of the drilling cycle.
N280 POSITION:	; Jump mark for repetition.
N290 HOLES2(0,0,25,0,45,6)	; Position pattern for drilling.
N300 ENDLABEL:	; End identifier for repetition.
N310 MCALL	; Resetting of the modal call.
N320 G0 Z200 M5 M9	
N330 T="SPB5"	; Call drill D 5 mm.
N340 M6	
N350 S2600 M3 M8	
N360 G90 G60 G54 G17 X25 Y0	
N370 MCALL CYCLE82(2,0,1,-13.5,,0)	; Modal call of the drilling cycle.
N380 REPEAT POSITION	; Repetition of the position description from centering.
N390 MCALL	; Resetting of the drilling cycle.
N400 G0 Z200 M5 M9	

Program code	Comment
N410 M30	; End of program.

2.4 Tool change

Tool change method

In circular magazines on turning machines, the tool change, that is the search for and change of the tool, is called with the T command only.

→ Tool change with T command (Page 62)

Whereas in chain, rotary-plate and box magazines, a tool change normally takes place in two stages:

1. The tool is sought in the magazine with the T command.
2. The tool is then loaded into the spindle with the M command.

→ Tool change with M6 (Page 64)

Note

The type of tool change mechanism is specified by the machine OEM during the commissioning.

Programming of the working plane

The appropriate machining plane (Page 34) has to be programmed for the tool change (initial state: G18). This ensures that the tool length compensation is assigned to the correct axis.

Activation of the tool offset


The tool change activates the tool offset values stored under a D number (Page 83).

2.4.1 Tool change with T command

There is a direct tool change when the T command is programmed.

Application

For turning machines with circular magazine.



Syntax

Selecting a tool

T<No>
T=<No>
T<n>=<No>

Deselecting a tool

T0
T0=<No>

Meaning

T:	Address for tool selection including tool change and activation of the tool offset	
<n>:	Spindle number as address extension Note: The possibility of programming a spindle number as an address extension depends on the configuration of the machine; → see machine manufacturer's specifications.	
<No>:	Number of the tool	
	Range of values:	0 ... 32000
T0:	Deselecting the active tool	

Example


Program code	Comment
N10, T1, D1	; Loading of tool T1 and activation of the tool offset D1.
...	
N70 T0	; Deselect tool T1.
...	

2.4.2 Tool change with M6

The tool is selected when the T command is programmed. The tool only becomes active with M6 (including tool offset).

Application

For milling machines with chain, rotary-plate or box magazines.



- ① Spindle
- ② Gripper
- ③ Magazine (here: Chain magazine)
- ④ Change position for spindle

Syntax

Selecting a tool

T<No>

T=<No>

T<n>=<No>

Tool change

M6

Deselecting a tool

T0

T0=<No>

Meaning

T:	Address for the tool selection	
<n>:	Spindle number as address extension Note: The possibility of programming a spindle number as an address extension depends on the configuration of the machine; → see machine manufacturer's specifications.	
<No>:	Number of the tool	
	Range of values:	0 ... 32000

M6:	M function for the tool change (according to DIN 66025) M6 activates the selected tool (T...) and the tool offset (D...).
T0:	Deselecting the active tool

Example

Program code	Comment
N10 T1 M6	; Loading of tool T1.
N20 D1	; Selection of tool length compensation.
N30 G1 X10 ...	; Machining with T1.
...	
N70 T5	; Preselection of tool T5.
N80 ...	; Machining with T1.
...	
N100 M6	; Loading of tool T5.
N110 D1 G1 X10 ...	; Machining with tool T5.
...	

2.4.3 Tool change with tool management (option)

Tool management

The optional "Tool management" function ensures that at any given time the correct tool is in the correct location in the machine, and that the data assigned to the tool are up to date. It also allows fast tool changes and avoids both scrap by monitoring the tool service life and machine downtimes by using spare tools.

Tool name

On a machine tool with active tool management, the tools must be assigned a name and number for clear identification (e.g. "Drill", "3").

The tool can then be called with the tool name, e.g.

```
T="Drill"
```

Note

The tool name may not contain any special characters.

2.4.3.1 Tool change with T command with active tool management (option)

There is a direct tool change when the T command is programmed.

Application

For turning machines with circular magazine.

Syntax

Selecting a tool

T=<No>

T=<Name>

T<n>=<No>

T<n>=<Name>

Deselecting a tool

T0

Meaning

T=:	Command for tool change and activating the tool offset The following specifications are possible:	
	<No>:	Number of the magazine location
	<name>:	Name of tool Note: The correct notation (uppercase/lowercase) must be used when programming a tool name.
<n>:	Spindle number as address extension Note: The possibility of programming a spindle number as an address extension depends on the configuration of the machine; → see machine manufacturer's specifications.	
T0:	Tool deselection (magazine location unoccupied)	


Note

If the selected magazine location is not occupied in a tool magazine, the command acts as for T0. The selection of the unoccupied magazine location can be used to position the empty location.

Example

A circular magazine has locations 1 to 12 with the following tool assignment:

Location	Tool	Tool group	Status
1	Drill, duplo no. = 1	T15	Disabled
2	Not occupied		
3	Drill, duplo no. = 2	T10	Enabled
4	Drill, duplo no. = 3	T1	Active
5 ... 12	Not occupied		



- ① ... Magazine/location number
- ⑫

The following tool call is programmed in the NC program:

```
N10 T=1
```

The call is processed as follows:

1. Magazine location 1 is considered and the tool identifier determined.
2. The tool management recognizes that this tool is blocked and therefore cannot be used.
3. A tool search for T="drill" is initiated in accordance with the set search strategy:
"Find the active tool; or select the one with the next highest duplo number."
4. The following usable tool is then found:
"Drill", duplo no. 3 (at magazine location 4)
This completes the tool selection process and the tool change is initiated.

Note

If the "Select the first available tool from the group" search strategy is employed, the order within the tool group being loaded has to be defined first. In this case, group T10 is loaded, as T15 is disabled.

When the search strategy "Take the first tool with "active" status from the group" is applied, T1 is loaded.

2.4.3.2 Tool change with M6 with active tool management (option)

The tool is selected when the T command is programmed. The tool only becomes active with M6 (including tool offset).

Application

For milling machines with chain, rotary-plate or box magazines.

Syntax

Selecting a tool

T=<No>
 T=<Name>
 T<n>=<No>
 T<n>=<Name>

Tool change

M6

Deselecting a tool

T0

Meaning

T=:	Address for the tool selection The following specifications are possible:	
	<No>:	Number of the magazine location
	<name>:	Name of tool Note: The correct notation (uppercase/lowercase) must be used when programming a tool name.
<n>:	Spindle number as address extension Note: The possibility of programming a spindle number as an address extension depends on the configuration of the machine; → see machine manufacturer's specifications.	
M6:	M function for the tool change (according to DIN 66025) M6 activates the selected tool (T...) and the tool offset (D...).	
T0:	Tool deselection (magazine location unoccupied)	

Note

If the selected magazine location is not occupied in a tool magazine, the command acts as for T0. The selection of the unoccupied magazine location can be used to position the empty location.

Example

Program code	Comment
N10 T=1 M6	; Loading of the tool from magazine location 1.
N20 D1	; Selection of tool length compensation.
N30 G1 X10 ...	; Machining with tool T=1.
...	
N70 T="Drill"	; Preselection of the tool with name "Drill".
N80 ...	; Machining with tool T=1.
...	

Program code	Comment
N100 M6	; Loading of the drill.
N140 D1 G1 X10 ...	; Machining with drill.
...	

2.4.4 Behavior with faulty T programming

The behavior with faulty T programming depends on the configuration of the machine:

MD22562 TOOL_CHANGE_ERROR_MODE		
Bit	Value	Meaning
7	0	Basic setting! With the T programming, a check is made immediately as to whether the NC recognizes the T number. If not, an alarm is triggered.
	1	The programmed T number will only be checked following D selection. If the NC does not recognize the tool number, an alarm is issued during D selection. This response is desirable if, for example, tool programming is also intended to achieve positioning and the tool data is not necessarily available (circular magazine).

2.5 Tool offsets

2.5.1 Programmed contour and tool path


Workpiece dimensions are programmed directly (e.g. according to the production drawing). Therefore, tool data, such as milling tool diameter, cutting edge position of the turning tool (counterclockwise/clockwise turning tool) and tool length, does not have to be taken into consideration when creating the program.

The control corrects the travel path

When machining a workpiece, the tool paths are controlled according to the tool geometry so that the programmed contour can be created with any tool.

So that the control can calculate the tool paths, the tool data must be entered in the tool compensation memory of the control. Only the required tool (T...) and the required offset data record (D...) are called via the NC program.


While the program is being processed, the control fetches the offset data it requires from the tool offset memory, and corrects the tool path individually for different tools:



2.5.2 Tool length compensation

The tool length compensation compensates for the differences in length between the tools used.

The tool length is the distance between the tool carrier reference point and the tool tip:



T Tool carrier reference point
P Tool tip


This length is measured and entered in the tool compensation memory of the control together with definable wear values. From this data, the control calculates the traversing movements in the infeed direction.

Note

The correction value of the tool length depends on the spatial orientation of the tool.

2.5.3 Tool radius compensation

The contour and tool path are not identical. The milling tool or cutting edge center point must travel along a path corresponding to the tool radius that is equidistant from the contour (tool center point path). To do this, while executing the program, the control shifts the programmed tool center point path – based on the radius of the active tool (tool offset memory) – so that the tool cutting edge traverses precisely along the programmed contour.



R Tool radius
S Cutting edge center point

The tool radius compensation is described in detail in the "Tool radius compensation (Page 246)" Chapter.

See also

2 1/2 D tool offset (CUT2D, CUT2DD, CUT2DF, CUT2DFD) (Page 282)

2.5.4 Tool compensation memory

The following data must be available in the tool offset memory of the control system for each tool edge:

- Tool type
- Cutting edge position
- Tool geometry variables (length, radius)

These data are entered as tool parameters (max. 25). Which parameters are required for a tool depends on the tool type. Any tool parameters that are not required must be set to "zero" (corresponds to the default setting of the system).

Note

Values that have been entered once in the offset memory are included in the processing at each tool call.


Tool type

The tool type (drill, milling or turning tool) determines which geometry data are necessary and how they are calculated.

Cutting edge position

The cutting edge position describes the position of the tool tip in relation to the cutting edge center point. The cutting edge position together with the cutting edge radius is required for the calculation of the tool radius compensation for turning tools (tool type 5xx) (Page 79).

Tool geometry variables (length, radius)



- T Tool carrier reference point
- R Tool radius
- L Tool length

The tool geometry variables consist of several components (geometry, wear). The control computes the components to a resulting size (e.g. total length 1, total radius). The relevant overall dimension becomes operative when the offset memory is activated.

How these values are calculated in the axes is determined by the tool type and the current plane (G17/G18/G19).

2.5.5 Tool types

2.5.5.1 Tool type number and tool groups

Each tool type is assigned a unique 3-digit number. The assignment of the tool to one of the following technologies or tool groups is realized using the first digit (the hundreds position):

Tool type	Tool group
1xy	Milling tools (Page 74)
2xy	Drills (Page 76)
3xy	Reserved
4xy	Grinding tools (Page 77)
5xy	Turning tools (Page 79)
6xy	Reserved
7xy	Special tools (Page 81)


2.5.5.2 Milling tools

The following tool types are available in the "Milling tools" group:

100	Milling tool according to CLDATA (Cutter Location Data)
110	Ball end mill
111	Cylindrical die-sinking milling cutter
120	End milling cutter without corner rounding
121	End mill with corner rounding
130	Angle head cutter without corner rounding
131	Angle head mill with corner rounding
140	Facing tool
145	Thread cutter
150	Side mill
151	Saw
155	Bevel cutter (without corner rounding)
156	Bevel cutter with corner rounding
157	Tapered die milling tool
160	Drill and thread milling cutter


Tool parameters

The following diagrams provide an overview of which milling tool parameters are entered in the compensation memory:



- ① Tool
- ② Tool holder
- ③ Tool adapter
- T Adapter reference point (for inserted tool = tool carrier reference point)
- T' Tool carrier reference point
- L1 Geometry - length 1
- L1' Adapter dimension - length 1
- L1 + L1' Total length L1
- R Radius

Tool parameters	Meaning
\$TC_DP1	Tool type 1xy
\$TC_DP3	Geometry - length 1
\$TC_DP6	Geometry - radius
\$TC_DP21	Adapter dimension - length 1
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Other values should be set to 0. 	



- T Tool carrier reference point
- T' Tool carrier reference point
- L1 Geometry - length 1
- R Tool radius
- L1' Base dimension - length 1
- L2' Base dimension - length 2
- L3' Base dimension - length 3

Tool parameters	Meaning
\$TC_DP1	Tool type
\$TC_DP3	Geometry - length 1
\$TC_DP6	Geometry - radius
\$TC_DP21	Base dimension - length 1
\$TC_DP22	Base dimension - length 2
\$TC_DP23	Base dimension - length 3
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Other values should be set to 0. 	

2.5.5.3 Drills


The following tool types are available in the "Drills" group:

No.	Tool type
200	Twist drill
205	Drill
210	Boring bar
220	Center drill

No.	Tool type
230	Countersink
231	Counterbore
240	Tap regular thread
241	Tap fine thread
242	Tap Whitworth thread
250	Reamer

Tool parameters

The following diagram provides an overview of which drill tool parameters are entered in the compensation memory:



- T Tool carrier reference point
- L1 Length 1

Tool parameters	Meaning
\$TC_DP1	Tool type
\$TC_DP3	Geometry - length 1
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Other values should be set to 0. 	


2.5.5.4 Grinding tools

The following tool types are available in the "Grinding tools" group:

400	Surface grinding wheel
401	Surface grinding wheel with monitoring
402	Surface grinding wheel without monitoring without base dimension (TOOLMAN)
403	Surface grinding wheel with monitoring without base dimension for grinding wheel peripheral speed GWPS
410	Facing wheel
411	Facing wheel (TOOLMAN) with monitoring
412	Facing wheel (TOOLMAN) without monitoring
413	Facing wheel with monitoring without base dimension for grinding wheel peripheral speed GWPS
490	Dresser

Tool parameters

The following diagram provides an overview of which grinding tool parameters are entered in the compensation memory:



- T Tool carrier reference point
- T' Tool holder reference point
- L1 Geometry - length 1
- L1' Base dimension - length 1
- L2 Geometry - length 2
- L2' Base dimension - length 2
- R Radius
- α Angle of inclined wheel

Cutting edge-specific parameters	Meaning
\$TC_DP1	Tool type 4xy
\$TC_DP2	Cutting edge position
\$TC_DP3	Geometry length 1
\$TC_DP4	Geometry length 2
\$TC_DP6	Radius
\$TC_DP21	Base dimension length 1
\$TC_DP22	Base dimension length 2
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Set other values to 0. 	

Tool-specific parameters	Meaning
\$TC_TPG1	Spindle number
\$TC_TPG2	Chaining rule ¹⁾
\$TC_TPG3	Minimum wheel radius
\$TC_TPG4	Minimum wheel width
\$TC_TPG5	Actual wheel width

Tool-specific parameters	Meaning
\$TC_TPG6	Maximum speed
\$TC_TPG7	Maximum circumferential velocity
\$TC_TPG8	Angle of inclined wheel
\$TC_TPG9	Parameter number for radius calculation
\$TC_TPG_DRSPATH	Directory path to the dressing program
\$TC_TPG_DRSPROG	Dressing program name

- 1) The geometry length compensations, wear and base dimension can be chained for the left and right tool nose radius compensation. This means that the length compensations for the left cutting edge are changed so that the values are also automatically entered for the right cutting edge, and vice versa.


2.5.5.5 Turning tools

The following tool types are available in the "Turning tools" group:

500	Roughing tool
510	Finishing tool
520	Plunge cutter
530	Parting tool
540	Threading tool
550	Button tool / forming tool (TOOLMAN)
560	Rotary drill (ECOCUT)
580	Probe with cutting edge position parameters

Tool parameters

The following diagram provides an overview of which turning tool parameters are entered in the compensation memory:



- ① Cutting edge position (1 ... 9) for machining behind the turning center
- P Tool tip
- S Cutting edge center point
- R Cutting edge radius
- T Tool carrier reference point
- T' Tool holder reference point
- L1 Geometry - length 1
- L2 Geometry - length 2
- L1' Base dimension - length 1
- L2' Base dimension - length 2
- L3' Base dimension - length 3

Tool parameters	Meaning
\$TC_DP1	Tool type
\$TC_DP2	Cutting edge position

Tool parameters	Meaning
\$TC_DP3	Geometry - length 1
\$TC_DP4	Geometry - length 2
\$TC_DP6	Geometry - radius (cutting edge radius)
\$TC_DP21	Base dimension - length 1
\$TC_DP22	Base dimension - length 2
\$TC_DP23	Base dimension - length 3
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Set other values to 0. 	


2.5.5.6 Special tools

The following tool types are available in the "Special tools" group:

700	Slotting saw
710	3D probe
711	Edge probe
712	Mono probe
713	L probe
714	Star probe
725	Calibration tool
730	Stop
731	Spindle sleeves
732	End support

Tool parameters

The following diagram provides an overview of which tool parameters for "Slotting saw" tool type are entered in the compensation memory:



- T' Tool carrier reference point
- L1 Geometry - length 1
- L2 Geometry - length 2
- d Diameter
- b Slot width
- k Projection

Tool parameters	Meaning
\$TC_DP1	Tool type
\$TC_DP3	Geometry - length 1
\$TC_DP4	Geometry - length 2
\$TC_DP6	Diameter
\$TC_DP7	Slot width
\$TC_DP8	Projection
\$TC_DP21	Base dimension length 1
\$TC_DP22	Base dimension length 2
\$TC_DP23	Base dimension length 3
<ul style="list-style-type: none"> • Wear values corresponding to the requirements. • Other values should be set to 0. 	

2.5.6 Tool offset call (D)

Cutting edges 1 to 8 of a tool (with active tool management 12) can be assigned different tool offset data blocks (e.g. different correction values for the left and right cutting edges of a grooving tool).

The offset data (including the data for the tool length compensation) of a special cutting edge is activated by calling the D number. When D0 is programmed, offsets for the tool have no effect.

A tool radius compensation must also be activated via G41/G42.

Note

Tool length compensations take immediate effect when the D number is programmed. If no D number is programmed, the default setting defined by the machine data is active for a tool change (→ see machine manufacturer's specifications).

Syntax

Activating a tool offset data block:
D<Number>

Activating the tool radius compensation:
G41 ...
G42 ...

Deactivation of the tool offsets:
D0
G40

Meaning

D:	Command for activating an offset data block for the active tool The tool length compensation is applied with the first programmed traverse of the associated length compensation axis. Notice: A tool length compensation can also take effect without D programming, if the automatic activation of a tool edge has been configured for the tool change (→ see machine manufacturer's specifications).
<Number>:	The tool offset data block to be activated is specified by the <Number> parameter. The type of D programming depends on the configuration of the machine (see paragraph "Type of D programming"). Range of values: 0 ... 32000
D0:	Command for deactivating the offset data block for the active tool
G41:	Command for activating the tool radius compensation with machining direction left of the contour
G42:	Command for activating the tool radius compensation with machining direction right of the contour
G40:	Command for deactivating the tool radius compensation

Note

The tool radius compensation is described in detail in the "Tool radius compensations" Chapter.

Type of D programming

The type of D programming is defined by machine data.

There are the following options:

- D number = cutting edge number
D numbers ranging from 1 to max. 12 are available for every tool T<Number> (without TOOLMAN) or T="Name" (with TOOLMAN). These D numbers are assigned directly to the tool cutting edges. An offset data block (\$TC_DPx[t,d]) is assigned to each D number (= cutting edge number).
- Free selection of D numbers
The D numbers can be freely assigned to the cutting edge numbers of a tool. A machine data specifies the upper limit for the D numbers that may be used.

Further information

Tools Function Manual; Tool Offset


Tool Management Function Manual; Variants of D Number Assignments

Examples

Example 1: Tool change with T command (turning)

Program code	Comment
N10, T1, D1	; Load tool T1 and activate tool offset data block D1 of T1.
N11 G0 X... Z...	; The tool length compensations are applied.
N50, T4, D2	; Load tool T4 and activate tool offset data block D2 of T4.
...	
N70 G0 Z... D1	; Activate other cutting edge D1 for tool T4.

Example 2: Different correction values for the left and right cutting edges of a grooving tool



2.5.7 Change in the tool offset data

Effectiveness

A change in the tool offset data takes effect the next time the T or D number is programmed.

Set tool offset data to be active immediately

The following machine data can be used to specify that entered tool offset data takes effect immediately:

MD9440 \$MM_ACTIVATE_SEL_USER

WARNING

Risk of collision

If MD9440 is set, tool offsets resulting from changes in tool offset data **during the part program stop**, are applied when the part program is continued.

2.5.8 Programmable tool offset (TOFFL, TOFF, TOFFR, TOFFLR):

With the TOFFx addresses, the user can modify the effective tool length and the effective tool radius in the NC program without changing the tool offset data stored in the compensation memory.

These programmed offsets are deleted again at the end of the program.

Syntax

Tool length offset

```
TOFFL=<Value>
TOFFL[1]=<Value> TOFFL[2]=<Value> TOFFL[3]=<Value>
TOFF[<GeoAx>]=<Value>
```

The tool length can be changed simultaneously in all three components. However, commands of the TOFFL/TOFFL[1..3] group and commands of the TOFF[<geometry axis>] group may not be used simultaneously in one block. Similarly TOFFL and TOFFL[1] may not be written simultaneously in one block.

If all three tool length components are not programmed in one block, the components not programmed remain unchanged. In this way, it is possible to build up offsets for several components block-by-block. However, this only applies as long as the tool components have been modified only with either TOFFL or TOFF. Changing the programming version from TOFFL to TOFF or vice versa deletes any previously programmed tool length offsets (see example 3).

Tool radius offset

```
TOFFR=<Value>
```

Simultaneous tool length offset and tool radius offset

```
TOFFLR=<Value>
```

Meaning

TOFFL:	Correction of the effective tool length TOFFL can be programmed with or without index:	
	TOFFL=...	The programmed offset value is applied in the same direction as the tool length component L1 stored in the compensation memory. The TOFFL and TOFFL[1] instructions have an identical effect.
	TOFFL[1]=... TOFFL[2]=... TOFFL[3]=...	The programmed offset value is effective in the same direction as the tool length components L1 , L2 and L3 stored in the offset memory.
	Note: How these tool length compensation values are calculated in the axes is determined by the tool type and the current working plane (G17/G18/G19).	

TOFF:	Correction of the tool length in the component parallel to the specified geometry axis TOFF is applied in the direction of the tool length component which is effective with non-rotated tool (orientable tool carrier or orientation transformation) parallel to the geometry axis specified in the index. Note: A frame does not influence the assignment of the programmed values to the tool length components. This means that the workpiece coordinate system (WCS) is not used to assign the tool length components to the geometry axes, but rather the tool coordinate system in the basic tool position.	
<GeoAx>:	Identifier of the geometry axis	
TOFFR:	Correction of the effective tool radius TOFFR changes the effective tool radius with active tool radius compensation by the programmed offset value.	
TOFFLR:	Correction of the effective tool length in the component L1 and the effective tool radius Note: For tools with corner rounding (types 111, 121, 131 and 156), TOFFLR also corrects the corner radius.	
<Value>:	Offset value	
	Type:	REAL

Examples

Example 1: Positive tool length offset

The active tool is a drill with length $L1 = 100$ mm.

The active plane is G17. This means that the drill points in the Z direction.

The effective drill length is to be increased by 1 mm. The following variants are available for programming this tool length offset:

- `TOFFL=1`
- `TOFFL[1]=1`
- `TOFF[Z]=1`

Example 2: Negative tool length offset

The active tool is a drill with length $L1 = 100$ mm.

The active plane is G18. This means that the drill points in the Y direction.

The effective drill length is to be decreased by 1 mm. The following variants are available for programming this tool length offset:

- `TOFFL=-1`
- `TOFFL[1]=-1`
- `TOFF[Y]=1`

Example 3: Change of programming version from TOFFL to TOFF

The active tool is a milling tool. The active plane is G17.

Program code	Comment
N10 TOFFL[1]=3 TOFFL[3]=5	; Effective offsets: L1=3, L2=0, L3=5
N20 TOFFL[2]=4	; Effective offsets: L1=3, L2=4, L3=5
N30 TOFF[Z]=1.3	; Effective offsets: L1=0, L2=0, L3=1.3

Example 4: Assignment of the offset values after a plane change

Program code	Comment
N10 \$TC_DP1[1,1]=120	
N20 \$TC_DP3[1,1]= 100	; Tool length L1=100 mm.
N30 T1 D1 G17	
N40 TOFF[Z]=1.0	; Offset in Z direction (corresponds to L1 for G17).
N50 G0 X0 Y0 Z0	; Machine axis position X0 Y0 Z101.
N60 G18 G0 X0 Y0 Z0	; Machine axis position X0 Y100 Z1.
N70 G17	
N80 TOFFL=1.0	; Offset in L1 direction (corresponds to Z for G17).
N90 G0 X0 Y0 Z0	; Machine axis position X0 Y0 Z101.
N100 G18 G0 X0 Y0 Z0	; Machine axis position X0 Y101 Z0.

In this example, the offset of 1 mm in the Z axis is retained when changing to G18 in block N60; the effective tool length in the Y axis is the unchanged tool length of 100 mm.

However, in block N100, the offset is effective in the Y axis when changing to G18 as it was assigned to tool length L1 in the programming, and this length component is effective in the Y axis with G18.

Example 5: Simultaneous tool length offset and tool radius offset

a, end milling cutter **without** corner rounding (tool type 120):

Program code	Comment
...	
TOFFLR=5	; Effective offsets: ; Tool length offset (L1) = 5 ; Tool radius offset = 5
...	

b, end mill **with** corner rounding (tool type 121):

Program code	Comment
...	
TOFFLR=5	; Effective offsets: ; Tool length offset (L1) = 5 ; Tool radius offset = 5 ; Offset corner radius = 5
...	

Further information

Tool length offsets

Depending on the type of programming, programmed tool length offsets are assigned either to the tool length components L1, L2 and L3 (TOFFL) stored in the compensation memory or to the geometry axes (TOFF). The programmed offsets are treated accordingly for a plane change (G17/G18/G19 ↔ G17/G18/G19):

- If the offset values are assigned to the tool length components, the directions in which the programmed offsets apply are replaced accordingly.
- If the offset values are assigned to the geometry axes, a plane change does not affect the assignment in relation to the coordinate axes.

The following setting data is evaluated when assigning the programmed offset values to the tool length components:

SD42940 \$SC_TOOL_LENGTH_CONST (change of tool length components on change of planes).

SD42950 \$SC_TOOL_LENGTH_TYPE (assignment of the tool length offset independent of tool type).

If this setting data has valid values not equal to 0, then these have priority over the contents of G group 6 (plane selection G17/G18/G19) or the tool type (\$TC_DP1[<T no.>, <D no.>]) contained in the tool data. This means that this setting data affects the evaluation of the offsets in the same way as the tool length components L1 to L3.

Tool radius offset

The TOFFR address has almost the same effect as the OFFN address (see " Tool radius compensation (Page 246) "). There is only a difference with active peripheral curve transformation (TRACYL) and active slot side compensation. In this case, the tool radius is affected by OFFN with a negative sign, but by TOFFR with a positive sign.

OFFN and TOFFR can be effective simultaneously. They then generally have an additive effect (except for slot side compensation).

Tool change

All offset values are retained during a tool change (cutting edge change). This means that they are also effective for the new tool (new cutting edge).

System variables for reading the current offset values

The currently effective offsets can be read with the following system variables:

System variable	Meaning
\$P_TOFFL [<n>] with 0 ≤ n ≤ 3	Reads the current offset value of TOFFL (for n = 0) or TOFFL[1...3] (for n = 1, 2, 3) in the preprocessing context.
\$P_TOFF [<GeoAx>]	Reads the current offset value of TOFF[<GeoAx>] in the preprocessing context.
\$P_TOFFR	Reads the current offset value of TOFFR in the preprocessing context.
\$P_TOFFCR	Reads the current offset value of the corner radius in the preprocessing context.

System variable	Meaning
\$AC_TOFFL[<n>] with $0 \leq n \leq 3$	Reads the current offset value of TOFFL (for n = 0) or TOFFL[1...3] (for n = 1, 2, 3) in the main run context (synchronized actions).
\$AC_TOFF[<GeoAx>]	Reads the current offset value of TOFF[<GeoAx>] in the main run context (synchronized actions).
\$AC_TOFFR	Reads the current offset value of TOFFR in the main run context (synchronized actions).
\$AC_TOFFCR	Reads the current offset value of the corner radius in the main run context (synchronized actions).

Note

The system variables \$AC_TOFFL, \$AC_TOFF, AC_TOFFR and AAC_TOFFCR trigger an automatic preprocessing stop when reading from the preprocessing context (NC program).

Applications

The "Programmable tool offset" function is especially interesting for ball mills and milling tools with corner radii as these are often calculated in the CAM system to the ball center instead of the ball tip. However, the tool tip is generally measured when the tool is measured, and stored as tool length in the compensation memory.

For the 3D tool radius compensation with a ball mill it is advantageous to correct the tool length and radius by the same value simultaneously. The TOFFLR address is available to the user for this purpose.

2.6 Spindle motion

2.6.1 Spindle speed (S), spindle direction of rotation (M3, M4, M5)

The spindle speed and direction of rotation values set the spindle in rotary motion and provide the conditions for chip removal.




Figure 2-7 Spindle motion during turning

Other spindles may be available in addition to the main spindle (e.g. the counterspindle or an actuated tool on turning machines). As a rule, the main spindle is declared the master spindle in the machine data. This assignment can be changed using an NC command.

Syntax

S... / S<n>=...

M3 / M<n>=3

M4 / M<n>=4

M5 / M<n>=5

SETMS (<n>)	
...	
SETMS	

Meaning

S...:	Spindle speed in rpm for the master spindle
S<n>=... :	Spindle speed in rpm for spindle <n>

	Note: The speed specified with S0=... applies to the master spindle
M3:	Direction of spindle rotation clockwise for master spindle
M<n>=3:	Spindle direction of rotation clockwise for spindle <n>
M4:	Direction of spindle rotation counter-clockwise for master spindle
M<n>=4:	Spindle direction of rotation counter-clockwise for spindle <n>
M5:	Spindle stop for master spindle
M<n>=5:	Spindle stop for spindle <n>
SETMS (<n>):	Set spindle <n> as master spindle
SETMS:	If SETMS is programmed without a spindle name, the configured master spindle is used instead.

Note

Up to three S-values can be programmed per NC block, e.g.:


S... S2=... S3=...

Note

SETMS must be in a separate block.

Example

S1 is the master spindle, S2 is the second spindle. The part is to be machined from two sides. To do this, it is necessary to divide the operations into steps. After the cut-off point, the synchronizing device (S2) takes over machining of the workpiece after the cut off. To do this, this spindle S2 is defined as the master spindle to which G95 then applies.



Program code	Comment
N10 S300 M3	; Speed and direction of rotation for drive spindle = pre-set master spindle.
...	; Machining of the right-hand workpiece side.

Program code	Comment
N100 SETMS(2)	; S2 is now the master spindle.
N110 S400 G95 F...	; Speed for new master spindle.
...	; Machining of the left-hand workpiece side.
N160 SETMS	; Switching back to master spindle S1.

Further information

Interpretation of the S value for the master spindle

If function G331 or G332 is active in G group 1 (modally valid motion commands), the programmed S-value will always be interpreted as the speed in rpm. Otherwise, the interpretation of the S-value will depend upon G group 15 (feedrate type): If G96, G961 or G962 is active, the S-value is interpreted as a constant cutting rate in m/min; otherwise, it is interpreted as a speed in rpm.

Changing from G96/G961/G962 to G331/G332 sets the value of the constant cutting rate to zero; changing from G331/G332 to a function within the G group 1 other than G331/G332 sets the speed value to zero. The corresponding S-values have to be reprogrammed if required.

Preset M commands M3, M4, M5

In a block with axis commands, functions M3, M4, M5 are activated **before** the axis movements commence (basic setting on the control).

Example:

Program code	Comment
N10 G1 F500 X70 Y20 S270 M3	; The spindle ramps up to 270 rpm and the movements then executed in X and Y.
N100 G0 Z150 M5	; Spindle stop before the retraction movement in Z.

Note

Machine data can be used to set when axis movements should be executed; either once the spindle has powered up to the setpoint speed, or immediately after the programmed switching operations have been traversed.

Working with multiple spindles

Five spindles (master spindle plus four additional spindles) can be available in one channel at the same time.

One of the spindles is defined in machine data as the **master spindle**. Special functions such as thread cutting, tapping, revolutional feedrate, and dwell time apply to this spindle. For the remaining spindles (e.g. a second spindle and an actuated tool) the numbers corresponding to the speed and the direction of rotation / spindle stop must be specified.

Example:

Program code	Comment
N10 S300 M3 S2=780 M2=4	; Master spindle: 300 rpm, CW rotation 2nd spindle: 780 rpm, CCW rotation

Programmable switchover of master spindle

The SETMS (<n>) command can be used in the NC program to define any spindle as the master spindle. SETMS must be in a separate block.

Example:

Program code	Comment
N10 SETMS (2)	; Spindle 2 is now the master spindle.


Note

The speed specified with S . . . , along with the functions programmed with M3, M4, M5, now apply to the newly declared master spindle.

If SETMS is programmed without a spindle name, the master spindle programmed in the machine data is used instead.

2.6.2 Tool cutting speed (SVC)

As an alternative to the spindle speed, the tool cutting speed, which is more commonly used in practice, can be programmed for milling operations.



- ① Spindle speed
- ② Tool radius
- ③ Tool cutting speed

The control uses the radius of the active tool to calculate the effective spindle speed from the programmed tool cutting speed:

$$S = (SVC * 1000) / (R_T * 2\pi)$$

- with: S: Spindle speed in rpm
- SVC: Tool cutting speed in m/min or ft/min
- R_T: Radius of the active tool in mm

The tool type (\$TC_DP1) of the active tool is not taken into account.

The programmed tool cutting speed is independent of path feedrate F and G function group 15 (feedrate type). The direction of rotation and the spindle start are implemented via M3 and M4, and the spindle stop via M5.

A change to the tool radius data in the offset memory will be applied the next time a tool offset is selected or the next time the active offset data is updated.

Changing the tool or selecting/deselecting a tool offset data set generates a recalculation of the effective spindle speed.

Requirements

Programming of the tool cutting speed requires:

- The geometric ratios of a rotating tool (milling cutter or drilling tool)
- An active tool offset data set

Syntax

```
T... D... SVC[<n>]=<Value>
...
S... M3/M4
```

Meaning

SVC:	Keyword for programming of the tool cutting speed	
[<n>]:	Number of spindle This address extension specifies which spindle the programmed cutting speed is to be applied for. In the absence of an address extension, the rate is always applied to the master spindle. Note: A separate cutting speed can be preset for each spindle. Note: Programming SVC without an address extension requires that the master spindle has the active tool. If the master spindle changes, the user will need to select a tool accordingly.	
<Value>:	Value of tool cutting speed	
	Unit:	m/min (for G71/G710) or ft/min (for G70/G700)
T... D...:	The tool radius must be established in the block with SVC. Thus, a corresponding tool including tool offset data block must either be active or selected in the block. There is no fixed sequence for SVC and T/D selection during programming in the same block.	
S... M3/M4:	Programming of the spindle speed will effect deselection of the tool cutting speed. Note: Switching between SVC programming and S programming is possible at any time, even while the spindle is rotating. In each case, the value that is not active is deleted.	

Note

SVC programming is not possible if the following spindle feedrate movements are active:

- Constant cutting speed: G96/G961/G962 S... (Page 100)
- Constant grinding wheel peripheral speed: SUG (Page 105)
- Position spindle: SPOS/SPOSA/M19 (Page 119)
- ; Switch master spindle over to axis mode: M70 (Page 119)

Conversely, programming one of these functions will effect a deselection of SVC (tool cutting speed).

Note

Maximum tool speed

System variable \$TC_TP_MAX_VELO[<tool number>] can be used to preset a maximum tool speed (spindle speed).

If no speed limit has been defined, there will be no monitoring.

Note

The tool paths of "standard tools" generated, e.g. using CAD systems which already take the tool radius into account and only contain the deviation from the standard tool in the tool nose radius, are not supported in conjunction with SVC programming.

Examples

The following shall apply to all examples: Tool carrier = spindle (for standard milling)

Example 1: Milling cutter 6 mm radius

Program code	Comment
N10 G0 X10 T1 D1	; Selection of milling tool with, e.g. \$TC_DP6[1,1] = 6 (tool radius = 6 mm)
N20 SVC=100 M3	; Cutting speed = 100 m/min ⇒ Resulting spindle speed: S = (100 m/min * 1000) / (6.0 mm * 2 * 3.14) = 2653.93 rpm
N30 G1 X50 G95 FZ=0.03	; SVC and tooth feedrate
...	

Example 2: Tool selection and SVC in the same block

Program code	Comment
N10 G0 X20	
N20 T1 D1 SVC=100	; Tool and offset data set selection together with SVC in block (no specific sequence).
N30 X30 M3	; Spindle start with CW direction of rotation, cut- ting speed 100 m/min

Program code	Comment
N40 G1 X20 F0.3 G95	; SVC and revolutional feedrate

Example 3: Defining cutting speeds for two spindles

Program code	Comment
N10 SVC[3]=100 M6 T1 D1	
N20 SVC[5]=200	; The tool radius of the active tool offset is the same for both spindles. The effective speed is different for spindle 3 and spindle 5.

Example 4:

Assumptions:

Master or tool change is determined by the tool carrier:

MD20124 \$MC_TOOL_MANAGEMENT_TOOL CARRIER > 1

In the event of a tool change the old tool offset is retained. A tool offset for the new tool is only activated when D is programmed:

MD20270 \$MC_CUTTING_EDGE_DEFAULT = - 2

Program code	Comment
N10 \$TC_MPP1[9998,1]=2	; Magazine location is tool carrier
N11 \$TC_MPP5[9998,1]=1	; Magazine location is tool carrier 1
N12 \$TC_MPP_SP[9998,1]=3	; Tool carrier 1 is assigned to spindle 3
N20 \$TC_MPP1[9998,2]=2	; Magazine location is tool carrier
N21 \$TC_MPP5[9998,2]=4	; Magazine location is tool carrier 4
N22 \$TC_MPP_SP[9998,2]=6	; Tool carrier 4 is assigned to spindle 6
N30 \$TC_TP2[2]="WZ2"	
N31 \$TC_DP6[2,1]=5.0	; Radius = 5.0 mm of T2, offset D1
N40 \$TC_TP2[8]="WZ8"	
N41 \$TC_DP6[8,1]=9.0	; Radius = 9.0 mm of T8, offset D1
N42 \$TC_DP6[8,4]=7.0	; Radius = 7.0 mm of T8, offset D4
...	
N100 SETMTH(1)	; Set master tool carrier number
N110 T="WZ2" M6 D1	; Tool T2 is loaded and offset D1 is activated.
N120 G1 G94 F1000 M3=3 SVC=100	; $S3 = (100 \text{ m/min} * 1000) / (5.0 \text{ mm} * 2 * 3.14) = 3184.71 \text{ rpm}$
N130 SETMTH(4)	; Set master tool carrier number
N140 T="WZ8"	; Corresponds to T8="WZ8"
N150 M6	; Corresponds to M4=6
	Tool "WZ8" is in the master tool carrier, but because MD20270=-2, the old tool offset remains active.
N160 SVC=50	; $S3 = (50 \text{ m/min} * 1000) / (5.0 \text{ mm} * 2 * 3.14) = 1592.36 \text{ rpm}$
	The offset applied to tool carrier 1 is still active and assigned to spindle 3.
N170 D4	; Offset D4 of the new tool "WZ8" becomes active (in tool carrier 4).

2.6 Spindle motion

Program code	Comment
N180 SVC=300	; S6 = (300 m/min * 1000) / (7.0 mm * 2 * 3.14) = 6824.39 rpm Spindle 6 is assigned to tool carrier 4.

Example 5:

Assumptions:

Spindles are tool carriers at the same time:

MD20124 \$MC_TOOL_MANAGEMENT_TOOL CARRIER = 0

In the event of a tool change, tool offset data set D4 is selected automatically:

MD20270 \$MC_CUTTING_EDGE_DEFAULT = 4

Program code	Comment
N10 \$TC_MPP1[9998,1]=2	; Magazine location is tool carrier
N11 \$TC_MPP5[9998,1]=1	; Magazine location is tool carrier 1 = spindle 1
N20 \$TC_MPP1[9998,2]=2	; Magazine location is tool carrier
N21 \$TC_MPP5[9998,2]=3	; Magazine location is tool carrier 3 = spindle 3
N30 \$TC_TP2[2]="WZ2"	
N31 \$TC_DP6[2,1]=5.0	; Radius = 5.0 mm of T2, offset D1
N40 \$TC_TP2[8]="WZ8"	
N41 \$TC_DP6[8,1]=9.0	; Radius = 9.0 mm of T8, offset D1
N42 \$TC_DP6[8,4]=7.0	; Radius = 7.0 mm of T8, offset D4
...	
N100 SETMS(1)	; Spindle 1 = master spindle
N110 T="WZ2" M6 D1	; Tool T2 is loaded and offset D1 is activated.
N120 G1 G94 F1000 M3 SVC=100	; S1 = (100 m/min * 1000) / (5.0 mm * 2 * 3.14) = 3184.71 rpm
N200 SETMS(3)	; Spindle 3 = master spindle
N210 M4 SVC=150	; S3 = (150 m/min * 1000) / (5.0 mm * 2 * 3.14) = 4777.07 rpm Refers to tool offset D1 of T="WZ2", S1 continues to turn at previous speed.
N220 T="WZ8"	; Corresponds to T8="WZ8"
N230 M4 SVC=200	; S3 = (200 m/min * 1000) / (5.0 mm * 2 * 3.14) = 6369.43 rpm Refers to tool offset D1 of T="WZ2".
N240 M6	; Corresponds to M3=6 Tool "WZ8" is in the master spindle, tool offset D4 of the new tool becomes active.
N250 SVC=50	; S3 = (50 m/min * 1000) / (7.0 mm * 2 * 3.14) = 1137.40 rpm Offset D4 on master spindle is active.
N260 D1	; Offset D1 of new tool "WZ8" active.
N270 SVC[1]=300	; S1 = (300 m/min * 1000) / (9.0 mm * 2 * 3.14) = 5307.86 rpm S3 = (50 m/min * 1000) / (9.0 mm * 2 * 3.14) = 884.64 rpm
...	

Further information

Tool radius

The following tool offset data (associated with the active tool) affect the tool radius when:

- \$TC_DP6 (radius - geometry)
- \$TC_DP15 (radius - wear)
- \$TC_SCPx6 (offset for \$TC_DP6)
- \$TC_ECPx6 (offset for \$TC_DP6)

The following are not taken into account:

- Online radius compensation
- Allowance on the programmed contour (OFFN)

Tool radius compensation (G41/G42)

Although tool radius compensation (G41/G42) and SVC both relate to the tool radius, they are not functionally linked and are independent of one another.

Tapping without compensating chuck (G331, G332)

SVC programming is also possible in conjunction with G331 or G332.

Synchronized actions

SVC cannot be programmed from synchronized actions.

Reading the cutting speed and the spindle speed programming variant

The cutting speed of a spindle and the speed programming variant (spindle speed S or tool cutting speed SVC) can be read using system variables:

- With preprocessing stop in the part program via system variables:


\$AC_SVC[<n>]	Effective cutting speed when the current main run block for spindle with number <n> was preprocessed.
\$AC_S_TYPE[<n>]	Effective spindle speed programming variant when the current main run block for spindle with number <n> was preprocessed.
Value:	Meaning:
1	Spindle speed S in rpm
2	Tool cutting speed SVC in m/min or ft/min

- Without preprocessing stop in the part program via system variables:

\$P_SVC[<n>]	Programmed cutting speed for spindle <n>
\$P_S_TYPE[<n>]	Programmed spindle speed programming variant for spindle <n>
Value:	Meaning:
1	Spindle speed S in rpm
2	Tool cutting speed SVC in m/min or ft/min

2.6.3 Constant cutting rate (G96/G961/G962, G97/G971/G972, G973, LIMS, SCC)

If the "Constant cutting speed" function is active, the spindle speed is modified as a function of the respective workpiece diameter so that the cutting speed S in m/min or ft/min remains constant at the tool edge.



This results in the following advantages:

- Uniformity and consequently improved surface quality of turned parts
- Machining with less wear on tools

Syntax

Activating/deactivating constant cutting speed for the master spindle:

```
G96/G961/G962 S...  
...  
G97/G971/G972/G973
```

Speed limitation for the master spindle:

```
LIMS=<value>  
LIMS [<spindle>]=<value>
```

Other reference axis for G96/G961/G962:

```
SCC [<axis>]
```

Note

SCC [<axis>] can be programmed together with G96/G961/G962 or in isolation.

Meaning

G96:	Revolutional feedrate (as for G95 (Page 107)) and constant cutting speed G95 is activated automatically with G96. If G95 has not been activated previously, a new feedrate value F... has to be specified when G96 is called.	
G961:	Linear feedrate (as for G94 (Page 107)) and constant cutting speed	
G962:	Linear feedrate or revolutional feedrate and constant cutting speed	
S . . . :	In conjunction with G96, G961 or G962, S... is not interpreted as a spindle speed but rather as a cutting speed. The cutting speed is always applied to the master spindle.	
	Unit:	m/min (for G71/G710) or ft/min (for G70/G700)
	Range of values:	0.1 m/min to 9999 9999.9 m/min
G97:	Revolutional feedrate and constant spindle speed (constant cutting speed OFF)	
G971:	Linear feedrate and constant spindle speed (constant cutting speed OFF)	
G972:	Linear feedrate or revolutional feedrate and constant spindle speed (constant cutting speed OFF)	
G973:	Revolutional feedrate without spindle speed limitation and constant spindle speed (G97 without LIMS for ISO mode)	
	Note: After G97 (or G971 ... G973), S... is again interpreted as a spindle speed in rpm. In the absence of a new spindle speed being specified, the last speed set with G96 (respectively G961 or G962) is retained.	
LIMS:	Speed limitation for the master spindle (only applied if G96/G961/G97 active) On machines with selectable master spindles, limitations of differing values can be programmed for up to four spindles within one block.	
	<spindle>:	Number of spindle
	<value>:	Spindle speed upper limit in rpm
SCC:	If any of the G96/G961/G962 functions are active, SCC[<axis>] can be used to assign any geometry axis as a reference axis.	

Note

If G96/G961/G962 is selected for the first time, a constant cutting speed S... must be entered; if G96/G961/G962 is selected again, the entry is optional.

Note

The speed limitation programmed with LIMS must not exceed the speed limit programmed with G26 or defined in the setting data.

Note

The reference axis for G96/G961/G962 must be a geometry axis assigned to the channel at the time when SCC[<axis>] is programmed. SCC[<axis>] can also be programmed when any of the G96/G961/G962 functions are active.

Examples

Example 1: Activating the constant cutting speed with speed limitation

Program code	Comment
N10 SETMS (3)	
N20 G96 S100 LIMS=2500	; Constant cutting speed = 100 m/min, max. speed = 2500 rpm
...	
N60 G96 G90 X0 Z10 F8 S100 LIMS=444	; Max. speed = 444 rpm

Example 2: Defining speed limitation for four spindles

Speed limitations are defined for spindle 1 (master spindle) and spindles 2, 3, and 4:

Program code
N10 LIMS=300 LIMS[2]=450 LIMS[3]=800 LIMS[4]=1500 ...

Example 3: Y-axis assignment for face cutting with X axis

Program code	Comment
N10 G18 LIMS=3000 T1 D1	; Speed limitation at 3000 rpm
N20 G0 X100 Z200	
N30 Z100	
N40 G96 S20 M3	; Constant cutting speed = 20 m/min, is dependent upon X axis.
N50 G0 X80	
N60 G1 F1.2 X34	; Face cutting in X at 1.2 mm/revolution.
N70 G0 G94 X100	
N80 Z80	
N100 T2 D1	
N110 G96 S40 SCC[Y]	; Y axis is assigned to G96 and G96 is activated (can be achieved in a single block). Constant cutting speed = 40 m/min, is dependent upon X axis.
...	
N140 Y30	
N150 G01 F1.2 Y=27	; Plunge-cutting in Y, feedrate F = 1.2 mm/revolution.
N160 G97	; Constant cutting speed off.
N170 G0 Y100	

Further information

Calculation of the spindle speed

The SZS position of the face axis (radius) is the basis for calculating the spindle speed from the programmed cutting rate.

Note

Frames between WCS and SZS (e.g. programmable frames such as SCALE, TRANS or ROT) are taken into account in the calculation of the spindle speed and can bring about a change in speed (for example, if there is a change in the effective diameter in the case of SCALE).

Speed limitation LIMS

If a workpiece that varies greatly in diameter needs to be machined, it is advisable to specify a speed limit for the spindle with LIMS (maximum spindle speed). This prevents excessively high speeds with small diameters. LIMS is only applied if G96, G961 and G97 are active. LIMS is not applied if G971 is selected. On loading the block into the main run, all programmed values are transferred into the setting data.

Note

The speed limits changed with LIMS in the part program are taken into the setting data and therefore remain saved after the end of program.

However, if the speed limits changed with LIMS are no longer to apply after the end of program, the following definition must be inserted in the GUD block of the machine manufacturer:

```
REDEF $SA_SPIND_MAX_VELO_LIMS PRLOC
```

Deactivating the constant cutting rate (G97/G971/G972/G973)

After G97 (or G971 ... G973), S... is again interpreted as a spindle speed in rpm. In the absence of a new spindle speed being specified, the last speed set with G96 (respectively G961 or G962) is retained.

The G96/G961 function can also be deactivated with G94 or G95. In this case, the last speed programmed S... is used for subsequent machining operations.

G97 can be programmed without G96 beforehand. The function then has the same effect as G95; LIMS can also be programmed.

Using G973, the constant cutting rate can be deactivated without activating a spindle speed limitation.

Note

The transverse axis must be defined in machine data.

Rapid traverse G0

With rapid traverse G0, there is no change in speed.

Exception:

If the contour is approached in rapid traverse and the next NC block contains a G1/G2/G3/... path command, the speed is adjusted in the G0 approach block for the next path command.

Other reference axis for G96/G961/G962

If any of the G96/G961/G962 functions are active, SCC[<axis>] can be used to assign any geometry axis as a reference axis. If the reference axis changes, which will in turn affect the TCP (tool center point) reference position for the constant cutting rate, the resulting spindle speed will be reached via the set braking or acceleration ramp.

Axis exchange of the assigned channel axis

The reference axis property for G96/G961/G962 is always assigned to a geometry axis. In the event of an axis exchange involving the assigned channel axis, the reference axis property for G96/G961/G962 is retained in the old channel.

A geometry axis exchange will not affect how the geometry axis is assigned to the constant cutting rate. If the TCP reference position for G96/G961/G962 is affected by a geometry axis exchange, the spindle will reach the new speed via a ramp.

If no new channel axis is assigned as a result of a geometry axis exchange (e.g. GEOAX(0,X)), the spindle speed will be frozen in accordance with G97.

Examples for geometry axis exchange with assignments of the reference axis:

Program code	Comment
N05 G95 F0.1	
N10 GEOAX(1, X1)	; Channel axis X1 becomes the first geometry axis.
N20 SCC[X]	; First geometry axis (X) becomes the reference axis ; for G96/G961/G962.
N30 GEOAX(1, X2)	; Channel axis X2 becomes the first geometry axis.
N40 G96 M3 S20	; Reference axis for G96 is channel axis X2.

Program code	Comment
N05 G95 F0.1	
N10 GEOAX(1, X1)	; Channel axis X1 becomes the first geometry axis.
N20 SCC[X1]	; X1 and implicitly the first geometry axis (X) becomes the reference axis for G96/G961/G962.
N30 GEOAX(1, X2)	; Channel axis X2 becomes the first geometry axis.
N40 G96 M3 S20	; Reference axis for G96 is X2 or X, no alarm.

Program code	Comment
N05 G95 F0.1	
N10 GEOAX(1, X2)	; Channel axis X2 becomes the first geometry axis.
N20 SCC[X1]	; X1 is not a geometry axis, alarm.

Program code	Comment
N05 G0 Z50	
N10 X35 Y30	
N15 SCC[X]	; Reference axis for G96/G961/G962 is X.
N20 G96 M3 S20	; Constant cutting rate ON at 10 mm/min.
N25 G1 F1.5 X20	; Face cutting in X at 1.5 mm/revolution.

Program code	Comment
N30 G0 Z51	
N35 SCC[Y]	; Reference axis for G96 is Y, reduction of spindle speed (Y30).
N40 G1 F1.2 Y25	; Face cutting in Y at 1.2 mm/revolution.

2.6.4 Switching constant grinding wheel peripheral speed (GWPSON, GWPSOF) on/off:

With the predefined procedures GWPSON(...) and GWPSOF(...), the constant grinding wheel peripheral speed (GWPS) for grinding tools (tool type: 400 to 499) is switched on and off.

Syntax

```
GWPSON (<TNo>)
S<n>=... :
...
GWPSOF (<TNo>)
```

Meaning

GWPSON (...):	Switch on the constant grinding wheel peripheral speed
GWPSOF (...):	Switch off the constant grinding wheel peripheral speed
<TNo>:	T number Note: Only required if the constant grinding wheel peripheral speed is to be switched on or off for an inactive grinding wheel rather than the active grinding wheel that is currently in use.
S<n>=...:	Grinding wheel peripheral speed in m/s or ft/s for spindle <n>
S0=... or S...:	Grinding wheel peripheral speed for the master spindle

Query status

The following system variable can be used to query from the part program whether the constant grinding wheel peripheral speed is active for a specific spindle.

\$P_GWPS[<n>] ; where <n> = spindle number

Value	Meaning
0 (= FALSE)	GWPS is inactive .
1 (= TRUE)	GWPS is active .

2.6.5 Programmable spindle speed limitation (G25, G26)

The minimum and maximum spindle speeds defined in the machine and setting data can be modified by means of a part program command.

Programmed spindle speed limitations are possible for all spindles of the channel.

Syntax

```
G25 S... S1=... S2=...
G26 S... S1=... S2=...
```

Meaning

G25: **Lower** spindle speed limit
 G26: **Upper** spindle speed limit
 S... S1=... S2=... : Minimum or maximum spindle speed(s)
Note:
 A maximum of three spindle speed limits can be programmed for each block.
 Range of values: 0.1 to 9999 9999.9 rpm

Note

A spindle speed limitation programmed with G25 or G26 overwrites the speed limits in the setting data and, therefore, remains stored even after the end of the program.

However, if the speed limits changed with G25/G26 are no longer to apply after the end of program, the following definitions must be inserted in the GUD block of the machine manufacturer:

```
REDEF $SA_SPIND_MIN_VELO_G25 PRLOC
REDEF $SA_SPIND_MAX_VELO_G26 PRLOC
```

Example

Program code	Comment
N10 G26 S1400 S2=350 S3=600	; Upper speed limit for master spindle, spindle 2 and spindle 3.

2.7 Feed control

2.7.1 Feedrate (G93, G94, G95, F, FGROUP, FL, FGREF)

These commands are used in the NC program to set the feedrates for all axes involved in the machining sequence.

Syntax

```
G93
G94
G95
F<value>
FGROUP(<axis_1>,<axis_2>,...)
FGREF[<rotary axis>]=<reference radius>
FL[<axis>]=<value>
```

Meaning

G93:	Path feed type: Inverse-time feedrate [rpm]
G94:	Path feed type: Linear feedrate [mm/min], [inch/min] or [degrees/min]
G95:	Path feed type: Revolutional feedrate [mm/revolution] or [inch/revolution] The revolutional feedrate can be derived from a master spindle, any other spindle or a rotary axis.
F<value>	Path feedrate for all or the path axes selected with FGROUP.
FGROUP:	Definition of the path axes to which the F-programmed path feed refers
FGREF:	FGREF is used to program the effective radius (<reference radius>) for each of the rotary axes specified under FGROUP
FL:	Limit velocity for synchronized/path axes The unit set with G94 applies One FL value can be programmed per axis (channel axes, geometry axis or orientation axis)
<axis>:	Name of a channel axis, type: AXIS

Examples

Example 1: Mode of operation of FGROUP

The following example is intended to demonstrate the effect of FGROUP on the path and path feedrate. The variable \$AC_TIME contains the time of the block start in seconds. It can only be used in synchronized actions.

Program code	Comment
N100 G0 X0 A0	
N110 FGROUP(X,A)	
N120 G91 G1 G710 F100	; Feedrate = 100mm/min or 100 degrees/min
N130 DO \$R1=\$AC_TIME	

Program code	Comment
N140 X10	; Feedrate = 100 mm/min, path = 10 mm, R1 = approx. 6 s
N150 DO \$R2=\$AC_TIME	
N160 X10 A10	; Feedrate = 100 mm/min, path = 14.14 mm, R2 = approx. 8 s
N170 DO \$R3=\$AC_TIME	
N180 A10	; Feedrate = 100 degrees/min, path = 10 degrees, R3 = approx. 6 s
N190 DO \$R4=\$AC_TIME	
N200 X0.001 A10	; Feedrate = 100 mm/min, path = 10 mm, R4 = approx. 6 s
N210 G700 F100	; Feedrate = 2540 mm/min or 100 degrees/min
N220 DO \$R5=\$AC_TIME	
N230 X10	; Feedrate = 2540 mm/min, path = 254 mm, R5 = approx. 6 s
N240 DO \$R6=\$AC_TIME	
N250 X10 A10	; Feedrate = 2540 mm/min, path = 254.2 mm, R6 = approx. 6 s
N260 DO \$R7=\$AC_TIME	
N270 A10	; Feedrate = 100 degrees/min, path = 10 degrees, R7 = approx. 6 s
N280 DO \$R8=\$AC_TIME	
N290 X0.001 A10	; Feedrate = 2540 mm/min, path = 10 mm, R8 = approx. 0.288 s
N300 FGREF[A]=360/(2*\$PI)	; Set 1 degree = 1 inch via the effective radius
N310 DO \$R9=\$AC_TIME	
N320 X0.001 A10	; Feedrate = 2540 mm/min, path = 254 mm, R9 = approx. 6 s
N330 M30	


Example 2: Traverse synchronized axes with limit speed FL

The path velocity of the path axes is reduced if the synchronized axis Z reaches the limit velocity.

Program code
N10 G0 X0 Y0
N20 FGROUP(X)
N30 G1 X1000 Y1000 G94 F1000 FL[Y]=500
N40 Z-50

Example 3: Helical interpolation

Path axes X and Y traverse with the programmed feedrate, the infeed axis Z is a synchronized axis.




Program code	Comment
N10 G17 G94 G1 Z0 F500	; Feed of the tool.
N20 X10 Y20	; Approach the starting position.
N25 FGROUPE(X,Y)	; Axes X/Y are path axes, Z is a synchronized axis.
N30 G2 X10 Y20 Z-15 I15 J0 F1000 FL[Z]=200	; On the circular path, the feedrate is 1,000 mm/min, traversing in the Z direction is synchronized.
...	
N100 FL[Z]=\$MA_AX_VELO_LIMIT[0,Z]	; The limit speed is deselected by reading the speed from the MD. Read the value from the MD.
N110 M30	; End of program

Further information

Feedrate for path axes (F)

The path feedrate is generally composed of the individual speed components of all geometry axes participating in the movement and refers to the center point of the cutter or the tip of the turning tool.



The feedrate is specified under address F . Depending on the default setting in the machine data, the units of measurement specified with the G commands are either in mm or inch.

One F value can be programmed per NC block. The feedrate unit is defined using one of the G commands $G93/G94/G95$. The feedrate F acts only on path axes and remains active until a new feedrate is programmed. Separators are permitted after the address F .

Examples:

$F100$ or $F 100$

$F.5$

$F=2*FEED$

Feedrate type ($G93/G94/G95$)

The G commands $G93$, $G94$ and $G95$ are modal. In the event of switching between $G93$, $G94$ and $G95$, the path feedrate value has to be reprogrammed. When machining with rotary axes, the feedrate can also be specified in degrees/min.

Inverse-time feedrate ($G93$)


The inverse-time feedrate specifies the time required to execute the motion commands in a block.

Unit: rpm

Example:

$N10 G93 G01 X100 F2$

Means: The programmed path is traversed in 0.5 min.

**Note**

If the path lengths vary greatly from block to block, a new F value should be specified in each block with $G93$. When machining with rotary axes, the feedrate can also be specified in degrees/min.

Feedrate for synchronized axes

The feedrate programmed under address F applies to all the path axes programmed in a block but not to the synchronized axes. The synchronized axes are controlled such that they require the same time for their path as the path axes, and all axes reach their end point at the same time.

Limit velocity for synchronized axes (FL)

The FL command can be used to program a limit velocity for synchronized axes. In the absence of a programmed FL , the rapid traverse velocity applies. FL is deselected by assignment to MD (MD36200 \$MA_AX_VELO_LIMIT).

Traverse path axis as synchronized axis (FGROUP)

$FGROUP$ is used to define whether a path axis should be traversed with path feedrate or as a synchronized axis. In helical interpolation, for example, it is possible to define that only two geometry axes, X and Y, are to be traversed at the programmed feedrate. The infeed axis Z is the synchronized axis in this case.

Example: $FGROUP(X, Y)$

Change FGROUP

The setting made with `FGROUP` can be changed:

1. By reprogramming `FGROUP`: e.g. `FGROUP (X, Y, Z)`
2. By programming `FGROUP` without a specific axis: `FGROUP ()`
In accordance with `FGROUP ()`, the initial setting in the machine data applies: Geometry axes are now once again traversed in the path axis grouping.

Note

With `FGROUP`, axis identifiers must be the names of channel axes.

Units of measurement for feedrate F

In addition to the geometrical settings `G700` and `G710`, the `G` commands are also used to define the measuring system for the feedrates `F`. In other words:

- For `G700`: [inch/min]
- For `G710`: [mm/min]

Note

`G70/G71` have **no** effect on feedrate settings.

Unit of measurement for synchronized axes with limit speed FL

The unit set for `F` using `G` command `G700/G710` is also valid for `FL`.


Unit for rotary and linear axes

For linear and rotary axes which are combined with `FGROUP` and traverse a path together, the feedrate is interpreted in the unit of the linear axes (depending on the default with `G94/G95`, in mm/min or inch/min and mm/rev or inch/rev).

The tangential velocity of the rotary axis in mm/min or inch/min is calculated according to the following formula:

$$F[\text{mm/min}] = F'[\text{degrees/min}] * \pi * D[\text{mm}]/360[\text{degrees}]$$

where: `F`: Tangential velocity
`F'`: Angular velocity
`π`: Circle constant
`D`: Diameter



Traverse rotary axes with path velocity F (FGREF)

For machining operations in which the tool or the workpiece or both are moved by a rotary axis, the effective machining feedrate is to be interpreted as a path feed in the usual way by reference to the F value. This requires the specification of an effective radius (reference radius) for each of the rotary axes involved.

The unit of the reference radius depends on the `G70/G71/G700/G710` setting.

All axes involved must be included in the `FGROUP` command to be taken into account in the calculation of the path feedrate.

In order to ensure compatibility with the behavior with no `FGREF` programming, the factor 1 degree = 1 mm is activated on system power up and RESET. This corresponds to a reference radius of $FGREF = 360 \text{ mm} / (2\pi) = 57.296 \text{ mm}$.

Note

This default is independent of the active basic system (MD10240 `$MN_SCALING_SYSTEM_IS_METRIC`) and the currently active `G70/G71/G700/G710` setting.

Special situations:

Program code
N100 <code>FGROUP (X, Y, Z, A)</code>
N110 <code>G1 G91 A10 F100</code>
N120 <code>G1 G91 A10 X0.0001 F100</code>

With this type of programming, the F value programmed in N110 is evaluated as the rotary axis feedrate in degrees/min, while the feedrate evaluation in N120 is either 100 inch/min or 100 mm/min, dependent upon the currently active G70/G71/G700/G710 setting.

NOTICE

Feedrate difference

FGREF evaluation also works if only rotary axes are programmed in the block. The normal F value interpretation as degree/min applies in this case only if the radius reference corresponds to the FGREF default:

- For G71/G710: FGREF [A]=57.296
- For G70/G700: FGREF [A]=57.296/25.4

Read reference radius

The value of the reference radius of a rotary axis can be read using system variables:

- In synchronized actions or with preprocessing stop in the part program via system variable:

\$AA_FGREF[<axis>] Current main run value

- Without preprocessing stop in the part program via system variable:

\$PA_FGREF[<axis>] Programmed value

If no values are programmed, the default $360 \text{ mm}/(2\pi) = 57.296 \text{ mm}$ (corresponding to 1 mm per degree) will be read in both variables.

For linear axes, the value in both variables is always 1 mm.

Read path axes affecting velocity

The axes involved in path interpolation can be read using system variables:

- In synchronized actions or with preprocessing stop in the part program via system variables:

\$AA_FGROUP[<axis>] Returns the value "1" if the specified axis affects the path velocity in the current main run record by means of the basic setting or through FGROUP programming. Otherwise, the variable returns the value "0".

\$AC_FGROUP_MASK Returns a bit key of the channel axes programmed with FGROUP which are to affect the path velocity.

- Without preprocessing stop in the part program via system variables:

\$PA_FGROUP[<axis>] Returns the value "1" if the specified axis affects the path velocity by means of the basic setting or through FGROUP programming. Otherwise, the variable returns the value "0".

\$P_FGROUP_MASK Returns a bit key of the channel axes programmed with FGROUP which are to affect the path velocity.

Path reference factors for orientation axes with FGREF

With orientation axes the mode of operation of the `FGREF []` factors is dependent upon whether the change in the orientation of the tool is implemented by means of rotary axis or vector interpolation.

In the case of **rotary axis interpolation**, as is the case with rotary axes, the relevant `FGREF` factors of the orientation axes are calculated individually as reference radius for the axis paths.

In the case of **vector interpolation**, an effective `FGREF` factor, which is calculated as the geometric mean value of the individual `FGREF` factors, is applied.

$$\text{FGREF}[\text{effective}] = \text{nth root of } [(\text{FGREF}[\text{A}] * \text{FGREF}[\text{B}] \dots)]$$

where: A: Axis identifier of 1st orientation axis
 B: Axis identifier of 2nd orientation axis
 C: Axis identifier of 3rd orientation axis
 n: Number of orientation axes

Example:

Since there are two orientation axes for a standard 5-axis transformation, the effective factor is, therefore, the root of the product of the two axial factors:

$$\text{FGREF}[\text{effective}] = \text{square root of } [(\text{FGREF}[\text{A}] * \text{FGREF}[\text{B}])]$$

Note

It is, therefore, possible to use the effective factor for orientation axes `FGREF` to define a reference point on the tool to which the programmed path feedrate refers.

2.7.2 Traverse positioning axes (POS, POSA, POSP, FA, WAITP, WAITMC)

Positioning axes are traversed independently of the path axes at a separate, axis-specific feedrate. There are no interpolation commands. The `POS/POSA/POSP` commands are used to traverse the positioning axes and coordinate the motion sequences at the same time.

The following are typical examples of positioning axes:

- Pallet feed equipment
- Gauging stations

`WAITP` can be used to identify a position in the NC program where the program is to wait until an axis programmed with `POSA` in a previous NC block reaches its end position.

`WAITMC` loads the next NC block immediately when the specified wait marker is received.

Syntax

```
POS[<axis>]=<position>
```

```
POSA[<axis>]=<position>
```

```
POSP[<axis>]=(<end position>,<partial length>,<mode>)
```

```
FA[<axis>]=<value>
```

WAITP (<axis>) ; Programming in a separate NC block.

WAITMC (<wait marker>)

Meaning

POS/POSA:	Move positioning axis to specified position POS and POSA have the same functionality but differ in their block change behavior:		
	<ul style="list-style-type: none"> • POS delays the enabling of the NC block until the position has been reached. • POSA enables the NC block even if the position has not been reached. 		
	<axis>:	Name of the axis to be traversed (channel or geometry axis identifier)	
<position>:	Axis position to be approached		
	Type:	REAL	
POSP:	Move positioning axis to specified end position in sections		
	<end position>:	Axis end position to be approached	
	<partial length>:	Length of a section	
	<mode>:	Approach mode	
		= 0:	For the last two sections, the path remaining until the end position is split into two residual sections of equal size (preset).
= 1:	The partial length is adjusted so that the total of all calculated partial lengths corresponds exactly to the path up to the end position.		
<p>Note: POSP is used specifically to program oscillating motion.</p> <p>References: Programming Manual, Job Planning; Section "Oscillation"</p>			
FA:	Feedrate for the specified positioning axis		
	<axis>:	Name of the axis to be traversed (channel or geometry axis identifier)	
	<value>:	Feedrate	
		Unit:	mm/min or inch/min or degrees/min
<p>Note: Up to five FA values can be programmed for each NC block.</p>			
WAITP:	Wait for a positioning axis to be traversed The subsequent blocks are not processed until the specified positioning axis programmed in a previous NC block with POSA has reached its end position (with exact stop fine).		
	<axis>:	Name of the axis (channel or geometry axis identifier) for which the WAITP command is to be applied	
	<p>Note: With WAITP, an axis can be made available as an oscillating axis or for traversing as a concurrent positioning axis (via PLC).</p>		
WAITMC:	Wait for the specified wait marker to be received When the wait marker is received, the next NC block is loaded immediately.		
	<wait marker>:	Number of the wait marker	

⚠ CAUTION**Travel with POSA**

If a command, which implicitly causes a preprocessing stop, is read in a following block, this block is not executed until all other blocks which are already preprocessed and stored have been executed. The previous block is stopped in exact stop (as G9).

Examples**Example 1: Travel with POSA and access to machine status data**

The control generates an internal preprocessing stop on access to machine status data (\$A...). Machining is stopped until all preprocessed and saved blocks have been executed in full.

Program code	Comment
N40 POSA[X]=100	
N50 IF \$AA_IM[X]==R100 GOTOF LABEL1	; Access to machine status data.
N60 G0 Y100	
N70 WAITP(X)	
N80 LABEL1:	
N...	

Example 2: Wait for end of travel with WAITP

Pallet feed equipment

Axis U: Pallet store

Transport of workpiece pallet to working area

Axis V: Transfer line to a gauging station where spot checks are carried out to assist the process

Program code	Comment
N10 FA[U]=100 FA[V]=100	; Axis-specific feedrate specifications for the individual positioning axes U and V.
N20 POSA[V]=90 POSA[U]=100 G0 X50 Y70	; Traverse positioning and path axes.
N50 WAITP(U)	; Program execution does not resume until axis U reaches the end point programmed in N20.
...	

Further information**Travel with POSA**

Block step enable or program execution is not affected by `POSA`. The movement to the end position can be performed during execution of subsequent NC blocks.

Travel with POS

The next block is not executed until all axes programmed under `POS` reach their end positions.

Wait for end of travel with WAITP

After a `WAITP`, assignment of the axis to the NC program is no longer valid; this applies until the axis is programmed again. This axis can then be operated as a positioning axis through the PLC, or as a reciprocating axis from the NC program/PLC or HMI.

Block change in the braking ramp with IPOBRKA and WAITMC

An axis is only decelerated if the wait marker has not yet been reached or if another end-of-block criterion is preventing the block change. After a `WAITMC`, the axis starts immediately if no other end-of-block criterion is preventing the block change.

2.7.3 Position-controlled spindle mode (SPCON, SPCOF)

With the commands `SPCON` or `SPCOF`, the position-controlled mode of the spindle is explicitly activated or deactivated.

Note

The switching on of the position control mode with `SPCON` requires a maximum of three position control cycles.

Syntax

```

SPCON
SPCON (<n>)
SPCON (<n>, <m>, ... )
SPCOF
SPCOF (<n>)
SPCOF (<n>, <m>, ... )
    
```

Meaning

SPCON:	Activate position-controlled mode The specified spindle is switched over from speed control to position control. <i>SPCON</i> s modal and is retained until <i>SPCOF</i> .
SPCOF:	Deactivate position-controlled mode The specified spindle is switched over from position control to speed control.
<n>, <m>, etc.:	0 ... k spindle numbers Without specification of a spindle number: Master spindle of the channel

Note


For a synchronous spindle with setpoint coupling, the leading spindle must not be switched to speed-controlled mode with `SPCOF`.

References

Function Manual, Extended Functions; Section "S3 Synchronous Spindle"

2.7.4 Positioning spindles (SPOS, SPOSA, M19, M70, WAITS)

`SPOS`, `SPOSA` or `M19` can be used to set spindles to specific angular positions, e.g. during tool change.



`SPOS`, `SPOSA` and `M19` induce a temporary switchover to position-controlled mode until the next `M3/M4/M5/M41` to `M45`.

Positioning in axis mode

The spindle can also be operated as a path axis, synchronized axis or positioning axis at the address defined in the machine data. When the axis identifier is specified, the spindle is in axis mode. `M70` switches the spindle directly to axis mode.

End of positioning

The end-of-motion criterion when positioning the spindle can be programmed using `FINEA`, `CORSEA`, `IPOENDA` or `IPOBRKA`.

The program advances to the next block if the end of motion criteria for all spindles or axes programmed in the current block plus the block change criterion for path interpolation are fulfilled.

Synchronization

In order to synchronize spindle movements, `WAITS` can be used to wait until the spindle position is reached.

Requirements

The spindle to be positioned must be capable of operation in position-controlled mode.

Syntax

Position spindle:

SPOS=<value>/SPOS [<n>]=<value>

SPOSA=<value>/SPOSA [<n>]=<value>

M19/M<n>=19

Switch spindle over to axis mode:

M70/M<n>=70

Define end-of-motion criterion:

FINEA/FINEA [S<n>]

COARSEA/COARSEA [S<n>]

IPOENDA/IPOENDA [S<n>]

IPOBRKA/IPOBRKA (<axis>[, <instant in time>]) ; Programming in a separate NC block.

Synchronize spindle movements:

WAITS/WAITS (<n>, <m>) ; Programming in a separate NC block.

Meaning

SPOS/SPOSA:	<p>Set spindle to specified angle</p> <p>SPOS and SPOSA have the same functionality but differ in their block change behavior:</p> <ul style="list-style-type: none"> • SPOS delays the enabling of the NC block until the position has been reached. • SPOSA enables the NC block even if the position has not been reached. 	
<n>:	<p>Number of the spindle to be positioned.</p> <p>If a spindle number is not specified or if the spindle number is set to "0", SPOS or SPOSA will be applied to the master spindle.</p>	
<value>:	Angular position to which the spindle is to be set.	
	Unit:	Degrees
	Type:	REAL
	The following options are available for programming the position approach mode:	
	=AC (<value>):	Absolute dimensions
		Range of values: 0 ... 359,9999
	=IC (<value>):	Incremental dimensions
		Range of values: 0 ... ±99 999,999
	=DC (<value>):	Approach absolute value directly
=ACN (<value>):	Absolute dimension, approach in negative direction	
=ACP (<value>):	Absolute dimension, approach in positive direction	
=<value>:	as DC (<value>)	
M<n>=19:	<p>Set the master spindle (M19 or M0=19) or spindle number <n> (M<n>=19) to the angular position preset with SD43240 \$SA_M19_SPOS with the position approach mode preset in SD43250 \$SA_M19_SPOSMODE.</p> <p>The NC block is not enabled until the position has been reached.</p>	
M<n>=70:	<p>Switch the master spindle (M70 or M0=70) or spindle number <n> (M<n>=70) over to axis mode.</p> <p>No defined position is approached. The NC block is enabled after the switchover has been performed.</p>	
FINEA:	Motion end when "Exact stop fine" reached	
COARSEA:	Motion end when "Exact stop coarse" reached	
IPOENDA:	End of motion on reaching "interpolator stop"	
S<n>:	Spindle for which the programmed end-of-motion criterion is to be effective	
	<n>:	Spindle number
	If a spindle is not specified in [S<n>] or a spindle number of "0" is specified, the programmed end-of-motion criterion will be applied to the master spindle.	

IPOBRKA:	A block change is possible in the braking ramp.	
	<axis>:	Channel axis identifier
	<instant in time>:	Instant in time of the block change with reference to the braking ramp
		Unit: Percent
	Range of values:	100 (application point of the braking ramp) to 0 (end of the braking ramp)
If a value is not assigned to the <instant in time> parameter, the current value of the setting data is applied: SD43600 \$SA_IPOBRAKE_BLOCK_EXCHANGE Note: IPOBRKA with an instant in time of "0" is identical to IPOENDA.		
WAITS:	Synchronization command for the specified spindle(s) The subsequent blocks are not processed until the specified spindle(s) programmed in a previous NC block with SPOSA has (have) reached its (their) end position(s) (with exact stop fine).	
	WAITS after M5:	Wait for the specified spindle(s) to come to a standstill.
	WAITS after M3/M4:	Wait for the specified spindle(s) to reach their setpoint speed.
	<n>, <m>:	Numbers of the spindles to which the synchronization command is to be applied. If a spindle number is not specified or if the spindle number is set to "0", WAITS will be applied to the master spindle.

Note

Three spindle positions are possible for each NC block.

Note

With incremental dimensions IC (<value>), spindle positioning can take place over several revolutions.

Note

If position control was activated with SPCON prior to SPOS, this remains active until SPCOF is issued.

Note

The control detects the transition to axis mode automatically from the program sequence. Explicit programming of M70 in the part program is, therefore, essentially no longer necessary. However, M70 can continue to be programmed, e.g. to increase the legibility of the part program.

Further information

Positioning with SPOSA

The block step enable or program execution is not affected by SPOSA. The spindle positioning can be performed during execution of subsequent NC blocks. The program moves onto the next block if all the functions (except for spindle) programmed in the current block have reached their block end criterion. The spindle positioning operation may be programmed over several blocks (see WAITS).

Note

If a command, which implicitly causes a preprocessing stop, is read in a following block, execution of this block is delayed until all positioning spindles are stationary.

Positioning with SPOS/M19

The block step enabling condition is met when all functions programmed in the block reach their end-of-block criterion (e.g. all auxiliary functions acknowledged by the PLC, all axes at their end point) and the spindle reaches the programmed position.

Velocity of the movements:

The velocity and the delay response for positioning are stored in the machine data. The configured values can be modified by programming or by synchronized actions, see:

- Feedrate for positioning axes / spindles (FA, FPR, FPRAON, FPRAOF) (Page 124)
- Programmable acceleration compensation (ACC) (Page 128)

Specification of spindle positions:

As the G90/G91 commands are not effective here, the corresponding dimensions apply explicitly, e.g. AC, IC, DC, ACN, ACP. If no specifications are made, traversing automatically takes place as for DC.

Synchronize spindle movements with WAITS

WAITS can be used to identify a point at which the NC program waits until one or more spindles programmed with SPOSA in a previous NC block reach their positions.

Example:

Program code	Comment
N10 SPOSA[2]=180 SPOSA[3]=0	
...	
N40 WAITS(2,3)	; The block waits until spindles 2 and 3 have reached the positions specified in block N10.


WAITS can be used after M5 to wait until the spindle(s) has (have) stopped. WAITS can be used after M3/M4 to wait until the spindle(s) has (have) reached the specified speed/direction of rotation.

Note

If the spindle has not yet been synchronized with synchronization marks, the positive direction of rotation is taken from the machine data (state on delivery).

Position spindle from rotation (M3/M4)

When M3 or M4 is active, the spindle comes to a standstill at the programmed value.



There is no difference between DC and AC dimensioning. In both cases, rotation continues in the direction selected by M3/M4 until the absolute end position is reached. With ACN and ACP, deceleration takes place if necessary, and the appropriate approach direction is taken. With IC, the spindle rotates additionally to the specified value starting at the current spindle position.

Position a spindle from standstill (M5)

The exact programmed distance is traversed from standstill (M5).

2.7.5 Feedrate for positioning axes / spindles (FA, FPR, FPRAON, FPRAOF)

It is also possible to derive the revolutional feedrate for path and synchronized axes or for individual positioning axes/spindles from another rotary axis or spindle.

Positioning axes such as workpiece transport systems, tool turrets and end supports are traversed independently of path and synchronized axes. A separate feedrate is therefore defined for each positioning axis.

A separate axial feedrate can also be programmed for spindles.

Syntax

Feedrate for positioning axis:

```
FA[<axis>]=...
```

Axis feedrate for spindle:

```
FA[SPI (<n>)] = ...
```

```
FA[S<n>] = ...
```

Derive revolutional feedrate for path/synchronized axes:

```
FPR (<rotary axis>)
```

```
FPR(SPI (<n>))
```

FPR (S<n>)

Derive rotational feedrate for positioning axes/spindles:

FPRAON (<axis>, <rotary axis>)

FPRAON (<axis>, SPI (<n>))

FPRAON (<axis>, S<n>)

FPRAON (SPI (<n>), <rotary axis>)

FPRAON (S<n>, <rotary axis>)

FPRAON (SPI (<n>), SPI (<n>))

FPRAON (S<n>, S<n>)

FPRAOF (<axis>, SPI (<n>), etc.)

FPRAOF (<axis>, S<n>, etc.)

Meaning

FA[...]=... :	Feedrate for the specified positioning axis or positioning speed (axial feedrate) for the specified spindle	
	Unit:	mm/min or inch/min or degrees/min
	Range of values:	... 999,999.999 mm/min, degrees/min ... 39 999.9999 inch/min
FPR (...):	FPR is used to identify the rotary axis (<rotary axis>) or spindle (SPI (<n>)/S<n>) from which the revolutional feedrate for the revolutional feedrate of the path and synchronized axes programmed under G95 is to be derived.	
FPRAON (...):	Derive rotational feedrate for positioning axes and spindles The first parameter (<axis>/SPI (<n>)/S<n>) identifies the positioning axis/spindle to be traversed with revolutional feedrate. The second parameter (<rotary axis>/SPI (<n>)/S<n>) identifies the rotary axis/spindle from which the revolutional feedrate is to be derived. Note: The second parameter can be omitted, in which case the feedrate will be derived from the master spindle.	
FPRAOF (...):	FPRAOF is used to deselect the derived revolutional feedrate for the specified axes or spindles.	
<axis>:	Axis identifier (positioning or geometry axis)	
SPI (<n>)/S<n>:	Spindle identifier SPI (<n>) and S<n> are identical in terms of function.	
	<n>:	Spindle number
	Note: SPI converts spindle numbers into axis identifiers. The transfer parameter (<n>) must contain a valid spindle number.	

Note

The programmed feedrate FA[...] is modal.

Up to five feedrates for positioning axes or spindles can be programmed in each NC block.

Note

The derived feedrate is calculated according to the following formula:

Derived feedrate = programmed feedrate * absolute master feedrate

Examples

Example 1: Synchronous spindle coupling

With synchronous spindle coupling, the positioning speed of the following spindle can be programmed independently of the master spindle, e.g. for positioning operations.

Program code	Comment
...	
FA[S2]=100	; Positioning speed of the following spindle (spindle 2) = 100 degrees/min
...	

Example 2: Derived revolutional feedrate for path axes

Path axes X, Y must be traversed at the revolutional feedrate derived from rotary axis A:

Program code
...
N40 FPR(A)
N50 G95 X50 Y50 F500
...

Example 3: Derive revolutional feedrate for master spindle

Program code	Comment
N30 FPRAON(S1,S2)	; The revolutional feedrate for the master spindle (S1) must be derived from spindle 2.
N40 SPOS=150	; Position master spindle.
N50 FPRAOF(S1)	; Deselect derived revolutional feedrate for the master spindle.

Example 4: Derive revolutional feedrate for positioning axis

Program code	Comment
N30 FPRAON(X)	; The revolutional feedrate for positioning axis X must be derived from the master spindle.
N40 POS[X]=50 FA[X]=500	; The positioning axis is traversing at 500 mm/revolution of the master spindle.
N50 FPRAOF(X)	

Further information**FA[...]**

The feedrate type is always G94. When G70/G71 is active, the unit is metric/inches according to the default setting in the machine data. G700/G710 can be used to modify the unit in the program.

Note

If no FA is programmed, the value defined in the machine data applies.

FPR(...)

As an extension of the G95 command (revolutional feedrate referring to the master spindle), FPR allows the revolutional feedrate to be derived from any chosen spindle or rotary axis. G95 FPR (...) is valid for path and synchronized axes.

If the rotary axis/spindle specified in the FPR command is operating on position control, then the setpoint linkage is active. Otherwise the actual-value linkage is effective.

FPRAON(...)

FPRAON is used to derive the revolutional feedrate for positioning axes and spindles from the current feedrate of another rotary axis or spindle.

FPRAOF(...)

The revolutional feedrate can be deactivated for one or a number of axes/spindles simultaneously with the FPRAOF command.

2.7.6 Programmable feedrate override (OVR, OVERRAP, OVRA)

The velocity of path/positioning axes and speed of spindles can be modified in the NC program.

Syntax

```
OVR=<value>
OVERRAP=<value>
OVRA [<axis>]=<value>
OVRA [SPI (<n>)] =<value>
OVRA [S<n>]=<value>
```

Meaning

OVR:	Feedrate modification for path feedrate F
OVRRAP:	Feedrate modification for rapid traverse velocity
OVRA:	Feedrate modification for positioning feedrate F_A or for spindle speed S
<axis>:	Axis identifier (positioning or geometry axis)
SPI (<n>)/S<n>:	Spindle identifier SPI (<n>) and S<n> are identical in terms of function.
<n>:	Spindle number
	Note: SPI converts spindle numbers into axis identifiers. The transfer parameter (<n>) must contain a valid spindle number.
<value>:	Feedrate modification in percent The value refers to or is combined with the feedrate override set on the machine control panel.
	Range of values: 0 ... 200%, integral
	Note: With path and rapid traverse override, the maximum velocities set in the machine data is not overshoot.

2.7.7 Programmable acceleration compensation (ACC)

In critical program sections, it may be necessary to limit the acceleration to below the maximum values, e.g. to prevent mechanical vibrations from occurring.

The programmable acceleration override can be used to modify the acceleration for each path axis or spindle via a command in the NC program. The limit is effective for all types of interpolation. The values defined in the machine data apply as 100% acceleration.

Syntax

```
ACC [<axis>]=<value>
ACC [SPI (<n>)] =<value>
ACC (S<n>) =<value>
```

Deactivate:
ACC [...] =100

Syntax

ACC:	Acceleration change for the specified path axis or speed change for the specified spindle.
<axis>:	Channel axis name of path axis

SPI (<n>)/S<n>:	Spindle identifier SPI (<n>) and S<n> are identical in terms of function.	
	<n>:	Spindle number
	Note: SPI converts spindle numbers into axis identifiers. The transfer parameter (<n>) must contain a valid spindle number.	
<value>:	Acceleration change in percent The value refers to or is combined with the feedrate override set on the machine control panel.	
	Range of values:	1 to 200%, integers

Note

With a greater acceleration rate, the values permitted by the manufacturer may be exceeded.

Example

Program code	Comment
N50 ACC[X]=80	; The axis slide in the X direction should only be traversed with 80% acceleration.
N60 ACC[SPI(1)]=50	; Spindle 1 should only accelerate or brake with 50% of the acceleration capacity.

Further information**Acceleration override programmed with ACC**

The acceleration override programmed with ACC[. . .] is always taken into consideration on output as in system variable \$AA_ACC. Readout in the parts program and in synchronized actions takes place at different times in the NC processing run.

In the part program

The value written in the part program is then only taken into consideration in system variable \$AA_ACC as written in the part program if ACC has not been changed in the meantime by a synchronized action.

In synchronized actions

The following thus applies: The value written to a synchronized action is then only considered in system variable \$AA_ACC as written to the synchronized action if ACC has not been changed in the meantime by a part program.

The preset acceleration can also be changed via synchronized actions (see Function Manual, Synchronized Actions).

Example:

Program code
...
N100 EVERY \$A_IN[1] DO POS[X]=50 FA[X]=2000 ACC[X]=140

The current acceleration value can be called with system variable \$AA_ACC[<axis>]. Machine data can be used to define whether the last ACC value set should apply on RESET/part program end or whether 100% should apply.

2.7.8 Feedrate with handwheel override (FD, FDA)

The FD and FDA commands can be used to traverse axes with handwheels during execution of the part program. The programmed settings for traversing the axes are then overlaid with the handwheel pulses evaluated as path or velocity defaults.

Path axes

In the case of path axes, the programmed path feedrate can be overlaid. The handwheel of the 1st geometry axis of the channel is evaluated. The handwheel pulses evaluated per interpolation cycle dependent on the direction of rotation correspond to the path velocity to be overlaid. The path velocity limit values which can be achieved by means of handwheel override are:

- Minimum: 0
- Maximum: Machine data limit values of the path axes involved in traversing

Note

Path feedrate

The path feedrate F and the handwheel feedrate FD cannot be programmed in the same NC block.

Positioning axes

In the case of positioning axes, the travel path or velocity can be overlaid as an axial value. The handwheel assigned to the axis is evaluated.

- Path override

The handwheel pulses evaluated dependent on the direction of rotation correspond to the axis path to be traveled. Only handwheel pulses in the direction of the programmed position are evaluated.
- Velocity override

The handwheel pulses evaluated per interpolation cycle dependent on the direction of rotation correspond to the axial velocity to be overlaid. The path velocity limit values which can be achieved by means of handwheel override are:

 - Minimum: 0
 - Maximum: Machine data limit values of the positioning axis

A detailed description of how to set handwheel parameters appears in:

Reference

/FB2/ Function Manual Extended Functions; manual traversing and manual handwheel travel (H1)

Syntax

```
FD=<velocity>
FDA[<axis>]=<velocity>
```

Meaning

FD=<velocity>:

Path feedrate and enabling of velocity override with handwheel

<velocity>:

- Value = 0: Not allowed!
- Value ≠ 0: Path velocity

FDA[<axis>]=<velocity>:

Axial feedrate

<velocity>:

- Value = 0: Path default with handwheel
- Value ≠ 0: Axial velocity


<axis>:

Axis identifier of positioning axis

Note

FD and FDA are non-modal.

Example



Path definition: The grinding wheel oscillating in the Z direction is traversed to the workpiece in the X direction with the handwheel.

The operator can continue to feed manually until the sparks are flying uniformly. Activating "Delete distance-to-go" switches to the next NC block and machining continues in AUTOMATIC mode.

Further information

Traverse path axes with velocity override (FD=<velocity>)

The following conditions must be met for the part program block in which path velocity override is programmed:

- Path command G1, G2 or G3 active
- Exact stop G60 active
- Linear feedrate G94 active

Feedrate override


The feedrate override only affects the programmed path velocity and not the velocity component generated with the handwheel (exception: (except if feed override = 0).

Example:

Program code	Description
N10 X... Y... F500	; Feedrate = 500 mm/min
N20 X... Y... FD=700	; Feedrate = 700 mm/min and velocity override with handwheel. ; Acceleration from 500 to 700 mm/min in N20. The handwheel can be used to vary the speed dependent on the direction of rotation between 0 and the maximum value (machine data).

Traverse positioning axes with path default (FDA[<axis>]=0)

In the NC block with programmed FDA[<axis>]=0 the feed is set to zero so that the program cannot generate any travel movement. The programmed travel movement to the target position is now controlled exclusively by the operator rotating the handwheel.



Example:

Program code	Description
...	
N20 POS[V]=90 FDA[V]=0	; Target position = 90 mm, axial feedrate = 0 mm/min and path override with handwheel. ; Velocity of axis V at start of block = 0 mm/min. ; Path and speed defaults are set using handwheel pulses

Direction of movement, travel velocity

The axes follow the path set by the handwheel in the direction of the sign. Forward and backwards travel is possible dependent on the direction of rotation. The faster the handwheel rotates, the higher the traversing speed.

Traversing range:

The traversing range is limited by the starting position and the programmed end point.

Traverse positioning axis with velocity override (FDA[<axis>]=<velocity>)

In NC blocks with programmed FDA[...]=..., the feedrate from the last programmed FA value is accelerated or decelerated to the value programmed under FDA. Starting from the current feedrate FDA, the handwheel can be turned to accelerate the programmed movement to the target position or decelerate it to zero. The values set as parameters in the machine data serve as the maximum velocity.

Example:

Program code	Description
N10 POS[V]=... FA[V]=100	; Axial feedrate = 100 mm/min
N20 POS[V]=100 FDA[V]=200	; Axial target position = 100, axial feedrate = 200 mm/min ; and velocity override with handwheel. ; Acceleration from 100 to 200 mm/min in N20. The ; Handwheel can be used to vary the velocity depending on the direction of rotation ; between 0 and the maximum value (machine data).

Traversing range:


The traversing range is limited by the starting position and the programmed end point.

2.7.9 Feedrate optimization for curved path sections (CFTCP, CFC, CFIN)

With activated correction mode G41/G42, the programmed feedrate for the milling tool radius first refers to the milling tool center path (refer to Chapter "Coordinate transformations (frames) (Page 300)").

When you mill a circle (the same applies to polynomial and spline interpolation) the extent to which the feedrate varies at the cutter edge is so significant under certain circumstances that it can impair the quality of the machined part.

Example: Milling a small outside radius with a large tool. The path that the outside of the milling tool must travel is considerably longer than the path along the contour.



Because of this, machining at the contour takes place with a very low feedrate. To prevent adverse effects, the feedrate needs to be controlled accordingly for curved contours.


Syntax

CFTCP
 CFC
 CFIN

Meaning

CFTCP:	Constant feedrate on the milling cutter center path The control keeps the feedrate constant and feedrate overrides are deactivated.
CFC:	Constant feedrate at the contour (tool cutting edge). This function is preset per default.
CFIN:	Constant feedrate at the tool cutting edge only at concave contours, otherwise on the milling cutter center path. The feedrate is reduced for inside radii.

Example




In this example, the contour is first produced with CFC-corrected feedrate. During finishing, the cutting base is also machined with CFIN. This prevents the cutting base being damaged at the outside radii by a feedrate that is too high.

Program code	Comment
N10 G17 G54 G64 T1 M6	
N20 S3000 M3 CFC F500 G41	
N30 G0 X-10	
N40 Y0 Z-10	; Feed to first cutting depth
N50 CONTOUR1	; Subprogram call
N40 CFIN Z-25	; Feed to second cutting depth
N50 CONTOUR1	; Subprogram call
N60 Y120	
N70 X200 M30	

Further information

Constant feedrate on contour with CFC



The feedrate is reduced for inside radii and increased for outside radii. This ensures a constant speed at the tool edge and thus at the contour.

2.7.10 Several feedrate values in one block (F, ST, SR, FMA, STA, SRA)

The "Multiple feedrates in one block" function can be used to activate different feedrate values for an NC block, a dwell time or a retraction motion-synchronously, dependent on external digital and/or analog inputs.

Syntax

Path motion

F=... F7=... F6=... F5=... F4=... F3=... F2=... ST=... SR=...

Axial motion:

FA [<Ax>]=... FMA [7, <Ax>]=... FMA [6, <Ax>]=... FMA [5, <Ax>]=...
 FMA [4, <Ax>]=... FMA [3, <Ax>]=... FMA [2, <Ax>]=... STA [<Ax>]=...
 SRA [<Ax>]=...

Meaning

F=... :	The path feedrate is programmed under the address F and remains valid during the absence of an input signal.
	Effective: Modal
F2=... to F7=... :	In addition to the path feedrate, up to six further feedrates can be programmed in the block. The numerical expansion indicates the bit number of the input that activates the feedrate when changed:
	Effective: Non-modal

ST= . . . :	Dwell time in s (for grinding technology: sparking-out time)	
	Input bit:	1
	Effective:	Non-modal
SR= . . . :	Retraction path The unit for the retraction path refers to the current valid unit of measurement (mm or inch).	
	Input bit:	0
	Effective:	Non-modal
FA [<Ax>] = . . . :	The axial feedrate is programmed under the address FA and remains valid during the absence of an input signal.	
	Effective:	Modal
FMA [2, <Ax>] = . . . to FMA [7, <Ax>] = . . . :	In addition to the axial feedrate FA up to six further feedrates per axis can be programmed in the block with FMA. The first parameter indicates the bit number of the input and the second the axis for which the feedrate is to apply.	
	Effective:	Non-modal
STA [<Ax>] = . . . :	Axial dwell time in s (for grinding technology: sparking-out time)	
	Input bit:	1
	Effective:	Non-modal
SRA [<Ax>] = . . . :	Axial retraction path	
	Input bit:	0
	Effective:	Non-modal
<Ax>:	Axis for which the feedrate is to apply	

Note**Priority of the signals**

The signals are scanned in ascending order starting at input bit 0 (I0). Therefore, the retraction motion has the highest priority and the feedrate F7 the lowest priority. Dwell time and retraction motion end the feedrate motions that were activated with F2 to F7.

The signal with the highest priority determines the current feedrate.

Note**Delete distance-to-go**

If input bit 1 is activated for the dwell time or bit 0 for the return path, the distance to go for the path axes or the relevant single axes is deleted and the dwell time or return started.

Note

Retraction path

The unit for the retraction path refers to the current valid unit of measurement (mm or inch).

The reverse stroke is always made in the opposite direction to the current motion. SR/SRA always programs the value for the reverse stroke. No sign is programmed.

Note

POS instead of POSA

If feedrates, dwell time or return path are programmed for an axis on account of an external input, this axis must not be programmed as POSA axis (positioning axis over multiple blocks) in this block.

Note

Status query

It is also possible to poll the status of an input for synchronous commands of various axes.

Note

LookAhead

Look Ahead is also active for multiple feedrates in one block. In this way, the current feedrate can be restricted by the Look Ahead value.

Examples

Example 1: Path motion

Program code	Comment
G1 X48 F1000 F7=200 F6=50 F5=25 F4=5 ST=1.5 SR=0.5	; Path feedrate = 1000 ; Additional path feedrate values: ; 200 (input bit 7) ; 50 (input bit 6) ; 25 (input bit 5) ; 5 (input bit 4) ; Dwell time 1.5 s ; Retraction 0.5 mm

Example 2: Axial motion

Program code	Comment
POS[A]=300 FA[A]=800 FMA[7,A]=720 FMA[6,A]=640	; Feedrate for axis A = 800
FMA[5,A]=560 STA[A]=1.5 SRA[A]=0.5	; Additional feedrate values for axis A: 720 (input bit 7) ; 640 (input bit 6) ; 560 (input bit 5) ; Axial dwell time: 1.5 s ; Axial retraction: 0.5 mm

Example 3: Multiple operations in one block

Program code	Comment
N20 T1 D1 F500 G0 X100	Initial setting
N25 G1 X105 F=20 F7=5 F3=2.5 F2=0.5 ST=1.5 SR=0.5	; Normal feedrate with F, ; roughing with F7, ; finishing with F3, ; smooth-finishing with F2, ; dwell time 1.5 s, ; retraction path 0.5 mm
...	

2.7.11 Non-modal feedrate (FB)

The "Non-modal feedrate" function can be used to define a separate feedrate for a single block. After this block, the previous modal feedrate is active again.

Syntax

FB=<value>

Meaning

FB:	Feedrate for current block only
<VALUE>:	The programmed value must be greater than zero. Values are interpreted based on the active feedrate type: <ul style="list-style-type: none"> • G94: feedrate in mm/min or degrees/min • G95: feedrate in mm/rev or inch/rev • G96: constant cutting rate

Note

If no traversing motion is programmed in the block (e.g. computation block), the **FB** has no effect.

If no explicit feedrate for chamfering/rounding is programmed, then the value of **FB** also applies for any chamfering/rounding contour element in this block.


Feedrate interpolations **FLIN**, **FCUB**, etc. are also possible without restriction.

Simultaneous programming of **FB** and **FD** (handwheel travel with feedrate override) or **F** (modal path feedrate) is **not** possible.

Example

Program code	Comment
N10 G0 X0 Y0 G17 F100 G94	;Initial setting
N20 G1 X10	; Feedrate 100 mm/min
N30 X20 FB=80	; Feedrate 80 mm/min
N40 X30	; Feedrate is 100 mm/min again.
...	

2.7.12 Tooth feedrate (G95 FZ)



The control uses the \$TC_DPNT (number of teeth) tool parameter associated with the active tool offset data block to calculate the effective revolutional feedrate for each traversing block from the programmed tooth feedrate.

$$F = FZ * \$TC_DPNT$$

with: F: Revolutional feedrate in mm/rev or inch/rev
 FZ: Tooth feedrate in mm/tooth or inch/tooth
 \$TC_DPNT: System variable tool parameter: Number of teeth/rev

The tool type (\$TC_DP1) of the active tool is not taken into account.

The programmed tooth feedrate is independent of the tool change and the selection/deselection of a tool offset data block; it is retained in modal format.

A change to the \$TC_DPNT tool parameter associated with the active tool cutting edge will be applied the next time a tool offset is selected or the next time the active offset data is updated.

Changing the tool or selecting/deselecting a tool offset data block generates a recalculation of the effective revolutional feedrate.

Note

The tooth feedrate refers only to the path (axis-specific programming is not possible).

Syntax

G95 FZ...

Meaning

G95:	Type of feedrate: Revolutional feedrate in mm/rev or inch/rev (dependent upon G700/G710) For G95 see "Feedrate (G93, G94, G95, F, FGROUP, FL, FGROUP) (Page 107)"	
FZ:	Tooth feedrate	
	Activation:	with G95
	Effectiveness:	Modal
	Unit:	mm/tooth or inch/tooth (dependent upon G700/G710)

NOTICE

Tool change/Changing the master spindle

A subsequent tool change or changing the master spindle must be taken into account by the user by means of corresponding programming, e.g. reprogramming FZ.

NOTICE

Tool operations undefined

Technological concerns such as climb milling or conventional milling, front face milling or peripheral face milling, etc., along with the path geometry (straight line, circle, etc.), are not taken into account automatically. Therefore, these factors have to be given consideration when programming the tooth feedrate.

Note

Switchover between G95 F... and G95 FZ...

With switchover between G95 F . . . (revolution feedrate) and G95 FZ . . . (tooth feedrate), the inactive feedrate value is deleted in each case.

Note

Derive feedrate with FPR

As is the case with the revolutional feedrate, FPR can also be used to derive the tooth feedrate of any rotary axis or spindle (see "Feedrate for positioning axes / spindles (FA, FPR, FPRAON, FPRAOF) (Page 124)").

Examples

Example 1: Milling cutter with 5 teeth (\$TC_DPNT = 5)

Program code	Comment
N10 G0 X100 Y50	
N20 G1 G95 FZ=0.02	; Tooth feedrate 0.02 mm/tooth
N30 T3 D1	; Load tool and activate tool offset data block.
M40 M3 S200	; Spindle speed 200 rpm
N50 X20	; Milling with:
	FZ = 0.02 mm/tooth
	effective revolutional feedrate:
	F = 0.02 mm/tooth * 5 teeth/rev = 0.1 mm/rev
	or
	F = 0.1 mm/rev * 200 rpm = 20 mm/min
...	

Example 2: Switchover between G95 F... and G95 FZ...

Program code	Comment
N10 G0 X100 Y50	
N20 G1 G95 F0.1	; Revolutional feedrate 0.1 mm/rev
N30 T1 M6	
N35 M3 S100 D1	
N40 X20	
N50 G0 X100 M5	

Program code	Comment
N60 M6 T3 D1	; Load tool with e.g. five teeth (\$TC_DPNT = 5).
N70 X22 M3 S300	
N80 G1 X3 G95 FZ=0.02	; Change G95 F... to G95 FZ..., tooth feedrate active with 0.02 mm/tooth.
...	

Example 3: Derive tooth feedrate of a spindle (FBR)

Program code	Comment
...	
N41 FPR(S4)	; Tool in spindle 4 (not the master spindle).
N51 G95 X51 FZ=0.5	; Tooth feedrate 0.5 mm/tooth dependent upon spindle S4.
...	

Example 4: Subsequent tool change

Program code	Comment
N10 G0 X50 Y5	
N20 G1 G95 FZ=0.03	; Tooth feedrate 0.03 mm/tooth
N30 M6 T11 D1	; Load tool with e.g. seven teeth (\$TC_DPNT = 7).
N30 M3 S100	
N40 X30	; Effective revolutional feedrate 0.21 mm/rev
N50 G0 X100 M5	
N60 M6 T33 D1	; Load tool with e.g. five teeth (\$TC_DPNT = 5).
N70 X22 M3 S300	
N80 G1 X3	; Tooth feedrate modal 0.03 mm/tooth, effective revolutional feedrate 0.15 mm/rev
...	

Example 5: Changing the master spindle

Program code	Comment
N10 SETMS (1)	; Spindle 1 is the master spindle.
N20 T3 D3 M6	; Tool 3 is changed to spindle 1.
N30 S400 M3	; Speed S400 of spindle 1 (and therefore T3).
N40 G95 G1 FZ0.03	; Tooth feedrate 0.03 mm/tooth
N50 X50	; Path motion, the effective feedrate is dependent upon: - The tooth feedrate FZ - The speed of spindle 1 - The number of teeth of the active tool T3
N60 G0 X60	
...	
N100 SETMS (2)	; Spindle 2 becomes the master spindle.
N110 T1 D1 M6	; Tool 1 is changed to spindle 2.
N120 S500 M3	; Speed S500 of spindle 2 (and therefore T1).

Program code	Comment
N130 G95 G1 FZ0.03 X20	; Path motion, the effective feedrate is dependent upon: - The tooth feedrate FZ - The speed of spindle 2 - The number of teeth of the active tool T1

Note

Following the change in the master spindle (N100), a tool actuated by spindle 2 must be substituted (N110).

Further information

Changing between G93, G94 and G95

FZ can also be programmed when G95 is not active, although it will have no effect and is deleted when G95 is selected. In other words, when changing between G93, G94, and G95, in the same way as with F, the FZ value is also deleted.

Reselection of G95

Reselecting G95 when G95 is already active has no effect (unless a change between F and FZ has been programmed).

Non-modal feedrate (FB)

When G95 FZ . . . (modal) is active, a non-modal feedrate FB . . . is interpreted as a tooth feedrate.

SAVE mechanism

In subprograms with the SAVE attribute FZ is written to the value prior to the subprogram starting (in the same way as F).

Multiple feedrate values in one block

The "Multiple feedrate values in one block" function is not possible with tooth feedrate.

Synchronized actions

FZ cannot be programmed from synchronized actions.

Read tooth feedrate and path feedrate type

The tooth feedrate and the path feedrate type can be read using system variables.

- With preprocessing stop in the part program via system variables:

	\$AC_FZ	Tooth feedrate effective when the current main run block was pre-processed.	
	\$AC_F_TYPE	Path feedrate type effective when the current main run block was pre-processed.	
		Value:	Meaning:
		0	mm/min
		1	mm/rev
		2	inch/min
		3	inch/rev
		11	mm/tooth
	33	inch/tooth	

- Without preprocessing stop in the part program via system variables:

	\$P_FZ	Programmed tooth feedrate	
	\$P_F_TYPE	Programmed path feedrate type	
		Value:	Meaning:
		0	mm/min
		1	mm/rev
		2	inch/min
		3	inch/rev
		11	mm/tooth
	33	inch/tooth	

Note

If G95 is not active, the \$P_FZ and \$AC_FZ variables will always return a value of zero.

2.8 Geometry settings

2.8.1 Settable zero offset (G54 to G57, G505 to G599, G53, G500, SUPA, G153)

The G54 to G57 and G505 to G599 commands activate the settable work offsets for offsetting the workpiece coordinate system compared with the basic coordinate system set from the user interface.

Syntax

Switching on:

G54
 ...
 G57
 G505
 ...
 G599

Switching off or suppressing:


G500 / G53 / G153 / SUPA

Meaning

G54 to G57:	Call of the 1st to 4th settable work offset (WO)	
G505 to G599:	Call of the 5th to 99th settable work offset	
G500:	Deactivation of the current settable work offset	
	G500=Zero frame: (default setting; contains no offset, rotation, mirroring or scaling)	Deactivation of the settable work offset until the next call, activation of the entire basic frame (\$P_ACTBFRAME).
	G500 not equal to 0:	Activation of the first settable work offset (\$P_UIFR[0]) and activation of the entire basic frame (\$P_ACTBFRAME) or possibly a modified basic frame is activated.
G53:	G53 suppresses the settable work offset and the programmable work offset non-modally.	
G153:	G153 has the same effect as G53 and also suppresses the entire basic frame.	
SUPA:	SUPA has the same effect as G153 and also suppresses:	
	<ul style="list-style-type: none"> • Handwheel offsets (DRF) • Overlaid movements • External work offset • PRESET offset 	

Example

Three workpieces that are arranged on a palette according to the work offset values G54 to G56 are to be machined in succession. The machining sequence is programmed in subprogram L47.



Program code	Comment
N10 G0 G90 X10 Y10 F500 T1	; Approach
N20 G54 S1000 M3	; Call of the first WO, spindle clockwise
N30 L47	; Program pass as subprogram
N40 G55 G0 Z200	; Call of the second WO, Z via obstruction
N50 L47	; Program pass as subprogram
N60 G56	; Call of the third WO
N70 L47	; Program pass as subprogram
N80 G53 X200 Y300 M30	; Suppress work offset, end of program


2.8.2 Settable work offset (G54 to G57, G505 to G599, G53, G500, SUPA, G153): Further information

Further information

Settable work offset

A settable work offset is in principle a set frame (Page 300). Consequently, the following components and frame values are also available for a settable work offset:

- Offset
- Rotation
- Scaling
- Scale



- ① Initial position in the BCS
- ② Offset
- ③ Offset + rotation
- ④ Offset + scaling

The frame values for the settable work offsets are input from the user interface:
 SINUMERIK Operate: "Parameters" > "Work offsets" > "Details" operating area

Parameterized number of parameterizable frames (G505 - G599)

The number of user-specific settable work offsets (G505 - G599) can be set for each specific channel via:

```
MD28080 $MC_MM_NUM_USER_FRAMES = <number>
```


See also

Programmable work offset (G58, G59) (Page 309)

2.8.3 Selection of the working plane (G17/G18/G19)

The specification of the working plane, in which the desired contour is to be machined, also defines the following functions:

- The plane for tool radius compensation
- The infeed direction for tool length offset depending on the tool type
- The plane for circular interpolation



Syntax

G17/G18/G19, etc.

Meaning

G17:	Working plane X/Y Infeed direction Z, plane selection 1st - 2nd geometry axis
G18:	Working plane Z/X Infeed direction Y, plane selection 3rd - 1st geometry axis
G19:	Working plane Y/Z Infeed direction X, plane selection 2nd - 3rd geometry axis

Note

In the default setting, G17 (X/Y plane) is defined for milling and G18 (Z/X plane) is defined for turning.

When calling the tool path correction G41/G42 (see Section "Tool radius compensation (Page 246)"), the working plane must be defined so that the control can correct the tool length and radius.

Example

The "conventional" approach for milling is:

1. Define working plane (G17 default setting for milling).
2. Select tool type (T) and tool offset values (D).
3. Switch on path correction (G41).
4. Program traversing movements.


Program code	Comment
N10 G17 T5 D8	; Call of working plane X/Y, tool call. Tool length offset is performed in the Z direction.
N20 G1 G41 X10 Y30 Z-5 F500	; Radius compensation is performed in the X/Y plane.
N30 G2 X22.5 Y40 I50 J40	; Circular interpolation / tool radius compensation in the X/Y plane.

Further information

General

It is recommended that the working plane G17 to G19 be selected at the start of the program. In the default setting, the Z/X plane is preset for turning G18.

Turning:



The control requires the specification of the working plane for the calculation of the direction of rotation (see circular interpolation G2/G3).


Machining on inclined planes

Rotate the coordinate system with ROT (see Section "Coordinate system offset") to position the coordinate axes on the inclined surface. The working planes rotate accordingly.

Tool length compensation on inclined planes

As a general rule, the tool length compensation always refers to the fixed, non-rotated working plane.

Milling:



Note

The tool length components can be calculated according to the rotated working planes with the functions for "Tool length compensation for orientable tools".

The compensation plane is selected with CUT2D, CUT2DF. For further information on this and for the description of the available calculation methods, see Chapter "Tool radius compensation (Page 246)".

The control provides convenient coordinate transformation functions for the spatial definition of the working plane. Please see Chapter "Coordinate transformations (frames) (Page 300)" for more information.

2.8.4 Dimensions

The basis of most NC programs is a workpiece drawing with specific dimensions.

These dimensions can be:

- In absolute dimensions or in incremental dimensions
- In millimeters or inches
- In radius or diameter (for turning)

Specific programming commands are available for the various dimension options so that the data from a dimension drawing can be transferred directly (without conversion) to the NC program.

2.8.4.1 Absolute dimensions (G90, AC)

With absolute dimensions, the position specifications always refer to the zero point of the currently valid coordinate system, i.e. the absolute position is programmed, on which the tool is to traverse.

Modal absolute dimensions

Modal absolute dimensions are activated with the G90 command. Generally it applies to all axes programmed in subsequent NC blocks.

Non-modal absolute dimensions

With preset incremental dimensions (G91), the AC command can be used to set non-modal absolute dimensions for individual axes.

Note

Non-modal absolute dimensions (AC) are also possible for spindle positioning (SPOS, SPOSA) and interpolation parameters (I, J, K).

Syntax


```
G90
<axis>=AC (<value>)
```

Meaning

G90:	Command for the activation of modal absolute dimensions
AC:	Command for the activation of non-modal absolute dimensions
<axis>:	Axis identifier of the axis to be traversed
<value>:	Position setpoint of the axis to be traversed in absolute dimensions

Examples

Example 1: Milling




Program code	Comment
N10 G90 G0 X45 Y60 Z2 T1 S2000 M3	; Absolute dimension input, in rapid traverse to position XYZ, tool selection, spindle on with clockwise direction of rotation.
N20 G1 Z-5 F500	; Linear interpolation, feed of the tool.
N30 G2 X20 Y35 I=AC(45) J=AC(35)	; Clockwise circular interpolation, circle end point and circle center point in absolute dimensions.
N40 G0 Z2	; Traverse
N50 M30	; End of block

Note

For information on the input of the circle center point coordinates I and J, see Section "Circular interpolation".

Example 2: Turning



Program code	Comment
N5 T1 D1 S2000 M3	; Loading of tool T1, spindle on with clockwise direction of rotation.
N10 G0 G90 X11 Z1	; Absolute dimension input, in rapid traverse to position XZ.
N20 G1 Z-15 F0.2	; Linear interpolation, feed of the tool.
N30 G3 X11 Z-27 I=AC(-5) K=AC(-21)	; Counter-clockwise circular interpolation, circle end point and circle center point in absolute dimensions.
N40 G1 Z-40	; Traverse
N50 M30	; End of block

Note

For information on the input of the circle center point coordinates I and J, see Section "Circular interpolation".

See also

Absolute and incremental dimensions for turning and milling (G90/G91) (Page 157)

2.8.4.2 Incremental dimensions (G91, IC)

With incremental dimensions, the position specification refers to the last point approached, i.e. the programming in incremental dimensions describes by how much the tool is to be traversed.

Modal incremental dimensions

Modal incremental dimensions are activated with the G91 command. Generally it applies to all axes programmed in subsequent NC blocks.

Non-modal incremental dimensions

With preset absolute dimensions (G90), the IC command can be used to set non-modal incremental dimensions for individual axes.

Note

Non-modal incremental dimensions (IC) are also possible for spindle positioning (SPOS, SPOSA) and interpolation parameters (I, J, K).

Syntax

```
G91
<axis>=IC (<value>)
```

Meaning

G91:	Command for the activation of modal incremental dimensions
IC:	Command for the activation of non-modal incremental dimensions
<axis>:	Axis identifier of the axis to be traversed
<value>:	Position setpoint of the axis to be traversed in incremental dimensions

G91 extension

For certain applications, such as scratching, it is necessary that only the programmed distance is traversed in incremental dimensions. The active zero offset or tool length offset is not traversed.

This behavior can be set separately for the active zero offset and tool length offset via the following setting data:


SD42440 \$SSC_FRAME_OFFSET_INCR_PROG (zero offsets in frames)

SD42442 \$SSC_TOOL_OFFSET_INCR_PROG (tool length offsets)

Value	Meaning
0	With incremental programming (incremental dimensions) of an axis, the zero offset or the tool length offset is not traversed.
1	With incremental programming (incremental dimensions) of an axis, the zero offset or the tool length offset is traversed.

Examples

Example 1: Milling




Program code	Comment
N10 G90 G0 X45 Y60 Z2 T1 S2000 M3	; Absolute dimension input, in rapid traverse to position XYZ, tool selection, spindle on with clockwise direction of rotation
N20 G1 Z-5 F500	; Linear interpolation, feed of the tool.
N30 G2 X20 Y35 I0 J-25	; Clockwise circular interpolation, circle end point in absolute dimensions, circle center point in incremental dimensions.
N40 G0 Z2	; Traverse
N50 M30	; End of block

Note

For information on the input of the circle center point coordinates I and J, see Section "Circular interpolation".

Example 2: Turning



Program code	Comment
N5 T1 D1 S2000 M3	; Loading of tool T1, spindle on with clockwise direction of rotation.
N10 G0 G90 X11 Z1	; Absolute dimension input, in rapid traverse to position XZ.
N20 G1 Z-15 F0.2	; Linear interpolation, feed of the tool.
N30 G3 X11 Z-27 I-8 K-6	; Counter-clockwise circular interpolation, circle end point in absolute dimensions, circle center point in incremental dimensions.
N40 G1 Z-40	; Traverse
N50 M30	; End of block

Note

For information on the input of the circle center point coordinates I and J, see Section "Circular interpolation".

Example 3: Incremental dimensions without traversing of the active zero offset

Settings:

- G54 contains an offset in X of 25
- SD42440 \$SSC_FRAME_OFFSET_INCR_PROG = 0

Program code	Comment
N10 G90 G0 G54 X100	
N20 G1 G91 X10	; Incremental dimensions active, traversing in X of 10 mm (the zero offset is not traversed).

Program code	Comment
N30 G90 X50	; Absolute dimensions active, traverse to position X75 (the zero offset is traversed).


See also

Absolute and incremental dimensions for turning and milling (G90/G91) (Page 157)


2.8.4.3 Absolute and incremental dimensions for turning and milling (G90/G91)

The two following figures illustrate the programming with absolute dimensions (G90) or incremental dimensions (G91) using turning and milling technology examples.

Milling:



Turning:




Note

On conventional turning machines, it is usual to consider incremental traversing blocks in the transverse axis as radius values, while diameter specifications apply for the reference dimensions. This conversion for G90 is performed using the commands DIAMON, DIAMOF or DIAM90.

2.8.4.4 Absolute dimensions for rotary axes (DC, ACP, ACN)

The non-modal and G90/G91-independent commands DC, ACP and ACN are available for the positioning of rotary axes in absolute dimensions.

DC, ACP and ACN differ in the basic approach strategy:



Syntax

```

<rotary axis>=DC(<value>)
<rotary axis>=ACP(<value>)
<rotary axis>=ACN(<value>)

```

Meaning

<rotary axis>:	Identifier of the rotary axis that is to be traversed (e.g. A, B or C)	
DC:	Command for the direct approach to the position The rotary axis approaches the programmed position directly on the shortest path. The rotary axis traverses a maximum range of 180°.	
ACP:	Command to approach the position in a positive direction The rotary axis traverses to the programmed position in the positive direction of axis rotation (counter-clockwise).	
ACN:	Command to approach the position in a negative direction The rotary axis traverses to the programmed position in the negative direction of axis rotation (clockwise).	
<value>:	Rotary axis position to be approached in absolute dimensions	
	Range of values:	0 - 360 degrees

Note

The positive direction of rotation (clockwise or counter-clockwise) is set in the machine data.

Note

The traversing range between 0° and 360° must be set in the machine data (modulo behavior) for positioning with direction specification (ACP, ACN). G91 or IC must be programmed to traverse modulo rotary axes more than 360° in a block.


Note

The commands DC, ACP and ACN can also be used for spindle positioning (SPOS, SPOSA) from standstill.

Example: SPOS=DC (45)

Example

Milling on a rotary table



The tool is stationary, the table turns to 270° in a clockwise direction to produce a circular groove.

Program code	Comment
N10 SPOS=0	; Spindle in position control.
N20 G90 G0 X-20 Y0 Z2 T1	; Absolute dimensions, feed tool T1 in rapid traverse.
N30 G1 Z-5 F500	; Lower tool during feed.
N40 C=ACP(270)	; Table turns clockwise to 270 degrees (positive), the tool mills a circular groove.
N50 G0 Z2 M30	; Retraction, end of program.

References

Function Manual, Extended Functions; Rotary Axes (R2)

2.8.4.5 Metric/inch dimension system (G70/G71, G700/G710)

Using the commands of G group 13 (inch/metric system of units) within a part program, you can switch over between the metric and inch system of units.

Activation

In order that commands G700 and G710 are available, the extended system of units functionality must be switched on (MD10260 \$MN_CONVERT_SCALING_SYSTEM = 1).

Syntax

G70
G71
G700

G710

Meaning


G70:	Activating the inch system of units The inch system of units is used to read and write geometrical data in units of length . Technological data in units of length (e.g. feedrates, tool offsets, adjustable work offsets, machine data and system variables) is read and written using the parameterized basic system .
	G group: 13
	Initial setting: Settable via MD20150 \$MC_GCODE_RESET_VALUES
	Effectiveness: Modal
G71:	Activating the metric system of units The metric system of units is used to read and write geometrical data in units of length . Technological data in units of length (e.g. feedrates, tool offsets, adjustable work offsets, machine data and system variables) is read and written using the parameterized basic system .
	G group: 13
	Initial setting: Settable via MD20150 \$MC_GCODE_RESET_VALUES
	Effectiveness: Modal
G700:	Activating the inch system of units All geometrical and technological data in units of length is read and written using the inch system of units.
	G group: 13
	Initial setting: Settable via MD20150 \$MC_GCODE_RESET_VALUES
	Effectiveness: Modal
G710:	Activating the metric system of units All geometrical and technological data in units of length is read and written using the metric system of units.
	G group: 13
	Initial setting: Settable via MD20150 \$MC_GCODE_RESET_VALUES
	Effectiveness: Modal

NOTICE**Axis-specific data of rotary axes**

Axis-specific data of rotary axes is read and written using the parameterized basic system.

Example

The basic system is metric (MD10240 \$MN_SCALING_SYSTEM_IS_METRIC = 1). However, the workpiece drawing has dimensions shown in inches. This is the reason why within the part program, the inch system of units is selected. After the inch dimensions have been processed, the metric system of units is again selected.



Program code	Comment
N10 G0 G90 X20 Y30 Z2 S2000 M3 T1	; X=20 mm, Y=30 mm, Z=2 mm, F=rapid traverse mm/min
N20 G1 Z-5 F500	; Z=-5 mm, F=500 mm/min
N30 X90	; X=90 mm
N40 G70 X2.75 Y3.22	; programmed system of units: inch ; X=2.75 inch, Y=3.22 inch, F=500 mm/min
N50 X1.18 Y3.54	; X=1.18 inch, Y=3.54 inch, F=500 mm/min
N60 G71 X20 Y30	; programmed system of units: Metric ; X=20 mm, Y=30 mm, F=500 mm/min
N70 G0 Z2	; Z=2 mm, F=rapid traverse mm/min
N80 M30	; end of program

Further information

Reading and writing data in the case of G70/G71 and G700/G710

Data area	G70 / G71		G700 / G710	
	Read	Write	Read	Write
Display, decimal places (WCS)	P	P	P	P
Display, decimal places (MCS)	G	G	G	G
Feedrates	G	G	P	P
Position data X, Y, Z	P	P	P	P

Data area	G70 / G71		G700 / G710	
	Read	Write	Read	Write
Interpolation parameters I, J, K	P	P	P	P
Circle radius (CR)	P	P	P	P
Polar radius (RP)	P	P	P	P
Thread pitch	P	P	P	P
Programmable FRAME	P	P	P	P
Settable FRAMES	G	G	P	P
Basic frames	G	G	P	P
External work offsets	G	G	P	P
Axial preset offset	G	G	P	P
Working area limits (G25/G26)	G	G	P	P
Protection areas	P	P	P	P
Tool offsets	G	G	P	P
Length-related machine data	G	G	P	P
Length-related setting data	G	G	P	P
Length-related system variables	G	G	P	P
GUDs	G	G	G	G
LUDs	G	G	G	G
PUDs	G	G	G	G
R parameters	G	G	G	G
Siemens cycles	P	P	P	P
Jog/handwheel increment factor	G	G	G	G
P: Writing/reading is performed in the programmed system of units.				
G: Writing/reading is performed in the configured basic system				

Synchronized actions

Note


Reading position data in synchronized actions

If a system of units has not been explicitly programmed in the synchronized action (condition component and/or action component) **length-related position data** in the synchronized action will always be read in the parameterized **basic system**.

Further information: Function Manual, Synchronized Actions

2.8.4.6 Channel-specific diameter/radius programming (DIAMON, DIAM90, DIAMOF, DIAMCYCOF)

During turning, the dimensions for the transverse axis can be specified in the diameter (①) or in the radius (②):



So that the dimensions from a technical drawing can be transferred directly (without conversion) to the NC program, channel-specific diameter or radius programming is activated using the modal commands DIAMON, DIAM90, DIAMOF, and DIAMCYCOF.

Note

The channel-specific diameter/radius programming refers to the geometry axis defined as transverse axis via MD20100 \$MC_DIAMETER_AX_DEF (→ see machine manufacturer's specifications).

Only one transverse axis per channel can be defined via MD20100.

Syntax

DIAMON
DIAM90
DIAMOF

Meaning

DIAMON:	Command for the activation of the independent channel-specific diameter programming.	
	The effect of DIAMON is independent of the programmed dimensions mode (absolute dimensions G90 or incremental dimensions G91):	
	• For G90:	Dimensions in the diameter
	• For G91:	Dimensions in the diameter

DIAM90:	Command for the activation of the dependent channel-specific diameter programming.	
	The effect of DIAM90 depends on the programmed dimensions mode:	
	• For G90:	Dimensions in the diameter
	• For G91:	Dimensions in the radius
DIAMOF:	Command for the deactivation of the channel-specific diameter programming	
	Channel-specific radius programming takes effect when diameter programming is deactivated. The effect of DIAMOF is independent of the programmed dimensions mode:	
	• For G90:	Dimensions in the radius
	• For G91:	Dimensions in the radius
DIAMCYCOF:	Command for the deactivation of channel-specific diameter programming during cycle processing.	
	In this way, computations in the cycle can always be made in the radius. The last G command active in this group remains active for the position indicator and the basic block indicator.	

Note

With DIAMON or DIAM90, the transverse-axis actual values will always be displayed as a diameter. This also applies to reading of actual values in the workpiece coordinate system with MEAS, MEAW, \$P_EP[x] and \$AA_IW[x].

Example

Program code	Comment
N10 G0 X0 Z0	; Approach starting point.
N20 DIAMOF	; Diameter programming off.
N30 G1 X30 S2000 M03 F0.7	; X axis = transverse axis, radius programming active; traverse to radius position X30.
N40 DIAMON	; The diameter programming is active for the transverse axis.
N50 G1 X70 Z-20	; Traverse to diameter position X70 and Z-20.
N60 Z-30	
N70 DIAM90	; Diameter programming for absolute dimensions and radius programming for incremental dimensions.
N80 G91 X10 Z-20	; Incremental dimensions active.
N90 G90 X10	; Absolute dimensions active.
N100 M30	; End of program

Additional information**Diameter values (DIAMON/DIAM90)**

The diameter values apply for the following data:

- Actual value display of the transverse axis in the workpiece coordinate system
- JOG mode: Increments for incremental dimensions and manual handwheel travel
- Programming of end positions:
Interpolation parameters I, J, K for G2/G3, if these have been programmed absolutely with AC.
If I, J, K are programmed incrementally (IC), the radius is always calculated.
- Reading actual values in the workpiece coordinate system for:
MEAS, MEAW, \$P_EP[X], \$AA_IW[X]

2.8.4.7 Axis-specific diameter/radius programming (DIAMONA, DIAM90A, DIAMOFA, DIACYCOFA, DIAMCHANA, DIAMCHAN, DAC, DIC, RAC, RIC)

In addition to channel-specific diameter programming, the axis-specific diameter programming function enables the modal or non-modal dimensions and display in the diameter for one or more axes.

Note

The axis-specific diameter programming is only possible for axes that are permitted as further transverse axes for the axis-specific diameter programming via MD30460 \$MA_BASE_FUNCTION_MASK (→ see machine manufacturer's specifications).

Syntax

Modal axis-specific diameter programming for several transverse axes in the channel:

```
DIAMONA [<axis>]
DIAM90A [<axis>]
DIAMOFA [<axis>]
DIACYCOFA [<axis>]
```

Acceptance of the channel-specific diameter/radius programming:

```
DIAMCHANA [<axis>]
DIAMCHAN
```

Non-modal axis-specific diameter/radius programming:

```
<axis>=DAC (<value>)
<axis>=DIC (<value>)
<axis>=RAC (<value>)
<axis>=RIC (<value>)
```

Meaning

Modal axis-specific diameter programming			
DIAMONA:	<p>Command for the activation of the independent axis-specific diameter programming</p> <p>The effect of DIAMONA is independent of the programmed dimensions mode (G90/G91 or AC/IC):</p> <ul style="list-style-type: none"> For G90, AC: Dimensions in the diameter For G91, IC: Dimensions in the diameter 		
DIAM90A:	<p>Command for the activation of the dependent axis-specific diameter programming</p> <p>The effect of DIAM90A depends on the programmed dimensions mode:</p> <ul style="list-style-type: none"> For G90, AC: Dimensions in the diameter For G91, IC: Dimensions in the radius 		
DIAMOFA:	<p>Command for the deactivation of the axis-specific diameter programming</p> <p>Axis-specific radius programming takes effect when diameter programming is deactivated. The effect of DIAMOFA is independent of the programmed dimensions mode:</p> <ul style="list-style-type: none"> For G90, AC: Dimensions in the radius For G91, IC: Dimensions in the radius 		
DIACYCOFA:	<p>Command for the deactivation of axis-specific diameter programming during cycle processing.</p> <p>In this way, computations in the cycle can always be made in the radius. The last G command active in this group remains active for the position indicator and the basic block indicator.</p>		
<axis>:	<p>Axis identifier of the axis for which the axis-specific diameter programming is to be activated.</p> <p>Permitted axis identifiers are as follows:</p> <ul style="list-style-type: none"> Geometry/channel axis name or Machine axis name <table border="1"> <tr> <td>Range of values:</td> <td> <p>The axis specified must be a known axis in the channel.</p> <p>Other conditions:</p> <ul style="list-style-type: none"> The axis must be permitted for the axis-specific diameter programming via MD30460 \$MA_BASE_FUNCTION_MASK. Rotary axes are not permitted to serve as transverse axes. </td> </tr> </table>	Range of values:	<p>The axis specified must be a known axis in the channel.</p> <p>Other conditions:</p> <ul style="list-style-type: none"> The axis must be permitted for the axis-specific diameter programming via MD30460 \$MA_BASE_FUNCTION_MASK. Rotary axes are not permitted to serve as transverse axes.
Range of values:	<p>The axis specified must be a known axis in the channel.</p> <p>Other conditions:</p> <ul style="list-style-type: none"> The axis must be permitted for the axis-specific diameter programming via MD30460 \$MA_BASE_FUNCTION_MASK. Rotary axes are not permitted to serve as transverse axes. 		
Acceptance of the channel-specific diameter/radius programming			
DIAMCHANA:	<p>With the DIAMCHANA [<axis>] command, the specified axis accepts the channel status of the diameter/radius programming and is then assigned to the channel-specific diameter/radius programming.</p>		
DIAMCHAN:	<p>With the DIAMCHAN command, all axes permitted for the axis-specific diameter programming accept the channel status of the diameter/radius programming and are then assigned to the channel-specific diameter/radius programming.</p>		
Non-modal axis-specific diameter/radius programming			
<p>The non-modal axis-specific diameter/radius programming specifies the dimension type as a diameter or radius value in the part program and synchronized actions. The modal status of diameter/radius programming remains unchanged.</p>			

DAC:	The DAC command sets the following dimensions to non-modal for the specified axis: Diameter in absolute dimensions
DIC:	The DIC command sets the following dimensions to non-modal for the specified axis: Diameter in incremental dimensions
RAC:	The RAC command sets the following dimensions to non-modal for the specified axis: Radius in absolute dimensions
RIC:	The RIC command sets the following dimensions to non-modal for the specified axis: Radius in incremental dimensions

Note

With DIAMONA[<axis>] or DIAM90A[<axis>], the transverse-axis actual values are always displayed as a diameter. This also applies to reading of actual values in the workpiece coordinate system with MEAS, MEAW, \$P_EP[x] and \$AA_IW[x].

Note

During the replacement of an additional transverse axis because of a GET request, the status of the diameter/radius programming in the other channel is accepted with RELEASE[<axis>].

Examples

Example 1: Modal axis-specific diameter/radius programming

X is the transverse axis in the channel, axis-specific diameter programming is permitted for Y.

Program code	Comment
N10 G0 X0 Z0 DIAMON	; Channel-specific diameter programming active for X.
N15 DIAMOF	; Channel-specific diameter programming off.
N20 DIAMONA[Y]	; Modal axis-specific diameter programming active for Y.
N25 X200 Y100	; Radius programming active for X.
N30 DIAMCHANA[Y]	; Y accepts the status of the channel-specific diameter/radius programming and is assigned to this.
N35 X50 Y100	; Radius programming active for X and Y.
N40 DIAMON	; Channel-specific diameter programming on.
N45 X50 Y100	; Diameter programming active for X and Y.

Example 2: Non-modal axis-specific diameter/radius programming

X is the transverse axis in the channel, axis-specific diameter programming is permitted for Y.

Program code	Comment
N10 DIAMON	; Channel-specific diameter programming on.

Program code	Comment
N15 G0 G90 X20 Y40 DIAMONA[Y]	; Modal axis-specific diameter programming active for Y.
N20 G01 X=RIC(5)	; Dimensions effective in this block for X: Radius in incremental dimensions.
N25 X=RAC(80)	; Dimensions effective in this block for X: Radius in absolute dimensions.
N30 WHEN \$SAA_IM[Y] > 50 DO POS[X]=RIC(1)	; X is command axis. Dimensions effective in this block for X: Radius in incremental dimensions.
N40 WHEN \$SAA_IM[Y] > 60 DO POS[X]=DAC(10)	; X is command axis. Dimensions effective in this block for X: Radius in absolute dimensions.
N50 G4 F3	

Further information

Diameter values (DIAMONA/DIAM90A)

The diameter values apply for the following data:

- Actual value display of the transverse axis in the workpiece coordinate system
- JOG mode: Increments for incremental dimensions and manual handwheel travel
- Programming of end positions:
Interpolation parameters I, J, K for G2/G3, if these have been programmed absolutely with AC.
If I, J, K are programmed incrementally (IC), the radius is always calculated.
- Reading actual values in the workpiece coordinate system for:
MEAS, MEAW, \$P_EP[X], \$AA_IW[X]

Non-modal axis-specific diameter programming (DAC, DIC, RAC, RIC)

The statements DAC, DIC, RAC, RIC are permissible for any commands for which channel-specific diameter programming is relevant:

- Axis position: X . . . , POS, POSA
- Oscillation: OSP1, OSP2, OSS, OSE, POSP
- Interpolation parameters: I, J, K
- Contour definition: Straight line with angle specification
- Rapid retraction: POLF[AX]
- Traversing in the tool direction: MOVT
- Smooth approach and retraction:
G140 to G143, G147, G148, G247, G248, G347, G348, G340, G341

2.8.5 Position of workpiece for turning

Axis identifiers


The two geometry axes perpendicular to one another are usually called:

Longitudinal axis	= Z axis (abscissa)
Transverse axis	= X axis (ordinate)

Workpiece zero

Whereas the machine zero is permanently defined, the workpiece zero can be freely selected on the longitudinal axis. Generally the workpiece zero is on the front or rear side of the workpiece.


Both the machine and the workpiece zero are on the turning center. The settable offset on the X axis is therefore zero.



M	Machine zero
W	Workpiece zero
Z	Longitudinal axis
X	Transverse axis
G54 to G599 or TRANS	Call for the position of the workpiece zero

Transverse axis

Generally the dimensions for the transverse axis are diameter specifications (double path dimension compared to other axes):



The geometry axis that is to serve as transverse axis is defined in the machine data (→ machine manufacturer).

2.9 Motion commands

2.9.1 General information about the travel commands

Contour elements

The programmed workpiece contour can be made up of the following contour elements:

- Straight lines
- Circular arcs
- Helical curves (through overlaying of straight lines and circular arcs)

Travel commands

The following travel commands are available for the creation of these contour elements:

- Rapid traverse motion (G0)
- Linear interpolation (G1)
- Circular interpolation clockwise (G2)
- Circular interpolation counter-clockwise (G3)

The travel commands are modal.

Target positions

A motion block contains the target positions for the axes to be traversed (path axes, synchronized axes, positioning axes).

The target positions can be programmed in Cartesian coordinates or in polar coordinates.

Note

The axis address may only be programmed once per block.

Starting point - target point

The traversing motion is always for the last point reached to the programmed target position. This target position is then the starting position for the next travel command.

Workpiece contour

NOTICE

Tool operation undefined

Before machining, the workpiece must be positioned in such a way that the tool or workpiece cannot be damaged.

The motion blocks produce the workpiece contour when performed in succession:




Figure 2-8 Motion blocks for turning




Figure 2-9 Motion blocks for milling

2.9.2 Travel commands with Cartesian coordinates (G0, G1, G2, G3, X..., Y..., Z...)

The position specified in the NC block with Cartesian coordinates can be approached with rapid traverse motion G0, linear interpolation G1 or circular interpolation G2 /G3.

Syntax

```
G0 X... Y... Z...
G1 X... Y... Z...
G2 X... Y... Z... ...
G3 X... Y... Z... ...
```


Meaning

G0:	Command for the activation of rapid traverse motion
G1:	Command for the activation of linear interpolation
G2:	Command for the activation of clockwise circular interpolation
G3:	Command for the activation of counter-clockwise circular interpolation
X...:	Cartesian coordinate of the target position in the X direction
Y...:	Cartesian coordinate of the target position in the Y direction
Z...:	Cartesian coordinate of the target position in the Z direction

Note

In addition to the coordinates of the target position X . . . , Y . . . , Z . . . , the circular interpolation G2 / G3 also requires further data (e.g. the circle center point coordinates; see "Overview (Page 188)").

Example



Program code	Comment
N10 G17 S400 M3	; Selection of the working plane, spindle clockwise
N20 G0 X40 Y-6 Z2	; Approach of the starting position specified with Cartesian coordinates in rapid traverse
N30 G1 Z-3 F40	; Activation of the linear interpolation, feed of the tool

Program code	Comment
N40 X12 Y-20	; Travel on an inclined line to an end position specified with Cartesian coordinates
N50 G0 Z100 M30	; Retraction in rapid traverse for tool change

2.9.3 Travel commands with polar coordinates

2.9.3.1 Reference point of the polar coordinates (G110, G111, G112)

The point from which the dimensioning starts is called the pole.

The pole can be specified in Cartesian or polar coordinates.

The reference point for the pole coordinates is clearly defined with the G110 to G112 commands. Absolute or incremental dimension inputs therefore have no effect.

Syntax

```
G110/G111/G112 X... Y... Z...
G110/G111/G112 AP=... RP=...
```

Meaning

G110 ...:	With the command G110, the following pole coordinates refer to the last position reached .	
G111 ...:	With the command G111, the following pole coordinates refer to the zero point of the current workpiece coordinate system .	
G112 ...:	With the command G112, the following pole coordinates refer to the last valid pole .	
	Note: The commands G110...G112 must be programmed in a separate NC block.	
X... Y... Z...:	Specification of the pole in Cartesian coordinates	
AP=... RP=...:	Specification of the pole in polar coordinates	
	AP=...:	Polar angle Angle between the polar radius and the horizontal axis of the working plane (e.g. X axis for G17). The positive direction of rotation runs counter-clockwise. Range of values: $\pm 0...360^\circ$
	RP=...:	Polar radius The specification is always in absolute positive values in [mm] or [inch].


Note

It is possible to switch block-by-block in the NC program between polar and Cartesian dimensions. It is possible to return directly to the Cartesian system by using Cartesian coordinate identifiers (X..., Y..., Z...). The defined pole is moreover retained up to program end.

Note

If no pole has been specified, the zero point of the current workpiece coordinate system applies.

Example




Poles 1 to 3 are defined as follows:

- Pole 1 with G111 X... Y...
- Pole 2 with G110 X... Y...
- Pole 3 with G112 X... Y...

2.9.3.2 Travel commands with polar coordinates (G0, G1, G2, G3, AP, RP)

Travel commands with polar coordinates are useful when the dimensions of a workpiece or part of the workpiece are measured from a central point and the dimensions are specified in angles and radii (e.g. for drilling patterns).



Syntax

G0/G1/G2/G3 AP=... RP=...

Meaning

G0:	Command for the activation of rapid traverse motion
G1:	Command for the activation of linear interpolation
G2:	Command for the activation of clockwise circular interpolation
G3:	Command for the activation of counter-clockwise circular interpolation
AP:	Polar angle Angle between the polar radius and the horizontal axis of the working plane (e.g. X axis for G17). The positive direction of rotation runs counter-clockwise.
	Range of values: $\pm 0 \dots 360^\circ$
	The angle can be specified either incremental or absolute:
	AP=AC (...): Absolute dimension input
	AP=IC (...): Incremental dimension input With incremental dimension input, the last programmed angle applies as reference.
	The polar angle remains stored until a new pole is defined or the working plane is changed.
RP:	Polar radius The specification is always in absolute positive values in [mm] or [inch]. The polar radius remains stored until a new value is entered.


Note

The polar coordinates refer to the pole specified with G110 ... G112 and apply in the working plane selected with G17 to G19.

Note


The 3rd geometry axis, which lies perpendicular to the working plane, can also be specified in Cartesian coordinates (see the following diagram). This enables spatial parameters to be programmed in cylindrical coordinates.

Example: G17 G0 AP... RP... Z...



Supplementary conditions


- No Cartesian coordinates such as interpolation parameters, axis addresses, etc. may be programmed for the selected working plane in NC blocks with polar end point coordinates.
- If a pole has not been defined with G110 ... G112, then the zero point of the current workpiece coordinate system is automatically considered as the pole:



- Polar radius $RP = 0$
The polar radius is calculated from the distance between the starting point vector in the pole plane and the active pole vector. The calculated polar radius is then saved as modal. This applies irrespective of the selected pole definition (G110 ... G112). If both points have been programmed identically, this radius = 0 and alarm 14095 is generated.
- Only polar angle AP has been programmed
If no polar radius RP has been programmed in the current block, but a polar angle AP , then when there is a difference between the current position and pole in the workpiece coordinates, this difference is used as polar radius and saved as modal. If the difference = 0, then the pole coordinates are specified again and the modal polar radius remains at zero.

Example

Creation of a drilling pattern



The positions of the holes are specified in polar coordinates.

Each hole is machined with the same production sequence:

Rough-drilling, drilling as dimensioned, reaming ...

The machining sequence is stored in the sub-program.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero.
N20 G111 X43 Y38	; Specification of the pole.
N30 G0 RP=30 AP=18 Z5	; Approach starting point, specification in cylindrical coordinates.
N40 L10	; Subprogram call.
N50 G91 AP=72	; Approach next position in rapid traverse, polar angle in incremental dimensions, polar radius from block N30 remains saved and does not have to be specified.
N60 L10	; Subprogram call.
N70 AP=IC(72)	.
N80 L10	...
N90 AP=IC(72)	.
N100 L10	...

Program code	Comment
N110 AP=IC(72)	
N120 L10	...
N130 G0 X300 Y200 Z100 M30	; Retract tool, end of program.

See also

Overview (Page 188)

2.9.4 Rapid traverse movements

2.9.4.1 Activating rapid traverse (G0)

The traversing of the path axes at rapid traversing velocity is activated with the G command G0.

Syntax


```
G0 X... Y... Z...
G0 RP=... AP=...
```

Meaning

G0:	Traversing the axis with rapid traverse velocity	
	Effective:	Modal
X... Y... Z...:	Specifying the end point in Cartesian coordinates	
RP=... AP=... :	Specifying the end point in polar coordinates	


Examples

Example 1: Milling



Program code	Comment
N10 G90 S400 M3	; Absolute dimension input, spindle clockwise
N20 G0 X30 Y20 Z2	; Approach the starting position
N30 G1 Z-5 F1000	; Tool infeed
N40 X80 Y65	; Traversing along a straight line
N50 G0 Z2	
N60 G0 X-20 Y100 Z100 M30	; Retract tool, end of program

Example 2: Turning



Program code	Comment
N10 G90 S400 M3	; Absolute dimension input, spindle clockwise
N20 G0 X25 Z5	; Approach the starting position
N30 G1 G94 Z0 F1000	; Tool infeed
N40 G95 Z-7.5 F0.2	
N50 X60 Z-35	; Traversing along a straight line
N60 Z-50	
N70 G0 X62	
N80 G0 X80 Z20 M30	; Retract tool, end of program

2.9.4.2 Switch on/off linear interpolation for rapid traverse movements (RTLION, RTLIOF)

Independently of the default setting (MD20730 \$MC_G0_LINEAR_MODE), the interpolation response for rapid traverse movements can also be set in the part program using the commands of the G group 55.

Syntax

```
RTLIOF
...
RTLION
```

Meaning

RTLIOF:	G command for switching off the linear interpolation ⇒ In the rapid traversing mode (G0), the non-linear interpolation is active. All of the path axes reach their end points independently of one another.	
	Effective:	Modal
RTLION:	G command for switching on the linear interpolation ⇒ In the rapid traversing mode (G0), the linear interpolation is active. All of the path axes reach their end points simultaneously.	
	Effective:	Modal

Note

Preconditions for RTLIOF

To ensure, with RTLIOF **non-linear** interpolation, the following conditions must be fulfilled:

- No transformation (TRAORI, TRANSMIT, etc.) active.
- G60 active (stop at the block end).
- No compressor active (COMPOF).
- No tool radius compensation active (G40).
- No contour handwheel selected.
- No nibbling active.

If one of these conditions is not met, linear interpolation is as with RTLION.

Example

Program code	Comment
	; Linear interpolation is the default:
	; MD20730 \$MC_GO_LINEAR_MODE == TRUE
...	
N30 RTLIOF	; Switch off linear interpolation.
N40 G0 X0 Y10	; G0 blocks are traversed using non-linear interpolation.
N50 G41 X20 Y20	; TRC active ⇒ G0 blocks are traversed using linear interpolation.
N60 G40 X30 Y30	; TRC not active ⇒ G0 blocks are traversed using non-linear interpolation.
N70 RTLION	; Switch on linear interpolation.
...	

Further information

Reading the current interpolation behavior

The current interpolation behavior can be read via the system variables \$AA_GOMODE.

2.9.4.3 Adjust relative G0 tolerance (STOLF)

The tolerance factor for rapid traverse movements (G0 tolerance factor) configured with the machine data MD20560 \$MC_GO_TOLERANCE_FACTOR may be temporarily adjusted in the part program. This does not change the setting in the machine data. After channel or end of program-RESET, the configured tolerance becomes effective again.

Requirements

The relative G0 tolerance is only effective if the following conditions are fulfilled:

- One of the following functions is active:
 - Compressor functions COMPON, COMPCURV, COMPCAD or COMPSURF
 - Smoothing function G642 or G645
 - Orientation smoothing OST
 - Orientation smoothing ORISON
 - Smoothing for path-relevant orientation ORIPATH
- There are several (≥ 2) consecutive G0 blocks in the part program.
For a single G0 block, the G0 tolerance factor is not effective, as the "lower tolerance" always applies (workpiece machining tolerance) at the transition from a non G0 motion to a G0 motion (and vice versa)!
- No absolute G0 tolerances have been configured (\neq default setting):
MD20561 \$MC_G0_TOLERANCE_CTOL_ABS (contour tolerance for G0 movements) = 0
MD20562 \$MC_G0_TOLERANCE_OTOL_ABS (orientation tolerance for G0 movements) = 0

Syntax

STOLF=<Value>

Meaning

STOLF:	Address for programming a temporarily effective G0 tolerance factor		
	<Value>:	G0 tolerance factor	
		Type:	REAL
		Value:	> 0:
		≤ 0:	Deletion of the programmed tolerance factor ⇒ The tolerance value preset in the machine data becomes effective again.

Example

Program code	Comment
COMPCAD G645 G1 F10000	; Compressor function COMPCAD
X... Y... Z...	; The machine and setting data apply here.
X... Y... Z...	

Program code	Comment
X... Y... Z...	
G0 X... Y... Z...	
G0 X... Y... Z...	; Machine data \$MC_G0_TOLERANCE_FACTOR (e.g. =3) is effective here, i.e. a smoothing tolerance of: \$MC_G0_TOLERANCE_FACTOR * \$MA_COMPRESS_POS_TOL
CTOL=0.02	
STOLF=4	
G1 X... Y... Z...	; A contour tolerance of 0.02 mm is applied starting from here.
X... Y... Z...	
X... Y... Z...	
G0 X... Y... Z...	
X... Y... Z...	; From here, a G0 tolerance factor of 4 applies, i.e. a contour tolerance of 0.08 mm.
...	

Further information

Reading G0 tolerance factor

The tolerance factor for rapid traverse movements effective in the part program or in the current IPO block can be read using system variables.

- In synchronized actions or with preprocessing stop in the part program via system variable:

\$AC_STOLF	Active G0 tolerance factor
	G0 tolerance factor, which was effective when processing the actual main run block.

- Without preprocessing stop in the part program via system variable:

\$P_STOLF	Programmed G0 tolerance factor
-----------	--------------------------------

If no value with STOLF is programmed in the active part program, then these two system variables return the value configured in the machine data.

If no rapid traverse (G0) is active in a block, then these system variables always supply a value of 1.

If an absolute value for the contour tolerance is active with G0, then these two variables return the factor between the contour tolerance for G0 movements and the contour tolerance for non-G0 movements.


Reading the absolute G0 tolerances

The contour and orientation tolerance for rapid traverse movements effective in the part program and interpolation block can be read by the system variable.

- In synchronized actions or with preprocessing stop in the part program by the system variables:
 - \$AC_CTOL_G0_ABS
 - \$AC_OTOL_G0_ABS
- Without preprocessing stop in the part program by the system variables:
 - \$P_CTOL_G0_ABS
 - \$P_OTOL_G0_ABS

2.9.5 Linear interpolation (G1)

With G1 the tool travels on paraxial, inclined or straight lines arbitrarily positioned in space. Linear interpolation permits machining of 3D surfaces, grooves, etc.



Syntax

```
G1 X... Y... Z ... F...
G1 AP=... RP=... F...
```

Meaning

G1:	Linear interpolation with feedrate (linear interpolation)
X... Y... Z...:	End point in Cartesian coordinates
AP=...:	End point in polar coordinates, in this case polar angle

RP=...:	End point in polar coordinates, in this case polar radius
F...:	Feedrate speed in mm/min. The tool travels at feedrate F along a straight line from the current starting point to the programmed destination point. You can enter the destination point in Cartesian or polar coordinates. The workpiece is machined along this path. Example: G1 G94 X100 Y20 Z30 A40 F100 The end point on X, Y, Z is approached at a feedrate of 100 mm/min; the rotary axis A is traversed as a synchronized axis, ensuring that all four movements are completed at the same time.

Note


G1 is modal.

Spindle speed S and spindle direction M3/M4 must be specified for the machining.

Axis groups, for which path feedrate F applies, can be defined with FGROUP. You will find more information in the "Path behavior" section.


Examples**Example 1: Machining of a groove (milling)**

The tool travels from the starting point to the end point in the X/Y direction. Infeed takes place simultaneously in the Z direction.



Program code	Comment
N10 G17 S400 M3	; Selection of the working plane, spindle clockwise
N20 G0 X20 Y20 Z2	; Approach the starting position
N30 G1 Z-2 F40	; Tool infeed
N40 X80 Y80 Z-15	; Travel on an inclined line
N50 G0 Z100 M30	; Retraction for tool change

Example 2: Machining of a groove (turning)



Program code	Comment
N10 G17 S400 M3	; Selection of the working plane, spindle clockwise
N20 G0 X40 Y-6 Z2	; Approach the starting position
N30 G1 Z-3 F40	; Tool infeed
N40 X12 Y-20	; Travel on an inclined line
N50 G0 Z100 M30	; Retraction for tool change

2.9.6 Circular interpolation

2.9.6.1 Overview

Circular interpolation enables the machining of full circles or arcs.




Figure 2-10 Application example: Milling a circular way


Programming options

The control system offers various options of programming circular movements. This allows the user to implement almost any type of drawing dimension directly.

- Circular interpolation with center point and end point (G2/G3, X... Y... Z..., I... J... K...) (Page 189)
- Circular interpolation with radius and end point (G2/G3, X... Y... Z..., CR) (Page 192)
- Circular interpolation with opening angle and end point / center point (G2/G3, X... Y... Z... / I... J... K..., AR) (Page 194)
- Circular interpolation with polar coordinates (G2/G3, AP, RP) (Page 196)
- Circular interpolation with intermediate point and end point (CIP, X... Y... Z..., I1... J1... K1...) (Page 198)
- Circular interpolation with tangential transition (CT, X... Y... Z...) (Page 200)

Plane for the circular interpolation

The control needs the working plane parameter (Page 148) to calculate the direction of rotation for the circle (G2 is clockwise or G3 is counter-clockwise).



Exception:

It is also possible to create circles outside the selected working plane (not with opening angle and helix parameters). In this case, the axis identifiers that the programmer specifies as circle end point determine the circle plane.

2.9.6.2 Circular interpolation with center point and end point (G2/G3, X... Y... Z..., I... J... K...)

Circular interpolation version, that uses the **center point** and **end point** of a circular contour element for the interpolation.

If the circle is programmed without an end point, the result is a full circle.

Syntax

G2/G3 X... Y... Z... I... J... K...
 G2/G3 X... Y... Z... I=AC (...) J=AC (...) K=(AC...)

Meaning


G2:	Circular interpolation clockwise	
	Effective:	Modal
G3:	Circular interpolation counter-clockwise	
	Effective:	Modal
X... Y... Z... :	Circle end point in Cartesian coordinates. Depending on the currently valid dimensional notation setting G90/G91 or ...=AC (...) / ...=IC (...), the circle end point coordinates are interpreted either in the absolute dimension or in the incremental dimension.	
I... J... K... :	Interpolation parameters to state the circle center point coordinates in the directions X, Y, Z Per default, the circle center point coordinates are stated in the incremental dimension in relation to the circle starting point. If the circle center point coordinates are stated in the absolute dimension in relation to workpiece zero, the interpolation parameters I, J, K must be programmed as follows: I=AC (...) J=AC (...) K=AC (...) Note An interpolation parameter with value 0 can be omitted, but the associated second parameter must always be specified.	

Note

The default setting G90/G91 absolute or incremental dimensions is only valid for the circle end point.

Examples

Example 1: Milling




Center point data using incremental dimensions

```
N10 G0 X67.5 Y80.211
N20 G3 X17.203 Y38.029 I-17.5 J-30.211 F500
```

Center point data using absolute dimensions

```
N10 G0 X67.5 Y80.211
N20 G3 X17.203 Y38.029 I=AC(50) J=AC(50)
```

Example 2: Turning



Center point data using incremental dimensions

```
N120 G0 X12 Z0
N125 G1 X40 Z-25 F0.2
N130 G3 X70 Z-75 I-3.335 K-29.25
N135 G1 Z-95
```

Center point data using absolute dimensions

```
N120 G0 X12 Z0
N125 G1 X40 Z-25 F0.2
N130 G3 X70 Z-75 I=AC(33.33) K=AC(-54.25)
N135 G1 Z-95
```

2.9.6.3 Circular interpolation with radius and end point (G2/G3, X... Y... Z..., CR)

Circular interpolation version, that uses the **radius** and **end point** of a circular contour element for the interpolation.

Note

Full circles (traversing angle 360 °) can **not** be programmed with this version.

Syntax


```
G2/G3 X... Y... Z... CR=±...
```

Meaning

G2:	Circular interpolation clockwise	
	Effective:	Modal
G3:	Circular interpolation counter-clockwise	
	Effective:	Modal
X... Y... Z... :	Circle end point in Cartesian coordinates. Depending on the currently valid dimensional notation setting G90/G91 or ...=AC(...) / ...=IC(...), the end point coordinates are interpreted either in the absolute dimension or in the incremental dimension.	
CR=±... :	Circle radius	
	The sign indicates whether the traversing angle is to be greater than or less than 180°. A positive sign can be omitted.	
	CR=+... :	Traversing angle ≤ 180°
	CR=-... :	Traversing angle > 180°
	Note There is no practical limitation on the maximum size of the programmable radius.	

Examples


Example 1: Milling



Program code

```
N10 G0 X67.5 Y80.511
N20 G3 X17.203 Y38.029 CR=34.913 F500
...
```

Example 2: Turning



Program code

```
...
N125 G1 X40 Z-25 F0.2
N130 G3 X70 Z-75 CR=30
N135 G1 Z-95
...
```

2.9.6.4 Circular interpolation with opening angle and end point / center point (G2/G3, X... Y... Z... / I... J... K..., AR)

Circular interpolation version, that uses the **opening angle** and **center point** or **end point** of a circular contour element for the interpolation.

Note

Full circles (traversing angle 360 °) can **not** be programmed with this version.

Syntax

G2/G3 X... Y... Z... AR=...


G2/G3 I... J... K... AR=...

Meaning

G2:	Circular interpolation clockwise	
	Effective:	Modal
G3:	Circular interpolation counter-clockwise	
	Effective:	Modal
X... Y... Z... :	Circle end point in Cartesian coordinates. Depending on the currently valid dimensional notation setting G90/G91 or ...=AC (...) / ...=IC (...), the circle end point coordinates are interpreted either in the absolute dimension or in the incremental dimension.	
I... J... K... :	Interpolation parameters to state the circle center point coordinates in the directions X, Y, Z Per default, the circle center point coordinates are stated in the incremental dimension in relation to the circle starting point. If the circle center point coordinates are stated in the absolute dimension in relation to workpiece zero, the interpolation parameters I, J, K must be programmed as follows: I=AC (...) J=AC (...) K=AC (...) Note An interpolation parameter with value 0 can be omitted, but the associated second parameter must always be specified.	
AR=... :	Opening angle	
	Range of values:	0° ... 360°

Examples


Example 1: Milling



Program code

```
N10 G0 X67.5 Y80.211
N20 G3 X17.203 Y38.029 AR=140.134 F500
N20 G3 I-17.5 J-30.211 AR=140.134 F500
```

Example 2: Turning



Program code

```
N125 G1 X40 Z-25 F0.2
N130 G3 X70 Z-75 AR=135.944
N130 G3 I-3.335 K-29.25 AR=135.944
N130 G3 I=AC(33.33) K=AC(-54.25) AR=135.944
```

Program code
N135 G1 Z-95

2.9.6.5 Circular interpolation with polar coordinates (G2/G3, AP, RP)

Circular interpolation version, that uses the **circle end point in polar coordinates** for the interpolation.

The following rule applies:

- The pole lies at the circle center.
- The polar radius corresponds to the circle radius.

Syntax


G2/G3 absolute pressure=... Recipe procedure=...

Meaning

G2:	Circular interpolation clockwise	
	Effective:	Modal
G3:	Circular interpolation counter-clockwise	
	Effective:	Modal
Absolute pressure=... Recipe procedure=... :	Circle end point in polar coordinates.	
	Absolute pressure=.. . :	Polar angle
	Recipe procedure=. . . :	Polar radius ($\hat{=}$ circle radius)

Examples


Example 1: Milling



Program code

```
N10 G0 X67.5 Y80.211
N20 G111 X50 Y50
N30 G3 RP=34.913 AP=200.052 F500
```

Example 2: Turning



Program code


```
N125 G1 X40 Z-25 F0.2
N130 G111 X33.33 Z-54.25
N135 G3 RP=30 AP=142.326
N140 G1 Z-95
```

2.9.6.6 Circular interpolation with intermediate point and end point (CIP, X... Y... Z..., I1... J1... K1...)

The circular interpolation version programmed with the G command CIP allows the interpolation of arcs lying at an incline in the space.

The circular motion is described by the **intermediate point** and the **end point** of the circular contour.

The traversing direction is determined by the order of the starting point → intermediate point → end point.



Syntax

```
CIP X... Y... Z... I1=AC(...) J1=AC(...) K1=(AC...)
```

Meaning

CIP:	Circular interpolation through intermediate point	
	Effective:	Modal
X... Y... Z... :	Circle end point in Cartesian coordinates. Depending on the currently valid dimensional notation setting G90/G91 or ...=AC(...) / ...=IC(...), the circle end point coordinates are interpreted either in the absolute dimension or in the incremental dimension.	
I1... J1... K1... :	Interpolation parameters to state the circle intermediate point coordinates in the directions X, Y, Z Depending on the currently valid dimensional notation setting G90/G91 or ...=AC(...) / ...=IC(...), the circle intermediate point coordinates are interpreted either in the absolute dimension or in the incremental dimension. Note An interpolation parameter with value 0 can be omitted, but the associated second parameter must always be specified.	

Note

The default settings G90/G91 (absolute or incremental dimensions) are only valid for the circle intermediate point and the circle end point.

With incremental dimensions G91 or `...=IC(...)` active, the circle starting point is used as the reference for the intermediate point and the end point.

Note


Turning technology

The diameter programming of the interpolation parameter for the transverse axis is not supported with CIP in the circular-path programming. The interpolation parameter for the transverse axis must therefore be programmed in the **radius**.

Examples


Example 1: Milling

In order to machine an inclined circular groove, a circle is described by specifying the intermediate point with three interpolation parameters, and the end point with three coordinates.



Program code	Comment
N10 G0 G90 X130 Y70.70 S800 M3	; Approach starting point.
N20 G17 G1 Z-2 F100	; Feed of the tool.
N30 CIP X80 Y120 Z-10 I1=IC(-85.35) J1=IC(-35.35) K1=-6	; Circle end point and intermediate point.
	; Coordinates for all three geometry axes.
N40 M30	; End of program

Example 2: Turning



Program code	Comment
...	
N125 G1 G90 X40 Z-25 F0.2	
N130 CIP X70 Z-75 I1=IC(26.665) K1=IC(-29.25)	; Interpolation parameter I1 for transverse axis must be programmed in the radius.
; or	
; N130 CIP X70 Z-75 I1=46.665 K1=-54.25	
N135 G1 Z-95	

2.9.6.7 Circular interpolation with tangential transition (CT, X... Y... Z...)

The circular interpolation version programmed with the G command CT allows the interpolation of arcs that connect tangentially to the previously programmed contour element.


The circle is defined by the **start and end points**, and the **tangent direction at the start point**.

Note

Tangent direction at the start point.

The tangent direction in the starting point of a CT block is determined from the end tangent of the programmed contour of the last block with a traversing motion.

There can be any number of blocks without traversing information between this block and the current block.



- S Start point
- E End point
- M Center of circle
- r Circle radius
- t End tangents of the programmed contour of the last block with a traversing movement.

Figure 2-11 Tangentially to the straight section 1-2 connecting circular path S-E




Figure 2-12 Tangentially connecting circular paths depend on the previous contour element

Syntax


CT X... Y... Z...

Meaning

CT:	Circular interpolation with tangential transition	
	Effective:	Modal
X... Y... Z... :	Circle end point in Cartesian coordinates. Depending on the currently valid dimensional notation setting G90/G91 or ...=AC(...) / ...=IC(...), the circle end point coordinates are interpreted either in the absolute dimension or in the incremental dimension.	


Examples

Example 1: Milling



Program code	Comment
N10 G0 Z100	
N20 G17 T1 M6	
N30 G0 X0 Y0 Z2 M3 S300 D1	
N40 Z-5 F1000	; Feed in tool.
N50 G41 X30 Y25 G1 F1000	; Switch on tool radius compensation.
N60 Y35	; Mill contour.
N70 X60 Y70	
N80 CT X80 Y55	; Circular-path programming with tangential transition.
N90 X90 Y35	
N100 G1 X100	
N110 Y25	
N120 X30	
N130 G0 G40 X0 Y0	; Switch off tool radius compensation.
N140 Z100	; Retract tool.
N140 M30	

Example 2: Turning



Program code	Comment
...	
N110 G1 X23.293 Z0 F10	
N115 X40 Z-30 F0.2	
N120 CT X58.146 Z-42	; Circular-path programming with tangential transition.
N125 G1 X70	
...	

Further information

Splines

In the case of splines, the tangential direction is defined by the straight line through the last two points. In the case of A and C splines with active ENAT or EAUTO, this direction is generally not the same as the direction at the end point of the spline.

The transition of B splines is always tangential, the tangent direction is defined as for A or C splines and active ETAN.

Frame change

If a frame change takes place between the block that defines the tangent and the CT block, the tangent is also subjected to this change.

Limit case

If the extension of the start tangent runs through the end point, a straight line is produced instead of a circle (limit case: circle with infinite radius). In this special case, TURN must either not be programmed or the value must be TURN=0.

Note

When the values tend towards this limit case, circles with an unlimited radius are produced and machining with TURN unequal to 0 is generally aborted with an alarm due to violation of the software limits.

Position of the circle plane


The position of the circle plane depends on the active plane (G17-G19).

If the tangent of the previous block does not lie in the active plane, its projection into the active plane is used.

If the start and end points do not have the same position components perpendicular to the active plane, a helix is produced instead of a circle.

2.9.7 Helical interpolation (G2/G3, TURN)

The helical interpolation enables, for example, the production of threads or oil grooves.



With helical interpolation, two motions are superimposed and executed in parallel:

- A plane circular motion on which
- A vertical linear motion is superimposed.

Syntax

G2/G3 X... Y... Z... I... J... K... TURN=

G2/G3 X... Y... Z... I... J... K... TURN=

G2/G3 AR=... I... J... K... TURN=

G2/G3 AR=... X... Y... Z... TURN=

G2/G3 AP... RP=... TURN=

Meaning


G2:	Travel on a circular path in clockwise direction
G3:	Travel on a circular path in counter-clockwise direction
X Y Z :	End point in Cartesian coordinates
I J K :	Circle center point in Cartesian coordinates

AR:	Opening angle
TURN= :	Number of additional circular passes in the range from 0 to 999
AP= :	Polar angle
RP= :	Polar radius

Note

G2 and G3 are modal.

The circular motion is performed in those axes that are defined by the specification of the working plane.

Example


Program code	Comment
N10 G17 G0 X27.5 Y32.99 Z3	; Approach the starting position.
N20 G1 Z-5 F50	; Feed of the tool.
N30 G3 X20 Y5 Z-20 I=AC(20) J=AC(20) TURN=2	; Helix with the specifications: Execute two full circles after the starting position, then travel to end point.
N40 M30	; End of program

Additional information**Motion sequence**

1. Approach starting point
2. Execute the full circles programmed with TURN=.

- 3. Approach circle end position, e.g. as part rotation.
- 4. Execute steps 2 and 3 across the infeed depth.

The pitch, with which the helix is to be machined is calculated from the number of full circles plus the programmed circle end position (executed across the infeed depth).



Programming the end point for helical interpolation

Please refer to circular interpolation for a detailed description of the interpolation parameters.

Programmed feedrate

For helical interpolation, it is advisable to specify a programmed feedrate override (CFC). FGROUP can be used to specify which axes are to be traversed with a programmed feedrate. For more information please refer to the Path behavior section.

2.9.8 Contour definitions

2.9.8.1 Contour definition programming

Function

The contour definition programming is used for the quick input of simple contours. Programmable are contour definitions with one, two, three or more points with the transition elements chamfer or rounding, through specification of Cartesian coordinates and/or angles (ANG or ANG1 and ANG2).

Additional arbitrary NC addresses can be used, e.g. address letters for further axes (single axes or axis perpendicular to the machining plane), auxiliary function specifications, G commands, velocities, etc. in the blocks that describe contour definitions.

Note**Contour calculator**

The contour definitions can be programmed easily with the aid of the contour calculator. This is a user interface tool that enables the programming and graphic display of simple and complex workpiece contours. The contours programmed via the contour calculator are transferred to the part program.

References:

Operating Manual

Parameterization

The identifiers for angle, radius and chamfer are defined via machine data:

MD10652 \$MN_CONTOUR_DEF_ANGLE_NAME (name of the angle for contour definitions)

MD10654 \$MN_RADIUS_NAME (name of the radius for contour definitions)

MD10656 \$MN_CHAMFER_NAME (name of the chamfer for contour definitions)

Note

See machine manufacturer's specifications.

2.9.8.2 Contour definitions: One straight line


Note

In the following description it is assumed that:

- G18 is active (⇒ active working plane is the Z/X plane).
(However, the programming of contour definitions is also possible without restrictions with G17 or G19.)
 - The following identifiers have been defined for angle, radius and chamfer:
 - ANG (angle)
 - RND (radius)
 - CHR (chamfer)
-

The end point of the straight line is defined by the following specifications:

- Angle ANG
- **One** Cartesian end point coordinate (X2 or Z2)



- ANG: Angle of the straight line
- X1, Z1: Start coordinates
- X2, Z2: End point coordinates of the straight line

Syntax

X... ANG=...
 Z... ANG=...

Meaning

X... :	End point coordinate in the X direction
Z... :	End point coordinate in the Z direction
ANG:	Identifier for angle programming The specified value (angle) refers to the abscissa of the active working plane (Z axis with G18).

Example

Program code	Comment
N10 X5 Z70 F1000 G18	; Approach the starting position
N20 X88.8 ANG=110	; Straight line with angle specification
N30 ...	

OR

Program code	Comment
N10 X5 Z70 F1000 G18	; Approach the starting position
N20 Z39.5 ANG=110	; Straight line with angle specification
N30 ...	


2.9.8.3 Contour definitions: Two straight lines

Note

In the following description it is assumed that:

- G18 is active (\Rightarrow active working plane is the Z/X plane).
(However, the programming of contour definitions is also possible without restrictions with G17 or G19.)
- The following identifiers have been defined for angle, radius and chamfer:
 - ANG (angle)
 - RND (radius)
 - CHR (chamfer)

The end point of the first straight line can be programmed by specifying the Cartesian coordinates or by specifying the angle of the two straight lines. The end point of the second straight line must always be programmed with Cartesian coordinates. The intersection of the two straight lines can be designed as a corner, curve or chamfer.



- ANG1: Angle of the first straight line
ANG2: Angle of the second straight line
X1, Z1: Start coordinates of the first straight line
X2, Z2: End point coordinates of the first straight line or start coordinates of the second straight line
X3, Z3: End point coordinates of the second straight line

Syntax

Programming of the end point of the first straight line by specifying the angle

- Corner as transition between the straight lines:

```
ANG=...  
X... Z... ANG=...
```

- Rounding as transition between the straight lines:

```
ANG=... RND=...  
X... Z... ANG=...
```

- Chamfer as transition between the straight lines:

```
ANG=... CHR=...  
X... Z... ANG=...
```

Programming of the end point of the first straight line by specifying the coordinates

- Corner as transition between the straight lines:

```
X... Z...  
X... Z...
```



- Rounding as transition between the straight lines:

```
X... Z... RND=...  
X... Z...
```

- Chamfer as transition between the straight lines:

```
X... Z... CHR=...  
X... Z...
```

Meaning

<p>ANG= . . . :</p>	<p>Identifier for angle programming The specified value (angle) refers to the abscissa of the active working plane (Z axis with G18).</p>
<p>RND= . . . :</p>	<p>Identifier for programming a rounding The specified value corresponds to the radius of the rounding:</p> 
<p>CHR= . . . :</p>	<p>Identifier for programming a chamfer The specified value corresponds to the width of the chamfer in the direction of motion:</p> 
<p>X . . . :</p>	<p>Coordinates in the X direction</p>
<p>Z . . . :</p>	<p>Coordinates in the Z direction</p>

Note

For further information on the programming of a chamfer or rounding, see "Chamfer, rounding (CHF, CHR, RND, RNDM, FRC, FRCM) (Page 240)".

Example

Program code	Comment
N10 X10 Z80 F1000 G18	; Approach the starting position.
N20 ANG=148.65 CHR=5.5	; Straight line with angle and chamfer specification.
N30 X85 Z40 ANG=100	; Straight line with angle and end point specification.
N40 ...	


2.9.8.4 Contour definitions: Three straight lines

Note

In the following description it is assumed that:

- G18 is active (⇒ active working plane is the Z/X plane).
(However, the programming of contour definitions is also possible without restrictions with G17 or G19.)
 - The following identifiers have been defined for angle, radius and chamfer:
 - ANG (angle)
 - RND (radius)
 - CHR (chamfer)
-

The end point of the first straight line can be programmed by specifying the Cartesian coordinates or by specifying the angle of the two straight lines. The end point of the second and third straight lines must always be programmed with Cartesian coordinates. The intersection of the straight lines can be designed as a corner, a curve, or a chamfer.



- ANG1: Angle of the first straight line
- ANG2: Angle of the second straight line
- X1, Z1: Start coordinates of the first straight line
- X2, Z2: End point coordinates of the first straight line or start coordinates of the second straight line
- X3, Z3: End point coordinates of the second straight line or start coordinates of the third straight line
- X4, Z4: End point coordinates of the third straight line

Note

The programming described here for a three point contour definition can be expanded arbitrarily for contour definitions with more than three points.

Syntax

Programming of the end point of the first straight line by specifying the angle

- Corner as transition between the straight lines:

```

ANG=...
X... Z... ANG=...
X... Z...
    
```

- Rounding as transition between the straight lines:

```

ANG=... RND=...
X... Z... ANG=... RND=...
X... Z...
    
```

- Chamfer as transition between the straight lines:

```
ANG=... CHR=...
X... Z... ANG=... CHR=...
X... Z...
```

Programming of the end point of the first straight line by specifying the coordinates

- Corner as transition between the straight lines:

```
X... Z...
X... Z...
X... Z...
```


- Rounding as transition between the straight lines:


```
X... Z... RND=...
X... Z... RND=...
X... Z...
```

- Chamfer as transition between the straight lines:

```
X... Z... CHR=...
X... Z... CHR=...
X... Z...
```

Meaning

<p>ANG= . . . :</p>	<p>Identifier for angle programming The specified value (angle) refers to the abscissa of the active working plane (Z axis with G18).</p>
<p>RND= . . . :</p>	<p>Identifier for programming a rounding The specified value corresponds to the radius of the rounding:</p> 

CHR=... :	<p>Identifier for programming a chamfer</p> <p>The specified value corresponds to the width of the chamfer in the direction of motion:</p> 
X... :	Coordinates in the X direction
Z... :	Coordinates in the Z direction

Note

For further information on the programming of a chamfer or rounding, see " Chamfer, rounding (CHF, CHR, RND, RNDM, FRC, FRCM) (Page 240) ".

Example

Program code	Comment
N10 X10 Z100 F1000 G18	; Approach the starting position
N20 ANG=140 CHR=7.5	; Straight line with angle and chamfer specification.
N30 X80 Z70 ANG=95.824 RND=10	; Straight line to intermediate point with angle and chamfer specification.
N40 X70 Z50	; Straight line to end point.

2.9.8.5 Contour definitions: End point programming with angle**Function**

If the address letter A appears in an NC block, either none, one or both of the axes in the active plane may also be programmed.

Number of programmed axes

- If **no axis** of the active plane has been programmed, then this is either the first or second block of a contour definition consisting of two blocks. If it is the second block of such a contour definition, then this means that the starting point and end point in the active plane are identical. The contour definition is then at best a motion perpendicular to the active plane.
- If **exactly one axis** of the active plane has been programmed, then this is either a single straight line whose end point can be clearly defined via the angle and programmed Cartesian coordinate or the second block of a contour definition consisting of two blocks. In the second case, the missing coordinate is set to the same as the last (modal) position reached.
- If **two axes** of the active plane have been programmed, then this is the second block of a contour definition consisting of two blocks. If the current block has not been preceded by a block with angle programming without programmed axes of the active plane, then this block is not permitted.


Angle A may only be programmed for linear or spline interpolation.

2.9.9 Thread cutting

2.9.9.1 Thread cutting with constant lead (G33, SF)

Threads with constant lead can be machined with G33:

- Cylindrical thread ①
- Face thread ②
- Taper thread ③




Note

Technical requirement for thread cutting with G33 is a variable-speed spindle with position measuring system.

Multiple thread

Multiple thread (thread with offset cuts) can be machined by specifying a starting point offset. The programming is performed in the G33 block at address SF.




Note

If no starting point offset is specified, the "starting angle for thread" defined in the setting data is used.

Thread chain

A thread chain can be machined with several G33 blocks programmed in succession:



Note

With continuous-path mode G64, the blocks are linked by the look-ahead velocity control in such a way that there are no velocity jumps.

Direction of rotation of the thread

The direction of rotation of the thread is determined by the direction of rotation of the spindle:

- Clockwise with M3 produces a right-hand thread
- Counter-clockwise with M4 produces a left-hand thread

Syntax

Cylinder thread:

```
G33 Z... K...
G33 Z... K... SF=...
```

Face thread:

```
G33 X... I...
G33 X... I... SF=...
```

Tapered thread:

```
G33 X... Z... K...
G33 X... Z... K... SF=...
G33 X... Z... I...
G33 X... Z... I... SF=...
```


Meaning

G33:	Command for thread cutting with constant lead
X... Y... Z... :	End point(s) in Cartesian coordinates
I... :	Thread lead in X direction
J... :	Thread lead in Y direction
K... :	Thread lead in Z direction
Z:	Longitudinal axis
X:	Transverse axis
Z... K... :	Thread length and lead for cylinder threads
X... I... :	Thread diameter and thread lead for face threads
I... or K... :	Thread lead for tapered threads
	The specification (I... or K...) refers to the taper angle:
< 45°:	The thread lead is specified with K... (thread lead in longitudinal direction).
> 45°:	The thread lead is specified with I... (thread lead in transverse direction).
= 45°:	The thread lead can be specified with I... or K...

SF=... :	Starting point offset (only required for multiple threads) The starting point offset is specified as an absolute angle position.
	Range of values: 0.0000 to 359.999 degrees


Examples

Example 1: Double cylinder thread with 180° starting point offset



Program code	Comment
N10 G1 G54 X99 Z10 S500 F100 M3	; Work offset, approach starting point, activate spindle.
N20 G33 Z-100 K4	; Cylinder thread: End point in Z.
N30 G0 X102	; Retraction to starting position.
N40 G0 Z10	
N50 G1 X99	
N60 G33 Z-100 K4 SF=180	; 2nd cut: Starting point offset 180°.
N70 G0 X110	; Retract tool.
N80 G0 Z10	
N90 M30	; End of program

Example 2: Tapered thread with angle less than 45°




Program code	Comment
N10 G1 X50 Z0 S500 F100 M3	; Approach starting point, activate spindle.
N20 G33 X110 Z-60 K4	; Tapered thread: End point in X and Z, specification of thread lead with K... in Z direction (since angle < 45°).
N30 G0 Z0 M30	; Retraction, end of program.

Further information

Feedrate for thread cutting with G33

From the programmed spindle speed and the thread lead, the control calculates the required feedrate with which the turning tool is traversed over the thread length in the longitudinal and/or transverse direction. The feedrate **F** is not taken into account for G33, the limitation to maximum axis velocity (rapid traverse) is monitored by the control.




Cylinder thread

The cylinder thread is described by:

- Thread length
- Thread lead

The thread length is entered with one of the Cartesian coordinates X, Y or Z in absolute or incremental dimensions (for turning machines preferably in the Z direction). Allowance must also be made for the run-in and run-out paths, across which the feed is accelerated or decelerated.


The thread lead is entered at addresses I, J, K (K is preferable for turning machines).



Face thread

The face thread is described by:

- Thread diameter (preferably in the X direction)
- Thread lead (preferably with I)




Tapered thread

The tapered thread is described by:

- End point in the longitudinal and transverse direction (taper contour)
- Thread lead

The taper contour is entered in Cartesian coordinates X, Y, Z in absolute or incremental dimensions - preferentially in the X and Z direction for machining on turning machines. Allowance must also be made for the run-in and run-out paths, across which the feed is accelerated or decelerated.

The specification of the lead depends on the taper angle (angle between the longitudinal axis and the outside of the taper):



2.9.9.2 Thread cutting with increasing or decreasing lead (G34, G35)

With the commands G34 and G35, the G33 functionality has been extended with the option of programming a change in the thread lead at address F. With G34, this results in a linear increase and with G35 to a linear decrease of the thread lead. The commands G34 and G35 can therefore be used for the machining of self-tapping threads.

Syntax

Cylinder thread with increasing lead:

```
G34 Z... K... F...
```

Cylinder thread with decreasing lead:

```
G35 Z... K... F...
```

Face thread with increasing lead:

```
G34 X... I... F...
```

Face thread with decreasing lead:

```
G35 X... I... F...
```

Taper thread with increasing lead:

G34 X... Z... K... F...

G34 X... Z... I... F...

Taper thread with decreasing lead:

G35 X... Z... K... F...

G35 X... Z... I... F...

Meaning

G34:	Command for thread cutting with linear increasing lead
G35:	Command for thread cutting with linear decreasing lead
X... Y... Z...:	End point(s) in Cartesian coordinates
I...:	Thread lead in X direction
J...:	Thread lead in Y direction
K...:	Thread lead in Z direction
F...:	Thread lead change If you already know the starting and final lead of a thread, you can calculate the thread lead change to be programmed according to the following equation: <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;">$F = \frac{k_e^2 - k_a^2}{2 * l_G} \text{ [mm/rev}^2\text{]}$</div> The meanings are as follows:
k_e :	Thread lead (thread lead of axis target point coordinate) [mm/rev]
k_a :	Starting thread lead (programmed under I, J, or K) [mm/rev]
l_G :	Thread length [mm]

Example

Program code	Comment
N1608 M3 S10	; Spindle on.
N1609 G0 G64 Z40 X216	; Approach starting point.
N1610 G33 Z0 K100 SF=R14	; Thread cutting with constant lead (100 mm/rev).
N1611 G35 Z-200 K100 F17.045455	; Lead decrease: 17.0454 mm/rev ² Lead at end of block: 50 mm/rev.
N1612 G33 Z-240 K50	; Traverse thread block without jerk.
N1613 G0 X218	
N1614 G0 Z40	
N1615 M17	


References

Function Manual, Basic Functions; Feedrates (V1), Section "Linear increasing/decreasing thread lead change with G34 and G35"

2.9.9.3 Programmed run-in and run-out path for G33, G34 and G35 (DITS, DITE)

The run-in and run-out path of the thread can be specified in the part program with the `DITS` and `DITE` addresses.

The thread axis is accelerated or braked along the specified path.



① Run-in/run-out path, depending on the machining direction

Short run-in path

Due to the collar on the thread runin, little room is left for the tool start ramp. This must therefore be specified shorter via `DITS`.

Short run-out path

Because of the shoulder at the thread run-out, there is not much room for the tool braking ramp, introducing a risk of collision between the workpiece and the tool cutting edge. The deceleration ramp can be specified shorter using `DITE`. Due to the inertia of the mechanical system, however, a collision can still occur.

Remedy: Program a shorter thread, reduce the spindle speed.

Note

`DITE` acts at the end of the thread as a rounding clearance. This achieves a smooth change in the axis motion.

Effects

The programmed run-in and run-out path only increases the rate of acceleration on the path. If one of the two paths is set larger than the thread axis needs with active acceleration, the thread axis is accelerated or decelerated with maximum acceleration.

Syntax

`DITS=<Value> DITE=<Value>`

Meaning

DITS:	Define thread run-in path
DITE:	Define thread run-out path
<value>:	Only paths, and not positions, are programmed with DITS and DITE. The programmed run-in/run-out path is handled according to the current dimension setting (inches, metric).

Example

Program code	Comment
...	
N40 G90 G0 Z100 X10 SOFT M3 S500	
N50 G33 Z50 K5 SF=180 DITS=1 DITE=3	; Start of smoothing with Z=53.
N60 G0 X20	

Further information

SD42010 \$SC_THREAD_RAMP_DISP

When a block containing DITS and/or DITE is inserted in the main run, the programmed run-in/run-out path is transferred into the setting data SD42010 \$SC_THREAD_RAMP_DISP:

- SD42010 \$SC_THREAD_RAMP_DISP[0] = programmed value of DITS
- SD42010 \$SC_THREAD_RAMP_DISP[1] = programmed value of DITE

If no run-in/run-out path is programmed before or in the first thread block, the current value of the setting data is used.

Behavior following channel / mode group / program end reset

SD 42010 values which have been overwritten by DITS and/or DITE remain active even following a channel / mode group / program end reset.

Behavior following warm start

In case of a warm start, the setting data is reset to the values which were active before overwriting by DITS and/or DITE (standard behavior).

If, however, the values programmed with DITS and DITE shall also be active following a warm restart, the setting data SD42010 \$SC_THREAD_RAMP_DISP must be listed in the machine data MD10710 \$MN_PROG_SD_RESET_SAVE_TAB:

```
MD10710 $MN_PROG_SD_RESET_SAVE_TAB[<n>] = 42010
```

Behavior if the run-in and/or run-out path is very short

If the run-in and/or run-out path is very short, the acceleration of the thread axis is higher than the configured value. This causes an acceleration overload on the axis.

Alarm 22280 "Programmed run-in path too short" is then issued for the thread run-in (with the appropriate configuration in MD11411 \$MN_ENABLE_ALARM_MASK). The alarm is purely for information and has no effect on part program execution.

2.9.9.4 Fast retraction during thread cutting (LFON, LFOF, DILF, ALF, LFTXT, LFWP, LFPOS, POLF, POLFMASK, POLFMLIN)

The "Rapid retraction during thread cutting (G33)" function can be used to interrupt thread cutting without causing irreparable damage in the following circumstances:

- NC stop via NC/PLC interface signal: DB21, ... DBX7.3 (NC stop)
- Alarms that implicitly trigger NC stop
- Switching of a rapid input

References

Programming Manual, Job Planning; Section "Rapid retraction from the contour"

The retraction motion can be programmed via:

- Retraction path and retraction direction (relative)
- Retraction position (absolute)

Note

NC stop signals

The following NC stop signals do not trigger a rapid retraction during thread cutting:

- DB21, ... DBX3.4 (NC stop axes plus spindles)
- DB21, ... DBX7.2 (NC stop at the block limit)

Tapping

The "Rapid retraction" function **cannot** be used with **tapping** (G331/G332).

Syntax

Enable rapid retraction, retraction motion via retraction path and retraction direction:

```
G33 ... LFON DILF=<value> LFTXT/LFWP ALF=<value>
```

Enable rapid retraction, retraction motion via retraction position:

```
POLF[<axis identifier>]=<value> LFPOS  
POLFMASK/POLFMLIN(<axis 1 name>,<axis 2 name>, etc.)  
G33 ... LFON
```

Disable rapid retraction during thread cutting:

```
LFOF
```

Meaning

LFON:	Enable rapid retraction during thread cutting (G33)
LFOF:	Disable rapid retraction during thread cutting (G33)
DILF= :	Define length of retraction path
	The value preset during MD configuration (MD21200 \$MC_LIFTFAST_DIST) can be modified in the part program by programming DILF.
	Note: The configured MD value is always active following NC-RESET.

LFTXT LFWP:	The retraction direction is controlled in conjunction with ALF with G commands LFTXT and LFWP.	
	LFTXT:	The plane in which the retraction motion is executed is calculated from the path tangent and the tool direction (default setting).
	LFWP:	The plane in which the retraction motion is executed is the active working plane.
ALF= :	The direction is programmed in discrete degree increments with ALF in the plane of the retraction motion.	
	With LFTXT, retraction in the tool direction is defined for ALF=1. For LFWP, the direction in the working/machining plane has the following assignment:	
	<ul style="list-style-type: none"> • G17 (X/Y plane) ALF=1 ; Retraction in the X direction ALF=3 ; Retraction in the Y direction • G18 (Z/X plane) ALF=1 ; Retraction in the Z direction ALF=3 ; Retraction in the X direction • G19 (Y/Z plane) ALF=1 ; Retraction in the Y direction ALF=3 ; Retraction in the Z direction 	
References:		Programming options with ALF are also described in "Traverse direction for rapid retraction from the contour" in the Programming Manual, Job Planning.
LFPPOS:	Retraction of the axis declared with POLFMASK or POLFMLIN to the absolute axis position programmed with POLF.	
POLFMASK:	Release of axes (<axis 1 name>,<axis 1 name>, etc.) for independent retraction to absolute position.	
POLFMLIN:	Release of axes for retraction to absolute position in linear relation Note: Depending on the dynamic response of all the axes involved, the linear relation cannot always be established before the lift position is reached.	
POLF[]:	Define absolute retraction position for the geometry axis or machine axis in the index	
	Effective:	Modal
	=<value>:	In the case of geometry axes, the assigned value is interpreted as a position in the workpiece coordinate system. In the case of machine axes, it is interpreted as a position in the machine coordinate system. The values assigned can also be programmed as incremental dimensions: =IC<value>
<axis identifier>:	Identifier of a geometry axis or machine axis.	

Note

LFOF or LFOF can always be programmed, but the evaluation is performed exclusively during thread cutting (G33).

Note

POLF with POLFMASK/POLFMLIN are not restricted to thread cutting applications.

Examples

Example 1: Enable rapid retraction during thread cutting

Program code	Comment
N55 M3 S500 G90 G18	; Active machining plane
...	; Approach the starting position
N65 MSG ("thread cutting")	; Tool infeed
MM_THREAD:	
N67 \$AC_LIFTFAST=0	; Reset before starting the thread.
N68 G0 Z5	
N68 X10	
N70 G33 Z30 K5 LFON DILF=10 LFWP ALF=7	; Enable rapid retraction during thread cutting. Retraction path = 10 mm Retraction plane: Z/X (because of G18) Retraction direction: -X (with ALF=3: Retraction direction +X)
N71 G33 Z55 X15	
N72 G1	; Deselect thread cutting.
N69 IF \$AC_LIFTFAST GOTOB MM_THREAD	; If thread cutting has been interrupted.
N90 MSG ("")	
...	
N70 M30	

Example 2: Switch off rapid retraction before tapping.

Program code	Comment
N55 M3 S500 G90 G0 X0 Z0	
...	
N87 MSG ("tapping")	
N88 LFOF	; Deactivate rapid retraction before tapping.
N89 CYCLE...	; Tapping cycle with G33.
N90 MSG ("")	
...	
N99 M30	

Example 3: Rapid retraction to absolute retraction position

Path interpolation of X is suppressed in the event of a stop and a motion executed to position POLF[X] at maximum velocity instead. The motion of the other axes continues to be determined by the programmed contour or the thread lead and the spindle speed.

Program code	Comment
N10 G0 G90 X200 Z0 S200 M3	
N20 G0 G90 X170	
N22 POLF[X]=210 LFPOS	
N23 POLFMASK(X)	; Activate (enable) rapid retraction from axis X.
N25 G33 X100 I10 LFON	
N30 X135 Z-45 K10	
N40 X155 Z-128 K10	
N50 X145 Z-168 K10	
N55 X210 I10	
N60 G0 Z0 LFOF	
N70 POLFMASK()	; Disable lift for all axes.
M30	

2.9.9.5 Convex thread (G335, G336)

The G commands G335 and G336 can be used to turn convex threads (= differing to the cylindrical form). Application is the machining of extremely large components that sag in the machine because of their self-weight. Paraxial thread would result in the thread being too small in the middle of the component. This can be compensated with convex threads.




Figure 2-13 Turning a convex thread

Programming

The turning of a convex thread is programmed with G335 or G336:

G335:	Turning of a convex thread on a circular tool path in a clockwise direction
G336:	Turning of a convex thread on a circular tool path in a counter-clockwise direction

The programming is performed first as for a linear thread by specifying the axial block end points and the pitch via parameters I, J and K (see "Thread cutting with constant lead (G33, SF) (Page 216)").

An arc is also specified. As for G2/G3, this can be programmed via the center point, radius, opening angle or intermediate point specification (see "Circular interpolation (Page 188)"). When programming the convex thread with center point programming, the following must be taken into account: Since I, J and K are used for the pitch in thread cutting, the circle parameters in the center point programming must be programmed with IR= . . . , JR= . . . and KR=

IR= . . . :	Cartesian coordinate for the circle center point in the X direction
JR= . . . :	Cartesian coordinate for the circle center point in the Y direction
KR= . . . :	Cartesian coordinate for the circle center point in the Z direction

Note

IR, JR and KR are the default values of the interpolation parameter names for a convex thread that can be set via machine data (MD10651 \$MN_IPO_PARAM_THREAD_NAME_TAB).

Differences to the default values must be taken from the specifications of the machine manufacturer.

Optionally, a starting point offset SF can also be specified (see "Thread cutting with constant lead (G33, SF) (Page 216)").

Syntax

The syntax for the programming of a convex thread therefore has the following general form: G335/G336 <axis target point coordinate(s)> <pitch> <arc> [<starting point offset>]

Examples

Example 1: Convex thread in the clockwise direction with end and center point programming

Program code	Comment
N5 G0 G18 X50 Z50	; Approach starting point.
N10 G335 Z100 K=3.5 KR=25 IR=-20 SF=90	; Turn convex thread in the clockwise direction.




Figure 2-14 Convex thread in the clockwise direction with end and center point programming

Example 2: Convex thread in the counter-clockwise direction with end and center point programming

Program code	Comment
N5 G0 G18 X50 Z50	; Approach starting point.
N10 G336 Z100 K=3.5 KR=25 IR=20 SF=90	; Turn convex thread in the counter-clockwise direction.




Figure 2-15 Convex thread in the counter-clockwise direction with end and center point programming

Example 3: Convex thread in the clockwise direction with end point and radius programming

Program code
N5 G0 G18 X50 Z50

Program code

N10 G335 Z100 K=3.5 CR=32 SF=90




Figure 2-16 Convex thread in the clockwise direction with end point and radius programming

Example 4: Convex thread in the clockwise direction with end point and opening angle programming

Program code

N5 G0 G18 X50 Z50
 N10 G335 Z100 K=3.5 AR=102.75 SF=90




Figure 2-17 Convex thread in the clockwise direction with end point and opening angle programming

Example 5: Convex thread in the clockwise direction with center point and opening angle programming

Program code

```
N5 G0 G18 X50 Z50
N10 G335 K=3.5 KR=25 IR=-20 AR=102.75 SF=90
```




Figure 2-18 Convex thread in the clockwise direction with center point and opening angle programming

Example 6: Convex thread in the clockwise direction with end and intermediate point programming

Program code

```
N5 G0 G18 X50 Z50
N10 G335 Z100 K=3.5 I1=60 K1=64
```





Figure 2-19 Convex thread in the clockwise direction with end and intermediate point programming

Further information

Permissible arc areas

The arc programmed at G335/G336 must be in an area in which the specified thread main axis (I, J or K) has the main axis share on the arc over the entire arc:



Permissible areas for the Z axis (pitch programmed with K)

Permissible areas for the X axis (pitch programmed with I)

A change of the thread main axis as shown in the following figure is **not** permitted:




Figure 2-20 Convex thread: Area that is not permissible

Frames

G335 and G336 are also possible with active frames. However, you must ensure that the permissible arc areas are maintained in the basic coordinate system (BCS).

Supplementary conditions for the circular-path programming

The supplementary conditions described for the circular-path programming with G2/G3 apply for the circular-path programming under G335/G336 (see "Circular interpolation (Page 188)").

2.9.10 Tapping without compensating chuck

2.9.10.1 Tapping without compensating chuck and retraction motion (G331, G332)

For tapping without compensating chuck, using the G331 and G332 commands, the following traversing motion is executed:

- G331: Tapping in the tapping direction up to the end of thread point
- G332: Retraction motion up to the tapping block G331 with automatic spindle direction of rotation reversal

Syntax

```
G331 <axis> <thread pitch>
G331 <axis> <thread pitch> S...
G332 <axis> <thread pitch>
```

Meaning

G331:	Tapping The tapped hole is defined by the traversing motion of the axis (drilling depth) and the thread pitch.
	Effectiveness: Modal
G332:	Retraction motion when tapping Retraction motion must have the same pitch as when tapping (G331). The direction of rotation of the spindle is reversed automatically.
	Effectiveness: Modal
<axis>:	Traversing distance/position of the geometry axis (X, Y or Z) at the end of the thread, e.g. Z50
<Thread pitch>:	Thread pitch I (X), J (Y) or K (Z):
	<ul style="list-style-type: none"> • Positive pitch: Right-handed thread, e.g. K1.25 • Negative pitch: Left-handed thread, e.g. K-1.25
	Range of values: ± 0.001 to ± 2000.00 mm/revolution
S...:	Spindle speed The last active spindle speed is used if a spindle speed is not specified.

Note

Second gear-stage data block

To achieve effective adaptation of spindle speed and motor torque and be able to accelerate faster, a second gear-stage data block for two further configurable switching thresholds (maximum speed and minimum speed) can be preset in axis-specific machine data deviating from the first gear step data block and also independent of these speed switching thresholds. The specifications of the machine manufacturer must be observed.

For further information see the "Axes and Spindles" Function Manual.

Examples

- Example: Tapping with G331 / G332 (Page 236)
- Example: Output the programmed drilling speed in the current gear stage (Page 236)
- Example: Application of the second gear-stage data block (Page 237)
- Example: Speed is not programmed, the gearbox stage is monitored (Page 237)
- Example: Gearbox stage cannot be changed, gearbox stage monitoring (Page 238)
- Example: Programming without SPOS (Page 238)

2.9.10.2 Example: Tapping with G331 / G332

Program code	Comment
N10 SPOS[n]=0	; Spindle: Position control mode ; Start position 0 degrees
N20 G0 X0 Y0 Z2	; Axes: Approach starting position
N30 G331 Z-50 K-4 S200	; Tapping in Z, ; Pitch K-4 negative => ; Direction of spindle rotation: CCW rotation, ; Spindle speed 200 rpm
N40 G332 Z3 K-4	; Retraction motion in Z, ; Pitch K-4 negative (counterclockwise), ; autom. direction of rotation reversal => ; Clockwise spindle direction of rotation
N50 G1 F1000 X100 Y100 Z100 S300 M3	; Spindle in spindle operation

2.9.10.3 Example: Output the programmed drilling speed in the current gear stage

Program code	Comment
N05 M40 S500	; Programmed spindle speed: 500 rpm => ; Gearbox stage 1 (20 to 1028 rpm)
...	
N55 SPOS=0	; Position the spindle
N60 G331 Z-10 K5 S800	; Tapping ; Spindle speed 800 rpm => gearbox stage 1

The appropriate gear stage for the programmed spindle speed S500 with M40 is determined on the basis of the first gear-stage data block. The programmed drilling speed S800 is output in the current gear stage and, if necessary, is limited to the maximum speed of the gear stage. No

automatic gear-stage change is possible following an SPOS operation. In order for an automatic change in gear stage to be performed, the spindle must be in speed-control mode.

Note

If gearbox stage 2 is selected at a spindle speed of 800 rpm, then the switching thresholds for the maximum and minimum speed must be configured in the relevant machine data of the second gear-stage data block (see the examples below).

2.9.10.4 Example: Application of the second gear-stage data block

The switching thresholds of the second gear-stage data block for the maximum and minimum speed are evaluated for G331/G332 and when programming an S value for the active master spindle. Automatic M40 gear-stage change must be active. The gear stage as determined in the manner described above is compared with the active gear stage. If they are found to be different, then the gearbox stage is changed.

Program code	Comment
N05 M40 S500	; Programmed spindle speed: 500 rpm
...	
N50 G331 S800	; Master spindle: Gearbox stage 2 is selected
N55 SPOS=0	; Position the spindle
N60 G331 Z-10 K5	; Tapping
	; Spindle acceleration from second gearbox stage data block 2

2.9.10.5 Example: Speed is not programmed, the gearbox stage is monitored

If no speed is programmed when using the second gearbox stage data block with G331, then the last speed programmed will be used to produce the thread. The gear stage does not change. However, monitoring is performed in this case to check that the last speed programmed is within the preset speed range (defined by the maximum and minimum speed thresholds) for the active gear stage. Otherwise, alarm 16748 is output.

Program code	Comment
N05 M40 S800	; Programmed spindle speed: 800 rpm
...	
N55 SPOS=0	; Position the spindle
N60 G331 Z-10 K5	; Tapping
	; Monitoring the spindle speed, 800 rpm
	; Gearbox stage 1 is active
	; Gearbox stage 2 should be active => Alarm 16748

2.9.10.6 Example: Gearbox stage cannot be changed, gearbox stage monitoring

If the spindle speed is programmed in addition to the geometry in the G331 block when using the second gear-stage data block, if the speed is not within the preset speed range (defined by the maximum and minimum speed thresholds) of the active gear stage, it will not be possible to change gear stages, because the path motion of the spindle and the infeed axis (axes) would not be retained.

As in the example above, the speed and gearbox stage are monitored in the G331 block and alarm 16748 is signaled if necessary.

Program code	Comment
N05 M40 S500	; Programmed spindle speed: 500 rpm => ; Gearbox stage 1
...	
N55 SPOS=0	; Position the spindle
N60 G331 Z-10 K5 S800	; Tapping ; Gearbox stage cannot be changed, ; Monitoring the spindle speed, 800 rpm ; with gearbox stage data set 1: Gearbox stage 2 ; should be active => Alarm 16748

2.9.10.7 Example: Programming without SPOS

Program code	Comment
N05 M40 S500	; Programmed spindle speed: 500 rpm => ; Gearbox stage 1 (20 to 1028 rpm)
...	
N50 G331 S800	; Master spindle: Gearbox stage 2 is selected
N60 G331 Z-10 K5	; Tapping ; Spindle acceleration from second gearbox stage data block 2

Thread interpolation for the spindle starts from the current position, which is determined by the previously processed section of the part program, e.g. if the gear stage was changed. Therefore, it might not be possible to remachine the thread.

Note

Please note that when machining with multiple spindles, the drill spindle also has to be the master spindle. SETMS(<spindle number>) can be programmed to set the drill spindle as the master spindle.

2.9.11 Tapping with compensating chuck

2.9.11.1 Tapping with compensating check and retraction motion (G63)

For tapping with compensating chuck, using the G63 command, the following traversing motion is executed:

- G63: Tapping in the tapping direction up to the end of thread point
- G63: Retraction motion with programmed spindle direction of rotation reversal

Note

After a G63 block, the last effective interpolation type G0, G1, G2 is active.

Syntax

G63 <axis> <direction of rotation> <speed> <feedrate>

Meaning

G63:	Tapping with compensating chuck	
	Effective:	Non-modal
<Axis>:	Traversing distance/position of the geometry axis (X, Y or Z) at the end of the thread, e.g. Z50	
<Direction of rotation>:	Direction of spindle rotation: <ul style="list-style-type: none"> • M3: Clockwise rotation, right-hand thread • M4: Counterclockwise rotation, left-hand thread 	
<Speed>:	Maximum permissible spindle speed while tapping, e.g. S100	
<Feedrate>:	Feedrate of the tapping axis F, with $F = \text{spindle speed} * \text{thread pitch}$	

Example

Tapping an M5 thread:

- Spindle pitch according to the standard: 0.8 mm/rev
- Spindle speed S: 200 rpm
- Feedrate $F = 200 \text{ rpm} * 0.8 \text{ mm/rev} = 160 \text{ mm/min}$.

Program code	Comment
N10 G1 X0 Y0 Z2 F1000 S200 M3	; Approach starting point ; Spindle clockwise direction of rotation, 200 rpm
N20 G63 Z-50 F160	; Tapping with compensating chuck ; Drilling depth: absolute Z=50mm ; Feedrate: 160 mm/min

Program code	Comment
N30 G63 Z3 M4	; Retraction movement: absolute Z=3mm ; Direction of rotation reversal ; Spindle with counterclockwise direction of rotation, 200 rpm

2.9.12 Chamfer, rounding (CHF, CHR, RND, RNDM, FRC, FRCM)

Contour corners within the active working plane can be executed as roundings or chamfers. For optimum surface quality, a separate feedrate can be programmed for chamfer/rounding. If a feedrate is not programmed, the standard path feedrate F will be applied. The "Modal rounding" function can be used to round multiple contour corners in the same way one after the other.

Syntax

```

Chamfer the contour corner:
G... X... Z... CHR/CHF=<value> FRC/FRCM=<value>
G... X... Z...

Round the contour corner:
G... X... Z... RND=<value> FRC=<value>
G... X... Z...

Modal rounding:
G... X... Z... RNDM=<value> FRCM=<value>
...
RNDM=0
    
```

Note

The technology (feedrate, feedrate type, M commands, etc.) for chamfer/rounding is derived from either the previous or the next block dependent on the setting of bit 0 in machine data MD20201 \$MC_CHFRND_MODE_MASK (chamfer/rounding behavior). The recommended setting is the derivation from the previous block (bit 0 = 1).

Meaning

CHF=... :	Chamfer the contour corner	
	<value>:	Length of the chamfer (unit corresponding to G70/G71)
CHR=... :	Chamfer the contour corner	
	<value>:	Width of the chamfer in the original direction of motion (unit corresponding to G70/G71)
RND=... :	Round the contour corner	
	<value>:	Radius of the rounding (unit corresponding to G70/G71)

RNDM=... :	Modal rounding (rounding multiple contour corners in the same way one after the other)	
	<value>:	Radius of the roundings (unit corresponding to G70/G71) Modal rounding is deactivated with RNDM=0.
FRC=... :	Non-modal feedrate for chamfer/rounding	
	<value>:	Feedrate in mm/min (with active G94) or mm/rev (with active G95)
FRCM=... :	Modal feedrate for chamfer/rounding	
	<value>:	Feedrate in mm/min (with active G94) or mm/rev (with active G95) FRCM=0 deactivates modal feedrate for chamfer/rounding and activates the feedrate programmed under F.

Note**Chamfer/rounding too high**

If the values programmed for chamfer (CHF/CHR) or rounding (RND/RNDM) are too high for the contour elements involved, chamfer or rounding will automatically be adapted:

1. If MD11411 \$MN_ENABLE_ALARM_MASK bit 4 is set, alarm 10833 "Chamfer or rounding must be reduces" is output (cancel alarm).
2. The chamfer/rounding is reduced until it fits in the contour corner. This results in at least one block without motion. At this block, the required motion is stopped.

Note**Chamfer/rounding not possible**

No chamfer/rounding is performed if:

- No straight or circular contour is available in the plane
- A movement takes place outside the plane
- The plane is changed
- The number of blocks specified in the machine data that are not to contain any information about traversing (e.g. only command outputs) is exceeded

Note**FRC/FRCM**

FRC/FRCM has no effect if a chamfer is traversed with G0; the command can be programmed according to the F value without error message.

FRC is only effective if a chamfer/rounding is programmed in the block or if RNDM has been activated.

FRC overwrites the F or FRCM value in the current block.


The feedrate programmed under FRC must be greater than zero.

FRCM=0 activates the feedrate programmed under F for chamfer/rounding.

If FRCM is programmed, the FRCM value will need to be reprogrammed like F on change G94 ↔ G95, etc. If only F is reprogrammed and if the feedrate type FRCM > 0 before the change, an error message will be output.

Examples

Example 1: Chamfer between two straight lines



- MD20201 Bit 0 = 1 (derived from previous block).
- G71 is active.
- The width of the chamfer in the direction of motion (CHR) should be 2 mm and the feedrate for chamfer 100 mm/min.

Programming can be performed in two ways:

- Programming with CHR


```

Program code
...
N30 G1 Z... CHR=2 FRC=100
N40 G1 X...
...
    
```

- Programming with CHF

```

Program code
...
N30 G1 Z... CHF=2(cosα*2) FRC=100
N40 G1 X...
...
    
```

Example 2: Rounding between two straight lines


- MD20201 Bit 0 = 1 (derived from previous block).
- G71 is active.
- The radius of the rounding should be 2 mm and the feedrate for rounding 50 mm/min.

Program code

```
...
N30 G1 Z... RND=2 FRC=50
N40 G1 X...
...
```

Example 3: Rounding between straight line and circle

The RND function can be used to insert a circle contour element with tangential connection between the linear and circle contours in any combination.



- MD20201 Bit 0 = 1 (derived from previous block).
- G71 is active.
- The radius of the rounding should be 2 mm and the feedrate for rounding 50 mm/min.

Program code

```
...
```

Program code
N30 G1 Z... RND=2 FRC=50
N40 G3 X... Z... I... K...
...

Example 4: Modal rounding to deburr sharp workpiece edges

Program code	Comment
...	
N30 G1 X... Z... RNDM=2 FRCM=50	; Activate modal rounding. Radius of rounding: 2 mm Feedrate for rounding: 50 mm/min
N40...	
N120 RNDM=0	; Deactivate modal rounding.
...	

Example 5: Apply technology from following block or previous block

- MD20201 Bit 0 = 0: Derived from following block (default setting!)

Program code	Comment
N10 G0 X0 Y0 G17 F100 G94	
N20 G1 X10 CHF=2	; Chamfer N20-N30 with F=100 mm/min
N30 Y10 CHF=4	; Chamfer N30-N40 with FRC=200 mm/min
N40 X20 CHF=3 FRC=200	; Chamfer N40-N60 with FRCM=50 mm/min
N50 RNDM=2 FRCM=50	
N60 Y20	; Modal rounding N60-N70 with FRCM=50 mm/min
N70 X30	; Modal rounding N70-N80 with FRCM=50 mm/min
N80 Y30 CHF=3 FRC=100	; Chamfer N80-N90 with FRC=100 mm/min
N90 X40	; Modal rounding N90-N100 with F=100 mm/min (de-selection of FRCM)
N100 Y40 FRCM=0	; Modal rounding N100-N120 with G95 FRC=1 mm/rev
N110 S1000 M3	
N120 X50 G95 F3 FRC=1	
...	
M02	

- MD20201 Bit 0 = 1: Derived from previous block (recommended setting!)


Program code	Comment
N10 G0 X0 Y0 G17 F100 G94	
N20 G1 X10 CHF=2	; Chamfer N20-N30 with F=100 mm/min
N30 Y10 CHF=4 FRC=120	; Chamfer N30-N40 with FRC=120 mm/min
N40 X20 CHF=3 FRC=200	; Chamfer N40-N60 with FRC=200 mm/min

Program code	Comment
N50 RNDM=2 FRCM=50	
N60 Y20	; Modal rounding N60-N70 with FRCM=50 mm/min
N70 X30	; Modal rounding N70-N80 with FRCM=50 mm/min
N80 Y30 CHF=3 FRC=100	; Chamfer N80-N90 with FRC=100 mm/min
N90 X40	; Modal rounding N90-N100 with FRCM=50 mm/min
N100 Y40 FRCM=0	; Modal rounding N100-N120 with F=100 mm/min
N110 S1000 M3	
N120 X50 CHF=4 G95 F3 FRC=1	; Chamfer N120-N130 with G95 FRC=1 mm/rev
N130 Y50	; Modal rounding N130-N140 with F=3 mm/rev
N140 X60	
...	
M02	

2.10 Tool radius compensation

2.10.1 Tool radius compensation (G40, G41, G42, OFFN)

When tool radius compensation (TRC) is active, the control automatically calculates the equidistant tool paths for various tools.



Syntax

G0/G1 X... Y... Z... G41/G42 [OFFN=<value>]	
...	
G40 X... Y... Z...	


Meaning

G41:	Activate TRC with machining direction left of the contour.
G42:	Activate TRC with machining direction right of the contour.
OFFN=<value>:	Allowance on the programmed contour (normal contour offset) (optional), e.g. to generate equidistant paths for rough finishing.
G40:	Deactivate TRC.

Example 2: "Conventional" procedure using milling as an example


"Conventional" procedure:

1. Tool call.
2. Change tool.
3. Activate working plane and tool radius compensation.




Program code	Comment
N10 G0 Z100	; Retraction for tool change.
N20 G17 T1 M6	; Tool change
N30 G0 X0 Y0 Z1 M3 S300 D1	; Call tool offset values, select length compensation.
N40 Z-7 F500	; Feed in tool.
N50 G41 X20 Y20	; Activate tool radius compensation, tool machines to the left of the contour.
N60 Y40	; Mill contour.
N70 X40 Y70	
N80 X80 Y50	
N90 Y20	
N100 X20	
N110 G40 G0 Z100 M30	; Retract tool, end of program.

Example 3: Turning



Program code	Comment
...	
N20 T1 D1	; Only tool length compensation is activated.
N30 G0 X100 Z20	; X100 Z20 is approached without compensation.
N40 G42 X20 Z1	; Radius compensation is activated, point X20/Z1 is approached with compensation.
N50 G1 Z-20 F0.2	
...	

Example 4: Turning



Program code	Comment
N5 G0 G53 X280 Z380 D0	; Starting point.
N10 TRANS X0 Z250	; Work offset.
N15 LIMS=4000	; Speed limitation (G96).
N20 G96 S250 M3	; Select constant feedrate
N25 G90 T1 D1 M8	; Select tool selection and offset.
N30 G0 G42 X-1.5 Z1	; Set tool with tool radius compensation.
N35 G1 X0 Z0 F0.25	
N40 G3 X16 Z-4 I0 K-10	; Turn radius 10.
N45 G1 Z-12	
N50 G2 X22 Z-15 CR=3	; Turn radius 3.
N55 G1 X24	
N60 G3 X30 Z-18 I0 K-3	; Turn radius 3.
N65 G1 Z-20	
N70 X35 Z-40	
N75 Z-57	
N80 G2 X41 Z-60 CR=3	; Turn radius 3.
N85 G1 X46	
N90 X52 Z-63	
N95 G0 G40 G97 X100 Z50 M9	; Deselect tool radius compensation and approach tool change location.

Program code	Comment
N100 T2 D2	; Call tool and select offset.
N105 G96 S210 M3	; Select constant cutting rate.
N110 G0 G42 X50 Z-60 M8	; Set tool with tool radius compensation.
N115 G1 Z-70 F0.12	; Turn diameter 50.
N120 G2 X50 Z-80 I6.245 K-5	; Turn radius 8.
N125 G0 G40 X100 Z50 M9	; Retract tool and deselect tool radius compensation.
N130 G0 G53 X280 Z380 D0 M5	; Approach tool change location.
N135 M30	; End of program.


Further information

The control requires the following information in order to calculate the tool paths:

- Tool no. (T...), cutting edge no. (D...)
- Machining direction (G41/G42)
- Working plane (G17/G18/G19)

Tool no. (T...), cutting edge no. (D...)

The distance between tool path and workpiece contour is calculated from the milling cutter radii or cutting edge radii and the specifications of the cutting edge position.



Machining direction (G41/G42)


From this information, the control detects the direction in which the tool path is to be displaced.

Note

A negative correction value has the same significance as a change of offset side (G41 ↔ G42).

Working plane (G17/G18/G19)

From this information, the control detects the plane and therefore the axis directions in which it is corrected.



Example: Milling tool

Program code	Comment
...	
N10 G17 G41 ...	; The tool radius compensation is performed in the X/Y plane, the tool length compensation is performed in the Z direction.
...	


Note

On 2-axis machines, tool radius compensation is only possible in "real" planes, usually with G18.

Tool length compensation

The wear parameter assigned to the diameter axis on tool selection can be defined as the diameter value using an MD. This assignment is not automatically altered when the plane is subsequently changed. To do this, the tool must be selected again after the plane change.

Turning:



NORM and KONT can be used to define the tool path on activation and deactivation of compensation mode (see "Approaching and leaving contour (NORM, KONT, KONTC, KONTT) (Page 255)").

Point of intersection


The intersection point is selected in the setting data:

SD42496 \$SC_CUTCOM_CLSD_CONT (behavior of tool radius compensation with closed contour)

Value	Meaning
FALSE	If two intersections appear on the inside when offsetting an (almost) closed contour, which consists of two successive circle blocks or one circle block and one linear block, the intersection positioned closer to the end of block on the first partial contour is selected in accordance with the standard procedure. A contour is deemed to be (almost) closed if the distance between the starting point of the first block and the end point of the second block is less than 10% of the effective compensation radius, but not more than 1000 path increments (corresponds to 1 mm with 3 decimal places).
TRUE	In the same situation as described above, the intersection positioned on the first partial contour closer to the block start is selected.

Change in compensation direction (G41 ↔ G42)

A change in compensation direction (G41 ↔ G42) can be programmed without an intermediate G40.



Change in the working plane

The working plane (G17/G18/G19) **cannot** be changed if G41/G42 is active.

Change of tool offset data block (D...)


The tool offset data block can be changed in compensation mode.

A changed tool radius already becomes active as from the block containing the new D number.

Note

The radius change or compensation movement is performed across the entire block and only reaches the new equidistance at the programmed end point.

In the case of linear movements, the tool travels along an inclined path between the starting point and the end point:



Circular interpolation produces spiral movements.

Changing the tool radius

The change can be made, e.g. using system variables. The sequence is the same as when changing the tool offset data block (D...).

Note

The modified values only take effect the next time T or D is programmed. The change does not apply until the next block.

Compensation mode

Compensation mode may only be interrupted by a certain number of consecutive blocks or M functions which do not contain traversing commands or positional data in the compensation plane.

Note

The number of consecutive blocks or M commands can be set in a machine data (see machine manufacturer's specifications).

Note

A block with a path distance of zero also counts as an interruption!

2.10.2 Approaching and leaving contour (NORM, KONT, KONTC, KONTT)**Requirement**

The **KONTC** and **KONTT** commands will only be available if the "Polynomial interpolation" option has been enabled in the control.

Function

If tool radius compensation is active (G41/G42), the **NORM**, **KONT**, **KONTC** or **KONTT** command can be used to adapt the tool's approach and retract paths to the required contour profile or blank form.

KONTC or **KONTT** ensure observance of the continuity conditions in all three axes. It is, therefore, permissible to program a path component perpendicular to the offset plane simultaneously.

Syntax

G41/G42 NORM/KONT/KONTC/KONTT X... Y... Z...	
...	
G40 X... Y... Z...	

Meaning

NORM:	Activate direct approach/retraction to/from a straight line. The tool is oriented perpendicular to the contour point.
KONT:	Activate approach/retraction with travel around the starting/end point according to the programmed corner behavior G450 or G451.
KONTC:	Activate approach/retraction with constant curvature.
KONTT:	Activate approach/retraction with constant tangent.

Note

Only G1 blocks are permissible as original approach/retraction blocks for KONTC and KONTT. The control replaces these with polynomials for the appropriate approach/retract path.

Supplementary conditions

KONTT and KONTC are not available in 3D variants of tool radius compensation (CUT3DC, CUT3DCC, CUT3DF). If they are programmed, the control switches internally to NORM without an error message.

Example

KONTC

The full circle is approached beginning at the circle center point. The direction and curvature radius at the block end point of the approach block are identical to the values of the next circle. Infeed takes place in the Z direction in both approach/retraction blocks simultaneously. The figure below shows the perpendicular projection of the tool path.




Figure 2-21 Perpendicular projection

The associated NC program segment is as follows:

Program code	Comment
\$TC_DP1[1,1]=121	; Milling tool
\$TC_DP6[1,1]=10	; Radius 10 mm
N10 G1 X0 Y0 Z60 G64 T1 D1 F10000	
N20 G41 KONTC X70 Y0 Z0	; Approach
N30 G2 I-70	; Full circle
N40 G40 G1 X0 Y0 Z60	; Retract
N50 M30	

At the same time as the curvature is being adapted to the circular path of the full circle, traversing is performed from Z60 to the plane of the circle Z0:





Figure 2-22 3D representation.

Further information

Approach/retraction with NORM


1. Approach:

If NORM is activated, the tool will move directly to the compensated start position along a straight line (irrespective of the preset approach angle programmed for the travel movement) and is positioned perpendicular to the path tangent at the starting point.




2. Retraction:

The tool is perpendicular to the last compensated path end point and then moves (irrespective of the preset approach angle programmed for the travel movement) directly in a straight line to the next uncompensated position, e.g. to the tool change point.




Modifying approach/retract angles introduces a collision risk:

**NOTICE****Risk of collision**

Modified approach/retract angles must be taken into account during programming in order that potential collisions can be avoided.

Approach/retraction with KONT

Prior to the approach, the tool can be located **in front of** or **behind** the contour. The path tangent at the starting point serves as a separation line:




2.10 Tool radius compensation


Accordingly, two scenarios need to be distinguished where approach/retraction with `KONT` is concerned:

1. The tool is located in front of the contour.
→ The approach/retract strategy is the same as with `NORM`.
2. The tool is located behind the contour.

- Approach:
The tool travels around the starting point either along a circular path or over the intersection of the equidistant paths depending on the programmed corner behavior (G450/G451).
The commands G450/G451 apply to the transition from the current block to the next block:



In both cases (G450/G451), the following approach path is generated:



A straight line is drawn from the uncompensated approach point. This line is a tangent to a circle with circle radius = tool radius. The center point of the circle is on the starting point.

- Retraction:
The same applies to retraction as to approach, but in the reverse order.


Approach/retraction with KONTC

The contour point is approached/exited with constant curvature. There is no jump in acceleration at the contour point. The path from the start point to the contour point is interpolated as a polynomial.

Approach/retraction with KONTT

The contour point is approached/exited with constant tangent. A jump in the acceleration can occur at the contour point. The path from the start point to the contour point is interpolated as a polynomial.

Difference between KONTC and KONTT




The figure below shows the differences in approach/retraction behavior between `KONTT` and `KONTC`. A circle with a radius of 20 mm about the center point at X0 Y-40 is compensated with a tool with an external radius of 20 mm. The tool center point therefore moves along a circular path with radius 40 mm. The end point of the approach blocks is at X40 Y30. The transition between the circular block and the retraction block is at the zero point. Due to the extended continuity of curvature associated with `KONTC`, the retraction block first executes a movement with a negative Y component. This will often be undesired. This response does not occur with the `KONTT` retraction block. However, with this block, an acceleration step change occurs at the block transition.

If the `KONTT` or `KONTC` block is the approach block rather than the retraction block, the contour is exactly the same, but it is machined in the opposite direction.

2.10.3 Compensation at the outside corners (G450, G451, DISC)

With tool radius compensation activated (G41/G42), command G450 or G451 can be used to define the course of the compensated tool path when traveling around outside corners:



With G450, the tool center point travels around the workpiece corner across an arc with tool radius.

With G451, the tool center point approaches the point of intersection of the two equidistants, which are located at a distance equivalent to the tool radius from the programmed contour. G451 applies only to circles and straight lines.

Note

G450/G451 is also used to define the approach path with `KONT` active and approach point behind the contour (see "Approaching and leaving contour (NORM, KONT, KONTC, KONTT) (Page 255)").

The `DISC` command can be used to distort the transition circles with G450, thereby producing sharper contour corners.

Syntax

```
G450 [DISC=<value>]
```

```
G451
```

Meaning


G450:	G450 is used to travel around workpiece corners on a circular path.					
DISC:	Flexible programming of the circular path with G450 (optional)					
	<value>:	Type:	INT			
		Range of values:	0, 1, 2, ... 100			
		Meaning:	<table border="1"> <tr> <td>0</td> <td>Transition circle</td> </tr> <tr> <td>100</td> <td>Intersection of the equidistant paths (theoretical value)</td> </tr> </table>	0	Transition circle	100
0	Transition circle					
100	Intersection of the equidistant paths (theoretical value)					
G451:	G451 is used to approach the intersection point of the two equidistant paths in the case of workpiece corners. The tool backs off from the workpiece corner.					

Note

DISC only applies with call of G450, but can be programmed in a previous block without G450. Both commands are modal.

Example

In the following example, a transition radius is programmed for all outside corners (corresponding to the programming of the corner behavior in block N30). This prevents the tool stopping and backing off at the change of direction.



Program code	Comment
N10 G17 T1 G0 X35 Y0 Z0 F500	; Starting conditions.
N20 G1 Z-5	; Feed in tool.
N30 G41 KONT G450 X10 Y10	; Activate TRC with KONT approach/retract mode and corner behavior G450 .
N40 Y60	; Mill the contour.
N50 X50 Y30	
N60 X10 Y10	

Program code	Comment
N80 G40 X-20 Y50	; Deactivate compensation mode, retraction on transition circle.
N90 G0 Y100	
N100 X200 M30	

Further information


G450/G451

At intermediate point P*, the control executes operations such as infeed movements or switching functions. These operations are programmed in blocks inserted between the two blocks forming the corner.

With G450 the transition circle belongs to the next travel command with respect to the data.

DISC


When DISC values greater than 0 are specified, intermediate circles are shown with a magnified height – the result is transition ellipses or parabolas or hyperbolas:



An upper limit can be defined in machine data – generally DISC=50.

Traversing behavior

When G450 is activated and with acute contour angles and high DISC values, the tool is lifted off the contour at the corners. In the case of contour angles equal to or greater than 120°, there is uniform travel around the contour:




When G451 is activated and with acute contour angles, superfluous non-cutting tool paths can result from lift-off movements. A parameter can be used in the machine data to define automatic switchover to transition circle in such cases.

2.10.4 Smooth approach and retraction

2.10.4.1 Approach and retraction (G140 to G143, G147, G148, G247, G248, G347, G348, G340, G341, DISR, DISCL, DISRP, FAD, PM, PR)

The SAR (Smooth Approach and Retraction) function is used to achieve a tangential approach to the start point of a contour, regardless of the position of the start point.



This function is used preferably in conjunction with the tool radius compensation.

When the function is activated, the control calculates the intermediate points in such a way that the transition to the following block (or the transition from previous block during retraction) is performed in accordance with the specified parameters.

The approach movement consists of a maximum of four sub-movements. The starting point of the movement is called P_0 , the end point P_4 in the following. Up to three intermediate points P_1 , P_2 and P_3 can be between these points. Points P_0 , P_3 and P_4 are always defined. Intermediate points P_1 and P_2 can be omitted, according to the parameters defined and the geometrical conditions. On retraction, the points are traversed in the reverse direction, i.e. starting at P_4 and ending at P_0 .

Syntax

Smooth approach:

- With a straight line:

```
G147 G340/G341 ... DISR=..., DISCL=..., DISRP=... FAD=...
```

- With a quadrant/semicircle:

```
G247/G347 G340/G341 G140/G141/G142/G143 ... DISR=... DISCL=...
DISRP=... FAD=...
```

Smooth retraction:

- With a straight line:

```
G148 G340/G341 ... DISR=..., DISCL=..., DISRP=... FAD=...
```

- With a quadrant/semicircle:

```
G248/G348 G340/G341 G140/G141/G142/G143 ... DISR=... DISCL=...
DISRP=... FAD=...
```


Meaning

G147:	Approach with a straight line
G148:	Retraction with a straight line
G247:	Approach with a quadrant
G248:	Retraction with a quadrant
G347:	Approach with a semicircle
G348:	Retraction with a semicircle
G340:	Approach and retraction in space (default setting)
G341:	Approach and retraction in the plane
G140:	Approach and retraction direction dependent on the current compensation side (default setting)
G141:	Approach from the left or retraction to the left
G142:	Approach from the right or retraction to the right
G143:	Approach and retraction direction dependent on the relative position of the start or end point to the tangent direction

2.10 Tool radius compensation

DISR= . . . :	<ol style="list-style-type: none"> For approach and retraction with straight lines (G147/G148): Distance of the cutter edge from the starting point of the contour For approach and retraction with circles (G247, G347/G248, G348): Radius of the tool center point path <p>Notice: For REPOS with a semicircle, DISR is the circle diameter</p>
DISCL= . . . :	Distance of the end point for the fast infeed motion from the machining plane DISCL=AC(...) Specification of the absolute position of the end point for the fast infeed motion
DISCL=AC (. . .) :	Specification of the absolute position of the end point for the fast infeed motion
DISRP:	Distance of point P1 (retraction plane) from the machining plane
DISRP=AC (. . .) :	Specification of the absolute position of point P1
FAD= . . . :	Speed of the slow feed movement The programmed value acts in accordance with the active feedrate type (G group 15).
FAD=PM (. . .) :	The programmed value is interpreted as linear feedrate (like G94) irrespective of the active feedrate type.
FAD=PR (. . .) :	The programmed value is interpreted as revolutionary feedrate (like G95) irrespective of the active feedrate type.

Example



- Smooth approach (block N20 activated)
- Approach with quadrant (G247)
- Approach direction not programmed, G140 applies, i.e. TRC is active (G41)
- Contour offset OFFN=5 (N10)

- Current tool radius=10, and so the effective compensation radius for TRC=15, the radius of the SAR contour =25, with the result that the radius of the tool center path is equal to DISR=10
 - The end point of the circle is obtained from N30, since only the Z position is programmed in N20
 - Infeed movement
 - From Z20 to Z7 (DISCL=AC(7)) with rapid traverse.
 - Then to Z0 with FAD=200.
 - Approach circle in X-Y-plane and following blocks with F1500 (for this velocity to take effect in the following blocks, the active G0 in N30 must be overwritten with G1, otherwise the contour would be machined further with G0).
 - Smooth retraction (block N60 activated)
 - Retraction with quadrant (G248) and helix (G340)
 - FAD not programmed, since irrelevant for G340
 - Z=2 in the starting point; Z=8 in the end point, since DISCL=6
 - When DISR=5, the radius of the SAR contour=20, the radius of the tool center point path=5
- Retraction movements from Z8 to Z20 and the movement parallel to the X-Y plane to X70 Y0.

Program code	Comment
\$TC_DP1[1,1]=120	;Tool definition T1/D1
\$TC_DP6[1,1]=10	; Radius
N10 G0 X0 Y0 Z20 G64 D1 T1 OFFN=5	; (P0 app)
N20 G41 G247 G341 Z0 DISCL=AC(7) DISR=10 F1500 FAD=200	; Approach (P3 app)
N30 G1 X30 Y-10	; (P4 app)
N40 X40 Z2	
N50 X50	; (P4 ret)
N60 G248 G340 X70 Y0 Z20 DISCL=6 DISR=5 G40 F10000	; Retraction (P3 ret)
N70 X80 Y0	; (P0 ret)
N80 M30	

Further information

Selecting the approach and retraction contour

The approach and retraction contour are selected with the appropriate G command from the 2nd G group:

G147:	Approach with a straight line
G247:	Approach with a quadrant
G347:	Approach with a semicircle
G148:	Retraction with a straight line
G248:	Retraction with a quadrant
G348:	Retraction with a semicircle




Figure 2-23 Approach movements with simultaneous activation of the tool radius compensation

Selecting the approach and retraction direction

Use the tool radius compensation (G140, default setting) to determine the approach and retraction direction with positive tool radius:


- G41 active → approach from left
- G42 active → approach from right

G141, G142 and G143 provide further approach options.

The G codes are only significant when the approach contour is a quadrant or a semicircle.

Motion steps between start point and end point (G340 and G341).

In all cases, the movements are made up of one or more straight lines and, depending on the G command for determining the approach contour, an additional straight line or a quadrant or semicircle. The two variants of the path segmentation are shown in the following figure:



G340:	<p>Approach with a straight line from point P_0 to point P_1. This straight line is parallel to the machining plane, if parameter DISRP has not been programmed.</p> <p>Infeed perpendicular to the machining plane from point P_1 to point P_3 to the safety clearance to the machining plane defined by the DISCL parameter.</p> <p>Approach end point P_4 with the curve determined by the G command of the second group (straight line, circle, helix). If G247 or G347 is active (quadrant or semicircle) and start point P_3 is outside the machining plane defined by the end point P_4, a helix is inserted instead of a circle. Point P_2 is not defined or coincides with P_3.</p> <p>The circle plane or the helix axis is determined by the plane, which is active in the SAR block (G17/G18/G19), i.e. the projection of the start tangent is used by the following block, instead of the tangent itself, to define the circle.</p> <p>The movement from point P_0 to point P_3 takes place along two straight lines at the velocity valid before the SAR block.</p>
G341:	<p>Approach with a straight line from point P_0 to point P_1. This straight line is parallel to the machining plane, if parameter DISRP has not been programmed.</p> <p>Infeed perpendicular to the machining plane from point P_1 up to the safety clearance to the machining plane defined by the DISCL parameter in point P_2.</p> <p>Infeed perpendicular to the machining plane from point P_2 to point P_3. Approach end point with the curve determined by the G command of the second group. P_3 and P_4 are located within the machining plane, with the result that a circle is always inserted instead of a helix with G247 or G347.</p>

In all cases that include the position of the active plane G17/G18/G19 (circular plane, helical axis, infeed motion perpendicular to the active plane), any active rotating frame is taken into account.

Length of the approach straight line or radius for approach circles (DISR)

- Approach/retract with straight lines

DISR specifies the distance of the cutter edge from the starting point of the contour, i.e. the length of the straight line when TRC is active is the sum of the tool radius and the programmed value of DISR. The tool radius is only taken into account when it is positive. The resulting straight line length must be positive, i.e. negative values for DISR are allowed provided that the absolute value of DISR is less than the tool radius.

- Approach/retract with circles

DISR specifies the radius of the tool center point path. If TRC is activated, a circle is produced with a radius that results in the tool center point path with the programmed radius.

Distance of point P2 from the machining plane (DISCL)

If the position of point P₂ is to be specified by an absolute reference on the axis perpendicular to the circle plane, the value must be programmed in the form `DISCL=AC(. . .)`.

The following applies for `DISCL=0`:

- With G340: The whole of the approach motion now only consists of two blocks (P₁, P₂ and P₃ are combined). The approach contour is formed by P₁ to P₄.
- With G341: The whole approach contour consists of three blocks (P₂ and P₃ are combined). If P₀ and P₄ are on the same plane, only two blocks result (infeed movement from P₁ to P₃ is omitted).
- The point defined by DISCL is monitored to ensure that it is located between P₁ and P₃, i.e. the sign must be identical for the component perpendicular to the machining plane in all motions that possess such a component.
- On detection of a reversal of direction, a tolerance defined by the machine data MD20204 `$MC_SAR_CLEARANCE_TOLERANCE` is permitted.

Distance of point P1 (retraction plane) from the machining plane (DISRP)

If the position of point P₁ is to be specified by an absolute reference on the axis perpendicular to the machining plane, the value must be programmed in the form `DISRP=AC(. . .)`.

If this parameter is not programmed, point P₁ has the same distance to the machining plane as point P₀, i.e. the approach straight line P₀ → P₁ is parallel to the machining plane.

The system checks that the point defined by DISRP lies between P₀ and P₂, i.e. in all movements that have a component perpendicular to the machining plane (e.g. infeed movements, approach movements from P₃ to P₄), this component must have the same leading sign. It is not permitted to change direction. An alarm is output if this condition is violated.

On detection of a reversal of direction, a tolerance defined by the machine data MD20204 `$MC_SAR_CLEARANCE_TOLERANCE` is permitted. However, if P₁ is outside the range defined by P₀ and P₂, but the deviation is less than or equal to this tolerance, it is assumed that P₁ is in the plane defined by P₀ or P₂.

Programming of the end point

The end point is generally programmed with X... Y... Z...

The programming of the contour end point when approaching differs greatly from that for retraction. Both cases are therefore treated separately here.

Programming of end point P4 for approach

End point P₄ can be programmed in the actual SAR block. Alternatively, P₄ can be determined by the end point of the next traversing block. More blocks can be inserted between an SAR block and the next traversing block without moving the geometry axes.

Example:

Program code	Comment
\$TC_DP1[1,1]=120	;Milling tool T1/D1
\$TC_DP6[1,1]=7	;Tool with 7 mm radius
N10 G90 G0 X0 Y0 Z30 D1 T1	
N20 X10	
N30 G41 G147 DISCL=3 DISR=13 Z=0 F1000	
N40 G1 X40 Y-10	
N50 G1 X50	
...	


N30/N40 can be replaced by:

```
N30 G41 G147 DISCL=3 DISR=13 X40 Y-10 Z0 F1000
```

or

```
N30 G41 G147 DISCL=3 DISR=13 F1000
```

```
N40 G1 X40 Y-10 Z0
```



Programming of end point P0 for retraction


For retraction, the end point of the SAR contour cannot be programmed in a following block, i.e. the end position is always taken from the SAR block, irrespective of how many axes have been

programmed. When determining the end point, a distinction is made between the following three cases:

1. No geometry axis is programmed in the SAR block. In this case, the contour ends at point P_1 (if DISRP has been programmed), at point P_2 (if DISCL, but not DISRP has been programmed) or point P_3 (if neither DISCL nor DISRP has been programmed). The position in the axes, which describe the machining plane, is determined by the retraction contour (end point of the straight line or arc). The axis component perpendicular to this is defined by DISCL or DISPR. If in this case both DISCL=0 and DISRP=0, the motion is completely in the plane, i.e. points P_0 to P_3 coincide.
2. Only the axis perpendicular to the machining plane is programmed in the SAR block. In this case, the contour ends at point P_0 . If DISRP has been programmed (i.e. points P_0 and P_1 do not coincide), the straight line $P_1 \rightarrow P_0$ is perpendicular to the machining plane. The positions of the two other axes are determined in the same way as in 1.
3. At least one axis of the machining plane is programmed. The second axis of the machining plane can be determined modally from its last position in the preceding block.

The position of the axis perpendicular to the machining plane is generated as described in 1. or 2., depending on whether this axis is programmed or not. The position generated in this way defines the end point P_0 . If the SAR retraction block is also used to deactivate the tool radius compensation, in the first two cases, an additional path component is inserted in the machining plane from P_1 to P_0 so that no movement is produced when the tool radius compensation is deactivated at the end of the retraction contour, i.e. this point defines the tool center point and not a position on a contour to be corrected. In case 3, no special measures are required for deselection of the tool radius compensation, because the programmed point P_0 already directly defines the position of the tool center point at the end of the complete contour.

The behavior in cases 1 and 2, i.e. when an end point is not explicitly programmed in the machining plane with simultaneous deselection of the tool radius compensation, is shown in the following figure:




Approach and retraction velocities

- Velocity of the previous block (G0)
All motions from P_0 up to P_2 are executed at this velocity, i.e. the motion parallel to the machining plane and the part of the infeed motion up to the safety clearance.
- Programming with FAD
Specification of the feedrate for
 - G341: Infeed movement perpendicular to the machining plane from P_2 to P_3
 - G340: From point P_2 or P_3 to P_4 .
If FAD is not programmed, this part of the contour is traversed at the speed which is active modally from the preceding block, in the event that no F command defining the speed is programmed in the SAR block.
- Programmed feedrate F
This feedrate value is effective as of P_3 or P_2 if FAD is not programmed. If no F word is programmed in the SAR block, the speed of the previous block is active.




Example:

Program code	Comment
\$TC_DP1[1,1]=120	;Milling tool T1/D1
\$TC_DP6[1,1]=7	;Tool with 7 mm radius
N10 G90 G0 X0 Y0 Z20 D1 T1	
N20 G41 G341 G247 DISCL=AC(5) DISR=13 FAD 500 X40 Y-10 Z=0 F200	
N30 X50	
N40 X60	
...	



During retraction, the roles of the modally active feedrate from the previous block and the programmed feedrate value in the SAR block are reversed, i.e. the actual retraction contour is traversed with the old feedrate and a new speed programmed with the F word applies from P_2 up to P_0 .

2.10 Tool radius compensation



Reading positions

Points P_3 and P_4 can be read in the WCS as a system variable during approach.

- \$P_APR: reading P
- P_3 (initial point)
- \$P_AEP: reading P
- P_4 (contour starting point)
- \$P_APDV: read whether \$P_APR and \$P_AEP contain valid data

2.10.4.2 Approach and retraction with extended retraction strategies (G460, G461, G462)

In certain special geometrical situations, special extended approach and retraction strategies, compared with the previous implementation with activated collision detection for the approach and retraction block, are required in order to activate or deactivate tool radius compensation. A collision detection can result, for example, in a section of the contour not being completely machined, see following figure:




Figure 2-24 Retraction behavior with G460

Syntax

G460

G461

G462

Meaning

G460:	As previously (activation of the collision detection for the approach and retraction block).
G461:	Insertion of a circle in the TRC block, if it is not possible to have an intersection whose center point is in the end point of the uncorrected block, and whose radius is the same as the tool radius. Up to the intersection, machining is performed with an auxiliary circle around the contour end point (i.e. up to the end of the contour).
G462:	Insertion of a circle in the TRC block, if it is not possible to have an intersection; the block is extended by its end tangent (default setting). Machining is performed up to the extension of the last contour element (i.e. until shortly before the end of the contour).

Note

The approach behavior is symmetrical to the retraction behavior.

The approach/retraction behavior is determined by the state of the G command in the approach/retraction block. The approach behavior can therefore be set independently of the retraction behavior.

Examples

Example 1: Retraction behavior with G460

The following example describes only the situation for deactivation of tool radius compensation: The behavior for approach is exactly the same.

Program code	Comment
G42 D1 T1	; Tool radius 20 mm
...	
G1 X110 Y0	
N10 X0	
N20 Y10	
N30 G40 X50 Y50	

Example 2: Approach with G461

Program code	Comment
N10 \$TC_DP1[1,1]=120	; Milling tool type
N20 \$TC_DP6[1,1]=10	; Tool radius
N30 X0 Y0 F10000 T1 D1	
N40 Y20	
N50 G42 X50 Y5 G461	
N60 Y0 F600	
N70 X30	
N80 X20 Y-5	
N90 X0 Y0 G40	
N100 M30	

Further information

G461

If no intersection is possible between the last TRC block and a preceding block, the offset curve of this block is extended with a circle whose center point lies at the end point of the uncorrected block and whose radius is equal to the tool radius.

The control attempts to cut this circle with one of the preceding blocks.




Figure 2-25 Retraction behavior with G461

Collision monitoring CDON, CDOF

If CDOF is active (see section Collision monitoring, CDON, CDOF), the search is aborted when an intersection is found, i.e., the system does not check whether further intersections with previous blocks exist.

If CDON is active, the search continues for further intersections after the first intersection is found.

An intersection point, which is found in this way, is the new end point of a preceding block and the start point of the deactivation block. The inserted circle is used exclusively to calculate the intersection and does not produce a traversing movement.


Note

If no intersection is found, alarm 10751 (collision danger) is output.

G462

If no intersection is possible between the last TRC block and a preceding block, a straight line is inserted, on retraction with G462 (initial setting), at the end point of the last block with tool radius compensation (the block is extended by its end tangent).

The search for the intersection is then identical to the procedure for G461.



Retraction behavior with G462 (see example)

With G462, the corner generated by N10 and N20 in the example program is not machined to the full extent actually possible with the tool used. However, this behavior may be necessary if the part contour (as distinct from the programmed contour), to the left of N20 in the example, is not permitted to be violated even with y values greater than 10 mm.

Corner behavior with KONT

If KONT is active (travel round contour at start or end point), the behavior differs according to whether the end point is in front of or behind the contour.

- **End point in front of contour**

If the end point is in front of the contour, the retraction behavior is the same as with NORM. This property does not change even if the last contour block for G451 is extended with a straight line or a circle. Additional circumnavigation strategies to avoid a contour violation in the vicinity of the contour end point are therefore not required.

- **End point behind contour**

If the end point is behind the contour, a circle or straight line is always inserted depending on G450/G451. In this case, G460-462 has no effect. If the last traversing block in this situation has no intersection with a preceding block, an intersection with the inserted contour element or with the straight line of the end point of the bypass circle to the programmed endpoint can result.

If the inserted contour element is a circle (G450), and this forms an interface with the preceding block, this is equal to the interface that would occur with NORM and G461. In general, however, a remaining section of the circle still has to be traversed. For the linear part of the retraction block, no further calculation of intersection is required.

In the second case, if no interface of the inserted contour element with the preceding blocks is found, the intersection between the retraction straight line and a preceding block is traversed.

Therefore, a behavior that deviates from G460 can only occur with active G461 or G462 either if NORM is active or the behavior with KONT is geometrically identical to that with NORM.

2.10.5 Activation/deactivation of collision detection ("bottleneck detection") (CDON, CDOF, CDOF2)

The collision detection ("bottleneck detection") with active TRC is activated or deactivated in the NC program with the commands of G group 23.

Syntax

```
G41/G42 CDON  
...  
CDOF/CDOF2
```


2.10.6 2 1/2 D tool offset (CUT2D, CUT2DD, CUT2DF, CUT2DFD)

The 2½ D tool radius compensation should be used if, when machining inclined surfaces, the **workpiece** is to be rotated, and not the tool alignment. This function is activated using commands CUT2D, CUT2DD, CUT2DF oder CUT2DFD.

Tool length offset

The tool length compensation is always taken into account referred to the machining plane that is not rotated and is fixed in space.

2½ D tool radius compensation for contour tools

2½ D tool radius compensation for contour tools is activated, if, together with CUT2D, CUT2DD, CUT2DF or CUT2DFD, one of the two commands G41 (tool radius compensation left of the contour) or G42 (tool radius compensation right of the contour) is programmed. It is used for automatic cutting-edge selection in the case of non-axially symmetrical tools that can be used for piece-by-piece machining of individual contour segments.

Note

If 2½ D tool radius compensation is not activated, a contour tool behaves like a standard tool, which only has the first cutting edge.

2½ tool radius compensation referred to a differential tool

2½ D tool radius compensation, referred to a differential tool, is activated using the CUT2DD or CUT2DFD commands. It should be applied if the programmed contour refers to the center point path of a differential tool, and a tool other than a differential tool is used for machining. When calculating the 2½ D tool radius compensation, only the wear of the radius of the active tool (\$TC_DP_15) and the possibly programmed tool offset OFFN (Page 246) and TOFFR (Page 85) are taken into account. The basic radius (\$TC_DP6) of the active tool is **not** taken into account.

Syntax

CUT2D
 CUT2DD
 CUT2DF
 CUT2DFD

Meaning

CUT2D:	Activating the 2½ D radius compensation
CUT2DD:	Activating the 2½ D radius compensation referred to a differential tool
CUT2DF:	Activating 2½ D radius compensation, tool radius compensation relative to the current frame and/or inclined plane
CUT2DFD:	Activating 2½ D radius compensation, tool radius compensation relative to the current frame and/or inclined plane


Further information

Contour tools

- Enabling
Tool radius compensation for contour tools is enabled on a channel-specific basis using:
MD28290 \$MC_MM_SHAPED_TOOLS_ENABLE
- Tool type
Contour tool types are defined on a channel-specific basis using:
MD20370 \$MC_SHAPED_TOOL_TYPE_NO
- Cutting edge
A number of cutting edges (D numbers) can be assigned to each contour tool in any sequence. The maximum number of cutting edges per tool is parameterized using:
MD18106 \$MN_MM_MAX_CUTTING_EDGE_PERTOOL
The first cutting edge of a contour tool is the cutting edge, which is selected when activating the tool. If, e.g. in a program, using the commands T3 D5, the fifth cutting edge (D5) of the third tool (T3) is activated, then D5 and the following cutting edges define with one part, or altogether, the contour tool. The cutting edges located before D5 are ignored.

2½ D tool radius compensation without rotating the correction plane (CUT2D, CUT2DD)

If a frame that contains a rotation is programmed, then for CUT2D or CUT2DD, the plane in which the tool radius compensation (correction plane) takes place **is not rotated at the same time**. The tool radius compensation is taken into account, referred to the **non rotated** machining plane (G17, G18, G19). The tool length compensation acts relative to the correction plane.




For machining inclined surfaces, the tool offsets must be appropriately defined or calculated based on the functions for "Tool length compensation for tools that can be orientated".

2½ D tool radius compensation with rotation of the compensation plane (CUT2DF, CUT2DFD)

If a frame is programmed that contains a rotation, then for CUT2DF or CUT2DFD, the plane in which the tool radius compensation takes place (correction plane) **is also rotated**. The tool radius compensation is taken into account, referred to the **rotated** machining plane (G17, G18, G19). However, the tool length compensation still acts relative to the **non-rotated** machining plane.

Requirement: At the machine, the tool orientation must be able to be adjusted perpendicular to the rotated machining plane, and set for machining.



Note

The tool length compensation continues to be active relative to the non-rotated working plane.

For further information see the "Tools" Function Manual.

2.10.7 Keep tool radius compensation constant (CUTCONON, CUTCONOF)

The "Keep tool radius compensation constant" function is used to suppress tool radius compensation for a number of blocks, whereby a difference between the programmed and the actual tool center path traveled set up by tool radius compensation in the previous blocks is retained as the compensation. It can be an advantage to use this method when several traversing blocks are required during line milling in the reversal points, but the contours produced by the tool radius compensation (follow strategies) are not wanted. It can be used independently of the type of tool radius compensation (2¹/₂D, 3D face milling, 3D circumferential milling).

Syntax


CUTCONON

CUTCONOF

Meaning

CUTCONON:	Command to activate the "Keep tool radius compensation constant" function
CUTCONOF:	Command to deactivate the "Keep tool radius compensation constant" function

Example



Program code	Comment
N10	; Definition of tool d1.
N20 \$TC_DP1[1,1] = 110	; Type
N30 \$TC_DP6[1,1]= 10.	; Radius
N40	
N50 X0 Y0 Z0 G1 G17 T1 D1 F10000	
N60	
N70 X20 G42 NORM	
N80 X30	
N90 Y20	
N100 X10 CUTCONON	; Activation of the compensation suppression.
N110 Y30 KONT	; If required, insert bypass circle when deactivating the compensation suppression.
N120 X-10 CUTCONOF	
N130 Y20 NORM	; No bypass circle when deactivating the TRC.

2.10 Tool radius compensation

Program code	Comment
N140 X0 Y0 G40	
N150 M30	

Further information

Tool radius compensation is normally active before the compensation suppression and is still active when the compensation suppression is deactivated again. In the last traversing block before `CUTCONON`, the offset point in the block end point is approached. All following blocks in which offset suppression is active are traversed without offset. However, they are offset by the vector from the end point of the last offset block to its offset point. These blocks can have any type of interpolation (linear, circular, polynomial).

The deactivation block of the compensation suppression, i.e. the block that contains `CUTCONOF`, is compensated normally. It starts in the offset point of the starting point. One linear block is inserted between the end point of the previous block, i.e. the last programmed traversing block with active `CUTCONON`, and this point.

Circular blocks, for which the circle plane is perpendicular to the compensation plane (vertical circles), are treated as though they had `CUTCONON` programmed. This implicit activation of the offset suppression is automatically canceled in the first traversing block that contains a traversing motion in the offset plane and is not such a circle. Vertical circle in this sense can only occur during circumferential milling.

2.10.8 Tools with a relevant cutting edge position

In the case of tools with a relevant tool point direction (turning and grinding tools - tool types 400-599; see Section "Sign evaluation wear"), a change from G40 to G41/G42 or vice-versa is treated as a tool change. If a transformation is active (e.g., `TRANSMIT`), this leads to a preprocessing stop (decoding stop) and hence possibly to deviations from the intended part contour.

This original functionality changes with regard to:


1. Preprocessing stop on `TRANSMIT`
2. Calculation of intersection points at approach and retraction with `KONT`
3. Tool change with active tool radius compensation
4. Tool radius compensation with variable tool orientation at transformation

Further information

The original functionality has been modified as follows:

- A change from G40 to G41/G42 and vice-versa is no longer treated as a tool change. Therefore, a preprocessing stop no longer occurs with TRANSMIT.
- The straight line between the tool edge center points at the block start and block end is used to calculate intersection points with the approach and retraction block. The difference between the tool edge reference point and the tool edge center point is superimposed on this movement.

On approach and retraction with KONT (tool circumnavigates the contour point, see above subsection "Contour approach and retraction"), superimposition takes place in the linear part block of the approach or retraction motion. The geometric conditions are therefore identical for tools with and without a relevant tool point direction. Deviations from the previous behavior occur only in relatively rare cases where the approach or retraction block does not intersect with an adjacent traversing block, see the following figure:



- In circle blocks and in motion blocks containing rational polynomials with a denominator degree > 4 , it is not permitted to change a tool with active tool radius compensation in cases where the distance between the tool edge center point and the tool edge reference point changes. With other types of interpolation, it is now possible to change when a transformation is active (e.g., TRANSMIT).
- For tool radius compensation with variable tool orientation, the transformation from the tool edge reference point to the tool edge center point can no longer be performed by means of a simple zero offset. Tools with a relevant tool point direction are therefore not permitted for 3D peripheral milling (an alarm is output).

Note

The subject is irrelevant with respect to face milling as only defined tool types without relevant tool point direction are permitted for this operation anyway. (A tool with a type, which has not been explicitly approved, is treated as a ball end mill with the specified radius. A tool point direction parameter is ignored).

2.11 Path action

2.11.1 Exact stop (G60, G9, G601, G602, G603)

In exact stop traversing mode, all path axes and special axes involved in the traversing motion that are not traversed modally, are decelerated at the end of each block until they come to a standstill.

Exact stop is used when sharp outside corners have to be machined or inside corners finished to exact dimensions.

The exact stop specifies how exactly the corner point has to be approached and when the transition is made to the next block:

- "Exact stop fine"
The block change is performed as soon as the axis-specific tolerance limits for "Exact stop fine" are reached for all axes involved in the traversing motion.
"Exact stop fine" is set via: MD36010 \$MA_STOP_LIMIT_FINE[<Axis>]
- "Exact stop coarse"
The block change is performed as soon as the axis-specific tolerance limits for "Exact stop coarse" are reached for all axes involved in the traversing motion.
"Exact stop coarse" is set via: MD36000 \$MA_STOP_LIMIT_COARSE[<Axis>]
- "Interpolator end"
The block change is performed as soon as the control has calculated a set velocity of zero for all axes involved in the traversing motion. The actual position or the following error of the axes involved are not taken into account

Syntax

```
G60 ...
G9 ...
G601/G602/G603, etc.
```

Meaning

G60:	Command for activation of the modal exact stop
G9:	Command for activation of the non-modal exact stop
G601:	Command for activation of the exact stop criterion " Exact stop fine "
G602:	Command for activation of the exact stop criterion " Exact stop coarse "
G603:	Command for activation of the exact stop criterion " Interpolator end "

Note

The commands for activating the exact stop criteria (G601/G602/G603) are only effective if G60 or G9 is active.

Example

Program code	Comment
N5 G602	; Criterion "Exact stop coarse" selected.
N10 G0 G60 Z...	; Exact stop modal active.
N20 X... Z...	; G60 continues to act.
...	
N50 G1 G601	; Criterion "Exact stop fine" selected.
N80 G64 Z...	; Switchover to continuous-path mode.
...	
N100 G0 G9	; Exact stop acts only in this block.
N110 ...	; Continuous-path mode active again.


Further information

G60, G9

G9 generates the exact stop in the current block, G60 in the current block and in all following blocks.

Continuous-path-mode commands G64 or G641 - G645 are used to deactivate G60.

G601, G602



The movement is decelerated and stopped briefly at the corner point.


Note

Do not set the limits for the exact stop criteria any tighter than necessary. The tighter the limits, the longer it takes to position and approach the target position.

G603

The block change is initiated when the control has calculated a set velocity of zero for the axes involved. At this point, the actual value lags behind by a proportionate factor depending on the

dynamic response of the axes and the path velocity. The workpiece corners can now be rounded.



Configured exact stop criterion

For G0 and the other commands of the 1st G group, for specific channels it can be set that contrary to the programmed exact stop criterion a preset criterion should be used automatically (see machine manufacturer's specifications).

References

Function Manual, Basic Functions, Continuouspath Mode, Exact Stop, Look Ahead (B1)

2.11.2 Continuous-path mode (G64, G641, G642, G643, G644, G645, ADIS, ADISPOS)

In continuous-path mode, the path velocity at the end of the block (for the block change) is not decelerated to a level which would permit the fulfillment of an exact stop criterion. The objective of this mode is, in fact, to avoid rapid deceleration of the path axes at the block-change point so that the axis velocity remains as constant as possible when the program moves to the next block. To achieve this objective, the "Look-head" function is also activated when continuous-path mode is selected.

Continuous-path mode with smoothing facilitates the tangential shaping and/or smoothing of angular block transitions caused by local changes in the programmed contour.

Continuous path mode:

- Rounds the contour
- Reduces machining times by eliminating braking and acceleration processes that are required to fulfill the exact-stop criterion
- Improves cutting conditions because of the more constant velocity

Continuous-path mode is suitable if:

- A contour needs to be traversed as quickly as possible (e.g. with rapid traverse)
- The exact contour may deviate from the programmed contour within a specific tolerance for the purpose of obtaining a continuous contour

Continuous-path mode is not suitable if:

- A contour needs to be traversed precisely
- An absolutely constant velocity is required

Note

Continuous-path mode is interrupted by blocks which trigger a preprocessing stop implicitly, e.g. due to:

- Access to specific machine status data (\$A...)
 - Auxiliary function outputs
-

Syntax

```
G64 ...
G641 ADIS=...
G641 ADISPOS=...
G642 ...
G643 ...
G644 ...
G645 ...
```

Meaning

G64:	Continuous-path mode with reduced velocity as per the overload factor
G641:	Continuous-path mode with smoothing as per distance criterion
ADIS=... :	Distance criterion with G641 for path functions G1, G2, G3, etc.
ADISPOS=... :	Distance criterion with G641 for rapid traverse G0
	<p>The distance criterion (= rounding clearance) ADIS or ADISPOS describes the maximum distance the rounding block may cover before the end of the block, or the distance after the end of block within which the rounding block must be terminated respectively.</p> <p>Note: If ADIS/ADISPOS is not programmed, a value of "zero" applies and the traversing behavior therefore corresponds to G64. The rounding clearance is automatically reduced (by up to 36%) for short traversing distances.</p>

G642:	<p>Continuous-path mode with smoothing within the defined tolerances</p> <p>In this mode, under normal circumstances smoothing takes place within the maximum permissible path deviation. However, instead of these axis-specific tolerances, observation of the maximum contour deviation (contour tolerance) or the maximum angular deviation of the tool orientation (orientation tolerance) can be configured.</p> <p>Note: Expansion to include contour and orientation tolerance is only supported on systems featuring the "Polynomial interpolation" option.</p>
G643:	<p>Continuous-path mode with smoothing within the defined tolerances (block-internal)</p> <p>G643 differs from G642 in that is not used to generate a separate rounding block; instead, axis-specific block-internal rounding movements are inserted. The rounding clearance can be different for each axis.</p>
G644:	<p>Continuous-path mode with smoothing with maximum possible dynamic response</p> <p>Note: G644 is not available with an active kinematic transformation. The system switches internally to G642.</p>
G645:	<p>Continuous-path mode with smoothing and tangential block transitions within the defined tolerances</p> <p>G645 has the same effect on corners as G642. With G645, rounding blocks are also only generated on tangential block transitions if the curvature of the original contour exhibits a jump in at least one axis.</p>


Note

Rounding cannot be used as a substitute for smoothing (RND). The user should not make any assumptions with respect to the appearance of the contour within the rounding area. The type of rounding can depend on dynamic conditions, e.g. on the tool path velocity. Rounding on the contour is therefore only practical with small ADIS values. RND must be used if a defined contour is to be traversed at the corner.

Note

If a rounding movement initiated by G641, G642, G643, G644 or G645 is interrupted, the starting or end point of the original traversing block (as appropriate for REPOS mode) will be used for subsequent repositioning (REPOS), rather than the interruption point.

Example




The two outside corners on the groove are to be approached exactly. Otherwise machining should be performed in continuous-path mode.

Program code	Comment
N05DIAMOF	; Radius as dimension
N10 G17 T1 G41 G0 X10 Y10 Z2 S300 M3	; Approach starting position, activate spindle, path compensation.
N20 G1 Z-7 F8000	; Feed in tool.
N30 G641 ADIS=0.5	; Contour transitions are smoothed.
N40 Y40	
N50 X60 Y70 G60 G601	; Approach position exactly with exact stop fine.
N60 Y50	
N70 X80	
N80 Y70	
N90 G641 ADIS=0.5 X100 Y40	; Contour transitions are smoothed.
N100 X80 Y10	
N110 X10	
N120 G40 G0 X-20	; Deactivate path compensation
N130 Z10 M30	; Retract tool, end of program.

Further information

Continuous-path mode G64

In continuous-path mode, the tool travels across tangential contour transitions with as constant a path velocity as possible (no deceleration at block boundaries). LookAhead deceleration is applied before corners and blocks with exact stop.



Corners are also traversed at a constant velocity. In order to minimize the contour error, the velocity is reduced according to an acceleration limit and an overload factor.

Note

The extent of smoothing the contour transitions depends on the feedrate and the overload factor. The overload factor can be set in MD32310 \$MA_MAX_ACCEL_OVL_FACTOR.

Setting MD20490 \$MC_IGNORE_OVL_FACTOR_FOR_ADIS means that block transitions will always be rounded irrespective of the set overload factor.

The following points should be noted in order to prevent an undesired stop in path motion (relief cutting):

- Auxiliary functions, which are enabled after the end of the motion or before the next motion, interrupt the continuous path mode (exception: fast auxiliary functions).
- Positioning axes always traverse according to the exact stop principle, positioning window fine (as for G601). If an NC block has to wait for positioning axes, continuous-path mode is interrupted on the path axes.

However, intermediate blocks containing only comments, calculation blocks or subprogram calls do not affect continuous-path mode.

Note


If FGROUP does not contain all the path axes, there is often a step change in the velocity at block transitions for those axes excluded from FGROUP; the control limits this change in velocity to the permissible values set in MD32300 \$MA_MAX_AX_ACCEL and MD32310 \$MA_MAX_ACCEL_OVL_FACTOR. This braking operation can be avoided through the application of a rounding function, which "smoothes" the specific positional interrelationship between the path axes.

LookAhead predictive velocity control

In continuous-path mode, the control automatically determines the velocity control for several NC blocks in advance. This enables acceleration and deceleration across multiple blocks with almost tangential transitions.

Look Ahead is particularly suitable for the machining of motion sequences comprising short traverse paths with high path feedrates.

The number of NC blocks included in the Look Ahead calculation can be defined in machine data.



Continuous-path mode with smoothing as per distance criterion (G641)

With G641, the control inserts transition elements at contour transitions. The rounding clearance `ADIS` (or `ADISPOS` for G0) specifies the maximum extent to which the corners can be rounded. Within this rounding clearance, the control is free to ignore the path construct and replace it with a dynamically optimized distance.


Disadvantage: Only one `ADIS` value is available for all axes.

The effect of G641 is similar to `RNDM`; however, it is not restricted to the axes of the working plane.

Like G64, G641 works with LookAhead predictive velocity control. Corner rounding blocks with a high degree of curvature are approached at reduced velocity.

Example:

Program code	Comment
N10 G641 ADIS=0.5 G1 X... Y...	; The rounding block must begin no more than 0.5 mm before the programmed end of the block and must finish 0.5 mm after the end of the block. This setting remains modal.



Note

Smoothing cannot and should not replace the functions for defined smoothing (RND, RNDM, ASPLINE, BSPLINE, CSPLINE).

Smoothing with axial precision with G642

With G642, smoothing does not take place within a defined ADIS range, but the axial tolerances defined with MD33100 \$MA_COMPRESS_POS_TOL are complied with. The rounding clearance is determined based on the shortest rounding clearance of all axes. This value is taken into account when generating a rounding block.

Block-internal smoothing with G643

The maximum deviations from the precise contour in the case of smoothing with G643 are defined for each axis using machine data MD33100 \$MA_COMPRESS_POS_TOL.

G643 is not used to generate a separate rounding block, but axis-specific block-internal rounding motions are inserted. In the case of G643, the rounding clearance of each axis can be different.

Smoothing with contour and orientation tolerance with G642/G643

MD20480 \$MC_SMOOTHING_MODE can be used to configure rounding with G642 and G643 so that instead of the axis-specific tolerances, a contour tolerance and an orientation tolerance can be applied.

The contour tolerance and orientation tolerance are set in the channel-specific setting data:

SD42465 \$SC_SMOOTH_CONTUR_TOL (maximum contour deviation)

SD42466 \$SC_SMOOTH_ORI_TOL (maximum angular deviation of the tool orientation)

The setting data can be programmed in the NC program; this means that it can be specified differently for each block transition. Very different specifications for the contour tolerance and the tolerance of the tool orientation can only take effect with G643.

Note

Expansion to include contour and orientation tolerance is only supported on systems featuring the "Polynomial interpolation" option.

Note

An orientation transformation must be active for smoothing within the orientation tolerance.

Corner rounding with greatest possible dynamic response in G644

Smoothing with maximum possible dynamic response is configured in the thousands place with MD20480 \$MC_SMOOTHING_MODE.

Value	Meaning
0	Specification of maximum axial deviations with: MD33100 \$MA_COMPRESS_POS_TOL
1	Specification of maximum rounding clearance by programming: ADIS=... or ADISPOS=...
2	Specification of the maximum possible frequencies of each axis occurring in the rounding area with: MD32440 \$MA_LOOKAH_FREQUENCY The rounding area is defined such that no frequencies in excess of the specified maximum can occur while the rounding motion is in progress.
3	When rounding with G644, neither the tolerance nor the rounding distance are monitored. Each axis traverses around a corner with the maximum possible dynamic response. With SOFT, both the maximum acceleration and the maximum jerk of each axis is maintained. With the BRISK command, the jerk is not limited; instead, each axis travels at the maximum possible acceleration.

Smoothing of tangential block transitions with G645

With G645, the smoothing motion is defined so that the acceleration of all axes involved remains smooth (no jumps) and the parameterized maximum deviations from the original contour (MD33120 \$MA_PATH_TRANS_POS_TOL) are not exceeded.

In the case of angular non-tangential block transitions, the smoothing behavior is the same as with G642.

No intermediate rounding blocks

An intermediate rounding block is not inserted in the following cases:

- The axis stops between the two blocks.
This occurs when:
 - The following block contains an auxiliary function output before the motion.
 - The following block does not contain a path motion.
 - An axis is traversed for the first time as a path axis for the following block when it was previously a positioning axis.
 - An axis is traversed for the first time as a positioning axis for the following block when it was previously a path axis.
 - The previous block traverses geometry axes and the following block does not.
 - The following block traverses geometry axes and the previous block does not.
 - Before tapping, the following block uses G33 as preparatory function and the previous block does not.
 - A change is made between BRISK and SOFT.
 - Axes involved in the transformation are not completely assigned to the path motion (e.g. for oscillation, positioning axes).
- The rounding block would slow down the part program execution.
This occurs:
 - Between very short blocks.
Since each block requires at least one interpolator clock cycle, the added intermediate block would double the machining time.
 - If a block transition G64 (continuous-path mode without smoothing) can be traversed without a reduction in velocity.
Rounding would increase the machining time. This means that the value of the permitted overload factor (MD32310 \$MA_MAX_ACCEL_OVL_FACTOR) affects whether a block transition is rounded or not. The overload factor is only taken into account for corner rounding with G641/G642. The overload factor has no effect in the case of smoothing with G643 (this behavior can also be set for G641 and G642 by setting MD20490 \$MC_IGNORE_OVL_FACTOR_FOR_ADIS to TRUE).

- Rounding is not parameterized.
This occurs when:
 - For G641 in G0 blocks `ADISPOS = 0` (default!)
 - For G641 in non-G0 blocks `ADIS = 0` (default!)
 - For G641 on transition from G0 and non-G0 or non-G0 and G0 respectively, the smaller value from `ADISPOS` and `ADIS` applies.
 - For G642/G643, all axis-specific tolerances are zero.
- The block does not contain traversing motion (zero block).
This occurs when:
 - Synchronized actions are active.
Normally, the Interpreter eliminates zero blocks. However, if synchronous actions are active, this zero block is included and also executed. In so doing, an exact stop is initiated corresponding to the active programming. This allows the synchronous action to also switch.
 - Zero blocks are generated by program jumps.

Continuous-path mode in rapid traverse G0

One of the specified functions `G60/G9` or `G64`, or `G641 - G645`, also has to be specified for rapid traverse motion. Otherwise, the default in the machine data is used.

References

For further information about the continuous-path mode see:
Function Manual, Basic Functions; Continuous-Path Mode, Exact Stop, LookAhead (B1).

2.12 Coordinate transformations (frames)

2.12.1 Frames

Frame

The frame is a self-contained arithmetic rule that transforms one Cartesian coordinate system into another Cartesian coordinate system.

Basic frame (basic offset)

The basic frame describes coordinate transformation from the basic coordinate system (BCS) to the basic zero system (BZS) and has the same effect as settable frames.

See Basic coordinate system (BCS) (Page 39).

Settable frames


Settable frames are the configurable zero offsets which can be called from within any NC program with the G54 to G57 and G505 to G599 commands. The offset values are predefined by the user and stored in the zero offset memory on the controller. They are used to define the settable zero system (SZS).

See:

- Settable zero system (SZS) (Page 42)
- Settable zero offset (G54 to G57, G505 to G599, G53, G500, SUPA, G153) (Page 146)

Programmable frames

Sometimes it is useful or necessary within an NC program, to move the originally selected workpiece coordinate system (or the "settable zero system") to another position and, if required, to rotate it, mirror it and/or scale it. This can be achieved using programmable frames.




See Frame instructions (Page 302).

2.12.2 Frame instructions


Function

The statements for programmable frames apply in the current NC program. They function as either additive or substitute elements:

- Substitute statement**
 Deletes all previously programmed frame statements. The reference is provided by the last settable zero offset called (G54 to G57, G505 to G599).




- Additive statement**
 Appended to existing frames. The reference is provided by the currently set workpiece zero or the last workpiece zero programmed with a frame statement.



Application example


1. Move the zero point of the workpiece coordinate system (WCS).
2. Rotate the workpiece coordinate system (WCS) to orientate a plane parallel to the desired work plane.



Syntax

Substituting statements	Additive statements
TRANS X... Y... Z...	ATRANS X... Y... Z...
ROT X... Y... Z...	AROT X... Y... Z...
ROT RPL=...	AROT RPL=...
ROTS/CROTS X... Y...	AROTS X... Y...
SCALE X... Y... Z...	ASCALE X... Y... Z...
MIRROR X0/Y0/Z0	AMIRROR X0/Y0/Z0

Meaning



TRANS/ATRANS:	Workpiece coordinate system offset in the direction of the specified geometry axis or axes					
ROT/AROT:	Workpiece coordinate system rotation:					
	<ul style="list-style-type: none"> By linking individual rotations around the specified geometry axis or axes or Around the angle $RPL = \dots$ in the current working plane (G17/G18/G19) 					
	Direction of rotation:					
	Rotation sequence:	<table border="1"> <tr> <td>With RPY notation:</td> <td>Z, Y', X''</td> </tr> <tr> <td>With Euler angle:</td> <td>Z, X', Z''</td> </tr> </table>	With RPY notation:	Z, Y', X''	With Euler angle:	Z, X', Z''
	With RPY notation:	Z, Y', X''				
	With Euler angle:	Z, X', Z''				
Range of values:	The angles of rotation are only defined unambiguously in the following ranges:					
	With RPY notation:	$-180 \leq x \leq 180$				
		$-90 < y < 90$				
		$-180 \leq z \leq 180$				
With Euler angle:	$0 \leq x < 180$					
	$-180 \leq y \leq 180$					
	$-180 \leq z \leq 180$					

ROTS/AROTS:	<p>Workpiece coordinate system rotation by means of the specification of solid angles</p> <p>The orientation of a plane in space is defined unambiguously by specifying two solid angles. Therefore, up to two solid angles may be programmed:</p> <p>ROTS/AROTS X... Y... / Z... X... / Y... Z...</p>
-------------	--

CROTS:	CROTS works in the same way as ROTS but refers to the valid frame in the database.
--------	--

SCALE/ASCALE:	Scaling in the direction of the specified geometry axis or axes to increase/reduce the size of a contour
---------------	--

MIRROR/AMIRROR:	Workpiece coordinate system mirroring by means of mirroring (direction change) the specified geometry axis
Value:	Freely selectable (in this case: "0")

Supplementary conditions

- Frame statements must be programmed in a separate NC block.
- Frame statements can be used individually or combined as required.


- Frame statements are executed in the programmed sequence.
- Additive statements are frequently used in subprograms. The basic statements defined in the main program are not lost after the end of the subprogram if the subprogram has been programmed with the SAVE attribute.

2.12.3 Programmable work offset (TRANS, ATRANS)


The **TRANS** command moves the WCS absolutely based on the SZS created with a settable work offset (G54 ... G57, G505 ... G599).

The **ATRANS** command moves additively the WCS created with **TRANS**.

Milling:



Turning:



Syntax


```
TRANS X... Y... Z...
ATRANS X... Y... Z...
```

Meaning

TRANS:	Absolute offset of the WCS with reference to the workpiece zero (SZS) set with a settable work offset (G54 ... G57, G505 ... G599).	
	Alone in the block:	yes
ATRANS:	Additive zero offset of the WCS with reference to the parameterized workpiece zero set with TRANS	
	Alone in the block:	yes
X... Y... Z... :	Offset values in the direction of the specified geometry axes	

Examples

Example 1: Milling




With this workpiece, the shapes shown recur in a program.

The machining sequence for this shape is stored in a subprogram.

Zero offset is used to set the workpiece zeros required in each case and then call the subprogram.

Program code	Comment
N10 G1 G54	; Working plane X/Y, workpiece zero
N20 G0 X0 Y0 Z2	; Approach starting point
N30 TRANS X10 Y10	; Absolute offset
N40 L10	; Subprogram call
N50 TRANS X50 Y10	; Absolute offset
N60 L10	; Subprogram call
N70 M30	; End of program

Example 2: Turning


Program code	Comment
...	
N10 TRANS X0 Z150	; Absolute offset
N15 L20	; Subprogram call
N20 TRANS X0 Z140 (or ATRANS Z-10)	; Absolute offset
N25 L20	; Subprogram call
N30 TRANS X0 Z130 (or ATRANS Z-10)	; Absolute offset
N35 L20	; Subprogram call
...	

Further information**TRANS X... Y... Z...**

Translation through the offset values programmed in the specified axis directions (path, synchronized axes and positioning axes). The reference is provided by the last settable work offset called (G54 to G57, G505 to G599).

NOTICE**No original frame**

The **TRANS** command resets all frame components of the previously activated programmable frame.




Note

ATRANS can be used to program an offset to be added to existing frames.

ATRANS X... Y... Z...


Translation through the offset values programmed in the specified axis directions. The currently set or last programmed zero point is used as the reference.



2.12.4 Programmable work offset (G58, G59)

The G58 and G59 functions can be used to substitute translation components of the programmable work offset (TRANS/ATRANS) (Page 305) with specific axes:

- G58: Absolute translation component (coarse offset)
- G59: Additive translation component (fine offset)



Requirements

The G58 and G59 functions can only be used if fine offset has been configured (MD24000 \$MC_FRAME_ADD_COMPONENTS = 1).

Syntax

```
G58 <axis_1><value_1> ... <axis_3><value_3>
G59 <axis_1><value_1> ... <axis_3><value_3>
```

Meaning

G58:	G58 replaces the absolute translation component of the programmable work offset for the specified axis, but the programmed additive offset remains valid. The reference is provided by the last settable work offset called (G54 ... G57, G505 ... G599).
	Alone in the block: yes
G59:	G59 replaces the additive translation component of the programmable work offset for the specified axis, but the programmed absolute offset remains valid.
	Alone in the block: yes
<axis_n>:	Geometry axis in channel
<value_n>:	Offset values in the direction of the specified geometry axis

Example

Program code	Comment
...	
N50 TRANS X10 Y10 Z10	; Absolute translation component X10 Y10 Z10
N60 ATRANS X5 Y5	; Additive translation component X5 Y5
	→ total offset: X15 Y15 Z10
N70 G58 X20	; Absolute translation component X20
	→ total offset X25 Y15 Z10
N80 G59 X10 Y10	; Additive translation component X10 Y10
	→ total offset X30 Y20 Z10
...	

Further information

The absolute translation component (**coarse offset**) is modified by the following statements:

- TRANS
- G58
- CTRANS
- CFINE
- \$P_PFRAME[X, TR]

The additive translation component (**fine offset**) is modified by the following statements:


- ATRANS
- G59
- CTRANS
- CFINE
- \$P_PFRAME[X, FI]

Examples

Command	Coarse offset V_C	Fine offset V_F
TRANS X10	$V_C = 10$	unchanged
G58 X10	$V_C = 10$	unchanged
\$P_PFRAME[X, TR]=10	$V_C = 10$	unchanged
ATrans X10	unchanged	$V_F = V_F + 10$
G59 X10	unchanged	$V_F = 10$
\$P_PFRAME[X, FI]=10	unchanged	$V_F = 10$
CTrans (X, 10)	$V_C = 10$	$V_F = 0$
CTrans ()	$V_C = 0$	$V_F = 0$
CFINE (X, 10)	$V_C = 0$	$V_F = 10$

2.12.5 Programmable rotation (ROT, AROT, RPL)

The workpiece coordinate system can be rotated in space with the ROT/AROT statements. The statements refer exclusively to the programmable frame \$P_PFRAME.



Syntax

```
ROT <1st GeoAx><angle> <2nd GeoAx><angle> <3rd GeoAx><angle>
ROT RPL=<angle>
AROT <1st GeoAx><angle> <2nd GeoAx><angle> <3rd GeoAx><angle>
AROT RPL=<angle>
```

Note

Euler angle

The rotations of the workpiece coordinate system are performed via Euler angles. A detailed description can be found in:

References

Function Manual, Basic Functions; Section "Axes, coordinate systems, frames (K2)" > "Frames" > "Frame components" > "Rotation ..."


Meaning

ROT:	Absolute rotation	
	Reference frame:	Programmable frame \$P_PFRAME
	Reference point:	Zero point of the current workpiece coordinate system set with G54 ... G57, G505 ... G599

AROT:	Additive rotation	
	Reference frame:	Programmable frame \$P_PFRAME
	Reference point:	Zero point of the current workpiece coordinate system set with G54 ... G57, G505 ... G599
<nth GeoAx>:	Identifier of the nth geometry axis around which rotation is to be performed with the specified angle. The value 0° is implicitly set as angle of rotation for a geometry axis that has not been programmed.	
RPL:	Rotation around the geometry axis perpendicular to the active plane (G17, G18, G19) by the specified angle	
	Reference frame:	Programmable frame \$P_PFRAME
	Reference point:	Zero point of the current workpiece coordinate system set with G54 ... G57, G505 ... G599
<Angle>	Angle specification in degrees.	
	Range of values:	-360° ≤ angle ≤ 360°

Examples

Example 1: Rotation in the G17 plane




With this workpiece, the shapes shown recur in a program. In addition to the zero offset, rotations have to be performed, as the shapes are not arranged paraxially.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero
N20 TRANS X20 Y10	; Absolute offset
N30 L10	; Subprogram call
N40 TRANS X55 Y35	; Absolute offset
N50 AROT RPL=45	; Additive rotation around the Z axis perpendicular; to the G17 plane through 45°
N60 L10	; Subprogram call

Program code	Comment
N70 TRANS X20 Y40	; Absolute offset (resets all previous offsets)
N80 AROT RPL=60	; Additive rotation around the Z axis perpendicular ; to the G17 plane through 60°
N90 L10	; Subprogram call
N100 G0 X100 Y100	; Retraction
N110 M30	; End of program

Example 2: Spatial rotation around the Y axis




In this example, paraxial and inclined workpiece surfaces are to be machined in a clamping.

Condition:

The tool must be aligned perpendicular to the inclined surface in the rotated Z direction.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero
N20 TRANS X10 Y10	; Absolute offset
N30 L10	; Subprogram call
N40 ATRANS X35	; Additive offset
N50 AROT Y30	; Additive rotation around the Y axis
N60 ATRANS X5	; Additive offset
N70 L10	; Subprogram call
N80 G0 X300 Y100 M30	; Retraction, end of program

Example 3: Multi-face machining



In this example, identical shapes are machined in two workpiece surfaces perpendicular to one another via subprograms. In the new coordinate system on the right-hand workpiece surface, infeed direction, working plane and the zero point have been set up as on the top surface. Therefore, the conditions required for the subprogram execution still apply: Working plane G17, coordinate plane X/Y, infeed direction Z.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero
N20 L10	; Subprogram call
N30 TRANS X100 Z-100	; Absolute offset of the WCS
N40 AROT Y90	; Additive rotation of the WCS around Y through 90°

Program code	Comment
N50 AROT Z90	; Additive rotation of the WCS around Z through 90°
N60 L10	; Subprogram call
N70 G0 X300 Y100 M30	; Retraction, end of program

Further information

Rotation in the active plane

When programming using `RPL=...`, the WCS is rotated around the axis perpendicular to the active plane.




Figure 2-26 Rotation around the Y axis or in the G18 plane

WARNING


Plane change

If a plane change (G17, G18, G19) is programmed after a rotation, the current angles of rotation of the respective axes are retained and are also effective in the new plane. It is therefore strongly recommended that the current angles of rotation be reset to 0 before a plane change:

- N100 ROT X0 Y0 Z0 ; explicit angle programming
- N100 ROT ; implicit angle programming

Absolute rotation with ROT X... Y... Z...

The WCS is rotated around the specified axes to the programmed angles of rotation.




① Angle of rotation

Figure 2-27 Absolute rotation around the Z axis

Additive rotation with AROT X... Y... Z...

The WCS is rotated further around the specified axes through the programmed angles of rotation.



① Angle of rotation

Figure 2-28 Absolute and additive rotation around the Z axis

Rotation of the working plane

During a rotation using ROT/AROT, the working plane (G17, G18, G19) also rotates.


Example: Working plane G17

The WCS is positioned on the top surface of the workpiece. Using offset and rotation, the coordinate system is moved to one of the side faces. Working plane G17 also rotates. In this way, traversing motions can still be programmed in the G17 plane via X and Y and infeeds via Z.

Requirement:

The tool must be perpendicular to the working plane and the positive direction of the infeed axis points in the direction of the tool base.

Specifying `CUT2DF` activates the tool radius compensation in the rotated plane.



2.12.6 Programmable frame rotations with solid angles (ROTS, AROTS, CROTS)

Rotations of the workpiece coordinate system can be specified in solid angles with the `ROTS`, `AROTS` and `CROTS` statements. Solid angles are the angles formed by the intersections of the plane rotated in space with the main planes of the not yet rotated WCS.


Note**Geometry axis identifiers**

The following definition is made as an example for the further description:

- 1st geometry axis: X
- 2nd geometry axis: Y
- 3rd geometry axis: Z

As shown in the following figure, the programming of `ROTS X α Y β` results in an alignment of the G17 plane of the WCS parallel to the displayed inclined plane. The position of the zero point of the WCS remains unchanged.

The orientation of the rotated WCS is defined so that the first rotated axis lies in the plane formed by this and the 3rd axis of the original coordinate system. In the example: X' is in the original X/Z plane.



- ① Inclined plane
- α, β, γ Solid angle
- A Alignment of the G17 plane parallel to the inclined plane:
 - 1st rotation
Rotation of x around y through angle $\alpha \Rightarrow$
 x' -axis parallel to the inclined plane
 - 2nd rotation
Rotation of y' around x' through $\beta \Rightarrow$
 y' -axis parallel to the inclined plane
 $\Rightarrow z'$ -axis parallel to the inclined plane
 \Rightarrow G17 parallel to the inclined plane
- B Alignment of the G18 plane parallel to the inclined plane:
 - 1st rotation
Rotation of z around x through the angle $\gamma \Rightarrow$
 z' -axis parallel to the inclined plane
 - 2nd rotation
Rotation of x' around z' through angle $\alpha \Rightarrow$
 x' -axis parallel to the inclined plane
 $\Rightarrow y'$ -axis parallel to the inclined plane
 \Rightarrow G18 parallel to the inclined plane
- C Alignment of the G19 plane parallel to the inclined plane:
 - 1st rotation
Rotation of y around z through the angle $\beta \Rightarrow$
 y' -axis parallel to the inclined plane
 - 2nd rotation
Rotation of z' around y' through angle $\gamma \Rightarrow$
 z' -axis parallel to the inclined plane
 $\Rightarrow x'$ -axis parallel to the inclined plane
 \Rightarrow G19 parallel to the inclined plane

Syntax

Requirements

The position of a plane in space is clearly defined by two solid angles. The plane would be "over-defined" by the specification of a third solid angle. It is therefore not permitted.

If only one solid angle is programmed, the rotation of the WCS is identical to ROT, AROT (see Section "Programmable rotation (ROT, AROT, RPL) (Page 311)").

Through the two programmed axes, a plane is specified according to the plane definitions for G17, G18, G19. This defines the sequence of the coordinate axes (1st axis / 2nd axis of the plane) or the sequence of the rotations through the solid angles:

Plane	1st axis	2nd axis
G17	X	Y
G18	Z	X
G19	Y	Z

Alignment of the G17 plane \Rightarrow solid angle for X and Y

- 1st rotation: X around Y through the angle α
- 2nd rotation: Y around X' through the angle β
- Orientation: X' is in the original Z/X plane.

ROTS X< α > Y< β >

AROTS X< α > Y< β >

CROTS X< α > Y< β >

Alignment of the G18 plane \Rightarrow solid angle for Z and X

- 1st rotation: Z around X through the angle γ
- 2nd rotation: X around Z' through the angle α
- Orientation: Z' is in the original Y/Z plane

ROTS Z< γ > X< α >

AROTS Z< γ > X< α >

CROTS Z< γ > X< α >

Alignment of the G19 plane \Rightarrow solid angle for Y and Z

- 1st rotation: Y around Z through the angle β
- 2nd rotation: Z around Y' through the angle γ
- Orientation: Y' is in the original X/Z plane.

ROTS Y< β > Z< γ >

AROTS Y< β > Z< γ >

CROTS Y< β > Z< γ >

Meaning

ROTS:	Absolute frame rotations with solid angles, reference frame: Programmable frame \$P_PFRAME
AROTS:	Additive frame rotations with solid angles, reference frame: Programmable frame \$P_PFRAME
CROTS:	Absolute frame rotations with solid angles, reference frame: Programmed frame \$P_ ...
X, Y, Z:	Geometry axis identifiers (see note above: Geometry axis identifiers)
A, β , γ :	Solid angle in relation to the appropriate geometry axis: <ul style="list-style-type: none"> • $\alpha \rightarrow X$ • $\beta \rightarrow Y$ • $\gamma \rightarrow Z$

2.12.7 Programmable scaling factor (SCALE, ASCALE)

SCALE/ASCALE can be used to program up or down scale factors for all path, synchronized, and positioning axes in the direction of the axes specified in each case. This makes it possible, therefore, to take geometrically similar shapes or different shrinkage allowances into account in the programming.

Syntax

```
SCALE X... Y... Z...
ASCALE X... Y... Z...
```


Note

Each frame operation is programmed in a separate NC block.

Meaning

SCALE:	Scale up/down absolute in relation to the currently valid coordinate system set with G54 to G57, G505 to G599.
ASCALE:	Scale up/down additive in relation to the currently valid set or programmed coordinate system.
X... Y... Z...:	Scale factors in the direction of the specified geometry axes.

Example



The pocket occurs twice on this workpiece, but with different sizes and rotated in relation to one another. The machining sequence is stored in the subprogram.

The required workpiece zeroes are set with zero offset and rotation, the contour is scaled down with scaling and the subprogram is then called again.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero
N20 TRANS X15 Y15	; Absolute offset
N30 L10	; Machine large pocket
N40 TRANS X40 Y20	; Absolute offset
N50 AROT RPL=35	; Rotation in the plane through 35°
N60 ASCALE X0.7 Y0.7	; Scaling factor for the small pocket
N70 L10	; Machine small pocket
N80G0 X300 Y100 M30	; Retraction, end of program

Further information


SCALE X... Y... Z...

You can specify an individual scale factor for each axis, by which the shape is to be reduced or enlarged. The scale refers to the workpiece coordinate system set with G54 to G57, G505 to G599.

NOTICE

No original frame


The `SCALE` command resets all frame components of the previously activated programmable frame.



ASCALE X... Y... Z...

The `ASCALE` command is used to program scale changes to be added to existing frames. In this case, the last valid scale factor is multiplied by the new one.

The currently set or last programmed coordinate system is used as the reference for the scale change.




Scaling and offset

Note

If an offset is programmed with `ATRANS` after `SCALE`, the offset values will also be scaled.

Different scale factors**NOTICE****Risk of collision**

Please take great care when using different scale factors! Circular interpolations can, for example, only be scaled using identical factors.

**Note**

However, different scale factors can be used specifically to program distorted circles.

2.12.8 Programmable mirroring (MIRROR, AMIRROR)

`MIRROR/AMIRROR` can be used to mirror workpiece shapes on coordinate axes. All traversing movements programmed after the mirror call (e.g. in the subprogram) are executed with mirroring.

Syntax

```
MIRROR X... Y... Z...
AMIRROR X... Y... Z...
```

Note


Each frame operation is programmed in a separate NC block.

Meaning

MIRROR:	Mirror absolute in relation to the currently valid coordinate system set with G54 to G57, G505 to G599.
AMIRROR:	Additive mirror image with reference to the currently valid set or programmed coordinate system.
X... Y... Z...:	Geometry axis whose direction is to be changed. The value specified here can be chosen freely, e.g. X0 Y0 Z0.


Examples

Example 1: Milling



The contour shown here is programmed once as a subprogram. The three other contours are generated using mirroring. The workpiece zero is located at the center of the contours.

Program code	Comment
N10 G17 G54	; Working plane X/Y, workpiece zero
N20 L10	; Machine first contour at top right
N30 MIRROR X0	; Mirror X axis (the direction is changed in X)
N40 L10	; Machine second contour at top left
N50 AMIRROR Y0	; Mirror Y axis (the direction is changed in Y)
N60 L10	; Machine third contour at bottom left
N70 MIRROR Y0	; MIRROR resets previous frames. Mirror Y axis (the direction is changed in Y)
N80 L10	; Machine fourth contour at bottom right
N90 MIRROR	; Deactivate mirroring
N100 G0 X300 Y100 M30	; Retraction, end of program

Example 2: Turning

The actual machining is stored as a subprogram and execution at the respective spindle is implemented by means of mirroring and offsets.


Program code	Comment
N10 TRANS X0 Z140	; Zero offset to W
...	; Machining of the first side with spindle 1
N30 TRANS X0 Z600	; Zero offset to spindle 2
N40 AMIRROR Z0	; Mirroring of the Z axis
N50 ATRANS Z120	; Zero offset to W1
...	; Machining of the second side with spindle 2

Further information**MIRROR X... Y... Z...**

The mirror is programmed by means of an axial change of direction in the selected working plane.

Example: Working plane G17 X/Y

The mirror (on the Y axis) requires a direction change in X and, accordingly, is programmed with MIRROR X0. The contour is then mirrored on the opposite side of the mirror axis Y.




Mirroring is implemented in relation to the currently valid coordinate system set with G54 to G57, G505 to G599.

NOTICE
No original frame
The <code>MIRROR</code> command resets all frame components of the previously activated programmable frame.

AMIRROR X... Y... Z...

A mirror image, which is to be added to an existing transformation, is programmed with `AMIRROR`. The currently set or last programmed coordinate system is used as the reference.



Deactivate mirroring


For all axes: `MIRROR` (without axis parameter)

All frame components of the previously programmed frame are reset.

Tool radius compensation

Note

The mirror command causes the control to automatically change the path compensation commands (G41/G42 or G42/G41) according to the new machining direction.



The same applies to the direction of circle rotation (G2/G3 or G3/G2).

Note

If you program an additive rotation with `AROT` after `MIRROR`, you may have to work with reversed directions of rotation (positive/negative or negative/positive). Mirrors on the geometry axes are converted automatically by the control into rotations and, where appropriate, mirrors on the mirror axis specified in the machine data. This also applies to settable zero offsets.

Mirror axis

The axis to be mirrored can be set in machine data:

MD10610 \$MN_MIRROR_REF_AX = <value>

Value	Meaning
0	Mirroring is performed around the programmed axis (negation of values).
1	The reference axis is the X axis.
2	The reference axis is the Y axis.
3	The reference axis is the Z axis.

Interpreting the programmed values

Machine data is used to specify how the programmed values are to be interpreted:

MD10612 \$MN_MIRROR_TOGGLE = <value>

Value	Meaning
0	Programmed axis values are not evaluated.
1	Programmed axis values are evaluated: <ul style="list-style-type: none"> • For programmed axis values $\neq 0$, the axis is mirrored if it has not yet been mirrored. • For a programmed axis value = 0, mirroring is deactivated.

2.12.9 Frame generation according to tool orientation (TOFRAME, TOROT, PAROT):

TOFRAME generates a rectangular frame whose Z axis coincides with the current tool orientation. This means that the user can retract the tool in the Z direction without risk of collision (e.g. after a tool break in a 5-axis program).


The position of the X and Y axes is determined by the setting in machine data MD21110 \$MC_X_AXES_IN_OLD_X_Z_PLANE (coordinate system with automatic frame definition). The new coordinate system is either left as generated from the machine kinematics or is turned around the new Z axis additionally so that the new X axis lies in the old Z/X plane (see machine manufacturer's specifications).

The resulting frame describing the orientation is written in the system variable for the programmable frame (\$P_PFRAME).

TOROT only overwrites the rotation component in the programmed frame. All other components remain unchanged.

TOFRAME and **TOROT** are designed for milling operations in which G17 (working plane X/Y) is typically active. In the case of turning operations or generally when G18 or G19 is active, however, frames are needed where the X or Y axis matches the orientation of the tool. These frames are programmed with the **TOFRAMEX/TOROTX** or **TOFRAMEY/TOROTY** statements.

PAROT aligns the workpiece coordinate system on the workpiece.



Syntax

TOFRAME/TOFRAMEZ/TOFRAMEY/TOFRAMEX

...

TOROTOF

TOROT/TOROTZ/TOROTY/TOROTX

...

TOROTOF

PAROT

...

PAROTOF

Meaning

TOFRAME:	Align Z axis of the WCS by rotating the frame parallel to the tool orientation
TOFRAMEZ:	As TOFRAME
TOFRAMEY:	Align Y axis of the WCS by rotating the frame parallel to the tool orientation
TOFRAMEX:	Align X axis of the WCS by rotating the frame parallel to the tool orientation
TOROT:	Align Z axis of the WCS by rotating the frame parallel to the tool orientation The rotation defined with TOROT is the same as that defined with TOFRAME.
TOROTZ:	As TOROT
TOROTY:	Align Y axis of the WCS by rotating the frame parallel to the tool orientation
TOROTX:	Align X axis of the WCS by rotating the frame parallel to the tool orientation
TOROTOF:	Deactivate orientation parallel to tool orientation
PAROT:	Rotate frame to align workpiece coordinate system on workpiece Translations, scaling and mirroring in the active frame remain valid
PAROTOF:	The workpiece-specific frame rotation activated with PAROT is deactivated with PAROTOF.

Note

The TOROT statement ensures consistent programming with active orientable toolholders for each kinematic type.

Just as in the situation for rotatable toolholders, PAROT can be used to activate a rotation of the work table. This defines a frame which changes the position of the workpiece coordinate system in such a way that no compensatory movement is performed on the machine. Language command PAROT is not rejected if no toolholder with orientation capability is active.

Example

Program code	Comment
N100 G0 G53 X100 Z100 D0	
N120 TOFRAME	
N140 G91 Z20	; TOFRAME is included in the calculation, all programmed geometry axis movements refer to the new coordinate system.
N160 X50	
...	

Further information

Assigning axis direction

If one of the TOFRAME_X, TOFRAME_Y, TOROT_X, TOROT_Y statements is programmed instead of TOFRAME/TOFRAME_Z or TOROT/TOROT_Z, the axis direction statements listed in this table will apply:

Statement	Tool direction (applied)	Secondary axis (abscissa)	Secondary axis (ordinate)
TOFRAME/TOFRAME _Z / TOROT/TOROT _Z	Z	X	Y
TOFRAME _Y /TOROT _Y	Y	Z	X
TOFRAME _X /TOROT _X	X	Y	Z

Separate system frame for TOFRAME or TOROT

The frames resulting from TOFRAME or TOROT can be written in a separate system frame \$P_TOOLFRAME. For this purpose, bit 3 must be enabled in machine data MD28082 \$MC_MM_SYSTEM_FRAME_MASK. The programmable frame remains unchanged. Differences occur when the programmable frame is processed further elsewhere.

References

For further information about machines with orientable toolholder, see:

- Programming Manual, Job Planning; Chapter: "Tool orientation"
- Function Manual, Basic Functions; Tool Offset (W1), Chapter: "Toolholder with orientation capability"

2.12.10 Deselect frame (G53, G153, SUPA, G500)

When executing certain processes, such as approaching the tool change point, various frame components have to be defined and suppressed at different times.

Settable frames can either be deactivated modally or suppressed non-modally.

Programmable frames can be suppressed or deleted non-modally.

Syntax

G53
 G153
 SUPA
 G500
 TRANS
 ROT
 SCALE
 MIRROR

Meaning

G53:	Non-modal suppression of all programmable and settable frames
G153:	G153 has the same effect as G53 and also suppresses the entire basic frame (\$P_ACTBFRAME).
SUPA:	SUPA has the same effect as G153 and also suppresses: <ul style="list-style-type: none"> • Handwheel offsets (DRF) • Overlaid movements • External zero offset • PRESET offset
G500:	Modal deactivation of all settable frames (G54 to G57, G505 to G599) if G500 does not contain a value.
TRANS ROT SCALE MIRROR:	Without axis details, a deletion of the programmable frames acts.

2.12.11 Programming: Deselecting overlays axis-specifically (CORROF)

The following axis-specific overlays (overrides) are deleted with the CORROF procedure:

- Additive work offsets (DRF offsets) set via handwheel traversal
- Position offsets programmed via the \$AA_OFF system variable

A preprocessing stop is initiated through the deletion of an overlay (override) value and the position component of the deselected overlaid movement is transferred to the position in the basic coordinate system. Whereby, no axis is traversed.

The position value that can be read via the \$AA_IM system variable (current **MCS** setpoint of the axis) **does not change** in the **machine** coordinate system.

The position value that can be read via the \$AA_IW system variable (current **WCS** setpoint of the axis) **changes** in the **workpiece** coordinate system because it now contains the deselected component of the overlaid movement.

Note

CORROF can be programmed in an **NC program**.

CORROF must **not** be programmed in a **synchronized action**.

Syntax

CORROF(<Axis>,"<String>"[,<Axis>,"<String>"])

Meaning

CORROF:	Procedure for the deselection of the following offsets and overlays of an axis:	
	<ul style="list-style-type: none"> • DRF offset • Position offsets (\$AA_OFF) 	
	Effective-ness:	Modal
<Axis>:	Axis identifier (channel, geometry or machine axis identifier)	
	Data type:	AXIS
<String>:	Character string for the definition of the overlay type	
	Data type:	BOOL
	Value	Meaning
	DRF	DRF offset
	AA_OFF	Position offset (\$AA_OFF)

Examples

Example 1: Axis-specific deselection of a DRF offset (1)

A DRF offset is generated in the X axis by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
N10 CORROF(X,"DRF")	; CORROF has the same effect as DRFOF here.
...	

Example 2: Axis-specific deselection of a DRF offset (2)

A DRF offset is generated in the X and Y axes by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
	; Only the DRF offset of the X axis is deselected; the DRF offset of the Y axis is retained.
	; With DRFOF, both offsets would have been deselected.
N10 CORROF(X,"DRF")	
...	

Example 3: Axis-specific deselection of a \$AA_OFF position offset

Program code	Comment
	; A position offset == 10 is interpolated for the X axis.
N10 WHEN TRUE DO \$AA_OFF[X]=10 G4 F5	
...	

Program code	Comment
<code>; The position offset of the X axis is deselected: \$AA_OFF[X]=0</code>	
<code>; The X axis is not traversed.</code>	
<code>; The position offset is added to the current position of the X axis.</code>	
<code>N80 CORROF(X,"AA_OFF")</code>	
<code>...</code>	

Example 4: Axis-specific deselection of a DRF offset and a \$AA_OFF position offset (1)

A DRF offset is generated in the X axis by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
<code>; A position offset of 10 is interpolated for the X axis.</code>	
<code>N10 WHEN TRUE DO \$AA_OFF[X]=10 G4 F5</code>	
<code>...</code>	
<code>; Only the DRF offset and the position offset of the X axis are deselected.</code>	
<code>; The DRF offset of the Y axis is retained.</code>	
<code>N70 CORROF(X,"DRF",X,"AA_OFF")</code>	
<code>...</code>	

Example 5: Axis-specific deselection of a DRF offset and a \$AA_OFF position offset (2)

A DRF offset is generated in the X and Y axes by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
<code>; A position offset == 10 is interpolated for the X axis.</code>	
<code>N10 WHEN TRUE DO \$AA_OFF[X]=10 G4 F5</code>	
<code>...</code>	
<code>; The DRF offset of the Y axis and the position offset of the X axis are deselected.</code>	
<code>; The DRF offset of the X axis is retained.</code>	
<code>N70 CORROF(Y,"DRF",X,"AA_OFF")</code>	
<code>...</code>	

Further information**\$AA_OFF_VAL**

Once the position offset has been deselected by means of \$AA_OFF, system variable \$AA_OFF_VAL (integrated distance of axis overlay) for the corresponding axis will equal zero.

\$AA_OFF in JOG mode

Also in JOG mode, if \$AA_OFF changes, the position offset will be interpolated as an overlaid movement if this function has been enabled via machine data MD 36750 \$MA_AA_OFF_MODE.

\$AA_OFF in synchronized action

If a synchronized action which immediately resets \$AA_OFF (DO \$AA_OFF[<axis>]=<value>) is active when the position offset is deselected using the CORROF (<axis>, "AA_OFF"), then \$AA_OFF will be deselected and not reset, and alarm 21660 will be displayed. However, if the synchronized action becomes active later, e.g. in the block after CORROF, \$AA_OFF will remain set and a position offset will be interpolated.

Automatic channel axis exchange

If an axis that is active in another channel has been programmed for a CORROF, it will be fetched into the channel with an axis exchange (requirement: MD30552 \$MA_AUTO_GET_TYPE > 0) and the position offset and/or the DRF offset deselected.

2.12.12 Deselecting additive work offsets (DRFROF)

The additive work offsets (DRF offsets) set via handwheel traversal are deselected via the DRFOF procedure.

A preprocessing stop is initiated through the deselection and the position component of the deselected DRF offset is transferred to the position in the basic coordinate system whereby no axis is traversed. The value of the \$AA_IM system variable (current MCS setpoint of an axis) does not change; the value of the \$AA_IW system variable (current WCS setpoint of an axis) changes because it now contains the deselected component from the overlaid movement.

Syntax

DRFOF

Meaning

DRFOF:	Procedure for deselection of the DRF offsets for all active axes in the channel	
	Effective-ness:	Modal

Examples

Example 1: Axis-specific deselection of a DRF offset (1)

A DRF offset is generated in the X axis by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
N10 CORROF(X, "DRF")	; CORROF has the same effect as DRFOF here.
...	

Example 2: Axis-specific deselection of a DRF offset (2)

A DRF offset is generated in the X and Y axes by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
N10 CORROF(X,"DRF")	; Only the DRF offset of the X axis is deselected; the DRF offset of the Y axis is retained (in the case of DRFOF both offsets would have been deselected).
...	

Example 3: Axis-specific deselection of a DRF offset and a \$AA_OFF position offset (1)

A DRF offset is generated in the X axis by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
N10 WHEN TRUE DO \$AA_OFF[X]=10 G4 F5	; A position offset == 10 is interpolated for the X axis.
...	
N70 CORROF(X,"DRF",X,"AA_OFF")	; Only the DRF offset and the position offset of the X axis are deselected; the DRF offset of the Y axis is retained.
...	

Example 4: Axis-specific deselection of a DRF offset and a \$AA_OFF position offset (2)

A DRF offset is generated in the X and Y axes by DRF handwheel traversal. No DRF offsets are operative for any other axes in the channel.

Program code	Comment
N10 WHEN TRUE DO \$AA_OFF[X]=10 G4 F5	; A position offset == 10 is interpolated for the X axis.
...	
N70 CORROF(Y,"DRF",X,"AA_OFF")	; The DRF offset of the Y axis and the position offset of the X axis are deselected; the DRF offset of the X axis is retained.
...	

2.12.13 Grinding-specific work offsets (GFRAME0, GFRAME1 ... GFRAME100)**Command for activating a grinding frame in the channel**

The programming of the GFRAME<n> command makes the associated grinding frame of the \$P_GFR[<n>] data management active in the channel. This sets the active \$P_GFRAME grinding frame identical to the \$P_GFR[<n>] grinding frame of the data management:

2.12 Coordinate transformations (frames)

GFRAME<n> ⇒ \$P_GFRAME = \$P_GFR[<n>]

Command	Grinding frame activated in the channel
GFRAME0	\$P_GFR[0] (null frame)
GFRAME1	\$P_GFR[1]
...	...
GFRAME100	\$P_GFR[100]

Syntax

GFRAME<n>

Meaning

GFRAME<n>:	Activation of the grinding frame <n> of the data management	
	G group:	64
	Basic position:	MD20150 \$MC_GCODE_RESET_VALUES[63]
	Effectiveness:	Modal
<n>:	Number of the grinding frame	
	Range of values:	0, 1, 2, ... 100

2.13 Auxiliary function outputs

Function

The auxiliary function output sends information to the PLC indicating when the NC program needs the PLC to perform specific switching operations on the machine tool. The auxiliary functions are output, together with their parameters, to the PLC interface. The transferred values and signals must be processed by the PLC user program.

Auxiliary functions

The following auxiliary functions can be transferred to the PLC:

Auxiliary Function	Address
Tool selection	T
Tool offset	D, DL
Feedrate	F/FA
Spindle speed	S
M functions	M
H functions	H

For each function group or single function, machine data is used to define whether the output is triggered **before**, **with** or **after** the traversing motion.

The PLC can be programmed to acknowledge auxiliary function outputs in various ways.

Properties

Important properties of the auxiliary function are shown in the following overview table:

Function	Address extension		Value			Explanations	Maximum number per block
	Meaning	Range	Range	Type	Meaning		
M	-	0 (implicit)	0 ... 99	INT	Function	The address extension is 0 for the range between 0 and 99. Mandatory without address extension: M0, M1, M2, M17, M30	5
	Spindle no.	1 - 12	1 ... 99	INT	Function	M3, M4, M5, M19, M70 with address extension spindle no. (e.g. M2=5; spindle stop for spindle 2). Without spindle number, the function applies for the master spindle.	
	Any	0 - 99	100 ... 2147483647	INT	Function	User M function*	

2.13 Auxiliary function outputs

Function	Address extension		Value			Explanations	Maximum number per block
	Meaning	Range	Range	Type	Meaning		
S	Spindle no.	1 - 12	0 ... $\pm 1.8 \cdot 10^{308}$	REAL	Speed	Without spindle number, the function applies for the master spindle.	3
H	Any	0 - 99	0 ... ± 2147483647 $\pm 1.8 \cdot 10^{308}$	INT REAL	Any	Functions have no effect in the NC; only to be implemented on the PLC.*	3
T	Spindle no. (for active tool management)	1 - 12	0 - 32000 (or tool names with active tool management)	INT	Tool selection	Tool names are not passed to the PLC interface.	1
D	-	-	0 - 12	INT	Tool offset selection	D0: Deselection Default setting: D1	1
DL	Location-dependent offset	1 - 6	0 ... $\pm 1.8 \cdot 10^{308}$	REAL	Tool fine offset selection	Refers to previously selected D number.	1
F	-	-	0.001 - 999 999.999	REAL	Path feedrate		6
FA	Axis No.	1 - 31	0.001 - 999 999.999	REAL	Axial feedrate		

* The meaning of the functions is defined by the machine manufacturer (see machine manufacturer's specifications).

Further information

Number of function outputs per NC block

Up to 10 function outputs can be programmed in one NC block. Auxiliary functions can also be output from the action component of **synchronized actions**.

References:

Function Manual, Synchronized Actions

Grouping

The functions described can be grouped together. Group assignment is predefined for some M commands. The acknowledgment behavior can be defined by the grouping.

High-speed function outputs (QU)

Functions, which have not been programmed as high-speed outputs, can be defined as high-speed outputs for individual outputs with the keyword **QU**. Program execution continues without waiting for the acknowledgment of the miscellaneous function (the program waits for the transport acknowledgment). This helps avoid unnecessary hold points and interruptions to traversing movements.

Note

The appropriate machine data must be set for the "High-speed function outputs" function (→ **machine manufacturer**).

Function outputs for travel commands

The transfer of information as well as waiting for the appropriate response takes time and therefore influences the traversing movements.

High-speed acknowledgment without block change delay

Block change behavior can be influenced by machine data. When the "without block change delay" setting is selected, the system response with respect to high-speed auxiliary functions is as follows:

Auxiliary function output	Response
Before the movement	The block transition between blocks with high-speed auxiliary functions occurs without interruption and without a reduction in velocity. The auxiliary function output takes place in the first interpolator clock cycle of the block. The following block is executed with no acknowledgment delay.
During the movement	The block transition between blocks with high-speed auxiliary functions occurs without interruption and without a reduction in velocity. The auxiliary function output takes place during the block. The following block is executed with no acknowledgment delay.
After the movement	The movement stops at the end of the block. The auxiliary function output takes place at the end of the block. The following block is executed with no acknowledgment delay.

CAUTION

Function outputs in continuous-path mode

Function outputs **before** the traversing movements interrupt the continuous-path mode (G64/G641) and generate an exact stop for the previous block.

Function outputs **after** the traversing movements interrupt the continuous-path mode (G64/G641) and generate an exact stop for the current block.

Important: A wait for an outstanding acknowledgment signal from the PLC can also interrupt the continuous-path mode, e.g. for M command sequences in blocks with extremely short path lengths.

2.13.1 M functions

The M functions initiate switching operations, such as "Coolant ON/OFF" and other functions on the machine.

Syntax

```
M<value>
M[<address extension>] = <value>
```

Meaning

M:	Address for the programming of the M functions.	
<address extension>:	The extended address notation applies for some M functions (e.g. specification of the spindle number for spindle functions).	
<value>:	Assignment is made to a certain machine function through the value assignment (M function number).	
	Type:	INT
	Range of values:	0 ... 2147483647 (max. INT value)

Predefined M functions

Certain important M functions for program execution are supplied as standard with the control:

M function	Meaning
M0*	Programmed stop
M1*	Optional stop
M2*	End of program, main program (as M30)
M3	Spindle clockwise
M4	Spindle counter-clockwise
M5	Spindle stop
M6	Tool change (default setting)
M17*	End of subprogram
M19	Spindle positioning
M30*	End of program, main program (as M2)
M40	Automatic gear change
M41	Gear stage 1
M42	Gear stage 2
M43	Gear stage 3
M44	Gear stage 4
M45	Gear stage 5
M70	Spindle is switched to axis mode

Note

Extended address notation cannot be used for the functions marked with *.

The functions M0, M1, M2, M17 and M30 are always triggered **after** the traversing movement.

M functions defined by the machine manufacturer

All free M function numbers can be used by the machine manufacturer, e.g. for switching functions to control the clamping devices or for the activation/deactivation of further machine functions.

Note

The functions assigned to the free M function numbers are machine-specific. A certain M function can therefore have a different functionality on another machine.

Refer to the machine manufacturer's specifications for the M functions available on a machine and their functions.

Examples

Example 1: Maximum number of M functions in the block

Program code	Comment
N10 S...	
N20 X... M3	; M function in the block with axis movement, ; spindle accelerates prior to X axis movement.
N180 M789 M1767 M100 M102 M376	; Maximum of five M functions in the block.

Example 2: M function as high-speed output

Program code	Comment
N10 H=QU(735)	; Fast output for H735.
N10 G1 F300 X10 Y20 G64	
N20 X8 Y90 M=QU(7)	; Fast output for M7.

M7 has been programmed as fast output so that the continuous-path mode (G64) is not interrupted.

Note

Only use this function in special cases as, for example, the chronological alignment is changed in combination with other function outputs.

Further information about the predefined M commands

Programmed stop: M0

The machining is stopped in the NC block with M0. You can now remove chips, remeasure, etc.

Programmed stop 1 - optional stop: M1

M1 can be set via:

- HMI / dialog box "Program Control"
or
- NC/PLC interface

The program execution of the NC is stopped by the programmed blocks.

Programmed stop 2 - an auxiliary function associated with M1 with stop in the program execution

Programmed stop 2 can be set via the HMI / dialog box "Program Control" and allows the technological sequences to be interrupted at any time at the end of the part to be machined. In this way, the operator can interrupt the production, e.g. to remove chip flows.

End of program: M2, M17, M30

A program is ended with M2, M17 or M30. If the main program is called from another program (as subprogram), M2/M30 has the same effect as M17 and vice versa, i.e. M17 has the same effect in the main program as M2/M30.

Spindle functions: M3, M4, M5, M19, M70

The extended address notation with specification of the spindle number applies for all spindles.

Example:

Program code	Comment
M2=3	; Clockwise spindle rotation for the second spindle

If an address extension has not been programmed, the function applies for the master spindle.

2.14 Supplementary commands

2.14.1 Output messages (MSG)

Using the `MSG ()` statement, any character string from the part program can be output as message to the operator.

Syntax

```
MSG("<Message text>"[,<Execution>])
...
MSG ()
```

Meaning

MSG:	Predefined subprogram call for output of a message		
<message text>:	Any character string to be displayed as message		
	Type:	STRING	
	Maximum length:	124 characters; the display takes up two lines (2*62 characters)	
	By using the link operator "<<", variables can also be output in the message text.		
<Execution>:	Parameter to define the time when the message is written (optional)		
	Type:	INT	
	Value:	0 (basic setting)	To write the message, a dedicated main run block is not generated. This is realized in the next NC block that can be executed. Active continuous-path mode is not interrupted.
		1	To write the message, a dedicated main run block is generated. Active continuous-path mode is interrupted.
MSG ():	The actual message can be deleted by programming <code>MSG ()</code> without message text. If not deleted, the display remains until the next message is present.		

Examples

Example 1: Output/delete message

Program code	Comment
N10 G91 G64 F100	; Continuous path mode
N20 X1 Y1	
N... X... Y...	
N20 MSG ("Machining part 1")	; The message is first output with N30.
	; continuous-path mode is retained.

Program code	Comment
N30 X... Y...	
N... X... Y...	
N400 X1 Y1	
N410 MSG ("Machining part 2",1)	; The message is output with N410. ; continuous-path mode is interrupted.
N420 X1 Y1	
N... X... Y...	
N900 MSG ()	; Delete message.

Example 2: Message text with variable

Program code	Comment
N10 R12=\$AA_IW [X]	; Actual position of the X axis in R12.
N20 MSG ("Check position of X axis"<<R12<<)	; Output message with variable R12.
...	
N90 MSG ()	; Clear message from N20.

2.14.2 Writing string in OPI variable (WRTPR)

Using the WRTPR() function, it is possible to write any character string from the part program into the OPI variable progProtText.

Syntax

WRTPR(<String>[,<ExecTime>])

Meaning

WRTPR:	Function call for outputting a character string.	
<String>:	Any character string, which is written to the OPI variable progProtText.	
	Type:	STRING
	Maximum length:	128 characters

<ExecTime>:	Optional parameters to define the instant in time when the string is written.		
	Type:	INT	
	Range of values:	0, 1	
		0 (default)	No dedicated main run block is not generated to write the character string. This is realized in the next NC block that can be executed. Active continuous-path mode is not interrupted.
1	A dedicated main run block is generated to write the character string. Active continuous-path mode is interrupted.		


Examples

Program code	Comment
N10 G91 G64 F100	; continuous path mode
N20 X1 Y1	
N30 WRTPR("N30")	; The character string "N30" is first written to N40. ; Continuous-path mode is kept.
N40 X1 Y1	
N50 WRTPR("N50",1)	; The character string "N50" is written to N50. ; Continuous-path mode is interrupted.
N60 X1 Y1	


2.14.3 Working area limitation

2.14.3.1 Working area limitation in BCS (G25/G26, WALIMON, WALIMOF)

G25/G26 limits the working area (working field, working space) in which the tool can traverse. The areas outside the working area limitations defined with G25/G26 are inhibited for any tool motion.



The coordinates for the individual axes apply in the basic coordinate system:



The working area limitation for all validated axes must be programmed with the `WALIMON` command. The `WALIMOF` command deactivates the working area limitation. `WALIMON` is the default setting. Therefore, it only has to be programmed if the working area limitation has been disabled beforehand.

Syntax

```
G25 X...Y...Z...
G26 X...Y...Z...
WALIMON
...
WALIMOF
```

Meaning

G25:	Lower working area limitation Assignment of values in channel axes in the basic coordinate system
G26:	Upper working area limitation Assignment of values in channel axes in the basic coordinate system
X... Y... Z...:	Lower or upper working area limits for individual channel axes The limits specified refer to the basic coordinate system.
WALIMON:	Switch working area limitation on for all axes
WALIMOF:	Switch working area limitation off for all axes

In addition to programming values using G25/G26, values can also be entered using axis-specific setting data:

SD43420 \$SA_WORKAREA_LIMIT_PLUS (Working area limitation plus)

SD43430 \$SA_WORKAREA_LIMIT_MINUS (Working area limitation minus)

Activating and deactivating the working area limitation, parameterized using SD43420 and SD43430, are carried out for a specific direction using the axis-specific setting data that becomes immediately effective:

SD43400 \$SA_WORKAREA_PLUS_ENABLE (Working area limitation active in the positive direction)

SD43410 \$SA_WORKAREA_MINUS_ENABLE (Working area limitation active in the negative direction)

Using the direction-specific activation/deactivation, it is possible to limit the working range for an axis in just one direction.


Note

The programmed working area limitation, programmed with G25/G26, has priority and overwrites the values entered in SD43420 and SD43430.

Note

G25/G26 can also be used to program limits for spindle speeds at the address S. For more information see "Programmable spindle speed limitation (G25, G26) (Page 106)".

Example



Using the working area limitation G25/26, the working area of a lathe is limited so that the surrounding devices and equipment - such as revolver, measuring station, etc. are protected against damage.

Default setting: WALIMON

Program code	Comment
N10 G0 G90 F0.5 T1	
N20 G25 X-80 Z30	; Define the lower limit for the individual coordinate axes
N30 G26 X80 Z330	; Define the upper limit
N40 L22	; Cutting program
N50 G0 G90 Z102 T2	; To tool change location
N60 X0	
N70 WALIMOF	; Deactivate working area limitation
N80 G1 Z-2 F0.5	; Drill
N90 G0 Z200	; Back
N100 WALIMON	; Switch on working area limitation
N110 X70 M30	; End of program

Further information

Reference point at the tool

When tool length offset is active, the tip of the tool is monitored as reference point, otherwise it is the toolholder reference point.

Consideration of the tool radius must be activated separately. This is done using channel-specific machine data:

MD21020 \$MC_WORKAREA_WITH_TOOL_RADIUS

If the tool reference point lies outside the working area defined by the working area limitation or if this area is left, the program sequence is stopped.

Note

If transformations are active, the tool data taken into consideration (tool length and tool radius) can deviate from the described behavior.

References:

Function Manual, Basic Functions; Axis Monitoring, Protection Zones (A3),
Section: "Monitoring the working area limitation"

Programmable working area limitation, G25/G26

An upper (G26) and a lower (G25) working area limitation can be defined for each axis. These values are effective immediately and remain effective for the corresponding MD setting (→ MD10710 \$MN_PROG_SD_RESET_SAVE_TAB) after RESET and after being powered-up again.

Note

The CALCPOSI subprogram is described in the Job Planning Programming Manual Using this subprogram before any traversing motion is made, it can be checked as to whether the predicted path is moved through taking into account the working area limits and/or the protection zones.

2.14.3.2 Working area limitation in WCS/SZS (WALCS0 ... WALCS10)

The "working area limitation in WCS/SZS" enables a flexible workpiece-specific limitation of the traversing range of the channel axes in the workpiece coordinate system (WCS) or settable zero system (SZS). It is intended mainly for use in conventional lathes.

Requirement

The channel axes must be homed.

Working area limitation group

In order that the axis-specific working area limits do not have to be rewritten for all channel axes when switching axis assignments, e.g. when switching transformations or the active frame on/off, working area limitation groups are available.

A working area limitation group comprises the following data:

- Working area limits for all channel axes
- Reference system of the working area limitation

Syntax

| ...

2.14 Supplementary commands

```

$P_WORKAREA_CS_COORD_SYSTEM[<WALimNo>]=<Value>
$P_WORKAREA_CS_PLUS_ENABLE[<WALimNo>,<Ax>]=<Value>
$P_WORKAREA_CS_LIMIT_PLUS[<WALimNo>,<Ax>]=<Value>
$P_WORKAREA_CS_MINUS_ENABLE[<WALimNo>,<Ax>]=<Value>
$P_WORKAREA_CS_LIMIT_MINUS[<WALimNo>,<Ax>]=<Value>
...
WALCS<n>
...
WALCS0
    
```

Meaning

\$P_WORKAREA_CS_COORD_SYSTEM[<WALimNo>]=<Value>	
The coordinate system to which the working area limitation group refers	
<WALimNo>:	Working area limitation group
	Type: INT
	Range of values: 0 (group 1) ... 9 (group 10)
<Value>:	Value of the type INT
	1 Workpiece coordinate system (WCS)
	3 Settable zero system (SZS)

\$P_WORKAREA_CS_PLUS_ENABLE[<WALimNo>,<Ax>]=<Value>	
Enable the working area limitation in the positive axis direction for the specified channel axis	
<WALimNo>:	Working area limitation group
	Type: INT
	Range of values: 0 (group 1) ... 9 (group 10)
<Ax>:	Channel axis name
<Value>:	Value of the type BOOL
	0 (FALSE) No release
	1 (TRUE) Release

\$P_WORKAREA_CS_MINUS_ENABLE[<WALimNo>,<Ax>]=<Value>	
Enable the working area limitation in the negative axis direction for the specified channel axis	
<WALimNo>:	Working area limitation group
	Type: INT
	Range of values: 0 (group 1) ... 9 (group 10)
<Ax>:	Channel axis name
<Value>:	Value of the type BOOL
	0 (FALSE) This has not been released
	1 (TRUE) Enable

\$P_WORKAREA_CS_LIMIT_PLUS [<WALimNo>, <Ax>]=<Value>	
Working area limitation in the positive direction of the specified channel axis	
<WALimNo>:	Working area limitation group
	Type: INT
	Range of values: 0 (group 1) ... 9 (group 10)
<Ax>:	Channel axis name
<Value>:	Value of the type REAL

\$P_WORKAREA_CS_LIMIT_MINUS [<WALimNo>, <Ax>]=<Value>	
Working area limitation in the negative direction of the specified channel axis	
<WALimNo>:	Working area limitation group
	Type: INT
	Range of values: 0 (group 1) ... 9 (group 10)
<Ax>:	Channel axis name
<Value>:	Value of the type REAL

WALCS<n>:	Activation of the working area limitations of a working area limitation group
<n>:	Number of the working area limitation group
	Range of values: 1 ... 10

WALCS0:	Deactivation of the working area limits active in the channel
---------	---

Note

The actual available number of working area limitation groups depends on the configuration (→ see details of the machine manufacturer).

Example

Three axes are defined in the channel: X, Y and Z

A working area limitation group No. 2 is to be defined and then activated in which the axes are to be limited in the WCS according to the following specifications:

- X axis in the plus direction: 10 mm
- X axis in the minus direction: No limitation
- Y axis in the plus direction: 34 mm
- Y axis in the minus direction: -25 mm

- Z axis in the plus direction: No limitation
- Z axis in the minus direction: -600 mm

Program code	Comment
...	
N51 \$P_WORKAREA_CS_COORD_SYSTEM[1]=1	; The working area limitation of working area limitation group 2 applies in the WCS.
N60 \$P_WORKAREA_CS_PLUS_ENABLE[1,X]=TRUE	
N61 \$P_WORKAREA_CS_LIMIT_PLUS[1,X]=10	
N62 \$P_WORKAREA_CS_MINUS_ENABLE[1,X]=FALSE	
N70 \$P_WORKAREA_CS_PLUS_ENABLE[1,Y]=TRUE	
N73 \$P_WORKAREA_CS_LIMIT_PLUS[1,Y]=34	
N72 \$P_WORKAREA_CS_MINUS_ENABLE[1,Y]=TRUE	
N73 \$P_WORKAREA_CS_LIMIT_MINUS[1,Y]=-25	
N80 \$P_WORKAREA_CS_PLUS_ENABLE[1,Z]=FALSE	
N82 \$P_WORKAREA_CS_MINUS_ENABLE[1,Z]=TRUE	
N83 \$P_WORKAREA_CS_LIMIT_PLUS[1,Z]=-600	
...	
N90 WALCS2	; Activate working area limitation group 2.
...	

Further information

Effectivity

The working area limitation with WALCS1 - WALCS10 acts independently of the working area limitation with WALIMON. If both functions are active, that limit becomes effective which the axis motion first reaches.

Reference point at the tool

Taking into account the tool data (tool length and tool radius) and therefore the reference point at the tool when monitoring the working area limitation corresponds to the behavior for the working area limitation with WALIMON.

2.14.4 Reference point approach (G74)

When the machine has been powered up (where incremental position measuring systems are used), all of the axis slides must approach their reference mark. Only then can traversing movements be programmed.

The reference point can be approached in the NC program with G74.

Syntax

G74 X1=0 Y1=0 Z1=0 A1=0 ... ; Programmed in a separate NC block

Meaning

G74:	G command call reference point approach
X1=0 Y1=0 Z1=0 ... :	The specified machine axis address X1, Y1, Z1 ... for linear axes is approached as the reference point.
A1=0 B1=0 C1=0 ... :	The specified machine axis address A1, B1, C1 ... for rotary axes is approached as the reference point.

Note

A transformation must not be programmed for an axis which is to approach the reference point with G74.

The transformation is deactivated with command TRAFOOF.

Example

When the measuring system is changed, the reference point is approached and the workpiece zero point is set up.


Program code	Comment
N10 SPOS=0	;Spindle in position control
N20 G74 X1=0 Y1=0 Z1=0 C1=0	;Reference point approach for linear axes and rotary axes
N30 G54	; Zero offset
N40 L47	;Cutting program
N50 M30	; End of program

2.14.5 Approaching a fixed point (G75)

The non-modal command G75 can be used to move axes individually and independently of one another to fixed points in the machine space, e.g. to tool change points, loading points, pallet change points, etc.

The fixed points are positions in the machine coordinate system which are stored in the machine data (MD30600 \$MA_FIX_POINT_POS[n]). A maximum of four fixed points can be defined for each axis.

The fixed points can be approached from every NC program irrespective of the current tool or workpiece positions. An internal preprocessing stop is executed prior to moving the axes.



Requirements

The following requirements must be satisfied to approach fixed points with G75:

- The fixed-point coordinates must have been calculated exactly and written to machine data.
- The fixed points must be located within the valid traversing range (→ note the software limit switch limits!)
- The axes to be traversed must be referenced.
- No tool radius compensation must be active.
- A kinematic transformation may not be active.
- None of the axes to be traversed must be involved in active transformation.
- None of the axes to be traversed must be a following axis in an active coupling.
- None of the axes to be traversed must be an axis in a gantry grouping.
- Compile cycles must not activate motion components.

Syntax

G75 <axis name><axis position> ... FP=<n>

Meaning

G75:	Fixed point approach
<axis name>:	Name of the machine axis to be traversed to the fixed point All axis identifiers are permitted.
<axis position>:	The position value has no significance. A value of "0" is, therefore, usually specified.

FP=:	Fixed point that is to be approached	
	<n>:	Fixed point number
	Range of values:	1, 2, 3, 4
Note: In the absence of FP=<n> or a fixed point number, or if FP=0 has been programmed, this is interpreted as FP=1 and fixed point 1 is approached.		

Note

Multiple axes can be programmed in one G75 block. The axes are then traversed simultaneously to the specified fixed point.

Note

The value of the address FP must not be greater than the number of fixed points specified for each programmed axis (MD30610 \$MA_NUM_FIX_POINT_POS).

Example

For a tool change, axes X (= AX1) and Z (= AX3) need to move to the fixed machine axis position 1 where X = 151.6 and Z = -17.3.

Machine data:

- MD30600 \$MA_FIX_POINT_POS[AX1,0] = 151.6
- MD30600 \$MA_FIX_POINT[AX3,0] = 17.3

NC program:

Program code	Comment
...	
N100 G55	; Activate settable zero offset.
N110 X10 Y30 Z40	; Approach positions in the WCS.
N120 G75 X0 Z0 FP=1 M0	; The X axis moves to 151.6 ; and the Z axis moves to 17.3 (in the MCS). ; Each axis travels at its maximum velocity. ; No additional movements are permitted to be active in this block. ; A stop is inserted here so that after reaching ; the end positions, ; no additional motion takes place.
N130 X10 Y30 Z40	; The position of N110 is approached again. ; The zero offset is reactivated.
...	

Note

If the "Tool management with magazines" function is active, the auxiliary function T... or M... (typically M6) will not be sufficient to trigger a block change inhibit at the end of G75 motion.

Reason: If "Tool management with magazines" is active, auxiliary functions for tool change are not output to the PLC.

Further information

G75

The axes are traversed as machine axes in rapid traverse. The motion is mapped internally using the "SUPA" (suppress all frames) and "G0 RTLIOf" (rapid traverse motion with single-axis interpolation) functions.

If the conditions for "RTLIOf" (single-axis interpolation) are not met, the fixed point is approached as a path.

When the fixed point is reached, the axes come to a standstill within the "Exact stop fine" tolerance window.

Parameterizable dynamic response for G75

The required dynamic response mode can be set via the following machine data for positioning movements to fixed-point positions (G75):

MD18960 \$MN_POS_DYN_MODE (type of positioning axis dynamic response)

References

Function Manual, Basic Functions, Chapter "Acceleration (B2)" > "Functions" > "Jerk limiting for single axis interpolation (SOFTA) (axis-specific)"

Additional axis movements

The following additional axis movements are taken into account at the instant in time at which the G75 block is interpolated:

- External zero offset
- DRF
- Synchronization offset (\$AA_OFF)

After this, the additional axis movements are not permitted to change until the end of traversing is reached by the G75 block.

Additional movements following interpretation of the G75 block will offset the approach to the fixed point accordingly.

The following additional movements are not taken into account, irrespective of the point at which interpolation takes place, and will offset the target position accordingly:

- Online tool offset
- Additional movements from compile cycles in the BCS and machine coordinate system

Active frames

All active frames are ignored. Traversing is performed in the machine coordinate system.

Working area limitation in the workpiece coordinate system/SZS

Coordinate-system-specific working area limitation (WALCS0 ... WALCS10) is not effective in the block with G75. The destination point is monitored as the starting point of the following block.

Axis/Spindle movements with POSA/SPOSA

If programmed axes/spindles were previously traversed with POSA or SPOSA, these movements will be completed first before the fixed point is approached.

Spindle functions in the G75 block

If the spindle is excluded from "fixed-point approach", then additional spindle functions (e.g. positioning with SPOS/SPOSA) can be programmed in the G75.

Modulo axes

In the case of modulo axes, the fixed point is approached along the shortest distance.

References


For further information about "Fixed-point approach", see:

Function Manual Extended Functions; manual traversing and manual handwheel travel (H1), Chapter: "Fixed-point approach in JOG"

2.14.6 Travel to fixed stop (FXS, FXST, FXSW)

Function

The "Travel to fixed stop" function can be used to establish defined forces for clamping workpieces, such as those required for tailstocks, quills and grippers. The function can also be used for the approach of mechanical reference points.



With sufficiently reduced torque, it is also possible to perform simple measurement operations without connecting a probe. The "travel to fixed stop" function can be implemented for axes as well as for spindles with axis-traversing capability.

Syntax

```
FXS [<axis>]=...
FXST [<axis>]=...
FXSW [<axis>]=...
FXS [<axis>]=... FXST [<axis>]=...
FXS [<axis>]=... FXST [<axis>]=... FXSW [<axis>]=...
```

Meaning

FXS:	Command for activation and deactivation of the "Travel to fixed stop" function
FXS [<axis>]=1:	Activate function
FXS=[<axis>]=0:	Deactivate function
FXST:	Optional command for setting the clamping torque
	Specified as % of the maximum drive torque
FXSW:	Optional command for setting the window width for the fixed stop monitoring
	Specified in mm, inches or degrees
<axis>:	Machine axis name
	Machine axes (X1, Y1, Z1, etc.) are programmed

Note

The commands `FXS`, `FXST` and `FXSW` are modal.

The programming of `FXST` and `FXSW` is optional: If no parameter is specified, the last programmed value or the value set in the relevant machine data applies.

Activate travel to fixed stop: `FXS[<axis>] = 1`

The movement to the destination point can be described as a path or positioning axis movement. With positioning axes, the function can be performed across block boundaries.

Travel to fixed stop can be performed simultaneously for several axes and parallel to the movement of other axes. The fixed stop must be located between the start and end positions.

NOTICE**Risk of collision**

It is not permissible to program a new position for an axis if the "Travel to fixed stop" function has already been activated for an axis/spindle.

Spindles must be switched to position-controlled mode before the function is selected.

Example:

Program code	Comment
X250 Y100 F100 FXS[X1]=1 FXST[X1]=12.3 FXSW[X1]=2	; Axis X1 travels with feedrate F100 (specification optional) to target position X=250 mm.
	The clamping torque is 12.3% of the maximum drive torque, monitoring is performed in a 2 mm wide window.
...	

Deactivate travel to fixed stop: `FXS[<axis>] = 0`

Deselection of the function triggers a preprocessing stop.

The block with `FXS [<axis>]=0` may and should contain traversing movements.

<p>NOTICE</p> <p>Risk of collision</p> <p>The traversing movement to the retraction position must move away from the fixed stop, otherwise damage to the stop or to the machine may result.</p> <p>The block change takes place when the retraction position has been reached. If no retraction position is specified, the block change takes place immediately after the torque limit has been deactivated.</p>
--

Example:

Program code	Comment
<code>X200 Y400 G01 G94 F2000 FXS[X1]=0</code>	<code>; Axis X1 is retracted from the fixed stop to position X = 200 mm. All other parameters are optional.</code>
<code>...</code>	

Clamping torque (FXST) and monitoring window (FXSW)

Any programmed torque limiting `FXST` is effective from the block start, i.e. the fixed stop is also approached at a reduced torque. `FXST` and `FXSW` can be programmed and changed in the part program at any time. The changes take effect before traversing movements in the same block.

<p>NOTICE</p> <p>Risk of collision</p> <p>Programming of a new fixed stop monitoring window causes a change not only in the window width, but also in the reference point for the center of the window if the axis has moved prior to reprogramming. The actual position of the machine axis when the window is changed is the new window center point.</p> <p>The window must be selected such that only a breakaway from the fixed stop causes the fixed stop monitoring to respond.</p>
--

Further information

Rise ramp

A rate of rise ramp for the new torque limit can be defined in MD to prevent any abrupt changes to the torque limit setting (e.g. insertion of a quill).

Alarm suppression

The fixed stop alarm can be suppressed for applications by the part program by masking the alarm in a machine data item and activating the new MD setting with `NEW_CONF`.

Activation

The commands for travel to fixed stop can be called from synchronized actions or technology cycles. They can be activated without initiation of a motion, the torque is limited instantaneously. As soon as the axis is moved via a setpoint, the limit stop monitor is activated.

Activation from synchronized actions

Example:

If the expected event (\$R1) occurs and travel to fixed stop is not yet running, FXS should be activated for axis Y. The torque must correspond to 10% of the rated torque value. The width of the monitoring window is set to the default.

Program code

```
N10 IDS=1 WHENEVER ((R1=1) AND ($AA_FXS[Y]==0)) DO R1=0 FXS[Y]=1
FXST[Y]=10
```

The normal part program must ensure that \$R1 is set at the desired point in time.

Deactivation from synchronized actions

Example:

If an anticipated event (\$R3) has occurred and the status "Limit stop contacted" (system variable \$AA_FXS) is reached, then FXS must be deselected.

Program code

```
IDS=4 WHENEVER ((R3==1) AND ($AA_FXS[Y]==1)) DO FXS[Y]=0
FA[Y]=1000 POS[Y]=0
```

Fixed stop reached

When the fixed stop has been reached:

- The distance-to-go is deleted and the set position is tracked.
- The drive torque increases up to the programmed limit value FXSW, and then remains constant.
- Fixed stop monitoring is activated within the specified window width.

Supplementary conditions

- Measurement with delete distance-to-go
"Measurement with delete distance-to-go" (MEAS command) and "Travel to fixed stop" cannot be programmed at the same time in one block.
Exception: One function acts on a path axis and the other on a positioning axis or both act on positioning axes.
- Contour monitoring
Contour monitoring is not performed while "Travel to fixed stop" is active.
- Positioning axes
For "Travel to fixed stop" with positioning axes, the block change is performed irrespective of the fixed stop movement.

- Travel to fixed stop is **not** possible:
 - With gantry axes
 - For competing positioning axes that are controlled exclusively from the PLC (FXS must be selected from the NC program).
- If the torque limit is reduced too far, the axis will not be able to follow the specified setpoint; the position controller then goes to the limit and the contour deviation increases. In this operating state, an increase in the torque limit may result in sudden, jerky movements. To ensure that the axis can follow the setpoint, check the contour deviation to make sure it is not greater than the deviation with an unlimited torque.

2.14.7 Dwell time (G4)

With the command G4, a time (dwell time) is programmed in a block that expires as soon as the block is executed in the main run. The block change to the following block is performed as soon as the time has completely expired.

Note

G4 interrupts continuous-path mode.

Syntax

```
G4 F<Time>
G4 S<NumSpi>
G4 S<n> = <NumSpi>
```

Meaning

G4:	Activate dwell time	
	Alone in the block:	Yes
F<Time>:	The dwell time <Time> in seconds is specified at address F.	
S<NumSpi>:	The dwell time is programmed at address S in spindle revolutions <NumSpi> with reference to the current main spindle.	
S<n>=NumSpi:	The dwell time is programmed at address S in spindle revolutions <NumSpi> with reference to the spindle addressed with the address extension <n>.	

Note

The addresses F and S used for the time specified in the dwell block G4 do not influence the feedrates F . . . and the spindle speeds S . . . of the program.

Supplementary conditions

Synchronized actions

Two synchronized actions are programmed in one program in such a way that the following block with the dwell time becomes the action block in which the synchronized actions are performed. One synchronized action is a modal synchronized action. The other synchronized action is a non-modal synchronized action. If the non-modal synchronized action is intended to influence the modal synchronized action, e.g. release it for execution with UNLOCK, **at least two interpolation cycles** e.g. `G4 F<interpolator_cycle * 2>` must be provided as the effective dwell time.

The effective dwell time depends on the setting in the machine data MD10280 \$MN_PROG_FUNCTION_MASK, Bit 4 = <value>

Value	Meaning
0	The effective dwell time is equal to the programmed dwell time
1	The effective dwell time is equal to the programmed dwell time rounded to the next largest multiple of the interpolator cycle (MD10071 \$MN_IPO_CYCLE_TIME)

Program example:

- MD10071 \$MN_IPO_CYCLE_TIME == 8 ms
- MD10280 \$MN_PROG_FUNCTION_MASK, Bit 4 = 1

Program code	Comment
N10 WHEN TRUE DO LOCK(1)	; Non-modal SynAct: LOCK of the ; modal SynAct. ID=1
N20 G4 F2	; Action block for SynAct from N10
N30 WHEN TRUE DO UNLOCK(1)	; Non-modal SynAct: UNLOCK ; of the modal SynAct. ID=1
N40 ID=1 WHENEVER TRUE DO \$R0=1 RDISABLE	; Modal SynAct ID=1 ; R parameter R0=1 ; Set the read-in disable
N50 G4 F0.012	; Action block for SynAct from N40 and N50 ; See paragraph "Description" below
N60 G4 F10	

Description

The desired behavior is that the modal synchronized action from N30 cancels the active lock (LOCK) of the modal synchronized action with ID=1 from N40, causing the R parameter to be written in N50 and the read-in disable to become active. This behavior is only achieved if the active dwell time is at least two interpolation cycles long.

The active dwell time results from the programmed dwell time, the interpolation cycle, and the setting in MD10280 \$MN_PROG_FUNCTION_MASK, Bit 4. To ensure that the active dwell time is at least two interpolation cycles long, the following dwell time must be programmed:

- Bit 4 == 0: Programmed dwell time $\geq 2 * \text{interpolator cycle}$
- Bit 4 == 1: Programmed dwell time $\geq 1.5 * \text{interpolator cycle}$

If the active dwell time is shorter than two interpolation cycles, writing the R parameter and read-in disable will not be executed until block N60.

Example

Program code	Comment
N10 G1 F200 Z-5 S300 M3	;Feed F; spindle speed S
N20 G4 F3	; Dwell time: 3 s
N30 X40 Y10	
N40 G4 S30	; Dwelling 30 revolutions of the spindle (at S=300 rpm and 100% speed override, corresponds to: t = 0.1 min).
N50 X...	; The feedrate and spindle speed programmed in N10 continue to apply.

2.14.8 Internal preprocessing stop

Function

The control generates an internal preprocessing stop on access to machine status data (\$A...). The following block is not executed until all preprocessed and saved blocks have been executed in full. The previous block is stopped in exact stop (as G9).

Example

Program code	Comments
...	
N40 POSA[X]=100	
N50 IF \$AA_IM[X]==R100 GOTOF MARK1	; Access to machine status data (\$A...), the control generates an internal preprocessing stop.
N60 G0 Y100	
N70 WAITP(X)	
N80 LABEL1:	
...	

2.15 Other information


2.15.1 Axes

2.15.1.1 Axes (overview)

Axis types

A distinction is made between the following types of axis types when programming:

- Main axes / geometry axes
- Special axes
- Main spindle, master spindle
- Machine axes
- Channel axes
- Path axes
- Positioning axes
- Synchronized axes
- Command axes
- PLC axes / competing positioning axes



2.15.1.2 Main axes/Geometry axes

The main axes define a right-angled, right-handed coordinate system. Tool movements are programmed in this coordinate system.

In NC technology, the main axes are called geometry axes. This term is also used in this Programming Guide.

Replaceable geometry axes

The "Replaceable geometry axes" function (see Function Manual, Job Planning) can be used to alter the geometry axes grouping configured using machine data from the part program. Here any geometry axis can be replaced by a channel axis defined as a synchronous special axis.


Axis identifier

The name/identifier of a geometry axis can be defined using the following machine data:

MD20060 \$MC_AXCONF_GEOAX_NAME_TAB (name of the geometry axis in the channel)

Standard identifier for turning machines:

1. Geometry axis: X
2. Geometry axis: Z



Standard identifier for milling machines:

1. Geometry axis: X
2. Geometry axis: Y
3. Geometry axis: Z

Further information

A maximum of three geometry axes are used for programming frames and the workpiece geometry (contour).

The identifiers for geometry and channel axes may be the same, provided a reference is possible.

Geometry and channel axis names must be the same in all channels. This means that a program can be executed in any channel.

2.15.1.3 Special axes

In contrast to the geometry axes, no geometrical relationship is defined between the special axes.

Typical special axes are:

- Tool revolver axes
- Swivel table axes
- Swivel head axes
- Loader axes

Axis identifier

On a turning machine with circular magazine, for example:

- Revolver position U
- Tailstock V

Programming example

Program code	Comment
N10 G1 X100 Y20 Z30 A40 F300	; Path axis movements
N20 POS[U]=10POS[X]=20 FA[U]=200 FA[X]=350	; Positioning axis movements.
N30 G1 X500 Y80 POS[U]=150FA[U]=300 F550	; Path and positioning axis.
N40 G74 X1=0 Z1=0	; Approach reference point.

2.15.1.4 Main spindle, master spindle

The machine kinematics determine, which spindle is the main spindle. This spindle is usually declared as the master spindle in the machine data.

This assignment can be changed with the `SETMS (<spindle number>)` program command. `SETMS` can be used without specifying a spindle number to switch back to the master spindle defined in the machine data.

Special functions such as thread cutting are supported by the master spindle.

Spindle identifier

S or S0

2.15.1.5 Machine axes

Machine axes are the axes physically existing on a machine.

The programmed motion of a path or additional axis can act on several machine axes due to transformation (`TRANSMIT`, `TRACYL` or `TRAORI`) active in the channel.

Machine axes are only directly addressed in the program in special circumstances (e.g. for reference point or fixed point approach).

Axis identifier

The name/identifier of a machine axis can be defined using the following NC-specific machine data:

`MD10000 $MN_AXCONF_MACHAX_NAME_TAB` (machine axis name)

Default setting: X1, Y1, Z1, A1, B1, C1, U1, V1

Further, machine axes have fixed axis identifiers, which can always be used, independent of the names set in the machine data:

AX1, AX2, ..., AX<n>

2.15.1.6 Channel axes

All geometry, special and machine axes, which are assigned to a channel, are called channel axes.

Axis identifier

The channel-specific name/identifier of a geometry and special axis can be defined using the following machine data:

MD20080 \$MC_AXCONF_CHANAX_NAME_TAB (channel axis name)

Default setting: X, Y, Z, A, B, C, U, V

The assignment regarding on which machine axis a geometry or special axis is emulated in the channel, is defined in the following machine data:

MD20070 \$MC_AXCONF_MACHAX_USED (machine axes used)

2.15.1.7 Path axes

Path axes define the path and therefore the movement of the tool in space.

The programmed feed is active for this path. The axes involved in this path reach their position at the same time. As a rule, these are the geometry axes.

However, default settings define, which axes are the path axes, and therefore determine the velocity.

Path axes can be specified in the NC program with `FGROUP`.

For more information about `FGROUP`, see "Feedrate (G93, G94, G95, F, FGROUP, FL, FGREF) (Page 107)".

2.15.1.8 Positioning axes

Positioning axes are interpolated separately; in other words, each positioning axis has its own axis interpolator and its own feedrate. Positioning axes do not interpolate with the path axes.

Positioning axes are traversed by the NC program or the PLC. If an axis is to be traversed simultaneously by the NC program and the PLC, an error message appears.

Typical positioning axes are:

- Loaders for moving workpieces to the machine
- Loaders for moving workpieces away from the machine
- Tool magazine/turret

Types

A distinction is made between positioning axes with synchronization at the block end or over several blocks.

POS axes

Block change occurs at the end of the block when all the path and positioning axes programmed in this block have reached their programmed end point.

POSA axes

The movement of these positioning axes can extend over several blocks.

POSP axes

The movement of these positioning axes for approaching the end position takes place in sections.

Note

Positioning axes become synchronized axes if they are traversed without the special POS/POSA identifier.

Continuous-path mode (G64) for path axes is only possible if the positioning axes (POS) reach their final position before the path axes.

Path axes programmed with POS/POSA are removed from the path axis grouping for the duration of this block.

For more information about POS, POSA, and POSP, see "Traverse positioning axes (POS, POSA, POSP, FA, WAITP, WAITMC) (Page 115)".

2.15.1.9 Synchronized axes

Synchronized axes traverse synchronously to the path from the start position to the programmed end position.

The feedrate programmed in F applies to all the path axes programmed in the block, but does not apply to synchronized axes. Synchronized axes take the same time as the path axes to traverse.

A synchronized axis can be a rotary axis, which is traversed synchronously to the path interpolation.

2.15.1.10 Command axes

Command axes are started from synchronized actions in response to an event (command). They can be positioned, started, and stopped fully asynchronous to the parts program. An axis cannot be moved from the part program and from synchronized actions simultaneously.

Command axes are interpolated separately; in other words, each command axis has its own axis interpolator and its own feedrate.

References:


Function Manual, Synchronized Actions

2.15.1.11 PLC axes

PLC axes are traversed by the PLC via special function blocks in the basic program; their movements can be asynchronous to all other axes. Traversing movements take place independently of path and synchronized movements.

2.15.2 From travel command to machine movement

The relationship between the programmed axis movements (travel commands) and the resulting machine movements is illustrated in the following figure:




2.15.3 Path calculation

The path calculation determines the distance to be traversed in a block, taking into account all offsets and compensations.

In general:

Path =
 setpoint - actual value + zero offset (ZO) + tool offset (TO)




If a new zero offset and a new tool offset are programmed in a new program block, the following applies:

- With absolute dimensioning:

$$\text{Path} = (\text{absolute dimension P2} - \text{absolute dimension P1}) + (\text{WO P2} - \text{WO P1}) + (\text{TO P2} - \text{TO P1}).$$
- With incremental dimensioning:

$$\text{Path} = \text{incremental dimension} + (\text{WO P2} - \text{WO P1}) + (\text{TO P2} - \text{TO P1}).$$



2.15.4 Addresses

Fixed addresses

These addresses are permanently set, that is the address characters cannot be changed.

A list can be found in Table "Fixed addresses (Page 1275)".

Settable addresses

The machine manufacturer may assign another name to these addresses via machine data.

Note

Settable addresses must be unique within the control, i.e. the same address name must not be used for different address types (axis values and end points, tool orientation, interpolation parameters, etc.).

A list can be found in Table "Settable addresses (Page 1279)".

Modal/non-modal addresses

Modal addresses remain valid with the programmed value (in all subsequent blocks) until a new value is programmed at the same address.

Non-modal addresses only apply in the block, in which they were programmed.

Example:

Program code	Comment
N10 G01 F500 X10	
N20 X10	; Feedrate F from N10 remains active until a new feedrate is entered.

Addresses with axial extension

In addresses with axial extension, an axis name is inserted in square brackets after the address. The axis name assigns the axis.

Example:

Program code	Comment
FA[U]=400	; Axis-specific feedrate for U axis.

See also Table "Fixed addresses (Page 1275)".

Extended address notation

Extended address notation enables a larger number of axes and spindles to be organized in a system.

An extended address consists of a numeric extension and an arithmetic expression assigned with an "=" character. The numeric extension has one or two digits and is always positive.

The extended address notation is only permitted for the following direct addresses:

Address	Meaning
X, Y, Z, ...	Axis addresses

I, J, K	Interpolation parameters
S	Spindle speed
SPOS, SPOSA	Spindle position
M	Special functions
H	Auxiliary functions
T	Tool number
F	Feedrate

Examples:

Program code	Comment
X7	; No "=" required, 7 is a value, but the "=" character can also be used here
X4=20	; Axis X4; "=" is required
CR=7.3	; Two letters; "=" are required
S1=470	; Speed for 1st spindle: 470 rpm
M3=5	; Spindle stop for 3rd spindle

The numeric extension can be replaced by a variable for addresses M, H, S and for SPOS and SPOSA. The variable identifier is enclosed in square brackets.

Examples:

Program code	Comment
S[SPINU]=470	; Speed for the spindle whose number is stored in the SPINU variable.
M[SPINU]=3	; Clockwise rotation for the spindle whose number is stored in the SPINU variable.
T[SPINU]=7	; Selection of the tool for the spindle whose number is stored in the SPINU variable.

2.15.5 Names

The commands according to DIN 66025 are supplemented with named objects, etc. by the NC high-level language.

Examples of named objects:

- System variables
- User-defined variables
- Axes/spindles
- Subprograms
- Keywords
- Jump markers
- Macros

Note

Identifiers must be unique. It is **not** permissible to use the same identifier for different objects.

Naming rules

A name can be chosen freely providing the following rules are observed:

- Permissible characters:
 - Letters: A ... Z, a ... z
 - Numbers: 0 ... 9
 - Underscore: _
- The first two characters should be letters or underscores.
- Maximum length:
 - Program names (Page 44): 24 characters
 - Axis names: 8 characters
 - Variable names: 31 characters

Note

Reserved keywords must not be used as identifiers.

Cycles

To prevent name conflicts, we recommend that the following specification for the assignment of names for user cycles is observed:

Character string	Reserved for names for
<ul style="list-style-type: none">• CYCLE• CUST_• GROUP_• _• S_• E_• F_	SIEMENS cycles
<ul style="list-style-type: none">• CCS_	SIEMENS compile cycles
<ul style="list-style-type: none">• CC_	User compile cycles

User cycles

We recommend that the names of user cycles begin with U_.

Variables

A detailed description of the name assignment for variables appears in:

Programming Manual Job Planning

- **System variables**
"Flexible NC programming" > "Variables" > "System variable" section
- **User variables**
"Flexible NC programming" > "Variables" > "Definition of user variables (DEF)" section

2.15.6 Constants

Constant (general)

A constant is a data element whose value does not change during the execution of a program, e.g. a value assignment to an address.

Decimal constant

The numeric value of a decimal constant is displayed in the decimal system.

INTEGER constant

An INTEGER constant is an integer value, i.e. a sequence of digits without decimal point, with or without sign.

Examples:

X10	Assignment of the value +10 to address X
X-35	Assignment of the value -35 to address X
X0	Assignment of the value 0 to address X Note: X0 cannot be replaced by X.

REAL constant

A REAL constant is a sequence of digits with decimal point, with or without sign and with or without exponent.

Examples:

X10.25	Assignment of the value +10.25 to address X
X-10.25	Assignment of the value -10.25 to address X
X0.25	Assignment of the value +0.25 to address X
X.25	Assignment of the value +0.25 to address X without leading "0"
X=-.1EX-3	Assignment of the value $-0.1 \cdot 10^{-3}$ to address X

Note

If, in an address, which permits decimal point input, more decimal places are specified than actually provided for the address, then they are rounded to fit the number of places provided.

Hexadecimal constant

Constants can also be interpreted as hexadecimal format, i.e. based on 16. The letters A to F are hexadecimal digits with the decimal values 10 to 15.

Hexadecimal constants are enclosed in single quotation marks and start with the letter "H", followed by the value in hexadecimal notation. Separators are permitted between the letters and digits.

Example:

Program code	Comment
<code>\$MC_TOOL_MANAGEMENT_MASK='H7F'</code>	<code>; By assigning the hexadecimal constant, bits 0 to 7 are set in the machine data.</code>

Note

The maximum number of characters is limited by the value range of the integer data type.

Binary constant

Constants can also be interpreted in binary format. In this case, only the digits "0" and "1" are used.

Binary constants are enclosed in single quotation marks and start with the letter "B", followed by the binary value. Separators are permitted between the digits.

Example:

Program code	Comment
<code>\$MN_AUXFU_GROUP_SPEC='B10000001'</code>	<code>; By assigning the binary constant, bit 0 and bit 7 are set in the machine data.</code>

Note

The maximum number of characters is limited by the value range of the integer data type.

2.15.7 Operators and arithmetic functions

Operators

Arithmetic operators

System variables of the REAL and INT type can be linked by the following operators:

Operator	Meaning
+	Addition
-	Subtraction
*	Multiplication
/	<ul style="list-style-type: none"> Division in synchronized actions: INT / INT ⇒ INT Division in synchronized actions with REAL result by using the function ITOR(): ITOR(INT) / ITOR(INT) ⇒ REAL Division in NC programs: INT / INT ⇒ REAL
DIV	Integer division: INT / INT ⇒ INT
MOD	Modulo division (only for type INT) supplies remainder of an INT division Example: 3 MOD 4 = 3

Note

Only variables of the same type may be linked by these operations.

Relational operators

Operator	Meaning
==	Equal to
>	Not equal to
<	Less than
>	Greater than
<=	Less than or equal to
>=	Greater than or equal to

Boolean operators

Operator	Meaning
NOT	NOT
AND	AND
OR	OR
XOR	Exclusive OR

Bit logic operators

Operator	Meaning
B_OR	Bit-by-bit OR
B_AND	Bit-by-bit AND
B_XOR	Bit-by-bit exclusive OR
B_NOT	Bit-by-bit negation

Priority of the operators

The operators have the following priorities for execution in the synchronized action (highest priority: 1):

Prio.	Operators	Meaning
1	NOT, B_NOT	Negation, bit-by-bit negation
2	*, /, DIV, MOD	Multiplication, division
3	+, -	Addition, subtraction
4	B_AND	Bit-by-bit AND
5	B_XOR	Bit-by-bit exclusive OR
6	B_OR	Bit-by-bit OR
7	AND	AND
8	XOR	Exclusive OR
9	OR	OR
10	<<	Concatenation of strings, result type STRING
11	==, <>, <, >, >=, <=	Relational operators

Note

It is strongly recommended that the individual operators are clearly prioritized by setting parentheses "(...)" when several operators are used in an expression.

Example of a condition with an expression with several operators:

```

Program code
... WHEN ($AA_IM[X] > VALUE) AND ($AA_IM[Y] > VALUE1) DO ...
    
```

Arithmetic functions

Operator	Meaning
SIN()	Sine
COS()	Cosine
TAN()	Tangent
ASIN()	Arc sine
ACOS()	Arc cosine
ATAN2()	Arc tangent 2
SQRT()	Square root

Operator	Meaning
ABS()	Absolute value
POT()	2nd power (square)
TRUNC()	Integer component The accuracy for comparison commands can be set using TRUNC
ROUND()	Round to an integer
LN()	Natural logarithm
EXP()	Exponential function

A detailed description of the functions can be found in:

References

Programming Manual, Job Planning; Section "Flexible NC programming" ff.

Indexing

The index of a system variable of type "Array of ..." can in turn be a system variable. The index is also evaluated in the main run in the interpolator clock cycle.

Example

Program code

```
... WHEN ... DO $AC_PARAM[$AC_MARKER[1]]=3
```

Restrictions

- It is not permissible to nest indices with further system variables.
- The index must not be formed via preprocessing variables. The following example is therefore **not** permitted since \$P_EP is a preprocessing variable:
\$AC_PARAM[1] = \$P_EP[\$AC_MARKER[0]]

Work preparation

3.1 Flexible NC programming

3.1.1 Variables

The use of variables from the system data and user data areas, especially in conjunction with arithmetic functions and check structures, enables highly flexible NC programs and cycles to be written.

WARNING

Material damage and personal injuries caused by changed variables

When using variables in the NC program it must be taken into account that machine operators or unauthorized persons with corresponding access rights can change the variables and thus affect the program run. This can result in material damage and personal injuries.

- In order to avoid negative effects on the program run caused by changed variables, appropriate data checks ("input validation") are to be provided in the NC program.
-
- **System data**
 The system data contains the variables predefined in the system. These variables have a defined meaning. They are primarily used by the system software. The user can read and write these variables in NC programs and cycles. Example: Machine data, setting data, system variables.
 Although the meaning of a system data item is fixed, the user can modify its properties within certain limits by redefinition.
 See "Redefinition of system data, user data, and NC commands (REDEF) (Page 392)"
 - **User data**
 The user data contains those variables defined by the user with meanings defined exclusively by the user. They are not evaluated by the system.
 The user data is divided into:
 - **Predefined user variables**
 Predefined user variables are variables that have already been defined in the system and whose number is parameterized in the machine data. The user can change the properties of these variables.
 See "Redefinition of system data, user data, and NC commands (REDEF) (Page 392)".
 - **User-defined variables**
 User-defined variables are variables that are defined by the user and are not created by the system until runtime. Their number, data type, visibility, and all other properties are defined exclusively by the user.
 See "Definition of user variables (DEF) (Page 387)"

3.1.1.1 System data

The system data contain the variables that are predefined in the system and enable access to the current parameter settings of the control, as well as to machine, control, and process states, in NC programs and cycles.

Preprocessing variables

Preprocessing variables are system data that are read and written during preprocessing, in other words, at the instant at which the block containing the variable is interpreted. Preprocessing variables do not trigger preprocessing stops.

Main run variables

Main run variables are system data that are read and written during the main run, in other words, at the instant at which the block containing the variable is executed. The following are main run variables:

- Variables that can be programmed in synchronized actions (read/write)
- Variables that can be programmed in the NC program and trigger preprocessing stops (read/write)
- Variables that can be programmed in the NC program and whose value is calculated during preprocessing but not written until the main run (main run synchronized: write only)

Prefix system

To distinguish system data from other data, their names are usually preceded by a prefix comprising the \$ sign followed by one or two letters and an underscore.

\$ + 1. Letter	Meaning: Data type
Preprocessing data (system data that are read/written during preprocessing)	
\$M	Machine data ¹⁾
\$S	Setting data, protection areas ¹⁾
\$T	Tool management data
\$P	Programmed values
\$C	Cycle variables of ISO envelope cycles
\$O	Option data
R	R-parameters (arithmetic parameters) ²⁾
Main run data (system data that are read/written during the main run)	
\$\$M	Machine data ¹⁾
\$\$\$	Setting data ¹⁾
\$A	Current main run data
\$V	Position controller data

\$ + 1. Letter	Meaning: Data type
\$R	R-parameters (arithmetic parameters) ²⁾
<p>¹⁾ Whether machine and setting data is treated as preprocessing or main run variables depends on whether they are written with one or two \$ characters. The notation is freely selectable for the specific application.</p> <p>²⁾ When an R-parameter is used in the part program/cycle as a preprocessing variable, the prefix is omitted, e.g. R10. When it is used in a synchronized action as a main run variable, a \$ sign is written as a prefix, e.g. \$R10.</p>	

2nd letter	Meaning: Visibility
N	NC global variable (NC)
C	Channel-specific variable (Channel)
A	Axis-specific variable (Axis)

Supplementary conditions

Exceptions in the prefix system

The following system of variables deviate from the prefix system specified above:

- \$TC_...: Here, the 2nd letter C does not refer to channel-specific system variables but to toolholder-specific system variables (TC= tool carrier).
- \$P_ ...: Channel-specific system variables

Use of machine and setting data in synchronized actions

When machine and setting data is used in synchronized actions, the prefix can be used to define whether the machine or setting data will be read/written synchronous to the preprocessing run or the main run.

If the data remains unchanged during machining, it can be read synchronous to the preprocessing run. For this purpose, the machine or setting data prefix is written with a \$ sign:

```
ID=1 WHENEVER $AA_IM[z] < $SA_OSCILL_REVERSE_POS2[Z]-6 DO $AA_OVR[X]=0
```

If the data changes during machining, it must be read/written synchronous to the main run. For this purpose, the machine or setting data prefix is written with two \$ signs:

```
ID=1 WHENEVER $AA_IM[z] < $$SA_OSCILL_REVERSE_POS2[Z]-6 DO $AA_OVR[X]=0
```

Note

Writing machine and setting data

When writing an item of machine or setting data, it is important to ensure that the access level which is active when the part program/cycle is executed permits write access and that the data is set to take "IMMEDIATE" effect.

References

A complete overview of all system variables appears in:

List Manual, System Variables

See also

Variables (Page 381)

3.1.1.2 Predefined user variables: Channel-specific arithmetic parameters (R)

Channel-specific arithmetic parameters or R parameters are predefined user variables with the designation R, defined as an array of the REAL data type. For historical reasons, notation both with array index, e.g. R[10], and without array index, e.g. R10, is permitted for R parameters.

When using synchronized actions, the \$ sign must be included as a prefix, e.g. \$R10.

Syntax

When used as a preprocessing variable:

R<n>
R[<expression>]

When used as a main run variable:

\$R<n>
\$R[<expression>]

Meaning

R:	Identifier when used as a preprocessing variable, e.g. in the part program	
\$R:	Identifier when used as a main run variable, e.g. in synchronized actions	
	Type:	REAL
	Range of values:	For a non-exponential notation: ± (0.000 0001 ... 9999 9999) Note: A maximum of 8 decimal places are permitted
		For an exponential notation: ± (1*10 ⁻³⁰⁰ ... 1*10 ⁺³⁰⁰) Note: • Notation: <Mantissa>EX<Exponent> e.g. 8.2EX-3 • A maximum of 10 characters are permitted including sign and decimal point.

<n>:	Number of the R parameter	
	Type:	INT
	Range of values:	0 - MAX_INDEX Note MAX_INDEX is calculated from the parameterized number of R-parameters: MAX_INDEX = (MD28050 \$MN_MM_NUM_R_PARAM) - 1
<expression>:	Array index Any expression can be used as an array index, as long as the result of the expression can be converted to the INT data type (INT, REAL, BOOL, CHAR).	

Example

Assignments to R-parameters and use of R-parameters in mathematical functions:

Program code	Comment
R0=3.5678	; Assignment in preprocessing
R[1]=-37.3	; Assignment in preprocessing
R3=-7	; Assignment in preprocessing
\$R4=-0.1EX-5	; Assignment in the main program run: R4 = -0.1 * 10 ⁻⁵
\$R[6]=1.874EX8	; Assignment in the main program run: R6 = 1.874 * 10 ⁸
R7=SIN(25.3)	; Assignment in preprocessing
R[R2]=R10	; Indirect addressing using R-parameter
R[(R1+R2)*R3]=5	; Indirect addressing using math. expression
X=(R1+R2)	; Traverse axis X to the position resulting from the sum of R1 and R2
Z=SQRT(R1*R1+R2*R2)	; Traverse axis Z to the square root position (R1 ² + R2 ²)

See also

Variables (Page 381)

3.1.1.3 Predefined user variables: Global arithmetic parameters (RG)

Function

In addition to the channel-specific R parameters, the user has access to global R parameters. They exist once within the control unit and can be read and written from all channels.

Global R parameters are used, for example, to transfer information from one channel to the next. Another example concerns global settings that should be evaluated for all channels, such as the overhang of the raw part from the spindle.

3.1 Flexible NC programming

The global R parameters are read and written from the user interface or in the NC program during the preprocessing. Synchronous actions and technology cycles cannot be used.

Note

No synchronization between the channels when reading and writing global R parameters.

Because the reading and writing is performed during the preprocessing, the point in time when a written value from one channel becomes active in another channel is not defined.

Example:

In channel 1, a loop runs with a global R parameter as loop counter. Channel 2 writes a value to this global R parameter; this causes a loop abort in channel 1. All loops that can be interpreted in the preprocessing in channel 1 are however still executed. The number of loops is not defined and depends on the channel loading, etc.

The user must implement a synchronization between the channels as application, e.g. with WAIT flags!

Syntax

Writing in the NC program

```
RG[<n>]=<value>
RG[<expression>]=<value>
```

Reading in the NC program

```
R...=RG[<n>]
R...=RG[<expression>]
```

Meaning

RG :	Default name of the NC address for global R parameters Note: The name of the NC address can be set via MD15800 \$MN_R_PARM_NCK_NAME	
<n>:	Number of the global R parameter	
	Type:	INT
	Range of values:	0 ... MAX_INDEX Note MAX_INDEX is calculated from the parameterized number of global R parameters: MAX_INDEX = (MD18156 \$MN_MM_NUM_R_PARM_NCK) - 1
<expression>:	Any expression can be used as an array index, as long as the result of the expression can be converted to the INT data type (INT, REAL, BOOL, CHAR).	

<value>:	Value of the global R parameter	
	Type:	REAL
	Range of values:	<p>For a non-exponential notation: $\pm (0.000\ 0001 \dots 9999\ 9999)$</p> <p>Note: A maximum of eight decimal places are permitted</p> <p>For an exponential notation: $\pm (1*10^{-300} \dots 1*10^{+300})$</p> <p>Note:</p> <ul style="list-style-type: none"> • Notation: <mantissa>EX<exponent> e.g. 8.2EX-3 • A maximum of ten characters are permitted including sign and decimal point.

3.1.1.4 Definition of user variables (DEF)

With the `DEF` command, you can define user-specific variables, or user variables (user data), and assign values to them.

According to the range of validity (in other words, the range in which the variable is visible) there are the following categories of user variable:

- **Local user variables (LUD)**
Local user variables (LUD) are variables defined in an NC program that is not the main program at the time of execution. They are created when the NC program is called, and deleted with an end of program reset – or the next time that the control system powers up. Local user variables can only be accessed within the NC program in which they are defined.
- **Program-global user variables (PUD)**
Program-global user variables (PUD) are user variables defined in an NC program used as the main program. They are created when the NC program is called, and deleted with an end of program reset – or the next time that the control system powers up. It is possible to access PUD in the main program and in all subprograms of the main program.

Note

Availability of program-global user variables (PUD)

Program-global user variables (PUD) defined in the main program are only available in subprograms if the following machine data is set:

MD11120 \$MN_LUD_EXTENDED_SCOPE = 1

If MD11120 = 0 the program-global user variables defined in the main program will only be available in the main program.

- **Global user variables (GUD)**
Global user variables (GUD) are NC or channel-global variables which are defined in a data block (SGUD, MGUD, UGUD, GUD4 to GUD9) and are kept even after an end of program reset or the next time that the control system powers up. GUD can be accessed in all NC programs.

3.1 Flexible NC programming

User variables must be defined before they can be used (read/write). The following rules must be observed in this context:

- GUDs must be defined in a definition file, e.g. `_N_DEF_DIR/_N_UGUD_DEF`.
- PUDs and LUDs must be defined in the definition section of the NC program.
- The data must be defined in a dedicated block.
- Only one data type may be used for each data definition.
- Several variables of the same data type can be defined for each data definition.

Syntax

LUD and PUD

```
DEF <type> <phys_unit> <limit values> <name>[<value_1>, <value_2>, <value_3>]=<init_value>
```

GUD

```
DEF <range> <pp_stop> <access_rights> <data class> <type> <phys_unit> <limit values> <name>[<value_1>, <value_2>, <value_3>]=<init_value>
```

Meaning

DEF:	Command for defining GUD, PUD, LUD user variables	
<range>:	Range of validity, only relevant for GUD:	
	NC:	NC-global user variable
	CHAN:	Channel-global user variable
<PP_stop>:	Preprocessing stop, only relevant for GUD (optional)	
	SYNR:	Preprocessing stop when reading
	SYNW:	Preprocessing stop when writing
	SYNRW:	Preprocessing stop when reading/writing
<access rights>:	Protection level for reading/writing GUD via NC program or OPI (optional)	
	APRP <protection level>:	Read: NC program
	APWP <protection level>:	Write: NC program
	APRB <protection level>:	Read: OPI
	APWB <protection level>:	Write: OPI
	<protection level>:	Range of values: 0 ... 7
	See "Attribute: Access rights (APR, APW, APRP, APWP, APRB, APWB) (Page 402)"	
<data class>:	Data class assignment (only SINUMERIK 828D)	
	DCM:	Data class M (= Manufacturer)
	DCI:	Data class I (= Individual)
	DCU:	Data class U (= User)

<type>:	Data type:	
	INT:	Integer with sign
	REAL:	Real number (LONG REAL to IEEE)
	BOOL:	Truth value TRUE (1)/FALSE (0)
	CHAR:	ASCII character
	STRING[<MaxLength>]:	Character string of a defined length
	AXIS:	Axis/spindle identifier
	FRAME:	Geometric data for a static coordinate transformation
See "Data types (Page 413)"		
<phys_unit>:	Physical unit (optional)	
	PHU <unit>:	Physical unit
	See "Attribute: Physical unit (PHU) (Page 400)"	
<limit values>:	Lower/upper limit value (optional)	
	LLI <limit value>:	Lower limit value (lower limit)
	ULI <limit value>:	Upper limit value (upper limit)
	See "Attribute: Limit values (LLI, ULI) (Page 398)"	
<name>:	Name of variable Note <ul style="list-style-type: none">• Maximum 31 characters• The first two characters must be a letter and/or an underscore.• The \$ sign is reserved for system variables and must not be used.	
[<value_1>, <value_2>, <value_3>]:	Specification of array sizes for 1- to max. 3-dimensional array variables (optional) For the Initialization of array variables, see "Definition and initialization of array variables (DEF, SET, REP) (Page 407)"	
<init_value>:	Initialization value (optional) See "Attribute: Initialization value (Page 396)" For the Initialization of array variables, see "Definition and initialization of array variables (DEF, SET, REP) (Page 407)"	

Examples

Example 1: Definition of user variables in the data block for machine manufacturers

Program code	Comment
%_N_MGUD_DEF	; GUD block: Machine manufacturer
\$PATH=/_N_DEF_DIR	
DEF CHAN REAL PHU 24 LLI 0 ULI 10 STROM_1, STROM_2	
;Description	
;Definition of two GUD items: STROM_1, STROM_2	
;Range of validity: Throughout the channel	
;Data type: REAL	

3.1 Flexible NC programming

Program code	Comment
PP stop: Not programmed => default value = no PP stop ; phys. unit: 24 = [A] ;Limit values: Low = 0.0, high = 10.0 ;Access rights: Not programmed => default value = 7 = key-operated switch position 0 ;Initialization value: Not programmed => default value = 0.0	
DEF NCK REAL PHU 13 LLI 10 APWP 3 APRP 3 APWB 0 APRB 2 ZEIT_1=12, ZEIT_2=45 ;Description ;Definition of two GUD items: ZEIT_1, ZEIT_2 ;Range of validity: Throughout NC ;Data type: REAL	
PP stop: Not programmed => default value = no PP stop ; phys. unit: 13 = [s] ;Limit values: low = 10.0, high = not programmed => upper definition range limit ;Access rights: ; NC program: Write/read = 3 = end user ;OPI: Write = 0 = Siemens, read = 3 = end user ;Initialization value: ZEIT_1 = 12.0, ZEIT_2 = 45.0	
DEF NCK APWP 3 APRP 3 APWB 0 APRB 3 STRING[5] GUD5_NAME = "COUNTER" ;Description ;Definition of one GUD item: GUD5_NAME ;Range of validity: Throughout NC ;Data type: STRING, max. 5 characters	
PP stop: Not programmed => default value = no PP stop ; phys. unit: Not programmed => default value = 0 = no phys. unit ;Limit values: Not programmed => definition range limits: Low = 0, high = 255 ;Access rights: ; NC program: Write/read = 3 = end user ;OPI: Write = 0 = Siemens, read = 3 = end user ;Initialization value: "COUNTER"	
M30	

Example 2: Global program and local user variables (PUD/LUD)

Program code	Comment
PROC MAIN	; Main program
DEF INT VAR1	;PUD definition
...	
SUB2	;Subprogram call
...	
M30	

Program code	Comment
PROC SUB2	;Subprogram SUB2
DEF INT VAR2	;LUD DEFINITION
...	
IF (VAR1==1)	;Read PUD
VAR1=VAR1+1	;Read & write PUD
VAR2=1	;Write LUD
ENDIF	
SUB3	;Subprogram call
...	
M17	

Program code	Comment
PROC SUB3	;Subprogram SUB3
...	
IF (VAR1==1)	;Read PUD
VAR1=VAR1+1	;Read & write PUD
VAR2=1	;Error: LUD from SUB2 not known
ENDIF	
...	
M17	

Example 3: Definition and use of user variables of data type AXIS

Program code	Comment
DEF AXIS ABSCISSA	; 1st Geometry axis
DEF AXIS SPINDLE	;Spindle
...	
IF ISAXIS(1) == FALSE GOTOF CONTINUE	
ABSCISSA = \$P_AXN1	
CONTINUE:	
...	
SPINDLE=(S1)	; 1st spindle
OVRA[SPINDLE]=80	;Spindle override = 80%
SPINDLE=(S3)	; 3rd spindle

Supplementary conditions

Global user variables (GUD)

In the context of the definition of global user variables (GUD), the following machine data has to be taken into account:

No.	Identifier: \$MN_	Meaning
11140	GUD_AREA_SAVE_TAB	Additional save for GUD blocks
18118 ¹⁾	MM_NUM_GUD_MODULES	Number of GUD files in the active file system
18120 ¹⁾	MM_NUM_GUD_NAMES_NCK	Number of global GUD names
18130 ¹⁾	MM_NUM_GUD_NAMES_CHAN	Number of channel-specific GUD names
18150 ¹⁾	MM_GUD_VALUES_MEM	Memory location for global GUD values
18660 ¹⁾	MM_NUM_SYNACT_GUD_REAL	Number of configurable GUD of the REAL data type
18661 ¹⁾	MM_NUM_SYNACT_GUD_INT	Number of configurable GUD of the INT data type
18662 ¹⁾	MM_NUM_SYNACT_GUD_BOOL	Number of configurable GUD of the BOOL data type
18663 ¹⁾	MM_NUM_SYNACT_GUD_AXIS	Number of configurable GUD of the AXIS data type
18664 ¹⁾	MM_NUM_SYNACT_GUD_CHAR	Number of configurable GUD of the CHAR data type
18665 ¹⁾	MM_NUM_SYNACT_GUD_STRING	Number of configurable GUD of the STRING data type

¹⁾ For SINUMERIK 828D, MD can only be read!

Cross-channel use of an NC-global user variable of the AXIS data type

An NC-global user variable of the `AXIS` data type initialized during definition in the data block with an axis identifier can then only be used in other NC channels if the axis has the same channel axis number in these channels.

If this is not the case, the variable has to be loaded at the beginning of the NC program or, as in the following example, the `AXNAME(...)` function (see "Axis functions (AXNAME, AX, SPI, AXTOSPI, ISAXIS, AXSTRING, MODAXVAL)" (Page 834)) has to be used.

Program code	Comment
DEF NCK STRING[5] ACHSE="X"	;Definition in the data block
...	
N100 AX[AXNAME(ACHSE)]=111 G00	; Use in the NC program

3.1.1.5 Redefinition of system data, user data, and NC commands (REDEF)

The `REDEF` command changes the attributes of system data, user data, and NC commands. A fundamental condition of redefinition is that it has to post-date the corresponding definition.

Multiple attributes cannot be changed simultaneously during redefinition. A separate `REDEF` command must be programmed for each attribute to be changed.

If several concurrent attribute changes are programmed, the last change is always active.

Resetting attribute values

The attributes for access rights and initialization time change with REDEF can be reset to their default values by reprogramming REDEF, followed by the name of the variable or the NC language command:

- Access rights: Protection level 7
- Initialization time: No initialization or retention of the current value

Redefinable attributes

See "Overview of definable and redefinable attributes (Page 406)".

Local user variables (PUD/LUD)

Redefinitions are not permitted for local user variables (PUD/LUD).

Syntax

```
REDEF <name> <PP_stop>
REDEF <name> <phys_unit>
REDEF <name> <limit_values>
REDEF <name> <access_rights>
REDEF <name> <init_time>
REDEF <name> <init_time> <init_value>
REDEF <name> <data class>
REDEF <name>
```

Meaning

REDEF:	Command for redefinition of a certain attribute or to reset the "Access rights" and/or "Initialization time" attributes of system variables, user variables and NC language commands	
<name>:	Name of an already defined variable or an NC language command	
<PP stop>:	Preprocessing stop	
	SYNR:	Preprocessing stop when reading
	SYNW:	Preprocessing stop when writing
	SYNRW:	Preprocessing stop when reading/writing
<phys_unit>:	Physical unit	
	PHU <unit>:	Physical unit
	See "Attribute: Physical unit (PHU) (Page 400)". Note Cannot be redefined for: <ul style="list-style-type: none"> • System variables • Global user data (GUD) of the data types: BOOL, AXIS, STRING, FRAME 	

<limit values>:	Lower/upper limit	
	LLI <limit value>:	Lower limit value (lower limit)
	ULI <limit value>:	Upper limit value (upper limit)
	See "Attribute: Limit values (LLI, ULI) (Page 398)". Note Cannot be redefined for: <ul style="list-style-type: none"> • System variables • Global user data (GUD) of the data types: BOOL, AXIS, STRING, FRAME 	
<access rights>:	Access rights for reading/writing via part program or OPI	
	APX <protection level>:	Execute: NC language element
	APRP <protection level>:	Read: Part program
	APWP <protection level>:	Write: Part program
	APRB <protection level>:	Read: OPI
	APWB <protection level>:	Write: OPI
	<protection level>:	Range of values: 0 ... 7
See "Attribute: Access rights (APR, APW, APRP, APWP, APRB, APWB) (Page 402)".		
<init_time>:	Point in time at which the variable is reinitialized	
	INIPO:	Power On
	INIRE:	End of main program, NC reset or Power On
	INICF:	NEWCONF or main program end, NC reset or Power On
	PRLOC:	End of main program, NC reset following local change or Power On
See "Attribute: Initialization value (Page 396)".		
<init_value>:	Initialization value When redefining the initialization value, an initialization time always has to be specified also (see <init_time>). See "Attribute: Initialization value (Page 396)". For the Initialization of array variables, see "Definition and initialization of array variables (DEF, SET, REP) (Page 407)". Note Cannot be redefined for system variables, except setting data.	
<data class>:	Data class assignment (only SINUMERIK 828D)	
	DCM:	Data class M (= Manufacturer)
	DCI:	Data class I (= Individual)
	DCU:	Data class U (= User)

Example

Redefinitions of system variable \$TC_DPCx in the data block for machine manufacturers

Program code
<code>%_N_MGUD_DEF ; GUD block: Machine manufacturer</code>

Program code

```
N100 REDEF $TC_DPC1 APWB 2 APWP 3
N200 REDEF $TC_DPC2 PHU 21
N300 REDEF $TC_DPC3 LLI 0 ULI 200
N400 REDEF $TC_DPC4 INIPO (100, 101, 102, 103)
N800 REDEF $TC_DPC1
N900 REDEF $TC_DPC4
M30
```

regard- Write access: OPI = protection level 2, part program = protection level 3
ing

N100:

regard- Physical unit [%]
ing

N200:

regard- Lower limit value = 0, upper limit value = 200
ing

N300:

regard- The array variable is initialized with the four values at POWER ON.
ing

N400:

regard- Reset of the "Access rights" and/or "Initialization time" attribute values
ing

N800 /

N900

Note

Use of ACCESS files

If ACCESS files are used, the redefinition of access rights has to be relocated from _N_MGUD_DEF to _N_MACCESS_DEF.

Supplementary conditions

Granularity

A redefinition is always applied to the entire variable which is uniquely identified by its name. Array variables do not, for example, support the assignment of different attributes to individual array elements.

3.1.1.6 Attribute: Initialization value

Definition (DEF) of user variables

During definition, an initialization value can be preassigned for the following user variables:

- Global user variables (GUD)
- Program-global user variables (PUD)
- Local user variables (LUD)

Redefinition (REDEF) of system and user variables

During redefinition, an initialization value can be preassigned for the following variables:

- System data
 - Setting data
- User data
 - R parameters
 - Synchronized action variables (\$AC_MARKER, \$AC_PARAM, \$AC_TIMER)
 - Synchronized action GUD (SYG_xy[], where x=R, I, B, A, C, S and y=S, M, U, 4 to 9)
 - EPS parameters
 - Tool data OEM
 - Magazine data OEM
 - Global user variables (GUD)

Reinitialization time

During redefinition, the point in time can be specified at which the variable should be reinitialized, i.e. reset to the initialization value.

- INIPO (POWER ON)
The variable is reinitialized at Power On.
- INIRE (reset)
The variable is reinitialized on NC reset, mode group reset, at the end of the part program (M02/M30) or at Power On.
- INICF (NEWCONF)
For the function "Set machine data active", the variable is reinitialized via HMI, part program command NEWCONF or NC reset, mode group reset, part program end (M02 / M30) or a Power On.
- PRLOC (program-local change)
The variable is only reinitialized on an NC reset, mode group reset or at the end of the part program (M02/M30) if it has changed during the current part program.
The PRLOC attribute may only be changed in conjunction with programmable setting data (see the table below).

Table 3-1 Programmable setting data

Number	Identifier	G command ¹⁾
42000	\$SC_THREAD_START_ANGLE	SF
42010	\$SC_THREAD_RAMP_DISP	DITS/DITE
42400	\$SA_PUNCH_DWELLTIME	PDELAYON
42800	\$SA_SPIND_ASSIGN_TAB	SETMS
43210	\$SA_SPIND_MIN_VELO_G25	G25
43220	\$SA_SPIND_MAX_VELO_G26	G26
43230	\$SA_SPIND_MAX_VELO_LIMS	LIMS
43300	\$SA_ASSIGN_FEED_PER_REV_SOURCE	FPRAON
43420	\$SA_WORKAREA_LIMIT_PLUS	G26
43430	\$SA_WORKAREA_LIMIT_MINUS	G25
43510	\$SA_FIXED_STOP_TORQUE	FXST
43520	\$SA_FIXED_STOP_WINDOW	FXSW
43700	\$SA_OSCILL_REVERSE_POS1	OSP1
43710	\$SA_OSCILL_REVERSE_POS2	OSP2
43720	\$SA_OSCILL_DWELL_TIME1	OST1
43730	\$SA_OSCILL_DWELL_TIME2	OST2
43740	\$SA_OSCILL_VELO	FA
43750	\$SA_OSCILL_NUM_SPARK_CYCLES	OSNSC
43760	\$SA_OSCILL_END_POS	OSE
43770	\$SA_OSCILL_CTRL_MASK	OSCTRL
43780	\$SA_OSCILL_IS_ACTIVE	OS
43790	\$SA_OSCILL_START_POS	OSB
1) This G command addresses the setting data.		

Supplementary conditions

Initialization value: Global user variables (GUD)

- Only `INIPO` (Power On) can be defined as the initialization time for global user variables (GUD) with the `NC` range of validity.
- In addition to `INIPO` (Power On), `INIRE` (reset) or `INICF` (NEWCONF) can be defined as the initialization time for global user variables (GUD) with the `CHAN` range of validity.
- In the case of global user variables (GUD) with the `CHAN` range of validity and `INIRE` (reset) or `INICF` (NEWCONF) initialization time, for an NC reset, mode group reset and "Activate machine data", the variables are only reinitialized in the channels in which the named events were triggered.

Initialization value: FRAME data type

It is not permitted to specify an initialization value for variables of the `FRAME` data type. Variables of the `FRAME` data type are initialized implicitly and always with the default frame.

Initialization value: CHAR data type

For variables of the `CHAR` data type, instead of the ASCII code (0...255), the corresponding ASCII character can be programmed in quotation marks, e.g. "A".

Initialization value: Data type STRING

In the case of variables of the `STRING` data type, the character string must be enclosed in quotation marks, e.g. ...= "MACHINE_1"

Initialization value: AXIS data type

In the case of variables of the `AXIS` data type, for an extended address notation, the axis identifier must be enclosed in brackets, e.g. ...=(X3).

Initialization value: System variable

For system variables, redefinition cannot be used to define user-specific initialization values. The initialization values for the system variables are specified by the system and cannot be changed. However, redefinition can be used to change the point in time (`INIRE`, `INICF`) at which the system variable is reinitialized.

Implicit initialization value: AXIS data type

For variables of the `AXIS` data type the following implicit initialization value is used:

- System data: "First geometry axis"
- Synchronized action GUD (designation: SYG_A*), PUD, LUD:
axis designation from the machine data: MD20082
\$MC_AXCONF_CHANAX_DEFAULT_NAME

Implicit initialization value: Tool and magazine data

Initialization values for tool and magazine data can be defined using the following machine data: MD17520 \$MN_TOOL_DEFAULT_DATA_MASK

Note

Synchronization

The synchronization of events triggering the reinitialization of a global variable when this variable is read in a different location is the sole responsibility of the user / machine manufacturer.

See also

Variables (Page 381)

3.1.1.7 Attribute: Limit values (LLI, ULI)

An upper and a lower limit of the definition range can only be defined for the following data types:

- INT
- REAL
- CHAR

Definition (DEF) of user variables: Limit values and implicit initialization values

If no explicit initialization value is defined when defining a user variable of one of the above data types, the variable is set to the data type's implicit initialization value.

- INT: 0
- REAL: 0.0
- CHAR: 0

If the implicit initialization value is outside the definition range specified by the programmed limit values, the variable is initialized with the limit value which is closest to the implicit initialization value:

- Implicit initialization value < lower limit value (LLI) ⇒ initialization value = lower limit value
- Implicit initialization value > upper limit value (ULI) ⇒ initialization value = upper limit value

Examples:

Program code	Comment
DEF REAL GUD1	; Lower limit value = definition range limit ; Upper limit value = definition range limit ; No initialization value programmed ; => Implicit initialization value = 0.0
DEF REAL LLI 5.0 GUD2	; Lower limit value = 5.0 ; Upper limit value = definition range limit ; => Initialization value = 5.0
DEF REAL ULI -5 GUD3	; Lower limit value = definition range limit ; Upper limit value = -5.0 ; => Initialization value = -5.0

Redefinition (REDEF) of user variables: Limit values and current actual values

If the limit values of a user variable are redefined, they change to the extent that the current actual value is outside the new definition range, an alarm will be issued and the limit values will be rejected.

Note

Redefinition (REDEF) of user variables

If the limit values of a user variable are redefined, care must be taken to ensure that the following values are changed consistently:

- Limit values
 - Actual value
 - Initialization value on redefinition and automatic reinitialization on the basis of INIPO, INIRE or INICF
-

See also

Variables (Page 381)

3.1.1.8 Attribute: Physical unit (PHU)

A physical unit can only be specified for variables of the following data types:

- INT
- REAL

Programmable physical units (PHU)

The physical unit is specified as fixed point number: PHU <unit>

The following physical units can be programmed:

<unit>	Meaning	Physical unit
0	Not a physical unit	-
1	Linear or angular position ¹⁾²⁾	[mm], [inch], [degree]
2	Linear position ²⁾	[mm], [inch]
3	Angular position	[degree]
4	Linear or angular velocity ¹⁾²⁾	[mm/min], [inch/min], [rpm]
5	Linear velocity ²⁾	[mm/min]
6	Angular velocity	[rpm]
7	Linear or angular acceleration ¹⁾²⁾	[m/s ²], [inch/s ²], [rev/s ²]
8	Linear acceleration ²⁾	[m/s ²], [inch/s ²]
9	Angular acceleration	[rev/s ²]
10	Linear or angular jerk ¹⁾²⁾	[m/s ³], [inch/s ³], [rev/s ³]
11	Linear jerk ²⁾	[m/s ³], [inch/s ³]
12	Angular jerk	[rev/s ³]
13	Time	[s]
14	Position controller gain	[16.667/s]
15	Revolutional feedrate ²⁾	[mm/rev], [inch/rev]
16	Temperature compensation ¹⁾²⁾	[mm], [inch]
18	Force	[N]
19	Mass	[kg]
20	Moment of inertia ³⁾	[kgm ²]
21	Percent	[%]
22	Frequency	[Hz]
23	Voltage	[V]
24	Current	[A]
25	Temperature	[°C]
26	Angle	[degree]
27	KV	[1000/min]
28	Linear or angular position ³⁾	[mm], [inch], [degree]

<unit>	Meaning	Physical unit
29	Cutting rate ²⁾	[m/min], [feet/min]
30	Peripheral speed ²⁾	[m/s], [feet/s]
31	Resistance	[ohm]
32	Inductance	[mH]
33	Torque ³⁾	[Nm]
34	Torque constant ³⁾	[Nm/A]
35	Current controller gain	[V/A]
36	Speed controller gain ³⁾	[Nm/(rad*s)]
37	Speed	[rpm]
42	Power	[kW]
43	Current, low	[μ A]
46	Torque, low ³⁾	[μ Nm]
48	Per mil	-
49	-	[Hz/s]
65	Flow rate	[l/min]
66	Pressure	[bar]
67	Volume ³⁾	[cm ³]
68	Controlled-system gain ³⁾	[mm/(V*min)]
69	Force controller controlled-system gain	[N/V]
155	Thread lead ³⁾	[mm/rev], [inch/rev]
156	Change in thread lead ³⁾	[mm/rev / rev], [inch/rev / rev]
1) The physical unit depends on the axis type: Linear or rotary axis		
2) System of units changeover G70/G71(inch/metric) After changing over the basic system (MD10240 \$MN_SCALING_SYSTEM_IS_METRIC) with G70/G71, for read/write operations to system and user variables involving a length, then the values are not converted (actual value, default value and limit values) G700/G710(inch/metric) After changing over the basic system (MD10240 \$MN_SCALING_SYSTEM_IS_METRIC) with G700/G710, for read/write operations to system and user variables involving a length, then the values are converted (actual value, default value and limit values)		
3) The variable is not converted to the NC's current measuring system (inch/metric) automatically. Conversion is the sole responsibility of the user/machine manufacturer.		

Note**Level overflow due to format conversion**

The internal storage format for all user variables (GUD/PUD/LUD) with physical units of length is metric. Excessive use of these types of variable in the NCK's main run, e.g. in synchronized actions, can lead to a CPU time overflow at interpolation level when the measuring system is switched over, generating alarm 4240.

Note

Compatibility of units

When using variables (assignment, comparison, calculation, etc.) the compatibility of the units involved is not checked. Should conversion be required, this is the sole responsibility of the user / machine manufacturer.

See also

Variables (Page 381)

3.1.1.9 Attribute: Access rights (APR, APW, APRP, APWP, APRB, APWB)

Designation

The designation of the access attribute AP... comprises:

1. A: Access
2. P: Protection
3. R / W: Read / Write
4. P / O: Program / BTSS (OPI)

Access rights / access levels

The following access levels, which have to be specified during programming, correspond to the access rights:

Access right	Protection level
System password	0
Machine manufacturer password	1
Service password	2
End user password	3
Key-operated switch position 3	4
Key-operated switch position 2	5
Key-operated switch position 1	6
Key-operated switch position 0	7

Definition (DEF) of user data

Access rights (APR.../APW...) can be defined for the following data:

- Global user data (GUD)

Redefinition (REDEF) of system and user data

Access rights (APR.../APW...) can be redefined for the following data:

- System data

- Machine data

Note

Redefinition of reading rights of machine data

The protection level for reading machine data can only be set with the keyword `APR` in common for part program and OPI.

The keywords `APRP` and `APRB` are not supported by the redefinition of the reading rights, and lead to the message of interrupt 12490 "Access right APRP/APRB <protection level> was not set".

- Setting data
 - System variable
 - Process data
 - Magazine data
 - Tool data
- User data
 - R parameters
 - Synchronized action variables (`$AC_MARKER`, `$AC_PARAM`, `$AC_TIMER`)
 - Synchronized action GUD (`SYG_xy[]`, where `x=R, I, B, A, C, S` and `y=S, M, U, 4 to 9`)
 - EPS parameters
 - Tool data OEM
 - Magazine data OEM
 - Global user variables (GUD)

Note

During redefinition the access right can be freely assigned to a variable between the lowest protection level 7 and the dedicated protection level, e.g. 1 (machine manufacturer).

Redefinition (REDEF) of NC language commands

The access or execution right (APX) can be redefined for the following NC language commands:

- G commands / preparatory functions

References

Programming Manual, Fundamentals, Section: G commands / preparatory functions

- Predefined functions

References

Programming Manual, Fundamentals, Section: Predefined functions

3.1 Flexible NC programming

- Predefined subprogram calls
References
Programming Manual, Fundamentals, Section: Predefined subprogram calls
- DO operation with synchronized actions
- Cycles program identifier
The cycle must be saved in a cycle directory and must contain a PROC operation.

Access rights in relation to NC programs and cycles (APRP, APWP)

The various access rights facilitate the following with regard to access from an NC program or cycle:

- APRP 0/APWP 0
 - During NC program processing the system password has to be set.
 - The cycle has to be stored in the `_N_CST_DIR` directory (system).
 - The execution right must be set to system for the `_N_CST_DIR` directory in MD11160 `$MN_ACCESS_EXEC_CST`.
- APRP 1/APWP 1 or APRP 2/APWP 2
 - During NC program processing the machine manufacturer or service password has to be set.
 - The cycle has to be stored in the `_N_CMA_DIR` (machine manufacturer) or `_N_CST_DIR` directory.
 - The execution rights must be set to at least machine manufacturer for the `_N_CMA_DIR` or `_N_CST_DIR` directories in machine data MD11161 `$MN_ACCESS_EXEC_CMA` or MD11160 `$MN_ACCESS_EXEC_CST` respectively.
- APRP 3/APWP 3
 - During NC program execution, the end-user password must be set.
 - The cycle has to be stored in the `_N_CUS_DIR` (user), `_N_CMA_DIR` or `_N_CST_DIR` directory.
 - The execution rights must be set to at least end user for the `_N_CUS_DIR`, `_N_CMA_DIR` or `_N_CST_DIR` directories in machine data MD11162 `$MN_ACCESS_EXEC_CUS`, MD11161 `$MN_ACCESS_EXEC_CMA` or MD11160 `$MN_ACCESS_EXEC_CST` respectively.
- APRP 4...7/APWP 4...7
 - During NC program processing the key-operated switch must be set to 3 ... 0.
 - The cycle has to be stored in directory `_N_CUS_DIR`, `_N_CMA_DIR` or in directory `_N_CST_DIR`.
 - The execution rights must be set to at least the corresponding key-operated switch position for the `_N_CUS_DIR`, `_N_CMA_DIR` or `_N_CST_DIR` directories in machine data MD11162 `$MN_ACCESS_EXEC_CUS`, MD11161 `$MN_ACCESS_EXEC_CMA` or MD11160 `$MN_ACCESS_EXEC_CST` respectively.

Access rights in relation to OPI (APRB, APWB)

The access rights (APRB, APWB) restrict access to system and user variables via the OPI equally for all system components (HMI, PLC, external computers, EPS services, etc.).

Note

Local HMI access rights

When changing access rights to system data, care must be taken to ensure that such changes are consistent with the access rights defined using HMI mechanisms.

APR/APW access attributes

For compatibility reasons, attributes APR and APW are implicitly mapped to the attributes APRP / APRB and APWP / APWB:

- APR x \Rightarrow APRP x APRB x
- APW y \Rightarrow APWP y APWB y

Access rights using ACCESS files

When using ACCESS files to assign access rights, access rights for system data, user data, and NC language commands must only be redefined in ACCESS files. Global user data (GUD) is an exception. For this data, access rights still have to be redefined in the corresponding definition files *_DEF.

For continuous access protection, the machine data for the execution rights and the access protection for the corresponding directories have to be modified consistently.

In principle, the procedure is as follows:

1. Creation of the necessary definition files:
 - _N_DEF_DIR/_N_SACCESS_DEF
 - _N_DEF_DIR/_N_MACCESS_DEF
 - _N_DEF_DIR/_N_UACCESS_DEF
2. Setting of the write right for the definition files to the value required for redefinition:
 - MD11170 \$MN_ACCESS_WRITE_SACCESS = <protection level>
 - MD11171 \$MN_ACCESS_WRITE_MACCESS = <protection level>
 - MD11172 \$MN_ACCESS_WRITE_UACCESS = <protection level>

3.1 Flexible NC programming

3. For access to protected elements from cycles, the execution and write rights for cycle directories `_N_CST_DIR`, `_N_CMA_DIR`, and `_N_CST_DIR` have to be modified.

Execution rights

- MD11160 \$MN_ACCESS_EXEC_CST = <protection level>
- MD11161 \$MN_ACCESS_EXEC_CMA = <protection level>
- MD11162 \$MN_ACCESS_EXEC_CUS = <protection level>

Write rights

- MD11165 \$MN_ACCESS_WRITE_CST = <protection level>
- MD11166 \$MN_ACCESS_WRITE_CMA = <protection level>
- MD11167 MN_ACCESS_WRITE_CUS = <protection level>

The execution right has to be set to at least the same protection level as the highest protection level of the element used.

The write right must be set to at least the same protection level as the execution right.

4. The write rights of the local HMI cycle directories must be set to the same protection level as the local NC cycle directories.

References

Operating Manual

Subprogram calls in ACCESS files

To structure access protection further, subprograms (SPF or MPF identifier) can be called in ACCESS files. The subprograms inherit the execution rights of the calling ACCESS file.

Note

Only access rights can be redefined in the ACCESS files. All other attributes have to continue to be programmed/redefined in the corresponding definition files.

See also

Variables (Page 381)

3.1.1.10 Overview of definable and redefinable attributes

The following tables show which attributes can be defined (DEF) and/or redefined (REDEF) for which data types.

System data

Data type	Init. value	Limit values	Physical unit	Access rights	Data class (only 828D)
Machine data	---	---	---	REDEF	REDEF
Setting data	REDEF	---	---	REDEF	---
FRAME data	---	---	---	REDEF	---
Process data	---	---	---	REDEF	---

Data type	Init. value	Limit values	Physical unit	Access rights	Data class (only 828D)
Leadscrew error comp. (EEC)	---	---	---	REDEF	---
Sag compensation (CEC)	---	---	---	REDEF	---
Quadrant error compensation (QEC)	---	---	---	REDEF	---
Magazine data	---	---	---	REDEF	---
Tool data	---	---	---	REDEF	---
Protection areas	---	---	---	REDEF	---
Toolholder, with orientation capability	---	---	---	REDEF	---
Kinematic chains	---	---	---	REDEF	---
3D protection areas	---	---	---	REDEF	---
Working area limitation	---	---	---	REDEF	---

User data

Data type	Init. value	Limit values	Physical unit	Access rights	Data class
R-parameters	REDEF	REDEF	REDEF	REDEF	---
Synchronized action variable (\$AC_...)	REDEF	REDEF	REDEF	REDEF	---
Synchronized action GUD (SYG_...)	REDEF	REDEF	REDEF	REDEF	---
EPS parameters	REDEF	REDEF	REDEF	REDEF	---
Tool data OEM	REDEF	REDEF	REDEF	REDEF	---
Magazine data OEM	REDEF	REDEF	REDEF	REDEF	---
Global user variables (GUD)	DEF/REDEF	DEF	DEF	DEF/REDEF	DEF/REDEF
Local user variables (PUD/LUD)	DEF	DEF	DEF	---	---

See also

Variables (Page 381)

3.1.1.11 Definition and initialization of array variables (DEF, SET, REP)

A user variable can be defined as a 1- up to a maximum of a 3-dimensional array.

- 1-dimensional: DEF <data type> <variable name>[<n>]
- 2-dimensional: DEF <data type> <variable name>[<n>, <m>]
- 3-dimensional: DEF <data type> <variable name>[<n>, <m>, <o>]

Note

STRING data type user variables can be defined as up to a maximum of 2-dimensional arrays.

Data types

User variables can be defined as arrays for the following data types: BOOL, CHAR, INT, REAL, STRING, AXIS, FRAME

Assignment of values to array elements

Values can be assigned to array elements at the following points in time:

- During array definition (initialization values)
- During program execution

Values can be assigned by means of:

- Explicit specification of an array element
- Explicit specification of an array element as a starting element and specification of a value list (**SET**)
- Explicit specification of an array element as a starting element and specification of a value and the frequency at which it is repeated (**REP**)

Note

FRAME data type user variables cannot be assigned initialization values.

Syntax (**DEF**)

```
DEF <data type> <variable name>[<n>,<m>,<o>]
DEF  STRING[<string length>] <variable name>[<n>,<m>]
```

Syntax (**DEF...=SET...**)

Using a value list:

- During definition:
DEF <data type> <variable name>[<n>,<m>,<o>]=SET(<value1>,<value2>, etc.)

Equivalent to:

```
DEF <data type> <variable name>[<n>,<m>,<o>]=(<value1>,<value2>,  
etc.)
```

Note

SET does not have to be specified for initialization via a value list.

- During value assignment:
<variable name>[<n>,<m>,<o>]=SET(<VALUE1>,<value2>, etc.)

Syntax (DEF...=REP...)

Using a value with repetition

- During definition:
 DEF <data type> <variable name>[<n>,<m>,<o>]=REP(<value>)
 DEF <data type> <variable name>[<n>,<m>,<o>]=REP(<value>,
 <number_array_elements>)
- During value assignment:
 <variable name>[<n>,<m>,<o>]=REP(<value>)
 DEF <data type> <variable name>[<n>,<m>,<o>]=REP(<value>,<number_array_elements>)

Meaning

DEF:	Command to define variables	
<data type>:	Data type of variables	
	Range of values: <ul style="list-style-type: none"> • for system variables: BOOL, CHAR, INT, REAL, STRING, AXIS • for GUD or LUD variables: BOOL, CHAR, INT, REAL, STRING, AXIS, FRAME 	
<string length>:	Maximum number of characters for a STRING data type	
<variable name>:	Variable name.	
[<n>,<m>,<o>]:	Array sizes or array indices	
<n>:	Array size or array index for 1st dimension	
	Type:	INT (for system variables, also AXIS)
	Range of values:	Max. array size: 65535 Array index: $0 \leq n \leq 65534$
<m>:	Array size or array index for 2nd dimension	
	Type:	INT (for system variables, also AXIS)
	Range of values:	Max. array size: 65535 Array index: $0 \leq m \leq 65534$
<o>:	Array size or array index for 3rd dimension	
	Type:	INT (for system variables, also AXIS)
	Range of values:	Max. array size: 65535 Array index: $0 \leq o \leq 65534$
SET:	Value assignment using specified value list	
(<value1>,<value2>, etc.):	Value list	
REP:	Value assignment using specified <value>	

<value>:	Value, which the array elements should be written when initializing with REP.
<number_array_elements>:	<p>Number of array elements to be written with the specified <value>. The following apply to the remaining array elements, dependent on the point in time:</p> <ul style="list-style-type: none"> • Initialization when defining the array: → Zero is written to the remaining array elements. • Assignment during program execution: → The actual values of the array elements remain unchanged. <p>If the parameter is not programmed, all array elements are written with <value>.</p> <p>If the parameter equals zero, the following apply dependent on the point in time:</p> <ul style="list-style-type: none"> • Initialization when defining the array: → All elements are pre-assigned zero • Assignment during program execution: → The actual values of the array elements remain unchanged.

Array index

The implicit sequence of the array elements, e.g. in the case of value assignment using SET or REP, is right to left due to iteration of the array index.

Example: Initialization of a 3-dimensional array with 24 array elements:

```

DEF INT FELD[2,3,4] = REP(1,24)
  FELD[0,0,0] = 1      1. array element
  FELD[0,0,1] = 1      2. array element
  FELD[0,0,2] = 1      3. array element
  FELD[0,0,3] = 1      4. array element
  ...
  FELD[0,1,0] = 1      5. array element
  FELD[0,1,1] = 1      6. array element
  ...
  FELD[0,2,3] = 1      12. array element
  FELD[1,0,0] = 1      13. array element
  FELD[1,0,1] = 1      14. array element
  ...
  FELD[1,2,3] = 1      24. array element
    
```

corresponding to:

```

FOR n=0 TO 1
  FOR m=0 TO 2
    FOR o=0 TO 3
    
```

```

        FELD[n,m,o] = 1
    ENDFOR
ENDFOR
ENDFOR

```


Example: Initializing complete variable arrays

For the actual assignment, refer to the diagram.

```

Program code
N10 DEF REAL FELD1[10,3]=SET(0,0,0,10,11,12,20,20,20,30,30,30,40,40,40,)
N20 ARRAY1[0,0] = REP(100)
N30 ARRAY1[5,0] = REP(-100)
N40 FELD1[0,0]=SET(0,1,2,-10,-11,-12,-20,-20,-20,-30, , , , -40,-40,-50,-60,-70)
N50 FELD1[8,1]=SET(8.1,8.2,9.0,9.1,9.2)

```



See also

Definition and initialization of array variables (DEF, SET, REP): Further Information (Page 412)
Variables (Page 381)

3.1.1.12 Definition and initialization of array variables (DEF, SET, REP): Further Information

Further information (SET)

initialization during definition

- Starting with the 1st array element, as many array elements are assigned with the values from the value list as there are elements programmed in the value list.
- A value of 0 is assigned to array elements without explicitly declared values in the value list (gaps in the value list).
- For variables of the AXIS data type, gaps in the value list are not permitted.
- If the value list contains more values than there are array elements defined, an alarm will be displayed.

Value assignment in program execution

In the case of value assignment in program execution, the rules described above for definition apply. The following options are also supported:

- Expressions are also permitted as elements in the value list.
- Value assignment starts with the programmed array index. Values can be assigned selectively to subarrays.

Example:

Program code	Comments
DEF INT ARRAY[5,5]	; Array definition
ARRAY[0,0]=SET(1,2,3,4,5)	; Value assignment to the first 5 array elements [0,0] - [0,4]
FELD[0,0]=SET(1,2, , ,5)	; Value assignment with gap to the first 5 array elements [0,0] - [0,4], array elements[0,2] and [0,3] = 0
ARRAY[2,3]=SET(VARIABLE,4*5.6)	; Value assignment with variable and expression starting at array index [2,3]: [2,3] = VARIABLE [2,4] = 4 * 5.6 = 22.4

Further information (REP)

initialization during definition

- All or the optionally specified number of array elements are initialized with the specified value (constant).
- Variables of the FRAME data type cannot be initialized.

Example:

Program code	Comments
DEF REAL varName[10]=REP(3.5,4)	; Initialize array definition and array elements [0] to [3] with value 3.5.

Value assignment in program execution

In the case of value assignment in program execution, the rules described above for definition apply. The following options are also supported:

- Expressions are also permitted as elements in the value list.
- Value assignment starts with the programmed array index. Values can be assigned selectively to subarrays.

Examples:

Program code	Comments
DEF REAL varName[10]	; Array definition
varName[5]=REP(4.5,3)	; Array elements [5] to [7] = 4.5
R10=REP(2.4,3)	; R-parameters R10 to R12 = 2.4
DEF FRAME FRM[10]	; Array definition
FRM[5] = REP(CTTRANS (X,5))	; Array elements [5] to [9] = CTRANS(X,5)

See also

Definition and initialization of array variables (DEF, SET, REP) (Page 407)

3.1.1.13 Data types

The following data types are available in the NC:

Data type	Meaning	Value Range
INT	Integer with sign	-2147483648 ... +2147483647
REAL	Real number (LONG REAL to IEEE)	$\pm(\sim 2,2 \cdot 10^{-308} \dots \sim 1,8 \cdot 10^{+308})$
BOOL	Truth value TRUE (1) and FALSE (0)	1, 0
CHAR	ASCII character	ASCII code 0 to 255
STRING	Character string of a defined length	Maximum of 200 characters (no special characters)
AXIS	Axis/spindle identifier	Channel axis identifier
FRAME	Geometric parameters for static coordinate transformation (translation, rotation, scaling, mirroring)	---

Implicit data type conversions

The following data type conversions are possible and are performed implicitly during assignments and parameter transfers:

from ↓/ to →	REAL	INT	BOOL
REAL	x	o	&
INT	x	x	&

from ↓/ to →	REAL	INT	BOOL
BOOL	x	x	x
x : Possible without restrictions o: Data loss possible due to the range of values being overshoot ⇒ alarm; rounding: decimal place value ≥ 0.5 ⇒ round up, decimal place value < 0.5 ⇒ round down &: value ≠ 0 ⇒ TRUE, value == 0 ⇒ FALSE			

See also

Variables (Page 381)

3.1.1.14 Variable minimum, maximum and range (MINVAL, MAXVAL and BOUND)

The MINVAL and MAXVAL commands compare the values of two variables. The smaller value (in the case of MINVAL) or the larger value (in the case of MAXVAL) respectively is delivered as a result.

The BOUND command tests whether the value of a test variable falls within a defined range of values.

Syntax

```

<smaller value>=MINVAL(<variable1>,<variable2>)
<larger value>=MAXVAL(<variable1>,<variable2>)
<return value>=<BOUND>(<minimum>,<maximum>,<test variable>)
    
```

Meaning

MINVAL:	Obtains the smaller value of two variables (<variable1>,<variable2>)
<smaller value>:	Result variable for the MINVAL command Set to the smaller variable value.
MAXVAL:	Obtains the larger value of two variables (<variable1>,<variable2>)
<larger value>:	Result variable for the MAXVAL command Set to the larger variable value.
BOUND:	Tests whether a variable (<test variable>) is within a defined range of values.
<minimum>:	Variable which defines the minimum value of the range of values.
<maximum>:	Variable which defines the maximum value of the range of values.
<return value>:	Result variable for the BOUND command If the value of the test variable is within the defined range of values, the result variable is set to the value of the test variable. If the value of the test variable is greater than the maximum value, the result variable is set to the maximum value of the definition range. If the value of the test variable is less than the minimum value, the result variable is set to the minimum value of the definition range.

Note

MINVAL, MAXVAL, and BOUND can also be programmed in synchronized actions.

Note

Behavior if values are equal

If the values are equal, MINVAL/MAXVAL are set to this equal value. In the case of BOUND the value of the variable to be tested is returned again.

Example

Program code	Comment
DEF REAL rVar1=10.5, rVar2=33.7, rVar3, rVar4, rVar5, rValMin, rValMax, rRetVar	
rValMin=MINVAL(rVar1,rVar2)	; rValMin is set to value 10.5.
rValMax=MAXVAL(rVar1,rVar2)	; rValMax is set to value 33.7.
rVar3=19.7	
rRetVar=BOUND(rVar1,rVar2,rVar3)	; rVar3 is within the limits, rRetVar is set to 19.7.
rVar3=1.8	
rRetVar=BOUND(rVar1,rVar2,rVar3)	; rVar3 is below the minimum limit, rRetVar is set to 10.5.
rVar3=45.2	
rRetVar=BOUND(rVar1,rVar2,rVar3)	; rVar3 is above the maximum limit, rRetVar is set to 33.7.

3.1.1.15 Check availability of a variable (ISVAR)

The predefined ISVAR function can be used to check whether a system/user variable (e.g. machine data, setting data, system variable, general variables such as GUD) is known in the NC.

Variable

The variables to be queried have the following structure:

- Dimensionless variable: <Variable>
- One-dimensional variable without array index: <Variable>[]
- One-dimensional variable with array index n: <Variable>[<n>]
- Two-dimensional variable without array index: <Variable>[,]
- Two-dimensional variable with array indices n and m: <Variable>[<n>,<m>]

Syntax

<Result>=ISVAR(<Variable>[<n>,<m>])

Meaning

<result>:	Return value				
	Data type:	BOOL			
	Range of values:	<table border="1"> <tr> <td>1</td> <td>Variable available</td> </tr> <tr> <td>0</td> <td>Variable unknown</td> </tr> </table>	1	Variable available	0
1	Variable available				
0	Variable unknown				
ISVAR:	Checks whether the specified system/user variable is known in the NC.				
<Variable>:	Name of the system/user variable				
	Data type:	STRING			
<n>:	Array index of the first dimension (optional)				
	Data type:	INT			
<m>:	Array index of the second dimension (optional)				
	Data type:	INT			

The following checks are made in accordance with the transfer parameter:

- Is the name known?
- Is the variable an array?
- Is it a one- or two-dimensional array?
- Is the respective array index in the permissible range?

Only if all checks are positive, TRUE (1) is returned.

If a check is negative or a syntax error has occurred, FALSE (0) is returned.

Examples

Program code	Comment
<pre>DEF INT VAR1 DEF BOOL IS_VAR=FALSE N10 IS_VAR=ISVAR("VAR1")</pre>	<pre>; IS_VAR is in this case TRUE.</pre>

Program code	Comment
<pre>DEF REAL VARARRAY[10,10] DEF BOOL IS_VAR=FALSE N10 IS_VAR=ISVAR("VARARRAY[,]")</pre>	<pre>; IS_VAR is in this case TRUE, is a two-dimensional array.</pre>
<pre>N20 IS_VAR=ISVAR("VARARRAY")</pre>	<pre>; IS_VAR is TRUE, variable exists.</pre>
<pre>N30 IS_VAR=ISVAR("VARARRAY[8,11]")</pre>	<pre>; IS_VAR is FALSE, array index is not permitted.</pre>
<pre>N40 IS_VAR=ISVAR("VARARRAY[8,8]")</pre>	<pre>; IS_VAR is FALSE, "]" missing (syntax error).</pre>
<pre>N50 IS_VAR=ISVAR("VARARRAY[,8]")</pre>	<pre>; IS_VAR is TRUE, array index is permitted.</pre>
<pre>N60 IS_VAR=ISVAR("VARARRAY[8,]")</pre>	<pre>; IS_VAR is TRUE, array index is permitted.</pre>

Program code	Comment
DEF BOOL IS_VAR=FALSE	
N100 IS_VAR=ISVAR("\$MC_GCODE_RESET_VALUES[1]"	; Transfer parameter is a machine data item, IS_VAR is TRUE.

Program code	Comment
DEF BOOL IS_VAR=FALSE	
N10 IS_VAR=ISVAR("\$P_EP")	; IS_VAR is in this case TRUE.
N20 IS_VAR=ISVAR("\$P_EP[X]")	; IS_VAR is in this case TRUE.

3.1.1.16 Reading attribute values / data type (GETVARPHU, GETVARAP, GETVARLIM, GETVARDIM, GETVARDFT, GETVARTYP)

The attribute values of system/user variables can be read with the predefined GETVARPHU, GETVARAP, GETVARLIM and GETVARDFT functions, the data type of a system/user variable with GETVARTYP.

Read physical unit

Syntax:

<Result>=GETVARPHU (<name>)

Meaning:

<result>:	Numeric value of the physical unit	
	Data type:	INT
	Range of values:	See Table in "Attribute: Physical unit (PHU) (Page 400)"
		In case of fault
	- 2	The specified <name> has not been assigned to a system parameter or a user variable.
GETVARPHU:	Reading of the physical unit of a system/user variable	
<name>:	Name of the system/user variables	
	Data type:	STRING

Example:

The NC contains the following GUD variables:

```
DEF CHAN REAL PHU 42 LLI 0 ULI 10000 electric
```

Program code	Comment
DEF INT result=0	
result=GETVARPHU("elec- tric")	; Determine the physical unit of the GUD variables.
IF (result < 0) GOTOF error	

The value 42 is returned as result. This corresponds to the physical unit [kW].

Note

GETVARPHU can be used, for example, to check whether both variables have the expected physical units in a variable assignment a = b.

Read access right

Syntax:

<Result>=GETVARAP (<name>, <access>)

Meaning:

<result>:	Protection level for the specified <access>		
	Data type:	INT	
	Range of values:	0 ... 7	See "Attribute: Access rights (APR, APW, APRP, APWP, APRB, APWB) (Page 402)".
		In case of fault	
		- 1	Cannot be written (only relevant for <Access> "WP" and "WB")
- 2		The specified <name> has not been assigned to a system parameter or a user variable.	
- 3	Incorrect value for <access>		
GETVARAP:	Reading of the access right to a system/user variable		
<name>:	Name of the system/user variables		
	Data type:	STRING	
<access>:	Type of access		
	Data type:	STRING	
	Range of values:	"RP"	Read via part program
		"WP"	Write via part program
		"RB"	Read via OPI
"WB"		Write via OPI	

Example:

Program code	Comment
DEF INT result=0	
result=GETVARAP("\$TC_MAP8", "WB")	; Determine the access protection for the system parameter "magazine position" with regard to writing via OPI.
IF (result < 0) GOTOF error	

The value 7 is returned as result. This corresponds to the key switch position 0 (= no access protection).

Note

GETVARAP can be used, for example, to implement a checking program that checks the access rights expected by the application.

Read limit values

Syntax:

<Status>=GETVARLIM(<name>,<limit value>,<result>)

Meaning:

<Status>:	Function status		
	Data type:	INT	
	Range of values:	1	OK
		-1	No limit value defined (for variables of type AXIS, STRING, FRAME)
		-2	The specified <name> has not been assigned to a system parameter or a user variable.
-3		Incorrect value for <limit value>	
GETVARLIM:	Reading of the lower/upper limit value of a system/user variable		
<name>:	Name of the system/user variables		
	Data type:	STRING	
<limit value>:	specifies which limit value should be read out		
	Data type:	CHAR	
	Range of values:	"L" :	= lower limit value
		"U" :	= upper limit value
<result>:	Return of the limit value		
	Data type:	VAR REAL	

Example:

Program code	Comment
DEF INT state=0	
DEF REAL result=0	
state=GETVARLIM("\$MA_MAX_AX_VE- LO","L",result)	Determine the lower limit value for MD32000 \$MA_MAX_AX_VELO.
IF (result < 0) GOTO error	

Read attributes / data type

Syntax:

<Result>=GETVARDIM(<Name>, Index)

Meaning:

<Result>:	Dimension / number of array <Index>	
	Data type:	INT
GETVARDIM:	Reading of the lower/upper limit value of a system/user variable	
<Name>:	Reading the number of elements of the array	
	Data type:	STRING
<Index>:	Number of the array, max. 3.	
	Data type:	INT

Example:

Program code	Comment
N5 DEF REAL myReal[5,4]	
N10 R1 = GETVATDIM("myReal",1)	R1 = 5
N15 R2 = GETVATDIM("myReal",2)	R2 = 4

Read default value

Syntax:

<Status>=GETVARDFT (<name>,<result>[,<index_1>,<index_2>,<index_3>])

Meaning:

<Status>:	Function status		
	Data type:	INT	
	Range of values:	1	OK
		-1	No default value available (e.g. because <result> has the wrong type for <name>)
		-2	The specified <name> has not been assigned to a system parameter or a user variable.
		-3	Incorrect value for <index_1>, dimension less than one (= no array = scalar)
		-4	Incorrect value for <index_2>
-5	Incorrect value for <index_3>		
GETVARDFT:	Reading of the default value of a system/user variable		
<name>:	Name of the system/user variables		
	Data type:	STRING	
<result>:	Return of the default value		
	Data type:	VAR REAL (when reading the default value of variables of the types INT, REAL, BOOL, AXIS)	
		VAR STRING (when reading the default value of variables of the types STRING and CHAR)	
		VAR FRAME (when reading the default value of variables of the type FRAME)	

<index_1>:	Index to the first dimension (optional)	
	Data type:	INT
	Not programmed means = 0	
<index_2>:	Index to the second dimension (optional)	
	Data type:	INT
	Not programmed means = 0	
<index_3>:	Index to the third dimension (optional)	
	Data type:	INT
	Not programmed means = 0	

Example:

Program code	Comment
DEF INT state=0	
DEF REAL resultR=0	; Variable to accept the default values of the types INT, REAL, BOOL, AXIS.
DEF FRAME resultF=0	; Variable to accept the default values of the type FRAME
IF (GETVARTYP("\$MA_MAX_AX_VELO") <> 4) GOTO error	
state=GETVARDFT("\$MA_MAX_AX_VELO", resultR, AXTOINT(X))	; Determine the default value of the "X" axis.
IF (result < 0) GOTO error	
IF (GETVARTYP("\$TC_TP8") <> 3) GOTO error	
state=GETVARDFT("\$TC_TP8", resultR)	
IF (GETVARTYP("\$P_UBFR") <> 7) GOTO error	
state=GETVARDFT("\$P_UBFR", resultF)	

Read data type

Syntax:

<Result>=GETVARTYP(<name>)

Meaning:

<result>:	Data type of the specified system/user variables		
	Data type:	INT	
	Range of values:	1	= BOOL
		2	= CHAR
		3	= INT
		4	= REAL
		5	= STRING
		6	= AXIS
		7	= FRAME
In case of fault			
< 0	The specified <name> has not been assigned to a system parameter or a user variable.		
GETVARTYP:	Reading of the data type of a system/user variable		
<name>:	Name of the system/user variables		
	Data type:	STRING	

Example:

Program code	Comment
DEF INT result=0	
DEF STRING name="R"	
result=GETVARTYP(name)	; Determine the type of the R parameter.
IF (result < 0) GOTO error	

The value 4 is returned as result. This corresponds to the REAL data type.

3.1.1.17 Possible type conversions

The constant numeric value, the variable, or the expression assigned to a variable must be compatible with the variable type. If this is the case, the type is automatically converted when the value is assigned.

Possible type conversions

	to	REAL	INT	BOOL	CHAR	STRING	AXIS	FRAME
from								
REAL		yes	Yes*	Yes ¹⁾	Yes*	-	-	-
INT		yes	yes	Yes ¹⁾	Yes ²⁾	-	-	-
BOOL		yes	yes	yes	yes	yes	-	-
CHAR		yes	yes	Yes ¹⁾	yes	yes	-	-
STRING		-	-	Yes ⁴⁾	Yes ³⁾	yes	-	-
AXIS		-	-	-	-	-	yes	-
FRAME		-	-	-	-	-	-	yes

Explanation

- * At type conversion from REAL to INT, fractional values that are ≥ 0.5 are rounded up, others are rounded down (cf. ROUND function).
- 1) Value $\neq 0$ is equivalent to TRUE; value $= 0$ is equivalent to FALSE
- 2) If the value is in the permissible range
- 3) If only 1 character
- 4) String length 0 = >FALSE, otherwise TRUE

Note

If conversion produces a value greater than the target range, an error message is output.
If mixed types occur in an expression, type conversion is automatic. Type conversions are also possible in synchronous actions, see Chapter "Motion-synchronous actions, implicit type conversion".

3.1.2 Indirect programming

3.1.2.1 Indirectly programming addresses

When indirectly programming addresses, the extended address (<index>) is replaced by a variable with a suitable type.

Note

It is not possible to indirectly program addresses for:

- N (block number)
 - L (subprogram)
 - Settable addresses
(e.g. X[1] instead of X1 is not permissible)
-

Syntax

<ADDRESS> [<Index>]

Meaning

<ADDRESS>[...]:	Fixed address with extension (index)
<index>:	Variable, e.g. for spindle number, axis,

Examples

Example 1: Indirectly programming a spindle number

Direct programming:

Program code	Comment
S1=300	; Speed in rpm for the spindle number 1.

Indirect programming:

Program code	Comment
DEF INT SPINU=1	; Defining variables, type INT and value assignment.
S[SPINU]=300	; Speed 300 rpm for the spindle, whose number is saved in the SPINU variable (in this example 1, the spindle with the number 1).

Example 2: Indirectly programming an axis

Direct programming:

Program code	Comment
FA[U]=300	; Feedrate 300 for axis "U".

Indirect programming:

Program code	Comment
DEF AXIS AXVAR2=U	; Defining a variable, type AXIS and value assignment.
FA[AXVAR2]=300	; Feedrate of 300 for the axis whose address name is saved in the variables with the name AXVAR2.

Example 3: Indirectly programming an axis

Direct programming:

Program code	Comment
\$AA_MM[X]	; Read probe measured value (MCS) of axis "X".

Indirect programming:

Program code	Comment
DEF AXIS AXVAR3=X	; Defining a variable, type AXIS and value assignment.
\$AA_MM[AXVAR3]	; Read probe measured value (MCS) whose name is saved in the variables AXVAR3.

Example 4: Indirectly programming an axis

Direct programming:

Program code	Comment
X1=100 X2=200	

Indirect programming:

Program code	Comment
DEF AXIS AXVAR1 AXVAR2	; Defining two type AXIS variables.
AXVAR1=(X1) AXVAR2=(X2)	; Assigning the axis names.
AX[AXVAR1]=100 AX[AXVAR2]=200	; Traversing the axes whose address names are saved in the variables with the names AXVAR1 and AXVAR2

Example 5: Indirectly programming an axis

Direct programming:

Program code
G2 X100 I20

Indirect programming:

Program code	Comment
DEF AXIS AXVAR1=X	; Defining a variable, type AXIS and value assignment.
G2 X100 IP[AXVAR1]=20	; Indirect programming the center point data for the axis, whose address name is saved in the variable with the name AXVAR1.

Example 6: Indirectly programming array elements

Direct programming:

Program code	Comment
DEF INT ARRAY1[4,5]	; Defining array 1

Indirect programming:

Program code	Comment
DEFINE DIM1 AS 4	; For array dimensions, array sizes must be specified as fixed values.
DEFINE DIM2 AS 5	
DEF INT ARRAY[DIM1,DIM2]	
ARRAY[DIM1-1,DIM2-1]=5	

Example 7: Indirect subprogram call

Program code	Comment
CALL "L" << R10	; Call the program, whose number is located in R10 (string cascading).

3.1.2.2 Indirectly programming G commands

Indirect programming of G commands permits cycles to be effectively programmed.

Syntax

G[<group>]=<number>

Meaning

G[...]:	G command with extension (index)	
<group>:	Index parameter: G group	
	Type:	INT
<number>:	Variable for the G command number	
	Type:	INT or REAL

Note

Generally, only G commands that do not determine the syntax can be indirectly programmed.

Only G group 1 is possible from the G commands that determine the syntax.

The syntax-determining G commands of G groups 2, 3 and 4 are not possible.

Note

Arithmetic functions are not permitted in the indirect G command programming. If it is necessary to calculate the G command number, this must be done in a separate part program line before the indirect G command programming.

Examples

Example 1: Adjustable work offset (G group 8)

Program code	Comment
N1010 DEF INT INT_VAR	
N1020 INT_VAR=2	
...	
N1090 G[8]=INT_VAR G1 X0 Y0	;G54
N1100 INT_VAR=INT_VAR+1	; G command calculation
N1110 G[8]=INT_VAR G1 X0 Y0	;G55

Example 2: Level selection (G group 6)

Program code	Comment
N2010 R10=\$P_GG[6]	; Read active G command of G group 6
...	
N2090 G[6]=R10	

References

For information on the G groups, see:
 Programming Manual, Fundamentals; Section "G groups"

3.1.2.3 Indirectly programming position attributes (GP)

Position attributes, e.g. the incremental or absolute programming of the axis position, can be indirectly programmed as variables in conjunction with the key word GP.

Application

The indirect programming of position attributes is used in **replacement cycles**, as in this case, the following advantage exists over programming position attributes as keyword (e.g. IC, AC, ...):

As a result of the indirect programming as variable, **no CASE statement** is required, which would otherwise branch for all possible position attributes.

Syntax

```
<POSITIONING COMMAND>[<axis/spindle>]=
GP(<position>,<position attribute>)
<axis/spindle>=BP(<position>,<position attribute>)
```

Meaning

<POSITIONING COMMAND>[:	The following positioning commands can be programmed together with the key word GP: POS, POSA, SPOS, SPOSA Also possible: <ul style="list-style-type: none"> All axis and spindle identifiers present in the channel: <axis/spindle> Variable axis/spindle identifier AX
<axis/spindle>:	Axis/spindle that is to be positioned
GP():	Key word for positioning
<position>:	Parameter 1 Axis/spindle position as constant or variable
<position attribute>:	Parameter 2 Position attribute (e.g. position approach mode as a variable (e.g. \$P_SUB_SPOSMODE) or as key word (IC, AC, ...))

The values supplied from the variables have the following significance:

Value	Meaning	Permissible for:
0	No change to the position attribute	
1	AC	POS, POSA, SPOS, SPOSA, AX, axis address
2	IC	POS, POSA, SPOS, SPOSA, AX, axis address
3	DC	POS, POSA, SPOS, SPOSA, AX, axis address
4	ACP	POS, POSA, SPOS, SPOSA, AX, axis address
5	ACN	POS, POSA, SPOS, SPOSA, AX, axis address
6	OC	-
7	PC	-

Value	Meaning	Permissible for:
8	DAC	POS, POSA, AX, axis address
9	DIC	POS, POSA, AX, axis address
10	RAC	POS, POSA, AX, axis address
11	RIC	POS, POSA, AX, axis address
12	CAC	POS, POSA
13	CIC	POS, POSA
14	CDC	POS, POSA
15	CACP	POS, POSA
16	CACN	POS, POSA

Example

For an active synchronous spindle coupling between the leading spindle S1 and the following spindle S2, the following replacement cycle to position the spindle is called using the `SPOS` command in the main program.

Positioning is realized using the statement in N2230:
`SPOS[1]=GP($P_SUB_SPOSIT,$P_SUB_SPOSMODE)`
`SPOS[2]=GP($P_SUB_SPOSIT,$P_SUB_SPOSMODE)`

The position to be approached is read from the system variable `$P_SUB_SPOSIT`; the position approach mode is read from the system variable `$P_SUB_SPOSMODE`.

Program code	Comment
N1000 PROC LANG_SUB DISPLOF SBLOF	
...	
N2100 IF(\$P_SUB_AXFCT==2)	
N2110	; Replacement of the SPOS / SPOSA / M19 command for an active synchronous spindle coupling
N2185 DELAYFSTON	; Start of stop delay area
N2190 COUPOF(S2,S1)	; Deactivate synchronous spindle coupling
N2200	; Position leading and following spindles
N2210 IF(\$P_SUB_SPOS==TRUE) OR (\$P_SUB_SPOSA==TRUE)	
N2220	; Positioning the spindle with SPOS:
N2230 SPOS[1]=GP(\$P_SUB_SPOSIT, \$P_SUB_SPOSMODE)	
SPOS[2]=GP(\$P_SUB_SPOSIT, \$P_SUB_SPOSMODE)	
N2250 ELSE	
N2260	; Positioning the spindle using M19:
N2270 M1=19 M2=19	; Position leading and following spindles
N2280 ENDIF	
N2285 DELAYFSTOF	; End of stop delay area
N2290 COUPON(S2,S1)	; Activate synchronous spindle coupling
N2410 ELSE	

Program code	Comment
N2420	; Query on further replacements
...	
N3300 ENDIF	
...	
N9999 RET	

Supplementary conditions

- The indirect programming of position attributes is not possible in synchronized actions.

References

Function Manual Basic Functions; BAG, Channel, Program Operation, Reset Response (K1),
Section: Replacement of NC functions by subprograms

3.1.2.4 Indirectly programming part program lines (EXECSTRING)

Using the part program command EXECSTRING, it is possible to execute a previously generated string variable as part program line.

Syntax

EXECSTRING is programmed in a separate part program line:
EXECSTRING (<string_variable>)

Meaning

EXECSTRING:	Command to execute a string variable as part program line
<string variable>:	Type STRING variable, that includes the actual part program line to be executed

Note

With EXECSTRING, all part program constructions that can be programmed in the **program section of a part program**, with the exception of control structures (Page 464), can be extracted. This means that PROC and DEF statements are excluded as well as the general use in INI and DEF files.

Example

Program code	Comment
N100 DEF STRING[100] MY_BLOCK	; Definition of string variables to accept the part program line to be executed.
N110 DEF STRING[10] MFCT1="M7"	
...	

3.1 Flexible NC programming

Program code	Comment
N200 EXECSTRING(MFCT1 << "M4711")	; Execute part program line "M7 M4711".
...	
N300 R10=1	
N310 MY_BLOCK="M3"	
N320 IF(R10)	
N330 MY_BLOCK = MY_BLOCK << MFCT1	
N340 ENDIF	
N350 EXECSTRING(MY_BLOCK)	; Execute part program line "M3 M7".

3.1.3 Instructions

3.1.3.1 Arithmetic functions

Operator / arithmetic function	Meaning
+	Addition
-	Subtraction
*	Multiplication
/ ¹⁾	Division ¹⁾
DIV ¹⁾	Integer number division ¹⁾
MOD ¹⁾	Modulo division (supplies the remainder of the integer number division) ¹⁾
:	Chain operator for FRAME variables
SIN ()	Sine
COS ()	Cosine
TAN ()	Tangent
ASIN ()	Arc sine
ACOS ()	Arc cosine
ATAN2 (,) ¹⁾	Arc tangent2 ¹⁾
SQRT ()	Square root
ABS ()	Absolute value
POT ()	2nd power (square)
TRUNC ()	Integer component The accuracy for comparison commands can be set using TRUNC (see "Precision correction on comparison errors (TRUNC) (Page 435)")
ROUND ()	Round to integer
LN ()	Natural logarithm
EXP ()	Exponential function

MINVAL ()	Lower value of two variables (see "Variable minimum, maximum and range (MINVAL, MAXVAL and BOUND) (Page 414)")
MAXVAL ()	Larger value of two variables (see "Variable minimum, maximum and range (MINVAL, MAXVAL and BOUND) (Page 414)")
BOUND ()	Variable value within the defined value range (see "Variable minimum, maximum and range (MINVAL, MAXVAL and BOUND) (Page 414)")
CTRANS ()	Offset
CROT ()	Rotation
CSCALE ()	Change of scale
CMIRROR ()	Mirroring
1) See the paragraph, "Examples"	

Programming

The usual mathematical notation is used for arithmetic functions. Priorities for execution are indicated by parentheses. Angles are specified for trigonometry functions and their inverse functions (right angle = 90°).

Examples

Division: /

(type REAL) = type INT or type REAL / (type INT or type REAL);

Example: $3 / 4 = 0.75$

Integer number division: DIV

(type INT) = (type INT or REAL) / (type INT or REAL);

Example: $7 \text{ DIV } 4.1 = 1$

Modulo division (supplies the remainder of the integer number division): MOD

(type REAL) = (type INT or REAL) MOD (type INT or REAL);


Example: $7 \text{ MOD } 4.1 = 2.9$

Arc tangent 2: ATAN2

The arithmetic function ATAN2 calculates the angle of the total vector from two mutually perpendicular vectors.

The result is in one of four quadrants ($-180^\circ < 0 < +180^\circ$).

The angular reference is always based on the 2nd value in the positive direction.



Programming examples

Program code	Comment
R1=R1+1	; New R1 = old R1 + 1
R1=R2+R3 R4=R5-R6 R7=R8*R9	
R10=R11/R12 R13=SIN(25.3)	
R14=R1*R2+R3	; Multiplication or division takes precedence over addition or subtraction.
R14=(R1+R2)*R3	; Expressions and parentheses are calculated first.
R15=SQRT(POT(R1)+POT(R2))	; Inner parentheses are resolved first: R15 = square root of (R1^2 + R2^2)
RESFRAME=FRAME1:FRAME2	; FRAME logic operation with chain operator
FRAME3=CTRANS(...):CROT(...)	Value assignment at a FRAME component

3.1.3.2 Comparison and logic operations

Comparison operations can be used, for example, to formulate a jump condition. Complex expressions can also be compared.

The comparison operations are applicable to variables of type CHAR, INT, REAL and BOOL. The code value is compared with the CHAR type.

For types STRING, AXIS and FRAME, the following are possible: == and <>, which can be used for STRING type operations, even in synchronous actions.

The result of comparison operations is always of BOOL type.

Logic operators are used to link truth values.

The logical operations can only be applied to type BOOL variables. However, they can also be applied to the CHAR, INT and REAL data types via internal type conversion.

For the logic (Boolean) operations, the following applies to the `BOOL`, `CHAR`, `INT` and `REAL` data types:

- 0 corresponds to: FALSE
- Not equal to 0 means: TRUE

Bit-by-bit logic operators

Logic operations can also be applied to single bits of types `CHAR` and `INT`. Type conversion is automatic.

Programming

Relational operator	Meaning
==	Equal to
<>	Not equal to
>	Greater than
<	Less than
>=	Greater than or equal to
<=	Less than or equal to

Logic operator	Meaning
AND	AND
OR	OR
NOT	Negation
XOR	Exclusive OR

Bit-by-bit logic operator	Meaning
B_AND	Bit-by-bit AND
B_OR	Bit-by-bit OR
B_NOT	Bit-by-bit negation
B_XOR	Bit-by-bit exclusive OR

Note

In arithmetic expressions, the execution order of all the operators can be specified by parentheses, in order to override the normal priority rules.

Note

Spaces must be left between BOOLEAN operands and operators.

Note

The operator `B_NOT` only refers to one operand. This is located after the operator.

Examples

Example 1: Comparison operators

```
IF R10>=100 GOTOF DEST
```

or

```
R11=R10>=100
IF R11 GOTOF DEST
```

The result of the R10>=100 comparison is first buffered in R11.

Example 2: Logic operators

```
IF (R10<50) AND ($AA_IM[X]>=17.5) GOTOF DESTINATION
```

or

```
IF NOT R10 GOTOB START
```

NOT only refers to one operand.

Example 3: Bit-by-bit logic operators

```
IF $MC_RESET_MODE_MASK B_AND 'B10000' GOTOF ACT_PLANE
```

3.1.3.3 Priority of the operations

Each operator is assigned a priority. When an expression is evaluated, the operators with the highest priority are always applied first. Where operators have the same priority, the evaluation is from left to right.

In arithmetic expressions, the execution order of all the operators can be specified by parentheses, in order to override the normal priority rules.

Order of operators

From the highest to lowest priority

1.	NOT, B_NOT	Negation, bit-by-bit negation
2.	*, /, DIV, MOD	Multiplication, division
3.	+, -	Addition, subtraction
4.	B_AND	Bit-by-bit AND
5.	B_XOR	Bit-by-bit exclusive OR
6.	B_OR	Bit-by-bit OR
7.	AND	AND
8.	XOR	Exclusive OR
9.	OR	OR
10.	<<	Concatenation of strings, result type STRING
11.	==, <>, >, <, >=, <=	Comparison operators

Note

The concatenation operator ":" for Frames must not be used in the same expression as other operators. A priority level is therefore not required for this operator.

Example: IF statement

```
If (otto==10) and (anna==20) gotof end
```

3.1.3.4 Precision correction on comparison errors (TRUNC)

The TRUNC command truncates the operand multiplied by a precision factor.

Settable precision for comparison commands

Program data of type REAL is displayed internally with 64 bits in IEEE format. This display format can cause decimal numbers to be displayed imprecisely and lead to unexpected results when compared with the ideally calculated values.

Relative equality

To prevent the imprecision caused by the display format from interfering with program flow, the comparison commands do not check for absolute equality, but rather for relative equality.

Syntax

Precision correction on comparison errors

```
TRUNC (R1*1000)
```

Meaning

TRUNC:	Truncate decimal places
--------	-------------------------

Relative quality of 10^{-12} taken into account for

- Equality: (==)
- Inequality: (<>)
- Greater than or equal to: (>=)
- Less than or equal to: (<=)
- Greater/less than: (><) with absolute equality
- Greater than: (>)
- Less than: (<)

Compatibility

For compatibility reasons, the check for relative quality for (>) and (<) can be deactivated by setting machine data MD10280 \$MN_PROG_FUNCTION_MASK Bit0 = 1.

Note

Comparisons with data of type REAL are subject to a certain imprecision for the above reasons. If deviations are unacceptable, use INTEGER calculation by multiplying the operands by a precision factor and then truncating with TRUNC.

Synchronized actions

The response described for the comparison commands also applies to synchronized actions.

Examples

Example 1: Precision considerations

Program code	Comments
N40 R1=61.01 R2=61.02 R3=0.01	;Assignment of initial values
N41 IF ABS(R2-R1) > R3 GOTOF ERROR	; Jump would have been executed up until now
N42 M30	; End of program
N43 ERROR: SETAL(66000)	
R1=61.01 R2=61.02 R3=0.01	;Assignment of initial values
R11=TRUNC(R1*1000) R12=TRUNC(R2*1000)	; Accuracy correction
R13=TRUNC(R3*1000)	
IF ABS(R12-R11) > R13 GOTOF ERROR	; Jump is no longer executed
M30	; End of program
ERROR: SETAL(66000)	

Example 2: Calculate and evaluate the quotient of both operands

Program code	Comments
R1=61.01 R2=61.02 R3=0.01	;Assignment of initial values
IF ABS((R2-R1)/R3)-1 > 10EX-5 GOTOF ERROR	; Jump is not executed
M30	; End of program
ERROR: SETAL(66000)	

3.1.3.5 Roundup (ROUNDUP)

Input values, type REAL (fractions with decimal point) can be rounded up to the next higher integer number using the ROUNDUP" function.

Syntax

ROUNDUP (<value>)

Meaning

ROUNDUP:	Command to roundup an input value
<value>:	Input value, type REAL

Note

Input value, type INTEGER (an integer number) is returned unchanged.

Examples

Example 1: Various input values and their rounding up results

Example	Rounding up result
ROUNDUP (3.1)	4.0
ROUNDUP (3.6)	4.0
ROUNDUP (-3.1)	-3.0
ROUNDUP (-3.6)	-3.0
ROUNDUP (3.0)	3.0
ROUNDUP (3)	3.0

Example 2: ROUNDUP in the NC program

```
Program code
-----
N10 X=ROUNDUP (3.5) Y=ROUNDUP (R2+2)
N15 R2=ROUNDUP ($AA_IM[Y])
N20 WHEN X=100 DO Y=ROUNDUP ($AA_IM[X])
...

```

3.1.4 String operations

String operations

In addition to the classic operations "assign" and "comparison" the following string operations are possible:

- Type conversion to STRING (AXSTRING) (Page 438)
- Type conversion from STRING (NUMBER, ISNUMBER, AXNAME) (Page 438)
- Concatenation of strings (<<) (Page 439)
- Conversion to lower/upper case letters (TOLOWER, TOUPPER) (Page 441)
- Determine length of string (STRLEN) (Page 441)
- Search for character/string in the string (INDEX, RINDEX, MINDEX, MATCH) (Page 442)
- Selection of a substring (SUBSTR) (Page 443)
- Reading and writing of individual characters (Page 444)
- Formatting a string (SPRINT) (Page 445)

Special significance of the 0 character

Internally, the 0 character is interpreted as the end identifier of a string. If a character is replaced with the 0 character, the string is truncated.

Example:

Program code	Comment
DEF STRING[20] STRG="axis . stationary"	
STRG[6]="X"	
MSG(STRG)	; Supplies the message "axis X stationary".
STRG[6]=0	
MSG(STRG)	; Supplies the message "axis".

3.1.4.1 Type conversion to STRING (AXSTRING)

The function "type conversion to STRING" allows variables of different types to be used as a component of a message (MSG).

When using the << operator this is realized implicitly for data types INT, REAL, CHAR and BOOL (see " Concatenation of strings (<<) (Page 439) ").

An INT value is converted to normal readable format. REAL values convert with up to 10 decimal places.

Type AXIS variables can be converted to STRING using the AXSTRING command.

Syntax

```
<STRING_RES> = << <any_type>
<STRING_RES> = AXSTRING(<axis identifier>)
```

Meaning

<STRING_RES>:	Variable for the result of the type conversion	
	Type:	STRING
<any_type>:	Variable types INT, REAL, CHAR, STRING and BOOL	
AXSTRING:	The AXSTRING command supplies the specified axis identifier as string.	
<axis identifier>:	Variable for axis identifier	
	Type:	AXIS

Note

FRAME variables cannot be converted.

3.1.4.2 Type conversion from STRING (NUMBER, ISNUMBER, AXNAME)

A conversion is made from STRING to REAL using the NUMBER command. The ability to be converted can be checked using the ISNUMBER command.

A string is converted into the axis data type using the AXNAME command.

Syntax

```
<REAL_RES>=NUMBER("<string>")
<BOOL_RES>=ISNUMBER("<string>")
<AXIS_RES>=AXNAME("<string>")
```

Meaning

NUMBER:	The NUMBER command returns the number represented by the <string> as REAL value.				
<string>:	Type STRING variable to be converted				
<REAL_RES>:	Variable for the result of the type conversion with NUMBER				
	Type:	REAL			
ISNUMBER:	The ISNUMBER command checks whether the <string> can be converted into a valid number.				
<BOOL_RES>:	Variable for the result of the interrogation with ISNUMBER				
	Type:	BOOL			
	Value:	<table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">TRUE</td> <td>ISNUMBER supplies the value TRUE, if the <string> represents a valid REAL number in compliance with the language rules.</td> </tr> <tr> <td>FALSE</td> <td>If ISNUMBER supplies the value FALSE, when calling NUMBER with the same <string>, an alarm is initiated.</td> </tr> </table>	TRUE	ISNUMBER supplies the value TRUE, if the <string> represents a valid REAL number in compliance with the language rules.	FALSE
TRUE	ISNUMBER supplies the value TRUE, if the <string> represents a valid REAL number in compliance with the language rules.				
FALSE	If ISNUMBER supplies the value FALSE, when calling NUMBER with the same <string>, an alarm is initiated.				
AXNAME:	The AXNAME command converts the specified <string> into an axis identifier. Note: If the <string> cannot be assigned a configured axis identifier, an alarm is initiated.				
<AXIS_RES>:	Variable for the result of the type conversion with AXNAME				
	Type:	AXIS			

Example

Program code	Comment
DEF BOOL BOOL_RES	
DEF REAL REAL_RES	
DEF AXIS AXIS_RES	
REAL_RES == 1234.9876Ex-7	; BOOL_RES == TRUE
BOOL_RES=ISNUMBER("1234XYZ")	; BOOL_RES == FALSE
REAL_RES=NUMBER("1234.9876Ex-7")	; REAL_RES == 1234.9876Ex-7
AXIS_RES=AXNAME("X")	; AXIS_RES == X

3.1.4.3 Concatenation of strings (<<)

The function "concatenation strings" allows a string to be configured from individual components.

The concatenation is realized using the operator "<<". This operator has STRING as the target type for all combinations of basic types CHAR, BOOL, INT, REAL, and STRING. Any conversion that may be required is carried out according to existing rules.

Syntax

<any_type> << <any_type>

Meaning

<any_type>:	Variable, type CHAR, BOOL, INT, REAL or STRING
<< :	Operator to chain variables (<any_type>) to configure a character string (type STRING). This operator is also available alone as a so-called "unary" variant. This can be used for explicit type converter to STRING (not for FRAME and AXIS): << <any_type>

For example, such a message or a command can be configured from text lists and parameters can be inserted (for example a block name):
MSG (STRG_TAB [LOAD_IDX] <<BLOCK_NAME)

Note

The intermediate results of string concatenation must not exceed the maximum string length.

Note

The FRAME and AXIS types cannot be used together with the operator "<<".

Examples

Example 1: Concatenation of strings

Program code	Comment
DEF INT IDX=2	
DEF REAL VALUE=9.654	
DEF STRING[20] STRG="INDEX:2"	
IF STRG=="Index:"<<IDX GOTOF NO_MSG	
MSG ("Index:"<<IDX<<"/value:"<<VALUE)	; Display: "Index:2/value:9.654"
NO_MSG:	

Example 2: Explicit type conversion with <<

Program code	Comment
DEF REAL VALUE=3.5	
<<VALUE	; The specified REAL type variable is converted into a STRING type.

3.1.4.4 Conversion to lower/upper case letters (TOLOWER, TOUPPER)

The "conversion to lowercase/uppercase letters" function allows all of the letters of a string to be converted into a standard representation.

Syntax

```
<STRING_RES>=TOUPPER("<string>")
<STRING_RES>=TOLOWER("<string>")
```

Meaning

TOUPPER:	Using the TOUPPER command, all of the letters in a character string are converted into uppercase letters.	
TOLOWER:	Using the TOLOWER command, all of the letters in a character string are converted into lowercase letters.	
<string>:	Character string that is to be converted	
	Type:	STRING
<STRING_RES>:	Variable for the result of the conversion	
	Type:	STRING

Example

Because user inputs can be initiated on the user interface, they can be given standard capitalization (uppercase or lowercase):

```
Program code
DEF STRING [29] STRG
...
IF "LEARN.CNC"==TOUPPER(STRG) GOTOF LOAD_LEARN
```

3.1.4.5 Determine length of string (STRLEN)

The STRLEN command determines the length of a character string.

Syntax

```
<INT_RES>=STRLEN("<STRING>")
```

Meaning

STRLEN:	The STRLEN command determines the length of the specified character string. The number of characters that are not the 0 character, counting from the beginning of the string is returned.	
<string>:	Character string whose length is to be determined	
	Type:	STRING

<INT_RES>:	Variable for the result of the determination	
	Type:	INT

Example

In conjunction with the single character access, this function allows the end of a character string to be determined:

Program code

```
IF (STRLEN(BLOCK_NAME)>10) GOTOF ERROR
```

3.1.4.6 Search for character/string in the string (INDEX, RINDEX, MINDEX, MATCH)

This functionality searches for single characters or a string within a string. The function results specify where the character/string is positioned in the string that has been searched.

Syntax

```
INT_RES=INDEX (STRING, CHAR) ; Result type: INT
INT_RES=RINDEX (STRING, CHAR) ; Result type: INT
INT_RES=MINDEX (STRING, STRING) ; Result type: INT
INT_RES=MINDEX (STRING, STRING) ; Result type: INT
```

Semantics

Search functions: It supplies the position in the string (first parameter) where the search has been successful. If the character/string cannot be found, then the value -1 is returned. The first character has position 0.

Meaning

INDEX:	Searches for the character specified as second parameter (from the beginning) in the first parameter.
RINDEX:	Searches for the character specified as second parameter (from the end) in the first parameter.
MINDEX:	Corresponds to the INDEX function, except for the case that a list of characters is transferred (as string) in which the index of the first found character is returned.
MATCH:	Searches for a string in a string.

This allows strings to be broken up according to certain criteria, for example, at positions with blanks or path separators ("/").

Example

Breaking up an input into path and block names

Program code	Comment
DEF INT PFADIDX, PROGIDX	
DEF STRING[26] INPUT	
DEF INT LISTIDX	
INPUT = "/_N_MPF_DIR/_N_EXECUTE_MPF"	
LISTIDX = MINDEX (INPUT, "M,N,O,P") + 1	; The value returned in LISTIDX is 3; because "N" is the first character in the parameter INPUT from the selection list starting from the beginning.
PFADIDX = INDEX (INPUT, "/") +1	; Therefore the following applies: PFADIDX = 1
PROGIDX = RINDEX (INPUT, "/") +1	; Therefore the following applies: PROGIDX = 12
	; The SUBSTR function introduced in the next section can be used to break-up variable INPUT into the components "path" and "module":
VARIABLE = SUBSTR (INPUT, PFADIDX, PROGIDX-PFADIDX-1)	; Then returns "_N_MPF_DIR"
VARIABLE = SUBSTR (INPUT, PROGIDX)	; Then returns "_N_EXECUTE_MPF"

3.1.4.7 Selection of a substring (SUBSTR)

Arbitrary parts within a string can be read with the SUBSTRING function.

Syntax

```
<STRING_RES>=SUBSTR(<string>,<index>,<length>)
<STRING_RES>=SUBSTR(<string>,<index>)
```

Meaning

SUBSTR:	This function returns a substring from <string>, starting with <index> with the specified <length>. If the parameter <length> is not specified, the function returns a substring starting with <index> until the end of the string.
<index>:	Start position of the substring within the string. If the start position is after the end of the string, an empty string (" ") is returned. First character of the string: Index = 0 Range of values: 0 ... (string length - 1)
<length>:	Length of the substring. If too long a length is specified, only the substring up to the end of the string is returned. Range of values: 1 ... (string length - 1)

Example

Program code	Comment
DEF STRING[29] RES	
;	1
;	0123456789012345678
RES = SUBSTR("QUITTING: 10 to 99", 10, 2)	; RES == "10"
RES = SUBSTR("QUITTING: 10 to 99", 10)	; RES == "10 to 99"

3.1.4.8 Reading and writing of individual characters

Individual characters can be read and written within a string.

The following supplementary conditions must be observed:

- Only possible with user-defined variables, not with system variables
- Individual characters of a string are only transferred "call by value" for subprogram calls

Syntax

```
<Character>=<string>[<index>]
<Character>=<string_array>[<array_index>,<index>]
<String>[<index>]=<character>
<String_array>[<array_index>,<index>]=<character>
```

Meaning

<string>:	Any string
<character>:	Variable of type CHAR
<index>:	Position of the character within the string. First character of the string: Index = 0 Range of values: 0 ... (string length - 1)

Examples

Example 1: Variable message

Program code	Comment
;	0123456789
DEF STRING [50] MESSAGE = "Axis n has reached position"	
MESSAGE [6] = "X"	
MSG (MESSAGE)	; "Axis X has reached position"

Example 2: Evaluating a system variable

Program code	Comment
DEF STRING[50] STRG	; Buffer for system variable
...	

Program code	Comment
STRG = \$P_MMCA	; Load system variable
IF STRG[0] == "E" GOTO ...	; Evaluating the system variable

Example 3: Parameter transfer "call by value" and "call by reference"

Program code	Comment
; 0123456	
DEF STRING[50] STRG = "Axis X"	
DEF CHAR CHR	
...	
EXTERN UP_VAL (ACHSE)	; Definition of subprogram with "call by value" parameters
EXTERN UP_REF (VAR ACHSE)	; Definition of subprogram with "call by reference" parameters
...	
UP_VAL (STRG[6])	; Parameter transfer "by value"
...	
CHR = STRG[6]	; Buffer
UP_REF (CHR)	; Parameter transfer "by reference"

3.1.4.9 Formatting a string (SPRINT)

Using the pre-defined SPRINT function, character strings can be formatted and e.g. prepared for output on external devices (also see "Process DataShare - Output to an external device/file (EXTOPEN, WRITE, EXTCLOSE): (Page 1040)").

Syntax

```
"<Result_string>"=SPRINT("<Format_string>", <value_1>, <value_2>, ..., <value_n>)
```

Meaning

SPRINT:	Identifier for a pre-defined function that supplies a value, type STRING.
"<Format_String>":	Character string that contains fixed and variable elements. The variable elements are defined using the format control character % and a subsequent format description.
< value_1>, < value_2>, ..., < value_n>:	Value in the form of a constant or NC variables, which is inserted at the location where the nth format control character % is located, corresponding to the format description in the <format_string>.
"<result_string>":	Formatted character string (maximum 400 bytes)

Format descriptions available

%B:	<p>Conversion into the "TRUE" string, if the value to be converted:</p> <ul style="list-style-type: none"> • Is not equal to 0. • Is not an empty string (for string values). <p>Conversion into the "FALSE" string, if the value to be converted:</p> <ul style="list-style-type: none"> • Is equal to 0. • Is an empty string. <p>Example:</p> <pre>N10 DEF BOOL BOOL_VAR=1 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF BOOL_VAR:%B", BOOL_VAR)</pre> <p>Result: The character string "CONTENT OF BOOL_VAR:TRUE" is written to the RESULT string variable.</p>
%C:	<p>Conversion into an ASCII character.</p> <p>Example:</p> <pre>N10 DEF CHAR CHAR_VAR="X" N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF CHAR_VAR:%C", CHAR_VAR)</pre> <p>Result: The character string "CONTENT OF CHAR_VAR:X" is written to the string variable RESULT.</p>
%D:	<p>Conversion into a string with an integer value (INTEGER).</p> <p>Example:</p> <pre>N10 DEF INT INT_VAR=123 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF INT_VAR:%D", INT_VAR)</pre> <p>Result: The character string "CONTENT OF INT_VAR:123" is written to the string variable RESULT.</p>
%<m>D:	<p>Conversion into a string with an integer value (INTEGER). The string has a minimum length of <m> characters. The missing locations are filled with spaces, left-justified.</p> <p>Example:</p> <pre>N10 DEF INT INT_VAR=-123 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF INT_VAR:%6D", INT_VAR)</pre> <p>Result: The character string "CONTENT OF INT_VAR:xx-123" is written to string variable RESULT ("x" in the example represents spaces).</p>
%F:	<p>Conversion into a string with a decimal number with 6 decimal places. Where relevant, the decimal places are rounded-off or filled with 0.</p> <p>Example:</p> <pre>N10 DEF REAL REAL_VAR=-1.2341234EX+03 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%F", REAL_VAR)</pre> <p>Result: The string variable RESULT is written with the character string "CONTENT OF REAL_VAR: -1234.123400".</p>

%<m>F:	<p>Conversion into a string with a decimal number with 6 decimal places and a total length of at least <m> characters. Where relevant, the decimal places are rounded-off or filled with 0. Missing characters are filled up to the total length <m> using spaces, left-justified.</p> <p>Example: N10 DEF REAL REAL_VAR=-1.23412345678EX+03 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%15F",REAL_VAR)</p> <p>Result: The string variable RESULT is written with the character string "CONTENT OF REAL_VAR: xxx-1234.123457" (where "x" is a placeholder for space).</p>
%.<n>F:	<p>Conversion into a string with a decimal number with <n> decimal places. Where relevant, the decimal places are rounded-off or filled with 0.</p> <p>Example: N10 DEF REAL REAL_VAR=-1.2345678EX+03 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%.3F",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:-1234.568" is written to the string variable RESULT.</p>
%<m>.<n>F:	<p>Conversion into a string with a decimal number with <n> decimal places and a total length of at least <m> characters. Where relevant, the decimal places are rounded-off or filled with 0. Missing characters are filled up to the total length <m> using spaces, left-justified.</p> <p>Example: N10 DEF REAL REAL_VAR=-1.2341234567890EX+03 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%10.2F",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xx-1234.12" is written to the string variable RESULT ("x" in the example represents spaces).</p>
%E:	<p>Conversion into a string with a decimal number in the exponential representation. The mantissa is saved, normalized with one pre-decimal place and 6 decimal places. Where relevant, the decimal places are rounded-off or filled with 0. The exponent starts with the keyword "EX". It is followed by the sign ("+" or "-") and a two or three-digit number.</p> <p>Example: N10 DEF REAL REAL_VAR=-1234.567890 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%E",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:-1.234568EX+03" is written to the string variable RESULT.</p>
%<m>E:	<p>Conversion into a string with a decimal number in the exponential representation and a total length of at least <m> characters. The missing characters are filled with spaces, left-justified. The mantissa is saved, normalized with one pre-decimal place and 6 decimal places. Where relevant, the decimal places are rounded-off or filled with 0. The exponent starts with the keyword "EX". It is followed by the sign ("+" or "-") and a two or three-digit number.</p> <p>Example: N10 DEF REAL REAL_VAR=-1234.5 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%20E",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xxxxxx-1.234500EX+03" is written to the string variable RESULT ("x" in the example represents spaces).</p>

<p>%.<n>E:</p>	<p>Conversion into a string with a decimal number in the exponential representation. The mantissa is saved, normalized with one pre-decimal place and <n> decimal places. Where relevant, the decimal places are rounded-off or filled with 0. The exponent starts with the keyword "EX". It is followed by the sign ("+" or "-") and a two or three-digit number.</p> <p>Example: N10 DEF REAL REAL_VAR=-1234.5678 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%.2E", REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:-1.23EX+03" is written to the string variable RESULT.</p>
<p>%<m>.<n>E:</p>	<p>Conversion into a string with a decimal number in the exponential representation and a total length of at least <m> characters. The missing characters are filled with spaces, left-justified. The mantissa is saved, normalized with one pre-decimal place and <n> decimal places. Where relevant, the decimal places are rounded-off or filled with 0. The exponent starts with the keyword "EX". It is followed by the sign ("+" or "-") and a two or three-digit number.</p> <p>Example: N10 DEF REAL REAL_VAR=-1234.5678 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%12.2E", REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xx-1.23EX+03" is written to the string variable RESULT ("x" in the example represents spaces).</p>
<p>%G:</p>	<p>Conversion into a string with a decimal number – depending on the value range – in a decimal or exponential representation: If the absolute value to be represented is less than 1.0EX-04 or greater than/equal to 1.0EX+06, then the exponential notation is selected, otherwise the decimal notation. A maximum of six significant places are displayed or if required, rounded-off.</p> <p>Example with decimal notation: N10 DEF REAL REAL_VAR=1.234567890123456EX-04 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%G", REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:0.000123457" is written to the string variable RESULT.</p> <p>Example with exponential notation: N10 DEF REAL REAL_VAR=1.234567890123456EX+06 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%G", REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:1.23457EX+06" is written to the string variable RESULT.</p>

%<m>G:	<p>Conversion into a string with a decimal number – depending on the value range – in a decimal or exponential notation (like %G). The string has a total length of at least <m> characters. The missing characters are filled with spaces, left-justified.</p> <p>Example with decimal notation: N10 DEF REAL REAL_VAR=1.234567890123456EX-04 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%15G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xxxx0.000123457" is written to the string variable RESULT ("x" in the example represents spaces).</p> <p>Example with exponential notation: N10 DEF REAL REAL_VAR=1.234567890123456EX+06 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%15G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xxx1.23457EX+06" is written to the string variable RESULT ("x" in the example represents spaces).</p>
%.<n>G:	<p>Conversion into a string with a decimal number – depending on the value range – in a decimal or exponential representation. A maximum of <n> significant places are displayed or if required, rounded-off. If the absolute value to be represented is less than 1.0EX-04 or greater than/equal to 1.0EX(+<n>), then the exponential notation is selected, otherwise the decimal notation.</p> <p>Example with decimal notation: N10 DEF REAL REAL_VAR=1.234567890123456EX-04 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%.3G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:0.000123" is written to the string variable RESULT.</p> <p>Example with exponential notation: N10 DEF REAL REAL_VAR=1.234567890123456EX+03 N20 DEF STRING[80] RESULT N30 RESULT = SPRINT("CONTENT OF REAL_VAR:%.3G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:1.23EX+03" is written to the string variable RESULT.</p>
%<m>.<n>G:	<p>Conversion into a string with a decimal number – depending on the value range – in a decimal or exponential notation (like %.<n>G). The string has a total length of at least <m> characters. The missing characters are filled with spaces, left-justified.</p> <p>Example with decimal notation: N10 DEF REAL REAL_VAR=1.234567890123456EX-04 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%12.4G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xxx0.0001235" is written to the string variable RESULT ("x" in the example represents spaces).</p> <p>Example with exponential notation: N10 DEF REAL REAL_VAR=1.234567890123456EX+04 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF REAL_VAR:%12.4G",REAL_VAR)</p> <p>Result: The character string "CONTENT OF REAL_VAR:xx1.235EX+06" is written to the string variable RESULT ("x" in the example represents spaces).</p>

%.<n>P:	<p>Converting a REAL value into an INTEGER value taking into account <n> decimal places. The INTEGER value is output as a 32-bit binary number. If the value to be converted cannot be represented with 32 bits, then processing is interrupted with an alarm.</p> <p>As a byte sequence generated using the format statement %.<n>P can also contain binary zeroes, then the total string that is generated in this way no longer corresponds to the conventions of the NC data type STRING. As a consequence, it can neither be saved in a variable, type STRING, nor be further processed using the string commands of the NC language. The only possible use is to transfer the parameter to the WRITE command with output at an appropriate external device (see the following example).</p> <p>As soon as the <Format_String> contains a format description, type %P then the complete string, with the exception of the binary number generated with %.<n>P, is output corresponding to the MD10750 \$MN_SPRINT_FORMAT_P_CODE in the ASCII character code, ISO (DIN6024) or EIA (RS244). If a character that cannot be converted is programmed, then processing is interrupted with an alarm.</p> <p>Example:</p> <pre> N10 DEF REAL REAL_VAR=123.45 N20 DEF INT ERROR N30 DEF STRING[20] EXT_DEVICE="/ext/dev/1" ... N100 EXTOPEN(ERROR,EXT_DEVICE) N110 IF ERROR <> 0 ... ; error handling N200 WRITE(ERROR,EXT_DEVICE,SPRINT("INTEGER BINARY CODED:%.3P",REAL_VAR) N210 IF ERROR <> 0 ... ; error handling </pre> <p>Result: The string "INTEGER BINARY CODED: 'H0001E23A'" is transferred to the output device /ext/dev/1. The hexadecimal value 0x0001E23A corresponds to the decimal value 123450.</p>
---------	---

%<m>.<n>P:	<p>Conversion of a REAL value corresponding to the setting in machine data MD10751 \$MN_SPRINT_FORMAT_P_DECIMAL into a string with:</p> <ul style="list-style-type: none"> • An integer of <m> + <n> places or • A decimal number with a maximum of <m> pre-decimal places and precisely <n> decimal places. <p>Just the same as for the format description %.<n>P, the complete string is saved in the character code defined by MD10750 \$MN_SPRINT_FORMAT_P_CODE.</p> <p>Conversion for MD10751 = 0:</p> <p>The REAL value is converted into a string with an integer number of <m> + <n> places. If required, decimal places are rounded-off to <n> places or filled with 0. The missing pre-decimal places are filled with spaces. The minus sign is attached, left-justified; a space is entered instead of the plus sign.</p> <p>Example:</p> <pre>N10 DEF REAL REAL_VAR=-123.45 N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("PUNCHED TAPE FORMAT:%5.3P",REAL_VAR)</pre> <p>Result: The character string "PUNCHED TAPE FORMAT:-xx123450" is written to the string variable RESULT ("x" in the example represents spaces).</p> <p>Conversion for MD10751 = 1:</p> <p>The REAL value is converted into a string with a decimal number with a maximum of <m> pre-decimal places and precisely <n> decimal places. Where necessary, the pre-decimal places are cut-off and the decimal places are rounded-off or filled with 0. If <n> is equal to 0, then the decimal point is also omitted.</p> <p>Example:</p> <pre>N10 DEF REAL REAL_VAR1=-123.45 N20 DEF REAL REAL_VAR2=123.45 N30 DEF STRING[80] RESULT N40 RESULT=SPRINT("PUNCHED TAPE FORMAT:%5.3P VAR2:%2.0P", REAL_VAR1,REAL_VAR2)</pre> <p>Result: The character string "PUNCHED TAPE FORMAT:-123.450 VAR2:23" is written to the string variable RESULT.</p>
%S:	<p>Inserting a string.</p> <p>Example:</p> <pre>N10 DEF STRING[16] STRING_VAR="ABCDEFGH" N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF STRING_VAR:%S",STRING_VAR)</pre> <p>Result: The character string "CONTENT OF STRING_VAR:ABCDEFGH" is written to the string variable RESULT.</p>
%<m>S:	<p>Inserting a string with a minimum of <m> characters. The missing places are filled with spaces.</p> <p>Example:</p> <pre>N10 DEF STRING[16] STRING_VAR="ABCDEFGH" N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF STRING_VAR:%10S",STRING_VAR)</pre> <p>Result: The character string "CONTENT OF STRING_VAR:xxxABCDEFGH" is written to the string variable RESULT ("x" in the example represents spaces).</p>

<p><code>%.<n>S:</code></p>	<p>Inserting <n> characters of a string (starting with the first character).</p> <p>Example:</p> <pre>N10 DEF STRING[16] STRING_VAR="ABCDEFGH" N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF STRING_VAR:%.3S",STRING_VAR)</pre> <p>Result: The character string "CONTENT OF STRING_VAR:ABC" is written to the string variable RESULT.</p>
<p><code>%<m>.<n>S:</code></p>	<p>Inserting <n> characters of a string (starting with the first character). The total length of the generated string has at least <m> characters. The missing places are filled with spaces.</p> <p>Example:</p> <pre>N10 DEF STRING[16] STRING_VAR="ABCDEFGH" N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("CONTENT OF STRING_VAR:%10.5S", STRING_VAR)</pre> <p>Result: The character string "CONTENT OF STRING_VAR:xxxxxABCDE" is written to the string variable RESULT ("x" in the example represents spaces).</p>
<p><code>%X:</code></p>	<p>Converting an INTEGER value into a string with the hexadecimal notation.</p> <p>Example:</p> <pre>N10 DEF INT INT_VAR='HA5B8' N20 DEF STRING[80] RESULT N30 RESULT=SPRINT("INTEGER HEXADECIMAL:%X",INT_VAR)</pre> <p>Result: The character string "INTEGER HEXADECIMAL:A5B8" is written to the string variable RESULT.</p>

Note

A property of the NC language, where a distinction is not made between uppercase and lowercase letters for identifiers and keywords, also applies to the format descriptions. As a consequence, you can program using either lowercase or uppercase letters without any functional difference.

Combination options

The following table provides information as to which NC data types can be combined with which format description. The rules regarding implicit data type conversion apply (see "Data types (Page 413)").

	NC data types						
	BOOL	CHAR	INT	REAL	STRING	AXIS	FRAME
%B	+	+	+	+	+	-	-
%C	-	+	-	-	+	-	-
%D	+	+	+	+	-	-	-
%F	-	-	+	+	-	-	-
%E	-	-	+	+	-	-	-
%G	-	-	+	+	-	-	-
%S	-	+	-	-	+	-	-
%X	+	+	+	-	-	-	-
%P	-	-	+	+	-	-	-

Note

The table indicates that the NC data types AXIS and FRAME cannot be directly used in the SPRINT function. However it is possible:

- To convert the AXIS data type into a string using the AXSTRING function – which can then be processed with SPRINT.
- To read the individual values of the FRAME data type per frame component access. As a consequence, a REAL data type is obtained, which can be processed with SPRINT.

3.1.5 Program jumps and branches

3.1.5.1 Return jump to the start of the program (GOTOS)

The GOTOS command can be used to jump back to the beginning of a main or subprogram in order to repeat the program.

Machine data can be used to set that for every return jump is made to the program start:

- The program runtime is set to "0".
- Workpiece counting is incremented by the value "1".

Syntax

GOTOS

Meaning

GOTOS:	Jump statement where the destination is the beginning of the program.	
	The execution is controlled via the NC/PLC interface signal: DB21, to DBX384.0 (control program branching)	
	Value:	Meaning:
	0	No return jump to the beginning of the program. Program execution is resumed with the next part program block after GOTOS.
	1	Return jump to the beginning of the program. The part program is repeated.

Supplementary conditions

- GOTOS internally initiates a STOPRE (pre-processing stop).
- For a subprogram with data definitions (LUD variables) with the GOTOS, a jump is made to the first program block after the definition section, i.e. data definitions are not executed again. This is the reason that the defined variables retain the value reached in the GOTOS block and are not reset to the standard values programmed in the definition section.
- The GOTOS command is not available in synchronized actions and technology cycles.

Example

Program code	Comment
N10 ...	; Start of the program.
...	
N90 GOTOS	; Jump to beginning of the program.
...	

3.1.5.2 Program jumps to jump markers (GOTOB, GOTOF, GOTO, GOTOC)

Jump labels can be set in a program, which can be jumped to from another location within the same program using the commands `GOTOF`, `GOTOB`, `GOTO`, or `GOTOC`. Program execution is resumed with the statement that immediately follows the jump label. This means that branches can be realized within the program.

In addition to jump labels, main and sub-block numbers are possible as jump designation.

If a jump condition (`IF ...`) is formulated before the jump statement, the program jump is only executed if the jump condition is fulfilled.

Syntax

```
GOTOB <jump destination>
IF <jump condition> == TRUE GOTOB <jump destination>
```

```
GOTOF <jump destination>
IF <jump condition> == TRUE GOTOF <jump destination>
```

```
GOTO <jump destination>
IF <jump condition> == TRUE GOTO <jump destination>
```

```
GOTOC <jump destination>
IF <jump condition> == TRUE GOTOC <jump destination>
```

Meaning

GOTOB:	Jump statement with jump destination toward the beginning of the program.
GOTOF:	Jump statement with jump destination toward the end of the program.
GOTO:	Jump statement with jump destination search. The search is first made in the direction of the end of the program, then in the direction of the beginning of the program.
GOTOC:	Same effect as for GOTO with the difference that Alarm 14080 "Jump designation not found" is suppressed. This means that program execution is not interrupted in the case that the jump destination search is unsuccessful – but is continued with the program line following the GOTOC command.

<jump destination>:	Jump destination parameter Possible data include:	
	<jump label>:	Jump destination is the jump label set in the program with a user-defined name:<jump label>:
	<block number>:	Jump destination is main block or sub-block number (e.g.: 200, N300)
	STRING type variable:	Variable jump destination. The variable stands for a jump label or a block number.
IF:	Keyword to formulate the jump condition. The jump condition permits all comparison and logical operations (result: TRUE or FALSE). The program jump is executed if the result of this operation is TRUE.	

Note**Jump labels**

Jump labels are always located at the beginning of a block. If a program number exists, the jump label is located immediately after the block number.

The following rules apply when naming jump labels:

- Number of characters:
 - Minimum 2
 - Maximum 32
- Permissible characters are:
 - Letters
 - Numbers
 - Underscores
- The first two characters must be letters or underscores.
- The name of the jump label is followed by a colon (":").

Supplementary conditions

- The jump destination can only be a block with jump label or block number that is located **within** the program.
- A jump statement without jump condition must be programmed in a separate block. This restriction does not apply to jump statements with jump conditions. In this case, several jump statements can be formulated in a block.
- For programs with jump statements without jump conditions, the end of the program M2/M30 does not necessarily be at the end of the program.

Examples**Example 1: Jumps to jump labels**

Program code	Comment
N10 ...	

3.1 Flexible NC programming

Program code	Comment
N20 GOTOF Label_1	; Jump toward end of program to ; jump label "Label_1".
N30 ...	
N40 Label_0: R1=R2+R3	; Jump label "Label_0" set.
N50 ...	
N60 Label_1:	; Jump label "Label_1" set.
N70 ...	
N80 GOTOB Label_0	; Jump toward beginning of program ; to the jump label "Label_0."
N90 ...	

Example 2: Indirect jump to the block number

Program code	Comment
IF <condition> == TRUE	
R10=100	; Assign jump destination
ELSE	
R10=110	; Assign jump destination
ENDIF	
	; Jump toward end of program to the block whose block number is located in R10
N10 GOTOF "N"<<R10	
...	
N90 ...	
N100 ...	; Jump destination
N110 ...	
...	

Example 3: Jump to variable jump destination

Program code	Comment
DEF STRING[20] DESTINATION	
IF <condition> == TRUE	
DESTINATION = "Label1"	; Assign jump destination
ELSE	
DESTINATION = "Label2"	; Assign jump destination
ENDIF	
	; Jump toward end of program to the variable jump destination "Content of DESTINATION."
GOTOF DESTINATION	
Label1: T="Drill1"	; Jump destination 1
...	
Label2: T="Drill2"	; Jump destination 2
...	

Example 4: Jump with jump condition

Program code	Comment
N40 R1=30 R2=60 R3=10 R4=11 R5=50 R6=20	; Assignment of the initial values
N41 LA1: G0 X=R2*COS(R1)+R5 Y=R2*SIN(R1)+R6	; Jump label LA1
N42 R1=R1+R3 R4=R4-1	
; IF jump condition == TRUE	
; THEN jump toward beginning of program to the jump label LA1	
N43 IF R4>0 GOTOB LA1	
N44 M30	; End of program

3.1.5.3 Program branch (CASE ... OF ... DEFAULT ...)

The CASE function provides the possibility of checking the actual value (type: INT) of a variable or an arithmetic function and, depending on the result, to jump to different positions in the program.

Syntax

```
CASE(<expression>) OF <constant_1> GOTOF <jump target_1>
<constant_2> GOTOF <jump target_2> ... DEFAULT GOTOF <jump target_n>
```

Meaning

CASE:	Jump statement
<expression>:	Variable or arithmetic function
OF:	Keyword to formulate conditional program branches.
<constant_1>:	First specified constant value for the variable or arithmetic function
	Type: INT
<constant_2>:	Second specified constant value for the variable or arithmetic function
	Type: INT
DEFAULT:	For the cases where the variable or arithmetic function does not assume any of the specified constant values, the DEFAULT statement can be used to determine the jump target. Note: If the DEFAULT statement is not programmed, then in these cases, the block following the CASE statement is the jump target.
GOTOF:	Jump statement with jump target towards the end of the program. Instead of GOTOF all other GOTO commands can be programmed (refer to the subject "Program jumps to jump markers").

<jump target_1>:	A branch is made to this jump target if the value of the variable or arithmetic function corresponds to the first specific constant. The jump target can be specified as follows:	
	<jump marker>:	Jump target is the jump marker (label) set in the program with a user-defined name: <jump marker>:
	<block number>:	Jump target is main block or sub-block number (e.g.: 200, N300)
	STRING type variable:	Variable jump target. The variable stands for a jump marker or a block number.
<jump target_2>:	A branch is made to this jump target if the value of the variable or arithmetic function corresponds to the second specified constant.	
<jump target_n>:	A branch is made to this jump target if the value of the variable does not assume the specified constant value.	

Example

Program code

```

...
N20 DEF INT VAR1 VAR2 VAR3
N30 CASE (VAR1+VAR2-VAR3) OF 7 GOTOF Label_1 9 GOTOF Label_2
    DEFAULT GOTOF Label_3
N40 Label_1: G0 X1 Y1
N50 Label_2: G0 X2 Y2
N60 Label_3: G0 X3 Y3
...

```

The CASE statement from N30 defines the following program branch possibilities:

1. If the value of the arithmetic function $VAR1+VAR2-VAR3 = 7$, then jump to the block with the jump marker definition "Label_1" (\rightarrow N40).
2. If the value of the arithmetic function $VAR1+VAR2-VAR3 = 9$, then jump to the block with the jump marker definition "Label_2" (\rightarrow N50).
3. If the value of the arithmetic function $VAR1+VAR2-VAR3$ is neither 7 nor 9, then jump to the block with the jump marker definition "Label_3" (\rightarrow N60).

3.1.6 Repeat program section (REPEAT, REPEATB, ENDLABEL, P)

Program section repetition allows you to repeat existing program sections within a program in any order.

The program lines or program sections to be repeated are identified by jump markers (labels).

Note

Jump markers (labels)

Jump markers are always located at the beginning of a block. If a program number exists, the jump marker is located immediately after the block number.

The following rules apply when naming jump markers:

- Number of characters:
 - Minimum 2
 - Maximum 32
 - Permissible characters are:
 - Letters
 - Numbers
 - Underscores
 - The first two characters must be letters or underscores.
 - The name of the jump marker is followed by a colon (":").
-

Syntax

1. Repeat individual program line:

```
<jump marker>: ...  
...  
REPEATB <jump marker> P=<n>  
...
```

2. Repeat program section between jump marker and REPEAT statement:

```
<jump marker>: ...  
...  
REPEAT <jump marker> P=<n>  
...
```

3. Repeat section between two jump markers:

```
<start jump marker>: ...  
...  
<end jump marker>: ...  
...  
REPEAT <start jump marker> <end jump marker> P=<n>  
...
```

Note

It is not possible to nest the REPEAT statement with the two jump markers in parentheses. If the <start jump marker> appears before the REPEAT statement and the <end jump marker> is not reached before the REPEAT statement, the section between the <start jump marker> and the REPEAT statement will be repeated.

4. Repeat section between jump marker and ENDLABEL:

```
<jump marker>: ...
...
ENDLABEL: ...
...
REPEAT <jump marker> P=<n>
...
```

Note

It is not possible to nest the REPEAT statement with the <jump marker> and the ENDLABEL in parentheses. If the <jump marker> appears before the REPEAT statement and the ENDLABEL is not reached before the REPEAT statement, the section between the <jump marker> and the REPEAT statement will be repeated.

Meaning

REPEATB:	Command for repeating a program line
REPEAT:	Command for repeating a program section
<jump marker>:	<p>The <jump marker> identifies:</p> <ul style="list-style-type: none"> • The program line to be repeated (in the case of REPEATB) or • The start of the program section to be repeated (in the case of REPEAT) <p>The program line identified by the <jump marker> can appear before or after the REPEAT/REPEATB statement. The search initially commences toward the start of the program. If the jump marker is not found in this direction, the search continues working toward the end of the program.</p> <p>Exception: If the program section between the jump marker and the REPEAT statement needs to be repeated (see 2. under Syntax), the program line identified by the <jump marker> has to appear before the REPEAT statement, since in this case the search runs only toward the beginning of the program. If the line with the <jump marker> contains further operations, these are executed again on each repetition.</p>
ENDLABEL:	<p>Keyword marking the end of a program section to be repeated.</p> <p>If the line with the ENDLABEL contains further operations, these are executed again on each repetition.</p> <p>ENDLABEL can be used more than once in the program.</p>

P:	Address for specifying the number of repetitions	
<n>:	Number of program section repetitions	
	Type:	INT
<p>The program section to be repeated is repeated <n> times. After the last repetition, the program is resumed at the line following the REPEAT/REPEATB line.</p> <p>Note: In the absence of a number being specified for P=<n>, the program section is repeated just once.</p>		

Examples

Example 1: Repeat individual program line

Program code	Comment
N10 POSITION1: X10 Y20	
N20 POSITION2: CYCLE(0,,9,8)	;Position cycle
N30 ...	
N40 REPEATB POSITION1 P=5	; Execute BLOCK N10 five times.
N50 REPEATB POSITION2	; Execute block N20 once.
N60 ...	
N70 M30	

Example 2: Repeat program section between jump marker and REPEAT statement:

Program code	Comment
N5 R10=15	
N10 Begin: R10=R10+1	;Width
N20 Z=10-R10	
N30 G1 X=R10 F200	
N40 Y=R10	
N50 X=-R10	
N60 Y=-R10	
N70 Z=10+R10	
N80 REPEAT BEGIN P=4	; Execute section from N10 to N70 four times.
N90 Z10	
N100 M30	

Example 3: Repeat section between two jump markers

Program code	Comment
N5 R10=15	
N10 Begin: R10=R10+1	;Width
N20 Z=10-R10	
N30 G1 X=R10 F200	
N40 Y=R10	
N50 X=-R10	

3.1 Flexible NC programming

Program code	Comment
N60 Y--R10	
N70 END: Z=10	
N80 Z10	
N90 CYCLE(10,20,30)	
N100 REPEAT BEGIN END P=3	; Execute section from N10 to N70 three times.
N110 Z10	
N120 M30	

Example 4: Repeat section between jump marker and ENDLABEL

Program code	Comment
N10 G1 F300 Z-10	
N20 BEGIN1:	
N30 X10	
N40 Y10	
N50 BEGIN2:	
N60 X20	
N70 Y30	
N80 ENDLABEL: Z10	
N90 X0 Y0 Z0	
N100 Z-10	
N110 BEGIN3: X20	
N120 Y30	
N130 REPEAT BEGIN3 P=3	; Execute section from N110 to N120 three times.
N140 REPEAT BEGIN2 P=2	; Execute section from N50 to N80 twice.
N150 M100	
N160 REPEAT BEGIN1 P=2	; Execute section from N20 to N80 twice.
N170 Z10	
N180 X0 Y0	
N190 M30	

Example 5: Milling, machine drill position with different technologies

Program code	Comment
N10 CENTER DRILL()	; Load centering drill.
N20 POS_1:	;Drilling positions 1
N30 X1 Y1	
N40 X2	
N50 Y2	
N60 X3 Y3	
N70 ENDLABEL:	
N80 POS_2:	;Drilling positions 2
N90 X10 Y5	
N100 X9 Y-5	
N110 X3 Y3	

Program code	Comment
N120 ENDLABEL:	
N130 DRILL()	; Change drill and drilling cycle.
N140 THREAD(6)	; Load tap M6 and threading cycle.
N150 REPEAT POS_1	; Repeat program section once from POS_1 up to ENDLABEL.
N160 DRILL()	; Change drill and drilling cycle.
N170 THREAD(8)	; Load tap M8 and threading cycle.
N180 REPEAT POS_2	; Repeat program section once from POS_2 up to ENDLABEL.
N190 M30	

Further information

- Program section repetitions can be nested. Each call uses a subprogram level.
- If M17 or RET is programmed during processing of a program section repetition, the repetition is canceled. The program is resumed at the block following the REPEAT line.
- In the actual program display, the program section repetition is displayed as a separate subprogram level.
- If the level is canceled during the program section repetition, the program resumes at the point after the program section repetition call.
Example:

Program code	Comments
N5 R10=15	
N10 BEGIN: R10=R10+1	;Width
N20 Z=10-R10	
N30 G1 X=R10 F200	
N40 Y=R10	; Interrupt level
N50 X=-R10	
N60 Y=-R10	
N70 END: Z10	
N80 Z10	
N90 CYCLE(10,20,30)	
N100 REPEAT BEGIN END P=3	
N120 Z10	; Resume program execution.
N130 M30	

- Check structures and program section repetitions can be used in combination. There should be no overlap between the two, however. A program section repetition should appear within a check structure branch or a check structure should appear within a program section repetition.
- If jumps and program section repetitions are mixed, the blocks are executed purely sequentially. For example, if a jump is performed from a program section repetition, processing continues until the programmed end of the program section is found.
Example:

Program code

```
N10 G1 F300 Z-10
N20 BEGIN1:
N30 X=10
N40 Y=10
N50 GOTOF BEGIN2
N60 ENDLABEL:
N70 BEGIN2:
N80 X20
N90 Y30
N100 ENDLABEL: Z10
N110 X0 Y0 Z0
N120 Z-10
N130 REPEAT BEGIN1 P=2
N140 Z10
N150 X0 Y0
N160 M30
```

Note

The REPEAT statement should appear after the traversing block.

3.1.7 Check structures

The control processes the NC blocks as standard in the programmed sequence.

This sequence can be variable by programming alternative program blocks and program loops. These check structures are programmed using the key words IF, ELSE, ENDF, LOOP, FOR, WHILE and REPEAT.

NOTICE

Programming error

Check structures may only be inserted in the statement section of a program. Definitions in the program header may not be executed conditionally or repeatedly.


It is not permissible to superimpose macros on keywords for check structures or on jump targets. No such check is made when the macro is defined.

Effectiveness

The check structure cannot be used program-wide.

Nesting depth

A nesting depth of up to 16 check structures can be set up on each subprogram level.



Runtime response

In interpreter mode (active as standard), it is possible to shorten program processing times more effectively by using program branches than can be obtained with check structures.

There is no difference between program branches and check structures in precompiled cycles.

Current block display for program loops

If only selected blocks are executed within a program loop, the last main run block **before** the program loop is shown in the current block display.

So that the processed selected blocks are also visible in the current block display, e.g. for diagnostic purposes, the decoding single block SBL2 must be activated.

References

Function Manual, Basic Functions, Section: Mode group, channel, program operation, reset response (K1) > Single block > Decoding single block SBL2 with implicit preprocessing stop

Grinding without main run block

If, within a program loop, no main run block has been programmed, then the loop is pre-processed until the loop condition is satisfied.

As a consequence, a high level of utilization can occur and this can have a negative impact on the display.

The STOPRE command or a dwell time G04 of 0 seconds can be inserted **in** the loop as countermeasure.

Supplementary conditions

- Blocks with check structure elements cannot be suppressed.
- Jumper markers (labels) are not permitted in blocks with check structure elements.
- Check structures are processed interpretively. When a loop end is detected, a search is made for the loop beginning, allowing for the check structures found in the process. For this reason, the block structure of a program is not checked completely in interpreter mode.
- It is not generally advisable to use a mixture of check structures and program branches.
- A check can be made to ensure that check structures are nested correctly when cycles are preprocessed.

3.1.7.1 Conditional statement and branch (IF, ELSE, ENDIF)

Conditional statement: IF - program block - ENDIF

With a conditional statement, the program block between `IF` and `ENDIF` is only executed when the condition is satisfied.

Branch: IF - program block_1 - ELSE - program block_2 - ENDIF

With a branch, one of two program blocks is always executed.

If the condition is satisfied, program block_1 between `IF` and `ELSE` is executed.

If the condition is **not** satisfied, program block_2 between `ELSE` and `ENDIF` is executed.

Note

ELSE in synchronized actions

The keyword `ELSE` can also be programmed in synchronized actions. Thus a synchronized action can be expanded by actions that are to be executed if the condition is not fulfilled.

Syntax

Conditional statement

```
IF <condition>  
    Program block                               ; Execution with: <Condition> == TRUE  
ENDIF
```

Branch

```
IF <condition>  
    Program block_1                             ; Execution with: <Condition> == TRUE  
ELSE  
    Program block_2                             ; Execution with: <Condition> == FALSE  
ENDIF
```

Meaning

IF:	Introduces the conditional statement or branch.
ELSE:	Introduces the alternative program block.
ENDIF:	Marks the end of the conditional statement or branch.
<condition>:	Logical expression that is evaluated as TRUE or FALSE.

Example: Tool change subprogram

Program code	Comment
PROC L6	Tool change routine
N500 DEF INT TNR_AKTUELL	Variable for active T number
N510 DEF INT TNR_VORWAHL	Variable for preselected T number
N520 STOPRE	Determine current tool
N530 IF \$P_ISTEST	In the program test mode ...
N540 TNR_AKTUELL = \$P_TOOLNO	... the "current" tool is read from the program context.
N550 ELSE	Otherwise ...
N560 TNR_AKTUELL = \$TC_MPP6[9998,1]	... the tool of the spindle is read-out.
N570 ENDIF	
N580 GETSELT(TNR_VORWAHL)	Read the T number of the pre-selected tool in the spindle.
N590 IF TNR_AKTUELL <> TNR_VORWAHL	If the pre-selected tool is still not the current tool, then ...
N600 G0 G40 G60 G90 SUPA X450 Y300 Z300 D0	... Approach tool change position ...
N610 M206	... and perform a tool change.
N620 ENDIF	
N630 M17	

3.1.7.2 Continuous program loop (LOOP, ENDLOOP)

Endless loops are used in endless programs. At the end of the loop, there is always a branch back to the beginning.

Syntax

```

LOOP
...
ENDLOOP

```

Meaning

LOOP:	Initiates the endless loop.
ENDLOOP:	Marks the end of the loop and results in a return jump to the beginning of the loop.

Example

```

Program code
...
LOOP
MSG ("no tool cutting edge active")
M0
STOPRE
ENDLOOP
...
    
```

3.1.7.3 Count loop (FOR ... TO ..., ENDFOR)

The count loop is used if an operation must be repeated with a fixed number of runs.

Syntax

```

FOR <variable> = <initial value> TO <end value>
...
ENDFOR
    
```

Meaning

FOR:	Initiates the count loop.	
ENDFOR:	Marks the end of the loop and results in a return jump to the beginning of the loop, as long as the end value of the count has still not been reached.	
<variable>:	Count variable, which is incremented from the initial to the end value and is increased by the value "1" at each run.	
	Type	INT or REAL Note: The REAL type is used if R parameters are programmed for a count loop, for example. If the count variable is of the REAL type, its value is rounded to an integer.
<initial value>:	Initial value of the count Condition: The start value must be lower than the end value.	
<full-scale value>:	End value of the count	

Examples

Example 1: INTEGER variable or R parameter as count variable

INTEGER variable as count variable:

Program code	Comment
DEF INT iVARIABLE1	
R10=R12-R20*R1 R11=6	
FOR iVARIABLE1 = R10 TO R11	; Count variable = INTEGER variable
R20=R21*R22+R33	
ENDFOR	
M30	

R parameter as count variable:

Program code	Comment
R11=6	
FOR R10=R12-R20*R1 TO R11	; Count variable = R parameter (real variable)
R20=R21*R22+R33	
ENDFOR	
M30	

Example 2: Production of a fixed quantity of parts

Program code	Comment
DEF INT WKPCCOUNT	; Defines type INT variable with the name "WKPCCOUNT".
FOR WKPCCOUNT = 0 TO 100	; Initiates the count loop. The "WKPCCOUNT" variable increments from the initial value "0" to the end value "100".
G01 ...	
ENDFOR	; End of count loop
M30	

3.1.7.4 Program loop with condition at start of loop (WHILE, ENDWHILE)

For a WHILE loop, the condition is at the beginning of the loop. The WHILE loop is executed as long as the condition is fulfilled.

Syntax

```
WHILE <condition>
...
ENDWHILE
```

Meaning

WHILE:	Initiates the program loop.
ENDWHILE:	Marks the end of the loop and results in a return jump to the beginning of the loop.
<condition>:	The condition must be fulfilled so that the WHILE loop is executed.

Example

Program code	Comment
...	
WHILE \$AA_IW[DRILL_AXIS] > -10	; Call the WHILE loop under the following condition: The actual WCS setpoint for the drilling axis must be greater than -10.
G1 G91 F250 AX[DRILL_AXIS] = -1	
ENDWHILE	
...	

3.1.7.5 Program loop with condition at the end of the loop (REPEAT, UNTIL)

For a REPEAT loop, the condition is at the end of the loop. The REPEAT loop is executed once and repeated continuously until the condition is fulfilled.

Syntax

```
REPEAT
...
UNTIL <significance>
```

Meaning

REPEAT:	Initiates the program loop.
UNTIL:	Marks the end of the loop and results in a return jump to the beginning of the loop.
<condition>:	The condition that must be fulfilled so that the REPEAT loop is no longer executed.

Example

Program code	Comment
...	
REPEAT	; Call the REPEAT loop.
...	
UNTIL ...	; Check whether the condition is fulfilled.
...	

3.1.7.6 Program example with nested check structures

Program code	Comment
LOOP	
IF NOT \$P_SEARCH	; IF no block search
G1 G90 X0 Z10 F1000	
WHILE \$AA_IM[X] <= 100	; WHILE (setpoint X axis <= 100)
G1 G91 X10 F500	; Drilling pattern
Z-5 F100	
Z5	
ENDWHILE	
ELSE	; ELSE block search
MSG("No drilling during block search")	
ENDIF	; ENDIF
\$A_OUT[1] = 1	; Next drilling plate
G4 F2	
ENDLOOP	
M30	

3.1.8 Cross-channel program coordination (INIT, START, WAITM, WAITMC, WAITE, SETM, CLEARM)

In principle, a channel of the NC can execute the program started in it independently of other channels in its mode group. If, however, several programs in several channels of the mode group are involved in machining a workpiece, the program sequences in the various channels must be coordinated with the following coordination commands.

Requirement

All the channels involved in the program coordination must belong to the **same** mode group:
MD10010 \$MC_ASSIGN_CHAN_TO_MODE_GROUP[<Channel>] = <Mode group number>

Channel name instead of channel number

Instead of the channel numbers, the channel names entered in MD20000 \$MC_CHAN_NAME[<Channel index>] can be used as parameters of the predefined procedures for the program coordination. The use of the channel names in the NC programs first has to be enabled:

MD10280 \$MN_PROG_FUNCTION_MASK, bit 1 = TRUE

Note**Minimum distance between commands**

At least two traversing block distances must be maintained between the commands `INIT`, `START`, `WAITE`, `WAITM`, `SETM`, `CLEARM` and the command `WAITMC`. `WAITMC` is an executable block, but is moved into the previous block for optimization, and then deleted as a block. `SETM` for example is not an executable block, and is moved into the next block so that if there were a distance of one block between two commands, both commands would be in the middle block. As only one block is possible, optimization is not performed with a one block distance for `WAITMC`.

This stops the program, and processing is briefly interrupted.

Syntax

```
INIT (<ChanNo>, <Prog>, <AckMode>)
START (<ChanNo>, <ChanNo>, ...)
WAITM (<MarkNo>, <ChanNo>, <ChanNo>, ...)
WAITE (<ChanNo>, <ChanNo>, ...)
WAITMC (<MarkNo>, <ChanNo>, <ChanNo>, ...)
SETM (<MarkNo>, <MarkNo>, ...)
CLEARM (<MarkNo>, <MarkNo>, ...)
```

Meaning

<code>INIT () :</code>	Predefined procedure for selecting the NC program that is to be executed in the specified channel
<code>START () :</code>	Predefined procedure for starting the selected program in the respective channel
<code>WAITM () :</code>	Predefined procedure to wait for a wait marker to be reached in the specified channels The specified wait marker is set by <code>WAITM</code> in the same channel. The previous block is terminated with exact stop. The wait marker is deleted after synchronization. A maximum of 10 markers can be set simultaneously in each channel.
<code>WAITE () :</code>	Predefined procedure to wait for the end of program in one or more other channels
<code>WAITMC () :¹⁾</code>	Predefined procedure to wait for a wait marker to be reached in the specified channels In contrast to <code>WAITM</code> , the braking of the axes to exact stop is only initiated if the other channels have not yet reached the wait marker.
<code>SETM () :¹⁾</code>	Predefined procedure to set one or more wait markers for the channel coordination The processing in own channel is not affected by this. <code>SETM</code> remains valid after a channel reset and NC start.
<code>CLEARM () :¹⁾</code>	Predefined procedure to delete one or more wait markers for the channel coordination The processing in own channel is not affected by this. <code>CLEARM ()</code> deletes all wait markers in the channel. <code>CLEARM (0)</code> only deletes wait marker "0". <code>CLEARM</code> remains valid after a channel reset and NC start.

<ChanNo>:	Channel number The number of the own channel does not have to be specified.				
	Type:	INT			
<Prog>:	Absolute or relative path specification (optional) + program name				
	Type:	STRING			
	For the path specification, see: Further information Programming Manual Advanced, "File and Program Administration" Chapter > "Program memory" > "Addressing the files of the program memory"				
<AckMode>:	Acknowledgment mode (optional)				
	Type:	CHAR			
	Val- ues:	<table border="0"> <tr> <td style="padding-right: 10px;">"N"</td> <td>Without acknowledgment Program execution is continued after the command has been sent. The sender is not informed if the command cannot be executed successfully.</td> </tr> <tr> <td style="padding-right: 10px;">"S"</td> <td>Synchronous acknowledgment The program execution is stopped until the receiving component has acknowledged the command. If the acknowledgment is positive, the next command is executed. If the acknowledgment is negative, an error message is output.</td> </tr> </table>	"N"	Without acknowledgment Program execution is continued after the command has been sent. The sender is not informed if the command cannot be executed successfully.	"S"
"N"	Without acknowledgment Program execution is continued after the command has been sent. The sender is not informed if the command cannot be executed successfully.				
"S"	Synchronous acknowledgment The program execution is stopped until the receiving component has acknowledged the command. If the acknowledgment is positive, the next command is executed. If the acknowledgment is negative, an error message is output.				
<MarkNo>:	Number of the wait marker Note In a multi-channel system, a maximum of 100 wait markers are available (wait markers 0 ... 99). Only wait marker 0 is available in a single-channel system.				
1) For user-specific communication and/or coordination of channels, wait markers can be deployed using SETM/CLEARM – and also without using the conditional wait command WAITMC. The wait markers retain their values, even after a channel reset and NC start.					

Examples

START using channel names from MD20000

- Parameter assignment

```
MD10280 $MN_PROG_FUNCTION_MASK, bit 1 = TRUE
$MC_CHAN_NAME[ 0 ] = "MACHINING"; Name of channel 1
$MC_CHAN_NAME[ 1 ] = "INFEED"; Name of channel 2
```
- Programming

Program code	Comment
START (MACHINING)	; Start of channel 1
START (INFEED)	; Start of channel 2

START using local "channel names" and user variables

Program code	Comment
DEF INT MACHINE = 1	; Definition of user variable for channel 1
DEF INT LOADER = 2	; Definition of user variable for channel 2
...	

3.1 Flexible NC programming

Program code	Comment
START (MACHINE)	; Start of channel 1
START (LOADER)	; Start of channel 2

START using local "channel names", user variables and parameterized channel names

Program code	Comment
DEF INT chanNo1	; Definition of user variable for channel 1
DEF INT chanNo2	; Definition of user variable for channel 2
chanNo1 = CHAN_1	; Assignment of parameterized channel name channel 1
chanNo2 = CHAN_2	; Assignment of parameterized channel name channel 2
...	
START (ChanNo1)	; Start of channel 1
START (ChanNo2)	; Start of channel 2

INIT command with absolute path specification

Selection of program /_N_MPF_DIR/_N_ABSPAN1_MPF in channel 2.

Program code

```
INIT (2, "/_N_WCS_DIR/_N_SHAFT1_WPD/_N_CUT1_MPF")
```

INIT command with program name

Selection of the program with the name "MYPROG". The control searches for the program using the search path.

Program code

```
INIT (2, "MYPROG")
```


Program coordination with WAITM

- Channel 1: The program /_N_MPF_DIR/_N_MPF100_MPF has already been selected and started.

Program code	Comment
	; Program MPF100
N10 INIT(2,"MPF200","N")	; Selection of program MPF200, channel 2
N11 START(2)	; Start of channel 2
...	
N80 WAITM(1,1,2)	; Wait for WAIT marker 1 in channels 1 and 2
N81 ...	; Channel 1, N81 and channel 2, N71 are ; started synchronously
...	
N180 WAITM(2,1,2)	; Wait for WAIT marker 2 in channels 1 and 2
N181 ...	; Channel 1, N181 and channel 2, N271 are ; started synchronously
...	
N200 WAITE(2)	; Wait for end of program in channel 2
N201 ...	; N201 is not started until the end of program ; MPF200 started in channel 2
N201 M30	; End of program channel 1

- Channel 2: In channel 1, the program MPF200_MPF is selected and started for channel 2 using blocks N10 and N20.

Program code	Comment
;\$PATH=/_N_MPF_DIR	; Program MPF200
...	
N70 WAITM(1,1,2)	Wait for WAIT marker 1 in channels 1 and 2
N71 ...	; Channel 1, N81 and channel 2, N71 are ; started synchronously
...	
N270 WAITM(2,1,2)	Wait for WAIT marker 2 in channels 1 and 2
N271 ...	; Channel 1, N181 and channel 2, N271 are ; started synchronously
...	
N400 M30	End of program channel 2



Supplementary conditions

Non-synchronous start of execution of following blocks after WAIT markers

In the case of channel coordination using WAIT markers, execution of the following blocks may start non-synchronously. This behavior occurs if an action is triggered in one of the channels to be synchronized immediately before reaching the common WAIT marker; the consequence of which is implicit repositioning (REPOSA) in this delete distance-to-go.

Assumption: Current axis assignment in channels 1 and 2

- Channel 1: Axes X1 and U
- Channel 2: Axis X2

Table 3-2 Time sequence in channels 1 and 2

Channel 1	Channel 2	Description
...	...	Arbitrary processing in channels 1 and 2
N100 WAITM(20,1,2)		Channel 1: reaches the WAIT marker and waits for synchronization with channel 2
<i>Start of the GETD(U) processing:</i> <ul style="list-style-type: none"> • Axis interchange • Delete distance-to-go • REPOSA <i>End</i>	N200 GETD(U)	Channel 2: Requests axis U from channel 1 Channel 1: Processing of GET(U) in the background
	N210 WAITM(20,1,2)	Channel 2: reaches the WAIT marker. ⇒ This completes the synchronization of channels 1 and 2
	N220 G0 X2=100	Channel 2: Start of processing of N220
N110 G0 X1=100		Channel 1: Staggered start of processing of N110

See also

Addressing program memory files (Page 544)

3.1.9 Macro technique (DEFINE ... AS)

NOTICE

Macro technology increases the complexity of the programming

Macros can significantly alter the control's programming language. Macro technology may only be used with great care.

A macro is a sequence of individual statements which have together been assigned a name of their own. When a macro is called during a program run, the statements programmed under the program name are executed one after the other.

According to the range of validity (in other words, the range in which the macro definition is active), there are the following macro categories:

- **Local macros**
Local macros are macros that are defined at the beginning of an NC program, which at the time of execution is not the main program. They are created when the NC program is called, and deleted with an end of program reset – or the next time that the control system powers up. Local macros can only be accessed within the NC program in which they are defined.
- **Program-global macros**
Program-global macros are macros that are defined at the beginning of an NC program, which is used as a main program. They are created when the NC program is called, and deleted with an end of program reset – or the next time that the control system powers up. Program-global macros can be accessed in the main program and in all subprograms.

Note

Availability of program-global macros

Program-global macros defined in the main program are only available in subprograms if the following machine data is set:

MD11120 \$MN_LUD_EXTENDED_SCOPE = 1

If MD11120 = 0, the program-global macros defined in the main program will only be available in the main program.

- **Global macros**
Global macros are NC or channel-global macros, which are defined in a definition file (macro file) – and are retained even after an end of program reset or the next time that the control system powers up. Global macros can be called in any main program or subprogram and executed.

Note

In order to use the macros of an **external** macro file in the NC program, the macro file must be downloaded to the NC.

Macros must be defined before they can be used. The following rules must be observed in this context:

- Any identifier, G, M, H functions and L subprogram names can be defined in a macro.
- The macro can be defined at the beginning of the program or in a dedicated definition file (macro file).
- Local and program-global macros are defined at the beginning of the program.
- Global macros must be defined in a macro file, e.g. `_N_DEF_DIR/_N_UMAC_DEF`.
- G command macros can only be defined as global macros.
- H and L functions can be programmed with 2 digits.
- M and G commands can be programmed with 3 digits.

Note

Keywords and reserved names may not be overwritten with macros. This also applies to all jump destinations within a GOTO command, and to the keywords in program loops, such as FOR, WHILE, LOOP, REPEAT.

Syntax

Macro definition:

```
DEFINE <Macro_name> AS <Operation_1> <Operation_2> ...
```

Call in the NC program:

```
<Macro_name>
```

Meaning

DEFINE ... AS:	Keyword combination to define a macro
<Macro_name>:	Macro name Only identifiers are permissible as macro names. The macro is called from the NC program by the macro name.
<Operation_1>:	First programming instruction in the macro
<Operation_2>:	Second programming instruction in the macro

Examples

Example 1: Macro definition at the beginning of the program

Program code	Comment
DEFINE LINE AS G1 G94 F300	; Macro definition
...	
N70 LINE X10 Y20	; Macro call
...	

Example 2: Macro definitions in a macro file

Program code	Comment
DEFINE M6 AS L6	; A subprogram is called at tool change to handle the necessary data transfer. The actual tool change M function is output in the subprogram (e.g. M106).
DEFINE G81 AS DRILL(81)	; Emulation of the DIN-G command.
DEFINE G33 AS M333 G333	; During thread cutting, synchronization is requested with the PLC. The original G command G33 was renamed to G333 by machine data so that the programming remains identical for the user.

Example 3: External macro file

After reading the external macro file into the control, the macro file must be downloaded into the NC. Only then can macros be used in the NC program.

Program code	Comment
%_N_UMAC_DEF	
;\$PATH=/_N_DEF_DIR	; Customer-specific macros
DEFINE PI AS 3.14	
DEFINE TC1 AS M3 S1000	
DEFINE M13 AS M3 M7	; Spindle clockwise, coolant on
DEFINE M14 AS M4 M7	; Spindle counter-clockwise, coolant on
DEFINE M15 AS M5 M9	; Spindle stop, coolant off
DEFINE M6 AS L6	; Call tool change program
DEFINE G80 AS MCALL	; Deselect drilling cycle
M30	

3.2 Subprogram technique


3.2.1 General information

3.2.1.1 Subprogram

The term "subprogram" has its origins during the time when part programs were split strictly into main and subprograms. Main programs were the part programs selected for processing on the control and then launched. Subprograms were the part programs called from within the main program.

This strict division no longer exists with today's SINUMERIK NC language. In principle, each part program can be selected as a main program and launched or called from another part program as a subprogram.

Accordingly, the subprogram can then be used to refer to a part program called from within another part program.



Application

As in all high-level programming languages, in the NC language, subprograms swap out program sections used more than once to independent, self-contained programs.

Subprograms offer the following advantages:

- Increase the transparency and readability of programs
- Increase quality by reusing tested program parts
- Offer the possibility of creating specific machining libraries
- Save memory space

3.2.1.2 Subprogram names

Naming rules

The subprogram name can be chosen freely providing the following rules are observed:

- Permissible characters:
 - Letters: A ... Z, a ... z
 - Numbers: 0 ... 9
 - Underscore: _
- The first two characters should either be two letters or an underscore followed by a letter.

Note

If this condition is satisfied, then an NC program can be called as subprogram from another program just by specifying the program name. However, if the program name starts with digits, the subprogram call is then only possible via the CALL statement.

- Maximum length: 24 characters

Note

Uppercase/lowercase letters

The SINUMERIK NC language does **not** distinguish between uppercase and lowercase letters.

Note

Impermissible program names

To avoid problems with Windows applications, the following program names may **not** be used:

- CON, PRN, AUX, NUL
 - COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9
 - LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9
-

Control-internal extensions

The program name assigned when the subprogram is created is expanded within the control with the addition of a prefix and a suffix:

- Prefix: `_N_`
- Postfix: `_SPF`

Using the program name

When using the program name, e.g. in the context of a subprogram call, all combinations of prefix, program name, and suffix are possible.

Example:

3.2 Subprogram technique

The subprogram with the program name SUB_PROG can be started using the following identifiers:

1. SUB_PROG
2. _N_SUB_PROG
3. SUB_PROG_SPF
4. _N_SUB_PROG_SPF

Main programs and subprograms with the same name

If a main program (.MPF) and a subprogram (.SPF) exist with the same program name, the appropriate file extension for the unique identification must be specified when the program name in the NC program is used. Otherwise the program found first in the search path with the specified name is used.

3.2.1.3 Nesting of subprograms


A main program can call subprograms which in turn call more subprograms. As such, the sequences of the programs are nested within each other. Each program runs on a dedicated program level.

Nesting depth

The NC language currently provides 16 program levels. The main program always runs at the uppermost program level, 0. A subprogram always runs at the next lowest program level following the call. Program level 1 is, therefore, the first subprogram level.

Division of program levels:

- Program level 0: Main program level
- Program level 1 to 15: Subprogram level 1 to 15



Interrupt routines (ASUB)

If a subprogram is called in the context of an interrupt routine, this will not be executed at the program level currently active in the channel (n) but at the next lowest program level (n+1). So that this remains possible even at the lowest program level, 2 additional program levels (16 and 17) are available in conjunction with interrupt routines.

If more than 2 program levels are required, this has to be taken into account explicitly in the structuring of the part program executed in the channel. In other words, only a maximum of as many program levels may be used in order to leave sufficient program levels available for interrupt processing.

If interrupt processing needs 4 program levels for example, the part program must be structured so that it uses a maximum of up to program level 13. In the event of an interrupt, the 4 program levels it requires (14 to 17) will be available to it.

Siemens cycles

Siemens cycles need 3 program levels. Therefore, a Siemens cycle must be called at the latest in:

- Part program processing: program level 12
- interrupt routine: program level 14

3.2.1.4 Search path

When a subprogram without path details is called, the control system searches the available program memory using a predefined search sequence (see "Search path for subprogram call (Page 548)").

3.2.1.5 Formal and actual parameters

Formal and actual parameters occur in conjunction with the definition and calling of subprograms with parameter transfer.

Formal parameter

When a subprogram is defined, the parameters to be transferred to it (known as the formal parameters) have to be defined with type and parameter name.

The formal parameters define, therefore, the interface of the subprogram.

Example:

Program code	Comment
PROC CONTOUR (REAL X, REAL Y)	; Formal parameters: X and Y, both REAL type
N20 X1=X Y1=Y	; Traversing of axis X1 to position X and axis Y1 to position Y
...	
N100 RET	

Actual parameters

When a subprogram is called, absolute values or variables (known as actual parameters) have to be transferred to it.

As such, the actual parameters assign up-to-date values to the interface of the subprogram when the latter is called.

Example:

Program code	Comment
N10 DEF REAL WIDTH	; Variable definition
N20 WIDTH=20.0	; Variable assignment
N30 CONTOUR(5.5, WIDTH)	; Subprogram call with actual parameters: 5.5 and WIDTH
...	
N100 M30	

3.2.1.6 Parameter transfer

Definition of a subprogram with parameter transfer

A subprogram with parameter transfer is defined using the `PROC` keyword and a complete list of all the parameters expected by the subprogram.

Incomplete parameter transfer

When the subprogram is called, not all the parameters defined in the subprogram interface have to be transferred explicitly. If a parameter is omitted, the default value "0" is transferred for it.

So that the parameter sequence can be uniquely identified, however, the commas used as parameter separators always have to be included. The last parameter is an exception. If it is omitted from the call, the last comma can also be left out.

Example:

Subprogram:

Program code	Comment
PROC SUB_PROG (REAL X, REAL Y, REAL Z)	; Formal parameters: X, Y, and Z
...	
N100 RET	

Main program:

Program code	Comment
PROC MAIN_PROG	
...	

Program code	Comment
N30 SUB_PROG(1.0,2.0,3.0)	; Subprogram call with complete parameter transfer: X=1.0, Y=2.0, Z=3.0
...	
N100 M30	

Examples for the subprogram call in N30 with incomplete parameter transfer:

N30 SUB_PROG(,2.0,3.0)	; X=0.0, Y=2.0, Z=3.0
N30 SUB_PROG(1.0, ,3.0)	; X=1.0, Y=0.0, Z=3.0
N30 SUB_PROG(1.0,2.0)	; X=1.0, Y=2.0, Z=0.0
N30 SUB_PROG(, ,3.0)	; X=0.0, Y=0.0, Z=3.0
N30 SUB_PROG(, ,)	; X=0.0, Y=0.0, Z=0.0

NOTICE

Call-by-reference parameter transfer

Parameters transferred using call-by-reference must not be left out of the subprogram call.

NOTICE

AXIS data type

AXIS data type parameters must not be left out of the subprogram call.

Checking the transfer parameters

System variable \$P_SUBPAR [n] where n = 1, 2, etc., can be used to check whether a parameter has been transferred explicitly or left out in the subprogram. The index n refers to the sequence of the formal parameters. Index n = 1 refers to the first formal parameter, index n = 2 to the second formal parameter, and so on.

The following program excerpt shows an example of how a check can be performed based on the first formal parameter:

Programming	Comment
PROC SUB_PROG (REAL X, REAL Y, REAL Z)	; Formal parameters: X, Y, and Z
N20 IF \$P_SUBPAR[1]==TRUE	; Check of the first formal parameter X.
...	; These actions are taken if the formal parameter X has been transferred explicitly.
N40 ELSE	
...	; These actions are taken if the formal parameter X has not been transferred.
N60 ENDIF	
...	; General actions
N100 RET	

3.2.2 Definition of a subprogram

3.2.2.1 Subprogram without parameter transfer

When defining subprograms without parameter transfer, the definition line at the beginning of the program can be omitted.

Syntax

```
[PROC <program name>]
...
```

Meaning

PROC:	Definition operation at the beginning of a program
<program name>:	Name of the program

Example

Example 1: Subprogram with PROC operation

Program code	Comment
PROC SUB_PROG	; Definition line
N10 G01 G90 G64 F1000	
N20 X10 Y20	
...	
N100 RET	; Subprogram return

Example 2: Subprogram without PROC operation

Program code	Comment
N10 G01 G90 G64 F1000	
N20 X10 Y20	
...	
N100 RET	; Subprogram return

See also


Subprogram call without parameter transfer (Page 512)

3.2.2.2 Subprogram with call-by-value parameter transfer (PROC)

A subprogram with call-by-value parameter transfer is defined using the PROC keyword followed by the name of the program and a complete list of all the parameters with their type and name. The definition operation must appear in the first program line.

Call-by-value

The calling program transfers only the value of a variable to the subprogram on a call-by-value parameter transfer. Thus the subprogram is not given direct access to the variable. In this way, only the value visible in the subprogram is modified when the parameter value is changed. The value of the variables defined in the calling program remains unchanged. As a consequence, the call-by-value parameter transfer does not affect the calling program.



Syntax

```
PROC <program name> (<parameter type> <parameter name>=<init_value>, ...)
```

Note

Up to 127 parameters can be transferred.

Meaning

PROC:	Definition operation at the beginning of a program
<program name>:	Name of the program
<parameter type>:	Data type of the parameter (e.g. REAL, INT, BOOL)
<parameter name>:	Name of the parameter
<init_value>:	Optional value for the initialization of the parameter (optional) If no parameter is specified when calling the subprogram, the parameter is assigned the initialization value.

Examples

Example 1

Definition of a subprogram SUB_PROG with three parameters of type REAL with default values:

Program code

```
PROC SUB_PROG (REAL LENGTH=10.0, REAL WIDTH=20.0, REAL HIGHT=30.0)
```

Example 2

Various call versions

Program code

```
PROC MAIN_PROG
  REAL PAR_1 = 100
  REAL PAR_2 = 200
  REAL PAR_3 = 300
  ; Call variants
  SUB_PROG
  SUB_PROG (PAR_1, PAR_2, PAR_3)
  SUB_PROG (PAR_1)
  SUB_PROG (PAR_1, , PAR_3)
  SUB_PROG ( , , PAR_3)
N100 RET
```

See also


Subprogram call with parameter transfer (EXTERN) (Page 514)

3.2.2.3 Subprogram with call-by-reference parameter transfer (PROC, VAR)

A subprogram with call-by-reference parameter transfer is defined using the `PROC` keyword followed by the name of the program and a complete list of all the parameters with the `VAR` keyword, type, and name. The definition operation must appear in the first program line. As parameters, references to arrays can also be transferred.

Call-by-reference

The calling program transfers not the value of a variable to the subprogram on a call-by-reference parameter transfer, but a reference (pointer) to the variable. This gives the subprogram direct access to the variable. In this way, not only the value visible in the subprogram is modified when a parameter value is changed, but also the value of the variables defined in the calling program. Call-by-reference parameter transfer therefore affects the calling program, even after the subprogram has ended.



Note

The call-by-reference parameter transfer is then only necessary if the transferred variable was defined locally in the calling program (LUD). Channel-global or NC-global variables do not have to be transferred, since these cannot be accessed directly from within the subprogram.

Syntax

```
PROC <program name> (VAR <parameter type> <parameter name>, etc.)
PROC <program name> (VAR <array type> <array name>, [<m>,<n>,<o>], etc.)
```

Note

Up to 127 parameters can be transferred.

Meaning

PROC:	Definition operation at the beginning of a program
VAR:	Keyword for parameter transfer via reference
<program name>:	Name of the program
<parameter type>:	Data type of the parameter (e.g. REAL, INT, BOOL)
<parameter name>:	Name of the parameter
<array type>:	Data type of the array elements (e.g. REAL, INT, BOOL)
<array name>:	Name of the array

[<m>, <n>, <o>]:	Array size	
	Currently, up to 3-dimensional arrays are possible:	
	<m>:	Array size for 1st dimension
	<n>:	Array size for 2nd dimension
	<o>:	Array size for 3rd dimension

Note

- The program name specified after the PROC keyword must match the program name assigned on the user interface.
- With arrays of an undefined array length, subprograms can process arrays of variable length as formal parameter. When defining a two-dimensional array as a formal parameter, for example, the length of the 1st dimension is not specified. However, the comma must be written.
Example: PROC <program name> (VAR REAL ARRAY[,5])

Example

Definition of a subprogram with two parameters as reference to REAL type:

Program code

```

; Parameter 1: Reference to type: REAL, name: LENGTH
; Parameter 2: Reference to type: REAL, name: WIDTH
PROC SUB_PROG(VAR REAL LENGTH, VAR REAL WIDTH)

```

See also

Subprogram call with parameter transfer (EXTERN) (Page 514)

3.2.2.4 Save modal G functions (SAVE)

The SAVE attribute means that before the subprogram call, active modal G commands are saved and are reactivated after the end of the subprogram.

NOTICE
Interrupt continuous-path mode
If, for active continuous-path mode, a subprogram is called with the SAVE attribute, the continuous-path mode is interrupted at the end of the subprogram (return jump).

Syntax

```
PROC <subprogram name> SAVE
```

Meaning

SAVE:	Saves the modal G commands before the subprogram call and restores after the end of the subprogram.
-------	---

Example

In the CONTOUR subroutine, the modal G command G91 incremental dimension applies. The modal G command G90 is effective in the main program (absolute dimension). G90 is again effective in the main program after the end of the subprogram due to the subprogram definition with SAVE.

Subprogram definition:

Program code	Comment
PROC CONTOUR (REAL VALUE1) SAVE	; Subprogram definition with the SAVE parameter
N10 G91 ...	; Modal G command G91: Incremental dimension
N100 M17	; End of subprogram

Main program:

Program code	Comment
N10 G0 X... Y... G90	; Modal G command G90: Absolute dimensions
N20 ...	
...	
N50 CONTOUR (12.4)	; Subprogram call
N60 X... Y...	; Modal G command G90 reactivated using SAVE

Supplementary conditions

Frames

The behavior of frames regarding subprograms with the SAVE attribute depends on the frame time and can be set using machine data.

References

Function Manual, Basic Functions; Axes, Coordinate Systems, Frames (K2),
Section: "Subprogram return with SAVE"

3.2.2.5 Suppress single block execution (SBLOF, SBLON)

Single-block suppression for the complete program

Programs designated with SBLOF are completely executed just like a block when single-block execution is active, i.e. single-block execution is suppressed for the complete program.

3.2 Subprogram technique

SBLOF is in the PROC line and is valid up to the end of the subprogram or until it is interrupted. At the return command, the decision is made whether to stop at the end of the subprogram:

- Return jump with M17: Stop at the end of the subprogram
- Return jump with RET: No stop at end of subprogram

Single-block suppression within the program

SBLOF alone must remain in the block. Single block is deactivated after this block until:

- The next SBLON
or
- The end of the active subprogram level

Syntax

Single-block suppression for the complete program:

PROC ... SBLOF

Single-block suppression within the program:

SBLOF
...
SBLON

Meaning

PROC:	First operation in a program
SBLOF:	Command to deactivate single-block execution SBLOF can be written in a PROC block or alone in the block.
SBLON:	Command to activate single-block execution SBLON must be in a separate block.

Supplementary conditions

- **Single-block suppression and block display**
The current block display can be suppressed in cycles/subprograms using `DISPLOF`.
If `DISPLOF` is programmed together with `SBLOF`, then the cycle/subprogram call continues to be displayed on single-block stops within the cycle/subprogram.
- **Single-block suppression in the system ASUB or user ASUB**
If the single-block stop in the system or user ASUB is suppressed using the settings in machine data MD10702 `$MN_IGNORE_SINGLEBLOCK_MASK` (bit0 = 1 or bit1 = 1), then the single-block stop can be reactivated by programming `SBLON` in the ASUB.
If the single-block stop in the user ASUB is suppressed using the setting in machine data MD20117 `$MC_IGNORE_SINGLEBLOCK_ASUP`, then the single-block stop **cannot** be reactivated by programming `SBLON` in the ASUB.
- **Special features of single-block suppression for various single-block execution types**
When single-block execution SBL2 is active (stop after each part program block) there is **no** execution stop in the `SBLON` block if bit 12 is set to "1" in the MD10702 `$MN_IGNORE_SINGLEBLOCK_MASK` (prevent single-block stop).
When single-block execution SBL3 is active (stop after every part program block - also in the cycle), the `SBLOF` command is suppressed.

Examples

Example 1: Single-block suppression within a program

Program code	Comment
N10 G1 X100 F1000	
N20 SBLOF	; Deactivate single block.
N30 Y20	
N40 M100	
N50 R10=90	
N60 SBLON	; Reactivate single block.
N70 M110	
N80 ...	

The area between N20 and N60 is executed as one step in single-block mode.

Example 2: A cycle is to act like a command for a user

Main program:

Program code
N10 G1 X10 G90 F200
N20 X-4 Y6
N30 CYCLE1
N40 G1 X0
N50 M30

Cycle CYCLE1:

Program code	Comment
N100 PROC CYCLE1 DISPLOF SBLOF	; Suppress single block
N110 R10=3*SIN(R20)+5	
N120 IF (R11 <= 0)	
N130 SETAL(61000)	
N140 ENDIF	
N150 G1 G91 Z=R10 F=R11	
N160 M17	

CYCLE1 is processed for active single-block execution, i.e. the Start key must be pressed once to process CYCLE1.

Example 3: An ASUB, which is started by the PLC in order to activate a modified zero offset and tool offsets, is to be executed invisibly.

Program code
N100 PROC ZO SBLOF DISPLOF
N110 CASE \$P_UIFRNUM OF
0 GOTOF _G500
1 GOTOF _G54
2 GOTOF _G55
3 GOTOF _G56
4 GOTOF _G57
DEFAULT GOTOF END
N120 _G54: G54 D=\$P_TOOL T=\$P_TOOLNO
N130 RET
N140 _G54: G55 D=\$P_TOOL T=\$P_TOOLNO
N150 RET
N160 _G56: G56 D=\$P_TOOL T=\$P_TOOLNO
N170 RET
N180 _G57: G57 D=\$P_TOOL T=\$P_TOOLNO
N190 RET
N200 END: D=\$P_TOOL T=\$P_TOOLNO
N210 RET

Example 4: Is not stopped with MD10702 Bit 12 = 1

Initial situation:

- Single-block execution is active.
- MD10702 \$MN_IGNORE_SINGLEBLOCK_MASK Bit12 = 1

Main program:

Program code	Comment
N10 G0 X0	; Stop in this part program line.
N20 X10	; Stop in this part program line.
N30 CYCLE	; Traversing block generated by the cycle.
N50 G90 X20	; Stop in this part program line.
M30	

Cycle CYCLE:

Program code	Comment
PROC CYCLE SBLOF	; Suppress single-block stop.
N100 R0 = 1	
N110 SBLON	; Execution is not stopped in the part program line due to the fact that MD10702 bit12=1.
N120 X1	; Execution is stopped in this part program line.
N140 SBLOF	
N150 R0 = 2	
RET	

Example 5: Single-block suppression for program nesting

Initial situation:

Single-block execution is active.

Program nesting:

Program code	Comment
N10 X0 F1000	; Execution is stopped in this block.
N20 UP1(0)	
PROC UP1(INT _NR) SBLOF	; Suppress single-block stop.
N100 X10	
N110 UP2(0)	
PROC UP2(INT _NR)	
N200 X20	
N210 SBLON	; Activate single-block stop.
N220 X22	; Execution is stopped in this block.
N230 UP3(0)	
PROC UP3(INT _NR)	
N300 SBLOF	; Suppress single-block stop.
N305 X30	
N310 SBLON	; Activate single-block stop.
N320 X32	; Execution is stopped in this block.

Program code	Comment
N330 SBLOF	; Suppress single-block stop.
N340 X34	
N350 M17	; SBLOF is active.
N240 X24	; Execution is stopped in this block. SBLON is active.
N250 M17	; Execution is stopped in this block. SBLON is active.
N120 X12	
N130 M17	; Execution is stopped in this return jump block. SBLOF of the PROC statement is active.
N30 X0	; Execution is stopped in this block.
N40 M30	; Execution is stopped in this block.

Further information

Single-block disable for unsynchronized subprograms

In order to execute an ASUB in the single block in one step, a PROC statement must be programmed in the ASUB with SBLOF. This also applies to the function "Editable system ASUB" (MD11610 \$MN_ASUP_EDITABLE).

Example of an editable system ASUB:

Program code	Comment
N10 PROC ASUP1 SBLOF DISPLOF	
N20 IF \$AC_ASUP=='H200'	
N30 RET	; No REPOS for mode change.
N40 ELSE	
N50 REPOSA	; REPOS in all other cases.
N60 ENDIF	

Program control in single-block mode

With the single-block execution function, the user can execute a part program block-by-block. The following setting types exist:

- SB1: Machining stops after every machine function block (except for cycles).
- SB2: Machining stops after every block, i.e. also for data blocks (except for cycles)
- SB3: Machining stops after every machine function block (also in cycles).

Single-block suppression for program nesting

If SBLOF was programmed in the PROC statement in a subprogram, then execution is stopped at the subprogram return jump with M17. That prevents the next block in the calling program from already running. If SBLOF, without SBLON is programmed in the PROC statement in a subprogram, single-block suppression is activated, execution is only stopped after the next machine function block of the calling program. If that is not wanted, SBLON must be programmed in the subprogram before the return (M17). Execution does not stop for a return jump to a higher-level program with RET.

3.2.2.6 Suppress current block display (DISPLOF, DISPLON, ACTBLOCNO)

The current program block is displayed as standard in the block display. The display of the current block can be suppressed in cycles and subprograms using the `DISPLOF` command. Instead of the current block, the call of the cycle or the subprogram is displayed. The `DISPLON` command revokes suppression of the block display.

`DISPLOF` and `DISPLON` are programmed in the program line with the `PROC` operation and are effective for the entire subprogram and implicitly for all subprograms called from it which do not contain a `DISPLON` or `DISPLOF` command. This is true for all ASUBs.

Syntax

```
PROC ... DISPLOF
PROC ... DISPLOF ACTBLOCNO
PROC ... DISPLON
```

Meaning

DISPLOF:	Command to suppress the current block display.	
	Location:	At the end of the program line with the <code>PROC</code> operation
	Effective:	Up to the return jump from the subprogram or end of program.
	Note: If further subprograms are called from the subprogram using the <code>DISPLOF</code> command, then the current block display is also suppressed in these subprograms unless <code>DISPLON</code> is explicitly programmed in them.	
DISPLON:	Command for revoking suppression of the display of the current block	
	Location:	At the end of the program line with the <code>PROC</code> operation
	Effective:	Up to the return jump from the subprogram or end of program.
	Note: If further subprograms are called from the subprogram using the <code>DISPLON</code> command, then the current block will also be displayed in these subprograms unless <code>DISPLOF</code> is explicitly programmed in them.	
ACTBLOCNO:	<code>DISPLOF</code> together with the <code>ACTBLOCNO</code> attribute means that in the case of an alarm, the number of the actual block is output in which the alarm occurred. This also applies if only <code>DISPLOF</code> is programmed in a lower program level. On the other hand, for <code>DISPLOF</code> without <code>ACTBLOCNO</code> , the block number of the cycle or subprogram call from the last program level not designated with <code>DISPLOF</code> is displayed.	

Examples

Example 1: Suppress current block display in the cycle

Program code	Comment
PROC CYCLE (AXIS TOMOV, REAL POSITION) SAVE DISPLOF	; Suppress current block display Instead, the cycle call should be displayed, e.g.: CYCLE (X,100.0)
DEF REAL DIFF	;Cycle contents
G01 ...	

3.2 Subprogram technique

Program code	Comment
...	
RET	; Subprogram return jump. The block following the cycle call is displayed in the block display.

Example 2: Block display for alarm output

Subprogram SUBPROG1 (with ACTBLOCNO):

Program code	Comment
PROC SUBPROG1 DISPLOF ACTBLOC-	
NO	
N8000 R10 = R33 + R44	
...	
N9040 R10 = 66 X100	; Trigger alarm 12080
...	
N10000 M17	

Subprogram SUBPROG2 (without ACTBLOCNO):

Program code	Comment
PROC SUBPROG2 DISPLOF	
N5000 R10 = R33 + R44	
...	
N6040 R10 = 66 X100	; Trigger alarm 12080
...	
N7000 M17	

Main program:

Program code	Comment
N1000 G0 X0 Y0 Z0	
N1010 ...	
...	
N2050 SUBPROG1	; Alarm output = "12080 channel K1 block N9040 syntax error for text R10="
N2060 ...	
N2350 SUBPROG2	; Alarm output = "12080 channel K1 block N2350 syntax error for text R10="
...	
N3000 M30	

Example 3: Revoke suppression of the current block display


Subprogram SUB1 with suppression:

Program code	Comment
PROC SUB1 DISPLOF	; Suppress current block display in SUB1 subprogram. Instead, the block is to be displayed with the SUB1 call.
...	
N300 SUB2	; Call subprogram SUB2.
...	
N500 M17	

Subprogram SUB2 without suppression:

Program code	Comment
PROC SUB2 DISPLON	; Revoke suppression of the current block display in subprogram SUB2.
...	
N200 M17	; Return to subprogram SUB1. Suppression of the current block display is restored in SUB1.

Example 4: Display response for different DISPLON/DISPLOF combinations



- ① The part program lines from program level 0 are displayed in the current block display.
- ② The part program lines from program level 3 are displayed in the current block display.
- ③ The part program lines from program level 3 are displayed in the current block display.
- ④ The part program lines from program level 7/8 are displayed in the current block display.

3.2.2.7 Identifying subprograms with preparation (PREPRO)

All files can be identified with the `PREPRO` keyword at the end of the `PROC` operation line during power up.

Note

This type of program preparation depends on the relevant set machine data. Please follow the manufacturer's instructions.

References:

Function Manual, Special Functions, Preprocessing (V2)

Syntax

```
PROC ... PREPRO
```

Meaning

PREPRO:	Keyword for identifying all files (of the NC programs stored in the cycle directories) prepared during power up
---------	---

Read subprogram with preparation and subprogram call

The cycle directories are processed in the same order both for subprograms preprocessed with parameters during power up and during subprogram call.

1. `_N_CUS_DIR` user cycles
2. `_N_CMA_DIR` manufacturer cycles
3. `_N_CST_DIR` standard cycles

In the case of NC programs sharing the same name but having different characteristics, the first `PROC` operation found is activated and the other `PROC` operation is overlooked without an alarm message.

3.2.2.8 Subprogram return M17

The return command `M17` (or the part program end command `M30`) appears at the end of a subprogram. It prompts the return to the calling program at the part program block following the subprogram call.

Note

`M17` and `M30` are treated as equivalents in the NC language.

Syntax

```
PROC <program name>
```

...
M17/M30

Supplementary conditions

Effect of the subprogram return on continuous-path mode

If M17 (or M30) appears on its own in the part program block, active continuous-path mode in the channel will be interrupted.

To avoid continuous-path mode being interrupted, M17 (or M30) has to be included in the last traversing block. Furthermore, the following machine data must be set to "0":

MD20800 \$MC_SPF_END_TO_VDI = 0 (no M30/M17 output to the NC/PLC interface)

Example

1. Subprogram with M17 in a separate block

Program code	Comment
N10 G64 F2000 G91 X10 Y10	
N20 X10 Z10	
N30 M17	; Return jump with interruption of continuous-path mode.

2. Subprogram with M17 in the last traversing block

Program code	Comment
N10 G64 F2000 G91 X10 Y10	
N20 X10 Z10 M17	; Return jump without interruption of continuous-path mode.

3.2.2.9 RET subprogram return

The RET command can also be used in the subprogram as a substitute for the M17 return jump command. RET must be programmed in a separate part program block. Like M17, RET prompts the return to the calling program at the part program block following the subprogram call.

Note

Parameters can be programmed to change the return jump behavior of RET (see "Parameterizable subprogram return jump (RET ...) (Page 502)").

Application

The RET operation should then be used if a G64 continuous-path mode (G641 to G645) is not to be interrupted by the return jump.

Requirement

The `RET` command can only be used in subprograms, which were not defined with the `SAVE` attribute.

Syntax

```
PROC <program name>
...
RET
```

Example

Main program:

Program code	Comment
PROC MAIN_PROGRAM	; Start of the program
...	
N50 SUB_PROG	; Subprogram call: SUB_PROG
N60 ...	
...	
N100 M30	; End of program

Subprogram:

Program code	Comment
PROC SUB_PROG	
...	
N100 RET	; Return jump to block N60 in the main program.

3.2.2.10 Parameterizable subprogram return jump (RET ...)

Generally, a return jump is made from a subprogram into the calling program using the `RET` command. Processing is then continued with the program line following the subprogram call. The following options are available if program processing is to be continued at another location:

- Resume program execution after calling the stock removal cycles in the ISO dialect mode (after describing the contour).
- Return to main program from any subprogram level (even after `ASUB`) for error handling.
- Return jump across several program levels for special applications in compile cycles and in the ISO dialect mode.

To achieve this, the `RET` command should be programmed with additional parameters.

Search direction

When specifying parameter `<target block>`, a return jump is first made to the block after the calling block. A search is then made for the target in the direction of the **end** of the program into

which a return jump was made. A search is made toward the start of the program if the search was not successful.

Syntax

```
RET("<target block>")
RET("<target block>",<block after target block>)
RET("<target block>",<block after target block> <number of return
jump levels>)
RET("<target block>",<block after target block>,<number of return
jump levels>,<return jump to the beginning of the program>)
RET("<target block>",<block after target block>,<number of return
jump levels>,<return jump to the beginning
of the program>)
```

Meaning

RET:	End of subprogram	
<target block>:	Declares as jump target the block where program execution should be resumed. If parameter <number of return jump levels> is not programmed, then the jump target is in the program from which the current subprogram was called. Possible data include:	
	<block number>	Number of the target block. The search for the block number is made in the program to which a return jump is made - initially toward the end of the program.
	<jump marker>	Jump marker, which must be available in the program into which a return jump is made. The search for the jump marker is made in the program to which a return jump is made - initially toward the end of the program.
	<character string>	Character string that must be available in the program into which a return jump is made (e.g. program or variable name). The search for the character string is made in the program to which a return jump is made - initially toward the end of the program. The following rules apply when programming the character string: <ul style="list-style-type: none"> • Blank at the end (contrary to the jump marker, which is identified by ":" at the end). • Before the character string only one block number and/or a jump marker may be set, no program commands.

<block after target block>:	The parameter specifies as to whether program processing should be continued in the block specified under parameter <target block> or in the following block.				
	Type:	INT			
	Value:	<table border="1"> <tr> <td>0</td> <td>The return jump is made to the block specified in parameter <target block>.</td> </tr> <tr> <td>> 0</td> <td>The return jump is made to the next block specified in parameter <target block>.</td> </tr> </table>	0	The return jump is made to the block specified in parameter <target block>.	> 0
0	The return jump is made to the block specified in parameter <target block>.				
> 0	The return jump is made to the next block specified in parameter <target block>.				
<number of return jump levels>:	The parameter specifies the number of program levels that should be jumped through (return jumps) to search there for the target block and continue processing the program.				
	Type:	INT			
	Value:	1	The program is resumed at the "current program level -1" (just like RET without parameter).		
		2	The program is resumed at the "current program level -2", i.e. one level is skipped.		
		3	The program is resumed at the "current program level -3", i.e. two levels are skipped.		
		...			
Range of values:	1 ... 15				
<return jump to the beginning of the program>:	The parameter specifies, for a return jump into the main program, whether the program should be continued at the start of the program in the active ISO dialect mode .				
	Type:	BOOL			
	Value:	<table border="1"> <tr> <td>1</td> <td>If the return jump is made into the main program and an ISO dialect mode is active there, then the program branches to the beginning of the program.</td> </tr> </table>	1	If the return jump is made into the main program and an ISO dialect mode is active there, then the program branches to the beginning of the program.	
1	If the return jump is made into the main program and an ISO dialect mode is active there, then the program branches to the beginning of the program.				

Note

For a subprogram return jump with a character string to specify the target block search, initially, a search is always made for a jump marker in the calling program.

If a jump target is to be uniquely defined using a character string, it is not permissible that the character string matches the name of a jump marker, as otherwise the subprogram return jump would always be made to the jump marker and not to the character string (refer to example 2).

Supplementary conditions

When making a return jump through several program levels, the SAVE statements of the individual program levels are evaluated.

If, for a return jump over several program levels, a modal subprogram is active and if in one of the skipped programs the deselection command `MCALL` is programmed for the modal subprogram, then the modal subprogram remains active.

<p>NOTICE</p> <p>Programming error</p> <p>For a return jump across several program levels, it is the user's responsibility to ensure that processing is continued with the necessary modal settings. This can be achieved, e.g. by programming an appropriate main block.</p>

Examples

Example 1: Resuming in the main program after ASUB execution

Programming	Comment
N10010 CALL "UP1"	; Program level 0 (main program)
N11000 PROC UP1	; Program level 1
N11010 CALL "UP2"	
N12000 PROC UP2	; Program level 2
...	
N19000 PROC ASUP	; Program level 3 (ASUB execution)
...	
N19100 RET("N10900", , \$P_STACK)	; Subprogram return jump into the main program ; \$P_STACK: actual program level
N10900	; Target block in the main program
N10910 MCALL	; Deactivate the modal subprogram call
N10920 G0 G60 G40 M5	; Initialize additional modal settings

Example 2: Character string (string>) to specify the target block search

Main program:

Program code	Comment
PROC MAIN_PROGRAM	
N1000 DEF INT iVar1=1, iVar2=4	
N1010 ...	
N1200 subProg1	; Calls subprogram "subProg1"
N1210 M2 S1000 X10 F1000	
N1220	
N1400 subProg2	; Calls subprogram "subProg2"
N1410 M3 S500 Y20	
N1420 ..	
N1500 lab1: iVar1=R10*44	
N1510 F500 X5	

3.2 Subprogram technique

Program code	Comment
N1520 ...	
N1550 subprog1: G1 X30	; "subProg1" is defined here as jump marker.
N1560 ...	
N1600 subProg3	; Calls subprogram "subProg3"
N1610 ...	
N1900 M30	

Subprogram subProg1:

Program code	Comment
PROC subProg1	
N2000 R10=R20+100	
N2010 ...	
N2200 RET("subProg2")	; Return jump into the main program at block N1400

Subprogram subProg2:

Program code	Comment
PROC subProg2	
N2000 R10=R20+100	
N2010 ...	
N2200 RET("iVar1")	; Return jump into the main program at block N1500


Subprogram subProg3:

Program code	Comment
PROC subProg3	
N2000 R10=R20+100	
N2010 ...	
N2200 RET("subProg1")	; Return jump into the main program at block N1550

Additional information


The following diagrams show the different effects of return jump parameters

1. <target block> = "N200", <block after target block> = 0




After the `RET` command, program execution is continued with block N200 in the main program.

2. <target block> = "N200", <block after target block> = 1



After the `RET` command, program execution is continued with the block (N210) that follows block N200 in the main program.

3. <target block> = "N220", <number of return jump levels> = 2



After the RET command, two program levels are jumped through and program execution is continued with block N220.

3.2.2.11 Parameterizable subprogram return jump (RETB ...)

Generally, a return jump is made from a subprogram into the calling program using the RETB command. Processing is then continued with the program line following the subprogram call. The following options are available if program processing is to be continued at another location:

- Resume program execution after calling the stock removal cycles in the ISO dialect mode (after describing the contour).
- Return to main program from any subprogram level (even after ASUB) for error handling.
- Return jump across several program levels for special applications in compile cycles and in the ISO dialect mode.

To achieve this, the RETB command should be programmed with additional parameters.

Search direction

When specifying parameter <target block>, a return jump is first made to the block after the calling block. A search is then made for the target in the direction of the **beginning** of the program into which a return jump is made. A search is made toward the end of the program if the search was not successful.

Syntax

```
RETB("<target block>")
RETB("<target block>",<block after target block>)
RETB("<target block>",<block after target block> <number of return
jump levels>)
RETB("<target block>",<number of return jump levels>)
```

```

RETB("<target block>",<block after target block>,<number of return
jump levels>,
<return jump to the beginning of the program>)
RETB( , ,<number of return jump levels>,<return jump to the beginning
of the program>)

```

Meaning

RETB:	End of subprogram				
<target block>:	Declares as jump target the block where program execution should be resumed. If parameter <number of return jump levels> is not programmed, then the jump target is in the program from which the current subprogram was called. Possible data include:				
	<block number>	Number of the target block. The search for the block number is realized in the program to which a return jump was made initially in the direction toward the beginning of the program.			
	<jump marker>	Jump marker, which must be available in the program into which a return jump is made. The search for the jump marker is realized in the program to which a return jump was made initially in the direction toward the beginning of the program.			
	<character string>	Character string that must be available in the program into which a return jump is made (e.g. program or variable name). The search for the character string is realized in the program to which a return jump was made initially in the direction toward the beginning of the program. The following rules apply when programming the character string: <ul style="list-style-type: none"> • Blank at the end (contrary to the jump marker, which is identified by ":" at the end). • Before the character string only one block number and/or a jump marker may be set, no program commands. 			
<block after target block>:	The parameter specifies as to whether program processing should be continued in the block specified under parameter <target block> or in the following block.				
	Type:	INT			
	Value:	<table border="1"> <tr> <td>0</td> <td>The return jump is made to the block specified in parameter <target block>.</td> </tr> <tr> <td>> 0</td> <td>The return jump is made to the next block specified in parameter <target block>.</td> </tr> </table>	0	The return jump is made to the block specified in parameter <target block>.	> 0
0	The return jump is made to the block specified in parameter <target block>.				
> 0	The return jump is made to the next block specified in parameter <target block>.				

<number of return jump levels>:	The parameter specifies the number of program levels that should be jumped through (return jumps) to search there for the target block and continue processing the program.		
	Type:	INT	
	Value:	1	The program is resumed at the "current program level -1" (just like <code>RET</code> without parameter).
		2	The program is resumed at the "current program level -2", i.e. one level is skipped.
		3	The program is resumed at the "current program level -3", i.e. two levels are skipped.
...			
Range of values:	1 ... 15		
<return jump to the beginning of the program>:	The parameter specifies, for a return jump into the main program, whether the program should be continued at the start of the program in the active ISO dialect mode .		
	Type:	BOOL	
	Value:	1	If the return jump is made into the main program and an ISO dialect mode is active there, then the program branches to the beginning of the program.

Note

For a subprogram return jump with a character string to specify the target block search, initially, a search is always made for a jump marker in the calling program.

If a jump target is to be uniquely defined using a character string, it is not permissible that the character string matches the name of a jump marker, as otherwise the subprogram return jump would always be made to the jump marker and not to the character string (refer to example 2).

Supplementary conditions

When making a return jump through several program levels, the `SAVE` statements of the individual program levels are evaluated.

If, for a return jump over several program levels, a modal subprogram is active and if in one of the skipped programs the deselection command `MCALL` is programmed for the modal subprogram, then the modal subprogram remains active.

<p>NOTICE</p> <p>Programming error</p> <p>For a return jump across several program levels, it is the user's responsibility to ensure that processing is continued with the necessary modal settings. This can be achieved, e.g. by programming an appropriate main block.</p>

Example

Program code	Comment
EXAMPLE.MPF	
...	
N3000 START_CYC(param1, param2, ...)	
N3010 TECH_CYC1(param1, param2, ...)	
N3020 TECH_CYC2(param1, param2, ...)	
N3030 TECH_CYC3(param1, param2, ...)	
N3040 END_CYC(param1, param2, ...)	
N3040 END_CYC (param1, param2, ...)	
N3050 ...	
N4500 START_CYC(param11, param12, ...)	
N4510 ...	
N4590 END_CYC(param11, param12, ..)	
N5000 ...	
...	
N6000 M30	
<hr/>	
Program code	Comment
PROC END_CYC(...)	; Call in the main program, line N3040
N10000 ...	
N15000 if status == 1	
N15010 RETB("START_CYC")	; Return jump to the calling program EXAMPLE.MPF ; Search for character string "START_CYC" ; Search direction: backward in the program start direction ; Program processing is continued with line N3000
N15020 endif	
N15030 if status == 0	
N15040 RET	; Return jump to the calling program EXAMPLE.MPF ; Program processing is continued with line N3050
N15050 endif	
N16000 RET("START_CYC")	; Return jump to the calling program EXAMPLE.MPF ; Search for character string "START_CYC" ; Search direction: forward in the program end di- rection ; Program processing is continued with line N4500
N17060 RETB	; Return jump to the calling program EXAMPLE.MPF ; Program processing is continued with line N3050 ; RETB without parameter is identical to RET

3.2.3 Subprogram call

3.2.3.1 Subprogram call without parameter transfer

A subprogram is called either with address L and subprogram number or by specifying the program name.

A main program can also be called as a subprogram. The end of program M2 or M30 set in the main program is evaluated as M17 in this case (end of program with return to the calling program).

Note

Accordingly, a subprogram can also be started as a main program.

Search strategy of the control:

Are there any *_MPF?

Are there any *_SPF?

This means, if the name of the subprogram to be called is identical to the name of the main program, the main program that issued the call is called again. This is generally an undesirable effect and must be avoided by assigning unique names to subprograms and main programs.

Note

Subprograms not requiring parameter transfer can also be called from an initialization file.

Syntax

L<number>/<program name>

Note


The subprogram call must always be programmed in a separate NC block.

Meaning


L:	Address for the subprogram call	
<number>:	Name of the subprogram	
	Type:	INT
	Value:	Maximum 7 decimal places Notice: Leading zeros are significant in names (⇒ L123, L0123 and L00123 are three different subprograms).
<program name>:	Name of the subprogram (or main program)	

Examples

Example 1: Subprogram call without parameter transfer



Example 2: Calling a main program as a subprogram



See also

Subprogram without parameter transfer (Page 486)

3.2.3.2 Subprogram call with parameter transfer (EXTERN)

For a subprogram call with parameter transfer, variables or values can be transferred directly (but not VAR parameters).

Subprograms with parameter transfer must be declared with EXTERNAL in the main program before they are called in the main program (e.g. at the beginning of the program). The name of the subprogram and the variable types are thereby specified in the sequence in which they are transferred.

NOTICE

Risk of confusion

Both the variable types and the sequence of the transfer must match the definitions declared under PROC in the subprogram. The parameter names can be different in the main program and the subprogram.

Syntax

```
EXTERNAL <program name>(<type_Par1>,<type_Par2>,<type_Par3>)
...
<program name>(<value_Par1>,<value_Par2>,<value_Par3>)
```

Note

The subprogram call must always be programmed in a separate NC block.


Meaning

<program name>:	Name of subprogram
EXTERNAL:	Keyword to declare a subprogram with parameter transfer. Note: You only have to specify EXTERNAL if the subprogram is in the workpiece or in the global subprogram directory. Cycles do not have to be declared as EXTERNAL.
<type_par1>,<type_par2>,<type_par3>:	Variable types of the parameters to be transferred in the sequence of the transfer
<value_par1>,<value_par2>,<value_par3>:	Variable values for the parameters to be transferred

Examples


Example 1: Subprogram call preceded by declaration

Program code	Comment
N10 EXTERNAL BORDERS (REAL, REAL, REAL)	; Specify the subprogram.
...	
N40 BORDER (15.3, 20.2, 5)	; Call the subprogram with parameter transfer.



Example 2: Subprogram call without declaration

Program code	Comment
N10 DEF REAL LENGTH, WIDTH, DEPTH	
N20 ...	
N30 LENGTH=15.3 WIDTH=20.2 DEPTH=5	
N40 BORDER (LENGTH, WIDTH, DEPTH)	; or: N40 BORDER (15.3, 20.2, 5)




See also

Subprogram with call-by-value parameter transfer (PROC) (Page 486)

Subprogram with call-by-reference parameter transfer (PROC, VAR) (Page 488)

3.2.3.3 Number of program repetitions (P)

If a subprogram is to be executed several times in succession, the desired number of program repetitions can be entered at address **P** in the block with the subprogram call.

 CAUTION
Subprogram call with program repetition and parameter transfer
Parameters are transferred only when the program is called, i.e., on the first run. The parameters remain unchanged for the remaining repetitions. If you want to change the parameters during program repetitions, you must make the appropriate provision in the subprogram.

Syntax

<program name> P<value>


Meaning

<program name>:	Subprogram call
P:	Address to program program repetitions

<code><value></code> :	Number of program repetitions	
	Type:	INT
	Range of values:	1 ... 9999 (unsigned)

Example

Program code	Comment
...	
N40 FRAME P3	; The BORDER subprogram is to be executed three times one after the other.
...	



3.2.3.4 Modal subprogram call (MCALL)

The specified subprogram is not immediately called as a result of the modal subprogram call `MCALL(<program name>)`. Instead, the call is performed as of this time in the part program after each traversing block with path motion. Also across program levels.

Note

When a program is being executed only the last modal subprogram call `MCALL(<program name>)` is effective (this is always the case). The current modal subprogram call replaces the one that has been active up until then.

If parameters are transferred to the subprogram, the parameters are only transferred with call `MCALL(<program name>(Par1, Par2, ...))`.

NOTICE
Modal subprogram calls without path motion
In the following situations the modal subprogram is also called without programming path motion:
<ul style="list-style-type: none"> • Programming addresses S or F if G0 or G1 is active. • If G0 or G1 were programmed alone in the block or with additional G commands.

Syntax

```

MCALL <program name>
...
MCALL
    
```

Meaning

MCALL <program name>:	Activate the "Modal subprogram call" function
<program name>:	Name of subprogram
MCALL:	The "Modal subprogram call" function is deactivated with MCALL without specification of a program name.

Supplementary conditions

ASUB

If the part program processing is interrupted by an ASUB (see Chapter "Interrupt routine (ASUB) (Page 528)"), then no modal subprogram calls are executed in this ASUB.

If an ASUB is started in the "Reset" channel state, then it behaves just like a normal part program with regard to the modal subprogram calls.

Tool change cycle

If the "Modal subprogram call" function is deselected during the tool change cycle, note that the tool change cycle is called implicitly, even after a block search, via the search ASUB, or manually via overstore. In this situation, the "Modal subprogram call" function must not be deselected because otherwise the search result is falsified. It is therefore recommended that the deselection of the "Modal subprogram call" function in the tool change cycle is programmed as follows:

Program code	Comment
...	
IF \$AC_ASUP == 0	; Call is not performed via search ASUB or overstore.
MCALL	; Deactivate the "Modal subprogram call" function.
ENDIF	

Program code	Comment
...	

Examples

Example 1

Program code	Comment
N10 G0 X0 Y0	
N20 MCALL L70	; Activate the modal subprogram call for L70.
N30 X10 Y10	; X10 Y10 is approached, and then L70 is called.
N40 X20 Y20	; X20 Y20 is approached, and then L70 is called.
...	
N100 MCALL	; Deactivate the "Modal subprogram call" function.
N110 X0 Y0	; X0 Y0 is approached, L70 is not called.

Example 2

Program code
N10 G0 X0 Y0
N20 MCALL L70
N30 L80

In this example, the following NC blocks with programmed path axes are in subprogram L80. L70 is called by L80.

3.2.3.5 Indirect subprogram call (CALL)

Depending on the prevailing conditions at a particular point in the program, different subprograms can be called. The name of the subprogram is stored in a variable of the STRING type. The subprogram call is realized with `CALL` and the variable name.

Note

The indirect subprogram call is only possible for subprograms without parameter transfer. For a direct subprogram call, save the name in a STRING constant.

Syntax

`CALL <program name>`

Meaning

CALL:	Command for the indirect subprogram call.	
<program name>:	Name of the subprogram (variable or constant)	
	Type:	STRING

Example

Direct call with STRING constant:

Program code	Comment
...	
CALL "/_N_WKS_DIR/_N_SUBPROG_WPD/_N_PART1_SPF"	; Direct call to subprogram PART1 with CALL.
...	

Indirect call via variable:

Program code	Comment
...	
DEF STRING[100] PROGNAME	: Define variable.
PROGNAME="/_N_WKS_DIR/_N_SUBPROG_WPD/_N_PART1_SPF"	; Assign subprogram PART1 to the PROGNAME variable.
CALL PROGNAME	; Indirect call to subprogram PART1 via CALL and the PROGNAME variable.
...	

3.2.3.6 Indirect subprogram call with specification of the calling program part (CALL BLOCK ... TO ...)

CALL and the keyword combination BLOCK ... TO is used to call a subprogram indirectly and execute the program section designated by the start and end labels.

Syntax

CALL <program name> BLOCK <start label> TO <end label>
 CALL BLOCK <start label> TO <end label>

Meaning

CALL:	Command for the indirect subprogram call.
<program name>:	Name of the subprogram (variable or constant) that contains the program section to be executed (specification optional).
	Type: STRING
<start label>:	Note: If a <program name> has not been programmed, the program section designated by <start label> and <end label> is searched for in the current program and executed.
	Type: STRING
BLOCK ... TO ... :	Keyword combination for indirect program section execution
<start label>:	Variable that refers to the start of the program section to be executed.
	Type: STRING

<code><end label></code> :	Variable that refers to the end of the program section to be executed.	
	Type:	STRING

Example

Main program:

Program code	Comment
...	
DEF STRING[20] STARTLABEL, ENDLABEL	; Variable definition for the start and end labels.
STARTLABEL="LABEL_1"	
ENDLABEL="LABEL_2"	
...	
CALL "CONTUR_1" BLOCK STARTLABEL TO ENDLABEL	; Indirect subprogram call and identifier associated with the calling program section.
...	

Subprogram:

Program code	Comment
PROC CONTUR_1 ...	
LABEL_1	; Start label: Start of program section execution.
N1000 G1 ...	
...	
LABEL_2	; End label: End of program section execution.
...	

3.2.3.7 Indirect call of a program programmed in ISO language (ISOCALL)

A program programmed in an ISO language can be called using the indirect program call `ISOCALL`. The ISO mode set in the machine data is then activated. The original execution mode becomes effective again at the end of the program. If no ISO mode is set in the machine data, the subprogram is called in Siemens mode.

For further information about the ISO mode, see

References:

ISO Dialects Functional Description

Syntax

```
ISOCALL <program_name>
```

Meaning

ISOCALL:	Keyword for an indirect subprogram call with which the ISO mode set in the machine data is activated.
<program name>:	Name of the program programmed in an ISO language (variable or constant, type STRING)

Example: Calling a contour with cycle programming from ISO mode

Program code	Comment
0122_SPF	; Contour description in ISO mode
N1010 G1 X10 Z20	
N1020 X30 R5	
N1030 Z50 C10	
N1040 X50	
N1050 M99	
N0010 DEF STRING[5] PROGNAME = "0122"	; Siemens part program (cycle)
...	
N2000 R11 = \$AA_IW[X]	
N2010 ISOCALL PROGNAME	
N2020 R10 = R10+1	; Execute program 0122.spf in ISO mode
...	
N2400 M30	

3.2.3.8 Call subprogram with path specification and parameters (PCALL)

With PCALL, you can call subprograms with the absolute path and parameter transfer.

Syntax

PCALL <path/program name>(<parameter 1>, ..., <parameter n>)

Meaning

PCALL:	Keyword for subprogram call with absolute path name
<path/program name>:	<p>Absolute path data including subprogram names. Rules regarding path data, see "Addressing program memory files (Page 544)".</p> <p>If no absolute path name is specified, PCALL behaves like a standard subprogram call with a program identifier.</p> <p>The program name is specified without prefix and without file identifier. If the program name is to be programmed with prefix and file identifier, then it must be explicitly declared with prefix and file identifier using the EXTERN command.</p>
<parameter 1>, ...:	Actual parameters in accordance with the PROC operation of the subprogram.

Example

Program code
PCALL/_N_WKS_DIR/_N_SHAFT_WPD/SHAFT(parameter1,parameter2,...)

3.2.3.9 Extend search path for subprogram calls (CALLPATH)

The search path for subprogram calls can be extended using the `CALLPATH` command. This means that also subprograms can be called from a non-selected workpiece directory without having to specify the complete, absolute path name of the subprogram.

Another application option is possible in the EES mode "EES without GDIR", if another directory is used on an external program memory to save global subroutines. In this case, using `CALLPATH` the search path can be extended by this subprogram directory.

The search path extension is made before the entry for user cycles (`_N_CUS_DIR`).

The search path extension is deselected again as a result of the following events:

- `CALLPATH` with blanks
- `CALLPATH` without parameter
- End of part program
- Reset

Syntax

```
CALLPATH("<path name>")
```

Meaning

CALLPATH:	Keyword for the programmable search path extension. Is programmed in a separate part program line.
<path name>:	Constant or variable, <code>STRING</code> type. Contains the absolute path name of the directory by which the search path should be extended. Rules regarding path data, see "Addressing program memory files (Page 544)".

Example

The search path should be extended by a certain workpiece directory:

Program code
<pre>... CALLPATH ("/_N_WKS_DIR/_N_MYWPD_WPD") ...</pre>

This means that the following search path is set (position 5. is new):

1. Actual directory/*name*
2. Actual directory/*name_SPF*
3. Actual directory/*name_MPF*
4. //NC:/_N_SPF_DIR/ *name_SPF*
5. /_N_WKS_DIR/_N_MYWPD_WPD/*name_SPF*
6. /N_CUS_DIR/*name_SPF*
7. /_N_CMA_DIR/*name_SPF*
8. /_N_CST_DIR/*name_SPF*

Supplementary conditions

- **CALLPATH** checks whether the programmed path name actually exists. In the case of an error, part program execution is interrupted with correction block alarm 14009.
- **CALLPATH** can also be programmed in INI files. It is only effective for the time it takes to process the INI file (WPD-INI file or initialization program for NC active data, e.g. frames in the 1st channel _N_CH1_UFR_INI). The search path is again reset.

3.2.3.10 Execute external subroutine (EXTCALL)

A part program can be loaded from an external memory and executed with the **EXTCALL** command.

The following are available as external memory:

- Local drive
- Network drive
- USB drive

Note

Only the USB interfaces on the operator panel front or the TCU can be used as an interface for processing an external program on a USB drive.

NOTICE

Tool/workpiece damage when using a USB flash drive

It is recommended that a USB flash drive is not used to execute an external subprogram. A communication interruption to the USB flash drive while executing the subprogram as a result of contact problems, drop out, interruption through a knock or accidental unplugging stops the machining immediately. The tool and/or workpiece could be damaged.

Default setting of the external program path

The path for the external program directory can be preset with the setting data:

SD42700 \$SC_EXT_PROG_PATH

Together with the program path and identifier specified with the `EXTCALL` call, this forms the entire path for the subprogram to be called.

Note

If the program path is specified only via the `EXTCALL` call, then `SD42700` must be empty.

Note

Parameters

When an external program is called, no parameters can be transferred to it.

Syntax

```
EXTCALL("<Path/><Program name>")
```

Meaning

EXTCALL:	Command for calling an external subprogram.	
"<Path/><Program name>":	Constant/variable of type STRING	
	<Path/>:	Absolute or relative path specification (optional)
	<Program name>:	The program name is specified without prefix "_N_". The file extensions ("MPF", "SPF") can be attached to program names using the "_" or "." character (optional). Example: "SHAFT" "SHAFT_SPF" "SHAFT.SPF"

Path specification: Short designations

The following short designations can be used to specify the path:

- Local drive: "LOCAL_DRIVE:"
- CF card: "CF_CARD:"
- USB drive (operator panel front): "USB:"

Alternatively, the abbreviations "CF_CARD:" and "LOCAL_DRIVE:" can be used.

Example

Execute from local drive

The "MAIN.MPF" main program is stored in the NC memory and is selected for execution.

Subprogram "SP_1"

The external subprogram "SP_1.SPF" or "SP_1.MPF" is on the local drive in the directory "/user/sinumerik/data/prog/WKS.DIR/WST1.WPD".

The path for the external program directory is set with:

```
SD42700 $SC_EXT_PROG_PATH = LOCAL_DRIVE:WKS.DIR/WST1.WPD
```

Note

Specification of the path for calling the external subprogram:

- Without the default setting: "LOCAL_DRIVE:WKS.DIR/WST1.WPD/SP_1"
 - With the default setting: "SP_1"
-

Subprogram "SP_2"

The external subprogram "SP_2.SPF" or "SP_2.MPF" is in the WKS.DIR/WST1.WPD directory of the USB drive. The default setting of the path to the external program directory is used for the path of subprogram "SP_1" and is also not rewritten in the main program. Therefore, the complete path has to be specified when subprogram "SP_2" is called.

Main program "MAIN"

```
Program code
N010 PROC MAIN
N020 ...
N030 EXTCALL("SP_1")
N030 EXTCALL("USB:WKS.DIR/WST1.WPD/SP_2")
N050 ...
N060 M30
```

Further information

EXTCALL call with absolute path name

If the subprogram exists under the specified path, it is executed with the EXTCALL call. If the subprogram does not exist under the specified path, the program execution is aborted with the EXTCALL call.

EXTCALL call with relative path name / without path name

In the event of an `EXTCALL` call with a relative path name or without a path name, the available program memories are searched as follows:

1. If a path name is preset in SD42700 `$SC_EXT_PROG_PATH`, the data specified in the `EXTCALL` call (program name or with relative path name) is searched for first, starting from this path. The absolute path is obtained from linking the following characters:
 - Default path specification in SD42700 `$SC_EXT_PROG_PATH`
 - Separator "/"
 - Path specification and subprogram name in the `EXTCALL` command
2. If the subprogram was not found under 1., the directories of the user memory are searched.

The search ends when the subprogram is found for the first time. If the subprogram is not found, the program execution is aborted with the `EXTCALL` call.

Adjustable reload memory (FIFO buffer)

A reload memory is required for the execution of an external subprogram. The size of the reload memory is preset with 30 kB and can only be changed by the machine manufacturer (using MD18360 `MM_EXT_PROG_BUFFER_SIZE`).

Note

Subprograms with jump commands

For external subprograms that contain jump commands (`GOTOF`, `GOTOB`, `CASE`, `FOR`, `LOOP`, `WHILE`, `REPEAT`, `IF`, `ELSE`, `ENDIF` etc.) the jump destinations must lie within the post loading memory.

Note

ShopMill/ShopTurn programs

The contour descriptions added at the file end mean the ShopMill and ShopTurn programs must be stored completely in the read-only memory.

A separate reload memory is required for external subprograms executed in parallel.

Reset / end of program / POWER ON

Reset and POWER ON cause external subprogram calls to be interrupted and the associated load memory to be deleted.

A program selected for "Execution from external source" remains selected for "Execution from external source" after a reset / end of program. The behavior does not differ from internally selected programs, assuming that the external program memory is still available.

References

Further information on "Execution from external source" can be found in:

Function Manual, Basic Functions, Mode Group, Channel, Program Operation, Reset Behavior (K1)


3.3 Interrupt routine (ASUB)

3.3.1 Function of an interrupt routine

Note

The terms "asynchronous subprogram (ASUB)" and "interrupt routine" are used interchangeably in the description below to refer to the same functionality.

A typical example should clarify the function of an interrupt routine:



The tool breaks during machining. This triggers a signal that stops the current machining process and simultaneously starts a subprogram – the so-called interrupt routine. The interrupt routine contains all the statements which are to be executed in this case.

When the interrupt routine execution has finished and the machine is ready to continue operation, the control jumps back to the main program and continues machining at the point of interruption – depending on the REPOS command (see " Repositioning at contour (Page 812) ").

⚠ CAUTION

Risk of collision

If a REPOS command has not been programmed in the subprogram, then the control goes to the end point of the block that follows the interrupted block.

References

Function Manual, Basic Functions; Mode Group, Channel, Program Operation, Reset Response (K1), Section: "Asynchronous subprograms (ASUBs), interrupt routines"

3.3.2 Creating an interrupt routine

Create interrupt routine as subprogram

The interrupt routine is identified as a subprogram in the definition.

Example:

Program code	Comment
PROC LIFT_Z	; Program name "ABHEB_Z"
N10 ...	; The NC blocks then follow:
...	
N50 M17	; Finally, end the program and return to the main program.

Saving modal G commands (SAVE)

The interrupt routine can be designated by defining with `SAVE`.

The `SAVE` attribute means that the active modal G commands are saved before calling the interrupt routine and are reactivated after the end of the interrupt routine (see "Subprograms with `SAVE` mechanism (`SAVE`) (Page 490)").

This means that it is possible to resume processing at the interruption point after the interrupt routine has been completed.

Example:

Program code
PROC LIFT_Z SAVE
N10 ...
...
N50 M17

Assign additional interrupt routines (SETINT)

`SETINT` statements can be programmed within the interrupt routine (see "Assign and start interrupt routine (`SETINT`)" (Page 530)) therefore activating additional interrupt routines. They are triggered via the input.

References

You will find more information on how to create subprograms in Section "Subprograms, Macros".

3.3.3 Assign and start interrupt routine (SETINT, PRIO, BLSYNC)

The control has several fast inputs (inputs 1 ... 8), which initiate an interrupt (1 ... 8). Each interrupt can be assigned a priority and an interrupt routine using the `SETINT` command. If the interrupt is initiated by setting the fast input, then processing in the channel is interrupted and the interrupt routine started.

Interrupt priority

If, in a part program, several inputs are assigned interrupts, then the interrupts must be assigned different priorities.

An interrupt can be assigned a priority value from 1 ... 128. Priority value 1 corresponds to the highest priority and 128 the lowest.

Syntax

```
SETINT (<n>) <NAME>
SETINT (<n>) PRIO=<value> <NAME>
SETINT (<n>) PRIO=<value> <NAME> BLSYNC
SETINT (<n>) PRIO=<value> <NAME> LIFTFAST
```

Meaning

SETINT (<n>):	Input <n> is assigned the interrupt routine <Name>. The assigned interrupt routine is started as soon as input <n> == 1 is detected. Note: If an already programmed input <n> is assigned another interrupt routine, then the previous assignment is no longer effective.	
<n>:	Input number	
	Type:	INT
	Range of values:	1 ... 8
PRIO= :	Priority of the interrupt (optional)	
<value>:	Priority value (optional)	
	Type:	INT
	Range of values:	1 ... 128 (1 ⇒ highest priority)
<NAME>:	Name of the interrupt routine (subprogram)	
BLSYNC:	BLSYNC ensures that after initiating the interrupt, the system first waits until the actual block has been completed. Only then is the interrupt routine executed. (optional)	
LIFTFAST:	LIFTFAST ensures that after initiating the interrupt, initially a fast retraction is realized (see Chapter "Fast retraction from the contour (SETINT LIFTFAST, ALF) (Page 533)"). Only then is the interrupt routine executed. (optional)	

Supplementary conditions

Interrupt rules

1. For every interrupt that cannot be immediately executed, or is presently already being processed, an additional interrupt request is saved. All other interrupt requests for this interrupt are lost.
2. If an interrupt is currently being processed and an additional interrupt with higher priority initiated, then this interrupts the lower-priority interrupt. The lower priority interrupt is continued after the higher priority interrupt has been completed. If, while the higher priority interrupt is being processed, additional requests are received for the lower-priority interrupt, then one request is saved. All others are lost.
3. If an interrupt is currently being processed and an additional interrupt with higher priority initiated, then this interrupts the lower-priority interrupt. The higher priority interrupt is processed. If a higher priority interrupt is initiated, the actual interrupt is interrupted and the higher priority interrupt processed. A maximum of six active interrupt levels are possible. One interrupt level presently being processed and five waiting interrupt levels. For each active interrupt level, a maximum of one additional interrupt request is saved. All other interrupt requests are lost. Interrupt requests are also lost if these are requested for additional interrupt levels (interrupt level ≥ 7).

Examples

Example 1: Assign interrupt routines and define the priority

Program code	Comment
...	
N20 SETINT(3) PRIO=1 ABHEB_Z	; IF input 3 == 1 THEN start interrupt routine "ABHEB_Z"
N30 SETINT(2) PRIO=2 ABHEB_X	; IF input 2 == 1 THEN start interrupt routine "ABHEB_X".
...	

The interrupt routines are executed in the sequence of the priority values if the inputs become available simultaneously (are energized simultaneously): First "ABHEB_Z", then "ABHEB_X".

Example 2: Newly assign an interrupt routine

Program code	Comment
...	
N20 SETINT(3) PRIO=2 ABHEB_Z	; IF input 3 == 1 THEN start interrupt routine "ABHEB_Z"
...	
N80 SETINT(3) PRIO=1 ABHEB_X	; IF input 3 == 1 THEN start interrupt routine "ABHEB_X"
...	

3.3 Interrupt routine (ASUB)

3.3.4 Deactivating/reactivating the assignment of an interrupt routine (DISABLE, ENABLE)

A SETINT statement can be deactivated with DISABLE and reactivated with ENABLE without losing the input → interrupt routine assignment.

Syntax

DISABLE (<n>)
 ENABLE (<n>)

Meaning

DISABLE (<n>):	Command: Deactivating the interrupt routine assignment of input <n>	
ENABLE (<n>):	Command: Reactivating the interrupt routine assignment of input <n>	
<n>:	Parameter: Number of the interrupt signal	
	Type:	INT
	Range of values:	1 ... 32

Example

Program code	Comment
N20 SETINT(3) PRIO=1 ABHEB_Z	; If input 3 switches, then interrupt ; routine "ABHEB_Z" should start.
...	
N90 DISABLE(3)	; The SETINT statement from N20 is deactivated.
...	
N130 ENABLE(3)	; The SETINT statement from N20 is reactivated.
...	

3.3.5 Delete assignment of interrupt routine (CLRINT)

An interrupt signal assignment defined with SETINT for an NC program (ASUP) can be deleted with CLRINT.

Syntax

CLRINT (<n>)

Meaning


CLRINT (<n>):	Command: Delete assignment of the interrupt signal <n> to the NC program (ASUP) defined with SETINT <n>	
<n>:	Parameter: Number of the interrupt signal	
	Type:	INT
	Range of values:	1 ... 32

Example

Program code	Comment
N20 SETINT(3) PRIO=2 ABHEB_Z	
...	
N50 CLRINT(3)	; The assignment between input "3" and interrupt routine "ABHEB_Z" is deleted.

3.3.6 Fast retraction from the contour (SETINT LIFTFAST, ALF)

For a SETINT statement with LIFTFAST, when the input is switched, the tool is moved away from the workpiece contour using fast retraction.



The further sequence is then dependent on whether the SETINT statement includes an interrupt routine in addition to LIFTFAST:

With interrupt routine: **After** the fast retraction, the interrupt routine is executed.

Without interrupt routine: Machining is stopped after fast retraction and an alarm is output.

3.3 Interrupt routine (ASUB)

Syntax

```
SETINT (<n>) PRIO=1 LIFTFAST
SETINT (<n>) PRIO=1 <NAME> LIFTFAST
```

Meaning

SETINT (<n>):	Command: Assign input <n> to an interrupt routine. The assigned interrupt routine starts when input <n> switches.	
<n>:	Parameter: Input number	
	Type:	INT
	Range of values:	1 ... 8
PRIO= :	Defining the priority	
<value>:	Priority value	
	Range of values:	1 ... 128
	Priority 1 corresponds to the highest priority.	
<NAME>:	Name of the subprogram (interrupt routine) that is to be executed.	
LIFTFAST:	Command: Fast retraction from the contour	
ALF=... :	Command: Programmable traverse direction (in motion block) Regarding the possibilities of programming with ALF, refer to the subject "Traversing direction for fast retraction from the contour (Page 535)".	

Supplementary conditions

Behavior for active frame with mirroring

When determining the retraction direction, a check is performed to see whether a frame with mirror is active. In this case, for the retraction direction, right and left are interchanged referred to the tangential direction. The direction components in tool direction are not mirrored. This behavior is activated with the MD setting:

```
MD21202 $MC_LIFTFAST_WITH_MIRROR = TRUE
```

Example

A broken tool should be automatically replaced by a daughter tool. Machining is then continued with the new tool.

Main program:

Main program	Comment
N10 SETINT(1) PRIO=1 W_WECHS LIFTFAST	; When input 1 is switched, the tool is immediately retracted from the contour with fast retraction (code no. 7 for tool radius compensation G41). Then interrupt routine "W_WECHS" is executed.
N20 G0 Z100 G17 T1 ALF=7 D1	
N30 G0 X-5 Y-22 Z2 M3 S300	
N40 Z-7	

Main program	Comment
N50 G41 G1 X16 Y16 F200	
N60 Y35	
N70 X53 Y65	
N90 X71.5 Y16	
N100 X16	
N110 G40 G0 Z100 M30	

Subprogram:

Subprogram	Comment
PROC W_CHANGE SAVE	; Subprogram where the actual operating state is saved
N10 G0 Z100 M5	; Tool changing position, spindle stop
N20 T11 M6 D1 G41	; Change tool
N30 REPOS L RMBBL M3	; Reposition at the contour and return jump into the main program (this is programmed in a block)

3.3.7 Traversing direction for fast retraction from the contour

Retraction movement

The following G commands define the retraction movement plane:

- **LFTXT**
The retraction movement plane is defined by the path tangent and the tool direction (default setting).
- **LFWP**
The plane of the retraction movement is the active working plane selected with G commands G17, G18 or G19. The direction of the retraction movement is not dependent on the path tangent. This allows a fast retraction to be programmed parallel to the axis.
- **LFPOS**
Retraction of the axis declared using POLFMASK/POLFMLIN to the absolute axis position programmed with POLF.
ALF has no influence on the retraction direction for several axes and for several axes in a linear system.
References:
Programming Manual, Fundamentals, Section: "Rapid retraction during thread cutting"

Programmable traversing direction (ALF=...)

The direction is programmed in discrete steps of 45 degrees with ALF in the plane of the retraction movement.

3.3 Interrupt routine (ASUB)


The possible traversing directions are stored in special code numbers on the control and can be called up using these numbers.

Example:

Program code

```
N10 SETINT(2) PRIO=1 ABHEB_Z LIFTFAST  
ALF=7
```


With G41 activated (machining direction to the left of the contour) the tool vertically moves away from the contour.



Reference plane for defining the traversing direction for LFTXT


At the point of application of the tool to the programmed contour, the tool is clamped at a plane which is used as a reference for specifying the retraction movement with the corresponding code number.

The reference plane is derived from the longitudinal tool axis (infeed direction) and a vector positioned perpendicular to this axis and perpendicular to the tangent at the point of application of the tool.



Code numbers with traversing direction for LFTXT

Starting from the reference plane, you will find the code numbers with traversing directions in the following diagram.



The retraction in the tool direction is defined for ALF=1.

The "fast retraction" function is deactivated with `ALF=0`.



CAUTION

Risk of collision

When the tool radius compensation is activated, then:

- For G41 codes 2, 3, 4
- For G42 codes 6, 7, 8

should not be used, as in these cases, the tool would move to the contour and would collide with the workpiece.

Code numbers with traversing directions for LFWP

With `LFWP`, the direction in the working plane is derived from the following assignment:

- G17: X/Y plane
ALF=1: Retraction in the X direction
ALF=3: Retraction in the Y direction
- G18: Z/X plane
ALF=1: Retraction in the Z direction
ALF=3: Retraction in the X direction
- G19: Y/Z plane
ALF=1: Retraction in the Y direction
ALF=3: Retraction in the Z direction

3.3.8 Motion sequence for interrupt routines

Interrupt routine without LIFTFAST

Axis motion is braked along the path down to standstill (zero speed). The interrupt routine then starts.

The standstill position is saved as interrupt position and is approached at the end of the interrupt routine for `REPOS` with `RMIBL`.

Interrupt routine with LIFTFAST

Axis motion is braked along the path. The `LIFTFAST` motion is simultaneously executed as superimposed motion. If the path motion and `LIFTFAST` motion have come to a standstill (zero speed), the interrupt routine is started.

The position on the contour is saved as interrupt position where the `LIFTFAST` motion is started and therefore the path was left.

The interrupt routine with `LIFTFAST` and `ALF=0` behaves in precisely the same way as the interrupt routine without `LIFTFAST`.

Note

The absolute value through which the geometry axes move when quickly retracting from the contour can be set using machine data.

3.4 File and Program Management

3.4.1 Program memory


3.4.1.1 Program memory in the NCK

Files and programs (e.g. main programs and subprograms, macro definitions) are saved in the non-volatile program memory (→ passive file system).

References:

Function Manual, Extended Functions; Memory Configuration (S7)

A number of file types are also stored here temporarily; these can be transferred to the work memory as required (e.g. for initialization purposes when machining a specific workpiece).



Standard directories

The following standard directories are available:

Directory	Content
_N_DEF_DIR	Data modules and macro modules
_N_CST_DIR	Standard cycles
_N_CMA_DIR	Manufacturer cycles
_N_CUS_DIR	User cycles
_N_WKS_DIR	Workpieces
_N_SPF_DIR	Global subprograms
_N_MPF_DIR	Main programs
_N_COM_DIR	Comments

File types

The following file types can be stored in the main memory:

File type	Description
<name>_MPF	Main program
<name>_SPF	Subprogram
<name>_TEA	Machine data
<name>_SEA	Setting data
<name>_TOA	Tool offsets
<name>_UFR	Zero offsets/frames
<name>_INI	Initialization files
<name>_GUD	Global user data
<name>_RPA	R-parameters
<name>_COM	Comment
<name>_DEF	Definitions for global user data and macros

Workpiece main directory (_N_WKS_DIR)

The workpiece main directory exists in the standard setup of the program memory under the name `_N_WKS_DIR`. The workpiece main directory contains all the workpiece directories for the workpieces that you have programmed.

Workpiece directories (..._WPD)

A workpiece directory contains all files required for machining a workpiece. These can be main programs, subprograms, any initialization programs and comment files.

The first time a part program is started, initialization programs are executed once, depending on the selected program (in accordance with machine data MD11280 \$MN_WPD_INI_MODE).

Example:

The workpiece directory `_N_SHAFT_WPD`, created for SHAFT workpiece contains the following files:

File	Description
<code>_N_SHAFT_MPF</code>	Main program
<code>_N_PART2_MPF</code>	Main program
<code>_N_PART1_SPF</code>	Subprogram
<code>_N_PART2_SPF</code>	Subprogram
<code>_N_SHAFT_INI</code>	General initialization program for the data of the workpiece
<code>_N_SHAFT_SEA</code>	Setting data initialization program
<code>_N_PART2_INI</code>	General initialization program for the data for the Part 2 program
<code>_N_PART2_UFR</code>	Initialization program for the frame data for the Part 2 program
<code>_N_SHAFT_COM</code>	Comment file

Data can also be stored in the workpiece directory which is not directly required by the NC for the machining. In addition to ASCII files, this can be binary files, such as images in JPG format or descriptions in PDF format. In order that these can be interpreted as binary files by the NC, the file extensions must be known in the NC (setting during commissioning via MD17000 \$MN_EXTENSIONS_OF_BIN_FILES; the following file extensions are preset in the basic setting: JPG, GIF, PNG, BMP, PDF, ICO, HTM).

Select workpiece for machining

A workpiece directory can be selected for execution in a channel. If a main program with the **same name** or only a single main program (`_MPF`) is stored in this directory, this is automatically selected for execution.

References:

Operating Manual

3.4.1.2 External program memory

In addition to the passive file system in the NC, external program memories can also be available at the machine (e.g. on the local drive or on a network drive).

Using the functions "Execute from external" or "EES (Execution from External Storage)" part programs can be **directly** executed from external program memories.

Reference:

Function Manual Basic Functions; K1: Mode Group, Channel, Program Operation, Reset Response

Global part program memory (GDIR)

When declaring the drives, one of the drives can be designated the global part program memory (GDIR).

References:

Operating Manual: section: "Manage programs" > "Setting up drives"


The system automatically creates the MPF.DIR, SPF.DIR and WKS.DIR directories on the drive. These three directories form the GDIR.

The GDIR only plays a role for the EES function. Depending on the drive configuration, the GDIR replaces or extends the NC part program memory. The creation of a GDIR is, however, not essential for EES operation.

The directories and files of the GDIR can be addressed in the part program in the same way as in the passive file system. This permits a compatible transfer of an NC program with path details from the passive file system to the GDIR. The directory SPF.DIR of the GDIR is contained in the search path for subprograms.

Program organization

The program organization on external program memories is shown in the following diagram:



Case-insensitive file systems


Note

To avoid problems with case-sensitivity for the file addressing (see "Addressing program memory files (Page 544)"), **case-insensitive** file systems should be used as external program memory.

3.4.1.3 Addressing program memory files

A file in the program memory, which is addressed with a file handling command (e.g. WRITE, DELETE, READ, ISFILE, FILEDATE, FILETIME, FILESIZE, FILESTAT, FILEINFO), is referenced with an absolute path plus file names or only with the file names. In the second case, the path of the selected program is used as file path.

Addressing in the NC/EES notation



Addressing files of the passive file system

Files of the passive file system are generally addressed in the **NC notation** (directory and file names begin with the domain identifier "_N_", "_" is the separator for the file identifier) without specifying the drive name. An addressing in **EES notation** (without domain identification "_N_", separator for the directory/file extension is ".") is, however, also permitted.

Example:

- NC notation: `"/_N_SPF_DIR/_N_SUB1_SPF"`
- EES notation: `"/SPF.DIR/SUB1.SPF"`

Note

The addressing schemes for files of the passive file system in EES notation are converted internally into NC notation in accordance with the following rules:

- Directory and file names are extended with the domain identification "_N_".
- If the fourth-last character in the directory or file name is a period ("."), it will be converted into an underscore ("_").

The passive file system can also be explicitly addressed using the predefined drive names `//NC:`.

Example:

- NC notation: "//NC:/_N_SPF_DIR/_N_SUB1_SPF"
- EES notation: "//NC:/SPF.DIR/SUB1.SPF"

Addressing files of an external program memory

Files of an external program memory not recorded as GDIR must be addressed in EES notation. The drive name (e.g. "//DEV1:") must be specified at the start of the addressing path. All symbolic device names configured in /user/sinumerik/hmi/cfg/logdrive.ini are permissible.

Example:

- EES notation: "//DEV1:/MyProgDir/pp1.xxx"
- NC notation: Not permissible

Addressing files of the global part program memory (GDIR)

When addressing files of the GDIR, in addition to specifying the path in the EES notation, it is also permissible to specify the path in the NC notation.

Example:

- EES notation: "//DEV2:/MPF.DIR/PROG11.MPF"
- NC notation: "/_N_MPF_DIR/_N_PROG11_MPF"

Note

The addressing schemes for files of the GDIR in NC notation are converted internally into EES notation in accordance with the following rules:

- The domain identification "_N_" in directory and file names is removed.
 - If the fourth-last character in the directory or file name is an underscore ("_"), it will be converted into a period (".").
-

Rules for the path specification

A complete path specification consists of drive name, directory path and file name.

Drive name

The following rules govern the specification of the drive name:

- All symbolic device names configured in /user/sinumerik/hmi/cfg/logdrive.ini are permissible.
- The character "/" is at the beginning, followed by at least one letter or one digit.
- The following characters can be any combination of letters, digits, "_" and spaces.
- The name is ended with a letter or a digit, followed by a ":".
- Other special characters are not permitted.

Note

The drive name "//NC:" is predefined for the passive file system.

Examples:

- External program memory:
 - //Drive1:
 - //Drive_1:
 - //Drive 1:
 - //A B:
 - //1 B C 2:

Directory path

The following rules govern the specification of the directory path:

- A "/" is located at the start and end of the directory path and as separator for the individual path sections.

Note

A double slash ("/") within the directory path is **not** permitted!

- Directory names:
 - Directory names must begin with a letter or a digit. Only for addressing in the NC notation do directory names begin with the domain identification "_N_".
 - The following characters can be any combination of letters, digits and "_".

Note

Spaces in directory names are also permitted for external program memories. This is not true, however, when the external program memory is created as global part program memory (GDIR).

- Other special characters are not permitted.
- Directory extensions:
 - Directory extensions must consist of three letters/digits.
 - They are separated with "_" (NC notation) or "." (EES notation) from the directory name.

Note

The passive file system has only the directory extensions _DIR and _WPD.

Examples:

- Passive file system or GDIR:
 - NC notation: `_N_WKS_DIR/_N_MYNCPROGS_WPD/...`
 - EES notation: `WKS.DIR/MYPROGS.WPD/...`
- External program memory:
 - `/abc`
 - `/ab_c.def`
 - `/ab c1.def`
 - `/a b c .d11`
 - `/abc.def/ghi.klm`

File name

The following rules apply to the file names:

- Only for addressing in NC notation do file names begin with the domain identification "`_N_`".
- The next two characters should be either two letters or an underscore followed by a letter.

Note

If this condition is satisfied, then an NC program can be called as subprogram from another program just by specifying the program name. However, if the program name starts with digits, the subprogram call is then only possible via the CALL statement.

- The following characters can be any combination of letters, digits and "`_`".
- File extension:
 - The file extension must consist of three letters/digits.

Note

Permitted file extensions in the passive file system, see "Program memory in the NCK (Page 540)".

- They are separated with "`_`" (NC notation) or "`.`" (EES notation) from the file names.

Examples:

- Passive file system or GDIR:
 - NC notation: `_N_SUB1_SPF`
 - EES notation: `SUB1.SPF`
- External program memory:
 - `Part 1`
 - `_Part1`
 - `Part_1.spf`
 - `Part1.mpf`

DIN subprogram name

The following rules apply to DIN subprogram names:

- The first character must be the letter "L".
- The following characters are digits (at least one).
- File extension:
 - The file extension must consist of three letters.
 - They are separated with "_" (NC notation) or "." (EES notation) from the file names.

Examples:

- L123
- L1_SPF (NC notation) or L1.SPF (EES notation)

Maximum path length

Maximum 128 bytes are available for specifying the drive name and the directory path; the maximum length of the file name is 31 bytes. The maximum length of the complete path is 159 bytes.

3.4.1.4 Search path for subprogram call

For subprogram calls without path data, the absolute path is determined by processing a fixed search path.

A search is then made in the program memory in the following sequence:

	Directory	Description
1	current directory / <i>name</i>	The current directory is the directory in which the program is selected.
2	current directory / <i>name_SPF</i>	
3	current directory / <i>name_MPF</i>	This can be: <ul style="list-style-type: none"> • A workpiece directory or the standard directory <code>_N_MPF_DIR</code> in the NC part program memory or global part program memory or <ul style="list-style-type: none"> • Any directory of an external program memory
4	a //NC:/_N_SPF_DIR / <i>name_SPF</i>	Subprogram directory in the NC part program memory
	b //DEV2:/_N_SPF_DIR / <i>name_SPF</i> ¹⁾	Subprogram directory in the global part program memory Note: This search step is not executed if a global part program memory has not been created, or the program is selected in the NC part program memory.
5	Search path extension programmed with <code>CALLPATH</code> (see "Extend search path for subprogram calls (<code>CALLPATH</code>) (Page 523)"). Note: This search step is not executed if <code>CALLPATH</code> has not been programmed.	

	Directory	Description
6	/_N_CUS_DIR / name_SPF	User cycle directory
7	/_N_CMA_DIR / name_SPF	Manufacturer cycle directory
8	/_N_CST_DIR / name_SPF	Standard cycle directory

¹⁾ //DEV2:" For example represents the drive on which the global part program memory has been created.

The following rules apply for the search:

- The search path is run through for each individual subprogram call, this means that it is irrelevant where the higher-level program is located.
- Depending on the directory, different file types are taken into account.
- A search is made in a directory, and not in lower-level, i.e. nested directories.

3.4.1.5 Interrogating the path and file name

The following system variables, which can be read in the part program, are available to interrogate the path and file name of an NC program:

System variable	Type	Meaning
\$P_STACK	INT	Supplies the program level in which the current NC program is executed.
\$P_PATH[<n>]	STRING	Supplies the path of the NC program, which is processed at the program level selected using field index <n>. <p>Examples:</p> <p>\$P_PATH[0] supplies the path for the main program, e.g. "/_N_WKS_DIR/_N_WELLE_WPD/".</p> <p>\$P_PATH[\$P_STACK - 1] supplies the path of the calling program.</p> <p>If the path refers to an NC program, which is saved in the passive file system of the NC or in the global part program memory (GDIR), then the path is supplied in the NC notation.</p> <p>If the path refers to an NC program, which is executed by an external program memory other than the global part program memory then \$P_PATH supplies the path in the EES notation.</p>
\$P_PROG[<n>]	STRING	Supplies the name of the NC program, which is processed at the program level selected using field index <n>. <p>If the NC program is saved in the passive file system of the NC or in the global part program memory, then the program name is supplied in the NC notation.</p> <p>If the NC program is executed by an external drive other than the global part program memory, then \$P_PROG supplies the name in the EES notation.</p>
\$P_PROGPATH	STRING	Supplies the path of the NC program that is presently being processed. <p>Calling \$P_PROGPATH is identical to \$P_PATH[\$P_STACK].</p>

System variable	Type	Meaning	
\$P_IS_EES_PATH[<n>]	BOOL	Interrogates whether the path supplied by \$P_PATH[<n>] or the program name supplied by \$P_PROG[<n>] corresponds to the NC notation or the EES notation.	
		= FALSE	<p>\$P_PATH[<n>] and \$P_PROG[<n>] supply a NC notation. This means that each identifier has the prefix "_N_". The separator for the file identifier is "_".</p> <p>Examples:</p> <ul style="list-style-type: none"> • Path in the NC notation: "/_N_WKS_DIR/_N_MYWPD_WPD/" • Program name in the NC notation: "_N_MYPROG_MPF" <p>A path in the NC notation can refer to the passive file system in the NC as well as also the global part program memory.</p>
		= TRUE	<p>\$P_PATH[<n>] and \$P_PROG[<n>] supply an EES notation. This means that the identifiers do not have the "_N_" prefix. The separator for the file identifier is ".".</p> <p>Examples:</p> <ul style="list-style-type: none"> • Path in the EES notation: "//DEV1:/WKS.DIR/MYWPD.WPD/" • Program name in the EES notation: "MYPROG.MPF"

<n>: Index <n> defines the program level, from which the path information should be read (value range: 0 ... 17)

Note

In the EES mode, outside the global part program memory (GDIR), system variables \$P_PROG, \$P_PATH and \$P_PROGPATH path names in the EES notation. For the EES mode, user programs that evaluate and process these path names must be extended so that they can also process pathnames in the EES notation.

3.4.2 Working memory (CHANDATA, COMPLETE, INITIAL)

Function

The working memory contains the current system and user data with which the control is operated (active file system), e.g.:

- Active machine data
- Tool offset data
- Zero offsets
- ...

Initialization programs

These are programs with which the working memory data is initialized. The following file types can be used for this:

File type	Description
name_TEA	Machine data
name_SEA	Setting data
name_TOA	Tool offsets
name_UFR	Zero offsets/frames
name_INI	Initialization files
name_GUD	Global user data
name_RPA	R-parameters

Data areas

The data can be organized in different areas in which they are to apply. For example, a control can have several channels or, as is commonly the case, several axes at its disposal.

There are:

Identifier	Data areas
NC	NC-specific data
CH<n>	Channel-specific data (<n> specifies the channel name)
AX<n>	Axis-specific data (<n> specifies the number of the machine axis)
TO	Tool data
COMPLETE	All data

Create initialization program at an external PC

The data area identifier and the data type identifier can be used to determine the areas which are to be treated as a unit when the data is saved:

_N_AX5_TEA_INI	Machine data for axis 5
_N_CH2_UFR_INI	Frames of channel 2
_N_COMPLETE_TEA_INI	All machine data

When the control is started up initially, a set of data is automatically loaded to ensure proper operation of the control.

Procedure for multi-channel controls (CHANDATA)

CHANDATA(<channel number>) for several channels is only permissible in the file `_N_INITIAL_INI`. This is the commissioning file with which all data of the control is initialized.

Program code	Comment
<code>%_N_INITIAL_INI</code> <code>CHANDATA (1)</code>	

3.4 File and Program Management

Program code	Comment
	; Machine axis assignment, channel 1:
\$MC_AXCONF_MACHAX_USED[0]=1	
\$MC_AXCONF_MACHAX_USED[1]=2	
\$MC_AXCONF_MACHAX_USED[2]=3	
CHANDATA (2)	
	; Machine axis assignment, channel 2:
\$MC_AXCONF_MACHAX_USED[0]=4	
\$MC_AXCONF_MACHAX_USED[1]=5	
CHANDATA (1)	
	; Axial machine data:
	; Exact stop window coarse:
\$MA_STOP_LIMIT_COARSE[AX1]=0.2	; Axis 1
\$MA_STOP_LIMIT_COARSE[AX2]=0.2	; Axis 2
	; Exact stop window fine:
\$MA_STOP_LIMIT_FINE[AX1]=0.01	; Axis 1
\$MA_STOP_LIMIT_FINE[AX2]=0.01	; Axis 2

NOTICE

CHANDATA statement

In the part program, the CHANDATA statement may only be set for that channel in which the NC program is executed. This means the statement can be used to protect NC programs so that they are not executed in the wrong channel.

Program processing is aborted if an error occurs.

Note

INI files in job lists do not contain any CHANDATA statements.

Save initialization program (COMPLETE, INITIAL)

The files of the working memory can be saved on an external PC and then read in again from there.

- The files are saved with COMPLETE.
- INITIAL is used to create an INI file (_N_INITIAL_INI) over all areas.

Read-in initialization program

NOTICE
Data loss
If the file is read-in with the name "INITIAL_INI", then all data that is not supplied in the file is initialized using standard data. Only machine data is an exception. This means that setting data, tool data, ZO, GUD values, ... are supplied with standard data (normally "ZERO").

For example, the file COMPLETE_TEA_INI is suitable for reading-in individual machine data. The control only expects machine data in this file. This is the reason that the other data areas remain unaffected in this case.

Loading initialization programs

The INI programs can also be selected and called as part programs if they only use data of one channel. This means that it is also possible to initialize program-controlled data.

3.5 File handling

3.5.1 Write file (WRITE)

The `WRITE` command writes sets/data from the NC program at the end of a file (log file) in the passive file system or to external program memory. This can also be the program that is presently being executed.

Note

If no such file exists in the program memory, one will be created and can be written to using the `WRITE` command.

Requirement

The currently set protection level must be equal to or greater than the `WRITE` right of the file. If this is not the case, access is denied with an error message (return value of error variable = 13).

Syntax

```
DEF INT <error>
...
WRITE (<error>,"<file name>"/"<ExtG>","<set/data>")
```

Meaning

WRITE:	Command for appending a block or data to the end of the specified file.		
<error>:	Parameter 1: Variable for returning the error value		
	Type:	INT	
	Value:	0	No error
		1	Path not permitted
		2	Path not found
		3	File not found
		4	Incorrect file type
		10	File is full
		11	The file is in use
		12	No resources available
		13	No access rights
		14	Missing or unsuccessful EXTOPEN for the output device
		15	Error when writing to an external device
16	Invalid external path has been programmed		

<file name>:	Parameter 2: The name of the file in which the specified block or specified data is to be added.
	Type: STRING
	The absolute path can be specified before the actual file name. If a path is not specified, the file is searched for in the current directory (= directory of selected program). Rules regarding path data, see "Addressing program memory files (Page 544)".
<ExtG>:	If the data is to be output to an external device/file using the "Process DataShare" function, then the symbolic identifiers for the external device/file to be opened must be specified instead of the file name.
	Type: STRING
	For further information, see "Process DataShare - Output to an external device/file (EXTOPEN, WRITE, EXTCLOSE): (Page 1040)". Note: The identifier must be identical to the identifier specified in the EXTOPEN command.
<block/data>:	Parameter 3: The block or data to be added to the specified file.
	Type: STRING

Note

When writing to the passive file system or to an external program memory, the `WRITE` command implicitly inserts an "LF" character (LINE FEED = new line) at the end of the output string.

This behavior does not apply for output to an external device/file using the "Process DataShare" function. If an "LF" is also to be output, then this must be explicitly specified in the output string.

→ also refer to example 3: Implicit/explicit "LF"!

Supplementary conditions

- **Maximum file size (→ machine manufacturer)**
The maximum possible file size of log files in the passive file system is set with the machine data:
`MD11420 $MN_LEN_PROTOCOL_FILE`
The maximum file length is applicable for all files created using the `WRITE` command in the passive file system. If it is exceeded, an error message is output and the block or data is not saved. If there is sufficient free memory, a new file can be created.

Examples**Example 1: WRITE command into the passive file system without absolute path data**

Program code	Comment
N10 DEF INT ERROR	; Definition of error variables.
N20 WRITE(ERROR, "PROT", "LOG FROM 7.2.97")	; Write the text "LOG FROM 7.2.97" to file _N_PROT_MPF.
N30 IF ERROR	;Error evaluation.

Program code	Comment
N40 MSG ("Error with WRITE command:" <<ERROR)	
N50 M0	
N60 ENDIF	
...	

Example 2: WRITE command into the passive file system with absolute path data

Program code
...
WRITE(ERROR, "/_N_WKS_DIR/_N_PROT_WPD/_N_PROT_MPF", "LOG FROM 7.2.97")
...

Example 3: Implicit/explicit "LF"

a) Write to the passive file system with implicitly generated "LF"

Program code
...
N110 DEF INT ERROR
N120 WRITE(ERROR, "/_N_MPF_DIR/_N_MYPROTFILE_MPF", "MY_STRING")
N130 WRITE(ERROR, "/_N_MPF_DIR/_N_MYPROTFILE_MPF", "MY_STRING")
N140 M30

Output result:

MY_STRING

MY_STRING

b) Write to an external file without implicitly generated "LF"

Program code
...
N200 DEF STRING[30] DEV_1
N210 DEF INT ERROR
N220 DEV_1="LOCAL_DRIVE/myprotfile.mpf"
N230 EXTOPEN(ERROR, DEV_1)
N240 WRITE(ERROR, DEV_1, "MY_STRING")
N250 WRITE(ERROR, DEV_1, "MY_STRING")
N260 EXTCLOSE(ERROR, DEV_1)
N270 M30

Output result:

MY_STRINGMY_STRING

c) Write to an external file with explicitly generated "LF"

The following must be programmed in order to achieve the same result as under a:

Program code

```

...
N200 DEF STRING[30] DEV_1
N210 DEF INT ERROR
N220 DEV_1="LOCAL_DRIVE/myprotfile.mpf"
N230 EXTOPEN(ERROR,DEV_1)
N240 WRITE(ERROR,DEV_1,"MY_STRING'H0A'")
N250 WRITE(ERROR,DEV_1,"MY_STRING'H0A'")
N260 EXTCLOSE(ERROR,DEV_1)
N270 M30

```

Output result:

MY_STRING

MY_STRING

3.5.2 Delete file (DELETE)

The `DELETE` command deletes all files, irrespective of whether these were created using the `WRITE` command or not. Files that were created using a higher access authorization can also be deleted with `DELETE`.

Syntax

```

DEF INT <error>
DELETE(<error>,"<file name>")

```

Meaning

DELETE:	Command for deleting the specified file.			
<error>:	Variable for returning the error value.			
	Type.	INT		
	Value:	0	No error	
		1	Path not allowed	
		2	Path not found	
		3	File not found	
		4	Incorrect file type	
		11	The file is in use	
		12	No resources available	
20		Other error		

<code><file name></code> :	Name of the file to be deleted	
	Type:	STRING
	The absolute path can be specified before the actual file name. If a path is not specified, the file is searched for in the current directory (= directory of selected program). Rules regarding path data, see "Addressing program memory files (Page 544)".	

Example

Program code	Comment
N10 DEF INT ERROR	; Definition of error variables.
N15 STOPRE	; Preprocessing stop.
N20 DELETE (ERROR, "/_N_SPF_DIR/_N_TEST1_SPF")	; Deletes file TEST1 in the sub-program directory.
N30 IF ERROR	; Error evaluation.
N40 MSG("error for DELETE command:" <<ERROR)	
N50 M0	
N60 ENDIF	

3.5.3 Read lines in the file (READ)

The READ command reads one or several lines in the specified file and stores the information read in a STRING type array. In this array, each read line occupies an array element.

Requirement

The currently set protection level must be equal to or greater than the READ right of the file. If this is not the case, access is denied with an error message (return value of error variable = 13).

Syntax

```
DEF INT <error>
DEF STRING[<string length>] <result>[<n>,<m>]
READ(<error>,"<file name>",<start line>,<number of lines>,<result>)
```

Meaning

READ:	Command for reading lines from the specified file and storing these lines in a variable array.		
<error>:	Variable for returning the error value (call-by-reference parameter)		
	Type:	INT	
	Value:	0	No error
		1	Path not allowed
		2	Path not found
		3	File not found
		4	Incorrect file type
		11	The file is in use
		13	Insufficient access rights
		21	Line does not exist (<start line> or <number of lines> parameter exceeds the number of lines in the specified file).
22		Field length of the result variable (<result>) is too small.	
23	Line range too large (<number of lines> parameter selected so large that the read would go beyond the end of the file).		
<file name>:	Name of the file to be read (call-by-value parameter)		
	Type:	STRING	
	The absolute path can be specified before the actual file name. If a path is not specified, the file is searched for in the current directory (= directory of selected program). Rules regarding path data, see "Addressing program memory files (Page 544)".		
<start line>:	Start line of the file section to be read (call-by-value parameter)		
	Type:	INT	
	Value:	0	Reads the number of lines specified with the <number of lines> parameter before the end of the file.
1 to n		Number of the first line to be read.	
<number of lines>:	Number of lines to be read (call-by-value parameter)		
	Type:	INT	
<result>:	Result variable (call-by-reference parameter)		
	Variable array in which the read text is stored.		
	Type:	STRING (max. length: 255)	
	If fewer lines are specified in the <number of lines> parameter than the array size [<n>, <m>] of the result variable, the remaining array elements will not be modified. Termination of a line by means of the control characters "LF" (Line Feed) or "CR LF" (Carriage Return Line Feed) is not stored in the result variable. Read lines are cropped if the line is longer than the defined string length. An error message is not output.		

Note

Binary files cannot be read in. The "incorrect data type" error is output (return value of the error variable = 4). The following types of file are not readable: `_BIN`, `_EXE`, `_OBJ`, `_LIB`, `_BOT`, `_TRC`, `_ACC`, `_CYC`, `_NCK`.

Example

Program code	Comment
N10 DEF INT ERROR	; Definition of error variables.
N20 DEF STRING[255] RESULT[5]	; Definition of result variables.
N30 READ(ERROR, "/_N_CST_DIR/_N_TEST- FILE_MPF", 1, 5, RESULT)	; File name with domain and file identifier and path name.
N40 IF ERROR <> 0	; Error evaluation.
N50 MSG("ERROR"<<ERROR<<"ON READ COMMAND")	
N60 M0	
N70 ENDIF	
...	

3.5.4 Check for presence of file (ISFILE)

The `ISFILE` command checks whether a file exists in the program memory.

Syntax

`<Result>=ISFILE("<File name>")`

Meaning

<code>ISFILE:</code>	Command to check the availability of a file			
<code><file name>:</code>	Name of the file whose availability is to be checked.			
	Type:	STRING		
	The absolute path can be specified before the actual file name. If a path is not specified, the file is searched for in the current directory (= directory of selected program). Rules regarding path data, see "Addressing program memory files (Page 544)".			
<code><result>:</code>	Result variable to which the result of the check is assigned.			
	Type.	BOOL		
	Value:	TRUE	File exists	
		FALSE	File does not exist	

Examples

Example 1

Program code	Comment
N10 DEF BOOL RESULT	; Definition of result variables.
N20 RESULT=ISFILE("TESTFILE")	
N30 IF (RESULT==FALSE)	
N40 MSG("FILE DOES NOT EXIST")	
N50 M0	
N60 ENDIF	
...	

Example 2

Program code	Comment
N10 DEF BOOL RESULT	; Definition of result variables.
N20 RESULT=ISFILE("TESTFILE")	
N30 IF (NOT ISFILE("TESTFILE"))	
N40 MSG("FILE DOES NOT EXIST")	
N50 M0	
N60 ENDIF	
...	

3.5.5 Read out file information (FILEDATE, FILETIME, FILESIZE, FILESTAT, FILEINFO)

The FILEDATE, FILETIME, FILESIZE, FILESTAT, and FILEINFO commands read out specific file information such as date/time of the last write access, current file size, file status or all of this information.

Requirement

The currently set protection level must be equal to or greater than the show right of the superordinate directory. If this is not the case, access is denied with an error message (return value of error variable = 13).

Syntax

```
FILE....(<Error>,"<File name>",<Result>)
```

Meaning

FILEDATE:	Returns the date of the last write access to a file
FILETIME:	Returns the time of the last write access to a file
FILESIZE:	Returns the current size of a file

FILESTAT:	Returns a file with regard to the following rights for the status : <ul style="list-style-type: none"> • Read (r: read) • Write (w: write) • Execute (x: execute) • Show (s: show) • Delete (d: delete) Note: These protection levels are specific properties of the passive file system. When accessing an external program memory, FILESTAT therefore supplies default access rights (77777).			
FILEINFO:	For a file, supplies the sum of the information , which can be read out via FILEDATE, FILETIME, FILESIZE and FILESTAT			
<Error>:	Variable for returning the error value (call-by-reference parameter)			
	Type:	VAR INT		
	Value:	0	No error	
		1	Path not allowed	
		2	Path not found	
		3	File not found	
		4	Incorrect file type	
		13	Insufficient access rights	
22	String length of the result variable (<result>) is too small.			
<file name>:	Name of the file from which the file information is to be read out			
	Type:	CHAR[160]		
	The absolute path can be specified before the actual file name. If a path is not specified, the file is searched for in the current directory (= directory of selected program). Rules regarding path data, see "Addressing program memory files (Page 544)".			
<result>:	Result variable (Call-By-Reference parameter)			
	Variable in which the requested file information is stored.			
	Type:	VAR CHAR[8]	at	FILEDATE Format: "dd.mm.yy"
		VAR CHAR[8]	at	FILETIME Format: "hh.mm.ss"
		VAR INT	at	FILESIZE The file size is output in bytes.
		VAR CHAR[5]	at	FILESTAT Format: "rwxsd" (r: read, w: write, x: execute, s: show, d: delete)
	VAR CHAR[32]	at	FILEINFO Format: "rwxsd nnnnnnnn dd.mm.yy hh:mm:ss"	

Example

Program code	Comment
N10 DEF INT ERROR	; Definition of error variables.
N20 STRING[32] RESULT	; Definition of result variables.
N30 FILEINFO(ERROR, "/_N_MPF_DIR/_N_TESTFILE_MPF", RESULT)	; File name with domain, file ID and path data.
N40 IF ERROR <> 0	; Error evaluation
N50 MSG("ERROR"<<ERROR<<"FOR FILE INFORMATION COMMAND")	
N60 M0	
N70 ENDIF	
...	

In the result variables RESULT, the example could supply the following result:

"77777 12345678 26.05.00 13:51:30"

3.6 Protection zones

3.6.1 Defining protection zones (CPROTDEF, NPROTDEF)

Protection zones, which protect machine elements against collisions, are defined in the part program in blocks. These contain the following elements:

1. Definition of the machining plane
Before the actual protection zone definition, the machining plane must be selected, to which the contour description of the protection zone refers.
2. Start of the definition
Depending on the particular NC command, either a channel-specific or machine-specific protection zone is created.
3. Contour description of the protection zone
The contour of a protection zone is defined with traversing motion. These are not executed and have no connection to previous or subsequent geometry descriptions. They only define the protection zone.
4. End of definition

Syntax

```
DEF INT <Var>
G17/G18/G19
CPROTDEF/NPROTDEF (<n>,<t>,<AppLim>,<AppPlus>,<AppMinus>)
G0/G1/... X/Y/Z...
...
EXECUTE (<Var>)
```

Meaning

DEF INT <Var>:	Definition of a local help variable, of the INTEGER data type	
<Var>:	Name of the Help variable	
G17/G18/G19:	Machining plane Note: It is not permissible to change the machining plane before the end of the definition. Programming the applicate is not permitted between start and end of the definition.	
CPROTDEF():	Predefined procedure to define a channel -specific protection zone	
NPROTDEF():	Predefined procedure to define a machine -specific protection zone	
<n>:	Number of defined protection zone	
	Data type:	INT

<t>:	Type of protection zone				
	Data type:	BOOL			
	Value:	<table border="1"> <tr> <td>TRUE</td> <td>Tool-related protection zone</td> </tr> <tr> <td>FALSE</td> <td>Workpiece-related protection zone</td> </tr> </table>	TRUE	Tool-related protection zone	FALSE
TRUE	Tool-related protection zone				
FALSE	Workpiece-related protection zone				
<AppLim>:	Type of limitation in the third dimension				
	Data type:	INT			
	Value:	0	No limitation		
		1	Limit in plus direction		
		2	Limit in minus direction		
3		Limit in positive and negative direction			
<AppPlus>:	Value of the limit in the positive direction in the 3rd dimension				
	Data type:	REAL			
<AppMinus>:	Value of the limit in the negative direction in the 3rd dimension				
	Data type:	REAL			
G0/G1/... X/Y/Z... . . . :	<p>The contour of a protection zone is specified with up to 11 traversing movements in the selected machining plane. The first traversing movement is the movement to the contour. The last point in the contour description must always coincide with the first point of the contour description.</p> <p>The valid protection zone is the zone left of the contour:</p> <ul style="list-style-type: none"> • Internal protection zone The contour of an internal protection zone must be described in the counterclockwise direction. • External protection zones (permitted only for workpiece-related protection zones) The contour for an external protection zone must be described in the clockwise direction. <p>The following contour elements are permissible:</p> <ul style="list-style-type: none"> • G0, G1 for straight contour elements • G2 for circle segments in the clockwise direction Permissible only for workpiece-related protection zones. Not permissible for tool-related protection zones because they must be convex. • G3 for circular segments in the counter-clockwise direction <p>Note: A protection zone cannot be described by a complete circle. A complete circle must be divided into two semicircles.</p> <p>Note: The sequence G2 → G3 or G3 → G2 is not permissible! A short G1 block must be inserted between the two circular blocks.</p>				
EXECUTE (<Var>):	<p>Predefined procedure that marks the end of the definition</p> <p>A switch is made back to normal program processing with EXECUTE.</p>				

Example

See example under "Activating/deactivating protection zones (CPROT, NPROT) (Page 567)".

Additional information

Machine-specific protection zones

A machine-specific protection zone or its contour is defined using the geometry axis, i.e. referenced to the basic coordinate system (BCS) of a channel. In order that correct protection-zone monitoring can take place in all channels in which the machine-specific protection zone is active, the basic coordinate system (BCS) of all of the channels involved must be identical:

- position of the coordinate origin referred to the machine zero
- Orientation of the coordinate axes

Reference point for contour description


- Tool-related protection zones
Coordinates for **tool**-related protection zones must be specified as absolute values referred to the **tool holder reference point F**.
- Workpiece-related protection zones
Coordinates for **workpiece**-related protection zones must be specified as absolute values referred to the zero point of the **basic coordinate system (BCS)**.

Protection zones symmetrical around the center of rotation

For protection zones symmetrical around the axis of rotation (e.g. spindle chuck), you must describe the complete contour and not only the contour up to the center of rotation.

Tool-related protection zones

Tool-related protection zones must always be convex. If a concave protected zone is desired, this should be subdivided into several convex protection zones.



- ① Convex protection zones
- ② Concave protection zones (**not permissible!**)
- F Toolholder reference point

General conditions

During the definition of a protection zone, the following functions must not be active or used:

- Tool radius compensation (cutter radius compensation, tool nose radius compensation)
- Transformation
- Reference point approach (G74)
- Fixed point approach (G75)
- Dwell time (G4)
- Block search stop (STOPRE)
- End of program (M17, M30)
- M functions: M0, M1, M2

3.6.2 Activating/deactivating protection zones (CPROT, NPROT)

Protection zones previously defined in the part program can be activated at any time – or can be preactivated for subsequent activation by the PLC user program. Active protection zones can be deactivated at any time.

When activating or preactivating, it is also possible to relatively shift the reference point of the protection zone.

Note

A protection zone is only taken into account after the referencing of all geometry axes of the channel in which it has been activated.

Note

Monitoring protection zones

If a tool-related protection area is not active, the tool path is checked against the workpiece-related protection zones.

If no workpiece-oriented protection zone is active, then there is no protection zone monitoring.

Syntax

```
CPROT (<n>, <Status>, <XMov>, <YMov>, <ZMov>)  
NPROT (<n>, <Status>, <XMov>, <YMov>, <ZMov>)
```

Meaning

CPROT:	Predefined procedure to activate a channel -specific protection zone
NPROT:	Predefined procedure to activate a machine -specific protection zone

<n>:	Number of the protection zone		
	Data type:	INT	
<Status>:	The channel-specific activation status is set using this parameter		
	Data type:	INT	
	Value:	0	Deactivate protection zone
		1	Preactivate protection zone
		2	Activate protection zone
3		Preactivate protection zone with conditional stop	
<XMov>, <YMov>, <ZMov>:	Additive offset values in the X/Y/Z direction The offset can take place in 1, 2, or 3 dimensions. The offset values refer to:		
	<ul style="list-style-type: none"> • The machine zero for a workpiece-related protection zone • The tool carrier reference point F for a tool-specific protection zone 		
	Data type:	REAL	

Example


Possible collision of a milling cutter with the measuring probe is to be monitored on a milling machine. The position of the measuring probe is to be defined by an offset when the function is activated.

The following protection zones are defined for this:

- A machine-specific and a workpiece-related protection zone for both the measuring probe holder (n-PZ1) and the measuring probe itself (n-PZ2).
- A channel-specific and a tool-related protection zone for the milling cutter holder (c-PZ1), the cutter shank (c-PZ2) and the milling cutter itself (c-PZ3).

The orientation of all protection zones is in the Z direction.

The position of the reference point of the measuring probe on activation of the function must be X = -120, Y = 60 and Z = 80.



- ① Name for the protection zone of the probe
F Toolholder reference point

Program code	Comment
DEF INT PROTZONE	; Definition of a Help variable
G17	; machining plane XY
; defining protection zones:	
NPROTDEF(1,FALSE,3,10,-10)	; protection zone n-PZ1
G01 X0 Y-10	
X40	
Y10	
X0	
Y-10	
EXECUTE (PROTZONE)	
NPROTDEF(2,FALSE,3,5,-5)	; protection zone n-PZ2
G01 X40 Y-5	
X70	
Y5	
X40	
Y-5	
EXECUTE (PROTZONE)	
CPROTDEF(1,TRUE,3,0,-100)	; protection zone c-PZ1
G01 X-20 Y-20	
X20	
Y20	
X-20	
Y-20	
EXECUTE (PROTZONE)	

Program code	Comment
CPROTDEF(2,TRUE,3,-100,-150)	; protection zone c-PZ2
G01 X0 Y-10	
G03 X0 Y10 J10	
X0 Y-10 J-10	
EXECUTE (PROTZONE)	
CPROTDEF(3,TRUE,3,-150,-170)	; protection zone c-PZ3
G01 X0 Y-27.5	
G03 X0 Y27.5 J27.5	
X0 Y27.5 J-27.5	
EXECUTE (PROTZONE)	
; activating protection zones:	
NPROT(1,2,-120,60,80)	; activate protection zone n-PZ1 with offset
NPROT(2.2,-120,60,80)	; activate protection zone n-PZ2 with offset
CPROT(1,2,0,0,0)	; activate protection zone c-PZ1
CPROT(2,2,0,0,0)	; activate protection zone c-PZ2
CPROT(3,2,0,0,0)	; activate protection zone c-PZ3

Further information

Activation status after the control powers up

A protection zone can already be active after the control system powers up and the axes have been referenced. This is the case if, for the protection zone, the following system variable is set to TRUE:

- `$SN_PA_ACTIV_IMMED[<n>]` (for machine-specific protection zone) or
- `$SC_PA_ACTIV_IMMED[<n>]` (for channel-specific protection zone)
Index "<n>" corresponds to the number of the protection zone: 0 = 1. Protection zone

The protection zone is activated with status = 2 – and without offset.

Multiple activation of a protection zone

A machine-specific protection zone can be active simultaneously in several channels (e.g. protection zone of a tailstock where there are two opposite sides). The protection zones are only monitored if all geometry axes have been referenced.

A protection zone cannot be activated simultaneously with different offsets in a single channel.

Protection zone monitoring for active tool radius compensation

For active tool radius compensation, a functioning protection zone monitoring is only possible if the plane of the tool radius compensation is identical to the plane of the protection zone definitions.

3.6.3 Checking for protection zone violation, working area limitation and software limit switches (CALCPOSI)

Function

In the workpiece coordinate system (WCS), the CALCPOSI function checks whether, starting from the starting position, the **geometry axes** can be traversed a specified distance without violating active limits. For the case that the distance cannot be fully traversed because of limits, a positive, decimal-coded status value and the maximum possible traversing distance are returned.

Definition

```
INT CALCPOSI (VAR REAL[3] <Start>, VAR REAL[3] <Dist>, VAR REAL[5]
<Limit>, VAR REAL[3] <MaxDist>, BOOL <MeasSys>, INT <TestLim>)
```

Syntax

```
<Status> = CALCPOSI (VAR <Start>, VAR <Dist>, VAR <Limit>, VAR
<MaxDist>, <MeasSys>, <TestLim>)
```

Meaning

CALCPOSI (...):	Predefined function for testing limit violations regarding the geometry axes	
	Preprocessing stop:	No
	Alone in the block:	Yes

<status>: (Part 1)	Function return value. Negative values indicate error states.		
	Data type:	INT	
	Value range:	$-8 \leq x \leq 100000$	
	Value:	0	The distance can be traversed completely.
		-1	At least one component is negative in <Limit>.
		-2	Error in a transformation calculation. Example: The traversing distance passes through a singularity so that the axis positions cannot be defined.
		-3	The specified traversing distance <Dist> and the maximum possible traversing distance <MaxDist> are linearly dependent. Note Can only occur in conjunction with <TestLim>, bit 4 == 1.
		-4	The projection of the traversing direction contained in <Dist> on to the limitation surface is the zero vector, or the traversing direction is perpendicular to the violated limitation surface. Note Can only occur in conjunction with <TestLim>, bit 5 == 1.
		-5	In <TestLim>, bit 4 == 1 AND bit 5 == 1
		-6	At least one machine axis that has to be considered for checking the traversing limits has not been referenced.
-7		Collision avoidance function: Invalid definition of the kinematic chain or the protection zones.	
-8	Collision avoidance function: This command cannot be executed because of insufficient memory.		
<status>: (Part 2)	Units digit		
	Note If several limits are violated simultaneously, the limit with the greatest restriction on the specified traversing distance is signaled.		
	Value:	1	Software limit switches are limiting the traversing distance
		2	Working area limits are limiting the traversing distance
		3	Protection zones are limiting the traversing distance
		4	Collision avoidance function: Protection zones are limiting the traversing path
	Tens digit		
	Value:	1x	The initial value violates the limit
		2x	The specified straight line violates the limit. This value is returned even if the end point does not violate any limit itself, but the path from the starting point to the end point would cause a limit value to be violated (e.g. by passing through a protection zone, curved software limit switches in the WCS for non-linear transformations, e.g. transmit).


<status>: (Part 3)	Hundreds digit		
	Value:	1xx	AND units digit == 1 or 2: The positive limit value has been violated. AND units digit == 3 ¹⁾ : An NC-specific protection zone has been violated.
		2xx	AND units digit == 1 or 2: The negative limit value has been violated. AND units digit == 3 ¹⁾ : A channel-specific protection zone is violated.
	Thousands digit		
<status>: (Part 4)	Value:	1xxx	AND units digit == 1 or 2: Factor with which the axis number is multiplied that violates the limit. Numbering of the axes begins with 1. Reference: <ul style="list-style-type: none"> • Software limit switches: Machine axes • Working area limitation: Geometry axes AND units digit == 3 ¹⁾ : Factor with which the number of the violated protection zone is multiplied.
<status>: (Part 5)	Hundred thousands digit		
	Value:	0xxxxx	Hundred thousands digit == 0: <Dist> remains unchanged
		1xxxxx	A direction vector is returned in <Dist>, which defines the further motion direction on the limitation surface. Can only occur with the following supplementary conditions: <ul style="list-style-type: none"> • Software limit switch or working area limit violated (not in the starting point) • A transformation is not active • <TestID>, bit 4 or bit 5 == 1
<Start>:	Reference to a vector with the start positions: <ul style="list-style-type: none"> • <Start> [0]: 1st geometry axis • <Start> [1]: 2nd geometry axis • <Start> [2]: 3rd geometry axis 		
	Parameter type:	Input	
	Data type:	VAR REAL [3]	
	Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value	

<Dist>:	Reference to a vector.	
	Input: Incremental traversing distance	
	<ul style="list-style-type: none"> • <Dist> [0]: 1st geometry axis • <Dist> [1]: 2nd geometry axis • <Dist> [2]: 3rd geometry axis 	
	Output (only for set hundred thousands digit in <Status>):	
	<p><Dist> contains a unit vector v as output value which defines the further traversing direction in the WCS.</p> <p>Case 1: Formation of vector v for <TestID>, bit 4 == 1</p> <p>The input vectors <Dist> and <MaxDist> span the motion plane. This plane is cut by the violated limitation surface. The intersecting line of the two planes defines the direction of vector v. The orientation (sign) is selected so that the angle between the input vector <MaxDist> and v is not greater than 90 degrees.</p> <p>Case 2: Formation of vector v for <TestID>, bit 5 == 1</p> <p>Vector v is the unit vector in the projection direction of the traversing vector contained in <Dist> on the limitation surface. If the projection of the traversing vector on the limitation surface is the zero vector, an error is returned.</p>	
Parameter type:	Input/output	
Data type:	VAR REAL [3]	
Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value	
<Limit>:	Reference to an array of length 5.	
	<ul style="list-style-type: none"> • <Limit> [0 - 2]: Minimum clearance of the geometry axes to the limits: <ul style="list-style-type: none"> – <Limit> [0]: 1st geometry axis – <Limit> [1]: 2nd geometry axis – <Limit> [2]: 3rd geometry axis <p>The minimum clearances are observed with:</p> <ul style="list-style-type: none"> – Working area limitation: No restrictions – Software limit switches: If no transformation is active, or a transformation is active in which a clear assignment of the geometry axes to the linear machine axes is possible, e.g. 5-axis transformations. 	
	<ul style="list-style-type: none"> • <Limit> [3]: Contains the minimum clearance for linear machine axes which, for example, cannot be assigned a geometry axis because of a non-linear transformation. This value is also used as limit value for the monitoring of the conventional protection zones and the collision avoidance protection zones. • <Limit> [4]: Contains the minimum clearance for rotary machine axes which, for example, cannot be assigned a geometry axis because of a non-linear transformation. 	
	<p>Note</p> <p>This value is only active for the monitoring of the software limit switches for special transformations.</p>	
	Parameter type:	Input
Data type:	VAR REAL [5]	
Value range:	-max. REAL value ≤ x[n] ≤ +max. REAL value	

<MaxDist>:	<p>Reference to a vector with the incremental traversing distance in which the specified minimum clearance of an axis limit is not violated by any of the relevant machine axes:</p> <ul style="list-style-type: none"> • <Dist> [0]: 1st geometry axis • <Dist> [1]: 2nd geometry axis • <Dist> [2]: 3rd geometry axis <p>If the traversing distance is not restricted, the contents of this return parameter are the same as the contents of <Dist>.</p> <p>For <TestID>, bit 4 == 1: <Dist> and <MaxDist></p> <p><MaxDist> and <Dist> must contain vectors as input values that span a motion plane. The two vectors must be mutually linearly independent. The absolute value of <MaxDist> is arbitrary. For the calculation of the motion direction, see the description for <Dist>.</p> <table border="1" data-bbox="598 676 1481 789"> <tr> <td>Parameter type:</td> <td>Output</td> </tr> <tr> <td>Data type:</td> <td>VAR REAL [3]</td> </tr> <tr> <td>Value range:</td> <td>-max. REAL value ≤ x[<n>] ≤ +max. REAL value</td> </tr> </table>		Parameter type:	Output	Data type:	VAR REAL [3]	Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value																														
Parameter type:	Output																																					
Data type:	VAR REAL [3]																																					
Value range:	-max. REAL value ≤ x[<n>] ≤ +max. REAL value																																					
<MeasSys>:	<p>Measuring system (inch/metric) for position and distance specifications (optional)</p> <table border="1" data-bbox="598 832 1481 1172"> <tr> <td>Data type:</td> <td colspan="2">BOOL</td> </tr> <tr> <td rowspan="2">Value:</td> <td>FALSE (Default)</td> <td>System of units corresponding to the currently active G command from the G group 13 (G70, G71, G700, G710). Note If G70 is active and the basic system is metric (or G71 is active and the basic system is inch), the system variables \$AA_IW and \$AA_MW are provided in the basic system and, if used, must be converted for CALCPOSI.</td> </tr> <tr> <td>TRUE</td> <td>System of units according to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM</td> </tr> </table>		Data type:	BOOL		Value:	FALSE (Default)	System of units corresponding to the currently active G command from the G group 13 (G70, G71, G700, G710). Note If G70 is active and the basic system is metric (or G71 is active and the basic system is inch), the system variables \$AA_IW and \$AA_MW are provided in the basic system and, if used, must be converted for CALCPOSI.	TRUE	System of units according to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM																												
Data type:	BOOL																																					
Value:	FALSE (Default)	System of units corresponding to the currently active G command from the G group 13 (G70, G71, G700, G710). Note If G70 is active and the basic system is metric (or G71 is active and the basic system is inch), the system variables \$AA_IW and \$AA_MW are provided in the basic system and, if used, must be converted for CALCPOSI.																																				
	TRUE	System of units according to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM																																				
<TestLim>:	<p>Bit-coded selection of the limits to be monitored (optional)</p> <table border="1" data-bbox="598 1208 1481 1810"> <tr> <td>Data type:</td> <td colspan="2">INT</td> </tr> <tr> <td>Default value:</td> <td colspan="2">Bits 0, 1, 2, 3, 6, 7 == 1 (207)</td> </tr> <tr> <td>Bit</td> <td>Decimal</td> <td>Meaning</td> </tr> <tr> <td>0</td> <td>1</td> <td>Software limit switch</td> </tr> <tr> <td>1</td> <td>2</td> <td>Working area limitation</td> </tr> <tr> <td>2</td> <td>4</td> <td>Activated conventional protection zones</td> </tr> <tr> <td>3</td> <td>8</td> <td>Preactivated conventional protection zones</td> </tr> <tr> <td>4</td> <td>16</td> <td>With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 1 (see above).</td> </tr> <tr> <td>5</td> <td>32</td> <td>With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 2 (see above).</td> </tr> <tr> <td>6</td> <td>64</td> <td>Activated collision avoidance protection zones</td> </tr> <tr> <td>7</td> <td>128</td> <td>Preactivated collision avoidance protection zones</td> </tr> <tr> <td>8</td> <td>256</td> <td>Pairs of activated and preactivated collision avoidance protection zones</td> </tr> </table>		Data type:	INT		Default value:	Bits 0, 1, 2, 3, 6, 7 == 1 (207)		Bit	Decimal	Meaning	0	1	Software limit switch	1	2	Working area limitation	2	4	Activated conventional protection zones	3	8	Preactivated conventional protection zones	4	16	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 1 (see above).	5	32	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 2 (see above).	6	64	Activated collision avoidance protection zones	7	128	Preactivated collision avoidance protection zones	8	256	Pairs of activated and preactivated collision avoidance protection zones
Data type:	INT																																					
Default value:	Bits 0, 1, 2, 3, 6, 7 == 1 (207)																																					
Bit	Decimal	Meaning																																				
0	1	Software limit switch																																				
1	2	Working area limitation																																				
2	4	Activated conventional protection zones																																				
3	8	Preactivated conventional protection zones																																				
4	16	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 1 (see above).																																				
5	32	With violated software limit switches or working area limits in <Dist>, return the traversing direction as in Case 2 (see above).																																				
6	64	Activated collision avoidance protection zones																																				
7	128	Preactivated collision avoidance protection zones																																				
8	256	Pairs of activated and preactivated collision avoidance protection zones																																				
<p>¹⁾ If several protection zones are violated, the protection zone with the greatest restriction on the specified traversing distance is returned.</p>																																						

Example

Limitations



In the example, the active software limit switches and working area limits in the X-Y plane and the following three protection zones are displayed:

- C2: Tool-related, channel-specific protection zone, active, circular, radius = 2 mm
- C4: Workpiece-related, channel-specific protection zone, preactivated, square, side length = 10 mm
- N3: Machine-specific protection zone, active, rectangular, side length = 10 mm x 15 mm

NC program

The protection zones and working area limits are defined first in the NC program. The `CALCPOSI()` function is then called with different parameter assignments.

Program code

```

N10 DEF REAL _START[3]
N20 DEF REAL _DIST[3]
N30 DEF REAL _LIMIT[5]
N40 DEF REAL _MAXDIST[3]
N50 DEF INT _PA
N60 DEF INT _STATUS

```


Program code

```
: toolrelated protection zone C2
N70 CPROTDEF(2, TRUE, 0)
N80 G17 G1 X-2 Y0
N90 G3 I2 X2
N100 I-2 X-2
N110 EXECUTE(_PA)

; workpiece-related protection zone C4
N120 CPROTDEF(4, FALSE, 0)
N130 G17 G1 X0 Y15
N140 X10
N150 Y25
N160 X0
N170 Y15
N180 EXECUTE(_PA)

; machine-specific protection zone N3
N190 NPROTDEF(3, FALSE, 0)
N200 G17 G1 X10 Y5
N210 X25
N220 Y15
N230 X10
N240 Y5
N250 EXECUTE(_PA)

; activate or preactivate protection zones
N260 CPROT(2, 2, 0, 0, 0)
N270 CPROT(4, 1, 0, 0, 0)
N280 NPROT(3, 2, 0, 0, 0)

; define working area limits
N290 G25 XX=-10 YY=-10
N300 G26 XX=20 YY=21

N310 _START[0] = 0.
N320 _START[1] = 0.
N330 _START[2] = 0.
N340 _DIST[0] = 35.
N350 _DIST[1] = 20.
N360 _DIST[2] = 0.
N370 _LIMIT[0] = 0.
N380 _LIMIT[1] = 0.
N390 _LIMIT[2] = 0.
N400 _LIMIT[3] = 0.
N410 _LIMIT[4] = 0.
N420 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST)
N430 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 3)
N440 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 1)
N450 _START[0] = 5.
N460 _START[1] = 17.
N470 _START[2] = 0.
N480 _DIST[0] = 0.
N490 _DIST[1] = -27.
N500 _DIST[2] = 0.
N510 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 14)
N520 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 6)
N530 _LIMIT[1] = 2.
```

Program code

```

N540 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,, 6)
N550 _START[0] = 27.
N560 _START[1] = 17.1
N570 _START[2] = 0.
N580 _DIST[0] = -27.
N590 _DIST[1] = 0.
N600 _DIST[2] = 0.
N610 _LIMIT[3] = 2.
N620 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,12)
N630 _START[0] = 0.
N640 _START[1] = 0.
N650 _START[2] = 0.
N660 _DIST[0] = 0.
N670 _DIST[1] = 30.
N680 _DIST[2] = 0.
N690 TRANS X10
N700 AROT Z45
N710 _STATUS = CALCPOSI(_START,_DIST, _LIMIT, _MAXDIST)
; delete frames from N690 and N700 again
N720 TRANS
N730 _START[0] = 0.
N740 _START[1] = 10.
N750 _START[2] = 0.
; vectors_DIST and _MAXDIST define the motion plane
N760 _DIST[0] = 30.
N770 _DIST[1] = 30.
N780 _DIST[2] = 0.
N790 _MAXDIST[0] = 1.
N800 _MAXDIST[1] = 0.
N810 _MAXDIST[2] = 1.
N820 _STATUS = CALCPOSI(_START, _DIST, _LIMIT, _MAXDIST,,17)
N830 M30
    
```

Results of CALCPOSI()

N...	<status>	<MaxDist>[0] Δ X	<MaxDist>[1] Δ Y	Remarks
420	3123	8.040	4.594	N3 is violated.
430	1122	20.000	11.429	No protection zone monitoring, working area limitation is violated.
440	1121	30.000	17.143	Only software limit monitoring is still active.
510	4213	0.000	0.000	Starting point violates C4
520	0000	0.000	-27.000	Preactivated C4 is not monitored. The specified distance can be traversed completely.
540	2222	0.000	-25.000	Because _LIMIT[1] = 2, the traversing distance is restricted by the working area limitation.

N...	<status>	<MaxDist>[0] Δ X	<MaxDist>[1] Δ Y	Remarks
620	4223	-13.000	0.000	Clearance to C4 is a total of 4 mm due to C2 and _LIMIT[3]. Clearance C2 → N3 of 0.1 mm does not result in limitation of the traversing distance.
710	1221	0.000	21.213	Frame with translation and rotation active. The permissible traversing distance in _DIST applies in the shifted and rotated WCS.
820	102121	18.000	18.000	The software limit switch of the Y axis is violated. The calculation of a further traversing direction is requested with <_TES-TLIM> = 17. This direction is in _DIST (0.707, 0.0, 0.707). It is valid because the hundred thousands digit is set in <_STATUS>.

Additional information

"Referenced" axis status

All machine axes considered by `CALCPOSI()` must be homed.

Circle-related distance specifications

All circle-related distance specifications are **always** interpreted as radius specifications. This must be taken into account particularly for transverse axes with activated diameter programming (`DIAMON/DIAM90`).

Traversing distance reduction

If the specified traversing distance of an axis is limited, the traversing distance of the other axes is also reduced proportionally in the `<MaxDist>` return value. The resulting end point is therefore still on the specified path.

Rotary axes

Rotary axes are only monitored when they are not modulo rotary axes.

It is permissible that no software limit switches, working area limits or protection zones are defined for one or more of the relevant axes.

Software limit switch and working area limitation status

Software limit switches and working area limits are only taken into account if they are active during the execution of `CALCPOSI()`. The status can be influenced, for example, via:

- Machine data: MD21020 \$MC_WORKAREA_WITH_TOOL_RADIUS
- Setting data: \$AC_WORKAREA_CS_...
- NC/PLC interface signals DB31, ... DBX12.2 / 3
- Commands: `WALIMON` / `WALIMOF`

Software limit switches and transformations

With `CALCPOSI ()`, the positions of the machine axes (MCS) cannot always be uniquely determined from the positions of the geometry axes (WCS) during various kinematic transformations (e.g. `TRANSMIT`) because of ambiguities at certain positions of the traversing distance. In normal traversing operation, the uniqueness generally results from the history and the condition that a continuous motion in the WCS must correspond to a continuous motion in the MCS. Therefore, when monitoring the software limit switches, the machine position at the time when `CALCPOSI ()` is executed is used to resolve the ambiguity in such cases.

Note

Preprocessing stop

When using `CALCPOSI ()` in conjunction with transformations, it is the sole responsibility of the user to program a preprocessing stop (`STOPRE`) with the preprocessing before `CALCPOSI ()` for the synchronization of the machine axis positions.

Protection zone clearance and conventional protection zones

With conventional protection zones, there is **no** guarantee that the safety clearance set in parameter `<Limit>[3]` is maintained for all protection zones during a traversing movement on the specified path. It is only guaranteed that no protection zone will be violated when the end point returned in `<Dist>` is extended by the safety clearance in the traversing direction. However, the straight line can pass very close to a protection zone.

Protection zone clearance and collision avoidance protection zones

With collision avoidance protection zones, there is a guarantee that the safety clearance set in parameter `<Limit>[3]` is maintained for all protection zones during a traversing movement on the specified traversing path.

The safety clearance specified in parameter `<Limit>[3]` only takes effect when the following applies:

`<Limit>[3] > (MD10619 $MN_COLLISION_TOLERANCE)`

If bit 4 is set in parameter `<TestLim>` (calculation of the ongoing traversing direction), then the direction vector received in `<DIST>` is only valid when the hundred thousands digit is set in the function return value (`<status>`). If a direction such as this cannot be determined, either because protection zones were violated, or because a transformation is active, then the input value in `<DIST>` remains unchanged. An additional error message is not output.

3.7 Special motion commands

3.7.1 Approaching coded positions (CAC, CIC, CDC, CACP, CACN)

You can traverse linear and rotary axes via position numbers to fixed axis positions saved in machine data tables using the following commands. This type of programming is called "approach coded positions".

Syntax

```
CAC (<n>)
CIC (<n>)
CACP (<n>)
CACN (<n>)
```

Meaning

CAC (<n>):	Approach coded position from position number n
CIC (<n>):	Starting from the actual position number, approach the coded position n position locations before (+n) or back (-n)
CDC (<n>):	Approach the position from position number n along the shortest path (only for rotary axes)
CACP (<n>):	Approach coded position from position number n in the positive direction (only for rotary axes)
CACN (<n>):	Approach coded position from position number n in the negative direction (only for rotary axes)
<n>:	Position number within the machine data table Range of values: 0, 1, ... (max. number of table locations - 1)

Example: Approach coded positions of a positioning axis

Programming code	Comment
N10 FA[B]=300	; Feedrate for positioning axis B
N20 POS[B]=CAC(10)	; Approach coded position from position number 10
N30 POS[B]=CIC(-4)	; Approach coded position from "current position number" - 4

References

- Function Manual Expanded Functions; Indexing Axes (T1)
- Function Manual, Synchronized Actions

3.7.2 Activating/deactivating NC block compression (COMPON, COMPCURV, COMPCAD, COMPSURF, COMPOF)

The functions to compress linear blocks (and dependent on the parameterization, also circular and/or rapid traverse blocks) are activated/deactivated using G commands of G group 30. The commands are modal.

Syntax

```
COMPON / COMPCURV / COMPCAD / COMPSURF
...
COMPOF
```

Meaning

COMPON:	Activating the compressor function COMPON
COMPCURV:	Activating the compressor function COMPCURV
COMPCAD:	Activating the compressor function COMPCAD
COMPSURF:	Activating the compressor function COMPSURF
COMPOF :	Deactivating the currently active compressor function

Note

The rounding function G642 and jerk limitation SOFT further improve the surface quality. These commands must be written at the beginning of the program.

Example: COMPCAD

Program code	Comment
N10 G00 X30 Y6 Z40	
N20 G1 F10000 G642	; Activation: Rounding function G642
N30 SOFT	; Activation: Jerk limitation SOFT
N40 COMPCAD	; Activation: Compressor function COMPCAD
N50 STOPFIFO	
N24050 Z32.499	; 1st traversing block
N24051 X41.365 Z32.500	; 2nd traversing block
...	
N99999 X... Z...	; last traversing block
COMPOF	; compressor function off.
...	

3.7.3 Polynomial interpolation (POLY, POLYPATH, PO, PL)

It actually involves a polynomial interpolation (POLY) and not a spline interpolation type. Its main purpose is to act as an interface for programming externally generated spline curves where the spline sections can be programmed directly.

This mode of interpolation relieves the NC of the task of calculating polynomial coefficients. It can be optimally applied in cases where the coefficients are supplied directly by a CAD system or post processor.

Syntax

3rd degree polynomial:

```
POLY PO[X]=(xe, a2, a3) PO[Y]=(ye, b2, b3) PO[Z]=(ze, c2, c3) PL=n
```

5th degree polynomial and new polynomial syntax:

```
POLY X=PO(xe, a2, a3, a4, a5) Y=PO(ye, b2, b3, b4, b5) Z=PO(ze, c2, c3, c4, c5)
```

```
PL=n
```

```
POLYPATH("AXES", "VECT")
```

Note

The sum of the polynomial coefficients and axes programmed in an NC block must not exceed the maximum permitted number of axes per block.

Meaning

POLY :	Activation of polynomial interpolation with a block containing POLY.
POLYPATH :	Polynomial interpolation can be selected for both AXIS or VECT axis groups
PO[axis identifier/variable] :	End points and polynomial coefficients
X, Y, Z :	Axis identifier
xe, ye, ze :	Specification of end position for the particular axis; value range as for path dimension
a2, a3, a4, a5 :	The coefficients a ₂ , a ₃ , a ₄ , and a ₅ are written with their value; value range as for path dimension. The last coefficient in each case can be omitted if it equals zero.
PL :	Length of the parameter interval where polynomials are defined (definition range of the function f(p)). The interval always starts at 0, p can assume values from 0 to PL. Theoretical value range for PL: 0.0001 ... 99 999.9999 Note: The PL value applies to the block in which it is located. If no PL is programmed, then PL=1 is applied.

Activating/deactivating polynomial interpolation

The polynomial interpolation is activated in the part program using the `POLX G` command.

The `POLY G` command together with `G0`, `G1`, `G2`, `G3`, `ASPLINE`, `BSPLINE` and `CSPLINE` belong to the 1st group.

Axes, which are only programmed with name and end point (e.g. `X10`), are linearly moved. If all axes of an NC block are programmed in this way, the control behaves the same as for `G1`.

The polynomial interpolation is implicitly deactivated again by programming another command of the 1st G group (`G0`, `G1`).

Polynomial coefficient

The `PO` value (`PO[]=`) or `...=PO(...)` specifies all polynomial coefficients for an axis. Several values are specified, separated by commas corresponding the degree of the polynomial. Different degrees of polynomials are possible for various axes within one block.

POLYPATH subprogram

Using `POLYPATH (...)`, the polynomial interpolation can be selectively released for certain axis groups:

Only path axes and supplementary axes:	<code>POLYPATH ("AXES")</code>
Only orientation axes: (when moving with orientation transformation)	<code>POLYPATH ("VECT")</code>

The axes that are not released are linearly moved.

Polynomial interpolation is enabled as standard for both axis groups.

Polynomial interpolation is deactivated for all axes by programming without the `POLYPATH ()` parameter.

Example

Program code	Comment
<code>N10 G1 X... Y... Z... F600</code>	
<code>N11 POLY PO[X]=(1,2.5,0.7) PO[Y]=(0.3,1,3.2) PL=1.5</code>	<code>; Polynomial interpolation on</code>
<code>N12 PO[X]=(0,2.5,1.7) PO[Y]=(2.3,1.7) PL=3</code>	
<code>...</code>	
<code>N20 M8 H126 ...</code>	
<code>N25 X70 PO[Y]=(9.3,1,7.67) PL=5</code>	<code>; Mixed data for the axes</code>
<code>N27 PO[X]=(10,2.5) PO[Y]=(2.3)</code>	<code>; No PL programmed; PL=1 applies</code>
<code>N30 G1 X... Y... Z.</code>	<code>; Polynomial interpolation off</code>
<code>...</code>	

Example: New polynomial syntax

Polynomial syntax that is still valid	New polynomial syntax
PO[axis identifier]=(.. , ..)	Axis identifier=PO(.. , ..)
PO[PHI]=(.. , ..)	PHI=PO(.. , ..)
PO[PSI]=(.. , ..)	PSI=PO(.. , ..)
PO[THT]=(.. , ..)	THT=PO(.. , ..)
PO[]=(.. , ..)	PO(.. , ..)
PO[variable]=IC(.. , ..)	variable=PO IC(.. , ..)


Example: Curve in the X/Y plane.

Programming


Program code

```
N9 X0 Y0 G90 F100
N10 POLY PO[Y]=(2) PO[X]=(4,0.25) PL=4
```

Shape of the curves X(p) and Y(p)



Shape of the curve in the XY plane



Description

The equation to express the polynomial function is generally as follows:

$$f(p) = a_0 + a_1p + a_2p^2 + \dots + a_np^n$$

with: a_i : constant coefficients ($i = 0, 1, \dots, n$)
 p : Parameter

In the control, polynomials up to a maximum of the 5th degree can be programmed:

$$f(p) = a_0 + a_1p + a_2p^2 + a_3p^3 + a_4p^4 + a_5p^5$$

By assigning concrete values to these coefficients, it is possible to generate various curve shapes such as line, parabola and power functions.

A straight line is generated with $a_2 = a_3 = a_4 = a_5 = 0$:

$$f(p) = a_0 + a_1p$$

The following still applies:

$$a_0: \text{Axis position at the end of the preceding block}$$

$$p = \text{PL}$$

$$a_1 = (x_E - a_0 - a_2 * p^2 - a_3 * p^3) / p$$

It is possible to program polynomials **without** the polynomial interpolation having been activated using the G command `POLY`. In this case, the programmed polynomials are not interpolated, but instead, all of the programmed end points of the axis are linearly approached (`G1`). The programmed polynomials are only moved as such after explicitly activating polynomial interpolation in the part program (`POLY`).

Special feature: Denominator polynomial

Command `PO[] = (...)` can be used to program a common denominator polynomial for the geometry axes (without specifying an axis name), i.e. the motion of the geometry axes is then interpolated as the quotient of two polynomials.

With this programming option, it is possible to represent shapes such as conics (circle, ellipse, parabola, hyperbola) exactly.

Example:

Program code	Comment
<code>POLY G90 X10 Y0 F100</code>	; Geometry axes traverse linearly to position X10 Y0.
<code>PO[X]=(0,-10) PO[Y]=(10) PO[]=(2,1)</code>	; Geometry axes traverse along the quadrant to X0 Y10.

The constant coefficient (a_0) of the denominator polynomial is always assumed to be 1. The programmed end point is independent of G90 / G91.

$X(p)$ and $Y(p)$ are calculated as follows from the programmed values:

$$X(p) = (10 - 10 * p^2) / (1 + p^2)$$

$$Y(p) = 20 * p / (1 + p^2)$$


$$\text{with } 0 \leq p \leq 1$$

As a result of the programmed start points, end points, coefficient a_2 and $PL=1$, the intermediate results are as follows:

$$\text{Numerator (X)} = 10 + 0 * p - 10 * p^2$$

$$\text{Numerator (Y)} = 0 + 20 * p + 0 * p^2$$

$$\text{Denominator} = 1 + p^2$$



3.7 Special motion commands

If polynomial interpolation is active and a denominator polynomial is programmed with zeros within the interval $[0, PL]$, this is rejected and an alarm is output. Denominator polynomials have no effect on the motion of special axes.

Note

Tool radius compensation can be activated with G41, G42 in conjunction with polynomial interpolation and can be applied in the same way as in linear or circular interpolation modes.

3.7.4 Settable path reference (SPATH, UPATH)

For polynomial interpolation (POLY, ASPLINE, BSPLINE, CSPLINE, COMCON, COMPCURV), the positions of the path axes i are specified as polynomials $p_i(U)$. The curve parameter U moves from 0 to 1 within an NC block.

FGROUP selects the axes (FGROUP axes) to which the path feedrate F applies. An interpolation with constant speed on the path S of the FGROUP axes means during the polynomial interpolation normally a non-constant change of the curve parameter U . Consequently, two possibilities are available for selecting the axes not contained in FGROUP on how they should follow the FGROUP axes:

- Synchronous to path S (SPATH)
- Synchronous to curve parameter U (UPATH)

Syntax

SPATH
UPATH

Meaning

SPATH:	The axes not contained in FGROUP are traversed with reference to path S
UPATH:	The axes not contained in FGROUP are traversed with reference to curve parameter U

Note

UPATH and SPATH also define the interrelationship of the F word polynomial (FPOLY, FCUB, FLIN) with path motion.

Supplementary conditions

SPATH and UPATH have no meaning for:

- Linear interpolation (G1)
- Circuit interpolation (G2, G3)
- Thread blocks (G33, G34, G35, G33x, G63)
- All path axes are contained in FGROUP

Example

The following example shows the difference between both types of motion control.


Program code

```
N10 FGROUP (X, Y, Z)
N15 G1 X0 A0 F1000 SPATH ; SPATH
N20 POLY PO[X]=(10,10) A10
```

Program code

```
N10 FGROUP (X, Y, Z)
N15 G1 X0 A0 F1000 UPATH ; UPATH
N20 POLY PO[X]=(10,10) A10
```

In both program sections, the path S of the FGROUP axes in N20 is dependent on the square of curve parameter U. Therefore, different positions arise for synchronized axis A along path X, according to whether SPATH or UPATH is active.



Further information

Control behavior for reset and machine/option data

The G command, defined with MD20150 \$MC_GCODE_RESET_VALUES[44], is effective after a reset (45th. G group).

The initial state for the type of smoothing is defined with MD20150 \$MC_GCODE_RESET_VALUES[9] (10th G group).


The axis-specific machine data MD33100 \$MA_COMPRESS_POS_TOL[<n>] has an extended significance: It contains the tolerances for the compressor function and for smoothing with G642.

3.7.5 Channel-specific measuring (MEAS, MEAW)

In the case of channel-specific measuring, the measuring process for an NC channel is always activated from the part program running in the relevant channel. **One** trigger event (positive or negative edge of the probe) and **one** measuring mode with deletion of distance-to-go (MEAS) or without deletion of distance-to-go (MEAW) are programmed in a measuring block. **All** the axes programmed in the measuring block then take part in the measuring process.

As soon as a measuring block becomes active, the probe is moved to the workpiece. On the probe's switching edge, the positions for all axes programmed in the measuring block are measured and written to the appropriate memory cell for each axis.

The results of measurements can be read in the part program or with synchronized actions in both the machine and the workpiece coordinate systems.



Syntax

```
MEAS=<TE> G... X... Y... Z...
MEAW=<TE> G... X... Y... Z...
```

Meaning

MEAS:	Measurement with delete distance-to-go	
	Effectiveness:	Non-modal
MEAW:	Measurement without delete distance-to-go	
	Effectiveness:	Non-modal
	Application:	For measuring tasks in which the programmed position is to be approached in every case.

<TE>:	Trigger event to initiate measurement			
	Type:	INT		
	Range of values:	-2, -1, 1, 2		
	Value:	(+1)	Positive edge of probe 1 (on measuring input 1)	
		-1	Negative edge of probe 1 (on measuring input 1)	
(+2)		Positive edge of probe 2 (on measuring input 2)		
-2		Negative edge of probe 2 (on measuring input 2)		
Note: There is a maximum of 2 probes (dependent on configuration level).				
G...:	Type of interpolation, e.g. G0, G1, G2 or G3			
X... Y... Z...:	End points in Cartesian coordinates			

Note

MEAS and MEAW are non-modal, and programmed together with motion operations. The feedrate and interpolation type (G0, G1, etc.) as well as the number of axes must be adapted for the respective measuring task.

Example

Program code	Comment
...	
N10 MEAS=1 G1 F1000 X100 Y730 Z40	; Measuring block with probe at first measuring input and linear interpolation. A preprocessing stop is automatically generated.
...	

Further information**Query status**

If an evaluation is required in the program, whether a probe has been deflected or has switched, the status can be queried through the following system variables:

System variable	Meaning	Data type	Value	
\$A_PROBE[<n>]	Probe state	INT	0	Probe not deflected.
			1	Probe deflected.
\$AC_MEA[<n>]	Switching status of the probe \$AC_MEA[<n>] is automatically reset at the beginning of a measurement.	INT	0	Probe has not switched
			1	Probe has switched.

<n> = number of the probe

Reading measured values

For channel-specific measuring, the positions of all traversing path and positioning axes of the block are acquired (maximum number of axes depends on the control configuration). For MEAS, the motion is braked in a defined fashion after the probe has been triggered.

Note

If a geometry axis is programmed in a measuring block, the measured values are stored for all current geometry axes.

If an axis participating in a transformation is programmed in a measuring block, the measured values are stored for all axes participating in this transformation.

Reading measurement results

The measured values of the axes acquired by probes can be read through the following system variables in the part program and in synchronized actions.

System variable	Meaning
\$AA_MM[<Axis>]	Probe measured value in the machine coordinate system
\$AA_MW[<Axis>]	Probe measured value in the workpiece coordinate system

3.7.6 Axis-specific measurement (MEASA, MEAWA, MEAC) (option)

With axis-specific measuring, activation can take place in the part program **or** in synchronized actions. If two measuring systems are available for the axis, both can be used for the measurement.

The following measuring methods are available:

- Measurement with delete distance-to-go (MEASA)
- Measurement without delete distance-to-go (MEAWA)
- Continuous measurement without delete distance-to-go (MEAC)

With MEASA or MEAWA for the programmed axis, up to four measured values are acquired for each measurement and are then saved in system variables in accordance with the trigger event.

With continuous measurement with MEAC, the measurement results are stored in FIFO variables.

Syntax

```
MEASA [<Axis>]= (<Mode>, <TE1>, . . . , <TE4>)
```

```
MEAWA [<Axis>]= (<Mode>, <TE1>, . . . , <TE4>)
```

```
MEAC [<Axis>]= (<Mode>, <MeasMem>, <TE1>, . . . , <TE4>)
```


Note

MEASA and MEAWA are non-modal; and can be programmed together in one block. If, on the contrary, MEASA/MEAWA are programmed with MEAS/MEAW in one block, there is an error message.

Meaning

MEASA:	Axis-specific measurement with deletion of distance-to-go	
	Effectiveness:	Non-modal
MEAWA:	Axes-specific measurement without delete distance-to-go	
	Effectiveness:	Non-modal
MEAC:	Axis-specific, continuous measurement without delete distance-to-go	
	Effectiveness:	Non-modal
<Axis>:	Name of channel axis used for measurement	
<Mode>:	Two-digit (xx) number indicating the operating mode (measuring mode and measuring system)	
	Units decade: Measuring mode Specifies whether the trigger events are to be activated in chronological or programmed order.	
	x0	Cancel measuring job.
	x1	Up to 4 different trigger events can be activated simultaneously.
	x2	Up to 4 trigger events that can be activated successively.
	x3	Up to 4 different trigger events can be activated in succession, but there is no monitoring of trigger event 1 at the start (alarms 21700/21703 are suppressed). Note: MEAC does not support this mode.
	Tens decade: Measuring system Specifies the measuring system with which measuring is to be performed.	
	0x (or no specification)	Active measuring system
	1x	Measuring system 1
	2x	Measuring system 2
	3x	Both measuring systems

3.7 Special motion commands

<TE>:	Trigger event to initiate measurement	
	Type:	INT
	Range of values:	-2, -1, 1, 2
	(+1)	Positive edge of probe 1
	-1	Negative edge of probe 1
	(+2)	Positive edge of probe 2
	-2	Negative edge of probe 2
Note: If the measuring process is performed with two measuring systems, a maximum of two trigger events can be programmed (positive or negative edge). The measured values of both measuring systems are acquired for both the trigger events.		
<MeasMem>:	Number of FIFO (circular buffer)	

Examples

Example 1: Axis-specific measurement with delete distance-to-go in mode 1 (evaluation in chronological sequence)

a) Measuring with one measuring system

Program code	Comment
...	
N100 MEASA[X]=(1,1,-1) G01 X100 F100	; Measuring in mode 1 with active measuring system. Wait for measuring signal with positive/negative edge from probe 1 for travel path to X=100.
N110 IF \$AC_MEA[1]==FALSE GOTOF END	; Check that the measurement was successful.
N120 R10=\$AA_MM1[X]	; Save measured value acquired at the first programmed trigger event (positive edge).
N130 R11=\$AA_MM2[X]	; Save measured value acquired at the second programmed trigger event (negative edge).
N140 END:	

b) Measuring with two measuring systems

Program code	Comment
...	
N200 MEASA[X]=(31,1,-1) G01 X100 F100	; Measuring in mode 1 with both measuring systems. Wait for measuring signal with positive/negative edge from probe 1 for travel path to X=100.
N210 IF \$AC_MEA[1]==FALSE GOTOF END	; Check that the measurement was successful.
N220 R10=\$AA_MM1[X]	; Save measured value of measuring system 1 at positive edge.

Program code	Comment
N230 R11=\$AA_MM2[X]	; Save measured value of measuring system 2 at positive edge.
N240 R12=\$AA_MM3[X]	; Save measured value of measuring system 1 at negative edge.
N250 R13=\$AA_MM4[X]	; Save measured value of measuring system 2 at negative edge.
N260 END:	

Example 2: Axis-specific measurement with delete distance-to-go in mode 2 (evaluation in programmed sequence)

Program code	Comment
...	
N100 MEASA[X]=(2,1,-1,2,-2) G01 X100 F100	; Measuring in mode 2 with active measuring system. Wait for measuring signal in the sequence positive edge probe 1, negative edge probe 1, positive edge probe 2, negative edge probe 2 while traversing path to X=100.
N110 IF \$AC_MEA[1]==FALSE GOTOF PROBE2	; Check that the measurement with probe 1 is successful.
N120 R10=\$AA_MM1[X]	; Save measured value acquired at the first programmed trigger event (positive edge of probe 1).
N130 R11=\$AA_MM2[X]	; Save measured value acquired at the second programmed trigger event (positive edge of probe 1).
N140, PROBE2:	
N150 IF \$AC_MEA[2]==FALSE GOTOF END	; Check that the measurement with probe 2 is successful.
N160 R12=\$AA_MM3[X]	; Save measured value acquired at the third programmed trigger event (positive edge of probe 2).
N170 R13=\$AA_MM4[X]	; Save measured value acquired at the fourth programmed trigger event (positive edge of probe 2).
N180 END:	

Example 3: Axis-specific, continuous measurement in mode 1 (evaluation in chronological sequence)

a) Measurement of up to 100 measured values

Program code	Comment
...	
N110 DEF REAL MEASVALUE[100]	
N120 DEF INT loop=0	

3.7 Special motion commands

Program code	Comment
N130 MEAC[X]=(1,1,-1) G01 X1000 F100	; Measuring in mode 1 with active measuring system, save measured values under \$AC_FIF01, wait for measuring system with negative edge from probe 1 on the travel path to X=1000.
N135 STOPRE	
N140 MEAC[X]=(0)	; Terminate measurement when axis position is reached.
N150 R1=\$AC_FIF01[4]	; Save number of accumulated measured values in parameter R1.
N160 FOR loop=0 TO R1-1	
N170 MEASURED VALUE[loop]=\$AC_FIF01[0]	; Read-out measured values from \$AC_FIF01 and save.
N180 ENDFOR	

b) Measurement with delete distance-to-go after 10 measured values

Program code	Comment
...	
N10 WHEN \$AC_FIF01[4]>=10 DO MEAC[x]=(0) DELDTG(x)	; Delete distance-to-go.
N20 MEAC[x]=(1,1,1,-1) G01 X100 F500	
N30 MEAC [X]=(0)	
N40 R1 = \$AC_FIF01[4]	; Number of measured values.
...	

c) Measurement of a positive/negative tooth flank with 2 probes

Program code	Comment
...	
N110 DEF REAL MEASVALUE[16]	
N120 DEF INT loop=0	
N130 MEAC[X]=(1,1,-1,2) G01 X100 F100	; Measurement in mode 1 with active measuring system, save measured values under \$AC_FIF01, wait for measuring signal in the sequence negative edge of probe 1, positive edge of probe 2 while traversing the travel path to X=100.
N140 STOPRE	; Preprocessing stop.
N150 MEAC[X]=(0)	; Terminate measurement when axis position is reached.
N160 R1=\$AC_FIF01[4]	; Save number of accumulated measured values in parameter R1.
N170 FOR loop=0 TO R1-1	
N180 MEASURED VALUE[loop]=\$AC_FIF01[0]	; Read-out measured values from \$AC_FIF01 and save.
N190 ENDFOR	

Further information

Measuring job

A measuring job can be programmed in the part program or from a synchronized action. Please note that only one measuring job can be active at any given time for each axis.

Note

The feed must be adjusted to suit the particular measuring task

In the case of MEASA and MEAWA, the correctness of results can be only guaranteed for feedrates at which no more than one trigger event of the same type and no more than 4 trigger events of different types occur in each position control cycle.

In the case of continuous measurement with MEAC, the ratio between interpolator cycle and the position control cycle must not exceed 1:8.

Trigger event

A trigger event comprises the number of the probe and the trigger criterion (positive or negative edge) of the measuring signal.

Up to 4 trigger events of the addressed probe can be processed for each measurement; in other words, up to two probes each with two measuring signal edges. The processing sequence and the maximum number of trigger events depend on the selected mode.

If the measuring operation is performed with two measuring systems, a maximum of two trigger events can be programmed (positive or negative edge). The measured values of both probes are acquired for both of the trigger events.

Note

With the use of PROFIBUS telegram 391 (default setting for PROFIBUS communication) only one measured value is possible for each trigger event and position control cycle.

For MEAC, the number of measured values per trigger event can be increased by using PROFIBUS telegram 395 to a total of 8 measured values for a positive edge and 8 measured values for a negative edge for each trigger event and position control cycle:

- One probe: 8 measured values for a positive and 8 for a negative edge
- Two probes: 4 measured values for a positive and 4 for a negative edge for each probe

This means that higher feed rates or higher speeds can be reached by using PROFIBUS telegram 395.

Operating mode

The first digit (tens decade) of the operating mode selects the required measuring system. If only one measuring system is installed, but a second is programmed, the installed system is automatically selected.

3.7 Special motion commands

The second digit (units decade) selects the desired measuring mode. The measuring process is thus adapted to the options supported by the relevant control:

- **Mode 1**
Trigger events are evaluated in the chronological sequence in which they occur. When this mode is selected, only one trigger event can be programmed for six-axis modules. If more than one trigger event is specified, the mode selection is switched automatically to mode 2 (without message).
- **Mode 2**
Trigger events are evaluated in the programmed sequence.
- **Mode 3**
Trigger events are evaluated in the programmed sequence but there is no monitoring of trigger event 1 at the start.

Measurement with and without delete distance-to-go

When command MEASA is programmed, the distance-to-go is not deleted until all required measured values have been acquired.

MEAWA is used for special measuring tasks in which a programmed position always has to be approached.

Note

MEASA cannot be programmed in synchronized actions. As an alternative, MEAWA plus delete distance-to-go can be programmed as a synchronized action.

If the measuring job with MEAWA is started from synchronized actions, the measured values will only be available in the machine coordinate system.

Geometry axes/transformations

If axial measurement is to be started for a geometry axis, the same measuring job must be programmed explicitly for all remaining geometry axes. The same applies to axes involved in a transformation.

Examples:

```
N10 MEASA[Z]=(1,1) MEASA[Y]=(1,1) MEASA[X]=(1,1) G0 Z100
```

or

```
N10 MEASA[Z]=(1,1) POS[Z]=100
```

Query status

If an evaluation is required in the program, whether a probe has been deflected or has switched, the status can be queried through the following system variables:

System variable	Meaning	Data type	Value	
\$A_PROBE[<n>]	Probe state	INT	0	Probe not deflected.
			1	Probe deflected.

System variable	Meaning	Data type	Value	
\$AC_MEA[<n>]	Switching status of the probe \$AC_MEA[<n>] is automatically reset at the beginning of a measurement.	INT	0	Probe has not switched
			1	Probe has switched (all trigger events programmed in the measuring block have taken place).

<n> = number of the probe

Note

If measurement is started from synchronized actions, \$AC_MEA is no longer updated. In this case, the NC/PLC interface signal DB31, ... DBX62.3 or the equivalent variable \$AA_MEA[ACT[<Axis>]] must be queried.

\$AA_MEA[ACT]==1: Measurement active

\$AA_MEA[ACT]==0: Measurement not active

Probe limitation

In the NC program or synchronized action, the probe limiting status can be read using system variable \$A_PROBE_LIMITED when using PROFIBUS telegram 395:

\$A_PROBE_LIMITED[<n>] == 0: Probe limitation inactive/reset

\$A_PROBE_LIMITED[<n>] == 1: Probe limitation active

<n> = probe number

Measurement results for MEASA / MEAWA

The values measured by probes can be read through the following system variables in the part program and in synchronized actions.

System variable	Meaning
\$AA_MM1[<Axis>]	Probe measured value for trigger event 1 in the machine coordinate system
...	...
\$AA_MM4[<Axis>]	Probe measured value for trigger event 4 in the machine coordinate system
\$AA_MW1[<Axis>]	Probe measured value for trigger event 1 in the workpiece coordinate system
...	...
\$AA_MW4[<Axis>]	Probe measured value for trigger event 4 in the workpiece coordinate system

<Axis> = measuring axis

If a measuring job is executed by two measuring systems, each of the two possible trigger events is acquired from both measuring systems. The assignment of system variables is then as follows:

\$AA_MM1[<Axis>]	or	\$AA_MW1[<Axis>]	Measured value from measuring system 1 on trigger event 1
\$AA_MM2[<Axis>]	or	\$AA_MW2[<Axis>]	Measured value from measuring system 2 on trigger event 1

\$AA_MM3[<Axis>]	or	\$AA_MW3[<Axis>]	Measured value from measuring system 1 on trigger event 2
\$AA_MM4[<Axis>]	or	\$AA_MW4[<Axis>]	Measured value from measuring system 2 on trigger event 2

Continuous measurement (MEAC)

The measured values for MEAC are available in the machine coordinate system and stored in the programmed FIFO[<n>] memory (circular buffer). If two probes are configured for the measurement, the measured values of the second probe are stored separately in the FIFO[<n>+1] memory configured specifically for this purpose (defined in machine data).

The FIFO memory is a circular buffer in which measured values are written to \$AC_FIFO variables according to the circular principle.

Note

FIFO contents can be read only once from the circular buffer. If this measured data is to be used several times, it must be buffered in the user data.

If the number of measured values for the FIFO memory exceeds the maximum value defined in machine data, the measurement is automatically terminated.

An endless measuring process can be implemented by reading out measured values cyclically. In this case, data must be read out at least with the same frequency as new measured values are input.

Further information

Synchronized Actions Function Manual; Detailed Description" > "Parameters (\$AC_FIFO)

Protection against programming errors

The following programming errors are detected and indicated as errors:

- MEASA/MEAWA programmed with MEAS/MEAW in the same block
Example:
N01 MEAS=1 MEASA[X]=(1,1) G01 F100 POS[X]=100
- MEASA/MEAWA with number of parameters <2 or >5
Example:
N01 MEAWA[X]=(1) G01 F100 POS[X]=100
- MEASA/MEAWA with trigger event not equal to 1/ -1/ 2/ -2
Example:
N01 MEASA[B]=(1,1,3) B100
- MEASA/MEAWA with invalid mode
Example:
N01 MEAWA[B]=(4,1) B100
- MEASA/MEAWA with trigger event programmed twice
Example:
N01 MEASA[B]=(1,1,-1,2,-1) B100

- MEASA/MEAWA and missing geometry axis

Example:

```
N01 MEASA[X]=(1,1) MEASA[Y]=(1,1) G01 X50 Y50 Z50 F100; GEO axis X/  
Y/Z
```

- Inconsistent measuring job with geometry axes

Example:

```
N01 MEASA[X]=(1,1) MEASA[Y]=(1,1) MEASA[Z]=(1,1,2) G01 X50 Y50 Z50  
F100
```

3.7.7 Special functions for OEM users (OMA1 ... OMA5, OEMIPO1, OEMIPO2, G810 ... G829)

OEM addresses

The meaning of OEM addresses is determined by the OEM user. Their functionality is incorporated by means of compile cycles. Five OEM addresses are reserved (OMA1 ... OMA5). The address identifiers are settable. OEM addresses can be programmed in any block.

Reserved G command calls

The following G command calls are reserved for OEM users:

- OEMIPO1, OEMIPO2 (from G group 1)
- G810 ... G819 (G group 31)
- G820 ... G829 (G group 32)

Their functionality is incorporated by means of compile cycles.

Functions and subprograms

OEM users can also set up predefined functions and subprograms with parameter transfer.

Note

Workpiece simulation

Up to SW 4.4, no compile cycles were supported, as of SW 4.4, only selected compile cycles (CC) are supported for the workpiece simulation.

Language commands in the part program of compile cycles that are not supported (OMA1 ... OMA5, OEMIPO1/2, G810 ... G829, own procedures and functions) - therefore result in an alarm message and cancellation of the simulation without any individual handling.

Solution: Individually handle the missing CC-specific language elements in the part program (\$P_SIM query).

Example:

```
N1 G01 X200 F500
IF (1==$P_SIM)
N5 X300 ;not active for CC simulation
ELSE
N5 X300 OMA1=10
ENDIF
```

3.7.8 Feedrate reduction with corner deceleration (FENDNORM, G62, G621)

With automatic corner deceleration the feed rate is reduced according to a bell-shaped curve before reaching the corner. It is also possible to parameterize the extent of the tool behavior relevant to machining via setting data. These are:

- Start and end of feed rate reduction
- Override with which the feed rate is reduced
- Detection of a relevant corner

Relevant corners are those whose inside angle is less than the corner parameterized in the setting data.

Default value `FENDNORM` deactivates the function of the automatic corner override.

References:

/FBFA/ "Function Description ISO Dialects"

Syntax

`FENDNORM`

`G62 G41`

`G621`

Meaning

FENDNORM:	Automatic corner deceleration OFF
G62:	Corner deceleration at inside corners when tool radius offset is active
G621:	Corner deceleration at all corners when tool radius offset is active

G62 only applies to inside corners with

- active tool radius offset G41, G42 and
- active continuous-path mode G64, G641

The corner is approached at a reduced feed rate resulting from:

$F * (\text{override for feed rate reduction}) * \text{feed rate override}$

The maximum possible feed rate reduction is attained at the precise point where the tool is to change directions at the corner, with reference to the center path.

G621 applies analogously with G62 at each corner of the axes defined by FGROUP.

3.7.9 Programmable end of motion criteria (FINEA, COARSEA, IPOENDA, IPOBRKA, ADISPOSA)

Similar to the block change criterion for path interpolation (G601, G602, and G603) it is also possible to program the end-of-motion criterion for single-axis interpolation in a part program or in synchronized actions for command/PLC axes.

The end-of-motion criterion set will affect how quickly or slowly part program blocks and technology cycle blocks with single-axis movements are completed. The same applies for PLC via FC15/16/18.

Syntax

```

FINEA[<axis>]
COARSEA[<axis>]
IPOENDA[<axis>]
IPOBRKA(<axis>[,<instant in time>])
ADISPOSA[<axis>]=(<mode>,<window size>)

```

Meaning

FINEA:	End-of-motion criterion: "Exact stop fine"	
	Effective:	Modal
COARSEA:	End-of-motion criterion: "Exact stop coarse"	
	Effective:	Modal
IPOENDA:	End-of-motion criterion: "Interpolator stop"	
	Effective:	Modal
IPOBRKA:	Block change criterion: Braking ramp	
	Effective:	Modal

3.7 Special motion commands

ADISPOSA:	Tolerance window for end-of-motion criterion	
	Effective:	Modal
<axis>:	Channel axis name (X, Y, ...)	
<instant in time>:	Time of the block change, referred to the braking ramp as a %:	
	<ul style="list-style-type: none"> • 100% = start of the braking ramp • 0% = end of the braking ramp, the same significance as IPOENDA 	
	Type:	REAL
<mode>:	Reference of the tolerance window	
	Range of values:	0 Tolerance window not active
		1 Tolerance window with respect to set position
		2 Tolerance window with respect to actual position
Type:	INT	
<window size>:	Size of the tolerance window	
	Type:	REAL

Examples

Example 1: End-of-motion criterion: "Interpolator stop"

Program code
<pre> ; traverse positioning axis X to 100, velocity 200 m/ min, acceleration 90%, ; end-of-motion criterion: Interpolator stop N110 G01 POS[X]=100 FA[X]=200 ACC[X]=90 IPOENDA[X] ; Synchronized action: ; ALWAYS IF: Input 1 is set ; THEN traverse positioning axis X to 50, velocity 200 m/ min, acceleration 140%, ; end-of-motion criterion: Interpolator stop N120 EVERY \$A_IN[1] DO POS[X]=50 FA[X]=200 ACC[X]=140 IPOENDA[X] </pre>

Example 2: Block change criterion: "Braking ramp"

Program code	Comment
N40 POS[X]=100	; Default setting is effective ; Positioning motion from X to position 100.
N20 IPOBRKA(X,100)	Block change criterion: Exact stop fine ; Block change criterion: "Braking ramp", 100% = start of the braking ramp
N30 POS[X]=200	; The block is changed as soon as the X axis starts to brake

Program code	Comment
N40 POS[X]=250	; X axis no longer brakes at position 200, but rather continues to traverse to position 250. As soon as the axis starts to brake, the block changes.
N50 POS[X]=0	; Axis X brakes and returns to position 0. The block change takes place at position 0 and "exact stop fine"
N60 X10 F100	; Axis X traverses as path axis to position 10

Further information

System variable for end-of-motion criterion

The effective end-of-motion criterion can be read using the system variable \$AA_MOTEND.

References: /LIS2sl/ List Manual, Book 2

Block-change criterion: "Braking ramp" (IPOBRKA)

If, when activating the block change criterion "brake ramp", a value is programmed for the optional block change instant in time, then this becomes effective for the next positioning motion and is written into the setting data synchronized to the main run. If no value is specified for the block change instant in time, then the actual value of the setting data is effective.

SD43600 \$SA_IPOBRAKE_BLOCK_EXCHANGE

IPOBRKA is deactivated for the corresponding access when an axis end-of-motion criterion (FINEA, COARSEA , IPOENDA) is next programmed for the axis.

Additional block-change criterion: "Tolerance window" (ADISPOSA)

Using ADISPOSA, a tolerance window around the end of block (either as actual or setpoint position) can be defined as additional block change criterion. Then, two conditions must be fulfilled for the block change:

- Block-change criterion: "Braking ramp"
- Block-change criterion: "Tolerance window"

References

For further information about the block change criterion for positioning axes, see:

- Function Manual, Extended Functions; Positioning Axes (P2)
- Programming Manual, Fundamentals; Chapter "Feedrate control".

3.8 Coordinate transformations (frames)

3.8.1 Coordinate transformation via frame variables

In addition to the commands such as `ROT`, `AROT` and `SCALE` described in the Fundamentals Programming Manual, "Coordinate transformations (frames)" section, the workpiece coordinate system (WCS) can also be transformed by the frame variables `$P_...FR` (data storage frames) and `$P_...FRAME` (active frames).

The following diagram provides an overview of structuring frame variables:

- Data management frames
- Active frames
- Active total frame: Chain of all active frames
- NCU global frames
- Channel-specific frames




Figure 3-1 Overview of the frame variables

3.8.1.1 Predefined frame variable (\$P_CHBFRAME, \$P_IFRAME, \$P_PFRAME, \$P_ACTFRAME)

Active: channel-specific base frames \$P_CHBFRAME[<n>] (\$P_BFRAME)

Note


The current base frame \$P_BFRAME and the data storage base frame \$P_UBFR are retained for compatibility reasons.

- $\$P_BFRAME \triangleq \$P_CHBFRAME[0]$
- $\$P_UBFR \triangleq \$P_CHBFR[0]$.

The frame variables \$P_CHBFRAME[<n>] define the reference between the basic coordinate system (BCS) and the basic origin system (BOS).

If the current channel-specific base frame \$P_CHBFRAME[<n>] should be active immediately in the NC program, the following possibilities are available.


- **Commands:**
 - G500 (deactivate all settable frames, the base frames remain active)
 - G54 to G599 (settable zero offsets)
- **Assignment of a channel-specific base frames of the data storage to a current channel-specific base frame:**
 $\$P_CHBFRAME[<n>] = \$P_CHBFR[<m>]$



Active: Channel-specific settable frame \$P_IFRAME

The frame variable \$P_IFRAME defines the reference between the basic origin system (BOS) and the settable zero system (SZS).

- \$P_IFRAME corresponds to \$P_UIFR[\$P_IFRNUM]
- After G54 is programmed, for example, \$P_IFRAME contains the translation, rotation, scaling and mirroring defined by G54.




Active: Channel-specific programmable frame \$P_PFRAME

The \$P_PFRAME frame variable defines the reference between the settable zero system (SZS) and the workpiece coordinate system (WCS).

\$P_PFRAME contains the resulting frame, that results

- From the programming of TRANS/ATRANS, ROT/AROT, SCALE/ASCALE, MIRROR/AMIRROR or
- From the assignment of CTRANS, CROT, CMIRROR, CSCALE to the programmed FRAME



Active: Total frame \$P_ACTFRAME

The total frame active in the channel results from the chaining of all frames acting in the channel.

```
$P_ACTFRAME = $P_PARTFRAME : $P_SETFRAME : $P_EXTFRAME :
               $P_ISO1FRAME : $P_ISO2FRAME : $P_ISO3FRAME :
               $P_ACTBFRAME : $P_IFRAME : $P_GFRAME :
               $P_TOOLFRAME : $P_WPFRAME : $P_TRAFRAME :
               $P_PFRAME      : $P_ISO4FRAME : $P_CYCFRAME
```

\$P_ACTFRAME describes the currently valid workpiece coordinate system.

3.8 Coordinate transformations (frames)





Figure 3-2 Frame variable \$P_ACTFRAME

If one of the following frames \$P_BFRAME / \$P_CHBFRAME [<n>], \$P_IFRAME or \$P_PFRAME is changed, the current total frame \$P_ACTFRAME is recalculated.



Basic frame and settable frame are effective after Reset if MD 20110 RESET_MODE_MASK is set as follows:

Bit0=1, bit14=1 --> \$P_UBFR (basic frame) acts

Bit0=1, bit5=1 --> \$P_UIFR [\$P_UIFRNUM] (settable frame) acts

Data storage: channel-specific base frames \$P_CHBFR[<n>]

The frame variables \$P_CHBFR[<n>] read/write the base frames in the data storage. The data storage frame is not immediately active in the channel when written. The written frame is activated with:

- Channel reset and MD20110 \$MC_RESET_MODE_MASK, Bit0 == 1 and Bit14 == 1
- Command G500, G54 ... G57, G505 ... G599 (activation/deactivation of base frames with subsequent recalculation of the current total frames)

Data storage: Channel-specific settable frames \$P_UIFR[<n>]

The frame variables \$P_UIFR[<n>] read/write the settable base frames in the data storage. The frame is not immediately active in the channel when written. The written frame in the channel is calculated with:

- G500 command (deactivate all settable frames or zero offsets)
- G54 ... G57, G505 ... G599 command (activate a settable frame or zero offset)

Active settable frame	Data storage frame	(corresponds to command)
\$P_IFRAME =	\$P_UIFR[0]	G500
	\$P_UIFR[1]	G54
	\$P_UIFR[2]	G55
	\$P_UIFR[3]	G56
	\$P_UIFR[4]	G57
	\$P_UIFR[5]	G505
	\$P_UIFR[6]	G506

	\$P_UIFR[99]	G599

3.8.2 Value assignments to frames**3.8.2.1 Assigning direct values (axis value, angle, scale)**

You can directly assign values to frames or frame variables in the NC program.

Syntax**Syntax**

```
$P_PFRAME = CTRANS(X, <offset value>, Y, <offset value>, Z, <offset value>, ...)
```

```
$P_PFRAME = ROT(X, <angle>, Y, <angle>, Z, <angle>, ...)
```

```
$P_UIFR[...] = CROT(X, <angle>, Y, <angle>, Z, <angle>, ...)
```

```
$P_PFRAME = CSCALE(X, <scale>, Y, <scale>, Z, <scale>, ...)
```

3.8 Coordinate transformations (frames)

`$P_PFRAME = CMIRROR(X, Y, Z)`

The syntax for `$P_CHBFRAME [<n>]` is identical to `$P_PFRAME`.

Meaning


CTrans:	Translation of specified axes
CROT:	Rotation around specified axes
CScale:	Scale change on specified axes
CMIRROR:	Direction reversal on specified axis
X, Y, Z:	Offset value in the direction of the specified geometry axis
<offset value>:	Offset value
<angle>:	The angle with the rotation
<scale>:	Scale value

Examples

Value assignments to frame components of the current programmable frame

Value assignment to the translation, rotation and mirror frame components of the current programmable frame:

`$P_PFRAME = CTRANS(X,10,Y,20,Z,5) : CROT(Z,45) : CMIRROR(Y)`



Writing the rotation components of a frame

Assignment of values to all three axes of the rotation component of the settable data storage frame `$P_UIFR` with `CROT` :

`$P_UIFR[5] = CROT(X, 0, Y, 0, Z, 0)`

Alternatively, the direct assignment of the individual values to the associated axis of the rotation component of the data storage frame:

```
$P_UIFR[5, Y, RT]=0
$P_UIFR[5, X, RT]=0
$P_UIFR[5, Z, RT]=0
```


Description

The chaining operator `:` combines several operations on a frame with each other. The operations are processed successively from left to right.

Example

Chained operations on `$P_PFRAME` with offset, rotation and scaling:

```
$P_PFRAME = CTRANS (...) : CROT (...) : CSCALE ...
```



3.8.2.2 Reading and changing frame components (TR, FI, RT, SC, MI)

This feature allows you to access **individual** data of a frame, e.g. a specific offset value or angle of rotation. You can modify these values or assign them to another variable.

Syntax

```
R10=$P_UIFR[$P_UIFNUM, X, RT]
```

Assign the angle of rotation RT around the X axis from the currently valid settable zero offset `$P_UIFRNUM` to the variable R10.

```
R12=$P_UIFR[25, Z, TR]
```

Assign the offset value TR in Z from the data set of set frame no. 25 to the variable R12.

```
R15=$P_PFRAME[Y, TR]
```

Assign the offset value TR in Y of the current programmable frame to the variable R15.

```
$P_PFRAME[X, TR] = 25
```

Modify the offset value TR in X of the current programmable frame. X25 applies immediately.

Meaning

\$P_UIFRNUM:	This command automatically establishes the reference to the currently valid settable zero offset.
P_UIFR[n, ..., ...] :	Specify the frame number n to access the settable frame no. n.
	Specify the component to be read or modified:
TR:	TR Translation
FI:	FI Translation Fine
RT:	RT Rotation
SC:	SC Scale scale modification
MI:	MI Mirroring
X, Y, Z:	The corresponding axis X, Y, Z is also specified (see examples).

Value range for RT rotation

Rotation around 1st geometry axis: -180° to $+180^{\circ}$

Rotation around 2nd geometry axis: -90° to $+90^{\circ}$

Rotation around 3rd geometry axis: -180° to $+180^{\circ}$

Description**Calling frame**

By specifying the system variable \$P_UIFRNUM you can access the current zero offset set with \$P_UIFR or G54, G55, ...

(\$P_UIFRNUM contains the number of the currently set frame).

All other stored settable \$P_UIFR frames are called up by specifying the appropriate number \$P_UIFR[n].

For predefined frame variables and user-defined frames, specify the name, e.g. \$P_IFRAME.


Calling data

The axis name and the frame component of the value you want to access or modify are written in square brackets, e.g. [X, RT] or [Z, MI].

3.8.2.3 Calculating with frames

A frame can be assigned to another frame or frames can be chained to each other in the NC program.

Frame chainings are suitable for the description of several workpieces, arranged on a pallet, which are to be machined in the same process.



The frame components can only contain intermediate values for the description of pallet tasks. These are chained to generate various workpiece zeroes.

Examples

Assignments

Program code	Comment
DEF FRAME SETTING_1	; Definition of a local frame variable
SETTING_1 = CTRANS(X,10)	; Assignment of the function result to the frame variable
\$P_PFRAME = SETTING_1	; Assignment of the frame variable to the current frame
DEF FRAME SETTING_4	; Definition of a local frame variable
SETTING_4 = \$P_PFRAME	; Buffer the current frame in the frame variable
...	
\$P_PFRAME = SETTING_4	; Fetch the current frame from the frame variable

3.8 Coordinate transformations (frames)

Chainings

The operator : chains frames with each other in the programmed sequence. The frame components, such as offsets and rotations, are executed successively additive.

Program code	Comment
\$P_IFRAME = \$P_UIFR[15] : \$P_UIFR[16]	; Assignment of the result frame from the chaining of the ; two settable data storage frames on the active ; settable total frame. ; Application example: ; \$P_UIFR[15]: Offset ; \$P_UIFR[16]: Rotation
\$P_UIFR[3] = \$P_UIFR[4] : \$P_UIFR[5]	; Assignment of the result frame from the chaining of the ; two settable data storage frames on a ; different settable data storage frame

3.8.2.4 Definition of frame variables (DEF FRAME)

In addition to the predefined frame variables, user frame variables can also be defined. The user-defined frame variables are user variables of type FRAME. The name of the frame can be assigned freely in accordance with the rules for user variables.

The CTRANS, CROT, CSCALE and CMIRROR functions assign values to user-defined frame variables.

Syntax

```
DEF FRAME <name>
```

Meaning

DEF FRAME:	Define user variable of the type FRAME.
<name>:	Name of the frame variable

Example

Definition of a "PALETTE" frame variable and the assignment of offset and rotation values:

Program code	Comment
DEF FRAME PALETTE	; Define PALETTE frame variable
PALETTE = CTRANS(...) : CROT(...)	; Assignment of the result frame of the chaining for
	; offset and rotation on the PALETTE frame variable

3.8.3 Coarse and fine offsets (CTRANS, CFINE)

Fine offset

A fine offset `CFINE (...)` can be applied to the following frames:

- Settable frames: `$P_UIFR` or `$P_IFRAME`
- Basic frames: `$P_NCBFR[<n>]`, `$P_CHBFR[<n>]`, `$P_CHBFRAMES[<n>]` or `$P_ACTBFRAME`
- Programmable frame: `$P_PFRAME`

The fine offset of a frame is programmed with the `CFINE (...)` command.

Coarse offset

A coarse offset `CTRANS (...)` can be applied to all frames.

Total offset

The total offset results from the addition of the coarse and the fine offset.

Machine data

Enable of the fine offset

The fine offset is enabled with the machine data:

```
MD18600 $MN_MM_FRAME_FINE_TRANS = 1
```

Syntax

Fine offset

- Complete frame
 - `<frame> = CFINE (<K_1>, <value>)`
 - `<frame> = CFINE (<K_1>, <value>, <K_2>, <value>)`
 - `<frame> = CFINE (<K_1>, <value>, <K_2>, <value>, <K_3>, <value>)`

- Frame component

- `<frame>[<n>, <K_1>, FI] = <value>`

Coarse offset

- Complete frame

- `<frame> = CTRANS (<K_1>, <value>)`
- `<frame> = CTRANS (<K_1>, <value>, <K_2>, <value>)`
- `<frame> = CTRANS (<K_1>, <value>, <K_2>, <value>, <K_3>, <value>)`

- Frame component

- `<frame>[<n>, <K_1>, TR] = <value>`

3.8 Coordinate transformations (frames)

In particular for the programmable frame \$P_PFRAME:


- TRANS <K_1> <value>
- TRANS <K_1> <value> <K_2> <value>
- TRANS <K_1> <value> <K_2> <value> <K_3> <value>

Meaning

<Frame>:	Frame, e.g. settable frame of the data storage \$P_UIFR[<n>]
CFINE:	Fine offset, additive offset.
CTRANS:	Coarse offset, absolute offset.
TRANS:	Only programmable frame: Coarse offset, absolute offset.
<K_n>:	Coordinate axes X, Y, Z
<value>:	Offset value

3.8.4 External zero offset (\$AA_ETRANS)

The external zero offset is a linear offset between the base coordinate system (BCS) and the basic origin system (BOS).



The external zero offset with \$AA_ETRANS acts in two ways depending on the machine data parameterization:

1. After activation by the NC/PLC interface signal, the system variable \$AA_ETRANS acts directly as offset value
2. After activation by the NC/PLC interface signal, the value of the system variable \$AA_ETRANS is transferred to the active system frames \$P:EXTFRAME and the data storage frame \$P_EXTFR. The active total frame \$P_ACTFRAME is then recalculated.

Machine data

In conjunction with the system variable \$AA_ETRANS, a differentiation is made between two procedures selected with the following machine data:

MD28082 \$MC_MM_SYSTEM_FRAME_MASK, Bit1 = <value>

<value>	Meaning
0	Function: \$AA_ETRANS[<axis>] written directly by PLC, HMI or NC program. Enable for retraction of the zero offset for \$AA_ETRANS[<axis>] in the next possible traversing block: DB31, ... DBX3.0
1	Function: Activation of the active system frame \$P:EXTFRAME and the data storage frame \$P_EXTFR Enable for retraction of the zero offset for \$AA_ETRANS[<axis>] by: DB31, ... DBX3.0. The following is performed in the channel: <ul style="list-style-type: none"> • Stop all traversal movements in the channel (other than command and PLC axes) • Preprocessing stop with subsequent reorganization (STOPRE) • Coarse offset of active frame \$P_EXTFRAME[<axis>] = \$AA_ETRANS[<axis>] • Coarse offset of data storage frame \$P_EXTFR[<axis>] = \$AA_ETRANS[<axis>] • Recalculation of the active total frame \$P_ACTFRAME • Retraction of the offset in the programmed axes. • Continuation of the interrupted traversing motion or of the NC program

Programming

- Syntax
\$AA_ETRANS[<axis>] = <value>
- Meaning

\$AA_ETRANS:	System variable for buffering the external zero offset
<axis>:	Channel axis
<value>:	Offset value

NC/PLC interface signal

DB31, ... DBX3.0 = 0 → 1 ⇒ \$P_EXTFRAME[<axis>] = \$P_EXTFR[<axis>] = \$AA_ETRANS[<axis>]

3.8.5 Set actual value with loss of the referencing status (PRESETON)

The PRESETON() procedure sets for one or more axes a new actual value in the machine coordinate system (MCS). This corresponds to a zero offset of the MCS of the axis. This does not cause the axis to be traversed.

PRESETON initiates a preprocessing stop with synchronization. The actual position is assigned to the axis only at standstill.

If the axis for PRESETON is not assigned to the channel, the further procedure depends on the axis-specific configuring of the axis replacement behavior:

MD30552 \$MA_AUTO_GET_TYPE


Referencing status

By setting a new actual value in the machine coordinate system, the referencing status of the machine axis is reset:

DB31, ... DBX60.4/.5 = 0 (referenced / synchronized measuring system 1/2)

For this reason it is recommended that PRESETON only be used for axes that do not require a reference point.

To restore the original machine coordinate system, the measuring system of the machine axis must be referenced again, e.g. through active referencing from the part program (G74).

 CAUTION
<p>Loss of the referencing status</p> <p>The setting of a new actual value in the machine coordinate system with PRESETON resets the referencing status of the machine axis to "not referenced / synchronized".</p>

Programming

Syntax

PRESETON (<axis_1>, <value_1> [, <axis_2>, <value_2>, ... <axis_8>, <value_8>])

Meaning

PRESETON:	Set actual value with loss of the referencing status	
	Preprocessing stop:	yes
	Alone in the block:	yes
<axis_x>:	Machine axis name	
	Type:	AXIS
	Range of values:	Machine axis names defined in the channel
<value_x>:	New actual value of the machine axis in the machine coordinate system (MCS) The input is made in the currently valid measuring system (inch/metric) An active diameter programming (DIAMON) is considered	
	Type:	REAL

References

PRESETONS in NC programs

A detailed description of PRESETON in NC programs is contained in:

Function Manual Basic Functions, Chapter "K2: Axes, coordinate systems, frames" > "Coordinate systems" > "Machine coordinate system (MCS)" > "Set actual value with loss of the referencing status (PRESETON)"

PRESETONS in synchronous actions

A detailed description of PRESETON in synchronous actions is contained in:

Function Manual, Synchronized Actions; Section: "Detailed description" > "Actions in synchronous actions" > "Set actual value with loss of the referencing status (PRESETON)"

3.8.6 Set actual value without loss of the referencing status (PRESETONS)

The PRESETONS () procedure sets for one or more axes a new actual value in the machine coordinate system (MCS). This corresponds to a zero offset of the MCS of the axis. This does not cause the axis to be traversed.

PRESETONS initiates a preprocessing stop with synchronization. The actual position is assigned to the axis only at standstill.

If the axis for PRESETONS is not assigned to the channel, the further procedure depends on the axis-specific configuring of the axis replacement behavior:

MD30552 \$MA_AUTO_GET_TYPE

Referencing status

The setting of a new actual value in the machine coordinate system (MCS) with PRESETONS does **not** change the referencing status of the machine axis.

Requirements

- **Encoder type**

PRESETONS is possible only for the following encoder types of the active measuring system:

- MD30240 \$MA_ENC_TYPE[<measuring system>] = 0 (simulated encoder)
- MD30240 \$MA_ENC_TYPE[<measuring system>] = 1 (raw signal encoder)

- **Referencing mode**

PRESETONS is possible only for the following referencing modes of the active measuring system:

- MD34200 \$MA_ENC_REFP_MODE[<measuring system>] = 0 (no reference point approach possible)
- MD34200 \$MA_ENC_REFP_MODE[<measuring system>] = 1 (referencing for incremental, rotary or linear measuring systems: Zero pulse on the encoder track)

Programming**Syntax**

```
PRESETONS(<axis_1>, <value_1> [, <axis_2>, <value_2>, ... <axis_8>, <value_8>])
```

Meaning

PRESETONS:	Set actual value without loss of the referencing status	
	Preprocessing stop:	yes
	Alone in the block:	yes
<axis_x>:	Machine axis name	
	Type:	AXIS
	Range of values:	Machine axis names defined in the channel
<value_x>:	New current actual value of the machine axis in the machine coordinate system (MCS) The input is made in the active measuring system (inch/metric) An active diameter programming (DIAMON) is considered	
	Type:	REAL

References**PRESETONS in NC programs**

A detailed description of PRESETONS in NC programs is contained in:

Function Manual Basic Functions, Chapter "K2: Axes, coordinate systems, frames" > "Coordinate systems" > "Machine coordinate system (MCS)" > "Set actual value without loss of the referencing status (PRESETONS)"

PRESETONS in synchronous actions

A detailed description of PRESETONS in synchronous actions is contained in:

Function Manual, Synchronized Actions; Section: "Detailed description" > "Actions in synchronous actions" > "Set actual value without loss of the referencing status (PRESETONS)"

3.8.7 Frame calculation from three measuring points in space (MEAFRAME)

The MEAFRAME function is used to support measuring cycles. It calculates the frame from three ideal points and the corresponding measured points.

When a workpiece is positioned for machining, its position relative to the Cartesian machine coordinate system is generally both offset and rotated in relation to its ideal position. For exact machining or measuring either a costly physical adjustment of the part is required or the motions defined in the part program must be changed.

A frame can be defined by sampling three points in space whose ideal positions are known. A touch-trigger probe or optical sensor is used for sampling that touches special holes precisely fixed on the supporting plate or probe balls.

Syntax

```
MEAFRAME(<ideal points>,<measuring points>,<quality>)
```

Meaning

MEAFRAME:	Function call		
<ideal points>:	2-dim. REAL array containing the three coordinates of the ideal points		
<measuring points>:	2-dim. REAL array containing the three coordinates of the measured points		
<quality>:	Variable with which information on the quality of the FRAME calculation is returned		
	Type:	VAR REAL	
	Value:	-1	The ideal points are almost on a straight line: The frame could not be calculated. The returned FRAME variable contains a neutral frame.
		-2	The measuring points are almost on a straight line: The frame could not be calculated. The returned FRAME variable contains a neutral frame.
		-4	The calculation of the rotation matrix failed for a different reason.
≥ 0.0		Sum of distortions (distances between the points), that are required to transform the measured triangle into a triangle that is congruent to the ideal triangle.	

Note

Quality of the measurement

In order to map the measured coordinates onto the ideal coordinates using a rotation and a translation, the triangle formed by the measured points must be congruent to the ideal triangle. This is achieved by means of a compensation algorithm that minimizes the sum of squared deviations needed to reshape the measured triangle into the ideal triangle.

Since the effective distortion can be used to judge the quality of the measurement, MEAFRAME returns it as an additional variable.

Note

The frame created by MEAFRAME can be transformed by the ADDFRAME function into another frame in the frame chain (see example "Chaining with ADDFRAME").

Examples

Example 1:

Part program 1:

```

Program code
...
DEF FRAME CORR_FRAME

```

3.8 Coordinate transformations (frames)

Setting measuring points:

Program code	Comment
DEF REAL IDEAL_POINT[3,3]= SET(10.0,0.0,0.0,0.0,10.0,0.0,0.0,0.0,10.0)	
DEF REAL MEAS_POINT[3,3]= SET(10.1,0.2,-0.2,-0.2,10.2,0.1,-0.2,0.2,9.8)	; For test.
DEF REAL FIT_QUALITY=0	
DEF REAL ROT_FRAME_LIMIT=5	; Permits max. five degree rotation of the part position.
DEF REAL FIT_QUALITY_LIMIT=3	; Permits max. three mm offset between the ideal and the measured triangle.
DEF REAL SHOW_MCS_POS1[3]	
DEF REAL SHOW_MCS_POS2[3]	
DEF REAL SHOW_MCS_POS3[3]	

Program code	Comment
N100 G01 G90 F5000	
N110 X0 Y0 Z0	
N200 CORR_FRAME=MEAFRAME(IDEAL_POINT,MEAS_POINT,FIT_QUALITY)	
N230 IF FIT_QUALITY < 0	
SETAL(65000)	
GOTOF NO_FRAME	
ENDIF	
N240 IF FIT_QUALITY > FIT_QUALITY_LIMIT	
SETAL(65010)	
GOTOF NO_FRAME	
ENDIF	
N250 IF CORR_FRAME[X,RT] > ROT_FRAME_LIMIT	; Limiting the 1st RPY angle.
SETAL(65020)	
GOTOF NO_FRAME	
ENDIF	
N260 IF CORR_FRAME[Y,RT] > ROT_FRAME_LIMIT	; Limiting the 2nd RPY angle.
SETAL(65021)	
GOTOF NO_FRAME	
ENDIF	
N270 IF CORR_FRAME[Z,RT] > ROT_FRAME_LIMIT	; Limiting the 3rd RPY angle.
SETAL(65022)	
GOTOF NO_FRAME	
ENDIF	
N300 \$P_IFRAME=CORR_FRAME	; Activate sample frame with settable frame.
	; Check frame by positioning the geometry axes to the ideal point.

Program code	Comment
N400 X=IDEAL_POINT[0,0] Y=IDEAL_POINT[0,1] Z=IDEAL_POINT[0,2]	
N410 SHOW_MCS_POS1[0]=\$AA_IM[X]	
N420 SHOW_MCS_POS1[1]=\$AA_IM[Y]	
N430 SHOW_MCS_POS1[2]=\$AA_IM[Z]	
N500 X=IDEAL_POINT[1,0] Y=IDEAL_POINT[1,1] Z=IDEAL_POINT[1,2]	
N510 SHOW_MCS_POS2[0]=\$AA_IM[X]	
N520 SHOW_MCS_POS2[1]=\$AA_IM[Y]	
N530 SHOW_MCS_POS2[2]=\$AA_IM[Z]	
N600 X=IDEAL_POINT[2,0] Y=IDEAL_POINT[2,1] Z=IDEAL_POINT[2,2]	
N610 SHOW_MCS_POS3[0]=\$AA_IM[X]	
N620 SHOW_MCS_POS3[1]=\$AA_IM[Y]	
N630 SHOW_MCS_POS3[2]=\$AA_IM[Z]	
N700 G500	; Deactivate settable frame as with zero frame (no value entered, pre-assigned).
No_FRAME	; Deactivate settable frame, as pre-assigned with zero frame (no value entered).
M0	
M30	

Example 2: Chaining of frames

Chaining of MEAFRAME for offsets

The MEAFRAME function returns an offset frame. If this offset frame is chained to the settable frame \$P_UIFR[1] that was active during the call of the function (e.g. G54), a settable frame is provided for further conversions for the traversing or machining.

Chaining with ADDFRAME

If you want this offset frame in the frame chain to apply at a different position or if other frames are active before the settable frame, the ADDFRAME function can be used for chaining into one of the channel basic frames or a system frame.

The following must not be active in the frames:

- Mirroring with MIRROR
- Scaling with SCALE

The input parameters for the setpoints and actual values are the workpiece coordinates. These coordinates must always be specified metrically or in inches (G71/G70) and radius-related (DIAMOF) in the basic system of the control.

References:

For further information on ADDFRAME, see:

Function Manual, Basic Functions; K2: Axis Types, Coordinate Systems, Frames

3.8.8 Global frames

There is only one set of global frames for all channels on each control. Global frames can be read and written from all channels. The global frames are activated in the respective channel.

Channel axes and machine axes with offsets can be scaled and mirrored by means of global frames.

Geometrical relationships and frame chains

With global frames there is no geometrical relationship between the axes. It is therefore not possible to perform rotations or program geometry axis identifiers.

Rotations cannot be used on global frames. The programming of a rotation is denied with alarm 18310 "Channel %1 Block %2 Frame: rotation not allowed".

It is possible to chain global frames and channel-specific frames. The resulting frame contains all frame components including the rotations for all axes. The assignment of a frame with rotation components to a global frame is denied with alarm "Frame: rotation not allowed".

Global frames

Global basic frames \$P_NCBFR[n]

Up to eight global basic frames can be configured:

Channel-specific basic frames can also be available.

Global frames can be read and written from all channels of a control. When writing global frames, the user must ensure channel coordination. This can be implemented, for example, through wait markers (WAITMC).

Note

Machine manufacturer

The number of global basic frames is configured via the machine data.

References:

Function Manual, Basic Functions; Axes, Coordinate Systems, Frames (K2)

Settable frames (\$P_UIFR[n])

All settable frames G500, G54...G599 can be configured either globally or channel-specifically.

Note

Machine manufacturer

All settable frames can be reconfigured as global frames with the aid of machine data MD18601 \$MN_MM_NUM_GLOBAL_USER_FRAMES.

Channel axis identifiers and machine axis identifiers can be used as axis identifiers in frame program commands. Programming the geometry identifiers is rejected with an alarm.

3.8.8.1 Channel-specific frames (\$P_CHBFR, \$P_UBFR)

Settable frames or basic frames can be read and written via the part program and via the OPI by the operator and by the PLC.

The fine offset can also be used for global frames. Global frames are suppressed in the same way as channel-specific frames, via G53, G153, SUPA and G500.

Machine manufacturer

The number of basic frames can be configured in the channel via the machine data MD28081 \$MC_MM_NUM_BASE_FRAMES. The standard configuration is designed for at least one basic frame per channel. A maximum of eight basic frames are supported per channel. In addition to the eight basic frames, there can also be eight NCU global basic frames in the channel.

Channel-specific frames

\$P_CHBFR[n]

System variable \$P_CHBFR[n] can be used to read and write the basic frames. When a basic frame is written, the chained total basic frame is not activated until the execution of a G500, G54 ... G599 statement. The variable is used primarily for storing write operations to the basic frame on HMI or PLC. These frame variables are saved by the data backup.

First basic frame in the channel

The basic frame with array index 0 is not activated simultaneously when writing to the predefined \$P_UBFR variable, but rather activation only takes place on execution of a G500, G54 ... G599 statement. The variable can also be read and written in the program.

\$P_UBFR

\$P_UBFR is identical to \$P_CHBFR[0]. One basic frame always exists in the channel by default, so that the system variable is compatible with older versions. If there is no channel-specific basic frame, an alarm is issued at read/write: "Frame: statement not permissible".

3.8.8.2 Frames active in the channel

Frames active in the channel are entered from the part program via the relevant system variables of these frames. This also includes system frames. The current system frame can be read and written in the part program via these system variables.

Frames currently active in the channel

Overview

Current system frames

\$P_PARTFRAME

\$P_SETFRAME

\$P_EXTFRAME

\$P_NCBFRAME[n]

For:

TCARR and PAROT

Preset actual value memory and scratching

External work offset

Current global basic frames

\$P_CHBFRAME[n]	Current channel basic frames
\$P_BFRAME	Current 1. Basic frame in the channel
\$P_ACTBFRAME	Complete basic frame
\$P_CHBFRMASK and \$P_NCBFRMASK	Complete basic frame
\$P_IFFRAME	Current settable frame
Current system frames	For:
\$P_TOOLFRAME	TOROT and TOFRAME
\$P_WPFRAME	Workpiece reference points
\$P_TRAFRAME	Transformations
\$P_PFRAME	Current programmable frame
Current system frame	For:
\$P_CYCFRAME	Cycles
P_ACTFRAME	Current total frame
FRAME chaining	Current frame is made up of the complete basic frame

\$P_NCBFRAME [n] current global basic frames

System variable \$P_NCBFRAME[n] can be used to read and write the current global basic frame field elements. The resulting total basic frame is calculated by means of the write process in the channel.

The modified frame is activated only in the channel in which the frame was programmed. If the frame is to be modified for all channels of a control, \$P_NCBFR[n] and \$P_NCBFRAME[n] must be written simultaneously. The other channels must then activate the frame, e.g. with G54. Whenever a basic frame is written, the complete basic frame is calculated again.

\$P_CHBFRAME[n] Current channel basic frames

System variable \$P_CHBFRAME[n] can be used to read and write the current channel basic frame field elements. The resulting complete basic frame is calculated by means of the write process in the channel. Whenever a basic frame is written, the complete basic frame is calculated again.

\$P_BFRAME current 1st Basic frame in the channel

The predefined frame variable \$P_BFRAME can be used to read and write the current basic frame with the array index 0, which is valid in the channel, in the part program. The written basic frame is immediately included in the calculation.


\$P_BFRAME is identical to \$P_CHBFRAME[0]. The system variable always has a valid default value. If there is no channel-specific basic frame, an alarm is issued at read/write: "Frame: statement not permissible".

\$P_ACTBFRAME Complete basic frame

The \$P_ACTFRAME variable determines the chained complete basic frame. The variable is read-only.

\$P_ACTFRAME corresponds to:

\$P_NCBFRAME[0] : ... : \$P_NCBFRAME[n] : \$P_CHBFRAME[0] : ... : \$P_CHBFRAME[n].



$\$P_CHBFRMASK$ and $\$P_NCBFRMASK$ Complete basic frame

The user can select which basic frames are to be included in the calculation of the "Complete" basic frame via the system variables $\$P_CHBFRMASK$ and $\$P_NCBFRMASK$. The variables can only be programmed in the program and read via the OPI. The value of the variable is interpreted as a bit mask and specifies which basic frame field element of $\$P_ACTFRAME$ is to be included in the calculation.

$\$P_CHBFRMASK$ can be used to specify which channel-specific basic frames and

$\$P_NCBFRMASK$ can be used to specify which global basic frames are to be included in the calculation.

The complete basic frame and the complete frame are recalculated with the programming of the variables. After a reset and in the basic setting, the values of $\$P_CHBFRMASK$ and $\$P_NCBFRMASK$ are as follows:

$\$P_CHBFRMASK = \$MC_CHBFRAME_RESET_MASK$

$\$P_NCBFRMASK = \$MC_CHBFRAME_RESET_MASK$

Example:

$\$P_NCBFRMASK = 'H81' ; \$P_NCBFRAME[0] : \$P_NCBFRAME[7]$

$\$P_CHBFRMASK = 'H11' ; \$P_CHBFRAME[0] : \$P_CHBFRAME[4]$

$\$P_IFRAME$ Current settable frame

The predefined frame variable $\$P_IFRAME$ can be used to read and write the current settable frame, which is valid in the channel, in the part program. The written settable frame is immediately included in the calculation.

In the case of global settable frames, the modified frame acts only in the channel in which the frame was programmed. If the frame is to be modified for all channels of a control, $\$P_UIFR[n]$ and $\$P_IFRAME$ must be written simultaneously. The other channels must then activate the corresponding frame, e.g. with G54.

\$P_PFRAME Current programmable frame

\$P_PFRAME is the programmable frame that results from the programming of TRANS/ATRANS, G58/G59, ROT/AROT, SCALE/ASCALE, MIRROR/AMIRROR or from the assignment of CTRANS, CROT, CMIRROR, CSCALE to the programmable frame.


Current, programmable frame variable that establishes the reference between the settable zero system (SZS) and the workpiece coordinate system (WCS).

P_ACTFRAME Current complete frame

The resulting current complete frame \$P_ACTFRAME is now a chain of all basic frames, the current settable frame and the programmable frame. The current frame is always updated whenever a frame component is changed.


\$P_ACTFRAME corresponds to:

\$P_PARTFRAME : \$P_SETFRAME : \$P_EXTFRAME : \$P_ACTBFRAME : \$P_IFRAME :
 \$P_TOOLFRAME : \$P_WPFRAME : \$P_TRAFRAME : \$P_PFRAME : \$P_CYCFRAME



Frame chaining

The current frame is composed of the complete basic frame, the settable frame, the system frame and the programmable frame in accordance with the current complete frame specified above.



3.9 Transformations

3.9.1 General programming of transformation types

3.9.1.1 General programming of transformation types

General function

You can choose to program transformation types with suitable parameters in order to adapt the controller to various machine kinematics. These parameters can be used to declare both the orientation of the tool in space and the orientation movements of the rotary axes accordingly for the selected transformation.

In three-, four-, and five-axis transformations, the programmed positional data always relates to the tip of the tool, which is tracked orthogonally to the machined surface in space. The Cartesian coordinates are converted from the basic coordinate system to the machine coordinate system and relate to the geometry axes. These describe the operating point. Virtual rotary axes describe the orientations of the tool in space and are programmed with TRAORI.

In the case of kinematic transformation, positions can be programmed in the Cartesian coordinate system. The control transforms the traversing movements of the Cartesian coordinate system programmed with TRANSMIT and TRACYL to the traversing movements of the real machine axes.

Programming

Three, four and five axis transformations (TRAORI)

The orientation transformation declared is activated with the TRAORI command and the three possible parameters for transformation number, orientation vector and rotary axis offsets.

```
TRAORI(transformation number, orientation vector, rotary axis  
offsets)
```

Kinematic transformations

TRANSMIT(transformation number) declared transformations are examples of kinematic transformation.

```
TRACYL(working diameter, transformation number)
```

Deactivate active transformation

TRAF00F can be used to deactivate the currently active transformation.

Orientation transformation

Three, four and five axis transformations (TRAORI)

For the optimum machining of surfaces configured in space in the working area of the machine, machine tools require other axes in addition to the three linear axes X, Y and Z. The additional

axes describe the orientation in space and are called orientation axes in subsequent sections. They are available as rotary axes on four types of machine with varying kinematics.

1. Two-axis swivel head, e.g. cardanic tool head with one rotary axis parallel to a linear axis on a fixed tool table.
2. Two-axis rotary table, e.g. fixed swivel head with tool table, which can rotate about two axes.
3. Single-axis swivel head and single-axis rotary table, e.g. one rotatable swivel head with rotated tool for tool table, which can rotate about one axis.
4. Two-axis swivel head and single-axis rotary table, e.g. on tool table, which can rotate about one axis, and one rotatable swivel head with tool, which can rotate about itself.

3- and 4-axis transformations are special types of 5-axis transformation and are programmed in the same way as 5-axis transformations.

The functional scope of "**generic 3-/4-/5-/6-axis transformation**" is suitable both for transformations for orthogonal rotary axes and transformations for the universal milling head and, like all other orientation transformations, can also be activated for these four machine types with TRAORI. In generic 5-/6-axis transformation, tool orientation has an additional third degree of freedom, whereby the tool can be rotated about its own axis relative to the tool direction so that it can be directed as required in space.

Further information

Transformations Function Manual; Multiple Transformations

Initial tool orientation setting regardless of kinematics

ORIRESET

If an orientation transformation is active using TRAORI, then ORIRESET can be used to specify the initial settings of up to 3 orientation axes with the optional parameters A, B, C. The order in which the programmed parameters are assigned to the round axes depends on the orientation axis order defined by the transformation. Programming ORIRESET(A, B, C) results in the orientation axes moving in linear and synchronous motion from their current position to the specified initial setting position.

Kinematic transformations

TRANSMIT and TRACYL

For milling on turning machines, either

1. Face machining in the turning clamp with TRANSMIT or
2. Machining of grooves with any path on cylindrical bodies with TRACYL

can be programmed for the transformation declared.

Cartesian PTP travel

Kinematic transformation also includes the so-called "Cartesian PTP travel" for which up to 8 different articulated joint positions STAT= can be programmed. Although the positions are programmed in a Cartesian coordinate system, the movement of the machine occurs in the machine coordinates.

Further information

Transformations Function Manual; Kinematics Transformation

Chained transformations

Two transformations can be switched one after the other. For the second transformation chained here, the motion parts for the axes are taken from the first transformation.

The first transformation can be:

- Orientation transformation TRAORI
- Polar transformation TRANSMIT
- Cylinder transformation TRACYL

3.9.1.2 Orientation movements for transformations

Travel movements and orientation movements

The traversing movements of the programmed orientations are determined primarily by the type of machine. For three-, four-, and five-axis type transformations with TRAORI, the rotary axes or pivoting linear axes describe the orientation movements of the tool.


Changes in the position of the rotary axes involved in the orientation transformation will induce compensating movements on the remaining machine axes. The position of the tool tip remains unchanged.

Orientation movements of the tool can be programmed using the rotary axis identifiers A..., B..., C... of the virtual axes as appropriate for the application either by entering Euler or RPY angles or directional or surface normal vectors, normalized vectors for the rotary axis of a taper or for intermediate orientation on the peripheral surface of a taper.

In the case of the kinematics transformation with TRANSMIT and TRACYL, the control maps the programmed Cartesian coordinate system traversing movements to the traversing movements of the real machine axes.

Machine kinematics for three, four and five axis transformation (TRAORI)

Either the tool or the tool table can be rotatable with up to two rotary axes. A combination of swivel head and rotary table (single-axis in each case) is also possible.



Machine type	Programming of orientation
Three-axis transformation machine types 1 and 2	Programming of tool orientation only in the plane, which is perpendicular to the rotary axis. There are two translatory axes (linear axes) and one axis of rotation (rotary axis).
Four-axis transformation machine types 1 and 2	Programming of tool orientation only in the plane, which is perpendicular to the rotary axis. There are three translatory axes (linear axes) and one axis of rotation (rotary axis).
Five-axis transformation machine types 3 Single-axis swivel head and single-axis rotary table	Programming of orientation transformation. Kinematics with three linear axes and two orthogonal rotary axes. The rotary axes are parallel to two of the three linear axes. The first rotary axis is moved by two Cartesian linear axes. It rotates the third linear axis with the tool. The second rotary axis rotates the workpiece.

Generic 5/6-axis transformations

Machine type	Programming of orientation transformation
Generic five/six-axis transformation machine types 4 Two-axis swivel head with tool which rotates around itself and single-axis rotary table	Programming of orientation transformation. Kinematics with three linear axes and three orthogonal rotary axes. The rotary axes are parallel to two of the three linear axes. The first rotary axis is moved by two Cartesian linear axes. It rotates the third linear axis with the tool. The second rotary axis rotates the workpiece. The basic tool orientation can also be programmed with additional rotation of the tool around itself with the THETA rotary angle.

When calling "generic three-, four-, and five/six-axis transformation", the basic orientation of the tool can also be transferred. The restrictions in respect of the directions of the rotary axes no longer apply. If the rotary axes are not exactly vertical to one another or existing rotary axes are

not exactly parallel with the linear axes, "generic five-/six-axis transformation" can provide better results in respect of tool orientation.

Kinematics transformations TRANSMIT and TRACYL

For milling on turning machines or an axis that can be set for inclined infeed during grinding, the following axis arrangements apply by default in accordance with the transformation declared:

TRANSMIT	Activation of polar transformation
Face machining in the turning clamp	A rotary axis An infeed axis vertical to the axis of rotation A longitudinal axis parallel to the axis of rotation

TRACYL	Activation of the cylinder surface transformation
Machining of grooves with any path on cylindrical bodies	A rotary axis An infeed axis vertical to the axis of rotation A longitudinal axis parallel to the axis of rotation

Cartesian PTP travel

The machine moves in machine coordinates and is programmed with:

TRAORI	Activation of transformation
PTP point-to-point traversing	Approach position in Cartesian coordinate system (MCS)
CP	Path motion of Cartesian axes in the BCS
STAT	Position of the articulated joints is dependent on the transformation
TU	The angle at which the axes traverse on the shortest path

PTP transversal with generic 5/6-axis transformation

The machine is moved using machine coordinates and the tool orientation, where the movements can be programmed both using round axis positions and using Euler and/or RPY angle vectors irrespective of the kinematics or the direction vectors.

Round axis interpolation, vector interpolation with large circle interpolation or interpolation of the orientation vector on a peripheral surface of a taper are possible in such cases.

Example: Three- to five-axis transformation on a universal milling head

The machine tool has at least five axes:

- Three translatory axes for movements in straight lines, which move the operating point to any position in the working area.
- Two rotary swivel axes arranged at a configurable angle (usually 45 degrees) allow the tool to swivel to positions in space that are limited to a half sphere in a 45-degree configuration.

3.9.1.3 Overview of orientation transformation TRAORI

Programming types available in conjunction with TRAORI


Machine type	Programming with active transformation TRAORI
<p>Machine types 1, 2, or 3 two-axis swivel head or two-axis rotary table or a combination of single-axis swivel head and single-axis rotary table.</p>	<p>The axis sequence of the orientation axes and the orientation direction of the tool can either be configured on a machine-specific basis using machine data depending on the machine kinematics or on a workpiece-specific basis with programmable orientation independently of the machine kinematics.</p> <p>The directions of rotation of the orientation axes in the reference system are programmed with:</p> <ul style="list-style-type: none"> - ORIMKS reference system = machine coordinate system - ORIWKS reference system = workpiece coordinate system <p>The default setting is ORIWKS.</p> <p>Programming of orientation axes with:</p> <p>A, B, C of the machine axis position direct</p> <p>A2, B2, C2 angle programming virtual axes with</p> <ul style="list-style-type: none"> - ORIEULER via Euler angle (standard) - ORIRPY via RPY angle - ORIVIRT1 via virtual orientation axes 1st definition - ORIVIRT2 via virtual orientation axes 2nd definition <p>with differentiation between the interpolation type:</p> <p>linear interpolation</p> <ul style="list-style-type: none"> - ORIAxes of orientation axes or machine axes <p>large radius circle interpolation (interpolation of the orientation vector)</p> <ul style="list-style-type: none"> - ORIVECT from orientation axes <p>Programming orientation axes by specifying</p> <p>A3, B3, C3 of the vector components (direction/surface normal)</p> <p>Programming the resulting tool orientation</p> <p>A4, B4, C4 of the vector surface normal at the beginning of the block</p> <p>A5, B5, C5 of the vector perpendicular to the surface at the end of the block</p> <p>LEAD leading angle for tool orientation</p> <p>TILT tilt angle for the tool orientation</p>

Machine type	Programming with active transformation TRAORI
	<p>Interpolation of the orientation vector on a taper peripheral surface Orientation changes to a taper peripheral surface anywhere in space using interpolation:</p> <ul style="list-style-type: none"> - ORIPLANE in the plane (large radius circle interpolation) - ORICONCW on a taper peripheral surface in the clockwise direction - ORICONCCW on a taper peripheral surface in the counter-clockwise direction <p>A6, B6, C6 director vector (axis of rotation of the taper)</p> <ul style="list-style-type: none"> - OICONIO interpolation on a taper peripheral surface with: A7, B7, C7 intermediate vectors (initial and ultimate orientation) or - ORICONTO on the peripheral surface of a taper, tangential transition <p>Changes in orientation in relation to a path with</p> <ul style="list-style-type: none"> - ORICURVE specification of the movement of two contact points using PO[XH]=(xe, x2, x3, x4, x5) orientation polynomials up to the fifth degree PO[YH]=(ye, y2, y3, y4, y5) orientation polynomials up to the fifth degree PO[ZH]=(ze, z2, z3, z4, z5) orientation polynomials up to the fifth degree - ORIPATHS smoothing of orientation characteristic with A8, B8, C8 reorientation phase of tool corresponding to: direction and path length of tool during retraction movement
<p>Machine types 1 and 3</p> <p>Other machine types with additional tool rotation around itself require a 3rd rotary axis</p> <p>Orientation transformation, e.g. generic 6-axis transformation. Rotations of orientation vector.</p>	<p>Programming of rotations for tool orientation with LEAD angle, angle relative to surface normal vector</p> <p>PO[PHI] programming of a polynomial up to the fifth degree</p> <p>TILT angle rotation about path tangent (Z direction)</p> <p>PO[PSI] programming of a polynomial up to the fifth degree</p> <p>THETA angle of rotation (rotation about tool direction in Z)</p> <p>THETA= value reached at end of block</p> <p>THETA=AC(...) absolute non-modal switching to dimensions</p> <p>THETA=IC(...) non-modal switching to chain dimensions</p> <p>THETA=Θ_e interpolate programmed angle G90/G91</p> <p>PO[THT]=(...) programming of a polynomial up to the fifth degree</p> <p>programming of the rotation vector</p> <ul style="list-style-type: none"> - ORIROTA rotation, absolute - ORIROTR relative rotation vector - ORIROTT tangential rotation vector
<p>Orientation relative to the path for orientation changes relative to the path or rotation of the rotary vector tangentially to the path</p>	<p>Changes in orientation relative to the path with</p> <ul style="list-style-type: none"> - ORIPATH tool orientation relative to the path - ORIPATHS also in the event of a blip in the orientation characteristic <p>programming of rotation vector</p> <ul style="list-style-type: none"> - ORIROTC tangential rotation vector, rotation to path tangent

3.9.2 Three, four and five axis transformation (TRAORI)

3.9.2.1 General relationships of universal tool head

To obtain optimum cutting conditions when machining surfaces with a three-dimensional curve, it must be possible to vary the setting angle of the tool.




The machine design to achieve this is stored in the axis data.

5-axis transformation

Cardanic tool head


Three linear axes (X, Y, Z) and two orientation axes (C, A) define the setting angle and the operating point of the tool here. One of the two orientation axes is created as an inclined axis, in our example A' - in many cases, placed at 45°.



In the examples shown here, you can see the arrangements as illustrated by the CA machine kinematics with the Cardanic tool head!

Machine manufacturer

The axis sequence of the orientation axes and the orientation direction of the tool can be set up using the machine data as appropriate for the machine kinematics.



In this example, A' lies below the angle ϕ to the X axis.


The following possible relations are generally valid:

A' lies below the angle φ to the X axis
 B' lies below the angle φ to the Y axis
 C' lies below the angle φ to the Z axis

Angle φ can be configured in the range 0° to $+89^\circ$ using machine data.

With swiveling linear axis

This is an arrangement with a moving workpiece and a moving tool. The kinematics consists of three linear axes (X, Y, Z) and two orthogonally arranged rotary axes. The first rotary axis is moved, for example, over a compound slide of two linear axes, the tool standing parallel to the third linear axis. The second rotary axis turns the workpiece. The third linear axis (swivel axis) lies in the compound slide plane.



The axis sequence of the rotary axes and the orientation direction of the tool can be set up using the machine data as appropriate for the machine kinematics.

There are the following possible relationships:

Axes:	Axis sequences:
1. rotary axis	A A B B C C
2. rotary axis	B C A C A B
Swiveled linear axis	Z Y Z X Y X

For more detailed information about configurable axis sequences for the orientation direction of the tool, see

References: /FB3/ Function Manual, Special Functions; 3- to 5-Axis Transformations (F2), Section Universal milling head, "Parameterization".

3.9.2.2 Three, four and five axis transformation (TRAORI)

The user can configure two or three translatory axes and one rotary axis. The transformations assume that the rotary axis is orthogonal on the orientation plane.

Orientation of the tool is possible only in the plane perpendicular to the rotary axis. The transformation supports machine types with movable tool and movable workpiece.

Three- and four-axis transformations are configured and programmed in the same way as five-axis transformations.

Reference:

Function Manual, Special Functions; Multi-Axis Transformations (F2)

Syntax

```
TRAORI (<n>)
TRAORI (<n>, <X>, <Y>, <Z>, <A>, <B>)
TRAFOOF
```

Meaning

TRAORI:	Activates the first specified orientation transformation	
TRAORI (<n>):	Activates the orientation transformation specified by n	
<n>:	Number of the transformation	
	Value:	1 or 2
	Example: TRAORI(1) activates orientation transformation 1	
<X>, <Y>, <Z>:	Component of orientation vector to which tool points	
<A>, :	Programmable offset for the rotary axes	
TRAFOOF:	Deactivate transformation	

Tool orientation

Depending on the orientation direction selected for the tool, the active working plane (G17, G18, G19) must be set in the NC program in such a way that tool length offset works in the direction of tool orientation.

Note

When the transformation is enabled, the positional data (X, Y, Z) always relates to the tip of the tool. Changing the positions of the rotary axes involved in the transformation causes compensating motion of the remaining machine axes - which means that the position of the tool tip remains unchanged.

Orientation transformation always points from the tool tip to the tool adapter.

Offset for orientation axes

When orientation transformation is activated an additional offset can be programmed directly for the orientation axes.

Parameters can be omitted if the correct sequence is used in programming.

Example:

TRAORI (, , , , A, B) ; If only a single offset is to be entered

As an alternative to direct programming, the additional offset for orientation axes can also be transferred automatically from the zero offset currently active. Transfer is configured in the machine data.

Examples

TRAORI (1,0,0,1)	; The basic orientation of the tool is in the Z direction
TRAORI (1,0,1,0)	; The basic orientation of the tool is in the Z direction
TRAORI (1,0,1,1)	; The basic orientation of the tool is in the Y/Z direction (corresponds to the position -45°)

3.9.2.3 Variants of orientation programming and initial setting (ORIRESET)

Orientation programming of tool orientation with TRAORI

In conjunction with a programmable TRAORI orientation transformation, in addition to the linear axes X, Y, Z, the rotary axis identifiers A., B..., C... can also be used to program axis positions or virtual axes with angles or vector components. Various types of interpolation are possible for orientation and machine axes. Regardless of which PO[angle] orientation polynomials and PO[axis] axis polynomials are currently active, a number of different types of polynomial can be programmed. These include G1, G2, G3, CIP or POLY.

Changes in tool orientation can even be programmed using orientation vectors in some cases. In such cases, the ultimate orientation of each block can be set either by means of direct programming of the vector or by programming the rotary axis positions.

Variants of orientation programming for three- to five-axis transformation

The following versions of orientation programming are mutually exclusive.

A, B, C	Direct entry of rotary axis positions.
A2, B2, C2	Angle programming of virtual axes via Euler angles or RPY angles
A3, B3, C3	Vector component designation
LEAD, TILT	Specification of lead and tilt angles with reference to path and surface
A4, B4, C4 A5, B5, C5	Surface normal vectors at the start of the block and at the end of the block
A6, B6, C6 A7, B7, C7	Interpolation of the orientation vector on a taper surface transformation.
A8, B8, C8	Redirection of the tool, direction and path length of the retraction movement

Approach initial setting of the tool orientation (ORIRESET)

Through `ORIRESET (. . .)`, the orientation axes of the relevant machine kinematics are traversed linearly and synchronously from their current positions to the programmed initial state positions. If a basic position is not programmed for an axis, the position from the associated machine data `$MC_TRAFO5_ROT_AX_OFFSET_1/2` is used.

Active frames of rotary axes are ignored.

Examples of machine kinematics CA (channel axis names C, A)

Commands	Description
<code>ORIRESET(90, 45)</code>	Axis C: 90° Axis A: 45°
<code>ORIRESET(, 30)</code>	Axis C: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[0]</code> Axis A: 30°
<code>ORIRESET()</code>	Axis C: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[0]</code> Axis A: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[1]</code>

Examples of machine kinematics CAC (channel axis names C, A, B)

Commands	Description
<code>ORIRESET(90, 45, 90)</code>	Axis C: 90° Axis A: 45° Axis B: 90°
<code>ORIRESET()</code>	Axis C: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[0]</code> Axis A: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[1]</code> Axis B: <code>\$MC_TRAFO5_ROT_AX_OFFSET_1/2[2]</code>

Note

Travel to the initial state of the tool orientation with `ORIRESET . . .)` may only take place with active orientation transformation `TRAORI . . .)`.

Programming LEAD, TILT and THETA rotations**Lead angle LEAD and tilt angle TILT.**

In respect of three- to five-axis transformation, tool orientation rotations are programmed with the LEAD and TILT angles.

Angle of rotation THETA

For a transformation **with third rotary axis**, the rotation of the tool about itself can be programmed with the THETA rotary angle both for orientation with vector components as well as for programming the angles LEAD, TILT.

3.9.2.4 Programming the tool orientation (A..., B..., C..., LEAD, TILT)

The following options are available when programming tool orientation:

1. Direct programming the motion of rotary axes. The change of orientation always occurs in the basic or machine coordinate system. The orientation axes are traversed as synchronized axes.
2. Programming in Euler or RPY angles in accordance with angle definition using A2, B2, C2
3. Programming the direction vector using A3, B3, C3 The direction vector points from the tool tip toward the tool adapter.
4. Programming the surface normal vector at the start of the block with A4, B4, C4 and at the end of the block with A5, B5, C5 (face milling).
5. Programming using lead angle LEAD and tilt angle TILT
6. Programming the rotary axis of taper as normalized vector using A6, B6, C6 or of intermediate orientation on the peripheral surface of a taper using A7, B7, C7, see "Orientation programming along the peripheral surface of a taper (ORIPLANE, ORICONxx)".
7. Programming the reorientation, direction and path length of tool during retraction movement using A8, B8, C8, see "Smoothing the orientation characteristic (ORIPATHS A8=, B8=, C8=)"

Note

In all cases, orientation programming is only permissible if an orientation transformation is active.

Advantage: These programs can be transferred to any machine kinematics.

Definition of tool orientation via G command

Note

Machine manufacturer

Machine data can be used to switch between Euler or RPY angles. If the machine data is set accordingly, changeovers are possible both depending on the active G command of group 50 and irrespective of this. The following setting options can be selected:

1. If both machine data for defining the orientation axes and defining the orientation angle are set to zero via G command:
The angles programmed using A2, B2, C2 are **dependent on machine data**. The angle definition of orientation programming is either interpreted as Euler or RPY angles.
2. If the machine data for defining the orientation axes is set to one via G command, the changeover is **dependent** on the active G command of group 50:
The angles programmed using A2, B2, C2 are interpreted in accordance with the active G commands ORIEULER, ORIRPY, ORIVIRT1, ORIVIRT2, ORIAXPOS and ORIPY2. The values programmed with the orientation axes are also interpreted as orientation angles in accordance with the active G command of group 50.
3. If the machine data for defining the orientation angle is set to one via G command and the machine data for defining the orientation axes is set to zero via G command, the changeover is **not dependent** on the active G command of group 50:
The angles programmed using A2, B2, C2 are interpreted in accordance with one of the active G commands ORIEULER, ORIRPY, ORIVIRT1, ORIVIRT2, ORIAXPOS and ORIPY2. The values programmed with the orientation axes are always interpreted as round axis positions irrespective of the active G command of group 50.

Syntax

Rotary axis positions

```
G1 X<Value> Y<Value> Z<Value> A<Value> B<Value> C<Value>
```

Euler angles

```
G1 X<Value> Y<Value> Z<Value> A2<Value> B2<Value> C2<Value>
```

Direction vector

```
G1 X<Value> Y<Value> Z<Value> A3<Value> B3<Value> C3<Value>
```

Surface normal vector at block start

```
G1 X<Value> Y<Value> Z<Value> A4<Value> B4<Value> C4<Value>
```

Surface normal vector at the end of the block

```
G1 X<Value> Y<Value> Z<Value> A5<Value> B5<Value> C5<Value>
```

Lead angle

```
LEAD=<Value>
```

Tilt angle

TILT=<Value>

Meaning

G1:	Linear interpolation
X, Y, Z:	Linear axis positions
A, B, C:	Rotary axis positions
A2=, B2=, C2=:	Angle programming (Euler or RPY angle)
A3=, B3=, C3=:	Directional vectors in the X, Y and Z coordinates of the WCS.
A4=, B4=, C4=:	Surface normal vectors at the start of the block in the X, Y and Z coordinates of the WCS.
A5=, B5=, C5=:	Surface normal vectors at the end of the block in the X, Y and Z coordinates of the WCS.
LEAD= :	Leading angle ¹⁾
TILT= :	Tilt angle ¹⁾
1) The interpretation of the angle indications depend on the setting in MD21094 \$MC_ORIPATH_MODE	

Further information

5-axis programs are usually generated by CAD/CAM systems and not entered at the control. So the following explanations are directed mainly at programmers of postprocessors.

The following commands are available for orientation programming:

Command	Meaning
ORIEULER:	Euler angle with rotation sequence ZX'Z"
ORIRPY:	RPY angle with rotation sequence XY'Z"
ORIRPY2:	RPY angle with rotation sequence ZY'X"
ORIVIRT1:	Virtual orientation axes with freely definable rotation sequence via: MD21120 \$MC_ORIAX_TURN_TAB_1
ORIVIRT2:	Virtual orientation axes with freely definable rotation sequence via: MD21130 \$MC_ORIAX_TURN_TAB_2
ORIAPOS:	Virtual orientation axes with rotary axis positions

Note

The machine manufacturer can use machine data to define various variants. Please refer to the machine manufacturer's instructions.

Programming in Euler angles ORIEULER, rotation sequence Z X' Z"

The values programmed during ORIEULER orientation programming with A2, B2, C2 are interpreted as Euler angles (in degrees).

The new orientation vector results from the following three rotations of the original orientation vector

1. with the rotary axis A_2 about the coordinate axis Z
2. with the rotary axis B_2 about the new coordinate axis X'
3. with the rotary axis C_2 about the coordinate axis Z''

In this case the value of C_2 (rotation around the new Z axis) is meaningless and does not have to be programmed.

Programming in RPY angles $ORIRPY$, rotation sequence $X' Y' Z''$

The values programmed during $ORIEULER$ orientation programming with A_2, B_2, C_2 are interpreted as RPY angles (in degrees) with the rotation sequence $X' Y' Z''$.

Note

In contrast to programming with $ORIEULER$, with $ORIRPY$ all three values here have an effect on the orientation vector.


The new orientation vector results from the following three rotations of the original orientation vector

1. with the rotary axis A_2 about the coordinate axis X
2. with the rotary axis B_2 about the new coordinate axis Y'
3. with the rotary axis C_2 about the coordinate axis Z''

Programming the directional vector

The components of the direction vector are programmed with A_3, B_3, C_3 . The vector points towards the tool adapter; the length of the vector is of no significance.

Vector components that have not been programmed are set equal to zero.




X, Y, Z Coordinate axes of the WCS
A3, B3, Components of the directional vector
C3
O Orientation vector
Figure 3-3 Programming the directional vector

Programming the tool orientation with LEAD and TILT

The resultant tool orientation is determined from:

- Path tangent
- Surface normal vector
At the start of the block A4, B4, C4 and at the end of the block A5, B5, C5
- Lead angle LEAD
Angle in the plane defined by the path tangent and surface normal vector
- Tilt angle TILT at end of block
Angle in the plane, perpendicular to the path tangent relative to the surface normal vector



- T Path tangent
- S Perpendicular to path tangent
- N Surface normal
- B Path
- TCP Tool Center Point
- O Orientation vector

Figure 3-4 Programming of LEAD TILT


Note

Behavior at inside corners with 3D tool offset

If the block is shortened at an inside corner, the programmed tool orientation is still taken over at the end of the block.

3.9.2.5 Face milling (A4, B4, C4, A5, B5, C5)

Face milling is used to machine curved surfaces of any kind.



For this type of 3D milling, you will require the line-by-line description of the 3D paths on the workpiece surface.

The tool shape and dimensions are taken into account in the calculations, which are normally performed in CAM. The fully calculated NC blocks are then read into the control via postprocessors.

Programming the path curvature

Surface description

The path curvature is described by surface normal vectors with the following components:

A4, B4, C4 Start vector at block start

A5, B5, C5 End vector at block end

If a block only contains the start vector, the surface normal vector will remain constant throughout the block. If a block only contains the end vector, interpolation will run from the end value of the previous block via large-circle interpolation to the programmed end value.

If the start and end vectors are programmed, interpolation runs between the two directions, also via large-circle interpolation. This allows continuously smooth paths to be created.

Regardless of the active G17 to G19 level, in the initial setting, surface normal vectors point in the Z direction.

The length of a vector is meaningless.

Vector components that have not been programmed are set to zero.

When ORIWKS is active (see "Reference of the orientation axes (ORIWKS, ORIMKS): (Page 652)"), the surface normal vectors refer to the active frame and are also rotated with frame rotation.

Machine manufacturer

The surface normal vector must be perpendicular to the path tangent, within a limit value set via machine data, otherwise an alarm will be output.

3.9.2.6 Reference of the orientation axes (ORIWKS, ORIMKS):

For orientation programming in the workpiece coordinate system using

- Euler or RPY angle or
- Orientation vector

the course of the rotary motion can be set using `ORIMKS/ORIWKS`.

Note

Machine manufacturer

The type of interpolation for the orientation is specified with machine data:

`MD21104 $MC_ORI_IPO_WITH_G_CODE`

= FALSE: The reference is provided by the G commands ORIWKS und ORIMKS.

= TRUE: The reference are the G commands of the 51th group (ORIAxes, ORIVect, ORIPLANE, ...)

Syntax

`ORIMKS= . . .`

`ORIWKS= . . .`

Meaning

ORIMKS:	Rotation in the machine coordinate system
ORIWKS:	Rotation in the workpiece coordinate system

Note


ORIWKS is the basic setting. In the case of a 5-axis program, if it is not immediately obvious on which machine it is to run, ORIWKS must always be selected. Which movements the machine actually executes depend on the machine kinematics.

`ORIMKS` can be used to program actual machine movements (to avoid collisions with devices or similar, for example).

Further information

With `ORIMKS`, the movement executed by the tool **depends** on the machine kinematics. In the case of a change in orientation of a tool tip at a fixed point in space, linear interpolation takes place between the rotary axis positions.

With `ORIWKS`, the movement executed by the tool **does not depend** on the machine kinematics. With an orientation change with a fixed tool tip, the tool moves in the plane set up by the start and end vectors.



Singular positions

Note

`ORIWKS`

Orientation movements in the singular setting area of the 5-axis machine require vast movements of the machine axes. (For example, with a rotary swivel head with C as the rotary axis and A as the swivel axis, all positions with $A = 0$ are singular.)

Machine manufacturer

To avoid overloading the machine axes, the velocity control vastly reduces the tool path velocity near the singular positions.

With machine data

```
$MC_TRAFO5_NON_POLE_LIMIT
```

```
$MC_TRAFO5_POLE_LIMIT
```

the transformation can be parameterized in such a way that orientation movements close to the pole are put through the pole and rapid machining is possible.

Singular positions are handled only with the MD `$MC_TRAFO5_POLE_LIMIT`.

References:

/FB3/ Function Manual, Special Functions; 3- to 5-Axis Transformation (F2), "Singular Points and How to Deal with Them" section.

3.9.2.7 Programming orientation axes (ORIXES, ORIVECT, ORIEULER, ORIRPY, ORIRPY2, ORIVIRT1, ORIVIRT2)

The "Orientation axes" function describes the orientation of the tool in space and is achieved by programming the offset for the rotary axes. An additional, third degree of freedom can be achieved by also rotating the tool about itself. In this case, the tool is oriented in space via a third rotary axis for which 6-axis transformation is required. The rotation of the tool about itself is defined using the THETA angle of rotation in accordance with the type of interpolation of the rotation vectors (see "Rotations of the tool orientation (ORIROTA, ORIROTR, ORIROTT, ORIROTC, THETA) (Page 663)").

Axis identifiers A2, B2 and C2 are used to program the orientation axes.

Syntax

```
N... ORIXES/ORIVECT                ; Linear or large-circle interpolation
N... G1 X Y Z A B C

N... ORIPLANE                       ; Orientation interpolation of the plane

N... ORIEULER/ORIRPY/ORIRPY2       : Orientation angle Euler/RPY angle
N... G1 X Y Z A2= B2= C2=          ; Angle programming of virtual axes

N... ORIVIRT1/ORIVIRT2             ; Virtual orientation axes def. 1/2
N... G1 X Y Z A3= B3= C3=          ; Direction vector programming
```

Note

Other rotary axis offsets of the orientation axes can be programmed for orientation changes along the peripheral surface of a taper in space, see "Orientation programming along the peripheral surface of a taper (ORIPLANE, ORICONCW, ORICONCCW, ORICONTO, ORICONIO) (Page 656)".

Meaning

ORIXES:	Linear interpolation of machine or orientation axes
ORIVECT:	Large-circle interpolation (identical to ORIPLANE)
ORIMKS: ORIWKS:	Rotation in the machine coordinate system Rotation in the workpiece coordinate system For a description, see "Reference of the orientation axes (ORIWKS, ORIMKS): (Page 652)".
A= B= C=:	Programming the machine axis position
ORIEULER:	Orientation programming via Euler angle

ORIRPY:	Orientation programming via RPY angle The rotation sequence is XYZ and: <ul style="list-style-type: none"> • A2 is the angle of rotation around X • B2 is the angle of rotation around Y • C2 is the angle of rotation around Z
ORIRPY2:	Orientation programming via RPY angle The rotation sequence is ZYX and: <ul style="list-style-type: none"> • A2 is the angle of rotation around Z • B2 is the angle of rotation around Y • C2 is the angle of rotation around X
A2= B2= C2=:	Angle programming of virtual axes
ORIVIRT1/ORIVIRT2:	Orientation programming using virtual orientation axes Definition 1: Definition according to MD21120 \$MC_ORIAX_TURN_TAB_1 Definition 2: Definition according to MD21130 \$MC_ORIAX_TURN_TAB_2
A3= B3= C3=:	Direction vector programming of direction axis

Further information

Machine manufacturer

MD21102 \$MC_ORI_DEF_WITH_G_CODE specifies how the programmed angles A2, B2, C2 are defined:

The definition is according to MD21100 \$MC_ORIENTATION_IS_EULER (standard) or the definition is according to G group 50 (ORIEULER, ORIRPY, ORIVIRT1, ORIVIRT2).

MD21104 \$MC_ORI_IPO_WITH_G_CODE defines which interpolation mode type is active: ORIWKS/ORIMKS or ORIAXES/ORIVECT.

JOG mode

Interpolation for orientation angles in this mode of operation is always linear. During continuous and incremental traversal via the traversing keys, only one orientation axis can be traversed. Orientation axes can be traversed simultaneously using the handwheels.

When orientation axes are traversed manually, the channel-specific feedrate override switch or the rapid traverse override switch in rapid traverse override is applied.

A separate velocity setting is possible with the following machine data:

MD21160 \$MC_JOG_VELO_RAPID_GEO

MD21165 \$MC_JOG_VELO_GEO

MD21150 \$MC_JOG_VELO_RAPID_ORI

MD21155 \$MC_JOG_VELO_ORI

Note

SINUMERIK 840D sl with "handling transformation package"


Using the "Cartesian manual traverse" function, the translation of geometry axes in JOG mode can be set separately from one another in the reference systems MCS, WCS and TCS.

References:

Function Manual Extended Functions; Kinematic Transformation (M1)

3.9.2.8 Orientation programming along the peripheral surface of a taper (ORIPLANE, ORICONCW, ORICONCCW, ORICONTO, ORICONIO)

With extended orientation it is possible to execute a change in orientation along the peripheral surface of a taper in space. The orientation vector is interpolated on the peripheral surface of a taper using the ORICONxx modal command. The end orientation can be programmed with ORIPLANE for interpolation on a plane. The start orientation is usually defined by the previous blocks.



Programming

The end orientation is either defined by specifying the angle programming in the Euler or RPY angle using A2, B2, C2 or by programming the rotary axis positions using A, B, C. Further programming details are needed for orientation axes along the peripheral surface of a taper:

- Rotary axis of taper as a vector with A6, B6, C6
- Opening angle PSI with identifier NUT
- Intermediate orientation outside of the taper with A7, B7, C7

Note

Programming direction vector A6, B6, C6 for the rotary axis of the taper

The programming of an end orientation is not absolutely necessary. If no end orientation is specified, a full outside taper with 360 degrees is interpolated.

Programming the opening angle of the taper with NUT=angle

An end orientation must be specified.

A complete outside taper with 360 degrees cannot be interpolated in this way.

Programming the intermediate orientation A7, B7, C7 on the outside of the taper

An end orientation must be specified. The change in orientation and the direction of rotation is defined uniquely by the three vectors Start orientation, End orientation and Intermediate orientation. All three vectors must be different. If the programmed intermediate orientation is parallel to the start or end orientation, a linear large-circle interpolation of the orientation is executed in the plane that is defined by the start and end vector.

Extended orientation interpolation on the peripheral surface of a taper

```
N... ORICONCW or ORICONCCW
N... A6= B6= C6= A3= B3= C3=
or
N... ORICONTO
N... G1 X Y Z A6= B6= C6=
or
N... ORICONIO
N... G1 X Y Z A7= B7= C7=
N... PO[PHI]=(a2, a3, a4, a5)
N... PO[PSI]=(b2, b3, b4, b5)
```

Interpolation on the outside of a taper with direction vector in the clockwise/counter-clockwise direction of the taper and end orientation or tangential transition and specification of end orientation or specification of end orientation and intermediate orientation on the outside of the taper with polynomials for angle of rotation and polynomials for opening angle

Parameters

ORIPLANE:	Interpolation in the plane (large-circle interpolation)
ORICONCW:	Interpolation on the peripheral surface of a taper in the clockwise direction
ORICONCCW:	Interpolation on the peripheral surface of a taper in the counter-clockwise direction

3.9 Transformations

ORICONTO:	Interpolation on the peripheral surface of a taper with tangential transition
A6= B6= C6=:	Programming of a rotary axis of the taper (normalized vector)
NUT=angle:	Opening angle of taper in degrees
NUT=+179:	Traverse angle less than or equal to 180 degrees
NUT=-181:	Traverse angle greater than or equal to 180 degrees
ORICONIO:	Interpolation on the peripheral surface of a taper
A7= B7= C7=:	Intermediate orientation (programming as normalized vector)
PHI:	Angle of rotation of the orientation about the direction axis of the taper
PSI:	Opening angle of the taper
Possible polynomials PO[PHI]=(a2, a3, a4, a5) PO[PSI]=(b2, b3, b4, b5)	Apart from the different angles, polynomials can also be programmed up to the 5th degree

Example: Different changes to orientation

Program code	Comment
...	
N10 G1 X0 Y0 F5000	
N20 TRAORI(1)	; Orientation transformation ON
N30 ORIVECT	; Interpolate tool orientation as a vector.
...	; Tool orientation in the plane.
N40 ORIPLANE	; Select large-circle interpolation.
N50 A3=0 B3=0 C3=1	
N60 A3=0 B3=1 C3=1	; Orientation in the Y/Z plane is rotated through 45 degrees, orientation (0,1/√2,1/√2) is reached at the end of the block.
...	
N70 ORICONCW	; Orientation programming on the outside of the taper:
N80 A6=0 B6=0 C6=1 A3=0 B3=0 C3=1	The orientation vector is interpolated on the outside of a taper with the direction (0,0,1) up to the orientation (1/√2,0,1/√2) in the clockwise sense, the angle of rotation is 270 degrees.
N90 A6=0 B6=0 C6=1	; The tool orientation goes through a full revolution on the outside of the same taper.

Further information

If changes of orientation along the peripheral surface of a taper anywhere in space are to be described, the vector about which the tool orientation is to be rotated must be known. The start and end orientation must also be specified. The start orientation results from the previous block and the end orientation has to be programmed or defined via other conditions.

Programming in the ORIPLANE plane corresponds to ORIVECT

The programming of large-radius circular interpolation together with angle polynomials corresponds to the linear and polynomial interpolation of contours. The tool orientation is interpolated in a plane that is defined by the start and end orientation. If additional polynomials are programmed, the orientation vector can also be tilted out of the plane.

Programming of circles in a plane G2/G3, CIP and CT

The extended orientation corresponds to the interpolation of circles in a plane. For the corresponding programming options for circles with centers or radii such as G2/G3, circle via intermediate point CIP and tangential circles CT, see

References: Programming Manual Fundamentals, "Programming motion commands".

Orientation programming

Interpolation of the orientation vector on the peripheral surface of a taper ORICONxx

Four different types of interpolation from G group 51 can be selected for interpolating orientations on the peripheral surface of a taper:

1. Interpolation on the outside of a taper in the clockwise direction `ORICONCW` with specification of end orientation and taper direction, or opening angle. The direction vector is programmed with identifiers `A6`, `B6`, `C6` and the opening angle of the taper with identifier `NUT=` value range in interval 0 degrees to 180 degrees.
2. Interpolation on the outside of a taper in the counterclockwise direction `ORICONCCW` with specification of end orientation and taper direction, or opening angle. The direction vector is programmed with identifiers `A6`, `B6`, `C6` and the opening angle of the taper with identifier `NUT=` value range in interval 0 degrees to 180 degrees.
3. Interpolation on the outside of a taper `ORICONIO` with specification of end orientation and an intermediate orientation, which is programmed with identifiers `A7`, `B7`, `C7`.
4. Interpolation on the outside of a taper `ORICONTO` with tangential transition and specification of end orientation. The direction vector is programmed with identifiers `A6`, `B6`, `C6`.

3.9.2.9 Specification of orientation for two contact points (ORICURVE, PO[XH]=, PO[YH]=, PO[ZH]=)

Programming the change in orientation using the second curve in space ORICURVE

Another way to program changes in orientation, besides using the tool tip along a curve in space, is to program the motion of a second contact point of the tool using `ORICURVE`. In this way, changes in tool orientation can be defined uniquely, as when programming the tool vector itself.

Machine manufacturer

Please refer to the machine manufacturer's notes on axis identifiers that can be set via machine data for programming the 2nd orientation path of the tool.

Programming

This type of interpolation can be used to program points (using G1) or polynomials (using POLY) for the two curves in space. Circles and involutes are not permitted. A BSPLINE spline interpolation and the "Combine short spline blocks" function can also be activated.

References:

Function Manual, Basic Functions; Continuous-Path Mode, Exact Stop, Look Ahead (B1), Section: Combine short spline blocks

The other spline types, ASPLINE and CSPLINE, and compressor activation using COMCON, COMPCURV or COMPCAD are not permitted.

The motion of the two contact points of the tool can be predefined up to the 5th degree when programming the orientation polynomials for coordinates.

Extended orientation interpolation with additional curve in space and polynomials for coordinates

N... ORICURVE

Specification of the motion of the second contact point of the tool and additional polynomials of the coordinates in question

N... PO[XH]=(xe, x2, x3, x4, x5)

N... PO[YH]=(ye, y2, y3, y4, y5)

N... PO[ZH]=(ze, z2, z3, z4, z5)

Parameters

ORICURVE	Interpolation of the orientation specifying a movement between two contact points of the tool.
XH YH ZH	Identifiers of the coordinates of the second contact point of the tool of the additional contour as a curve in space
Possible polynomials PO[XH]=(xe, x2, x3, x4, x5) PO[YH]=(ye, y2, y3, y4, y5) PO[ZH]=(ze, z2, z3, z4, z5)	Apart from using the appropriate end points, the curves in space can also be programmed using polynomials.
xe, ye, ze	End points of the curve in space
xi, yi, zi	Coefficients of the polynomials up to the 5th degree

Note

Identifiers XH YH ZH for programming a 2nd orientation path

The identifiers must be selected such that no conflict arises with the other identifiers or linear axes

X Y Z axes

and rotary axes such as

A2 B2 C2 Euler angle or RPY angle

A3 B3 C3 direction vectors

A4 B4 C4 or A5 B5 C5 surface normal vectors

A6 B6 C6 rotation vectors or A7 B7 C7 intermediate point coordinates
or other interpolation parameters.

3.9.3 Orientation polynomials (PO[angle], PO[coordinate])

Irrespective of the polynomial interpolation from G group 1 that is currently active, two different types of orientation polynomial can be programmed up to the 5th degree for a three-axis to five-axis transformation.

1. Polynomials for **angles**: lead angle LEAD, tilt angle TILT
in relation to the plane that is defined by the start and end orientation.
2. Polynomials for **coordinates**: XH, YH, ZH of the second curve in space for the tool orientation of a reference point on the tool.

With a 6-axis transformation, the rotation of rotation vector THT can be programmed with polynomials up to the 5th degree for rotations of the tool itself, in addition to the tool orientation.

Syntax

Type 1 orientation polynomials for **angles**

N... PO[PHI]=(a2, a3, a4, a5) 3-axis to 5-axis transformation
N... PO[PSI]=(b2, b3, b4, b5)

Type 2 orientation polynomials for **coordinates**

N... PO[XH]=(xe, x2, x3, x4, x5) Identifiers for the coordinates of the second
N... PO[YH]=(ye, y2, y3, y4, y5) orientation path for tool orientation
N... PO[ZH]=(ze, z2, z3, z4, z5)

In both cases, with 6-axis transformations, a polynomial can also be programmed for the **rotation** using

N... PO[THT]=(c2, c3, c4, c5)

Interpolation of the rotation relative to the path

or

N... PO[THT]=(d2, d3, d4, d5)

Interpolation absolute, relative and tangential to the change of orientation

of the orientation vector. This is possible if the transformation supports a rotation vector with an offset that can be programmed and interpolated using the THETA angle of rotation.

Meaning

PO[PHI]	Angle in the plane between start and end orientation
PO[PSI]	Angle describing the tilt of the orientation from the plane between start and end orientation
PO[THT]	Angle of rotation created by rotating the rotation vector of one of the G commands of group 54 that is programmed using THETA
PHI	Lead angle LEAD
PSI	Tilt angle TILT
THETA	Rotation about the tool direction in Z
PO[XH]	X coordinate of the reference point on the tool
PO[YH]	Y coordinate of the reference point on the tool
PO[ZH]	Z coordinate of the reference point on the tool

Further information

Orientation polynomials cannot be programmed:

- If ASPLINE, BSPLINE, CSPLINE spline interpolations are active.
Type 1 polynomials for orientation angles are possible for every type of interpolation except spline interpolation, that is, linear interpolation with rapid traverse G00 or with feedrate G01 with polynomial interpolation using POLY and circular/involute interpolation G02, G03, CIP, CT, INVCW and INCCCW.
However, type 2 polynomials for orientation coordinates are only possible if linear interpolation with rapid traverse G00 or with feedrate G01 or polynomial interpolation with POLY is active.
- If the orientation is interpolated using ORIAXES axis interpolation. In this case, polynomials can be programmed directly with PO[A] and PO[B] for orientation axes A and B.

Type 1 orientation polynomials with ORIVECT, ORIPLANE and ORICONxx

Only type 1 orientation polynomials are possible for large-radius circular interpolation and interpolation outside of the taper with ORIVECT, ORIPLANE and ORICONxx.

Type 2 orientation polynomials with ORICURVE

If interpolation with the additional curve in space ORICURVE is active, the Cartesian components of the orientation vector are interpolated and only type 2 orientation polynomials are possible.

3.9.4 Rotations of the tool orientation (ORIROTA, ORIROTR, ORIROTT, ORIROTC, THETA)

If you also want to be able to change the orientation of the tools on machine types with movable tools, program each block with end orientation. Depending on the machine kinematics you can either program the orientation direction of the orientation axes or the direction of rotation of orientation vector THETA. Different interpolation types can be programmed for these rotation vectors:

- ORIROTA: Angle of rotation to an absolute direction of rotation.
- ORIROTR: Angle of rotation relative to the plane between the start and end orientation.
- ORIROTT: Angle of rotation relative to the change in the orientation vector.
- ORIROTC: Tangential angle of rotation to the path tangent.

Syntax

Only if interpolation type ORIROTA is active can the angle of rotation or rotation vector be programmed in all four modes as follows:

1. Directly as rotary axis positions A, B, C
2. Euler angles (in degrees) with A2, B2, C2
3. RPY angles (in degrees) with A2, B2, C2
4. Direction vector via A3, B3, C3 (angle of rotation using THETA=<value>)

If ORIROTR or ORIROTT is active, the angle of rotation can only be programmed directly with THETA.

A rotation can also be programmed in a separate block without an orientation change taking place. In this case, ORIROTR and ORIROTT are irrelevant. In this case, the angle of rotation is always interpreted with reference to the absolute direction (ORIROTA).

N... ORIROTA	Define the interpolation of the rotation vector
N... ORIROTR	
N... ORIROTT	
N... ORIROTC	
N... A3= B3= C3= THETA=<value>	Define the rotation of the orientation vector
N... PO[THT]=(d ₂ , d ₃ , d ₄ , d ₅)	Interpolate angle of rotation with a 5th order polynomial

Meaning

ORIROTA:	Angle of rotation to an absolute direction of rotation
ORIROTR:	Angle of rotation relative to the plane between the start and end orientation
ORIROTT:	Angle of rotation as a tangential rotation vector to the change of orientation
ORIROTC:	Angle of rotation as a tangential rotation vector to the path tangent
THETA:	Rotation of the orientation vector
THETA=<value>:	Angle of rotation in degrees reached by the end of the block
THETA=Θ _e :	Angle of rotation with end angle Θ _e of rotation vector
THETA=AC (...):	Non-modal switchover to absolute dimensions
THETA=AC (...):	Non-modal switchover to incremental dimensions
Θ _e :	End angle of rotational vector both absolute with G90 and relative with G91 (incremental dimensioning) is active
PO[THT]=(...):	Polynomial for angle of rotation

Example: Rotations of the orientations

Program code	Comment
N10 TRAORI	; Activate orientation transformation
N20 G1 X0 Y0 Z0 F5000	; Tool orientation
N30 A3=0 B3=0 C3=1 THETA=0	; In Z direction with angle of rotation 0
N40 A3=1 B3=0 C3=0 THETA=90	; In X direction and rotation about 90 degrees
N50 A3=0 B3=1 C3=0 PO[THT]=(180,90)	; Orientation
N60 A3=0 B3=1 C3=0 THETA=IC(-90)	; In Y direction and rotation about 180 degrees
N70 ORIROTT	; Remains constant and rotation to 90 degrees
N80 A3=1 B3=0 C3=0 THETA=30	; Angle of rotation relative to change of orientation ; Rotation vector in angle 30 degrees to X/Y plane

When interpolating block N40, the angle of rotation from initial value of 0 degrees to final value of 90 degrees is interpolated linearly. In block N50, the angle of rotation changes from 90 degrees to 180 degrees, according to parabola $\theta(u) = +90u^2$. In N60, a rotation can also be executed without a change in orientation taking place.

With N80, the tool orientation is rotated from the Y direction toward the X direction. The change in orientation takes place in the X/Y plane and the rotation vector describes an angle of 30 degrees to this plane.

Further information

ORIROTA

The angle of rotation `THETA` is interpolated with reference to an absolute direction in space. The basic direction of rotation is defined in the machine data.

ORIROTR

The angle of rotation `THETA` is interpreted relative to the plane defined by the start and end orientation.

ORIROTT

The angle of rotation `THETA` is interpreted relative to the change in orientation. For `THETA=0` the rotation vector is interpolated tangentially to the change in orientation and only differs from `ORIROTR` if at least one polynomial has been programmed for "tilt angle `PSI`" for the orientation. The result is a change in orientation that is not executed in the plane. An additional angle of rotation `THETA` can then be used to interpolate the rotation vector such that it always produces a specific value referred to the change in orientation.

ORIROTC

The rotation vector is interpolated relative to the path tangent with an offset that can be programmed using the `THETA` angle. A polynomial `PO[THT]=(c2, c3, c4, c5)` up to the 5th degree can also be programmed for the offset angle.

3.9.5 Orientations relative to the path

3.9.5.1 Orientation types relative to the path

By using this expanded function, relative orientation is not only achieved at the end of the block, but across the entire trajectory. The orientation achieved in the previous block is transferred to the programmed end orientation using large-circle interpolation. There are basically two ways of programming the desired orientation relative to the path:

1. Like the tool rotation, the tool orientation is interpolated relative to the path using `ORIPATH`, `ORPATHTS`.
2. The orientation vector is programmed and interpolated in the usual manner. The rotation of the orientation vector is initiated relative to the path tangent using `ORIROTC`.

Syntax

The type of interpolation of the orientation and the rotation of the tool is programmed using:

<code>N... ORIPATH</code>	Orientation relative to the path
<code>N... ORIPATHS</code>	Orientation relative to the path with smoothing of orientation characteristic
<code>N... ORIROTC</code>	Interpolation of the rotation vector relative to the path

An orientation blip caused by a corner on the trajectory can be smoothed using `ORIPATHS`. The direction and path length of the retracting movement is programmed via the vector using the components `A8=X`, `B8=Y` `C8=Z`.

ORIPATH/ORIPATHS can be used to program various references to the path tangent via the three angles

- LEAD= Specification of lead angle relative to the path and surface
- TILT= Specification of tilt angle relative to the path and surface
- THETA= Angle of rotation

for the entire trajectory. Polynomials up to the 5th degree can be programmed in addition to the THETA angle of rotation using PO [THT] = (. . .) .

Note

Machine manufacturer

Please refer to the machine manufacturer's instructions. Other settings can be made for orientations relative to the path via configurable machine and setting data. For more detailed information, please refer to

References:

/FB3/ Function Manual, Special Functions; 3 to 5-Axis Transformation (F2), Section "Orientation"

Meaning

Various settings can be made for the interpolation of angles LEAD and TILT via machine data:

- The tool-orientation reference programmed using LEAD and TILT is retained for the entire block.
 - Lead angle LEAD: rotation about the direction vertical to the tangent and normal vector TILT: rotation of the orientation about the normal vector.
 - Lead angle LEAD: rotation about the direction vertical to the tangent and normal vector Tilt angle TILT: rotation of the orientation in the direction of the path tangent.
 - Angle of rotation THETA: rotation of the tool about itself with an additional third rotary axis acting as an orientation axis in 6-axis transformation.
-

Note

Orientation relative to the path not permitted in conjunction with OSC, OSS, OSSE, OSD and OST

Orientation interpolation relative to the path, that is ORIPATH or ORIPATHS and ORIOTC, cannot be programmed in conjunction with orientation characteristic smoothing with a G command from group 34. OSOF has to be active for this.

3.9.5.2 Rotation of the tool orientation relative to the path (ORIPATH, ORIPATHS, angle of rotation)

With a 6-axis transformation, the tool can be rotated about itself with a third rotary axis to orientate the tool as desired in space. With a rotation of the tool orientation relative to the path using ORIPATH or ORIPATHS, the additional rotation can be programmed via the THETA angle of rotation. Alternatively, the LEAD and TILT angles can be programmed using a vector, which is located in the plane vertical to the tool direction.

Machine manufacturer

Please refer to the machine manufacturer's instructions. The interpolation of the LEAD and TILT angles can be set differently using machine data.

Syntax

Rotation of tool orientation and tool

The type of tool orientation relative to the path is activated using ORIPATH or ORIPATHS.

N... ORIPATH	Activate type of orientation relative to the path
N... ORIPATHS	Activate type of orientation relative to the path with smoothing of the orientation characteristic

Activating the three angles that can be rotated:

N... LEAD=	Angle for the programmed orientation relative to the surface normal vector
N... TILT=	Angle for the programmed orientation in the plane, vertical to the path tangent relative to the surface normal vector
N... THETA=	Angle of rotation relative to the change of orientation in the tool direction of the third rotary axis

The values of the angles at the end of block are programmed using LEAD=value, TILT=value or THETA=value. In addition to the constant angles, polynomials can be programmed for all three angles up to the 5th degree.

N... PO[PHI]=(a2, a3, a4, a5)	Polynomial for the leading angle LEAD
N... PO[PSI]=(b2, b3, b4, b5)	Polynomial for the tilt angle TILT
N... PO[THT]=(d2, d3, d4, d5)	Polynomial for the angle of rotation THETA

The higher polynomial coefficients, which are zero, can be omitted when programming.
Example: PO[PHI]=a2 results in a parabola for the LEAD angle.

Meaning

Tool orientation relative to the path

ORIPATH:	Tool orientation in relation to path
ORIPATHS :	Tool orientation in relation to path, blips in the orientation characteristic are smoothed
LEAD:	Angle relative to the surface normal vector in the plane that is defined by the path tangent and the surface normal vector
TILT:	Rotation of orientation in the Z direction or rotation about the path tangent
THETA:	Rotation about the tool direction toward Z
PO[PHI]:	Orientation polynomial for the LEAD angle
PO[PSI]:	Orientation polynomial for the TILT angle
PO[THT]:	Orientation polynomial for the THETA angle of rotation

Note

Angle of rotation THETA

A 6-axis transformation is required to rotate a tool with a third rotary axis that acts as an orientation axis about itself.

3.9.5.3 Interpolation of the tool rotation relative to the path (ORIROTC, THETA)

Interpolation with rotation vectors

The rotation vector of the tool rotation, programmed with ORIROTC, relative to the path tangent can also be interpolated with an offset that can be programmed using the THETA angle of rotation. A polynomial can, therefore, be programmed up to the 5th degree for the offset angle using PO[THT].

Syntax

N... ORIROTC	Initiate the rotation of the tool relative to the path tangent
N... A3= B3= C3= THETA=value	Define the rotation of the orientation vector
N... A3= B3= C3= PO[THT]=(c2, c3, c4, c5)	Interpolate offset angle with polynomial up to 5th degree

A rotation can also be programmed in a separate block without an orientation change taking place.

Meaning

Interpolation of the rotation of tool relative to the path in 6-axis transformation

ORIROTC:	Initiate tangential rotation vector relative to path tangent
THETA=value:	Angle of rotation in degrees reached by the end of the block
THETA= θ_e :	Angle of rotation with end angle Θ_e of rotation vector
THETA=AC (...):	Non-modal switchover to absolute dimensions
THETA=IC (...):	Non-modal switchover to incremental dimensions
PO[THT]=(c2, c3, c4, c5):	Interpolate offset angle with polynomial of 5th degree

Note

Interpolation of the rotation vector ORIROTC

Initiating rotation of the tool relative to the path tangent in the opposite direction to the tool orientation, is only possible with a 6-axis transformation.

With active ORIROTC

Rotation vector ORIROTA cannot be programmed. If programming is undertaken, ALARM 14128 "Absolute programming of tool rotation with active ORIROTC" is output.

Orientation direction of the tool for 3-axis to 5-axis transformation

The orientation direction of the tool can be programmed via Euler angles, RPY angles or direction vectors as with 3-axis to 5-axis transformations. Orientation changes of the tool in space can also be achieved by programming the large-circle interpolation ORIVECT, linear interpolation of the orientation axes ORIAxes, all interpolations on the peripheral surface of a taper ORICONxx, and interpolation in addition to the curve in space with two contact points of the tool ORICURVE.

G.....:	Details of the rotary axis motion
X, Y, Z:	Details of the linear axes
ORIAxes:	Linear interpolation of machine or orientation axes
ORIVECT:	Large-circle interpolation (identical to ORIPLANE)
ORIMKS:	Rotation in the machine coordinate system
ORIWKS:	Rotation in the workpiece coordinate system
	Description, see the Rotations of the tool orientation section
A= B= C=:	Programming the machine axis position
ORIEULER:	Orientation programming via Euler angle
ORIRPY:	Orientation programming via RPY angle
A2= B2= C2=:	Angle programming of virtual axes
ORIVIRT1:	Orientation programming using virtual orientation axes
ORIVIRT2:	(definition 1), definition according to MD \$MC_ORIAX_TURN_TAB_1 (definition 2), definition according to MD \$MC_ORIAX_TURN_TAB_2
A3= B3= C3=:	Direction vector programming of direction axis
ORIPLANE:	Interpolation in the plane (large-circle interpolation)

ORICONCW:	Interpolation on the peripheral surface of a taper in the clockwise direction
ORICONCCW:	Interpolation on the peripheral surface of a taper in the counter-clockwise direction
ORICONTO:	Interpolation on the peripheral surface of a taper with tangential transition
A6= B6= C6=:	Programming of a rotary axis of the taper (normalized vector)
NUT=angle	Opening angle of taper in degrees
NUT=+179	Traverse angle less than or equal to 180 degrees
NUT=-181	Traverse angle greater than or equal to 180 degrees
ORICONIO:	Interpolation on the peripheral surface of a taper
A7= B7= C7=:	Intermediate orientation (programming as normalized vector)
ORICURVE XH YH ZH, e.g. with polynomials PO[XH]=(xe, x2, x3, x4, x5)	Interpolation of the orientation specifying a movement between two contact points of the tool. In addition to the end points, additional curve polynomials can also be programmed.

Note

If the tool orientation with active ORIAXES is interpolated via the orientation axes, the angle of rotation is only initiated relative to the path at the end of block.

3.9.5.4 Smoothing of orientation characteristic (ORIPATHS A8=, B8=, C8=)

Changes of orientation that take place with constant acceleration on the contour can cause unwanted interruptions to the path motions, particularly at the corner of a contour. The resulting blip in the orientation characteristic can be smoothed by inserting a separate intermediate block. If ORIPATHS is active during reorientation, the change in orientation occurs at a constant acceleration. The tool can be retracted in this phase.

Machine manufacturer

Please refer to the machine manufacturer's notes on any predefined machine and setting data used to activate this function.

Machine data can be used to set how the retracting vector is interpreted:

1. In the TCS, the Z coordinate is defined by the tool direction.
2. In the WCS, the Z coordinate is defined by the active plane.

For further explanations about the "Orientation relative to the path" function, see

References:

Function Manual, Special Functions; Multi-axis Transformations (F2)

Syntax

Further programming details are needed at the corner of the contour for constant tool orientations relative to the path as a whole. The direction and path length of this motion is programmed via the vector using the components A8=X, B8=Y C8=Z.

N... ORIPATHS A8=X B8=Y C8=Z

Meaning

ORIPATHS:	Tool orientation relative to the path; blip in orientation characteristic is smoothed
A8= B8= C8=:	Vector components for direction and path length
X, Y, Z:	Retracting movement in tool direction

Note

Programming direction vectors A8, B8, C8

If the length of this vector is exactly zero, no retracting movement is executed.

ORIPATHS

Tool orientation relative to the path is activated using ORIPATHS. The orientation is otherwise transferred from the start orientation to the end orientation by means of linear large-circle interpolation.

3.9.6 Compression of the orientation (COMPON, COMPCURV, COMPCAD, COMPSURF)

NC programs, in which orientation transformation (TRAORI) is active and tool orientations are programmed (no matter what type), can be compressed if kept within specified limits.

Programming

Tool orientation

If orientation transformation (TRAORI) is active, for 5-axis machines, tool orientation can be programmed in the following way (independent of the kinematics):

- Programming of the direction **vectors** via:
A3=<...> B3=<...> C3=<...>
- Programming of the Euler**angles** or RPY-**angles** via:
A2=<...> B2=<...> C2=<...>

Rotation of the tool

For **6-axis** machines you can program the tool rotation in addition to the tool orientation.

The angle of rotation is programmed with:

THETA=<...>

See " Rotation of tool orientation (Page 663) ".

Note

NC blocks, in which a rotation is also programmed, can only be compressed if the angle of rotation changes **linearly**. This means that it is not permissible that a polynomial with $PO[THT]=(...)$ is programmed for the angle of rotation.

General structure of an NC block that can be compressed

The general structure of an NC block that can be compressed can therefore look like this:

N... X=<...> Y=<...> Z=<...> A3=<...> B3=<...> C3=<...> THETA=<...> F=<...>

or

N... X=<...> Y=<...> Z=<...> A2=<...> B2=<...> C2=<...> THETA=<...> F=<...>

Note

The position values can be entered directly (e.g. X90) or indirectly via parameter settings (e.g. $X=R1*(R2+R3)$).

Programming tool orientation using rotary axis positions

Tool orientation can be also specified using rotary axis positions, e.g. with the following structure:

N... X=<...> Y=<...> Z=<...> A=<...> B=<...> C=<...> THETA=<...> F=<...>

In this case, compression is executed in two different ways, dependent on whether large radius circular interpolation is executed. If no large radius circular interpolation takes place, then the compressed change in orientation is represented in the usual way by axial polynomials for the rotary axes.

Contour accuracy

Depending on the selected compression mode (MD20482 \$MC_COMPRESSOR_MODE) either the configured axis-specific tolerances (MD33100 \$MA_COMPRESS_POS_TOL) or the following channel-specific tolerances – set using setting data – are effective for the geometry axes and orientation axes for compression:

SD42475 \$SC_COMPRESS_CONTUR_TOL (maximum contour deviation)

SD42476 \$SC_COMPRESS_ORI_TOL (maximum angular deviation for tool orientation)

SD42477 \$SC_COMPRESS_ORI_ROT_TOL (maximum angular deviation for the angle of rotation of the tool) (only available on 6-axis machines)

References:

Function Manual Basic Functions; 3 to 5-Axis Transformation (F2),
Section: "Compression of the orientation"

Activation/deactivation

Compressor functions are activated by modal G commands `COMPON`, `COMPCURV`, `COMPCAD` or `COMPSURE`.

COMPOF terminates the compressor function.

See " NC block compression (COMPON, COMPCURV, COMPCAD) (Page 582) ".

Note

Orientation motion is only compressed when large radius circular interpolation is active (i.e. tool orientation is changed in the plane which is determined by start and end orientation).

Large radius circular interpolation is executed under the following conditions:

- MD21104 \$MC_ORI_IPO_WITH_G_CODE = 0,
ORIWKS is active and
the orientation is programmed as a vector (with A3, B3, C3 or A2, B2, C2).
 - MD21104 \$MC_ORI_IPO_WITH_G_CODE = 1 and
ORIVECT or ORIPLANE is active.
The tool orientation can be programmed either as a direction vector or with rotary axis positions. No large radius circle interpolation is performed, if one of the G commands ORICON_{xx} or ORICURVE is active, or if polynomials for orientation angle (PO[PHI] and PO[PSI]) are programmed.
-

Example

In the example program below, a circle approached by a polygon definition is compressed. The tool orientation moves on the outside of the taper at the same time. Although the programmed orientation changes are executed one after the other, but in an unsteady way, the compressor function generates a smooth motion of the orientation.

Programming	Comment
DEF INT NUMBER=60	
DEF REAL RADIUS=20	
DEF INT COUNTER	
DEF REAL ANGLE	
N10 G1 X0 Y0 F5000 G64	
\$SC_COMPRESS_CONTUR_TOL=0.05	; Maximum deviation of the contour = 0.05 mm
\$SC_COMPRESS_ORI_TOL=5	; Maximum deviation of the orientation = 5 degrees
TRAORI	
COMPCURV	; The movement describes a circle generated from polygons. The orientation moves on a taper around the Z axis with an opening an- gle of 45 degrees.
N100 X0 Y0 A3=0 B3=-1 C3=1	
N110 FOR COUNTER=0 TO NUMBER	
N120 ANGLE=360*COUNTER/NUMBER	
N130 X=RADIUS*cos(angle) Y=RADIUS*sin(angle)	
A3=sin(angle) B3=-cos(angle) C3=1	
N140 ENDFOR	

3.9.7 Activating/deactivating the orientation characteristic (ORISON, ORISOF)

The "Smoothing of the orientation characteristic" is activated/deactivated in the part program using the commands of G group 61. The commands are modal.

Preconditions

- System with 5/6-axis transformation.
- Compressor function COMPCAD is active.

Syntax

```
ORISON
...
ORISOF
```

Meaning

ORISON:	Activating the orientation characteristic smoothing
ORISOF:	Deactivating the orientation characteristic smoothing

Example

Program code	Comment
...	
TRAORI()	; Activation of orientation transformation.
COMPCAD	; Activating the COMPCAD compressor function.
ORISON	; Activating orientation smoothing.
\$SC_ORISON_TOL=1.0	; Maximum angular deviation of the tool orientation = 1.0 degrees.
G91	
X10 A3=1 B3=0 C3=1	
X10 A3=-1 B3=0 C3=1	
X10 A3=1 B3=0 C3=1	
X10 A3=-1 B3=0 C3=1	
X10 A3=1 B3=0 C3=1	
X10 A3=-1 B3=0 C3=1	
X10 A3=1 B3=0 C3=1	
X10 A3=-1 B3=0 C3=1	
X10 A3=1 B3=0 C3=1	
X10 A3=-1 B3=0 C3=1	
...	
ORISOF	; Deactivation of orientation smoothing.
...	

The orientation is pivoted through 90 degrees on the XZ plane from -45 to +45 degrees. Due to the smoothing of the orientation characteristic the orientation is no longer able to reach the maximum angle values of -45 or +45 degrees.

3.9.8 Kinematic transformation

3.9.8.1 Activate face end transformation (TRANSMIT)

The front face transformation (TRANSMIT) is activated in the part program or synchronized action using the TRANSMIT statement.

Syntax

```
TRANSMIT  
TRANSMIT (<n>)
```

Meaning

TRANSMIT:	Activate TRANSMIT with the first TRANSMIT data set
TRANSMIT (n):	Activate TRANSMIT with the nth TRANSMIT data set

Note

A TRANSMIT transformation active in the channel is activated with:

- Deactivate transformation: TRAFOOF
- Activation of another transformation: E.g. TRACYL, TRAANG, TRAORI

3.9.8.2 Activate cylinder surface transformation (TRACYL)

The cylinder surface transformation (TRACYL) is activated in the part program or synchronized action using the TRACYL statement.

Syntax

```
TRACYL (<d>)  
TRACYL (<d>, <n>)  
TRACYL (<d>, <n>, <k>)
```

Meaning

TRACYL (<d>):	Activate TRACYL with the first TRACYL data set and working diameter <d>
TRACYL (<d>, <n>):	Activate TRACYL with the <n>th TRACYL data set and working diameter <d>
<d>:	Reference or working diameter The value must be greater than 1.
<n>:	TRACYL data set number (optional) Range of values: 1, 2
<k>:	The parameter <k> is only relevant for transformation type 514 k = 0: without groove side correction k = 1: with groove side correction If the parameter is not specified, then the parameterized basic position applies: \$MC_TRACYL_DEFAULT_MODE_<n> With <n> = TRACYL data set number

Note

A TRACYL transformation active in the channel is switched-off with:

- Deactivate transformation: TRAFOOF
- Activation of another transformation: E.g. TRAANG, TRANSMIT, TRAORI

Example

Program code	Comment
...	
N40 TRACYL(40.)	; Activate TRACYL with the first TRACYL data set and working diameter 40 mm.
...	

Further information

Program structure

A part program for milling a groove with TRACYL transformation 513 (TRACYL with groove side offset) generally comprises the following steps:

1. Select tool.
2. Select TRACYL.
3. Select suitable coordinate offset (frame).
4. Positioning.
5. Program OFFN.
6. Select TRC.


7. Approach block (position TRC and approach groove side).
8. Groove center line contour.
9. Deselect TRC.
10. Retraction block (retract TRC and move away from groove side).
11. Positioning.
12. TRAFOOF.
13. Reselect original coordinate shift (frame).

Contour offset (OFFN)

In order to mill grooves using TRACYL transformation 513, the center line of the groove and **half of the groove width** via the OFFN address are programmed in the part program.

To avoid damage to the groove side, OFFN acts only when the tool radius compensation is active.

It is possible to change OFFN within a part program. This allows the groove center line to be offset from the center:



- ① OFFN
- ② Programmed path

Note

OFFN should be at least as large as the tool radius to avoid damage occurring to the opposite side of the groove wall.

Note

OFFN acts differently with TRACYL than it does without TRACYL. Since, even without TRACYL, OFFN is included when TRC is active, OFFN should be reset to zero after TRAFOOF.

NOTICE**Effect of OFFN depends on the transformation type**

For TRACYL transformation 513 (TRACYL with groove side offset), half the groove width is programmed for OFFN.

For TRACYL transformation 512 (TRACYL with groove side offset), the value of OFFN acts as an allowance for the TRC.

Tool radius compensation (TRC)

For TRACYL transformation 513, the TRC is not taken into account relative to the groove side, but to the programmed center of the groove. In order that the tool travels to the left of the groove side, statement G42 must be programmed instead of G41 or the value of OFFN specified with a negative sign.

Tool diameter

With TRACYL and a tool whose diameter is less than the groove width, the same groove side geometry is not generated as with a tool whose diameter is the same as the groove width. To improve the precision, it is recommended that the tool diameter is selected to be only slightly less than the groove width.

Axis utilization**Note**

The following axes cannot be used as a positioning axis or a reciprocating axis:

- The geometry axis in the peripheral direction of the cylinder peripheral surface (Y axis).
- The additional linear axis for groove side compensation (Z axis).

3.9.8.3 Oblique plunge-cutting on grinding machines (G5, G7)

The G commands G7 and G5 are used to simplify programming of oblique plunge-cutting on grinding machines with "inclined axis (TRAANG)", so that when plunge cutting, only the inclined axis is traversed.

Only the required end position of the plunge-cutting motion has to be programmed in X and Z. For G7, starting from the actual position of the X axis, the NC calculates and approaches the programmed end position and angle α of the inclined axis.

The starting position is calculated from the point where the two straight lines intersect:

- Straight line parallel to the Z axis, at a distance from the actual position of the X axis
- Straight line parallel to the inclined axis through the programmed end position

With the subsequent G5, the inclined axis is traversed to the programmed end position.

Syntax


```
G7 <Endpos_X> <Endpos_Z>
```

G5 <Endpos_X>

Meaning

G7:	Calculate the starting position for the oblique plunge-cutting and approach.
G5:	Traverse the inclined axis to the programmed end position
<Endpos_X>:	X axis end position
<Endpos_Z>:	End position of the Z axis

Example



- ① Grinding wheel
- ② Workpiece
- ③ Parallel to the inclined axis through the programmed end position
- ④ Starting position
- ⑤ Plunge-cutting: Starting position
- ⑥ Plunge-cutting: End position
- ⑦ Parallel to the Z axis, at a distance from the actual position of the X axis
- X Geometry axis
- Z Geometry axis
- ZM Machine axis
- UM Machine axis

Figure 3-5 Programming an inclined axis

Program code	Comment
N... G18	; Select XZ plane.
N40 TRAANG (45.0)	; Activate TRAANG transformation, angle = 45°
N50 G7 X40 Z70 F4000	; Calculate the starting position and approach
N60 G5 X40 F100	; Traverse inclined axis to the end position.
N70 ...	

3.9.9 Cartesian PTP travel

3.9.9.1 Activating/deactivating Cartesian PTP travel (PTP, PTPG0, PTPWOC, CP)

The Cartesian point-to-point or PTP travel is activated/deactivated in the NC program using G group 49 commands.

The commands are modal. The default setting is travel with Cartesian path motion (CP).

Contrary to CP, for active PTP travel, only the Cartesian target point is transformed, and the machine axes are traversed in synchronism.

In order that the Cartesian target point can be uniquely converted into machine axis values, in addition to position and angular data, information is also necessary that identifies the axis positions. This data is retrieved from the adjustable addresses STAT (Page 681) and TU (Page 685).

Precondition

Transformation TRAORI, TRANSMIT, RCTRA or ROBX is active.

Syntax

```
PTP / PTPG0 / PTPWOC
...
CP
```

Meaning

PTP:	Activating point-to-point motion PTP The programmed Cartesian position in G0 and G1 blocks is approached with synchronous axis motion.
PTPG0:	Activating point-to-point motion PTPG0 Only in G0 blocks is the programmed Cartesian position approached with synchronous axis motion. In G1 blocks, a switchover is made to CP path motion.

PTPWOC:	Activate point-to-point movement PTPWOC (only possible if orientation transformation is active) Just the same as PTP, however, without any compensatory motion, which is caused by motion of rotary axes and orientation axes.
CP:	Deactivating point-to-point motion and activating path motion CP Cartesian path motion is executed with CP.

Note

PTPWOC

It does not make any sense to use PTPWOC in combination with a RCTRA or ROBX transformation!

Examples

See:

- Example 1: PTP travel of a 6-axis robot with ROBX transformation (Page 688)
- Example 2: PTP travel for generic 5-axis transformation (Page 689)
- Example 3: PTPG0 and TRANSMIT (Page 690)

3.9.9.2 Specify the position of the joints (STAT)

Position data with Cartesian coordinates and specification of the tool orientation are not sufficient to uniquely identify the machine position, as several joint positions are possible for the same tool orientation. Depending on the kinematics involved, there can be as many as 8 different joint positions. These different joint positions are transformation-specific.

In an order to avoid any ambiguity, the joint positions are specified under the STAT address.

Note

The control takes into account programmed STAT values only for PTP motions. They are ignored with CP motions because a change of position is not normally possible while traversing with an active transformation. When traversing with active CP, the position for the target point is taken from the starting point.

Syntax


STAT=<Value>

Meaning

STAT:	Adjustable address to specify joint positions
<Value>:	Binary or decimal value Contains one bit for each possible position. The significance of the bits is defined by the particular transformation.



3.9 Transformations

The use of STAT is to be illustrated by the example of a 6-axis articulated robot with milling spindle. The kinematic transformation is to be realized using the ROBX robot transformation (precondition: Compile cycle "RMCC/ROBX Transformation Extended Robotics" is loaded and active).



Axes A1, A2 and A3 are the main axes of the articulated robot. The axes A4, A5 and A6, which are also designated as head or hand/wrist axes, are positioned in the working area with the main axes. The additional motion options of the hand/wrist axes enable the milling spindle to be orientated in space as required for the particular machining task. Various articulated joint positions are possible to achieve the same tool orientation.

The articulated joint positions required for machining are selected by programming bit 0 ... 2 of the adjustable STAT address:

Bit 0	Position of the intersection points of the hand/wrist axes (A4, A5, A6)		 <p>Example: The intersection point of the hand/wrist axes lies in the basic range</p>
	= 0	Basic range (shoulder right) The robot is in the basic range if the X value of the intersection point of the hand/wrist axes is positive in relation to the A1 coordinate system.	
	= 1	Overhead range (shoulder left) The robot is in the overhead range if the X value of the intersection point of the hand/wrist axes is negative in relation to the A1 coordinate system.	
Bit 1	Position of axis 3		 <p>Offset between A3 and A4</p>
	= 0	A3 < 0° (elbow down)	
	= 1	A3 ≥ 0° (elbow up)	
Note: For robots with an offset between axes 3 and 4, the angle at which the value of bit 1 changes depends on the magnitude of this offset.			
Bit 2	Position of axis 5		
	= 0	A5 ≥ 0° (no handflip)	
	= 1	A5 < 0° (handflip)	


Program example:

Program code	Comment
...	
N14 T="T8MILLD20" D1	; \$TC_DP3[1,1]=132.95


3.9 Transformations

Program code	Comment
N16 ORIMKS	
N17 G1 PTP X1665.67 Y0 Z1377.405 A=0 B=0 C=0 STAT=... F2000	The STAT value defines the articulated joint positions (see below)
...	


STAT=1 ('B001')
 → Shoulder left
 → Elbow down
 → No handflip




STAT=2 ('B010')
 → Shoulder right
 → Elbow up
 → No handflip



STAT=5 ('B101')
 → Shoulder left
 → Elbow down
 → Handflip



STAT=6 ('B110')
 → Shoulder right
 → Elbow up
 → Handflip



TRANSMIT

For TRANSMIT, the STAT address is used to initiate the equivocality regarding the pole.

The following applies if the rotary axis must rotate through 180° or the contour for CP would go through the pole:

Bit 0	Only relevant for \$MC_TRANSMIT_POLE_SIDE_FIX_1/2 = 1 or 2:	
	= 0	Rotary axis traverses through $+180^\circ$ or rotates clockwise.
	= 1	Rotary axis rotates through -180° or rotates counterclockwise.
Bit 1	Only relevant for \$MC_TRANSMIT_POLE_SIDE_FIX_1/2 = 0:	
	= 0	The axis traverses through the pole. The rotary axis does not rotate.
	= 1	The axis rotates around the pole. Bit 0 of STAT is relevant.

3.9.9.3 Specify the sign of the axis angle (TU)

In order that rotary axes can also approach axis angles exceeding $+180^\circ$ or less than -180° without requiring a special traversing strategy (e.g. intermediate point), the sign of the axis angle must be specified under the adjustable address TU.

Note

The control only takes into account programmed TU values for PTP motion. CP motion is ignored.


Syntax

TU=<Value>

Meaning

TU:	Adjustable address to specify axis angle signs		
<Value>:	Binary or decimal value		
	For each axis that is involved in the transformation, there is a bit that indicates the sign of the axis angle (θ), and therefore the traversing direction.		
	Bit	= 0	Axis angle sign: +
	= 1	Axis angle sign: -	Axis angular range: $-360^\circ < \theta < 0^\circ$

Example: 6-axis articulated robot



Bit	Meaning	Value	Axis angle sign	Axis angle
Bit 0 ¹⁾	Sign for the axis angle of A1	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$
Bit 1 ¹⁾	Sign for the axis angle of A2	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$
Bit 2 ¹⁾	Sign for the axis angle of A3	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$
Bit 3 ¹⁾	Sign for the axis angle of A4	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$
Bit 4 ¹⁾	Sign for the axis angle of A5	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$

Bit	Meaning	Value	Axis angle sign	Axis angle
Bit 5 ¹⁾	Sign for the axis angle of A6	= 0	+	$\geq 0^\circ$
		= 1	-	$< 0^\circ$

¹⁾ The actual TU bit numbers obtained from the channel axis numbers of the robot axes! In the example, robot axes (A1 to A6) are the first six axes in the channel; as a consequence, TU bits 0 ... 5 are used. For another channel axis assignment of the robot axes, the TU bit numbers of the robot axes would correspondingly change (e.g.: robot axes are the 3rd to 8th channel axis, i.e. TU bits 2 ... 7 are used for the robot axes).

TU=19 (corresponds to TU="B010011) would therefore signify:

Bit	Value		Axis angle
0	= 1	①	$\theta_{A1} < 0^\circ$
1	= 1	①	$\theta_{A2} < 0^\circ$
2	= 0	①	$\theta_{A3} \geq 0^\circ$
3	= 0	①	$\theta_{A4} \geq 0^\circ$
4	= 1	①	$\theta_{A5} < 0^\circ$
5	= 0	①	$\theta_{A6} \geq 0^\circ$

Note

In the case of axes with a traversing range $> \pm 360^\circ$, the axis always moves along the shortest path because the axis position cannot be specified uniquely by the TU information.


If no TU is programmed for a position, then depending on MD30455 \$MA_MISC_FUNCTION_MASK, the shorter or longer path is traversed (see Chapter "Taking into account the software limits for PTP travel" in the Extended Functions Function Manual).

TRANSMIT

For PTP travel with TRANSMIT active, the address of TU has no meaning!

Example

The rotary axis position shown in the following diagram can be approached in the negative or positive direction. The angular position is programmed under address A1. The traversing direction is only absolutely clear when TU is specified.



3.9.9.4 Example 1: PTP travel of a 6-axis robot with ROBX transformation

In the following application example, Cartesian PTP travel and the associated NC commands are shown in the form of an example.




Figure 3-6 6-axis articulated robot with milling spindle

```

N1 G90
N2 T="T8MILLD20" D1 M6
N3 TRAORI
; $P_UIFR[1]=CTRANS(X,1500,Y,0,Z,400):CROT(X,0,Y,0,Z,-90)
N4 G54
N5 M3 S20000
N6 ORIWKS
N7 ORIVIRT1
N8 CYCLE832(0.01,_FINISH,1)
;HOME
N9 TRAFOOF
N10 G0 RA1=0.0000 RA2=-90.0000 RA3=90.0000 A=0.0000 B=90.0000 C=0.0000
N11 TRAORI

```



```

N12 G54
N13 G0 PTP X1369.2426 Y956.7528 Z502.5517 A=135.5761 B=-33.2223
C=161.1435 STAT='B010' TU='B001011'
N14 G0 X1355.1242 Y1014.9394 Z424.9695 A=135.8491 B=-33.1439
C=160.9941 STAT='B010' TU='B001011'
N15 G1 CP X1354.8361 Y1016.1269 Z423.3862 A=136.0635 B=-33.0819 C=160.8770
F1000
N16 G1 X1336.4283 Y1016.1269 Z426.6311 A=136.0484 B=-32.2151 C=160.9643
F2000
N17 G1 X1317.9831 Y1016.1269 Z429.6730 A=136.0175 B=-31.3394 C=161.0655
;HOME
N18 TRAFOOF
N19 G0 RA1=0.0000 RA2=-90.0000 RA3=90.0000 A=0.0000 B=90.0000 C=0.0000
N20 M30

```

3.9.9.5 Example 2: PTP travel for generic 5-axis transformation

Assumption: Right-angled CA kinematics used as basis.


Program code	Comment
TRAORI	;Transformation CA kinematics ON
PTP	; Activate PTP traversal
N10 A3=0 B3=0 C3=1	; rotary axis positions C=0 A=0
N20 A3=1 B3=0 C3=1	; rotary axis positions C=90 A=45
N30 A3=1 B3=0 C3=0	; rotary axis positions C=90 A=90
N40 A3=1 B3=0 C3=1 STAT=1	; rotary axis positions C=270 A=-45

Select clear approach position of rotary axis position:

In block N40, the rotary axes – as a result of the programming of **STAT=1** – travel the longer distance from their start point (C=90, A=90) to the end point (C=270, A=-45). On the other hand, with **STAT=0**, the rotary axes would travel along the shortest path to the end point (C=90, A=45).


3.9.9.6 Example 3: PTPG0 and TRANSMIT

Traversing around the pole with PTPG0 and TRANSMIT



Program code	Comment
N001 G0 X30 Z0 F10000 T1 D1 G90	;Initial setting absolute dimension
N002 SPOS=0	
N003 TRANSMIT	;TRANSMIT transformation
N010 PTPG0	; for each G0 block, automatically PTP - and then CP again.
N020 G0 X30 Y20	
N030 X-30 Y-20	
N120 G1 X30 Y20	
N110 X30 Y0	
M30	

Traversing from the pole with PTPG0 and TRANSMIT



Programming	Comment
N001 G0 X90 Z0 F10000 T1 D1 G90	;Initial setting
N002 SPOS=0	
N003 TRANSMIT	;TRANSMIT transformation
N010 PTPG0	; for each G0 block, automatically PTP - and then CP again.
N020 G0 X90 Y60	
N030 X-90 Y-60	
N040 X-30 Y-20	
N050 X10 Y0	
N060 X0 Y0	
N070 X-20 Y2	
N170 G1 X0 Y0	
N160 X10 Y0	
N150 X-30 Y-20	
M30	

3.9.10 Constraints when selecting a transformation

Function

Transformations can be selected via a part program or MDA. Please note:

- No intermediate movement block is inserted (chamfer/radii).
- Spline block sequences must be excluded; if not, a message is displayed.
- Fine tool compensation must be deselected (FTOCOF); if not a message is displayed.

- Tool radius compensation must be deselected (G40); if not a message is displayed.
- An activated tool length offset is included in the transformation by the control.
- The control deselects the current frame active before the transformation.
- The control deselects an active operating range limit for axes affected by the transformation (corresponds to WALIMOF).
- Protection zone monitoring is deselected.
- Continuous path control and rounding are interrupted.
- All the axes specified in the machine data must be synchronized relative to a block.
- Axes that are exchanged are exchanged back; if not, a message is displayed.
- A message is output for dependent axes.

Tool change

Tools may only be changed when the tool radius compensation function is deselected.

A change in tool length offset and tool radius compensation selection/deselection must not be programmed in the same block.

Frame change

All statements, which refer exclusively to the base coordinate system, are permissible (FRAME, tool radius compensation). However, a frame change with G91 (incremental dimension) – unlike with an inactive transformation – is not handled separately. The increment to be traveled is evaluated in the workpiece coordinate system of the new frame – regardless of which frame was effective in the previous block.

Exceptions

Axes affected by the transformation cannot be used

- as a preset axis (alarm),
- for approaching a checkpoint (alarm),
- for referencing (alarm).

3.9.11 Deselecting a transformation (TRAFOOF)

The predefined TRAFOOF procedure deactivates all active transformations and frames.

Note

For deselecting the transformation, the same secondary conditions (Page 691) apply as for selecting.

Frames required after this must be activated by renewed programming.

Syntax

```
...  
TRAFOOF
```

Meaning

TRAFOOF:	Deactivating all active transformations/frames
----------	--

3.10 Kinematic chains

3.10.1 Deletion of components (DELOBJ)

The `DELOBJ()` function "deletes" components by resetting the assigned system variables to their default values:

- Elements from kinematic chains
- Protection areas, protection area elements and collision pairs
- Transformation data

Syntax

```
[<RetVal>=] DELOBJ (<CompType> [ , , , <NoAlarm> ] )  
[<RetVal>=] DELOBJ (<CompType> , <Index1> [ , , <NoAlarm> ] )  
[<RetVal>=] DELOBJ (<CompType> [ , <Index1> ] [ , <Index2> ] [ , <NoAlarm> ] )
```

Meaning

DELOBJ:	Deletion of elements from kinematic chains, protection areas, protection area elements, collision pairs and transformation data
<CompType>:	Component type to be deleted
	Data type: STRING
	Value: "KIN_CHAIN_ELEM" Meaning: System variables of all kinematic elements: \$NK_...
	Value: "KIN_CHAIN_SWITCH" Meaning: System variable \$NK_SWITCH[<i>]]
	Value: "KIN_CHAIN_ALL" Meaning: All kinematic elements and switches. Is the same as the successive call of DELOBJ with "KIN_CHAIN_ELEM" and "KIN_CHAIN_SWITCH"
	Value: "PROT_AREA" Meaning: System variables of the protection areas: <ul style="list-style-type: none"> • \$NP_PROT_NAME • \$NP_CHAIN_NAME • \$NP_CHAIN_ELEM • \$NP_1ST_PROT
	Value: "PROT_AREA_ELEM" Meaning: System variables of the protection area elements of machine protection areas and/or automatic tool protection areas: <ul style="list-style-type: none"> • \$NP_NAME • \$NP_NEXT • \$NP_NEXTP • \$NP_COLOR • \$NP_D_LEVEL • \$NP_USAGE • \$NP_TYPE • \$NP_FILENAME • \$NP_PARA • \$NP_OFF • \$NP_DIR • \$NP_ANG
	Value: "PROT_AREA_COLL_PAIRS" Meaning: System variables of the collision pairs: <ul style="list-style-type: none"> • \$NP_COLL_PAIR • \$NP_SAFETY_DIST
	Value: "PROT_AREA_ALL" Meaning: All protection areas, protection area elements and collision pairs (system variable \$NP_...) Is the same as the successive call of DELOBJ with "PROT_AREA," "PROT_AREA_ELEM," and "PROT_AREA_COLL_PAIRS"
	Value: "TRAFO_DATA" Meaning: System variables of all transformations \$NT_...

<Index1>:	Index of the first component to be deleted (optional)	
	Data type:	INT
	Default value:	-1
	Range of values:	$-1 \leq x \leq$ (maximum number of configured components -1)
	Value	Meaning
	0, 1, 2, ...	Index of the component to be deleted.
	-1	All components of the specified type are deleted. <Index2> is not evaluated.
<Index2>:	Index of the last components to be deleted (optional) If <Index2> is not programmed, only the system variables of the component referenced in <Index1> are deleted.	
	Data type:	INT
	Default value:	Only the system variables of the component referenced in <Index1> are deleted.
	Range of values:	$\langle \text{Index1} \rangle < x \leq$ (max. number of configured components -1)
<NoAlarm>:	Alarm suppression (optional)	
	Data type:	BOOL
	Default value:	FALSE
	Value	Meaning
	FALSE	In the event of an error ($\langle \text{RetVal} \rangle < 0$), program processing is stopped and an alarm displayed.
TRUE	In the event of an error, the program processing is not stopped and no alarm displayed. Application: User-specific reaction corresponding to the return value	
<RetVal>:	Function return value	
	Data type:	INT
	Range of values:	0, -1, -2, ... -7
	Value	Meaning
	0	No error occurred.
	-1	Call of the function without parameters. At least parameter <CompType> must be specified.
	-2	<CompType> identifies an unknown component
	-3	<Index1> is less than -1
	-4	<Index1> is greater than the configured number of components
	-5	<Index1> has a value not equal to -1 when deleting a component group
	-6	<Index2> is less than <Index1>
-7	<Index2> is greater than the configured number of components	

3.10.2 Index determination by means of names (NAMETOINT)

User-specific names are entered in the system variable arrays of type STRING. Based on the identifier of the system variables and the name, the `NAMETOINT()` function determines the index value belonging to the name under which it is stored in the system variable array.

Syntax

```
<RetVal> = NAMETOINT (<SysVar>, <Name> [, <NoAlarm>])
```

Meaning

NAMETOINT:	Determining the system variable index	
<SysVar>:	Name of the system variable array of type STRING	
	Data type:	STRING
	Range of values:	Name of all NC system variable arrays of type STRING
<Name>:	Character string or name for which the system variable index is to be determined.	
	Data type:	STRING
<NoAlarm>:	Alarm suppression (optional)	
	Data type:	BOOL
	Default value:	FALSE
	Value	Meaning
	TRUE	In the event of an error, the program processing is not stopped and no alarm displayed. Application: User-specific reaction corresponding to the return value
FALSE	In the event of an error (<RetVal> < 0), program processing is stopped and an alarm displayed.	
<RetVal>:	System variable index or error message	
	Data type:	INT
	Range of values:	$-1 \leq x \leq (\text{max. number of configured components} - 1)$
	Value	Meaning
	≥ 0	The sought name has been found under the specified system variable index.
-1	The sought name has not been found or an error has occurred.	

Example

Program code	Comment
DEF INT INDEX	
\$NP_PROT_NAME[27]="Cover"	
...	
INDEX = NAMETOINT("\$NP_PROT_NAME", "Cover")	; INDEX == 27

3.11 Collision avoidance with kinematic chains

Note

Protection areas

The protection areas specified in the following chapters refer to the "Geometric machine modeling" function.

References:

Monitoring and Compensation Function Manual, Chapter "Geometric Machine Modeling"

3.11.1 Check for collision pair (COLLPAIR)

The COLLPAIR () function determines whether two protection areas form a collision pair.

Syntax

```
[<RetVal> =] COLLPAIR (<Name_1>, <Name_2>[, <NoAlarm>])
```

Meaning

COLLPAIR:	Check whether part of a collision pair			
<RetVal>:	Function return value			
	Data type:	INT		
	Value:	≥ 0	The two protection zones form a collision pair. Return value == collision pair index m (see \$NP_COLL_PAIR)	
		-1	Either two strings have not been specified or at least one of the two is the zero string.	
		-2	The protection zone specified in the first parameter has not been found.	
		-3	The protection zone specified in the second parameter has not been found.	
		-4	Neither of the two specified protection zones has been found.	
-5	Both specified protection zones have been found, but not together in a collision pair.			
<Name_1>:	Name of the first protection zone			
	Data type:	STRING		
	Range of values:	Parameterized protection zone names		
<Name_2>:	Name of the second protection area			
	Data type:	STRING		
	Range of values:	Parameterized protection zone names		

<NoAlarm>:	Alarm suppression (optional)		
	Data type:	BOOL	
	Value:	FALSE (Default)	In the event of an error (<RetVal> < 0), the program processing is stopped and an alarm displayed.
TRUE		In the event of an error, the program processing is not stopped and no alarm displayed. Application: User-specific reaction corresponding to the return value	

3.11.2 Request recalculation of the machine model of the collision avoidance (PROTA)

If system variables of the kinematic chain \$NK_..., the geometric machine modeling or the collision avoidance \$NP_... are written in the part program, the PROTA procedure must subsequently be called so that the change becomes effective in the NC-internal machine model of the collision avoidance.

Syntax

```
PROTA[ (<Par> ) ]
```

Meaning

PROTA:	Request recalculation of the machine model of the collision avoidance		
	<ul style="list-style-type: none"> • Triggers a preprocessing stop. • Must be alone in the block. 		
<Par>:	Parameter (optional)		
	Data type:	STRING	
	Value:	---	No parameters. The machine model is recalculated. The states of the protection areas are retained.
"R"		The machine model is recalculated. The protection areas are set to their initialization status corresponding to \$NP_INIT_STAT.	

Supplementary conditions

Simulation

The PROTA procedure must not be used in part programs in conjunction with the simulation (simNC).

Example: Avoiding the PROTA call while the simulation is active.

Program code	Comment
...	
IF \$P_SIM == FALSE	; IF simulation not active

3.11 Collision avoidance with kinematic chains

Program code	Comment
PROTA	THEN recalculate collision model
ENDIF	; ENDIF
...	

See also

Setting the protection zone status (PROTS) (Page 700)

3.11.3 Setting the protection zone status (PROTS)

The PROTS () procedure sets the state of protection areas to the specified value.

Syntax

PROTS (<State> [, <Name_1>, ..., <Name_n>])

Meaning

PROTS:	Sets the state of protection areas			
	<ul style="list-style-type: none"> Must be alone in the block. 			
<State>:	Status to which the specified protection zones are to be set			
	Data type:	CHAR		
	Value:	"A" or "a"	Status: Active	
		"I" or "i"	Status: Inactive	
		"P" or "p"	Status: Preactivated or PLC-controlled ¹⁾	
"R" or "r"		Status: NC-internal value of the initialization status ²⁾		
<Name_1> ... <Name_n>:	Name of one or more protection areas that are to be set to the specified status (optional)			
	If no name is specified, the specified status is set for all defined protection zones.			
	Data type:	STRING		
	Range of values:	Parameterized protection zone names		
	<p>Note</p> <p>The maximum number of protection areas that can be specified as parameters depends only on the maximum possible number of characters per program line.</p>			
<p>¹⁾ The activation/deactivation is performed via: DB10.DBX234.0 - DBX241.7</p> <p>²⁾ The status is set to the NC-internal value of the initialization status, i.e. to the value that the system variable \$NP_INIT_STAT had at the time of the last PROTA () (Page 699) call.</p>				

3.11.4 Determining the clearance of two protection zones (PROTD)

The PROTD () function calculates the clearance of two protection areas.

Function properties:

- The clearance calculation is performed independent of the protection area status (activated, deactivated, preactivated).
- To calculate the clearance of two protection areas, only protection area elements are used, which are marked with \$NP_USAGE = "C" or "A". Protection area elements of the protection area, which are marked with \$NP_USAGE = "V", are not taken into consideration.
- Protection areas, where all protection area elements of the protection area are marked with \$NP_USAGE = "V", cannot be used for the clearance calculation.
- The clearance calculation is performed with the positions valid at the end of the previous block.
- Overlays that are included in the main run calculation (e.g. DRF offset or external zero offset) are included in the clearance calculation with the values valid at the function **interpretation time**.

Note

Synchronization

When using the `PROTD()` function, it is the sole responsibility of the user to synchronize the main run and preprocessing, if required, with the `STOPRE` preprocessing stop.

Collision

If there is a collision between the specified protection areas, the function returns a clearance of 0.0. There is a collision if both the protection areas touch or intersect each other.

The safety clearance for the collision check (MD10622 \$MN_COLLISION_SAFETY_DIST) is not taken into account in the clearance calculation.

Syntax

```
[<RetVal> =] PROTD([<Name_1>],[<Name_2>],VAR <Vector>[,<System>])
```

Meaning

PROTD:	Calculates the clearance of the two specified protection areas.	
	<ul style="list-style-type: none"> • Must be alone in the block. 	
<RetVal>:	Function return value: Absolute clearance value of the two protection areas or 0.0 with collision (see above: Collision paragraph)	
	Data type:	REAL
	Range of values:	$0.0 \leq x \leq +\text{max. REAL value}$
<Name_1>, <Name_2>:	Names of the two protection areas whose clearance is to be calculated (optional)	
	Data type:	STRING
	Range of values:	Parameterized protection area names
	Default value:	"" (empty string)
	If no protection areas have been specified, the function calculates the current smallest clearance from all the activated and preactivated protection areas in the collision model.	

3.11 Collision avoidance with kinematic chains

<Vector>:	Return value: 3-dimensional clearance vector from protection area <Name_2> to protection area <Name_1> with:	
	<ul style="list-style-type: none"> • <Vector>[0]: X coordinate in the world coordinate system • <Vector>[1]: Y coordinate in the world coordinate system • <Vector>[2]: Z coordinate in the world coordinate system 	
	For collision: <Vector> == zero vector	
Data type:	VAR REAL [3]	
Range of values:	<Vector> [n]: $0.0 \leq x \leq \pm\text{max. REAL value}$	
<System>:	Measuring system (inch/metric) for clearance and clearance vector (optional)	
	Data type:	BOOL
	Value:	FALSE (Default)
TRUE		Measuring system corresponding to the set basic system: MD52806 \$MN_ISO_SCALING_SYSTEM

3.12 Transformation with kinematic chains

3.12.1 Activating a transformation (TRAFOON)

A transformation defined with kinematic chains is activated with the predefined TRAFOON procedure. The call must be alone in a block.

Note

Alternatively, a transformation defined with kinematic chains can also be activated via conventional NC commands, such as TRAORI or TRANSMIT. For this purpose, an appropriate value, not equal to zero, must be entered in the \$NT_TRAFO_INDEX system variable.

For further information on \$NT_TRAFO_INDEX see "System Variables List Manual".

Syntax

```
TRAFOON (<Trafoname>, <Diameter>, <k>)
```

Meaning

TRAFOON:	Procedure for activating a transformation defined with kinematic chains		
<Trafoname>:	Name of the transformation data set		
	Data type:	STRING	
	Range of values:	All names of transformation data sets defined via \$NK_NAME	
	Note: The name of the transformation data set must be unique. It must only occur once in \$NT_NAME.		
<Diameter>:	Reference or working diameter (TRACYL only)		
	Data type:	REAL	
	The value must be > 1.		
<k>:	Defines the use of the groove side offset (TRACYL only).		
	Data type:	BOOL	
	Value:	FALSE	Without groove side offset
		TRUE	With groove side offset
	Corresponds to the TRACYL transformation type 514 (groove side offset can be programmed). If <k> is not specified, the parameterized setting of bit 10 in \$NT_CNTRL[<n>] applies.		

Example

Program code	Comment
TRAFOON["Trans_1"]	Activates the transformation with the name Trans_1.

3.12.2 Modifying the orientation transformation after the machine measurement (CORRTRAFO)

For machines with orientation transformations that were defined by means of kinematic chains, the user can use the predefined CORRTRAFO function in order to modify the offset vectors or the direction vectors of the orientation axes in the kinematic model of the machine after a machine measurement.

Note

The correction values written with the CORRTRAFO function are not immediately effective in the transformation. The correction values do not become effective until after a transformation deselection, NEWCONF and transformation selection.

Syntax

```
<Corr_Status> = CORRTRAFO (<Corr_Vect>, <Corr_Index>, <Corr_Mode>,  
[ <No_Alarm>])
```


Meaning

CORRTRAF0:	Function call
------------	---------------

3.12 Transformation with kinematic chains

<code><Corr_Status></code> :	Function return value		
	Data type:	INT	
	Values:	0	The function was executed without an error.
		1	No transformation is active.
		2	The currently active transformation is not an orientation transformation.
		3	The active orientation transformation was not defined with kinematic chains.
		10	The <code><Corr_Index></code> call parameter is negative.
		11	The <code><Corr_Mode></code> call parameter is negative.
		12	Invalid reference to a section of a subchain (units position of <code><Corr_Index></code>). The value must not be greater than the number of orientation axes in the subchain.
		13	Invalid reference to the orientation axis of a subchain (units position of <code><Corr_Index></code>). The value must be less than the number of orientation axes in the subchain.
		14	Invalid reference to a subchain (tens position of <code><Corr_Index></code>). Only the values 0 and 1 are permissible (reference to part or tool chain). This error number occurs if the subchain to which <code><Corr_Index></code> refers does not exist.
		15	There is no correction element in the section referred to with the <code><Corr_Index></code> parameter (<code>\$NT_CORR_ELEM_P</code> or <code>\$NT_CORR_ELEM_T</code>).
		20	Invalid correction mode (units position of <code><Corr_Mode></code>). Only the values 0 and 1 are permissible.
		21	Invalid correction mode (tens and/or hundreds position of <code><Corr_Mode></code>). Only the units position can be not equal to zero when writing an axis direction.
		30	The hundreds position of <code><Corr_Mode></code> is invalid. Only the values 0 and 1 are permissible.
31	The thousands position of <code><Corr_Mode></code> is invalid. Only the values 0 and 1 are permissible.		
40	The direction vector that is to be taken as axis direction is the zero vector. This error can only happen if the thousands position of <code><Corr_Mode></code> is equal to 0. If the thousands position of this parameter is equal to 1 (monitoring of the maximum correction deactivated), the zero vector can also be written.		
41	For the correction of an offset vector, the difference to the current value in at least one coordinate is greater than the maximum value specified by the setting data SD41610 <code>\$SN_CORR_TRAFO_LIN_MAX</code> . The <code><Corr_Vect></code> parameter will be overwritten by an error vector. This also applies when the processing is aborted with alarm (see <code><No_Alarm></code> parameter). In the components whose correction value has exceeded the permissible limit, the error vector has the difference, with the correct sign, between the determined correction value and the limit. The content of the components that have not exceeded their limit is zero.		

		42	For the correction of a direction vector, the angular displacement compared to the current direction is greater than the maximum value specified by the setting data SD41611 \$SN_CORR_TRAFO_DIR_MAX.
		43	The attempt to write a system variable was rejected because of missing write rights.
<Corr_Vect>:	Correction vector The content of the correction vector is defined by the following parameters <Corr_Index> and <Corr_Mode>. If <Corr_Status> = 41, the content of the vector is overwritten (see above).		
	Data type:	REAL	
<Corr_Index>:	Section whose correction element is to be modified / index of the orientation axis whose direction vector is to be modified		
	Data type:	INT	
	The <Corr_Index> parameter is decimal coded (units to tens position):		
	Units position:	Contains the index of the section or the orientation axis in the sub-chain.	
	Tens position:	Refers to the subchain.	
		0x	Workpiece chain
		1x	Tool chain

3.12 Transformation with kinematic chains

<Corr_Mode> :	Correction mode		
	Data type:	INT	
	The <Corr_Index> parameter is decimal coded (units to thousands position):		
	Units position:	Specifies which element is to be corrected.	
		xxx0	Correction of a linear offset vector
		xxx1	Correction of the direction vector of an orientation axis
	Tens position:	Specifies how the correction element to which the content of <Corr_Index> refers, is to be modified.	
		xx0x	The correction vector is written immediately to the correction element. This variant can be used to immediately write the correction element without the index <n> of the relevant system data (\$NK_OFF_DIR[<n>, ...]) having to be known.
		xx1x	As 0, but with the difference that the transferred correction value is interpreted in world coordinates. A difference between variants 0 and 1 can always occur when the kinematic chain in the initial state (positions of all orientation axes equal to 0) contains other rotations.
		xx2x	As 1, but with the difference that the correction value refers to the entire section, i.e. a value is entered in the correction element so that the entire section reaches the length defined by the correction value.
		Note: The values 1 and 2 are not permissible when writing the direction vector of an orientation axis.	
	Hundreds position:	Specifies how the content of the <Corr_Vect> parameter is to be interpreted.	
		x0xx	The transferred correction vector <Corr_Vect> contains the entire new length of the correction element or the section to which the <Corr_Index> in conjunction with the tens position of <Corr_Mode> refers (absolute correction).
		x1xx	The transferred correction vector <Corr_Vect> only contains the difference compared to the current length of the correction element or the section to which the <Corr_Index> in conjunction with the tens position of <Corr_Mode> refers (incremental correction).
		Note: For the correction of the direction vector of an orientation axis, the content of the hundreds position must be 0.	
	Thousands position:	Specifies whether the correction is to be limited by the following maximum value:	
		<ul style="list-style-type: none"> • SD41610 \$SN_CORR_TRAFO_LIN_MAX <li style="text-align: center;">or • SD41611 \$SN_CORR_TRAFO_DIR_MAX 	
		0xxx	Monitoring of the maximum correction is active.
		1xxx	Monitoring of the maximum correction is not active.

<No_Alarm>:	Behavior in the event of an error (return value > 0) (optional)		
	Data type:	BOOL	
	Value:	FALSE (default)	In the event of an error, the program processing is stopped and alarm 14103 is displayed.
TRUE		In the event of an error, the program processing is not stopped and no alarm is displayed. Application: User-specific reaction corresponding to the return value	

Note

In the event of an error when the function is called, either an alarm is output or an error number returned (see <No_Alarm> parameter), so that the user can respond in a suitable way to the error state. The cause of the error is described in more detail through an alarm parameter. An error number returned instead of an alarm is identical to the alarm parameter.

Further information on CORRTRAF0

The kinematic structure of a machine with orientation transformation is described by one or two kinematic chains (subchains), starting from the zero point of the world coordinate system. One of the two chains, the **tool chain**, ends at the reference point of the tool, the other chain, the **workpiece chain** ends in the zero point of the basic coordinate system.

The CORRTRAF0 function writes lever arm lengths and axis directions on machines with an orientation transformation in special correction elements. A kinematic chain is described, for example, with elements of the type OFFSET, which are defined via \$ NK_TYPE.

CORRTRAF0 works with sections

The two subchains can each be divided into a maximum of four sections:

- Section 1 begins at the starting point of the chain and ends at the first orientation axis.
- Section 2 is the section between orientation axis 1 and orientation axis 2.
- Section 3 is the section between orientation axis 2 and orientation axis 3.
- Section 4 is the section between orientation axis 3 and the end of the tool or workpiece chain.

Each section may contain constant chain elements of the type OFFSET or ROT_CONST.

The following figure shows an orientation transformation with 2 orientation axes.




Figure 3-7 CORRTRAF0 example

The sections are clearly defined: If you run through the kinematic subchain from the starting point to the end point, the first section has the index 0, the next the index 1, and so on. The index of the last section is then always equal to the number of orientation axes.

Correction elements

A reference can be made to a constant kinematic chain element (chain element of the type $\$NK_TYPE[\langle n \rangle] = "OFFSET"$) in each section with the $\$NT_CORR_ELEM_T[\langle n \rangle, 0 \dots 3]$ or $\$NT_CORR_ELEM_P[\langle n \rangle, 0 \dots 3]$ system variables. The correction values that were determined during the machine measurement are written to these elements with the CORRTRAF0 function.

Example with transformation index = 1:

- $\$NT_CORR_ELEM_T[1,0] = "C_AXIS_OFFSET"$; Offset of the C axis (orientation axis 1) in section 1 is defined as correction element.
- $\$NT_CORR_ELEM_T[1,1] = "B_AXIS_OFFSET"$; Offset of the B axis (orientation axis 2) in section 2 is defined as correction element.
- $\$NT_CORR_ELEM_T[1,2] = "BASE_TOOL_OFFSET"$; Offset of the B axis from the tool reference point in section 3 is defined as correction element.

The sequence of the references in $\$NT_CORR_ELEM_T/P[\langle n \rangle, 0 \dots 3]$ must correspond to the sections described above, i.e. only one chain element can be in $\$NT_CORR_ELEM_T/P[\langle n \rangle, 0]$ which is before the first orientation axis, etc.

The CORRTRAF0 function writes the values determined by measuring the machine into the correction elements defined in this way. The modification of the correction values is defined in CORRTRAF0 via the $\langle Corr_Mode \rangle$ parameter.

Closing a chain

If bit 7 or bit 8 are set in the $\$NT_CNTRL[\langle n \rangle]$ system variable, additional constant chain elements that establish a connection from the end point of the chain to the machine zero point are automatically inserted internally at the end of the workpiece chain (bit 7) or before the starting point of the tool chain (bit 8) ("close chain").

These automatically inserted elements cannot be written externally, only read (see the $\$AC_TRAF0_CORR_ELEM_P/T$ system variables).

Point to close the tool chain

If the `$NT_CLOSE_CHAIN_T` system variable is not empty, the tool chain is not closed at the end point of the chain, but rather at the end point of the designated chain element. Other chain elements that are behind this point result in a corresponding work offset when the transformation is activated.

Index of an orientation axis

In addition to the constants offsets between the orientation axes, the direction vectors of the orientation axes can also be written with the `CORRTRAFO` function. The index of an orientation axis is the index that results when the kinematic subchain is run through from the origin to the end, where the count starts at zero. The index of an orientation axis is therefore always the same as the index of the preceding section.

The index of an orientation axis can also be determined with the `$AC_TRAFO_ORIAX_LOC` system variable.

Maximum permissible change of a chain element

The maximum permissible change of a chain element can be limited by the two setting data `SD41610 $SN_CORR_TRAFO_LIN_MAX` for offset vectors and `SD41611 $SN_CORR_TRAFO_DIR_MAX` for direction vectors of the orientation axes. `SD41610 $SN_CORR_TRAFO_LIN_MAX` specifies the maximum amount by which each individual vector component can be changed with regard to its reference value. `SD41611 $SN_CORR_TRAFO_DIR_MAX` specifies the maximum angle by which the direction of the axis vector can be changed with regard to its reference value. The reference value is always the corresponding value that is active in the transformation that is active when `CORRTRAFO` is called. This means that the changed content of the kinematic data may have no effect on the method of operation of the `CORRTRAFO` function after the activation of the transformation.

3.13 Tool offsets

3.13.1 Offset memory

Structure of the offset memory

Every data field can be called with a T and D number, and contains not only the geometric specifications for the tool but also further entries, such as the tool type.

User cutting edge data

User cutting edge data can be configured via machine data. Please refer to the machine manufacturer's instructions.

Tool parameters

Note

Individual values in the offset memory

The individual values of the offset memory P1 to P25 can be read and written by the program via system variables. All other parameters are reserved.

The tool parameters \$TC_DP6 to \$TC_DP8, \$TC_DP10 and \$TC_DP11 as well as \$TC_DP15 to \$TC_DP17, \$TC_DP19 and \$TC_DP20 have another meaning depending on tool type.

Tool parameter number (DP)	Meaning of system variables	Remark
\$TC_DP1	Tool type	For overview see list
\$TC_DP2	Cutting edge position	Only for turning tools
Geometry	Length compensation	
\$TC_DP3	Length 1	Allocation to
\$TC_DP4	Length 2	Type and level
\$TC_DP5	Length 3	
Geometry	Radius	
\$TC_DP6 ¹⁾	Radius 1 / length 1	Milling/turning/grinding tool
\$TC_DP6 ²⁾	diameter d	Slotting saw
\$TC_DP7 ¹⁾	Length 2 / corner radius, tapered milling tool	Milling tools
\$TC_DP7 ²⁾	Slot width b corner radius	Slotting saw
\$TC_DP8 ¹⁾	Rounding radius 1 for milling tools	Milling tools
\$TC_DP8 ²⁾	projecting length k	Slotting saw
\$TC_DP9 ^{1) 3)}	Rounding radius 2	Reserved
\$TC_DP10 ¹⁾	Angle 1 face end of tool	Tapered milling tools
\$TC_DP11 ¹⁾	Angle 2 tool longitudinal axis	Tapered milling tools
Wear	Length and radius compensation	
\$TC_DP12	Length 1	
\$TC_DP13	Length 2	

Tool parameter number (DP)	Meaning of system variables	Remark
\$TC_DP14	Length 3	
\$TC_DP15 ¹⁾	Radius 1 / length 1	Milling/turning/grinding tool
\$TC_DP15 ²⁾	diameter d	Slotting saw
\$TC_DP16 ¹⁾	Length 2 / corner radius, tapered milling tool, slot width	Milling tools
\$TC_DP16 ³⁾	b corner radius	Slotting saw
\$TC_DP17 ¹⁾	Rounding radius 1 for milling tools	Milling / 3D face milling
\$TC_DP17 ²⁾	projecting length k	Slotting saw
\$TC_DP18 ¹⁾³⁾	Rounding radius 2	Reserved
\$TC_DP19 ¹⁾	Angle 1 face end of tool	Tapered milling tools
\$TC_DP20 ¹⁾	Angle 2 tool longitudinal axis	Tapered milling tools
Tool base dimension/ adapter		
Length offsets		
\$TC_DP21	Length 1	
\$TC_DP22	Length 2	
\$TC_DP23	Length 3	
Technology		
\$TC_DP24	Clearance angle	Only for turning tools
\$TC_DP25		Reserved

¹⁾ Also applies with milling tools for 3D face milling

²⁾ For slotting saw tool type

³⁾ Reserved (is not used by SINUMERIK 840D sl)

Remarks

Several entry components are available for geometric variables (e.g. length 1 or radius). These are added together to produce a value (e.g. total length 1, total radius), which is then used for the calculations.

Offset values not required must be assigned the value zero.

Tool parameters \$TC-DP1 to \$TC-DP23 with contour tools

Note

The tool parameters not listed in the table, such as \$TC_DP7, are not evaluated, i.e. their content is meaningless.

Tool parameter number (DP)	Meaning	Cutting Dn		Remark
\$TC_DP1	Tool type			400 to 599
\$TC_DP2	Cutting edge position			
Geometry	Length compensation			
\$TC_DP3	Length 1			
\$TC_DP4	Length 2			

Tool parameter number (DP)	Meaning	Cutting Dn		Remark
\$TC_DP5	Length 3			
Geometry	Radius			
\$TC_DP6	Radius			
Geometry	Limit angle			
\$TC_DP10	Minimum limit angle			
\$TC_DP11	Maximum limit angle			
Wear	Length and radius compensation			
\$TC_DP12	Wear length 1			
\$TC_DP13	Wear length 2			
\$TC_DP14	Wear length 3			
\$TC_DP15	Wear radius			
Wear	Limit angle			
\$TC_DP19	Wear min. limit angle			
\$TC_DP20	Wear max. limit angle			
Tool base dimension/ adapter	Length offsets			
\$TC_DP21	Length 1			
\$TC_DP22	Length 2			
\$TC_DP23	Length 3			

Basic value and wear value

The resultant values are each a total of the basic value and wear value (e.g. \$TC_DP6 + \$TC_DP15 for the radius). The basic measurement (\$TC_DP21 – \$TC_DP23) is also added to the tool length of the first cutting edge. All the other parameters, which may also impact on effective tool length for a standard tool, also affect this tool length (adapter, orientational toolholder, setting data).

Limit angles 1 and 2

Limit angles 1 and 2 each relate to the vector of the cutting edge center point to the cutting edge reference point and are counted clockwise.

3.13.2 Additive offsets

3.13.2.1 Selecting additive offsets (DL)

Additive offsets can be considered as process offsets that can be programmed in the machining. They refer to the geometrical data of a cutting edge and are therefore a component of tool cutting data.

Data of an additive offset is addressed using a DL number (DL: Locationdependent; offsets regarding the location of use) and entered via the user interface.

Application

Dimension errors caused by the location of use can be compensated using additive offsets.

Syntax

DL=<number>

Meaning


DL:	Command to activate an additive offset
<number>:	The additive tool offset data to be activated is specified using the <number> parameter

Note

The machine data is used to define the number of additive offsets and also activate them (→ carefully observe the machine OEM's data!).

Example

The same cutting edge is used for two bearing seats:



Program code	Comment
N110 T7 D7	; The revolver is positioned to location 7. D7 and DL=1 are activated and moved through in the next block.
N120 G0 X10 Z1	
N130 G1 Z-6	
N140 G0 DL=2 Z-14	; DL=2 is activated in addition to D7 and is moved through in the next block.
N150 G1 Z-21	
N160 G0 X200 Z200	; Approach tool change point.

3.13 Tool offsets

Program code	Comment
...	

3.13.2.2 Specify wear and setup values (\$TC_SCPxy[t,d], \$TC_ECPxy[t,d])

Wear and setting-up values can be read and written to using system variables. The logic is based on the logic of the corresponding system variables for tools and tool noses.

System variables

\$TC_SCPxy[<t>,<d>]:	Wear values that are assigned to the particular geometry parameters via xy, whereby x corresponds to the number of the wear value and y establishes the reference to the geometry parameter.
\$TC_ECPxy[<t>,<d>]:	Setting-up values that are assigned to the particular geometry parameter via xy, whereby x corresponds to the number of the setting-up value and y establishes the reference to the geometry parameter.
<t>: T number of the tool <d>: D number of the tool cutting edge	

Note

The defined wear and setup values are added to the geometry parameters and the other offset parameters (D numbers).

Example

The wear value of length 1 is set to the value of 1.0 for the cutting edge <d> of tool <t>.

Parameter: \$TC_DP3 (length 1, with turning tools)

Wear values: \$TC_SCP13 to \$TC_SCP63

Setup values: \$TC_ECP13 to \$TC_ECP63

\$TC_SCP43 [<t>,<d>] = 1.0

3.13.2.3 Delete additive offsets (DELDL)

The DELDL command deletes the additive offsets for the cutting edge of a tool (to release memory space). Both the defined wear values and the setup values are deleted.

Syntax

```
DELDL [<t>,<d>]
DELDL [<t>]
DELDL
<Status>=DELDL [<t>,<d>]
```

Meaning

DELDL:	Command to delete additive offsets	
<t>:	T number of the tool	
<d>:	D number of the tool cutting edge	
DELDL [<t>, <d>]:	All additive offsets of the cutting edges <d> of the tool <t> are deleted.	
DELDL [<t>]:	All additive offsets of all cutting edges of tool <t> are deleted.	
DELDL:	All additive offsets of all cutting edges of all tools of the TO unit are deleted (for the channel in which the command is programmed).	
<Status>:	Delete status	
	Value:	Meaning:
	0	Deletion was successfully completed.
	-	Offsets have not been deleted (if the parameter settings specify exactly one tool edge), or not deleted completely (if the parameter settings specify several cutting edges).

Note

Wear and setting-up values of active tools cannot be deleted (essentially the same as the delete behavior of D or tool data).

3.13.3 Special handling of tool offsets

The evaluation of the sign for tool length and wear can be controlled using setting data SD42900 to SD42960.

The same applies to the behavior of the wear components when mirroring geometry axes or changing the machining plane, and also to temperature compensation in tool direction.

Wear values:

If reference is made to wear values in the following, then this should be understood as the sum of the actual wear values (\$TC_DP12 to \$TC_DP20) and the sum offsets with the wear values (\$SCPX3 to \$SCPX11) and setting-up values (\$ECPX3 to \$ECPX11).

For more information about summed offsets, refer to:

References:

Function Manual, Tool Management

Setting data

SD42900 \$SC_MIRROR_TOOL_LENGTH	Mirroring of tool-length components and components of the tool base dimension.
SD42910 \$SC_MIRROR_TOOL_WEAR	Mirroring of wear values of the tool-length components.
SD42920 \$SC_WEAR_SIGN_CUTPOS	Evaluating the sign of the wear components as a function of the cutting edge position.

SD42930 \$SC_WEAR_SIGN	Inverts the sign of wear dimensions.
SD42935 \$SC_WEAR_TRANSFORM	Transformation of wear values.
SD42940 \$SC_TOOL_LENGTH_CONST	Assignment of tool length components to geometry axes.
SD42950 \$SC_TOOL_LENGTH_TYPE	Assignment of the tool length components independent of tool type.
SD42960 \$SC_TOOL_TEMP_COMP	Temperature compensation value in tool direction. Also operative when tool orientation is programmed.

References

Function Manual Basic Functions; Tool Offset (W1)

Further information

Activation of modified setting data

When the setting data described above is modified, the tool components are not reevaluated until the next time a tool edge is selected. If a tool is already active and the data of this tool is to be reevaluated, the tool must be selected again.

The same applies in the event that the resulting tool length is modified due to a change in the mirroring status of an axis. The tool must be selected again after the mirror command, in order to activate the modified tool-length components.

Orientable toolholders and new setting data

Setting data SD42900 to SD42940 has no effect on the components of an active toolholder with orientation capability. However, the calculation with an orientable toolholder always allows for a tool with its total resulting length (tool length + wear + tool base dimension). All modifications initiated by the setting data are included in the calculation of the resulting total length, i.e. vectors of the orientable toolholder are independent of the machining plane.

Note


When orientable toolholders are used, it is frequently practical to define all tools for a non-mirrored basic system, even those which are only used for mirrored machining. When machining with mirrored axes, the toolholder is then rotated such that the actual position of the tool is described correctly. All tool-length components then automatically act in the correct direction, dispensing with the need for control of individual component evaluation via setting data, depending on the mirroring status of individual axes.

Further application options

The use of orientable toolholder functionality can also be useful if there is no physical option of turning tools on the machine, even though tools with different orientations are permanently installed. Tool dimensioning can then be performed uniformly in a basic orientation, where the dimensions relevant for machining are calculated according to the rotations of a virtual toolholder.

3.13.3.1 Mirroring of tool lengths

When setting data SD42900 \$SC_MIRROR_TOOL_LENGTH and SD42910 \$SC_MIRROR_TOOL_WEAR are not set to zero, then you can mirror the tool length components and components of the basis dimensions with wear values and their associated axes.



SD42900 \$SC_MIRROR_TOOL_LENGTH

Setting data **not equal to zero**:

The tool length components (\$TC_DP3, \$TC_DP4 and \$TC_DP5) and the components of the basis dimensions (\$TC_DP21, \$TC_DP22 and \$TC_DP23) are mirrored against their associated axes, also mirrored – by inverting the sign.

The wear values are **not** mirrored. If these are also to be mirrored, then setting data SD42910 \$SC_MIRROR_TOOL_WEAR must be set.

SD42910 \$SC_MIRROR_TOOL_WEAR

Setting data **not equal to zero**:

The wear values of the tool length components - whose associated axes are mirrored - are also mirrored by inverting the sign.

3.13.3.2 Wear sign evaluation

When setting data SD42920 \$SC_WEAR_SIGN_CUTPOS and SD42930 \$SC_WEAR_SIGN are set not equal to zero, then you can invert the sign evaluation of the wear components.

SD42920 \$SC_WEAR_SIGN_CUTPOS

Setting data **not equal to zero**:

For tools with the relevant cutting edge position (turning and grinding tools, tool types 400), then the sign evaluation of the wear components in the machining plane depends on the cutting edge position. This setting data is of no significance for tool types without relevant cutting edge position.

In the following table, the dimensions, whose sign is inverted using SD42920 (not equal to zero), are designed using an X:

Cutting edge position	Length 1	Length 2
1		
2		X
3	X	X
4	X	
5		
6		
7		X
8	X	
9		

Note

The sign evaluation using SD42920 and SD42910 are independent of one another. If, for example, the sign of a dimension is changed using both setting data, then the resulting sign remains unchanged.

SD42930 \$SC_WEAR_SIGN

Setting data **not equal to zero**:

Inverts the sign of all wear dimensions. This affects both the tool length and other variables such as tool radius, rounding radius, etc.

If a positive wear dimension is entered, the tool becomes "shorter" and "thinner", refer to Chapter "tool offset, special handling", activating changed setting data".

3.13.3.3 Coordinate system of the active machining operation (TOWSTD, TOWMCS, TOWWCS, TOWBCS, TOWTCS, TOWKCS)

Depending on the kinematics of the machine or the availability of an orientable tool carrier, the wear values measured in one of these coordinate systems are converted or transformed to a suitable coordinate system.

Coordinate systems of active machining operation

The following coordinate systems produce tool length offsets which the tool length wear component incorporates in an active tool via the corresponding G command of Group 56:

- Machine coordinate system (MCS)
- Basic coordinate system (BCS)
- Workpiece coordinate system (WCS)
- Tool coordinate system (TCS)
- Tool coordinate system of kinematic transformation (KCS)

Syntax

TOWSTD
 TOWMCS
 TOWWCS
 TOWBCS
 TOWTCS
 TOWKCS

Meaning

TOWSTD:	Initial setting value for offsets in tool length wear value
TOWMCS:	Offsets in tool length in MCS
TOWWCS:	Offsets in tool length in WCS
TOWBCS:	Offsets in tool length in BCS
TOWTCS:	Offsets in tool length at tool carrier reference point (orientable tool carrier)
TOWKCS:	Compensations of tool length for tool head (kinematic transformation)

Further information

Distinguishing features

The most important distinguishing features are shown in the following table:

G command	Wear value	Active orientable tool carrier
TOWSTD:	Initial value, tool length	Wear values are subject to rotation.
TOWMCS:	Wear value in MCS. TOWMCS is identical to TOWSTD if a tool carrier that can be orientated is not active.	It only rotates the vector of the resultant tool length without taking into account the wear.
TOWWCS:	The wear value is converted to the MCS in the WCS.	The tool vector is calculated as for TOWMCS without taking into account the wear.
TOWBCS:	The wear value is converted to the MCS in the BCS.	The tool vector is calculated as for TOWMCS without taking into account the wear.
TOWTCS:	The wear value is converted to the MCS in the workpiece coordinate system.	The tool vector is calculated as for TOWMCS without taking into account the wear.

TOWWCS, TOWBCS, TOWTCS: The wear vector is added to the tool vector.

Linear transformation

The tool length can be defined meaningfully in the MCS only if the MCS is generated by linear transformation from the BCS.

Non-linear transformation

For example, if with TRANSMIT a non-linear transformation is active, then when specifying the MCS as requested coordinate system, BCS is automatically used.

No kinematic transformation and no orientable tool carrier

If neither a kinematic transformation nor an orientable tool carrier is active, then all the other four coordinate systems (except for the WCS) are combined. It is then only the WCS, which is different to the other systems. Since only tool lengths need to be evaluated, translations between the coordinate systems are irrelevant.

References:

For more information on tool compensation, see:
Function Manual Basic Functions; Tool Offset (W1)

Inclusion of wear values in calculation

The setting data **SD42935 \$SC_WEAR_TRANSFORM** defines which of the three wear components:

- Wear
- Total offsets fine
- Total offsets coarse

should be subject to a rotation using adapter transformation or a tool carrier that can be orientated if one of the following G commands is active:

- TOWSTD
Basic position. For corrections in the tool length.
- TOWMCS
Wear values in the machine coordinate system (MCS).
- TOWWCS
Wear values in the workpiece coordinate system (WCS).
- TOWBCS
Wear values in the basic coordinate system (BCS).
- TOWTCS
Wear values in the tool coordinate system at the tool carrier fixture (T tool carrier reference).
- TOWKCS
Wear values in the coordinate system of the tool head for kinematic transformation.

Note

Evaluation of individual wear components (assignment to geometry axes, sign evaluation) is influenced by the following factors:

- Active plane
 - Adapter transformation
 - Setting data:
 - SD42910 \$SC_MIRROR_TOOL_WEAR
 - SD42920 \$SC_WEAR_SIGN_CUTPOS
 - SD42930 \$SC_WEAR_SIGN
 - SD42940 \$SC_TOOL_LENGTH_CONST
 - SD42950 \$SC_TOOL_LENGTH_TYPE
-

3.13.3.4 Tool length and plane change

When setting data SD42940 \$SC_TOOL_LENGTH_CONST is set not equal to zero, then you can assign the tool length components – such as lengths, wear and basic dimension – to the geometry axes for turning and grinding tools when changing the plane.

SD42940 \$SC_TOOL_LENGTH_CONST

Setting data **not equal to zero**:

The assignment of tool length components (length, wear and tool base dimension) to geometry axes does not change when the machining plane is changed (G17 - G19).

The following table shows the assignment of tool length components to geometry axes for turning and grinding tools (tool types 400 to 599):

Content	Length 1	Length 2	Length 3
17	Y	X	Z
*)	X	Z	Y
19	Z	Y	X
-17	X	Y	Z
-18	Z	X	Y
-19	Y	Z	X

*) Each value not equal to 0, which is not equal to one of the six listed values, is evaluated as value 18.

The following table shows the assignment of tool length components to geometry axes for all other tools (tool types < 400 or > 599):

Operating plane	Length 1	Length 2	Length 3
*)	Z	Y	X
18	Y	X	Z
19	X	Z	Y
-17	Z	X	Y
-18	Y	Z	X
-19	X	Y	Z

*) Each value not equal to 0, which is not equal to one of the six listed values, is evaluated as value 17.

Note

For representation in tables, it is assumed that geometry axes up to 3 are designated with X, Y, Z. The axis order and not the axis identifier determines the assignment between a compensation and an axis.

3.13.4 Online tool offset

3.13.4.1 Defining a polynomial function (FCTDEF)


Certain dressing strategies (e.g. dressing roller) are characterized by the fact that the grinding wheel radius is continuously (linearly) reduced as the dressing roller is fed in. This strategy requires a linear function between infeed of the dressing roller and writing the wear value of each length. The linear function is defined using the predefined procedure FCTDEF(...) for up to third order polynomial functions.

Straight line equation

$$y = f(x) = a_0 + a_1 * x_1$$

a_1 : Gradient of the straight line, with $a_1 = \Delta x / \Delta y$

a_0 : Shift of the straight line along the X axis with $a_0 = -a_1 * X_v$



Syntax

FCTDEF (<Func>, <LLimit>, <ULimit>, <a0>, <a1>, <a2>, <a3>)

Meaning


FCTDEF (...):	Defining a polynomial function for PUTFTOCF(...): $y = f(x) = a_0 + a_1 * x + a_2 * x^2 + a_3 * x^3$	
<Func>:	Function number	
	Data type:	INT
	Range of values:	1, 2, 3
<LLimit>:	Lower limit value	
	Data type:	REAL
<ULimit>:	Upper limit value	
	Data type:	REAL
<a0>, <a1>, <a2>, <a3>:	Coefficients of polynomial function	
	Data type:	REAL

Example

Definitions

- Function number: 1
- Lower and upper limit value: -100, 100
- Gradient of the characteristic: $a_1 = 1$
- The operating point should be located at the center of the characteristic. Based on the setpoint position of axis XA in the WCS at the instant that the function is defined in the NC program, the characteristic must be shifted in the negative Y direction: $a_0 = -a_1 * XA_D = -1 * \AA_IW
- $a_2 = a_3 = 0$

Characteristic



UL Upper limit value

LL Lower limit value

XA_D Setpoint of axis XA at the time that the function is defined in the NC program

Programming

Program code	Comment
FCTDEF(1,-100,100,-\$AA_IW[XA],1)	; Function definition

3.13.4.2 Write online tool offset continuously (PUTFTOCF)

Using the predefined procedure PUTFTOCF(...), an online tool offset is executed based on a polynomial function previously defined with FCTDEF(...) (Page 724).

Note

The online tool offset can also be realized using a synchronized action.

For further information, see Function Manual Synchronized Actions.

Syntax

PUTFTOCF (<Func>, <RefVal>, <ToolPar>, <Chan>, <Sp>)

Meaning

PUTFTOCF (...):	Write online tool offset, continuously block-by-block using the polynomial function defined with FCTDEF(...)	
<Func>:	Function number, defined in the function definition with FCTDEF(...)	
	Data type:	INT
	Range of values:	1, 2, 3
<RefVal>:	Reference value, from which the offset is to be derived (e.g. setpoint of an axis).	
	Data type:	VAR REAL
<ToolPar>:	Number of the wear parameter (length 1, 2 or 3) in which the offset value is to be included.	
	Data type:	INT
<Chan>:	Number of the channel in which the online tool offset is to take effect.	
	Note: Only required if the offset is not to take effect in the active channel.	
	Data type:	INT
<Sp>:	Number of the spindle for which the online tool offset is to take effect.	
	Note: Only required if the offset is to be applied to a non-active grinding wheel rather than the active tool that is currently in use.	
	Data type:	INT

3.13.4.3 Write online tool offset, discrete (PUTFTOC)

Function

Using the predefined procedurePUTFTOC(...), an online tool offset is executed based on a fixed offset value.

Syntax

PUTFTOC (<CorrVal>, <ToolPar>, <Chan>, <Sp>)

Meaning

PUTFTOC (...):	Write online tool offset	
<CorrVal>:	Offset value, which is added to the wear parameter.	
	Data type:	REAL
<ToolPar>:	Number of the wear parameter (length 1, 2 or 3) in which the offset value is to be included.	
	Data type:	INT

<Chan>:	Number of the channel in which the online tool offset is to take effect. Note: Only required if the offset is not to take effect in the active channel.
	Data type: INT
<Sp>:	Number of the spindle for which the online tool offset is to take effect. Note: Only required if the offset is to be applied to a non-active grinding wheel rather than the active tool that is currently in use.
	Data type: INT

3.13.4.4 Activate/deactivate online tool offset (FTOCON/FTOCOF)

The online tool offset is activated or deactivated using the G commands FTOCON and FTOCOF.

Syntax


```
FTOCON
...
FTOCOF
```

Meaning

FTOCON:	Activate online tool offset The command must be programmed in the channel in which the online tool offset is to be activated.
FTOCOF:	Deactivate online tool offset The command must be programmed in the channel in which the online tool offset is to be deactivated. Note: On FTOCOF, the axis does not move further out for the tool offset. However, the value calculated with PUTFTOC/PUTFTOCF remains in the cutting-specific offset data. To finally deactivate the online tool offset, the tool (T...) must again be selected/deselected after FTOCOF.

3.13.5 Tool orientation (ORIC, ORID, OSOF, OSC, OSS, OSSE, ORIS, OSD, OST)

The term tool orientation describes the geometric alignment of the tool in space. The tool orientation on a 5-axis machine tool can be set by means of program commands.



Orientation rounding movements activated with `OSD` and `OST` are formed differently depending on the type of interpolation for tool orientation.

If vector interpolation is active, the smoothed orientation characteristic is also interpolated using vector interpolation. On the other hand, if rotary axis interpolation is active, the orientation is smoothed directly using rotary axis movements.


Programming

Programming a orientation change:

A change in tool orientation can be programmed by:

- Direct programming of rotary axes A, B, C (rotary axis interpolation)
- Euler or RPY angle
- Direction vector (vector interpolation by specifying `A3` or `B3` or `C3`)
- `LEAD/TILT` (face milling)

The reference coordinate system is either the machine coordinate system (`ORIMKS`) or the current workpiece coordinate system (`ORIWKS`).



Programming tool orientation:

ORIC:	Orientation and path movement in parallel
ORID:	Orientation and path movement consecutively
OSOF:	No orientation smoothing
OSC:	Orientation constantly
OSS:	Orientation smoothing only at beginning of block
OSSE:	Orientation smoothing at beginning and end of block
ORIS:	Velocity of the orientation change with orientation smoothing activated in degrees per mm (valid for OSS and OSSE)
OSD:	Smoothing of orientation by specifying smoothing distance with setting data: SD42674 \$SC_ORI_SMOOTH_DIST
OST:	Smoothing of orientation by specifying angular tolerance in degrees for vector interpolation with setting data: SD42676 \$SC_ORI_SMOOTH_TOL With rotary axis interpolation, the specified tolerance is assumed to be the maximum variance of the orientation axes.

Note


All commands for smoothing the tool orientation (OSOF, OSC, OSS, OSSE, OSD, and OST) are summarized in G group 34. They are modal; in other words, only one of these commands can ever be effective at the same time.

Examples

Example 1: ORIC

If two or more blocks with orientation changes are programmed between the traversing blocks N10 and N20 (e.g. A2=... B2=... C2=...) programmed and ORIC is active, then the


inserted circle block is distributed among these intermediate blocks according to the absolute changes in angle.



Program code	Comment
ORIC	
N8 A2=... B2=... C2=...	
N10 X... Y... Z...	
N12 C2=... B2=...	; The circle block inserted at the external corner is distributed between N12 and N14, corresponding to the change in orientation. The circular motion and the orientation change are executed in parallel.
N14 C2=... B2=...	
N20 X =...Y=... Z=... G1 F200	

Example 2: ORID

If ORID is active, then all blocks between the two traversing blocks are executed at the end of the first traversing block. The circle block with constant orientation is executed immediately before the second traversing block.




Program code	Comment
ORID	
N8 A2=... B2=... C2=...	
N10 X... Y... Z...	
N12 A2=... B2=... C2=...	; The N12 and N14 blocks are executed at the end of N10. The circle block is then executed with the actual orientation.
N14 M20	; Help functions, etc.
N20 X... Y... Z...	

Note

The method which is used to change orientation at an outer contour is determined using the program command that is active in the first traversing block of an outer corner.

Without change in orientation: If the orientation is not changed at the block boundary, the cross-section of the tool is a circle, which touches both of the contours.

Example 3: Change in orientation at an inside corner



Program code


```
ORIC  
N10 X ...Y... Z... G1 F500  
N12 X ...Y... Z... A2=... B2=... C2=...  
N15 X ...Y... Z... A2=... B2=... C2=...
```

Further information

Behavior at outer corners

A circle block with the radius of the cutter is always inserted at an outside corner.

The `ORIC` and `ORID` program commands are used to determine whether changes in orientation programmed between block `N1` and `N2` are executed before the inserted circle block is processed or at the same time.



If an orientation change is required at outside corners, this can be performed either at the same time as interpolation or separately together with the path movement.

When `ORID` is programmed, the inserted blocks are executed first without path motion. The circle block generating the corner is inserted immediately before the second of the two traversing blocks.

If several orientation blocks are inserted at an external corner and `ORIC` is selected, the circular motion is distributed among the individual inserted blocks according to the absolute values of the orientation changes.

Smoothing orientation with `OSD` or `OST`

When blending with `G642`, the maximum variance for the contour axes and orientation axes cannot vary greatly. The smaller tolerance of the two determines the type of smoothing motion and/or angular tolerance to smooth the orientation characteristic relatively strongly without having to accept higher contour deviations.

`OSD` and `OST` can be activated to "generously" smooth very slight deviations from the orientation characteristics with a specified smoothing distance and angular tolerance without serious contour deviations.

Note

Unlike the process of rounding the contour (and orientation characteristics) with `G642`, when rounding the orientation with `OSD` and/or `OST`, a separate block is not formed, instead the rounding movement is added directly to the programmed original blocks.

With `OSD` and/or `OST`, block transitions cannot be rounded if there is a change in the type of interpolation for tool orientation (vector → rotary axis, rotary axis → vector). These block transitions can if necessary be rounded with the standard rounding functions `G641`, `G642` and `G643`.

3.13.6 Free assignment of D numbers, cutting edge numbers

3.13.6.1 Free assignment of D numbers, cutting edge numbers (CE address)

D number

The D numbers can be used as offset numbers. The number of the cutting edge can also be addressed via the CE address. The cutting edge number can be written by the system variable \$TC_DPCE.

Default setting: Compensation no. == cutting edge no.

Machine data are used to define the maximum number of D numbers (cutting edge numbers) and the maximum number of cutting edges per tool (→ machine manufacturer). The following commands are only practical if the maximum cutting edge number (MD18105) was specified to be greater than the number of cutting edges per tool (MD18106). Observe the machine manufacturer's specifications.

References

Function Manual Basic Functions; Tool Offset (W1)

3.13.6.2 Free assignment of D numbers: Checking D numbers (CHKDNO)

Using the `CHKDNO` command, you can check whether the existing D numbers were uniquely assigned. The D numbers of all tools defined within a TO unit may not occur more than once. No allowance is made for replacement tools.

Syntax

```
state=CHKDNO (Tno1, Tno2, Dno)
```

Meaning

state:	=TRUE:	The D numbers are assigned uniquely to the checked areas.
	=FALSE:	There was a D number collision or the parameters are invalid. Tno1, Tno2 and Dno return the parameters that caused the collision. These data can now be evaluated in the part program.
CHKDNO (Tno1, Tno2):	All D numbers of the part specified are checked.	
CHKDNO (Tno1):	All D numbers of Tno1 are checked against all other tools.	
CHKDNO:	All D numbers of all tools are checked against all other tools.	

3.13.6.3 Free assignment of D numbers: Rename D numbers (GETDNO, SETDNO)

You must assign unique D numbers. Two different cutting edges of a tool must not have the same D number.

GETDNO

This command returns the D number of a particular cutting edge (ce) of a tool with tool number t. If no D number exists for the entered parameters, d=0 will be set. If the D number is invalid, a value greater than 32000 is returned.

SETDNO

This command assigns the value d of the D number to a cutting edge (ce) of tool t. The result of this statement is returned via state (TRUE or FALSE). If there is no data block for the specified parameter, the value FALSE is returned. Syntax errors generate an alarm. The D number cannot be set explicitly to 0.

Syntax

```
d = GETDNO (t,ce)
state = SETDNO (t,ce,d)
```

Meaning

d:	D number of the tool edge
t:	T number of the tool
ce:	Cutting edge number (CE number) of the tool
state:	Indicates whether the command could be executed (TRUE or FALSE).

Example for renaming a D number

Programming	Comment
\$TC_DP2[1,2]=120	
\$TC_DP3[1,2] = 5.5	
\$TC_DPCE[1,2] = 3	; Cutting edge number CE
...	
N10 def int DNoOld, DNoNew = 17	
N20 DNoOld = GETDNO(1,3)	
N30 SETDNO(1,3,DNoNew)	

The new D value 17 is then assigned to cutting edge CE=3. Now the data for the cutting edge is addressed via D number 17; both via the system variables and in the programming with the NC address.

3.13.6.4 Free assignment of D numbers: Determine T number to the specified D number (GETACTTD)

The pre-defined function GETACTTD determines the T number associated with an absolute D number. There is no check for uniqueness. If several D numbers within a TO unit are the same, the T number of the first tool found in the search is returned.

Syntax

<Status>=GETACTTD (<TNo>, <DNo>)

Meaning

GETACTTD():	Function call			
<DNo>:	D number for which the T number shall be searched.			
	Data type:	INT		
<TNo>:	T number found			
	Data type:	VAR INT		
<status>:	Result			
	Data type:	INT		
	Value:	0	The T number was found. <Tno> contains the value of the T number.	
		-1	No T number exists for the specified D number; <Tno>=0.	
		-2	The D number is not absolute. <TNo> receives the value of the first tool found that contains the D number with the value <Dno>.	
-5		The function was not able to be executed for another reason.		

3.13.6.5 Free assignment of D numbers: Invalidate D numbers (DZERO)

The DZERO command is used for support during retooling. Compensation data sets tagged with this command are no longer verified by the CHKDNO command. These data sets can be accessed again by setting the D number once more with SETDNO.

Syntax

DZERO

Meaning

DZERO:	Marks all D numbers of the TO unit as invalid.
--------	--

3.13.7 Toolholder kinematics

Requirements

A toolholder can only orientate a tool in all possible directions in space if

- Two rotary axes v_1 and v_2 are present.
- The rotary axes are mutually orthogonal.
- The tool longitudinal axis is perpendicular to the second rotary axis v_2 .


In addition, the following requirement is applicable to machines for which all possible orientations have to be settable:

- The tool longitudinal axis must be perpendicular to the first rotary axis v_1 .

Function

The toolholder kinematics with a maximum of two rotary axes v_1 or v_2 are defined using the 17 system variables \$TC_CARR1[m] to \$TC_CARR17[m]. The description of the toolholder consists of:

- The vectoral distance from the first rotary axis of the toolholder I_1 , the vectoral distance from the first rotary axis to the second rotary axis I_2 , the vectoral distance from the second rotary axis to the reference point of the tool I_3 .
- The direction vectors of both rotary axes v_1 , v_2 .
- The angles of rotation α_1 , α_2 around the two axes. The rotation angles are counted in viewing direction of the rotary axis vectors, positive, in clockwise direction of rotation.



For machines with **resolved kinematics** (both the tool and the part can rotate), the system variables have been extended with the entries \$TC_CARR18[m] to \$TC_CARR23[m].

Parameters

Function of the system variables for orientable toolholders			
Designation	x component	y component	z component
I_1 offset vector	\$TC_CARR1[m]	\$TC_CARR2[m]	\$TC_CARR3[m]
I_2 offset vector	\$TC_CARR4[m]	\$TC_CARR5[m]	\$TC_CARR6[m]
v_1 rotary axis	\$TC_CARR7[m]	\$TC_CARR8[m]	\$TC_CARR9[m]
v_2 rotary axis	\$TC_CARR10[m]	\$TC_CARR11[m]	\$TC_CARR12[m]

Function of the system variables for orientable toolholders			
α_1 angle of rotation	\$TC_CARR13[m] \$TC_CARR14[m]		
α_2 angle of rotation			
l_3 offset vector	\$TC_CARR15[m]	\$TC_CARR16[m]	\$TC_CARR17[m]

Extensions of the system variables for orientable toolholders			
Designation	x component	y component	z component
l_4 offset vector	\$TC_CARR18[m]	\$TC_CARR19[m]	\$TC_CARR20[m]
Axis identifier Rotary axis v_1 Rotary axis v_2	Axis identifier of the rotary axes v_1 and v_2 (initialized with zero) \$TC_CARR21[m] \$TC_CARR22[m]		
Kinematic type	\$TC_CARR23[m]		
Tool	Kinematics type T ->	Kinematics type P ->	Kinematics type M
Part	Only the tool can rotate	Only the part can rotate	Part and tool can rotate
Mixed mode	(default).		
Offset of the Rotary axis v_1 Rotary axis v_2	Angle in degrees of the rotary axes v_1 and v_2 on assuming the initial setting \$TC_CARR24[m] \$TC_CARR25[m]		
Angle offset of the rotary axis v_1 Rotary axis v_2	Offset of the Hirth tooth system in degrees for rotary axes v_1 and v_2 \$TC_CARR26[m] \$TC_CARR27[m]		
Angle increment v_1 rotary axis v_2 rotary axis	Offset of the Hirth tooth system in degrees for rotary axes v_1 and v_2 \$TC_CARR28[m] \$TC_CARR29[m]		
Min. position Rotary axis v_1 Rotary axis v_2	Software limit for the minimum position of the rotary axes v_1 and v_2 \$TC_CARR30[m] \$TC_CARR31[m]		
Max. position Rotary axis v_1 Rotary axis v_2	Software limits for the maximum position of the rotary axes v_1 and v_2 \$TC_CARR32[m] \$TC_CARR33[m]		
Toolholder name	A toolholder can be given a name instead of a number. \$TC_CARR34[m]		
User:	Intended use in user measuring cycles \$TC_CARR35[m]		
Axis name 1	\$TC_CARR36[m]		
Axis name 2	\$TC_CARR37[m]		
Identifier	\$TC_CARR38[m]	\$TC_CARR39[m]	\$TC_CARR40[m]
Position			
Fine offset	Parameters that can be added to the values in the basic parameters.		
l_1 offset vector	\$TC_CARR41[m]	\$TC_CARR42[m]	\$TC_CARR43[m]
l_2 offset vector	\$TC_CARR44[m]	\$TC_CARR45[m]	\$TC_CARR46[m]
l_3 offset vector	\$TC_CARR55[m]	\$TC_CARR56[m]	\$TC_CARR57[m]
l_4 offset vector	\$TC_CARR58[m]	\$TC_CARR59[m]	\$TC_CARR60[m]
v_1 rotary axis	\$TC_CARR64[m]		
v_2 rotary axis	\$TC_CARR65[m]		

Note**Explanations of parameters**

"m" specifies the number of the toolholder to be programmed.

\$TC_CARR47 to \$TC_CARR54 and \$TC_CARR61 to \$TC_CARR63 are not defined and produce an alarm if read or write access is attempted.

The start/end points of the distance vectors on the axes can be freely selected. The rotation angles α_1 , α_2 around the two axes are defined in the initial state of the toolholder by 0° . In this way, the kinematics of a toolholder can be programmed for any number of possibilities.

Toolholders with only one or no rotary axis at all can be described by setting the direction vectors of one or both rotary axes to zero.

With a toolholder without rotary axis the distance vectors act as additional tool offsets whose components cannot be affected by a change of machining plane (G17 to G19).

Parameter extensions**Parameters of the rotary axes**

The system variables have been extended by the entries \$TC_CARR24[m] to \$TC_CARR33[m] and described as follows:

Offset of rotary axes v_1, v_2	Changing the position of the rotary axis v_1 or v_2 for the initial setting of the oriented toolholder.
The angle offset/ angle increment of the rotary axes v_1, v_2	The offset or the angle increment of the Hirth tooth system of the rotary axes v_1 and v_2 . Programmed or calculated angle is rounded up to the next value that results from $\phi = s + n * d$ when n is an integer.
The minimum and maximum position of the rotary axes v_1, v_2	The minimum and maximum position of the rotary axis limit angle (software limit) of the rotary axes v_1 and v_2 .

Parameters for the user


\$TC_CARR34 to \$TC_CARR40 contain parameters that are freely available to users and up to SW 6.4 were as standard, not further evaluated within the NCK or had no significance.

Fine offset parameters

\$TC_CARR41 to \$TC_CARR65 include fine offset parameters that can be added to the values in the basis parameters. The fine offset value assigned to a basic parameter is obtained when the value 40 is added to the parameter number.

Example

The toolholder used in the following example can be fully described by a rotation around the Y axis.



Program code	Comment
N10 \$TC_CARR8[1]=1	; Definition of the Y component of the first rotary axis of toolholder 1.
N20 \$TC_DP1[1,1] = 120	; Definition of a shaft miller.
N30 \$TC_DP3[1,1]=20	; Definition of a shaft miller, 20 mm long.
N40 \$TC_DP6[1,1]=5	; Definition of a shaft miller with 5 mm radius.
N50 ROT Y37	; Frame definition with 37° rotation around the Y axis.
N60 X0 Y0 Z0 F10000	; Approach start position.
N70 G42 CUT2DF TCOFR TCARR=1 T1 D1 X10	Set radius compensation, tool length compensation in rotated frame, select toolholder 1, tool 1.
N80 X40	; Perform machining under a rotation of 37°.
N90 Y40	
N100 X0	
N110 Y0	
N120 M30	

Further information

Resolved kinematics

For machines with resolved kinematics (both the tool as well as the workpiece can be rotated), the system variables have been expanded by the entries `$TC_CARR18 [m]` up to `$TC_CARR23 [m]` and are described as follows:

The rotatable tool table consisting of:

- The vectorial clearance of the second rotary axis V_2 to the reference point of a tool table that can be rotated I_4 of the third rotary axis.

The rotary axes consisting of:

- The two channel identifiers for the reference of the rotary axes V_1 and V_2 , whose position is, when required, accessed to determine the orientation of the toolholder that can be orientated.

The type of kinematics with one of the values T, P or M:

- Kinematics type T: Only tool can rotate.
- Kinematics type P: Only part can rotate.
- Kinematics type M: Tool and part can rotate.

Clearing the toolholder data

Data of all toolholder data sets can be deleted using `$TC_CARR1 [0]=0`.

The kinematic type `$TC_CARR23 [T]=T` must be assigned with one of the three permissible uppercase or lowercase letters (T,P,M) and for this reason, should not be deleted.

Changing the toolholder data

Each of the described values can be modified by assigning a new value in the part program. Any character other than T, P or M results in an alarm when an attempt is made to activate the toolholder that can be orientated.

Reading the toolholder data

Each of the described values can be read by assigning it to a variable in the part program.


Fine offsets

An illegal fine offset value is only detected if a toolholder that can be orientated is activated, which contains such a value and at the same time setting data `SD42974 $SC_TOCARR_FINE_CORRECTION = TRUE`.

The maximum permissible fine offset is limited to a permissible value in the machine data.

3.13.8 Tool length compensation for orientable toolholders (TCARR, TCOABS, TCOFR, TCOFRX, TCOFRY, TCOFRZ)

When the spatial orientation of the tool changes, its tool length components also change.



After a reset, e.g. through manual setting or change of the toolholder with a fixed spatial orientation, the tool length components also have to be determined again. This is performed using the TCOABS and TCOFR path commands.

For a toolholder of an active frame that can be orientated, when selecting the tool with TCOFRZ, TCOFRY and TCOFRX, it is possible to define the direction in which the tool should point.

Syntax

```
TCARR= [<m>]
TCOABS
TCOFR
TCOFRZ
TCOFRY
TCOFRX
```

Meaning

TCARR= [<m>]:	Request toolholder with the number "m"
TCOABS:	Determine tool length components from the orientation of the current toolholder
TCOFR:	Determine tool length components from the orientation of the active frame
TCOFRZ:	Orientable toolholder from active frame with a tool pointing in the Z direction
TCOFRY:	Orientable toolholder from active frame with a tool pointing in the Y direction
TCOFRX:	Orientable toolholder from active frame with a tool pointing in the X direction

Further information

Determine tool length offset from the orientation of the toolholder (TCOABS)

TCOABS calculates the tool length offset from the current orientation angles of the toolholder; saved in the system variables \$TC_CARR13 and \$TC_CARR14.

For a definition of toolholder kinematics with system variables, see "Toolholder kinematics (Page 736)".

In order to make a new calculation of the tool length offset when frames are changed, the tool has to be selected again.

Tool direction from active frame

The toolholder with orientation capability is set so that the tool points in the following directions:

- With TCOFR or TCOFRZ in the Z direction
- With TCOFRY in the Y direction
- With TCOFRX in the X direction

The tool length offset is re-calculated when changing over between TCOFR and TCOABS.

Request toolholder (TCARR)

With TCARR, the toolholder number m is requested with its geometry data (compensation memory).

With m=0, the active toolholder is deselected.

The geometry data of the toolholder only becomes active after a tool is called. The selected tool remains active after a toolholder change has taken place.

The current geometry data for the toolholder can also be defined in the part program via the corresponding system variables.

Recalculation of tool length offset (TCOABS) for a frame change

In order to make a new calculation of the tool length offset when frames are changed, the tool has to be selected again.

Note

The tool orientation must be manually adapted to the active frame.

When the tool length offset is calculated, the angle of rotation of the toolholder is calculated in an intermediate step. With toolholders with two rotary axes, there are generally two sets of rotation angles, which can be used to adapt the tool orientation to the active frame; therefore,

the rotation angle values stored in the system variables must at least correspond approximately to the mechanically set rotation angles.

Note

Tool orientation

It is not possible for the control to check whether the rotation angles calculated by means of the frame orientation are settable on the machine.

If the rotary axes of the toolholder are arranged such that the tool orientation calculated by means of the frame orientation cannot be reached, then an alarm is output.

The combination of tool precision compensation and the functions for tool length offset on movable toolholders is not permissible. If both functions are called simultaneously, an error message is issued.

The `TOFRAME` function allows a frame to be defined on the basis of the direction of orientation of the selected toolholder. For more information please refer to chapter "Frames".

When orientation transformation is active (3, 4 or 5-axis transformation), it is possible to select a toolholder with an orientation deviating from the zero position without causing output of an alarm.

Transfer parameter from standard and measuring cycles

For the transfer parameter of standard and measuring cycles, the following defined value ranges apply.

For angular value, the value range is defined as follows:

- Rotation around 1st geometry axis: -180 degrees to +180 degrees
- Rotation around 2nd geometry axis: -90 degrees to +90 degrees
- Rotation around 3rd geometry axis: -180 degrees to +180 degrees

Refer to Chapter Frames, "Programmable rotation (ROT, AROT, RPL)".

Note

When transferring angular values to a standard or measuring cycle, the following should be carefully observed:

Values less than the calculation resolution of the NC should be rounded-off to zero!

The calculation resolution of the NC for angular positions is defined in the machine data:

MD10210 \$MN_INT_INCR_PER_DEG

3.13.9 Modifying the orientable tool carrier according to the machine measurement (CORRTC)

Measured kinematic chain elements of a tool carrier can be written to special correction elements with the `CORRTC` function.

Note

The correction values written with the CORRTC function are not immediately effective in the transformation. The correction values do not become effective until after a transformation deselection, NEWCONF and transformation selection.

Syntax

```
<_Corr_Status> = CORRTC(<_Corr_Vect>, <_Corr_Index>, <_Corr_Mode>,
[ <_No_Alarm>])
```

Meaning

CORRTC:	Function call	
<_Corr_Status>:	Function return value	
	Data type: INT	
	Values:	0 The function was executed without an error.
		1 No tool carrier is active.
		2 The active tool carrier was not defined with kinematic chains.
		10 The <_Corr_Index> call parameter is negative.
		11 The <_Corr_Mode> call parameter is negative.
		12 Invalid reference to a section of a subchain (_CORR_INDEX).
		13 No correction element has been defined in the section referred to by the _CORR_INDEX parameter (\$TC_CARR_CORR_ELEM).
		20 The hundreds position of <_CORR_MODE> is invalid. Only the values 0 and 1 are permissible.
	21 The thousands position of <_CORR_MODE> is invalid. Only the values 0 and 1 are permissible.	
	30 For the correction of an offset vector, the deviation from the current value in at least one coordinate is greater than the maximum value specified by the setting data SD41612 \$SN_CORR_TRAFO_LIN_MAX.	
	31 The attempt to write a system variable was rejected because of missing write rights.	
<_Corr_Vect>:	Correction vector The content of the correction vector is defined by the following parameters <_Corr_Index> and <_Corr_Mode>. If <_Corr_Status> = 30, the content of the vector is overwritten (see above).	
	Data type: REAL	
<_Corr_Index>:	Designates the section for which the direction vector of the correction element is to be corrected.	
	Data type: INT	

<_Corr_Mode>:	Correction mode		
	Data type:	INT	
	The <Corr_Index> parameter is decimal coded (units to thousands position):		
	Units position:	Reserved	
	Tens position:	Specifies how the correction element to which the content of <_Corr_Index> refers, is to be modified.	
		xx0x	The correction vector is written immediately to the correction element. This variant can be used to immediately write the correction element without the index <n> of the relevant system data (\$NK_OFF_DIR[<n>, ...]) having to be known.
		xx1x	As 0, but with the difference that the transferred correction value is interpreted in world coordinates. A difference between variants 0 and 1 can always occur when the kinematic chain in the initial state (positions of all rotary axes equal to 0) contains other rotations.
		xx2x	As 1, but with the difference that the correction value refers to the entire section, i.e. a value is entered in the correction element so that the entire section reaches the length defined by the correction value.
	Hundreds position:	Specifies how the content of the <_Corr_Vect> parameter is to be interpreted.	
		x0xx	The transferred correction vector <_Corr_Vect> contains the entire new length of the correction element or the section to which the <_Corr_Index> in conjunction with the tens position of <_Corr_Mode> refers (absolute correction).
x1xx		The transferred correction vector <_Corr_Vect> only contains the difference compared to the current length of the correction element or the section to which the <_Corr_Index> in conjunction with the tens position of <_Corr_Mode> refers (incremental correction).	
Thousands position:	Determines whether or not the maximum permissible correction is to be limited by the setting data \$SN_CORR_TOCARR_LIN_MAX.		
	0xxx	Threshold value monitoring is active.	
	1xxx	The threshold value monitoring is suppressed.	
<_No_Alarm>:	Behavior in the event of an error (return value > 0) (optional)		
	Data type:	BOOL	
	Value:	FALSE (default)	In the event of an error, the program execution is stopped and an alarm displayed.
		TRUE	In the event of an error, the program processing is not stopped and no alarm is displayed. Application: User-specific reaction corresponding to the return value

Further information about CORRTC

The kinematic structure of a tool carrier is described by one (type T and type P) or two (type M) kinematic chains (subchains), which start from the associated reference point, machine zero or tool carrier reference point). One of the two chains, the tool chain, ends at the reference point of the tool, the other chain, the workpiece chain ends in the zero point of the basic coordinate system.

The CORRTC function writes lever arm lengths and axis directions on machines with an orientation transformation in special correction elements. A kinematic chain is described, for example, with elements of the type OFFSET, which are defined via \$NK_TYPE.

CORRTC works with sections

The two subchains can each be divided into a maximum of four sections:

- Section 1 begins at the starting point of the chain and ends at the first orientation axis.
- Section 2 is the section between orientation axis 1 and orientation axis 2.
- Section 3 is the section between orientation axis 2 and the end of the chain.

The following figure shows an orientable tool carrier with 2 rotary axes.




Figure 3-8 CORRTC example

The sections are clearly defined: If the kinematic subchain is executed from its starting point to its end point, then the first section has the index 1, next has index 2, and so on.

Correction elements

A reference can be made to a constant kinematic chain element (chain element of the type \$NK_TYPE[<n>] = "OFFSET") in each of these sections with the \$TC_CARR_CORR_ELEM [, 0 ... 3] system variables. The correction values determined during the machine measurement are written to the so designated elements with the CORRTC function.

The sequence of references in \$TC_CARR_CORR_ELEM[m, 0 ... 3] must correspond to the sections described above, that is there can only be one chain element in \$TC_CARR_CORR_ELEM[m, 0] which belongs to the offset vector I1, etc.

The reference value is always the corresponding value effective in the tool carrier active when CORRTC is called. After selection of the tool carrier, changed contents of the stored kinematic data have no effect on the method of operation of the CORRTC function.

3.13.10 Online tool length compensation (TOFFON, TOFFOF)

Use the system variable \$AA_TOFF[<n>] to overlay the effective tool lengths in accordance with the three tool directions three-dimensionally in real time.

The three geometry axis identifiers are used as index <n>. Thus, the number of active direction offsets is determined by the geometry axes that are active at the same time.

All offsets can be active at the same time.

The online tool length offset function can be used for:

- Orientation transformation TRAORI
- Orientable toolholder TCARR

Note

Online tool length offset is an **option**, which must be enabled in advance. This function is only practical in conjunction with an active orientation transformation or an active orientable toolholder.

Syntax

```
TRAORI
TOFFON(<compensation direction>[,<offset value>])
WHEN TRUE DO $AA_TOFF[<compensation direction>]           ; In synchronized actions.
...
TOFFOF(<compensation direction>)
```

Meaning

TOFFON:	Activate online tool length offset	
	<compensation direction>:	Tool direction (X, Y, Z), in which the online tool length offset should be active.
	<offset value>:	When activating, an offset value can be specified for the relevant direction of compensation and this is immediately recovered.
TOFFOF:	Reset online tool length offset The compensation values in the specified compensation direction are reset and a pre-processing stop is initiated.	

Examples

Example 1: Selecting the tool length compensation

Program code	Comment
MD21190 \$MC_TOFF_MODE = 1	; Absolute values are approached.
MD21194 \$MC_TOFF_VELO[0] =1000	
MD21196 \$MC_TOFF_VELO[1] =1000	
MD21194 \$MC_TOFF_VELO[2] =1000	
MD21196 \$MC_TOFF_ACCEL[0] =1	
MD21196 \$MC_TOFF_ACCEL[1] =1	
MD21196 \$MC_TOFF_ACCEL[2] =1	

Program code	Comment
N5 DEF REAL XOFFSET	
N10 TRAORI(1)	; Transformation on.
N20 TOFFON(Z)	; Activation of online tool length compensation for the Z tool direction.
N30 WHEN TRUE DO \$AA_TOFF[Z]=10 G4 F5	; A TLC of 10 is interpolated for the Z tool direction.
...	
N100 XOFFSET=\$AA_TOFF_VAL[X]	; Assigns actual compensation in the X direction.
N120 TOFFON(X,-XOFFSET) G4 F5	; For the X tool direction, the TLC is reduced back to 0.

Example 2: Deselect the tool length offset

Program code	Comment
N10 TRAORI(1)	; Transformation on.
N20 TOFFON(X)	; Activation of online tool length compensation for the X tool direction.
N30 WHEN TRUE DO \$AA_TOFF[X]=10 G4 F5	; A TLC of 10 is interpolated for the X tool direction.
...	
N80 TOFFOF(X)	; Position offset of the X tool direction is deleted: ...\$AA_TOFF[X]=0 No axis is moved. The position offset is added to the actual position in the Work corresponding to the actual orientation.

Further information

Block preparation

During block preparation in preprocessing, the current tool length offset active in the main run is also taken into consideration. To allow extensive use to be made of the maximum permissible axis velocity, it is necessary to stop block preparation with a `STOPRE` preprocessing stop while a tool offset is established.

The tool offset is always known at the time of run-in when the tool length offsets are not changed after program start or if more blocks have been processed after changing the tool length offsets than the IPO buffer can accommodate between run-in and main run.

Variable \$AA_TOFF_PREP_DIFF

The dimension for the difference between the currently active compensation in the interpolator and the compensation that was active at the time of block preparation can be polled in the variable \$AA_TOFF_PREP_DIFF[<n>].

Adjusting machine data and setting data

The following system data is available for online tool length offset:

- MD20610 \$MC_ADD_MOVE_ACCEL_RESERVE (acceleration margin for overlaid motion)
- MD21190 \$MC_TOFF_MODE
Content of system variable \$AA_TOFF[<n>] is moved through as absolute value or is integrated up.
- MD21194 \$MC_TOFF_VELO (velocity of the online tool length offset)
- MD21196 \$MC_TOFF_ACCEL (acceleration of the online tool length offset)
- Setting data for presetting limit values
:
SD42970 \$SC_TOFF_LIMIT (upper limit of the tool length offset value)

Reference:

Function Manual, Special Functions; F2: Multi-axis transformations

3.13.11 Modification of the offset data for rotatable tools

3.13.11.1 Calculating orientations (ORISOLH)

The predefined ORISOLH function helps the user to set the rotary axis positions of a machine so that a turning tool can be brought into a defined, kinematic-independent position relative to the workpiece. Prerequisite is that a 6-axis transformation is active that has been parameterized with kinematic chains.

Two basic functions are available:

- Tool alignment
The β and γ angles are specified. The function calculates the angles of the three orientation axes required for this.
- Direct tool alignment
The angles of the second and third orientation axes are specified. The function calculates the associated β and γ angles as well as that of the missing first orientation axis.

Note**Order of the orientation axes**

If you run through the kinematic chain that describes the structure of the machine, from the workpiece to the tool, then the following specifications apply for the order of the three orientation axes of a 6-axis transformation:

- The orientation axis that is closest to the **workpiece** is the **first** orientation axis.
- The orientation axis that is closest to the **tool** is the **third** orientation axis.

Generally, the first orientation axis is a spindle and the corresponding rotation is therefore implemented in these cases through a rotating frame.

Syntax

```
<RetVal> = ORISOLH(<Cntrl>, <W1>, <W2>)
```

Meaning

ORISOLH:	Function call		
<RetVal>:	Function return value		
	Data type:	INT	
	Range of values:	0, -2, -3, ..., -17	
	Values:	0	Function has ended without an error.
		-2	No valid transformation (6-axis orientation transformation) is active.
		-3	The first parameter (<Cntrl>) is negative.
		-4	The unit position of the first parameter (<Cntrl>) is invalid. Only the values 0 and 1 are permissible.
		-5	The tens position of the first parameter (<Cntrl>) is invalid. Only the values 0 to 3 are permissible.
		-6	The hundreds position of the first parameter (<Cntrl>) is invalid. Only the values 0 and 1 are permissible.
		-7	The thousands position of the first parameter (<Cntrl>) is invalid. Only the values 0 to 3 are permissible.
		-8	Angle γ is too large for the "Direct tool alignment" function.
		-9	At least one of the specified axis positions violates an axis limit for the "Direct tool alignment" function.
		-10	No tool is active.
-11	The requested orientation cannot be set.		
-12	The adaptation of the free axis angle for the Hirth joint is not possible for the first or only solution.		
-13	The adaptation of the free axis angle for the Hirth joint is not possible for the second solution.		
-14	The adaptation of the free axis angle for the Hirth joint is not possible for either of the two solutions.		
-15	The first orientation axis is parameterized as Hirth axis.		
-16	The second as well as the third rotary axis has been parameterized as Hirth axis. Only one of the two axes can be the Hirth axis.		
-17	At least one of the specified axis positions is not compatible with the associated Hirth joint for the "Swivel directly" function.		

<Cntrl>:	Controls the behavior of the function		
	Data type:	INT	
	The <Cntrl> parameter is decimal coded (unit to thousands position):		
	Unit position:	The unit position controls the response to errors.	
		xxx0	In the event of an error (return value < 0), alarm 14106 is output and program processing is aborted. Note: The alarm is also output irrespective of the value of the unit position when the <Cntrl> parameter is negative.
		xxx1	In the event of an error (return value < 0) no alarm is output. The user can react suitably in the program.
	Tens position:	Controls the behavior when an orientation axis with Hirth joint is present. Note: This parameter is only evaluated for the "Tool alignment" function (i.e. when the hundreds position has the value "0").	
		xx0x	The axis position is rounded off to the nearest position.
		xx1x	The axis positions are rounded off so that the difference of the β angle to its programmed value is minimal.
		xx2x	The axis positions are rounded off so that the β angle is equal to the highest possible value which is less than the programmed value (β is rounded down).
		xx3x	The axis positions are rounded off so that the β angle is equal to the lowest possible value which is greater than the programmed value (β is rounded up).
	Hundreds position:	Specifies which function is to be executed or the significance of the two following parameters <W1> and <W2>.	
		x0xx	"Tool alignment" function Parameters <W1> and <W2> have the following meaning: <ul style="list-style-type: none"> • <W1> = β • <W2> = γ The associated angles of the orientation axes are calculated.
		x1xx	"Direct tool alignment" function <W1> is the position specification for the second orientation axis, <W2> is the position specification for the third orientation axis of a 6-axis transformation. The position of the first orientation axis and the β and γ angles are defined which are compatible with the two position specifications. If no error occurs, two solutions are always output in the \$P_ORI_POS[<n>, <m>] system variables. The first index <n> (0 or 1) refers to the solution and the second index <m> (0 ... 2) to the orientation axis: <ul style="list-style-type: none"> • \$P_ORI_POS[0/1, 0]: Position of the first orientation axis • \$P_ORI_POS[0/1, 1]: Angle β • \$P_ORI_POS[0/1, 2]: Angle γ A check is made as to whether the position specifications <W1> and <W2> are compatible with any Hirth joints or active software limits. If this is not the case, a corresponding error number is returned (see <RetVal> parameter).

3.13 Tool offsets

			If the angles <W1> and <W2> are selected arbitrarily, the cutting edge of the tool is generally not in the machining plane. The angle γ through which the cutting edge is rotated out of the machining plane, must not be greater than the limit value which is defined by the setting data SD42999 \$SC_OR-ISOLH_INCLINE_TOL.
	Thousands position:		Specifies which positions of the solutions may be modified when the hundreds position has the value "0", i.e. for the "Tool alignment" function.
		0xxx	The calculated axis positions should be as close as possible to the current machine axis positions.
		1xxx	The calculated axis positions for modulo axes should be as close as possible to the middle of the modulo range, for other axes as close as possible to 0. For non-modulo axes, this means that the axis positions are reduced to the range -180° ... +180°.
		2xxx	The calculated axis positions should be reduced to the range -180° ... +180° irrespective of the axis type.
<W1>:	First angle The meaning results from the hundreds position of the <Cntrl> paramter.		
	Data type:	REAL	
<W1>:	Second angle The meaning results from the hundreds position of the <Cntrl> paramter.		
	Data type:	REAL	

Note

Parameters that have not been programmed have the default value "0".

Further information

The number of solutions found together with further status information when executing the ORISOLH function, can be read via the following system variables:

System variable	Meaning
\$P_ORI_POS [<n>, <m>]	Returns the angles of the orientation axes that result from the orientation programming.
	<n>: Index of the solution
	Range of values: 0, 1
	<m>: Index of the orientation axis
	Range of values: 0 ... 2
	The order of the orientation axes (1 ... 3) refers to the definition of the axes in \$NT_ROT_AX_NAME.
	When the ORISOLH function is called in the "Direct tool alignment" mode, the \$P_ORI_POS[0/1, 1] and P_ORI_POS[0/1, 2] variables contain the values of the two angles β and γ belonging to the two solutions.
	The first solution entered in \$P_ORI_POS[<n>, <m>], i.e. with the index <n> = 0, is always the solution that is selected by the control when the requested orientation is approached directly. The second index <m> refers to the orientation axis, i.e. on \$NT_ROT_AX_NAME.
	The axis positions entered in \$P_ORI_POS[<n>, <m>] take into account the offsets entered in \$NK_OFF and \$NK_OFF_FINE, i.e. these axis angles can be used in the following blocks to set the required orientation without any further modification.
	If a rotary axis is a Hirth axis, the solution positions are rounded off to the nearest position of rest of the Hirth joint. For Hirth jointed rotary axes, you can read the differences between the axis positions for the exact solutions and those of the solutions adapted to the Hirth incrementing in the \$P_ORI_DIFF system variable.
\$P_ORI_DIFF [<n>, <m>]	Returns the difference between the exact positions of the orientation axes and those provided in \$P_ORI_POS that result from the orientation programming.
	<n>: Index of the solution
	Range of values: 0, 1
	<m>: Index of the orientation axis
	Range of values: 0 ... 2
	The order of the orientation axes (1 ... 3) refers to the definition of the axes in \$NT_ROT_AX_NAME.
	The content can only be not equal to zero when the positions are incremented (Hirth joint), i.e. when the system data \$NT_HIRTH_INCR of the relevant axis is not equal to zero and when this axis is a manual rotary axis.

System variable	Meaning																				
\$P_ORI_SOL	<p>If for an orientation transformation with more than one orientation axis, the axis angles are calculated that should result in a specified orientation, there is generally more than one solution. The \$P_ORI_SOL system variables contain the number of valid solutions together with additional status information.</p> <p>The content of \$P_ORI_SOL is coded as follows:</p>																				
	<table border="1"> <tr> <td>Values < 0</td> <td>General error states</td> </tr> <tr> <td>-1</td> <td>No solutions have been calculated yet for the active transformation (missing call of ORISOLH).</td> </tr> <tr> <td>-2</td> <td>A transformation is not active, or the active transformation is not an orientation transformation (6-axis transformation) that can provide positions for a specified orientation programming.</td> </tr> <tr> <td>-4</td> <td>The desired orientation cannot be set with the present kinematics.</td> </tr> <tr> <td>-5</td> <td>No solution was found when the ORISOLH function was called in the "Direct tool alignment" mode.</td> </tr> <tr> <td>-6</td> <td>Angle γ is too large when the ORISOLH function was called in the "Direct tool alignment" mode.</td> </tr> <tr> <td>-7</td> <td>An angle was specified when the ORISOLH function was called in the "Direct tool alignment" mode that cannot be set because of the Hirth joint.</td> </tr> <tr> <td>-8</td> <td>The first orientation axis (frame axis) must not be parameterized as Hirth axis.</td> </tr> <tr> <td>-9</td> <td>The second as well as the third rotary axis has been parameterized as Hirth axis. Only one of the two axes can be the Hirth axis.</td> </tr> <tr> <td>-10</td> <td>No adaptation of the solution(s) to the Hirth joint has been found.</td> </tr> </table>	Values < 0	General error states	-1	No solutions have been calculated yet for the active transformation (missing call of ORISOLH).	-2	A transformation is not active, or the active transformation is not an orientation transformation (6-axis transformation) that can provide positions for a specified orientation programming.	-4	The desired orientation cannot be set with the present kinematics.	-5	No solution was found when the ORISOLH function was called in the "Direct tool alignment" mode.	-6	Angle γ is too large when the ORISOLH function was called in the "Direct tool alignment" mode.	-7	An angle was specified when the ORISOLH function was called in the "Direct tool alignment" mode that cannot be set because of the Hirth joint.	-8	The first orientation axis (frame axis) must not be parameterized as Hirth axis.	-9	The second as well as the third rotary axis has been parameterized as Hirth axis. Only one of the two axes can be the Hirth axis.	-10	No adaptation of the solution(s) to the Hirth joint has been found.
	Values < 0	General error states																			
	-1	No solutions have been calculated yet for the active transformation (missing call of ORISOLH).																			
	-2	A transformation is not active, or the active transformation is not an orientation transformation (6-axis transformation) that can provide positions for a specified orientation programming.																			
	-4	The desired orientation cannot be set with the present kinematics.																			
	-5	No solution was found when the ORISOLH function was called in the "Direct tool alignment" mode.																			
	-6	Angle γ is too large when the ORISOLH function was called in the "Direct tool alignment" mode.																			
	-7	An angle was specified when the ORISOLH function was called in the "Direct tool alignment" mode that cannot be set because of the Hirth joint.																			
	-8	The first orientation axis (frame axis) must not be parameterized as Hirth axis.																			
-9	The second as well as the third rotary axis has been parameterized as Hirth axis. Only one of the two axes can be the Hirth axis.																				
-10	No adaptation of the solution(s) to the Hirth joint has been found.																				
Values > 0	Number of mathematically possible solutions without consideration of axis limits and any error conditions.																				
Unit position	<table border="1"> <tr> <td>0</td> <td> <p>There is no solution, i.e. the requested orientation cannot be set.</p> <p>There can be three different causes for this case:</p> <ul style="list-style-type: none"> In principle, the requested orientation cannot be achieved because of the machine kinematics (orientation axes not arranged at right angles) even with an arbitrary traversing range of the orientation axes. In this case, the tens and hundreds positions of \$P_ORI_SOL are both zero, the \$P_ORI_STAT status variables assigned to the orientation axis have the value "-4". The calculated solutions cannot be achieved because they would violate the axis limits. The positions of the orientation axes that would result without the axis limits, can be read in \$P_ORI_POS. Axis positions were specified when the ORISOLH function was called in the "Direct tool alignment" mode which would result in either the orientation vector or the orientation normal vector of the tool being aligned parallel to the first orientation axis, whose position is to be calculated. The position of this axis is not defined in these cases. </td> </tr> </table>	0	<p>There is no solution, i.e. the requested orientation cannot be set.</p> <p>There can be three different causes for this case:</p> <ul style="list-style-type: none"> In principle, the requested orientation cannot be achieved because of the machine kinematics (orientation axes not arranged at right angles) even with an arbitrary traversing range of the orientation axes. In this case, the tens and hundreds positions of \$P_ORI_SOL are both zero, the \$P_ORI_STAT status variables assigned to the orientation axis have the value "-4". The calculated solutions cannot be achieved because they would violate the axis limits. The positions of the orientation axes that would result without the axis limits, can be read in \$P_ORI_POS. Axis positions were specified when the ORISOLH function was called in the "Direct tool alignment" mode which would result in either the orientation vector or the orientation normal vector of the tool being aligned parallel to the first orientation axis, whose position is to be calculated. The position of this axis is not defined in these cases. 																		
0	<p>There is no solution, i.e. the requested orientation cannot be set.</p> <p>There can be three different causes for this case:</p> <ul style="list-style-type: none"> In principle, the requested orientation cannot be achieved because of the machine kinematics (orientation axes not arranged at right angles) even with an arbitrary traversing range of the orientation axes. In this case, the tens and hundreds positions of \$P_ORI_SOL are both zero, the \$P_ORI_STAT status variables assigned to the orientation axis have the value "-4". The calculated solutions cannot be achieved because they would violate the axis limits. The positions of the orientation axes that would result without the axis limits, can be read in \$P_ORI_POS. Axis positions were specified when the ORISOLH function was called in the "Direct tool alignment" mode which would result in either the orientation vector or the orientation normal vector of the tool being aligned parallel to the first orientation axis, whose position is to be calculated. The position of this axis is not defined in these cases. 																				

System variable	Meaning	
	1	<p>There is a solution.</p> <p>There can be three different causes for this case:</p> <ul style="list-style-type: none"> Based on the specified orientation and the machine kinematics, there is only one solution (from the mathematical point of view, two coinciding solutions) even without consideration of the axis limits. This case occurs at the edge of the orientation range for kinematics that are not at right angles. \$P_ORI_POS contains both (identical) solutions. There is only one solution because a second solution is invalid due to the violated axis limits. The valid solution is always the first solution in \$P_ORI_POS. The second solution which would result when the axis limits are not taken into account, can also be read in \$P_ORI_POS. This is the normal case when the ORISOLH function is called in the "Direct tool alignment" mode. For the specified axis positions of two orientation axes, there is generally only one valid position for the missing orientation axis to be calculated.
	2	There are two solutions.
	8	There are an infinite number of solutions, i.e. the position of an orientation axis (the polar axis) is arbitrary. However, from the two possible positions of the other axes, one is excluded because of the violated axis limits.
	9	There are an infinite number of solutions, i.e. the position of an orientation axis (the polar axis) is indefinite. The indefinite axis can be determined from the hundreds position or from the \$P_ORI_STAT system variable.
Values > 0 Tens position	Bit-coded display for violated axis limits. The precise cause of the error can be determined from the \$P_ORI_STAT system variable.	
	Bit 0 (value 10):	For at least one solution, at least one axis limit of the first orientation axis is violated.
	Bit 1 (value 20):	For at least one solution, at least one axis limit of the second orientation axis is violated.
Values > 0 Hundreds position	Bit-coded display for non-defined axis positions (can only occur when there is an infinite number of solutions, i.e. when the unit position is equal to "9").	
	Bit 0 (value 100):	The position of the first orientation axis is not defined.
	Bit 1 (value 200):	The position of the second orientation axis is not defined.
	Bit 2 (value 400):	The position of the third orientation axis is not defined.
The designations first, second and third orientation axis refer to the definition of the axes in \$NT_ROT_AX_NAME.		

System variable	Meaning		
\$P_ORI_STAT [<n>]	Returns the status for each of the maximum three orientation axes after ORISOLH has been called.		
	<n>:	Index of the orientation axis (corresponds to the index of the relevant orientation axis in \$NT_ROT_AX_NAME)	
		Range of values: 0 ... 2 The order of the orientation axes (1 ... 3) refers to the definition of the axes in \$NT_ROT_AX_NAME.	
	The content of \$P_ORI_STAT is coded as follows:		
	Values < 0	General error states	
		-1	The status is not defined (missing call of ORISOLH).
		-2	A transformation is not active, or the active transformation is not an orientation transformation (6-axis transformation) that can provide positions for a specified orientation programming.
		-3	The axis is not included in the active transformation.
		-4	The position of the axis cannot be calculated because the requested orientation cannot be achieved with the present kinematics even with an arbitrary assumed traversing range of the axis.
		-5	Axis positions were specified when the ORISOLH function was called in the "Direct tool alignment" mode which would result in either the orientation vector or the orientation normal vector of the tool being aligned parallel to the first orientation axis, whose position is to be calculated. The position of this axis is not defined in these cases.
		-6	Angle γ is too large when the ORISOLH function was called in the "Direct tool alignment" mode.
		-7	An angle was specified when the ORISOLH function was called in the "Direct tool alignment" mode that cannot be set because of the Hirth joint.
		-8	The first orientation axis (frame axis) must not be parameterized as Hirth axis.
-9		The second as well as the third rotary axis has been parameterized as Hirth axis. Only one of the two axes can be the Hirth axis.	
-10	No adaptation of the solution(s) to the Hirth joint has been found.		
Values > 0	Bit-coded display for violated axis limits of the first solution.		
Unit position	Bit 0 (value 1):	The first solution violates the lower axis limit.	
	Bit 1 (value 2):	The first solution violates the upper axis limit.	
Values > 0	Bit-coded display for violated axis limits of the second solution.		
Tens position	Bit 0 (value 10):	The second solution violates the lower axis limit.	
	Bit 1 (value 20):	The second solution violates the upper axis limit.	
Values > 0	Display of a non-defined axis position.		
Hundreds position	Bit 0 (value 100):	The position of the orientation axis is not defined, i.e. the requested orientation is achieved with each arbitrary setting of the rotary axis (polar po-	

System variable	Meaning
	<p>sition). This information is also contained in the \$P_ORI_SOL system variable.</p> <p>Of the error numbers that indicate a violation of the axis limits, several can occur simultaneously. When an axis limit is violated, an attempt is made to reach a position within the permissible axis limits by adding or subtracting multiples of 360°. If this is not possible, it is not clearly defined whether the lower or the upper axis limit has been violated.</p> <p>If there is no solution for the requested orientation (\$P_ORI_SOL = 0), the status of the orientation axes in the transformation is "0".</p>

Note**\$NT_ROT_AX_NAME**

This system variable refers to a maximum of three axes used for setting the orientation. It contains the names of the chain elements (\$NK_NAME) that define the machine axes (rotary axes) that must perform the orientation movements resulting from a kinematic transformation. The order in which the maximum three rotary axes are contained in this system variable is irrelevant for the machine kinematics because this is derived from the structure of the kinematic chains. However, as it defines the order in which other variables access the rotary axes, the order of the orientation axes in \$NT_ROT_AX_NAME must match the kinematic description.

Note**Status information**

The status information that shows, for example, that an orientation cannot be achieved or can only be achieved when relevant axis limits are violated, does not trigger an NC alarm. It is the responsibility of the user to react suitably to the specified conditions.

3.13.11.2 Activating the modification of the offset data for rotatable tools (CUTMOD, CUTMODK)

The modification of the offset data for rotatable tools is activated in the NC program via the CUTMOD (in combination with orientable tool carriers) or CUTMODK language command (for orientation transformations that were defined by means of kinematic chains).

Note

As the orientable tool carriers and orientation transformations that were defined by means of kinematic chains cannot be active at the same time, there are no conflicts between the two variants.

Syntax

CUTMOD = <Value>

or

CUTMODK = <Command>

Meaning

CUTMOD:	Function call in combination with orientable tool carriers		
<Value>:	Assigned value		
	Data type:	INT	
	Value:	0	The function is deactivated. The values supplied from system variables \$P_AD... are the same as the corresponding tool parameters.
		> 0	The function is activated if an orientable tool carrier with the specified number is active, i.e. the activation is linked to a specific orientable tool carrier. The values supplied from system variables \$P_AD... may be modified with respect to the corresponding tool parameters depending on the active rotation. The deactivation of the designated orientable tool carrier temporarily deactivates the function; the activation of another orientable tool carrier permanently deactivates it. This is the reason why in the first case, the function is re-activated when again selecting the same orientable tool carrier; in the second case, a new selection is required - even if at a subsequent time, the orientable tool carrier is re-activated with the specified number. The function is not influenced by a reset.
		-1	The function is always activated if an orientable tool carrier is active. When changing the tool carrier or when de-selecting it and a subsequent new selection, CUTMOD does not have to be set again.
		-2	The function is always activated if an orientable tool carrier is active whose number is the same as the currently active orientable tool carrier. If an orientable tool carrier is not active, then this has the same significance as CUTMOD=0. If an orientable tool carrier is active, then this has the same significance as when directly specifying the actual tool carrier number.
< -2		Values less than 2 are ignored, i.e. this case is treated as if CUTMOD was not programmed. Note: This value range should not be used as it is reserved for possible subsequent expansions.	
CUTMODK:	Function call in combination with orientation transformations that have been defined by means of kinematic chains		

<Command>:	Assigned Command		
	Data type:	STRING	
	Value:	"NEW"	The states of an active transformation defined with kinematic chains relevant for the "Modification of the offset data", the name of the transformation and the current contour frame are saved. Note: This command is only permissible when a suitable transformation (TRAORI_DYN, TRAORI_STAT or TRAANG_K) is active.
		"OFF"	Switches the active "Modification of the offset data" off. The data previously stored with "NEW" is retained. Note: This command is also permissible when CUTMODK is not active. It then remains without effect. Any data set present for the "Modification of the offset data" is retained.
		"ON"	With this command, the "Modification of the offset data" is reactivated with a data set previously stored with the "NEW" command. If a transformation with the name of the stored data set is active when this command is executed, the "Modification of the offset data" takes effect immediately. Otherwise, the activation is delayed until an active transformation is activated.
"CLEAR"		As with the "OFF" command, switches the "Modification of the offset data" off and also deletes the stored data set. Note: This command is also permissible when CUTMODK is not active.	

Note**SD42984 \$SC_CUTDIRMOD**

The CUTMOD or CUTMODK command replaces the function that can be activated using the setting data SD42984 \$SC_CUTDIRMOD. However, this function remains available unchanged. However, as it doesn't make sense to use both functions in parallel, it can only be activated if CUTMOD is equal to zero and CUTMODK is the zero string.

Further information**Reading modified offset data**

The modified offset data is provided in the following system variables and OPI variables:

Meaning	System variable	OPI variable
Cutting edge position	\$P_AD[2]	cuttEdgeParam2
Holder angle	\$P_AD[10]	cuttEdgeParam10
Cut direction	\$P_AD[11]	cuttEdgeParam11
Clearance angle	\$P_AD[24]	cuttEdgeParam24

The data is always modified with respect to the corresponding tool parameters (\$TC_DP2[... , ...] etc.) when the "Modification of the offset data for rotatable tools" function was activated with the CUTMOD or CUTMODK command and the tool was rotated by an orientable tool carrier or a suitable orientation transformation.

Further function-relevant system variables

System variable	Meaning
\$P_CUTMOD_ANG / \$AC_CUTMOD_ANG	Returns the angle through which a tool was rotated in the active machining plane and the modified cutting edge data available for the CUTMOD and CUTMODK functions.
\$P_CUTMOD / \$AC_CUTMOD	Reads the currently valid value that was last programmed with the CUTMOD command (number of the tool carrier for which the modification of the offset data should be activated). If the last programmed value was CUTMOD = -2 (activation with the currently active orientable tool carrier), then the value "-2" is not returned in the system variable, but rather the number of the orientable tool carrier active at the time of programming.
\$P_CUTMODK / \$AC_CUTMODK	Reads the name of the transformation under which the currently valid data set for the "Modification of the offset data" was created.
\$P_CUT_INV / \$AC_CUT_INV	Supplies the value TRUE if the tool is rotated so that the spindle direction of rotation must be inverted. To do this, the following four conditions must be fulfilled in the block to which the read operations refer: <ol style="list-style-type: none"> 1. If a turning or grinding tool is active (tool types 400 to 599 and / or SD42950 \$SC_TOOL_LENGTH_TYPE = 2). 2. The modification of the offset data was activated with the CUTMOD or CUTMODK command. 3. An orientable tool carrier or an orientation transformation defined with kinematic chains is active, which was selected with the CUTMOD or CUTMODK command. 4. The tool is rotated by the orientable tool carrier or the kinematic orientation transformation so that the resulting normal of the tool cutting edge is rotated with respect to the initial position by more than 90° (typically 180°). <p>If at least one of the specified four conditions is not fulfilled, the variable returns the value FALSE. For tools whose cutting edge position is not defined, the value of the variable is always FALSE.</p>

System variable	Meaning
\$P_CUTMOD_ERR	Error state after the last call of the CUTMOD function The CUTMOD function can also be called implicitly for a tool change. At a reset, the variable is reset to zero. It is reset at every tool change and, if required, rewritten. The variable is bit-coded. The bits have the following meanings:
	Bit 0: No valid cut direction is defined for the active tool.
	Bit 1: The cutting edge angle (clearance angle and holder angle) of the active tool are both zero.
	Bit 2: The clearance angle of the active tool has an impermissible value (< 0° or > 180°).
	Bit 3: The holder angle of the active tool has an impermissible value (< 0° or > 90°).
	Bit 4: The plate angle of the active tool has an impermissible value (< 0° or > 90°).
	Bit 5: The cutting edge position - holder angle combination of the active tool is not permitted (the holder angle must be ≤ 90° for cutting edge position 1 to 4; for cutting edge positions 5 to 8 it must be ≥ 90°).
	Bit 6: Illegal rotation of the active tool. The tool was rotated out of the active machining plane by ± 90° (with a tolerance of about 1°). The cutting edge position is therefore no longer defined in the machining plane.
	Bit 7: The cutting plate is not in the machining plane and the angle between the cutting plate and the machining plane exceeds the upper limit specified with the setting data SD42998 \$SC_CUT-MOD_PLANE_TOL.
	Bit 8: The cutting plate is not in the machining plane. Angle α is greater than 1°. Angle α is the angle of rotation around the coordinate axis which is perpendicular to the axis of rotation of angle β as well as to the axis of rotation of angle γ (the X axis for G18).

\$P_...: Preprocessing variables

\$AC_...: Main run variables

All main run variables can be read in synchronized actions. A read access operation from the preprocessing generates a preprocessing stop.

Plane change

To determine the modified cutting edge position, cutting direction and holder or clearance angle, the evaluation of the cutting edge in the active plane (G17 - G19) is decisive.

However, if setting data SD42940 \$SC_TOOL_LENGTH_CONST (change of the tool length component when selecting the plane) has a valid non-zero value (plus or minus 17, 18 or 19), its contents define the plane in which the relevant quantities are evaluated.


This priority rule of the setting data over the G code can be deactivated by setting bit 18 of the machine data \$MC_TOOL_PARAMETER_DEF_MASK. This means that when this bit is set, the plane defined with the G command of group 6 is still valid.

Effectiveness of the modified cutting data

The modified cutting edge position and the modified cutting edge reference point are immediately effective when programming, even for a tool that is already active. A tool does not have to be re-selected for this purpose.

Example

For a tool with cutting edge position 3 and an orientable tool carrier that can rotate the tool around the B axis, the cutting edge position shall be modified after a tool rotation with the aid of the CUTMOD command.



- S: Cutting edge center point
- P: Cutting edge reference point
- SL: Cutting edge position

Program code	Comment
N10 \$TC_DP1[1,1]=500	
N20 \$TC_DP2[1,1]=3	;Cutting edge position
N30 \$TC_DP3[1,1]=12	
N40 \$TC_DP4[1,1]=1	
N50 \$TC_DP6[1,1]=6	
N60 \$TC_DP10[1,1]=110	; Holder angle
N70 \$TC_DP11[1,1]=3	; Cut direction
N80 \$TC_DP24[1,1]=25	; Clearance angle
N90 \$TC_CARR7[2]=0 \$TC_CARR8[2]=1 \$TC_CARR9[2]=0	; B axis

Program code	Comment
N100 \$TC_CARR10[2]=0 \$TC_CARR11[2]=0 \$TC_CARR12[2]=1	; C axis
N110 \$TC_CARR13[2]=0	
N120 \$TC_CARR14[2]=0	
N130 \$TC_CARR21[2]=X	
N140 \$TC_CARR22[2]=X	
N150 \$TC_CARR23[2]="M"	
N160 TCOABS CUTMOD=0	
N170 G18 T1 D1 TCARR=2	; X Y Z
N180 X0 Y0 Z0 F10000	; 12.000 0.000 1.000
N190 \$TC_CARR13[2]=30	
N200 TCARR=2	
N210 X0 Y0 Z0	; 10.892 0.000 -5.134
N220 G42 Z-10	; 8.696 0.000 -17.330
N230 Z-20	; 8.696 0.000 -21.330
N240 X10	; 12.696 0.000 -21.330
N250 G40 X20 Z0	; 30.892 0.000 -5.134
N260 CUTMOD=2 X0 Y0 Z0	; 8.696 0.000 -7.330
N270 G42 Z-10	; 8.696 0.000 -17.330
N280 Z-20	; 8.696 0.000 -21.330
N290 X10	; 12.696 0.000 -21.330
N300 G40 X20 Z0	; 28.696 0.000 -7.330
N310 M30	

The numerical values in the comments specify the end of block positions in the machine coordinates (MCS) in the sequence X → Y → Z.

Explanations

In block N180, initially the tool is selected for CUTMOD=0 and non-rotated tool holders that can be orientated. As all offset vectors of the tool holder that can be orientated are 0, the position that corresponds to the tool lengths specified in \$TC_DP3[1,1] and \$TC_DP4[1,1] is approached.

The tool holder that can be orientated with a rotation of 30° around the B axis is activated in block N200. As the cutting edge position is not modified due to CUTMOD=0, the old cutting edge reference point is decisive just as before. This is the reason why in block N210 the position is approached, which keeps the old tool nose reference point at the zero (i.e. the vector (1, 12) is rotated through 30° in the Z/X plane).

In block N260, contrary to block N200, CUTMOD=2 is effective. As a result of the tool holder rotation that can be orientated, the modified cutting edge position becomes 8. Deviating axis positions also result from this.

The tool radius compensation (TRC) is activated in blocks N220 and/or N270. The different cutting edge position in both program sections has no effect on the end positions of the blocks

in which the TRC is active; the corresponding positions are therefore identical. The different cutting edge positions only become effective again in the deselect blocks N260 and/or N300.

3.13.12 Working with tool environments

Overview of functions

- Save tool environment (TOOLENV) (Page 766)
- Delete tool environment (DELTOOLENV) (Page 769)
- Read T, D and DL number (GETTENV) (Page 770)
- Read tool lengths and/or tool length components (GETTCOR) (Page 771)
- Change tool components (SETTCOR) (Page 777)

System variables overview

- Read information about the saved tool environments (\$P_TOOLENVN, (\$P_TOOLENV) (Page 771)

3.13.12.1 Save tool environment (TOOLENV)

The TOOLENV function is used to save any current states needed for the evaluation of tool data stored in the memory.

The individual data are as follows:

- The active G command of group:
 - 6 (G17, G18, G19)
 - 56 (TOWSTD, TOWMCS, TOWWCS, TOWBCS, TOWTCS, TOWKCS)
- The active transverse axis
- Machine data:
 - MD18112 \$MN_MM_KIND_OF_SUMCORR (properties of the summed offsets in the TO area)
 - MD20360 \$MC_TOOL_PARAMETER_DEF_MASK (definition of tool parameters).

- Setting data:
 - SD42900 \$SC_MIRROR_TOOL_LENGTH (sign change tool length when mirroring)
 - SD42910 \$SC_MIRROR_TOOL_WEAR (sign change tool wear when mirroring)
 - SD42920 \$SC_WEAR_SIGN_CUTPOS (sign of the tool wear with cutting edge systems)
 - SD42930 \$SC_WEAR_SIGN (sign of wear)
 - SD42935 \$SC_WEAR_TRANSFORM (transformations for tool components)
 - SD42940 \$SC_LENGTH_CONST (change of the tool length components for a plane change)
 - SD42942 \$SC_TOOL_LENGTH_CONST_T (change of tool length components for turning tools at change of plane)
 - SD42950 \$SC_TOOL_LENGTH_TYPE (allocation of the tool length components independent of tool type)
 - SD42954 \$SC_TOOL_ORI_CONST_M (change of tool orientation components for milling tools at change of plane)
 - SD42956 \$SC_TOOL_ORI_CONST_T (change of tool orientation components for turning tools at change of plane)
- The orientation component of the current complete frame (rotation and mirroring, no work offsets or scaling)
- The orientation component and the resulting length of the active toolholder with orientation capability
- The orientation component and the resulting length of an active transformation

In addition to the data describing the environment of the tool, the T number, D number and DL number of the active tool are also stored, so that the tool can be accessed later in the same environment as the TOOLENV call, without having to name the tool again.

Syntax

```
<Status> = TOOLENV(<name>)
```

Meaning

TOOLENV (. . .):	Predefined function to save a tool environment	
	Alone in the block:	Yes

<Status>:	Function return value. Negative values indicate error states.		
	Data type:	INT	
	Value:	0	Function OK
		-1	No memory reserved for tool environments: MD18116 \$MN_MM_NUM_TOOL_ENV = 0 This means that the "tool environments" functionality is not available.
		-2	No more free memory locations for tool environments available.
		-3	Null string illegal as name of a tool environment.
-4		No parameter (<name>) specified.	
Parameters			
1	<name>:	Name, under which the current data set should be saved. If a data set of the same name already exists, then it is overwritten. In this case, the status is "0".	
		Data type: STRING	

Additional information

Base dimension/adaptor dimension – tool length compensation

When the tool magazine management is active (only available with the "Tool management" option!), the value of the following machine data defines whether the adapter length or the tool base dimension (cutting edge-specific parameters \$TC_DP21, \$TC_DP22 and \$TC_DP23) is incorporated in the calculation of the tool length:

MD18104 \$MN_MM_NUM_TOOL_ADAPTER (tool adapter in TO area).

Since a change to this machine data only takes effect after the control system has powered up, it is not saved in the tool environment.

Resulting length of toolholders with orientation capability and transformations:

Note

Both toolholders with orientation capability and transformations can use system variables or machine data, which act as additional tool length components, and which can be subjected partially or completely to the rotations performed. The resulting additional tool length components must also be saved when TOOLENV is called, because they represent part of the environment, in which the tool is used.

Adapter transformation

The adapter transformation is a property of the tool adapter and thus of the complete tool. It is, therefore, not part of a tool environment, which can be applied to another tool.

By saving the complete data necessary to determine the overall tool length, it is possible to calculate the effective length of the tool at a later point in time, even if the tool is no longer active or if the conditions of the environment (e.g. G codes or setting data) have changed. Similarly, the effective length of a different tool can be calculated assuming that it would be used under the same conditions as the tool, for which the status was saved.

Maximum number of data sets for tool environments

Machine data MD18116 \$MN_MM_NUM_TOOL_ENV is used to define the maximum number of data sets that can be saved to describe the tool environments. The data are in the TOA area. They are kept even when the control system is switched off.

Data cannot be backed up. This means that this data cannot be transferred between the different control systems.

3.13.12.2 Delete tool environment (DELTOOLENV)

The DELTOOLENV function is used to delete the data sets that are used to describe tool environments. Deletion means that the set of data stored under a particular name can no longer be accessed (an access attempt triggers an alarm).

Note

Data sets can only be deleted using the DELTOOLENV function, by an INITIAL.INI download or by a cold start (NC power up with default machine data). There are no additional automatic deletion operations.

Syntax

<Status> = DELTOOLENV (<name>)

<Status> = DELTOOLENV ()

Meaning

DELTOOLENV (...):		Predefined function to delete a tool environment		
		Alone in the block:	Yes	
<Status>:		Function return value. Negative values indicate error states.		
		Data type:	INT	
		Value:	0	Function OK
			-1	No memory reserved for tool environments: MD18116 \$MN_MM_NUM_TOOL_ENV = 0 This means that the "tool environments" functionality is not available.
	-2	A tool environment with the specified name does not exist.		
Parameters				
1	<name>:	Name of data set to be deleted		
		Data type:	STRING	
DELTOOLENV ():		DELTOOLENV () deletes data sets describing tool environments without specifying a name		

3.13.12.3 Read T, D and DL number (GETTENV)

The GETTENV function is used to read the T, D and DL numbers stored in a tool environment.

Syntax

<Status> = GETTENV(<name>, <TDDL>)

Meaning

GETTENV(...):		Predefined function to read T, D and DL numbers in a data set to describe a tool environment	
		Alone in the block:	Yes
<Status>:		Function return value. Negative values indicate error states.	
		Data type:	INT
		Value:	0 Function OK
			-1 No memory reserved for tool environments: MD18116 \$MN_MM_NUM_TOOL_ENV = 0 This means that the "tool environments" functionality is not available.
			-2 A tool environment with the specified name does not exist.
Parameters			
1	<name>:	Name of the data set from which the T, D and DL numbers are to be read	
		Data type:	STRING
2	<TDDL>:	The field of this result parameter contains the T, D and DL numbers of the tool, whose tool environment is saved in the specified data set:	
		<ul style="list-style-type: none"> • <TDDL> [0]: T number • <TDDL> [1]: D number • <TDDL> [2]: DL number 	
		Data type:	INT[3]
GETTENV(, <TDDL>), GETTENV("", <TDDL>):		When calling function GETTENV, it is permissible to omit the first parameter – or to transfer the null string as first parameter. In these two special cases, in <TDDL>, the T, D and DL numbers of the active tool are returned.	

3.13.12.4 Read information about the saved tool environments (\$P_TOOLENVN, \$P_TOOLENV)

Information regarding the saved tool environments can be read using the following system variables:

\$P_TOOLENVN:	Supplies the number of data sets (which have still not been deleted) – defined using TOOLENV – to describe tool environments		
	Syntax:	<n> = \$P_TOOLENVN	
	Meaning:	<n>:	Number of defined data sets
			Data type: INT
			Value range: 0 ... MD18116 \$MN_MM_NUM_TOOL_ENV
This system variable can be accessed even if no tool environments are possible (MD18116 = 0). In this case, the return value is "0".			
\$P_TOOLENV:	Supplies the name of the <i>th data set to describe a tool environment		
	Syntax:	<Name> = \$P_TOOLENV[<i>]	
	Meaning:	<name>:	Name of the data set with number <i>
			Data type: STRING
		<i>:	Number of the data set
			Data type: INT
			Value range: 1 ... \$P_TOOLENVN
The assignment of numbers to data sets is not fixed, but can be changed as a result of deleting or creating data sets. The data sets are numbered internally. If <i> refers to a data set that has not been defined, then the null string is returned. If index <i> is not valid, i.e. <i> is less than 1 or higher than that the maximum number of data sets for tool environments (MD18116 \$MN_MM_NUM_TOOLENV), then the following alarm is output: Alarm 17020 "inadmissible array index 1"			

3.13.12.5 Read tool lengths and/or tool length components (GETTCOR)

The GETTCOR function is used to read out tool lengths or tool length components.

The parameters can be used to specify which components are considered and the conditions under which the tool is used.

Syntax

```
<Status> = GETTCOR(<Len>[, <Comp>, <Stat>, <T>, <D>, <DL>])
```

Meaning

GETTCOR(...):	Predefined function to read tool lengths or to read tool length components	
	Alone in the block:	Yes

<Status>:	Function return value. Negative values indicate error states.		
	Data type:	INT	
	Value:	0	Function OK
		-1	No memory reserved for tool environments: MD18116 \$MN_MM_NUM_TOOL_ENV = 0 This means that the "tool environments" functionality is not available.
		-2	A tool environment with the name specified under <Stat> does not exist.
		-3	Invalid string in parameter <Comp>. Causes of this error can be invalid characters or characters programmed twice.
		-4	Invalid T number
		-5	Invalid D number
		-6	Invalid DL number
		-7	Attempt to access a non-existent memory module.
-8		Attempt to access a non-existent option (programmable tool orientation, tool management).	
-9	The <Comp> string contains a colon (identifier for the specification of a coordinate system), but it is not followed by a valid character denoting the coordinate system.		
Parameters			
1	<Len>:	Result vector	
		Data type: REAL[11]	
<p>The vector components are arranged in the following order:</p> <ul style="list-style-type: none"> • <Len> [0]: Tool type • <Len> [1]: Cutting edge position • <Len> [2]: Abscissa • <Len> [3]: Ordinate • <Len> [4]: Applicate • <Len> [5]: Tool radius <p>The coordinate system defined in <Comp> and <Stat> is used as the reference coordinate system for the length components. If a coordinate system is not defined in <Comp>, then tool lengths are displayed in the machine coordinate system.</p> <p>The assignment of the abscissa, ordinate and applicate to the geometry axes depends on the active plane used in the tool environment. This means, for G17, the abscissa is parallel to X, with G18 it is parallel to Z, etc.</p> <p>Components <Len>[6] to <Len>[10] contain the additional parameters, which can be used to specify the geometry description of a tool (e.g. \$TC_DP7 to \$TC_DP11 for the geometry and the corresponding components for wear or sum and setup offsets).</p> <p>These 5 additional elements and the tool radius are only defined for components E, G, S, and W. Their evaluation does not depend on <Stat>. The corresponding values in <Len>[6] to <Len>[10] can thus only be not equal to zero if at least one of the four specified components is involved in the tool length calculation. The remaining components do not influence the result. The dimensions refer to the control's basic system (inch or metric).</p>			

2	<Comp>:	Tool length components (optional)			
		Data type:	STRING		
		The character string consists of two substrings, which are separated from one another by a colon.			
		General form: "<SubStr_1> [: <SubStr_2>]"			
		<SubStr_1>:	The first substring designates the tool length components to be taken into account when calculating the tool length.		
			The order of the characters in the substrings, and their notation (upper or lower case), is arbitrary. Any number of blanks or white spaces can be inserted between the characters.		
			Note: It is not permissible that the characters in the substring are programmed twice.		
			Charac- ters:	-	Minus symbol (only allowed as first character) The complete tool length is calculated, minus the components specified in the next string.
				C	Adapter or tool base dimension (whichever of the two alternative components is active for the tool in use)
				E	Setup offsets
G	Geometry				
K	Kinematic transformation (is only evaluated for generic 3, 4 and 5-axis transformation)				
S	Summed offsets				
T	Toolholder with orientation capability				
W	Wear				
If the first substring is empty (except for white spaces), the complete tool length is calculated allowing for all components. This applies even if the <Comp> parameter is not specified.					
<Substr_2>:	The optional second substring identifies the coordinate system, in which the tool length is to be output.				
	The second substring only comprises one single relevant character.				
	Charac- ters:	A	Adjustable coordinate system (ACS)		
		B	Basic coordinate system (BCS)		
		K	Tool coordinate system of kinematic transformation (KCS)		
		M	Machine coordinate system (MCS)		
		T	Tool coordinate system (TCS)		
W		Workpiece coordinate system (WCS)			
If no coordinate system is specified, the evaluation is performed in the MCS (machine coordinate system). If any rotations are to be taken into account, they are specified in the tool environment defined in <Stat>.					

3	<_Stat>:	Name of the data set for describing a tool environment (optional)	
		Data type:	STRING
		If the value of this parameter is the null string (""), or is not specified, then the current status is used. The current tool is used if a tool is not specified.	

4	<T>:	Internal T number of the tool (optional).	
		Data type:	INT
		<p>If this parameter is not specified or if its value is "0", then the tool stored in <Stat> is used.</p> <p>If the value of this parameter is "-1", then the T number of the active tool is used. It is also possible to explicitly specify the number of the active tool.</p> <p>Note: If <Stat> is not specified, the actual status is used as the tool environment. Since <T> = 0 refers to the T number saved in the tool environment, the active tool is used in this environment, i.e. parameters <T> = 0 and <T> = -1 have the same meaning in this special case.</p>	
5	<D>:	Cutting edge of the tool (optional).	
		Data type:	INT
		<p>If this parameter is not specified, or if its value is "0", then the D number used is based on the source of the T number. If the T number from the tool environment is used, then the D number of the tool environment is also read, otherwise the D number of the currently active tool is read.</p>	
6	<DL>:	Number of the offset dependent on the location (optional).	
		Data type:	INT
		<p>If this parameter is not specified, then the DL number used is based on the source of the T number. If the T number from the tool environment is used, then the D number of the tool environment is also read, otherwise the D number of the currently active tool is read.</p>	

Examples

GETTCOR (_LEN)	Calculates the tool length of the currently active tool in the machine coordinate system allowing for all components.
GETTCOR (_LEN, "CGW:W")	Calculates the tool length for the active tool, consisting of the adapter or tool base dimension, geometry and wear. Further components, such as toolholder with orientation capability or kinematic transformation, are not considered. Output in the workpiece coordinate system.
GETTCOR (_LEN, "-K:B")	Calculates the complete tool length of the active tool without allowing for the length components of a possibly active kinematic transformation. Output in the basic coordinate system.
GETTCOR (_LEN, ":M", "Testenv1", , 3)	Calculates the complete tool length in the machine coordinate system for the tool stored in the tool environment named "Testenv1". However, the calculation is performed for cutting edge number D3, regardless of the cutting edge number stored.

Additional information

Adapter transformation/toolholder with orientation capability/kinematic transformation

Any rotations and component exchanges initiated by the adapter transformation, toolholder with orientation capability and kinematic transformation, are part of the tool environment. They are thus always performed, even if the corresponding length component is not supposed to be included. If this is undesirable, tool environments must be defined, in which the corresponding transformations are not active. In many cases (i.e. any time a transformation or toolholder with orientation capability is not used on a machine), the data sets stored for the tool environments automatically fulfill these conditions, with the result that the user does not need to make special provision.

Turning and grinding tools: Calculating the tool length depending on MD20360 \$MC_TOOL_PARAMETER_DEF_MASK

The following machine data defines how the wear and tool length are to be evaluated if a diameter axis is used for turning and grinding tools.

MD20360 \$MC_TOOL_PARAMETER_DEF_MASK (definition of tool parameters).

Bit	Value
0	For turning and grinding tools, the wear parameter of the transverse axis is taken into account as the diameter value:
	= 0 (default) No
	= 1 Yes
1	For turning and grinding tools, the tool length component of the transverse axis is taken into account as the diameter value:
	= 0 (default) No
	= 1 Yes

If the bits involved are set, the associated entry is weighted with a factor of 0.5. This weighting is reflected in the tool length returned by GETTCOR.

Example:

MD20360 \$MC_TOOL_PARAMETER_DEF_MASK = 3

MD20100 \$MC_DIAMETER_AX_DEF (geometry axis with transverse axis function) = "X"

X is diameter axis (standard turning machine configuration)

Program code	Comment
N30 \$TC_DP1[1,1]=500	
N40 \$TC_DP2[1,1]=2	
N50 \$TC_DP3[1,1]=3.0	; geometry L1
N60 \$TC_DP4[1,1]=4.0	
N70 \$TC_DP5[1,1]=5.0	
N80 \$TC_DP12[1,1]=12.0	; wear L1
N90 \$TC_DP13[1,1]=13.0	
N100 \$TC_DP14[1,1]=14.0	
N110 T1 D1 G18	
N120 R1=GETTCOR(_LEN, "GW")	
N130 R3=_LEN[2]	; 17.0 (= 4.0 + 13.0)

Program code	Comment
N140 R4=_LEN[3]	; 7.5 (= 0.5 * 3.0 + 0.5 * 12.0)
N150 R5=_LEN[4]	; 19.0 (= 5.0 + 14.0)
N160 M30	

Length components of the kinematic transformation and toolholder with orientation capability

If a **toolholder with orientation capability** is taken account of during the tool length calculation, the following vectors are included in that calculation:

Type	Vectors
M	I1 and I2
T	I1, I2 and I3
P	The tool length is not influenced by the toolholder with orientation capability.

In generic **5-axis transformation**, the following machine data are included in the tool length calculation for transformer types 24 and 56:

Transformation type	Machine data
24	MD24550/24650 \$MC_TRAFO5_BASE_TOOL_1/2 MD24560/24660 \$MC_TRAFO5_JOINT_OFFSET_1/2 MD24558/24658 \$MC_TRAFO5_PART_OFFSET_1/2
56	MD24550/24650 \$MC_TRAFO5_BASE_TOOL_1/2 MD24560/24660 \$MC_TRAFO5_JOINT_OFFSET_1/2

Transformation type 56 (moving tool and moving workpiece) corresponds to type M for toolholders with orientation capability.

For this 5-axis transformation, in the previous software releases, vector MD24560/24660 \$MC_TRAFO5_JOINT_OFFSET_1/2 (vector of kinematic offset of the 1st/2nd 5-axis transformation in the channel) corresponds to the sum of the two vectors I₁ and I₃ for a type M tool carrier with orientation capability.

Only the sum is relevant for the transformation in both cases. The way, in which the two individual components are composed, is insignificant. However, when calculating the tool length, it is relevant which component is assigned to the tool and which is assigned to the tool table. This is the reason that machine data MD24558/24658 \$MC_TRAFO5_JOINT_OFFSET_PART_1/2 (vector kinematic offset in table) was introduced. It corresponds to vector I₃. Machine data:MD24560/24660 \$MC_TRAFO5_JOINT_OFFSET_1/2 no longer corresponds to the sum of I₁ and I₃, but only to vector I₁. If machine data MD24558/24658 \$MC_TRAFO5_JOINT_OFFSET_PART_1/2 is equal to zero, the behavior is the same as before.

Compatibility

The GETTCOR function is used in conjunction with the TOOLENV and SETTCOR functions to replace parts of the functionality, which were previously implemented externally in the measuring cycles.

Only some of the parameters, which actually determine the effective tool length, were implemented in the measuring cycles. The functions mentioned above can be configured to reproduce the behavior of the measuring cycles in relation to the tool length calculation.

3.13.12.6 Change tool components (SETTCOR)

The SETTCOR function is used to change tool components taking into account all general conditions that can be involved when evaluating the individual components.

Note

Regarding the terminology: If in the following, in conjunction with the tool length, tool components are involved, then the components considered from a vectorial perspective are meant, which make up the complete tool length (e.g. geometry or wear). Such a component comprises three individual values (L1, L2, L3), which are called coordinate values in the following.

The tool component "geometry" therefore comprises three coordinate values \$TC_DP3 to \$TC_DP5.

Syntax

```
<Status> = SETTCOR(<CorVal>, <Comp>, [<CorComp>, <CorMode>, <GeoAx>,
<Stat>, <T>, <D>, <DL>])
```

Meaning

SETTCOR(...):	Predefined function to change tool components	
	Alone in the block:	Yes

<Status>:	Function return value. Negative values indicate error states.		
	Data type:	INT	
	Value:	0	Function OK
		-1	No memory reserved for tool environments: MD18116 \$MN_MM_NUM_TOOL_ENV = 0 This means that the "tool environments" functionality is not available.
		-2	A tool environment with the name specified under <Stat> does not exist.
		-3	Invalid string in parameter <Comp>. Causes of this error can be invalid characters or characters programmed twice.
		-4	Invalid T number.
		-5	Invalid D number.
		-6	Invalid DL number.
		-7	Attempt to access a non-existent memory module.
		-8	Attempt to access a non-existent option (programmable tool orientation, tool management).
		-9	Illegal numerical value for parameter <CorComp>.
		-10	Illegal numerical value for parameter <CorMode>.
		-11	The contents of parameters <Comp> and <CorComp> are contradictory.
		-12	The contents of parameters <Comp> and <CorMode> are contradictory.
-13		The content of the <GeoAx parameter does not designate a geometry axis.	
-14	Write attempt to a non-existent setup offset.		
Parameters			
1	<CorVal>:	Correction vector In the workpiece coordinate system (WCS) defined by <Stat>, the following assignment applies: <ul style="list-style-type: none"> • <CorVal> [0]: Abscissa • <CorVal> [1]: Ordinate • <CorVal> [2]: Applicate If only one tool component is to be corrected (i.e. no vectorial correction, see parameter <CorMode>), the correction value is always in <CorVal>[0], independent of the axis on which it acts. The contents of the other two components are then not evaluated. If <CorVal> or a component of <CorVal> refers to the transverse axis, then the data is evaluated as radius dimension . This means that a tool is, for example, "longer" by the specified dimension; this correspondingly results in a change to the workpiece diameter that is twice as large. The dimensions refer to the basic system (inch or metric) of the control system.	
		Data type:	REAL[3]

2	<Comp>:	Tool component(s)			
		Data type:	STRING		
		The character string consists of two substrings, which are separated from one another by a colon.			
		General form: "<SubStr_1> [: <SubStr_2>]"			
		<SubStr_1>:	The first substring must always be available, and can either comprise one or two characters. The first or only character for the 1st component (Val ₁) and the second character for the 2nd component (Val ₂), which are processed according to the subsequent parameters <CorComp> and <CorMode>.		
			Charac- ters:	C	Adapter or tool base dimension (whichever of the two alternative components is active for the tool in use)
				E	Setup offsets
				G	Geometry
				S	Sum offsets
		W		Wear	
<Substr_2>:	The second substring is optional. Alternatively, it can comprise (individual) letters "W" or "T".				
	Charac- ters:	W	If the second substring is empty or contains the letter "W", then the offset values are taken into account as if they had been measured in the workpiece coordinate system (WCS).		
		T	If the second substring contains the letter "T", then the offset values are taken into account as if they had been measured in the tool coordinate system (Tool Coordinate System, TCS).		
The notation of the characters in the string (upper or lower case) is arbitrary. Any number of spaces or tabs (white spaces) can be inserted.					

3	<CorComp>:	Specifies the component(s) of the tool data sets that are to be described (optional).		
		Data type:	INT	
		Value:	0	Offset value <CorVal>[0] refers to the geometry axis transferred in parameter <GeoAx> in the workpiece coordinate system – or in the tool coordinate system (also see a description of parameter <Comp>). This means that the offset value must be calculated in the designated tool components so that, taking account all the parameters that can influence the tool length calculation, a change of the total tool length by the specified value in the specified axis direction is obtained. This change should be achieved by correcting the component specified in <Comp> and the symbolic algorithm specified in <CorMode> (see the following parameters). The resulting correction can therefore have an effect on all three axis components.
			1	Like "0", however, vectorial. The content of vector <CorVal> refers to abscissa, ordinate and applicate in the workpiece coordinate system or tool coordinate system (see the description of parameter <Comp>). Subsequent parameter <GeoAx> is not evaluated.
			2	Vectorial offset, i.e. L1, L2 and L3 can change simultaneously. In contrast to the versions from "0 and "1", the offset values contained in <CorVal> refer to the coordinates of Val _i components (see following parameter <CorMode>) of the tool. Any possible inclination of an existing tool compared with the workpiece coordinate system has no influence on the offset.
			3 - 5	Correction of tool lengths L1 to L3 (\$TC_DP3 to \$TC_DP5) or the corresponding values for wear, setting up or additive offsets. The offset value is contained in <CorVal>[0]. It is measured in the coordinates of the Val _i component (see following parameter <CorMode>) of the tool. Any possible inclination of an existing tool compared with the workpiece coordinate system has no influence on the offset.
			6	Correction of the tool radius (\$TC_DP6) or the corresponding values for wear, setting up or additive offsets. Bits 10 and 11 (evaluation of the diameter and/or diameter wear data, either specified as a radius or diameter) in machine data MD20360 \$MC_TOOL_PARAMETER_DEF_MASK are taken into account.
			7 - 11	Correction of \$TC_DP7 to \$TC_DP11 or the corresponding values for wear, setting up or additive offsets. These parameters are treated just like the tool radius.
If this parameter is not specified then its value is "0".				

4	<CorMode>:	Specifies the type of write operation to be executed (optional).		
		Data type:	INT	
		Value:	0	$Val_{1new} = \langle CorVal \rangle$
			1	$Val_{1new} = Val_{1old} + \langle CorVal \rangle$
2	$Val_{1new} = \langle CorVal \rangle$ $Val_{2new} = 0$			
3	$Val_{1new} = Val_{1old} + Val_{2old} + \langle CorVal \rangle$ $Val_{2new} = 0$			
<p>The notation $Val_{1old} + Val_{2old}$ is symbolic. If the two components (due to the status of <_Stat>) are evaluated in different ways, i.e. if a rotation is effective between the two components, then Val_{2old} is transformed prior to addition so that the resulting tool length after deleting Val_{2new} and prior to the addition of $\langle CorVal \rangle$ remains unchanged.</p> <p>$\langle CorVal \rangle$ always refers to Val_1. $\langle CorVal \rangle$ is a value, which dependent on the second part of parameter <Comp>, is measured in the workpiece coordinate system (WCS) or in the tool coordinate system (TCS). It is therefore already transformed with respect to the tool components, in which it should be calculated. Therefore, it cannot be directly calculated together with the saved value, but must be transformed back prior to adding to Val_1 or Val_2. This can mean that the offset acts on an axis different than the one defined by <CorComp> – or that it acts on several axes.</p> <p>For the case <CorComp> = 0, i.e. when $\langle CorVal \rangle$ does not contain a vector, but only an individual value, then the described operations are executed in the coordinates in which $\langle CorVal \rangle$ was measured (WCS/TCS). In particular, this also applies to setting Val_{2new} to zero in variants 2 and 3. This result is then transformed back into the coordinates of the tool. This can mean that none of the coordinate values to be set to zero (L1, L2, L3) become zero, or coordinate values, that were previously zero, are now not equal to zero. However, if the corresponding operations are successively executed for all three geometry axes, then it is guaranteed that all three coordinate values of the components to be deleted are zero. If the tool is not rotated with respect to the workpiece coordinate system or is rotated so that all tool components remain parallel to the coordinate axes (axis exchange operations), then this also ensures that only one tool coordinate changes.</p> <p>The successive execution of the same operation (<CorMode>) with <CorComp> = 0 for all three coordinate axes in any sequence is identical with the single execution of the same operation with <CorComp>=1.</p> <p>For parameter values "0" and "1", parameter <Comp> must contain one character, and for parameter values "2" and "3", two characters.</p> <p>Example: <Comp> contains string "ES", <CorMode> the value "2" \Rightarrow Setup offset_{new} = $\langle CorVal \rangle$, summed offset_{new} = 0 If parameter <CorMode> is not specified, then its value is "0".</p>				
5	<GeoAx>:	Specifies the index of the geometry axis in which the offset value <CorVal>[0] was read (optional)		
		Data type:	INT	
		Value range:	0 ... 2	
		<p>Indices 0 to 2 refer to abscissa, ordinate and applicate in the active plane (G17/G18/G19) of the current tool environment.</p> <p>The content of this parameter is only evaluated if parameter <CorComp> has a value of "0".</p>		

6	<Stat>:	Name of the data set for describing a tool environment (optional)	
		Data type:	STRING
		If the value of this parameter is the null string (""), or is not specified, then the current status is used. The current tool is used if a tool is not specified.	
7	<T>:	Internal T number of the tool (optional).	
		Data type:	INT
		<p>If this parameter is not specified or if its value is "0", then the tool stored in <Stat> is used.</p> <p>If the value of this parameter is "-1", then the T number of the active tool is used. It is also possible to explicitly specify the number of the active tool.</p> <p>Note: If <Stat> is not specified, the actual status is used as the tool environment. Since <T> = 0 refers to the T number saved in the tool environment, the active tool is used in this environment, i.e. parameters <T> = 0 and <T> = -1 have the same meaning in this special case.</p>	
8	<D>:	Cutting edge of the tool (optional).	
		Data type:	INT
		If this parameter is not specified, or if its value is "0", then the D number used is based on the source of the T number. If the T number from the tool environment is used, the D number of the tool environment is also read, otherwise the D number of the currently active tool is read.	
9	<TL>:	Number of the offset dependent on the location (optional).	
		Data type:	INT
		If this parameter is not specified, then the DL number used is based on the source of the T number. If the T number from the tool environment is used, the D number of the tool environment is also read, otherwise the D number of the currently active tool is read. If T, D and DL specify a tool without location-dependent offsets, no summed or setup offsets may be specified in parameter <Comp> (error code in <Status>).	

Note

Not all possible combinations of the three parameters <Comp>, <CorComp> and <CorMode> make sense. For example, algorithm 3 in <CorComp> requires that two characters are specified in <Comp>. If an invalid parameter combination is specified, then a corresponding error code is returned in the <Status>.

Examples

Example 1

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=120	; Milling tool
N30 \$TC_DP3[1,1]=10.0	; Geometry L1
N40 \$TC_DP12[1,1]=1.0	; wear L1
N50 _CORVAL[0]=0.333	
N60 T1 D1 G17 G0	

Program code	Comment
N70 R1=SETTCOR (_CORVAL, "G", 0, 0, 2)	
N80 T1 D1 X0 Y0 Z0	; ==> MCS position X0.000 Y0.000 Z1.333
N90 M30	

<CorComp> is "0", therefore, the coordinate value of the geometry component acting in the Z direction must be replaced by the offset value 0.333.

The resulting total tool length is thus: $L1 = 0.333 + 1.000 = 1.333$

Example 2

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=120	; milling tool
N30 \$TC_DP3[1,1]=10.0	; geometry L1
N40 \$TC_DP12[1,1]=1.0	; wear L1
N50 _CORVAL[0]=0.333	
N60 T1 D1 G17 G0	
N70 R1=SETTCOR (_CORVAL, "W", 0, 1, 2)	
N80 T1 D1 X0 Y0 Z0	; ==> MCS position X0.000 Y0.000 Z11.333
N90 M30	

<CorComp> is "1", this means that the offset value of 0.333 – acting in the Z axis – is added to the wear value of 1.0.

The resulting total tool length is thus: $L1 = 10.0 + 1.333 = 11.333$

Example 3

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=120	; Milling tool
N30 \$TC_DP3[1,1]=10.0	; Geometry L1
N40 \$TC_DP12[1,1]=1.0	; Wear L1
N50 _CORVAL[0]=0.333	
N60 T1 D1 G17 G0	
N70 R1=SETTCOR (_CORVAL, "GW", 0, 2, 2)	
N80 T1 D1 X0 Y0 Z0	; ==> MCS position X0.000 Y0.000 Z0.333
N90 M30	

<CorComp> is "2", therefore, the offset effective in the Z axis is entered in the geometry component (the old value is overwritten) and the wear value is deleted.

The resulting total tool length is thus: $L1 = 0.333 + 0.0 = 0.333$

Example 4

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=120	; Milling tool
N30 \$TC_DP3[1,1]=10.0	; Geometry L1

3.13 Tool offsets

Program code	Comment
N40 \$TC_DP12[1,1]=1.0	; wear L1
N50 _CORVAL[0]=0.333	
N60 T1 D1 G17 G0	
N70 R1=SETTCOR(_CORVAL,"GW",0,3,2)	
N80 T1 D1 X0 Y0 Z0	; ==> MCS position X0.000 Y0.000 Z11.333
N90 M30	

<CorComp> is "3", therefore, the wear value and compensation value are added to the geometry component and the wear component is deleted.

The resulting total tool length is thus: $L1 = 11.333 + 0.0 = 11.333$

Example 5

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=120	; Milling tool
N30 \$TC_DP3[1,1]=10.0	; Geometry L1
N40 \$TC_DP12[1,1]=1.0	; Wear L1
N50 _CORVAL[0]=0.333	
N60 T1 D1 G17 G0	
N70 R1=SETTCOR(_CORVAL,"GW",0,3,0)	
N80 T1 D1 X0 Y0 Z0	; ==> MCS position X0.333 Y0.000 Z11.000
N90 M30	

<CorComp> is "3", as in the previous example, but the compensation is now effective on the geometry axis with index "0" (X axis), which for a milling tool, is assigned to tool component L3 due to G17. As a consequence, when calling SETTCOR, tool parameters \$TC_DP3 and \$TC_DP12 are not influenced. Instead, the compensation value is entered in \$TC_DP5.

Example 6

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=500	; turning tool
N30 \$TC_DP3[1,1]=10.0	; geometry L1
N40 \$TC_DP4[1,1]=15.0	; geometry L2
N50 \$TC_DP12[1,1]=10.0	; wear L1
N60 \$TC_DP13[1,1]=0.0	; wear L2
N70 _CORVAL[0]=5.0	
N80 ROT Y-30	
N90 T1 D1 G18 G0	
N100 R1=SETTCOR(_CORVAL,"GW",0,3,1)	
N110 T1 D1 X0 Y0 Z0	; ==> MCS position X24.330 Y0.000 Z17.500
N120 M30	

The tool is a turning tool. A frame rotation is activated in N80, causing the basic coordinate system (BCS) to be rotated in relation to the workpiece coordinate system (WCS). In the WCS, the compensation value (N70) acts on the geometry axis with index 1, i.e. on the X axis because

G18 is active. Since $\langle \text{CorMode} \rangle = 3$, the tool wear in the direction of the X axis of the WCS must become zero once N100 has been executed.

The contents of the relevant tool parameters at the end of the program are thus:


$\$TC_DP3[1,1]$: 21.830 ; geometry L1

$\$TC_DP4[1,1]$: 21.830 ; geometry L2

$\$TC_DP12[1,1]$: 2.500 ; wear L1

$\$TC_DP13[1,1]$: -4.330 ; wear L2

The geometrical relationships are shown in the figure below: The total wear including $_CORVAL$ is mapped onto the X' direction in the WCS. This produces point P2. The coordinates of this point (measured in X/Y coordinates) are entered in the geometry component of the tool. The difference vector $P_2 - P_1$ remains in the wear. The wear thus no longer has a component in the direction of $_CORVAL$.



If the program example is continued after N110 with the following instructions, then the remaining wear is included completely in the geometry because the compensation is now effective in the Z' axis (parameter $\langle \text{GeoAx} \rangle = 0$):

```
N120  $\_CORVAL[0]=0.0$ 
N130 R1=SETTCOR( $\_CORVAL$ , "GW", 0, 3, 0)
N140 T1 D1 X0 Y0 Z0 ; ==> MCS position X24.330 Y0.000 Z17.500
```

Since the new compensation value is "0", the total tool length and thus the position approached in N140 may not change. If $_CORVAL$ were not equal to "0" in N120, a new total tool length and thus a new position in N140 would result, however, the wear component of the tool length would always be zero, i.e. the total tool length is subsequently always contained in the geometry component of the tool.

The same result as that achieved by calling the SETTCOR function with the <CorComp> = 0 parameter twice can also be reached by calling <CorComp> = 1 (vectorial compensation) just once:

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=500	; turning tool
N30 \$TC_DP3[1,1]=10.0	; geometry L1
N40 \$TC_DP4[1,1]=15.0	; geometry L2
N50 \$TC_DP12[1,1]=10.0	; wear L1
N60 \$TC_DP13[1,1]=0.0	; wear L2
N70 _CORVAL[0]=0.0	
N71 _CORVAL[1]=5.0	
N72 _CORVAL[2]=0.0	
N80 ROT Y-30	
N90 T1 D1 G18 G0	
N100 R1=SETTCOR(_CORVAL,"GW",1,3,1)	
N110 T1 D1 X0 Y0 Z0	; ==> MCS position X24.330 Y0.000 Z17.500
N120 M30	

In this case, all wear components of the tool are set to zero immediately after the first call of SETTCOR in N100.

Example 7


Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=500	; turning tool
N30 \$TC_DP3[1,1]=10.0	; geometry L1
N40 \$TC_DP4[1,1]=15.0	; geometry L2
N50 \$TC_DP12[1,1]=10.0	; wear L1
N60 \$TC_DP13[1,1]=0.0	; wear L2
N70 _CORVAL[0]=5.0	
N80 ROT Y-30	
N90 T1 D1 G18 G0	
N100 R1=SETTCOR(_CORVAL,"GW",3,3)	
N110 T1 D1 X0 Y0 Z0	; ==> MCS position X25.000 Y0.000 Z15.000
N120 M30	

When compared to example 6, parameter <CorComp> = 3, and so the <GeoAx> parameter can be omitted. The value contained in _CORVAL[0] now acts immediately on the tool length component L1, the rotation in N80 has no effect on the result, the wear components in \$TC_DP12 are included in the geometry component together with _CORVAL[0], with the result that the total tool length is stored in the geometry component of the tool, due to \$TC_DP13, after the first SETTCOR call in N100.

Example 8

Program code	Comment
N10 DEF REAL _CORVAL[3]	
N20 \$TC_DP1[1,1]=500	; turning tool
N30 \$TC_DP3[1,1]=10.0	; geometry L1
N40 \$TC_DP4[1,1]=15.0	; geometry L2
N50 \$TC_DP5[1,1]=20.0	; geometry L3
N60 \$TC_DP12[1,1]=10.0	; wear L1
N70 \$TC_DP13[1,1]=0.0	; wear L2
N80 \$TC_DP14[1,1]=0.0	; wear L3
N90 \$SC_WEAR_SIGN=TRUE	
N100 _CORVAL[0]=10.0	
N110 _CORVAL[1]=15.0	
N120 _CORVAL[2]=5.0	
N130 ROT Y-30	
N140 T1 D1 G18 G0	
N150 R1=SETTCOR(_CORVAL,"W",1,1)	
N160 T1 D1 X0 Y0 Z0	; ==> MCS position X7.990 Y25.000 Z31.160
N170 M30	

Setting data:SD42930 \$SC_WEAR_SIGN is enabled in N90, i.e. the wear must be evaluated with a negative sign. The compensation is vectorial (<CorComp> = 1), and the compensation vector must be added to the wear (<CorMode> = 1). The geometrical relationships in the Z/X plane are shown in the diagram below:



The geometry component of the tool remains unchanged due to <CorMode> = 1. The compensation vector defined in the WCS (rotation around the y axis) must be included in the wear component such that the total tool length in Fig. 3 refers to point P₂. Therefore, the resulting wear component of the tool is given by the distance of the two points P₁ and P₂.

However, since the wear is evaluated negatively, due to setting data SD42930 \$SSC_WEAR_SIGN, the compensation determined in this way has to be entered in the compensation memory with a negative sign. The contents of the relevant tool parameters at the end of the program are thus:

```
$TC_DP3[1,1]: 10.000 ; geometry L1 (unchanged)
$TC_DP4[1,1] : 15.000 ; geometry L2 (unchanged)
$TC_DP5[1,1]: 10.000 ; geometry L3 (unchanged)
$TC_DP12[1,1] : 2.010 ; wear L1 (= 10 - 15 * cos(30) + 10 * sin(30))
$TC_DP13[1,1] : -16.160 ; wear L2 (= -15 * sin(30) - 10 * cos(30))
$TC_DP14[1,1] : -5.000 ; wear L3
```

The effect of setting data SD42930 \$SSC_WEAR_SIGN on the L3 component in the Y direction can be recognized without the additional complication caused by the frame rotation.

Additional information

Turning/grinding tools: Calculating the tool length depending on MD20360 \$MC_TOOL_PARAMETER_DEF_MASK

The following machine data defines how the wear and tool length are to be evaluated if a diameter axis is used for turning/grinding tools:

MD20360 \$MC_TOOL_PARAMETER_DEF_MASK.<Bit> = <Value>

<Bit>	<Value>	Meaning
0	0	For turning/grinding tools, the wear parameter of the transverse axis is taken into account in the radius value :
	1	For turning/grinding tools, the wear parameter of the transverse axis is taken into account as the diameter value :
1	0	For turning/grinding tools, the tool length component of the transverse axis is taken into account as the radius value :
	1	For turning/grinding tools, the tool length component of the transverse axis is taken into account as the diameter value :

If the bits involved are set, the associated entry is weighted with a factor of 0.5. The correction using SETTCOR is executed so that the total effective tool length change is equal to the value transferred in <CorVal>. If, when calculating the length, a length is evaluated with a factor of 0.5 as a result of machine data MD20360 \$MC_TOOL_PARAMETER_DEF_MASK, then the compensation of this component must be realized with twice the value transferred.

Example

MD20360 \$MC_TOOL_PARAMETER_DEF_MASK = 2 (tool length must be evaluated in the diameter axis using a factor of 0.5)

Axis X is the diameter axis.

Program code	Comment
N10 DEF REAL _LEN[11]	
N20 DEF REAL _CORVAL[3]	
N30 \$TC_DP1[1,1]=500	; Tool type

Program code	Comment
N40 \$TC_DP2[1,1]=2	; Cutting edge position
N50 \$TC_DP3[1,1]=3.	; Geometry - length 1
N60 \$TC_DP4[1,1]=4.	; Geometry - length 2
N70 \$TC_DP5[1,1]=5.	; Geometry - length 3
N80 _CORVAL[0]=1.	
N90 _CORVAL[1]=1.	
N100 _CORVAL[2]=1.	
N110 T1 D1 G18 G0 X0 Y0 Z0	; ==> MCS position X1.5 Y5 Z4
N120 R1=SETTCOR(_CORVAL,"G",1,1)	
N130 T1 D1 X0 Y0 Z0	; ==> MCS position X2.5 Y6 Z5
N140 R3=\$TC_DP3[1,1]	; = 5. = (3.000 + 2.*1.000)
N150 R4=\$TC_DP4[1,1]	; = 5. = (4.000 + 1.000)
N160 R5=\$TC_DP5[1,1]	; = 6. = (5.000 + 1.000)
N170 M30	

In each axis, the tool length compensation should be 1 mm (N80 to N100). 1 mm is thus added to the original length in lengths L2 and L3. Twice the compensation value (2 mm) is added to the original tool length in L1, in order to change the total length by 1 mm as required. If the positions approached in blocks N110 and N130 are compared, it can be seen that each axis position has changed by 1 mm.

3.13.13 Read the assignment of the tool lengths L1, L2, L3 to the coordinate axes (LENTOAX)

The LENTOAX function provides information about the assignment of tool lengths L1, L2 and L3 of the **active** tool to the abscissa, ordinate and applicate. The assignment of abscissa, ordinate and applicate to the geometry axes is affected by frames and the active plane (G17 - G19).

Only the geometry component of a tool (\$TC_DP3[<t>,<d>] to \$TC_DP5[<t>,<d>]) is considered, i.e. a different axis assignment for other components (e.g. wear) has no effect on the result.

Syntax

```
<Status> = LENTOAX(<AxInd>, <Matrix>[, <Coord>])
```

Principle

LENTOAX(...):	Predefined function to read the assignment of tool lengths L1, L2 and L3 of the active tool to the coordinate axes
Alone in the block:	Yes

<Status>:	Function return value. Negative values indicate error states.			
	Data type:	INT		
	Value:	0	Function OK Information provided in <AxInd> is sufficient for the description (all tool length components are in parallel to the geometry axes).	
		1	Function is OK, however, the content of <Matrix> must be evaluated for a correct description (the tool length components are not parallel to the geometry axes).	
		-1	Invalid string in parameter <Coord>.	
-2		No tool active.		
Parameters				
1	<AxInd>:	If the tool length components are parallel to the geometry axes, the axis indices assigned to length components L1 to L3 are returned in the <AxInd> array. <ul style="list-style-type: none"> • <AxInd> [0]: Abscissa • <AxInd> [1]: Ordinate • <AxInd> [2]: Applicata 		
		Data type:	INT[3]	
		Value:	0	No assignment exists (axis does not exist)
			1 ... 3 or	Number of the length effective in the corresponding coordinate axis.
			-1 ... -3	The sign is negative if the tool length component is pointing in the negative coordinate direction.
If not all length components are parallel or antiparallel to the geometry axes, the index of the axis, which contains the largest part of a tool length component, is returned in <AxInd>. In this case (if the function does not return an error for a different reason), then the return value is <Status> = 1. The mapping of tool length components L1 to L3 to geometry axes 1 to 3 is then described completely by the content of the 2nd parameter <Matrix>.				
2	<Matrix>:	Matrix which represents the vector of the tool lengths (L1=1, L2=1, L3=1) to the vector of the coordinate axes (abscissa, ordinate, applicata), i.e. the tool length components are assigned to the columns in the order L1, L2, L3 and the axes are assigned to the lines in the order abscissa, ordinate, applicata.		
		Data type:	REAL	
		All elements are always valid in the matrix, even if the geometry axis belonging to the coordinate axis is not available, i.e. if the corresponding entry in <AxInd> is 0.		

3	<Coord>:	coordinate system applicable for the assignment (optional)		
		Data type:	STRING	
		Charac- ters:	MCS M	The tool length is represented in the machine coordinate system.
			BCS B	The tool length is represented in the basic coordinate system.
			WCS W	The tool length is represented in the workpiece coordinate system (default setting).
			KCS K	The tool length is represented in the tool coordinate system of the kinematic transformation.
			TCS T	The tool length is represented in the tool coordinate system.
The notation of the characters in the string (upper or lower case) is arbitrary. If the parameter <Coord> is not specified, then WCS is used (default setting).				

Note

In the TCS, all tool length components are always parallel or antiparallel to the axes.

The components can only be antiparallel when mirroring is active and the following setting data is activated:

SD42900 \$SC_MIRROR_TOOL_LENGTH (sign change tool length when mirroring)

Example

Standard application, milling tool for G17.

L1 applies in Z (applicate), L2 applies in Y (ordinate), L3 applies in X (abscissa).

Function call in the form:

```
<Status>=LENTOAX (<AxInd>, <Matrix>, "WCS")
```

The result parameter <AxInd> then contains the values:

```
<AxInd>[0] = 3
```

```
<AxInd>[1] = 2
```

```
<AxInd>[2] = 1
```

Or, in short: (3, 2, 1)

In this case, the associated matrix (<Matrix>) is:

$$\langle \text{Matrix} \rangle = \begin{pmatrix} 0 & 0 & 1 \\ 0 & 1 & 0 \\ 1 & 0 & 0 \end{pmatrix}$$

A change from G17 to G18 or G19 does not alter the result, because the assignment of the length components to the geometry axes changes in the same way as the assignment of the abscissa, ordinate and applicate.

A frame rotation of Z through 60 degrees is now programmed with G17 active, e.g.

3.13 Tool offsets

ROT Z60

The direction of the applicator (Z direction) remains unchanged; the main component of L2 now lies in the direction of the new X axis; the main component of L1 now lies in the direction of the negative Y axis. As a consequence, the return value (<Status>) is "1", <AxInd> contains the values (2, -3, 1).

In this case, the associated matrix (<Matrix>) is:

$$\langle \text{Matrix} \rangle = \begin{pmatrix} 0 & \sin 60^\circ & \cos 60^\circ \\ 0 & \cos 60^\circ & -\sin 60^\circ \\ 1 & 0 & 0 \end{pmatrix}$$

3.14 Path traversing behavior

3.14.1 Feedrate characteristic (FNORM, FLIN, FCUB, FPO)

To permit flexible definition of the feedrate characteristic, the feedrate programming according to DIN 66025 has been extended by linear and cubic characteristics.

The cubic characteristics can be programmed either directly or as interpolating splines. These additional characteristics make it possible to program continuously smooth velocity characteristics depending on the curvature of the workpiece to be machined.

These additional characteristics make it possible to program continuously smooth velocity characteristics depending on the curvature of the workpiece to be machined.

Syntax

```
F... FNORM
F... FLIN
F... FCUB
F=FPO (... , ... , ...)
```

Meaning


FNORM:	Basic setting. The feed value is specified as a function of the traverse path of the block and is then valid as a modal value.
FLIN:	Path velocity profile linear : The feed value is approached linearly via the traverse path from the current value at the block beginning to the block end and is then valid as a modal value. The response can be combined with G93 and G94.
FCUB:	Path velocity profile cubic : The blockwise programmed F values (relative to the end of the block) are connected by a spline. The spline begins and ends tangentially with the previous and following defined feedrate and takes effect with G93 and G94. If the F address is missing from a block, the last F value to be programmed is used.
F=FPO... :	Polynomial path velocity profile: The F address defines the feed characteristic via a polynomial from the current value to the block end. The end value is valid thereafter as a modal value.

Feed optimization on curved path sections

Feed polynomial `F=FPO` and feed spline `FCUB` should always be traversed at constant cutting rate `CFC`, thereby allowing a jerk-free setpoint feed profile to be generated. This enables creation of a continuous acceleration setpoint feed profile.

Example: Various feed profiles

This example shows you the programming and graphic representation of various feed profiles.




Program code	Comment
N1 F1000 FNORM G1 X8 G91 G64	; Constant feedrate profile, incremental dimension data
N2 F2000 X7	; Setpoint velocity step change
N3 F=FPO(4000, 6000, -4000)	; Feed profile via polynomial with feed 4000 at the end of the block
N4 X6	; Polynomial feedrate 4000 is valid as modal value
N5 F3000 FLIN X5	; Linear feedrate profile
N6 F2000 X8	; Linear feedrate profile
N7 X5	; Linear feedrate is valid as modal value
N8 F1000 FNORM X5	; Constant feedrate profile with acceleration step change
N9 F1400 FCUB X8	; All of the following F values programmed in blocks are connected with splines
N10 F2200 X6	
N11 F3900 X7	
N12 F4600 X7	
N13 F4900 X5	; Switch-out spline profile
N14 FNORM X5	
N15 X20	

Further information

FNORM

The feed address F defines the path feedrate as a constant value according to DIN 66025.

Please refer to Programming Manual "Fundamentals" for more detailed information on this subject.




FLIN

The feedrate characteristic is approached linearly from the current feedrate value to the programmed F value until the end of the block.

Example:

```
N30 F1400 FLIN X50
```



FCUB


The feedrate is approached according to a cubic characteristic from the current feedrate value to the programmed F value until the end of the block. The control uses splines to connect all the

3.14 Path traversing behavior

feedrate values programmed non-modally that have an active FCUB. The feedrate values act here as interpolation points for calculation of the spline interpolation.

Example:

```
N50 F1400 FCUB X50
N60 F2000 X47
N70 F3800 X52
```



F=FPO(.....)

The feedrate characteristic is programmed directly via a polynomial. The polynomial coefficients are specified according to the same method used for polynomial interpolation.


Example:

```
F=FPO(endfeed, quadf, cubf)
```

endfeed, quadf and cubf are previously defined variables.

endfeed:	Feedrate at block end
quadf:	Quadratic polynomial coefficient
cubf:	Cubic polynomial coefficient

With an active FCUB, the spline is linked tangentially to the characteristic defined via FPO at the block beginning and block end.



Supplementary conditions

- The functions for programming the path traversing characteristics apply regardless of the programmed feedrate characteristic.
- The programmed feedrate characteristic is always absolute regardless of G90 or G91.
- The feed characteristic curve `FLIN` and `FCUB` does **not** act with G93 and G94 for G95, G96/G961 and G97/G971.
- With an active compressor `COMPON` the following applies when several blocks are joined to form a spline segment:

<code>FNORM:</code>	The F word of the last block in the group applies to the spline segment.
<code>FLIN:</code>	The F word of the last block in the group applies to the spline segment. The programmed F value applies until the end of the segment and is then approached linearly.
<code>FCUB:</code>	The generated feedrate spline deviates from the programmed end points by an amount not exceeding the value set in machine data MD20172 \$MC_COMPRESS_VELO_TOL.
<code>F=FPO (... , ... , ...) :</code>	These blocks are not compressed.

3.14.2 Acceleration behavior

3.14.2.1 Acceleration mode (BRISK, BRISKA, SOFT, SOFTA, DRIVE, DRIVEA)

The following part program commands are available for programming the current acceleration mode:

- "BRISK, BRISKA"
The single axes or the path axes traverse with maximum acceleration until the programmed feedrate is reached (**acceleration without jerk limitation**).
- "SOFT, SOFTA"
The single axes or the path axes traverse with constant acceleration until the programmed feedrate is reached (**acceleration with jerk limitation**).
- "DRIVE, DRIVEA"
The single axes or the path axes traverse with maximum acceleration up to a programmed velocity limit (MD setting!). The acceleration rate is then reduced (MD setting) until the programmed feedrate is reached.




Figure 3-9 Path velocity curve with BRISK and SOFT




Figure 3-10 Path velocity curve with DRIVE

Syntax

```

BRISK
BRISKA(<axis1>,<axis2>,...)
SOFT
SOFTA(<axis1>,<axis2>,...)
DRIVE
DRIVEA(<axis1>,<axis2>,...)

```

Meaning

BRISK:	Command for activating the "acceleration without jerk limitation" for the path axes.
BRISKA:	Command for activating the "acceleration without jerk limitation" for single axis movements (JOG, JOG/INC, positioning axis, oscillating axis, etc.).
SOFT:	Command for activating the "acceleration with jerk limitation" for the path axes.
SOFTA:	Command for activating the "acceleration with jerk limitation" for single axis movements (JOG, JOG/INC, positioning axis, oscillating axis, etc.).
DRIVE:	Command for activating the reduced acceleration above a configured velocity limit (MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT) for the path axes.
DRIVEA:	Command for activating the reduced acceleration above a configured velocity limit (MD35220 \$MA_ACCEL_REDUCTION_SPEED_POINT) for single axis movements (JOG, JOG/INC, positioning axis, oscillating axis, etc.).
(<axis1>,<axis2>, etc.):	Single axes for which the called acceleration mode is to apply.

Supplementary conditions

Changing acceleration mode during machining

If the acceleration mode is changed in a part program during machining (BRISK ↔ SOFT), then there is a block change with exact stop at the end of the block during the transition even with continuous-path mode.

Examples

Example 1: SOFT and BRISKA

Program code

```

N10 G1 X... Y... F900 SOFT
N20 BRISKA(AX5,AX6)
...

```

Example 2: DRIVE and DRIVEA

```

Program code
N05 DRIVE
N10 G1 X... Y... F1000
N20 DRIVEA (AX4, AX6)
...
    
```

References

Function Manual, Basic Functions; Acceleration (B2)

3.14.2.2 Influence of acceleration on following axes (VELOLIMA, ACCLIMA, JERKLIMA)

In the case of axis couplings (tangential correction, coupled motion, master value coupling, electronic gear; see "Axis couplings (Page 844)").

The dynamics limits of the following axes/spindles can be manipulated using the VELOLIMA, ACCLIMA, and JERKLIMA functions from the part program or from synchronized actions, even if the axis coupling is already active.

Note

The JERKLIMA function is not available for all types of coupling.

References:

- Function Manual, Special Functions; Axis Couplings (M3)
- Function Manual, Extended Functions; Synchronous Spindle (S3)

Note

Availability for SINUMERIK 828D

The VELOLIMA, ACCLIMA and JERKLIMA functions can only be used with SINUMERIK 828D in conjunction with the "coupled motion" function!

Syntax

```

VELOLIMA (<axis>) =<value>
ACCLIMA (<axis>) =<value>
JERKLIMA (<axis>) =<value>
    
```

Meaning

VELOLIMA:	Command to correct the parameterized maximum velocity
ACCLIMA:	Command to correct the parameterized maximum acceleration
JERKLIMA:	Command to correct the parameterized maximum jerk
<axis>:	Following axis whose dynamics limits need to be corrected
<value>:	Percentage correction value

Examples

Example 1: Correction of the dynamics limits for a following axis (AX4)

Program code	Comment
...	
VELOLIMA[AX4]=75	; Limit correction to 75% of the maximum axial velocity stored in the machine data
ACCLIMA[AX4]=50	; Limit correction to 50% of the maximum axial acceleration stored in the machine data
JERKLIMA[AX4]=50	; Limit correction to 50% of the maximum axial jerk stored in the machine data
...	

Example 2: Electronic gear

Axis 4 is coupled to axis X via an "electronic gear" coupling. The acceleration capacity of the following axis is limited to 70% of the maximum acceleration. The maximum permissible velocity is limited to 50% of the maximum velocity. Once the coupling has been activated successfully, the maximum permissible velocity is restored to 100%.

Program code	Comment
...	
N120 ACCLIMA[AX4]=70	; Reduced maximum acceleration.
N130 VELOLIMA[AX4]=50	; Reduced maximum velocity.
...	
N150 EGON (AX4, "FINE", X, 1, 2)	; Activation of the EG coupling.
...	
N200 VELOLIMA[AX4]=100	; Full maximum velocity.
...	

Example 3: Influencing master value coupling by static synchronized action

Axis 4 is coupled to X by master value coupling. The acceleration response is limited to position 80% by static synchronized action 2 from position 100.

Program code	Comment
...	
N120 IDS=2 WHENEVER \$AA_IM[AX4] > 100 DO ACCLIMA[AX4]=80	; Synchronized action
N130 LEADON (AX4, X, 2)	; Master value coupling on
...	

3.14.2.3 Activation of technology-specific dynamic values (DYNNORM, DYNPOS, DYNROUGH, DYNSEMIFIN, DYNFINISH, DYNPREC)

The appropriate dynamic response for differing technological machining steps can be activated with the commands of G group 59 "Dynamic response mode for path interpolation".

Dynamic values and G commands can be configured and are, therefore, dependent on machine data settings (→ machine manufacturer).

References:

Function Manual, Basic Functions; Continuous-Path Mode, Exact Stop, Look Ahead (B1)

Syntax

Activate dynamic values:

DYNNORM
 DYNPOS
 DYNROUGH
 DYNSEMIFIN
 DYNFINISH
 DYNPREC

Note

The dynamic values are already active in the block in which the associated G command is programmed. Machining is not stopped.

Read or write a specific field element:

R<m>=\$MA... [n, X]
 \$MA... [n, X]=<value>

Meaning

DYNNORM:	Activate normal dynamic response	
DYNPOS:	Activate dynamic response for positioning mode, tapping	
DYNROUGH:	Activate dynamic response for roughing	
DYNSEMIFIN:	Activate dynamic response for semi-finishing	
DYNFINISH:	Activate dynamic response for finishing	
DYNPREC:	Activate dynamic response for smooth finishing	
R<m>:	R-parameter with number <m>	
\$MA... [n, X]:	Machine data with field element affecting dynamic response	
<n>:	Array index	
	Range of values:	0 ... 5
	0	Normal dynamic response (DYNNORM)
	1	Dynamic response for positioning mode (DYNPOS)
	2	Dynamic response for roughing (DYNROUGH)
	3	Dynamic response for semi-finishing (DYNSEMIFIN)
	4	Dynamic response for finishing (DYNFINISH)
5	Dynamic response for smooth finishing (DYNPREC)	
<X>:	Axis address	
<value>:	Dynamic value	

Examples

Example 1: Activate dynamic values

Program code	Comment
DYNNORM G1 X10	; Initial setting
DYNPOS G1 X10 Y20 Z30 F...	; Positioning mode, tapping
DYNROUGH G1 X10 Y20 Z30 F10000	;Roughing
DYNSEMIFIN G1 X10 Y20 Z30 F2000	; Semi-finishing
DYNFINISH G1 X10 Y20 Z30 F1000	;Finishing
DYNPREC G1 X10 Y20 Z30 F600	; Smooth finishing

Example 2: Read or write a specific field element

Maximum acceleration for roughing, axis X

Program code	Comment
R1=\$MA_MAX_AX_ACCEL[2,X]	; reading
\$MA_MAX_AX_ACCEL[2,X]=5	; writing

3.14.3 Traversing with feedforward control (FFWON, FFWOF)

The feedforward control reduces the velocity-dependent overtravel when contouring towards zero. Traversing with feedforward control permits higher path accuracy and thus improved machining results.

Syntax

FFWON

FFWOF

Meaning

FFWON:	Command to activate the feedforward control
FFWOF:	Command to deactivate the feedforward control

Note

The type of feedforward control and which path axes are to be traversed with feedforward control is specified via machine data.

Default: Velocity-dependent feedforward control

Option: Acceleration-dependent feedforward control

Example

```

Program code
N10 FFWON
N20 G1 X... Y... F900 SOFT
    
```

3.14.4 Programmable contour accuracy (CPRECON, CPRECOF)

The "Programmable contour accuracy" function reduces the path error on curved contours through automatic adaptation of the velocity.

The contour accuracy to be maintained is specified depending on the configuration of the machine (MD20470 \$MC_MC_CPREC_WITH_FFW; see machine manufacturer specifications) either via the setting data \$SC_CONTPREC or via the programmed contour tolerance CTOL. The smaller the value and the smaller the K_v factor of the geometry axes, the greater the path feedrate is reduced on curved contours.

The "Programmable contour accuracy" function is activated or deactivated via the operations CPRECON and CPRECOF in the NC program.

Syntax

```

CPRECON
...
CPRECOF
    
```

Meaning

CPRECON:	G command call: Switch "Programmable contour accuracy" on	
	Effectiveness:	Modal
CPRECOF:	G command call: Switch "Programmable contour accuracy" off	
	Effectiveness:	Modal

Together CPRECON and CPRECOF form the G function group 39 (programmable contour accuracy).

Note

The user can specify a minimum velocity for the path feedrate via the setting data \$SC_MINFEED (minimum path feedrate with CPRECON).

The feedrate is not limited below this value, unless a lower F value has been programmed or the dynamic limits of the axes require a lower path velocity.

Note

The "Programmable contour accuracy" function only considers the geometry axes of the path. It has no effect on the velocities of positioning axes.

Example


Program code	Comment
N10 G0 X0 Y0	
N20 CPRECON	; Activate the "programmable contour accuracy".
N30 G1 G64 X100 F10000	; Machining with 10 m/min in the continuous-path mode.
N40 G3 Y20 J10	; Automatic feed limitation in circular block.
N50 G1 X0	; Feedrate again without limitation (10 m/min).
...	
N100 CPRECOF	; Deactivate the "programmable contour accuracy".
N110 G0 ...	

See also

Programming contour/orientation tolerance (CTOL, OTOL, ATOL) (Page 823)

3.14.5 Program sequence with preprocessing memory (STOPFIFO, STARTFIFO, FIFCTRL, STOPRE)

Depending on its expansion level, the control system has a certain quantity of so-called preprocessing memory in which prepared blocks are stored prior to program execution and then output as high-speed block sequences while machining is in progress. These sequences allow short paths to be traversed at a high velocity. Provided that there is sufficient residual control time available, the preprocessing memory is always filled.



Designate machining step

The beginning and end of the machining step to be buffered in the preprocessing memory are identified in the part program with "STOPFIFO" and "STARTFIFO" respectively. The processing of the preprocessed and buffered blocks starts only after the "STARTFIFO" command or if the preprocessing memory is full.

Automatic preprocessing memory control

Automatic preprocessing memory control is called with the "FIFOCTRL" command. "FIFOCTRL" acts initially just like "STOPFIFO". Whatever the programming, processing will not start until the preprocessing memory is full. However, the response to the emptying of the preprocessing memory does differ: With "FIFOCTRL", the path velocity is reduced increasingly once the fill level reaches 2/3 in order to prevent complete emptying and deceleration to standstill.

Preprocessing stop

Programming the "STOPRE" command in a block will stop block preprocessing and buffering. The following block is not executed until all preprocessed and saved blocks have been executed in full. The preceding block is halted in exact stop (as with G9).

NOTICE
Program abort
If tool offset or spline interpolations are active, a "STOPRE" command should not be programmed, as this will lead to contiguous block sequences being interrupted.

Syntax

Table 3-3 Identify machining step:

STOPFIFO
...
STARTFIFO

Table 3-4 Automatic preprocessing memory control:

...
FIFOCTRL
...

Table 3-5 Preprocessing stop:

...
STOPRE
...

Note

The "STOPFIFO", "STARTFIFO", "FIFOCTRL" and "STOPRE" commands must be programmed in their own block.

Meaning

STOPFIFO:	"STOPFIFO" identifies the start of a machining step to be buffered in the preprocessing memory. "STOPFIFO" stops processing and fills the preprocessing memory until: <ul style="list-style-type: none"> • "STARTFIFO" or "STOPRE" is recognized or • The preprocessing memory is full or • The end of the program is reached
STARTFIFO:	"STARTFIFO" starts rapid processing of the machining step; the preprocessing memory is filled in parallel to this.
FIFOCTRL:	Activation of automatic preprocessing memory control
STOPRE:	Stop preprocessing

Note

The preprocessing memory is not filled or filling is interrupted if the machining step contains commands that require unbuffered operation (search for reference, measuring functions, etc.).

Note

The control generates an internal preprocessing stop in the event of access to status data (\$SA...).

Example: Stop preprocessing

Program code	Comment
...	
N30 MEAW=1 G1 F1000 X100 Y100 Z50	; Measurement block with probe at first measuring input and linear interpolation.
N40 STOPRE	; Preprocessing stop.
...	

3.14.6 Defining a stop delay range (DELAYFSTON, DELAYFSTOF)

The predefined DELAYFSTON and DELAYFSTOF procedures are used to define a conditionally interruptible range in the part program (stop delay range).

Note

DELAYFSTON and DELAYFSTOF are **not** permitted in synchronized actions!

Syntax

```

DELAYFSTON
...
DELAYFSTOF
    
```

Meaning

DELAYFSTON:	Defining the start of a stop delay range	
	Alone in the block:	Yes
DELAYFSTOF:	Define the end of the stop delay area	
	Alone in the block:	Yes

Programming example


The following program block is repeated in a loop:

Program code

```

...
N99 MY_LOOP:
N100 G0 Z200
N200 G0 X0 Z200
N300 DELAYFSTON
N400 G33 Z5 K2 M3 S1000
N500 G33 Z0 X5 K3
N600 G0 X100
N700 DELAYFSTOF
N800 GOTOB MY_LOOP
...
    
```

In the following diagram it can be seen that the user pressed "Stop" in the stop delay range, and the NC started braking outside the stop delay range, i.e. in block N100. That causes the NC to stop at the beginning of N100.



Additional information

End of subprogram

DELAYFSTOF is activated implicitly at the end of the subprogram in which DELAYFSTON is called.

Nesting

If subprogram 1 calls subprogram 2 in a stop delay area, the whole of subprogram 2 is a stop delay area. In particular, DELAYFSTOF in subprogram 2 has no effect.

Example:

Program code	Comment
N10010 DELAYFSTON	; Blocks with N10xxx program level 1.
N10020 R1 = R1 + 1	
N10030 G4 F1	; Stop delay area starts.
...	
N10040 subprogram2	
...	
...	; Interpretation of subprogram 2.
N20010 DELAYFSTON	; Ineffective, repeated start, 2nd level.
...	
N20020 DELAYFSTOF	; Ineffective, end at another level.
N20030 RET	
N10050 DELAYFSTOF	; Stop delay end of range at the same level.
...	
N10060 R2 = R2 + 2	
N10070 G4 F1	; Stop delay area ends. From now, stops act immediately.

System variables

The following system variables can be queried to determine whether part program processing is currently in a stop delay area:

- in the part program with \$P_DELAYFST
- in synchronized actions with \$AC_DELAYFST

Value	Meaning
0	Delay stop range not active
1	Delay stop area active

3.14.7 Prevent program position for SERUPRO (IPTRLOCK, IPTRUNLOCK)

For some complicated mechanical situations on the machine it is necessary to the stop block search SERUPRO.

By using a programmable interruption pointer it is possible to intervene before an untraceable point with "Search at point of interruption".

It is also possible to define untraceable sections in part program sections that the NC cannot yet re-enter. When the program is interrupted, the NC notes the last block that was processed that can then be searched for via the HMI user interface.

Syntax

IPTRLOCK
IPTRUNLOCK

The commands are located in a part program line and allow a programmable interruption pointer

Meaning

IPTRLOCK:	Start of untraceable program section
IPTRUNLOCK:	End of untraceable program section

Both commands are only permitted in part programs, but **not** in synchronous actions.

Example

Nesting of untraceable program sections in two program levels with implicit "IPTRUNLOCK". Implicit "IPTRUNLOCK" in subprogram 1 ends the untraceable section.

Program code	Comment
N10010 IPTRLOCK()	
N10020 R1 = R1 + 1	
N10030 G4 F1	; Hold block of the search-suppressed program section starts.
...	

Program code	Comment
N10040 subprogram2	
...	; Interpretation of subprogram 2.
N20010 IPTRLOCK ()	; Ineffective, repeated start.
...	
N20020 IPTRUNLOCK ()	; Ineffective, end at another level.
N20030 RET	
...	
N10060 R2 = R2 + 2	
N10070 RET	; End of search-suppressed program section.
N100 G4 F2	; Main program is continued.

The interruption pointer then produces an interruption at 100 again.

Further information

Acquiring and finding untraceable sections

Untraceable program sections are identified with language commands "IPTRLOCK" and "IPTRUNLOCK".

Command "IPTRLOCK" freezes the interruption pointer at a single block executable in the main run (SB1). This block will be referred to as the hold block below. If the program is aborted after "IPTRLOCK", this hold block can be searched for from the HMI user interface.

Continuing from the current block

The interruption pointer is placed on the current block with "IPTRUNLOCK" as the interruption point for the following program section.

Once the search target is found a new search target can be repeated with the hold block.

An interrupt pointer edited by the user must be removed again via the HMI.

Rules for nesting

The following points govern the interaction between language commands "IPTRLOCK" and "IPTRUNLOCK" with nesting and the subprogram end.

- "IPTRLOCK" is activated implicitly at the end of the subprogram in which "IPTRUNLOCK" is called.
- "IPTRLOCK" in an untraceable section has no effect.
- If subprogram 1 calls subprogram 2 in an untraceable section, the whole of subprogram 2 remains untraceable. "IPTRUNLOCK" in particular has no effect in subprogram 2.

For more information, see

/FB1/ Function Manual, Basic Functions; Mode Group, Channel, Program Operation Mode (K1).

System variable

An untraceable section can be detected in the part program with "\$P_IPTRLOCK".

Automatic interrupt pointer

The automatic interrupt pointer automatically defines a previously defined coupling type as untraceable. Using machine data, for the


- Electronic gear for "EGON"
- Axial master value coupling for "LEADON"

the automatic interrupt pointer is activated. If the programmed interrupt pointer and the automatic interrupt pointer that can be activated via machine data overlap, then the largest possible untraceable section will be generated.

3.14.8 Repositioning to the contour (REPOSA, REPOSL, REPOSQ, REPOSQA, REPOSH, REPOSHA, DISR, DISPR, RMIBL, RMBBL, RMEBL, RMNBL)

If you interrupt the program run and retract the tool during the machining operation – because, for example, the tool has broken or you wish to measure the workpiece – you can reposition at any selected point on the contour under control by the program.

The command `REPOS` acts in an ASUB as a subprogram return (e.g. M17). The following blocks are not executed. For information on interrupting program runs, see also "Interrupt routine (ASUB) (Page 528)."



Syntax

```
REPOSA RMIBL DISPR=...
REPOSA RMBBL
REPOSA RMEBL
REPOSA RMNBL
REPOSL RMIBL DISPR=...
REPOSL RMBBL
REPOSL RMEBL
```

```

REPOSL RMNBL
REPOSQ RMIBL DISPR=... DISR=...
REPOSQ RMBBL DISR=...
REPOSQ RMEBL DISR=...
REPOSQA DISR=...
REPOSH RMIBL DISPR=... DISR=...
REPOSH RMBBL DISR=...
REPOSH RMEBL DISR=...
REPOSHA DISR=...

```

Meaning

Selecting the approach path

REPOSA:	Repositioning to the contour with the geometry axes along a straight line. All other channel axes are also repositioned.
REPOSL:	Repositioning to the contour with the geometry axes along a straight line. Other axes have to be programmed explicitly.
REPOSQ DISR=... :	Repositioning to the contour with the geometry axes along a quadrant of radius DISR. Other axes have to be programmed explicitly.
REPOSQA DISR=... :	Repositioning to the contour with the geometry axes along a quadrant of radius DISR. All other channel axes are also repositioned.
REPOSH DISR=... :	Repositioning to the contour with the geometry axes along a semicircle of diameter DISR. Other axes have to be programmed explicitly.
REPOSHA DISR=... :	Repositioning to the contour with the geometry axes along a semi-circle of radius DISR. All other channel axes are also repositioned.

Selecting the repositioning point

RMIBL:	Approach interruption point
RMIBL DISPR=...:	Entry point at distance DISPR in mm/inch in front of interruption point
RMBBL:	Approach block start point
RMEBL:	Approach end of block
RMEBL DISPR=... :	Approach block end point at distance DISPR in front of end point
RMNBL:	Approach at nearest path point
A0 B0 C0 :	Axes in which approach is to be made

Note

Compatibility


To remain compatible with older software versions, you can still program the `REPOS` approach mode via the modal commands `RMI`, `RMB`, `RME` and `RMN`. When used within an `ASUB`, this should be allocated the attribute `SAVE` in the `PROC` statement. Otherwise the modal `REPOS` approach mode used in the `ASUB` will take effect in subsequent `REPOS` processes, too, if it deviates from the preset `RMI`.

Repositioning to the contour along a straight line, REPOSA, REPOS�

The tool approaches the repositioning point along a straight line.

Example

```
REPOS� RMIBL DISPR=6 F400
```




Repositioning to the contour along a quadrant, REPOSQ, REPOSQA

The tool approaches the repositioning point along a quadrant with a radius of `DISR=...`. The control automatically calculates the necessary intermediate point between the start and repositioning point.

Example

```
REPOSQ RMIBL DISR=10 F400
```




Repositioning to the contour along a semicircle, REPOSH, REPOSHA

The tool approaches the repositioning point along a semi-circle with a diameter of $DISR=...$. The control automatically calculates the necessary intermediate point between the start and repositioning point.

Example


```
REPOSH RMIBL DISR=20 F400
```



Specifying the repositioning point (not for SERUPRO approaching with RMNBL)

With reference to the NC block in which the program run has been interrupted, it is possible to select one of three different repositioning points:

- RMIBL, interruption point
- RMBBL, block start point or last end point
- RMEBL, block end point



RMIBL DISPR=... or RME DISPR=... allows you to select a repositioning point which lies before the interruption point or the block end point.

DISPR=... allows you to describe the contour distance in mm/inch between the repositioning point and the interruption before the end point. Even for high values, this point cannot be further away than the block start point.

If no DISPR=... command is programmed, then DISPR=0 applies and with it the interruption point (with RMIBL) or the block end point (with RMEBL).

DISPR sign

The sign of DISPR is evaluated. In the case of a plus sign, the behavior is as previously.

In the case of a minus sign, approach is behind the interruption point or, with RMBBL, behind the block start point.

The distance between interruption point and approach point depends on the value of DISPR. Even for higher values, this point can lie in the block end point at the maximum.


Application example:

A sensor will recognize the approach to a clamp. An ASUB is initiated to bypass the clamp.

Afterwards, a negative DISPR is repositioned on one point behind the clamp and the program is continued.

SERUPRO approach with RMNBL

If an abort is forced during machining at any position, the shortest path from the abort point is approached with SERUPRO approach and RMNBL so that afterward only the distance-to-go is processed. The user starts a SERUPRO process at the interruption block and uses the JOG keys to move in front of the problem component of the target block.




Note

SERUPRO

For SERUPRO, RMIBL and RMBBL are identical. RMNBL is not only limited to SERUPRO, but is generally valid.

Approach from the nearest path point RMNBL

When REPOSA is interpreted, the repositioning block with RMNBL is not started again in full after an interruption, but only the distance-to-go processed. The nearest path point of the interrupted block is approached.



Status for the valid REPOS mode

The valid REPOS mode of the interrupted block can be read with synchronized actions and variable \$AC_REPOS_PATH_MODE:


- 0 Approach not defined
- 1 RMBBL: Approach to beginning
- 2 RMIBL: Approach to point of interruption
- 3 RMEBL: Approach to end of block
- 4 RMNBL: Approach to next path point of the interrupted block

Approaching with a new tool

The following applies if you have stopped the program run due to tool breakage:

When the new D number is programmed, the machining program is continued with modified tool offset values at the repositioning point.

Where tool offset values have been modified, it may not be possible to reapproach the interruption point. In such cases, the point closest to the interruption point on the new contour is approached (possibly modified by DISPR).



Approach contour

The motion with which the tool is repositioned on the contour can be programmed. Enter zero for the addresses of the axes to be traversed.

The REPOSA, REPOSQA and REPOSHA commands automatically reposition all axes. Individual axis names need not be specified.

When the commands REPOSL, REPOSQ and REPOSH are programmed, all geometry axes are traversed automatically, i.e. they do not have to be specified in the command. All other axes must be specified in the commands.


The following applies to the REPOSH and REPOSQ circular motions:

The circle is traversed in the specified working planes G17 to G19.

If you specify the third geometry axis (infeed direction) in the approach block, the repositioning point is approached along a helix in case the tool position and programmed position in the infeed direction do not coincide.

In the following cases, there is an automatic switchover to linear approach REPOS:

- You have not specified a value for DISR.
- No defined approach direction is available (program interruption in a block without travel information).
- With an approach direction that is perpendicular to the current working plane.



3.14.9 Influencing the motion control

3.14.9.1 Percentage jerk correction (JERKLIM)

Using the NC command "JERKLIM", the maximum jerk of an axis for path motion - set using machine data - can be reduced or increased in critical program sections.

Requirement

The acceleration mode SOFT must be active.

Effectiveness

The function is effective:

- In the AUTOMATIC operating modes.
- Only on path axes.

Syntax

JERKLIM[<axis>]=<value>

Meaning

JERKLIM:	Command for jerk correction	
<axis>:	Machine axis whose jerk limit value is to be adapted.	
<value>:	Percentage correction value, referred to the configured maximum axis jerk for path motion (MD32431 \$MA_MAX_AX_JERK).	
	Range of values:	1 ... 200
	Value 100 does not influence the jerk.	

Note

The behavior of JERKLIM at the end of the part program and channel reset is configured with bit 0 in machine data MD32320 \$MA_DYN_LIMIT_RESET_MASK:

- Bit 0 = 0:
The programmed value for JERKLIM is reset to 100% with channel reset/M30.
- Bit 0 = 1:
The programmed value for JERKLIM is retained beyond the channel reset/M30.

Example

Program code	Comment
...	
N60 JERKLIM[X]=75	; The axis slide in the X direction should only be accelerated/decelerated with a maximum of 75% of the jerk permissible for the axis.
...	

3.14.9.2 Percentage velocity correction (VELOLIM)

The maximum possible velocity of an axis or the maximum possible gear-stage-dependent speed of a spindle set via machine data can be reduce with the VELOLIM command in the part program or synchronized action.

Effectiveness

The function is effective:

- In the AUTOMATIC operating modes.
- On path and positioning axes.
- On spindles in spindle/axis operations

Syntax

```
VELOLIM[<axis/spindle>]=<value>
```

Meaning

VELOLIM:	Command for velocity correction		
<axis/spindle>:	<p>Axis or spindle whose velocity or speed limit value should be adapted.</p> <p>VELOLIM for spindles</p> <p>Using machine data (MD30455 \$MA_MISC_FUNCTION_MASK, bit 6), when programming in the part program, it can be set as to whether "VELOLIM" is effective independent of whether used as spindle or axis (bit 6 = 1) - or is able to be programmed separately for each operating mode (bit 6 = 0). If they are to be separately effective, then the selection is made using the identifier when programming:</p> <ul style="list-style-type: none"> • Spindle identifier S<n> for spindle operating modes • Axis identifier, e.g. "C", for axis operation 		
<value>:	<p>Percentage correction value</p> <p>The correction value refers to:</p> <ul style="list-style-type: none"> • For axes/spindles in axis operation (MD30455 bit 6 == 0): To the configured maximum axis velocity (MD32000 \$MA_MAX_AX_VELO). • For spindles in spindle or axis operation (MD30455 bit 6 == 1): To the maximum speed of the active gear unit stage (MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT[<n>]) 		
	<table border="1"> <tr> <td>Range of values:</td> <td>1 ... 100</td> </tr> </table> <p>The value 100 does not influence the velocity or speed.</p>	Range of values:	1 ... 100
Range of values:	1 ... 100		

Note

Behavior at the end of the part program and for a channel reset

The behavior of "VELOLIM" at the end of the part program and channel reset can be set via the machine data: MD32320 \$MA_DYN_LIMIT_RESET_MASK, bit 0

Detection of an active speed limitation in spindle operation

A speed limitation via "VELOLIM" (less than 100%) can be detected in spindle operation via the following system variables:

- \$AC_SMAXVELO (maximum possible spindle speed)
- \$AC_SMAXVELO_INFO (identifier for the speed-limiting cause)

Examples

Example 1: Velocity limitation, machine axis

Program code	Comment
...	
N70 VELOLIM[X]=80	; The axis slide in the X direction should only be traversed with a maximum of 80% of the velocity permissible for the axis.

Program code	Comment
...	

Example 2: Speed limitation, spindle

Program code	Comment
N05 VELOLIM[S1]=90	; Limiting the maximum speed of spindle 1 to 90% of 1000 rpm.
...	
N50 VELOLIM[C]=45	; Limiting the speed to 45% of 1000 rpm, C is the axis identifier of S1.
...	

Machine data settings for spindle 1 (AX5)

- Maximum speed of gear stage 1 = 1000 rpm:
MD35130 \$MA_GEAR_STEP_MAX_VELO_LIMIT[1, AX5] = 1000
- Programming "VELOLIM" acts together for spindle and axis operation independent of the programmed identifier:
MD30455 \$MA_MISC_FUNCTION_MASK[AX5], bit 6 = 1

3.14.9.3 Program example for JERKLIM and VELOLIM

The following program presents an application example for the percentage jerk and velocity limit:

Program code	Comments
N1000 G0 X0 Y0 F10000 SOFT G64	
N1100 G1 X20 RNDM=5 ACC[X]=20 ACC[Y]=30	
N1200 G1 Y20 VELOLIM[X]=5	; The axis slide in the X direction should only be traversed with max. 5% of the velocity permissible for the axis.
JERKLIM[Y]=200	; The axis slide in the Y direction can be accelerated/decelerated with max. 200% of the jerk permissible for the axis.
N1300 G1 X0 JERKLIM[X]=2	; The axis slide in the X direction should only be accelerated/decelerated with max. 2% of the jerk permissible for the axis.
N1400 G1 Y0	
M30	

3.14.10 Programming contour/orientation tolerance (CTOL, OTOL, ATOL)

Addresses CTOL, OTOL and ATOL can be used to adapt the machining tolerances - parameterized using machine and setting data - for compressor functions, smoothing and orientation smoothing in the part program.

3.14 Path traversing behavior

The programmed tolerance values are valid until they are reprogrammed or deleted by assigning a negative value. Further, they are deleted at the end of the program or a reset. The parameterized tolerance values become effective again after deletion.

Syntax

CTOL=<Value>
 OTOL=<Value>
 ATOL [<Axis>]=<Value>

Meaning

CTOL:	Address to program the contour tolerance			
	Applications:	<ul style="list-style-type: none"> All compressor functions All rounding types except G641 and G644 		
	Preprocessing stop:	No		
	Effective:	Modal		
	<Value>:	The value for the contour tolerance is specified as a length.		
		Type:	REAL	
Unit:		inch/mm (dependent on the current dimensions setting)		
Value range:		≥ 0:	Tolerance value	
	< 0:	The programmed tolerance value is deleted ⇒ The tolerance value parameterized in the machine or setting data becomes effective again.		
OTOL:	Address to program the orientation tolerance			
	Applications:	<ul style="list-style-type: none"> All compressor functions ORISON orientation smoothing All smoothing types except G641, G644 and OSD 		
	Preprocessing stop:	No		
	Effective:	Modal		
	<Value>:	The value for the orientation tolerance is specified as an angle.		
		Type:	REAL	
Unit:		degrees		
Value range:		≥ 0:	Tolerance value	
	< 0:	The programmed tolerance value is deleted ⇒ The tolerance value parameterized in the machine or setting data becomes effective again.		

ATOL:	Address for programming an axis-specific tolerance		
Applications:	<ul style="list-style-type: none"> • All compressor functions • ORISON orientation smoothing • All smoothing types except G641, G644 and OSD 		
Preprocessing stop:	No		
Effective:	Modal		
<Axis>:	Name of the channel axis to which the programmed tolerance will apply		
<Value>:	The value for the axis tolerance will be specified as a length or an angle dependent on the axis type (linear or rotary axis).		
	Type:	REAL	
	Unit:	For linear axes:	inch/mm (dependent on the current dimensions setting)
		For rotary axes:	degrees
Value range:	≥ 0:	Tolerance value	
	< 0:	The programmed tolerance value is deleted ⇒ The tolerance value parameterized in the machine or setting data becomes effective again.	

Note

The channel-specific tolerance values programmed with CTOL and OTOL have higher priority than the axis-specific tolerance values programmed with ATOL.

Note**Scaling frames**

Scaling frames affect programmed tolerances in the same way as axis positions; in other words, the relative tolerance remains the same.

Example

Program code	Comment
COMPCAD G645 G1 F10000	; Activate COMPCAD compressor function.
X... Y... Z...	; The machine and setting data is applied here.
X... Y... Z...	
X... Y... Z...	
CTOL=0.02	; A contour tolerance of 0.02 mm is applied starting from here.
X... Y... Z...	
X... Y... Z...	
X... Y... Z...	
ASCALE X0.25 Y0.25 Z0.25	; A contour tolerance of 0.005 mm is applied starting from here.

Program code	Comment
X... Y... Z...	
X... Y... Z...	
X... Y... Z...	
CTOL=-1	; The machine and setting data is applied again starting from here.
X... Y... Z...	
X... Y... Z...	
X... Y... Z...	

System variables

Reading with preprocessing stop

Using the following system variables, the currently active tolerances can be read in the part program and synchronized action:

- **\$AC_CTOL**
Channel-specific contour tolerance effective when the actual main run block was preprocessed.
If no contour tolerance is effective, \$AC_CTOL will return the root of the sum of the squares of the tolerances of the geometry axes.
- **\$AC_OTOL**
Channel-specific orientation tolerance effective when the actual main run block was preprocessed.
If no orientation tolerance is effective, \$AC_OTOL will return the root of the sum of the squares of the tolerances of the orientation axes during active orientation transformation. Otherwise, it will return the value "-1."
- **\$AA_ATOL[<axis>]**
Axis-specific contour tolerance effective when the actual main run block was preprocessed.
If no contour tolerance is active, \$AA_ATOL[<geometry axis>] returns the contour tolerance divided by the root of the number of geometry axes.
If an orientation tolerance and an orientation transformation are active
\$AA_ATOL[<orientation axis>] will return the orientation tolerance divided by the root of the number of orientation axes.

Note

If now tolerance values have been programmed, the \$A variables are not differentiated enough to distinguish the tolerance of the individual functions.

Circumstances like this can occur if the machine data and the setting data set different tolerances for compressor functions, smoothing and orientation smoothing. The system variables then return the greatest value occurring with the functions that are currently active. For example, if a compressor function is active with an orientation tolerance of 0.1° and ORISON orientation smoothing with 1°, the \$AC_OTOL variable will return the value "1." If orientation smoothing is deactivated, \$AC_OTOL returns a value value "0.1."

Reading without preprocessing stop

Using the following system variables, the currently active tolerances can be read in the part program:

- `$P_CTOL`
Currently active channel-specific contour tolerance.
- `$P_OTOL`
Currently active channel-specific orientation tolerance.
- `$PA_ATOL`
Currently active axis-specific contour tolerance.

Supplementary conditions

The tolerances programmed with CTOL, OTOL and ATOL also affect functions that indirectly depend on these tolerances:

- Limiting the chord error in the setpoint value calculation
- The basic functions of the free-form surface mode

The following smoothing functions are **not** affected by the programming of CTOL, OTOL and ATOL:

- Smoothing the orientation with OSD
OSD does not use a tolerance, it uses a distance from the block transition.
- Smoothing with G644
G644 is not used for smoothing, it is used for optimizing tool changes and other motion not involving machining.
- Smoothing with G645
G645 virtually always behaves like G642 and, thus, uses the programmed tolerances. The tolerance value from machine data MD33120 `$MA_PATH_TRANS_POS_TOL` is only used in uniformly tangential block transitions with a jump in curvature, e.g. a tangential circle/straight line transition. The rounding path at these points may also be located outside the programmed contour, where many applications are less tolerant. Furthermore, it generally takes a small, fixed tolerance to compensate for the sort of changes in curvature which need not concern the NC programmer.

3.14.11 Block change behavior with active coupling (CPBC)

The CPBC command specifies the block change criterion that must be satisfied so that a block change can be executed in the part program with active coupling.

Syntax

```
CPBC[<following axis>] = <criterion>
```

Meaning

CPBC:	Block change criterion with active coupling	
<following axis>:	Axis identifier of the following axis	
<criterion>:	Block change criterion	
	Type:	STRING
	Value	Meaning: Block change is performed
	"NOC"	Irrespective of the coupling status
	"IPOSTOP"	For setpoint synchronism
	"COARSE"	For actual value synchronism "coarse"
"FINE"	For actual value synchronism "fine"	

Example

Program code

```

; Block change takes place with:
; - Coupling to following axis X2 == active
; - Setpoint synchronism == active
CPBC[X2]="IPOSTOP"

```

3.15 Axis functions

3.15.1 Axis replacement, spindle replacement (RELEASE, GET, GETD)

One or more axes or spindles can only ever be interpolated in one channel. If an axis has to alternate between two different channels (e.g. pallet changer) it must first be enabled in the current channel and then transferred to the other channel. Axis replacement is effective between channels.

Axis replacement extensions

An axis/spindle can be replaced either with a preprocessing stop and synchronization between preprocessing and main run, or without a preprocessing stop. An axis interchange is also possible via:

- Frame with rotation if this process links the axis with other axes.
- Synchronized actions, see Motion-synchronous actions, "Axis replacement RELEASE, GET".

Machine manufacturer

Please refer to the machine manufacturer's instructions. For the purpose of axis replacement, one axis must be defined uniquely in all channels in the configurable machine data and the axis replacement characteristics can also be set using machine data.

Syntax

RELEASE (axis name, axis name, ...) or RELEASE (S1)

GET (axis name, axis name, ...) or GET (S2)

GETD (axis name, axis name, etc.) or GETD(S3)


With GETD (GET Directly), an axis is fetched directly from another channel. This means that no suitable RELEASE must be programmed for this GETD in another channel. It also means that other channel communication has to be established (e.g. wait markers).

Meaning

RELEASE (axis name, axis name, etc.):	Release the axis (axes)
GET (axis name, axis name, etc.):	Accept the axis (axes)
GETD (axis name, axis name, etc.):	Directly accept the axis (axes)
Axis name:	Axis assignment in the system: AX1, AX2, ... or specify machine axis name
RELEASE (S1):	Release spindles S1, S2, ...
GET (S2):	Accept spindles S1, S2, ...
GETD (S3):	Direct acceptance of spindles S1, S2, ...

GET request without preprocessing stop

If, following a GET request **without** preprocessing stop, the axis is enabled again with RELEASE (axis) or WAITP (axis), a subsequent GET will induce a GET **with** preprocessing stop.

 CAUTION Axis assignment changed An axis or spindle accepted with GET remains assigned to this channel even after a key or program RESET. When a program is restarted the replaced axes or spindles must be reassigned in the program if the axis is required in its original channel. It is assigned to the channel defined in the machine data on POWER ON.
--

Examples

Example 1: Axis exchange between two channels

Of the six axes, the following are used for machining in channel 1: 1st, 2nd, 3rd and 4th axis. 5th and 6th axis is used in channel 2 for the workpiece change.

Axis 2 should be exchanged between two channels and after POWER ON can be assigned to channel 1.

Program "MAIN" in channel 1:

Program code	Comment
INIT (2, "TRANSFER2")	; Select program TRANSFER2 in channel 2.
N... START (2)	; Start the program in channel 2.
N... GET (AX2)	; Accept axis AX2.
...	
N... RELEASE (AX2)	; Release axis AX2.
N... WAITM (1,1,2)	; Wait for WAIT marker in channel 1 and 2 for synchronizing in both channels.
...	; Rest of program after axis replacement.
N... M30	

Program "TRANSFER2" in channel 2:

Programming	Comment
N... RELEASE (AX2)	
N160 WAITM(1,1,2)	; Wait for WAIT marker in channel 1 and 2 for synchronizing in both channels.
N150 GET(AX2)	; Accept axis AX2.
...	; Rest of program after axis replacement.
N... M30	

Example 2: Axis exchange without synchronization

If the axis does not have to be synchronized no preprocessing stop is generated by GET.

Programming	Comment
N01 G0 X0	
N02 RELEASE (AX5)	
N03 G64 X10	
N04 X20	
N05 GET (AX5)	; If synchronization is not required, then this is not a block that can be executed.
N06 G01 F5000	; Block that cannot be executed.
N07 X20	; Block that cannot be executed, because X position as in N04.
N08 X30	; First block that can be executed after N05.
...	

Example 3: Activating an axis exchange without a preprocessing stop

Requirement: Axis replacement without a preprocessing stop must be configured via machine data.

Programming	Comment
N010 M4 S100	
N011 G4 F2	
N020 M5	
N021 SPOS=0	
N022 POS[B]=1	
N023 WAITP (B)	; Axis B becomes the neutral axis.
N030 X1 F10	
N031 X100 F500	
N032 X200	
N040 M3 S500	; Axis does not trigger a preprocessing stop / REORG
N041 G4 F2	
N050 M5	
N099 M30	

If the spindle or axis B is traversed, e.g. to 180 degrees and then back to 1 degree immediately after block N023 as the **PLC axis**, this axis will revert to its neutral status and will not trigger a preprocessing stop in block N40.

Further information**Requirements for axis replacement**

- The axis must be defined in all channels that use the axis in the machine data.
- It is necessary to define to which channel the axis will be assigned after POWER ON in the **axis**-specific machine data.

Description

Release axis: RELEASE

When enabling the axis please note:

1. The axis must not be involved in a transformation.
2. All the axes involved in an axis link (tangential control) must be enabled.
3. A concurrent positioning axis cannot be replaced in this situation.
4. All the following axes of a gantry master axis are transferred with the master.
5. With coupled axes (coupled motion, master value coupling, electronic gear) only the leading axis of the group can be enabled.

Accept axis: GET

The actual axis replacement is performed with this command. The channel for which the command is programmed takes full responsibility for the axis.

Effects of GET:

Axis replacement with synchronization:

An axis always has to be synchronized if it has been assigned to another channel or the PLC in the meantime and has not been resynchronized with "WAITP", G74 or delete distance-to-go before GET.

- A preprocessing stop follows (as for STOPRE).
- Execution is interrupted until the replacement has been completed.

Automatic "GET"

If an axis is in principle available in a channel but is not currently defined as a "channel axis", GET is executed automatically. If the axis/axes is/are already synchronized no preprocessing stop is generated.

Varying the axis replacement behavior

The transfer point of axes can be set as follows using machine data:

- Automatic axis replacement between two channels then also takes place when the axis has been brought to a neutral state by WAITP (response as before)
- When requesting an axis container rotation, all axes of the axis container which can be assigned to the executing channel are brought into the channel using implicit GET or GETD. A subsequent axle replacement is only permitted again once the axis container rotation has been completed.

- When an intermediate block is inserted in the main run, a check will be made to determine whether or not reorganization is required. Reorganization is only necessary if the axis states of this block do **not** match the current axis states.
- Instead of a GET block with preprocessing stop and synchronization between preprocessing and main run, axes can be replaced without a preprocessing stop. In this case, an intermediate block is simply generated with the GET request. In the main run, when this block is executed, the system checks whether the states of the axes in the block match the current axis states.

For more information about how axis or spindle replacement works, see Function Manual, Extended Functions, Mode Groups, Channels, Axis Replacement (K5).

3.15.2 Transfer axis to another channel (AXTOCHAN)

The `AXTOCHAN` language command can be used to request an axis in order to move it to a different channel. The axis can be moved to the corresponding channel both from the NC part program and from a synchronized action.

Syntax

```
AXTOCHAN(axis name,channel number[,axis name,channel number[,...]])
```

Meaning

Element	Description
<code>AXTOCHAN:</code>	Request axis for a specific channel
<code>Axis name:</code>	Axis assignment in the system: X, Y, ... or entry of machine axis names concerned. The executing channel does not have to be the same channel or even the channel currently in possession of the interpolation right for the axis.
<code>Channel number:</code>	Name of the channel to which the axis is to be assigned

Note

Competing positioning axis and PLC controlled axis exclusively

A PLC axis cannot replace the channel as a competing positioning axis. An axis controlled exclusively by the PLC cannot be assigned to the NC program.

References:

Function Manual, Extended Functions; Positioning Axes (P2)

Example**AXTOCHAN in the NC program**

Axes X and Y have been declared in the first and second channels. Currently, channel 1 has the interpolation right and the following program is started in that channel.

Program code	Comment
N110 AXTOCHAN(Y,2)	;Move Y axis to the second channel
N111 M0	
N120 AXTOCHAN(Y,1)	; Retrieve Y axis (neutral).
N121 M0	
N130 AXTOCHAN(Y,2,X,2)	;Move Y axis and X axis to the second channel (axes are neutral).
N131 M0	
N140 AXTOCHAN(Y,2)	; Move Y axis to the second channel (NC program).
N141 M0	

Further information**AXTOCHAN in the NC program**

A **GET** is only executed in the event of the axis being requested for the NC program in the same channel (this means that the system waits for the state to actually change). If the axis is requested for another channel or is to become the neutral axis in the same channel, the request is sent accordingly.

AXTOCHAN from a synchronized action

In the event of an axis being requested for the same channel, **AXTOCHAN** from a synchronized action is mapped to a **GET** from a synchronized action. In this case, the axis becomes the neutral axis on the first request for the same channel. On the second request, the axis is assigned to the NC program in the same way as the **GET** request in the NC program. For more information about **GET** requests from a synchronized action, see "Motion-synchronous actions".

3.15.3 Axis functions (AXNAME, AX, SPI, AXTOCHI, ISAXIS, AXSTRING, MODAXVAL)

"AXNAME" is used, e.g. to generate cycles that are generally valid, if the names of the axes are not known.

"AX" is used to indirectly program geometry and synchronous axes. The axis identifier is saved in a type **AXIS** variable or is supplied from a command such as "AXNAME" or "SPI".

"SPI" is used if axis functions are programmed for a spindle, e.g. a synchronous spindle.

"AXTOCHI" is used to convert an axis identifier into a spindle index (inverse function to "SPI").

"AXSTRING" is used to convert an axis identifier (data type **AXIS**) into a string (inverse function to "AXNAME").

"ISAXIS" is used in universal cycles in order to ensure that a specific geometry axis exists and thus that any following \$P_AXNX call is not aborted with an error message.

"MODAXVAL" is used in order to determine the modulo position for modulo rotary axes.

Syntax

```
AXNAME("string")
AX[AXNAME("string")]
SPI(n)

AXTOSPI(A) or AXTOSPI(B) or AXTOSPI(C)
AXSTRING( SPI(n) )
ISAXIS(<geometry axis number>)
<Modulo position>=MODAXVAL(<axis>,<axis position>)
```

Meaning

AXNAME:	Converts an input string into axis identifiers; the input string must contain a valid axis name.
AX:	Variable axis identifier
SPI:	Converts the spindle number into an axis identifier; the transfer parameter must contain a valid spindle number.
n:	Spindle number
AXTOSPI:	Converts an axis identifier into an integer spindle index. "AXTOSPI" corresponds to the inverse function to "SPI".
X, Y, Z:	Axis identifier of AXIS type as variable or constant
AXSTRING:	The string is output with the associated spindle number.
ISAXIS:	Checks whether the specified geometry axis exists.
MODAXVAL:	For modulo rotary axes, determines the modulo position; this corresponds to the modulo rest referred to the parameterized modulo range (in the default setting, this is 0 to 360 degrees; the start and size of the modulo range can be changed using MD30340 MODULO_RANGE_START and MD30330 \$MA_MODULO_RANGE).

Note

SPI extensions

The axis function SPI(n) can also be used to read and write frame components. This means that frames can be written, e.g. with the syntax \$P_PFRAME[SPI(1),TR]=2.22.

An axis can be traversed by additionally programming axis positions using the address AX[SPI(1)]=<axis position>. The prerequisite is that the spindle is either in the positioning or axis mode.

Examples

Example 1: AXNAME, AX, ISAXIS

Program code	Comment
OVRA[AXNAME("Transverse axis")]=10	; Override for transverse axis
AX[AXNAME("Transverse axis")]=50.2	; End position for transverse axis
OVRA[SPI(1)]=70	; Override for spindle 1
AX[SPI(1)]=180	; End position for spindle 1
IF ISAXIS(1) == FALSE GOTOF CONTINUE	; Abscissa available?
AX[\$P_AXN1]=100	; Move abscissa
CONTINUE:	

Example 2: AXSTRING

When programming with AXSTRING[SPI(n)], the axis index of the axis, which is assigned to the spindle, is no longer output as spindle number, but instead the string "Sn" is output.

Program code	Comment
AXSTRING[SPI(2)]	; String "S2" is output.

Example 3: MODAXVAL

The modulo position of modulo rotary axis A is to be determined.

Axis position 372.55 is the starting value for the calculation.

The parameterized modulo range is 0 to 360 degrees:

MD30340 MODULO_RANGE_START = 0

MD30330 \$MA_MODULO_RANGE = 360

Program code	Comment
R10=MODAXVAL(A,372.55)	; Calculated modulo position R10 = 12.55.

Example 4: MODAXVAL

If the programmed axis identifier does not refer to a modulo rotary axis, then the value to be converted (<axis position>) is returned unchanged.

Program code	Comment
R11=MODAXVAL(X,372.55)	; X is a linear axis; R11 = 372.55.

3.15.4 Replaceable geometry axes (GEOAX)

The "Switchable geometry axes" function allows the geometry axes configured via machine data to be replaced by other channel axes.

Syntax

```
GEOAX (<n>, <channel axis>, <n>, <channel axis>, <n>, <channel axis>)
GEOAX ()
```


Meaning

GEOAX (...)	Function for switching geometry axes. Note: GEOAX () without parameter specification activates the basic configuration of the geometry axes parameterized in the machine data again.
<n>	Number of the geometry axis that is to be replaced by the specified channel axis. Range of values: 0, 1, 2, 3 Note: 0: The specified channel axis is removed from the geometry axis group without being replaced 1: 1. geometry axis $\hat{=}$ coordinate axis X (abscissa) of the WCS 2: 2. geometry axis $\hat{=}$ coordinate axis Y (ordinate) of the WCS 3: 3. geometry axis $\hat{=}$ coordinate axis Z (applicata) of the WCS
<channel axis>	Name of the channel axis which is to added to the geometry axis group

Examples

Example 1: Switching two axes alternating as geometry axis

A tool slide can be traversed using channel axes X1, Y1, Z1, Z2:



The geometry axes are configured so that after powering-up, initially Z1 is effective as 3rd geometry axis under the geometry axis name "Z" and together with X1 and Y1 forms the geometry axis group.

Axes Z1 and Z2 should now be used, alternating, as geometry axis Z in the part program:

Program code	Comment
...	
N100 GEOAX(3,Z2)	; Channel axis Z2 acts as 3rd geometry axis (Z).

3.15 Axis functions

Program code	Comment
N110 G1 ...	
N120 GEOAX(3,Z1)	; Channel axis Z1 acts as 3rd geometry axis (Z).
...	

Example 2: Changing over the geometry axes for six channel axes

A machine has six channel axes with the names XX, YY, ZZ, U, V, W.

The basic setting of the geometry axis configuration via machine data is:

Channel axis XX = 1st geometry axis (X axis)

Channel axis YY = 2nd geometry axis (Y axis)

Channel axis ZZ = 3rd geometry axis (Z axis)

Program code	Comment
N10 GEOAX()	; The basic configuration of the geometry axes is effective.
N20 G0 X0 Y0 Z0 U0 V0 W0	; All axes in rapid traverse to position 0.
N30 GEOAX(1,U,2,V,3,W)	; Channel axis U becomes the first (X), V the second (Y) ; and W the third geometry axis (Z).
N40 GEOAX(1,XX,3,ZZ)	; Channel axis XX becomes the first (X), ZZ the third geometry axis (Z). Channel axis V remains the second geometry axis (Y).
N50 G17 G2 X20 I10 F1000	; Full circle in the X/Y plane. Channel axes ; XX and V traverse.
N60 GEOAX(2,W)	; Channel axis W becomes the second geometry (Y).
N80 G17 G2 X20 I10 F1000	; Full circle in the X/Y plane. Channel axes ; XX and W traverse.
N90 GEOAX()	; Reset to the initial state.
N100 GEOAX(1,U,2,V,3,W)	; Channel axis U becomes the first (X), V the second ; (Y) and W the third geometry axis (Z).
N110 G1 X10 Y10 Z10 XX=25	; Channel axes U, V, W each traverse to ; position 10. XX as special axis traverses to position 25.
N120 GEOAX(0,V)	; V is removed from the geometry axis group. ; U and W remain the first (X) and third ; geometry axis (Z). ; The second geometry (Y) axis remains unassigned.
N130 GEOAX(1,U,2,V,3,W)	; Channel axis U remains the first (X), V becomes ; the second (Y), W remains the third geometry axis (Z).
N140 GEOAX(3,V)	; V becomes the third geometry axis (Z), whereby W ; is overwritten and therefore removed from the geometry ; axis group. The second geometry axis (Y) ; still remains unassigned.

Machine data

Axis configuration

Assignment of geometry, special and machine axes to channel axes:

- MD10000 \$MN_AXCONF_MACHAX_NAME_TAB
- MD20050 \$MC_AXCONF_GEOAX_ASSIGN_TAB
- MD20060 \$MC_AXCONF_GEOAX_NAME_TAB
- MD20070 \$MC_AXCONF_MACHAX_USED
- MD20080 \$MC_AXCONF_CHANAX_NAME_TAB
- MD35000 \$MA_SPIND_ASSIGN_TO_MACHAX

Reset behavior

Reset behavior of changed geometry axis assignments:

- MD20110 \$MC_RESET_MODE_MASK, bit 12
- MD20118 \$MC_GEOAX_CHANGE_RESET

NC start behavior

- MD20112 \$MC_START_MODE_MASK, bit 12

Notification to the PLC user program

Parameterization option of the M command which is output on the NC/PLC interface when the geometry axes are changed.

- MD22532 \$MC_GEOAX_CHANGE_M_CODE

Supplementary conditions

No geometry axis changeover

- If one of the following functions is active, a geometry axis changeover is not possible:
 - Transformation
 - Spline interpolation
 - Tool radius compensation
 - Tool fine offset
- The geometry axis and another channel axis have the same name.
- One of the axes participating in the geometry axis changeover is involved in an action that goes beyond block limits, e.g. block-wide positioning axis or following axis of an axis coupling.

Rotary axes

Rotary axes cannot be programmed as geometry axes.

Axis state after replacing

An axis replaced by the changeover in the geometry axis group can be programmed as supplementary axis after the changeover operation via its channel axis names.

Frames, protection areas, working area limits

All frames, protection areas and working area limits are deleted after changing over the geometry axes.

Polar coordinates

Replacing the geometry axes with `GEOAX` sets analog to a level change with `G17-G19`, the modal polar coordinates to a value of 0.

DRF, WO

A possible handwheel offset (DRF) or an external work offset (WO) remains effective after the changeover.

Basic configuration of the geometry axes

The `GEOAX ()` command calls the basic configuration of the geometry axis group.

The system automatically changes back to the basic configuration after POWER ON and when changing over into the "reference point approach" mode.

Tool length compensation

An active tool length compensation is also effective after the changeover operation. However, for geometry axes that have been newly added or those where the position has been replaced, it is still considered not to have been moved through. For the first motion command for these geometry axes, the resulting traversing distance correspondingly comprises the sum of the tool length compensation and the programmed traversing distance.

Geometry axes, which retain their position in the axis group after a replacement operation, also retain their status with respect to tool length compensation.

Geometry axis configuration for active transformation

- The geometry axis configuration parameterized for an active transformation via transformation machine data cannot be changed using the "Switchable geometry axes" function.
- Different data sets must be parameterized in the transformation machine data for a different geometry axis configuration for a transformation.
- A geometry axis configuration changed using `GEOAX` is deleted by activating a transformation.
- With regard to the geometry axes, the transformation-specific geometry axis parameterizations of active transformations have priority over the parameterizations relevant for the changeover of geometry axes.
Example: A transformation is active. According to the machine data, the transformation should be retained at a channel reset. At the same time, the basic configuration of the geometry axes should be restored at a channel reset. The geometry axis configuration that has been specified for the transformation is retained.
- If a transformation is switched off, the parameterized basic setting of the geometry axis configuration takes effect again.

JOG mode, REF machine function

When switching over to the JOG mode, REF machine function (reference point approach), the geometry axis configuration parameterized in the machine data takes effect

3.15.5 Wait for valid axis position (WAITENC)

Using the language command "WAITENC", the NC program waits until the synchronized or restored axis positions are available for the axes configured with MD34800 \$MA_WAIT_ENC_VALID = 1.

An interruption can take place in the wait state, e.g. by starting an ASUB or by changing the operating mode to JOG. When the program is continued, where relevant, the wait state is resumed.

Note

In the user interface, the wait state is displayed using the hold state "Wait for measuring system".

Syntax

"WAITENC" can be programmed in the program section of any NC program.

Programming must be realized in a dedicated block:

```
...
WAITENC
...
```

Example

"WAITENC" is for example used in an event-controlled user program, .../_N_CMA_DIR/_N_PROG_EVENT_SPF, as shown in the following application example.

Application example: Tool withdrawal after POWER OFF with orientation transformation

Machining with tool orientation was interrupted due to a power failure.

When powering up again, the event-controlled user program .../_N_CMA_DIR/_N_PROG_EVENT_SPF is called.

In the event-controlled user program, the system waits for synchronized or restored axis positions using "WAITENC"; in order to then be able to calculate a frame, which aligns the Work in the tool direction.

Program code	Comment
...	
IF \$P_PROG_EVENT == 4	; Run-up.
IF \$P_TRAFO <> 0	; Transformation has been selected.
WAITENC	; Wait for valid axis positions of the orientation axes.

Program code	Comment
TOROTZ	; Rotate the Z axis of the WCS towards the tool axis.
ENDIF	
M17	
ENDIF	
...	

The tool can then be retracted in JOG mode by means of a retraction movement towards the tool axis.

3.15.6 Programmable parameter set changeover (SCPARA)

The changeover to a specific parameter set can be requested for an axis with the SCPARA command.

Note

No parameter set changeover during thread cutting

During thread cutting G33 and tapping G331/G332, the parameter set is selected by the control and cannot be changed.

Disabled parameter set changeover

A parameter set changeover can also be requested via the NC/PLC interface. In order to avoid changeover conflicts, the parameter set changeover of the NC (SCPARA) can be disabled via the NC/PLC interface:

DB31, ... DBX9.3 (parameter set specification disabled by NC)

Note

If a parameter set changeover is requested by SCPARA while the parameter set changeover is disabled via the NC/PLC interface, the changeover is rejected without an error message.

Syntax

SCPARA [<axis>]=<value>

Meaning

SCPARA:	Command: Change parameter set	
<axis>:	Axis identifier (channel axis)	
	Type:	AXIS
<value>:	Parameter set number: 1, 2, 3, ... max. parameter set number	

Example

Program code	Comment
...	
N110 SCPARA[X]= 3	; Select: Axis X, 3rd parameter set
...	

Further information

Enable of the parameter set changeover

The parameter set changeover of the axis must be explicitly enabled:

```
MD35590 $MA_PARAMSET_CHANGE_ENABLE[<axis>]
```

Read parameter set number

The number of the selected parameter set (specified parameter set) can be read via the system variable \$AA_SCPAR.

References

Detailed information on the parameter sets can be found in:

Function Manual, Basic Functions; Section "Velocities, setpoint / actual value systems, closed-loop control (G2)" > "Closed-loop control" > "Parameter sets of the position controller"

3.16 Axis couplings


3.16.1 Coupled motion (TRAILON, TRAILOF)

When a defined leading axis is moved, the coupled motion axes (= following axes) assigned to it traverse through the distances described by the leading axis, allowing for a coupling factor.

Together, the leading axis and following axis represent coupled axes.

Applications

- Traversal of an axis by means of a simulated axis. The leading axis is a simulated axis and the coupled axis a real axis. In this way, the real axis can be traversed as a function of the coupling factor.
- Two-sided machining with two coupled motion groups:
 1. leading axis Y, coupled motion axis V
 2. leading axis Z, coupled motion axis W



Syntax

```
TRAILON(<following axis>,<leading axis>,<coupling factor>)
TRAILOF(<following axis>,<leading axis>,<leading axis 2>)
TRAILOF(<following axis>)
```

Meaning

TRAILON:	Command for activating and defining a coupled axis grouping	
	Effective:	Modal
<following axis>:	Parameter 1: Axis name of trailing axis Note: A coupled-motion axis can also act as the leading axis for other coupled-motion axes. In this way, it is possible to create a range of different coupled axis groupings.	
<leading axis>:	Parameter 2: Axis name of trailing axis	

<coupling factor>:	Parameter 3: Coupling factor The coupling factor specifies the desired relationship between the paths of the coupled-motion axis and the leading axis: <coupling factor> = path of coupled-motion axis/path of leading axis	
	Type:	REAL
	Default:	1
	The input of a negative value causes the master and coupled axes to traverse in opposition. If a coupling factor is not programmed, then coupling factor 1 automatically applies.	
TRAILOF:	Command for deactivating a coupled axis grouping	
	Effective:	Modal
	TRAILOF with 2 parameters deactivates only the coupling to the specified leading axis: TRAILOF(<following axis>,<leading axis>) If a coupled-motion axis has two leading axes, TRAILOF can be called with three parameters to deactivate both couplings. TRAILOF(<following axis>,<leading axis>,<leading axis 2>) Programming TRAILOF without specifying a leading axis produces the same result: TRAILOF(<following axis>)	


Note

Coupled axis motion is always executed in the base coordinate system (BCS).

The number of coupled axis groupings which may be simultaneously activated is limited only by the maximum possible number of combinations of axes on the machine.

Example

The workpiece is to be machined on two sides with the axis configuration shown in the diagram. To do this, you create two combinations of coupled axes.



Program code	Comment
...	
N100 TRAILON(V,Y)	; Activation of 1st coupled axis group.
N110 TRAILON(W,Z,-1)	; Activation of 2nd coupled axis grouping, Negative coupling factor: Coupled-motion axis traverses in the opposite direction from leading axis.
N120 G0 Z10	; Infeed of Z and W axes in opposite axial directions.
N130 G0 Y20	; Infeed of Y and V axes in same axis direction.
...	
N200 G1 Y22 V25 F200	; Overlaying of a dependent and independent movement of coupled motion axis V.
...	
TRAILOF(V,Y)	; Deactivation of 1st coupled axis grouping.
TRAILOF(W,Z)	; Deactivation of 2nd coupled axis grouping.

Further information

Axis types

A coupled axis grouping can consist of any desired combinations of linear and rotary axes. A simulated axis can also be defined as a leading axis.

Coupled-motion axes


Up to two leading axes can be assigned simultaneously to a trailing axis. The assignment is made in different combinations of coupled axes.

A coupled-motion axis can be programmed with the full range of available motion commands (G0, G1, G2, G3, etc.). The coupled axis not only traverses the independently defined paths, but also those derived from its leading axes on the basis of coupling factors.

Dynamics limit

The dynamics limit is dependent on the type of activation of the coupled axis grouping:

- **Activation in part program**
If activation is performed in the part program and all leading axes are active as program axes in the activated channel, the dynamic response of all coupled-motion axes is taken into account during traversing of the leading axis to avoid overloading the coupled-motion axes. If activation is performed in the part program with leading axes that are not active as program axes in the activating channel ($\$AA_TYP \neq 1$), then the dynamic response of the coupled-motion axes is not taken into account during traversing of the leading axis. This can cause the overloading of coupled-motion axes with a dynamic response which is less than that required for the coupling.
- **Activation in synchronized action**
If activation is performed in a synchronized action, the dynamic response of the coupled-motion axes is not taken into account during traversing of the leading axis. This can cause the overloading of coupled-motion axes with a dynamic response which is less than that required for the coupling.

 CAUTION
Axis overload
If a coupled axis grouping is activated:
<ul style="list-style-type: none"> • In synchronized actions • In the part program with leading axes that are not program axes in the channel of the coupled-motion axes
It is the specific responsibility of the user / machine manufacturer to take suitable action to ensure that the traversing of the leading axis will not cause the overloading of the coupled-motion axes.

Coupling status

The coupling status of an axis can be checked in the part program with the system variable:

$\$AA_COUP_ACT[<axis>]$

Value	Meaning
0	No coupling active
8	Coupled motion active

Display of distance-to-go of the coupled-motion axis for modulo rotary axes

If the leading and coupled-motion axes are modulo rotary axes, traversing movements in the leading axis from $n * 360^\circ$ with $n = 1, 2, 3 \dots$, add up in the distance-to-go display of the coupled-motion axis until the coupling is switched off.

Example: Program section with TRAILON and leading axis B and following axis C

Program code	Comment
TRAILON(C,B,1)	; Activate coupling
G0 B0	; Starting position
	; Distance-to-go display at block start:


Program code	Comment
G91 B360	; B=360, C=360
G91 B720	; B=720, C=1080
G91 B360	; B=360, C=1440

3.16.2 Curve tables (CTAB)

Curve tables can be used to program position and velocity relationships between two axes (leading and following axis). Curve tables are defined in the part program.

Application


Curve tables replace mechanical cams. The curve table forms the basis for the axial master value coupling by creating the functional relationship between the leading and the following value: With appropriate programming, the control calculates a polynomial that corresponds to the cam from the relative positions of the leading and following axes.



3.16.2.1 Define curve tables (CTABDEF, CATBEND)

A curve table represents a part program or a section of a part program enclosed by CTABDEF at the start and CTABEND at the end.

Within this part program section, unique following axis positions are assigned to individual positions of the leading axis using motion operations; these following axis positions are used as intermediate points when calculating the curve definition in the form of a polynomial up to the 5th order.



Requirement

The MD must be configured accordingly to ensure that sufficient memory space is reserved for the definition of curve tables (→ machine manufacturer).

Syntax

```
CTABDEF(<following axis>,<leading axis>,<n>,<periodicity>[,<memory location>])
...
CTABEND
```

Meaning

CTABDEF ():	Start of curve table definition	
CTABEND:	End of curve table definition	
<following axis>:	Axis whose motion is to be calculated using the curve table	
<leading axis>:	Axis providing the master values for the calculation of the following axis motion	
<n>:	Number (ID) of curve table The number of a curve table is unique and independent of the memory location. It is not possible for there to be tables with the same number in the static and dynamic NC memory.	
<periodicity>:	Table periodicity	
	0	Table is non-periodic (table is processed only once, even for rotary axes)
	1	Table is periodic with regard to the leading axis
	2	Table is periodic with regard to leading axis and following axis

<memory location>:	Specification of memory location (optional)	
	"SRAM"	The curve table is created in the static NC memory.
	"DRAM"	The curve table is created in the dynamic NC memory.
Note: If a value is not programmed for this parameter, the default memory location set with MD20905 \$MC_CTAB_DEFAULT_MEMORY_TYPE is used.		

Note

Overwrite

A curve table is overwritten as soon as its number (<n>) is used in another table definition. (exception: the curve table is either active in an axis coupling or locked with CTABLOCK). **No warning is output when curve tables are overwritten.**


Examples

Example 1: Program section as curve table definition

A program section is to be used unchanged for defining a curve table. The STOPRE command for preprocessing stop can remain and is reactivated immediately as soon as the program section is no longer being used for table definition and CTABDEF and CTABEND have been removed.

Program code	Comment
...	
CTABDEF(Y,X,1,1)	; Definition of a curve table.
...	
IF NOT (\$P_CTABDEF)	
STOPRE	
ENDIF	
...	
CTABEND	

Example 2: Definition of a non-periodic curve table



Program code	Comment
N100 CTABDEF(Y,X,3,0)	; Beginning of the definition of a ;non-periodic curve table with number 3.
N110 X0 Y0	; 1st motion operation, defines the starting values and 1st intermediate point: Master value: 0, Following value: 0
N120 X20 Y0	; 2nd interpolation point: Master value: 0...20, Following value: starting value...0
N130 X100 Y6	; 3rd interpolation point: Master value: 20...100, Following value: 0...6
N140 X150 Y6	; 4th interpolation point: Master value: 100...150, Following value: 6...6
N150 X180 Y0	; 5th interpolation point: Master value: 150...180, Following value: 6...0
N200 CTABEND	; End of the definition. The curve table is generated in its internal representation as a polynomial of up to the 5th order. The calculation of the curve definition with the specified intermediate points is dependent on the modally selected interpolation type (circular, linear, spline interpolation). The part program state before starting the definition is restored.

Example 3: Definition of a periodic curve table

Definition of a periodic curve table with number 2, master value range 0 to 360, following axis motion from 0 to 45 and back to 0:

Program code	Comment
N10 DEF REAL DEPPPOS	

3.16 Axis couplings

Program code	Comment
N20 DEF REAL GRADIENT	
N30 CTABDEF(Y,X,2,1)	; Start of definition.
N40 G1 X=0 Y=0	
N50 POLY	
N60 PO[X]=(45.0)	
N70 PO[X]=(90.0) PO[Y]=(45.0,135.0,-90)	
N80 PO[X]=(270.0)	
N90 PO[X]=(315.0) PO[Y]=(0.0,-135.0,90)	
N100 PO[X]=(360.0)	
N110 CTABEND	; End of the definition.
;Test of the curve by coupling Y to X:	
N120 G1 F1000 X0	
N130 LEADON(Y,X,2)	
N140 X360	
N150 X0	
N160 LEADOF(Y,X)	
N170 DEPPPOS=CTAB(75.0,2,GRADIENT)	; Read the table function for master value 75.0.
N180 G0 X75 Y=DEPPPOS	; Positioning leading and following axes.
;After activating the coupling, no synchronization of the following axis is required.	
N190 LEADON(Y,X,2)	
N200 G1 X110 F1000	
N210 LEADOF(Y,X)	
N220 M30	

Further Information

Starting and end value of the curve table

The starting value for the beginning of the definition range of the curve table are the first associated axis positions specified (the first traverse statement) within the curve table definition. The end value of the definition range of the curve table is determined in accordance with the last traverse command.

Available language scope

Within the definition of the curve table, you have use of the entire NC language.

Note

The following entries are not permitted in curve table definitions:

- Preprocessing stop
- Jumps in the leading axis movement (e.g. on changing transformations)
- Traverse statement for the following axis only
- Reversal of the leading axis, i.e. position of the leading axis must always be unique
- CTABDEF and CTABEND statement on various program levels.

Effectiveness of modal operations

All modal statements that are made within the curve table definition are invalid when the table definition is completed. The part program in which the table definition is made is therefore before and after the table definition in the same state.

Assignments to R-parameters

Assignments to R-parameters in the table definition are reset after CTABEND.

Example:

Program code	Comment
...	
R10=5 R11=20	;R10=5
...	
CTABDEF	
G1 X=10 Y=20 F1000	
R10=R11+5	;R10=25
X=R10	
CTABEND	
...	;R10=5

Activating ASPLINE, BSPLINE, CSPLINE

If an ASPLINE, BSPLINE or CSPLINE is activated within a curve definition table CTABDEF ... CTABEND, at least a start point should be programmed before this spline activation. Immediate activation after CTABDEF should be avoided, otherwise the spline will depend on the current axis position before the curve table definition.

Example:

Program code
...
CTABDEF(Y,X,1,0)
X0 Y0
ASPLINE
X=5 Y=10

Program code

```
X10 Y40  
...  
CTABEND
```

Repeated use of curve tables

The functional relationship between the leading axis and the following axis calculated using the curve table will be retained under the selected table number after the end of the part program and POWER OFF if the table has been saved to the static NC memory (SRAM).

A table created in the dynamic memory (DRAM) will be deleted on POWER ON and may have to be regenerated.

Once created, the curve table can be applied to any axis combinations of leading and following axis and is independent of the axes used to create the curve table.

Overwriting curve tables

A curve table is overwritten as soon as its number is used in another table definition.

Exception: A curve table is either active in an axis coupling or locked with CTABLOCK.

Note

No warning is output when curve tables are overwritten.

Curve table definition active?

The `$P_CTABDEF` system variable can be used at any time in the part program to check whether a curve table definition is active.

Revoking the curve table definition

Once the operations relating to the curve table definition have been excluded, the part program section can be used as a real part program again.

Loading curve tables using "Execution from external source"

If curve tables are executed from an external source, the selection of the size of the reload buffer (DRAM) in MD18360 `$MN_MM_EXT_PROG_BUFFER_SIZE` has to support the simultaneous storage of the entire curve table definition in the reload buffer. If it is not, part program processing will be canceled with an alarm.

Jumps in the following axis

Depending on the setting in machine data MD20900 `$MC_CTAB_ENABLE_NO_LEADMOTION`, jumps in the following axis may be tolerated if a movement is missing in the leading axis.

3.16.2.2 Check for presence of curve table (CTABEXISTS)

The CTABEXISTS command can be used to check if a specific curve table number is present in the NC memory.

Syntax

CTABEXISTS (<n>)

Meaning

CTABEXISTS:	Checks for the presence of curve table number <n> in the static or dynamic NC memory.	
	0	Table does not exist
	1	Table exists
<n>:	Number (ID) of curve table	

3.16.2.3 Delete curve tables (CTABDEL)

CTABDEL can be used to delete curve tables.

Note

Curve tables that are active in an axis coupling cannot be deleted.

Syntax

CTABDEL (<n>)
 CTABDEL (<n>, <m>)
 CTABDEL (<n>, <m>, <memory location>)
 CTABDEL ()
 CTABDEL (, , <memory location>)

Meaning

CTABDEL:	Command for deleting curve tables	
<n>:	Number (ID) of the curve table to be deleted When a curve table range CTABDEL (<n>, <m>) is deleted, <n> is used to specify the number of the first curve table in the range.	
<m>:	When a curve table range CTABDEL (<n>, <m>) is deleted, <m> is used to specify the number of the last curve table in the range. <m> has to be greater than <n>.	
<memory location>:	Specification of memory location (optional) In the case of deletion without a memory location being specified, the specified curve tables are deleted in the static and the dynamic NC memory. In the case of deletion with a memory location being specified, of the specified curve tables, only those located in the specified memory location are deleted. The rest are retained.	
	"SRAM"	Deletion in the static NC memory
	"DRAM"	Deletion in the dynamic NC memory

3.16 Axis couplings

If CTABDEL is programmed without specification of the curve table to be deleted, then **all** curve tables or all curve tables in the specified memory will be deleted:

CTABDEL () :	Deletes all curve tables in the static and the dynamic NC memory
CTABDEL (, , "SRAM") :	Deletes all curve tables in the static NC memory
CTABDEL (, , "DRAM") :	Deletes all curve tables in the dynamic NC memory

Note

If, in the case of multiple deletion with CTABDEL (<n>, <m>) or CTABDEL () , at least one of the of the curve tables to be deleted is active in a coupling, the delete command will not be executed; in other words, **none** of the addressed curve tables will be deleted.

3.16.2.4 Locking curve tables to prevent deletion and overwriting (CTABLOCK, CTABUNLOCK)

Locks can be set to protect curve tables against unintentional deletion and overwriting. Once a lock has been set, it can be revoked at any time.

Syntax

Lock:

CTABLOCK (<n>)
 CTABLOCK (<n>, <m>)
 CTABLOCK (<n>, <m>, <memory location>)
 CTABLOCK ()
 CTABLOCK (, , <memory location>)

Unlock:

CTABUNLOCK (<n>)
 CTABUNLOCK (<n>, <m>)
 CTABUNLOCK (<n>, <m>, <memory location>)
 CTABUNLOCK ()
 CTABUNLOCK (, , <memory location>)

Meaning

CTABLOCK:	Command for setting a lock to prevent deletion/overwriting
CTABUNLOCK:	Command for revoking a lock to prevent deletion/overwriting CTABUNLOCK unlocks the curve tables locked with CTABLOCK. Curve tables which are involved in an active coupling remain locked and cannot be deleted. The lock with CTABLOCK is unlocked as soon as the lock applied due to the active coupling is unlocked when the coupling is deactivated. This table can therefore be deleted. It is not necessary to call CTABUNLOCK again.
<n>:	Number (ID) of the curve table to be locked/unlocked When a curve table range CTABLOCK (<n>, <m>) /CTABUNLOCK (<n>, <m>) is locked/unlocked, <n> is used to specify the number of the first curve table in the range.

<m>:	When a curve table range CTABLOCK (<n>, <m>)/CTABUNLOCK (<n>, <m>) is locked/unlocked, <m> is used to specify the number of the last curve table in the range. <m> has to be greater than <n>.	
<memory location>:	Specification of memory location (optional) In the case of locking/unlocking without a memory location being specified, the specified curve tables are locked/unlocked in the static and the dynamic NC memory. In the case of locking/unlocking with a memory location being specified, of the specified curve tables, only those located in the specified memory location are locked/unlocked. The rest are not locked/unlocked.	
	"SRAM"	Lock/unlock in the static NC memory
	"DRAM"	Lock/unlock in the dynamic NC memory

If CTABLOCK/CTABUNLOCK is programmed without specification of the curve table to be locked/unlocked, then **all** curve tables or all curve tables in the specified memory will be locked/unlocked:

CTABLOCK () :	Locks all curve tables in the static and the dynamic NC memory
CTABLOCK (, , "SRAM") :	Locks all curve tables in the static NC memory
CTABLOCK (, , "DRAM") :	Locks all curve tables in the dynamic NC memory
CTABUNLOCK () :	Unlocks all curve tables in the static and dynamic NC memory
CTABUNLOCK (, , "SRAM") :	Unlocks all curve tables in the static NC memory
CTABUNLOCK (, , "DRAM") :	Unlocks all curve tables in the dynamic NC memory

3.16.2.5 Curve tables: Determine table properties (CTABID, CTABISLOCK, CTABMEMTYP, CTABPERIOD)

These commands can be used to poll important properties of a curve table (table number, lock state, memory location, periodicity).

Syntax

```
CTABID (<p>)
CTABID (<p>, <memory location>)
CTABISLOCK (<n>)
CTABMEMTYP (<n>)
TABPERIOD (<n>)
```

Meaning

CTABID:	<p>Returns the table number entered as the <p>th curve table in the specified memory.</p> <p>Example:</p> <p>CTABID(1, "SRAM") returns the number of the first curve table in the static NC memory. In this context the first curve table is the curve table with the highest table number.</p> <p>Note:</p> <p>If the sequence of curve tables in the memory changes between consecutive calls of CTABID, e.g. due to the deletion of curve tables with CTABDEL, CTABID(<p>, . . .) can return a different curve table with the same number <p>.</p>										
CTABISLOCK:	<p>Returns the lock state of curve table number <n>:</p> <table border="1"> <tr> <td>0</td> <td>Table is not locked</td> </tr> <tr> <td>1</td> <td>Table is locked by CTABLOCK</td> </tr> <tr> <td>2</td> <td>Table is locked by active coupling</td> </tr> <tr> <td>3</td> <td>Table is locked by CTABLOCK and active coupling</td> </tr> <tr> <td>-1</td> <td>Table does not exist</td> </tr> </table>	0	Table is not locked	1	Table is locked by CTABLOCK	2	Table is locked by active coupling	3	Table is locked by CTABLOCK and active coupling	-1	Table does not exist
0	Table is not locked										
1	Table is locked by CTABLOCK										
2	Table is locked by active coupling										
3	Table is locked by CTABLOCK and active coupling										
-1	Table does not exist										
CTABMEMTYP:	<p>Returns the memory location of curve table number <n>:</p> <table border="1"> <tr> <td>0</td> <td>Table in the static NC memory</td> </tr> <tr> <td>1</td> <td>Table in the dynamic NC memory</td> </tr> <tr> <td>-1</td> <td>Table does not exist</td> </tr> </table>	0	Table in the static NC memory	1	Table in the dynamic NC memory	-1	Table does not exist				
0	Table in the static NC memory										
1	Table in the dynamic NC memory										
-1	Table does not exist										
CTABPERIOD:	<p>Returns the periodicity of curve table number <n>:</p> <table border="1"> <tr> <td>0</td> <td>Table is not periodic</td> </tr> <tr> <td>1</td> <td>Table is periodic in the leading axis</td> </tr> <tr> <td>2</td> <td>Table is periodic in the leading and following axes</td> </tr> <tr> <td>-1</td> <td>Table does not exist</td> </tr> </table>	0	Table is not periodic	1	Table is periodic in the leading axis	2	Table is periodic in the leading and following axes	-1	Table does not exist		
0	Table is not periodic										
1	Table is periodic in the leading axis										
2	Table is periodic in the leading and following axes										
-1	Table does not exist										
<p>:	Entry number in memory										
<n>:	Number (ID) of curve table										
<memory location>:	<p>Specification of memory location (optional)</p> <table border="1"> <tr> <td>"SRAM"</td> <td>Static NC memory</td> </tr> <tr> <td>"DRAM"</td> <td>Dynamic NC memory</td> </tr> </table> <p>Note:</p> <p>If a value is not programmed for this parameter, the default memory location set with MD20905 \$MC_CTAB_DEFAULT_MEMORY_TYPE is used.</p>	"SRAM"	Static NC memory	"DRAM"	Dynamic NC memory						
"SRAM"	Static NC memory										
"DRAM"	Dynamic NC memory										

3.16.2.6 Read curve table values (CTABTSV, CTABTEV, CTABTSP, CTABTEP, CTABSSV, CTABSEV, CTAB, CTABINV, CTABTMIN, CTABTMAX)

The following curve table values can be read in the part program:

- Following axis and leading axis values at the start and end of a curve table
- Following axis values at the start and end of a curve segment
- Following axis value for a leading axis value

- Leading axis value for a following axis value
- Following axis minimum and maximum values
 - In the entire definition range of the curve table
or
 - In a defined curve table interval

Syntax

```
CTABTSV(<n>,<gradient>[,<following axis>])
CTABTEV(<n>,<gradient>[,<following axis>])
CTABTSP(<n>,<gradient>[,<leading axis>])
CTABTEP(<n>,<gradient>[,<leading axis>])
CTABSSV(<master value>,<n>,<gradient>[,<following axis>])
CTABSEV(<master value>,<n>,<gradient>[,<following axis>])
CTAB(<master value>,<n>,<gradient>[,<following axis>,<leading axis>])
CTABINV(<following value>,<approximate
value>,<n>,<gradient>[,<following axis>,<leading axis>])
CTABTMIN(<n>[,<following axis>])
CTABTMAX(<n>[,<following axis>])
CTABTMIN(<n>,<a>,<b>[,<following axis>,<leading axis>])
CTABTMAX(<n>,<a>,<b>[,<following axis>,<leading axis>])
```

Meaning

CTABTSV:	Read following axis value at the start of curve table no. <n>
CTABTEV:	Read following axis value at the end of curve table no. <n>
CTABTSP:	Read leading axis value at the start of curve table no. <n>
CTABTEP:	Read leading axis value at the end of curve table no. <n>
CTABSSV:	Read following axis value at the start of the curve segment belonging to the specified leading axis value (<master value>)
CTABSEV:	Read following axis value at the end of the curve segment belonging to the specified leading axis value (<master value>)
CTAB:	Read following axis value for specified leading axis value (<master value>)
CTABINV:	Read leading axis value for specified following axis value (<following value>)
CTABTMIN:	Define following axis minimum value : <ul style="list-style-type: none"> • In the entire definition range of the curve table or • In a defined interval <a> ...
CTABTMAX:	Define following axis maximum value : <ul style="list-style-type: none"> • In the entire definition range of the curve table or • In a defined interval <a> ...
<n>:	Number (ID) of curve table
<gradient>:	The <gradient> parameter returns the incline of the curve table function at the calculated position.

3.16 Axis couplings

<following axis>:	Axis whose motion is to be calculated using the curve table (optional)
<leading axis>:	Axis providing the master values for the calculation of the following axis motion (optional)
<following value>:	Following axis value for reading the associated leading axis value for CTABINV
<leading value>:	Leading axis value: <ul style="list-style-type: none"> • For reading the associated following axis value with CTAB or • For the selection of the curve segment with CTABSSV/CTABSEV
<approximate value>:	The assignment of a leading axis value to a following axis value with CTABINV must not always be unique. CTABINV requires, therefore, an approximate value for the expected leading axis value as a parameter.
<a>:	Lower limit of the master value interval with CTABTMIN/CTABTMAX
:	Upper limit of the master value interval with CTABTMIN/CTABTMAX
	Note: The master value interval <a> to always has to be within the curve table's definition range.

Examples

Example 1:

Define following axis and leading axis values at the start and end of the curve table, along with the minimum and maximum values of the following axis in the entire definition range of the curve table.

Program code	Comment
N10 DEF REAL STARTPOS	
N20 DEF REAL ENDPOS	
N30 DEF REAL STARTPARA	
N40 DEF REAL ENDPARA	
N50 DEF REAL MINVAL	
N60 DEF REAL MAXVAL	
N70 DEF REAL GRADIENT	
...	
N100 CTABDEF(Y,X,1,0)	; Start of table definition
N110 X0 Y10	; Start position 1st table segment
N120 X30 Y40	; End position 1st table segment = start position 2nd table segment
N130 X60 Y5	; End position 2nd table segment = ...
N140 X70 Y30	
N150 X80 Y20	
N160 CTABEND	; End of table definition.
...	
N200 STARTPOS=CTABTSV(1,GRADIENT)	; Following axis value at start of curve table = 10
N210 ENDPOS=CTABTEV(1,GRADIENT)	; Following axis value at end of curve table = 20

Program code	Comment
N220 STARTPARA=CTABTSP(1,GRADIENT)	; Master axis value at start of curve table = 0
N230 ENDPARA=CTABTEP(1,GRADIENT)	; Master axis value at end of curve table = 80
N240 MINVAL=CTABTMIN(1)	; Minimum value of following axis with Y=5
N250 MAXVAL=CTABTMAX(1)	; Maximum value of following axis with Y=40

Example 2:

Determination of following axis values at the start and end of the curve segment associated with leading axis value X=30.

Program code	Comment
N10 DEF REAL STARTPOS	
N20 DEF REAL ENDPOS	
N30 DEF REAL GRADIENT	
...	
N100 CTABDEF(Y,X,1,0)	; Start of table definition.
N110 X0 Y0	; Start position 1st table segment
N120 X20 Y10	; End position 1st table segment = start position 2nd table segment
N130 X40 Y40	; End position 2nd table segment = ...
N140 X60 Y10	
N150 X80 Y0	
N160 CTABEND	; End of table definition.
...	
N200 STARTPOS=CTABSSV(30.0,1,GRADIENT)	; Start position Y in 2nd segment = 10
N210 ENDPOS=CTABSEV(30.0,1,GRADIENT)	; End position Y in 2nd segment = 40

Further information**Use in synchronized actions**


All commands for reading curve table values can also be used in synchronized actions (see also the chapter titled "Motion-synchronous actions").

When using the CTABINV, CTABTMIN, and CTABTMAX commands, make sure that:

- Sufficient NC power is available at the time of execution
or
- The number of segments in the curve table is queried prior to the call, so that the table concerned can be subdivided if necessary


CTAB with non-periodic curve tables

If the specified <master value> is outside the definition range, the upper or lower limit will be output as the following value:



CTAB with periodic curve tables

If the specified <master value> is outside the definition range, the master value is evaluated modulo of the definition range and the corresponding following value is output:



Approximate value for CTABINV

The CTABINV command, therefore, requires an approximate value for the expected master value. CTABINV returns the leading value that is closest to the approximate value. The approximate value can be, for example, the master value from the previous interpolator clock cycle.

Incline of the curve table function

The output of the incline (<gradient>) makes it possible to calculate the velocity of the leading or following axis at the corresponding position.

Specification of the leading or following axis

The optional specification of the leading and/or following axis is important if the leading and following axes are configured in different length units.

CTABSSV, CTABSEV

The CTABSSV and CTABSEV commands are **not** suitable to query programmed segments in the following cases:

- Circles or involutes are programmed.
- Chamfer or rounding with CHE/ RND is active
- Smoothing with G643 is active
- NC block compression with COMPON/COMPCURV/COMPCAD is active

3.16.2.7 Curve tables: Check use of resources (CTABNO, CTABNOMEM, CTABFNO, CTABSEGID, CTABSEG, CTABFSEG, CTABMSEG, CTABPOLID, CTABPOL, CTABFPOL, CTABMPOL)

The programmer can use these commands to obtain up-to-date information about the use of resources for curve tables, table segments, and polynomials.

Syntax

```
CTABNO
CTABNOMEM(<memory location>)
CTABFNO(<memory location>)
CTABSEGID(<n>,<memory location>)
CTABSEG(<memory location>,<segment type>)
CTABFSEG(<memory location>,<segment type>)
CTABMSEG(<memory location>,<segment type>)
CTABPOLID(<n>)
CTABPOL(<memory location>)
CTABFPOL(<memory location>)
CTABMPOL(<memory location>)
```

Meaning

CTABNO:	Determine the total number of defined curve tables (in the static and the dynamic NC memory)
CTABNOMEM:	Determine the number of defined curve tables in the specified <memory location>
CTABFNO:	Determine the number of curve tables remaining possible in the specified <memory location>
CTABSEGID:	Determine the number of curve segments of the specified <segment type> used by curve table number <n>

3.16 Axis couplings


CTABSEG:	Determine the number of curve segments of the specified <segment type> used in the specified <memory location>
CTABFSEG:	Determine the number of curve segments of the specified <segment type> remaining possible in the specified <memory location>
CTABMSEG:	Determine the maximum possible number of curve segments of the specified <segment type> in the specified <memory location>
CTABPOLID:	Determine the number of curve polynomials used by curve table number <n>
CTABPOL:	Determine the number of curve polynomials used in the specified <memory location>
CTABFPOL:	Determine the number of curve polynomials remaining possible in the specified <memory location>
CTABMPOL:	Determine the maximum possible number of curve polynomials in the specified <memory location>
<n>:	Number (ID) of curve table
<memory location>:	Specification of memory location (optional)
	"SRAM" Static NC memory
	"DRAM" Dynamic NC memory
	Note: If a value is not programmed for this parameter, the default memory location set with MD20905 \$MC_CTAB_DEFAULT_MEMORY_TYPE is used.
<segment type>:	Specification of segment type (optional)
	"L" Linear segments
	"P" Polynomial segments
	Note: If no value is programmed for this parameter, the sum of the linear and polynomial segments is output.

3.16.3 Axial master value coupling (LEADON, LEADOF)

Note

This function is not available for SINUMERIK 828D!

With the axial master value coupling, a leading and a following axis are moved in synchronism. It is possible to assign the position of the following axis via a curve table or the resulting polynomial uniquely to a position of the leading axis – simulated if necessary.



The **leading axis** is the axis which supplies the input values for the curve table. The **following axis** is the axis, which takes the positions calculated by means of the curve table.

Actual value and setpoint coupling

The following can be used as the master value, i.e. as the output values for position calculation of the following axis:

- Actual values of the leading axis position: Actual value coupling
- Setpoints of the leading axis position: Setpoint value coupling

The master value coupling always applies in the basic coordinate system.

For information on the creation of curve tables, see Section "Curve tables".

Syntax

```
LEADON(<following axis>,<leading axis>,<n>)
LEADOF(<following axis>,<leading axis>)
```

or deactivation without specifying the leading axis:

```
LEADOF(<following axis>)
```

The master value coupling can be activated/deactivated both from the part program and also during motion from synchronized actions.

Meaning

LEADON:	Activate master value coupling
LEADOF:	Deactivate master value coupling
<following axis>:	Following axis
<leasing axis>:	Leading axis

<n>:	Curve table number
\$SA_LEAD_TYPE:	Switching between setpoint and actual value coupling

Deactivate master value coupling, LEADOF

When you deactivate the master value coupling, the following axis becomes a normal command axis again!

Axial master value coupling and different operating states, RESET

Depending on the setting in the machine data, the master value couplings are deactivated with RESET.

Example of master value coupling from synchronous action

In a pressing plant, an ordinary mechanical coupling between a leading axis (stanchion shaft) and axis of a transfer system comprising transfer axes and auxiliary axes is to be replaced by an electronic coupling system.

It demonstrates how a mechanical transfer system is replaced by an electronic transfer system. The coupling and decoupling processes are implemented as **static synchronized actions**.

From the leading axis LV (stanchion shaft), transfer axes and auxiliary axes are controlled as following axes that are defined via curve tables.

Following axes

X feed or longitudinal axis
 YL closing or transverse axis
 ZL lifting axis
 U roll feed, auxiliary axis
 V guide head, auxiliary axis
 W greasing, auxiliary axis

Actions

The actions that occur include, for example, the following synchronized actions:

- Activate coupling, LEADON(<following axis>,<leading axis>,<curve table number>)
- Deactivate coupling, LEADOF(<following axis>,<leading axis>)
- Set actual value, PRESETON(<axis>,<value>)
- Set marker, \$AC_MARKER[i]=<value>
- Coupling type: real/virtual master value
- Approaching axis positions, POS[<axis>]=<value>

Conditions

Fast digital inputs, real-time variables `$AC_MARKER` and position comparisons are linked using the Boolean operator AND for evaluation as conditions.

Note

In the following example, line change, indentation and **bold** type are used for the sole purpose of improving readability of the program. For the control, everything that follows a line number constitutes a single line.

Comment

Program code	Comment
	; Defines all static synchronized actions.
	; ****Reset marker
N2 \$AC_MARKER[0]=0 \$AC_MARKER[1]=0 \$AC_MARKER[2]=0 \$AC_MARKER[3]=0 \$AC_MARKER[4]=0 \$AC_MARKER[5]=0 \$AC_MARKER[6]=0 \$AC_MARKER[7]=0	
	; **** E1 0=>1 transfer ON
N10 IDS=1 EVERY (\$A_IN[1]==1) AND (\$A_IN[16]==1) AND (\$AC_MARKER[0]==0) DO LEADON(X,LW,1) LEADON(YL,LW,2) LEADON(ZL,LW,3) \$AC_MARKER[0]=1	
	;**** E1 0=>1 coupling roller feed ON
N20 IDS=11 EVERY (\$A_IN[1]==1) AND (\$A_IN[5]==0) AND (\$AC_MARKER[5]==0) DO LEADON(U,LW,4) PRESETON(U,0) \$AC_MARKER[5]=1	
	; **** E1 0->1 coupling alignment head ON
N21 IDS=12 EVERY (\$A_IN[1]==1) AND (\$A_IN[5]==0) AND (\$AC_MARKER[6]==0) DO LEADON(V,LW,4) PRESETON(V,0) \$AC_MARKER[6]=1	
	; **** E1 0->1 lubrication coupling ON
N22 IDS=13 EVERY (\$A_IN[1]==1) AND (\$A_IN[5]==0) AND (\$AC_MARKER[7]==0) DO LEADON(W,LW,4) PRESETON(W,0) \$AC_MARKER[7]=1	
	; **** E2 0=>1 coupling OFF
N30 IDS=3 EVERY (\$A_IN[2]==1) DO LEADOF(X,LW) LEADOF(YL,LW) LEADOF(ZL,LW) LEADOF(U,LW) LEADOF(V,LW) LEADOF(W,LW) \$AC_MARKER[0]=0 \$AC_MARKER[1]=0 \$AC_MARKER[3]=0 \$AC_MARKER[4]=0 \$AC_MARKER[5]=0 \$AC_MARKER[6]=0 \$AC_MARKER[7]=0	
N110 G04 F01	
N120 M30	


Description

Master value coupling requires synchronization of the leading and the following axes. This synchronization can only be achieved if the following axis is inside the tolerance range of the curve definition calculated from the curve table when the master value coupling is activated.

The tolerance range for the position of the following axis is defined via machine data MD 37200: COUPLE_POS_POL_COARSE A_LEAD_TYPE.

If the following axis is not yet at the correct position when the master value coupling is activated, the synchronization run is automatically initiated as soon as the position setpoint value calculated for the following axis is approximately the real following axis position. During the synchronization procedure the following axis is traversed in the direction that is defined by the

setpoint speed of the following axis (calculated from master spindle and using the CTAB curve table).




No synchronism


If the following axis position calculated moves away from the current following axis position when the master value coupling is activated, it is not possible to establish synchronization.

Actual value and setpoint coupling

Setpoint coupling provides better synchronization of the leading and following axis than actual value coupling and is therefore set by default.



Setpoint coupling is only possible if the leading and following axis are interpolated by the same NCU. With an external leading axis, the following axis can only be coupled to the leading axis via the actual values.



A **switchover** can be programmed via setting data `$SA_LEAD_TYPE`.

You must always switch between the actual-value and setpoint coupling when the following axis stops. It is only possible to resynchronize after switchover when the axis is motionless.

Application example

You cannot read the actual values without error during large machine vibrations. If you use master value coupling in press transfer, it might be necessary to switchover from actual-value coupling to setpoint coupling in the work steps with the greatest vibrations.

Master value simulation with setpoint coupling

Via machine data, you can disconnect the interpolator for the leading axis from the servo. In this way you can generate setpoints for setpoint coupling without actually moving the leading axis.

Master values generated from a setpoint link can be read from the following variables so that they can be used, for example, in synchronized actions:

- <code>\$AA_LEAD_P</code>	Master value position
- <code>\$AA_LEAD_V</code>	Master value velocity

Create master value

As an option, master values can be generated with other self-programmed methods. The master values generated in this way are written to and read from variables

- <code>\$AA_LEAD_SP</code>	Master value position
- <code>\$AA_LEAD_SV</code>	Master value velocity

Before you use these variables, the setting data `$SA_LEAD_TYPE = 2` must be set.

Status of coupling

You can query the status of the coupling in the NC program with the following system variable:

```
$AA_COUP_ACT[[axis]]
```

0: No coupling active
16: Master value coupling active

Status management for synchronized actions

Switching and coupling events are managed via real-time variables:

```
$AC_MARKER[i] = n
```

managed with:

i flag number
n status value

3.16.4 Electronic gear (EG)

The "Electronic gear" function allows you to control the movement of a **following axis** according to linear traversing block as a function of up to five **leading axes**. The relationship between each leading axis and the following axis is defined by the coupling factor.

The following axis motion part is calculated by an addition of the individual leading axis motion parts multiplied by their respective coupling factors. When an EG axis grouping is activated, it is possible to synchronize the following axes in relation to a defined position. A gear group can be:

- Defined
- Activated
- Deactivated
- Deleted

.

The following axis movement can be optionally derived from

- Setpoints of the leading axes, as well as
- Actual values of leading axes.

Non-linear relationships between each leading axis and the following axis can also be realized as extension using **curve tables** (see "Path traversing behavior" section). Electronic gears can be cascaded, i.e., the following axis of an electronic gear can be the leading axis for a further electronic gear.

3.16.4.1 Defining an electronic gear (EGDEF)

An EG axis group is defined by specifying the following axis and at least one, however not more than five, leading axis, each with the relevant coupling type.

Requirement

Requirements for defining an EG axis group:

It is not permissible to define an axis coupling for the following axis (or an existing one must first be deleted with EGDEL).

Syntax

```
EGDEF(following axis,leading axis1,coupling type1,leading  
axis2,coupling type2,...)
```

Meaning

EGDEF:	Definition of an electronic gear	
Following axis:	Axis that is influenced by the leading axes	
Leading axis1 , . . . , Leading axis5	Axes that influence the following axis	
Coupling type1 , . . . , Coupling type5	Coupling type The coupling type does not need to be the same for all leading axes and must be programmed separately for each individual master.	
	Value:	Meaning:
	0	The following axis is influenced by the actual value of the corresponding leading axis.
	1	The following axis is influenced by the setpoint of the corresponding leading axis.

Note

The coupling factors are preset to zero when the EG axis grouping is defined.

Note

EGDEF triggers preprocessing stop. The gearbox definition with EGDEF should also be used unaltered if, for systems, one or more leading axes affect the following axis via a **curve table**.

Example

Program code	Comment
EGDEF(C,B,1,Z,1,Y,1)	; Definition of an EG axis group. Leading axes B, Z, Y influence the following axis C via the setpoint.

3.16.4.2 Switch-in the electronic gearbox (EGON, EGONSYN, EGONSYNE)

There are 3 ways to switch-in an EG axis group.

Syntax

Variant 1:

The EG axis group is selectively switched-in without synchronization with:

```
EGON(FA, "block change mode", LA1, Z1, N1, LA2, Z2, N2, . . . , LA5, Z5, N5)
```

Variant 2:

The EG axis group is selectively activated with synchronization with:

```
EGONSYN(FA, "block change mode", SynPosFA, [, LAi, SynPosLAI, Zi, Ni])
```

Variant 3:

The EG axis group is selectively switched-in with synchronization and the approach mode specified with:

EGONSYNE (FA, "block change mode", SynPosFA, approach mode [, LAi, SynPosLAi, Zi, Ni])

Meaning

Variant 1:

FA	Following axis
Block change mode:	The following modes can be used:
	"NOC" Block change takes place immediately
	"FINE" Block change is performed in "Fine synchronism"
	"COARSE" Block change is performed in "Coarse synchronism"
"IPOSTOP" Block change is performed for setpoint-based synchronism	
LA1, ... LA5	Leading axes
Z1, ... Z5	Numerator for coupling factor i
N1, ... N5	Denominator for coupling factor i Coupling factor i = numerator i/denominator i

Only the leading axes previously specified with the EGDEF command may be programmed in the activation line. At least one leading axis must be programmed.

Variant 2:

FA	Following axis
Block change mode:	The following modes can be used:
	"NOC" Block change takes place immediately
	"FINE" Block change is performed in "Fine synchronism"
	"COARSE" Block change is performed in "Coarse synchronism"
"IPOSTOP" Block change is performed for setpoint-based synchronism	
[, LAi, SynPosLAi, Zi, Ni]	(do not write the square brackets) Min. 1, max. 5 sequences of:
LA1, ... LA5	Leading axes
SynPosLAi	Synchronized position for i-th leading axis
Z1, ... Z5	Numerator for coupling factor i
N1, ... N5	Denominator for coupling factor i Coupling factor i = numerator i/denominator i

Only leading axes previously specified with the EGDEF command may be programmed in the activation line. Through the programmed "Synchronized positions" for the following axis (SynPosFA) and for the leading axes (SynPosLA), positions are defined for which the axis

grouping is interpreted as *synchronous*. If the electronic gear is not in the synchronized state when the grouping is switched on, the following axis traverses to its defined synchronized position.

Variant 3:

The parameters correspond to those of variant 2 plus:

Approach mode:	The following modes can be used:	
	"NTGT"	Approach next tooth gap time-optimized
	"NTGP"	Approach next tooth gap path-optimized
	"ACN"	Traverse rotary axis in negative direction absolute
	"ACP"	Traverse rotary axis in positive direction absolute
	"DCT"	Time-optimized for programmed synchronous position
	"DCP"	Distance-optimized to the programmed synchronous position

Variant 3 only affects modulo following axes that are coupled to modulo leading axes. Time optimization takes account of velocity limits of the following axis.

Further information

Description of the switch-in versions

Variant 1:

The positions of the leading axes and following axis at the instant the grouping is switched on are stored as "Synchronized positions". The "Synchronized positions" can be read with the system variable \$AA_EG_SYN.

Variant 2:

If modulo axes are contained in the coupling group, their position values are modulo-reduced. This ensures that the next possible synchronized position is approached (so-called *relative synchronization*: e.g. the next tooth gap). The synchronized position is only approached if "Enable following axis override" interface signal DB(30 + axis number), DBX 26 bit 4 is issued for the following axis. Instead, the program stops at the EGONSYN block and self-clearing alarm 16771 is output until the above mentioned signal is set.

Variant 3:

The tooth distance (deg.) is calculated like this: $360 * Z_i/N_i$. If the following axis is stopped at the time of calling, path optimization returns responds identically to time optimization.

If the following axis is already in motion, NTGP will synchronize at the next tooth gap irrespective of the current velocity of the following axis. If the following axis is already in motion, NTGT will synchronize at the next tooth gap depending on the current velocity of the following axis. The axis is also decelerated, if necessary.

Curve tables

If a **curve table** is used for one of the leading axes:

- Ni The denominator of the coupling factor for linear coupling must be set to 0. (Denominator 0 would be illegal for linear couplings.) Denominator zero tells the control that
- Zi is the number of the curve table to use. The curve table with the specified number must already be defined at POWER ON.
- LAI The leading axis specified corresponds to the one specified for coupling via coupling factor (linear coupling).

For more information about using curve tables and cascading and synchronizing electronic gears, please refer to:

References:

Function Manual Special Functions; Coupled Axes and ESR (M3), "Coupled Motion and Leading Value Coupling".

Response of the electronic gear for power on, RESET, operating mode change, block search

- **No** coupling is active after POWER ON.
- The status of active couplings is not affected by RESET or operating mode switchover.
- During block searches, commands for switching, deleting and defining the electronic gear are not executed or collected, but skipped.

System variables of the electronic gear

By means of the electronic gear's system variables, the part program can determine the current states of an EG axis grouping and react to them if required.

The system variables of the electronic gearbox are designated as follows:

\$AA_EG_ ...

or

\$VA_EG_ ...

References:

System Variables Manual

3.16.4.3 Switching-in the electronic gearbox (EGOFS, EGOFC)

There are 3 different ways to switch-out an active EG axis group.

Programming

Variant 1:

Syntax	Meaning
EGOFS (following axis)	The electronic gear is deactivated. The following axis is braked to a standstill. This call triggers a preprocessing stop.

Variant 2:

Syntax	Meaning
EGOFS (following axis, leading axis1, ..., leading axis5)	This command parameter setting made it possible to selectively remove the influence of the individual leading axes on the following axis' motion.

At least one leading axis must be specified. The influence of the specified leading axes on the slave is selectively inhibited. This call triggers a preprocessing stop. If the call still includes active leading axes, then the slave continues to operate under their influence. If the influence of all leading axes is excluded by this method, then the following axis is braked to a standstill.

Variant 3:

Syntax	Meaning
EGOFC (following spindle1)	The electronic gear is deactivated. The following spindle continues to traverse at the speed/velocity that applied at the instant of deactivation. This call triggers a preprocessing stop.

Note

This variant is only permitted for spindles.

3.16.4.4 Deleting the definition of an electronic gear (EGDEL)

An EG axis group must be switched-out before its definition can be deleted.

Programming

Syntax	Meaning
EGDEL (following axis)	The coupling definition of the axis group is deleted. Additional axis groups can be defined by means of EGDEF until the maximum number of simultaneously activated axis groups is reached. This call triggers a preprocessing stop.

3.16.4.5 Rotational feedrate (G95) / electronic gear (FPR)

The FPR command can be used to specify the following axis of an electronic gear as the axis, which determines the revolutional feedrate. Please note the following with respect to this command:

- The feedrate is determined by the setpoint velocity of the following axis of the electronic gear.
- The setpoint velocity is calculated from the speeds of the leading spindles and modulo axes (which are not path axes) and from their associated coupling factors.
- Speed parts of linear or non-modulo leading axes and overlaid movement of the following axis are not taken into account.

3.16.5 Synchronous spindle

Synchronous operation involves a following spindle (FS) and a leading spindle (LS), referred to as the **synchronous spindle pair**. The following spindle imitates the movements of the leading spindle when a coupling is active (synchronous operation) in accordance with the defined functional interrelationship.

The synchronous spindle pairs for each machine can be assigned a fixed configuration by means of channel-specific machine data or defined for specific applications via the CNC part program. Up to two synchronized spindle pairs can be operated simultaneously on each NC channel.

Refer to the part program for the following coupling actions

- Defined or changed
- Activated
- Deactivated
- Deleted

In addition, depending on the software status

- It is possible to wait for the synchronism conditions
- The block change method can be changed
- Either the setpoint coupling or actual value coupling type is selected or the angular offset between master and following spindle specified
- When activating the coupling, previous programming of the following axis is transferred
- Either a measured or a known synchronism variance is corrected

3.16.5.1 Synchronous spindle: Programming (COUPDEF, COUPDEL, COUPON, COUPONC, COUPOF, COUPOFS, COUPRES, WAITC)


The "Synchronous spindle" enables the speed-synchronous traversing of the following spindle (FS) and leading spindle (LS) with a programmable transformation ratio.

The function supports the following modes:

- Speed synchronism ($n_{FS} = n_{LS}$)
- Position synchronism ($\phi_{FS} = \phi_{LS}$)
- Position synchronism with angular offset ($\phi_{FS} = \phi_{LS} + \Delta\phi$)


Application examples:

- Flying workpiece transfer, e.g. to machine the rear side, transformation ratio: 1:1



- ① Synchronize the speed
- ② Transfer the workpiece
- ③ Machine the rear side

- Multi-edge machining (polygonal turning), speed synchronism, transformation ratio: $n_1:n_2$



Syntax

```

COUPDEF (<FS>, <LS>, <ZFS>, <NLS>, <block change>, <coupling type>)
COUPON (<FS>, <LS>, <POSFS>)
COUPONC (<FS>, <LS>)
COUPOF (<FS>, <LS>, <POSFS>, <POSLS>)
COUPOFS (<FS>, <LS>)
COUPOFS (<FS>, <LS>, <POSFS>)
COUPRES (<FS>, <LS>)
COUPDEL (<FS>, <LS>)
WAITC (<FS>, <block change>, <LS>, <block change>)

```

Note**Abbreviated notation**

A shorter notation without specification of the leading spindle is possible for the COUPOF, COUPOFS, COUPRES and COUPDEL statements.

Meaning

COUPDEF:	Define/change coupling on user-specific basis
COUPON:	Activate coupling. The following spindle synchronizes to the leading spindle based on the actual speed
COUPONC:	Coupling when activating with previous programming of M3 S... or M4 S... A difference in speed for the following spindle is transferred immediately.
COUPOF:	Deactivate coupling. <ul style="list-style-type: none"> with immediate block change: COUPOF (<S2>, <S1>) Block change only after <POSFS> or <POSLS> deactivation position(s) has (have) been crossed: COUPOF (<S2>, <S1>, <POSFS>) COUPOF (<S2>, <S1>, <POSFS>, <POSLS>)
COUPOFS:	Deactivating a coupling with stop of following spindle. Block change as quickly as possible with immediate block change: COUPOFS (<S2>, <S1>) Block change only after passing the switch-off position: COUPOFS (<S2>, <S1>, <POSFS>)
COUPRES:	Reset coupling parameters to configured MD and SD
COUPDEL:	Delete user-defined coupling
WAITC:	Wait for synchronized run condition (NOC are increased to IPO during block changes)
<FS>:	Designation of following spindle
Optional parameters:	
<LS>:	Designation of main spindle Specification with spindle number: e.g. S2, S1
<ZFS>, <NLS>:	Transformation ratio between FS and LS. $\text{<ZFS>/<NLS> = numerator/denominator}$ Default setting: <ZFS> / <NLS> = 1.0 ; specification of denominator optional

<block change>:	Block change behavior	
	The block change is:	
	"NOC"	Immediately
	"FINE"	On reaching "Synchronism fine"
	"COARSE"	On reaching "Synchronism coarse"
	"IPOSTOP"	On reaching IPOSTOP; in other words, after setpoint-based synchronism (default)
The block change behavior is effective modally.		
<coupling type>:	Coupling type: Coupling between FS and LS	
	"DV"	Setpoint linkage (default)
	"AV"	Actual value coupling
	"VV"	Speed coupling
	The coupling type is modal.	
<POSFS>:	Angle offset between leading and following spindles	
	Range of values:	0°... 359.999°
<POSFS>, <POSLS>:	Switch-off positions of the following and leading spindles "The block change is enabled once POS _{FS} , POS _{LS} has been passed"	
	Range of values:	0°... 359.999°

Examples

Working with leading and following spindles

Program code	Comment
	Leading spindle = master spindle = spindle 1 Following spindle = spindle 2
N05 M3 S3000 M2=4 S2=500	Leading spindle rotates at 3000 rpm, following spindle at 500 rpm.
N10 COUPDEF(S2,S1,1,1,"NOC","Dv")	Definition of the coupling (can also be configured).
...	
N70 SPCON	Bring leading spindle into closed-loop position control (setpoint coupling).
N75 SPCON(2)	Bring following spindle into closed-loop position control.
N80 COUPON(S2,S1,45)	On-the-fly coupling to offset position = 45 degrees.
...	
N200 FA[S2]=100	Positioning speed = 100 degrees/min
N205 SPOS[2]=IC(-90)	Traverse with 90 degrees overlay in negative direction.
N210 WAITC(S2,"Fine")	Wait for "fine" synchronism.
N212 G1 X... Y... F...	Machining
...	

3.16 Axis couplings

Program code	Comment
N215 SPOS[2]=IC(180)	Traverse with 180 degrees overlay in the positive direction.
N220 G4 S50	Dwell time = 50 revolutions of the master spindle
N225 FA[S2]=0	Activate configured velocity (MD).
N230 SPOS[2]=IC(-7200)	20 revolutions. Move with configured velocity in the negative direction.
...	
N350 COUPOF(S2,S1)	Couple-out on-the-fly, S=S2=3000
N355 SPOSA[2]=0	Stop FS at zero degrees.
N360 G0 X0 Y0	
N365 WAITS(2)	Wait for spindle 2.
N370 M5	Stop FS.
N375 M30	

Programming a difference in speed

Program code	Comment
	Leading spindle = master spindle = spindle 1 Following spindle = spindle 2
N01 M3 S500	Leading spindle rotates at 500 rpm.
N02 M2=3 S2=300	Following spindle rotates at 300 rpm.
...	
N10 G4 F1	Dwell time of master spindle.
N15 COUPDEF (S2,S1,-1)	Coupling factor with ratio -1:1
N20 COUPON(S2,S1)	Activate coupling. The speed of the following spindle results from the speed of the leading spindle and coupling factor.
...	
N26 M2=3 S2=100	Programming a difference in speed.

Examples of transfer of a movement for difference in speed

1. Activate coupling during previous programming of following spindle with COUPON

Program code	Comment
	Leading spindle = master spindle = spindle 1 Following spindle = spindle 2
N05 M3 S100 M2=3 S2=200	Leading spindle rotates at 100 rpm, following spindle at 200 rpm.
N10 G4 F5	Dwell time = 5 seconds of master spindle
N15 COUPDEF(S2,S1,1)	Transformation ratio of FS to LS is 1.0 (default).
N20 COUPON(S2,S1)	On-the-fly coupling to the leading spindle.
N10 G4 F5	Following spindle rotates at 100 rpm.

2. Activate coupling during previous programming of following spindle with COUPONC

Program code	Comment
	Leading spindle = master spindle = spindle 1 Following spindle = spindle 2
N05 M3 S100 M2=3 S2=200	Leading spindle rotates at 100 rpm, following spindle at 200 rpm.
N10 G4 F5	Dwell time = 5 seconds of master spindle
N15 COUPDEF(S2,S1,1)	Transformation ratio of FS to LS is 1.0 (default).
N20 COUPONC(S2,S1)	On-the-fly coupling to leading spindle and transfer previous speed to S2.
N10 G4 F5	S2 rotates at 100 rpm + 200 rpm = 300 rpm

3. Activate coupling with following spindle stationary with COUPON

Program code	Comment
	Leading spindle = master spindle = spindle 1 Following spindle = spindle 2
N05 SPOS=10 SPOS[2]=20	Following spindle S2 in positioning mode.
N15 COUPDEF(S2,S1,1)	Transformation ratio of FS to LS is 1.0 (default).
N20 COUPON(S2,S1)	On-the-fly coupling to the leading spindle.
N10 G4 F1	Coupling is closed, S2 stops at 20 degrees.

4. Activate coupling with following spindle stationary with COUPONC

Note

Positioning or axis mode

If the following spindle is in positioning or axis mode before coupling, then the following spindle behaves the same for COUPON (<FS>, <LS>) and COUPONC (<FS>, <LS>).

Note

Leading spindle and axis operation

If, prior to the coupling being defined, the leading spindle is in axis operation, the velocity limit value from machine data

MD32000 \$MA_MAX_AX_VELO (maximum axis velocity) will still apply even after the coupling is activated.

To avoid this behavior, the axis must be switched to spindle mode (M3 S... or M4 S...) prior to the coupling being defined.

Further information

Configured coupling

For the configured coupling, the LS and FS are defined via machine data. The configured spindles cannot be changed in the part program. The coupling can be parameterized in the part program using `COUPDEF` (on condition that no write protection is valid).

User-defined coupling

`COUPDEF` can be used to redefine or change a coupling in the part program. If a coupling is already active, it has to be deleted first with `COUPDEL` before a new coupling is defined.

A coupling is defined in its entirety by:

```
COUPDEF(<FS>,<LS>,<TFS>,<TLS>, block change behavior, coupling type)
```

Following spindle (FS) and leading spindle (LS)

The coupling is uniquely defined using the axis names for the FS and LS. The axis names have to be programmed with every `COUPDEF` statement. The other coupling parameters are modal and only have to be programmed if they change.

Example:

```
COUPDEF(S2,S1)
```

Transformation ratio

The transformation ratio is defined as the speed ratio between FS and LS:


Following spindle / leading spindle = numerator/denominator

The numerator must be programmed. The denominator must not be programmed. The default value 1.0 is then set for the denominator.

Example:

Following spindle S2 and leading spindle S1, transformation ratio = 1/1

```
COUPDEF(S2, S1, 1.0)
```



Note

The transformation ratio can also be changed on-the-fly (when the coupling is active and the spindles are rotating).

Block change behavior NOC, FINE, COARSE, IPOSTOP

The following abbreviated notation can be used when programming the block change behavior:

- "NO": Immediately (default)
- "FI": On reaching "Synchronism fine"
- "CO": On reaching "Synchronism coarse"
- "IP": On reaching IPOSTOP; i.e. after setpoint-based synchronism

Type of coupling

Note

The coupling type may only be changed when the coupling is deactivated.

Activate synchronous mode COUPON, <POSFS>

- Activation of coupling with any angular offset between LS and FS:
 - COUPON (S2, S1)
 - COUPON (S2)
- Activation of coupling with angular offset <POSFS>
<POSFS> refers to the 0° position of the leading spindle in the positive direction of rotation <POSFS> value range: 0°... 359,999°
 - COUPON (S2, S1, 30)

Note

The angular offset can also be changed when the coupling is active.

Position the following spindle

Even with activated synchronous spindle coupling, the FS can be positioned in the range $\pm 180^\circ$ independently of the LS.

- Spindle positioning of the FS with SPOS
Example: SPOS [2]=IC (-90)
Further information on SPOS can be found in:

References:

Programming Manual, Fundamentals

Differential speed

A speed difference results in speed control mode and active synchronous spindle coupling through signed overlay of an FS speed because of LS movement and an FS speed because of spindle programming:

- Synchronous spindle coupling with COUPONC
 - S<FS>=<speed> [M<FS>=<direction of rotation>]
-

Note

Supplementary conditions

- Speed S . . . must also be reprogrammed with direction of rotation M3/M4.
- Overlay of a spindle speed (M<direction of rotation> S<FS>) through the LS movement with synchronous spindle coupling COUPONC only becomes effective if the overlay has been enabled.
- The dynamic responses of the leading spindle have to be restricted to such an extent that when overlaying is applied to the following spindle, its dynamics limit values are not exceeded.

For more information about the speed difference, see:

References:

Function Manual, Extended Functions; Synchronous Spindle (S3)

Velocity, acceleration: FA, ACC, OVRA, VELOLIMA

Axial velocity and acceleration of a following spindle can be programmed with:

- FA[SPI(S<n>)] or FA[S<n>] (axial velocity)
- ACC[SPI(S<n>)] or ACC[S<n>] (axial acceleration)
- OVRA[SPI(S<n>)] and OVRA[S<n>] (axial override)
- VELOLIMA[SPI(S<n>)] and VELOLIMA[S<n>] (increase and reduction of axial velocity respectively)

When <n> = 1, 2, 3, ... (spindle numbers of the following spindles)

References:

Programming Manual, Fundamentals

Note

A reduction or increase of the maximum axial jerk has no effect with spindles.

Further information about the axial dynamic response is provided in:

References:

Function Manual, Extended Functions; Rotary Axes (R2)

Programmable block change behavior WAITC

WAITC can be used to define block change behavior, for example after a change to coupling parameters or positioning actions, with a variety of synchronism conditions (coarse, fine, IPOSTOP). If no synchronism conditions are specified, the block change behavior specified in the COUPDEF definition will apply.

Examples

- Wait for synchronism condition `FINE` to be fulfilled for following spindle `S2` and `COARSE` to be fulfilled for following spindle `S4`: `WAITC (S2, "FINE", S4, "COARSE")`
- Wait for synchronism condition according to `COUPDEF` to be fulfilled: `WAITC ()`

Deactivate coupling COUPOF

`COUPOF` can be used to define the turn-off behavior of the coupling:

- Deactivation of coupling with immediate block change:
 - `COUPOF (S2, S1)` (with specification of leading spindle)
 - `COUPOF (S2)` (without specification of leading spindle)
- Deactivation of coupling after switch-off positions have been crossed. The block change takes place after the switch-off positions have been crossed.
 - `COUPOF (S2, S1, 150)` (switch-off position FS: 150°)
 - `COUPOF (S2, S1, 150, 30)` (switch-off position FS: 150°, LS: 30°)

Deactivate coupling with following spindle stop COUPOFS

`COUPOFS` can be used to define the turn-off behavior of the coupling with following spindle stop:

- Deactivation of coupling with following spindle stop and immediate block change:
 - `COUPOFS (S2, S1)` (with specification of leading spindle)
 - `COUPOFS (S2)` (without specification of leading spindle)
- Deactivation of coupling after switch-off positions have been crossed with following spindle stop. The block change takes place after the switch-off positions have been crossed.
 - `COUPOFS (S2, S1, 150)` (switch-off position FS: 150°)

Delete couplings COUPDEL

`COUPDEL` deletes the coupling:

- `COUPDEL (S2, S1)` (with specification of leading spindle)
- `COUPDEL (S2)` (without specification of leading spindle)

Reset coupling parameters, COUNPRES

`COUNPRES` activates the coupling values parameterized in the machine and setting data:

- `COUNPRES (S2, S1)` (with specification of leading spindle)
- `COUNPRES (S2)` (without specification of leading spindle)

System variables

- Current coupling status of following spindle
The current coupling status of a following spindle can be read bit-coded via:
`<value> = $AA_COUP_ACT [<FS>]`

Bit	<value>	Meaning
-	0	No coupling active
2	4	Synchronous spindle coupling active

Note

- All other values refer to axis mode
- If the spindle is a following spindle or several couplings, then the value of the coupling state of all couplings is returned as a total state.

- **Current angular offset**

The current angular offset of the following spindle to the leading spindle can be read via:

- \$AA_COUP_OFFS [<FS>] (angular offset on the setpoint side)
- \$VA_COUP_OFFS [<FS>] (angular offset on the actual value side)

Application example

Correction of the angular offset difference in the NC program after cancelling the follow-up mode:

Angular offset difference = programmed angular offset - system variable

References

Detailed information on the system variables can be found in:

List Manual, System Variables

3.16.6 Generic coupling (CP...)

"Generic Coupling" is a general coupling function, combining all coupling characteristics of existing coupling types (coupled motion, master value coupling, electronic gearbox and synchronous spindle).

The function allows flexible programming:

- Users can select the coupling properties required for their applications (building block principle).
- Each coupling property can be programmed individually.
- The coupling properties of a defined coupling (e.g. coupling factor) can be changed.
- Later use of additional coupling properties is possible.
- The coordinate reference system of the following axis (base coordinate system or machine coordinate system) is programmable.
- Certain coupling properties can also be programmed with synchronous actions.

References: Function Manual, Synchronized Actions

Note

Previous coupling calls for coupled motion (TRAIL*), Master value coupling (LEAD*), Electronic Gearbox (EG*) and Synchronous spindle (COUP*) are supported via adaptive cycles.

Overview of all keywords and coupling characteristics

The following table gives an overview of all keywords of the generic coupling and the programmable coupling characteristics:

Keyword	Coupling characteristics / meaning	Syntax		
CPDEF	Creation of a coupling module	CPDEF= (<FAx>)		
CPDEL	Deletion of a coupling module	CPDEL= (<FAx>)		
CPLA	Definition of a leading axis	CPLA [<FAx>] = (<LAX>)		
CPLDEF	Definition of a leading axis and creation of a coupling module (also possible with CPDEF + CPLA)	CPLDEF [<FAx>] = (<LAX>) or CPDEF= (<FAx>) CPLA [<FAx>] = (<LAX>)		
CPLDEL	Deletion of a leading axis of a coupling module (also possible with CPDEF + CPLA)	CPLDEL [<FAx>] = (<LAX>) or CPDEL= (<FAx>) CPLA [<FAx>] = (<LAX>)		
CPON	Switching on a coupling module	CPON= (<FAx>)		
CPOF	Switching off a coupling module	CPOF= (<FAx>)		
CPLON	Switching on a leading axis of a coupling module	CPLON [<FAx>] = <LAX>		
CPLOF	Switching off a leading axis of a coupling module	CPLOF [<FAx>] = <LAX>		
CPLNUM	Numerator of the coupling factor	CPLNUM [FAx, LAX] = <value>		
CPLDEN	Denominator of the coupling factor	CPLDEN [FAx, LAX] = <value>		
CPLCTID	Number of the curve table	CPLCTID [FAx, LAX] = <value>		
CPLSETVAL	Coupling reference	CPLSETVAL [FAx, LAX] = "<coupling reference>"		
		"<coupling reference>":	"CMDPOS"	Setpoint value coupling
		"CMDVEL"	Speed coupling	
		"ACTPOS"	Actual value coupling	
CPFRS	Coordinate reference system	CPFRS [FAx] = "<coordinate reference>"		
		"<coordinate reference>":	"BCS"	Basic Coordinate System
		"MCS"	Machine Coordinate System	

3.16 Axis couplings

Keyword	Coupling characteristics / meaning	Syntax	
CPBC	Block change criterion	CPBC[FAx]="<block change criterion>"	
		"<block change criterion>":	"NOC" Block change is performed irrespective of the coupling status.
		"IPOSTOP" Block change is performed with setpoint synchronism.	
		"COARSE" Block change is performed with actual value synchronism "coarse".	
		"FINE" Block change is performed with actual value synchronism "fine".	
CPFPOS + CPON	Synchronized position of the following axis when switching on	CPON=FAx CPFPOS[FAx]=<value>	
CPLPOS + CPON	Synchronized position of the leading axis when switching on	CPLPOS[FAx, LAx]=<value>	

Keyword	Coupling characteristics / meaning	Syntax		
CPFMSON	Synchronization mode	CPFMSON[FAx]="<synchronization mode>"		
		"<synchronization mode>":	"CFAST"	The coupling is closed time-optimized.
			"CCOARSE"	The coupling is only closed when the following axis position, required according to the coupling rule, is in the range of the current following axis position.
			"NTGT"	The next tooth gap is approached time-optimized.
			"NTGP"	The next tooth gap is approached path-optimized.
			"NRGT"	The next segment is approached in a time-optimized manner, in accordance with the ratio of the number of gears to the number of teeth.
			"NRGP"	The next segment is approached in a path-optimized manner, in accordance with the ratio of the number of gears to the number of teeth.
			"ACN"	For rotary axes only! The rotary axis traverses to the synchronized position in the negative axis direction. Synchronization is realized immediately.
			"ACP"	For rotary axes only! The rotary axis traverses to the synchronized position in the positive axis direction. Synchronization is realized immediately.
			"DCT"	For rotary axes only! The rotary axis traverses to the programmed synchronized position time-optimized. Synchronization is realized immediately.
"DCP"	For rotary axes only! The rotary axis traverses to the programmed synchronized position path-optimized. Synchronization is realized immediately.			

3.16 Axis couplings

Keyword	Coupling characteristics / meaning	Syntax		
CPFMON	Behavior of the following axis when switching on	CPFMON[FAx]= "<switch-on behavior>"		
		"<switch-on behavior>":	"STOP"	For spindles only! An active motion of the following spindle is stopped before switch-on.
			"CONT"	For spindles and main traverse axes only! The current motion of the following axis/spindle is taken over into the coupling as start motion.
"ADD"	For spindles only! The motion components of the coupling operate in addition to the currently overlaid motion, i.e. the current motion of the following axis/spindle is retained as overlaid motion.			
CPFMOF	Behavior of the following axis at complete switch-off	CPFMOF[FAx]="<switch-off behavior>"		
		"<switch-off behavior>":	"STOP"	Stop of a following axis/spindle. An active overlaid motion is also braked to standstill. The coupling is then opened
"CONT"	For spindles and main traverse axes only! The following spindle continues to traverse at the speed/velocity that applied at the instant of deactivation.			
CPFPOS + CPOF	Switch-off position of the following axis when switching off	CPOF= (FAx) CPFPOS[FAx]=<value>		

Keyword	Coupling characteristics / meaning	Syntax		
CPMRESET	Coupling behavior for RESET	CPMRESET[FAx]="<Reset behavior>"		
		"<reset behavior>":	"NONE"	The current state of the coupling is retained.
			"ON"	When the appropriate coupling module is created, the coupling is switched on. All defined leading axis relationships are activated. This is also performed when all or parts of these leading axis relationships are active, i.e. resynchronization is performed even with a completely activated coupling.
			"OF"	An active overlaid motion is also braked to standstill. The coupling is then deactivated. When the relevant coupling module was created without an explicit definition (CPDEF), the coupling module is deleted. Otherwise it is retained, i.e. it can still be used.
			"OFC"	Possible only in spindles! The following spindle continues to traverse at the speed/velocity that applied at the instant of deactivation. The coupling is switched off. When the relevant coupling module was created without an explicit definition (CPDEF), the coupling module is deleted. Otherwise it is retained, i.e. it can still be used.
			"DEL"	An active overlaid motion is also braked to standstill. The coupling is then deactivated and then deleted.
			"DELC"	Possible only in spindles! The following spindle continues to traverse at the speed/velocity that applied at the instant of deactivation. The coupling is deactivated and then deleted.

3.16 Axis couplings

Keyword	Coupling characteristics / meaning	Syntax		
CPMSTART	Coupling behavior at part program start	CPMSTART[FAx]="<start behavior>"		
		"<start behavior>":	"NONE"	The current state of the coupling is retained.
			"ON"	Coupling switched-on. All defined leading axis relationships are activated. This is also performed when all or parts of these leading axis relationships are active, i.e. resynchronization is performed even with a completely activated coupling.
			"OF"	The coupling is switched off. When the relevant coupling module was created without an explicit definition (CPDEF), the coupling module is deleted. Otherwise it is retained, i.e. it can still be used.
		"DEL"	The coupling is deactivated and then deleted.	
CPMPRT	Coupling response at part program start under block search run via program test	CPMPRT[FAx]="<start behavior>"		
		"<start behavior>":	see CPMSTART	
CPLINTR	Offset value of the input value of a leading axis	CPLINTR[FAx, LAx]=<value>		
CPLINSC	Scaling factor of the input value of a leading axis	CPLINSC[FAx, LAx]=<value>		
CPLOUTTR	Offset value for the output value of a coupling	CPLOUTTR[FAx, LAx]=<value>		
CPLOUTSC	Scaling factor for the output value of a coupling	CPLOUTSC[FAx, LAx]=<value>		
CPSYNCOF	Threshold value of position synchronism "Coarse"	CPSYNCOF[FAx]=<value>		
CPSYNFIP	Threshold value of position synchronism "Fine"	CPSYNFIP[FAx]=<value>		
CPSYNCOF2	Second threshold value for the "Coarse" position synchronism	CPSYNCOF2[FAx]=<value>		
CPSYNFIP2	Second threshold value for the "Fine" position synchronism	CPSYNFIP2[FAx]=<value>		
CPSYNCOV	Threshold value of velocity synchronism "Coarse"	CPSYNCOV[FAx]=<value>		
CPSYNFIV	Threshold value of velocity synchronism "Fine"	CPSYNFIV[FAx]=<value>		

Keyword	Coupling characteristics / meaning	Syntax										
CPMBRAKE	Response of the following axis to certain stop signals and stop commands	CPMBRAKE[FAx]=<bit-coded value>										
CPMVDI	Response of the following axis to certain NC/PLC interface signals	CPMVDI[FAx]=<bit-coded value>										
CPMALARM	Suppression of special coupling-related alarm outputs	CPMALARM[FAx]=<bit-coded value>										
CPSETTYPE	Coupling type	CPSETTYPE[FAx]="<coupling type>" "<coupling type>": <table border="1" data-bbox="1007 634 1481 944"> <tbody> <tr> <td>"CP"</td> <td>Freely programmable</td> </tr> <tr> <td>"TRAIL"</td> <td>Coupling type "Coupled motion"</td> </tr> <tr> <td>"LEAD"</td> <td>Coupling type "Master Value Coupling"</td> </tr> <tr> <td>"EG"</td> <td>Coupling type "Electronic gearbox"</td> </tr> <tr> <td>"COUP"</td> <td>Coupling type "Synchronized spindle"</td> </tr> </tbody> </table>	"CP"	Freely programmable	"TRAIL"	Coupling type "Coupled motion"	"LEAD"	Coupling type "Master Value Coupling"	"EG"	Coupling type "Electronic gearbox"	"COUP"	Coupling type "Synchronized spindle"
"CP"	Freely programmable											
"TRAIL"	Coupling type "Coupled motion"											
"LEAD"	Coupling type "Master Value Coupling"											
"EG"	Coupling type "Electronic gearbox"											
"COUP"	Coupling type "Synchronized spindle"											

FAx: Following axis/spindle

LAx: Leading axis/spindle

Note

Coupling characteristics, which are not explicitly programmed (in part program of synchronous actions), become effective with their default settings.

Depending on the settings of the keyword CPSETTYPE instead of the default settings (CPSETTYPE="CP") preset coupling characteristics can become effective.

References

For detailed information on generic couplings, see:

- Function Manual, Special Functions; M3: Axis couplings, Chapter: "Generic coupling"

3.16.7 Tangential control

3.16.7.1 Defining coupling (TANG)

Via the predefined procedure TANG(...), a tangential coupling between a rotary axis is defined as the following axis and two geometry axes as the leading axes. The following axis is continuously aligned with the path tangent of the leading axes.

Note

Coupling factor

A coupling factor of 1 does not have to be programmed explicitly.
 The direction of the tangential axis is rotated using the coupling factor of -1.

Syntax

TANG(<following axis>, <leading axis_1>, <leading axis_2>, <coupling factor>, <coordinate system>, <optimization>)

Meaning

TANG(...):	Define tangential coupling		
<following axis>:	Axis name of the following axis (rotary axis)		
	Data type:	AXIS	
	Range of values:	Channel axis names	
<leading axis_1> <leading axis_2>:	Axis names of the leading axes (geometry axes) ¹⁾		
	Data type:	AXIS	
	Range of values:	Geometry axis names of the channel	
<coupling factor>:	Factor n of the angle change of the following axis for changing the path tangent of the leading axes: Angle change _{following axis} = angle change _{path tangent} * n		
	Data type:	REAL	
	Default value:	1.0	
<coordinate system>:	Active coordinate system ²⁾		
	Data type:	CHAR	
	Value:	"B":	Basic coordinate system (default value)
		"W":	Workpiece coordinate system (not available)

<optimization>:	Optimization type				
	Data type:	CHAR			
	Value:	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; vertical-align: top;">"S":</td> <td> Standard (default value) The dynamic response of the rotary axis has no effect on the leading axes. If the dynamic response of the rotary axis is greater than required for tracking, this method is sufficiently precise. If the dynamic response of the rotary axis is not great enough to follow the change in the path tangent, the orientation of the rotary axis will deviate from the target orientation along an undefined rounding clearance. </td> </tr> <tr> <td style="vertical-align: top;">"P":</td> <td> The dynamic response of the rotary axis is considered in the path planning of the leading axes. For this purpose, on activation of the tangential coupling with TANGON(), two additional parameters must be specified: <ul style="list-style-type: none"> • Rounding clearance • Angular tolerance See Section "Activating the coupling (TANGON) (Page 896)" Note With kinematic transformations, we recommend using optimization method "P." </td> </tr> </table>	"S":	Standard (default value) The dynamic response of the rotary axis has no effect on the leading axes. If the dynamic response of the rotary axis is greater than required for tracking, this method is sufficiently precise. If the dynamic response of the rotary axis is not great enough to follow the change in the path tangent, the orientation of the rotary axis will deviate from the target orientation along an undefined rounding clearance.	"P":
"S":	Standard (default value) The dynamic response of the rotary axis has no effect on the leading axes. If the dynamic response of the rotary axis is greater than required for tracking, this method is sufficiently precise. If the dynamic response of the rotary axis is not great enough to follow the change in the path tangent, the orientation of the rotary axis will deviate from the target orientation along an undefined rounding clearance.				
"P":	The dynamic response of the rotary axis is considered in the path planning of the leading axes. For this purpose, on activation of the tangential coupling with TANGON(), two additional parameters must be specified: <ul style="list-style-type: none"> • Rounding clearance • Angular tolerance See Section "Activating the coupling (TANGON) (Page 896)" Note With kinematic transformations, we recommend using optimization method "P."				

Note
Default values do not have to be programmed explicitly.

¹⁾ **Note**
As the leading axes for tangential coupling, the geometry axes must be used that travel along the programmed path in the machine coordinate system (MCS) with reference to the initial position of the machine. For example, if swivel cycle CYCLE800 is used on a milling machine with a swivel head, depending on how the cycle is configured, interpolation will be performed in the WCS, e.g. with the geometry axes X and Y. The tangential coupling, however, must be defined with the geometry axes as the leading axes, which travel along the programmed path in the MCS. For this purpose, the geometry axes in the **non-swiveled** condition of the machine must be used as the leading axes.

²⁾ **Note**
The basic coordinate system (BCS) must not be rotated with respect to the MCS. For example, if the BCS is rotated with the ROT command or with the swivel cycle CYCLE800, the tangential control is no longer correct.

3.16.7.2 Activating intermediate block generation (TLIFT)

If the tangent change of the following axis at any position along the programmed path of the leading axes exceeds the limit parameterized in machine data MD37400 \$MA_EPS_TLIFT_TANG_STEP, further path planning will depend on the set behavior at corners. Without use of the predefined procedure TLIFT(...), the path is traversed in accordance with the rounding behavior programmed in connection with TANG(...) (Page 893) and TANGON(...) (Page 896).

Activating intermediate block generation

If TLIFT(...) is programmed after TANG(...), an intermediate block automatically generated by the control is inserted at this point when a corner is detected during preprocessing.

When the program is executed, the leading axes are stopped when the intermediate block is reached. In the intermediate block, the following axis is rotated with maximum axis dynamics toward the path tangent of the following block. The leading axes are then traversed further on the programmed path.

Deactivating intermediate block generation

To deactivate intermediate block generation, the tangential coupling must be defined again using TANG(...), but without subsequent activation of intermediate block generation by means of TLIFT(...).

Syntax

TLIFT(<following axis>)

Meaning

TLIFT(...):	Activate corner detection with intermediate block calculation	
<following axis>:	Axis name of the following axis (rotary axis)	
	Data type:	AXIS
	Range of values:	Channel axis names

Speed of rotation of the following axis

Path axis

If the following axis had already been traversed as a path axis before tangential coupling was activated, the rotational movement is performed in the intermediate block as a path axis.

If you specify the reference radius with FGRF[<axis>]=0.001, the rotational movement will be performed with the parameterized maximum axis velocity:

MD32000 \$MA_MAX_AX_VELO[<following axis>]

Positioning axis

If the following axis had not yet been traversed as a path axis before tangential coupling was activated, the rotation is performed in the intermediate block as a positioning axis.

The rotational movement is performed with the parameterized positioning axis velocity:

MD32060 \$MA_POS_AX_VELO[<following axis>]

3.16.7.3 Activating the coupling (TANGON)

Via the predefined procedure TANGON(...), a tangential coupling previously defined with TANG(...) (Page 893) is activated. The following axis is then continuously aligned with the path tangent during subsequent travel.

Angle of the following axis

The angle of the following axis with respect to the path tangent depends on the transformation ratio specified in TANG(...), the offset angle parameterized in the machine data MD37402 \$MA_TANG_OFFSET, and the offset angle specified for TANGON(...), which is applied additively.

Optimization "P"

If the value "P" was specified as the optimization parameter in the definition of the tangential coupling (TANG(...)), the parameter "rounding clearance" and optionally the parameter "angular tolerance" must be set when coupling is activated.

If the value 0 is specified as the angular tolerance, only the parameter "rounding clearance" will be active.

If a value greater than 0 is specified as the angular tolerance, the active rounding clearance results from the minimum of the parameterized rounding clearance and the rounding clearance based on the parameterized angular tolerance.

If the dynamic response of the following axis is not sufficient to follow the parameterized conditions, the path velocity of the leading axes will be reduced accordingly.

Syntax

```
TANGON(<following axis>, <offset angle>, <rounding clearance>,
<angular tolerance>)
```

Meaning

TANGON(...):	Activate tangential coupling	
<following axis>:	Axis name of the following axis (rotary axis)	
	Data type:	AXIS
	Range of values:	Channel axis names
<offset angle>:	Offset angle of following axis with respect to the path tangent The reference point is the zero point of the rotary axis.	
	Data type:	REAL
<rounding clearance>:	Maximum permissible rounding clearance If the rounding clearance is increased due to the dynamic conditions, the path velocity of the leading axes is reduced.	
	Data type:	REAL
<angular tolerance>:	Maximum permissible tolerance with respect to the specified angle between the following axis zero setting and the path tangent	
	Data type:	REAL

3.16.7.4 Deactivating the coupling (TANGOF)

Via the predefined procedure TANGOF(...), a tangential coupling defined with TANG(...) (Page 893) and activated with TANGON(...) (Page 896) is deactivated. The following axis is then no longer aligned with the path tangent of the leading axis. However, the coupling of the following axis to the leading axes is retained even after deactivation, which prevents the following functions, for example:

- Plane change
- Geometry axis switchover
- Definition of a new tangential coupling for the following axis

Final cancellation of the connection of the coupling of the following axis to the leading axes is not completed until the coupling has been deleted with TANGDEL(...) (Page 898).

Programming

TANGOF(<following axis>)

Meaning

TANGOF(...):	Deactivate a tangential coupling	
<following axis>:	Axis name of the following axis (rotary axis)	
	Data type:	AXIS
	Range of values:	Channel axis names

3.16.7.5 Deleting a coupling (TANGDEL)

A tangential coupling defined with TANG(...) (Page 893) will be retained even after deactivation of the tangential coupling with TANGOF(...) (Page 898). The existing tangential coupling then continues to prevent, for example, the following functions:

- Plane change
- Geometry axis switchover
- Definition of a new tangential coupling for the following axis

With the predefined procedure TANGDEL(...), the existing tangential coupling is deleted after the tangential coupling has been deactivated with TANGOF(...).

Syntax

TANGDEL(<following axis>)

Meaning

TANGDEL(...):	Delete a tangential coupling defined with TANG()	
	Effective:	Non-modal

<following axis>:	Axis name of the following axis whose tangential coupling is to be deleted	
	Data type:	AXIS
	Range of values:	Channel axis names

Examples

Leading axis change

Before a new tangential coupling can be defined with another leading axis for the following axis, the existing tangential coupling must first be deleted.

Program code	Comment
N10 TANG (A, X, Y, 1)	; Define tangential coupling for following axis A: A to X and Y
N20 TANGON(A)	; Activate tangential coupling for following axis A
N30 X10 Y20	
...	
N80 TANGOF(A)	; Deactivate tangential coupling for following axis A
N90 TANGDEL (A)	; Delete tangential coupling for following axis A
...	
N120 TANG (A, X, Z)	; Define new tangential coupling for following axis A
N130 TANGON(A)	; Activate new tangential coupling for following axis A
...	

Geometry axis switchover

Before geometry axis switchover can be performed for an existing coupling, the coupling must first be deleted.

Program code	Comment
N10 GEOAX(2, Y1)	; 2nd geometry axis = machine axis Y1
N20 TANG(A, X, Y)	; Define tangential coupling for following axis A
N30 TANGON(A, 90)	; Activate tangential coupling for following axis A
N40 G2 F8000 X0 Y0 I0 J50	; Motion block
N50 TANGOF(A)	; Deactivate tangential coupling for following axis A
N60 TANGDEL (A)	; Delete tangential coupling for following axis A
N70 GEOAX (2, Y2)	; 2nd geometry axis = machine axis Y2
N80 TANG(A, X, Y)	; Define new tangential coupling for following axis A
N90 TANGON(A, 90)	; Activate new tangential coupling for following axis A
...	

3.16.8 Master/slave coupling (MASLDEF, MASLDEL, MASLON, MASLOF, MASLOFS)

The "master/slave coupling" enables:

- The coupling of the slave axes to the master axis, when the axes involved are at standstill.
- The coupling/decoupling of **rotating**, speed-controlled spindles.
- The dynamic configuration.

Note

Positioning mode

For axes and spindles in the positioning mode, the coupling is only closed and opened at standstill.

Syntax

```
MASLON(<slave_1>,<slave_2>,...)
MASLOF(<slave_1>,<slave_2>,...)
MASLOFS(<slave_1>,<slave_2>,...)
```

Dynamic configuration:

```
MASLDEF(<slave_1>,<slave_2>, ... ,<master>)
MASLDEL(<slave_1>,<slave_2>,...)
```

Meaning

MASLON:	Activating a temporary master/slave coupling	
	<Slave_x>, ...:	Slave axis 1 ... n
MASLOF:	Decoupling an active master/slave coupling	
	<slave_1>, ...:	Slave axis 1 ... n
MASLOFS:	Decoupling a master/slave coupling and automatically braking slave spindles (see note "Coupling behavior for spindles! in speed control mode!")	
	<slave_1>, ...:	Slave axis 1 ... n
MASLDEF:	Creating/changing a master/slave group from the part program	
	<slave_1>, ...:	Slave axis 1 ... n
	<master>:	Master axis
MASLDEL:	Separate master/slave coupling and delete the definition of the grouping	
	<slave_1>, ...:	Slave axis 1 ... n
	Note: The master/slave definitions configured in the machine data are retained.	

Note

Coupling behavior for spindles in speed control mode

For spindles in the speed control mode, the coupling behavior of `MASLON`, `MASLOF`, `MASLOFS` and `MASLDEL` are specified explicitly via the following machine data:

`MD37263 $MA_MS_SPIND_COUPLING_MODE`

For the default setting with `MD37263 = 0`, the slave axes are coupled-in and coupled-out only when the axes involved are at standstill. `MASLOFS` corresponds to `MASLOF`.

For `MD37263 = 1`, the coupling instruction is immediately executed and therefore also the motion. For `MASLON` the coupling is immediately closed and for `MASLOFS` or `MASLOF` immediately opened. With `MASLOF`, the slave spindles rotating at this instant keep their speeds until a new speed is programmed. However, with `MASLOFS`, they are braked automatically.

Note

For `MASLOF/MASLOFS`, the implicit preprocessing stop is not required. Because of the missing preprocessing stop, the \$P system variables for the slave axes do not provide updated values until next programming.

Note

For the slave axis, the actual value can be synchronized to the same value of the master axis using `PRESETON`. To do this, the permanent/slave coupling must be briefly switched off in order to set the actual value of the non-referenced slave axis to the value of the master/axis with `POWER ON`. Then the coupling is permanently re-established.

The permanent master/slave coupling is activated with the following MD setting:

`MD37262 $MA_MS_COUPLING_ALWAYS_ACTIVE = 1`

It has no effect on the language commands of the temporary coupling.

Example

For a permanent master/slave coupling, `PRESETON` sets the actual value of the slave axis to the value of the master axis.

Program code	Comment
<code>\$MA_MS_COUPLING_ALWAYS_ACTIVE[AX2]=0</code>	; Deactivate the permanent coupling of the slave axis
<code>NEWCONF</code>	; Activate machine data change
<code>STOPRE</code>	
<code>MASLOF (Y1)</code>	; Deactivate temporary coupling
<code>PRESETON (AX2, \$VA_IM(M_AX))</code>	; Actual value of the slave axis = actual value of the master axis
<code>\$MA_MS_COUPLING_ALWAYS_ACTIVE[AX2]=1</code>	; Activate the permanent coupling of the slave axis
<code>NEWCONF</code>	; Activate machine data change

3.17 Synchronized actions

3.17.1 Brief description

General

A synchronized action consists of a series of related statements within a part program that is called cyclically in the interpolator clock cycle synchronously to the machining blocks.

A synchronized action is essentially divided into two parts, the optional condition and the obligatory action part. The time at which the actions are executed can be made dependent on a specific system state using the condition part. The conditions are evaluated cyclically in the interpolator clock cycle. The actions are then a reaction to user-definable system states. Their execution is not bound to block limits.

Furthermore, the validity of the synchronized action (non-modal, modal or static) and the frequency of the execution of the actions (once, repeatedly) can be defined.


Examples of permissible actions

- Output of auxiliary functions to PLC
- Writing and reading of main run variables
- Traversing of positioning axes
- Activation of synchronous procedures, such as:
 - Read-in disable
 - Delete distance-to-go
 - End preprocessing stop
- Activation of technology cycles
- Calculation of function values
- Tool offsets
- Activating/deactivating couplings
- Measuring
- Enabling/disabling of synchronized actions

Examples of non-permissible actions

- Traversing of path axes

Schematic diagram of synchronized actions



3.17.2 Definition of a synchronized action

A synchronized action is defined in a block of a part program. Any further commands that are not part of the synchronized action, must not be programmed within this block.

Components of a synchronized action

A synchronized action consists of the following components:

Validity, ID no. (Page 905) (optional)	Condition part (optional)			Action part with condition fulfilled			Action part with condition unfulfilled (optional)		
	Frequency (Page 906)	G command (Page 907) (optional)	Condition (Page 908)	Keyword	G command (Page 907) (optional)	Actions (Page 909)	Keyword	G command (Page 907) (optional)	Actions (Page 909)
--- ¹⁾ ID=<no.> IDS=<no.> >	--- ¹⁾ WHENEVER FROM WHEN EVERY	G...	Logical Expressio n	DO	G...	Action 1 ... Action n	ELSE	G...	Action 1 ... Action n

¹⁾ Not programmed

Syntax

Examples:

- DO <Action 1...n>
- <frequency> [<G function>] <condition> DO <action 1...n>
- ID=<no.> <frequency> [<G function>] <condition> DO <action 1...n>
- IDS=<no.> <frequency> [<G function>] <condition> DO <action 1...n>
- IDS=<no.> <frequency> [<G function>] <condition> DO <action 1...n>
ELSE <action 1...n>

3.17.3 Components of synchronized actions

3.17.3.1 Validity, identification number (ID, IDS)

Validity

The validity defines when and where the synchronized action will be processed:

Validity	Meaning
--- 1)	<p>Non-modal synchronized action</p> <p>A non-modal synchronized action applies:</p> <ul style="list-style-type: none"> As long as the main run block following the synchronized action is active Only in the AUTOMATIC mode <p>Example:</p> <p>The synchronized action from N10 takes effect as long as N20 is active.</p> <pre>N10 WHEN \$A_IN[1]==TRUE DO \$A_OUTA[1]=10 N20 G90 F1000 X100</pre>
ID=<ID number>	<p>Modal synchronized action</p> <p>A modal synchronized action applies:</p> <ul style="list-style-type: none"> Until the part program has been completed Only in the AUTOMATIC mode <p>Range of values: See the paragraph below "Identification number" > "Value range"</p> <p>Example:</p> <pre>N20 ID=1 EVERY \$A_IN[1]==TRUE DO \$A_OUTA[1]=10</pre>
IDS=<ID number>	<p>Static synchronized action</p> <p>A static synchronized action applies:</p> <ul style="list-style-type: none"> In all operating modes for an unlimited period of time <p>Range of values: See the paragraph below "Identification number" > "Value range"</p> <p>Example:</p> <pre>N30 IDS=1 EVERY \$A_IN[1]==TRUE DO \$A_OUTA[1]=10</pre>

1) Not programmed

Note

Static synchronized actions

Static synchronized actions (IDS) can be defined in an ASUB and activated at any time by activation of the ASUB via the PLC user program.

Identification number ID/IDS

Range of values

The identification numbers ID/IDS are in various number ranges. The number ranges are assigned to different users.

ID/IDS	User	Directory
1 ... 999	"General area"	Any directory
	"Safety Integrated" function	/_N_CST_DIR/_N_SAFE_SPF
1000 ... 1199	Machine manufacturer	/_N_CMA_DIR
1200 ... 1399	Siemens	/_N_CST_DIR

Parallelization

If several synchronized actions are to be active in parallel in a channel, their identification numbers ID/IDS must be different. Synchronized actions with the same identification number replace each other within a channel.

Sequence of execution

Modal and static synchronized actions are executed in the order of their identification numbers ID/IDS.

Non-modal synchronized actions are executed after execution of the modal synchronized actions in the order of their programming.

Coordination via part programs and synchronized actions

Synchronized actions can be coordinated via part programs and synchronized actions based on the identification numbers ID/IDS (see Section "Coordination via part program and synchronized action (LOCK, UNLOCK, CANCEL) (Page 1011)").

Coordination via PLC

Synchronized actions with identification numbers ID/IDS in the range from 1 to 64 can be coordinated via the NC/PLC interface from the PLC user program (see Section "Coordination via PLC (Page 1011)").

3.17.3.2 Frequency (WHENEVER, FROM, WHEN, EVERY)

The frequency specifies how often the condition is queried and, when the condition is fulfilled, how often the action should be executed. The frequency is part of the condition.

Frequency	Meaning
--- ¹⁾	If no frequency is specified, the action is executed cyclically in every interpolator clock cycle.
WHENEVER	If the condition is fulfilled, the action is executed cyclically in every interpolator clock cycle.
FROM	After the condition has been fulfilled once, the action is executed cyclically in every interpolator clock cycle for as long as the synchronized action is active.

Frequency	Meaning
WHEN	If the condition is fulfilled, the action is executed once and then the condition is no longer checked.
EVERY	In the following cases, the action is executed once: <ul style="list-style-type: none"> • The condition is already satisfied at the start of the synchronized action (state: TRUE) • At every state transition of the condition from FALSE to TRUE (rising edge)

¹⁾ Not programmed

See also

Technology cycles (Page 1006)

3.17.3.3 G command (condition)

Defined initial state

With regard to the part program sequence, synchronized actions can be executed at any time depending on fulfillment of the condition. It is therefore recommended that the measuring system (inch or metric) be defined in a synchronized action **before** the condition and/or in the action part. This generates a defined initial position for the evaluation of the condition and the execution of the action, irrespective of the current part program state.

G commands

The following G commands are permissible:

- G70 (Inch dimensions for geometric specifications (lengths))
- G71 (Metric dimensions for geometric specifications (lengths))
- G700 (Inch dimensions for geometric and technological specifications (lengths, feedrate))
- G710 (Metric dimensions for geometric and technological specifications (lengths, feedrate))

Note

No other G commands are permitted in synchronized actions except G70, G71, G700 and G710.

Validity

A G command programmed in the condition part also applies for the action part even if no G command has been programmed in the action part itself.

A G command programmed in the action part only applies within the action part.

3.17.3.4 Condition

Execution of the action can be made dependent on the fulfillment of a condition. As long as the synchronized action is active, the condition is checked cyclically in the interpolator clock cycle. If no condition is specified, the action is executed cyclically in every interpolator clock cycle.

All operations that return a truth value (TRUE/FALSE) as the result can be programmed as a condition:

- Comparisons of system variables with constants
- Comparisons of system variables with system variables
- Comparisons of system variables with results of arithmetic operations
- Linking of comparisons through Boolean expressions

Examples

Comparisons

Program code

```
ID=1 WHENEVER $AA_IM[X] > $$AA_IM[Y] DO ...
ID=2 WHENEVER $AA_IM[X] > (10.5 * SIN(45)) DO ...
```

Boolean operations

Program code

```
ID=1 WHENEVER ($A_IN[1]==1) OR ($A_IN[3]==0) DO ...
```

See also

System variables for synchronized actions (Page 910)

3.17.3.5 G command (action)

Defined initial state

With regard to the part program sequence, synchronized actions can be executed at any time depending on fulfillment of the condition. Therefore, it is advisable to define the required measuring system (inch or metric) in the action part in a synchronized action. This generates a defined initial position for the execution of the action, irrespective of the current part program state.

G commands

The following G commands are permissible:

- G70 (Inch dimensions for geometric specifications (lengths))
- G71 (Metric dimensions for geometric specifications (lengths))

- G700 (Inch dimensions for geometric and technological specifications (lengths, feedrate))
- G710 (Metric dimensions for geometric and technological specifications (lengths, feedrate))

Validity

A G command programmed in the condition part also applies for the action part even if no G command has been programmed in the action part itself.

A G command programmed in the action part only applies within the action part.

3.17.3.6 Actions with condition fulfilled (DO)

The action part of a synchronized action is initiated with the keyword `DO`.

One or more actions can be programmed in the action part. These are executed when the appropriate condition is fulfilled. If several actions are programmed in one synchronized action, they are all executed in the same interpolator clock cycle.

Example:

If the actual value of the Y axis is greater than or equal to 35.7, the auxiliary function M135 is output on the PLC and, at the same time, digital output 1 = 1 is set.

Program code

```
WHEN $AA_IM[Y] >= 35.7 DO M135 $A_OUT[1]=1
```

Technology cycle

A technology cycle can be called as an action (see Section "Technology cycles (Page 1006)").

3.17.3.7 Actions with condition unfulfilled (ELSE)

With the keyword `ELSE`, every synchronized action can be expanded by actions which are to be executed if the condition is not fulfilled. This allows the combination of synchronized actions which have contrary conditions.

Example:

```
ID=101 WHENEVER $VA_IM[x] < 100 DO $AC_OVR=100
```

```
ID=102 WHENEVER $VA_IM[x] >= 100 DO $AC_OVR=50
```

The two synchronized actions can be brought together by programming `ELSE`:

```
ID=101 WHENEVER $VA_IM[x] < 100 DO $AC_OVR=100 ELSE $AC_OVR=50
```

Additional properties

- In the ELSE branch, the same conditions apply as for the actions with the condition fulfilled (Page 909)
- ELSE is always possible with every condition. The practical use is the responsibility of the user.

Example:

```
WHEN $AA_IW[X] > 100 DO $R1=1 ELSE $R1=2  
GO X100 F10
```

Here, the expression \$R1=2 is executed in each interpolation cycle and the R parameter is written, even if this is not essential. This must be taken into account by the user.

- The language command ELSE can be used together with all frequency variants.

Examples:

- The ELSE branch is always executed when the condition is not fulfilled:

```
WHENEVER $AA_IW[X] > 100 DO $R1=1 ELSE $R1=2  
EVERY $AA_IW[X] > 100 DO $R1=1 ELSE $R1=2
```

- As long as the condition is not fulfilled, the ELSE branch is executed, then always the action:

```
FROM $AA_IW[X] > 100 DO $R1=1 ELSE $R1=2
```

- As long as the condition is not fulfilled, the ELSE branch is executed, then the action and the synchronized action are ended:

```
WHEN $AA_IW[X] > 100 DO $R1=1 ELSE $R1=2
```

3.17.4 System variables for synchronized actions

The system variables of the NC are listed in the "System Variables" Parameter Manual with their respective properties. System variables that can be read or written in synchronized actions, are marked with an "X" in the corresponding line (Read or Write) of the "SA" (synchronized action) column.

Note

System variables used in synchronized actions are implicitly read and written synchronous to the main run.

References

A comprehensive description of the system variables listed in this function manual can be found in:

- System Variables Parameter Manual

3.17.4.1 Reading and writing

The reading and writing of variables is performed in the main run in synchronized actions with a few exceptions. Exceptions are:

- User-defined variables: LUD, GUD
- Machine data: \$M...
- Setting data: \$S...
- R parameters: R<number> or R[<index>]

These variables are already read and written during the preprocessing.

System variables

Generally, all system variables that can be used in synchronized actions are read/written in the main run. These system variables are marked with an "X" in the "Read" and/or "Write" line of the "SA" (synchronized action) column in the "System Variables" Parameter Manual.

References:

System Variables Parameter Manual

System of the identifiers

The identifiers of the system variables that are read/written in the main run have the following system:

\$A...	Current main run data
\$V...	Servo data
\$R...	R parameters to be read/written in the main run
\$\$M...	Machine data to be read/written in the main run
\$\$S...	Setting data to be read/written in the main run

3.17.4.2 Operators and arithmetic functions

Operators

Arithmetic operators

System variables of the REAL and INT type can be linked by the following operators:

Operator	Meaning
+	Addition
-	Subtraction
*	Multiplication
/	<ul style="list-style-type: none"> • Division in synchronized actions: INT / INT ⇒ INT • Division in synchronized actions with REAL result by using the function ITOR(): ITOR(INT) / ITOR(INT) ⇒ REAL • Division in NC programs: INT / INT ⇒ REAL

3.17 Synchronized actions

Operator	Meaning
DIV	Integer division: INT / INT ⇒ INT
MOD	Modulo division (only for type INT) supplies remainder of an INT division Example: 3 MOD 4 = 3

Note

Only variables of the same type may be linked by these operations.

Relational operators

Operator	Meaning
==	Equal to
<>	Not equal to
<	Less than
>	Greater than
<=	Less than or equal to
>=	Greater than or equal to

Boolean operators

Operator	Meaning
NOT	NOT
AND	AND
OR	OR
XOR	Exclusive OR

Bit logic operators

Operator	Meaning
B_OR	Bit-by-bit OR
B_AND	Bit-by-bit AND
B_XOR	Bit-by-bit exclusive OR
B_NOT	Bit-by-bit negation

Priority of the operators

The operators have the following priorities for execution in the synchronized action (highest priority: 1):

Pri-ty	Operators	Meaning
1	NOT, B_NOT	Negation, bit-by-bit negation
2	*, /, DIV, MOD	Multiplication, division
3	+, -	Addition, subtraction
4	B_AND	Bit-by-bit AND

Pri- ty	Operators	Meaning
5	B_XOR	Bit-by-bit exclusive OR
6	B_OR	Bit-by-bit OR
7	AND	AND
8	XOR	Exclusive OR
9	OR	OR
10	<<	Concatenation of strings, result type STRING
11	==, <>, <, >, >=, <=	Relational operators

Note

It is strongly recommended that the individual operators are clearly prioritized by setting parentheses "(...)" when several operators are used in an expression.

Example of a condition with an expression with several operators:

Program code

```
... WHEN ($AA_IM[X] > VALUE) AND ($AA_IM[Y] > VALUE1) DO ...
```

Arithmetic functions

Operator	Meaning
SIN()	Sine
COS()	Cosine
TAN()	Tangent
ASIN()	Arc sine
ACOS()	Arc cosine
ATAN2()	Arc tangent 2
SQRT()	Square root
ABS()	Absolute value
POT()	2nd power (square)
TRUNC()	Integer component The accuracy for comparison commands can be set using TRUNC
ROUND()	Round to an integer
LN()	Natural logarithm
EXP()	Exponential function

A detailed description of the functions can be found in:

References

Programming Manual, Job Planning; Section "Flexible NC programming" ff.

Indexing

The index of a system variable of type "Array of ..." can in turn be a system variable. The index is also evaluated in the main run in the interpolator clock cycle.

3.17 Synchronized actions

Example

Program code

```
... WHEN ... DO $AC_PARAM[$AC_MARKER[1]]=3
```

Restrictions

- It is not permissible to nest indices with further system variables.
- The index must not be formed via preprocessing variables. The following example is therefore **not** permitted since \$P_EP is a preprocessing variable:
\$AC_PARAM[1] = \$P_EP[\$AC_MARKER[0]]

3.17.4.3 Type conversions

An implicit type conversion is performed between the following data types for value assignments and parameter transfers with different data types:

- REAL
- INT
- BOOL

Note**Conversion REAL to INT**

For the conversion from REAL to INT, a decimal place value ≥ 0.5 rounded up to the next higher integer. For a decimal place value < 0.5 , rounding is to the next lower integer. Behavior in accordance with the ROUND function.

If the REAL value is outside the INT value range, an alarm is displayed and a conversion is not performed.

Conversion from REAL or INT to BOOL

- Value $\neq 0 \rightarrow$ TRUE
 - Value $= 0 \rightarrow$ FALSE
-

Examples

Conversion: **INT \$AC_MARKER** \rightarrow **REAL \$AC_PARAM**

Program code

```
$AC_MARKER[1]=561
ID=1 WHEN TRUE DO $AC_PARAM[1] = $AC_MARKER[1]
```

Conversion: **REAL \$AC_PARAM** \rightarrow **INT \$AC_MARKER**

Program code

```
$AC_PARAM[1]=561.0
ID=1 WHEN TRUE DO $AC_MARKER[1] = $AC_PARAM[1]
```

Conversion: **INT** \$AC_MARKER → **BOOL** \$A_OUT

```

Program code
$AC_MARKER[1]=561
ID=1 WHEN $A_IN[1] == TRUE DO $A_OUT[0]=$AC_MARKER[1]
    
```

Conversion: **REAL** \$R401 → **BOOL** \$A_OUT

```

Program code
R401 = 100.542
WHEN $A_IN[0] == TRUE DO $A_OUT[2]=$R401
    
```

Conversion: **BOOL** \$A_OUT → **INT** \$AC_MARKER

```

Program code
ID=1 WHEN $A_IN[2] == TRUE DO $AC_MARKER[4] = $A_OUT[1]
    
```

Conversion: **BOOL** \$A_OUT → **REAL** \$R10

```

Program code
WHEN $A_IN[3] == TRUE DO $R10 = $A_OUT[3]
    
```

3.17.4.4 Marker/counter (\$AC_MARKER)

The \$AC_MARKER[<index>] variables are channel-specific arrays of system variables for use as markers or counters.

Data type: INT (integer)
 <Index>: Array index: 0, 1, 2, ... (max. number – 1)

Number per channel

The maximum number of \$AC_MARKER variables per channel can be set via the machine data:

MD28256 \$MC_MM_NUM_AC_MARKER = <maximum number>

Storage location

The storage location of the \$AC_MARKER variables can be defined channel-specifically via the machine data:

MD28257 \$MC_MM_BUFFERED_AC_MARKER = <value>

Value	Storage location
0	Dynamic memory (default setting)
1	Static memory

Note

Data backup and memory space

- The \$AC_MARKER variables created in the static memory can be saved channel-specifically via the data backup. Data block: _N_CH<channel number>_ACM
 - Please ensure that sufficient memory is available in the selected memory area. An array element requires 4 bytes of memory space.
-

Reset behavior

The reset behavior depends on the storage location of the \$AC_MARKER variables:

- Dynamic memory: Initialization with the value "0"

Static memory: Retention of the current value

3.17.4.5 Parameters (\$AC_PARAM)

The \$AC_PARAM[<index>] variables are channel-specific arrays of system variables for use as general buffers.

Data type: REAL

<Index>: Array index: 0, 1, 2, ... (max. number - 1)

Number per channel

The maximum number of \$AC_PARAM variables per channel can be set via the machine data:

MD28254 \$MC_MM_NUM_AC_PARAM = <maximum number>

Storage location

The storage location of the \$AC_PARAM variables can be defined channel-specifically via the machine data:

MD28255 \$MC_MM_BUFFERED_AC_PARAM = <value>

Value	Storage location
0	Dynamic memory (default setting)
1	Static memory

Note**Data backup and memory space**

- The \$AC_PARAM variables created in the static memory can be saved channel-specifically via the data backup. Data block: _N_CH<channel number>_ACP
 - Please ensure that sufficient memory is available in the selected memory area. An array element requires 4 bytes of memory space.
-

Reset behavior

The reset behavior depends on the storage location of the \$AC_PARAM variables:

- Dynamic memory: Initialization with the value "0"
- Static memory: Retention of the current value

3.17.4.6 R parameters (\$R)

Whether R parameters are treated as preprocessing or main run variables depends on whether they are written with or without \$ characters. In principle, the notation is freely selectable. For use in synchronized actions, R parameters should be used as main run variables, i.e. with \$ characters:

- \$R[<index>]
- \$R<number>

Data type: REAL

<Index>: Array index: 0, 1, 2, ...

<Number>: Number of the R parameter: 0, 1, 2, ...

The notations with index or number are equivalent.

Parameterizable number per channel

The maximum number of R parameters per channel can be set via the machine data:

MD28050 \$MC_MM_NUM_R_PARAM = <maximum number>

Reset behavior

R parameters are saved persistently in the static memory of the NC. Therefore, R parameters retain their values with all reset types:

- Power on reset
- NC reset
- End of part program reset

Example

Value assignment to R10 in the action part of the synchronized action and subsequent evaluation in the part program

```
WHEN $A_IN[1]==1 DO $R[10]=$AA_IM[Y] ; assignment
G1 X100 F150
STOPRE
IF R[10] > 50 ... ; evaluation in the part program
```

3.17.4.7 Machine and setting data (\$M, \$\$S)**Reading and writing MD and SD**

When machine and setting data is used in synchronized actions, a distinction must be made as to whether this remains unchanged during the execution of the synchronized action, or is changed through parallel processes.

Data that remains **unchanged** can already be read or written by the NC during **preprocessing**.

Data that is **changed** can only be read or written by the NC during the **main run**.

Data access during preprocessing

Machine and setting data that can already be read and written in synchronized actions during preprocessing, is programmed with the same identifiers as in the part program: \$M ... or \$S ...

Program code

```
; The reversal position of the Z axis $SA_OSCILL_REVERSE_POS2[Z]
; remains unchanged over the entire machining period
ID=2 WHENEVER $AA_IM[z]<$SA_OSCILL_REVERSE_POS2[Z]-6 DO $AA_OVR[X]=0
```

Data access during the main run

An additional "\$" is added as prefix for machine and setting data that may only be read or written in synchronized actions during the main run: \$\$M... or \$\$S...

Program code

```
; The reversal position of the Z axis $SA_OSCILL_REVERSE_POS2[Z]
; can be changed by operator input at any time
ID=1 WHENEVER $AA_IM[z] < $$SA_OSCILL_REVERSE_POS2[Z] DO $AA_OVR[X] = 0
```

Writing during the main run

The following requirements must be satisfied for writing during the main run:

- The access authorization at the time of writing must be sufficient for writing.
- The machine or setting data must have the property "Effective immediately".

Program code

```

; The switching position of the SW cam $SN_SW_CAM_ ... must,
; depending on the current setpoint of the X axis in WCS $AA_IW[X],
; only be written during the main run
ID=2 WHEN $AA_IW[X] > 10 DO $$SN_SW_CAM_PLUS_POS_TAB_1[0] = 20
                                $$SN_SW_CAM_MINUS_POS_TAB_1[0]=20

```

A complete overview of the properties of the machine and setting data can be found in:

References

- Parameter Manual: Lists (Book 1)
- Parameter Manual: Detailed Machine Data Description

3.17.4.8 Timer (\$AC_TIMER)

The \$AC_TIMER[<index>] variables are channel-specific arrays of system variables.

Data type:	REAL
<Index>:	Array index: 0, 1, 2, ... (max. number - 1)
Unit:	Seconds

Number per channel

The maximum number of \$AC_TIMER variables per channel can be set via the machine data:

MD28258 \$MC_MM_NUM_AC_TIMER = <maximum number>

Function**Starting**

A timer is started by assigning a value ≥ 0 :

\$AC_TIMER[<index>] = <starting value>; with starting value ≥ 0

Incrementing

The value of the timer is incremented by the duration of the set interpolator clock cycle (MD10071 IPO_CYCLE_TIME) for each interpolator clock cycle.

\$AC_TIMER[<index>] += <interpolator clock cycle>

Stopping

A timer is stopped by assigning a value < 0 :

\$AC_TIMER[<index>] = <stopping value>; with stopping value < 0

3.17 Synchronized actions

When a stopping value is assigned, only the further incrementing of the timer is stopped. The stopping value is not assigned. After the timer is stopped, the last valid value is retained and can still be read.

Note

The current value of a timer can be read when the timer is running or stopped.


Example

Output the actual value of the X axis as voltage value via analog output \$A_OUTA[3], 500 ms after the detection of digital input \$A_IN[1]:

Program code	Comment
WHEN \$A_IN[1] == 1 DO \$AC_TIMER[1]=0	; Start timer, starting value 0
WHEN \$AC_TIMER[1]>=0.5 DO \$A_OUTA[3]=\$AA_IM[X] \$AC_TIMER[1]=-1	

3.17.4.9 FIFO variables (\$AC_FIFO)

A FIFO variable provides a complex data structure based on R parameters. The data structure comprises one administration part and one user data part. The user data part is structured as a stack according to the FIFO principle (first in, first out). Using the index of the FIFO variables, the different functions are addressed in the administration part as well as the user data.



- ① Administration part
- ② User data part
- ③ R parameter range above the FIFO variables: Read and write permitted
- ④ R parameter range below the FIFO variables: Only read permitted

Note

The statements regarding R parameters also apply to FIFO variables. See Chapter "R parameters (\$R) (Page 917)".

Syntax

Write

```
$AC_FIFO<n>[<i>] = <value>
$AC_FIFO[<n>, <i>] = <value>
```

Read

```
<variable> = $AC_FIFO<n>[<i>]
<variable> = $AC_FIFO[<n>, <i>]
```

Meaning

\$AC_FIFO:	FIFO data structure in the R parameters, starting from value in MD28262 \$MC_START_AC_FIFO	
	Data type:	REAL
<n>:	Number of FIFO variables	
	Data type:	INT
	Value range:	1, 2, ... max. number (see references below)

3.17 Synchronized actions

<code><i></code> :	Index of the FIFO variables with which the various functions and data within the data structure of the FIFO variables is accessed.	
	Value range:	0, 1, 2, ... (MD28264 \$MC_LEN_AC_FIFO - 1)
	Value	Meaning
	Administrative data	
	0	<p>Write</p> <p>A value is written to the FIFO stack by assigning a value to the FIFO stack via index 0 (<code>\$AC_FIFO[0] = <value></code>). The assigned value is written to the next free location in the FIFO stack.</p> <p>If all memory locations in the FIFO stack are already occupied, an alarm is displayed:</p> <ul style="list-style-type: none"> • When writing in an NC program: Alarm 20149 • When writing in a synchronized action: Alarm 17020 <p>Read</p> <p>A value is read from the FIFO stack by assigning the FIFO stack to a variable with index 0 (<code><variable> = \$AC_FIFO[0]</code>). The oldest value is read and then removed from the FIFO stack.</p> <p>Note</p> <ul style="list-style-type: none"> • Reading in the NC program / synchronized action If a value is read in an NC program / synchronized action with index 0, the oldest value is read and removed from the FIFO stack as described above. • Reading on the user interface, e.g. SINUMERIK Operate If a value is read or displayed with index 0 on the user interface, e.g. SINUMERIK Operate: "Diagnosis" > "NC/PLC Variables", the value is read internally with index 1 (oldest value) without changing the FIFO stack.
	1	Write / Read: The "oldest" user data is addressed; the FIFO stack is not changed
	2	Write / Read: The "newest" user data is addressed; the FIFO stack is not changed
	3	Read: Returns the sum of the values of all user data Enable via MD28266 \$MC_MODE_AC_FIFO, bit 0 required. See paragraph below "Summation across all user data"
	4	Read: Supplies the number of user data currently stored in the FIFO stack. Write: Reset to the initial state is realized by writing the value of 0 to FIFO variable, index 4. Example: <code>\$AC_FIFO1[4] = 0</code>
	5	Read: Returns the current write index, relative to the beginning of the FIFO stack
	User data	
	6	Write/read: The 1st field element of the user data range is addressed
7	Write/read: The 2nd field element of the user data range is addressed	
n	Write/read: The nth field element of the user data range is addressed	
References		
List Manual, System Variables		

Machine data

Number of FIFO variables per channel

The number of FIFO variables per channel is set using:

MD28260 \$MC_NUM_AC_FIFO = <number of FIFO variables per channel>

Beginning of the R parameter range of FIFO variables

The R parameter, from which the range of FIFO variables for the channel begins, is set using:

MD28262 \$MC_START_AC_FIFO = <number of the start R parameter>

Note

Free R parameters

Only the R parameters whose numbers are below the start R parameter of the FIFO variables, can be written to the NC program.

Number of field elements for each FIFO variable

The maximum number of field elements per FIFO variable is set using:

MD28264 \$MC_LEN_AC_FIFO = <number of field elements per FIFO variable>

Total number of R parameters in the channel

The total number of R parameters, which are required in the channel, is set using:

$$\begin{aligned} \text{MD28050 } \$\text{MC_MM_NUM_R_PAR-} & \text{ MD28262 } \$\text{MC_START_AC_FIFO} + \\ \text{AM} = & \text{ MD28260 } \$\text{MC_NUM_AC_FIFO} * \\ & (\text{MD28264 } \$\text{MC_LEN_AC_FIFO} + 6) \end{aligned}$$

Summation of all user data


The sum of the values of all user data is only provided via \$AC_FIFO[3] if the function is activated via machine data:

MD28266 \$MC_MODE_AC_FIFO, bit 0 = <value>

Value	Meaning
FALSE	The sum of the values of all user data is not provided
TRUE	The sum of the values of all user data is provided


Example

Serial determination of the length of workpieces that move past an automatic measuring station on a conveyor belt.



The measurement results are written to or read from the \$AC_FIFO1 system variable via synchronized actions.

- **Read:** With index 0, the "oldest" user data element is read and deleted from the FIFO stack.
- **Write:** With index 0, the value is written to the next free user data element.



3.17.4.10 Path tangent angle (\$AC_TANEB)

The angle between the tangent at the end point of the current block and the tangent at the start point of the following block can be read via the channel-specific system variable \$AC_TANEB (Tangent ANgle at End of Block).

Data type: REAL

The tangent angle is always specified positive in the range 0.0 to 180.0°.

If the tangent angle cannot be determined, the value -180.0° is output.

Used only with programmed blocks

It is recommended that the tangent angle only be read for programmed blocks, not for intermediate blocks generated by the system. A distinction can be made via the system variable \$AC_BLOCKTYPE:

\$AC_BLOCKTYPE == 0 (programmed block)

Example:

Program code
ID=2 EVERY \$AC_BLOCKTYPE==0 DO \$R1=\$AC_TANEB

3.17.4.11 Override (\$A...OVR)

Current override

Channel-specific override

The path feedrate can be changed via the channel-specific system variable \$AC_OVR.

Data type: REAL

Unit: %

Range of values: 0.0 to machine data

- For **binary**-coded override switch
MD12100 \$MN_OVR_FACTOR_LIMIT_BIN
- For **gray**-coded override switch
MD12030 \$MN_OVR_FACTOR_FEEDRATE[30]

The system variable \$AC_OVR must be written in every interpolator clock cycle, otherwise the value "100%" is effective.

Channel-specific rapid traverse override

With G0 blocks (rapid traverse), the rapid traverse feedrate can also be influenced via the setting data SD42122 \$SC_OVR_RAPID_FACTOR in addition to the system variable \$AC_OVR.

Requirement: Release of the rapid traverse override via the user interface.

Axis-specific override

The axial feedrate can be changed via the axis-specific system variable \$AA_OVR:

Data type: REAL
Unit: %
Range of values: 0.0 to machine data

- For **binary**-coded override switch
MD12100 \$MN_OVR_FACTOR_LIMIT_BIN
- For **gray**-coded override switch
MD12030 \$MN_OVR_FACTOR_FEEDRATE[30]

The system variable \$AA_OVR must be written in every interpolator clock cycle, otherwise the value "100%" is effective.

PLC override

Channel-specific override

The channel-specific override (DB21, ... DBB4) set via the machine control panel can be read via the channel-specific system variable \$AC_PLC_OVR:

Data type: REAL
Unit: %
Range of values: 0.0 to maximum value

Axis-specific override

The axis-specific override (DB31, ... DBB0) set via the machine control panel can be read via the axis-specific system variable \$AA_PLC_OVR:

Data type: REAL
Unit: %
Range of values: 0.0 to maximum value

Effective override

Effective channel-specific override

The effective channel-specific override can be read via the channel-specific system variable \$AC_TOTAL_OVR:

Data type: REAL
Unit: %
Range of values: 0.0 to maximum value

Effective axis-specific override

The effective axis-specific override can be read via the axis-specific system variable \$AA_TOTAL_OVR:

Data type: REAL
 Unit: %
 Range of values: 0.0 to maximum value

3.17.4.12 Capacity evaluation (\$AN_IPO ... , \$AN/AC_SYNC ... , \$AN_SERVO)

The values of the current, maximum and average system utilization due to synchronized actions can be read via the following system variables:

NC-specific system variable	Meaning
\$AN_IPO_ACT_LOAD	Current computing time of the interpolator level (incl. synchronized actions of all channels)
\$AN_IPO_MAX_LOAD	Longest computing time of the interpolator level (incl. synchronized actions of all channels)
\$AN_IPO_MIN_LOAD	Shortest computing time of the interpolator level (incl. synchronized actions of all channels)
\$AN_IPO_LOAD_PERCENT	Current computing time of the interpolator level in relation to the interpolator cycle (%)
\$AN_SYNC_ACT_LOAD	Current computing time for synchronized actions over all channels
\$AN_SYNC_MAX_LOAD	Longest computing time for synchronized actions over all channels
\$AN_SYNC_TO_IPO	Percentage share that the synchronized actions have of the total computing time (over all channels)
\$AN_SERVO_ACT_LOAD	Current computing time of the position controller
\$AN_SERVO_MAX_LOAD	Longest computing time of the position controller
\$AN_SERVO_MIN_LOAD	Shortest computing time of the position controller

Channel-specific system variable	Meaning
\$AC_SYNC_ACT_LOAD	Current computing time for synchronized actions in the channel
\$AC_SYNC_MAX_LOAD	Longest computing time for synchronized actions in the channel
\$AC_SYNC_AVERAGE_LOAD	Average computing time for synchronized actions in the channel

3.17 Synchronized actions




Figure 3-11 Computing time shares of the synchronized actions on the interpolator cycle

Activation

The system variables only contain valid values when the "Utilization evaluation via synchronized actions" diagnostic function is active.

For this, the following machine data must be greater than zero:

MD11510 \$MN_IPO_MAX_LOAD > 0 (maximum permissible interpolator utilization)

When the function is active, the current values are displayed in the "Time required for synchronized actions" line in the "Diagnostics" > "System utilization" operating area.

Note

The system variables always contain the values of the previous interpolator cycle.

Overload limit

An overload limit is specified via the value set via MD11510 \$MN_IPO_MAX_LOAD:

MD11510 \$MN_IPO_MAX_LOAD = <maximum permissible utilization in % of the interpolator cycle>

If the value set in the machine data is exceeded, the following system variable is set:

\$AN_IPO_LOAD_LIMIT = TRUE

If the value falls below the set value again, the system variable is reset:

\$AN_IPO_LOAD_LIMIT = FALSE

Application

A user-specific strategy to avoid a level overflow can be implemented via the system variable \$AN_IPO_LOAD_LIMIT.

Resetting of min./max. values

The following system variables for min./max. values are reset by writing arbitrary values:

System variable	Meaning
\$AN_SERVO_MAX_LOAD	Longest computing time of the position controller
\$AN_SERVO_MIN_LOAD	Shortest computing time of the position controller
\$AN_IPO_MAX_LOAD	Longest computing time of the interpolator level (incl. synchronized actions of all channels)
\$AN_IPO_MIN_LOAD	Shortest computing time of the interpolator level (incl. synchronized actions of all channels)
\$AN_SYNC_MAX_LOAD	Longest computing time for synchronized actions over all channels
\$AC_SYNC_MAX_LOAD	Longest computing time for synchronized actions in the channel

Example

Program code	Comment
\$MN_IPO_MAX_LOAD=80	; Overload limit
;	
; Initialization of the min./max. values	
N01 \$AN_SERVO_MAX_LOAD=0	
N02 \$AN_SERVO_MIN_LOAD=0	
N03 \$AN_IPO_MAX_LOAD=0	
N04 \$AN_IPO_MIN_LOAD=0	
N05 \$AN_SYNC_MAX_LOAD=0	
N06 \$AC_SYNC_MAX_LOAD=0	
;	
; Alarm 63111 when the overload limit is exceeded	
N10 IDS=1 WHENEVER \$AN_IPO_LOAD_LIMIT == TRUE DO M4711 SETAL(63111)	
;	
; Alarm 63222 when the computing time share of the	
; synchronized actions over all channels exceeds 30% of the interpolator cycle	
N20 IDS=2 WHENEVER \$AN_SYNC_TO_IPO > 30 DO SETAL(63222)	
;	
N30 G0 X0 Y0 Z0	
...	
N999 M30	

3.17.4.13 Working-area limitation (\$SA_WORKAREA_ ...)

Only the activation via the setting data is effective for the traversable command axes in synchronized actions with regard to the programmable working-area limitation G25/G26:

- \$SA_WORKAREA_PLUS_ENABLE
- \$SA_WORKAREA_MINUS_ENABLE

3.17 Synchronized actions

Switching the working-area limitation on and off via the commands WALIMON/WALIMOF in the part program has no effect on the command axes traversable via synchronized actions.

3.17.4.14 SW cam positions and times (\$\$SN_SW_CAM_ ...)

The values of the SW cam positions and times can be read and written via the following setting data:

NC-specific setting data	Meaning
\$\$SN_SW_CAM_MINUS_POS_TAB_1[0..7]	Minus cam positions
\$\$SN_SW_CAM_MINUS_POS_TAB_2[0..7]	Minus cam positions
\$\$SN_SW_CAM_PLUS_POS_TAB_1[0..7]	Plus cam positions
\$\$SN_SW_CAM_PLUS_POS_TAB_2[0..7]	Plus cam positions
\$\$SN_SW_CAM_MINUS_TIME_TAB_1[0..7]	Minus cam lead or delay time
\$\$SN_SW_CAM_MINUS_TIME_TAB_2[0..7]	Minus cam lead or delay time
\$\$SN_SW_CAM_PLUS_TIME_TAB_1[0..7]	Plus cam lead or delay time
\$\$SN_SW_CAM_PLUS_TIME_TAB_2[0..7]	Plus cam lead or delay time

Note

The setting of a software cam via synchronized actions must not be performed immediately before the cam is reached. At least three interpolation cycles must be available before the cam is reached.

A detailed description of the "Software cam" function can be found in:

References

Function Manual for Extended Functions, Software Cams, Position-Switching Signals (N3)

Examples

```

Program code
; Changing a cam position:
ID=1 WHEN $AA_IW[x] > 0 DO $$SN_SW_CAM_MINUS_POS_TAB_1[0] = 50.0
...
; Changing a lead time
ID=1 WHEN $AA_IW[x] > 0 DO $$SN_SW_CAM_MINUS_TIME_TAB_1[0] = 1.0
    
```

See also

Machine and setting data (\$\$M, \$\$S) (Page 918)

3.17.4.15 Path length evaluation / machine maintenance (\$AA_TRAVEL ... , \$AA_JERK ...)

The data of the path length evaluation, e.g. for machine maintenance, can be read via the system variables listed below.

Activation

The activation for the recording of the path length evaluation data is performed via:

MD18860 \$MN_MM_MAINTENANCE_MON = 1

The data to be recorded for the specific axis can be selected via the following axis-specific machine data:

MD33060 \$MA_MAINTENANCE_DATA[<axis>], bit n = 1

Bit	Meaning
0	Recording of total traversing distance, total traversing time and number of traversing operations of the axis.
1	Recording of total traversing distance, total traversing time and number of traversing operations of the axis at high speed.
2	Recording of total number of axis jerks, the time during which the axis is traversed with jerk and the number of traversing operations with jerk.

System variable

System variable	Meaning	n
\$AA_TRAVEL_DIST	Total travel distance: Sum of all set position changes in MCS in [mm] or [deg.]	0
\$AA_TRAVEL_TIME	Total travel time: Sum of IPO cycles of set position changes in MCS in [s] (resolution: 1 IPO cycle)	
\$AA_TRAVEL_COUNT	Total travel count: A complete machine axis trip is defined by the following succession of states, as based on set position: standstill > traversing > standstill	
\$AA_TRAVEL_DIST_HS	Total traversing distance at high axis velocities ¹⁾	1
\$AA_TRAVEL_TIME_HS	Total traversing time at high axis velocities ¹⁾	
\$AA_TRAVEL_COUNT_HS	Total number of traversing operations at high axis velocities ³⁾	
\$AA_JERK_TOT	Total sum of axis jerks: Sum of all jerk setpoints in [m/s ³] or [deg./s ³]	2
\$AA_JERK_TIME	Total travel time with jerk: Sum of IPO cycles from jerk setpoint changes in [s] (solution: 1 IPO cycle)	
\$AA_JERK_COUNT	Total number of traversing operations with jerk	
¹⁾ Actual machine axis velocity ≥ 80% of the maximum parameterized axis velocity (MD32000 MAX_AX_VELO)		

References

For a detailed description of the function, refer to:

Function Manual, Special Functions, Section "Path length evaluation (W6)"

3.17.4.16 Polynomial coefficients, parameters (\$AC_FCT ...)

Function

Using the FCTDEF function, as a maximum, a 3rd degree polynomial can be defined:

$$f(x) = a_0 + a_1 \cdot x + a_2 \cdot x^2 + a_3 \cdot x^3$$

Note

The definition must be made in a **part program**.

Syntax

FCTDEF (<Poly_No>, <Lo_Limit>, <Up_Limit>, a₀, a₁, a₂, a₃)

Meaning

Parameter	Meaning
<Poly_No>:	Number of the polynomial function
<Lo_Limit>:	Lower limit of the function values
<Up_Limit>:	Upper limit of the function values
a ₀ , a ₁ , a ₂ , a ₃ :	Polynomial coefficient

Note

Polynomial coefficients (a₂, a₃) that are not required can be omitted when programming the FCTDEF (. . .) function.

System variable

Read and write access to polynomial coefficients and parameters is also possible from synchronized actions via the following system variables:

System variable	Meaning
\$AC_FCTLL[<Poly_No>]:	Lower limit for function value
\$AC_FCTUL[<Poly_No>]:	Upper limit for function value
\$AC_FCT0[<Poly_No>]:	a ₀
\$AC_FCT1[<Poly_No>]:	a ₁
\$AC_FCT2[<Poly_No>]:	a ₂
\$AC_FCT3[<Poly_No>]:	a ₃
<Poly_No>:	The number specified during the definition of the polynomial function (see above: Syntax)

Part program

When writing system variables in the part program, preprocessing stop `STOPRE` must be programmed explicitly for block-synchronous writing.

Note

Block-synchronous writing in the part program

So that the system variables can be written block-synchronously in the part program, the `STOPRE` command (preprocessing stop) must be used after writing the system variables.

Synchronized action

When writing system variables in synchronized actions, they take effect immediately.

Use

The function value $f(x)$ of the polynomial can be used as input value in synchronized actions, e.g. for the following functions:

- "Polynomial evaluation (SYNFCT) (Page 957)"
- "Online tool offset (FTOC) (Page 962)"

Example: Linear dependency




Figure 3-12 Example of linear dependency

Parameter	Meaning
<Poly_No>:	Number of the polynomial, e.g. = 1
<Lo_Limit>:	Lower limit of the function values = -100
<Up_Limit>:	Upper limit of the function values = 100
a_0 :	Axis section on the ordinate (feedrate): $(5 - 4) / 100 = 5 / a_0$ $a_0 = 100 * 5 / (5 - 4) = \mathbf{500}$
a_1 :	Gradient of the straight line: $a_1 = 100 / (4 - 5) = \mathbf{-100}$

3.17 Synchronized actions

Parameter	Meaning
a ₂ :	= 0 (no square component)
a ₃ :	= 0 (no cubic component)

Program code

```
FCTDEF(1, -100, 100, 500, -100, 0, 0)
; Or in abbreviated notation without parameters a2 and a3
FCTDEF(1, -100, 100, 500, -100)
```

3.17.4.17 Overlaid movements (\$AA_OFF)

Overlaid movements

The system variable \$AA_OFF can be used to specify a position offset in a channel axis which is traversed immediately:

```
$AA_OFF[<channel axis>] = <position offset>
```

The following machine data can be used to set whether the position offset of the system variable is to be assigned or summed up (integrated):

```
MD36750 $MA_AA_OFF_MODE, bit 0 = <value>
```

<value>	Meaning
0	Assignment: \$AA_OFF = <position offset>
1	Summing (integration): \$AA_OFF += <position offset>

Limitation of the overlay velocity

The maximum permissible velocity with which the position offset can be traversed can be set via the machine data:

```
MD32070 $MA_CORR_VELO (axis velocity for overlay)
```

Axial jerk limitation

Setting the following machine data activates an axial jerk limitation for the \$AA_OFF overlaying:

```
MD32420 $MA_JOG_AND_POS_JERK_ENABLE (basic position of axial jerk limitation) = 1
```

The axial jerk is limited to the value set in MD32430 \$MA_JOG_AND_POS_MAX_JERK (axial jerk).

Note

No predictive velocity control can be made for the overlaid \$AA_OFF motion. This can cause a discontinuous velocity change, in particular for clocked specification (via synchronous actions) for \$AA_OFF overlay values. In such cases, we recommend the deactivation of the jerk limitation when possible.

Upper limit of the compensation value

The value of \$AA_OFF can be limited via the following setting data:

SD43350 \$SA_AA_OFF_LIMIT (upper limit of the compensation value \$AA_OFF in case of clearance control)

The status of the limitation can be read via the following system variable:

\$AA_OFF_LIMIT[<axis>] == <value>

Value	Meaning
-1	Compensation value is limited in the negative direction
1	Compensation value is limited in the positive direction.
0	No limitation of the offset value

Reset behavior

With static synchronized actions (IDS = <number> DO \$AA_OFF = <value>), deselection of the position offset effective in \$AA_OFF results in an immediate new overlaid movement. The reset behavior with regard to \$AA_OFF can therefore be set via the following machine data:

MD36750 \$MA_AA_OFF_MODE, bit 1 = <value>

<value>	Meaning
0	The position offset in \$AA_OFF is deselected with RESET
1	The position offset in \$AA_OFF is retained after RESET

JOG mode

Execution of an overlaid movement because of \$AA_OFF can also be enabled for JOG mode:

MD36750 \$MA_AA_OFF_MODE, bit 2 = <value>

<value>	Meaning
0	JOG mode: Overlaid movement because of \$AA_OFF disabled
1	JOG mode: Overlaid movement because of \$AA_OFF enabled

A mode change to JOG mode is only possible when the current position offset has been traversed. Otherwise the following alarm is displayed:

Alarm "16907 Action ... only possible in stop state"

Supplementary conditions

- **Interrupt routines and ASUB**
When an interrupt routine is activated, modal motion-synchronous actions are retained and are also effective in the ASUB. If the subprogram return is not made with `REPOS`, the modal synchronized actions changed in the asynchronous subprogram continue to be effective in the main program.
- **REPOS**
In the remainder of the block, the synchronized actions are treated in the same way as in an interruption block. Modifications to modal synchronized actions in the ASUB are not effective in the interrupted program. Polynomial coefficients programmed with `FCTDEF` are not affected by ASUB and `REPOS`.
The polynomial coefficients from the calling program are active in the ASUB. The polynomial coefficients from the ASUB continue to be active in the calling program.
- **End of program**
Polynomial coefficients programmed with `FCTDEF` remain active after the end of program.
- **Block search: Collection of the polynomial coefficients**
During block search with calculation, the polynomial coefficients are collected in the system variables.
- **Block search: Deselection of active overlaid movements**
During block search, the `CORROF` and `DRFOF` commands are collected and output in an action block. All the deselected DRF offsets are collected in the last block that contains `CORROF` or `DRFOF`.
The commands for the deselection of overlaid movements `CORROF(<axis>, "AA_OFF")` are not collected during a block search. If a user wishes to continue to use this block search, this is possible by means of block search via "SERUPRO" program testing.
Reference:
Function Manual Basic Functions; Mode Group, Channel, Program Operation (K1)
- **Deselection of the position offset in case of synchronized actions**
Alarm 21660 is displayed if a synchronized action is active when the position offset is deselected via the `CORROF(<axis>, "AA_OFF")` command. `$AA_OFF` is deselected simultaneously and not set again. If the synchronized action becomes active later in the block after `CORROF`, `$AA_OFF` remains set and a position offset is interpolated.

References:

Programming Manual, Fundamentals

Note

The coordinate system (BCS or WCS) in which a main run variable is defined determines whether frames will or will not be included.

Distances are always calculated in the set basic system (metric or inch). A change with `G70` or `G71` has no effect.

DRF offsets, zero offsets external, etc., are only taken into consideration in the case of main run variables that are defined in the MCS.

3.17.4.18 Online tool length compensation (\$AA_TOFF)

Function

In conjunction with an active orientation transformer or an active tool carrier, tool length compensations can be applied during processing/machining in real time. Changing the effective tool length using online tool length compensation produces changes in the compensatory movements of the axes involved in the transformation in the event of changes in orientation. The resulting velocities can be higher or lower depending on machine kinematics and the current axis position.

Velocity and acceleration with which specified tool length compensations can be traversed via the system variable \$AA_TOFF, can be specified via the following machine data:

- MD21194 \$MC_TOFF_VELO (velocity, online offset in tool direction)
- MD21196 \$MC_TOFF_ACCEL (acceleration, online offset in tool direction)

For further information regarding the activation of the function, see:

References:

Programming Manual, Job Planning; Section "Transformations "TOFFON, TOFFOF""

Applications in synchronized actions

In synchronized actions, tool length compensations can be applied in all three dimensions via the system variable \$AA_TOFF. The three geometry axis names X, Y, Z are used as index. All three offset directions can be active at the same time.

For an active orientation transformation or for an active tool carrier that can be oriented, the offsets are effective in the respective tool axes. An overlaid motion must be switched off with TOFFOF () before switching a transformation on or off.

After deselection of the tool length compensation in one dimension, the value of the system variable \$AA_TOFF in this dimension is equal to 0.

Mode of operation of the offset in the tool direction

The tool length compensations do not change the tool parameters, but are taken into account within the transformation or the tool carrier that can be orientated, so that offsets are obtained in the tool coordinate system.

For each dimension, it is possible to define whether the tool length compensation specified in \$AA_TOFF should be calculated as an absolute or incremental (integrating) value via the following machine data:

MD21190 \$MC_TOFF_MODE (operation of tool offset in tool direction)

The current value of the tool length compensation can be read via the system variable \$AA_TOFF_VAL.

Note

An evaluation of the variables \$AA_TOFF_VAL is only useful in conjunction with an active orientation transformation or an active tool carrier.

Examples

Selecting the online tool length compensation

Machine data for online tool length compensation:

- MD21190 \$MC_TOFF_MODE = 1
- MD21194 \$MC_TOFF_VEL[0] = 10000
- MD21194 \$MC_TOFF_VEL[1] = 10000
- MD21194 \$MC_TOFF_VEL[2] = 10000
- MD21196 \$MC_TOFF_ACC[0] = 1
- MD21196 \$MC_TOFF_ACC[1] = 1
- MD21196 \$MC_TOFF_ACC[2] = 1

Activate online tool length compensation in the part program:

Program code

```
N5 DEF REAL XOFFSET
; Activate orientation transformation
N10 TRAORI
; Activate tool length compensation in the Z direction
N20 TOFFON(Z)
; Tool length compensation in the Z direction: 10 mm
N30 WHEN TRUE DO $AA_TOFF[Z] = 10
G4 F5
...
; Static synchronized action: Tool length compensation in the X direction
; corresponds to the position of the X2 axis in the WCS
N50 ID=1 DO $AA_TOFF[X] = $AA_IW[X2]
G4 F5
...
; Note: Current total tool length compensation in the X direction
N100 XOFFSET = $AA_TOFF_VAL[X]
; Retract the tool length compensation in the X direction to 0
N120 TOFFON(X, -XOFFSET)
G4 F5
```

Deselecting the online tool length compensation

```

Program code
; Activate orientation transformation
N10 TRAORI
; Activate tool length compensation in the X direction
N20 TOFFON(X)
; Tool length compensation in the X direction: 10 mm
N30 WHEN TRUE DO $AA_TOFF[X] = 10
G4 F5
...
; Delete tool length compensation in the X direction
; No axis is traversed. To the current position in the WCS,
; the position offset in accordance with the current orientation
; is added.
N80 TOFFOF(X)
N90 TRAFOOF
    
```

Activating and deactivating in the part program

The online tool length compensation is activated in the part program with `TOFFON` and deactivated with `TOFFOF`. When activating for the respective offset direction, an offset value can be specified, e.g. `TOFFON(Z, 25)`, which is then immediately traversed. The status of the online tool length compensation is activated at the NC/PLC interface via the following signals:

- DB21, ... DBX318.2 (TOFF active)
- DB21, ... DBX318.3 (TOFF movement active)

Note

The online tool length compensation remains inactive until it is reselected using via `TOFFON` in the part program.

Behavior at reset and power on

The behavior at reset can be set via the machine data:

MD21190 \$MC_TOFF_MODE, bit 0 = <value> (operation of tool offset in tool direction)

Value	Meaning
0	The tool length offset \$AA_TOFF is deselected at reset
1	The tool length offset \$AA_TOFF is retained at reset

This is always necessary in case of synchronized actions `IDS=<number> DO $AA_TOFF[n]=<value>`, as otherwise there would be an immediate tool length compensation.

Similarly, a transformation or a tool carrier that can be oriented, can be deselected **after** reset via the following machine data:

MD20110 \$MC_RESET_MODE_MASK (initial setting after reset)

3.17 Synchronized actions

The tool length compensation must also be deleted in this case.

If a tool length offset is to remain active extending beyond a reset, and a transformation change or a change of the tool carrier that can be oriented takes place, then alarm 21665 "Channel %1 \$AA_TOFF[] reset" is output. The tool length compensation is set to 0.

After power on, all tool length offsets are set to 0.

The function is deactivated after POWER ON.

Behavior at change of operating mode

The tool length compensation remains active after a change of operating mode. The offset is executed in all operating modes except JOG and REF.

If a tool length compensation is traversed because of \$AA_TOFF[] at a change of operating mode, the operating mode changeover is only carried out after the traversal of the tool length compensation. Alarm 16907 "Channel %1 action %2 <ALNX> possible only in stop state" is displayed.

Behavior with REPOS

The tool length compensation is active in REPOS mode.

Supplementary conditions

With an existing tool length offset, the following supplementary conditions must be taken into account:

- A transformation must be switched off with TRAFOOF.
- Before activating a transformation in the part program, an active tool length offset must be deleted with TOFFOF.
- A transformation is switched off when changing over from CP to PTP. A tool length offset must be deleted **before** the changeover. If a tool length compensation is active when you change to axis-specific manual travel in JOG mode, the change to PTP is not performed. CP remains active until the tool length compensation has been deleted via TOFFOF.
- Before a geometry axis interchange, an active tool length offset in the direction of the geometry axis must be deleted via TOFFOF.
- Before a change of plane, an active tool length offset must be deleted via TOFFOF.
- The TOFFON and TOFFOF are not collected during a block search and not output in the action block.

3.17.4.19 Current block in the interpolator (\$AC_BLOCKTYPE, \$AC_BLOCKTYPEINFO, \$AC_SPLITBLOCK)

Information on the block currently being processed in the main run can be read in synchronized actions via the following system variables.

\$AC_BLOCKTYPE and \$AC_BLOCKTYPEINFO

The system variable \$AC_BLOCKTYPE contains the block type or the ID for the function that generated the block.

The system variable \$AC_BLOCKTYPEINFO contains, in addition to the block type (thousands position), the function-specific cause for the generation of the intermediate block.

\$AC_BLOCKTYPE		\$AC_BLOCKTYPEINFO	
Value	Meaning: Current block has been generated because of ...	Value	Meaning
0	Programmed block!	-	-
1	NC as intermediate block	1000	Contains no further information
2	Chamfer/rounding	2001	Straight line
		2002	Circle
3	Smooth approach/retraction (SAR)	3001	Approach with straight line
		3002	Approach with quadrant
		3003	Approach with semicircle
4	Tool offset	4001	Approach block after STOPRE
		4002	Connection blocks if intersection point not found
		4003	Point-type circle on inner corners (on TRACYL only)
		4004	Bypass circle (or conical cut) at outer corners
		4005	Approach blocks for offset suppression
		4006	Approach blocks on repeated TRC activation
		4007	Block split due to excessive curvature
		4008	Compensation blocks for 3D front milling (tool vector parallel to plane vector)
5	Corner rounding	5001	Rounding contour through G641
		5002	Rounding contour through G642
		5003	Rounding contour through G643
		5004	Rounding contour through G644
6	Tangential tracking (TLIFT)	6001	Linear movement of the tangential axis without lift movement
		6002	Non-linear movement of the tangential axis (polynomial) without lift movement
		6003	Lift movement: Tangential axis and lift movement start simultaneously
		6004	Lift movement: Tangential axis does not start until a certain lift position is reached
7	Path segmentation	7001	Programmed path segmentation is active without punching or nibbling
		7002	Programmed path segmentation with active punching or nibbling
		7003	Automatically, internally generated path segmentation
8	Compile cycle	x	x: ID of the compile cycle application that generated the block
9	Path-relative orientation interpolation (ORIPATH/ORIOTC)	9000	Interpolation of the tool orientation with ORIPATH
		9001	Interpolation of the rotation of the tool with ORIOTC

3.17 Synchronized actions

\$AC_BLOCKTYPE		\$AC_BLOCKTYPEINFO	
Value	Meaning: Current block has been generated because of ...	Value	Meaning
10	Pole handling with orientation transformation	10000	Look-ahead positioning of the pole axis
		10001	Traversal of the pole taper

\$AC_SPLITBLOCK

The system variable \$AC_SPLITBLOCK can be used to determine whether an internally generated block or a programmed block shortened by the NC is present.

\$AC_SPLITBLOCK	
Value	Meaning:
0	Programmed block. A block generated by the compressor is also treated as a programmed block.
1	Internally generated block or a shortened original block
3	Last block in a chain of internally generated blocks or shortened original blocks

Example

Synchronized actions for counting smoothing blocks.

The query of the system variable \$AC_TIMEC == 0 (interpolation cycles since start of the block) ensures that the block type is determined only once at the start of the block.

Program code	Comment
\$AC_MARKER[0]=0	; Counter for all smoothing blocks
\$AC_MARKER[1]=0	; Counter for G641 smoothing blocks
\$AC_MARKER[2]=0	; Counter for G642 smoothing blocks
...	
; Synchronized action for counting all smoothing blocks	
ID=1 WHENEVER (\$AC_TIMEC==0) AND (\$AC_BLOCKTYPE==5) DO	
\$AC_MARKER[0] = \$AC_MARKER[0] + 1	
...	
; Synchronized action for counting the G641 smoothing blocks	
ID=2 WHENEVER (\$AC_TIMEC==0) AND (\$AC_BLOCKTYPEINFO==5001) DO	
\$AC_MARKER[1] = \$AC_MARKER[1]+1	
...	
; Synchronized action for counting the G642 smoothing blocks	
ID=3 WHENEVER (\$AC_TIMEC==0) AND (\$AC_BLOCKTYPEINFO==5002) DO	
\$AC_MARKER[2] = \$AC_MARKER[2] + 1	
...	

3.17.4.20 Initialization of array variables (SET, REP)

Function

Array variables can also be initialized in synchronized actions via the `SET` and `REP` commands.
For a detailed description of the commands, refer to:

References

Programming Manual, Job Planning; Section "Flexible NC programming" > "Variables" > "Definition and initialization of array variables (DEF, SET, REP)"

Example

Program code
<pre> PROC MAIN N10 DEF REAL SYG_IS[3,2] ... WHEN TRUE DO SYG_IS[0,0]=REP(0.0,3) WHEN TRUE DO SYG_IS[1,1]=SET(3,4,5) ... </pre>

Supplementary conditions

- Only array variables that can be written in synchronized actions are initialized.

3.17.4.21 Grinding-specific system variables (\$AC_IN_KEY_G...)

When grinding, input signals asynchronous with the machine operation must be identified and the appropriate actions must be integrated in the program sequence. The following system variables and NC/PLC interface signals are available:

System variable	NC/PLC interface DB21, ...	Description
NC-internal communication		
\$AC_IN_KEY_G_ENABLE[1 ... 8] ¹	---	Input signal enable on the NC side
Communication NC → PLC ²⁾		
\$AC_IN_KEY_G_IENABLE[1 ... 8] ¹⁾	DBX390.0 ... 7	Input signal enable
\$AC_IN_KEY_G_RUN_OUT[1 ... 8]	DBX391.0 ... 7	Enable request for the action on the NC side (optional)
Communication PLC → NC ³⁾		
\$AC_IN_KEY_G[1 ... 8]	DBX385.0 ... 7	Input signal
---	DBX386.0 ... 7 ¹⁾	Input signal inhibit on the PLC side

3.17 Synchronized actions


System variable	NC/PLC interface DB21, ...	Description
\$AC_IN_KEY_G_RUN_IN[1 ... 8]	DBX387.0 ... 7	Enable request for the action on the PLC side (optional)
1) As a result of the AND logic operation of the NC enable signal on the NC side in \$AC_IN_KEY_G_ENABLE and PLC enable signal NOT (DBX386.0 ... 7), the enable signal is formed in \$AC_IN_KEY_G_IENABLE and DBX390.0 ... 7. 2) The content of the system variable is transferred in the NC/PLC interface 3) The content of the NC/PLC interface is transferred in the system variable		

Example

Inputs

- The main program starts a cycle (ZYKLUS_1), in which grinding is executed as well as the intermediate dressing.
- An operator can request an "intermediate dressing" action asynchronous to the machining operation itself using an input signal of the PLC I/O.
- Identifying the input signal and requesting the action is realized in a technology cycle. Technology cycle ("SIGNAL_IN_x") is called in the action part of the synchronized action (ID <xy>) set up in the cycle.

The call schematic, the relevant commands and the signal flow are shown in the following diagram.



The PLC user program must provide the functions on the PLC side, for example "enable input signal x".

Sequence

- Main program
 - Call cycle "ZYKLUS_1"
- Cycle "ZYKLUS_1"
 - Set the enable for input signal x (\$AC_IN_KEY_G_ENABLE)
 - Set up the synchronized action with technology cycle "SIGNAL_IN_x"
 - Initialize the trigger for action x "intermediate dressing" (R01)
 - Grind the component
- Technology cycle "SIGNAL_IN_x" (in parallel with the cycle)
 - Identify the input signal (\$AC_IN_KEY_G) with the enable active (\$AC_IN_KEY_G_ISENABLE)
 - Request the enable of action x from the PLC (\$AC_IN_KEY_G_RUN_OUT)
 - Wait for the enable of action x from the PLC (\$AC_IN_KEY_G_RUN_IN)
 - Request action x in cycle (R01)
 - Feedback signal of the request to the PLC (\$AC_IN_KEY_G_RUN_OUT)
 - Wait for acknowledgment from the PLC (\$AC_IN_KEY_G_RUN_IN)
- Cycle "ZYKLUS_1" (after completing grinding)
 - Reset the enable for input signal x (\$AC_IN_KEY_G_ENABLE)
 - If action x is requested ⇒ execute intermediate dressing
 - ... (possibly re-execute grinding/intermediate dressing operations etc.)
- PLC user program
 - Function "Enable input signal x":
Set interface signal DBX386.0 ... 7
 - Function "Enable input signal x":
Logically combine (AND) the input signal from the PLC I/O and the enable of input signal (DBX390.0 ... 7) - and set the result in the interface (DBX385.0 ... 7)
 - Function "Enable action x":
Check/set the interface signals DBX391.0 ... 7 / DBX387.0 ... 7

3.17.4.22 Status Synchronized action disabled (\$AC_SYNA_STATE)

System variable \$AC_SYNA_STATE outputs in bit code whether a synchronized action is disabled via the PLC (see "Coordination via PLC (Page 1011)") or via a synchronized action is disabled (see "Coordination via part program and synchronized action (LOCK, UNLOCK, CANCEL) (Page 1011)").

These bits have the following meaning:

Bit	Value	Meaning
0	0	Not disabled
	1	Disabled via PLC or synchronized action

Bit	Value	Meaning
1	0	Not disabled via PLC
	1	Disabled via PLC
2	0	Not disabled via synchronized action
	1	Disabled via synchronized action

Disabling via PLC or synchronized action have different levels of priority. The following hierarchy of priorities applies:

- Priority 1 (highest priority): Disabled via PLC across all channels (⇒ all synchronized actions in the channel are inhibited)
- Priority 2: Disabled via synchronized action
- Priority 3: Individual disabling via PLC (⇒ a single synchronized action in the channel is disabled)

\$AC_SYNA_STATE only outputs the value of the disable with the highest priority, even if disabling is simultaneously active via PLC **and** Synchronized action:

Status	Highest priority	\$AC_SYNA_STATE			
		Bit 2	Bit 1	Bit 0	Bit-coded value
Channel-wide disable via PLC is active. In addition, disable via synchronized action can be active.	Channel-wide disable via PLC	0	1	1	3
Channel-wide disable via PLC is not active. Disable via synchronized action is active. Additionally, a single disable can be active via PLC.	Disabled via synchronized action	1	0	1	5
Channel-wide disable via PLC is not active. Disable via synchronized action is not active. Single disable via PLC is active.	Single disable via PLC	0	1	1	3
No disable is active.	-	0	0	0	0

3.17.5 User-defined variables for synchronized actions

GUD variables capable of synchronized actions

As well as specific system variables, predefined global synchronized-action user variables (synchronized action GUD) can also be used in synchronized actions. The number of synchronized action GUD items available to the user is parameterized for each specific data type and access using the following machine data:

- MD18660 \$MM_NUM_SYNACT_GUD_REAL[<x>] = <number>
- MD18661 \$MM_NUM_SYNACT_GUD_INT[<x>] = <number>
- MD18662 \$MM_NUM_SYNACT_GUD_BOOL[<x>] = <number>
- MD18663 \$MM_NUM_SYNACT_GUD_AXIS[<x>] = <number>

3.17 Synchronized actions

- MD18664 \$MM_NUM_SYNACT_GUD_CHAR[<x>] = <number>
- MD18665 \$MM_NUM_SYNACT_GUD_STRING[<x>] = <number>

The index <x> is used to specify the data block (access rights) and the value <number> to specify the number of synchronized-action GUDs for each data type (REAL, INT, etc.). A 1-dimensional array variable with the following naming scheme is then created in the relevant data block for each data type.: SYG_<data type><access right>[<index>]:

Index <x>	Data type (MD18660 to MD18665)						
	Block	REAL	INT	BOOL	AXIS	CHAR	STRING
0	SGUD	SYG_RS[i]	SYG_IS[i]	SYG_BS[i]	SYG_AS[i]	SYG_CS[i]	SYG_SS[i]
1	MGUD	SYG_RM[i]	SYG_IM[i]	SYG_BM[i]	SYG_AM[i]	SYG_CM[i]	SYG_SM[i]
2	UGUD	SYG_RU[i]	SYG_IU[i]	SYG_BU[i]	SYG_AU[i]	SYG_CU[i]	SYG_SU[i]
3	GUD4	SYG_R4[i]	SYG_I4[i]	SYG_B4[i]	SYG_A4[i]	SYG_C4[i]	SYG_S4[i]
4	GUD5	SYG_R5[i]	SYG_I5[i]	SYG_B5[i]	SYG_A5[i]	SYG_C5[i]	SYG_S5[i]
5	GUD6	SYG_R6[i]	SYG_I6[i]	SYG_B6[i]	SYG_A6[i]	SYG_C6[i]	SYG_S6[i]
6	GUD7	SYG_R7[i]	SYG_I7[i]	SYG_B7[i]	SYG_A7[i]	SYG_C7[i]	SYG_S7[i]
7	GUD8	SYG_R8[i]	SYG_I8[i]	SYG_B8[i]	SYG_A8[i]	SYG_C8[i]	SYG_S8[i]
8	GUD9	SYG_R9[i]	SYG_I9[i]	SYG_B9[i]	SYG_A9[i]	SYG_C9[i]	SYG_S9[i]

Where i = 0 to (<number> - 1)
 Block: _N_DEF_DIR/_N_ ... _DEF, e.g for SGUD => _N_DEF_DIR/_N_SGUD_DEF

Properties

Synchronized-action GUD have the following properties:

- Synchronized-action GUD can be read and written in synchronized actions and part programs/cycles.
- Synchronized-action GUD can be accessed via the OPI.
- Synchronized-action GUD is displayed on the HMI user interface in the "Parameters" operating area.
- Synchronized-action GUD can be used on the HMI in the Wizard, in the variables view and in the variables log.
- The array size for STRING type synchronized action GUD is set to a fixed value of 32 (31 characters + \0).
- Even if no definition files have been created manually for global user data (GUD), synchronized-action GUD defined using machine data can be read in the corresponding GUD block from the HMI.

Note

User variables (GUD, PUD, LUD) can only be defined with the same name as synchronized-action GUD (DEF ... SYG_xy) if no synchronized-action GUD has been parameterized with the same name (MD18660 - MD18665). These user-defined items of GUD **cannot** be used in synchronized actions.

Access rights

The access rights defined in a GUD definition file remain valid and refer only to the GUD variables defined in this GUD definition file.

Deletion behavior

If the content of a particular GUD definition file is reactivated, the old GUD data block in the active file system is deleted first. The configured synchronized-action GUD is also reset at this point. This process is also possible using the HMI in the operator area "Services" > "Define and activated user data (GUD)".

3.17.6 Language elements for synchronized actions and technology cycles

The following language elements can be used in synchronized actions and technology cycles:

Fixed addresses	
L	Subprogram number
F	Feed
S ^{1) 2)}	Spindle
M ^{1) 2)}	M function
H ¹⁾	H function
1) Chapter: "Output of M, S and H auxiliary functions to the PLC (Page 955)"	
2) Chapter: "Traversing spindles (M, S, SPOS) (Page 980)"	

Fixed addresses with axis extension: Miscellaneous	
POS	Traversing axes, to position (POS) (Page 967)
POSA	Modal positioning axis
SPOS	Spindle positioning Chapter: "Traversing spindles (M, S, SPOS) (Page 980)"
MOV ¹⁾	Positioning axis Chapter: "Traversing axes, endless (MOV) (Page 973)"
FA	Axial feedrate (FA) (Page 974)
OVRA	Axial override
ACC	Axial acceleration
MEASA	Axial measurement with deletion of distance-to-go
MEAWA	Axial measurement without deletion of distance-to-go Chapter: "Measurement (MEAWA, MEAC) (Page 999)"
MEAC	Cyclic measuring Chapter: "Measurement (MEAWA, MEAC) (Page 999)"
SCPARA	Parameter set changeover
VELOLIMA	Axial velocity/speed limitation
ACCLIMA	Axial acceleration limitation

3.17 Synchronized actions

Fixed addresses with axis extension: Miscellaneous	
JERKLIMA	Axial jerk limitation
1) Not permitted in technology cycles	

Settable addresses: Travel to fixed stop ¹⁾	
FXS	Activate travel to fixed stop
FXST	Torque limit for travel to fixed stop
FXSW	Monitoring window for travel to fixed stop
FOC	Non-modal torque/force limitation
FOCON	Activate travel with limited torque/force
FOCOF	Deactivate travel with limited torque/force
1) Chapter: "Travel to fixed stop (FXS, FXST, FXSW, FOCON, FOCOF, FOC) (Page 1002)"	

Settable addresses: Couplings > Generic coupling ¹⁾	
CPBC	Block change criterion with active coupling
CPDEF	Create coupling module
CPDEL	Delete coupling module
CPFMOF	Behavior of the following axis when switching off the coupling
CPFMON	Behavior of the following axis when switching on the coupling
CPFMSON	Synchronization mode during coupling
CPFPOS	Synchronized position of the following axis when switching on
CPFRS	Reference system for the coupling module of the following axis
CPLA ²⁾	Assigning an axis as leading axis to a following axis
CPLCTID	Number of the curve table for the coupling of the following axis
CPLDEF	Definition of the reference: Leading axis to following axis
CPLDEL	Cancellation of the reference: Leading axis to following axis
CPLDEN	Coupling factor: Numerator
CPLNUM	Coupling factor: Denominator
CPLDYPRIO	Priority of the leading axis for the dynamic limitation
CPLDYVLL	Limitation of the overlaid motion of the leading axis: Lower limit
CPLDYVLU	Limitation of the overlaid motion of the leading axis: Upper limit
CPLINSC	Scaling factor for the input value of the leading axis
CPLINTR	Offset value for the input value of the leading axis
CPLOF	Coupling of leading axis to following axis: Switch off
CPLON	Coupling of leading axis to following axis: Switch on
CPLOUTSC	Scaling of the output value
CPLOUTTR	Offset of the output value
CPLPOS	Synchronized position of the leading axis when switching on
CPLSETVAL	Coupling type of the following axis to the leading axis
CPMALARM	Define alarm behavior
CPMBRAKE ²⁾	Defining the response to a stop signal and commands
CPMPRT	Define start behavior for program test

Settable addresses: Couplings > Generic coupling ¹⁾	
CPMRESET	Define reset behavior
CPMSTART	Define start behavior
CPMVDI	Define behavior regarding NC/PLC interface signals
CPOF	Deactivation of the coupling to all defined leading axes
CPON	Activation of the coupling to all defined leading axes
CPRES ²⁾	Activates the coupling parameter parameterized in the machine data
CPSETTYPE	Define basic coupling properties
CPSYNCOF	Position synchronism "coarse"
CPSYNCOF2	Position synchronism 2 "coarse"
CPSYNFIP	Position synchronism "fine"
CPSYNFIP2	Position synchronism 2 "fine"
CPSYNCOV	Velocity synchronism "coarse"
CPSYNFIV	Velocity synchronism "fine"
1) Chapter: "Couplings (CP..., LEAD..., TRAIL..., CTAB...) (Page 994)"	
2) Currently not available in synchronized actions	

G functions: Set measuring system ¹⁾	
G70	Inch measuring system
G71	Metric measuring system
G700	Inch measuring system
G710	Metric measuring system
1) Chapter: "Setting the measuring system (G70, G71, G700, G710) (Page 971)"	

Predefined subprograms: Miscellaneous	
POLFA	Axial retraction position for single axis
POLFC	Axial retraction position for channel axes
STOPREOF	Cancel preprocessing stop (STOPREOF) (Page 965)
RDISABLE	Programmed read-in disable (RDISABLE) (Page 964)
DELDTG	Delete distance-to-go (DELDTG) (Page 965)
LOCK	Lock synchronized action
UNLOCK	Unlock synchronized action
ICYCON	Technology cycle: One block per interpolator clock cycle
ICYCOF	Technology cycle: All blocks in one interpolator clock cycle
SYNFCT	Polynomial evaluation (SYNFCT) (Page 957)
FTOC	Tool fine compensation Section: "Online tool offset (FTOC) (Page 962)"
SOFTENDSA	Software limit switch
PROTA	Change status of a protection zone
SETM	Set marker of the channel coordination Section: "Channel synchronization (SETM, CLEARM) (Page 1004)"

3.17 Synchronized actions

Predefined subprograms: Miscellaneous	
CLEARM	Delete marker of the channel coordination Section: "Channel synchronization (SETM, CLEARM) (Page 1004)"
RET	Subprogram return
GET	Request axis Section: "Axis replacement (GET, RELEASE, AXTOCHAN) (Page 974)"
RELEASE	Release axis Section: "Axis replacement (GET, RELEASE, AXTOCHAN) (Page 974)"
AXTOCHAN	Transfer axis to another channel Section: "Axis replacement (GET, RELEASE, AXTOCHAN) (Page 974)"
AXCTSWEC	Withdrawing the enable for the axis container rotation (AXCTSWEC) (Page 981)
SETAL	User-specific error reactions (SETAL) (Page 1004)
IPOBRKA	Block change criterion: Deceleration ramp
ADISPOSA	Tolerance window for end-of-motion criterion

Predefined subprograms: Coupling > Coupled motion ¹⁾	
TRAILON	Coupled motion on
TRAILOF	Coupled motion off
1) Section: "Couplings (CP..., LEAD..., TRAIL..., CTAB...) (Page 994)"	

Predefined subprograms: Couplings > Master value coupling ¹⁾	
LEADON	Master value coupling on
LEADOF	Master value coupling off
1) Section: "Couplings (CP..., LEAD..., TRAIL..., CTAB...) (Page 994)"	

Predefined subprograms: Couplings > Torque coupling (master/slave)	
MASLON	Coupling on
MASLOF	Coupling off
MASLDEF	Define coupling
MASLDEL	Delete coupling
MASLOFS	Coupling with slave spindle off

Predefined functions: Coupling > Curve tables ¹⁾	
CTAB	Calculates the following axis position based on the leading axis position using the curve table
CTABINV	Calculates the leading axis position based on the following axis position using the curve table
CTABID	Determines the table number of the curve table

Predefined functions: Coupling > Curve tables ¹⁾	
CTABLOCK	Disable curve table
CTABUNLOCK	Enable curve table
CTABISLOCK	Determines the lock status of the curve table
CTABEXISTS	Checks whether the curve table exists
CTABMENTYP	Determines the storage location of the curve table (static/dynamic memory)
CTABPERIOD	Determines the periodicity of the curve table
CTABNO	Determines the number of curve tables
CTABNOMEM	Determines the number of existing curve tables in a specific storage location
CTABSEG	Determines the number of already used curve segments in a specific storage location
CTABSEGID	Determines the number of already used curve segments in a specific table
CTABFSEG	Determines the number of curve segments that are still possible in a specific table
CTABMSEG	Determines the maximum possible number of curve segments in a specific storage location
CTABPOL	Determines the number of already used polynomials in a specific storage location
CTABPOLID	Determines the number of already used polynomials in a specific table
CTABFPOL	Determines the number of polynomials that are still possible in a specific table
CTABMPOL	Determines the maximum possible number of polynomials in a specific storage location
CTABTSV	Determines the following value at the start of the table
CTABTEV	Determines the following value at the end of the table
CTABTSP	Determines the leading value at the start of the table
CTABTEP	Determines the leading value at the end of the table
CTABTMIN	Determines the minimum following value of the table
CTABTMAX	Determines the minimum following value of the table
CTABFNO	Determines the number of curve tables that are still possible in a specific storage location
CTABSSV	Determines the starting value of a table segment for the following axes
CTABSEV	Determines the end value of a table segment for the following axes
1) Section: "Couplings (CP..., LEAD..., TRAIL..., CTAB...) (Page 994)"	

Predefined functions: Arithmetic	
SIN	Sine
ASIN	Arc sine
COS	Cosine
ACOS	Arc cosine
TAN	Tangent
ATAN2	Arc tangent 2

3.17 Synchronized actions

Predefined functions: Arithmetic	
SQRT	Square root
POT	2nd power (square)
TRUNC	Integer component
ROUND	Round to next integer
ROUNDUP	Rounding up of an input value to the next integer
ABS	Absolute value
LN	Natural logarithm
EXP	Exponential function
MINVAL	Smaller of two values
MAXVAL	Larger of two values
BOUND	Check for defined value range

Predefined functions: Current machine data values	
GETMDACT	Determines the current value of the machine data
GETMDPEAK	Determines the maximum value that has occurred in the machine data since the last RESETPEAK
GETMDLIM	Determines the maximum or minimum limit value of the machine data
RESETPEAK	Resets the maximum value again for GETMDPEAK

Predefined functions: Format conversions	
ITOR	INT → REAL
RTOI	REAL → INT
RTOB	REAL → BOOL
BTOR	BOOL → REAL
ITOB	INT → BOOL
BTOI	BOOL → INT

Predefined functions: Safety Integrated	
SIRELAY	Activation of the safety functions parameterized with SIRELIN, SIREL-OUT and SIRELTIME

Predefined functions: Miscellaneous	
POSRANGE	Position in specified reference range (POSRANGE) (Page 972)
PRESETON	Actual value setting with loss of the referencing status (PRESETON) (Page 984)
PRESETONS	Actual value setting without loss of the referencing status (PRESETONS) (Page 989)

Predefined procedures: Miscellaneous	
CANCELSUB	Cancel the actual subprogram level (CANCELSUB) (Page 1005)

References

For detailed descriptions of the language elements not described in this manual, refer to:

- Programming Manual, Fundamentals
- Programming Manual, Job Planning

3.17.7 Language elements for technology cycles only

The following language elements may only be used in technology cycles:

Jump statements	
IF	Branch
GOTO	Jump to label, search direction forward, then backward
GOTOF	Jump to label, search direction forward
GOTOB	Jump to label, search direction backward

End of program	
M02	End of program
M17	End of program
M30	End of program
RET	End of program

References

For detailed descriptions of the statements not described in this manual, refer to:

- Programming Manual, Fundamentals
- Programming Manual, Job Planning

3.17.8 Actions in synchronized actions

3.17.8.1 Output of M, S and H auxiliary functions to the PLC

Output timing

Auxiliary functions of the M, S and H type can be output from synchronized actions. The output to the PLC is immediate, i.e. directly in the interpolator clock cycle in which the action is executed.

3.17 Synchronized actions

Any output times set via the machine data for auxiliary functions have no effect when output from synchronized actions:

- MD11110 \$MN_AUXFU_GROUP_SPEC (auxiliary function group specification)
- MD22200 \$MC_AUXFU_M_SYNC_TYPE (output time of M functions)
- MD22210 \$MC_AUXFU_S_SYNC_TYPE (output time of the S functions)
- MD22230 \$MC_AUXFU_H_SYNC_TYPE (output time of the H functions)

Maximum number

General

A maximum of 10 auxiliary functions can be output simultaneously from the part program and the active synchronized actions of a channel, i.e. in one OB40 cycle of the PLC.

Synchronized-action-specific

The maximum permissible number of auxiliary functions in the action part of a synchronized action is:

- M functions: 5
- S functions: 3
- H functions: 3

Non-modal synchronized actions

In non-modal synchronized actions (without specification of `ID` or `IDS`), auxiliary functions can only be output in conjunction with the scanning frequency `WHEN` or `EVERY`.

Predefined M functions

Predefined M functions generally must not be output in synchronized actions.

Exceptions: M3, M4, M5, M40, M41, M42, M43, M44, M45, M70 and M17

See also

Frequency (`WHENEVER`, `FROM`, `WHEN`, `EVERY`) (Page 906)

3.17.8.2 Reading and writing of system variables

The system variables of the NC are listed in the "System Variables" Parameter Manual with their respective properties. System variables that can be read or written in the action part of synchronized actions are marked with an "X" in the corresponding line (Read or Write) of the "SA" (synchronized action) column.

Note

System variables used in synchronized actions are implicitly read and written synchronous to the main run.

References:

System Variables Parameter Manual

3.17.8.3 Polynomial evaluation (SYNFCT)

Application

A variable that is evaluated via a polynomial can be read with the SYNFCT function in the main run and the result can be written to another variable. Application examples:

- Feedrate as a function of drive load
- Position as a function of a sensor signal
- Laser power as a function of path velocity

Syntax

SYNFCT (<Poly_No>, <SysVar_Out>, <SysVar_In>)

Meaning

Parameter	Meaning
<Poly_No>:	Number of the polynomial defined with FCTDEF: $f(x) = a_0 + a_1 \cdot x + a_2 \cdot x^2 + a_3 \cdot x^3$
<SysVar_Out>:	System variable, output: $\langle \text{SysVar_Out} \rangle = f(x)$
<SysVar_In>:	System variable, input: $x = \langle \text{SysVar_In} \rangle$
For information on FCTDEF, see Chapter "Polynomial coefficients, parameters (\$AC_FCT ...)" (Page 932)"	

Example: Additive override of the path feedrate

An override value is added to the programmed feedrate (F word):

3.17 Synchronized actions

$$F_{\text{active}} = F_{\text{programmed}} + F_{\text{AC}}$$

<SysVar_Out>	Meaning
\$AC_VC	additive path feedrate override
\$AA_VC[axis]	additive axial feedrate override

Input value is the actual current value \$AA_CURR of the X axis.

The operating point is set to 5 A.

The feedrate may be altered by ±100 mm/min and the axial current deviation may be ±1 A.




Figure 3-13 Example: Additive control of path feed

Determining the parameters of the FCTDEF function:

FCTDEF(<Poly_No>, <Lo_Limit>, <Up_Limit>, a_0, a_1, a_2, a_3)

<Poly_No>: = 1 (example)

<Lo_Limit>: = -100

<Up_Limit>: = 100

Polynomial: $f(x) = a_0 + a_1x + a_2x^2 + a_3x^3$

a_0 : $1 / 100 = 5 / a_0 \Rightarrow a_0 = 500$

a_1 = 100 mm/min / -1 A = -100 [mm/min / A]

a_2 = 0 (not a square component)

a_3 = 0 (not a cubic component)

Calculation of the override value:

SYNFCT(<Poly_No>, <SysVar_Out>, <SysVar_In>)

<Poly_No>: = 1

<SysVar_Out>: \$AC_VC (additive path feedrate override)

<SysVar_In>: \$AA_CURR (drive actual current value)

Programming:

Program code

```
N100 FCTDEF(1, -100, 100, 500, -100)
```

```

Program code
-----
N110 ID=1 DO SYNFACT(1, $AC_VC[X], $AA_CURR[X])

```

Example: Multiplicative override of the path feedrate

The programmed feedrate is multiplied by a percentage factor (additional override):

$$F_{\text{active}} = F_{\text{programmed}} * \text{Factor}_{\text{AC}}$$

<SysVar_Out>	Meaning
\$AC_OVR	Path override can be specified via synchronized action

Input value is the percentage drive load \$AA_LOAD of the X axis.

The operating point is set to 100% at 30% drive load.

The axis must stop at 80% load.

An excessive velocity corresponding to the programmed value +20% is permissible.




Figure 3-14 Example: Multiplicative control

Determining the parameters of the FCTDEF function:

```
FCTDEF(<Poly_No>, <Lo_Limit>, <Up_Limit>, a0, a1, a2, a3)
```

<Poly_No>: = 2 (example)

<Lo_Limit>: = 0

<Up_Limit>: = 120

Polynomial: $f(x) = a_0 + a_1x + a_2x^2 + a_3x^3$

a_0 : $50 / 100 = 80 / a_0 \Rightarrow a_0 = 160$

a_1 = 100 % / -50 % = -2

a_2 = 0 (not a square component)

a_3 = 0 (not a cubic component)

Calculation of the override value:

```
SYNFCT(<Poly_No>, <SysVar_Out>, <SysVar_In>)
```

<Poly_No>: = 2

3.17 Synchronized actions

<SysVar_Out>: \$AC_OVR (path override can be specified via synchronized action)
 <SysVar_In>: \$AA_LOAD (drive load)

Programming:

Program code

```
N100 FCTDEF(2, 0, 120, 160, -2)
N110 ID=1 DO SYNFACT(2, $AC_OVR[X], $AA_LOAD[X])
```

Example: Clearance control




Figure 3-15 Clearance control: Principle

The clearance control of the infeed axis Z is performed via the `FCTDEF` and `SYNFACT` functions as well as by the system variables `$AA_OFF` and `$A_INA`.

Supplementary conditions:

- The analog voltage of the clearance sensor is connected via the analog input `$A_INA[3]`.
- The position deviations are summated in `$AA_OFF` (integrated):
`MD36750 $MA_AA_OFF_MODE, bit 0 = 1`
- If the upper limit of the Z axis is exceeded by 1 mm, the X axis is stopped:
`SD43350 $SA_AA_OFF_LIMIT[Z] = 1`
 See also Chapter "Overlaid movements (`$AA_OFF`) (Page 934)."

Note

`$AA_OFF` is effective in the basic coordinate system (BCS)

The offset is effective before the kinematic transformation in the basic coordinate system (BCS). The example therefore **cannot** be used for a clearance control in the orientation direction of the tool (workpiece coordinate system WCS).

For clearance control system with high dynamic response or 3D clearance control, see:

References:

Function Manual Special Functions; Clearance Control (TE1)

Customized responses

When the limit value `SD43350 $SA_AA_OFF_LIMIT` is reached, customized responses can be triggered, for example:

- Chapter "Override (`$A...OVR`) (Page 925)"
 - Chapter "User-specific error reactions (SETAL) (Page 1004)"
-




Figure 3-16 Clearance control

Determining the parameters of the FCTDEF function:

FCTDEF(<Poly_No>,<Lo_Limit>,<Up_Limit>,a_0,a_1,a_2,a_3)

<Poly_No>: = 1 (example)

<Lo_Limit>: = 0.2

<Up_Limit>: = 0.5

Polynomial: $f(x) = a_0 + a_1x + a_2x^2 + a_3x^3$

a_0 : $10 / x = 20 / 0.3 \Rightarrow a_0 = x + 0.2 = 0.15 + 0.2 = 0.35$

a_1 = 0.15 mm / 10 V = $1.5 \cdot 10^{-2}$ mm/V

a_2 = 0 (not a square component)

a_3 = 0 (not a cubic component)

Calculation of the override value:

SYNFCT(<Poly_No>,<SysVar_Out>,<SysVar_In>)

<Poly_No>: = 1

<SysVar_Out>: \$AA_OFF (overlaid movement of an axis)

<SysVar_In>: \$A_INA (analog input)

Programming:

Program code: %_N_AON_SPF	Comment
PROC AON	; Clearance control "ON"
FCTDEF(1, 0.2, 0.5, 0.35, 1.5 EX-2)	; Polynomial definition
ID=1 DO SYNFCT(1,\$AA_OFF[Z],\$A_INA[3])	; Clearance control
ID=2 WHENEVER \$AA_OFF_LIMIT[Z]<>0 DO \$AA_OVR[X] = 0	; Limit value test
RET	
ENDPROC	

Program code: %_N_AOFF_SPF	Comment
PROC AOFF	; Clearance control "OFF"
CANCEL(1)	; Delete clearance control
CANCEL(2)	; Delete limit value check
RET	

3.17 Synchronized actions

Program code: %_N_AOFF_SPF	Comment
ENDPROC	

Program code: %_N_MAIN_MPF	Comment
N100 \$SA_AA_OFF_LIMIT[Z]=1	
N110 AON	; Clearance control "ON"
...	
N200 G1 X100 F1000	
N210 AOFF	; Clearance control "OFF"
M30	

See also

Online tool offset (FTOC) (Page 962)

3.17.8.4 Online tool offset (FTOC)

The FTOC function enables the overlaid movement of a geometry axis for the online tool offset, depending on a reference value, e.g. the actual value of an arbitrary axis. The offset value is calculated on the basis of a polynomial defined with `FCTDEF` (see Section "Polynomial coefficients, parameters (\$AC_FCT ...) (Page 932)"). The coefficient a_0 specified in the polynomial definition is also evaluated by `FTOC`.

Example: Machining and dressing in the "Grinding" technology




Figure 3-17 Dressing during machining using a dressing roller

References:

Function Manual, Extended Functions; Grinding (W4)

Syntax

FTOC (<Poly_No>, <Systemvar>, <Wear>[, <Channel_No>, <Spindle_No>])

Meaning

Parameter	Meaning
<Poly_No>:	Number of the polynomial defined with FCTDEF
<Systemvar>:	Arbitrary system variable of the REAL type that can be used in synchronized actions.
<Wear>:	Wear parameter (length 1, 2 or 3) in which the offset value is added .
<Channel_No>:	Target channel in which the offset must be applied. This enables simultaneous dressing from a parallel channel. In the target channel of the offset, the online offset must be switched on with FTOCON. If no channel number is programmed, the offset acts in the active channel.
<Spindle_No>:	The spindle number is programmed if a non-active grinding wheel needs to be dressed. Requirement: One of the following functions is active <ul style="list-style-type: none"> • "Constant grinding wheel peripheral speed" • "Tool monitoring" If no spindle number is programmed, the active tool is compensated.

Example

Compensate length of an active grinding wheel

Program code	Comment
FCTDEF(1, -1000, 1000, -\$AA_IW[V], 1)	
; FTOC:	
; Polynomial no.: 1	
; System variable: \$AA_IW[V] (axial actual value of the V axis)	
; Wear parameter: Length 3	
; Target channel: Channel 1	
ID=1 DO FTOC(1, \$AA_IW[V], 3, 1)	
WAITM (1,1,2)	; Synchronization with the machining channel
G1 V-0.05 F0.01 G91	; Traversing motion of the V axis
...	
CANCEL(1)	; Deselect online offset
...	

Note

Because no frequency and no condition has been specified in the synchronized action, the action part is executed in every interpolator clock cycle.

3.17.8.5 Programmed read-in disable (RDISABLE)

Function

The `RDISABLE` command in the active section causes block processing to be stopped when the relevant condition is fulfilled. Processing of programmed motion-synchronous actions still continues. The read-in disable is canceled again as soon as the condition for the `RDISABLE` is no longer fulfilled.

An exact stop is initiated at the end of the block containing `RDISABLE` irrespective of whether or not the read-in disable is still active. The exact stop is also triggered if the control is in the continuous-path mode (G64, G641 ... G645).

`RDISABLE` can be programmed with reference to the block or also modal (`ID=`, `IDS=`)!

Application

Using `RDISABLE`, for example, the program can be started in the interpolator clock cycle as a function of external inputs.

Example

Program code	Comment
WHENEVER \$A_INA[2]<7000 DO RDISABLE	; Program processing is stopped if the voltage at input 2 drops to below 7 V (assuming that the value 1000 corresponds to 1 V).
...	
N10 G01 X10	; RDISABLE acts at the end of N10, if the condition is fulfilled during its processing.
N20 Y20	
...	

Supplementary conditions

Read-in disable RDISABLE in conjunction with axis exchange

Acts via the synchronized actions `RDISABLE` read-in disable and axis exchange (e.g. path axis → positioning axes) together in one block, `RDISABLE` does not act on the action block, but the re-approach block `REPOSA` implicitly generated as a result of the axis exchange:

Program code	Comment
N100 G0 G60 X300 Y300	
N105 WHEN TRUE DO POS[X]=20 FA[X]=20000	; Synchronized action → REORG → REPOSA
N110 WHENEVER \$AA_IM[X]<>20 DO RDISABLE	; RDISABLE acts on REPOSA
N115 G0 Y20	; 1. X-axis, 2nd Y axis
N120 Y-20	
N125 M30	

Path axis X becomes a positioning axis as a result of the synchronized action in the block N105. `REORG` is therefore executed in the channel with `REPOSA`. Therefore, `RDISABLE` in N110 does

not act on block N115 – but instead on the internal REPOSA block. As a consequence, to start, positioning axis X is traversed to its programmed position and then in block N115, the Y axis to its programmed position.

An explicit release of path axis X before traversing as positioning axis (synchronized action in N105) with `RELEASE (X)` avoids the REORG operation, and the X and Y axes traverse together in block N115.

Program code	Comment
N100 G0 G60 X300 Y300	
N101 RELEASE (X)	; Explicit release
N105 WHEN TRUE DO POS[X]=20 FA[X]=20000	
...	

3.17.8.6 Cancel preprocessing stop (STOPREOF)

With the `STOPREOF` command, an existing preprocessing stop can be cancelled from a synchronized action.

Note

The `STOPREOF` command can only be programmed in non-modal synchronized actions (without specification of ID or IDS) and only in conjunction with the scanning frequency `WHEN`.

Example

- N10: Non-modal synchronized action.
If the path distance-to-go `$AC_DTEB` is less than 5 mm, the existing preprocessing stop due to the reading of the analog input `$A_INA` is cancelled.
- N20: Traversing block whose path distance-to-go is evaluated via `$AC_DTEB`.
- N30: Branch that triggers the preprocessing stop due to the reading of `$A_INA`.

Due to the synchronized action, input `$A_INA` is not evaluated at the end of the N20 block, but already 5 mm before the end of the block. If the voltage is then greater than 5 V at input `$A_INA`, there is a branch to "MARKE_1".

Program code
N10 WHEN <code>\$AC_DTEB < 5</code> DO <code>STOPREOF</code>
N20 G01 X100
N30 IF <code>\$A_INA[7] > 5000</code> GOTO <code>MARKE_1</code>

3.17.8.7 Delete distance-to-go (DELDTG)

The path distance-to-go can be deleted with the `DELDTG` command and axial distances-to-go can be deleted with the `DELDTG (. . .)` function in synchronized actions.

After deletion of the distance-to-go, the value of the deleted distance-to-go can be read via a system variable:

- Path distance-to-go: \$AC_DELT
- Axial distance-to-go: \$AA_DELT

Syntax

```
DELDTG
```

```
DELDTG (<axis 1>[,<axis 2>, ... ])
```

Meaning

Parameter	Meaning
DELDTG	Deletion of the path distance-to-go
DELDTG (...)	Deletion of the axial distances-to-go of the specified channel axes
<Axis n>:	Channel axis

Supplementary conditions

Path-specific and axial delete distance-to-go

Path-specific and axial delete distance-to-go can only be executed in a **non-modal** synchronized action (without specification of ID or IDS).

Path-specific delete distance-to-go

- The deletion of the path distance-to-go can only be executed in a non-modal synchronized action (without specification of ID or IDS).
- The deletion of the path distance-to-go must **not** be used with active tool radius compensation.

Axial delete distance-to-go

Delete distance-to-go for indexing axes:

- **Without** Hirth tooth system: The axis is braked immediately
- **With** Hirth tooth system: The axis traverses to the next indexing position

Examples

Delete path distance-to-go

If the input \$A_IN is set during the traversing block N20, the path distance-to-go is deleted.

Program code

```
N10 WHEN $A_IN[1]==1 DO DELDTG
N20 G01 X100 Y100 F1000
```

Delete axial distances-to-go

N10: If input 1 is set at any time within the part program, the V axis is started as a positioning axis in the positive traversing direction.

N100: Non-modal synchronized action to delete distance-to-go of the V axis, depending on digital input 2.

N110: Non-modal synchronized action to delete distance-to-go of the X1 axis, depending on digital input 3.

N120: The X1 axis is positioned modally. The Y and Z axes are traversed as path axes. The non-modal synchronized actions from N100 and N110 are executed together with N120. The non-modal synchronized actions are also terminated with the end of block N120.

For this reason, the distances-to-go of the X1 and V axes can only be deleted as long as N120 is active.

Program code
N10 ID=1 WHEN \$A_IN[1]==1 DO MOV[V]=1 FA[V]=700
...
N100 WHEN \$A_IN[2]==1 DO DELDTG(V)
N110 WHEN \$A_IN[3]==1 DO DELDTG(X1)
N120 POSA[X1]=100 FA[X1]=10 G1 Y100 Z100 F1000

3.17.8.8 Traversing axes, to position (POS)

With the POS command, an axis can be traversed using a synchronized action. The axis is then called the command axis. It is possible to traverse the axis alternating via the part program and the synchronized action. If a command axis traversed via synchronized actions is subsequently traversed via the part program, a preprocessing stop with reorganization (STOPRE) is executed in the channel of the part program.

Example 1: Alternate traversing via part program and synchronized action

Program code	Comment
N10 G01 x100 Y200 F1000	; Traversing via part program
...	
; Traversing via static synchronized action when input 1 is set	
N20 ID=1 WHEN \$A_IN[1]==1 DO POS[X]=150 FA[X]=200	
...	
CANCEL(1)	; Deselect synchronized action
...	
; Traversing again via part program => implicit preprocessing stop	
; with reorganization, if the X axis in the meantime has been	
; traversed via synchronized action	
N100 G01 x240 Y200 F1000	

Example 2: Alternate traversing of the X-axis via two synchronized actions

3.17 Synchronized actions

If the traversing motion of one synchronized action is still active when the traversing motion of the other synchronized action is started, the second traversing motion replaces the first.

Program code

```
; 1st Traversing motion
ID=1 EVERY $A_IN[1]>=1 DO POS[V]=100 FA[V]=560
; 2nd Traversing motion
ID=2 EVERY $A_IN[2]>=1 DO POS[V]=$AA_IM[V] FA[V]=790
```

Dimensions: Absolute/incremental

The commands G90/G91 to specify the dimensions (absolute/incremental) cannot be programmed in synchronized actions. Therefore by default, the dimensions that were active in the part program at the time of execution of the synchronized action are also effective in the synchronized action.

The following commands can be programmed in the action part to specify the dimensions within a synchronized action:

Command	Meaning
IC (...)	Incremental
AC (...)	Absolute
DC (...)	Direct (position rotary axis via shortest route)
ACN (...)	Position modulo rotary axis absolutely in negative direction of motion
ACP (...)	Position modulo rotary axis absolutely in positive direction of motion
CAC (...)	Traverse axis to coded position absolutely
CIC (...)	Traverse axis to coded position incrementally
CDC (...)	Traverse rotary axis to coded position via shortest route
CACN (...)	Traverse modulo rotary axis to coded position in negative direction
CACP (...)	Traverse modulo rotary axis to coded position in positive direction

Examples:**Program code**

```
; Incremental traversing by 10 mm
ID=1 EVERY G710 $AA_IM[B]>75 DO POS[X]=IC (10)
...
; Absolute traversing
ID=1 EVERY G710 $AA_IM[B]>75 DO POS[X]=AC ($AA_MW[V]-$AA_IM[W]+13.5)
```

Behavior with active axis-specific frames

Whether programmable and settable axis-specific frames and tool length compensations are included in synchronized actions, depends on the following MD setting:

MD32074 \$MA_FRAME_OR_CORRPOS_NOTALLOWED

Bit	Value	Meaning
9	0 (default)	The active axis-specific frame and/or tool length compensation which is active in the part program at the time of execution takes effect in the synchronized action which is executed parallel to the part program.
	1.	Axis-specific frames and tool length compensation are not considered for command axes.

Example 1: Traversing with **active** frames / tool length compensations (bit 9 == 0):

Program code	Comment
N100 TRANS X20	; Zero offset in X: 20 mm.
; Synchronized action: The X axis traverses to position 60 mm	
IDS=1 EVERY G710 \$A_IN==1 DO POS[X]=40	
...	
; Zero offset in X: -10 mm. =>	
; Synchronized action: The X axis now traverses to position 30 mm	
N130 TRANS X-10	
...	

Example 2: Traversing with **deactivated** frames / tool length compensations (bit 9 == 1):

Program code	Comment
N100 TRANS X=0.001	; Zero offset in X: 0.001 degrees
N120 POS[X]=270	; X traverses to position 270.001 degrees
...	
; With \$A_IN=1, X traverses to position 180.000 degrees.	
IDS=1 EVERY G710 \$A_IN==1 DO POS[X]=180	
...	
; X traverses to position 90.001 degrees	
N130 POS[X]=90	
...	
; Coded position 1 = 100 degrees => X traverses to 100.001 degrees	
N140 POS[X]=CAC(1)	
...	
; Coded position 2 = 200 degrees => X traverses to 200.000 degrees	
N150 POS[X]=CIC(1)	

Note

If a command axis travels to indexing positions incrementally, the axis-specific frames have **no** effect on this command axis.

Non-modal suppression of the active frame with G153

If MD32074 is set so that active axis-specific frames and tool offsets always have to be taken into account for command axes (bit 9 == 0), the active frame can be suppressed in a non-modal synchronized action, if necessary, with G153. For this purpose, the block must be turned into

3.17 Synchronized actions

an executable block with the G153 command via program code G4 F0.1. In this case, it must be ensured that the dwell time is at least 0.1. This is the only way to ensure that the processing time in the interpolator is sufficient.

Examples:

```

...
WHEN TRUE DO POS[Z]=401 FA[Z]=$MA_MAX_AX_VELO[Z]
G153 G4 F0.1
...

```

```

...
WHILE $AA_IM[Z]<400
ENDWHILE
WHEN TRUE DO POS[Z]=400
G153 G4 F0.1
...

```

Takeover of the control of a command axis by the PLC

The control of a command axis that has been started via a static synchronized action (IDS) is taken over by the PLC irrespective of the status of the part program containing the synchronized action:

DB31, ... DBX28.7 == 1 (request for PLC to control axis)

References:

Function Manual, Extended Functions; Chapter "P2: positioning axes"

Parameterizable axis status

The behavior with regard to the axis status after the end of the part program and NC Reset can be parameterized via the following machine data:

MD30450 \$MA_IS_CONCURRENT_POS_AX[<axis>] = <value>

<value>	Axis status before PP end / NC RESET ¹⁾	Axis status after PP end / NC RESET ¹⁾
0.	Channel axis	Channel axis
0.	Command axis	Channel axis
1.	Channel axis	Command axis
1.	Command axis	Command axis

¹⁾ PP end: Part program end

See also

Technology cycles (Page 1006)

3.17.8.9 Setting the measuring system (G70, G71, G700, G710)

If a specific measuring system (inch/metric) is not explicitly defined in a synchronized action with G70, G71, G700, G710, the measuring system active in the part program at the time the synchronized action is executed takes effect:

- G70/G71 active in the part program:
 - All the **programmed** position values are interpreted in the **programmed** measuring system.
 - All the **read** position data is interpreted in the **parameterized basic system**.
- G700/G710 active in the part program:
 - All the **programmed** position values are interpreted in the **programmed** measuring system.
 - All the **read** position data is interpreted in the **parameterized basic system**.

The following rules apply when defining the measuring system in the synchronized action:

- If a measuring system is programmed in the condition part, this also takes effect in the action part if a measuring system has not been specifically programmed there.
- If there is only a measuring system programmed in the action part, the system which is currently activated in the part program takes effect in the condition part.
- Different systems of units can be programmed in the condition and action parts.
- The measuring system programmed in the synchronized action has no effect on the part program.

Example

Program code	Comment
N10 ID=1 EVERY \$AA_IM[Z]>200 DO POS[Z2]=10	; \$AA_IM: # ; 200: # ; 10: #
N20 ID=2 EVERY \$AA_IM[Z]>200 DO G70 POS[Z2]=10	; \$AA_IM: # ; 200: # ; 10: inch
N30 ID=3 EVERY G71 \$AA_IM[Z]>200 DO POS[Z2]=10	; \$AA_IM: # ; 200: mm ; 10: mm
N40 ID=4 EVERY G71 \$AA_IM[Z]>200 DO G70 POS[Z2]=10	; \$AA_IM: # ; 200: mm ; 10: inch
N50 ID=5 EVERY \$AA_IM[Z]>200 DO G700 POS[Z2]=10	; \$AA_IM: # ; 200: # ; 10: inch
N60 ID=6 EVERY G710 \$AA_IM[Z]>200 DO POS[Z2]=10	; \$AA_IM: mm ; 200: mm ; 10: mm
N70 ID=7 EVERY G710 \$AA_IM[Z]>200 DO G700 POS[Z2]=10	; \$AA_IM: mm ; 200: mm ; 10: inch

3.17 Synchronized actions

Program code	Comment
#:	The unit depends on the parameterized basic system (MD10240 \$MN_SCALING_SYS-TEM_IS_METRIC) and the measuring system programmed in the part program

Note

Measuring system and technology cycles

If a technology cycle is being used, the measuring system can also be programmed in the technology cycle instead of the measuring system having to be assigned in the action part of the synchronized action.

3.17.8.10 Position in specified reference range (POSRANGE)

Function

The POSRANGE function can be used to determine whether the current position of an axis is within the tolerance range around a specified reference position.

Note

With modulo axes, the modulo offset is taken into account.

Syntax

<Status> POSRANGE (<axis>, <RefPos>, <tolerance>, [<CoordSys>])

Meaning

<status>	Function return value Type: BOOL TRUE: The current position of the axis is within the tolerance range. FALSE: The current position of the axis is not within the tolerance range.
<axis>	Name of the channel axis Type: AXIS
<RefPos>	Reference position Type: REAL
<Tolerance>	Permissible tolerance around the reference position Type: REAL The tolerance is specified as an absolute value. The tolerance range results from: Reference position +/- tolerance

<code><CoordSys></code>	Optional: Coordinate system Type: INT Range of values: 0 = MCS (machine coordinate system) 1 = BCS (basic coordinate system) 2 = SZS (settable zero system) 3 = WCS (workpiece coordinate system)
-------------------------------	---

3.17.8.11 Traversing axes, endless (MOV)

Function

An axis can be traversed endlessly, i.e. without specifying an end position, in a specific direction via the `MOV` command. The axis traverses so long in the specified direction until it is stopped or another traversing direction is specified by a `MOV` command.

Application example: Endlessly rotating rotary axes

Syntax

```
MOV[<axis>] = <direction>
```

Meaning

<code>MOV</code>	Traversing command for a command axis
<code><axis></code>	Channel axis name Type: AXIS
<code><Direction></code>	Traversing direction Type: INT Range of values: <ul style="list-style-type: none"> > 0: Positive traversing direction (default: +1) < 0: Negative traversing direction (default: -1) = 0: Stop

Note

Indexing axis

If an indexing axis is stopped with `MOV[<indexing axis>] = 0`, it stops at the next indexing position.

Technology cycle

The `MOV` command must **not** be used in technology cycles.

See also

Axial feedrate (FA) (Page 974)

3.17.8.12 Axial feedrate (FA)

An axial feedrate can be specified in a synchronized action via the `FA` command. The axial feedrate is modal.

Examples

Constant feedrate value:

Program code

```
ID=1 EVERY $AA_IM[B]>75 DO POS[U]=100 FA[U]=990
```

Variable feedrate value:

Program code

```
ID=1 EVERY $AA_IM[B] > 75 DO POS[U]=100 FA[U]=$AA_VACTM[W]+100  
IDS=2 WHENEVER $A_IN[1] == 1 DO POS[X]=100 FA[X]=$R1
```

Remarks

- The default value for the feedrate of positioning axes is set via axial machine data: MD32060 \$MA_POS_AX_VELO (initial setting for positioning axis velocity)
- The axial feedrate can be specified as a linear or revolutional feedrate. The feedrate type can be set via the setting data: SD43300 \$SA_ASSIGN_FEED_PER_REV_SOURCE (revolutional feedrate for positioning axes / spindles)
- The feedrate type can be switched synchronous to the part program via the `FPRAON` and `FPRAOF` commands. Refer to:

References:

/FB1/ Function Manual Basic Functions; Feedrates (V1)

Note

So that technology cycles executed in parallel do not obstruct each other, the axial feedrate from synchronized actions is not output as an auxiliary function to the NC/PLC interface.

See also

Traversing axes, endless (MOV) (Page 973)

3.17.8.13 Axis replacement (GET, RELEASE, AXTOCHAN)

Command axes can be interchanged between channels via the `GET`, `RELEASE` and `AXTOCHAN` commands.

Requirement

The command axis that is interchanged between the channels must be known and parameterized as command axis in the respective channel.

Programming

Syntax

```
GET(<axis 1> [{, <axis n>}])  
RELEASE((<axis 1> [{, <axis n> }]))  
AXTOCHAN(<axis 1>, <channel number 1> [{, <axis n>, <channel number  
n> }])
```

Meaning

GET:	Request to replace an axis in the same channel
RELEASE:	Release of an axis for an axis replacement
AXTOCHAN:	Request for an axis for replacement in the specified channel
<Axis n>:	Machine axis name
	Type: AXIS
	Range of values: Machine axis names defined in the channel
<channel number n>:	Channel number
	Type: INTEGER
	Range of values: 1 ... maximum channel number

Axis type and axis status regarding axis replacement

The axis type and axis status currently valid at the time of the synchronized action activation can be queried via the \$AA_AXCHANGE_TYP or \$AA_AXCHANGE_STAT system variable. Depending on the channel that has the current interpolation authorization for this axis and depending on the status for the permissible axis replacement, a different sequence results from the synchronized action.

An axis can be requested with GET from a synchronized action, if

- Another channel has the write or interpolation authorization for the axis
- The requested axis is already assigned to the requested channel
- The axis in the neutral axis state is controlled by the PLC
- The axis is a command axis, oscillating axis, or concurrent PLC axis
- The axis is already assigned to the NC program of the channel

Note

Supplementary condition: An "axis controlled exclusively by the PLC" or a "permanently assigned PLC axis" cannot be assigned to the NC program.

An axis can be released from a synchronized action with `RELEASE`, if the axis:

- Was previously assigned to the NC program of the channel.
- Is already in the neutral axis state.
- Already has another channel that has the interpolation authorization of this axis

Request axis from another channel

If, when the `GET` action is activated, **another channel** has the interpolation authorization for the axis `$AA_AXCHANGE_TYP[axis] == 2`, axis replacement is used to fetch the axis from this channel `$AA_AXCHANGE_TYP[axis] == 6` and assign it to the requesting channel as soon as possible. The axis then becomes the **neutral axis** (`$AA_AXCHANGE_TYP[axis]==3`).

The state change to a neutral axis does **not** result in reorganization in the requesting channel.

Requested axis was already requested as neutral axis:

`$AA_AXCHANGE_TYP[axis]==6`, the axis is required for the NC program `$AA_AXCHANGE_TYP[axis] == 5` and assigned as soon as possible to the NC program of the channel `$AA_AXCHANGE_TYP[axis] == 0`.

Note

This assignment **results in a reorganization**.

Axis is already assigned to the requested channel

If the requested axis has already been assigned **to this channel** at the point of activation, and its status is that of a neutral axis not controlled by the PLC `$AA_AXCHANGE_TYP[axis]==3`, it is assigned to the NC program `$AA_AXCHANGE_TYP[axis]==0`.

This **results in a reorganization procedure**.

Axis in the state of the neutral axis is controlled from the PLC

If the axis in neutral axis state is **controlled by the PLC** `$AA_AXCHANGE_TYP[axis]==4`, the axis is requested as a neutral axis `$AA_AXCHANGE_TYP[axis] == 8`. This disables the axis for automatic axis replacement between channels (Bit 0 == 0) in accordance with the value of bit 0 in machine data:

MD10722 `$MN_AXCHANGE_MASK` (parameterization of the axis replacement behavior)

This corresponds to `$AA_AXCHANGE_STAT[axis] == 1`.

Axis is active as command axis / assigned to the PLC

If the axis is active as a command axis or oscillating axis or a concurrent positioning axis (PLC axis) (`$AA_AXCHANGE_TYP[<axis>] == 1`), the axis is requested as a neutral axis (`$AA_AXCHANGE_TYP[<axis>] == 8`). Depending on the setting in the following machine data, the axis is blocked for an automatic axis replacement between channels:

MD10722 `$MN_AXCHANGE_MASK` (parameterization of the axis replacement behavior)

This corresponds to $\$AA_AXCHANGE_STAT[<axis>] == 1$.

With a further `GET` request, the axis is then requested for the NC program \Rightarrow $\$AA_AXCHANGE_TYP[axis] == 7$.

Axis already assigned to the NC program of the channel

If the axis is already assigned to the NC program of the channel ($\$AA_AXCHANGE_TYP[<axis>] == 0$) or if this assignment is requested, e.g. axis replacement triggered by the NC program ($\$AA_AXCHANGE_TYP[<axis>] == 5$ or $\$AA_AXCHANGE_TYP[<axis>] == 7$), there is **no** state change.

Release axis for axis replacement

If the axis is assigned to the NC program at the time of release ($\$AA_AXCHANGE_TYP[<axis>] == 0$), it is transferred to the neutral axis state ($\$AA_AXCHANGE_TYP[<axis>] == 3$) and if required, released for axis replacement in another channel.

This **results in a** reorganization procedure.

Axis to be released is already a neutral axis:

If the axis is already in the neutral axis state ($\$AA_AXCHANGE_TYP[<axis>] == 3$) or active as command or oscillating axis or assigned to the PLC as concurrent positioning axis ($\$AA_AXCHANGE_TYP[<axis>] == 1$), the axis is released for an automatic axis replacement between channels.

$\$AA_AXCHANGE_STAT[<axis>]$ is reset from 1 to 0 if there is no other reason to link the axis to the channel. Such a link of the axis is present, for example, with:

- Active axis coupling
- Active fast retraction
- Active transformation
- JOG request
- Rotating frame with PLC, command or oscillating axis motion

Another channel already has the interpolation authorization

If another channel already has the interpolation authorization ($\$AA_AXCHANGE_TYP[<axis>] == 2$), there is no state change. This also means that waiting for an axis, triggered by NC program ($\$AA_AXCHANGE_TYP[<axis>] == 5$) or a previous `GET` request from a synchronized action ($\$AA_AXCHANGE_TYP[<axis>] == 6$) cannot be aborted by a `RELEASE` from a synchronized action.

Supplementary conditions

- If several `GET` and `RELEASE` requests are programmed for the same axis, they may mutually cancel each other under certain circumstances and only the last respective requests are performed.
Example:

3.17 Synchronized actions

Programming: GET(X,Y) RELEASE(Y,Z) GET(Z)

Execution: GET(X) RELEASE(Y) GET(Z)

- If further commands are programmed in the action part of a synchronized action in addition to GET/RELEASE, there is no waiting period until the GET/RELEASE request is completed before these commands are executed. This can lead to an error if, for example, an axis requested for the positioning motion with GET is not yet available:
GET[<axis>] POS[<axis>]

Example 1: GET and RELEASE as action in synchronized actions in two channels

Requirement: The Z axis must be known in the 1st and 2nd channels

1. Program sequence in the first channel:

Program code	Comment
WHEN TRUE DO RELEASE(Z)	; Z axis becomes neutral
; Read-in disable as long as Z axis is program axis	
WHENEVER \$AA_TYP[Z] == 1 DO RDISABLE	
N110 G4 F0.1	
...	
; Z axis returns to status as NC program axis	
WHEN TRUE DO GET(Z)	
; Read-in disable until Z axis is program axis	
WHENEVER(\$AA_TYP[Z]<>1) DO RDISABLE	
N120 G4 F0.1	
...	
WHEN TRUE DO RELEASE(Z)	; Z axis becomes neutral
; Read-in disable as long as Z axis is program axis	
WHENEVER \$AA_TYP[Z] == 1 DO RDISABLE	
N130 G4 F0.1	
...	
N140 START(2)	; Start 2nd channel
N150	; See below: "3. Continuation: Program sequence in the first channel"

2. Program sequence in the second channel:

Program code	Comment
WHEN TRUE DO GET(Z)	; Move Z axis to second channel (neutral)
; Read-in disable as long as Z axis is in other channel	
WHENEVER \$AA_TYP[Z] == 0 DO RDISABLE	
N210 G4 F0.1	
...	
WHEN TRUE DO GET(Z)	; Z axis is NC program axis
; Read-in disable until Z axis is program axis	
WHENEVER(\$AA_TYP[Z]<>1) DO RDISABLE	
N220 G4 F0.1	

Program code	Comment
...	
WHEN TRUE DO RELEASE(Z)	; Z axis in second channel is neutral axis
; Read-in disable as long as Z axis is program axis	
WHENEVER \$AA_TYP[Z] == 1 DO RDISABLE	
N230 G4 F0.1	
...	
N250 WAITM(10,1,2)	;Synchronize with channel 1
N999 M30	

3. Continuation: Program sequence in the first channel:

Program code	Comment
N150 WAITM(10,1,2)	;Synchronize with channel 2
...	
WHEN TRUE DO GET(Z)	;Move Z axis to this channel
; Read-in disable as long as Z axis is in other channel	
WHENEVER \$AA_TYP[Z] == 0 DO RDISABLE	
N160 G4 F0.1	
...	
N199 WAITE(2)	;Wait for end of program in channel 2
N999 M30	

Transfer axis to another channel (AXTOCHAN)

An axis can be requested for an arbitrary channel from a synchronized action with the AXTOCHAN command.

If the axis is already assigned to the NC program of the channel (\$AA_AXCHANGE_TYP[<axis>] == 0), there is **no** state change.

If an axis is requested for the same channel from a synchronized action, AXTOCHAN is mapped on the GET command.

- With the **first** request for the same channel, the axis becomes a neutral axis.
- With the **second** request, the axis is assigned to the NC program.

Supplementary condition

A "PLC-controlled axis" corresponds to a "concurrent positioning axis" where special supplementary conditions must be carefully observed. For further details, see:

References:

/FB2/ Function Manual, Extended Functions; Positioning Axes (P2)

Note

A PLC axis cannot replace the channel.

An axis controlled exclusively by the PLC cannot be assigned to the NC program.

3.17.8.14 Traversing spindles (M, S, SPOS)

Spindles can be started, positioned and stopped via synchronized actions. The programming is performed in the action part of the synchronized action with the same syntax as in the part program. Without numeric extension the commands for the master spindle apply. By specifying a numeric extension, it is possible to program each spindle individually:

Program code	Comment
ID = 1 EVERY \$A_IN[1]==1 DO M3 S1000	; Master spindle
ID = 2 EVERY \$A_IN[2]==1 DO SPOS=270	; Master spindle
ID = 1 EVERY \$A_IN[1]==1 DO M1=3 S1=1000 SPOS[2]=90	

If concurrent commands are specified for a spindle through synchronized actions that are active in parallel, the chronological sequence decides the activation.

User-specific spindle enable

The start of spindle motions at defined times can be achieved via synchronized actions by blocking the motion programmed in the part program.

Example:

The spindle is programmed within a part program and should not start at the beginning of the block, but only when input 1 is set. The synchronized action holds the spindle override at 0% until the enable via input 1. See Section "Override (\$A...OVR) (Page 925)".

Program code
; As long as input 1 is not set => spindle override = 0%
ID=1 WHENEVER \$A_IN[1]==0 DO \$AA_OVR[S1]=0
...
; The start of the spindle is triggered
; The spindle is enabled when input 1 is set
G01 X100 F1000 M3 S1=1000

Transition between command axis and spindle

Since several synchronized actions can be active simultaneously, the situation may arise where a spindle motion is started when the spindle is already active. In this case, the most recently activated motion is applicable. At a reversal in the direction of motion, the spindle is first braked and then traversed in the opposite direction.

Direction of rotation, speed and position can also be changed during the motion.

Examples

Program code	Comment
ID=1 EVERY \$AC_TIMER[1] >= 5 DO M3 S300	; Speed and direction of rotation
ID=2 EVERY \$AC_TIMER[1] >= 7 DO M4 S500	; Speed and direction of rotation
ID=3 EVERY \$A_IN[1]==1 DO S1000	; Speed
ID=4 EVERY (\$A_IN[4]==1) AND (\$A_IN[1]==0) DO SPOS=0	; Spindle positioning

Transitions between axis and spindle

In state ↓	To →	POS	MOV<>0	MOV=0	SPOS	M3/M4	M5	LEADON	TRAIL ON
during traversing									
Axis		x	x	x	x	x	x	x	x
Position-controlled spindle		x	x	x	x	x	x	-	-
Speed-controlled spindle		-	-	-	x	x	x	-	-
in motion									
Axis		x	x	x	-	-	-	x	x
Position-controlled spindle		-	-	-	-	-	-	-	-
Speed-controlled spindle		-	-	-	x	x	x	-	-
Transitions marked with x are permitted: The transitions marked with - are rejected with an alarm.									

See also

Couplings (CP..., LEAD..., TRAIL..., CTAB...) (Page 994)

3.17.8.15 Withdrawing the enable for the axis container rotation (AXCTSWEC)

Function

Using the command `AXCTSWEC` an already issued enable signal to rotate the axis container can be withdrawn again. The command triggers a preprocessing stop with reorganization (`STOPRE`).

The following conditions must be fulfilled so that in the channel, the enable signal to rotate the axis container is withdrawn again:

- In the channel, the axis container rotation must already have been enabled:
 - `AXCTSWE(<container>)`
 - `$AC_AXCTSWA[<container>] == 1`
- Axis container rotation was still not started:
 - `$AN_AXCTSWA[<container>] == 0`

As feedback signal for the successful withdrawal of the enable signal, the following channel-specific system variable is reset:

```
$AC_AXCTSWA[<container>] == 0
```

For a detailed description of the system variables, refer to:

References:

Parameter Manual System Variables

Syntax

```
DO AXCTSWEC(<container>)
```

Meaning

- AXCTSWEC: Withdrawing the enable for the axis container rotation for the channel
- <Container>: Name of axis container:
 Possible data include:
- CT<container number>:
 The number of the axis container is attached to the CT letter combination. Example: CT3
 - <container name>:
 Individual name of the axis container set using MD12750 \$MN_AXCT_NAME_TAB. Example: A_CONT3
 - <Axis name>:
 Axis name of a container axis known in the channel.

Example

Program code	Comment
; Initialization of the global counter for the technology cycle CTSWEC	
N100 \$AC_MARKER[0]=0	
N110 ID=1 DO CTSWEC	; For technology cycle CTSWEC, see below.
NEXT:	
N200 G0 X30 Z1	
N210 G95 F.5	
N220 M3 S1000	
N230 G0 X25	
N240 G1 Z-10	
N250 G0 X30	
N260 M5	
; Enable of the axis container rotation for container spindle S1.	
N270 AXCTSWE(S1)	
N200 GOTO NEXT	

Program code	Comment
PROC CTSWEC(STRING _ex_CT="CT1"	
INT _ex_CTs1_BITmask=1H	
INT _ex_CT_SL_Number=1	
INT _ex_WAIT_number_of_IPOs=1000	
) DISPLOF ICYCOF	
DEFINE _ex_number_of_IPOs AS \$AC_MARKER[0]	
IF (\$AC_STOP_COND[0] + \$AC_STOP_COND[1] + \$AC_STOP_COND[2] + \$AC_STOP_COND[3] +	
\$AC_STOP_COND[4] + \$AC_STOP_COND[5] + \$AC_STOP_COND[6] + \$AC_STOP_COND[7] +	
\$AC_STOP_COND[8] + \$AC_STOP_COND[9] + \$AC_STOP_COND[10]) > 0)	
; Increment IPO cycle counter	
_ex_number_of_IPOs = _ex_number_of_IPOs + 1	

Program code	Comment
<pre> ; If a stop condition for longer than "_ex_WAIT_number_of_IPOs" ; IPO cycles is present AND its own slot has not been enabled IF (_ex_number_of_IPOs >= _ex_WAIT_number_of_IPOs) AND (\$AN_AXCTSWEC[_ex_CT] == _ex_CTsl_BITmask) AXCTSWEC ENDIF ELSE ; Reset IPO cycle counter _ex_number_of_IPOs = 0 ENDIF RET </pre>	<pre> ; Cancel the enable of the axis container rotation. </pre>

Supplementary condition

Time of execution of synchronized actions

Program code
<pre> ; Enable of the axis container rotation. N10 AXCTSWE(CT3) ; Traversing of the container axis AX_A => before the axis is traversed, there ; is a waiting period for the end of the axis container rotation: \$AN_AXCTSWA[CT3]==0 N20 AX_A = 10 ; Cancellation of the enable. No effect! WHEN <condition> DO AXCTSWEC(AX_A) N30 G4 F1 </pre>

Because after the enable of the axis container rotation in block N10, an axis of the axis container (AX_A) is used in block N20 and this use leads to the system waiting for the end of the axis container rotation, the synchronized action only comes together with the program block N30 in the main run and has therefore no effect.

Remedy:

Program code	Comment
<pre> ; Enable of the axis container rotation. N11 AXCTSWE(CT3) ; Cancellation of the enable. WHEN <condition> DO AXCTSWEC(AX_A) N21 ... ; Traversing of the container axis AX_A => before the axis is traversed, there ; is a waiting period for the end of the axis container rotation: \$AN_AXCTSWA[CT3]==0 N31 AX_A = 10 </pre>	<pre> ; Executable NC block </pre>

Note

Without the executable block N21, the synchronized action would only be implemented after the end of the axis container rotation with the next executable program block N31 in the main run and would therefore have no effect, just the same as in the example above.

3.17.8.16 Actual value setting with loss of the referencing status (PRESETON)**Function**

The `PRESETON()` procedure sets new actual values in the machine coordinate system (MCS) from synchronized actions for **one** axis. This corresponds to work offset of the axis MCS. The axis is not traversed.

From synchronized actions, `PRESETON` **must only be used on command axes**, i.e. on axes that have been started from a synchronized action. The axis must also be assigned to the channel, i.e. this channel must have the interpolation right for this axis. The axis is **not** requested from another channel via axis replacement.

Referencing status

By setting a new actual value in the machine coordinate system, the referencing status of the machine axis is reset.

DB31, ... DBX60.4/.5 = 0 (referenced/synchronized measuring system 1/2)

It is recommended that `PRESETON` only be used for axes that do not require a reference point.

To restore the original machine coordinate system, the measuring system of the machine axis must be referenced again, e.g. through active referencing from the part program (G74).

 CAUTION
--

Loss of the referencing status

By setting a new actual value in the machine coordinate system with `PRESETON`, the referencing status of the machine axis is reset to "not referenced/synchronized".

Programming**Syntax**

```
WHEN | EVERY ... DO PRESETON(<axis>,<value>)
```

Meaning

WHEN, EVERY: Only WHEN and EVERY must be used as frequency (Page 906).

PRESETON: Actual value setting with loss of the referencing status

<axis>:	Machine axis name Type: AXIS Range of values: Machine axis names defined in the channel
<value>:	New actual value of the machine axis in the machine coordinate system (MCS) The input is made in the current valid system of units (inch/metric) An active diameter programming (DIAMON) is taken into account Type: REAL

System variable

\$AC_PRESET

The axis-specific system variable **\$AC_PRESET** provides the vector from the zero point of the currently offset MCS' to the zero point of the original MCS₀ after the referencing of the machine axis.

\$AC_PRESET<axis> = \$AC_PRESET<axis> + "current actual position of the axis in the MCS" - "PRESETON actual position"

The work offset can be undone with the system variables:

```
PRESETON(<axis>, $VA_IM + $AC_PRESET[<axis>]) ; "current actual position of the axis in the MCS'" + "offsets"
```

Example

Program code

```
N10 G1 X=10 F5000
; Traverse the X axis as command axis to position 200
N20 WHEN TRUE DO G71 POS[X]=200
; IF set position of the X axis in the MCS ($AA_IM[X]) >= 80
; THEN "actual position of the X axis in the MCS" = "set position of the X
axis in the MCS" + "offset"
;
;           = 80 + 70 = 150
;   "progr. end position of the X axis" = "progr. end position of the X
axis" + "offset"
;
;           = 200 + 70 = 270
;   $AC_PRESET = $AC_PRESET - 70
N30 WHEN G71 $AA_IM[X] >= 80 DO PRESETON(X, $AA_IM[X]+70)
N40 G4 F3
```

Supplementary conditions

Axes for which PRESETON must not be used

- Traversing command axes in spindle mode
- Traversing concurrent positioning axes (FC18)
- Axes involved in a transformation

3.17 Synchronized actions

- Traversing path axes
- Reciprocating axes
- Axes on which one or more of the following safety functions (Safety Integrated) are active
 - Enable "Safe software limit switch"
MD36901 \$MA_SAFE_FUNCTION_ENABLE[<safe axis>], bit 1 = 1
 - Enable "Safe software cam", pair 1 ... 4, cam +/-
MD36901 \$MA_SAFE_FUNCTION_ENABLE[<safe axis>], bits 8 ... 15 = 1
or
Enable "Safe Cam Track", cam 1 ... 30
MD36903 \$MA_SAFE_CAM_ENABLE[<safe axis>], bits 0 ... 29 = 1
- Hirth axes
- Synchronized axes of a gantry grouping
- Axes for which the reference point approach from the part program (G74) is active
- Slave axis of a speed/torque coupling (master-slave)

Geometry axes

- PRESETON can be used on a stationary geometry axis when a further geometry axis is not being traversed in the channel at the same time.
- PRESETON can be used on a stationary geometry axis even when a further geometry axis is being traversed in the channel at the same time, but this axis is in the "neutral axis" state or traversing as a command axis.
Example: A further geometry (X) is traversing at the same time in the "neutral axis" state

Program code	Comment
N10 G0 X0 Y0	; X, Y: Geometry axes
N15 RELEASE(Y) ¹⁾	; Neutral axis
N20 ID=1 WHEN 20.0 < \$AA_IM[X] DO PRESETON(Y,20)	; \$AA_IM: Set position in the MCS
N30 G0 X40	; Geometry axis X traverses
N40 M30	

1) Note

The release of an axis in the action part of a synchronized action does not ensure that the release is on time.
N20 ID=1 WHEN 20.0 < \$AA_IM[X] DO RELEASE(Y) PRESETON(Y,20) ; NOT recommended!

Example: A further geometry (X) is traversing at the same time as **command axis**

Program code	Comment
N10 G0 X0 Y0	; X, Y: Geometry axes
N20 ID=1 WHEN TRUE DO POS[X]=40 FA[X]=1000	; X command axis
N30 ID=2 WHEN 20.0 < \$AA_IM[X] DO PRESETON(Y,20)	; \$AA_IM: Set position in the MCS
N40 M30	

PLC-controlled axes

- PRESETON can be used on PLC-controlled axes according to their current type.

Spindle states

The following table shows the reactions that occur when PRESETON is used on a spindle in a synchronized action:

PRESETON in synchronized action			
Spindle mode	Traversing status	Assigned to the NC program	Main axis
Speed control mode	In motion	Alarm 17601	Alarm 17601
	Stationary	+/-	+/-
Positioning mode SPOS	In motion	Alarm 17601	Alarm 17601
	Stationary	+/-	+/-
Positioning across block boundaries SPOSA	In motion	Alarm 17601	-
Axis mode	In motion	Alarm 17601	+/-
	Stationary	+/-	+/-
+/- Possible -: Not possible			

PRESETON in the NC program			
Spindle mode	Traversing status	Assigned to the NC program	Main axis
Speed control mode	In motion	Alarm 22324	Alarm 22324
	Stationary	+/-	+/-
Positioning mode SPOS	In motion	-	+/-
	Stationary	+/-	+/-
Positioning across block boundaries SPOSA	In motion	Alarm 10610	-
Axis mode	In motion	-	+/-
	Stationary	+/-	+/-
+/- Possible -: Not possible			

Axis couplings

- Leading axes: The sudden change of the leading axis position caused by PRESETON is not traversed in the following axes. The coupling is not changed.
- Following axes: Only the overlaid position component of the following axis is affected by PRESETON.

Gantry grouping

- If PRESETON is used on the guide axis of a gantry grouping, the work offset is also performed in all synchronized axes of the gantry grouping.

Indexing axes

- `PRESETON` can be used on indexing axes.

Software limit switches, operating range limit, protection areas

- If the axis position is outside the specified limits after a work offset by `PRESETON`, an alarm is not displayed until an attempt is made to traverse the axis.

Block search with calculation

`PRESETON` commands are collected during the block search and executed with the NC start to continue the NC program.

Position-dependent NC/PLC interface signals

- The status of the position-dependent NC/PLC interface signals is redetermined based on the new actual position.
Example: Fixed point positions
 - Parameterized fixed point positions: `MD30600 $MA_FIX_POINT_POS[0...3] = <fixed point position 1...4>`
 - NC/PLC interface signals `DB31, ... DBX75.3 ... 5` (JOG approach fixed point: reached)If the axis is at a fixed point position with the exact stop tolerance, the associated NC/PLC interface signal is set. The NC/PLC interface signal is reset when the actual value is set by `PRESETON` to a different value outside the exact stop tolerance around the fixed point position.

DRF offset

- A DRF offset of the axis is deleted by `PRESETON`.

Overlaid movement `$AA_OFF`

- An overlaid movement (`$AA_OFF`) (Page 934) is not affected by `PRESETON`.

Online tool offset `FTOC`

- An active online tool offset (`FTOC`) (Page 962) remains active even after `PRESETON`.

Axis-specific compensations

Axis-specific compensations remain active after `PRESETON`.

JOG mode

- `PRESETON` must only be used on a stationary axis.

JOG mode, REF machine function

- `PRESETON` must **not** be used.

3.17.8.17 Actual value setting without loss of the referencing status (PRESETONS)

Function

The `PRESETONS ()` procedure sets new actual values in the machine coordinate system (MCS) from synchronized actions for **one** axis. This corresponds to work offset of the axis MCS. The axis is not traversed.

From synchronized actions, `PRESETONS` **must only be used on command axes**, i.e. on axes that have been started from a synchronized action. The axis must also be assigned to the channel, i.e. this channel must have the interpolation right for this axis. The axis is **not** requested from another channel via axis replacement.

Referencing status

By setting a new actual value in the machine coordinate system (MCS) with `PRESETONS`, the referencing status of the machine axis is **not** changed.

Requirements

- **Encoder type**

`PRESETONS` is only possible with the following encoder types of the active measuring system:

- MD30240 `$MA_ENC_TYPE[<measuring system>] = 0` (simulated encoder)
- MD30240 `$MA_ENC_TYPE[<measuring system>] = 1` (raw signal encoder)

- **Referencing mode**

`PRESETONS` is only possible with the following referencing mode of the active measuring system:

- MD34200 `$MA_ENC_REFP_MODE[<measuring system>] = 0` (no reference point approach possible)
- MD34200 `$MA_ENC_REFP_MODE[<measuring system>] = 1` (referencing of incremental, rotary or linear measuring systems: zero pulse on the encoder track)

Startup

Axis-specific machine data

Actual value setting without loss of the referencing status (`PRESETONS`) must be set axis-specifically:

MD30460 `$MA_BASE_FUNCTION_MASK`, bit 9 = 1

Note

PRESETON deactivated

Activation of the "Actual value setting without loss of the referencing status `PRESETONS`" function deactivates the "Actual value setting with loss of the referencing status `PRESETON`" function. The options mutually exclude each other.

Programming

Syntax

```
<frequency> ... DO PRESETONS (<axis>, <value>)
```

Meaning

<frequency>: Only WHEN and EVERY must be used as frequency (Page 906).
 PRESETONS: Actual value setting with loss of the referencing status
 <axis>: Machine axis name
 Type: AXIS
 Range of values: Machine axis names defined in the channel
 <value>: New current actual value of the machine axis in the machine coordinate system (MCS)
 The input is made in the active system of units (inch/metric)
 An active diameter programming (DIAMON) is taken into account
 Type: REAL

System variable

\$AC_PRESET

The axis-specific system variable \$AC_PRESET provides the vector from the zero point of the currently offset MCS' to the zero point of the original MCS₀ after the referencing of the machine axis.

```
$AC_PRESET<axis> = $AC_PRESET<axis> + "current actual position of the axis in the MCS" - "PRESETONS actual position"
```

The work offset can be undone with the system variables:

```
PRESETONS (<axis>, $VA_IM + $AC_PRESET[<axis>]) ; "current actual position of the axis in the MCS'" + "offsets"
```

Example

Work offset of the X axis MCS by 70 units.

The programmed end position of the X axis (command axis) is transformed to the new MCS with PRESETONS.

Program code

```
N10 G1 X=10 F5000
; Traverse the X axis as command axis to position 200
N20 WHEN TRUE DO G71 POS[X]=200
```

Program code

```

; IF set position of the X axis in the MCS ($AA_IM[X]) >= 80
; THEN "actual position of the X axis in the MCS" = "set position of the X
axis in the MCS" + "offset"
;                                     = 80 + 70 = 150
;     "progr. end position of the X axis" = "progr. end position of the X
axis" + "offset"
;                                     = 200 + 70 = 270
;     $AC_PRESET = $AC_PRESET - 70
N30 WHEN G71 $AA_IM[X] >= 80 DO PRESETONS(X, $AA_IM[X]+70)
N40 G4 F3

```

Supplementary conditions**Axes for which PRESETONS must not be used**

- Traversing command axes in spindle mode
- Traversing concurrent positioning axes (FC18)
- Axes involved in a transformation
- Traversing path axes
- Reciprocating axes
- Axes on which one or more of the following safety functions (Safety Integrated) are active
 - Enable "Safe software limit switch"
MD36901 \$MA_SAFE_FUNCTION_ENABLE[<safe axis>], bit 1 = 1
 - Enable "Safe software cam", pair 1 ... 4, cam +/-
MD36901 \$MA_SAFE_FUNCTION_ENABLE[<safe axis>], bits 8 ... 15 = 1
or
Enable "Safe Cam Track", cam 1 ... 30
MD36903 \$MA_SAFE_CAM_ENABLE[<safe axis>], bits 0 ... 29 = 1
- Hirth axes
- Synchronized axes of a gantry grouping
- Axes for which the reference point approach from the part program (G74) is active
- Slave axis of a speed/torque coupling (master-slave)

3.17 Synchronized actions

Geometry axes

- PRESETONS can be used on a stationary geometry axis when a further geometry axis is not being traversed in the channel at the same time.
- PRESETONS can be used on a stationary geometry axis even when a further geometry axis is being traversed in the channel at the same time, but this axis is in the "neutral axis" state or traversing as a command axis.

Example: A further geometry (X) is traversing at the same time in the "neutral axis" state

Program code	Comment
N10 G0 X0 Y0	; X, Y: Geometry axes
N15 RELEASE(Y) ¹⁾	; Neutral axis
N20 ID=1 WHEN 20.0 < \$AA_IM[X] DO PRESETONS(Y,20)	; \$AA_IM: Set position in the MCS
N30 G0 X40	; Geometry axis X traverses
N40 M30	
<p>1) Note</p> <p>The release of an axis in the action part of a synchronized action does not ensure that the release is on time.</p> <p>N20 ID=1 WHEN 20.0 < \$AA_IM[X] DO RELEASE(Y) PRESETONS(Y,20) ; NOT recommended!</p>	

Example: A further geometry (X) is traversing at the same time as **command axis**

Program code	Comment
N10 G0 X0 Y0	; X, Y: Geometry axes
N20 ID=1 WHEN TRUE DO POS[X]=40 FA[X]=1000	; X command axis
N30 ID=2 WHEN 20.0 < \$AA_IM[X] DO PRESETONS(Y,20)	; \$AA_IM: Set position in the MCS
N40 M30	

PLC-controlled axes

- PRESETONS can be used on PLC-controlled axes according to their current type.

Spindle states

The following table shows the reactions that occur when PRESETONS is used on a spindle in a synchronized action:

PRESETONS in synchronized action			
Spindle mode	Traversing status	Assigned to the NC program	Main axis
Speed control mode	In motion	Alarm 17601	Alarm 17601
	Stationary	+/-	+/-
Positioning mode SPOS	In motion	Alarm 17601	Alarm 17601
	Stationary	+/-	+/-
Positioning across block boundaries SPOSA	In motion	Alarm 17601	-

PRESETONS in synchronized action			
Spindle mode	Traversing status	Assigned to the NC program	Main axis
Axis mode	In motion	Alarm 17601	+/-
	Stationary	+/-	+/-
+/- Possible -: Not possible			

PRESETONS in the NC program			
Spindle mode	Traversing status	Assigned to the NC program	Main axis
Speed control mode	In motion	Alarm 22324	Alarm 22324
	Stationary	+/-	+/-
Positioning mode <i>SPOS</i>	In motion	-	+/-
	Stationary	+/-	+/-
Positioning across block boundaries <i>SPOSA</i>	In motion	Alarm 10610	-
Axis mode	In motion	-	+/-
	Stationary	+/-	+/-
+/- Possible -: Not possible			

Axis couplings

- Leading axes: The sudden change of the leading axis position caused by PRESETONS is not traversed in the following axes. The coupling is not changed.
- Following axes: Only the overlaid position component of the following axis is affected by PRESETONS.

Gantry grouping

- If PRESETONS is used on the guide axis of a gantry grouping, the work offset is also performed in all synchronized axes of the gantry grouping.

Indexing axes

- PRESETONS can be used on indexing axes.

Software limit switches, operating range limit, protection areas

- If the axis position is outside the specified limits after a work offset by PRESETONS, an alarm is not displayed until an attempt is made to traverse the axis.

Block search with calculation

PRESETONS commands are collected during the block search and executed with the NC start to continue the NC program.

Position-dependent NC/PLC interface signals

- The status of the position-dependent NC/PLC interface signals is redetermined based on the new actual position.

Example: Fixed point positions

- Parameterized fixed point positions: MD30600 \$MA_FIX_POINT_POS[0...3] = <fixed point position 1...4>
- NC/PLC interface signals DB31, ... DBX75.3 ... 5 (JOG approach fixed point: reached)

If the axis is at a fixed point position with the exact stop tolerance, the associated NC/PLC interface signal is set. The NC/PLC interface signal is reset when the actual value is set by PRESETONS to a different value outside the exact stop tolerance around the fixed point position.

DRF offset

- A DRF offset of the axis is deleted by PRESETONS.

Overlaid movement \$AA_OFF

- An overlaid movement (\$AA_OFF) (Page 934) is not affected by PRESETONS.

Online tool offset FTOC

- An active online tool offset (FTOC) (Page 962) remains active even after PRESETONS.

Axis-specific compensations

Axis-specific compensations remain active after PRESETONS.

JOG mode

- PRESETONS must only be used on a stationary axis.

JOG mode, REF machine function

- PRESETONS must not be used.

3.17.8.18 Couplings (CP..., LEAD..., TRAIL..., CTAB...)

The commands listed in Section "Language elements for synchronized actions and technology cycles (Page 949)" can be programmed in synchronized actions for the functions coupled motion (TRAIL...), curve tables (CTAB...), master value coupling (LEAD...) and generic coupling (CP...):

Note

Generic coupling

Note that the "generic coupling" CP... commands are always executed in synchronized actions in the sequence of the programming from left to right. This means that in contrast to the programming in the part program, the effect of the various commands depends on their sequence in the synchronized action.

Curve tables

The CTAB and CTABINV commands can be used in the condition and in the action.

References

Detailed information on coupling commands can be found in:

- Coupled motion, curve tables, master value coupling:
Programming Manual, Job Planning; Section "Axis couplings"
- Generic coupling
Description of Functions, Special Functions, Section "Axis couplings (M3)" > "Generic coupling"

Coupled motion

When the coupling is activated from the synchronized action, the leading axis can be in motion. In this case the following axis is accelerated up to the set velocity. The position of the leading axis at the time of synchronization of the velocity is the starting position for coupled-axis motion.

Master value coupling

Syntax

```
... DO LEADON(<FA>, <LA>, <NO>, <OVW>)
```

Meaning

<FA>:	Name of the following axis Type: AXIS
<LA>:	Name of the leading axis Type: AXIS
<NO>:	Number of the curve table Type: INT
<OVW>:	Status of the overwrite permission Type: BOOL 0: Overwriting of the table is not permitted 1: Overwriting of the table is permitted

- Synchronized actions can be used to change the basic curve table without a resynchronization even during an active master value coupling. The following axis attempts as fast as possible to follow the position values specified by the new curve table.
- In order to be able to program an axis to be coupled via synchronized actions, the axis must first be released with the `RELEASE` command.
Example:

```
Program code  
...  
N60 RELEASE(X)  
N50 ID=1 EVERY SR1==1 DO LEADON(C, X, 1)
```

Example: On-the-fly parting

An extruded material which passes continuously through the operating area of a cutting tool must be cut into parts of equal length.

- X axis: Axis in which the extruded material moves (WCS)
- X1 axis: Machine axis of the extruded material (MCS)
- Y axis: Axis in which the cutting tool "tracks" the extruded material

It is assumed that the infeed and control of the cutting tool are controlled via the PLC user program. The signals at the PLC interface can be evaluated to determine whether the extruded material and cutting tool are synchronized.

Program code	Comment
N100 R3=1500	; Length of a part to be cut off
N200 R2=100000 R13=R2/300	
N300 R4=100000	
N400 R6=30	; Start position Y axis
N500 R1=1	; Start condition for conveyor axis
N600 LEADOF(Y,X)	; Delete coupling
N700 CTABDEF(Y,X,1,0)	; Table definition
N800 X=30 Y=30	; Value pairs
N900 X=R13 Y=R13	
N1000 X=2*R13 Y=30	
N1100 CTABEND	; End of table definition
N1200 PRESETON(X1,0)	; PRESET at beginning
N1300 Y=R6 GO	; Start position Y axis, axis is linear
	; PRESET after length R3, new start after parting
N1400 ID=1 WHENEVER \$AA_IW[X]>\$R3 DO PESETON(X1,0)	
N1500 RELEASE(Y)	
	; Couple Y to X via table 1, for X < 10
N1800 ID=6 EVERY \$AA_IM[X]<10 DO LEADON(Y,X,1)	
	; > 30 before traversed parting distance, deactivate coupling
N1900 ID=10 EVERY \$AA_IM[X]>\$R3-30 DO LEADOF(Y,X)	
N2000 WAITP(X)	
	; Set extruded material axis continuously in motion
N2100 ID=7 WHEN \$R1==1 DO MOV[X]=1 FA[X]=\$R4	
N2200 M30	

Generic coupling

- When a coupling module is activated in a synchronized action, the following axis **must** already be active in the channel and be in the state "neutral axis " or "axis already assigned to the part program of the channel". The corresponding axis state can be generated, if necessary, in the synchronized action by programming `GET[<following axis>]`.
- The commands of the generic coupling `CP . . .` are processed directly in synchronized actions by the coupling module. The command therefore takes effect immediately.
- With the programming of a coupling factor (`CPLNUM`, `CPLDEN`) or table number (`CPLCTID`), a previously activated non-linear coupling relationship, e.g. a curve table, is deactivated.

Generic coupling: Using the TRAIL, LEAD, EG or COUP coupling type.

If in the framework of the generic coupling, a behavior corresponding to one of the known coupling types "Coupled motion", "Master value coupling", "Electronic gear" or "Synchronous spindle" is required, the command `CPSETTYPE` is also possible in synchronized actions when creating or defining the coupling module:

```
CPSETTYPE[FAx] = <coupling type>
```

<Coupling type>	Meaning
CP	Freely programmable
TRAIL	"Coupled motion" coupling type
LEAD	"Master value coupling" coupling type
EG	"Electronic gearbox" coupling type
COUP	"Synchronous spindle" coupling type

Supplementary conditions

Synchronism status of a following axis

The system variable `$AA_SYNC[<axis>]` can be used to read the synchronism status of a following axis in the part program or synchronized action.

Axis replacement with cross-channel coupling

For axis replacement, the following and leading axes must be known to the calling channel. Axis replacement of leading axes can be performed independently of the state of the coupling. A defined or active coupling does not produce any other supplementary conditions.

Note

With the activation of the coupling, the following axis becomes the main run axis and is not available for an axis replacement. The following axis is thus logged out of the channel. With this type of coupling, an overlaid movement is therefore not possible.

See also Section "Axis replacement (GET, RELEASE, AXTOCHAN) (Page 974)"

Conflict prevention when changing from following axis to channel axis

In order to be able to traverse a following axis traversed via synchronized actions as a channel axis again, you must ensure that the coupling is deactivated before the channel requests the relevant axis.

The following example shows an **error case**:

Program code
...
N50 WHEN TRUE DO TRAILOF(Y, X)
N60 Y100

The Y axis is not released early enough in N50 because TRAILOF only becomes active with N60 through the non-modal synchronized action.

Corrected example:

Program code	Comment
...	
N50 WHEN TRUE DO TRAILOF(Y, X)	
N55 WAITP(Y)	; Wait for end of travel of the positioning axis
N60 Y100	

Examples

Define coupling: Y = following axis, X = leading axis

Program code
... DO CPLDEF[Y]=X CPLNUM[Y,X]=1.5

Activate coupling and define coupling relationship.

- N10 with the correct sequence: First CPLON then CPLNUM
- N20 with **incorrect** sequence: First CPLNUM then CPLON

Program code
N10 ... DO CPLON[Y]=X CPLNUM[X,Y]=1.5
N20 ... DO CPLNUM[X,Y]=2 CPLON[Y]=X ; Error

Activate coupling, deactivation/activation with implicit resynchronization

Program code
N10 ... DO CPLON[X]=Y CPLNUM[X,Y]=3
N20 Y100 F100
N30 ... DO CPLOF=X CPLON[X]=Y CPLNUM[X,Y]=3

Activate coupling, deactivate and traverse as a command axis

Program code
N10 ... DO CPLON[X]=Y CPLNUM[X,Y]=3
N20 Y100 F100

Program code
N30 ... DO CPLOF=X MOV[X]=10

3.17.8.19 Measurement (MEAWA, MEAC)

The following commands can be used in synchronized actions for measurement:

- MEAWA (measurement without delete distance-to-go)
- MEAC (continuous measurement without delete distance-to-go)

While the measuring function in the part program is limited to one motion block, the measuring function can be switched on and off any number of times from synchronized actions.

Note

Measurement can also be performed in JOG mode via static synchronized actions `IDS`

References

Detailed information on measuring commands can be found in:

- Coupled motion, curve tables, master value coupling:
Programming Manual, Job Planning; Section "Axis couplings"
- Generic coupling
Description of Functions, Special Functions, Section "Axis couplings (M3)" > "Generic coupling"

Measurement tasks and state changes

When a measurement task has been executed from a synchronized action, the control system responds in the following way:

State	Response
Operating mode change	A measurement task activated by a modal synchronized action is not affected by a change in operating mode. It remains active beyond block limits.
Reset	The measurement task is aborted.
Block search	Measurement tasks are collected, but not activated until the programmed condition is fulfilled.
REPOS	Activated measurement tasks are not affected.
End of program	Measurement tasks started from static synchronized actions remain active.

Remarks

System variables

The following system variables can be used in conjunction with synchronous actions:

- \$AA_MEA ACT (axial measuring active)
- \$A_PROBE (probe state)
- \$AA_MM1 ... 4 (probe position 1st to 4th trigger (machine coordinate system))

The following system variable **cannot** be used in conjunction with synchronized actions:

- \$AC_MEA (probe has responded)

Measurement job

Only one measurement job at a time may be active for an axis.

Priority with more than one measurement

A new measurement task for the same axis has the effect that the trigger events are reactivated and the measurement results reset.

Measurement jobs started from the part program cannot be influenced from synchronized actions. If a measurement task is started from a synchronized action for an axis for which a measurement task is already active from the part program, an alarm is displayed.

If a measurement task is already active from a synchronized action, measurement can no longer be started from the part program.

Saving measurement results

A FIFO memory is set up in the \$AC_FIFO system variables to save the measurement results. See Section "FIFO variables (\$AC_FIFO) (Page 920)".

Examples

In the following examples, two FIFO memories are set up via machine data:

- MD28050 \$MC_MM_NUM_R_PARAM = 300
- MD28258 \$MC_MM_NUM_AC_TIMER = 1
- MD28260 \$MC_NUM_AC_FIFO = 1 (set up FIFO memory)
- MD28262 \$MC_START_AC_FIFO = 100 (FIFO memory starts from R100)
- MD28264 \$MC_LEN_AC_FIFO = 28 (22 variables + 6 management data)
- MD28266 \$MC_MODE_AC_FIFO = 0 (no summation)

Example 1

All rising edges of probe 1 are to be recorded between 0 and 100 mm for the X axis. It is assumed that no more than 22 measuring edges occur.

Program code	Comment
DEF INT NUMBER	; number of current measured values
DEF INT INDEX_R	; loop index

Program code	Comment
N10 G0 X0	; approach starting point for the measurement
;Measurement: Mode = 1 (simultaneously), FIFO memory = 1, ; trigger event = 1 (rising edge of probe 1)	
N20 MEAC[X]=(1, 1, 1) POS[X]=100	
N30 STOPRE	; stop preprocessing
N40 MEAC[X]=(0)	; cancel measurement
N50 ANZAHL=\$AC_FIFO1[4]	; number of saved measured values
N60 ANZAHL = ANZAHL - 1	
N70 FOR INDEX_R=0 TO ANZAHL	
N80 R[INDEX_R]=\$AC_FIFO1[0]	; save measured value in R parameter
N90 ENDFOR	

Example 2

All rising and falling edges of probe 1 are to be recorded between 0 and 100 mm for the X axis. The number of measurements is not known. Therefore, the measured values must be fetched parallel to the measurement and stored in ascending order as of \$R1. The number of stored measured values is entered in \$R0.

Program code	Comment
\$AC_MARKER[1]=1	; initialize index for R parameter index
N10 G0 X0	; approach starting point for the measurement
; If measured values are available in the FIFO memory, the oldest value is read and ; stored in the current R parameter[\$AC_MARKER[1]]. ; The R parameter index is then incremented.	
N20 ID=1 WHENEVER \$AC_FIFO1[4] >= 1 DO \$R[\$AC_MARKER[1]] = \$AC_FIFO1[0]	\$AC_MARKER[1] = \$AC_MARKER[1] + 1
; Continuous measurement: Mode = 1 (simultaneously), FIFO memory = 1, ; trigger event 1 = 1 (rising edge of probe 1), ; trigger event 2 = -1 (falling edge of probe 1)	
N30 MEAC[X]=(1, 1, 1, -1) POS[X]=100	
N40 MEAC[X]=(0)	; turn off measurement
N50 STOPRE	; stop preprocessing
N60 R0 = \$AC_MARKER[1]	; number of recorded measured values

Example 3

Rising and falling edges of probe 1 are to be recorded between 0 and 500 mm for the X axis. The number of measurements is limited to 10.

The distance-to-go of the X axis is then deleted.

Program code	Comment
N10 G0 X0	; approach starting point for the measurement
; Abort condition: Deselect continuous measurement after 10 or more measurements ; and perform "delete distance-to-go"	

3.17 Synchronized actions

Program code	Comment
N10 WHEN \$AC_FIFO1[4] >= 10 DO MEAC[X]=(0) DELDTG(X)	
; Continuous measurement: Mode = 1 (simultaneously), FIFO memory = 1,	
; trigger event 1 = 1 (rising edge of probe 1),	
; trigger event 2 = -1 (falling edge of probe 1)	
N20 MEAC[X]=(1, 1, 1, -1) G01 X100 F500	
N30 MEAC [X]=(0)	; turn off measurement
N40 R0 = \$AC_FIFO1[4]	; number of recorded measured values

3.17.8.20 Travel to fixed stop (FXS, FXST, FXSW, FOCON, FOCOF, FOC)

Function

Travel to fixed stop

The function "Travel to fixed stop" can be controlled via synchronized actions with the FXS, FXST and FXSW commands.

The activation can also be performed without traversing motion of the relevant axis. The torque is immediately limited. The fixed stop is monitored as soon as the axis is traversed.

Travel with limited torque/force

Travel with limited torque/force can be controlled via synchronized actions with the FOCON, FOCOF and FOC commands.

Syntax

```
FXS[<axis>]=<request>
FXST[<axis>]=<clamping torque>
FXSW[<axis>] = <window width>
FOCON[<axis>]
FOCOF[<axis>]
FOC[<axis>]
```

Meaning

Parameter	Meaning
FXS:	Travel to fixed stop
<Request>:	Request to the "Travel to fixed stop" function: 0 = switch off 1 = switch on
FXST:	Set clamping torque
<Clamping torque>:	Clamping torque as % of the maximum drive torque
FXSW:	Set monitoring window
<Window width>:	Width of the tolerance window around the fixed stop Unit: mm, inch or degrees
FOCON:	Switch on modal torque/force limitation

Parameter	Meaning
FOCOF:	Switch off modal torque/force limitation
FOC:	Non-modal torque/force limitation
<axis>:	Name of the channel axis on which the command will be applied

Remarks

Avoidance of multiple selection

The "Travel to fixed stop" function must only be switched on once per axis. In the event of an error, alarm 20092 is displayed and the corresponding alarm response takes effect.

To avoid multiple selections, it is recommended that a selection marker be used in the synchronized action.

Example:

Program code	Comment
N10 R1=0	; Initialize selection marker
...	
N20 IDS=1 WHENEVER (\$R1==0 AND \$AA_IW[AX3] > 7) DO \$R1=1 FXS[AX1]=1	

Switching on during the approach motion

"Travel to fixed stop" can also be switched on during the approach motion through a non-modal synchronized action.

Example:

Program code	Comment
N10 G0 G90 X0 Y0	; Approach initial setting
...	
; "Travel to fixed stop" is switched on for the X axis,	
; as soon as the position setpoint in the WCS is > 20 mm	
; Execution of the non-modal synchronized action: With N30	
N20 WHEN G71 \$AA_IW[X] > 20 DO FXS[X]=1	
N30 G1 F200 X100	; Traversing block of the X axis

Example: Travel to fixed stop completely via synchronized actions

Program code	Comment
; IF selection request \$R1==1 AND state of the Y axis == "not to fixed stop"	
; THEN: For the Y axis:	
; - Switch on FXS	
; - Traverse to position 150 mm	
; - Reduce drive torque to 10%	
IDS=1 WHENEVER G71 ((\$R1==1) AND \$AA_FXS[Y]==0) DO \$R1=0 FXS[Y]=1 FXST[Y]=10	
FA[Y]=200 POS[Y]=150	
...	

3.17 Synchronized actions

Program code	Comment
<code>; IF state of the Y-Axis == "Fixed stop has been detected"</code>	
<code>; THEN: Increase drive torque to 30%</code>	
<code>IDS=2 WHENEVER (\$AA_FXS[Y]==4) DO FXST[Y]=30</code>	
<code>...</code>	
<code>; IF state of the Y axis == "Successful travel to fixed stop"</code>	
<code>; THEN: Set drive torque in accordance with setting \$R0</code>	
<code>IDS=3 WHENEVER (\$AA_FXS[Y]==1) DO FXST[Y]=\$R0</code>	
<code>...</code>	
<code>; Deselection depending on R3 and retract.</code>	
<code>IDS=4 WHENEVER ((\$R3==1) AND \$AA_FXS[Y]==1) DO FXS[Y]=0 FA[Y]=1000 POS[Y]=0</code>	
<code>...</code>	
<code>N10 R1=0 FXS[Y]=0 G0 G90 Y0</code>	<code>; Initialization</code>
<code>N30 RELEASE(Y)</code>	<code>; Enable Y axis for traversing in synchronized actions</code>
<code>N50 ...</code>	
<code>N60 GET(Y)</code>	<code>; Include Y axis in the path group again</code>

3.17.8.21 Channel synchronization (SETM, CLEARM)

Synchronization markers can be set and deleted in the channel in which the synchronized action runs with the `SETM` and `CLEARM` commands.

Syntax

```
SETM(<No_marker 1> [, <No_marker 2> {, ... <No_marker n>} ] )
CLEARM(<No_marker 1> [, <No_marker 2> {, ... <No_marker n>} ] )
```

Meaning

A detailed description of the `SETM` and `CLEARM` commands can be found in:

References

Programming Manual, Job Planning; Section "Flexible NC programming" > "Program coordination (INIT, START, WAITM, WAITMC, WAITE, SETM, CLEARM)"

3.17.8.22 User-specific error reactions (SETAL)

Synchronized actions can be used to react user-specifically to application-specific error states. Possible reactions are:

- Axis with stop via override = 0%
- Display user-specific alarm
- Set digital output

Display alarm

Syntax

```
SETAL(<Alarm_no>[,"Alarm text"])
```

Meaning

Parameter	Meaning
<Alarm_no>:	Alarm number from the range: 65000 - 69999

A complete description of the configuration of user alarms can be found in:

References

Base Software and HMI Advanced Commissioning Manual,
Section "HMI Advanced" > "Configuring the HMI system" > "Configuring user alarms"

Examples

```
; If the distance between axes X1 and X2 is less than 5 mm =>
; stop axis X2
ID=1 WHENEVER G71 ($AA_IM[X1]-$AA_IM[X2])<5.0 DO $AA_OVR[X2]=0

; If the distance between axes X1 and X2 is less than 5 mm =>
; display alarm 65000
ID=1 WHENEVER G71 ($AA_IM[X1]-$AA_IM[X2])<5.0 DO SETAL(65000)
```

3.17.8.23 Cancel the actual subprogram level (CANCELSUB)

Using `CANCELSUB`, in the channel in which the synchronized action is executed, the NC program active in the current subprogram level is canceled and in the calling program, the next higher program level is selected. There, program execution is continued normally.

Properties

- For each call, only the current subprogram level is canceled.
- After a cancellation, the next higher program level can only be canceled if a return jump is made from the canceled subprogram level.
- The main program level cannot be canceled.

Syntax

```
CANCELSUB
```

Meaning

CANCELSUB:	Cancels the current subprogram level
------------	--------------------------------------

See also

The cancellation of the current subprogram level can be realized using the channel-specific NC/PLC interface signal, also from the PLC user program, which is functionally identical:

DB21,DBX6.4 (program level cancellation)

3.17.9 Technology cycles

3.17.9.1 General

Definition

A technology cycle is an NC program that is called in the action part of a synchronized action. All language elements and system variables that are also used in the action part of a synchronized action can be used in a technology cycle. In addition, there are also the following language elements that may only be used within a technology cycle:

- Chapter "System variables for synchronized actions (Page 910)"
- Chapter "User-defined variables for synchronized actions (Page 947)"
- Chapter "Language elements for synchronized actions and technology cycles (Page 949)"
- Chapter "Language elements for technology cycles only (Page 955)"
- Chapter "Actions in synchronized actions (Page 955)"

End of program

The following commands are permitted as end of program: M02, M17, M30, RET

Search path

When calling a technology cycle, the same search path is used as for subprograms and cycles.

References

Programming Manual, Job Preparation, Section "Flexible NC programming" > "Subprogram technique" > "General" > "Search path"

Multiple calls

If a condition is fulfilled again while the technology cycle is being executed, the technology cycle is **not** restarted.

If a technology cycle is started because of a fulfilled `WHENEVER` condition and the condition is still fulfilled after completion of the technology cycle, then the technology cycle is started again.

Behavior with non-modal synchronized actions

A non-modal synchronized action is always linked to the next main run block. If the execution time of the technology cycle is longer than the processing time of the associated main run block, the technology cycle is aborted with the block change.

Execution sequence of technology cycles


If several technology cycles are programmed in the action part of a synchronized action, they are executed in the programmed sequence from left to right.

Example

Calling three technology cycles in the action part of a synchronized action.

Program code

```
ID=1 <condition part> DO AXIS_X AXIS_Y AXIS_Z
```



Execution sequence of the technology cycle blocks: N10, N11, N12, N20, N21, N22, N30, N31, N32

Note

Supplementary conditions

- A maximum of eight technology cycles may be called in the action part of a synchronized action.
- Except for the call of further technology cycles, no other action may be programmed in the action part of a synchronized action in which a technology cycle is called.

See also

Processing mode (ICYCON, ICYCOF) (Page 1008)

3.17.9.2 Processing mode (ICYCON, ICYCOF)

Function

The `ICYCOF` and `ICYCON` commands can be used to control the processing mode of the actions within technology cycles.

Per default, the processing mode `ICYCON` is active.

Processing mode: ICYCON

A non-modal technology cycle is executed in the `ICYCON` processing mode. The execution of all actions programmed in a block is initiated in the same interpolator clock cycle. As soon as all initiated actions are completed, the next block is processed in the following interpolator clock cycle.

A distinction is made between single-cycle and multi-cycle actions. Examples are:

- Single-cycle actions: Auxiliary function output, value assignments
- Multi-cycle actions: Traversing motions of axes and spindles

Each block of a technology cycle requires at least one interpolator clock cycle.

Processing mode: ICYCOF

All actions of all blocks of a technology cycle are initiated in parallel in the `ICYCOF` processing mode.

NC program as a part program

If an NC program is executed as a part program, the `ICYCOF` and `ICYCON` commands have no effect.

Syntax

In the action part of a synchronized action

```
ID=1 <condition part> DO [ICYCOF] <technology cycle 1> [ICYCOF | ICYCON] <technology cycle 2> ...
```

As property of an NC program

```
PROC <name> [ICYCOF | ICYCON]
```

Within an NC program

```
PROC <name>  
  N10 ...  
  N20 [ICYCOF | ICYCON]  
  N90 ...  
  N100 [ICYCOF | ICYCON]  
  N110 ...  
RET
```


Example

Program code	Effective processing mode	Interpolator cycle
PROC TECHNOCYC	ICYCON	
\$R1=1	ICYCON	1
POS[X]=100	ICYCON	2 ... 25
ICYCOF	ICYCOF	26
\$R1=2	ICYCOF	26
\$R2=\$R1+1	ICYCOF	26
POS[X]=110	ICYCOF	26
\$R3=3	ICYCOF	26
RET	ICYCOF	26

3.17.9.3 Definitions (DEF, DEFINE)

If an NC program is used as technology cycle, that contains commands for variable (`DEF`) and/or macro definition (`DEFINE`) then these have **no effect** when executing the technology cycle.

Although variables and macro definitions have no effect within a technology cycle, they must nevertheless have the correct syntax. In the event of an error, the execution of the technology cycle is aborted and an alarm displayed.

As the variables and macros are not available in the technology cycle, special measures may have to be taken in the program code. See Chapter "Context variable (`$P_TECCYCLE`)" (Page 1010).

3.17.9.4 Parameter transfer

Only the Call-by-Value parameter transfer is possible in a subprogram being applied as a technology cycle.

The application of Call-by-Reference parameters is **not** permissible and will trigger a corresponding alarm.

References:

A detailed description of the parameter transfer and parameter definition in subprograms can be found in:

Programming Manual Job Planning, Section "Flexible NC programming" > "Subprogram technique" > "Definition of a subprogram" or "Call of a subprogram"

3.17.9.5 Context variable (\$P_TECCYCLE)

Function

If an NC program is used as part program as well as also technology cycle, then context-specific program sections can be defined using system variable \$P_TECCYCLE:

- \$P_TECCYCLE == TRUE ⇒ The NC program is currently being executed as technology cycle
- \$P_TECCYCLE == FALSE ⇒ The NC program is currently being executed as part program

Application

The (DEF) variables and (DEFINE) macro definitions have no effect in technology cycles. If an NC program is executed as a technology cycle that contains the appropriate definitions, a context-specific case distinction has to be made in the program code as the variables and macros are then no longer available.

Example

Travel parameters via user variables in the part program and R parameters in the technology cycle

Program code	Comment: Use in
PROC UP_1	
DEF REAL POS_X=100.0	Part program
DEF REAL F_X=250.0	Part program
IF \$P_TECCYCLE==TRUE	
\$R1=100.0	Technology cycle
\$R2=250.0	Technology cycle
ENDIF	
IF \$P_TECCYCLE==TRUE	
N100 POS[X]=\$R1 FA[X]=\$R2	Technology cycle
ELSE	
N200 POS[X]=POS_X FA[X]=F_X	Part program
ENDIF	
RET	

See also

Definitions (DEF, DEFINE) (Page 1009)

3.17.10 Coordination via part program and synchronized action (LOCK, UNLOCK, CANCEL)

Each modal and static synchronized action must be assigned a unique identification number during the definition:

Program code
ID=<number> condition part DO action part
IDS=<number> condition part DO action part

By specifying the identification number, synchronized actions from part programs and from synchronized actions can be coordinated via the following commands:

Keyword	Meaning	TP ¹⁾	SA ²⁾
LOCK (<number>):	Lock synchronized action An active positioning action is interrupted.	-	x
UNLOCK (<number>):	Continue interrupted synchronized action An interrupted positioning operation is continued.	-	x
CANCEL (<number>):	Delete synchronized action An active positioning action is terminated.	x	-
¹⁾ Can be programmed in the part program ²⁾ Can be programmed in a synchronized action / technology cycle			

3.17.11 Coordination via PLC

With regard to their execution by the NC, synchronized actions that are not protected can be locked. Either all synchronized actions in the channel can be locked together or individually in the ID/IDS 1 - 64 area.

All, channel-specific

Lock all synchronized actions in the channel:

DB21, ... DBX1.2 = 1 (inhibit all synchronized actions)

Individually, channel-specific

Synchronized actions that can be locked

The synchronized actions ID/IDS that can be inhibited are displayed using:

DB21, ... DBX308.0 - 315.7 == 1 (synchronized actions ID/IDS can be locked)

The update of the inhibit signals in the interface by the NC must be actively requested from the PLC user program:

DB21, ... DBX281.1 = 1 (request: Update synchronized actions that can be locked)

The NC then updates the inhibit signals in the interface, and acknowledges the update by resetting the request:

3.17 Synchronized actions

DB21, ... DBX281.1 = **0** (acknowledgement: Synchronized actions that can be locked updated)

Lock synchronized actions

For each synchronized action ID/IDS, which is to be inhibited in the channel, the PLC user program must set the associated inhibit signal:

DB21, ... DBX300.0 - 307.7 = **1** (inhibit synchronized action ID/IDS)

The acceptance of the inhibit signals from the interface in the NC must be actively requested from the PLC user program:

DB21, ... DBX280.1 = **1** (request: Accept synchronized actions to be locked)

The NC then accepts the inhibit signals from the interface in the channel and acknowledges the acceptance by resetting the request:

DB21, ... DBX280.1 = **0** (acknowledgement: Synchronized actions to be locked accepted)

3.18 Oscillation

3.18.1 Asynchronous oscillation (OS, OSP1, OSP2, OST1, OST2, OSCTRL, OSNSC, OSE, OSB)

An oscillating axis travels back and forth between two reversal points 1 and 2 at a defined feedrate, until the oscillating motion is deactivated.

Other axes can be interpolated as desired during the oscillating motion. A continuous infeed can be achieved via a path movement or with a positioning axis, however, there is **no relationship** between the oscillating movement and the infeed movement.

Properties of asynchronized oscillation

- Asynchronous oscillation is active on an axis-specific basis beyond block limits.
- Block-oriented activation of the oscillation movement is ensured by the part program.
- Combined interpolation of several axes and superimposing of oscillation paths are not possible.

Programming

The following commands can be used to activate and control asynchronous oscillation from the part program.

The programmed values are entered in the corresponding setting data with block synchronization during the main run and remain active until changed again.

Syntax

```
OSP1[<axis>]=<value> OSP2[<axis>]=<value>
OST1[<axis>]=<value> OST2[<axis>]=<value>
FA[<axis>]=<value>
OSCTRL[<axis>]=(<setting option>,<reset option>)
OSNSC[<axis>]=<value>
OSE[<axis>]=<value>
OSB[<axis>]=<value>
OS[<axis>] = 1
OS[<axis>] = 0
```

Meaning

<axis>:	Name of oscillating axis		
OS:	Activate/deactivate oscillation		
	Value:	1	Switch oscillation on
		0	Switch oscillation off
OSP1:	Define position of reversal point 1		

OSP2:	Define position of reversal point 2 Note: If incremental movement is active, the position will be calculated incrementally to the last corresponding reversal position programmed in the NC program.																									
OST1:	Define stopping time in reversal point 1 in [s]																									
OST2:	Define stopping time in reversal point 2 in [s]																									
	<value>:	<table border="1"> <tr> <td>-2</td> <td>Interpolation continues without wait for exact stop</td> </tr> <tr> <td>-1</td> <td>Wait for exact stop coarse</td> </tr> <tr> <td>0</td> <td>Wait for exact stop fine</td> </tr> <tr> <td>>0</td> <td>Wait for exact stop fine and then wait for specified stopping time Note: The unit for the stopping time is identical to that of the stopping time programmed with G4.</td> </tr> </table>	-2	Interpolation continues without wait for exact stop	-1	Wait for exact stop coarse	0	Wait for exact stop fine	>0	Wait for exact stop fine and then wait for specified stopping time Note: The unit for the stopping time is identical to that of the stopping time programmed with G4.																
-2	Interpolation continues without wait for exact stop																									
-1	Wait for exact stop coarse																									
0	Wait for exact stop fine																									
>0	Wait for exact stop fine and then wait for specified stopping time Note: The unit for the stopping time is identical to that of the stopping time programmed with G4.																									
FA:	Define feedrate The feedrate is the defined feedrate of the positioning axis. If no feedrate is defined, the value stored in the machine data applies.																									
OSCTRL:	Specify setting and reset options Option values 0 to 3 encrypt the behavior at the reversal points on deactivation. One of the variants from 0 to 3 can be selected. The remaining settings can be combined at will with the selected variant. Multiple options are appended with plus characters (+).																									
	<value>:	<table border="1"> <tr> <td>0</td> <td>Stop at next reversal point on deactivation of oscillation (default) Note: Only possible if values 1 and 2 are reset.</td> </tr> <tr> <td>1</td> <td>When the oscillation is deactivated, stop at reversal point 1</td> </tr> <tr> <td>2</td> <td>When the oscillation is deactivated, stop at reversal point 2</td> </tr> <tr> <td>3</td> <td>When the oscillation is deactivated, do not approach reversal point if no spark-out strokes are programmed</td> </tr> <tr> <td>4</td> <td>Approach end position after spark-out</td> </tr> <tr> <td>8</td> <td>If oscillation is canceled by deletion of distance-to-go, sparking-out strokes will then need to be executed and the end position approached if necessary.</td> </tr> <tr> <td>16</td> <td>If oscillation is canceled by deletion of distance-to-go, the corresponding reversal point will need to be approached as is the case with shutdown.</td> </tr> <tr> <td>32</td> <td>New feed is only active after the next reversal point</td> </tr> <tr> <td>64</td> <td>FA equal to 0, FA = 0: Path overlay is active FA not equal to 0, FA <> 0: Speed overlay is active</td> </tr> <tr> <td>128</td> <td>For rotary axis DC (shortest path)</td> </tr> <tr> <td>256</td> <td>The sparking-out stroke is a dual stroke (default). 1=Single stroke.</td> </tr> <tr> <td>512</td> <td>First approach start position</td> </tr> </table>	0	Stop at next reversal point on deactivation of oscillation (default) Note: Only possible if values 1 and 2 are reset.	1	When the oscillation is deactivated, stop at reversal point 1	2	When the oscillation is deactivated, stop at reversal point 2	3	When the oscillation is deactivated, do not approach reversal point if no spark-out strokes are programmed	4	Approach end position after spark-out	8	If oscillation is canceled by deletion of distance-to-go, sparking-out strokes will then need to be executed and the end position approached if necessary.	16	If oscillation is canceled by deletion of distance-to-go, the corresponding reversal point will need to be approached as is the case with shutdown.	32	New feed is only active after the next reversal point	64	FA equal to 0, FA = 0: Path overlay is active FA not equal to 0, FA <> 0: Speed overlay is active	128	For rotary axis DC (shortest path)	256	The sparking-out stroke is a dual stroke (default). 1=Single stroke.	512	First approach start position
0	Stop at next reversal point on deactivation of oscillation (default) Note: Only possible if values 1 and 2 are reset.																									
1	When the oscillation is deactivated, stop at reversal point 1																									
2	When the oscillation is deactivated, stop at reversal point 2																									
3	When the oscillation is deactivated, do not approach reversal point if no spark-out strokes are programmed																									
4	Approach end position after spark-out																									
8	If oscillation is canceled by deletion of distance-to-go, sparking-out strokes will then need to be executed and the end position approached if necessary.																									
16	If oscillation is canceled by deletion of distance-to-go, the corresponding reversal point will need to be approached as is the case with shutdown.																									
32	New feed is only active after the next reversal point																									
64	FA equal to 0, FA = 0: Path overlay is active FA not equal to 0, FA <> 0: Speed overlay is active																									
128	For rotary axis DC (shortest path)																									
256	The sparking-out stroke is a dual stroke (default). 1=Single stroke.																									
512	First approach start position																									
OSNSC:	Define number of sparking-out strokes																									

OSE:	Define end position (in workpiece coordinate system) to be approached after deactivation of oscillation. Note: When programming "OSE" option 4 becomes effective implicitly for "OSCTRL".
OSB:	Define start position (in workpiece coordinate system) to be approached prior to activation of oscillation. The start position is approached before reversal point 1. If the start position coincides with reversal position 1, reversal position 2 is approached next. No stopping time applies when the start position is reached, even if this position coincides with reversal position 1; instead, the axis waits for the exact stop fine signal. Any exact stop condition configured is fulfilled. Note: Bit 9 in setting data SD43770 \$SA_OSCILL_CTRL_MASK must be set to initiate an approach to the start position.

Examples

Example 1: Oscillating axis to oscillate between two reversal points

Oscillating axis Z is to oscillate between position 10 and 100. Reversal point 1 is to be approached with exact stop fine, reversal point 2 with exact stop coarse. The feedrate for the oscillating axis must be 250. 3 sparking-out strokes must be executed at the end of the machining operation and the oscillating must approach end position 200. The feedrate for the infeed axis must be 1 and the end of infeed in the X direction should be reached at position 15.

Program code	Comment
WAITP(X,Y,Z)	; Initial setting.
G0 X100 Y100 Z100	; Switch over to positioning axis operation.
WAITP(X,Z)	
OSP1[Z]=10 OSP2[Z]=100	; Reversal point 1, reversal point 2.
OSE[Z]=200	; End position.
OST1[Z]=0 OST2[Z]=-1	; Stopping time at U1: Exact stop fine ; Stopping time at U2: Exact stop coarse
FA[Z]=250 FA[X]=1	; Feed for oscillating axis, infeed axis
OSCTRL[Z]=(4,0)	; Setting options.
OSNSC[Z]=3	; 3 sparking-out strokes.
OS[Z]=1	; Start oscillation.
WHEN \$A_IN[3]==TRUE DO DELDTG(X)	; Deletion of distance-to-go.
POS[X]=15	; Starting position X axis.
POS[X]=50	; End position X axis.
OS[Z]=0	; Stop oscillation.
M30	

Note

The "OSP1[Z]=..." to "OSNCS[Z]=..." command sequence can also be programmed in a block.

Example 2: Oscillation with online modification of the reversal position

The setting data necessary for asynchronous oscillation can be set in the part program.

If the setting data is described directly in the program, the change takes effect during preprocessing. A synchronized response can be achieved by means of a preprocessing stop (STOPRE).

Program code	Comment
\$SA_OSCILL_REVERSE_POS1[Z]=-10	
\$SA_OSCILL_REVERSE_POS2[Z]=10	
G0 X0 Z0	
WAITP(Z)	
ID=1 WHENEVER \$AA_IM[Z] < \$\$AA_OSCILL_REVERSE_POS1[Z] DO \$AA_OVR[X]=0	; If the actual value of the oscillating axis has exceeded the reversal point, then the infeed axis is stopped.
ID=2 WHENEVER \$AA_IM[Z] < \$\$AA_OSCILL_REVERSE_POS2[Z] DO \$AA_OVR[X]=0	
OS[Z]=1 FA[X]=1000 POS[X]=40	; Activate oscillation.
OS[Z]=0	; Deactivate oscillation.
M30	

Further information**Oscillating axis**

The following apply to the oscillating axis:

- Every axis may be used as an oscillation axis.
- Several oscillation axes can be active at the same time (maximum: the number of the positioning axes).
- Linear interpolation G1 is always active for the oscillating axis – irrespective of the G command currently valid in the program.

The oscillating axis can:

- Act as an input axis for dynamic transformation
- Act as a guide axis for gantry and coupled-motion axes
- Be traversed:
 - Without jerk limitation "BRISK"
 - or
 - With jerk limitation "SOFT"
 - or
 - With acceleration curve with a knee (as positioning axes)

Oscillation reversal points

The current offsets must be taken into account when oscillation positions are defined:

- Absolute specification
"OSP1[Z]=<value>"
Position of reversal point = sum of offsets + programmed value
- Relative specification
"OSP1[Z]=IC(<value>)"
Position of reversal point = reversal point 1 + programmed value

Example:

Program code
N10 OSP1[Z]=100 OSP2[Z]=110
...
N40 OSP1[Z]=IC(3)

WAITP

If oscillation is to be performed with a geometry axis, you must enable this axis for oscillation with "WAITP".

When oscillation has finished, "WAITP" is used to enter the oscillating axis as a positioning axis again, so that normal use can resume.

Oscillation with motion-synchronous actions and stopping times

Once the set stop times have expired, the internal block change is executed during oscillation (indicated by the new distances to go of the axes). The deactivation function is checked when the block changes. The deactivation function is defined according to the control setting for the motion sequence (OSCTRL). *This dynamic response can be influenced by the feed override.*

An oscillation stroke may then be executed before the sparking-out strokes are started or the end position approached. *Although it appears as if the deactivation response has changed, this is not in fact the case.*

3.18.2 Oscillation controlled by synchronized actions (OSCILL)

With this mode of oscillation, an infeed motion may only be executed at the reversal points or within defined reversal areas.

Depending on requirements, the oscillation movement can be

- Continued or
- Stopped until the infeed has finished executing.

Syntax

1. Define parameters for oscillation
2. Define motion-synchronous actions
3. Assign axes, define infeed

Meaning

OSP1[<oscillating axis>]=	Position of reversal point 1
OSP2[<oscillating axis>]=	Position of reversal point 2
OST1[<oscillating axis>]=	Stopping time at reversal point 1 in seconds
OST2[<oscillating axis>]=	Stopping time at reversal point 2 in seconds
FA[<oscillating axis>]=	Feed for oscillating axis
OSCTRL[<oscillating axis>]=	Set or reset options
OSNSC[<oscillating axis>]=	Number of sparking-out strokes
OSE[<oscillating axis>]=	End position
WAITP (<oscillating axis>)	Enable axis for oscillation

Axis assignment, infeed

OSCILL[<oscillating axis>]=(<infeed axis 1>,<infeed axis 2>,<infeed axis 3>)

POSP[<infeed axis>]=(<end position>,<partial length>,<mode>)


OSCILL:	Assign infeed axis or axes for oscillating axis
POSP:	Define complete and partial infeeds (see Section "File and Program Management")
End position:	End position for the infeed axis after all partial infeeds have been traversed.
Partial length:	Length of the partial infeed at reversal point/reversal area
Mode:	Division of the complete infeed into partial infeeds = Two residual steps of equal size (default); = All partial infeeds of equal size

Motion-synchronous actions

WHEN... .. DO	when..., do...
WHENEVER ... DO	whenever..., do...

Example

No infeed must take place at reversal point 1. At reversal point 2, the infeed is to start at a distance of *ii2* before reversal point 2 and the oscillating axis is not to wait at the reversal point for the end of the partial infeed. Axis Z is the oscillation axis and axis X the infeed axis.



1. Parameters for oscillation

Program code	Comment
DEF INT ii2	; Define variable for reversal area 2
OSP1[Z]=10 OSP2[Z]=60	; Define reversal points 1 and 2
OST1[Z]=0 OST2[Z]=0	; Reversal point 1: Exact stop fine Reversal point 2: Exact stop fine
FA[Z]=150 FA[X]=0.5	; Oscillating axis Z feedrate, infeed axis X feedrate
OSCTRL[Z]=(2+8+16.1)	; Deactivate oscillating motion at reversal point 2; after delete DTG spark-out and approach end position; after delete DTG approach reversal position
OSNC[Z]=3	; Sparking-out strokes
OSE[Z]=70	; End position = 70
ii2=2	; Set reversal point range
WAITP(Z)	; Enable oscillation for Z axis

2. Synchronized action

Program code	Comment
WHENEVER \$AA_IM[Z]<\$SA_OSCILL_REVERSE_POS2[Z] DO -> \$AA_OVR[X]=0 \$AC_MARKER[0]=0	; If the actual position of oscillating axis Z in MCS is less than the start of reversal range 2, then always set the axial override of the infeed axis X to 0% and the bit memory with index 0 to the value 0.

Program code	Comment
WHENEVER \$AA_IM[Z]>=\$SA_OSCILL_REVERSE_POS2[Z] DO \$AA_OVR[Z]=0	; If the actual position of the oscillating axis Z in MCS is greater than the reversal position 2, then always set the axial override of the oscillating axis Z to 0%.
WHENEVER \$AA_DTEPW[X] == 0 DO \$AC_MARKER[0]=1	; If the remaining distance to go of the partial infeed is 0, then always set the bit memory with index 0 to the value 1.
WHENEVER \$AC_MARKER[0]==1 DO \$AA_OVR[X]=0 \$AA_OVR[Z]=100	; Whenever the bit memory with index 0 is equal to 1, then set the axial override of the infeed axis X to 0%. As a consequence, a premature infeed is prevented (oscillating axis Z has still not left reversal area 2, but infeed axis X is ready for a new infeed). Set the axial override of oscillating axis Z from 0% (action of the 2nd synchronized action) back to 100% to move.

-> must be programmed in a single block

3. Start oscillation

Program code	Comment
OSCILL[Z]=(X) POSP[X]=(5,1,1)	; Start the axes Oscillating axis Z is assigned axis X as infeed axis. Up to end position 5, axis X should travel in steps of 1.
M30	; End of program

Further information

1. Define oscillation parameters

The parameters for oscillation should be defined before the movement block containing the assignment of infeed and oscillating axes and the infeed definition (see "Asynchronized oscillation").

2. Define motion-synchronized actions

The following synchronization conditions can be defined:

Suppress infeed until the oscillating axis is located within a reversal area (ii1, ii2) or at a reversal point (U1, U2).

Stop oscillation motion during infeed at reversal point.

Restart oscillation movement on completion of partial infeed. Define **start of next partial infeed**.

3. Assign oscillating and infeed axes as well as partial and complete infeed.

Define oscillation parameters

Assignment of oscillating and infeed axes: OSCILL

```
OSCILL[<oscillating axis>]=(<infeed axis1>,<infeed axis2>,<infeed axis3>)
```

The axis assignments and the start of the oscillation movement are defined with the "OSCILL" command.

Up to 3 infeed axes can be assigned to an oscillating axis.

Note

Before oscillation starts, the synchronization conditions must be defined for the behavior of the axes.

Define infeeds: POSP

```
POSP[<infeed axis>]=(<end position>,<partial length>,<mode>)
```

The following are declared to the control with the "POSP" command:

- Complete infeed (with reference to end position)
- The length of the partial infeed at the reversal point or in the reversal area
- The partial infeed response when the end position is reached (with reference to mode)

Mode = 0	The distance-to-go to the destination point for the last two partial infeeds is divided into two equal steps (default setting).
Mode = 1	All partial infeeds are of equal size. They are calculated from the complete infeed.

Define motion-synchronized actions

The synchronized-motion actions listed below are used for general oscillation.

You are given example solutions for individual tasks, which you can use as modules for creating user-specific oscillation movements

Note

In individual cases, the synchronization conditions can be programmed differentially.

Keywords

WHEN ... DO ...	when..., do...
WHENEVER ... DO	whenever..., do...

Functions

You can implement the following functions with the language resources described in detail below:

1. Infeed at reversal point.
2. Infeed at reversal area.
3. Infeed at both reversal points.
4. Stop oscillation movement at reversal point.
5. Restart oscillation movement.
6. Do not start partial infeed too early.

The following assumptions are made for all examples of synchronized actions presented here:

- Reversal point 1 < reversal point 2
- Z = oscillating axis
- X = infeed axis

Note

For more details, see the "Motion-synchronous actions" section.

Assign oscillating and infeed axes as well as partial and complete infeed

Infeed in reversal point range

The infeed motion must start within a reversal area before the reversal point is reached.

These synchronized actions inhibit the infeed movement until the oscillating axis is within the reversal area.

The following instructions are used subject to the above assumptions:

Reversal range 1:

```
WHENEVER $AA_IM[Z]>$SA_OSCILL_RESERVE_POS1[Z]+ii1 DO $AA_OVR[X] = 0
```

Whenever the actual position of the oscillating axis in the MCS is greater than the start of reversal range 1, then set the axial override of the infeed axis to 0%.

Reversal range 2:

```
WHENEVER $AA_IM[Z]<$SA_OSCILL_RESERVE_POS2[Z]+ii2 DO $AA_OVR[X] = 0
```

Whenever the actual position of the oscillating axis in the MCS is less than the start of reversal range 2, then set the axial override of the infeed axis to 0%.

Infeed at reversal point

As long as the oscillation axis has not reached the reversal point, the infeed axis does not move.

The following instructions are used subject to the above assumptions:

Reversal range 1:

```
WHENEVER $AA_IM[Z]<>$SA_OSCILL_RESERVE_POS1[Z] DO $AA_OVR[X]=0
$AA_OVR[Z]=100
```

Whenever the actual position of oscillating axis Z in MCS is greater or less than the position reversal point 1, then set the axial override of the infeed axis X to 0% and the axial override of the oscillating axis Z to 100%.

Reversal range 2:

For reversal point 2:

```
WHENEVER $AA_IM[Z]<>$SA_OSCILL_RESERVE_POS2[Z] DO $AA_OVR[X]=0
$AA_OVR[Z]=100
```

Whenever the actual position of oscillating axis Z in MCS is greater or less than the position reversal point 2, then set the axial override of the infeed axis X to 0% and the axial override of the oscillating axis Z to 100%.

Stop oscillation movement at the reversal point

The oscillation axis is stopped at the reversal point, the infeed motion starts at the same time. The oscillating motion is continued when the infeed movement is complete.

At the same time, this synchronized action can be used to start the infeed movement if this has been stopped by a previous synchronized action, which is still active.

The following instructions are used subject to the above assumptions:

Reversal range 1:

```
WHENEVER $SA_IM[Z]==$SA_OSCILL_RESERVE_POS1[Z] DO $AA_OVR[X]=0
$AA_OVR[Z]=100
```

Whenever the actual position of the oscillating axis in the MCS is the same as the reversal position 1, then set the axial override of the oscillating axis to 0% and the axial override of the infeed axis to 100%.

Reversal range 2:

```
WHENEVER $SA_IM[Z]==$SA_OSCILL_RESERVE_POS2[Z] DO $AA_OVR[X]=0
$AA_OVR[Z]=100
```

Whenever the actual position of the oscillating axis Z in the MCS is the same as the reversal position 2, then set the axial override of the oscillating axis X to 0% and the axial override of the infeed axis to 100%.

Online evaluation of reversal point

If there is a main run variable coded with \$\$ on the right of the comparison, then the two variables are evaluated and compared with one another continuously in the IPO cycle.

Note

Please refer to Section "Motion-synchronized actions" for more information.

Oscillation movement restarting

The purpose of this synchronized action is to continue the movement of the oscillation axis on completion of the part infeed movement.

The following instructions are used subject to the above assumptions:

```
WHENEVER $AA_DTEPW[X]==0 DO $AA_OVR[Z]= 100
```

Whenever the remaining distance for the partial infeed of infeed axis X in the WCS is equal to zero, then set the axial override of the oscillating axis to 100%.

Next partial infeed

When infeed is complete, a premature start of the next partial infeed must be inhibited.

A channel-specific marker (`$AC_MARKER[Index]`) is used for this purpose. It is enabled at the end of the partial infeed (partial distance-to-go \equiv 0) and deleted when the axis leaves the reversal area. The next infeed movement is then prevented by a synchronized action.

On the basis of the given assumptions, the following instructions apply for reversal point 1:

1. Set marker:

```
WHENEVER $AA_DTEPW[X] == 0 DO $AC_MARKER[1]=1
```

Whenever the remaining distance for the partial infeed of infeed axis X in the WCS is equal to zero, then set the bit memory with index 1 to 1.

2. Delete marker

```
WHENEVER $AA_IM[Z]<> $SA_OSCILL_RESERVE_POS1[Z] DO $AC_MARKER[1] = 0
```

Whenever the actual position of oscillating axis Z in the MCS is greater or less than the position of reversal point 1, then set the bit memory 1 to 0.

3. Inhibit infeed

```
WHENEVER $AC_MARKER[1]==1 DO $AA_OVR[X]=0
```

Whenever bit memory 1 is the same, then set the axial override of the infeed axis X to 0%.

3.19 Grinding

3.19.1 Activate/deactivate grinding-specific tool monitoring (TMON, TMOF)

With the predefined procedures TMON(...) and TMOF(...), the grinding-specific tool monitoring is activated or deactivated (geometry and speed monitoring).

Requirement

The tool-specific parameters \$TC_TPG1 to \$TC_TPG9 must be set.

Syntax

```
TMON (<TNo>)
...
TMOF (<TNo>)
```

Meaning

TMON (. . .) :	Activate grinding-specific tool monitoring The command must be programmed in the channel in which the grinding-specific tool monitoring is to be activated.
TMOF (. . .) :	Deactivate grinding-specific tool monitoring The command must be programmed in the channel in which the grinding-specific tool monitoring is to be deactivated.
<TNo>:	T number Note: Only required if the monitoring is to be switched on or off for an inactive grinding wheel rather than the active grinding wheel that is currently in use.
TMOF (0) :	Deactivate monitoring for all tools

3.20 Program runtime/part counter

Information on the program runtime and workpiece counter is provided to support the machine tool operator.

This information can be processed as system variables in the NC and/or PLC program. This information is also available to be displayed on the operator interface.

3.20.1 Program runtime

The "program runtime" function provides internal NC timers to monitor technological processes, which can be read into the part program and into synchronized actions via the NC and channel-specific system variables.

The trigger for the runtime measurement (\$AC_PROG_NET_TIME_TRIGGER) is the only system variable of the function that can be written to – and is used to selectively measure program sections. This means, by writing \$AC_PROG_NET_TIME_TRIGGER in the NC program, the time measurement can be enabled and disabled again:

System variable	Meaning	Activity
NC-specific		
\$AN_SETUP_TIME	Time since the last control power up with default values ("cold restart") in minutes. Is automatically reset to "0" every time the control powers up with default values.	<ul style="list-style-type: none"> Always active
\$AN_POWERON_TIME	Time since the last normal control power up ("warm restart") in minutes. Is automatically reset to "0" every time the control powers up normally.	
Channel-specific		
\$AC_OPERATING_TIME	Total runtime of NC programs in automatic mode in seconds. The value is automatically reset to "0" every time the control powers up.	<ul style="list-style-type: none"> Activated via MD27860 Only AUTOMATIC mode
\$AC_CYCLE_TIME	Runtime of the selected NC program in seconds. The value is automatically reset to "0" every time a new NC program starts up.	
\$AC_CUTTING_TIME	Processing time in seconds The runtime of the path axes (at least one is active) is measured in all NC programs between NC start and end of program/NC reset without rapid traverse active. The measurement is interrupted when a dwell time is active. The value is automatically reset to "0" every time the control powers up with default values.	

System variable	Meaning	Activity	
\$AC_ACT_PROG_NET_TIME	Actual net runtime of the current NC program in seconds. Is automatically reset to "0" when a new NC program starts.	<ul style="list-style-type: none"> Always active Only AUTOMATIC mode 	
\$AC_OLD_PROG_NET_TIME	Net runtime in seconds of the program that has just been correctly ended with M30		
\$AC_OLD_PROG_NET_TIME_COUNT	Changes to \$AC_OLD_PROG_NET_TIME After POWER ON, \$AC_OLD_PROG_NET_TIME_COUNT is at "0". \$AC_OLD_PROG_NET_TIME_COUNT is always increased if the control has newly written to \$AC_OLD_PROG_NET_TIME.		
\$AC_PROG_NET_TIME_TRIGGER	Trigger for the runtime measurement:	<ul style="list-style-type: none"> Only AUTOMATIC mode 	
	0		Neutral state The trigger is not active.
	1		Exit Ends the measurement and copies the value from \$AC_ACT_PROG_NET_TIME into \$AC_OLD_PROG_NET_TIME. \$AC_ACT_PROG_NET_TIME is set to "0" and then continues to run.
	2		Start Starts the measurement and in so doing sets \$AC_ACT_PROG_NET_TIME to "0". \$AC_OLD_PROG_NET_TIME is not changed.
	3		Stop Stops the measurement. Does not change \$AC_OLD_PROG_NET_TIME and keeps \$AC_ACT_PROG_NET_TIME constant until it resumes
4	Resume The measurement is resumed, i.e. a measurement that was previously stopped is continued. \$AC_ACT_PROG_NET_TIME continues. \$AC_OLD_PROG_NET_TIME is not changed.		
All system variables are reset to 0 as a result of POWER ON!			

Note**Machine manufacturer**

Machine data MD27860 \$MC_PROCESSTIMER_MODE is used to switch-in the timer that can be activated.

The behavior of active time measurements for certain functions (e.g. GOTOS, override = 0%, active test run feed, program test, ASUB, PROG_EVENT, ...) is configured using machine data MD27850 \$MC_PROG_NET_TIMER_MODE and MD27860 \$MC_PROCESSTIMER_MODE.

References:

Function Manual, Basic Functions; BAG, Channel, Program Operation, Reset Response (K1), Chapter: Program runtime

Note

Residual time for a workpiece

If the same workpieces are machined one after the other, using the following timer values, the remaining residual time for a workpiece can be determined.

- Processing time for the last workpiece produced (see \$AC_OLD_PROG_NET_TIME)
- Current processing time (see \$AC_ACT_PROG_NET_TIME)

The residual time is displayed on the user interface in addition to the current processing time.

Note

Using STOPRE

The system variables \$AC_OLD_PROG_NET_TIME and \$AC_OLD_PROG_NET_TIME_COUNT do not generate any implicit preprocessing stop. This is uncritical when used in the part program if the value of the system variables comes from the previous program run. However, if the trigger for the runtime measurement (\$AC_PROG_NET_TIME_TRIGGER) is written very frequently and as a result \$AC_OLD_PROG_NET_TIME changes very frequently, then an explicit STOPRE should be used in the part program.

Supplementary conditions

- **Block search**
No program runtimes are determined through block searches.
- **REPOS**
The duration of a REPOS process is added to the current processing time (\$AC_ACT_PROG_NET_TIME).

Examples

Example 1: Measuring the duration of "mySubProgrammA"

Program code

```
...
N50 DO $AC_PROG_NET_TIME_TRIGGER=2
N60 FOR ii= 0 TO 300
N70 mySubProgrammA
N80 DO $AC_PROG_NET_TIME_TRIGGER=1
N95 ENDFOR
N97 mySubProgrammB
N98 M30
```

After the program has processed line N80, the net runtime of "mySubProgrammA" is located in \$AC_OLD_PROG_NET_TIME.

The value from \$AC_OLD_PROG_NET_TIME:

- is kept beyond M30.
- is updated each time the loop is run through.

Example 2: Measuring the duration of "mySubProgrammA" and "mySubProgrammC"

```

Program code
...
N10 DO $AC_PROG_NET_TIME_TRIGGER=2
N20 mySubProgrammA
N30 DO $AC_PROG_NET_TIME_TRIGGER=3
N40 mySubProgrammB
N50 DO $AC_PROG_NET_TIME_TRIGGER=4
N60 mySubProgrammC
N70 DO $AC_PROG_NET_TIME_TRIGGER=1
N80 mySubProgrammD
N90 M30

```

3.20.2 Workpiece counter

The "Workpiece counter" function makes available various counters which can be used in particular internally in the control to count workpieces.

The counters exist as channel-specific system variables with read and write access in a range of values from 0 to 999 999 999.

System variable	Meaning
\$AC_REQUIRED_PARTS	Number of workpieces to be produced (setpoint number of workpieces) In this counter the number of workpieces at which the actual workpiece count (\$AC_ACTUAL_PARTS) will be reset to "0" can be defined.
\$AC_TOTAL_PARTS	Total number of completed workpieces (actual workpiece total) This counter specifies the total number of all workpieces produced since the start time. The value is only automatically reset to "0" when the control powers up with default values.
\$AC_ACTUAL_PARTS	Number of completed workpieces (actual workpiece total) This counter registers the total number of all workpieces produced since the start time. On condition that \$AC_REQUIRED_PARTS > 0, the counter is automatically reset to "0" when the required number of workpieces (\$AC_REQUIRED_PARTS) is reached.
\$AC_SPECIAL_PARTS	Number of workpieces selected by the user This counter supports user-specific workpiece counts. An alarm can be defined to be output when the setpoint number of workpieces is reached (\$AC_REQUIRED_PARTS). Users must reset the counter themselves.

Note

All workpiece counters are set to "0" when the control powers up with default values and can be read and written independent of their activation.

Note

Channel-specific machine data can be used to control counter activation, counter reset timing and the counting algorithm.

Note

Workpiece counting with user-defined M command

Machine data can be set so that the count pulses for the various workpiece counters are triggered using user-defined M commands rather than the end of the program (M2/M30).

3.21 Additional functions

3.21.1 Activate machine data (NEWCONF)

The `NEWCONF` command activates all machine data. The function can also be activated in the HMI user interface by pressing the "MD data effective" softkey.

When the "NEWCONF" function is executed there is an implicit preprocessing stop; in other words, path movement is interrupted.

Syntax

```
NEWCONF
```

Meaning

NEWCONF:	Command for setting all machine data of the "NEW_CONFIG" effectiveness level active
----------	---

Cross-channel execution of NEWCONF from the part program

If changes are made to axial machine data from the part program and then activated with `NEWCONF`, `NEWCONF` will only activate the machine data containing changes affecting the part program channel.

Note

In order to ensure that all changes are applied, the `NEWCONF` command must be executed in every channel in which the axes or functions affected by the changes to the machine data is being calculated.

No axial machine data is effective for `NEWCONF`.

An axial RESET must be performed for axes controlled by the PLC.

Example

Milling: Machine drill position with different technologies

Program code	Comment
N10 \$MA_CONTOUR_TOL[AX]=1.0	; Change machine data.
N20 NEWCONF	; Activate machine data.
...	

3.21.2 Check scope of NC language present (STRINGIS)

Using the function "STRINGIS(...)" it can be checked as to whether the specified string is available as element of the NC programming language in the actual language scope.

Definition

INT STRINGIS (STRING <Name>)

Syntax

STRINGIS (<Name>)

Meaning

STRINGIS:	Function with return value
<name>:	Name of the NC programming language element to be checked
Return value:	The return value format is yxx (decimal).

Elements of the NC programming language

The following elements of the NC programming language can be checked:

- G commands of all existing G groups, e.g. "G0", "INVCW", "POLY", "ROT", "KONT", "SOFT", "CUT2D", "CDON", "RMBBL", "SPATH"
- DIN or NC addresses, such as "ADIS", "RNDM", "SPN", "SR", "MEAS"
- Functions, e.g. "TANG(...)" or "GETMDACT"
- Procedures, e.g. "SBLOF".
- Keywords, e.g. "ACN", "DEFINE" or "SETMS"
- System data, e.g. machine data \$M... , setting data \$S... or option data \$O...
- System variables \$A... , \$V... , \$P...
- Arithmetic parameter R...
- Cycle names of activated cycles
- GUD and LUD variables
- Macro names
- Label names

Return value

Only the first three decimal positions of the return value are relevant. The return value format is yxx, with y = basis information and xx = detailed information.

Return value	Meaning
000	The 'name' string is not known in this system ¹⁾
100	The 'name' string is an element of the NC programming language, but currently cannot be programmed (option/function is inactive)

Return value	Meaning	
2xx	The 'name' string is a programmable element of the NC programming language (option/function is active). The detailed information xx contains additional information about the element type:	
	xx	Meaning
	01	DIN address or NC address ²⁾
	02	G command (e.g. G04, INVCW)
	03	Function with return value
	04	Function without return value
	05	Keyword, e.g. DEFINE
	06	Machine (\$M...), setting (\$S...) or option data (\$O...)
	07	System parameters, e.g. system variable (\$...) or arithmetic parameter (R...)
	08	Cycle (the cycle must be loaded into the NC and the cycle program must be active ³⁾)
	09	GUD variable (the GUD variable must be defined in the GUD definition files and the GUD variables activated)
	10	Macro name (the macro must be defined in the macro definition files and macros activated) ⁴⁾
	11	LUD variable of the actual part program
	12	ISO G command (ISO language mode must be active)
400	The 'name' string is an NC address, that was not identified as xx == 01 or xx == 10 and is not G or R ²⁾	
y00	No specific assignment possible	
<p>1) Depending on the control, under certain circumstances, only a subset of the Siemens NC language commands are known, e.g. SINUMERIK 802D sl. For these controls, for strings that are principally Siemens NC language commands, a value of 0 is returned. This behavior can be changed using MD10711 \$MN_NC_LANGUAGE_CONFIGURATION. For MD10711 = 1, then a value of 100 is always returned for Siemens NC language commands.</p> <p>2) NC addresses are the following letters: A, B, C, E, I, J, K, Q, U, V, W, X, Y, Z. These NC addresses can also be programmed with an address extension. The address extension can be specified when checking with STRINGIS. Example: 201 == STRINGIS("A1").</p> <p>The letters: D, F, H, L, M, N, O, P, S, T are NC addresses or auxiliary functions that are defined by the user. A value of 400 is always returned for these. Example: 400 == STRINGIS("D"). These NC addresses cannot be specified with address extension when checking with STRINGIS.</p> <p>Example: 000 == STRINGIS("M02"), but 400 == STRINGIS("M").</p> <p>3) Names of cycle parameters cannot be checked with STRINGIS.</p> <p>4) Address, defined as macro, e.g. G, H, M, L are identified as macro.</p>		

Examples

In the following examples it is assumed that the NC language elements specified as string - as long as nothing else is noted - can in principle be programmed in the control.

1. String "T" is defined as auxiliary function:

```
400 == STRINGIS("T")
000 == STRINGIS("T3")
```

2. String "X" is defined as axis:

```
201 == STRINGIS("X")
201 == STRINGIS("X1")
```

3. String "A2" is defined as address with extension:

```
201 == STRINGIS("A")
201 == STRINGIS("A2")
```

4. String "INVCW" is defined as named G command:

```
202 == STRINGIS("INVCW")
```

5. String "\$MC_GCODE_RESET_VALUES" is defined as machine data:
206 == STRINGIS("\$MC_GCODE_RESET_VALUES")
6. String "GETMDACT" is an NC language function:
203 == STRINGIS("GETMDACT ")
7. String "DEFINE" is a keyword:
205 == STRINGIS("DEFINE")
8. String "\$TC_DP3" is a system parameter (tool length component):
207 == STRINGIS("\$TC_DP3")
9. String "\$TC_TP4" is a system parameter (tool size):
207 == STRINGIS("\$TC_TP4")
10. String "\$TC_MPP4" is a system parameter (magazine location state):
 - Tool magazine management is active: 207 == STRINGIS("\$TC_MPP4") ;
 - Tool magazine management is not active: 000 == STRINGIS("\$TC_MPP4")Also refer to the paragraph below: Tool magazine management.
11. String "MACHINERY_NAME" is defined as GUD variable:
209 == STRINGIS("MACHINERY_NAME")
12. String "LONGMACRO" is defined as macro:
210 == STRINGIS("LONGMACRO")
13. String "MYVAR" is defined as LUD variable:
211 == STRINGIS("MYVAR")
14. String "XYZ" is a command that is not known in the NC, GUD variable, macro or cycle name:
000 == STRINGIS("XYZ")

Tool magazine management

If the tool magazine management function is not active, supplies STRINGIS for the system parameters of the tool magazine management, independent of the machine data

- MD10711 \$MN_NC_LANGUAGE_CONFIGURATION

always a value of 000.

ISO mode

If the "ISO mode" function is active:

- MD18800 \$MN_MM_EXTERN_LANGUAGE (activation, external NC languages)
- MD10880 \$MN_MM_EXTERN_CNC_SYSTEM (control system to be adapted)

STRINGIS checks the specified string initially as SINUMERIK G command. If the string is not a SINUMERIK G command, then it is subsequently checked as ISO G command.

Programmed switchovers (G290 (SINUMERIK mode), G291 (ISO Mode)) have no effect on STRINGIS.

Example

The machine data, relevant for the function STRINGIS(...), has the following values:

- MD10711 \$MN_NC_LANGUAGE_CONFIGURATION = 2 (only the NC language commands whose options are set are considered to be known)
- MD19410 \$ON_TRAFO_TYPE_MASK = 'H0' (option: transformations)
- MD10700 \$MN_PREPROCESSING_LEVEL='H43' (preprocessing for cycles is active)

The following program example is executed without error message:

Program code	Comment
N1 R1=STRINGIS("TRACYL")	; R1 == 0, because TRACYL is identified as "not known" because of the missing transformation option
N2 IF STRINGIS("TRACYL") == 204	
N3 TRACYL(1,2,3)	; N3 is skipped
N4 ELSE	
N5 G00	; and instead, N5 is executed
N6 ENDIF	
N7 M30	

3.21.3 Interactively call the window from the part program (MMC)

User-specific dialogs from an NC program can be displayed on the user interface via the predefined subprogram MMC(...).

The configuration of the dialogs can be done for the following types of dialogs:

- Run MyScreens
- Easy XML
- User XML

Further information:

- Programming Manual Run MyScreens
- Programming Manual Easy XML

Syntax

```
MMC ("<ADDRESS>, <COMMAND>, <FILE>, <DIALOG>", "<QUIT>")
```

Meaning

MMC (...):	Subprogram identifier The parameters are specified position-coded and separated by a comma within two strings, the command string and the acknowledgement string.
Parameters within the command string:	

3.21 Additional functions

<ADDRESS>:	Operating area in which the configured user dialog boxes are implemented	
	Function	Operating areas
	"Run MyScreens" user dialog	CYCLES
	"Easy XML" user dialog	CYCLES
	User XML	XML
	Pop-up window "Run MyScreens"	POPUDDLG
	Popup window "Easy XML"	POPUDDLG
<COMMAND>:	Command to be executed	
	Function	Commands
	"Run MyScreens" user dialog	PICTURE_ON, PICTURE_OFF
	"Easy XML" user dialog	PICTURE_ON, PICTURE_OFF
	User XML	XML_ON, XML_OFF
	Pop-up window "Run MyScreens"	PICTURE_ON, PICTURE_OFF
	Popup window "Easy XML"	PICTURE_ON, PICTURE_OFF
<FILE>:	Name of the file in which the dialog to be displayed is programmed	
	Function	Files
	"Run MyScreens" user dialog	<name>.com
	"Easy XML" user dialog	<name>.xml
	User XML	<name>.xml
	Pop-up window "Run MyScreens"	<name>.com
	Popup window "Easy XML"	<name>.xml
Popup window "Easy XML" with configuration direct in the NC program (see example 2)	xml_dial_emb.xml	
<DIALOG>:	Name of the dialog to be displayed	
	Function	Dialog name
	All functions except popup window "Easy XML" with configuration direct in the NC program	Name of the dialog configured in the <FILE> file
	Popup window "Easy XML" with configuration direct in the NC program (see example 3)	main
Parameters within the acknowledgment string:		
<QUIT>:	Acknowledgment type	
	N:	No acknowledgment. Program execution is continued after the command has been sent. There is no feedback if the command could not be successfully executed. Note Acknowledgement type "N" must be used if a display time (dwell time) is programmed in the NC program (see Example 2 below)
	A:	Asynchronous acknowledgment The program execution is continued after the command is issued. The return value is saved in a user-specific acknowledgement variable (GUD variable), which is defined within the scope of the dialog configuration, and can be read in the NC program.

Supplementary conditions

- The definition files *.com of the dialogs must be saved in the "proj" folder.
- The Easy XML definition files *.xml of the dialogs must be saved in the "appl" folder.
If the definition files are saved in a different directory, the path must be specified indirectly, starting from the "appl" directory.
- User-defined dialogs from different channels cannot be simultaneously displayed.
- The MMC functionality is not supported in the simulation.

Examples

Example 1

Display of a dialog and response to the user operation in an NC program.

Program code	Comment
; The acknowledgement variable QUIT has already been created as a global user variable (GUD)	
; Of the type STRING when the dialog was configured:	
; DEF NCK STRING[20] QUIT	
QUIT = "XXX"	; Initialize acknowledgment variable
G4 F5	
MMC("CYCLES,PIC-	; Display dialog
TURE_ON,test.com,test1","A")	; - Operating area: CYCLES
	; - Picture status: PICTURE_ON (display)
	; - Dialog screen file: test.com
	; - Dialog screen: test1
INPUT:	; Wait for user input
STOPRE	; Preprocessing stop
IF MATCH (QUIT,"RUN") >= 0 GOTOF WORK	; Softkey "RUN"
IF MATCH (QUIT,"CHK") >= 0 GOTOF CHECK	; Softkey "CHK"
GOTOF INPUT	; => Wait
WORK:	; Softkey "RUN" pressed
MSG("Continue with processing -> NC start")	; Output message
MMC("CYCLES,PICTURE_OFF","N")	; Close dialog
M0	; Wait for NC start
GOTOF END	; => Program end
CHECK:	; Softkey "CHK" pressed
MSG("Approach position -> NC start")	; Output message
MMC("CYCLES,PICTURE_OFF","N")	; Close dialog
M0	; Wait for NC start
GOTOF END	; => Program end

Program code	Comment
END:	
...	

Example 2

The display time of a dialog is defined in the NC program via a dwell time, for example.

Program code	Comment
F1000 G94	
...	
MMC("POPUPDLG, PICTURE_ON, xmldial_emb.xml, main", "N")	; Display dialog
X200	
Z40	
MMC("POPUPDLG, PICTURE_OFF", "N")	; Close dialog

Example 3

Embedding a popup script in an NC program and its use.

Program code

```

PROC POPUP_TEST
; ----- Script -----
; <main_dialog entry="rpara_main">
;   <let name="xpos" />
;   <let name="ypos" />
;   <let name="field_name" type="string" />
;   <let name="num" />
;   <menu name="rpara_main">
;     <open_form name="rpara_form"/>
;     <softkey_back>
;       <close_form />
;     </softkey_back>
;   </menu>
;   <form name="rpara_form">
;     <init>
;       <caption>mask from NC part program</caption>
;       <let name="count" >0</let>
;       <op>
;         xpos = 120;
;         ypos = 34;
;         "nck/Channel/Parameter/R[10]" = 10;
;       </op>
;       <!-- load the number of controls -->
;       <op>
;         num = "nck/Channel/Parameter/R[10]";
;       </op>
;     <while>

```

Program code

```

;          <condition> count < num</condition>
;          <print name="field_name" text="edit%d">count</print>
;          <op>
;              ypos = ypos + 24;
;              count = count + 1;
;          </op>
;      </while>
;  </init>
;  <paint>
;      <op>
;          xpos = 8;
;          ypos = 36;
;          count = 0;
;      </op>
;      <while>
;          <condition>count < num</condition>
;          <print name="field_name" text="R-Parameter%d">count</print>
;          <text xpos = "$xpos" ypos = "$ypos" >$$$field_name</text>
;          <op>
;              ypos = ypos + 24;
;              count = count + 1;
;          </op>
;      </while>
;  </paint>
; </form>
; </main_dialog>
; ===== Program section =====
...
G94 F100
MMC ("POPUDDL,PICTURE_ON,xmldial_emb.xml,main","N")
G4 F4
X200
MMC ("POPUDDL,PICTURE_OFF","N")
G4 F2
X0
...

```

3.21.4 Process DataShare - Output to an external device/file (EXTOPEN, WRITE, EXTCLOSE):

The writing of data from a part program to an external device/file is performed in three steps:

1. Open the external device/file
The external device/file is opened for the channel for writing using the EXTOPEN command.
2. Writing data
The output data can be processed using the string functions of the NC language, e.g. SPRINT. The WRITE command is used for writing.
3. Close the external device/file
The external device/file assigned in the channel is released again using the EXTCLOSE command, when the end of the program is reached (M30) or for a channel reset.

Syntax

```
DEF INT <Result>
DEF STRING[<n>] <Output>
...
EXTOPEN(<Result>,<ExtDev>,<SyncMode>,<AccessMode>,<WriteMode>)
...
<Output>="data output"
WRITE(<Result>,<ExtDev>,<Output>)
...
EXTCLOSE(<Result>,<ExtDev>)
```


Meaning

EXTOPEN:	Pre-defined procedure to open an external device/file		
<Result>:	Parameter 1: Result variable		
	By using the result variable value, it can be evaluated in the program as to whether the operation was successful and processing is then appropriately continued.		
	Type:	INT	
	Values:	0	No error
		1	External device cannot be opened
		2	External device is not configured
		3	External device with invalid path configured
		4	No access rights for external device
		5	Usage mode: External device already "exclusively" occupied
		6	Usage mode: External device already being "shared"
		7	File length longer than LOCAL_DRIVE_MAX_FILESIZE
		8	Maximum number of external devices has been exceeded
		9	Option for LOCAL_DRIVE not set
		11	Reserved
12		Write mode: Data contradicts extdev.ini	
16		Invalid external path has been programmed	
22	External device not mounted		

<Ext.Dev>:	Parameter 2: Symbolic identifier for the external device/file to be opened					
	Type:	STRING				
	The symbolic identifier comprises: <ol style="list-style-type: none"> 1. the logical device name 2. where relevant, followed by a file path (attached using "/"). The following logical device names have been defined:					
	"LOCAL_DRIVE":	Local CF card (pre-defined)				
	"CYC_DRIVE":	Reserved drive name for use in SIEMENS cycles (pre-defined)				
	"/dev/ext/1", ... "/dev/ext/9":	Available network drives Note: It is necessary to configure in the extdev.ini file!				
	"/dev/cyc/1", "/dev/cyc/2":	Reserved drive names for use in SIEMENS cycles Note: It is necessary to configure in the extdev.ini file!				
	File path: <ul style="list-style-type: none"> • A file path must be specified for "LOCAL_DRIVE" and "CYC_DRIVE" e.g. "LOCAL_DRIVE/my_dir/my_file.txt" • The logical device names "/dev/ext/1...9" and "/dev/cyc/1...2" can be configured: <ul style="list-style-type: none"> – To already refer to a file, in which case only the logical device names may be specified, e.g.: "/dev/ext/4" – Or to a directory, in which case a file path must be specified, e.g.: "/dev/ext/5/my_dir/my_file.txt" 					
	Note: For the logical device names "/dev/ext/1...9", "/dev/v24" and "/dev/cyc/1...2" uppercase/lowercase is ignored; uppercase/lowercase is significant for specifying a path to a file. Only uppercase letters are permissible for "LOCAL_DRIVE" and "CYC_DRIVE".					
	<SyncMode>:	Parameter 3: Processing mode for the WRITE commands to this device/file				
Type:		STRING				
Values:		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">"SYN":</td> <td style="padding: 5px;"> Synchronous writing Program execution is stopped until the write operation has been completed. Successfully completing the synchronous write operation can be checked by evaluating the error variables of the WRITE command. </td> </tr> <tr> <td style="padding: 5px;">"ASYN":</td> <td style="padding: 5px;"> Asynchronous writing Program execution is not interrupted by the WRITE command. Note. In this mode, the result variable of the WRITE command does not provide any information and always has the value 0 (no error). In this particular mode, there is no certainty that the WRITE command was successful. </td> </tr> </table>	"SYN":	Synchronous writing Program execution is stopped until the write operation has been completed. Successfully completing the synchronous write operation can be checked by evaluating the error variables of the WRITE command.	"ASYN":	Asynchronous writing Program execution is not interrupted by the WRITE command. Note. In this mode, the result variable of the WRITE command does not provide any information and always has the value 0 (no error). In this particular mode, there is no certainty that the WRITE command was successful.
"SYN":		Synchronous writing Program execution is stopped until the write operation has been completed. Successfully completing the synchronous write operation can be checked by evaluating the error variables of the WRITE command.				
"ASYN":	Asynchronous writing Program execution is not interrupted by the WRITE command. Note. In this mode, the result variable of the WRITE command does not provide any information and always has the value 0 (no error). In this particular mode, there is no certainty that the WRITE command was successful.					

<AccessMode>:	Parameter 4: Usage mode for this device/file		
	Type:	STRING	
	Values:	"SHARED":	Device/file is requested in the "shared" mode. Other channels can also use the device, i.e. also open in this mode.
"EXCL":		Device/file is exclusively used in the channel; no other channel can use the device.	
<WriteMode>:	Parameter 5: Write mode for the WRITE commands to this file/device (optional)		
	Type:	STRING	
	Values:	"APP":	Attaching The file is always kept regarding its contents; write calls are attached at the end.
		"OVR":	Overwrite The contents of the file are deleted and re-generated using the subsequent write calls.
Note: Using this parameter, the write mode configured in the extdev.ini file cannot be overwritten. In the case of a conflict, then the EXTOPEN call is acknowledged with error.			

WRITE:	Pre-defined procedure to write output data
--------	--

EXTCLOSE:	Pre-defined procedure to close an external device/file that has been opened		
<Result>:	Parameter 1: Result variable		
	Type:	INT	
	Values:	0	No error
		16	Invalid external path has been programmed
21		Error when closing the external device	
<ExtDev>:	Parameter 2: Symbolic identifier for the external device/file description to be closed, see EXTOPEN! Note: The identifier must be identical to the identifier specified in the EXTOPEN call!		

Example

Program code	
N10	DEF INT RESULT
N20	DEF BOOL EXTDEVICE
N30	DEF STRING[80] OUTPUT
N40	DEF INT PHASE
N50	EXTOPEN (RESULT, "LOCAL_DRIVE/my_file.txt", "SYN", "SHARED")
N60	IF RESULT > 0
N70	MSG("Error for EXTOPEN:" << RESULT)
N80	ELSE
N90	EXTDEVICE=TRUE

3.21 Additional functions

```

Program code
N100      ENDIF
...
N200      PHASE=4
N210      IF EXTDEVICE
N220          OUTPUT=SPRINT("End phase: %D",PHASE)
N230          WRITE(RESULT,"LOCAL_DRIVE/my_file.txt",OUTPUT)
N240      ENDIF
...
    
```

See also

String operations (Page 437)

Write file (WRITE) (Page 554)

3.21.5 Alarms (SETAL)

Alarms can be set in an NC program. Alarms are displayed in a separate field at the user interface. An alarm always goes hand in hand with a response from the control according to the alarm category.

References:

For further information on alarm responses, refer to the Commissioning Manual.

Syntax

SETAL(<alarm number>[,<character string>])

Meaning

SETAL:	Keyword to program an alarm. SETAL must be programmed in a separate NC block.	
<alarm number>:	Variable of the INT type. Contains the alarm number. The valid range for alarm numbers lies between 60000 and 69999, of which 60000 to 64999 are reserved for SIEMENS cycles and 65000 to 69999 are available to users.	
<character string>:	When programming user cycle alarms, in addition, a character string with up to four parameters can be specified. Variable user texts can be defined in these parameters. However, the following predefined parameters are available:	
	Parameter	Meaning
	%1	Channel number
	%2	Block number, label
	%3	Text index for cycle alarms
	%4	Additional alarm parameters

Note

Alarm texts must be configured in the user interface.

Example

Program code	Comment
...	
N100 SETAL (65000)	;Set alarm no. 65000
...	

3.21.6 Define blank (WORKPIECE)

The controller must know the shape and size of a blank to be able to display it in the graphical simulation. The user therefore has the capability of defining blanks via the user interface or directly in the NC program. The definitions of blanks are retained beyond a (program end/channel/BAG) reset. They are automatically deleted the next time that the control system powers up.

Syntax

```
WORKPIECE("<WP>", "<RefP>", "<ZeroOffset>", "<Type>", <Par5>,
<Par6>, ..., <Par12>)
```

Meaning

WORKPIECE (...):		Predefined procedure for defining a blank	
		Preprocessing stop:	Yes
		Alone in the block:	Yes
Parameters:			
1	"<WP>":	Name of the workpiece (optional)	
		Data type:	STRING
		A specification is only necessary if there can be several workpieces in one channel. Without specifying, "WORKP<n>" is automatically accepted, with <n> being the number of the declaring channel.	

3.21 Additional functions

2	"<RefP>":	Clamping (optional, only for milling machines)		
		Data type:	STRING	
		Range of values:	"Table"	Clamping of the fixed table
			"A"	Clamping on rotary axis A
			"B"	Clamping on rotary axis B
"C"	Clamping on rotary axis C			
Precondition: The table or the rotary axis must be enabled via the corresponding machine data for the clamping of the blank (see SINUMERIK Operate Commissioning Manual).				
3	"<ZeroOffset>":	Settable work offset for positioning the blank (not programmable) The selection of a settable work offset for positioning the blank is only offered for the blank entry via the user interface. For the direct definition of the blank in the part program, the blank always relates to the currently valid work offset.		
4	"<Type>":	Blank shape		
		Data type:	STRING	
		Range of values:	"CYLINDER":	Cylinder
			"PIPE":	Pipe
			"RECTANGLE":	Centered cuboid
"BOX":	Cuboid			
"N_CORNER":	Polygon with n edges			
5 ... 12	<Par5> ... <Par12>:	Parameters for description of the blank shape		
		Data type:	REAL	
		The number of parameters required and their meaning depend on the respective blank shape and the value of the bit parameter. See: <ul style="list-style-type: none"> • "Parameters for description of the blank shape" table • "Bit parameters" table 		
WORPIECE ():		A WORKPIECE call without parameters deletes all blank definitions.		
WORPIECE (<WP>):		A WORKPIECE call with workpiece name only deletes this blank definition.		

Table 3-6 Parameters for description of the blank shape

Blank shape	Parameter							
	<Par5>	<Par6>	<Par7>	<Par8>	<Par9>	<Par10>	<Par11>	<Par12>
Cylinder	Bit parameter Real value that is interpreted as bit-coded integer value. The bits define the meaning of the following parameters (see "Bit parameters" table).	Reference point Z_0	Length Z_1	Machining dimension Z_B	Outer diameter d_0	-	Rotation about rotary axis	-
Pipe		Reference point Z_0	Length Z_1	Machining dimension Z_B	Outer diameter d_0	Wall thickness (inc) / inner diameter d_1 (abs)	Rotation about rotary axis	-
Centered cuboid		Reference point Z_0	Length Z_1	Machining dimension Z_B	Width W	Length L	Rotation about rotary axis	-
Cuboid		Reference point Z_0	Length Z_1	Machining dimension Z_B	X_0	Y_0	X_1	Y_1
Polygon with n edges		Reference point Z_0	Length Z_1	Machining dimension Z_B	Number of corners	Width across flats	Rotation about rotary axis	-

Table 3-7 Bit parameter


Bit	Meaning	
4 (0x0010)	Cuboid: X_1	
	= 0	inc
	= 1	abs
5 (0x0020)	Cuboid: Y_1	
	= 0	inc
	= 1	abs
6 (0x0040)	Length Z_1 (final dimension)	
	= 0	inc
	= 1	abs
Bit 7 (0x0080)	Machining dimension Z_B	
	= 0	inc
	= 1	abs
Bit 8 (0x0100)	Pipe: Wall thickness / inner diameter	
	= 0	inc
	= 1	abs
9 (0x0200)	Polygon with n edges	
	= 0	Width across flats
	= 1	Edge length
12 (0x1000)	Clamping for turning machines	
	= 0	Main spindle
	= 1	Counterspindle

3.21 Additional functions

Bit	Meaning	
13 (0x2000)	Counterspindle	
	= 0	with mirroring
	= 1	without mirroring


Examples

Example 1: Cylinder-shaped blank on a turning machine



Program code	Comment
...	
WORKPIECE(,,,"CYLINDER",0,0,-200,-150,100)	; Blank definition:
	; Blank shape: Cylinder
	; Bit parameter=0(no bit set) → Values for length and machining dimension are incremental, blank on main spindle
	; Reference point (Z0)=0
	; Length (Z1)=-200
	; Machining dimension (ZB)=-150
	; Outer diameter (d0)=100
...	

Example 2: Pipe-shaped blank on a turning machine



Program code	Comment
...	
WORKPIECE(,,, "PIPE", 256, 0, -200, -150, 100, 80)	; Blank definition: ; Blank shape: Pipe ; Bit parameter=256(Bit8=1) → Inner diameter is absolute; length and machining dimension are incremental, blank on main spindle ; Reference point (Z0)=0 ; Length (Z1)=-200 ; Machining dimension (ZB)=-150 ; Outer diameter (d0)=100 ; Inner diameter (d1)=80
...	

3.21.7 Switch language mode (G290, G291)

The controller gives you the capability of reading in part programs from external CNC systems and processing them. The prerequisite is that the corresponding NC language mode (ISO dialect) has been defined during commissioning.

Reference:

Function Manual ISO Dialects

The ISO dialect mode can be activated separately for each channel. For example, channel 1 can run in ISO dialect mode while channel 2 is active in SINUMERIK mode.

The switchover between SINUMERIK mode and ISO dialect mode is done in the NC program via the commands of the G-group 47. The active tool, tool compensation and work offsets are not influenced by the switchover.

Syntax

| G291

...
G290

Meaning

G290:	Activate SINUMERIK language mode	
	Alone in the block:	Yes
	Effective:	Modal
G291:	Activate ISO language mode	
	Alone in the block:	Yes
	Effective:	Modal

Conditions

SINUMERIK mode

- The default of the G commands can be defined for each channel via machine data.
- No language commands from the ISO dialects can be programmed in SINUMERIK mode.

ISO dialect mode

- The ISO dialect mode can be set with machine data as the basic setting of the control system. In ISO dialect mode, the control system then reboots by default.
- Only G commands from the ISO dialect can be programmed. The programming of SINUMERIK G functions is not possible in ISO dialect mode.
- ISO dialect and SINUMERIK language cannot be mixed in the same NC block.
- G commands cannot be used to switch between ISO dialect M (milling) and ISO dialect T (turning).
- Subprograms that are programmed in SINUMERIK mode can be called.
- If SINUMERIK functions are to be used, a switchover to SINUMERIK mode must first be made (see example).

Example

Compression of linear blocks in the ISO dialect mode

Program code	Comment
N5 G290	; Activate SINUMERIK language mode.
N10 COMPON	; COMPON is a command in the Siemens language and activates a compressor function that replaces the successive linear blocks with polynomial blocks with path lengths that are as long as possible.
N15 G291	; Activate ISO language mode.

Program code	Comment
N20 G01 X100 Y100 F1000	; Since COMPON has been activated in SIN-UMERIK mode, even linear blocks in the ISO dialect mode can be compressed with this function.
...	

3.22 User stock removal programs

3.22.1 Supporting functions for stock removal

Preprogrammed stock removal programs are provided for stock removal. Beyond this, you have the possibility of generating your own stock removal programs using the following listed functions:

- Generate contour table (CONTPRON)
- Generate coded contour table (CONTDCON)
- Deactivate contour preparation (EXECUTE)
- Determine point of intersection between two contour elements (INTERSEC)
(Only for tables that were generated using CONTPRON)
- Execute contour elements of a table block-by-block (EXECTAB)
(Only for tables that were generated using CONTPRON)
- Calculate circle data (CALCDAT)

Note

You can use these functions universally, not just for stock removal.

Requirements

The following must be done before calling the CONTPRON or CONTDCON functions:

- A starting point that permits collision-free machining must be approached.
- The cutting radius compensation must be deactivated with G40.

3.22.2 Generate contour table (CONTPRON)

CONTPRON switches on the contour preparation. The NC blocks that are subsequently called are not executed, but are split-up into individual movements and stored in the contour table. Each contour element corresponds to one row in the two-dimensional array of the contour table. The number of relief cuts is returned.

Syntax

Activate contour preparation:

```
CONTPRON(<contour table>,<machining type>,<relief cuts>,  
<machining direction>)
```

Deactivate contour preparation and return to the normal execution mode:

```
EXECUTE (<ERROR>)
```

See "Deactivate contour preparation (EXECUTE) (Page 1066)"

Meaning


CONTPRON:	Predefined procedure to activate the contour preparation to generate a contour table		
<contour table>:	Name of contour table		
<machining type>:	Parameter for the machining type		
	Type:	CHAR	
	Value:	"G":	Longitudinal turning: Internal machining
		"L":	Longitudinal turning: External machining
		"N":	Face turning: Internal machining
"P":		Face turning: External machining	
<relief cuts>:	Result variable for the number of relief cut elements that occur		
	Type:	INT	
<machining direction>:	Parameters for the machining direction		
	Type:	INT	
	Value:	0	Contour preparation, forward (default value)
		1	Contour preparation in both directions

Example 1

Generating a contour table with:

- Name "KTAB"
- Max. 30 contour elements (circles, straight lines)
- One variable for the number of relief cut elements that occur
- One variable for error messages

3.22 User stock removal programs



NC program:

Program code	Comment
N10 DEF REAL KTAB[30,11]	; Contour table with the name KTAB and max. 30 contour elements, parameter value 11 (number of table columns) is a fixed quantity.
N20 DEF INT ANZHINT	; Variable for the number of relief cut elements with the name ANZHINT.
N30 DEF INT ERROR	; Variable for error feedback signal (0=no error, 1=error).
N40 G18	
N50 CONTPRON(KTAB,"G",ANZHINT)	; Activate contour preparation.
N60 G1 X150 Z20	; N60 to N120: Contour description
N70 X110 Z30	
N80 X50 RND=15	
N90 Z70	
N100 X40 Z85	
N110 X30 Z90	
N120 X0	
N130 EXECUTE(ERROR)	; End filling the contour table, switch-over to normal program mode.
N140 ...	; Continue to process the table.

Contour table KTAB:

Index Line	Column									
	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)
7	7	11	0	0	20	150	0	82.40535663	0	0

0	2	11	20	150	30	110	-1111	104.0362435	0	0
1	3	11	30	110	30	65	0	90	0	0
2	4	13	30	65	45	50	0	180	45	65
3	5	11	45	50	70	50	0	0	0	0
4	6	11	70	50	85	40	0	146.3099325	0	0
5	7	11	85	40	90	30	0	116.5650512	0	0
6	0	11	90	30	90	0	0	90	0	0
0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0

Explanation of the column contents:


- (0) Pointer to next contour element (to the row number of that column)
- (1) Pointer to previous contour element
- (2) Coding the contour mode for motion
Possible values for X = abc
a = 10² G90 = 0 G91 = 1
b = 10¹ G70 = 0 G71 = 1
c = 10⁰ G0 = 0 G1 = 1 G2 = 2 G3 = 3
- (3), (4) Starting point of contour elements
(3) = abscissa, (4) = ordinate of the current plane
- (5), (6) Starting point of the contour elements
(5) = abscissa, (6) = ordinate of the current plane
- (7) Max/min indicator: Identifies local maximum and minimum values on the contour
- (8) Maximum value between contour element and abscissa (for longitudinal machining) or ordinate (for face cutting). The angle depends on the type of machining programmed.
- (9), (10) Center point coordinates of contour element, if it is a circle block.
(9) = abscissa, (10) = ordinate

Example 2

Generating a contour table with

- Name KTAB
- Max. 92 contour elements (circles, straight lines)
- Operating mode: Longitudinal turning, external machining
- Preparation, forward and backward

3.22 User stock removal programs



NC program:

Program code	Comment
N10 DEF REAL KTAB[92,11]	; Contour table with name KTAB and max. 92 contour elements, parameter value 11 is a fixed quantity.
N20 DEF CHAR BT="L"	; Mode for CONTPRON: Longitudinal turning, external machining
N30 DEF INT HE=0	; Number of relief cut elements=0
N40 DEF INT MODE=1	; Preparation, forward and backward
N50 DEF INT ERR=0	; Error feedback signal
...	
N100 G18 X100 Z100 F1000	
N105 CONTPRON(KTAB,BT,HE,MODE)	; Activate contour preparation.
N110 G1 G90 Z20 X20	
N120 X45	
N130 Z0	
N140 G2 Z-15 X30 K=AC(-15) I=AC(45)	
N150 G1 Z-30	
N160 X80	
N170 Z-40	
N180 EXECUTE(ERR)	; End filling the contour table, switch-over to normal program mode.
...	

Contour table KTAB:

After contour preparation is finished, the contour is available in both directions.

Index	Column										
Line	(0)	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)
0	6 ¹⁾	7 ²⁾	11	100	100	20	20	0	45	0	0
1	0 ³⁾	2	11	20	20	20	45	-3	90	0	0
2	1	3	11	20	45	0	45	0	0	0	0
3	2	4	12	0	45	-15	30	5	90	-15	45
4	3	5	11	-15	30	-30	30	0	0	0	0
5	4	7	11	-30	30	-30	45	-1111	90	0	0
6	7	0 ⁴⁾	11	-30	80	-40	80	0	0	0	0
7	5	6	11	-30	45	-30	80	0	90	0	0
8	1 ⁵⁾	2 ⁶⁾	0	0	0	0	0	0	0	0	0
	...										
83	84	0 ⁷⁾	11	20	45	20	80	0	90	0	0
84	90	83	11	20	20	20	45	-1111	90	0	0
85	0 ⁸⁾	86	11	-40	80	-30	80	0	0	0	0
86	85	87	11	-30	80	-30	30	88	90	0	0
87	86	88	11	-30	30	-15	30	0	0	0	0
88	87	89	13	-15	30	0	45	-90	90	-15	45
89	88	90	11	0	45	20	45	0	0	0	0
90	89	84	11	20	45	20	20	84	90	0	0
91	83 ⁹⁾	85 ¹⁰⁾	11	20	20	100	100	0	45	0	0

Explanation of column contents and comments for lines 0, 1, 6, 8, 83, 85 and 91

The explanations of the column contents given in example 1 apply.

Always in table line 0:

- 1) Predecessor: Line n contains the contour end (forward)
- 2) Successor: Line n is the contour table end (forward)

Once each within the contour elements forward:

- 3) Predecessor: Contour start (forward)
- 4) Successor: Contour end (forward)

Always in line contour table end (forward) +1:

- 5) Predecessor: Number of relief cuts (forward)
- 6) Successor: Number of relief cuts (backward)

Once each within the contour elements backward:

- 7) Successor: Contour end (backward)
- 8) Predecessor: Contour start (backward)

Always in last line of table:

- 9) Predecessor: Line n is the contour table start (backward)

10) Successor: Line n contains the contour start (backward)

Further information

Permitted traversing commands, coordinate system

The following G commands can be used for the contour programming:

- G group 1: G0, G1, G2, G3

In addition, the following are possible:

- Rounding and chamfer
- Circle programming using CIP and CT

The spline, polynomial and thread functions result in errors.

Changes to the coordinate system by activating a frame are not permissible between `CONTPRON` and `EXECUTE`. The same applies for a change between G70 and G71 or G700 and G710.

Replacing the geometry axes with `GEOAX` while preparing the contour table produces an alarm.

Relief cut elements

The contour description for the individual relief cut elements can be performed either in a subprogram or in individual blocks.

Stock removal independent of the programmed contour direction

The contour preparation with `CONTPRON` was expanded so that after it has been called, the contour table is available independent of the programmed direction.

3.22.3 Generate coded contour table (CONTDCON)

With the contour preparation activated with `CONTDCON`, the following NC blocks that are called are saved in a coded form in a 6-column contour table to optimize memory use. Each contour element corresponds to one row in the contour table. When familiar with the coding rules specified below, e.g. you can combine DIN code programs for cycles from the table lines. The data of the output point is saved in the table line with the number 0.

Syntax

Activate contour preparation:

```
CONTDCON(<contour table>,<machining direction>)
```

Deactivate contour preparation and return to the normal execution mode:

```
EXECUTE (<ERROR>)
```

See "Deactivate contour preparation (EXECUTE) (Page 1066)"

Meaning

CONTDCON:	Predefined procedure to activate the contour preparation to generate a coded contour table		
<contour table>:	Name of the contour table		
<machining direction>:	Parameter for machining direction		
	Type:	INT	
	Value:	0	Contour preparation according to the sequence of contour blocks (default value)
		1	Not permissible


Note

The G commands permitted for CONTDCON in the program section to be included in the table are more comprehensive than for CONTPRON. Further, feedrates and feedrate type are saved for each contour section.

Example

Generating a contour table with:

- Name "KTAB"
- Contour elements (circles, straight lines)
- Operating mode: Turning
- Machining direction: Forward



NC program:

Program code	Comment
N10 DEF REAL KTAB[9,6]	;Contour table with name KTAB and 9 table cells. These allow 8 contour sets. The parameter value 6 (column number in table) is a fixed size.
N20 DEF INT MODE = 0	; Variable for the machining direction. Standard value 0: Only in the programmed direction of the contour.
N30 DEF INT ERROR = 0	; Variable for the error feedback signal.
...	
N100 G18 G64 G90 G94 G710	
N101 G1 Z100 X100 F1000	
N105 CONTDCON (KTAB, MODE)	; Contour preparation call (MODE can be omitted).
N110 G1 Z20 X20 F200	; Contour description.
N120 G9 X45 F300	
N130 Z0 F400	
N140 G2 Z-15 X30 K=AC(-15) I=AC(45)F100	
N150 G64 Z-30 F600	
N160 X80 F700	
N170 Z-40 F800	
N180 EXECUTE(ERROR)	; End filling the contour table, switchover to normal program mode.
...	

Contour table KTAB:

Line index	Column index					
	0	1	2	3	4	5
	Contour mode	End point abscissa	End point ordinate	Center point abscissa	Center point ordinate	Feedrate
0	30	100	100	0	0	7
1	11031	20	20	0	0	200
2	111031	20	45	0	0	300
3	11031	0	45	0	0	400
4	11032	-15	30	-15	45	100
5	11031	-30	30	0	0	600
6	11031	-30	80	0	0	700
7	11031	-40	80	0	0	800
8	0	0	0	0	0	0

Explanation of the column contents:**Line 0 Coding for the starting point:**

Column 0:	10 ⁰ (ones digit): G0 = 0
	10 ¹ (tens digit): G70 = 0, G71 = 1, G700 = 2, G710 = 3
Column 1:	Starting point abscissa
Column 2:	Starting point ordinate
Column 3-4:	0
Column 5:	Line index of last contour piece in the table

Lines 1-n: Entries for contour pieces

Column 0:	10 ⁰ (ones digit): G0 = 0, G1 = 1, G2 = 2, G3 = 3
	10 ¹ (tens digit): G70 = 0, G71 = 1, G700 = 2, G710 = 3
	10 ² (hundreds digit): G90 = 0, G91 = 1
	10 ³ (thousands digit): G93 = 0, G94 = 1, G95 = 2, G96 = 3
	10 ⁴ (ten thousands digit): G60 = 0, G44 = 1, G641 = 2, G642 = 3
	10 ⁵ (hundred thousands digit): G9 = 1
Column 1:	End point abscissa
Column 2:	End point ordinate
Column 3:	Center point abscissa for circular interpolation
Column 4:	Center point ordinate for circular interpolation
Column 5:	Feedrate

Further information**Permitted traversing commands, coordinate system**

The following G groups and G commands can be used for the contour programming:

G group 1:	G0, G1, G2, G3
G group 10:	G60, G64, G641, G642
G group 11:	G9
G group 13:	G70, G71, G700, G710
G group 14:	G90, G91
G group 15:	G93, G94, G95, G96, G961

In addition, the following are possible:

- Rounding and chamfer
- Circle programming using CIP and CT

The spline, polynomial and thread functions result in errors.

Changes to the coordinate system by activating a frame are not permissible between CONTDCON and EXECUTE. The same applies for a change between G70 and G71 or G700 and G710.

Replacing the geometry axes with GEOAX while preparing the contour table produces an alarm.

Machining direction

The contour table generated using `CONTRCON` is used for stock removal in the programmed direction of the contour.

3.22.4 Determine point of intersection between two contour elements (INTERSEC)

`INTERSEC` determines the point of intersection of two normalized contour elements from the contour tables generated using `CONTRCON`.

Syntax

```
<Status>=INTERSEC (<contour table_1>[<contour element_1>],
<contour table_2>[<contour element_2>],<intersection
point>,<machining type>)
```

Meaning

<code>INTERSEC:</code>	Predefined function to determine the point of intersection between two contour elements from the contour tables generated with <code>CONTRCON</code>		
<code><Status>:</code>	Variable for the point of intersection status		
	Type:	BOOL	
	Value:	TRUE	Point of intersection found
		FALSE	No intersection found
<code><contour table_1>:</code>	Name of the first contour table		
<code><contour element_1>:</code>	Number of the contour element of the first contour table		
<code><contour table_2>:</code>	Names of the second contour table		
<code><contour element_2>:</code>	Number of the contour element of the second contour table		
<code><point of intersection>:</code>	Intersection coordinates in the active plane (G17 / G18 / G19)		
	Type:	REAL	
<code><machining type>:</code>	Parameter for the machining type		
	Type:	INT	
	Value:	0	Point of intersection calculation in the active plane with parameter 2 (standard value)
		1	Point of intersection calculation independent of the transferred plane

Note

Please note that the variables must be defined before they are used.

The values defined with `CONTPRON` must be observed when transferring the contours:

Parameter	Meaning
2	Coding of contour mode for the movement
3	Contour start point abscissa
4	Contour start point ordinate
5	Contour end point abscissa
6	Contour end point ordinate
9	Center point coordinates for abscissa (only for circle contour)
10	Center point coordinates for ordinate (only for circle contour)

Example

Calculate the intersection of contour element 3 in table `TABNAME1` and contour element 7 in table `TABNAME2`. The intersection coordinates in the active plane are stored in the variables `ISCOORD` (1st element = abscissa, 2nd element = ordinate). If no intersection exists, the program jumps to `NOCUT` (no intersection found).

Program code	Comment
<code>DEF REAL TABNAME1[12,11]</code>	<code>; Contour table 1</code>
<code>DEF REAL TABNAME2[10,11]</code>	<code>; Contour table 2</code>
<code>DEF REAL ISCOORD [2]</code>	<code>; Variable for the intersection coordinates.</code>
<code>DEF BOOL ISPOINT</code>	<code>; Variable for the intersection status.</code>
<code>DEF INT MODE</code>	<code>; Variable for the machining type.</code>
<code>...</code>	
<code>MODE=1</code>	<code>; Calculation independent of the active plane.</code>
<code>N10 ISPOINT=INTERSEC(TABNAME1[3],TABNAME2[7], ISCOORD,MODE)</code>	<code>; Intersection of the contour elements call.</code>
<code>N20 IF ISPOINT==FALSE GOTOF NOCUT</code>	<code>; Jump to NOCUT.</code>
<code>...</code>	

3.22.5 Execute the contour elements of a table block-by-block (EXECTAB)

Using `EXECTAB`, you can execute the contour elements of a table – that were generated, e.g. with `CONTPRON` – block-by-block.

Syntax

```
EXECTAB(<contour table>[<contour element>])
```

Meaning

EXECTAB:	Predefined procedure to execute a contour element
<contour table>:	Name of the contour table
<contour element>:	Number of the contour element

Example

Contour elements 0 to 2 in table KTAB should be executed block-by-block.

Program code	Comment
N10 EXECTAB(KTAB[0])	; Traverse element 0 of table KTAB.
N20 EXECTAB(KTAB[1])	; Traverse element 1 of table KTAB.
N30 EXECTAB(KTAB[2])	; Traverse element 2 of table KTAB.

3.22.6 Calculate circle data (CALCDAT)

With `CALCDAT`, you can calculate the radius and the circle center point coordinates from the three or four points known along the circle. The specified points must be different.

Where four points do not lie directly on the circle an average value is formed for the circle center point and the radius.

Note**Calculation regulation for the averaging**

The arc calculation is performed four times:

1. With circle points 1, 2, 3
2. With circle points 1, 2, 4
3. With circle points 1, 3, 4
4. With circle points 2, 3, 4

The values of the circle center point coordinates abscissa and ordinate are calculated by adding the abscissa and ordinate values of the four arc calculations and dividing by four.

The radius is calculated by forming the root from the sum of the four radii from the arc calculations and multiplying the result with 0.5.

Syntax

```
<Status>=CALCDAT(<circle points>[<number>,<type>],<number>,<result>)
```


Meaning


CALCDAT:	Predefined function to calculate the radius and center point coordinates of a circle from three or four points		
<Status>:	Variable for the circle calculation status		
	Type:	BOOL	
	Value:	TRUE	The specified points lie on a circle.
FALSE		The specified points do not lie on a circle.	
<circle points>[]:	Variable to specify the circle points using parameters		
	<number>:	Number of circle points (3 or 4)	
	<type>:	Type of coordinate data, e.g. 2 for 2-point coordinates	
<number>:	Parameter for the number of the points used for the calculation (3 or 4)		
<result>[3]:	Variable for result: Circle center point coordinates and radius		
	0	Circle center point coordinate: Abscissa value	
	1	Circle center point coordinate: Ordinate value	
	2	Radius	

Note

Please note that the variables must be defined before they are used.

Example

Using three points it should be determined as to whether they are located on a circle segment.



Program code	Comment
N10 DEF REAL PT[3,2]=(20,50,50,40,65,20)	; Variable to specify the points of a circle.
N20 DEF REAL RES[3]	; Variable for result.
N30 DEF BOOL STATUS	; Variable for status.
N40 STATUS=CALCDAT(PKT,3,ERG)	; Call of the determined circle data.
N50 IF STATUS == FALSE GOTOF ERROR	; Jump to error.

3.22.7 Deactivate contour preparation (EXECUTE)

EXECUTE deactivates the contour preparation and at the same time the system returns to the normal execution mode.

Syntax

EXECUTE (<ERROR>)

Meaning

EXECUTE:	Predefined procedure to terminate contour preparation	
<ERROR>:	Variable for the error feedback signal	
	Type:	INT
	The value of the variable indicates whether the contour was able to be prepared error-free:	
	0	Error
	1	No error

Example

```

Program code
...
N30 CONTPRON(...)
N40 G1 X... Z...
...
N100 EXECUTE(...)
...
    
```

3.23 Programming cycles externally

3.23.1 Technology cycles

3.23.1.1 Introduction

Contents

This section contains a description of the cycles for the turning, milling, and grinding technologies.

Structure

The description of a cycle is structured as follows:

- **Syntax**
Cycle name and call sequence of the transfer parameters
- **Parameters**
Tables to explain the individual parameters

Parameter description

The following data is specified in the table for a parameter: Name, description, value range, and dependencies on other parameters.

The column for reference to the parameter in the screen form is provided to more easily locate values programmed on the control when externally generated cycle calls are recompiled.

"For interface only" parameters

Certain parameters are marked "for interface only" in the table. These are not relevant to operation of the cycle. They are only needed in order to be able to recompile cycle calls completely. If they are not programmed the cycle can still be recompiled; the fields are then identified by color and must be completed in the mask.

"Reserved" parameters

Parameters that are described as "reserved" must be programmed with the value 0 or a comma so that the assignment of the following call parameters matches the internal cycle parameters. Exception: string parameters with the value "" or a comma.

Repeating cycles on a position pattern

Drilling and milling cycles can be repeated on the position pattern (modal calls). In such cases `MCALL` should be written in the same line before the cycle, e.g. `MCALL CYCLE83 (. . .)`.

Note

If certain transfer parameters (e.g. <_VARI>, <_GMODE>, <_DMODE>, <_AMODE>) have been indirectly programmed as parameters, the screen form is opened on recompiling but it cannot be stored as there is no unambiguous assignment to defined selection fields.

3.23.1.2 Technology-specific overview

The following overview table lists all available externally programmable technology cycles and the technology assigned to each of them:

Technology	Technology cycle
Drilling	<ul style="list-style-type: none"> • CYCLE81 - drilling, centering (Page 1107) • CYCLE82 - drilling, counterboring (Page 1108) • CYCLE85 - reaming (Page 1117) • CYCLE86 - boring (Page 1118) • CYCLE83 – deep-hole drilling 1 (Page 1111) • CYCLE830 - deep-hole drilling 2 (Page 1141) • CYCLE84 - tapping without compensating chuck (Page 1114) • CYCLE840 - tapping with compensating chuck (Page 1150) • CYCLE78 - Drill thread milling (Page 1103) • CYCLE802 - arbitrary positions (Page 1139) • HOLES1 – row position pattern (Page 1070) • CYCLE801 – grid or frame position pattern (Page 1137) • HOLES2 – circle or pitch circle position pattern (Page 1070)
Turning	<ul style="list-style-type: none"> • CYCLE951 - stock removal (Page 1161) • CYCLE930 - groove (Page 1156) • CYCLE940 – undercut form E and F / undercut thread (Page 1158) • CYCLE99 - thread turning (Page 1127) • CYCLE98 - thread chain (Page 1123) • CYCLE92 - cut-off (Page 1119)
Contour turning	<ul style="list-style-type: none"> • CYCLE62 - contour call (Page 1089) • CYCLE952 – stock removal / residual stock removal / plunge cutting / residual plunge cutting / plunge turning / residual plunge turning (Page 1164)

Technology	Technology cycle
Milling	<ul style="list-style-type: none"> • CYCLE61 - Face milling (Page 1087) • POCKET3 – rectangular pocket (Page 1072) • POCKET4 – circular pocket (Page 1075) • CYCLE76 – rectangular spigot (Page 1098) • CYCLE77 – circular spigot (Page 1101) • CYCLE79 - multi-edge (Page 1105) • SLOT1 - longitudinal slot (Page 1077) • SLOT2 - circumferential slot (Page 1080) • CYCLE899 – open slot (Page 1153) • LONGHOLE - elongated hole (Page 1082) • CYCLE70 - thread milling (Page 1094) • CYCLE60 – engraving (Page 1084)
Contour milling	<ul style="list-style-type: none"> • CYCLE62 - contour call (Page 1089) • CYCLE72 - Path milling (Page 1095) • CYCLE63 – contour pocket milling / contour pocket residual material / contour spigot milling / contour spigot residual material (Page 1089) • CYCLE64 - Predrilling contour pocket (Page 1092)
Grinding	<ul style="list-style-type: none"> • CYCLE495 - form-truing (Page 1132) • CYCLE435 - Set dresser coordinate system (Page 1132) • CYCLE4071 - longitudinal grinding with infeed at the reversal point (Page 1170) • CYCLE4072 - longitudinal grinding with infeed at the reversal point and cancel signal (Page 1172) • CYCLE4073 - longitudinal grinding with continuous infeed (Page 1176) • CYCLE4074 - longitudinal grinding with continuous infeed and cancel signal (Page 1177) • CYCLE4075 - surface grinding with infeed at the reversal point (Page 1180) • CYCLE4077 - surface grinding with infeed at the reversal point and cancel signal (Page 1183) • CYCLE4078 - surface grinding with continuous infeed (Page 1187) • CYCLE4079 - surface grinding with intermittent infeed (Page 1189)
Other	<ul style="list-style-type: none"> • CYCLE800 – swivel plane / swivel tool / align tool (Page 1134) • CYCLE832 - High-Speed Settings (Page 1147)
All	<ul style="list-style-type: none"> • GROUP_BEGIN - beginning of program block (Page 1192) • GROUP_END - end of program block (Page 1192) • GROUP_ADDEND - End of trial cut addition (Page 1193)

3.23.1.3 HOLES1 – row position pattern

Syntax

HOLES1 (<SPCA>, <SPCO>, <STA1>, <FDIS>, <DBH>, <NUM>, <_VARI>, <_UMODE>, <_HIDE>, <_NSP>, <_DMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	X0	<SPCA>	REAL	Reference point for row of holes along the 1st axis (abs)
2	Y0	<SPCO>	REAL	Reference point for row of holes along the 2nd axis (abs)
3	α 0	<STA1>	REAL	Basic angle of rotation (angle to 1st axis)
4	L0	<FDIS>	REAL	Distance from 1st hole to reference point
5	L	<DBH>	REAL	Spacing between the holes
6	N	<NUM>	INT	Number of holes
7		<_VARI>	INT	Reserved
8		<_UMODE>	INT	Reserved
9		<_HIDE>	STRING [200]	Hidden positions <ul style="list-style-type: none"> Max. 198 characters Specification of consecutive position numbers, e.g. "1,3" (positions 1 and 3 are not executed)
10		<_NSP>	INT	Reserved
11		<_DMODE>	INT	Display mode
			UNITS:	Machining plane G17/18/19
				0 = Compatibility, the plane effective before the cycle call remains active
				1 = G17 (only active in the cycle)
				2 = G18 (only active in the cycle)
				3 = G19 (only active in the cycle)

3.23.1.4 HOLES2 – circle or pitch circle position pattern

Syntax

HOLES2 (<CPA>, <CPO>, <RAD>, <STA1>, <INDA>, <NUM>, <_VARI>, <_UMODE>, <_HIDE>, <_NSP>, <_DMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	X0	<CPA>	REAL	Center point for circle of holes along the 1st axis (abs) Reference point in the 1st axis (for XY) (for XA, YB, ZC)	
2	Y0	<CPO>	REAL	Center point for circle of holes along the 2nd axis (abs) Reference point in the 2nd axis (for XY) (for XA, YB, ZC)	
3	R	<RAD>	REAL	Radius of the circle of holes (for XY)	
4	$\alpha 0$	<STA1>	REAL	Starting angle or 1st rotary axis position (for XY) (for XA, YB, ZC)	
5	$\alpha 1$	<INDA>	REAL	Advance angle (for pitch circle only) (for XY, XA, YB, ZC)	
				< 0 = Clockwise > 0 = Counter-clockwise	
6	N	<NUM>	INT	Number of positions	
7		<_VARI>	INT	Machining type	
				UNITS:	Reserved
				TENS:	Positioning type
				0 =	Approach position - linear
				1 =	Approach position - circular path
				HUNDREDS:	Reserved
				THOUSANDS:	Circular pattern
				0 =	Compatibility mode, if INDA = 0 then full circle, INDA <> 0 then pitch circle
				1 =	Full circle
				2 =	Pitch circle
				TEN THOUSANDS:	Position pattern with rotary axis
				0 =	XY (without rotary axis) (for XY)
				1 =	XA (X axis and rotary axis around X) (only for XA)
2 =	YB (Y axis and rotary axis around Y) (only for YB)				
3 =	ZC (Z axis and rotary axis around C) (only for ZC)				
ONE MILLION + HUNDRED THOUSANDS:	Offset (for several rotary axes around the same axis; if index too large, then 1st axis)				
00 =	1st A, B or C axis				
01 =	2nd A, B or C axis				
...					
10 =	20th A, B or C axis				
8		<_UMODE>	INT	Reserved	

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning
9		<_HIDE>	STRING [200]	Reserved
10		<_NSP>	INT	Reserved
11		<_DMODE>	INT	Display mode
			UNITS:	Machining plane G17/18/19
			0 =	Compatibility, the plane effective before the cycle call remains active
			1 =	G17 (only active in the cycle)
			2 =	G18 (only active in the cycle)
			3 =	G19 (only active in the cycle)

3.23.1.5 POCKET3 – rectangular pocket

Syntax

POCKET3 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_LENG>, <_WID>, <_CRAD>, <_PA>, <_PO>, <_STA>, <_MID>, <_FAL>, <_FALD>, <_FFP1>, <_FFD>, <_CDIR>, <_VARI>, <_MIDA>, <_AP1>, <_AP2>, <_AD>, <_RAD1>, <_DP1>, <_UMODE>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Pocket depth (abs/inc), see <_AMODE>
5	L	<_LENG>	REAL	Pocket length (inc, to be entered with sign)
6	W	<_WID>	REAL	Pocket width (inc, to be entered with sign)
7	R	<_CRAD>	REAL	Corner radius of pocket
8	X0	<_PA>	REAL	Reference point 1st axis (abs)
9	YO	<_PO>	REAL	Reference point 2nd axis (abs)
10	α0	<_STA>	REAL	Angle of rotation, angle between longitudinal axis (L) and 1st axis
11	DZ	<_MID>	REAL	Maximum depth infeed
12	UXY	<_FAL>	REAL	Finishing allowance, plane
13	UZ	<_FALD>	REAL	Finishing allowance, depth
14	F	<_FFP1>	REAL	Feedrate in the plane
15	FZ	<_FFD>	REAL	Depth infeed rate
16		<_CDIR>	INT	Milling direction:
			0 =	Down-cut
			1 =	Up-cut

No.	Parameter mask	Parameter internal	Data type	Meaning		
17		<_VARI>	INT	Machining type		
				UNITS:	1 =	Roughing
				2 =	Finishing	
				4 =	Edge finishing	
				5 =	Chamfering	
				TENS:	0 =	Predrilled, infeed with G0
				1 =	Vertically, infeed with G1	
				2 =	Helical	
				3 =	Oscillation on pocket longitudinal axis	
				HUNDREDS:	Reserved	
18	DXY	<_MIDA>	REAL	Maximum plane infeed, for unit, see <_AMODE>		
19	L1	<_AP1>	REAL	Length of premachining (inc)		
20	W1	<_AP2>	REAL	Width of premachining (inc)		
21	AZ	<_AD>	REAL	Depth of premachining (inc)		
22	ER	<_RAD1>	REAL	Radius of helical path on helical insertion		
	EW			Maximum insertion angle for oscillation		
23	EP	<_DP1>	REAL	Helical pitch on helical insertion		
24		<_UMODE>	INT	Reserved		
25	FS	<_FS>	REAL	Chamfer width (inc)		
26	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>		

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
27		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Select machining/only calculation of start point	
					0 =	Compatibility mode
					1 =	Normal machining
				THOUSANDS:	Dimensioning via center/corner	
					0 =	Compatibility mode
					1 =	Dimensioning via center
					2 =	Dimensioning of corner point, pocket position +LENG/+WID
					3 =	Dimensioning of corner point, pocket position -LENG/+WID
					4 =	Dimensioning of corner point, pocket position +LENG/-WID
				TEN THOUSANDS:	Complete machining/remachining	
					0 =	Compatibility mode (process <_AP1>, <_AP2> and <_AD> as before)
1 =	Complete machining					
2 =	Post machining					
28		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				TENS:	3 =	G19 (only active in the cycle)
					Type of feedrate: G group (G94/G95) for surface and depth feedrate	
					0 =	Compatibility mode
				HUNDREDS:	1 =	G command as before cycle call. G94/G95 same for surface and depth feedrate
					---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
					0 =	Input: Complete
	1 =	Input: Simple				

No.	Parameter mask	Parameter internal	Data type	Meaning		
29		<_AMODE>	INT	Alternative mode		
				UNITS:	Pocket depth (Z1)	
					0 =	Absolute (compatibility mode)
					1 =	Incremental
				TENS:	Unit for plane infeed (DXY)	
					0 =	mm
					1 =	% of tool diameter
				HUNDREDS:	Insertion depth for chamfering (ZFS)	
					0 =	Absolute
1 =	Incremental					

3.23.1.6 POCKET4 – circular pocket

Syntax

```
POCKET4 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_CDIAM>, <_PA>, <_PO>,
<_MID>, <_FAL>, <_FALD>, <_FFP1>, <_FFD>, <_CDIR>, <_VARI>, <_MIDA>,
<_AP1>, <_AD>, <_RAD1>, <_DP1>, <_UMODE>, <_FS>, <_ZFS>, <_GMODE>,
<_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	RP	<_RTP>	REAL	Retraction plane (abs)	
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)	
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)	
4	Z1	<_DP>	REAL	Pocket depth (abs/inc), see <_AMODE>	
5	∅	<_CDIAM>	REAL	Pocket diameter or radius, see <_DMODE>	
6	X0	<_PA>	REAL	Reference point 1st axis (abs)	
7	Y0	<_PO>	REAL	Reference point 2nd axis (abs)	
8	DZ	<_MID>	REAL	Maximum depth setting, see <_VARI> = by planes Maximum helical setting, see <_VARI> = helically	
9	UXY	<_FAL>	REAL	Finishing allowance, plane	
10	UZ	<_FALD>	REAL	Finishing allowance, depth	
11	F	<_FFP1>	REAL	Feedrate for surface machining	
12	FZ	<_FFD>	REAL	Depth infeed rate	
13		<_CDIR>	INT	Milling direction	
				0 =	Down-cut
				1 =	Up-cut

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
14		<_VARI>	INT	Machining type	
				UNITS:	Machining
				1 =	Roughing
				2 =	Finishing
				4 =	Edge finishing
				5 =	Chamfering
				TENS:	Infeed type (roughing and finishing)
				0 =	Predrilled, infeed with G0 (pocket is premachined)
				1 =	Vertically, infeed with G1
				2 =	Helical
	HUNDREDS:	Reserved			
	THOUSANDS:				
	0 =	Plane-by-plane			
	1 =	Helical			
15	DXY	<_MIDA>	REAL	Maximum plane infeed, see <_AMODE>, 0 = 0.8 x tool diameter	
16	∅	<_AP1>	REAL	Diameter/radius of premachining (inc)	
17	AZ	<_AD>	REAL	Depth of premachining (inc)	
18	ER	<_RAD1>	REAL	Radius of helical path on helical insertion	
19	EP	<_DP1>	REAL	Helical pitch on insertion on helical path	
20		<_UMODE>	INT	Reserved	
21	FS	<_FS>	REAL	Chamfer width (inc)	
22	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>	
23		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Machining/calculation of start point
				0 =	Compatibility mode
				1 =	Normal machining
				THOUSANDS:	Reserved
				TEN THOUSANDS:	Complete machining/remachining
				0 =	Compatibility mode (process <_AP1> and <_AD> as before)
				1 =	Complete machining
2 =	Post machining				

No.	Parameter mask	Parameter internal	Data type	Meaning					
24		<_DMODE>	INT	Display mode					
				UNITS:	Machining plane G17/18/19				
					0 =	Compatibility, the plane effective before the cycle call remains active			
					1 =	G17 (only active in the cycle)			
					2 =	G18 (only active in the cycle)			
								3 =	G19 (only active in the cycle)
				TENS:	Type of feedrate: G group (G94/G95) for surface and depth feedrate				
					0 =	Compatibility mode			
								1 =	G command as before cycle call. G94/G95 same for surface and depth feedrate
				HUNDREDS:					
0 =	Compatibility mode (enter <_CDIAM>/<_AP1> as radius)								
				1 =	Enter <_CDIAM>/<_AP1> as diameter				
THOUSANDS:	---	Reserved							
TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)								
	0 =	Input: Complete							
	1 =	Input: Simple							
25		<_AMODE>	INT	Alternative mode					
				UNITS:	Pocket depth (Z1)				
					0 =	Absolute (compatibility mode)			
								1 =	Incremental
				TENS:	Unit for infeed width (DXY)				
					0 =	mm			
								1 =	% of tool diameter
				HUNDREDS:	Insertion depth for chamfering (ZFS)				
0 =	Absolute								
				1 =	Incremental				

3.23.1.7 SLOT1 - longitudinal slot

Syntax

```
SLOT1 (<RTP>, <RFP>, <SDIS>, <_DP>, <_DPR>, <NUM>, <LENG>, <WID>,
<_CPA>, <_CPO>, <RAD>, <STA1>, <INDA>, <FFD>, <FFP1>, <_MID>,
<CDIR>, <_FAL>, <VARI>, <_MIDF>, <FFP2>, <SSF>, <_FALD>, <_STA2>,
<_DP1>, <_UMODE>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point of tool axis (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Slot depth (abs)
5		<_DPR>	REAL	Slot depth (inc) with respect to Z0 (enter without sign)
6		<NUM>	INT	Number of slots = 1
7	L	<LENG>	REAL	Slot length
8	W	<WID>	REAL	Slot width
9	X0	<_CPA>	REAL	Reference point in the 1st axis of the plane
10	Y0	<_CPO>	REAL	Reference point in the 2nd axis of the plane
11		<RAD>	REAL	Reserved
12	α	<STA1>	REAL	Angle of rotation
13		<INDA>	REAL	Reserved
14	FZ	<FFD>	REAL	Depth infeed rate
15	F	<FFP1>	REAL	Feedrate
16	DZ	<_MID>	REAL	Maximum depth infeed
17		<CDIR>	INT	Milling direction 0 = Down-cut 1 = Up-cut
18	UXY	<_FAL>	REAL	Finishing allowance on plane or slot edge
19		<VARI>	INT	Machining type UNITS: 0 = Reserved 1 = Roughing 2 = Finishing 4 = Edge finishing (only machine the edge) 5 = Chamfering TENS: Approach 0 = Predrilled, infeed with G0 (slot is premachined) 1 = Vertically, infeed with G1 2 = Helical 3 = Oscillation HUNDREDS: Reserved
20	DZF	<_MIDF>	REAL	Reserved
21	FF	<FFP2>	REAL	Reserved
22	SF	<SSF>	REAL	Reserved
23	UZ	<_FALD>	REAL	Finishing allowance, depth
24	ER	<_STA2>	REAL	Radius of helical path on helical insertion
	EW			Maximum insertion angle for oscillation
25	EP	<_DP1>	REAL	Insertion depth per rev for helix

No.	Parameter mask	Parameter internal	Data type	Meaning	
26		<_UMODE>	INT	Reserved	
27	FS	<_FS>	REAL	Chamfer width (inc) for chamfering	
28	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>	
29		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining or just calculation of start point
					1 = Normal machining
				THOUSANDS:	Dimensioning of reference point, slot length
					0 = Center
					1 = Inner left-hand +L
					2 = Inner right-hand -L
					3 = Left-hand edge +L
4 = Right-hand edge -L					
30		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/18/19
					0 = Compatibility, the plane effective before the cycle call remains active
					1 = G17 (only active in the cycle)
					2 = G18 (only active in the cycle)
				3 = G19 (only active in the cycle)	
				TENS:	Reserved
				HUNDREDS:	Reserved
				THOUSANDS:	Software version identification
					1 = Function extension SLOT1
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)
					0 = Input: Complete
				1 = Input: Simple	
31		<_AMODE>	INT	Alternative mode	
				UNITS:	Final depth Z1 (abs/inc)
					0 = Compatibility
					1 = Z1 (inc)
				2 = Z1 (abs)	
				TENS:	Reserved
				HUNDREDS:	Insertion depth for chamfering ZFS
					0 = ZFS (abs)
1 = ZFS (inc)					

Note

The cycle is provided with new functions that are not on earlier software versions. Consequently certain parameters in the screen form (<NUM>, <RAD>, <INDA>) are no longer displayed. Multiple slots on one position pattern can be programmed using "MCALL" and calling the desired position pattern, e.g. HOLES2.

3.23.1.8 SLOT2 - circumferential slot

Syntax

SLOT2 (<RTP>, <RFP>, <SDIS>, <_DP>, <_DPR>, <NUM>, <AFSL>, <WID>, <_CPA>, <_CPO>, <RAD>, <STA1>, <INDA>, <FFD>, <FFP1>, <_MID>, <CDIR>, <_FAL>, <VARI>, <_MIDF>, <FFP2>, <SSF>, <_FFCP>, <_UMODE>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point of tool axis (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Slot depth (abs)
5		<_DPR>	REAL	Slot depth (inc) with respect to Z0 (enter without sign)
6	N	<NUM>	INT	Number of slots
7	$\alpha 1$	<AFSL>	REAL	Opening angle of the slot
8	W	<WID>	REAL	Slot width
9	X0	<_CPA>	REAL	Reference point = Center point of circle, 1st axis of the plane
10	Y0	<_CPO>	REAL	Reference point = Center point of circle, 2nd axis of the plane
11	R	<RAD>	REAL	Radius of the circle
12	$\alpha 0$	<STA1>	REAL	Starting angle
13	$\alpha 2$	<INDA>	REAL	Incrementing angle
14	FZ	<FFD>	REAL	Depth infeed rate
15	F	<FFP1>	REAL	Feedrate
16	DZ	<_MID>	REAL	Maximum depth infeed
17		<CDIR>	INT	Milling direction 0 = Down-cut 1 = Up-cut
18	UXY	<_FAL>	REAL	Finishing allowance on plane or slot edge

No.	Parameter mask	Parameter internal	Data type	Meaning	
19		<VARI>	INT	Machining type	
				UNITS:	0 = Complete machining
				1 = Roughing	
				2 = Finishing	
				3 = Edge finishing	
				5 = Chamfering	
				TENS:	0 = Intermediate positioning with G0 line
				1 = Intermediate positioning on circular path	
				HUNDREDS:	Reserved
				THOUSANDS:	0 = Compatibility mode, if <INDA> = 0 then full circle, <INDA> <> 0 then pitch circle
1 = Full circle					
2 = Pitch circle					
20	DZF	<_MIDF>	REAL	Reserved	
21		<FFP2>	REAL	Reserved	
22		<SSF>	REAL	Reserved	
23	FF	<_FFCP>	REAL	Reserved	
24		<_UMODE>	INT	Reserved	
25	FS	<_FS>	REAL	Chamfer width (inc)	
26	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>	
27		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining or just calculation of start point
				0 = Compatibility mode	
1 = Normal machining					

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning					
28		<_DMODE>	INT	Display mode					
				UNITS:	Machining plane G17/18/19				
					0 =	Compatibility, the plane effective before the cycle call remains active			
					1 =	G17 (only active in the cycle)			
					2 =	G18 (only active in the cycle)			
								3 =	G19 (only active in the cycle)
				TENS:	Reserved				
				HUNDREDS:	Reserved				
				THOUSANDS:	Software version identification				
					1 =	SLOT2 functions as of software version 2.5			
TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)								
	0 =	Input: Complete							
	1 =	Input: Simple							
29		<_AMODE>	INT	Alternative mode					
				UNITS:	Final depth Z1 (abs/inc)				
					0 =	Compatibility			
					1 =	Z1 (inc)			
						2 =	Z1 (abs)		
				TENS:	Reserved				
				HUNDREDS:	Insertion depth for chamfering ZFS				
0 =	ZFS (abs)								
		1 =	ZFS (inc)						

3.23.1.9 LONGHOLE - elongated hole

Syntax

LONGHOLE (<RTP>, <RFP>, <SDIS>, <_DP>, <_DPR>, <NUM>, <LENG>, <_CPA>, <_CPO>, <RAD>, <STAL>, <INDA>, <FFD>, <FFP1>, <MID>, <_VARI>, <_UMODE>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Long hole depth (abs)

No.	Parameter mask	Parameter internal	Data type	Meaning	
5		<_DPR>	REAL	Long hole depth (inc) with respect to Z0 (enter without sign)	
6		<NUM>	INT	Number of long holes = 1	
7	L	<LENG>	REAL	Length of long hole	
8	X0	<_CPA>	REAL	Reference point 1st axis of the plane	
9	Y0	<_CPO>	REAL	Reference point 2nd axis of the plane	
10		<RAD>	REAL	Reserved	
11	$\alpha 0$	<STA1>	REAL	Angle of rotation	
12		<INDA>	REAL	Reserved	
13	FZ	<FFD>	REAL	Depth infeed rate	
14	F	<FFP1>	REAL	Feedrate	
15	DZ	<MID>	REAL	Maximum depth infeed	
16		<_VARI>	INT	Machining type	
				UNITS:	Infeed type
					1 = Vertically with G1
					3 = Oscillation
	HUNDREDS:	Reserved			
17		<_UMODE>	INT	Reserved	
18		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining or just calculation of start point
					0 = Compatibility mode
					1 = Normal machining
				THOUSANDS:	Dimensioning of reference point, slot length
					0 = Center
					1 = Inner left-hand +L
					2 = Inner right-hand -L
	3 = Left-hand edge +L				
	4 = Right-hand edge -L				

No.	Parameter mask	Parameter internal	Data type	Meaning		
19		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/18/19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)	
				TENS:	Type of feedrate: G group (G94/G95) for surface and depth feedrate	
					0 =	Compatibility mode
1 =	G command as before cycle call. G94/G95 same for surface and depth feedrate					
HUNDREDS:	Reserved					
THOUSANDS:	Software version identification					
	1 =	Function extension LONGHOLE (dimensioning of reference point)				
20		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth Z1 (abs/inc)	
					0 =	Compatibility
					1 =	Z1 (inc)
2 =	Z1 (abs)					

Note

The cycle is provided with new functions that are not on earlier software versions. Consequently certain parameters in the screen form (<NUM>, <RAD>, <INDA>) are no longer displayed. Multiple slots on one position pattern can be programmed using "MCALL" and calling the desired position pattern, e.g. HOLES2.

3.23.1.10 CYCLE60 – engraving**Syntax**

```
CYCLE60 (<_TEXT>, <_RTP>, <_RFP>, <_SDIS>, <_DP>, <_DPR>, <_PA>,
<_PO>, <_STA>, <_CP1>, <_CP2>, <_WID>, <_DF>, <_FFD>, <_FFP1>,
<_VARI>, <_CODEP>, <_UMODE>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1		<_TEXT>	STRING [200]	Text to be engraved (up to 100 characters)
2	RP	<_RTP>	REAL	Retraction plane (abs)
3	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
4	SC	<_SDIS>	REAL	Safety clearance (to be added to the reference plane, enter without sign)
5	Z1	<_DP>	REAL	Depth (abs), see <_AMODE>
6	Z1	<_DPR>	REAL	Depth (inc), see <_AMODE>
7	X0	<_PA>	REAL	Reference point 1st axis of plane (abs) - right-angled, see <_VARI>
	R			Reference point, length (radius) - polar, see <_VARI>
8	Y0	<_PO>	REAL	Reference point 2nd axis of plane (abs) - right-angled, see <_VARI>
	α 0			Reference point, angle with respect to 1st axis - polar, see <_VARI>
9	α 1	<_STA>	REAL	Text direction, angle of line of text with respect to 1st axis), see <_VARI>
10	XM	<_CP1>	REAL	Center of the text circle, 1st axis of plane (abs) - right-angled, see <_VARI>
	LM			Center of circle of text, length (radius) with respect to WNP - polar, see <_VARI>
11	YM	<_CP2>	REAL	Center of the text circle, 2nd axis of plane (abs) - right-angled, see <_VARI>
	α M			Center of text circle, angle with respect to 1st axis axis - polar, see <_VARI>
12	W	<_WID>	REAL	Height of characters (enter without sign)
13	DX1	<_DF>	REAL	Distance between characters / overall width, see <_VARI>
	DX2			
	α 2			Opening angle, see <_VARI>
14	FZ	<_FFD>	REAL	Depth infeed rate, see <_DMODE>
15	F	<_FFP1>	REAL	Feedrate for surface machining

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
16		<_VARI>	INT	Machining (alignment and reference point for engraved text)	
				UNITS:	Reference point
				0 =	Right-angled
				1 =	Polar
				TENS:	Text alignment
				0 =	Text on one line
				1 =	Text in an upward pointing arc
				2 =	Text in a downward curving arc
				HUNDREDS:	Reserved
				THOUSANDS:	Reference point of the text, horizontal
				0 =	Left
				1 =	Center
				2 =	Right
				TEN THOUSANDS:	Reference point of the text, vertical
				0 =	Bottom
				1 =	Center
				2 =	Top
				HUNDRED THOUSANDS:	Text length
				0 =	Character spacing
				1 =	Overall text width (linear text only)
2 =	Opening angle (only for circular text)				
ONE MILLION:	Circle center				
0 =	Right-angled (Cartesian)				
1 =	Polar				
TEN MILLIONS:	Mirror writing				
0 =	Compatibility				
1 =	Mirror writing ON				
2 =	Mirror writing OFF				
17		<_CODEP>	INT	Code page number for writing (currently only 1252)	
18		<_UMODE>	INT	Reserved	
19		_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining/only calculation of start point
				0 =	Compatibility mode
1 =	Normal machining				

No.	Parameter mask	Parameter internal	Data type	Meaning		
20		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/18/19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)	
TENS:	Type of feedrate: G group (G94/G95) for surface and depth feedrate					
	0 =	Compatibility mode				
21		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth (<_DP>, <_DPR>)	
					0 =	Compatibility
					1 =	Incremental (<_DPR>)
2 =	Absolute (<_DP>)					

3.23.1.11 CYCLE61 - Face milling

Syntax

```
CYCLE61 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_PA>, <_PO>, <_LENG>,
<_WID>, <_MID>, <_MIDA>, <_FALD>, <_FFP1>, <_VARI>, <_LIM>,
<_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis, height of blank (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Height of finished part (abs/inc), see <_AMODE>
5	X0	<_PA>	REAL	Corner point 1 in 1st axis (abs)
6	Y0	<_PO>	REAL	Corner point 1 in 2nd axis (abs)
7	X1	<_LENG>	REAL	Corner point 2 in 1st axis (abs/inc), see <_AMODE>
8	Y1	<_WID>	REAL	Corner point 2 in 2nd axis (abs/inc), see <_AMODE>
9	DZ	<_MID>	REAL	Maximum depth infeed
10	DXY	<_MIDA>	REAL	Maximum plane infeed (for unit, see <_AMODE>)
11	UZ	<_FALD>	REAL	Finishing allowance, depth

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
12	F	<_FFP1>	REAL	Machining feedrate	
13		<_VARI>	INT	Machining type	
				UNITS:	Machining
				1 =	Roughing
				2 =	Finishing
				TENS:	Machining direction
				1 =	Parallel to the 1st axis, in one direction
				2 =	Parallel to the 2nd axis, in one direction
				3 =	Parallel to the 1st axis, varying direction
4 =	Parallel to the 2nd axis, varying direction				
14		<_LIM>	INT	Limits	
				UNITS:	Limit 1st axis negative
				0 =	No
				1 =	Yes
				TENS:	Limit 1st axis positive
				0 =	No
				1 =	Yes
				HUNDREDS:	Limit 2nd axis negative
				0 =	No
				1 =	Yes
				THOUSANDS:	Limit 2nd axis positive
				0 =	No
1 =	Yes				
15		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/18/19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)

No.	Parameter mask	Parameter internal	Data type	Meaning		
16		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth (<_DP>)	
					0 =	Absolute
					1 =	Incremental
				TENS:	Units for plane infeed (<_MIDA>)	
					0 =	mm
					1 =	% of tool diameter
				HUNDREDS:	Reserved	
				THOUSANDS:	Length of surface	
					0 =	Incremental
					1 =	Absolute
				TEN THOUSANDS:	Width of surface	
0 =	Incremental					
1 =	Absolute					

3.23.1.12 CYCLE62 - contour call

Syntax

```
CYCLE62 (<_KNAME>, <_TYPE>, <_LAB1>, <_LAB2>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	PRG/CON	<_KNAME>	STRING [140]	Contour name or subprogram name does not have to be programmed in _TYPE = 2	
2		<_TYPE>	INT	Determination of contour input	
				0 =	Subprogram
				1 =	Contour name
				2 =	Labels
		3 =	Labels in the subprogram		
3	LAB1	<_LAB1>	STRING[32]	Label 1, start of contour	
4	LAB2	<_LAB2>	STRING[32]	Label 2, end of contour	

3.23.1.13 CYCLE63 – contour pocket milling / contour pocket residual material / contour spigot milling / contour spigot residual material

Syntax

```
CYCLE63 (<_PRG>, <_VARI>, <_RP>, <_Z0>, <_SC>, <_Z1>, <_F>, <_FZ>, <_DXY>, <_DZ>, <_UXY>, <_UZ>, <_CDIR>, <_XS>, <_YS>, <_ER>, <_EP>,
```

3.23 Programming cycles externally

<_EW>, <_FS>, <_ZFS>, <_TR>, <_DR>, <_UMODE>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	PRG	<_PRG>	STRING [100]	Name of removal program	
2		<_VARI>	INT	Machining type	
				UNITS:	Machining process
				1 =	Roughing
				3 =	Base finishing
				4 =	Edge finishing
				5 =	Chamfering
				TENS:	Infeed type
				0 =	Central insertion
				1 =	Helical insertion
				2 =	Oscillating insertion
HUNDREDS:	Reserved				
THOUSANDS:	Lift mode				
0 =	Lift off to retraction plane				
1 =	Lift off to reference point + safety clearance				
TEN THOUSANDS:	Start point for roughing and finishing base				
0 =	Auto				
1 =	Manual				
3	RP	<_RP>	REAL	Retraction plane (abs)	
4	Z0	<_Z0>	REAL	Reference point of tool axis (abs)	
5	SC	<_SC>	REAL	Safety clearance (to be added to reference point, enter without sign)	
6	Z1	<_Z1>	REAL	Final depth (see <_AMODE> UNITS)	
7	F	<_F>	REAL	Feedrate in the plane during roughing/finishing	
8	FZ	<_FZ>	REAL	Depth infeed rate	
9	DXY	<_DXY>	REAL	Infeed plane - unit (see <_AMODE> TENS)	
10	DZ	<_DZ>	REAL	Depth infeed	
11	UXY	<_UXY>	REAL	Finishing allowance, plane	
12	UZ	<_UZ>	REAL	Finishing allowance, depth	
13		<_CDIR>	INT	Milling direction	
				0 =	Down-cut
1 =	Up-cut				
14	XS	<_XS>	REAL	Starting point X, absolute	
15	YS	<_YS>	REAL	Starting point Y, absolute	
16	ER	<_ER>	REAL	Helical insertion: Radius	
17	EP	<_EP>	REAL	Helical insertion: Pitch	
18	EW	<_EW>	REAL	Oscillating insertion: Maximum insertion angle	

No.	Parameter mask	Parameter internal	Data type	Meaning	
19	FS	<_FS>	REAL	Chamfer width (inc) for chamfering	
20	ZFS	<_ZFS>	REAL	Insertion depth of tool tip when chamfering (see <_AMODE> HUNDREDS)	
21	TR	<_TR>	STRING[32]	Reference tool name when machining residual material	
22	DR	<_DR>	INT	Reference tool D number when machining residual material	
23		<_UMODE>	INT	Reserved	
24		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining/only calculation of start point
				0 =	Normal machining (no compatibility mode needed)
				1 =	Normal machining
2 =	Reserved				
25		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)
				TENS:	Reserved
				HUNDREDS:	Technology mode
				1 =	Pocket
				2 =	Spigot
				THOUSANDS:	Machine residual material
				0 =	No
				1 =	Yes
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)
				0 =	Input: Complete
				1 =	Input: Simple
HUNDRED THOUSANDS:	Automatic program name				
0 =	No				
1 =	Yes				

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
26		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth (Z1)	
					0 =	Absolute (compatibility mode)
					1 =	Incremental
				TENS:	Unit for plane infeed (DXY)	
					0 =	mm
					1 =	% of tool diameter
				HUNDREDS:	Insertion depth for chamfering (ZFS)	
					0 =	Absolute
					1 =	Incremental
THOUSANDS:	---	Reserved				

3.23.1.14 CYCLE64 - Predrilling contour pocket

Syntax

CYCLE64 (<_PRG>, <_VARI>, <_RP>, <_Z0>, <_SC>, <_Z1>, <_F>, <_DXY>, <_UXY>, <_UZ>, <_CDIR>, <_TR>, <_DR>, <_UMODE>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	PRG	<_PRG>	STRING [100]	Name of drilling/centering program	
2		<_VARI>	INT	Machining type	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Reserved
				THOUSANDS:	Lift mode
	0 =	Lift off to retraction plane			
	1 =	Lift off to reference point + safety clearance			
3	RP	<_RP>	REAL	Retraction plane (abs)	
4	Z0	<_Z0>	REAL	Reference point (abs)	
5	SC	<_SC>	REAL	Safety clearance (to be added to reference point, enter without sign)	
6	Z1	<_Z1>	REAL	Drilling/centering depth (see <_AMODE> UNITS)	
7	F	<_F>	REAL	Drilling/centering feedrate	
8	DXY	<_DXY>	REAL	Infeed plane - unit (see <_AMODE> TENS)	
9	UXY	<_UXY>	REAL	Finishing allowance, plane	
10	UZ	<_UZ>	REAL	Finishing allowance, depth	

No.	Parameter mask	Parameter internal	Data type	Meaning		
11		<_CDIR>	INT	Milling direction		
				0 = Down-cut 1 = Up-cut		
12	TR	<_TR>	STRING[20]	Reference tool name		
13	DR	<_DR>	INT	Reference tool D number		
14		<_UMODE>	INT	Reserved		
15		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Select machining/only calculation of start point	
				0 =	Normal machining (no compatibility mode needed)	
				1 =	Normal machining	
2 =	Reserved					
25		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	Technology mode	
				1 =	Predrilling	
				2 =	Centering	
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	---	Reserved
				HUNDRED THOUSANDS:	Automatic program name	
				0 =	No	
1 =	Yes					
26		<_AMODE>	INT	Alternative mode		
				UNITS:	Drilling/centering depth Z1	
				0 =	Absolute (compatibility mode)	
				1 =	Incremental	
				TENS:	Unit for plane infeed (DXY)	
				0 =	mm	
1 =	% of tool diameter					

3.23.1.15 CYCLE70 - thread milling

Syntax

CYCLE70 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_DIATH>, <_H1>, <_FAL>, <_PIT>, <_NT>, <_MID>, <_FFR>, <_TYPH>, <_PA>, <_PO>, <_NSP>, <_VARI>, <_PITA>, <_PITM>, <_PTAB>, <_PTABA>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Thread length (abs, inc), see <_AMODE> Take account of runout at base of hole (at least half pitch)
5	Ø	<_DIATH>	REAL	Nominal diameter of the thread
6	H1	<_H1>	REAL	Thread depth
7	U	<_FAL>	REAL	Finishing allowance
8	P	<_PIT>	REAL	Pitch (select <_PITA>: mm, inch, MODULE, threads/inch)
9	NT	<_NT>	INT	Number of teeth on the tool tip Tool length is always with respect to bottom tooth.
10	DXY	<_MID>	REAL	Maximum infeed per cut <_MID> > <_H1>: All in one cut
11	F	<_FFR>	REAL	Milling feed
12		<_TYPH>	INT	Thread type 0 = Internal thread 1 = External thread
13	X0	<_PA>	REAL	Circle center 1st axis (abs)
14	Y0	<_PO>	REAL	Circle center 2nd axis (abs)
15	αS	<_NSP>	REAL	Start angle (multi-start thread)
16		<_VARI>	INT	Machining type UNITS: 1 = Roughing 2 = Finishing TENS: 1 = From top to bottom 2 = From bottom to top HUNDREDS: 0 = Right-hand thread 1 = Left-hand thread

No.	Parameter mask	Parameter internal	Data type	Meaning	
17		<_PITA>	INT	Evaluation of thread pitch	
				0 =	Compatibility mode
				1 =	Pitch in mm
				2 =	Pitch in threads per inch (TPI)
				3 =	Pitch in inches
4 =	Pitch as MODULE				
18		<_PITM>	STRING[15]	String as marker for pitch input (for the interface only)	
19		<_PTAB>	STRING[20]	String for thread table ("", "ISO", "BSW", "BSP", "UNC") (for the interface only)	
20		<_PTABA>	STRING[20]	String for selection from thread table (e.g. "M 10", "M 12", ...) (for the interface only)	
21		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Machining/calculation of start point
				0 =	Compatibility mode
1 =	Normal machining				
22		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				
23		<_AMODE>	INT	Alternative mode	
				UNITS:	Thread length (<_DP>)
				0 =	Absolute
				1 =	Incremental

3.23.1.16 CYCLE72 - Path milling

Syntax

```
CYCLE72 (<_KNAME>, <_RTP>, <_RFP>, <_SDIS>, <_DP>, <_MID>, <_FAL>,
<_FALD>, <_FFP1>, <_FFD>, <_VARI>, <_RL>, <_AS1>, <_LP1>, <_FF3>,
<_AS2>, <_LP2>, <_UMODE>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1		<_KNAME>	STRING [141]	Name of the contour subprogram
2	RP	<_RTP>	REAL	Retraction plane (abs)
3	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
4	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
5	Z1	<_DP>	REAL	End point, final depth (abs/inc), see <_AMODE>
6	DZ	<_MID>	REAL	Maximum depth infeed (inc; enter without sign)
7	UXY	<_FAL>	REAL	Finishing allowance, plane (inc), allowance at edge contour
8	UZ	<_FALD>	REAL	Finishing allowance depth (inc), allowance at base (enter without sign)
9	FX	<_FFP1>	REAL	Feedrate on contour
10	FZ	<_FFD>	REAL	Feedrate for depth infeed (or spatial infeed)
11		<_VARI>	INT	Machining type
				UNITS:
				Machining
				1 = Roughing
				2 = Finishing
				5 = Chamfering
				TENS:
				0 = Intermediate paths with G0
				1 = Intermediate paths with G1
				HUNDREDS:
				Retraction at the end of contour
				0 = Retraction at the end of contour to reference point
				1 = Retraction at the end of contour to reference point + <_SDIS>
				2 = Retraction at the end of contour by <_SDIS>
				3 = No retraction at the end of contour, approach next start point with contour feed
				THOUSANDS:
				Reserved
				TEN THOUSANDS:
				Machine contour
				0 = Machine contour forward
				1 = Machine contour backward
				Restrictions with backward machining:
				<ul style="list-style-type: none"> • Max 170 contour elements (including chamfers or rounding) • Only values in the (X/Y) and F planes are evaluated

No.	Parameter mask	Parameter internal	Data type	Meaning	
12		<_RL>	INT	Machining direction	
				40 =	Center of contour (G40, approach and retract: straight line or vertical)
				41 =	Left of contour (G41, approach and retract: straight line or circle)
				42 =	Right of contour (G42, approach and retract: straight line or circle)
13		<_AS1>	INT	Contour approach movement	
				UNITS:	
				1 =	Straight line
				2 =	Quadrant
				3 =	Semi-circle
				4 =	Approach and retraction vertically
				TENS:	
0 =	Last movement, in the plane				
1 =	Last movement, spatial				
14	L1	<_LP1>	REAL	Approach path or approach radius (inc; enter without sign)	
15	FZ	<_FF3>	REAL	Feedrate for intermediate paths (G94/G95 as to contour)	
16		<_AS2>	INT	Contour approach movement (not vertical approach/retract)	
				UNITS:	
				1 =	Straight line
				2 =	Quadrant
				3 =	Semi-circle
				TENS:	
				0 =	Last movement, in the plane
1 =	Last movement, spatial				
17	L2	<_LP2>	REAL	Retract path or retract radius (inc, to be entered without sign)	
18		<_UMODE>	INT	Reserved	
19	FS	<_FS>	REAL	Chamfer width (inc)	
20	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>	
21		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Reserved
				HUNDREDS:	Select machining/only calculation of start point
				0 =	Compatibility mode
1 =	Normal machining				

No.	Parameter mask	Parameter internal	Data type	Meaning					
22		<_DMODE>	INT	Display mode					
				UNITS:	Machining plane G17/18/19				
					0 =	Compatibility, the plane effective before the cycle call remains active			
					1 =	G17 (only active in the cycle)			
					2 =	G18 (only active in the cycle)			
								3 =	G19 (only active in the cycle)
				TENS:	Type of feedrate: G group (G94/G95) for surface and depth feedrate				
					0 =	Compatibility mode			
								1 =	G command as before cycle call. G94/G95 same for surface and depth feedrate
				THOUSANDS:					
0 =	Compatibility mode: Contour name is in <_KNAME>								
				1 =	Contour name is programmed in CYCLE62 and transferred to _SC_CONT_NAME				
23		<_AMODE>	INT	Alternative mode					
				UNITS:	End point Z1 (<_DP>)				
					0 =	Absolute (compatibility mode)			
					1 =	Incremental			
				TENS:	Units for plane infeed				
					0 =	mm, inch			
					1 =	Reserved			
				HUNDREDS:	Insertion depth for chamfering (<_ZFS>)				
					0 =	Absolute			
								1 =	Incremental

Note

If the following transfer parameters are programmed indirectly (as parameters), the screen form is not reset:

<_VARI>, <_RL>, <_AS1>, <_AS2>, <_UMODE>, <_GMODE>, <_DMODE>, <_AMODE>

3.23.1.17 CYCLE76 – rectangular spigot

Syntax

CYCLE76 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_DPR>, <_LENG>, <_WID>, <_CRAD>, <_PA>, <_PO>, <_STA>, <_MID>, <_FAL>, <_FALD>, <_FFP1>,

<_FFD>, <_CDIR>, <_VARI>, <_AP1>, <_AP2>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Spigot depth (abs)
5		<_DPR>	REAL	Spigot depth (inc) with respect to Z0 (enter without sign)
6	L	<_LENG>	REAL	Spigot length, see <_GMODE> (enter without sign)
7	W	<_WID>	REAL	Spigot width, see <_GMODE> (enter without sign)
8	R	<_CRAD>	REAL	Spigot corner radius (enter without sign)
9	X0	<_PA>	REAL	Reference point for spigot in 1st axis of plane (abs)
10	Y0	<_PO>	REAL	Reference point for spigot in 2nd axis of plane (abs)
11	$\alpha 0$	<_STA>	REAL	Angle of rotation, angle between longitudinal axis (L) and 1st axis of plane
12	DZ	<_MID>	REAL	Maximum depth infeed (inc; enter without sign)
13	UXY	<_FAL>	REAL	Finishing allowance, plane (inc), allowance at edge contour
14	UZ	<_FALD>	REAL	Finishing allowance depth (inc), allowance at base (enter without sign)
15	FX	<_FFP1>	REAL	Feedrate on contour
16	FZ	<_FFD>	REAL	Depth infeed rate
17		<_CDIR>	INT	Milling direction (enter without sign) UNITS: 0 = Down-cut 1 = Up-cut
18		<_VARI>	INT	Machining UNITS: 1 = Roughing 2 = Finishing 5 = Chamfering
19	L1	<_AP1>	REAL	Length of blank spigot
20	W1	<_AP2>	REAL	Width of blank spigot
21	FS	<_FS>	REAL	Chamfer width (inc)
22	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs, inc), see <_AMODE>

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
23		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Select machining or just calculation of start point	
					0 =	Compatibility mode
					1 =	Normal machining
				THOUSANDS:	Dimensioning of spigot acc. to center or corner	
					0 =	Compatibility mode
					1 =	Dimensioning via center
					2 =	Dimensioning of corner point, spigot +L +W
					3 =	Dimensioning of corner point, spigot -L +W
					4 =	Dimensioning of corner point, spigot +L -W
				TEN THOUSANDS:	Complete machining or remachining	
					0 =	Compatibility mode
					1 =	Complete machining
2 =	Post machining					
24		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/18/19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)	
				TENS:	---	Reserved
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
0 =	Input: Complete					
1 =	Input: Simple					

No.	Parameter mask	Parameter internal	Data type	Meaning		
25		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth Z1 (DP)	
					0 =	Compatibility
					1 =	Incremental
				TENS:	Reserved	
					HUNDREDS:	Insertion depth for chamfering (ZFS)
				0 =		Absolute
1 =	Incremental					

3.23.1.18 CYCLE77 – circular spigot

Syntax

```
CYCLE77 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_DPR>, <_CDIAM>, <_PA>,
<_PO>, <_MID>, <_FAL>, <_FALD>, <_FFP1>, <_FFD>, <_CDIR>, <_VARI>,
<_AP1>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning		
1	RP	<_RTP>	REAL	Retraction plane (abs)		
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)		
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)		
4	Z1	<_DP>	REAL	Spigot depth (abs)		
5		<_DPR>	REAL	Spigot depth (inc) with respect to Z0 (enter without sign)		
6	∅	<_CDIAM>	REAL	Spigot diameter (enter without sign)		
7	X0	<_PA>	REAL	Reference point for spigot in 1st axis of plane (abs)		
8	Y0	<_PO>	REAL	Reference point for spigot in 2nd axis of plane (abs)		
9	DZ	<_MID>	REAL	Maximum depth infeed (inc; enter without sign)		
10	UXY	<_FAL>	REAL	Finishing allowance, plane (inc), allowance at edge contour		
11	UZ	<_FALD>	REAL	Finishing allowance depth (inc), allowance at base (enter without sign)		
12	FX	<_FFP1>	REAL	Feedrate on contour		
13	FZ	<_FFD>	REAL	Depth infeed rate		
14		<_CDIR>	INT	Milling direction (enter without sign)		
				UNITS:		
					0 =	Down-cut
1 =	Up-cut					

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
15		<_VARI>	INT	Machining type		
				UNITS:	Machining	
				1 =	Roughing to final machining allowance	
				2 =	Finishing (allowance X/Y/Z=0)	
				5 =	Chamfering	
16	Ø1	<_AP1>	REAL	Diameter of blank spigot		
17	FS	<_FS>	REAL	Chamfer width (inc)		
18	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>		
19		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Select machining/only calculation of start point	
				0 =	Compatibility mode	
				1 =	Normal machining	
				THOUSANDS:	Reserved	
				TEN THOUSANDS:	Complete machining/remachining	
				0 =	Compatibility mode (process <_AP1> as before)	
				1 =	Complete machining	
				2 =	Post machining	
20		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/18/19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	---	Reserved
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
0 =	Input: Complete					
1 =	Input: Simple					

No.	Parameter mask	Parameter internal	Data type	Meaning		
21		<_AMODE>	INT	Alternative mode		
				UNITS:	Final depth Z1 (DP)	
					0 =	Absolute (compatibility mode)
					1 =	Incremental
				2 =	Absolute	
				TENS:	Reserved	
HUNDREDS:	Insertion depth for chamfering (ZFS)					
	0 =	Absolute				
	1 =	Incremental				

3.23.1.19 CYCLE78 - Drill thread milling

Syntax

```
CYCLE78 (<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_ADPR>, <_FDPR>, <_LDPR>,
<_DIAM>, <_PIT>, <_PITA>, <_DAM>, <_MDEP>, <_VARI>, <_CDIR>, <_GE>,
<_FFD>, <_FRDP>, <_FFR>, <_FFP2>, <_FFA>, <_PITM>, <_PTAB>,
<_PTABA>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	RP	<_RTP>	REAL	Retraction plane (abs)	
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)	
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)	
4	Z1	<_DP>	REAL	Final drilling depth (abs/inc), see <_AMODE>	
5		<_ADPR>	REAL	Predrilling depth with reduced drilling feedrate (inc) effective with <_VARI> TEN THOUSANDS	
6	D	<_FDPR>	REAL	Maximum depth infeed (inc) D ≥ Z1 ⇒ One infeed to the final drilling depth D < Z1 ⇒ Deep drilling cycle with multiple infeeds and chip removal	
7	ZR	<_LDPR>	REAL	Remaining drilling depth when through-drilling (inc) with FR feed	
8	∅	<_DIAM>	REAL	Nominal diameter of the thread	
9	P	<_PIT>	REAL	Pitch as a numerical value	
10		<_PITA>	INT	Evaluation of thread pitch P	
				1 =	Pitch in mm/rev
				2 =	Pitch in threads/inch
				3 =	Pitch in inch/rev
				4 =	Pitch as MODULE
11	DF	<_DAM>	REAL	Absolute value / percentage for each additional infeed (degression), see <_AMODE>	
12	V1	<_MDEP>	REAL	Minimum infeed (inc), only active for degression	

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
13		<_VARI>	INT	Machining type	
				UNITS:	Reserved
				TENS:	Swarf removal before thread milling
				0 =	No chip removal before thread milling (only active at final drilling depth)
				1 =	Chip removal before thread milling (only active at final drilling depth)
				HUNDREDS:	Right-hand/left-hand threads
				0 =	Right-hand thread
				1 =	Left-hand thread
				THOUSANDS:	Remaining drilling depth with drilling feedrate
				0 =	No remaining drilling depth with drilling feedrate FR
1 =	Remaining drilling depth with drilling feedrate FR				
14		<_CDIR>	INT	Milling direction	
				0 =	Down-cut
				1 =	Up-cut
4 =	Up-cut + down-cut (combined roughing + finishing)				
15	Z2	<_GE>	REAL	Retraction distance before thread milling (inc)	
16	F1	<_FFD>	REAL	Drilling feedrate (mm/min or in/min or mm/rev)	
17	FR	<_FRDP>	REAL	Drilling feedrate for remaining drilling depth (mm/min or mm/rev)	
18	F2	<_FFR>	REAL	Feedrate for thread milling (mm/min or mm/tooth)	
19	FS	<_FFP2>	REAL	Finishing feedrate for <_CDIR> =4 (mm/min or mm/tooth)	
20		<_FFA>	INT	Evaluation of feedrates	
				UNITS:	Drilling feed F1
				TENS:	Drilling feedrate for remaining drilling depth FR
				HUNDREDS:	Feedrate for thread milling F2
				THOUSANDS:	Finishing feedrate FS
21		<_PITM>	STRING[15]	String as marker for pitch input (for the interface only) ¹⁾	
22		<_PTAB>	STRING[20]	String for thread table ("", "ISO", "BSW", "BSP", "UNC") (for the interface only) ¹⁾	
23		<_PTABA>	STRING[20]	String for selection from thread table (e.g. "M 10", "M 12", ...) (for the interface only) ¹⁾	

No.	Parameter mask	Parameter internal	Data type	Meaning	
24		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data), reserved	
25		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/18/19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				
26		<_AMODE>	INT	Alternative mode	
				UNITS:	Drilling depth = Final drilling depth Z1 abs/inc
				0 =	Absolute
				1 =	Incremental
				TENS:	Absolute value / percentage DF for each additional infeed (degression)
0 =	Absolute value				
1 =	Percentage (0.001 to 100%)				

Note

¹⁾ Parameters 21, 22 and 23 are only used for thread selection in the screen form thread tables. The thread tables cannot be accessed via cycle definition in the cycle run time.

3.23.1.20 CYCLE79 - multi-edge**Syntax**

```
CYCLE79(<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_NUM>, <_SWL>, <_PA>,
<_PO>, <_STA>, <_RC>, <_AP1>, <_MIDA>, <_MID>, <_FAL>, <_FALD>,
<_FFP1>, <_CDIR>, <_VARI>, <_FS>, <_ZFS>, <_GMODE>, <_DMODE>,
<_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Multiple-edge depth (abs/inc), see <_AMODE>
5	N	<_NUM>	INT	Number of edges (1...n)

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning
6	SW/L	<_SWL>	REAL	Width across flats or edge length (depending on <_VARI>) ("SW" for width across flats, "L" for edge length) Width across flats only if even number of edges, and single edge
7	X0	<_PA>	REAL	Spigot reference point, 1st axis (abs)
8	Y0	<_PO>	REAL	Spigot reference point, 2nd axis (abs)
9	α0	<_STA>	REAL	Angle of rotation, center of edge against 1st axis (X axis)
10	R1/FS1	<_RC>	REAL	Corner rounding with <_NUM> > 2 (radius/chamfer, see <_AMODE>) (inc, to be entered without sign) ("R1" for radius, "FS1" for chamfer)
11	∅	<_AP1>	REAL	Unmachined diameter of spigot
12	DXY	<_MIDA>	REAL	Maximum infeed width (for unit, see <_AMODE>)
13	DZ	<_MID>	REAL	Maximum depth infeed
14	UXY	<_FAL>	REAL	Finishing allowance, plane
15	UZ	<_FALD>	REAL	Finishing allowance, depth
16	F	<_FFP1>	REAL	Machining feedrate
17		<_CDIR>	INT	Milling direction 0 = Down-cut 1 = Up-cut
18		<_VARI>	INT	Machining type UNITS: Machining 1 = Roughing 2 = Finishing 3 = Edge finishing 5 = Chamfering TENS: Width across flats or edge length 0 = Width across flats 1 = Edge length
19	FS	<_FS>	REAL	Chamfer width (inc)
20	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>
21		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data) UNITS: Reserved TENS: Reserved HUNDREDS: Select machining or just calculation of start point 1 = Normal machining

No.	Parameter mask	Parameter internal	Data type	Meaning					
22		<_DMODE>	INT	Display mode					
				UNITS:	Machining plane G17/18/19				
					0 =	Compatibility, the plane effective before the cycle call remains active			
					1 =	G17 (only active in the cycle)			
					2 =	G18 (only active in the cycle)			
								3 =	G19 (only active in the cycle)
				TENS:	---	Reserved			
				HUNDREDS:	---	Reserved			
				THOUSANDS:	---	Reserved			
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)				
0 =	Input: Complete								
1 =	Input: Simple								
23		<_AMODE>	INT	Alternative mode					
				UNITS:	Final depth (<_DP>)				
					0 =	Absolute			
					1 =	Incremental			
				TENS:	Units for plane infeed (<_MIDA>)				
					0 =	mm			
					1 =	% of tool diameter			
				HUNDREDS:	Insertion depth for chamfering (<_ZFS>)				
					0 =	Absolute			
					1 =	Incremental			
				THOUSANDS:	Corner rounding (<_RC>)				
					0 =	Radius			
					1 =	Chamfer			

3.23.1.21 CYCLE81 - drilling, centering

Syntax

```
CYCLE81 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <_GMODE>,
<_DMODE>, <_AMODE>)
```

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
4	Z1Ø	<DP>	REAL	Drilling depth (abs) / centering diameter (abs), see <_GMODE>	
5	Z1	<DPR>	REAL	Drilling depth (inc)	
6	DT	<DTB>	REAL	Dwell time at final drilling depth, see <_AMODE>	
7		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Centering with respect to depth/diameter
				0 =	Compatibility, depth
				1 =	Diameter
8		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)
9		<_AMODE>	INT	Alternative mode	
				UNITS:	Drilling depth Z1 (abs/inc)
				0 =	Compatibility, from DP/DPR programming
				1 =	Incremental
				2 =	Absolute
				TENS:	Dwell time at final drilling depth DT in seconds/revolutions
				0 =	Compatibility, from DTB sign (> 0 seconds or < 0 revolutions)
				1 =	In seconds
				2 =	In revolutions

3.23.1.22 CYCLE82 - drilling, counterboring

Syntax

CYCLE82 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <_GMODE>, <_DMODE>, <_AMODE>, <_VARI>, <S_ZA>, <S_FA>, <S_ZD>, <S_FD>)

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)

No.	Parameter mask	Parameter internal	Data type	Meaning
4	Z1	<DP>	REAL	Drilling depth (abs), see <_AMODE>
5	Z1	<DPR>	REAL	Drilling depth (inc), see <_AMODE>
6	DT	<DTB>	REAL	Dwell time at final drilling depth, see <_AMODE>
7		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)
				UNITS: Reserved
				TENS: Drilling depth with respect to tip/shank
				0 = Compatibility, tip
				1 = Shank
8		<_DMODE>	INT	Display mode
				UNITS: Machining plane G17/G18/G19
				0 = Compatibility, the plane effective before the cycle call remains active
				1 = G17 (only active in the cycle)
				2 = G18 (only active in the cycle)
				3 = G19 (only active in the cycle)
				TENS: Reserved
				HUNDREDS: Reserved
				THOUSANDS: Reserved
				TEN THOUSANDS: Technology scaling in cycle screen forms (Page 1193)
				0 = Input: Complete
				1 = Input: Basic

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
9		<_AMODE>	INT	Alternative mode		
				UNITS:	Drilling depth Z1 (abs/inc)	
					0 =	Compatibility, from DP/DPR programming
					1 =	Incremental
					2 =	Absolute
				TENS:	Dwell time DT at final drilling depth in seconds/revolutions	
					0 =	Compatibility, from DT sign (> 0 seconds / < 0 revolutions)
					1 =	In seconds
					2 =	In revolutions
				HUNDREDS:	Drilling depth ZA abs/inc	
					0 =	Incremental
					1 =	Absolute
				THOUSANDS:	Evaluation of predrilling feedrate	
					0 =	As % of drilling feedrate
					1 =	F/min
					2 =	F/rev
				TEN THOUSANDS:	Remaining drilling depth ZD abs/inc	
					0 =	Incremental
1 =	Absolute					
HUNDRED THOUSANDS:	Evaluation of remaining drilling feedrate					
	0 =	As % of drilling feedrate				
	1 =	F/min				
	2 =	F/rev				
10		<_VARI>	INT	Predrilling/through-drilling machining type		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Reserved	
				THOUSANDS:	Through drilling	
					0 =	Through drilling "No"
					1 =	Through drilling "Yes"
				TEN THOUSANDS:	Predrilling	
					0 =	Predrilling "No"
					1 =	Predrilling "Yes"
11	ZA	<S_ZA>	REAL	Incremental predrilling depth in relation to reference point or absolute (see <_AMODE> HUNDREDS)		
12	FA	<S_FA>	REAL	Predrilling feedrate as value or in % (in conjunction with <_AMODE> THOUSANDS)		

No.	Parameter mask	Parameter internal	Data type	Meaning
13	ZD	<S_ZD>	REAL	Incremental remaining drilling depth in relation to final drilling depth or absolute (see <_AMODE> TEN THOUSANDS)
14	FD	<S_FD>	REAL	Remaining drilling feedrate as value or in % (in conjunction with <_AMODE> HUNDRED THOUSANDS)

3.23.1.23 CYCLE83 – deep-hole drilling 1

Syntax

```
CYCLE83(<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <FDEP>, <FDPR>, <_DAM>,
<DTB>, <DTS>, <FRF>, <VARI>, <_AXN>, <_MDEP>, <_VRT>, <_DTD>,
<_DIS1>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<DP>	REAL	Final drilling depth (abs), see <_AMODE>
5	Z1	<DPR>	REAL	Final drilling depth (inc), see <_AMODE>
6	D	<FDEP>	REAL	1st drilling depth (abs), see <_AMODE>
7	D	<FDPR>	REAL	1st drilling depth (inc), see <_AMODE>
8	DF	<_DAM>	REAL	Degression value / percentage for each additional infeed, see <_AMODE>
9	DTB	<DTB>	REAL	Dwell time at drilling depth, see <_AMODE>
10	DTS	<DTS>	REAL	Dwell time at start point (for chip removal only), see <_AMODE>
11	FD1	<FRF>	REAL	Percentage for the feedrate for the first infeed, see <_AMODE>
12		<VARI>	INT	Machining type UNITS: Chip breaking/removal 0 = Chip breaking 1 = Swarf removal
13		<_AXN>	INT	Tool axis 0 = 3rd geometry axis 1 = 1st geometry axis 2 = 2nd geometry axis > 2 = 3rd geometry axis
14	V1	<_MDEP>	REAL	Minimum infeed (only for degression percentage)
15	V2	<_VRT>	REAL	Retraction distance after each machining step (for chip breaking only) > 0 Variable retraction distance 0 = Default value 1 mm
16	DT	<_DTD>	REAL	Dwell time at final drilling depth, see <_AMODE>

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
17	V3	<_DIS1>	REAL	Limit distance (for chip removal only), see <_AMODE>		
18		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Drilling depth with respect to tip/shank	
				0 =	Tip	
				1 =	Shank	
19		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	---	Reserved
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
0 =	Input: Complete					
1 =	Input: Simple					

No.	Parameter mask	Parameter internal	Data type	Meaning	
20		<_AMODE>	INT	Alternative mode	
				UNITS:	Drilling depth = Final drilling depth Z1 (abs/inc)
				0 =	Compatibility, from programming <DP>/<DPR>
				1 =	Incremental
				2 =	Absolute
				TENS:	Dwell time at drilling depth DTB in seconds/revolutions
				0 =	Compatibility, from DTB sign (> 0 seconds or < 0 revolutions)
				1 =	In seconds
				2 =	In revolutions
				HUNDREDS:	Dwell time at start point of DTS in seconds/revolutions
				0 =	Compatibility, from DTS sign (> 0 seconds or < 0 revolutions)
				1 =	In seconds
				2 =	In revolutions
				THOUSANDS:	Dwell time at final drilling depth DTD in seconds/revolutions
				0 =	Compatibility, from DTD sign (> 0 seconds or < 0 revolutions)
				1 =	In seconds
				2 =	In revolutions
				TEN THOUSANDS:	1st drilling depth D (abs/inc)
				0 =	Compatibility, from programming <FDEPF>/<DPR>
				1 =	Incremental
				2 =	Absolute
				HUNDRED THOUSANDS:	Degression value / percentage <_DAM> for each additional infeed
				0 =	Compatibility, from <_DAM> sign (> 0 degression value or < 0 factor 0.001 to 1.0)
				1 =	Degression value
2 =	Percentage (0.001 to 100%)				
ONE MILLION:	Limit distance V3 automatic/manual				
0 =	Compatibility from <_DIS1> sign (= 0 automatic or > 0 manual)				
1 =	Automatic (calculated in the cycle)				
2 =	Manual (programmed value)				
TEN MILLIONS:	Feedrate factor for first infeed <FRF> as factor/percentage				

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning
				0 = Compatibility, as a factor (0.001 to 1.0, FRF = 0 means 100%)
				1 = Percentage (0.001 to 999.999%)

3.23.1.24 CYCLE84 - tapping without compensating chuck

Syntax

CYCLE84 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <SDAC>, <MPIT>, <PIT>, <POSS>, <SST>, <SST1>, <_AXN>, <_PITA>, <_TECHNO>, <_VARI>, <_DAM>, <_VRT>, <_PITM>, <_PTAB>, <_PTABA>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<DP>	REAL	Drilling depth = final drilling depth (abs), see <_AMODE>
5	Z1	<DPR>	REAL	Drilling depth = final drilling depth (inc), see <_AMODE>
6	DT	<DTB>	REAL	Dwell time at drilling depth in seconds
7	SDE	<SDAC>	INT	Direction of rotation after end of cycle
8		<MPIT>	REAL	Thread size for "ISO metric" only (pitch is calculated internally during run time)
9	P	<PIT>	REAL	Pitch as a value, for unit see <_PITA>
10	αS ¹⁾	<POSS>	REAL	Spindle position for oriented spindle stop
11	S	<SST>	REAL	Spindle speed for tapping
12	SR	<SST1>	REAL	Spindle speed for retraction
13		<_AXN>	INT	Drilling axis
				0 = 3rd geometry axis
				1 = 1st geometry axis
				2 = 2nd geometry axis
				≥ 3 = 3rd geometry axis
14		<_PITA>	INT	Pitch unit (evaluation of <PIT> and <MPIT>)
				0 = Pitch in mm - evaluation<MPIT>/<PIT>
				1 = Pitch in mm - evaluation<PIT>
				2 = Pitch in TPI - evaluation of <PIT> (threads per inch)
				3 = Pitch in inches - evaluation<PIT>
				4 = MODULUS - evaluation<PIT>

No.	Parameter mask	Parameter internal	Data type	Meaning				
15		<_TECHNO>	INT	Technology ¹⁾				
				UNITS:	Exact stop response			
					0 =	Exact stop response active as before cycle call		
					1 =	Exact stop G601		
					2 =	Exact stop G602		
						3 =	Exact stop G603	
				TENS:	Feedforward control			
					0 =	With/without feedforward control active as before cycle call		
					1 =	With feedforward control FFWON		
						2 =	Without feedforward control FFWOF	
				HUNDREDS:	Acceleration			
					0 =	SOFT/BRISK/DRIVE active as before cycle call		
					1 =	With jerk limitation SOFT		
					2 =	Without jerk limitation BRISK		
		3 =	Reduced acceleration DRIVE					
THOUSANDS:	MCALL spindle mode							
	0 =	Reactivate spindle operation for MCALL						
		1 =	For MCALL remain in position control					
16		<_VARI>	INT	Machining type				
				UNITS:	0 =	1 cut		
					1 =	Chip breaking (deep hole tapping)		
					2 =	Chip removal (deep hole tapping)		
				THOUSANDS:	ISO/SIEMENS mode not relevant for screen form			
0 =	Call from ISO compatibility							
		1 =	Call from SIEMENS context					
17	D	<_DAM>	REAL	Maximum depth infeed (for chip removal/breaking only)				
18	V2	<_VRT>	REAL	Retraction distance after each machining step (for chip breaking only), see <_AMODE>				
19		<_PITM>	STRING[15]	String as marker for pitch input ²⁾				
20		<_PTAB>	STRING[5]	String for thread table ("", "ISO", "BSW", "BSP", "UNC") ²⁾				
21		<_PTABA>	STRING[20]	String for selection from thread table (e.g. "M 10", "M 12", ...) ²⁾				
22		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)				
				UNITS:	Reserved			
				TENS:	Reserved			

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning																												
23		<_DMODE>	INT	<table border="1"> <tr> <td colspan="2" data-bbox="665 306 906 336">Display mode</td> </tr> <tr> <td data-bbox="665 342 906 372">UNITS:</td> <td data-bbox="911 342 1439 372">Machining plane G17/G18/G19</td> </tr> <tr> <td data-bbox="916 378 986 408">0 =</td> <td data-bbox="991 378 1439 442">Compatibility, the plane effective before the cycle call remains active</td> </tr> <tr> <td data-bbox="916 449 986 478">1 =</td> <td data-bbox="991 449 1439 478">G17 (only active in the cycle)</td> </tr> <tr> <td data-bbox="916 485 986 514">2 =</td> <td data-bbox="991 485 1439 514">G18 (only active in the cycle)</td> </tr> <tr> <td data-bbox="916 521 986 551">3 =</td> <td data-bbox="991 521 1439 551">G19 (only active in the cycle)</td> </tr> <tr> <td data-bbox="665 557 906 587">TENS:</td> <td data-bbox="911 557 1439 587">Reserved</td> </tr> <tr> <td data-bbox="665 593 906 623">HUNDREDS:</td> <td data-bbox="911 593 1439 623">Reserved</td> </tr> <tr> <td data-bbox="665 629 906 659">THOUSANDS:</td> <td data-bbox="911 629 1439 736">Compatibility mode (for recompilation screen form only), if MD 52216 bit0 = 1¹⁾</td> </tr> <tr> <td data-bbox="916 742 986 772">0 =</td> <td data-bbox="991 742 1439 849">Technology parameters are displayed (compatibility): TECHNO parameters effective</td> </tr> <tr> <td data-bbox="916 834 986 863">1 =</td> <td data-bbox="991 834 1439 919">Technology parameters are not displayed: Technology active "as before cycle call"</td> </tr> <tr> <td data-bbox="665 925 906 955">TEN THOUSANDS:</td> <td data-bbox="911 925 1439 989">Technology scaling in cycle screen forms (Page 1193)</td> </tr> <tr> <td data-bbox="916 995 986 1025">0 =</td> <td data-bbox="991 995 1439 1025">Input: Complete</td> </tr> <tr> <td data-bbox="916 1032 986 1061">1 =</td> <td data-bbox="991 1032 1439 1061">Input: Simple</td> </tr> </table>	Display mode		UNITS:	Machining plane G17/G18/G19	0 =	Compatibility, the plane effective before the cycle call remains active	1 =	G17 (only active in the cycle)	2 =	G18 (only active in the cycle)	3 =	G19 (only active in the cycle)	TENS:	Reserved	HUNDREDS:	Reserved	THOUSANDS:	Compatibility mode (for recompilation screen form only), if MD 52216 bit0 = 1 ¹⁾	0 =	Technology parameters are displayed (compatibility): TECHNO parameters effective	1 =	Technology parameters are not displayed: Technology active "as before cycle call"	TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	0 =	Input: Complete	1 =	Input: Simple
Display mode																																
UNITS:	Machining plane G17/G18/G19																															
0 =	Compatibility, the plane effective before the cycle call remains active																															
1 =	G17 (only active in the cycle)																															
2 =	G18 (only active in the cycle)																															
3 =	G19 (only active in the cycle)																															
TENS:	Reserved																															
HUNDREDS:	Reserved																															
THOUSANDS:	Compatibility mode (for recompilation screen form only), if MD 52216 bit0 = 1 ¹⁾																															
0 =	Technology parameters are displayed (compatibility): TECHNO parameters effective																															
1 =	Technology parameters are not displayed: Technology active "as before cycle call"																															
TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)																															
0 =	Input: Complete																															
1 =	Input: Simple																															

No.	Parameter mask	Parameter internal	Data type	Meaning		
24		<_AMODE>	INT	Alternative mode		
				UNITS:	Drilling depth = Final drilling depth Z1 (abs/inc)	
					0 =	Compatibility, from programming <DP>/<DPR>
					1 =	Incremental
					2 =	Absolute
				TENS:	Reserved	
				HUNDREDS:	Reserved	
				THOUSANDS:	Thread direction of rotation right/left	
					0 =	Compatibility, from PIT/MPTI sign
					1 =	Right
					2 =	Left
				TEN THOUSANDS:	Reserved	
				HUNDRED THOUSANDS:	Reserved	
				ONE MILLION:	Retraction distance after each machining step V2 manual/automatic	
0 =	Compatibility, from <_VRT> programming (> 0 variable value or ≤ 0 standard value 1 mm / 0.0394 inch)					
1 =	Automatic (standard value 1 mm / 0.0394 inch)					
	2 =	Manual (programmed as under V2)				
<p>¹⁾ Technology fields may be hidden, depending on the setting date SD52216 \$MCS_FUNCTION_MASK_DRILL</p> <p>²⁾ Parameters 19, 20 and 21 are only used for thread selection in the screen form thread tables. The thread tables cannot be accessed via cycle definition in the cycle run time.</p>						

3.23.1.25 CYCLE85 - reaming

Syntax

```
CYCLE85 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <FFR>, <RFF>, <_GMODE>, <_DMODE>, <_AMODE>)
```

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<RTP>	REAL	Retraction plane (abs)
2	Z0	<RFP>	REAL	Reference point (abs)
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<DP>	REAL	Drilling depth (abs), see <_AMODE>
5	Z1	<DPR>	REAL	Drilling depth (inc), see <_AMODE>
6	DT	<DTB>	REAL	Dwell time at final drilling depth, see <_AMODE>

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
7	F	<FFR>	REAL	Feedrate	
8	FR	<RFF>	REAL	Feedrate during retraction	
9		<_GMODE>	INT	Reserved	
10		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				
11		<_AMODE>	INT	Alternative mode (drilling)	
				UNITS:	Drilling depth Z1 (abs/inc)
				0 =	Compatibility, from DP/DPR programming
				1 =	Incremental
				2 =	Absolute
				TENS:	Dwell time DT at final drilling depth in seconds/revolutions
0 =	Compatibility, from DT sign (> 0 seconds or < 0 revolutions)				
1 =	In seconds				
2 =	In revolutions				

3.23.1.26 CYCLE86 - boring

Syntax

CYCLE86 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <SDIR>, <RPA>, <RPO>, <RPAP>, <POSS>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	RP	<RTP>	REAL	Retraction plane (abs)	
2	Z0	<RFP>	REAL	Reference point (abs)	
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)	
4	Z1	<DP>	REAL	Drilling depth (abs), see <_AMODE>	
5	Z1	<DPR>	REAL	Drilling depth (inc), see <_AMODE>	
6	DT	<DTB>	REAL	Dwell time at final drilling depth, see <_AMODE>	
7	DIR	<SDIR>	INT	3 =	M3
				4 =	M4

No.	Parameter mask	Parameter internal	Data type	Meaning	
8	DX	<RPA>	REAL	Lift-off distance in X direction	
9	DY	<RPO>	REAL	Lift-off distance in the Y direction	
10	DZ	<RPAP>	REAL	Lift-off distance in the Z direction	
11	SPOS	<POSS>	REAL	Spindle position for lift-off (for oriented spindle stop, in degrees)	
12		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Lift mode
				0 =	Lift off, compatibility
	1 =	Do not lift off contour			
13		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				
14		<_AMODE>	INT	Alternative mode	
				UNITS:	Drilling depth Z1 (abs/inc)
				0 =	Compatibility, from programming<DP>/<DPR>
				1 =	Incremental
				2 =	Absolute
				TENS:	Dwell time at final drilling depth DT in seconds/revolutions
				0 =	Compatibility, from DT sign (> 0 seconds or < 0 revolutions)
1 =	In seconds				
2 =	In revolutions				

3.23.1.27 CYCLE92 - cut-off

Syntax

```
CYCLE92 (<_SPD>, <_SPL>, <_DIAG1>, <_DIAG2>, <_RC>, <_SDIS>, <_SV1>,
<_SV2>, <_SDAC>, <_FF1>, <_FF2>, <_SS2>, <_DIAGM>, <_VARI>, <_DN>,
<_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	X0	<_SPD>	REAL	Reference point (abs, always diameter)
2	Y0	<_SPL>	REAL	Reference point (abs)

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
3	X1	<_DIAG1>	REAL	Depth for speed reduction, see <_AMODE> (UNITS)	
4	X2	<_DIAG2>	REAL	Final depth, see <_AMODE> (TENS)	
5	R/FS	<_RC>	REAL	Rounding status or chamfer width, see <_AMODE> (THOUSANDS)	
6	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)	
7	S	<_SV1>	REAL	Constant spindle speed, see <_AMODE> (TEN THOUSANDS)	
	V			Constant cutting rate	
8	SV	<_SV2>	REAL	Maximum speed at constant cutting speed	
9	DIR	<_SDAC>	INT	Direction of spindle rotation	
				3 = For M3 4 = For M4	
10	F	<_FF1>	REAL	Infeed as far as depth for speed reduction	
11	FR	<_FF2>	REAL	Reduced infeed as far as final depth	
12	SR	<_SS2>	REAL	Reduced speed as far as final depth	
13	XM	<_DIAGM>	REAL	Depth to withdraw parts gripper (abs, always diameter)	
14		<_VARI>	INT	Machining type	
				UNITS:	Retraction
				0 =	Retraction to <_SPD> + <_SDIS>
				1 =	No retraction at the end
				TENS:	Parts gripper
				0 =	No, do not execute M command
1 =	Yes, call from CUST_TECHCYC(101)- open drawer, CUST_TECHCYC(102)- close drawer				
15		<_DN>	INT	D number for 2nd edge of tool; if not programmed => D+1	
20		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				

No.	Parameter mask	Parameter internal	Data type	Meaning		
21		<_AMODE>	INT	Alternative mode		
				UNITS:	Depth for speed reduction (<_DIAG1>)	
					0 =	Absolute, value of transverse axis in the diameter
				1 =	Incremental, value of transverse axis in the radius	
				TENS:	Final depth (<_DIAG2>)	
					0 =	Absolute, value of transverse axis in the diameter
				1 =	Incremental, value of transverse axis in the radius	
				HUNDREDS:	Reserved	
				THOUSANDS:	Radius/chamfer (<_RC>)	
					0 =	Radius
				1 =	Chamfer	
				TEN THOUSANDS:	Spindle speed / cutting rate (<_SV1>)	
0 =	Constant spindle speed					
1 =	Constant cutting rate					

3.23.1.28 CYCLE95 - contour cutting

Syntax

CYCLE95 (<NPP>, <MID>, <FALZ>, <FALX>, <FAL>, <FF1>, <FF2>, <FF3>, <_VARI>, <DT>, <DAM>, <_VRT>, <_GMODE>, <_DMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	CON	<NPP>	STRING [140]	Contour name
2	D	<MID>	REAL	Maximum depth infeed during roughing, see <_GMODE>
3	UZ	<FALZ>	REAL	Finishing allowance in Z
4	UX	<FALX>	REAL	Finishing allowance in X
5	U	<FAL>	REAL	Finishing allowance parallel to contour (effective in both axes)
6	F	<FF1>	REAL	Feedrate for roughing
7	FY	<FF2>	REAL	Insertion feedrate, relief cuts
8	FS	<FF3>	REAL	Finishing feedrate

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
9		<_VARI>	INT	Machining type		
				UNITS and TENS:	1 =	Roughing, longitudinal, external
					2 =	Roughing, transverse, external
					3 =	Roughing, longitudinal, internal
					4 =	Roughing, transverse, internal
					5 =	Finishing, longitudinal, external
					6 =	Finishing, transverse, external
					7 =	Finishing, longitudinal, internal
					8 =	Finishing, transverse, internal
					9 =	Complete machining, longitudinal, external
					10 =	Complete machining, transverse, external
					11 =	Complete machining, longitudinal, internal
					12 =	Complete machining, transverse, internal
				HUNDREDS:	0 =	With rounding at the contour, without residual corners
1 =	Without rounding at the contour					
2 =	Rounding only to previous intersection, residual corners can result					
10	DT	<DT>	REAL	Dwell time at feed interruption		
11	DI	<DAM>	REAL	Distance for feed interruptions		
12	VRT	<_VRT>	REAL	Lift-off distance from the contour		
				0 =	A lift-off distance of 1 mm is used internally regardless of the active system (inch or metric)	
				> 0 =	Lift-off distance	
13		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Evaluation of the infeed depth	
					0 =	Infeed depth is calculated corresponding to the G group DIAMON/DIAMOF
				1 =	Infeed depth acts as radius value (independent of DIAMON/DIAMOF)	

No.	Parameter mask	Parameter internal	Data type	Meaning		
14		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)	
				THOUSANDS:		
0 =	Compatibility mode: Contour name is in NPP					
1 =	Contour name is programmed in CYCLE62 and transferred to _SC_CONT_NAME					

3.23.1.29 CYCLE98 - thread chain

Syntax

CYCLE98 (<_PO1>, <_DM1>, <_PO2>, <_DM2>, <_PO3>, <_DM3>, <_PO4>, <_DM4>, <APP>, <ROP>, <TDEP>, <FAL>, <_IANG>, <NSP>, <NRC>, <NID>, <_PP1>, <_PP2>, <_PP3>, <_VARI>, <_NUMTH>, <_VRT>, <_MID>, <_GDEP>, <_IFLANK>, <_PITA>, <_PITM1>, <_PITM2>, <_PITM3>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	Z0	<_PO1>	REAL	Reference point in Z (abs)
2	X0	<_DM1>	REAL	Reference point in X (abs), in diameter
3	Z1	<_PO2>	REAL	Intermediate point 1 in Z (abs/inc), see <_AMODE> (UNITS)
4	X1	<_DM2>	REAL	Intermediate point 1 in X (abs/inc), see <_AMODE> (TENS) or
	X1 α			Thread inclination 1 (-90° to 90°) abs is always diameter, inc is always radius
5	Z2	<_PO3>	REAL	Intermediate point 2 in Z, (abs/inc), see <_AMODE> (HUNDREDS)
6	X2	<_DM3>	REAL	Intermediate point 2 in X (abs/inc), see <_AMODE> (THOUSANDS) or
	X2 α			Thread inclination 2 (-90° to 90°) abs is always diameter, inc is always radius
7	Z3	<_PO4>	REAL	End point in Z, (abs/inc), see <_AMODE> (TEN THOUSANDS)
8	X3	<_DM4>	REAL	End point in X, (abs/inc), see <_AMODE> (HUNDRED THOUSANDS) or
	X3 α			Thread inclination 3 (-90° to 90°) abs is always diameter, inc is always radius
9	LW	<APP>	REAL	Thread run-in (inc, to be entered without sign)

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
10	LR	<ROP>	REAL	Thread run-out (inc, to be entered without sign)	
11	H1	<TDEP>	REAL	Thread depth (inc, to be entered without sign)	
12	U	<FAL>	REAL	Finishing allowance in X and Z	
13	DP αP	<_IANG>	REAL	Infeed slope as a distance or an angle, see <_AMODE> (ONE MILLION)	
				The infeed slope is applied according to the setting of parameter <_VARI> (HUNDREDS).	
				Definition for <_VARI_HUNDREDS = 0 - Compatibility mode:	
				> 0 =	Side infeed on one side
				0 =	Infeed vertical in the thread
				< 0 =	Side infeed with alternating sides
				Definition for <_VARI_HUNDREDS <> 0:	
> 0 =	Infeed on the positive side				
0 =	Center infeed				
< 0 =	Infeed on the negative side				
14	α0	<NSP>	REAL	Starting angle offset for the 1st thread	
15		<NRC>	INT	Number of roughing cuts, see <_VARI> (TEN THOUSANDS)	
16	NN	<NID>	INT	Number of non-cuts	
17	P0	<_PP1>	REAL	Pitch for 1st section of thread, see <_PITA>	
18	P1	<_PP2>	REAL	Pitch for 2nd section of thread, see <_PITA>	
19	P2	<_PP3>	REAL	Pitch for 3rd section of thread, see <_PITA>	

No.	Parameter mask	Parameter internal	Data type	Meaning		
20		<_VARI>	INT	Machining		
				UNITS:	Technology	
					1 =	External thread with linear infeed
					2 =	Internal thread with linear infeed
					3 =	External thread with degressive infeed, cross-section of cut remains constant
					4 =	Internal thread with degressive infeed, cross-section of cut remains constant
				TENS:	Reserved	
				HUNDREDS:	Infeed type	
					0 =	Compatibility mode for <_IANG>
					1 =	Infeed on one side
					2 =	Infeed alternate sides
				THOUSANDS:	Reserved	
				TEN THOUSANDS:	Alternative depth infeed	
					0 =	Compatibility, preset number of roughing cuts (<_NRC>)
					1 =	Preset value for 1st infeed (<_MID>)
				HUNDRED THOUSANDS:	Machining type	
					0 =	Compatibility (roughing and finishing)
1 =	Roughing					
2 =	Finishing					
	3 =	Roughing and finishing				
ONE MILLION:	Machining sequence for multistart thread					
	0 =	In ascending order of threads				
	1 =	In descending order of threads				
21	N	<_NUMTH>	INT	Number of thread turns		
22		<_VRT>	REAL	Return distance (inc)		
				0 =	A lift-off distance of 1 mm is used internally regardless of the active system (inch or metric)	
				> 0 =	Lift-off distance	
23	D1	<_MID>	REAL	First infeed, see <_VARI> (TEN THOUSANDS)		
24	DA	<_GDEP>	REAL	Thread changeover depth (only effective with "multiple start")		
				0 =	Do not observe any thread changeover depth	
				> 0 =	Observe thread changeover depth	
25		<_IFLANK>	REAL	Infeed slope as width (for interface only)		

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
26		<_PITA>	INT	Evaluation of thread pitch		
				0 =	Compatibility mode for pitch, evaluation <_PP1> to <_PP3> as previously, according to active system (metric/inch)	
				1 =	Pitch in mm	
				2 =	Pitch in TPI (threads per inch)	
				3 =	Pitch in inches	
4 =	MODULUS					
27		<_PITM1>	STRING[15]	String as marker for pitch input (for the interface only)		
28		<_PITM2>	STRING[15]	String as marker for pitch input (for the interface only)		
29		<_PITM3>	STRING[15]	String as marker for pitch input (for the interface only)		
30		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	---	Reserved
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
0 =	Input: Complete					
1 =	Input: Simple					

No.	Parameter mask	Parameter internal	Data type	Meaning		
31		<_AMODE>	INT	Alternative mode		
				UNITS:	1st intermediate point in Z (Z1)	
					0 =	Absolute
					1 =	Incremental
				TENS:	1st intermediate point in X (X1)	
					0 =	Absolute
					1 =	Incremental
					2 =	α
				HUNDREDS:	2nd intermediate point in Z (Z2)	
					0 =	Absolute
					1 =	Incremental
				THOUSANDS:	2nd intermediate point in X (X2)	
					0 =	Absolute
					1 =	Incremental
					2 =	α
				TEN THOUSANDS:	End point in Z (Z3)	
					0 =	Absolute
					1 =	Incremental
				HUNDRED THOUSANDS:	End point in X (X3)	
					0 =	Absolute
					1 =	Incremental
					2 =	α
				ONE MILLION:	Select infeed slope as angle or width	
					0 =	Infeed angle <_IANG>
1 =	Infeed slope <_IFLANK>					
TEN MILLIONS:	Single/multiple thread					
	0 =	Compatibility mode (starting angle <_NSP> is evaluated)				
	1 =	Single thread (with starting angle offset <_NSP>)				
	2 =	Multiple				

3.23.1.30 CYCLE99 - thread turning

Syntax

```
CYCLE99 (<_SPL>, <_SPD>, <_FPL>, <_FPD>, <_APP>, <_ROP>, <_TDEP>,
<_FAL>, <_IANG>, <_NSP>, <_NRC>, <_NID>, <_PIT>, <_VARI>, <_NUMTH>,
<_SDIS>, <_MID>, <_GDEP>, <_PIT1>, <_FDEP>, <_GST>, <_GUD>,
<_IFLANK>, <_PITA>, <_PITM>, <_PTAB>, <_PTABA>, <_DMODE>, <_AMODE>,
<_S_XRS>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	Z0	<_SPL>	REAL	Reference point (abs)	
2	X0	<_SPD>	REAL	Reference point (abs, always diameter)	
3	Z1	<_FPL>	REAL	End point in conjunction with <_AMODE> (UNITS)	
4	X1	<_FPD>	REAL	End point in conjunction with <_AMODE> (TENS)	
5	LW/LW2	<_APP>	REAL	Thread run-in in conjunction with <_AMODE> (HUNDREDS) or Thread run-in = thread run-out in conjunction with <_AMODE> (HUNDREDS)	
6	LR	<_ROP>	REAL	Thread run-out	
7	H1	<_TDEP>	REAL	Thread depth	
8	U	<_FAL>	REAL	Finishing allowance in X and Z	
9	DP	<_IANG>	REAL	Infeed slope as a distance or an angle, in conjunction with <_AMODE> (THOUSANDS)	
	αP			> 0 =	Infeed on the positive side
				< 0 =	Infeed on the negative side
				0 =	Center infeed
10	α0	<_NSP>	REAL	Starting angle offset (only effective with "single start")	
11	ND	<_NRC>	INT	Number of roughing cuts, in combination with <_VARI> (TEN THOUSANDS)	
12	NN	<_NID>	INT	Number of non-cuts	
13	P	<_PIT>	REAL	Pitch as a value, in conjunction with <_PITA>	

No.	Parameter mask	Parameter internal	Data type	Meaning		
14		<_VARI>	INT	Machining type		
				UNITS:	Technology	
					1 =	External thread with linear infeed
					2 =	Internal thread with linear infeed
					3 =	External thread with degressive infeed, cross-section of cut remains constant
				4 =	Internal thread with degressive infeed, cross-section of cut remains constant	
				TENS:	Reserved	
				HUNDREDS:	Infeed type	
					1 =	Infeed on one side
				2 =	Infeed alternate sides	
				THOUSANDS:	Reserved	
				TEN THOUSANDS:	Alternative depth infeed	
					0 =	Preset number of roughing cuts (<_NRC>)
					1 =	Preset value for 1st infeed (<_MID>)
HUNDRED THOUSANDS:	Machining type					
	1 =	Roughing				
	2 =	Finishing				
	3 =	Roughing and finishing				
ONE MILLION:	Machining sequence for multistart thread					
	0 =	In ascending order of threads				
1 =	In descending order of threads					
15	N	<_NUMTH>	INT	Number of thread turns		
16	VR	<_SDIS>	REAL	Return distance, inc		
17	D1	<_MID>	REAL	First infeed depth, in conjunction with <_VARI> (TEN THOUSANDS)		
18	DA	<_GDEP>	REAL	Thread changeover depth (only effective with "multiple start")		
				0 =	Do not observe any thread changeover depth	
				> 0 =	Observe thread changeover depth	
19	G	<_PIT1>	REAL	Change of pitch per revolution		
				0 =	Pitch is constant (G33)	
				> 0 =	Pitch increases (G34)	
				< 0 =	Pitch decreases (G35)	
20		<_FDEP>	REAL	Insertion depth (enter without sign)		
21	N1	<_GST>	INT	Starting thread N1 = 1...N, in conjunction with <_AMODE> (HUNDRED THOUSANDS)		
22		<_GUD>	INT	Reserved		
23		<_IFLANK>	REAL	Infeed slope as width (for interface only)		

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
24		<_PITA>	INT	Pitch unit (evaluation of PIT and/or MPIT)		
				0 =	Pitch in mm - MPIT/PIT evaluation	
				1 =	Pitch in mm - PIT evaluation	
				2 =	Pitch in TPI - PIT evaluation (threads per inch)	
				3 =	Pitch in inches - PIT evaluation	
				4 =	MODULE - PIT evaluation	
25		<_PITM>	STRING[15]	String as marker for pitch input (for the interface only) ¹⁾		
26		<_PTAB>	STRING[20]	String for thread table (for the interface only) ¹⁾		
27		<_PTABA>	STRING[20]	String for selection in the thread table (for the interface only) ¹⁾		
28		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	Type of thread	
				0 =	Longitudinal thread	
				1 =	Face thread	
				2 =	Tapered thread	
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
0 =	Input: Complete					
1 =	Input: Basic					

No.	Parameter mask	Parameter internal	Data type	Meaning		
29		<_AMODE>	INT	Alternative mode		
				UNITS:	Thread length in Z	
					0 =	Absolute
					1 =	Incremental
				TENS:	Thread length in X	
					0 =	Absolute, value of transverse axis in the diameter
					1 =	Incremental, value of transverse axis in the radius
					2 =	α
				HUNDREDS:	Calculation of approach/run-in path <_APP>	
					0 =	Thread run-in <_APP>
					1 =	Thread run-in = thread run-out <_APP> = -<_ROP>
					2 =	Specify thread run-in path <_APP> = -<_APP>
				THOUSANDS:	Select infeed slope as angle or width	
					0 =	Infeed angle <_IANG>
					1 =	Infeed slope <_IFLANK>
				TEN THOUSANDS:	Single/multiple thread	
					0 =	Single thread (with starting angle offset <_NSP>)
1 =	Multiple					
HUNDRED THOUSANDS:	Starting thread <_GST>					
	0 =	Full machining				
	1 =	Start machining from this thread				
	2 =	Only machine this thread				
ONE MILLION:	Sag compensation for longitudinal thread					
	0 =	Segment height, crowned thread XS				
	1 =	Radius, crowned thread RS				
30	XS/RS	<_S_XRS>	REAL	Sag compensation for longitudinal thread in conjunction with <_AMODE>: ONE MILLION		

Note

¹⁾ Parameters <_PITM>, <_PTAB> and <_PTABA> are only used for thread selection in the screen form thread tables.

The thread tables cannot be accessed via cycle definition in the cycle run time.

3.23.1.31 CYCLE435 - Set dresser coordinate system

Syntax

CYCLE435 (<_T>, <_DD>, <S_TA>, <S_DA>, <S_AD>, <S_AL>, <S_PVD>, <S_PVL>, <S_PD>, <S_PL>, <_AMODE>)

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1		<_T>	STRING[32]	Tool name of the grinding wheel
2		<_DD>	INT	Cutting edge number of the grinding wheel
3		<S_TA>	STRING[32]	Dressing tool reference point - dressing tool name
4		<S_DA>	INT	Cutting edge number of the dressing tool
5		<S_AD>	REAL	Dressing value, diameter
6		<S_AL>	REAL	Dressing value, face
7		<S_PVD>	REAL	Form-truing offset, diameter
8		<S_PVL>	REAL	Form-truing offset, face
9		<S_PD>	REAL	Form-truing allowance, diameter
10		<S_PL>	REAL	Form-truing allowance, face
11		<_AMODE>	INT	Alternative mode
			UNITS:	active tool at the end of the cycle
				0 = dressing tool active
				1 = wheel active

3.23.1.32 CYCLE495 - form-truing

Syntax

CYCLE495 (<_T>, <_DD>, <_SC>, <_F>, <_VARI>, <_D>, <_DX>, <_DZ>, <S_PA>, <S_N>, <_DMODE>, <_AMODE>, <S_FW>, <S_HW>)

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning
1		<_T>	STRING[20]	Tool name of the grinding wheel
2		<_DD>	INT	Cutting edge number of the grinding wheel
3		<_SC>	REAL	Lift-off distance for avoiding obstacles, incremental
4		<_F>	REAL	Form-truing feedrate

No.	Parameter mask	Parameter internal	Data type	Meaning			
5		<_VARI>	INT	Machining type			
				UNITS:	Form-truing type		
					1 =	Parallel to the axis	
					2 =	Parallel to the contour	
				TENS:	Machining direction		
					0 =	Pulling Possible with cutting edge positions 1 to 4	
					1 =	Pushing Possible with cutting edge positions 1 to 4	
					2 =	Alternating Possible with cutting edge positions 1 to 8	
					3 =	Start → end Possible with cutting edge positions 1 to 8	
					4 =	End → start Possible with cutting edge positions 1 to 8	
				HUNDREDS:	Infeed direction		
					1 =	Infeed X for G18 or Y- for G19	
					2 =	Infeed X+ for G18 or Y+ for G19	
3 =	Infeed Z- for G18 and for G19						
	4 =	Infeed Z+ for G18 and for G19					
6		<_D>	REAL	Dressing value for form-truing type parallel to the axis			
7		<_DX>	REAL	Dressing value X for G18 or Y for G19 for form-truing type parallel to the contour			
8		<_DZ>	REAL	Dressing value Z for G18 and G19 for form-truing type parallel to the contour			
9		<S_PA>	REAL	Form-truing allowance			
10		<S_N>	INT	Number of strokes in the form-truing program			
11		<_DMODE>	INT	Display mode			
				UNITS:	Machining plane G17/G18/G19		
					0 =	Compatibility, the plane effective before the cycle call remains active	
					1 =	G17 (only active in the cycle)	
					2 =	G18 (only active in the cycle)	
3 =	G19 (only active in the cycle)						

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
12		<_AMODE>	INT	Alternative mode	
				UNITS:	Form-truing selection, new/continue
				1 =	New
				2 =	Continue
				TENS:	Select form-truing allowance
0 =	From the rough contour to the lowest point of the contour				
1 =	From the rough contour to the highest point of the contour				
13		<S_FW>	REAL	Clear angle of the dressing tool	
14		<S_HW>	REAL	Holder angle of the dressing tool	

3.23.1.33 CYCLE800 – swivel plane / swivel tool / align tool

Syntax

CYCLE800 (<_FR>, <_TC>, <_ST>, <_MODE>, <_X0>, <_Y0>, <_Z0>, <_A>, <_B>, <_C>, <_X1>, <_Y1>, <_Z1>, <_DIR>, <_FR_I>, <_DMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1		<_FR>	INT	Retraction mode:	
				0 =	No retraction
				1 =	Retraction machine axis Z
				2 =	Retraction machine axis Z and then XY
				3 =	Reserved
				4 =	Maximum retraction in tool direction
5 =	Incremental retraction in tool direction				
2		<_TC>	STRING[32]	Name of swivel data block:	
				""	"" (no name) if only one swivel data block exists
				"0"	Deselect swivel data block (delete the swivel frames)

No.	Parameter mask	Parameter internal	Data type	Meaning		
3		<_ST>	INT	Status transformations		
				UNITS:	0 =	New, swivel level is deleted and recalculated using the current parameters
					1 =	Additive, swivel level is added to active swivel level
				TENS:	Track tool tip yes/no (only active when the SWIVEL function is created in the commissioning)	
					0 =	Do not track tool tip
					1 =	Track tool tip (TRAORI)
				HUNDREDS:	Approach/align tool (function is shown in tool swivel screen form)	
					0 =	Do not approach tool
					1 =	Approach tool (preferably radial mill)
					2 =	Align turning tool (when B axis kinematic is set up for milling in commissioning swiveling)
					3 =	Align milling tool (when B axis kinematic is set up for milling in commissioning swiveling)
				THOUSANDS:	Internal "Swiveling in JOG" parameter	
				TEN THOUSANDS:	See direction parameter <_DIR>	
					0 =	Swivel "Yes"
					1 =	Swivel "No", "Minus" direction ³⁾
					2 =	Swivel "No", "Plus" direction ³⁾
				HUNDRED THOUSANDS:	See direction parameter <_DIR>	
					0 =	Compatibility
					1 =	Direction selection "Minus" optimized (only for user interface) ⁴⁾
					2 =	Direction selection "Plus" optimized (only for user interface) ⁴⁾

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
4		<_MODE> ⁵⁾	INT	Swivel mode: Evaluation of swivel angle and swivel sequence (bit-coded)		
				Bit: 7 6	0 0:	Swivel angle axis-by-axis -> see parameters <_A>, <_B>, <_C>
					0 1:	Solid angle -> see parameters <_A>, <_B> ¹⁾
					1 0:	Projection angle -> see parameters <_A>, <_B>, <_C> ¹⁾
					1 1:	Direct rotary axis swivel mode -> see parameters <_A>, <_B> ¹⁾
				Bit: 5 4 3 2 1 0 (these do not apply to solid angles)	x x x x 0 1	1st rotation _A around X
					x x x x 1 0	1st rotation _A around Y
					x x x x 1 1	1st rotation _A around Z
					x x 0 1 x x	2nd rotation _B around X
					x x 1 0 x x	2nd rotation _B around Y
					x x 1 1 x x	2nd rotation _B around Z
					0 1 x x x x	3rd rotation _C around X
1 0 x x x x	3rd rotation _C around Y					
1 1 x x x x	3rd rotation _C around Z					
5	X0	<_X0>	REAL	Reference point X prior to rotation		
6	Y0	<_Y0>	REAL	Reference point Y prior to rotation		
7	Z0	<_Z0>	REAL	Reference point Z prior to rotation		
8	X(A)	<_A>	REAL	1st rotation acc. to setting in parameter <_MODE>		
9	Y(B)	<_B>	REAL	2nd rotation acc. to setting in parameter <_MODE>		
10	Z(C)	<_C>	REAL	3rd rotation acc. to setting in parameter <_MODE>		
11	X1	<_X1>	REAL	Reference point X after rotation		
12	Y1	<_Y1>	REAL	Reference point Y after rotation		
13	Z1	<_Z1>	REAL	Reference point Z after rotation		
14	- or +	<_DIR>	INT	Initiate travel of rotary axes (default = -1!)		
				-1 =	Position at smaller value of rotary axis 1 or 2 ²⁾	
				+1 =	Position at larger value of rotary axis 1 or 2 ²⁾	
				0 =	Do not swivel (merely calculate swivel frame) ^{1) 3)}	
15	FR	<_FR_I>	REAL	Value (inc) of retraction in tool direction incremental		

No.	Parameter mask	Parameter internal	Data type	Meaning		
16		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)	
				TENS:	Representation of the beta value during align tool	
0 =	Value					
1 =	Arrow					

Note

If the following transfer parameters are programmed indirectly (as parameters), the screen form is not reset: <_FR>, <_ST>, <_TC>, <_MODE>, <_DIR>

¹⁾ Can be selected if the SWIVEL function is created in the commissioning

²⁾ Can be selected if direction reference to rotary axis 1 or 2 is set in IBN SWIVEL

If direction reference is "No" there is no selection field

³⁾ Swivel selection "No" can be grayed out SD 55221 Bit 0

Swivel "No", "Minus" direction corresponds to <_DIR> = 0 and _ST TEN THOUSANDS = 1

Swivel "No", "Plus" direction corresponds to <_DIR> = 0 and _ST TEN THOUSANDS = 2

⁴⁾ The direction selection for rotary axis 1 or 2 also occurs if the rotary axis with the direction reference is in the pole position (position value equals zero).

⁵⁾ Coding example: Axis-by-axis rotation, rotary sequence ZYX

Binary: 00011011 Decimal: 27

The axis identifiers XYZ correspond to the geometry axes of the NC channel. Individual rotations around the XYZ axes are permissible. For example, rotary sequence around ZXZ is not permitted in one call of CYCLE800

3.23.1.34 CYCLE801 – grid or frame position pattern**Syntax**

```
CYCLE801 (<_SPCA>, <_SPCO>, <_STA>, <_DIS1>, <_DIS2>, <_NUM1>,
<_NUM2>, <_VARI>, <_UMODE>, <_ANG1>, <_ANG2>, <_HIDE>, <_NSP>,
<_DMODE>)
```

Parameters

No.	Parameter mask	Parameters internal	Data type	Meaning										
1	X0	<_SPCA>	REAL	Reference point for position pattern (grid/frame) along the 1st axis (abs)										
2	Y0	<_SPCO>	REAL	Reference point for position pattern (grid/frame) along the 2nd axis (abs)										
3	α 0	<_STA>	REAL	Basic angle of rotation (angle to 1st axis) <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>< 0 =</td> <td>Clockwise rotation</td> </tr> <tr> <td>> 0 =</td> <td>Counterclockwise rotation</td> </tr> </table>	< 0 =	Clockwise rotation	> 0 =	Counterclockwise rotation						
< 0 =	Clockwise rotation													
> 0 =	Counterclockwise rotation													
4	L1	<_DIS1>	REAL	Distance between columns (position distance from the 1st axis, enter without sign)										
5	L2	<_DIS2>	REAL	Distance between rows (distance from the 2nd axis, enter without sign)										
6	N1	<_NUM1>	INT	Number of columns										
7	N2	<_NUM2>	INT	Number of rows										
8		<_VARI>	INT	Machining type <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>UNITS:</td> <td>Position pattern</td> </tr> <tr> <td>0 =</td> <td>Grid</td> </tr> <tr> <td>1 =</td> <td>Frame</td> </tr> <tr> <td>TENS:</td> <td>Reserved</td> </tr> <tr> <td>HUNDREDS:</td> <td>Reserved</td> </tr> </table>	UNITS:	Position pattern	0 =	Grid	1 =	Frame	TENS:	Reserved	HUNDREDS:	Reserved
UNITS:	Position pattern													
0 =	Grid													
1 =	Frame													
TENS:	Reserved													
HUNDREDS:	Reserved													
9		<_UMODE>	INT	Reserved										
10	α X	<_ANG1>	REAL	Shear angle to 1st axis (lines inclined in relation to the 1st axis) <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>< 0 =</td> <td>Clockwise measurement (0 to -90 degrees)</td> </tr> <tr> <td>> 0 =</td> <td>Counter-clockwise measurement (0 to 90 degrees)</td> </tr> </table>	< 0 =	Clockwise measurement (0 to -90 degrees)	> 0 =	Counter-clockwise measurement (0 to 90 degrees)						
< 0 =	Clockwise measurement (0 to -90 degrees)													
> 0 =	Counter-clockwise measurement (0 to 90 degrees)													
11	α Y	<_ANG2>	REAL	Shear angle to 2nd axis (columns inclined in relation to the 2nd axis) <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>< 0 =</td> <td>Clockwise measurement (0 to -90 degrees)</td> </tr> <tr> <td>> 0 =</td> <td>Counter-clockwise measurement (0 to 90 degrees)</td> </tr> </table>	< 0 =	Clockwise measurement (0 to -90 degrees)	> 0 =	Counter-clockwise measurement (0 to 90 degrees)						
< 0 =	Clockwise measurement (0 to -90 degrees)													
> 0 =	Counter-clockwise measurement (0 to 90 degrees)													
12		<_HIDE>	STRING [200]	Hidden positions <ul style="list-style-type: none"> • Max. 198 characters • Specification of consecutive position numbers, e.g. "1,3" (positions 1 and 3 are not executed) 										
13		<_NSP>	INT	Reserved										
14		<_DMODE>	INT	Display mode <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>UNITS:</td> <td>Machining plane G17/G18/G19</td> </tr> <tr> <td>0 =</td> <td>Compatibility, the plane effective before the cycle call remains active</td> </tr> <tr> <td>1 =</td> <td>G17 (only active in the cycle)</td> </tr> <tr> <td>2 =</td> <td>G18 (only active in the cycle)</td> </tr> <tr> <td>3 =</td> <td>G19 (only active in the cycle)</td> </tr> </table>	UNITS:	Machining plane G17/G18/G19	0 =	Compatibility, the plane effective before the cycle call remains active	1 =	G17 (only active in the cycle)	2 =	G18 (only active in the cycle)	3 =	G19 (only active in the cycle)
UNITS:	Machining plane G17/G18/G19													
0 =	Compatibility, the plane effective before the cycle call remains active													
1 =	G17 (only active in the cycle)													
2 =	G18 (only active in the cycle)													
3 =	G19 (only active in the cycle)													

3.23.1.35 CYCLE802 - arbitrary positions

Syntax

```
CYCLE802 (<_XA>, <_YA>, <_X0>, <_Y0>, <_X1>, <_Y1>, <_X2>, <_Y2>,
<_X3>, <_Y3>, <_X4>, <_Y4>, <_X5>, <_Y5>, <_X6>, <_Y6>, <_X7>, <_Y7>,
<_X8>, <_Y8>, <_VARI>, <_UMODE>, <_DMODE>, <S_ABA>, <S_AB0>,
<S_AB1>, <S_AB2>, <S_AB3>, <S_AB4>, <S_AB5>, <S_AB6>, <S_AB7>,
<S_AB8>)
```

Parameters

No.	Parameter mask	Parameters internal	Data type	Meaning		
1		<_XA>	INT	Alternatives for all X positions (9-digit decimal value) Number of digits: 876543210 (digit position corresponds to drilling position Xn)		
				Position value:	1 =	Absolute (1st programmed position is always absolute)
					2 =	Incremental
2		<_YA>	INT	Alternatives for all Y positions (9-digit decimal value) Number of digits: 876543210 (digit position corresponds to drilling position Yn)		
				Position value:	1 =	Absolute (1st programmed position is always absolute)
					2 =	Incremental
3	X0	<_X0>	REAL	1. Position X		
4	Y0	<_Y0>	REAL	1. Position Y		
5	X1	<_X1>	REAL	2. Position X		
6	Y1	<_Y1>	REAL	2. Position Y		
7	X2	<_X2>	REAL	3. Position X		
8	Y2	<_Y2>	REAL	3. Position Y		
9	X3	<_X3>	REAL	4. Position X		
10	Y3	<_Y3>	REAL	4. Position Y		
11	X4	<_X4>	REAL	5. Position X		
12	Y4	<_Y4>	REAL	5. Position Y		
13	X5	<_X5>	REAL	6. Position X		
14	Y5	<_Y5>	REAL	6. Position Y		
15	X6	<_X6>	REAL	7. Position X		
16	Y6	<_Y6>	REAL	7. Position Y		
17	X7	<_X7>	REAL	8. Position X		
18	Y7	<_Y7>	REAL	8. Position Y		
19	X8	<_X8>	REAL	9. Position X		
20	Y8	<_Y8>	REAL	9. Position Y		

3.23 Programming cycles externally

No.	Parameter mask	Parameters internal	Data type	Meaning	
21		<_VARI>	INT	Machining	
				HUNDREDS:	(Only for call from Jobshop) (At present only 0 and 2 evaluated)
				0 =	Do not clamp spindle
				1 =	Only clamp spindle for vertical insertion with G00 or G01
				2 =	Clamp spindle during the entire machining operation
				THOUSANDS:	Reserved
				TEN THOUSANDS:	Position pattern with/without rotary axis – axis combination (with <_VARI> HUNDRED THOUSANDS)
				0 =	XY (only XY without rotary axis, compatibility)
				1 =	X,Y or Z and rotary axis: XA, YB, ZC (1 rotary axis with geometry axis around which the rotary axis rotates)
				2 =	XY and rotary axis: XYA, XYB, XYC (1 rotary axis with 1st and 2nd geometry axis, without TRACYL)
				HUNDRED THOUSANDS:	Rotary axis
				0 =	Without rotary axis (only XY, compatibility)
				1 =	A axis (rotary axis around X)
				2 =	B axis (rotary axis around Y)
				3 =	C axis (rotary axis around Z)
TEN MILLIONS + ONE MILLION:	Position pattern with rotary axis – offset (for several rotary axes around the same axis; if index too large, then 1st axis)				
00 =	1st A, B or C axis or for compatibility				
01 =	2nd A, B or C axis				
...					
19 =	20th A, B or C axis				
22		<_UMODE>	INT	Selection of the spindle to be clamped: (Only for call from Jobshop) (Call of user cycle CUST_TECHCYC)	
				3 =	Clamp/release main spindle
				23 =	Clamp/release counterspindle

No.	Parameter mask	Parameters internal	Data type	Meaning		
23		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)					
24		<S_ABA>	INT	Alternatives for all AB positions (9-digit decimal value) Number of digits: 876543210 (digit position corresponds to position ABn)		
				Position value:	1 =	Absolute (1st programmed position is always absolute)
				2 =	Incremental	
25	A0	<S_AB0>	REAL	1st rotary axis position for position pattern with rotary axis (in conjunction with <_VARI>))		
26	A1	<S_AB1>	REAL	2nd rotary axis position for position pattern with rotary axis		
27	A2	<S_AB2>	REAL	3rd rotary axis position for position pattern with rotary axis		
28	A3	<S_AB3>	REAL	4th rotary axis position for position pattern with rotary axis		
29	A4	<S_AB4>	REAL	5th rotary axis position for position pattern with rotary axis		
30	A5	<S_AB5>	REAL	6th rotary axis position for position pattern with rotary axis		
31	A6	<S_AB6>	REAL	7th rotary axis position for position pattern with rotary axis		
32	A7	<S_AB7>	REAL	8th rotary axis position for position pattern with rotary axis		
33	A8	<S_AB8>	REAL	9th rotary axis position for position pattern with rotary axis		

Note

Positions that are not required for parameters X1/Y1/A1 to X8/Y8/A8 can be ignored. The alternative values for <_XA>, <_YA> and <S_ABA>, however, must be provided in full for all 9 positions.

For position pattern XA, YB or ZC (a geometry axis and rotary axis), the axis of the machining plane that is not traversed via the position pattern (Y for G17 and XA) must be positioned before the cycle call.

3.23.1.36 CYCLE830 - deep-hole drilling 2**Syntax**

```
CYCLE830 (<RTP>, <RFP>, <SDIS>, <_DP>, <FDEP>, <_DAM>, <DTB>, <DTS>,
<FRF>, <VARI>, <_MDEP>, <_VRT>, <_DTD>, <_DIS1>, <S_FP>, <S_SDAC2>,
<S_SV2>, <S_FB>, <_SDAC>, <_SV1>, <S_SPOS>, <S_ZA>, <S_FA>, <S_ZP>,
<S_FS>, <S_ZS1>, <S_ZS2>, <S_N>, <S_ZD>, <S_FD>, <S_FR>, <S_SDAC3>,
<S_SV3>, <S_CON>, <S_COFF>, <_GMODE>, <_DMODE>, <_AMODE>,
<S_AMODE2>, <S_AMODE3>, <S_ZPV>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning																																																
1	RP	<RTP>	REAL	Retraction plane (abs)																																																
2	Z0	<RFP>	REAL	Reference point (abs)																																																
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, without sign)																																																
4	Z1	<_DP>	REAL	Final drilling depth abs/inc (see <_AMODE>UNITS)																																																
5	D	<FDEP>	REAL	1st drilling depth for the absolute or incremental chip breaking/removal in relation to the reference point with/without predrilling or in relation to pilot hole depth (see <_AMODE> TEN THOUSANDS)																																																
6	DF	<_DAM>	REAL	Absolute value / percentage for each additional infeed, degression absolute value / percentage (see <_AMODE> HUNDRED THOUSANDS)																																																
7	DTB	<DTB>	REAL	Dwell time at each drilling depth (see <_AMODE> TENS)																																																
8	DTS	<DTS>	REAL	Dwell time during chip removal at starting point (see <_AMODE> HUNDREDS)																																																
9	FD1	<FRF>	REAL	Percentage for the feedrate for the first infeed (see <_AMODE> TEN MILLION)																																																
10		<VARI>	INT	<p>Machining</p> <table border="1"> <tr> <td rowspan="5">UNITS:</td> <td colspan="2">Chip breaking / swarf removal</td> </tr> <tr> <td>0 =</td> <td>In one cut</td> </tr> <tr> <td>1 =</td> <td>Chip breaking</td> </tr> <tr> <td>2 =</td> <td>Swarf removal</td> </tr> <tr> <td>3 =</td> <td>Chip breaking and swarf removal</td> </tr> <tr> <td rowspan="3">TENS:</td> <td colspan="2">Retraction during swarf removal</td> </tr> <tr> <td>0 =</td> <td>To pilot hole depth</td> </tr> <tr> <td>1 =</td> <td>To safety clearance</td> </tr> <tr> <td rowspan="3">HUNDREDS:</td> <td colspan="2">Soft first cut</td> </tr> <tr> <td>0 =</td> <td>No</td> </tr> <tr> <td>1 =</td> <td>Yes</td> </tr> <tr> <td rowspan="3">THOUSANDS:</td> <td colspan="2">Through drilling</td> </tr> <tr> <td>0 =</td> <td>No</td> </tr> <tr> <td>1 =</td> <td>Yes</td> </tr> <tr> <td rowspan="4">TEN THOUSANDS:</td> <td colspan="2">Predrilling / pilot hole</td> </tr> <tr> <td>0 =</td> <td>Without predrilling</td> </tr> <tr> <td>1 =</td> <td>With predrilling</td> </tr> <tr> <td>2 =</td> <td>With pilot hole</td> </tr> <tr> <td rowspan="3">HUNDRED THOUSANDS:</td> <td colspan="2">Retraction</td> </tr> <tr> <td>0 =</td> <td>To pilot hole depth</td> </tr> <tr> <td>1 =</td> <td>To retraction plane</td> </tr> </table>	UNITS:	Chip breaking / swarf removal		0 =	In one cut	1 =	Chip breaking	2 =	Swarf removal	3 =	Chip breaking and swarf removal	TENS:	Retraction during swarf removal		0 =	To pilot hole depth	1 =	To safety clearance	HUNDREDS:	Soft first cut		0 =	No	1 =	Yes	THOUSANDS:	Through drilling		0 =	No	1 =	Yes	TEN THOUSANDS:	Predrilling / pilot hole		0 =	Without predrilling	1 =	With predrilling	2 =	With pilot hole	HUNDRED THOUSANDS:	Retraction		0 =	To pilot hole depth	1 =	To retraction plane
UNITS:	Chip breaking / swarf removal																																																			
	0 =	In one cut																																																		
	1 =	Chip breaking																																																		
	2 =	Swarf removal																																																		
	3 =	Chip breaking and swarf removal																																																		
TENS:	Retraction during swarf removal																																																			
	0 =	To pilot hole depth																																																		
	1 =	To safety clearance																																																		
HUNDREDS:	Soft first cut																																																			
	0 =	No																																																		
	1 =	Yes																																																		
THOUSANDS:	Through drilling																																																			
	0 =	No																																																		
	1 =	Yes																																																		
TEN THOUSANDS:	Predrilling / pilot hole																																																			
	0 =	Without predrilling																																																		
	1 =	With predrilling																																																		
	2 =	With pilot hole																																																		
HUNDRED THOUSANDS:	Retraction																																																			
	0 =	To pilot hole depth																																																		
	1 =	To retraction plane																																																		
11	V1	<_MDEP>	REAL	Minimum incremental infeed (only for degression percentage)																																																
12	V2	<_VRT>	REAL	<p>Retraction distance after each incremental machining step (for chip breaking only)</p> <table border="1"> <tr> <td>0 =</td> <td>Default value 1 mm</td> </tr> <tr> <td>> 0 =</td> <td>Variable retraction distance</td> </tr> </table>	0 =	Default value 1 mm	> 0 =	Variable retraction distance																																												
0 =	Default value 1 mm																																																			
> 0 =	Variable retraction distance																																																			
13	DT	<_DTD>	REAL	Dwell time at final drilling depth (see <_AMODE> THOUSANDS)																																																

No.	Parameter mask	Parameter internal	Data type	Meaning	
14	V3	<_DIS1>	REAL	Incremental limit distance for chip removal only (see <_AMODE> ONE-MILLION)	
15	FP	<S_FP>	REAL	Feedrate for travel into the pilot hole as value or in % (in conjunction with <S_AMODE2> HUNDREDS)	
16		<S_SDAC2>	INT	Direction of spindle rotation during approach	
				3 =	M3
				4 =	M4
				5 =	M5 (default)
17	SP	<S_SV2>	REAL	Approach with constant spindle speed (see <S_AMODE2> TEN MILLION)	
	V4			constant cutting rate	
				Spindle speed in % of the drilling speed	
18	F	<S_FB>	REAL	Drilling feedrate (see <S_AMODE2> UNITS)	
19		<_SDAC>	REAL	Direction of spindle rotation during drilling	
				3 =	M3
				4 =	M4
20	S	<_SV1>	REAL	Drilling with constant spindle speed (see <S_AMODE2> ONE MILLION)	
	V5			constant cutting rate	
21	SPOS	<S_SPOS>	REAL	Spindle position, only if approach with M5	
22	ZA	<S_ZA>	REAL	Incremental predrilling depth in relation to reference point or absolute (see <S_AMODE3> UNITS)	
23	FA	<S_FA>	REAL	Predrilling feedrate as value or in % (in conjunction with <S_AMODE2> TENS)	
24	ZP	<S_ZP>	REAL	Incremental pilot hole in relation to reference point or absolute or factor of the hole diameter (see <S_AMODE3> TENS)	
25	FS	<S_FS>	REAL	First cut feedrate as value or in % (in conjunction with <S_AMODE2> THOUSANDS)	
26	ZS1	<S_ZS1>	REAL	Depth of each first cut with constant feedrate (inc)	
27	ZS2	<S_ZS2>	REAL	Depth of each first cut for feedrate increase (inc)	
28	N	<S_N>	INT	Number of chip breaking strokes before each chip removal	
29	ZD	<S_ZD>	REAL	Incremental remaining drilling depth in relation to final drilling depth or absolute (see <S_AMODE3> HUNDREDS)	
30	FD	<S_FD>	REAL	Remaining drilling feedrate as value or in % (in conjunction with <S_AMODE2> TEN THOUSANDS)	
31	FR	<S_FR>	REAL	Retraction feedrate (in conjunction with <S_AMODE2> HUNDRED THOUSANDS)	
32		<S_SDAC3>	INT	Direction of spindle rotation during retraction	
				3 =	M3
				4 =	M4
				5 =	M5
33	SR	<S_SV3>	REAL	Retraction with constant spindle speed (see <S_AMODE2> HUNDRED MILLION)	
	V6			constant cutting rate	
				Spindle speed in % of the drilling speed	

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
34	Coolant on	<S_CON>	STRING[10]	Coolant on, M command or subprogram call	
35	Coolant off	<S_COFF>	STRING[10]	Coolant off, M command or subprogram call	
36		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)	
				UNITS:	Reserved
				TENS:	Drilling depth with respect to tip/shank
				0 =	Tip
				1 =	Shank
37		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
				3 =	G19 (only active in the cycle)
				TENS:	Reserved
				HUNDREDS:	Reserved
				THOUSANDS:	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)
	0 =	Input: Complete			
	1 =	Input: Basic			

No.	Parameter mask	Parameter internal	Data type	Meaning	
38		<_AMODE>	INT	Alternative mode 1	
				UNITS:	Drilling depth = Final drilling depth Z1 abs/inc
					0 = Incremental
				1 = Absolute	
				TENS:	Dwell time at each drilling depth DTB in seconds/revolutions
					0 = In seconds
				1 = In revolutions	
				HUNDREDS:	Dwell time for chip removal DTS in seconds/revolutions
					0 = In seconds
				1 = In revolutions	
				THOUSANDS:	Dwell time at final drilling depth DT in seconds/revolutions
					0 = In seconds
				1 = In revolutions	
				TEN THOUSANDS:	1st drilling depth D abs/inc
0 = Incremental					
1 = Absolute					
HUNDRED THOUSANDS:	Absolute value / percentage DF for each additional infeed (degression)				
	0 = Absolute value				
1 = Percentage (0.001 to 100%)					
ONE MILLION:	Limit distance V3 automatic/manual				
	0 = Automatic (calculated in the cycle)				
1 = Manual (programmed value)					

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
39		<S_ AMODE2 >	INT	Alternative mode 2	
				UNITS:	UNITS: Drilling feedrate F
				0 =	F/min
				1 =	F/rev
				TENS:	Evaluation of predrilling feedrate FA
				0 =	As % of drilling feedrate
				1 =	F/min
				2 =	F/rev
				HUNDREDS:	Evaluation of feedrate for travel into pilot hole FP
				0 =	As % of drilling feedrate
				1 =	F/min
				2 =	F/rev
				THOUSANDS:	Evaluation of first cut feedrate FS
				0 =	As % of drilling feedrate
				1 =	F/min
				2 =	F/rev
				TEN THOUSANDS:	Evaluation of through-drilling feedrate FD
				0 =	As % of drilling feedrate
				1 =	F/min
				2 =	F/rev
				HUNDRED THOUSANDS:	Retraction feedrate FR
				0 =	F/min
				1 =	Rapid traverse
				ONE MILLION:	Drilling - spindle speed / cutting rate (S/V5)
0 =	Constant spindle speed				
1 =	Constant cutting rate				
TEN MILLIONS:	Approach with spindle speed / cutting rate (SP/V4)				
0 =	Constant spindle speed				
1 =	Constant cutting rate				
2 =	Spindle speed in % of the drilling speed				
HUNDRED MILLIONS:	Retraction - spindle speed / cutting rate (SR/V6)				
0 =	Constant spindle speed				
1 =	Constant cutting rate				
2 =	Spindle speed in % of the drilling speed				

No.	Parameter mask	Parameter internal	Data type	Meaning		
40		<S_AMODE3 >	INT	Alternative mode 3		
				UNITS:	Drilling depth ZA abs/inc	
					0 =	Incremental
					1 =	Absolute
				TENS:	Depth of the pilot hole ZP	
					0 =	Incremental
					1 =	Absolute
				HUNDREDS:	Remaining drilling depth ZD abs/inc	
					0 =	Incremental
					1 =	Absolute
41	ZPV	<S_ZPV>	REAL	Incremental limit distance from pilot hole depth		

3.23.1.37 CYCLE832 - High-Speed Settings

Syntax

CYCLE832 (<S_TOL>, <S_TOLM>, <S_OTOL>)

Note

CYCLE832 does not relieve the machine manufacturer from optimization tasks that are necessary when commissioning the machine. This involves the optimization of the axes involved in the machining process and NCU settings (precontrol, jerk limiting, etc.).

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	Tolerance	<S_TOL>	REAL	Contour tolerance The contour tolerance corresponds to the axis tolerance of the geometry axes.	
2		<S_TOLM>	INT	Machining type (technology)	
				UNITS:	
				0 =	Deselection
				1 =	Finishing
				2 =	Rough finishing (semi-finishing)
				3 =	Roughing
				4 =	Smooth finishing (precision)
				TENS:	
				0 =	Compatibility ¹⁾ or no orientation tolerance
				1 =	Orientation tolerance in parameter <S_OTOL>
				HUNDREDS ... HUNDRED THOUSANDS	Assigned for reasons of compatibility
				ONE MILLION:	
0 =	Compatibility. The best available mold making function is automatically used: <ul style="list-style-type: none"> • Option Top Surface not active: <input type="checkbox"/> Advanced Surface • Option Top Surface active: ⇒ Top Surface with smoothing 				
1 =	Top Surface without smoothing				
2 =	Top Surface with smoothing				
3	ORI tolerance	<S_OTOL>	REAL	Orientation tolerance or version identifier CYCLE832 Tolerance parameter for the orientation of the workpiece. Is required when executing a high-speed machining program on machines with dynamic orientation transformation (e.g. 5-axis machining). Parameter <S_OTOL> must be programmed. This also applies for applications on 3-axis machines for programs without orientation of the tool (<S_OTOL> = 1).	

¹⁾ Orientation tolerance derived from the cycle setting data SD55451 ... SD55454 (orientation tolerance for dynamic response mode...) or SD55445 ... SD55449 (contour tolerance for dynamic response mode...) multiplied by the factor from SD55441 ... SD55444.

Further information: SINUMERIK Operate Commissioning Manual

Plain text entry

To improve the readability of the cycle call, parameter <S_TOLM> (machining type) can also be entered in the plain text. Plain texts are independent of any language. The following entries are permitted:

<code>_OFF</code>	for	0	Deselection
<code>_FINISH</code>	for	1	Finishing
<code>_SEMIFIN</code>	for	2	Rough finishing
<code>_ROUGH</code>	for	3	Roughing
<code>_PRECISION</code>	for	4	Smooth finishing
<code>_ORI_FINISH</code>	for	11	Finishing with input of an orientation tolerance
<code>_ORI_SEMIFIN</code>	for	12	Semi-finishing with input of an orientation tolerance
<code>_ORI_ROUGH</code>	for	13	Roughing with input of an orientation tolerance
<code>_ORI_PRECISION</code>	for	14	Smooth finishing with input of an orientation tolerance
<code>_TOP_SURFACE_SMOOTH_OFF</code>	for	1000000	Top Surface without smoothing
<code>_TOP_SURFACE_SMOOTH_ON</code>	for	2000000	Top Surface with smoothing

For plain text input for Top Surface, plain texts are combined as shown in the following example:

```
CYCLE832 (0.1, _TOP_SURFACE_SMOOTH_OFF+_ORI_FINISH, 1)
```

Note

The plain texts are based on the function names of the G group 59 (dynamic mode for path interpolation). With these plain texts, 3-axis machines and machines with multi-axis orientation transformation (TRAORI) are clearly separated in the application.

Deselecting CYCLE832

When CYCLE832 is deselected, parameter <S_TOL> must be transferred with zero.

Example: `CYCLE832 (0, 0, 1)`

The syntax `CYCLE832 ()` is also permitted for deselecting CYCLE832.

Examples**Example 1: CYCLE832 on 3-axis machine without orientation transformation**

a) Cycle call with plain text input

Program code	Comment
G710	; Dimension system is metric.

3.23 Programming cycles externally

Program code	Comment
CYCLE832 (0.004, _FINISH, 1)	; CYCLE832 call with: Contour tolerance = 0.004 mm, machining type: Finishing
...	; Execution of a high-speed machining program

b) Cycle call without plain text input

Program code	Comment
G710	; See above
CYCLE832 (0.004, 1, 1)	; See above
...	; See above

Example 2: CYCLE832 on 5-axis machine with orientation transformation

a) Cycle call and deselection with plain text input

Program code	Comment
G710	; Dimension system is metric.
TRAORI	; Activate orientation transformation.
CYCLE832 (0.3, _ORI_ROUGH, 0.8)	; CYCLE832 call with: Contour tolerance = 0.3 mm, machining type: Roughing with input of an orientation toler- ance; orientation tolerance = 0.8 degrees
...	; Execution of a high-speed machining program
CYCLE832 (0, _OFF, 1)	; Contour tolerance = 0, machining type: Deselection of CYCLE832, orientation tolerance = 0 degrees

b) Cycle call and deselection without plain text input

Program code	Comment
G710	; See above
TRAORI	; See above
CYCLE832 (0.3, 13, 0.8)	; See above
...	; See above
CYCLE832 (0, 0, 1)	; See above

3.23.1.38 CYCLE840 - tapping with compensating chuck

Syntax

CYCLE840 (<RTP>, <RFP>, <SDIS>, <DP>, <DPR>, <DTB>, <SDR>, <SDAC>, <ENC>, <MPIT>, <PIT>, <_AXN>, <_PITA>, <_TECHNO>, <_PITM>, <_PTAB>, <_PTABA>, <_GMODE>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning												
1	RP	<RTP>	REAL	Retraction plane (abs)												
2	Z0	<RFP>	REAL	Reference point (abs)												
3	SC	<SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)												
4	Z1	<DP>	REAL	Drilling depth (abs), see <_AMODE>												
5	Z1	<DPR>	REAL	Drilling depth (inc), see <_AMODE>												
6	DT	<DTB>	REAL	Dwell time in seconds at drilling depth / safety clearance after retraction, see <ENC>												
7		<SDR>	INT	Direction of rotation for retraction												
8	SDE	<SDAC>	INT	Direction of rotation after end of cycle												
9		<ENC>	INT	Tapping with spindle mounted encoder (G33)/tapping without spindle mounted encoder (G63) <table border="1" data-bbox="699 761 1471 1330"> <tr> <td>0 =</td> <td>With spindle mounted encoder</td> <td>- Pitch from <MPIT>/<PIT> - without DT</td> </tr> <tr> <td>20 =</td> <td>With spindle mounted encoder</td> <td>- Pitch from <MPIT>/<PIT> - with DT after retraction to safety clearance</td> </tr> <tr> <td>11 =</td> <td>Without spindle mounted encoder</td> <td>- Pitch from <MPIT>/<PIT> - with DT at drilling depth</td> </tr> <tr> <td>1 =</td> <td>Without spindle mounted encoder</td> <td>- Pitch from programmed feedrate - with DT at drilling depth (feedrate = speed · pitch)</td> </tr> </table>	0 =	With spindle mounted encoder	- Pitch from <MPIT>/<PIT> - without DT	20 =	With spindle mounted encoder	- Pitch from <MPIT>/<PIT> - with DT after retraction to safety clearance	11 =	Without spindle mounted encoder	- Pitch from <MPIT>/<PIT> - with DT at drilling depth	1 =	Without spindle mounted encoder	- Pitch from programmed feedrate - with DT at drilling depth (feedrate = speed · pitch)
0 =	With spindle mounted encoder	- Pitch from <MPIT>/<PIT> - without DT														
20 =	With spindle mounted encoder	- Pitch from <MPIT>/<PIT> - with DT after retraction to safety clearance														
11 =	Without spindle mounted encoder	- Pitch from <MPIT>/<PIT> - with DT at drilling depth														
1 =	Without spindle mounted encoder	- Pitch from programmed feedrate - with DT at drilling depth (feedrate = speed · pitch)														
10		<MPIT>	REAL	Thread size for "ISO metric" only (pitch is calculated internally during run time) Range of values: 3 to 48 (for M3 to M48), alternative to <PIT>												
11		<PIT>	REAL	Pitch as a value, for unit see <_PITA> Range of values: > 0, alternative to MPIT												
12		<_AXN>	INT	Drilling axis <table border="1" data-bbox="949 1515 1471 1664"> <tr> <td>0 =</td> <td>3rd geometry axis</td> </tr> <tr> <td>1 =</td> <td>1st geometry axis</td> </tr> <tr> <td>2 =</td> <td>2nd geometry axis</td> </tr> <tr> <td>≥ 3 =</td> <td>3rd geometry axis</td> </tr> </table>	0 =	3rd geometry axis	1 =	1st geometry axis	2 =	2nd geometry axis	≥ 3 =	3rd geometry axis				
0 =	3rd geometry axis															
1 =	1st geometry axis															
2 =	2nd geometry axis															
≥ 3 =	3rd geometry axis															

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning		
13		<_PITA>	INT	Pitch unit (evaluation of <PIT> and <MPIT>)		
				0 =	Pitch in mm	- evaluation<MPIT>/<PIT>
				1 =	Pitch in mm	- evaluation<PIT>
				2 =	Pitch in TPI	- evaluation of <PIT> (threads per inch)
				3 =	Pitch in inches	- evaluation<PIT>
				4 =	MODULUS	- evaluation<PIT>
14		<_TECHNO>	INT	Technology ¹⁾		
				UNITS:	Exact stop response	
				0 =	Exact stop response active as before cycle call	
				1 =	Exact stop G601	
				2 =	Exact stop G602	
				3 =	Exact stop G603	
				TENS:	Feedforward control	
				0 =	With/without feedforward control active as before cycle call	
1 =	With feedforward control FFWON					
2 =	Without feedforward control FFWOF					
15		<_PITM>	STRING[15]	String as marker for pitch input ²⁾		
16		<_PTAB>	STRING[5]	String for thread table ("", "ISO", "BSW", "BSP", "UNC") ²⁾		
17		<_PTABA>	STRING[20]	String for selection from thread table (e.g. "M 10", "M 12", ...) ²⁾		
18		<_GMODE>	INT	Reserved		

No.	Parameter mask	Parameter internal	Data type	Meaning			
19		<_DMODE>	INT	Display mode			
				UNITS:	Machining plane G17/G18/G19		
					0 =	Compatibility, the plane effective before the cycle call remains active	
					1 =	G17 (only active in the cycle)	
					2 =	G18 (only active in the cycle)	
					3 =	G19 (only active in the cycle)	
				TENS:	Reserved		
				HUNDREDS:	Reserved		
				THOUSANDS:	Compatibility mode (for recompilation screen form only), if MD 52216 bit0 = 1 ¹⁾		
					0 =	Technology parameters are displayed (compatibility): TECHNO parameters effective	
					1 =	Technology parameters are not displayed: Technology active "as before cycle call"	
TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)						
	0 =	Input: Complete					
	1 =	Input: Simple					
20		<_AMODE>	INT	Alternative mode			
				UNITS:	Drilling depth Z1 (abs/inc)		
					0 =	Compatibility, from programming <DP>/<DPR>	
					1 =	Incremental	
					2 =	Absolute	
¹⁾ Technology fields may be hidden, depending on the setting date SD52216 MCS_FUNCTION_MASK_DRILL ²⁾ Parameters 15, 16 and 17 are only used for thread selection in the screen form thread tables. The thread tables cannot be accessed via cycle definition in cycle run time.							

3.23.1.39 CYCLE899 – open slot

Syntax

```
CYCLE899(<_RTP>, <_RFP>, <_SDIS>, <_DP>, <_LENG>, <_WID>, <_PA>,
<_PO>, <_STA>, <_MID>, <_MIDA>, <_FAL>, <_FALD>, <_FFP1>, <_CDIR>,
<_VARI>, <_GMODE>, <_DMODE>, <_AMODE>, <_UMODE>, <_FS>, <_ZFS>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	RP	<_RTP>	REAL	Retraction plane (abs)
2	Z0	<_RFP>	REAL	Reference point of tool axis (abs)
3	SC	<_SDIS>	REAL	Safety clearance (to be added to reference point, enter without sign)
4	Z1	<_DP>	REAL	Slot depth (abs/inc), see <_AMODE>
5	L	<_LENG>	REAL	Length of slot (inc)
6	W	<_WID>	REAL	Width of slot (inc)
7	X0	<_PA>	REAL	Reference point/starting position 1st axis (abs)
8	Y0	<_PO>	REAL	Reference point/starting position 2nd axis (abs)
9	α0	<_STA>	REAL	Angle of rotation with respect to 1st axis
10	DZ	<_MID>	REAL	Maximum infeed depth (inc), for vortex milling only
11	DXY	<_MIDA>	REAL	Maximum plane infeed, see <_AMODE>
12	UXY	<_FAL>	REAL	Finishing allowance, plane
13	UZ	<_FALD>	REAL	Finishing allowance, depth
14	F	<_FFP1>	REAL	Feedrate
15		<_CDIR>	INT	Milling direction
				UNITS:
				0 = Down-cut
				1 = Up-cut
				4 = Alternating
16		<_VARI>	INT	Machining
				UNITS:
				1 = Roughing
				2 = Finishing
				3 = Base finishing
				4 = Edge finishing
				5 = Rough-finishing
				6 = Chamfering
				TENS: Reserved
				HUNDREDS: Reserved
				THOUSANDS:
				1 = Vortex milling
				2 = Plunge cutting

No.	Parameter mask	Parameter internal	Data type	Meaning		
17		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Reserved	
				TENS:	Reserved	
				HUNDREDS:	Select machining/only calculation of start point	
				1 =	Normal machining	
				THOUSANDS:	Dimensioning via center/edge	
				0 =	Dimensioning via center	
				1 =	"Left-hand" dimensioning using edge ("- direction of 1st axis)	
2 =	"Right-hand" dimensioning using edge ("+" direction of 1st axis)					
18		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
				0 =	Compatibility, the plane effective before the cycle call remains active	
				1 =	G17 (only active in the cycle)	
				2 =	G18 (only active in the cycle)	
				3 =	G19 (only active in the cycle)	
				TENS:	---	Reserved
				HUNDREDS:	---	Reserved
				THOUSANDS:	---	Reserved
				TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	
				0 =	Input: Complete	
1 =	Input: Simple					
19		<_AMODE>	INT	Alternative mode		
				UNITS:	Slot depth Z1	
				0 =	Absolute	
				1 =	Incremental	
				TENS:	Unit for plane infeed (<_MIDA>) DXY	
				0 =	mm	
				1 =	% of tool diameter	
				HUNDREDS:	Insertion depth for chamfering ZFS	
0 =	Absolute					
1 =	Incremental					
20		<_UMODE>	INT	Reserved		
21	FS	<_FS>	REAL	Chamfer width (inc)		
22	ZFS	<_ZFS>	REAL	Insertion depth (tool tip) on chamfering (abs/inc), see <_AMODE>		

3.23.1.40 CYCLE930 - groove

Syntax

CYCLE930 (<_SPD>, <_SPL>, <_WIDG>, <_WIDG2>, <_DIAG>, <_DIAG2>, <_STA>, <_ANG1>, <_ANG2>, <_RCO1>, <_RCI1>, <_RCI2>, <_RCO2>, <_FAL>, <_IDEP1>, <_SDIS>, <_VARI>, <_DN>, <_NUM>, <_DBH>, <_FF1>, <_NR>, <_FALX>, <_FALZ>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning	
1	X0	<_SPD>	REAL	Reference point in the plane axis (always diameter)	
2	Z0	<_SPL>	REAL	Reference point along the longitudinal axis	
3	B1	<_WIDG>	REAL	Width at bottom of groove	
4	B2	<_WIDG2>	REAL	Width at top of groove (for interface only)	
5	T1	<_DIAG>	REAL	Depth of groove at the reference point for abs and longitudinal machining = diameter, otherwise inc	
6	T2	<_DIAG2>	REAL	Groove depth opposite the reference point (for interface only), for abs and longitudinal machining = diameter, otherwise inc	
7	α0	<_STA>	REAL	Angle of inclination ($-180 \leq \text{<_STA>} \leq 180$)	
8	α1	<_ANG1>	REAL	Side angle 1 ($0 \leq \text{<_ANG1>} < 90$) at the side of the groove determined by the reference point	
9	α2	<_ANG2>	REAL	Side angle 2 ($0 \leq \text{<_ANG2>} < 90$) opposite the reference point	
10	R1/FS1	<_RCO1>	REAL	Rounding radius or chamfer width 1, external at the reference point	
11	R2/FS2	<_RCI1>	REAL	Rounding radius or chamfer width 2, internal at the reference point	
12	R3/FS3	<_RCI2>	REAL	Rounding radius or chamfer width 3, internal opposite the reference point	
13	R4/FS4	<_RCO2>	REAL	Rounding radius or chamfer width 4, external opposite the reference point	
14	U	<_FAL>	REAL	Finishing allowance in X and Z, see <_VARI> (TEN THOUSANDS) (to be entered without sign)	
15	D	<_IDEP1>	REAL	Maximum depth infeed on insertion (enter without sign)	
				0 =	1. Cut directly to full depth
				> 0 =	1. Cut <_IDEP1>, 2nd cut 2 · <_IDEP1>, etc.
16	SC	<_SDIS>	REAL	Safety clearance (enter without sign)	

No.	Parameter mask	Parameter internal	Data type	Meaning		
17		<_VARI>	INT	Machining type		
				UNITS:	Reserved	
				TENS:	Machining process	
					1 =	Roughing
					2 =	Finishing
				3 =	Roughing and finishing	
				HUNDREDS:	Position longitudinal/transverse external/internal +Z/+Z and +X/-X	
					1 =	Longitudinal/external +Z
					2 =	Transverse/internal -X
					3 =	Longitudinal/internal +Z
					4 =	Transverse/internal +X
					5 =	Longitudinal/external -Z
					6 =	Transverse/external -X
					7 =	Longitudinal/internal -Z
8 =	Transverse/external +X					
THOUSANDS:	Position of reference point					
	0 =	Upper reference point				
	1 =	Lower reference point				
TEN THOUSANDS:	Define effect of finishing allowances					
	0 =	Finishing allowance U parallel to the contour				
	1 =	Separate UX and UZ finishing allowances				
18		<_DN>	INT	D number for 2nd edge of tool		
				> 0 =	D number for tool offset of 2nd edge of grooving tool	
				0 =	No 2nd edge programmed	
19	N	<_NUM>	INT	Number of grooves (0 = 1 groove)		
20	DP	<_DBH>	REAL	Distance between grooves (only needed when <_NUM> > 1)		
21	F	<_FF1>	REAL	Feedrate		
22		<_NR>	INT	Identification for form of groove corresponds to vertical softkey for form selection		
				0 =	90° sides without chamfers/rounding	
				1 =	Inclined sides with chamfers/rounding (without α_0)	
				2 =	As 1, but on taper (with α_0)	
23	UX	<_FALX>	REAL	Finishing allowance in X axis, see <_VARI> (TEN THOUSANDS) (to be entered without sign)		
24	UZ	<_FALZ>	REAL	Finishing allowance in Z axis, see <_VARI> (TEN THOUSANDS) (to be entered without sign)		

No.	Parameter mask	Parameter internal	Data type	Meaning	
25		<_DMODE>	INT	Display mode	
				UNITS:	Machining plane G17/G18/G19
				0 =	Compatibility, the plane effective before the cycle call remains active
				1 =	G17 (only active in the cycle)
				2 =	G18 (only active in the cycle)
3 =	G19 (only active in the cycle)				
26		<_AMODE>	INT	Alternative mode	
				UNITS:	Dimensioning for top of groove (for interface only)
				0 =	At the reference point
				1 =	Opposite the reference point
				TENS:	Depth
				0 =	Absolute
				1 =	Incremental
				HUNDREDS:	Dimensioning for width (for interface only)
				0 =	At outer diameter (top)
				1 =	At inner diameter (bottom)
				THOUSANDS:	Radius/chamfer 1 (<_RCO1>)
				0 =	Radius
				1 =	Chamfer
				TEN THOUSANDS:	Radius/chamfer 2 (<_RCI1>)
				0 =	Radius
				1 =	Chamfer
				HUNDRED THOUSANDS:	Radius/chamfer 3 (<_RCI2>)
				0 =	Radius
				1 =	Chamfer
ONE MILLION:	Radius/chamfer 4 (<_RCO2>)				
0 =	Radius				
1 =	Chamfer				

3.23.1.41 CYCLE940 – undercut form E and F / undercut thread

Various undercuts can be programmed using the CYCLE940 cycle. In some cases, these differ significantly regarding the parameterization.

The additional columns in the table indicate which parameters are required for which undercut type. They correspond to the vertical selection softkeys in the cycle screen form:

- E: Undercut form E
- F: Undercut form F

- A-D: DIN thread undercut (forms A-D)
- T: Thread undercut (free definition of form)

Syntax

CYCLE940 (<_SPD>, <_SPL>, <_FORM>, <_LAGE>, <_SDIS>, <_FFP>, <_VARI>, <_EPD>, <_EPL>, <_R1>, <_R2>, <_STA>, <_VRT>, <_MID>, <_FAL>, <_FALX>, <_FALZ>, <_PITI>, <_PTAB>, <_PTABA>, <_DMODE>, <_AMODE>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Prog. for form				Meaning								
				E	F	A-D	T									
1	X0	<_SPD>	REAL	x	x	x	x	Reference point in the plane axis (always diameter)								
2	Z0	<_SPL>	REAL	x	x	x	x	Reference point on longitudinal axis (abs)								
3	FORM	<_FORM>	CHAR	x	x	x	x	Form of undercut (capital letters, e.g. "T") Selection, table from which the undercut values should be taken								
								A =	External, reference DIN76, A = normal							
								B =	External, reference DIN76, B = short							
								C =	Internal, reference DIN76, C = normal							
								D =	Internal, reference DIN76, D = short							
								E =	Reference DIN509							
								F =	Reference DIN509							
								T =	Free-form							
4	POSITION	<_LAGE>	INT	x	x	x	x	Position of undercut (parallel Z)								
								0 =	External +Z: ___							
								1 =	External -Z: ___/							
								2 =	Internal +Z: /-----							
								3 =	Internal -Z: -----\							
5	SC	<_SDIS>		x	x	x	x	Safety clearance (inc)								
6	F	<_FFP>		x	x	x	x	Machining feedrate (mm/rev)								
7		<_VARI>	INT	-	-	x	x	Machining type								
								UNITS:	Machining							
									1 =	Roughing						
									2 =	Finishing						
															3 =	Roughing + finishing
								TENS:	Machining strategy							
									0 =	Parallel to the contour						
								1 =	Longitudinal							
Undercut forms E and F are always machined in a single pass like finishing.																

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Prog. for form				Meaning			
8	X1	<_EPD>		x	x	-	-	Allowance X (abs/inc), see <_AMODE>			
				-	-	-	x	Undercut depth (abs/inc), see <_AMODE>			
9	Z1	<_EPL>		-	x	-	-	Allowance Z			
				-	-	-	x	Undercut width (abs/inc), see <_AMODE>			
10	R1	<_R1>		-	-	-	x	Rounding radius on slopes			
11	R2	<_R2>		-	-	-	x	Rounding radius in the corner			
12	α	<_STA>		-	-	x	x	Insertion angle			
13	VX	<_VRT>		x	x	-	-	Cross-feed X (abs/inc), see <_AMODE>			
				-	-	x	x	Cross-feed X when finishing, (abs/inc), see <_AMODE>			
14	D	<_MID>		-	-	x	x	Depth infeed			
15	U	<_FAL>		-	-	x	x	Finishing allowance parallel to contour, see <_AMODE>			
16	UX	<_FALX>		-	-	x	x	Finishing allowance X			
17	UZ	<_FALZ>		-	-	x	x	Finishing allowance Z			
18	P	<_PITI>	INT	-	-	x	-	Select pitch, form A-D, corresponds to M1 ... M68			
								0 = 0.20	6 = 0.50	12 = 1.25	18 = 3.50
								1 = 0.25	7 = 0.60	13 = 1.50	19 = 4.00
								2 = 0.30	8 = 0.70	14 = 1.75	20 = 4.50
				3 = 0.35	9 = 0.75	15 = 2.00	21 = 5.00				
				4 = 0.40	10 = 0.80	16 = 2.50	22 = 5.50				
				5 = 0.45	11 = 1.00	17 = 3.00	23 = 6.00				
				x	x	-	-	Select radius/depth, form E, F			
				0 = 0.6 x 0.3		4 = 2.5 x 0.4		8 = 0.1 x 0.1			
				1 = 1.0 x 0.4		5 = 4.0 x 0.5		9 = 0.2 x 0.1			
				2 = 1.0 x 0.2		6 = 0.4 x 0.2					
				3 = 1.6 x 0.3		7 = 0.6 x 0.2					
19		<_PTAB>	STRING [5]					String for thread table ("", "ISO", "BSW", "BSP", "UNC") (for the surface only)			
20		<_PTABA>	STRING [20]					String for selection from thread table (e.g. "M 10", "M 12", ...) (for the surface only)			
21		<_DMODE>	INT					Display mode			
				x	x	x	x	UNITS:	Machining plane G17/G18/G19		
								0 =	Compatibility, the plane effective before the cycle call remains active		
								1 =	G17 (only active in the cycle)		
								2 =	G18 (only active in the cycle)		
				3 =	G19 (only active in the cycle)						

No.	Parameter mask	Parameter internal	Data type	Prog. for form	Meaning				
22		<_AMODE>	INT	Alternative mode					
				x	x	-	x	UNITS:	Parameter <_EPD> allowance X or undercut depth
									0 =
								1 =	Incremental
				x	x	-	x	TENS:	Parameter <_EPL> allowance Z or undercut width
									0 =
								1 =	Incremental
				x	x	x	x	HUNDREDS:	Parameter <_VRT> cross-feed X
									0 =
								1 =	Incremental
				-	-	x	x	THOUSANDS:	Finishing allowance
									0 =
				1 =	Separate machining allowance (<_FALX>/<_FALZ>)				

3.23.1.42 CYCLE951 - stock removal

Syntax

```
CYCLE951 (<_SPD>, <_SPL>, <_EPD>, <_EPL>, <_ZPD>, <_ZPL>, <_LAGE>,
<_MID>, <_FALX>, <_FALZ>, <_VARI>, <_RF1>, <_RF2>, <_RF3>, <_SDIS>,
<_FF1>, <_NR>, <_DMODE>, <_AMODE>)
```

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	X0	<_SPD>	REAL	Reference point (abs, always diameter)
2	Z0	<_SPL>	REAL	Reference point (abs)
3	X1	<_EPD>	REAL	End point
4	Z1	<_EPL>	REAL	End point
5	XM α1 α2	<_ZPD>	REAL	Intermediate point, see <_DMODE> (TENS)
6	ZM α1 α2	<_ZPL>	REAL	Intermediate point, see <_DMODE> (TENS)

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
7	Position	<_LAGE>	INT	Position of stock removal corner	
				0 =	External/rear
				1 =	External/front
				2 =	Internal/rear
				3 =	Internal/front
8	D	<_MID>	REAL	Maximum depth infeed on insertion	
9	UX	<_FALX>	REAL	Finishing allowance in X	
10	UZ	<_FALZ>	REAL	Finishing allowance in Z	
11		<_VARI>	INT	Machining type	
				UNITS:	Stock removal direction (longitudinal or transverse) in the coordinate system
				1 =	Longitudinal
				2 =	Face
				TENS:	
				1 =	Roughing to final machining allowance
				2 =	Finishing
				HUNDREDS:	Reserved
THOUSANDS:	Reserved				
TEN THOUSANDS:	Reserved				
12	R1/FS1	<_RF1>	REAL	Rounding radius or chamfer width 1, see <_AMODE> (TEN THOUSANDS)	
13	R2/FS2	<_RF2>	REAL	Rounding radius or chamfer width 2, see <_AMODE> (HUNDRED THOUSANDS)	
14	R3/FS3	<_RF3>	REAL	Rounding radius or chamfer width 3, see <_AMODE> (ONE MILLION)	
15	SC	<_SDIS>	REAL	Safety clearance	
16	F	<_FF1>	REAL	Feedrate for roughing/finishing	
17		<_NR>	INT	Identification of stock removal type (corresponds to vertical softkey for selecting form):	
				0 =	Stock removal 1, 90 degree corner without chamfers/rounding
				1 =	Stock removal 2, 90 degree corner with chamfers/rounding
				2 =	Stock removal 3, any corner with chamfers/rounding

No.	Parameter mask	Parameter internal	Data type	Meaning		
18		<_DMODE>	INT	Display mode		
				UNITS:	Machining plane G17/G18/G19	
					0 =	Compatibility, the plane effective before the cycle call remains active
					1 =	G17 (only active in the cycle)
					2 =	G18 (only active in the cycle)
					3 =	G19 (only active in the cycle)
				TENS:	Form of input <_ZPD>/<_ZPL>	
					0 =	Xm/Zm
					1 =	Xm/ α 1
					2 =	Xm/ α 2
					3 =	α 1/Zm
5 =	α 1/ α 2					
21		<_AMODE>	INT	Alternative mode		
				UNITS:	Intermediate point in X	
					0 =	Absolute, value of transverse axis in the diameter
					1 =	Incremental, value of transverse axis in the radius
				TENS:	Intermediate point in Z	
					0 =	Absolute
					1 =	Incremental
				HUNDREDS:	End point in X	
					0 =	Absolute, value of transverse axis in the diameter
					1 =	Incremental, value of transverse axis in the radius
				THOUSANDS:	End point in Z.	
					0 =	Absolute
					1 =	Incremental
				TEN THOUSANDS:	Radius/chamfer 1	
					0 =	Radius
					1 =	Chamfer
				HUNDRED THOUSANDS:	Radius/chamfer 2	
					0 =	Radius
					1 =	Chamfer
				ONE MILLION:	Radius/chamfer 3	
					0 =	Radius
1 =	Chamfer					

3.23.1.43 CYCLE952 – stock removal / residual stock removal / plunge cutting / residual plunge cutting / plunge turning / residual plunge turning

Syntax

CYCLE952 (<_PRG>, <_CON>, <_CONR>, <_VARI>, <_F>, <_FR>, <_RP>, <_D>, <_DX>, <_DZ>, <_UX>, <_UZ>, <_U>, <_U1>, <_BL>, <_XD>, <_ZD>, <_XA>, <_ZA>, <_XB>, <_ZB>, <_XDA>, <_XDB>, <_N>, <_DP>, <_DI>, <_SC>, <_DN>, <_GMODE>, <_DMODE>, <_AMODE>, <_PK>, <_DCH>, <_FS>)

Parameters

No.	Parameter mask	Parameter internal	Data type	Meaning
1	PRG	<_PRG>	STRING[100]]	Name of the stock removal program
2	CON	<_CON>	STRING[100]]	Name of the program from which the updated contour of the blank is read (for residual machining)
3	CONR	<_CONR>	STRING[100]]	Name of the program into which the updated contour for the blank (see <_AMODE> TEN THOUSANDS) will be written

No.	Parameter mask	Parameter internal	Data type	Meaning	
4		<_VARI>	INT	Machining type	
				UNITS:	Type of stock removal
				1 =	Longitudinal
				2 =	Face
				3 =	Parallel to the contour
				TENS:	Machining process (see <_GMODE> HUNDREDS)
				1 =	Roughing
				2 =	Finishing
				3 =	Reserved
				4 =	Roughing, two-channel
				5 =	Finishing, two-channel
				HUNDREDS:	Machining direction
				1 =	Machining direction X -
				2 =	Machining direction X +
				3 =	Machining direction Z -
				4 =	Machining direction Z +
				THOUSANDS:	Infeed direction
				1 =	External X -
				2 =	Internal X +
				3 =	Front face Z -
				4 =	Rear face Z +
				TEN THOUSANDS:	Define effect of finishing allowances
				0 =	Separate UX and UZ finishing allowances
				1 =	Finishing allowance U parallel to the contour
HUNDRED THOUSANDS:	Rounding				
0 =	Compatibility, automatic rounding				
1 =	With rounding at the contour				
2 =	Without rounding				
3 =	Automatic rounding				
ONE MILLION:	Relief cuts				
0 =	Position is not evaluated during grooving, - residual and groove turning, - remainder				
1 =	Machine relief cuts				
2 =	No machining of relief cuts				
TEN MILLIONS:	Behind/in front of turning center				
0 =	Machining in front of the turning center				
1 =	Reserved				

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning	
5	F	<_F>	REAL	Feedrate for roughing/finishing	
	FZ			Infeed abscissa groove turning	
6	FR	<_FR>	REAL	Feedrate for insertion into relief cuts, roughing	
	FX			Infeed ordinate groove turning	
7	RP	<_RP>	REAL	Retraction plane for internal machining (abs., always diameter)	
8	D	<_D>	REAL	Roughing infeed (see <_AMODE> UNITS)	
9	DX	<_DX>	REAL	X infeed (see <_AMODE> UNITS)	
10	DZ	<_DZ>	REAL	Z infeed (see <_AMODE> UNITS)	
11	UX	<_UX>	REAL	Finishing allowance X, (see <_VARI> TEN THOUSANDS)	
12	UZ	<_UZ>	REAL	Finishing allowance Z, (see <_VARI> TEN THOUSANDS)	
13	U	<_U>	REAL	Finishing allowance parallel to contour, (see <_VARI> TEN THOUSANDS)	
14	U1	<_U1>	REAL	Additional finishing allowance while finishing (see <_AMODE> THOUSANDS)	
15	BL	<_BL>	INT	Definition of blank	
				1 =	Cylinder with allowance
				2 =	Allowance at contour of finished part
3 =	Contour of blank is specified				
16	XD	<_XD>	REAL	Definition of blank X (see <_AMODE> HUNDRED THOUSANDS)	
17	ZD	<_ZD>	REAL	Definition of blank Z (see <_AMODE> ONE MILLION)	
18	XA	<_XA>	REAL	Limit 1 X (abs., always diameter)	
19	ZA	<_ZA>	REAL	Limit 1 Z (abs.)	
20	XB	<_XB>	REAL	Limit 2 X (see <_AMODE> TEN MILLIONS)	
21	ZB	<_ZB>	REAL	Limit 2 Z (see <_AMODE> HUNDRED MILLIONS)	
22	XDA	<_XDA>	REAL	Grooving limit 1 for the 1st groove position on the end face (abs., always diameter)	
23	XDB	<_XDB>	REAL	Grooving limit 2 for the 1st groove position on the end face (abs., always diameter)	
24	N	<_N>	INT	Number of grooves	
25	DP	<_DP>	REAL	Distance between grooves	
				Longitudinal groove: Parallel to Z axis Transverse groove: Parallel to X axis	
26	DI	<_DI>	REAL	Distance for interruption of infeed	
				0 = No interruption > 0 = With interruption	
27	SC	<_SC>	REAL	Safety clearance for avoiding obstacles, incremental	
28	D2	<_DN>	INT	D number for 2nd cutting edge if not programmed ⇒ D+1	

No.	Parameter mask	Parameter internal	Data type	Meaning		
29		<_GMODE>	INT	Geometrical mode (evaluation of programmed geometrical data)		
				UNITS:	Re-serve d	
				TENS:	Re-serve d	
				HUNDREDS:	Select machining/only calculation of start point	
					0 =	Normal machining (no compatibility mode needed)
					1 =	Normal machining
				THOUSANDS:	2 =	Calculate start point - no machining (only for call from ShopMill/ShopTurn)
					Limit	
					0 =	No
				TEN THOUSANDS:	1 =	Yes
					Enter limit 1 X	
					0 =	No
				HUNDRED THOUSANDS:	1 =	Yes
					Enter limit 2 X	
					0 =	No
				ONE MILLION:	1 =	Yes
					Enter limit 1 Z	
0 =	No					
TEN MILLIONS:	1 =	Yes				
	Enter limit 2 Z					
	0 =	No				

3.23 Programming cycles externally

No.	Parameter mask	Parameter internal	Data type	Meaning																																										
30		<_DMODE>	INT	<table border="1"> <tr> <td colspan="2" data-bbox="676 304 987 336">Display mode</td> </tr> <tr> <td data-bbox="676 340 987 372">UNITS:</td> <td data-bbox="991 340 1439 372">Machining plane G17/G18/G19</td> </tr> <tr> <td data-bbox="994 376 1066 408">0 =</td> <td data-bbox="1069 376 1439 472">Compatibility, the plane effective before the cycle call remains active</td> </tr> <tr> <td data-bbox="994 476 1066 508">1 =</td> <td data-bbox="1069 476 1439 508">G17 (only active in the cycle)</td> </tr> <tr> <td data-bbox="994 512 1066 544">2 =</td> <td data-bbox="1069 512 1439 544">G18 (only active in the cycle)</td> </tr> <tr> <td data-bbox="994 549 1066 580">3 =</td> <td data-bbox="1069 549 1439 580">G19 (only active in the cycle)</td> </tr> <tr> <td data-bbox="676 585 987 617">TENS:</td> <td data-bbox="991 585 1439 617">Technology mode</td> </tr> <tr> <td data-bbox="994 621 1066 653">1 =</td> <td data-bbox="1069 621 1439 653">Stock removal along the contour</td> </tr> <tr> <td data-bbox="994 657 1066 689">2 =</td> <td data-bbox="1069 657 1439 689">Contour grooving</td> </tr> <tr> <td data-bbox="994 693 1066 725">3 =</td> <td data-bbox="1069 693 1439 725">Groove turning</td> </tr> <tr> <td data-bbox="676 729 987 761">HUNDREDS:</td> <td data-bbox="991 729 1439 761">Machine residual material</td> </tr> <tr> <td data-bbox="994 766 1066 798">0 =</td> <td data-bbox="1069 766 1439 798">No</td> </tr> <tr> <td data-bbox="994 802 1066 834">1 =</td> <td data-bbox="1069 802 1439 834">Yes</td> </tr> <tr> <td data-bbox="676 838 987 870">THOUSANDS:</td> <td data-bbox="991 838 1439 870">---</td> </tr> <tr> <td data-bbox="994 853 1066 885">---</td> <td data-bbox="1069 853 1439 885">Reserved</td> </tr> <tr> <td data-bbox="676 889 987 921">TEN THOUSANDS:</td> <td data-bbox="991 889 1439 921">Technology scaling in cycle screen forms (Page 1193)</td> </tr> <tr> <td data-bbox="994 925 1066 957">0 =</td> <td data-bbox="1069 925 1439 957">Input: Complete</td> </tr> <tr> <td data-bbox="994 961 1066 993">1 =</td> <td data-bbox="1069 961 1439 993">Input: Simple</td> </tr> <tr> <td data-bbox="676 998 987 1029">HUNDRED THOUSANDS:</td> <td data-bbox="991 998 1439 1029">Automatic program name</td> </tr> <tr> <td data-bbox="994 1034 1066 1066">0 =</td> <td data-bbox="1069 1034 1439 1066">No</td> </tr> <tr> <td data-bbox="994 1070 1066 1102">1 =</td> <td data-bbox="1069 1070 1439 1102">Yes</td> </tr> </table>	Display mode		UNITS:	Machining plane G17/G18/G19	0 =	Compatibility, the plane effective before the cycle call remains active	1 =	G17 (only active in the cycle)	2 =	G18 (only active in the cycle)	3 =	G19 (only active in the cycle)	TENS:	Technology mode	1 =	Stock removal along the contour	2 =	Contour grooving	3 =	Groove turning	HUNDREDS:	Machine residual material	0 =	No	1 =	Yes	THOUSANDS:	---	---	Reserved	TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)	0 =	Input: Complete	1 =	Input: Simple	HUNDRED THOUSANDS:	Automatic program name	0 =	No	1 =	Yes
Display mode																																														
UNITS:	Machining plane G17/G18/G19																																													
0 =	Compatibility, the plane effective before the cycle call remains active																																													
1 =	G17 (only active in the cycle)																																													
2 =	G18 (only active in the cycle)																																													
3 =	G19 (only active in the cycle)																																													
TENS:	Technology mode																																													
1 =	Stock removal along the contour																																													
2 =	Contour grooving																																													
3 =	Groove turning																																													
HUNDREDS:	Machine residual material																																													
0 =	No																																													
1 =	Yes																																													
THOUSANDS:	---																																													
---	Reserved																																													
TEN THOUSANDS:	Technology scaling in cycle screen forms (Page 1193)																																													
0 =	Input: Complete																																													
1 =	Input: Simple																																													
HUNDRED THOUSANDS:	Automatic program name																																													
0 =	No																																													
1 =	Yes																																													

No.	Parameter mask	Parameter internal	Data type	Meaning	
31		<_AMODE>	INT	Alternative mode	
				UNITS:	Select infeed
				0 =	DX and DZ infeed for stock removal parallel to contour
				1 =	D infeed
				TENS:	Infeed strategy
				0 =	Variable cutting depth (90 ... 100%)
				1 =	Constant cutting depth
				HUNDREDS:	Cut segmentation
				0 =	Uniform
				1 =	Align to edges
				THOUSANDS:	Select contour allowance U1, double finishing
				0 =	No
				1 =	Yes
				TEN THOUSANDS:	Update selection of blank
				0 =	No
				1 =	Yes
				HUNDRED THOUSANDS:	Select allowance on blank XD
				0 =	Absolute, value of transverse axis in the diameter
				1 =	Incremental, value of transverse axis in the radius
				ONE MILLION:	Select allowance on blank ZD
0 =	Absolute				
1 =	Incremental				
TEN MILLIONS:	Select limit 2 XB				
0 =	Absolute, value of transverse axis in the diameter				
1 =	Incremental, value of transverse axis in the radius				
HUNDRED MILLION:	Select limit 2 ZB				
0 =	Absolute				
1 =	Incremental				
ONE BILLION:					
0 =	Leading channel				
1 =	Following channel				
32		<_PK>	INT	Number of the partner channel if there are more than two channels available at the machine.	
33	DCH	<_DCH>	REAL	Channel offset	
34	FS	<_FS>	REAL	Finishing feedrate during complete machining	

3.23.1.44 CYCLE4071 - longitudinal grinding with infeed at the reversal point

Syntax

CYCLE4071 (<S_A>, <S_B>, <S_W>, <S_U>, <S_I>, <S_K>, <S_H>, <S_A1>, <S_A2>)


Parameters

No.	Parameter	Data type	Meaning
1	<S_A>	REAL	Infeed depth at the start
2	<S_B>	REAL	Infeed depth at the end
3	<S_W>	REAL	Grinding width
4	<S_U>	REAL	Sparking-out time
5	<S_I>	REAL	Feedrate for infeed
6	<S_K>	REAL	Feedrate for transverse infeed
7	<S_H>	INT	Number of repetitions
8	<S_A1>	AXIS	Infeed axis (optional) or 1st geometry axis
9	<S_A2>	AXIS	Oscillating axis (optional) or 2nd geometry axis

Function

The cycle is used for the execution of repeating infeeds. The infeed depth at the start and at the end can be different. There is a tangential motion between the infeeds.

Sequence



- ① Start of the cycle at the current position of the oscillating axis.
 - ② Traversing of the infeed axis to the infeed depth at the start $\langle S_A \rangle$ with the feedrate for infeed $\langle S_I \rangle$.
 - ③ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ④ Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path and the feedrate for transverse infeed $\langle S_K \rangle$.
 - ⑤ Traversing of the infeed axis to the infeed depth at the end $\langle S_B \rangle$ with the feedrate for infeed $\langle S_I \rangle$.
 - ⑥ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ⑦ Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path to the starting point and the feedrate for transverse infeed $\langle S_K \rangle$.
- Indicates reiterating sequential steps.
The sequence is repeated until the programmed number of repetitions $\langle S_H \rangle$ has been reached.

Note

The sequence cannot be interrupted with a single block.

Example

Executing two oscillating motions with the following cycle parameters:

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Infeed feedrate: 1 mm/min
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Program code

```
N10 T1 D1
```

3.23 Programming cycles externally

Program code

```
N20 CYCLE4071(0.02,0.01,100,1,1,1000,2)
N30 M30
```

3.23.1.45 CYCLE4072 - longitudinal grinding with infeed at the reversal point and cancel signal

Syntax

```
CYCLE4072 (<S_GAUGE>, <S_A>, <S_B>, <S_W>, <S_U>, <S_I>, <S_K>,
<S_H>, <S_A1>, <S_A2>)
```

Parameters


No.	Parameter	Data type	Meaning
1	<S_GAUGE>	STRING	Cancel conditions for infeed: 1. Number of a rapid input 2. Logical expression
2	<S_A>	REAL	Infeed depth at the start
3	<S_B>	REAL	Infeed depth at the end
4	<S_W>	REAL	Grinding width
5	<S_U>	REAL	Sparking-out time
6	<S_I>	REAL	Feedrate for infeed
7	<S_K>	REAL	Feedrate for transverse infeed
8	<S_H>	INT	Number of repetitions
9	<S_A1>	AXIS	Infeed axis (optional) or 1st geometry axis
10	<S_A2>	AXIS	Oscillating axis (optional) or 2nd geometry axis

Function


The cycle is used for the execution of repeating infeeds taking into account an external cancel signal. The infeed depth can be different at the start and at the end. There is a tangential motion between the infeeds. The depth infeed is cancelled when the cancel condition is satisfied. A complete stroke is always performed after the cancellation of the depth infeed.

Sequence

Cancellation of the infeed at the end



Cancellation of the infeed at the start



- ① Start of the cycle at the current position of the oscillating axis.
 - ② Traversing of the infeed axis to the infeed depth at the start $\langle S_A \rangle$ with the feedrate for infeed $\langle S_I \rangle$.
 - ③ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ④ Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path and the feedrate for transverse infeed $\langle S_K \rangle$.
 - ⑤ Traversing of the infeed axis to the infeed depth at the end $\langle S_B \rangle$ with the feedrate for infeed $\langle S_I \rangle$.
 - ⑥ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ⑦ Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path to the starting point and the feedrate for transverse infeed $\langle S_K \rangle$.
 - ⑧ Cancel signal: The machining stops when the next start point is reached.
 - ⑨ Without Cancel signal: The sequence is repeated until the programmed number of repetitions $\langle S_H \rangle$ has been reached.
- Indicates reiterating sequential steps.

Note

The sequence cannot be interrupted with a single block.

Resources

As resources, the cycle uses a block-wide synchronized action and a synchronized action variable. The synchronized action is determined dynamically from the free area of the synchronized action range (CUS.DIR - 1 ..., CMA.DIR - 1000 ..., CST.DIR - 1199 ...). SYG_IS[1] is used as the synchronized action variable.

Examples

Example 1: Oscillation with two strokes:

Cycle parameters

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Infeed feedrate: 1 mm/min
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Cancel signal: Rapid input 1 (\$A_IN[1])

Program code

```
N10 T1 D1
N20 CYCLE4072 ("1",0.02,0.01,100,1,1,1000,2)
N30 M30
```

Example 2: Oscillation with two strokes:

Cycle parameters

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Infeed feedrate: 1 mm/min
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Cancel signal: Variable \$A_DBR[20] < 0.01

Program code

```
N10 T1 D1
N20 CYCLE4072 ("($A_DBR[20]<0.01)",0.02,0.01,100,1,1,1000,2)
N30 M30
```

3.23.1.46 CYCLE4073 - longitudinal grinding with continuous infeed

Syntax

CYCLE4073 (<S_A>, <S_B>, <S_W>, <S_U>, <S_K>, <S_H>, <S_A1>, <S_A2>)


Parameters

No.	Parameter	Data type	Meaning
1	<S_A>	REAL	Infeed depth at the start
2	<S_B>	REAL	Infeed depth at the end
3	<S_W>	REAL	Grinding width
4	<S_U>	REAL	Sparking-out time
5	<S_K>	REAL	Feedrate for transverse infeed
6	<S_H>	INT	Number of repetitions
7	<S_A1>	AXIS	Infeed axis (optional) or 1st geometry axis
8	<S_A2>	AXIS	Oscillating axis (optional) or 2nd geometry axis

Function

The cycle is used for the execution of repeating infeeds. The infeed from the start to the end and from the end to the start can be different.

Sequence



- ① Start of the cycle at the current position of the oscillating axis with infeed depth 0.
- ② Traversing of the oscillating axis with the grinding width <S_W> as travel path and feedrate for transverse infeed <S_K> with continuous increase in the infeed depth up to the infeed depth at the start <S_A>.
- ③ Sparking out with the sparking-out time <S_U>.
- ④ Traversing of the oscillating axis with the grinding width <S_W> as travel path to the starting point and feedrate for transverse infeed <S_K> with continuous increase in the infeed depth up to the infeed depth at the end <S_B>.
- ⑤ Sparking out with the sparking-out time <S_U>.

■ Indicates reiterating sequential steps.

The sequence is repeated until the programmed number of repetitions <S_H> has been reached.

Note

The sequence cannot be interrupted with a single block.

Example**Oscillation with two strokes:**

Cycle parameters

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Program code

```
N10 T1 D1
N20 CYCLE4073(0.02,0.01,100,1,1000,2)
N30 M30
```

3.23.1.47 CYCLE4074 - longitudinal grinding with continuous infeed and cancel signal**Syntax**

```
CYCLE4074 (<S_GAUGE>, <S_A>, <S_B>, <S_W>, <S_U>, <S_K>, <S_H>,
<S_A1>, <S_A2>)
```

Parameters

No.	Parameter	Data type	Meaning
1	<S_GAUGE>	STRING	Cancel conditions for infeed: 1. Number of a rapid input 2. Logical expression
2	<S_A>	REAL	Infeed depth at the start
3	<S_B>	REAL	Infeed depth at the end
4	<S_W>	REAL	Grinding width
5	<S_U>	REAL	Sparking-out time
6	<S_K>	REAL	Feedrate for transverse infeed
7	<S_H>	INT	Number of repetitions


No.	Parameter	Data type	Meaning
8	<S_A1>	AXIS	Infeed axis (optional) or 1st geometry axis
9	<S_A2>	AXIS	Oscillating axis (optional) or 2nd geometry axis

Function


The cycle is used for the execution of repeating infeeds taking into account e.g. an external cancel signal. The infeed depth can be different at the start and at the end. The depth infeed is cancelled when the cancel condition is satisfied. A complete stroke is always performed after the cancellation of the depth infeed.

Sequence

Cancellation of the infeed from the end to the start



Cancellation of the infeed from the start to the end



- ① Start of the cycle at the current position of the oscillating axis with infeed depth 0.
 - ② Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path and feedrate for transverse infeed $\langle S_K \rangle$ with continuous increase in the infeed depth up to the infeed depth at the start $\langle S_A \rangle$.
 - ③ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ④ Traversing of the oscillating axis with the grinding width $\langle S_W \rangle$ as travel path to the starting point and feedrate for transverse infeed $\langle S_K \rangle$ with continuous increase in the infeed depth up to the infeed depth at the end $\langle S_B \rangle$.
 - ⑤ Sparking out with the sparking-out time $\langle S_U \rangle$.
 - ⑥ Cancel signal: The depth infeed is canceled. The machining stops when the next start point is reached.
 - ⑦ Without Cancel signal: The sequence is repeated until the programmed number of repetitions $\langle S_H \rangle$ has been reached.
- Indicates reiterating sequential steps.

Note

The sequence cannot be interrupted with a single block.

Resources

As resources, the cycle uses a block-wide synchronized action and a synchronized action variable. The synchronized action is determined dynamically from the free area of the synchronized action range (CUS.DIR - 1 ..., CMA.DIR - 1000 ..., CST.DIR - 1199 ...). SYG_IS[1] is used as the synchronized action variable.

Examples

Example 1: Oscillation with two strokes:

Cycle parameters

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Cancel signal: Rapid input 1 (\$A_IN[1])

Program code

```
N10 T1 D1
N20 CYCLE4074 ("1",0.02,0.01,100,1,1000,2)
N30 M30
```

Example 2: Oscillation with two strokes:

Cycle parameters

- Infeed depth at the start: 0.02 mm
- Infeed depth at the end: 0.01 mm
- Stroke: 100 mm
- Sparking-out time: 1 s
- Transverse feedrate: 1000 mm/min
- Repetitions: 2
- Oscillating and infeed axes: Standard geometry axes

Cancel signal: Variable \$A_DBR[20] < 0.01

Program code

```
N10 T1 D1
N20 CYCLE4074 ("($A_DBR[20]<0.01)",0.02,0.01,100,1,1000,2)
N30 M30
```

3.23.1.48 CYCLE4075 - surface grinding with infeed at the reversal point

Syntax

```
CYCLE4075 (<S_I>, <S_J>, <S_K>, <S_A>, <S_R>, <S_F>, <S_P>, <S_A1>,
<S_A2>)
```

Parameters

No.	Parameter	Data type	Meaning
1	<S_I>	REAL	Infeed depth at the start
2	<S_J>	REAL	Infeed depth at the end
3	<S_K>	REAL	Total infeed depth
4	<S_A>	REAL	Grinding width
5	<S_R>	REAL	Feedrate for infeed
6	<S_F>	REAL	Feedrate for transverse infeed
7	<S_P>	REAL	Sparking-out time
8	<S_A1>	AXIS	Infeed axis (optional)
9	<S_A2>	AXIS	Oscillating axis (optional)

Function

The cycle is used for machining with a total infeed depth in infeed steps. The infeed depths at the start and at the end can be different. There is a tangential motion between the infeeds.


The positional data P1 to P4 can be negative or positive.

The specification of the infeed axis and/or oscillating axis is optional. If one or both parameters are not specified, the cycle uses the first two geometry axes of the channel.


If the sum of the infeed depth at the start and end is 0 or the total infeed depth is 0, only one sparking-out stroke is performed.

Sequence

Total infeed depth reached with infeed at the second reversal point



Total infeed depth reached with infeed at the first reversal point



- ① Start of the cycle at the current position of the oscillating axis.
 - ② Traversing of the infeed axis to the infeed depth at the start $\langle S_I \rangle$ with the feedrate for infeed $\langle S_R \rangle$.
 - ③ Sparking out with the sparking-out time $\langle S_P \rangle$.
 - ④ Traversing of the oscillating axis with the grinding width $\langle S_A \rangle$ as travel path and the feedrate for transverse infeed $\langle S_F \rangle$.
 - ⑤ Traversing of the infeed axis to the infeed depth at the end $\langle S_J \rangle$ with the feedrate for infeed $\langle S_R \rangle$.
 - ⑥ Sparking out with the sparking-out time $\langle S_P \rangle$.
 - ⑦ Traversing of the oscillating axis with the grinding width $\langle S_A \rangle$ as travel path to the starting point and the feedrate for transverse infeed $\langle S_F \rangle$.
- Indicates reiterating sequential steps.
 The sequence is repeated until the total infeed depth $\langle S_K \rangle$ has been reached. The last stroke is then distributed unevenly.

Note

The sequence cannot be interrupted with a single block.

Example

Oscillation with:

- 0.02 mm infeed depth at the start
- 0.01 mm infeed depth at the end
- Total infeed depth 1 mm
- 100 mm stroke
- Infeed feedrate 1 mm/min
- Transverse feedrate 1000 mm/min

- 1 second sparking-out time
- Standard geometry axes

```

Program code
-----
N10 T1 D1
N20 CYCLE4075(0.02,0.01,1,100,1,1000,1)
N30 M30

```

3.23.1.49 CYCLE4077 - surface grinding with infeed at the reversal point and cancel signal

Syntax

```
CYCLE4077(<S_GAUGE>, <S_I>, <S_J>, <S_K>, <S_A>, <S_R>, <S_F>,
<S_P>, <S_A1>, <S_A2>)
```

Parameters

No.	Parameter	Data type	Meaning
1	<S_GAUGE>	STRING	Cancel condition for infeed: <ul style="list-style-type: none"> • Number of a rapid input • Logical expression
2	<S_I>	REAL	Infeed depth at the start
3	<S_J>	REAL	Infeed depth at the end
4	<S_K>	REAL	Total infeed depth
5	<S_A>	REAL	Grinding width
6	<S_R>	REAL	Feedrate for infeed
7	<S_F>	REAL	Feedrate for transverse infeed
8	<S_P>	REAL	Sparking-out time
9	<S_A1>	AXIS	Infeed axis (optional)
10	<S_A2>	AXIS	Oscillating axis (optional)

Function

The cycle is used for machining with a total infeed depth in infeed steps. The infeed depths at the start and at the end can be different. There is a tangential motion between the infeeds. The depth infeed is cancelled when the cancel signal of the rapid input is 1 or the cancel condition is satisfied. A complete stroke is performed after the cancellation.


The positional data P2 to P5 can be negative or positive.

The specification of the infeed axis and/or oscillating axis is optional. If one or both parameters are not specified, the cycle uses the first two geometry axes of the channel.


If the sum of the infeed depth at the start and end is 0 or the total infeed depth is 0, only one sparking-out stroke is performed.

Sequence

Cancellation of the infeed at the end



Cancellation of the infeed at the start



- ① Start of the cycle at the current position of the oscillating axis.
 - ② Traversing of the infeed axis to the infeed depth at the start <S_I> with the feedrate for infeed <S_R>.
 - ③ Sparking out with the sparking-out time <S_P>.
 - ④ Traversing of the oscillating axis with the grinding width <S_A> as travel path and the feedrate for transverse infeed <S_F>.
 - ⑤ Traversing of the infeed axis to the infeed depth at the end <S_J> with the feedrate for infeed <S_R>.
 - ⑥ Sparking out with the sparking-out time <S_P>.
 - ⑦ Traversing of the oscillating axis with the grinding width <S_A> as travel path to the starting point and the feedrate for transverse infeed <S_F>.
 - ⑧ Cancel signal: The machining stops when the next start point is reached.
 - ⑨ Without Cancel signal: The sequence is repeated until the total infeed depth <S_K> has been reached. The last stroke is then distributed unevenly.
- Indicates reiterating sequential steps.

Note

The sequence cannot be interrupted with a single block.

Resources

As resources, the cycle uses a block-wide synchronized action and a synchronized action variable. The synchronized action is determined dynamically from the free area of the synchronized action range (CUS.DIR - 1 ..., CMA.DIR - 1000 ..., CST.DIR - 1199 ...). SYG_IS[1] is used as the synchronized action variable.

Examples

Example 1

Oscillation with:

- 0.02 mm infeed depth at the start
- 0.01 mm infeed depth at the end
- Total infeed depth 1 mm
- 100 mm stroke
- Infeed feedrate 1 mm/min
- Transverse feedrate 1000 mm/min
- 1 second sparking-out time
- Standard geometry axes

Cancel signal: Rapid input 1 (\$A_IN[1])

Program code

```
N10 T1 D1
N20 CYCLE4077 ("1",0.02,0.01,1,100,1,1000,1)
N30 M30
```

Example 2

Oscillation with:

- 0.02 mm infeed depth at the start
- 0.01 mm infeed depth at the end
- Total infeed depth 1 mm
- 100 mm stroke
- Infeed feedrate 1 mm/min
- Transverse feedrate 1000 mm/min
- 1 second sparking-out time
- Standard geometry axes

Cancel signal: Dual-port RAM variable 20 less than 0.01 (\$A_DBR[20] < 0.01)

Program code

```
N10 T1 D1
N20 CYCLE4077 ("($A_DBR[20]<0.01)",0.02,0.01,1,100,1,1000,1)
N30 M30
```

3.23.1.50 CYCLE4078 - surface grinding with continuous infeed

Syntax

CYCLE4078 (<S_I>, <S_J>, <S_K>, <S_A>, <S_F>, <S_P>, <S_A1>, <S_A2>)

Parameters

No.	Parameter	Data type	Meaning
1	<S_I>	REAL	Infeed depth from the start to the end
2	<S_J>	REAL	Infeed depth from the end to the start
3	<S_K>	REAL	Total infeed depth
4	<S_A>	REAL	Grinding width
5	<S_F>	REAL	Feedrate
6	<S_P>	REAL	Sparking-out time
7	<S_A1>	AXIS	Infeed axis (optional)
8	<S_A2>	AXIS	Oscillating axis (optional)

Function


The cycle is used for machining with a total infeed depth by means of continuous infeed. The infeed depths from the start to the end and from the end to the start can be different.

The positional data P1 to P4 can be negative or positive.

The specification of the infeed axis and/or oscillating axis is optional. If one or both parameters are not specified, the cycle uses the first two geometry axes of the channel.

If the sum of the infeed depths P1 and P2 is 0 or the total infeed depth is 0, only one sparking-out stroke is performed.

Sequence



- ① Start of the cycle at the current position of the oscillating axis with infeed depth 0.
- ② Traversing of the oscillating axis with the grinding width $\langle S_A \rangle$ as travel path and feedrate $\langle S_F \rangle$ with continuous increase in the infeed depth up to the infeed depth at the start $\langle S_I \rangle$.
- ③ Sparking out with the sparking-out time $\langle S_P \rangle$.
- ④ Traversing of the oscillating axis with the grinding width $\langle S_A \rangle$ as travel path to the starting point and feedrate $\langle S_F \rangle$ with continuous increase in the infeed depth up to the infeed depth at the end $\langle S_J \rangle$.
- ⑤ Sparking out with the sparking-out time $\langle S_P \rangle$.
- ⑥ Traversing of the oscillating axis with the grinding width $\langle S_A \rangle$ as travel path to the starting point and feedrate $\langle S_F \rangle$.

■ Indicates reiterating sequential steps.

The sequence is repeated until the total infeed depth $\langle S_K \rangle$ has been reached. The last stroke is then distributed unevenly.

Note

The sequence cannot be interrupted with a single block.

Example

Oscillation with:

- 20 mm infeed depth at the start
- 10 mm infeed depth at the end
- Total infeed depth 100 mm
- 100 mm stroke
- Feedrate 1000 mm/min
- 1 second sparking-out time
- Standard geometry axes

```

Program code
N10 T1 D1
N20 CYCLE4078(20,10,100,100,1000,1)
N30 M30

```

3.23.1.51 CYCLE4079 - surface grinding with intermittent infeed

Syntax

```
CYCLE4079(<S_I>, <S_J>, <S_K>, <S_A>, <S_R>, <S_F>, <S_P>, <S_A1>,
<S_A2>)
```

Parameters

No.	Parameter	Data type	Meaning
1	<S_I>	REAL	Infeed depth at the start
2	<S_J>	REAL	Infeed depth at the end
3	<S_K>	REAL	Total infeed depth
4	<S_A>	REAL	Grinding width
5	<S_R>	REAL	Feedrate for infeed
6	<S_F>	REAL	Feedrate for transverse infeed
7	<S_P>	REAL	Sparking-out time
8	<S_A1>	AXIS	Infeed axis (optional)
9	<S_A2>	AXIS	Oscillating axis (optional)

Function

The cycle is used for machining with a total infeed depth in infeed steps. The infeed depths at the start and at the end can be different. There is a tangential motion between the infeeds.


The positional data P1 to P4 can be negative or positive.

The specification of the infeed axis and/or oscillating axis is optional. If one or both parameters are not specified, the cycle uses the first two geometry axes of the channel.

If the sum of the infeed depth at the start and end is 0 or the total infeed depth is 0, only one sparking-out stroke is performed.

Sequence

Total infeed depth reached with infeed at the second reversal point



3.23 Programming cycles externally

- 1 second sparking-out time
- Standard geometry axes

```

Program code
-----
N10 T1 D1
N20 CYCLE4079(0.02,0.01,1,100,1,1000,1)
N30 M30
    
```

3.23.1.52 GROUP_BEGIN - beginning of program block

Syntax

GROUP_BEGIN (<_LEVEL>, <_NAME>, <_SP>, <_MODE>, <S_ICON>)

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning		
1		<_LEVEL>	INT	Level		
				0 =	Main level	
				1 =	1st sublevel	
2		<_NAME>	STRING[128]	Block name		
3		<_SP>	INT	Spindle		
				0 =	No spindle	
				1 =	Main spindle	
				2 =	Counterspindle	
4		<_MODE>	INT	Mode		
				Bit 0	= 1	GROUP_ADDEND exists
				Bit 1	= 1	ShopTurn: Automatic retraction (traverse to tool change point)
				Bit 12	Reserved	
				Bit 13	Reserved	
5		<S_ICON>	STRING[32]	Name of the icon (only for operator interface)		

3.23.1.53 GROUP_END - end of program block

Syntax

GROUP_END (<_LEVEL>, <_SP>)

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning	
1		<_LEVEL>	INT	Level	
				0 =	Main level
				1 =	1st sublevel
2		<_SP>	INT	Spindle	
				0 =	No spindle
				1 =	Main spindle
				2 =	Counterspindle

3.23.1.54 GROUP_ADDEND - End of trial cut addition**Syntax**

```
GROUP_ADDEND(<_LEVEL>, <_SP>)
```

Parameter

No.	Parameter mask	Parameter internal	Data type	Meaning	
1		<_LEVEL>	INT	Level	
				0 =	Main level
				1 =	1st sublevel
2		<_SP>	INT	Spindle	
				0 =	No spindle
				1 =	Main spindle
				2 =	Counterspindle

3.23.1.55 Supplementary conditions**Technology scaling in cycle screen forms**

When the technology scaling is active, the simplified input can be selected for various cycle screen forms, in which only the most important cycle parameters are displayed

For example, the simplified input can be selected for the following cycle screen forms:

Technology	Cycle screen form
Drilling	Deep-hole drilling
	Tapping
Milling	Rectangular pocket
	Contour milling: Pocket

Technology	Cycle screen form
Turning	Thread turning: Longitudinal
	Contour turning: Stock removal
	Contour turning: Grooving
	Contour turning: Groove turning

In the user interface of the relevant cycle screen forms, the options "Input: **Simple**" and "Input: **Complete**" are available.

Cycle parameters that are not displayed

The cycle parameters that are not displayed in the simplified input are pre-assigned fixed, technologically useful, but not variable values. Or the cycle parameters are assigned parameterizable values via the channel-specific cycle setting data. See the paragraph below "Commissioning" > "Channel-specific cycle setting data"

Switchover from "Input: Complete" > "Input: Simple"

If a cycle screen form is filled in with the setting "Input complete" and then switched to "Input simple", the default or setting data values are used for the parameters no longer displayed when generating the cycle call.

Commissioning

Channel-specific configuration machine data

The technology scaling in cycle screen forms can be activated with the machine data:
MD52210 \$MCS_FUNCTION_MASK_DISP, bit 9 = 1 (select display "Input simple")

Channel-specific cycle setting data

If the simplified input in cycle screen forms is active, the values for certain cycle parameters can be specified via the following setting data:

Number	Identifier	Meaning
SD55300	\$SCS_EASY_SAFETY_CLEARANCE	Safety clearance
SD55301	\$SCS_EASY_DWELL_TIME	Dwell time
SD55305	\$SCS_EASY_DRILL_DEEP_FD1	Deep-hole drilling: Percentage: 1st feedrate
SD55306	\$SCS_EASY_DRILL_DEEP_DF	Deep-hole drilling: Percentage: Infeed
SD55307	\$SCS_EASY_DRILL_DEEP_V1	Deep-hole drilling: Minimum depth infeed
SD55308	\$SCS_EASY_DRILL_DEEP_V2	Deep-hole drilling: Retraction distance
SD55309	\$SCS_EASY_THREAD_RETURN_DIST	Thread turning: Return distance

3.23.2 Overview of measuring cycle parameters

3.23.2.1 CYCLE973 measuring cycle parameters

```
PROC CYCLE973 (INT S_MVAR, INT S_PRNUM, INT S_CALNUM, REAL S_SETV, INT S_MA, INT S_MD, REAL
S_FA, REAL S_TSA, REAL S_VMS, INT S_NMSP, INT S_MCBIT, INT _DMODE, INT _AMODE)
```

Table 3-8 CYCLE973 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring variant (default=0012103)	
			Val- ues:	UNITS: Calibration on a surface, edge or in a groove 0 = Length on surface/edge (in the WCS) with known setpoint 1 = Radius on surface (in the WCS) with known setpoint 2 = Length in groove (in the WCS), see S_CALNUM 3 = Radius in groove (in the WCS), see S_CALNUM
			TENS: Reserved 0 = 0	
			HUNDREDS: Reserved 0 = 0	
			THOUSANDS: Selection of measuring axis and measuring direction for calibration ²⁾ 0 = No specification (for surface calibration on the groove base, no selection of the measuring axis and measuring direction) ⁴⁾ 1 = Specify selection of measuring axis and measuring direction, see S_MA, S_MD (one measuring direction in a measuring axis) 2 = Specify selection of measuring axis, see S_MA (two measuring directions in a measuring axis)	
			TEN THOUSANDS: Determination of the positional deviation (probe skew) ^{2), 3)} 0 = Determine positional deviation 1 = Do not determine positional deviation	
			HUNDRED THOUSANDS: Reserved 0 = 0	
			ONE MILLION: adapt tool length ⁷⁾ 0 = Do not adapt tool length (only trigger points) 1 = Adapt tool length	
2	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)	
3		S_CALNUM	Number of the calibration groove for calibration on a groove (default=1) ⁵⁾	
4		S_SETV	Setpoint for calibration on a surface	

3.23 Programming cycles externally

No.	Screen form parameters	Cycle parameters	Meaning
5	X0	S_MA	Measuring axis (number of the axis) ⁶⁾ (default=1)
			Val-ues: 1 = 1st axis of the plane (for G18 Z) 2 = 2nd axis of the plane (for G18 X) 3 = 3rd axis of the plane (for G18 Y) ⁶⁾
6	+-	S_MD	Measuring direction (default=1)
			Val-ues: 0 = Positive measuring direction 1 = Negative measuring direction
7	DFA	S_FA	Measurement path
8	TSA	S_TSA	Safe area
9	VMS	S_VMS	Variable measuring velocity for calibration ²⁾
10	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (default=1)
11		S_MCBIT	Reserved
12		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
13		_AMODE	Alternative mode

- 1) All default values = 0 or marked as default=x
- 2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 3) Only relevant for calibration in two axis directions
- 4) Only measuring axis and measuring direction are determined automatically from the cutting edge position (SL) of the probe.
SL=8 → -X , SL=7 → -Z
- 5) The number of the calibration groove (n) refers to the following general setting data (all positions in machine coordinate system):
For cutting edge SL=7:
SD54615 \$SNS_MEA_CAL_EDGE_BASE_AX1[n] Position base of the groove in the 1st axis of the plane (for G18 Z)
SD54621 \$SNS_MEA_CAL_EDGE_PLUS_DIR_AX2[n] Position of the groove wall in the positive direction of the 2nd axis of the plane (for G18 X)
SD54622 \$SNS_MEA_CAL_EDGE_MINUS_DIR_AX2[n] Position of the groove wall in the negative direction of the 2nd axis of the plane
for cutting edge position SL=8:
SD54619 \$SNS_MEA_CAL_EDGE_BASE_AX2[n] Position of the groove base in the 2nd axis of the plane
SD54620 \$SNS_MEA_CAL_EDGE_UPPER_AX2[n] Position of the upper edge of the groove in the 2nd axis of the plane (only to preposition the probe)
SD54617 \$SNS_MEA_CAL_EDGE_PLUS_DIR_AX1[n] Position of the groove wall in the positive direction of the 1st axis of the plane
SD54618 \$SNS_MEA_CAL_EDGE_MINUS_DIR_AX1[n] Position of the groove wall in the negative direction of the 1st axis of the plane
Note:
The positions values for the groove wall +/- can be determined roughly.
The groove width from the difference of the position values of the groove wall must be determined precisely (precision dial gauge).
For calibration in the groove, it is assumed that the tool length of the probe of the calibrated axis = 0.
The positions values for the groove base must also be determined precisely on the machine (no drawing dimensions).
- 6) Measuring axis S_MA=3 for calibration on a surface and on a turning machine with real 3rd axis of the plane (for G18 Y).

- 7) Adapt tool length when calibrating length in the groove, or for lengths at the surface.
 Workpiece probe in lathes can be defined using 2 lengths (X Z).
 Turning probe, type 580
 cutting-edge position 7: For length calibration, optionally, the Z length is corrected.
 Turning probe, type 580
 cutting edge position 8: For length calibration, optionally, the X length is corrected
 The tool length is not adapted for the measurement version, radius at groove or radius at the surface.
 Only the corresponding trigger points are saved.

3.23.2.2 CYCLE974 measuring cycle parameters

```
PROC CYCLE974 (INT S_MVAR, INT S_KNUM, INT S_KNUM1, INT S_PRNUM, REAL S_SETV, INT S_MA, REAL
S_FA, REAL S_TSA, REAL S_STA1, INT S_NMSP, STRING[32] S_TNAME, INT S_DLNUM, REAL S_TZL, REAL
S_TDIF, REAL S_TUL, REAL S_TLL, REAL S_TMV, INT S_K, INT S_EVNUM, INT S_MCBIT, INT _DMODE, INT
_AMODE, INT _DP)
```

Table 3-9 CYCLE974 call parameters ¹⁾

No.	Screen form parameter	Cycle parameter	Meaning
1		S_MVAR	Measuring variant Val-ues: UNITS: 0 = Measure front face 1 = Inside measurement 2 = Outside measurement TENS: Reserved HUNDREDS: Correction target 0 = Only measurement (no correction of the WO or no tool offset) 1 = Measurement, determination and correction of the WO (see S_KNUM) ³⁾ 2 = Measurement and tool offset (see S_KNUM1) THOUSANDS: Reserved TEN THOUSANDS: Measurement with or without reversal of the main spindle (workspindle) 0 = Measurement without reversal 1 = Measurement with reversal

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
2	Selection	S_KNUM	<p>Correction in work offset (WO) or basic WO or basic reference ²⁾</p> <p>Val-ues:</p> <p>UNITS:</p> <p>TENS:</p> <p>0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset</p> <p>HUNDREDS: Reserved</p> <p>THOUSANDS: Correction in WO or basic WO or basic reference</p> <p>0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 3 = Correction of the global basic WO 9 = Correction of the active WO or for G500, last active channel-specific basic WO</p> <p>TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference</p> <p>0 = Fine correction ⁶⁾ 1 = Coarse correction</p>

No.	Screen form parameter	Cycle parameter	Meaning	
3	Selection	S_KNUM1	Correction in tool offset ^{2), 4)}	
			Val-ues:	UNITS:
				TENS:
				HUNDREDS: 0 = No correction 1 to max. 999 D numbers (cutting edge numbers) for tool offset; for additive and setup offset, see also S_DLNUM
				THOUSANDS: 0 or unique D number
				TEN THOUSANDS: 0 or unique D number 1 to max. 32000 if unique D numbers in MD have been set up
				HUNDRED THOUSANDS: Tool offset ²⁾ 0 = No specification (offset in tool geometry) 1 = Offset of length L1 2 = Offset of length L2 3 = Offset of length L3 4 = Radius offset
				ONE MILLION: Tool offset ²⁾ 0 = No specification (offset of the tool length wear) 1 = Tool offset, additive offset (AO) ⁵⁾ Tool offset value is added to the existing AO 2 = Tool offset, setup offset (SO) ⁵⁾ SO (new) = SO (old) + AO (old) offset value, AO (new) = 0 3 = Tool offset, setup offset (SO) ⁵⁾ Tool offset value is added to the existing SO 4 = Tool offset, geometry
				TEN MILLION: Tool offset ²⁾ 0 = No specification (offset in tool geometry normal (not inverted)) 1 = Offset inverted
4	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)	
5	X0	S_SETV	Setpoint	
6	X	S_MA	Measuring axis (number of the axis) (default=1)	
			Val-ues:	1 = 1st axis of the plane (for G18 Z) 2 = 2nd axis of the plane (for G18 X) 3 = 3rd axis of the plane (for G18 Y) ⁵⁾
7	DFA	S_FA	Measurement path	
8	TSA	S_TSA	Safe area	
9	α	S_STA1	Starting angle for measurement with reversal	
10	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (default=1)	
11	T	S_TNAME	Tool name ²⁾	
12	DL	S_DLNUM	Setup additive offset DL number ⁵⁾	

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
13	ST	_DP	Number of the replacement tool (duplo number) to be corrected
14	TZL	S_TZL	Work offset ^{2), 4)}
15	DIF	S_TDIF	Dimensional difference check ^{2), 4)}
16	TUL	S_TUL	Upper tolerance limit (incremental to the setpoint) ⁴⁾
17	TLL	S_TLL	Lower tolerance limit (incremental to the setpoint) ⁴⁾
18	TMV	S_TMV	Offset range for averaging ²⁾
19	FW	S_K	Weighting factor for averaging ²⁾
20	EVN	S_EVNUM	Number of the empirical mean value memory ^{2), 7)}
21		S_MCBIT	Reserved
22		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
23		_AMODE	Alternative mode
			Val-ues: UNITS: Dimensional tolerance yes/no 0 = No 1 = Yes

- 1) All default values = 0 or marked as default=x
- 2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 3) Correction in WO only possible for measurement without reversal
- 4) For tool offset in the channel-specific MD 20360 TOOL_PARAMETER_DEF_MASK , observe bit0 and bit1
- 5) Only if the "Setup additive offset" function has been set-up in the general MD 18108 \$MN_MM_NUM_SUMCORR . In addition, in the general MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK , bit8 must be set to 1.
- 6) If WO "fine" has not been set up in MDs, correction is according to WO "coarse"
- 7) Empirical averaging only possible for tool offset
 Value range for empirical mean value memory:
 1 to 20 numbers (n) of the empirical value memory, see channel-specific SD 55623 \$SCS_MEA_EMPIRIC_VALUE[n-1]
 10000 to 200000 numbers (n) of the mean value memory, see channel-specific SD 55625 \$SCS_MEA_AVERAGE_VALUE[n-1]

3.23.2.3 CYCLE994 measuring cycle parameters

```
PROC CYCLE994 (INT S_MVAR, INT S_KNUM, INT S_KNUM1, INT S_PNUM, REAL S_SETV, INT S_MA, REAL
S_SZA, REAL S_SZO, REAL S_FA, REAL S_TSA, INT S_NMSP, STRING[32] S_TNAME, INT S_DLNUM, REAL
S_TZL, REAL S_TDIF, REAL S_TUL, REAL S_TLL, REAL S_TMV, INT S_K, INT S_EVNUM, INT S_MCBIT, INT
_DMODE, INT _AMODE, INT _DP)
```


Table 3-10 CYCLE994 call parameters ¹⁾

No.	Screen form parameter	Cycle parameter	Meaning	
1		S_MVAR	Measuring variant	
			Val- ues:	UNITS: Inside or outside measurement (default = 1) 1 = Inside measurement 2 = Outside measurement
				TENS: Reserved
				HUNDREDS: Correction target 0 = Only measurement (no correction of the WO or no tool offset) 1 = Measurement and determination and correction of the WO (see S_KNUM) ³⁾ 2 = Measurement and tool offset (see S_KNUM1)
				THOUSANDS: Bypass area 0 = no bypass area 1 = bypass axis 1st axis of the plane (for G18 Z) Measuring axis, see S_MA. 2 = bypass axis 2nd axis of the plane (for G18 X) Measuring axis, see S_MA. 3 = bypass axis 3rd axis of the plane (for G18 Y). Measuring axis, see S_MA. ⁸⁾
2	Selection	S_KNUM	Correction of work offset (WO) or basic WO or basic reference ²⁾	
			Val- ues:	UNITS:
				TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
				HUNDREDS: Reserved
				THOUSANDS: Correction of WO or basic or basic reference 0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 3 = Correction of the global basic WO 9 = Correction of the active WO or for G500 in last active channel-specific basic WO
		TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference 0 = Fine correction ⁶⁾ 1 = Coarse correction		

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning	
3	Selection	S_KNUM1	Correction in tool offset ^{2), 4)}	
			Val- ues:	UNITS:
				TENS:
				HUNDREDS: 0 = No correction 1 to max. 999 D numbers (cutting edge numbers) for tool offset; for additive and setup offset, see also S_DLNUM
				THOUSANDS: 0 or unique D numbers
				TEN THOUSANDS: 0 or unique D numbers 1 to max. 32000, if unique D numbers in MD have been set up
				HUNDRED THOUSANDS: Tool offset ²⁾ 0 = No specification (offset tool geometry) 1 = Offset of length L1 2 = Offset of length L2 3 = Offset of length L3 4 = Radius offset
				ONE MILLION: Tool offset ²⁾ 0 = No specification (offset of the tool length wear) 1 = Tool offset, additive offset (AO) ⁵⁾ Tool offset value is added to the existing AO 2 = Tool offset, setup offset (SO) ⁵⁾ SO (new) = SO (old) + AO (old) offset value, AO (new) = 0 3 = Tool offset, setup offset (SO) ⁵⁾ Tool offset value is added to the existing SO 4 = Tool offset, geometry
				TEN MILLION: Tool offset ²⁾ 0 = No specification (offset in tool geometry normal, not inverted) 1 = Offset inverted
				HUNDRED MILLIONS: Tool offset 0 = tool offset without replacement tools 1 = tool offset in replacement tool (_DP)
4	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)	
5	X0	S_SETV	Setpoint	
6	X	S_MA	Number of the measuring axis (default=1)	
			Val- ues:	1 = 1st axis of the plane (for G18 Z) 2 = 2nd axis of the plane (for G18 X) 3 = 3rd axis of the plane (for G18 Y) ⁸⁾
7	X1	S_SZA	Bypass distance in the measured axis	
8	Y1	S_SZO	Bypass distance in the bypass axis	
9	DFA	S_FA	Measurement path	
10	TSA	S_TSA	Safe area	
11	Measure- ments	S_NMSP	Number of measurements at the same location ²⁾ (default=1)	
12	T	S_TNAME	Tool name ²⁾	

No.	Screen form parameter	Cycle parameter	Meaning
13	DL	S_DLNUM	Setup additive offset DL number ⁵⁾
14	ST	_DP	Number of the replacement tool (duplo number) to be corrected
15	TZL	S_TZL	Work offset ^{2), 4)}
16	DIF	S_TDIF	Dimensional difference check ^{2), 4)}
17	TUL	S_TUL	Upper tolerance limit (incremental to the setpoint) ⁴⁾
18	TLL	S_TLL	Lower tolerance limit (incremental to the setpoint) ⁴⁾
19	TMV	S_TMV	Offset range for averaging ²⁾
20	FW	S_K	Weighting factor for averaging ²⁾
21	EVN	S_EVNUM	Number of the empirical value memory ^{2), 7)}
22		S_MCBIT	Reserved
23		_DMODE	Display mode
			Val- ues:
24		_AMODE	Alternative mode
			Val- ues:

1) All default values = 0 or marked as default=x

2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE

3) Correction in WO only possible for measurement without reversal

4) For tool offset, observe the channel MD 20360 TOOL_PARAMETER_DEF_MASK

5) Only if the "Setup additive offset" function has been set-up in the general MD 18108 \$MN_MM_NUM_SUMCORR . In addition, the general MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK , bit8 must be set to 1.

6) If WO "fine" has not been set up in MDs, correction is according to WO "coarse"

7) Empirical averaging only possible for tool offset

Value range for empirical mean value memory:

1 to 20 numbers (n) of the empirical value memory, see channel-specific SD 55623 \$SCS_MEA_EMPIRIC_VALUE[n-1]

10000 to 200000 numbers (n) of the mean value memory, see channel-specific SD 55625

\$SCS_MEA_AVERAGE_VALUE[n-1]

8) If Y axis is available on the machine

3.23.2.4 CYCLE976 measuring cycle parameters

```
PROC CYCLE976 (INT S_MVAR, INT S_PRNUM, REAL S_SETV, REAL S_SETV0, INT S_MA, INT S_MD, REAL
S_FA, REAL S_TSA, REAL S_VMS, REAL S_STAI, INT S_NMSP, INT S_SETV1, INT _DMODE, INT _AMODE)
```

3.23 Programming cycles externally

Table 3-11 CYCLE976 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring version (default=1000)	
			Val- ues:	UNITS: Calibration on surface, calibration sphere or calibration ring ²⁾ 0 = Length on surface with known setpoint 1 = Radius in calibration ring with known diameter (setpoint) and known center point. 2 = Radius in calibration ring with known diameter (setpoint) and an unknown center point 3 = Radius and length at the calibration sphere 4 = Radius at the edge with known setpoint. Note selection of measuring axis and measuring direction. ³⁾ 5 = Radius between two edges with known setpoint and edge clearance. Measuring axis should be selected.
				TENS: Reserved 0 = 0
				HUNDREDS: Reserved 0 = 0
				THOUSANDS: Selection of measuring axis and measuring direction during calibration. 0 = No specification (no selection of the measuring axis and measuring direction required) ⁸⁾ 1 = Specify selection of measuring axis and measuring direction, see S_MA, S_MD (one measuring direction in a measuring axis) 2 = Specify selection of measuring axis, see S_MA (two measuring directions in a measuring axis)
				TEN THOUSANDS: Determination of the positional deviation (probe skew) ²⁾ 0 = Determine positional deviation of the probe ⁶⁾ 1 = Do not determine positional deviation
				HUNDRED THOUSANDS: Paraxial calibration or at an angle 0 = Paraxial calibration in the active WCS 1 = Calibration at an angle ⁷⁾
				ONE MILLION: Determination of tool length during calibration on surface or on sphere 0 = tool length is not determined 1 = tool length is determined ⁴⁾ 2 = infeed axis is calibrated at the sphere, the tool length is determined, the tool length measured difference is entered in the calibration data
2	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)	
3		S_SETV	Setpoint	
4	Z0	S_SETV0	Setpoint of the length for sphere calibration	
5	X / Y / Z	S_MA	Measuring axis (number of the axis) ^{2), 6)} (default=1)	
			Val- ues:	1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y) 3 = 3rd axis of the plane (for G17 Z)

No.	Screen form parameters	Cycle parameters	Meaning
6	+-	S_MD	Measuring direction ^{2), 6)}
			Val-ues: 0 = Positive 1 = Negative
7	DFA	S_FA	Measurement path
8	TSA	S_TSA	Safe area
9	VMS	S_VMS	Variable measuring velocity for calibration ²⁾
10	α	S_STA1	Starting angle ^{2), 5)}
11	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (default=1)
12	X0	S_SETV1	Edge reference point when calibrating between 2 edges ³⁾
13		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
14		_AMODE	Alternative mode

1) All default values = 0 or marked as default=x

2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE

3) For "Radius in the calibration ring" calibration, the diameter and the center point of the ring must be known (four measuring directions).

For "Radius on two edges" calibration, the distance to the edges in the direction of the measuring axis must be known (two measuring directions).

For "Radius on one edge" calibration, the setpoint of the surface must be known.

4) Measuring variant only calibration on a surface (length on surface), corrected tool length results from S_MD and S_MA.

5) Only for measuring variant "Calibration ring, ... and known center point" (S_MVAR=1xxx02).

6) Measuring axis only for measuring variant S_MVAR=0 or =xx1x01 or =xx2x01 or =20000

Measuring variant: "Calibration on a surface" → selection of measuring axis and measuring direction

or on the "Calibration ring, ... and known center point" → selection of an axis direction and selection of measuring axis and measuring direction

or on the "Calibration ring, ... and known center point" → selection of two axis directions and selection of measuring axis or "Determination of the probe length" → S_MA=3 → 3rd axis of the plane (for G17 Z)

7) Measuring version, only calibration in calibration ring or on calibration sphere

For "Calibration on calibration sphere", for measuring at an angle, the axis circles around the sphere at the equator.

8) For "Radius in calibration ring" calibration with unknown center point, four measuring directions in the plane (for G17 +-X +-Y).

For "Length on surface" calibration in minus direction of the tool axis (for G17 -Z).

3.23.2.5 CYCLE978 measuring cycle parameters

```
PROC CYCLE978 (INT S_MVAR, INT S_KNUM, INT S_KNUM1, INT S_PRNUM, REAL S_SETV, REAL S_FA, REAL
S_TSA, INT S_MA, INT S_MD, INT S_NMSP, STRING[32] S_TNAME, INT S_DLNUM, REAL S_TZL, REAL
S_TDIF, REAL S_TUL, REAL S_TLL, REAL S_TMV, INT S_K, INT S_EVNUM, INT S_MCBIT, INT _DMODE, INT
_AMODE, INT _DP)
```

Table 3-12 CYCLE978 call parameters ¹⁾

No.	Screen form parameter	Cycle parameter	Meaning	
1		S_MVAR	Measuring variant	
			Val- ues:	UNITS: Contour element 0 = Measure surface
				TENS: Reserved
				HUNDREDS: Correction target 0 = Only measurement (no correction of the WO or no tool offset) 1 = Measurement, determination and correction of the WO (see S_KNUM) 2 = Measurement and tool offset (see S_KNUM1)
				THOUSANDS: Reserved
				TEN THOUSANDS: Measurement with/without spindle reversal or align probe in the switching direction ⁹⁾ 0 = Measurement without spindle reversal, without probe alignment 1 = Measurement with spindle reversal 2 = Align probe in switching direction
2	Selection	S_KNUM	Correction of work offset (WO) or basic WO or basic reference ²⁾	
			Val- ues:	UNITS:
				TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
				HUNDREDS: Reserved
				THOUSANDS: Correction of WO or basic or basic reference 0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 3 = Correction of the global basic WO 9 = Correction of the active WO or for G500 in last active channel-specific basic WO
				TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference 0 = Fine correction ⁶⁾ 1 = Coarse correction

No.	Screen form parameter	Cycle parameter	Meaning	
3	Selection	S_KNUM1	Correction in tool offset ²⁾	
			Val- ues:	UNITS:
				TENS:
				HUNDREDS: 0 = No correction 1 to max. 999 D numbers (cutting edge numbers) for tool offset, for additive and setup offset, see also S_DLNUM
				THOUSANDS: 0 or unique D numbers
				TEN THOUSANDS: 0 or unique D numbers 1 to max. 32000 if unique D numbers in MDs have been set up
				HUNDRED THOUSANDS: Tool offset ²⁾ 0 = No specification (offset in tool geometry) 1 = Offset of length L1 2 = Offset of length L2 3 = Offset of length L3 4 = Radius offset
				ONE MILLION: Tool offset ²⁾ 0 = No specification (offset of the tool radius wear) 1 = Tool offset, additive offset (AO) ⁵⁾ Tool offset value is added to the existing AO 2 = Tool offset, setup offset (SO) ⁵⁾ SO (new) = SO (old) + AO (old) offset value, AO (new) = 0 3 = Tool offset, setup offset (SO) ⁵⁾ Tool offset value is added to the existing SO 4 = Tool offset, geometry
				TEN MILLION: Tool offset ²⁾ 0 = No specification (offset in tool geometry normal, not inverted) 1 = Offset inverted
				HUNDRED MILLIONS: Tool offset 0 = tool offset without replacement tools 1 = tool offset in replacement tool (_DP)
4	Icon+number	S_PRNUM		Number of the field of the probe parameters (not probe number) (value range 1 to 40)
5	X0	S_SETV	Setpoint	
6	DFA	S_FA	Measurement path	
7	TSA	S_TSA	Safe area	
8	X	S_MA	Number of the measuring axis ⁷⁾ (value range 1 to 3)	
			Val- ues: 1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y) 3 = 3rd axis of the plane (for G17 Z) measurement in tool direction	
9		S_MD	Measuring direction of the measuring axis	
			Val- ues: 1 = Positive measuring direction 2 = Negative measuring direction	
10	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (value range 1 to 9)	
11	TR	S_TNAME	Tool name ³⁾	

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
12	DL	S_DLNUM	Setup additive offset DL number ⁵⁾
13	ST	_DP	Number of the replacement tool (duplo number) to be corrected
14	TZL	S_TZL	Work offset ^{2), 3)}
15	DIF	S_TDIF	Dimensional difference check ^{2), 3)}
16	TUL	S_TUL	Upper tolerance limit (incremental to the setpoint) ³⁾
17	TLL	S_TLL	Lower tolerance limit (incremental to the setpoint) ³⁾
18	TMV	S_TMV	Offset range for averaging ²⁾
19	FW	S_K	Weighting factor for averaging ²⁾
20	EVN	S_EVNUM	Date set, empirical value memory ^{2), 8)}
21		S_MCBIT	Reserved
22		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
23		_AMODE	Alternative mode
			Val-ues: UNITS: Dimensional tolerance yes/no 0 = No 1 = Yes

- 1) All default values = 0 or marked as the range of values a to b
- 2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 3) Only for offset in tool, otherwise parameter = ""
- 4) Only for offset in tool and dimensional tolerance "Yes", otherwise parameter = 0
- 5) Only if the "Setup additive offset" function has been set-up in the general MD 18108 \$MN_MM_NUM_SUMCORR . In addition, in the general MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK , bit8 must be set to 1.
- 6) If WO "fine" has not been set up in MDs, correction is according to WO "coarse"
- 7) Offset in tool geometry:
For measurement in the plane (S_MA=1 or S_MA=2) Offset in tool radius
For measurement in tool direction (S_MA=3) Offset in tool length L1
- 8) Empirical averaging for tool offset and correction in WO possible
Value range for empirical mean value memory:
1 to 20 numbers (n) of the empirical value memory, see channel-specific SD 55623 \$SCS_MEA_EMPIRIC_VALUE[n-1]
10000 to 200000 numbers (n) of the mean value memory, see channel-specific SD 55625 \$SCS_MEA_AVERAGE_VALUE[n-1]
- 9) When measuring with spindle reversal, the radius/diameter of the probe must be precisely determined. This should be realized with a calibration variant of the CYCLE976 radius at the ring or at the edge or at the sphere. Otherwise, the measurement result will be falsified.

3.23.2.6 CYCLE998 measuring cycle parameters

```
PROC CYCLE998 (INT S_MVAR, INT S_KNUM, INT S_RA, INT S_PRNUM, REAL S_SETV, REAL S_STA1, REAL
S_INCA, REAL S_FA, REAL S_TSA, INT S_MA, INT S_MD, REAL S_ID, REAL S_SETV0, REAL S_SETV1, REAL
S_SETV2, REAL S_SETV3, INT S_NMSP, INT S_EVNUM, INT _DMODE, INT _AMODE)
```


Table 3-13 CYCLE998 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring variant (default=5)	
			Val- ues:	UNITS: Contour element 5 = Measure edge (one angle) 6 = Measure plane (two angles)
			TENS:	Reserved
			HUNDREDS:	Correction target 0 = Only measurement and no correction of WO 1 = Measurement and determination and correction of the WO (see S_KNUM)
			THOUSANDS:	Protection zone 0 = No consideration of a protection zone 1 = Consideration of a protection zone
			TEN THOUSANDS:	Measurement with spindle reversal (difference measurement) 0 = Measurement without spindle reversal 1 = Measurement with spindle reversal
			HUNDRED THOUSANDS:	Measurement at an angle or paraxial 0 = Measurement at an angle 1 = Measurement paraxial
2	Selection	S_KNUM	Correction of work offset (WO) or basic WO or basic reference ²⁾	
			Val- ues:	UNITS: TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
			HUNDREDS:	Reserved
			THOUSANDS:	Correction of WO or basic or basic reference 0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 9 = Correction of the active WO or for G500 in last active channel-specific basic WO
			TEN THOUSANDS:	Coarse or fine correction in the WO or basic WO or basic reference ³⁾ 0 = Fine correction 1 = Coarse correction
3	A, B, C	S_RA	Correction target coordinate rotation or rotary axis	
			Val- ues:	0 = Correction target coordinate rotation around the axis that results from parameter S_MA ⁴⁾ >0 = Correction target rotary axis. Number of the channel axis number of the rotary axis (preferably rotary table). The angular offset is made in the translatory part of the WO of the rotary axis.
4	Icon+ number	S_PRNUM	Number of the field of the probe parameter (default=1)	
5	DX / DY / DZ	S_SETV	Distance (incremental) from the starting position to measuring point P1 of the measuring axis (S_MA) ⁵⁾	

3.23 Programming cycles externally

No	Screen form parameters	Cycle parameters	Meaning
6	α	S_STAL	Angle setpoint for "Align edge" or for "Align plane" around the 1st axis of the plane (for G17 X) ⁹⁾
7	β	S_INCA	Angle setpoint for "Align plane" around the 2nd axis of the plane (for G17 Y) ⁹⁾
8	DFA	S_FA	Measurement path
9	TSA	S_TSA	Safe area Monitoring of the angle difference to the angle setpoint [degrees] ⁶⁾
10	X / Y / Z	S_MA	Measuring axis, offset axis ⁷⁾ (default=201)
			Val-ues: UNITS: Number of the measuring axis 1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y) 3 = 3rd axis of the plane (for G17 Z)
			TENS: Reserved
			HUNDREDS: Number of the offset axis 1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y) 3 = 3rd axis of the plane (for G17 Z)
11	+-	S_MD	Measuring direction of the measuring axis ⁸⁾
			Val-ues: 0 = Measuring direction is determined from the setpoint and the actual position of the measuring axis (compatibility) 1 = Positive measuring direction 2 = Negative measuring direction
12	L2	S_ID	For measuring variant "Align edge": Distance (incremental) between the measuring points P1 and P2 in the offset axis (value >0) For measuring variant "Align plane", the parameters listed below apply.
13	L2	S_SETV0	Distance between the measuring points P1 and P2 in the 1st axis of the plane ¹⁰⁾
14		S_SETV1	Distance between the measuring points P1 and P2 in the 2nd axis of the plane ^{11), 12)}
15	L3x	S_SETV2	Distance between the measuring points P1 and P3 in the 1st axis of the plane ¹¹⁾
16	L3y	S_SETV3	Distance between the measuring points P1 and P3 in the 2nd axis of the plane ¹⁰⁾
17	Measure-ments	S_NMSP	Number of measurements at the same location ²⁾ (default=1)
18		S_EVNUM	Date set, empirical value memory ^{2), 13)}
19		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
20		_AMODE	Reserved (alternative mode)

¹⁾ All default values = 0 or marked as default=x

²⁾ Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE

³⁾ WO "fine" only if correction target is rotary axis and MD 52207 \$MCS_AXIS_USAGE_ATTRIB[n] Bit6=1.
If WO has not been set up in MDs, correction is according to WO "coarse".

⁴⁾ Example for offset in coordinate rotation: S_MA=102 Measuring axis Y, offset axis X results in coordinate rotation around Z (for G17)

⁵⁾ Value only relevant for protection zone "Yes" (S_MVAR THOUSANDS position = 1)

- 6) When positioning from measuring point P1 to measuring point P2 in the offset axis, the angles in parameters `S_STA1` and `S_TSA` are added.
- 7) Number of the measuring axis must not be the same as the number of the offset axis (e.g. 101 not permitted)
- 8) Measuring direction only for "Align edge" and "Measurement paraxial" (`S_MVAR=10x105`)
- 9) Angular range `S_STA1` ± 45 degrees for "Align edge"
Angular range `S_STA1` 0 to $+60$ degrees and `S_INCA` ± 30 degrees for "Align plane"
- 10) For measuring variants "Align plane" and "Align edge"
- 11) For measuring variants "Measure plane" and "Measurement paraxial"
- 12) Not for measuring cycle version SW04.04.
- 13) Empirical value generation for correction in WO; value range of the empirical mean value memory:
1 to 20 numbers of the empirical value memory, see channel-specific SD 55623 `$SCS_MEA_EMPIRIC_VALUE[n-1]`

3.23.2.7 CYCLE977 measuring cycle parameters

```
PROC CYCLE977 (INT S_MVAR, INT S_KNUM, INT S_KNUM1, INT S_PRNUM, REAL S_SETV, REAL S_SETV0, REAL
S_SETV1, REAL S_FA, REAL S_TSA, REAL S_STA1, REAL S_ID, REAL S_SZA, REAL S_SZO, INT S_MA, INT
S_NMSP, STRING[32] S_TNAME, INT S_DLNUM, REAL S_TZL, REAL S_TDIF, REAL S_TUL, REAL S_TLL, REAL
S_TMV, INT S_K, INT S_EVNUM, INT S_MCBIT, INT _DMODE, INT _AMODE, REAL S_XM, REAL S_YM, INT _DP)
```

Table 3-14 CYCLE977 call parameters ¹⁾

No.	Screen form parameter	Cycle parameter	Meaning
1		<code>S_MVAR</code>	<p>Measuring variant</p> <p>Val- ues:</p> <p>UNITS: Contour element (value range 1 to 6)</p> <p>1 = Measure hole 2 = Measure spigot (shaft) 3 = Measure groove 4 = Measure rib 5 = Measure rectangle, inside 6 = Measure rectangle, outside</p> <p>TENS: Reserved</p> <p>HUNDREDS: Correction target</p> <p>0 = Only measurement (no correction of the WO or no tool offset) 1 = Measurement and determination and correction of the WO (see <code>S_KNUM</code>) 2 = Measurement and tool offset (see <code>S_KNUM1</code>)</p> <p>THOUSANDS: Protection zone</p> <p>0 = No consideration of a protection zone 1 = Consideration of a protection zone</p> <p>TEN THOUSANDS: Measurement with/without spindle reversal (differential measurement) or align probe in the switching direction</p> <p>0 = Measurement without spindle reversal, do not align probe 1 = Measurement with spindle reversal 2 = Align probe in switching direction</p>

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
2	Selection	S_KNUM	<p>Correction of work offset (WO) or basic WO or basic reference ²⁾</p> <p>Val-ues:</p> <p>UNITS:</p> <p>TENS:</p> <p>0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset</p> <p>HUNDREDS: Reserved</p> <p>THOUSANDS: Correction of WO or basic or basic reference</p> <p>0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 3 = Correction of the global basic WO 9 = Correction of the active WO or for G500 in last active channel-specific basic WO</p> <p>TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference</p> <p>0 = Fine correction ⁶⁾ 1 = Coarse correction</p>

No.	Screen form parameter	Cycle parameter	Meaning	
3	Selection	S_KNUM1	Correction in tool offset ²⁾	
			Val- ues:	UNITS:
				TENS:
				HUNDREDS: 0 = No correction 1 to max. 999 D numbers (cutting edge numbers) for tool offset; for additive and setup offset, see also S_DLNUM
				THOUSANDS: 0 or unique D numbers
				TEN THOUSANDS: 0 or unique D numbers 1 to max. 32000 if unique D numbers in MDs have been set up
				HUNDRED THOUSANDS: Tool offset ²⁾ 0 = No specification (offset tool radius) 1 = Offset of length L1 2 = Offset of length L2 3 = Offset of length L3 4 = Radius offset
				ONE MILLION: Tool offset ²⁾ 0 = No specification (offset of the tool radius wear) 1 = Tool offset, additive offset (AO) ⁵⁾ Tool offset value is added to the existing AO 2 = Tool offset, setup offset (SO) ⁵⁾ SO (new) = SO (old) + AO (old) offset value, AO (new) = 0 3 = Tool offset, setup offset (SO) ⁵⁾ Tool offset value is added to the existing SO 4 = Tool offset, geometry
				TEN MILLION: Tool offset ²⁾ 0 = No specification (offset in tool geometry normal, not inverted) 1 = Offset inverted
				HUNDRED MILLIONS: Tool offset 0 = tool offset without replacement tools 1 = tool offset in replacement tool (_DP)
4	Icon+ number	S_PRNUM		Number of the field of the probe parameters (not probe number) (value range 1 to 40)
5	X0	S_SETV	Setpoint	
6	X0	S_SETV0	Setpoint for rectangle in 1st axis of the plane (X for G17)	
7	Y0	S_SETV1	Setpoint for rectangle in 2nd axis of the plane (Y for G17)	
8	XM	S_XM	Setpoint center point input geometry axis X	
9	YM	S_YM	Setpoint center point input geometry axis Y	
10	DFA	S_FA	Measurement path	
11	TSA	S_TSA	Safe area	
12	α 0	S_STA1	Starting angle	

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
13	DZ	S_ID	Absolute incremental value 1. Incremental infeed of the 3rd axis of the plane (Z for G17) Infeed direction via sign of S_ID. For measurement of spigot, rib and rectangle outside, S_ID is used to define the lowering to measuring height. 2. Consideration of a protection zone For measurement of hole, groove and rectangle inside and a protection zone, S_ID is used to define the overtravel height.
14	X1	S_SZA	Diameter or length (width) of the protection zone ⁷⁾
15	Y1	S_SZO	For "Measure rectangle": Width of the protection zone of the 2nd axis of the plane
16	X	S_MA	Number of the measuring axis ⁷⁾ (only for measurement of groove or rib) Val-ues: 1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y)
17	ST	_DP	Number of the replacement tool (duplo number) to be corrected
18	Measure-ments	S_NMSP	Number of measurements at the same location ²⁾ (value range 1 to 9)
19	TR	S_TNAME	Tool name ²⁾
20	DL	S_DLNUM	Setup additive offset DL number ⁵⁾
21	TZL	S_TZL	Work offset ^{2), 4)}
22	DIF	S_TDIF	Dimensional difference check ^{2), 4)}
23	TUL	S_TUL	Upper tolerance limit (incremental to the setpoint) ⁴⁾
24	TLL	S_TLL	Lower tolerance limit (incremental to the setpoint) ⁴⁾
25	TMV	S_TMV	Offset range for averaging ²⁾
26	FW	S_K	Weighting factor for averaging ²⁾
27		S_EVNUM	Data set, empirical mean value memory ^{2), 8)}
28		S_MCBIT	Reserved
29		_DMODE	Display mode Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
30		_AMODE	Alternative mode Val-ues: UNITS: Dimensional tolerance yes/no 0 = No 1 = Yes

- 1) All default values = 0 or marked as the range of values a to b
- 2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 3) Only for offset in tool, otherwise parameter = ""
- 4) Only for offset in tool and dimensional tolerance "Yes", otherwise parameter = 0
- 5) Only if the "Setup additive offset" function has been set-up in the general MD 18108 \$MN_MM_NUM_SUMCORR . In addition, in the general MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK , bit8 must be set to 1.
- 6) If WO "fine" has not been set up in MDs, correction is according to WO "coarse"

- 7) Diameter or width of the protection zone within a hole or groove
Diameter or width of the protection zone outside of a spigot or rib
- 8) Empirical averaging possible for tool offset
Value range for empirical mean value memory:
1 to 20 numbers (n) of the empirical value memory, see channel-specific SD 55623 \$SCS_MEA_EMPIRIC_VALUE[n-1]
10000 to 200000 numbers (n) of the mean value memory, see channel-specific SD 55625
\$SCS_MEA_AVERAGE_VALUE[n-1]

3.23.2.8 CYCLE961 measuring cycle parameters

```
PROC CYCLE961 (INT S_MVAR, INT S_KNUM, INT S_PRNUM, REAL S_SETV0, REAL S_SETV1, REAL
S_SETV2, REAL S_SETV3, REAL S_SETV4, REAL S_SETV5, REAL S_SETV6, REAL S_SETV7, REAL S_SETV8, REAL
S_SETV9, REAL S_STA1, REAL S_INCA, REAL S_ID, REAL S_FA, REAL S_TSA, INT S_NMSP, INT S_MCBIT, INT
_DMODE, INT _AMODE)
```

Table 3-15 CYCLE961 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning
1		S_MVAR	<p>Measuring variant (default ≥ 6)</p> <p>Values:</p> <p>UNITS: Contour element</p> <p>5 = Setup of right-angled inside corner, setpoint specification of angle and distances A1 to A3</p> <p>6 = Setup of right-angled outside corner, setpoint specification of angle and distances A1 to A3</p> <p>7 = Setup of inside corner, specification of angle and distances A1 to A4</p> <p>8 = Setup of outside corner, specification of angle and distances A1 to A4</p> <p>TENS: Setpoint specification as distance or via four points</p> <p>0 = Setpoint specification as distance (polar)</p> <p>1 = Setpoint specification using four points (measuring points P1 to P4)</p> <p>HUNDREDS: Correction target</p> <p>0 = Only measurement (no correction of the WO or no tool offset)</p> <p>1 = Measurement and determination and correction of the WO, see S_KNUM</p> <p>THOUSANDS: Protection zone</p> <p>0 = No consideration of a protection zone (obstacle)</p> <p>1 = Consideration of a protection zone (obstacle), see S_ID</p> <p>TEN THOUSANDS: Position of the corner in the WCS</p> <p>0 = Position of the corner is determined via parameter S_STA1 (compatibility)</p> <p>1 = Position 1 of the corner in the positioned starting point of the measurement ⁶⁾</p> <p>2 = Position 2 of the corner, distances in the 1st axis of the plane (for G17 X) are negative (see S_SETV0, S_SETV1)</p> <p>3 = Position 3 of the corner, distances in the 1st and 2nd axis of the plane (for G17 XY) are negative (see S_SETV0 to S_SETV3)</p> <p>4 = Position 4 of the corner, distances in the 2nd axis of the plane (for G17 Y) are negative (see S_SETV2, S_SETV3)</p>

3.23 Programming cycles externally

No.	Screen form parameters	Cycle parameters	Meaning	
2	Selection	S_KNUM	Correction of work offset (WO) or basic WO or basic reference ²⁾	
			Val- ues:	UNITS:
				TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
				HUNDREDS: Reserved
				THOUSANDS: Correction of WO or basic or basic reference 0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 9 = Correction of the active WO or for G500 in last active channel-specific basic WO
				TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference 0 = Fine correction ⁵⁾ 1 = Coarse correction
3	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (value range 1 to 40)	
4	L1/X1	S_SETV0	Distance L1 between the pole and measuring point P1 in the direction of the 1st axis of the plane (for G17 X) ³⁾ (if the actual distance L1=0, then L1 = M_SETV1 / 2 is automatically calculated) or starting point P1x of the 1st axis of the plane (for G17 X) ⁴⁾	
5	L2/Y1	S_SETV1	Distance L2 between the pole and measuring point P2 in the direction of the 1st axis of the plane ³⁾ or starting point P1y of the 2nd axis of the plane (for G17 Y) ⁴⁾	
6	L3/X2	S_SETV2	Distance L3 between the pole and measuring point P3 in the direction of the 2nd axis of the plane ³⁾ (if the distance L3=0, then for a corner that is not right angled, L3 = M_SETV3 / 2 is automatically calculated) or starting point P2x of the 1st axis of the plane ⁴⁾	
7	L4/Y2	S_SETV3	Distance L4 between the pole and measuring point P3 in the direction of the 2nd axis of the plane with a corner that is not right angled ³⁾ or starting point P2y of the 2nd axis of the plane ⁴⁾	
8	XP/X3	S_SETV4	Position of the pole in the 1st axis of the plane ³⁾ or starting point P3x of the 1st axis of the plane ⁴⁾	
9	XP/Y3	S_SETV5	Position of the pole in the 2nd axis of the plane ³⁾ or starting point P3y of the 2nd axis of the plane ⁴⁾	
10	X4	S_SETV6	Starting point P4x of the 1st axis of the plane ⁴⁾	
11	Y4	S_SETV7	Starting point P4y of the 2nd axis of the plane ⁴⁾	
12	X0	S_SETV8	Setpoint of the measured corner in the 1st axis of the plane for correcting in WO	
13	Y0	S_SETV9	Setpoint of the measured corner in the 2nd axis of the plane for correcting in WO	
14	α0	S_STA1	Starting angle from the positive direction of the 1st axis of the plane to the reference edge of the workpiece in the MCS (+-270 degrees)	
15	α1	S_INCA	Angle between workpiece reference edges when measuring a non-right-angled corner ⁷⁾	
16	DZ	S_ID	Infeed amount at the measuring height for each measuring point for active protection zone (see S_MVAR).	

No .	Screen form parameters	Cycle parameters	Meaning
17	DFA	S_FA	Measurement path
18	TSA	S_TSA	Safe area Monitoring the angular difference to the angle setpoint [degrees]
19	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (value range 1 to 9) ²⁾
20		S_MCBIT	Reserved
21		_DMODE	Display mode Val-ues: UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
22		_AMODE	Alternative mode

1) All default values = 0 or marked as the range of values a to b

2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE

3)) Input of the measuring points in polar coordinates, taking into account the starting angle S_STA1 for measuring point 3 or 4 of the incremental angle S_INCA .

4) Input of the measuring points in the right-angled coordinate system (input using 4 points),

5) If WO "fine" has not been set up in MDs, correction is according to WO "coarse".

6) Value range of angle S_INCA: -180 to +180 degrees

7) Starting angle S_STA1, value range: right-angled corner: +- 90 degrees, any corner: +- 45 degrees

3.23.2.9 CYCLE979 measuring cycle parameters

```
PROC CYCLE979 (INT S_MVAR, INT S_KNUM, INT S_KNUM1, INT S_PRNUM, REAL S_SETV, REAL S_FA, REAL
S_TSA, REAL S_CPA, REAL S_CPO, REAL S_STA1, REAL S_INCA, INT S_NMSP, STRING[32] S_TNAME, REAL
S_DLNUM, REAL S_TZL, REAL S_TDIF, REAL S_TUL, REAL S_TLL, REAL S_TMV, INT S_K, INT S_EVNUM, INT
S_MCBIT, INT _DMODE, INT _AMODE, REAL S_XM, REAL S_YM, INT _DP)
```

3.23 Programming cycles externally

Table 3-16 CYCLE979 call parameters ⁰⁾

No.	Screen form parameter	Cycle parameter	Meaning	
1		S_MVAR	Measuring variant	
			Val-ues:	UNITS: Contour element 1 = Measure hole 2 = Measure spigot (shaft)
				TENS: Reserved
				HUNDREDS: Correction target 0 = Only measurement (no correction of the WO or no tool offset) 1 = Measurement and determination and correction of the WO (see S_KNUM) 2 = Measurement and tool offset (see S_KNUM1)
				THOUSANDS: Number of measurement points 0 = 3 measuring points 1 = 4 measuring points
				TEN THOUSANDS: Measurement with/without spindle reversal (differential measurement) or align probe in the switching direction 0 = Measurement without spindle reversal, without probe alignment 1 = Measurement with spindle reversal 2 = Align probe in switching direction
2	Selection	S_KNUM	Correction of work offset (WO) or basic WO or basic reference ²⁾	
			Val-ues:	UNITS:
				TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
				HUNDREDS: Reserved
				THOUSANDS: Correction of WO or basic or basic reference 0 = Correction of the adjustable WO 1 = Correction of the channel-specific basic WO 2 = Correction of the basic reference 3 = Correction of the global basic WO 9 = Correction of the active WO or for G500 in last active channel-specific basic WO
				TEN THOUSANDS: Coarse or fine correction in the WO, basic WO or basic reference 0 = Fine correction ⁶⁾ 1 = Coarse correction

No.	Screen form parameter	Cycle parameter	Meaning
3	Selection	S_KNUM1	Correction in tool offset ²⁾
			Val- ues:
			UNITS:
			TENS:
			HUNDREDS: 0 = No correction 1 to max. 999 D numbers (cutting edge numbers) for tool offset; for additive and setup offset, see also S_DLNUM
			THOUSANDS: 0 or unique D numbers
			TEN THOUSANDS: 0 or unique D numbers 1 to max. 32000 if unique D numbers in MDs have been set up
			HUNDRED THOUSANDS: Tool offset ²⁾ 0 = No specification (offset in tool radius) 1 = Offset of length L1 2 = Offset of length L2 3 = Offset of length L3 4 = Radius offset
			ONE MILLION: Tool offset ²⁾ 0 = No specification (offset of the tool radius wear) 1 = Tool offset, additive offset (AO) ⁵⁾ Tool offset value is added to the existing AO 2 = Tool offset, setup offset (SO) ⁵⁾ SO (new) = SO (old) + AO (old) offset value, AO (new) = 0 3 = Tool offset, setup offset (SO) ⁵⁾ Tool offset value is added to the existing SO 4 = Tool offset, geometry
			TEN MILLION: Tool offset ²⁾ 0 = No specification (offset in tool geometry normal, not inverted) 1 = Offset inverted
HUNDRED MILLIONS: Tool offset 0 = tool offset without replacement tools 1 = tool offset in replacement tool (_DP)			
4	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (value range 1 to 40)
5	X0	S_SETV	Setpoint
6	DFA	S_FA	Measurement path
7	TSA	S_TSA	Safe area
8	X0	S_CPA	Center point of the 1st axis of the plane (for G17 X)
9	Y0	S_CPO	Center point of the 2nd axis of the plane (for G17 Y)
10	XM	S_XM	Setpoint center point input geometry axis X
11	YM	S_YM	Setpoint center point input geometry axis Y
12	alpha 0	S_STA1	Starting angle ⁷⁾
13	Alpha 1	S_INCA	Incremental angle ⁸⁾
14	Measure- ments	S_NMSP	Number of measurements at the same location ¹⁾ (value range 1 to 9)
15	ST	_DP	Number of the replacement tool (duplo number) to be corrected

3.23 Programming cycles externally

No.	Screen form parameter	Cycle parameter	Meaning
16	T	S_TNAME	Tool name ²⁾
17	DL	S_DLNUM	Setup additive offset DL number ^{1), 4)}
18	TZL	S_TZL	Work offset ^{1), 2)}
19	DIF	S_TDIF	Dimensional difference check ^{1), 2)}
20	TUL	S_TUL	Upper tolerance limit (incremental to the setpoint) ²⁾
21	TLL	S_TLL	Lower tolerance limit (incremental to the setpoint) ²⁾
22	TMV	S_TMV	Offset range for averaging ¹⁾
23	FW	S_K	Weighting factor for averaging ¹⁾
24		S_EVNUM	Date set, empirical value memory ^{1), 6)}
25		S_MCBIT	Reserved
26		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
27		_AMODE	Alternative mode
			Val-ues: UNITS: Dimensional tolerance yes/no 0 = No 1 = Yes

- 0) All default values = 0 or marked as the range of values a to b
- 1) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 2) Only for offset in tool, otherwise parameter = ""
- 3) Only for offset in tool and dimensional tolerance "Yes", otherwise parameter = 0
- 4) Only if the "Setup additive offset" function has been set-up in the general MD 18108 \$MN_MM_NUM_SUMCORR .
- 5) If WO "fine" has not been set up in MDs, correction is according to WO "coarse".
- 6) Empirical averaging only possible for tool offset
 Value range for empirical mean value memory:
 1 to 20 numbers (n) of the empirical value memory, see channel-specific SD 55623 \$SCS_MEA_EMPIRIC_VALUE[n-1]
 10000 to 200000 numbers (n) of the mean value memory, see channel-specific SD 55625 \$SCS_MEA_AVERAGE_VALUE[n-1]
- 7) Value range of starting angle -360 to +360 degrees
- 8) Value range of incremental angle >0 to ≤90 degrees for four measuring points or >0 to ≤120 degrees for three measuring points.

3.23.2.10 CYCLE997 measuring cycle parameters

```
PROC CYCLE997 (INT S_MVAR,INT S_KNUM,INT S_PNUM,REAL S_SETV,REAL S_FA,REAL S_TSA,REAL
S_STA1,REAL S_INCA,REAL S_SETV0,REAL S_SETV1,REAL S_SETV2,REAL S_SETV3,REAL S_SETV4,REAL
S_SETV5,REAL S_SETV6,REAL S_SETV7,REAL S_SETV8,REAL S_TNVL,INT S_NMSP,INT S_MCBIT,INT
_DMODE,INT _AMODE)
```

Table 3-17 CYCLE997 call parameters ^{1), 2)}

No.	Screen form parameters	Cycle parameters	Meaning
1		S_MVAR	<p>Measuring variant (default =9)</p> <p>Val-ues:</p> <p>UNITS: Contour element 9 = Measure sphere</p> <p>TENS: Repeat measurement 0 = Without measurement repetition 1 = With measurement repetition</p> <p>HUNDREDS: Correction target 0 = Only measurement (no correction of WO) 1 = Measurement and determination and correction of the WO (see S_KNUM)</p> <p>THOUSANDS: Measuring strategy 0 = Paraxial measurement, without starting angle, probe alignment corresponding to SD55740, bit 1 1 = Circling measurement, with starting angle, probe alignment corresponding to SD55740, Bit 1 2 = Circling measurement, with starting angle, align probe in the switching direction 3 = Paraxial measurement, with starting angle, probe alignment corresponding to SD55740, bit 1 4 = Paraxial measurement, with starting angle, align probe in the switching direction</p> <p>TEN THOUSANDS: Number of spheres to be measured 0 = Measure one sphere 1 = Measure three spheres</p> <p>HUNDRED THOUSANDS: Number of measuring points, only for measurement at an angle (note measuring strategy: THOUSANDS position > 0) 0 = Three measuring points for measurement at an angle (traversing around the sphere) 1 = Four measuring points for measurement at an angle (traversing around the sphere)</p> <p>ONE MILLION: Determination of the diameter setpoint of the sphere 0 = No determination of the diameter setpoint of the sphere 1 = Determination of the diameter setpoint of the sphere</p>

3.23 Programming cycles externally

No.	Screen form parameters	Cycle parameters	Meaning
2	Selection	S_KNUM	Correction in work offset (WO) or basic or basic reference ³⁾
			Val-ues:
			UNITS:
			TENS: 0 = No correction 1 to max. 99 numbers of the work offset or 1 to max. 16 numbers of the basic offset
			HUNDREDS: Reserved
			THOUSANDS: Correction in WO or basic WO or basic reference 0 = Correction in adjustable WO 1 = Correction in channel-specific basic WO 2 = Correction in basic reference 3 = Correction in global basic WO ⁷⁾ 9 = Correction in active WO or for G500 in last active channel-specific basic WO
TEN THOUSANDS: Correction in WO or basic WO or basic reference coarse or fine 0 = Fine correction ⁶⁾ 1 = Coarse correction			
3	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (value range 1 to 40)
4		S_SETV	Diameter of the sphere(s) ⁴⁾
5	DFA	S_FA	Measurement path
6	TSA	S_TSA	Safe area
7	Alpha 0	S_STA1	Starting angle for measurement at an angle
8	Alpha 1	S_INCA	Incremental angle for measurement at an angle
9	X1	S_SETV0	Position setpoint of the 1st sphere of the 1st axis of the plane (for G17 X) for 3 sphere measurement
10	Y1	S_SETV1	Position setpoint of the 1st sphere of the 2nd axis of the plane (for G17 Y) for 3 sphere measurement
11	Z1	S_SETV2	Position setpoint of the 1st sphere of the 3rd axis of the plane (for G17 Z) for 3 sphere measurement
12	X2	S_SETV3	Position setpoint of the 2nd sphere of the 1st axis of the plane for 3 sphere measurement
13	Y2	S_SETV4	Position setpoint of the 2nd sphere of the 2nd axis of the plane for 3 sphere measurement
14	Z2	S_SETV5	Position setpoint of the 2nd sphere of the 3rd axis of the plane for 3 sphere measurement
15	X3	S_SETV6	Position setpoint of the 3rd sphere of the 1st axis of the plane for 3 sphere measurement
16	Y3	S_SETV7	Position setpoint of the 3rd sphere of the 2nd axis of the plane for 3 sphere measurement
17	Z3	S_SETV8	Position setpoint of the 3rd sphere of the 3rd axis of the plane for 3 sphere measurement
18	TVL	S_TNVL	Limit value for distortion of the triangle (sum of the deviations) for 3 sphere measurement ⁵⁾
19	Measure-ments	S_NMSP	Number of measurements at the same location ²⁾ (value range 1 to 9)
20		S_MCBIT	Reserved

No.	Screen form parameters	Cycle parameters	Meaning
21		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
22		_AMODE	Alternative mode

- 1) All default values = 0 or marked as the range of values a to b
- 2) Display depends on the general SD 54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 3) Intermediate positioning, circling around the sphere at the equator
- 4) 3 sphere measurement: The same diameter setpoint applies for all three spheres (_SETV)
- 5) Default value for S_TNVL=1.2
Correction in WO: Correction is only performed in the WO when the determined distortion is below the S_TNVL limit value.
- 6) If WO "fine" has not been set up in MDs, correction is according to WO "coarse"
- 7) For measuring variant "Measure three spheres", correction in a global basic frame is not possible (S_KNUM = 3001 to 3016), as the frame does not have a rotation component.

3.23.2.11 CYCLE995 measuring cycle parameters

```
PROC CYCLE995 (INT S_MVAR,INT S_KNUM,INT S_PRNUM,REAL S_SETV,REAL S_FA,REAL S_TSA,REAL
S_STAL,REAL S_INCA,REAL S_DZ,REAL S_SETV0,REAL S_SETV1,REAL S_SETV2,REAL S_TUL,REAL
S_TZL,INT S_NMSP,INT S_MCBIT,INT _DMODE,INT _AMODE)
```

Table 3-18 CYCLE995 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring variant (default=5)	
			Val- ues:	UNITS: Contour element 5 = Spindle geometry (parallel to the tool axis)
				TENS: Repeat measurement 1 = with repeat measurement
				HUNDREDS: No offset target 0 = measurement only
				THOUSANDS: Measuring strategy 2 = measurement at an angle, align probe in direction of switching
				TEN THOUSANDS: Number of spheres to be measured 0 = measure a sphere
				HUNDRED THOUSANDS: Number of measurement points 1 = 4 measurement points when measuring at an angle (circle the sphere)
				ONE MILLION: Determination of the diameter setpoint of the sphere 0 = No determination of the diameter setpoint of the sphere 1 = Determination of the diameter setpoint of the sphere
2	Selection	S_KNUM		Correction target 0 = 0
3	Icon+ number	S_PRRUM	Number of the field of the probe parameters (not probe number) (value range 1 to 40)	
4	DM	S_SETV	Diameter of the calibration sphere ⁴⁾	
5	DFA	S_FA	Measurement path	
6	TSA	S_TSA	Safe area ⁵⁾	
7	alpha 0	S_STA1	Starting angle for measurement at an angle ³⁾	
8		S_INCA	Incremental angle for measurement at an angle ²⁾	
9	DZ	S_DZ	Clearance 1st measurement P1 to the 2nd measurement P2 at the shaft of the probe	
10		S_SETV0	Setpoint position of the sphere of the 1st axis of the plane (for G17 X) ²⁾	
11		S_SETV1	Setpoint position of the sphere of the 2nd axis of the plane (for G17 Y) ²⁾	
12		S_SETV2	Setpoint position of the sphere of the 3rd axis of the plane (for G17 Z) ²⁾	
13	TUL	S_TUL	Upper tolerance value of the angular deviation	
14	TZL	S_TZL	Zero offset range ^{1), 4)}	
15	Number	S_NMSP	Number of measurements at the same location ²⁾ (value range 1 to 9)	
16		S_MCBIT	Reserved ²⁾	
17		_DMODE	Display mode	
			Val- ues:	UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)

No.	Screen form parameters	Cycle parameters	Meaning
18		_AMODE	Alternative mode
			Values: UNITS: Dimensional tolerance yes/no 0 = No 1 = Yes

All default values = 0 or marked as the range of values a to b

- 1) Display depends on the general SD54760 \$SNS_MEA_FUNCTION_MASK_PIECE
- 2) Parameters are currently not used and also not displayed in the input screen.
The parameter incremental angle S_INCA is permanently set to 90 degrees.
- 3) Value range of starting angle -360 to +360 degrees
- 4) for dimensional tolerance yes:
If the measured angle is less than the value of the work offset range TZL, then the result parameters for the angle (_OVR[2], _OVR[3]) and deviations (_OVR[7], _OVR[8]) are set to zero.
DisplayTZL is realized using the general SD54760 \$SNS_MEA_FUNCTION_MASK_PIECE bit25=1.
(enable selected zero offset when measuring angularity, spindle)
- 5) Parameter TSA refers to the 1st measurement of the calibration sphere.

3.23.2.12 CYCLE996 measuring cycle parameters

```
PROC CYCLE996 (INT S_MVAR, INT S_TC, INT S_PRNUM, REAL S_SETV, REAL S_STAL, REAL S_SETV0, REAL
S_SETV1, REAL S_SETV2, REAL S_SETV3, REAL S_SETV4, REAL S_SETV5, REAL S_TNVL, REAL S_FA, REAL
S_TSA, INT S_NMSP, INT S_MCBIT, INT _DMODE, INT _AMODE)
```

Table 3-19 CYCLE996 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measurement version (default=1)	
			Val-ues:	<p>UNITS: Measuring sequence</p> <p>0 = Calculate kinematics (selection with: Result display, protocol, change of the swivel data sets, where relevant with operator acknowledgment), see <code>_AMODE</code></p> <p>1 = 1st measurement</p> <p>2 = 2nd measurement</p> <p>3 = 3rd measurement</p>
				<p>TENS: Reserved</p> <p>0 = 0</p>
				<p>HUNDREDS: Measurement version for 1st to 3rd measurement</p> <p>0 = Measurement of the calibration ball paraxial</p> <p>1 = Measurement of the calibration sphere at an angle and no spindle correction ³⁾</p> <p>2 = Measurement of the calibration sphere and correction of the spindle in the switching direction of the probe ³⁾</p> <p>3 = Paraxial measurement, with starting angle ⁸⁾</p> <p>4 = Paraxial measurement, with starting angle, tracking spindle in the switching direction of the probe ⁸⁾</p>
				<p>THOUSANDS: Calculate correction target for kinematics ⁴⁾</p> <p>0 = measuring only. Swivel data sets are calculated, but remain unchanged</p> <p>1 = calculate swivel data set. Swivel data sets are, if necessary, changed after acknowledgment by the operator ⁴⁾</p>
				<p>TEN THOUSANDS: Measuring axis (rotary axis 1 or 2) or vector chain open or closed for calculate kinematics</p> <p>0 = Vector chain closed (only for calculate kinematics)</p> <p>1 = Rotary axis 1 (only for 1st to 3rd measurement)</p> <p>2 = rotary axis 2 (only for the 1st to 3rd measurement) ⁵⁾</p> <p>3 = vector chain open (only for calculate kinematics)</p>
				<p>HUNDRED THOUSANDS: Normalizing of rotary axis 1 for calculate kinematics</p> <p>0 = no scaling rotary axis 1</p> <p>1 = scaling in the direction of the 1st axis of the plane (for G17 X)</p> <p>2 = scaling in the direction of the 2nd axis of the plane (for G17 Y)</p> <p>3 = scaling in the direction of the 3rd axis of the plane (for G17 Z)</p>
				<p>ONE MILLION: Normalizing of rotary axis 2 for calculate kinematics ⁵⁾</p> <p>0 = no scaling rotary axis 2</p> <p>1 = scaling in the direction of the 1st axis of the plane (for G17 X)</p> <p>2 = scaling in the direction of the 2nd axis of the plane (for G17 Y)</p> <p>3 = scaling in the direction of the 3rd axis of the plane (for G17 Z)</p>
				<p>TEN MILLION: Log file</p> <p>0 = no protocol file</p> <p>1 = protocol file with the calculated vectors (tool carrier) and the 1st dynamic 5-axis transformation (TRAORI(1)), if set-up in MDs.</p>
2		S_TC	Number of the swivel data record (tool carrier)	
3	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)	

No.	Screen form parameters	Cycle parameters	Meaning
4		S_SETV	Diameter of the calibration ball
5	alpha 0	S_STA1	Starting angle for measurement at an angle
6	alpha 0	S_SETV0	Position value of rotary axis 1 (if rotary axis is manual or semi-automatic)
7	alpha 1	S_SETV1	Position value of rotary axis 2 (if rotary axis is manual or semi-automatic) ⁶⁾
8	XN	S_SETV2	Position value for normalizing rotary axis 1
9	XN	S_SETV3	Position value for normalizing of rotary axis 2 ⁶⁾
10	Delta	S_SETV4	Tolerance value of the offset vectors I1 to I4
11	Delta	S_SETV5	Tolerance value of rotary axis vectors V1 and V2
12	TVL	S_TNVL	Limit value of angular segment of the rotary axis (value range 1 to 60 degrees) (default=20) ⁷⁾
13	DFA	S_FA	Measurement path
14	TSA	S_TSA	Safe area
15	Measurements	S_NMSP	Number of measurements at the same location ²⁾ (default=1)
16		S_MCBIT	Reserved
17		_DMODE	<p>Display mode</p> <p>Values:</p> <p>UNITS: Machining plane G17/G18/G19</p> <p>0 = compatibility, the plane active before the cycle call remains active</p> <p>1 = G17 (only active in the cycle)</p> <p>2 = G18 (only active in the cycle)</p> <p>3 = G19 (only active in the cycle)</p>
18		_AMODE	<p>Alternative mode</p> <p>Values:</p> <p>UNITS: Tolerance check yes/no</p> <p>0 = No</p> <p>1 = Yes: Evaluation of the tolerance values of the vectors S_SETV4, S_SETV5</p> <p>TENS: Acknowledgment by the operator when entering the calculated vectors in the swivel data set ⁴⁾</p> <p>0 = yes: Operator must acknowledge the change</p> <p>1 = no: calculated vectors are entered immediately (only effective if HUNDREDS and THOUSANDS position = 0)</p> <p>HUNDREDS: Measurement result display ⁵⁾</p> <p>0 = no</p> <p>1 = yes</p> <p>THOUSANDS: Measurement result display can be edited</p> <p>0 = no</p> <p>1 = yes, and can be edited (only effective, if the HUNDREDS position = 1)</p>

1) All default values = 0 or marked as default=x

2) Display depends on the general SD54760 \$SNS_MEA_FUNCTION_MASK_PIECE

3) Using this version, for example, for 90 degree positions, the kinematics can be measured at the calibration ball, without colliding with the retaining shaft of the calibration ball. A starting angle S_STA1 (0 to 360 degrees) can be entered. The incremental angle when circling the sphere is equal to 90 degrees.
As feedrate along the circular path, the channel-specific SD55634 \$SCS_MEA_FEED_PLANE_VALUE is used

4) There is an operator prompt with M0 before entering. The vectors are only entered with NC start.
If the measuring program is aborted with RESET no calculated vectors are entered.
Vectors are only entered when the tolerance of the offset vectors has not been exceeded during the calculation.

3.23 Programming cycles externally

- 5) Measurement result display only for the calculated kinematics measuring version.
If the measurement result should also be displayed after the 1st to the 3rd measurement, then this is realized by setting the channel-specific SD 55613 \$SCS_MEA_RESULT_DISPLAY.
- 6) Rotary axis 2 only for kinematics with two rotary axes
- 7) Limit value angular segment of the rotary axis. Value range of S_TNVL between 20 and 60 degrees. For values of S_TNVL < 20 degrees, inaccuracies can be expected as a result of the measuring inaccuracies in the micrometer range of the probe.
If the limit value is violated, then error message 61430 is output – with a display of the minimum limit value.
- 8) Spindle is tracked in the probe switching direction if SD54760 bit 17 = 1

3.23.2.13 CYCLE9960 measuring cycle parameters

```
PROC CYCLE9960 (INT S_MVAR, STRING[40] S_TNAME, INT S_PRNUM, REAL S_SETV, REAL S_SETV1, REAL
S_START_RA1, REAL S_END_RA1, INT S_CMEA_RA1, REAL S_POS_RA2, REAL S_SETV2, REAL
S_START_RA2, REAL S_END_RA2, INT S_CMEA_RA2, REAL S_POS_RA1, REAL S_SETV4, REAL S_FA, REAL
S_TSA, INT S_NMSP, INT S_DMODE, INT S_AMODE, INT S_KNUM)
```

Table 3-20 CYCLE9960 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning
1	Selection	S_MVAR	Measurement version (default=1) Values: UNITS: Measuring variant 0 = measure and calculate kinematics (select with: Result display, protocol, change of swivel data set (see thousands S_MVAR) 1 = measure reference head 2 = adapt head to reference head 3 = measure and calculate interpolation points (E996) TENS: Reserved HUNDREDS: Ball measuring variant 2 = measurement of the calibration ball and tracking of the spindle in the switching direction of the probe 4 = paraxial measurement, with starting angle, tracking spindle in the switching direction of the probe ²⁾ THOUSANDS: Calculate correction target for kinematics ³⁾ 0 = measure and calculate. Data sets are calculated and remain unchanged 1 = calculated data sets may be changed after operator acknowledgment 2 = previously measured kinematics are calculated and, if applicable, changed after operator acknowledgment TENTHOUSANDS: Measuring axis (rotary axis 1 or 2) 1 = measure and calculate all existing rotary axes 4 = measure and calculate only rotary axis 1 5 = measure and calculate only rotary axis 2
2		S_TNAME	Name of the transformation (swivel data set or transformation based on kinematic chains)
3	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number) (default=1)
4		S_SETV	Diameter of the calibration ball

No.	Screen form parameters	Cycle parameters	Meaning
5	Alpha 1	S_SETV1	Starting angle for measuring at an angle for the 1st rotary axis
6			S_START_RA1: Starting angle of the 1st rotary axis
7			S_END_RA1: Final angle of 1st rotary axis
8			S_CMEA_RA1: Number of measurements of the 1st rotary axis, 3 for measuring and calculating kinematics. Up to 12 measurements are possible for interpolation points.
9			S_POS_RA2: Position of the 2nd rotary axis while measuring the 1st rotary axis ⁴⁾
10	Alpha 2	S_SETV2	Starting angle for measuring at an angle for the 2nd rotary axis ⁴⁾
11			S_START_RA2: Starting angle of the 2nd rotary axis ⁴⁾
12			S_END_RA2: Final angle of 2nd rotary axis ⁴⁾
13			S_CMEA_RA2: Number of measurements of the 2nd rotary axis, 3 for measuring and calculating kinematics. Up to 12 measurements are possible for interpolation points. ⁴⁾
14			S_POS_RA1: Position of the 1st rotary axis while measuring the 2nd rotary axis
15	Delta	S_SETV4	Tolerance value of offset vectors
16	DFA	S_FA	Measurement path
17	TSA	S_TSA	Safe area
18	Number	S_NMSP	Number of measurements at the same location ⁵⁾ (default=1)
19		_DMODE	Display mode Values: UNITS: Machining plane G17/G18/G19 0 = compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
20		_AMODE	Alternative mode Values: ONES: Tolerance check yes/no 0 = no 1 = yes: Evaluation of the tolerance values of the vectors -> S_SETV4, S_SETV5 TENS: Automatic calibration 0 = without automatic calibration 1 = automatic calibration HUNDREDS: Automatic starting angle 0 = set starting angle is used 1 = automatic calculation of the starting angle, for each measuring point
21		S_KNUM	Number of the WO to be corrected for reference head measurement Values UNITS: The correction is always applied to the coarse offset, the fine offset is deleted TENS: 1 ... 99 number of the adjustable WO (1=G54) THOUSANDS: 9 correction active, adjustable WO

1) All default values = 0 or marked as default = xx

2) Spindle is tracked in the switching direction of the probe if SD54760 bit 17 = 1

3) There is an operator prompt with M0 before entering. The vectors cannot be entered until the NC has been started. If the measuring program is interrupted with RESET, no calculated vectors are entered. Vectors are entered only if the tolerance of the offset vectors is not exceeded in the calculation.

4) Rotary axis 2 only for kinematics with 2 rotary axes

5) Display depends on the general SD54760 \$SNS_MEA_FUNCTION_MASK_PIECE.

3.23.2.14 CYCLE982 measuring cycle parameters

```
PROC CYCLE982 (INT S_MVAR, INT S_KNUM, INT S_PNUM, INT S_MA, INT S_MD, REAL S_ID, REAL S_FA, REAL
S_TSA, REAL S_VMS, REAL S_STA1, REAL S_CORA, REAL S_TZL, REAL S_TDIF, INT S_NMSP, INT S_EVNUM, INT
S_MCBIT, INT _DMODE, INT _AMODE)
```

Table 3-21 CYCLE982 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring version	
			Val-ues:	UNITS: Calibration/measurement 0 = Calibrate tool probe 1 = Single tool measurement ³⁾ 2 = Multiple tool measurement, determine lengths and tool radius (for milling tools)
				TENS: Calibration or measurement in the MCS or WCS 0 = Machine-related ⁴⁾ 1 = Workpiece-related
				HUNDREDS: Measurement with or without reversal for milling tools 0 = Measurement without reversal 1 = Measurement with reversal
				THOUSANDS: Correction target for milling tools 0 = determine length or length and radius (see S_MVAR 1st position) 1 = determine radius, if S_MVAR 1st position = 1 2 = determine length and radius (face side), if S_MVAR 1st position = 1 or 2 3 = side milling tool, upper cutting edge (rear side) and determine length and radius ⁵⁾
				TEN THOUSANDS: Position of the milling tool or the drill 0 = Axial position of the milling tool or the drill, radius in 2nd axis of the plane (for G18 X) ⁷⁾ 1 = Radial position of the milling tool or the drill, radius in 1st axis of the plane (for G18 Z) ⁷⁾
				HUNDRED THOUSANDS: Incremental calibration or measurement 0 = No specification 1 = Incremental calibration or measurement
				ONE MILLION: Position spindle at starting angle S_STA1 (only for measurement of milling tools) 0 = spindle is not positioned 1 = spindle is positioned at the starting angle S_STA1
2	Selection	S_KNUM	Offset variant ²⁾	
			Val-ues:	UNITS: Tool offset 0 = No specification (tool offset in geometry) 1 = Tool offset in wear
3	Icon+ number	S_PNUM	Number of the field of the probe parameters (not probe number) (default=1)	

No.	Screen form parameters	Cycle parameters	Meaning	
4	X0	S_MA	Measuring axis	
			Val-ues:	1 = 1. Axis of the plane (for G18 Z) 2 = 2nd axis of the plane (for G18 X)
5	+-	S_MD	Measuring direction	
			Val-ues:	0 = No selection (measuring direction is determined from actual value) 1 = Positive 2 = Negative
6	Z2	S_ID	Offset	
7	DFA	S_FA	Measurement path	
8	TSA	S_TSA	Safe area	
9	VMS	S_VMS	Variable measuring velocity for calibration ²⁾	
10	Alpha1	S_STA1	Starting angle when measuring milling tools	
11	Alpha2	S_CORA	Offset angle when measuring milling tools with reversal ⁸⁾	
12	TZL	S_TZL	Work offset when measuring milling tools When calibrating S_TZL = 0	
13	DIF	S_TDIF	Dimension difference check	
14	Measure-ments	S_NMSP	Number of measurements at the same location ²⁾ (default=1)	
15	EVN	S_EVNUM	Number of the empirical mean value memory ^{2), 9)}	
16		S_MCBIT	Reserved	
17		_DMODE	Display mode	
			Val-ues:	UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)
				TENS: Cutting edge position for turning and milling tools (only for display in the input screens 1 to 9)
				HUNDREDS: Tool type 0 = Turning tool 1 = Milling tool 2 = Drill
				THOUSANDS: The approach strategy with reference to the tool probe 0 = PLUS [X/Z]; X if tool position axial, Z if tool position radial 1 = MINUS [X/Z]; X if tool position axial, Z if tool position radial
18		_AMODE	Alternative mode	
			Val-ues:	UNITS: Reserved
				TENS: Reserved
				HUNDREDS: Reserved
				THOUSANDS: approach starting position after measurement for calibration and single measurement (see S_MVAR - UNITS) 0 = tool is located, offset by DFA with respect to the probe edge 1 = approach starting position

¹⁾ All default values = 0 or marked as default=x

3.23 Programming cycles externally

- 2) Display depends on the general SD 54762 `_MEA_FUNCTION_MASK_TOOL`
- 3) Measure turning or milling tool or drill. Measuring axis in parameter `S_MA`
Specification for turning tools via cutting edge position 1...8, for milling tools via HUNDREDS to THOUSANDS position in parameter `S_MVAR`.
- 4) Measurement and calibration are performed in the basic coordinate system (MCS for kinematic transformation switched off).
- 5) Not for incremental measuring
- 6) Only for multiple measurements `S_MVAR=x2x02` or `x3x02` (example, disk-type or groove milling tools)
- 7) If the channel-specific SD 42950 `$SC_TOOL_LENGTH_TYPE = 2`, then the tool length components are assigned just the same as for turning tools
- 8) Only for measurement with reversal `S_MVAR=xx1x1`
- 9) Empirical value generation
Value range of the empirical value memory: 1 to 20 numbers(n) of the empirical value memory, see channel-specific SD 55623 `$SCS_MEA_EMPIRIC_VALUE[n-1]`.

3.23.2.15 CYCLE971 measuring cycle parameters

```
PROC CYCLE971 (INT S_MVAR, INT S_KNUM, INT S_PRNUM, INT S_MA, INT S_MD, REAL S_ID, REAL S_FA, REAL  
S_TSA, REAL S_VMS, REAL S_TZL, REAL S_TDIF, INT S_NMSP, REAL S_F1, REAL S_S1, REAL S_F2, REAL  
S_S2, REAL S_F3, REAL S_S3, INT S_EVNUM, INT S_MCBIT, INT _DMODE, INT _AMODE)
```


Table 3-22 CYCLE971 call parameters ¹⁾

No.	Screen form parameters	Cycle parameters	Meaning	
1		S_MVAR	Measuring version	
			Val-ues:	UNITS: 0 = Calibrate tool probe 1 = Measure tool with stationary spindle (length or radius) 2 = Measure tool with rotating spindle (length or radius), see parameters S_F1 to S_S4
				TENS: Measurement in the machine coordinate system or workpiece coordinate system 0 = Measurement in MCS (machine-related), measure tool or calibrate tool probe 1 = Measurement in WCS (workpiece-related), measure tool or calibrate tool probe
				HUNDREDS: Individually check teeth 0 = no 1 = yes
				THOUSANDS: 0 = 0
				TEN THOUSANDS: Incremental calibration or measurement 0 = No specification 1 = Incremental calibration or measurement
				HUNDRED THOUSANDS: Calibrate tool probe automatically 0 = Do not calibrate tool probe automatically 1 = Calibrate tool probe automatically
				ONE MILLION: Calibrating in the plane with spindle reversal 0 = Calibrating in the plane without spindle reversal 1 = Calibrating in the plane with spindle reversal
2	Selection	S_KNUM	Offset variant ²⁾	
			Val-ues:	UNITS: Tool offset 0 = No specification (tool offset in geometry) 1 = Tool offset in wear
3	Icon+ number	S_PRNUM	Number of the field of the probe parameters (not probe number)	
4	X0	S_MA	Measuring axis, offset axis ⁴⁾	
			Val-ues:	UNITS: Number of the measuring axis 1 = 1st axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y) 3 = 3rd axis of the plane (for G17 Z)
				TENS: 0 = 0
			HUNDREDS: Number of the offset axis 0 = not an offset axis 1 = 1. axis of the plane (for G17 X) 2 = 2nd axis of the plane (for G17 Y)	

3.23 Programming cycles externally

No.	Screen form parameters	Cycle parameters	Meaning
5	+/-	S_MD	Measuring direction
			Val-ues: 0 = No selection (measuring direction is determined from actual value) 1 = Positive 2 = Negative
6	V	S_ID	Offset
			Val-ues: 0 = For tools without offset >0 = <ul style="list-style-type: none"> • Calibration: The offset acts on the 3rd axis of the plane (for G17 Z) if the diameter of the calibration tool is greater than the upper diameter of the probe. The tool is offset by the tool radius from the center of the probe, minus the value of S_ID. The offset axis is also specified in S_MA . • Measure: With multiple cutting edges, the offset of tool length and the highest point of the cutting edge must be specified for radius measurement or the offset of tool radius to the highest point of the cutting edge must be specified when measuring the length.
7	DFA	S_FA	Measurement path
8	TSA	S_TSA	Safe area
9	VMS	S_VMS	Variable measuring velocity for calibration ²⁾
10	TZL	S_TZL	Work offset (only for tool measurement)
11	DIF	S_TDIF	Dimensional difference check for tool measurement (S_MVAR=xx1 or S_MVAR=xx2)
12	Measurements	S_NMSP	Number of measurements at the same location ²⁾
13	F1	S_F1	1st feedrate for contact with rotating spindle ²⁾
14	S1	S_S1	1st speed for contact with rotating spindle ²⁾
15	F2	S_F2	2nd feedrate for contact with rotating spindle ²⁾
16	S2	S_S2	2nd speed for contact with rotating spindle ²⁾
17	F3	S_F3	2nd feedrate for contact with rotating spindle ³⁾
18	S3	S_S3	2nd speed for contact with rotating spindle ³⁾
19	EVN	S_EVNUM	Number of the empirical value memory ²⁾
20		S_MCBIT	Screen form of the _CBITs or _CHBITs
21		_DMODE	Display mode
			Val-ues: UNITS: Machining plane G17/G18/G19 0 = Compatibility, the plane active before the cycle call remains active 1 = G17 (only active in the cycle) 2 = G18 (only active in the cycle) 3 = G19 (only active in the cycle)

No.	Screen form parameters	Cycle parameters	Meaning	
22		_AMODE	Alternative mode	
			Val- ues:	UNITS: Measuring the tool offset for radius 1 = no 2 = yes
				TENS: Direction of the tool offset when measuring the radius in the 3rd axis of the plane (for G17 Z) 1 = Positive 2 = Negative
			HUNDREDS: Tool offset when measuring the length or when calibrating the probe in the 3rd axis 0 = Compatibility, auto 1 = No 2 = Yes	
			THOUSANDS: Direction of the tool offset when measuring the length in the offset axis (see S_MA HUNDREDS) 1 = Positive 2 = Negative	

- 1) All default values = 0 or marked as default=x
- 2) Display depends on the general SD 54762 MEA_FUNCTION_MASK_TOOL
- 3) Only for offset in tool and dimensional tolerance "Yes", otherwise parameter = 0
- 4) For automatic measurement (S_MVAR=1x00xx), no display of measuring axis, offset axis ⇒ S_MA=0.

3.23.2.16 CYCLE150 measuring cycle parameters

```
PROC CYCLE150 (INT S_PICT, INT S_PROT, STRING[160] S_PATH) SAVE
ACTBLOCNO DISPLOF
```

Table 3-23 CYCLE150 call parameters

No.	Screen parameters	Cycle parameters	Meaning	
1	Measuring result screen	S_PICT	Select result display (default = 0)	
			Values:	UNITS: 0 = Measuring result screen OFF 1 = Measuring result screen ON
				Tens: Select display mode (values as for SD 55613) 1 = Display measuring result screen - automatically deselect after 8 s 3 = Display measuring result screen - acknowledge using NC Start 4 = Display measuring result screen - only for alarms (61303 ... 61306)
2		S_PROT	Select logging (default = 0)	

3.23 Programming cycles externally

No.	Screen parameters	Cycle parameters	Meaning
	Log		Values: UNITS: Select protocol off / on / last measurement 0 = Log OFF 1 = Log ON 2 = Log last measurement
	Log type		TENS: Select log type 0 = Standard log 1 = User log (can be freely defined)
	Log format		HUNDREDS: Select log format 0 = Text format 1 = Table format (for import to Excel)
	Log data		THOUSANDS: Rewrite or attach selection 0 = New 1 = Attach
	Log archive		TEN THOUSANDS: Select log archive 0 = As part program 1 = Directory
3		S_PATH	Path for the log file corresponding to the log archive selection (complete path name or only file name, e.g.: "//NC:/WKS.DIR/NAME.WPD or "MESSPROTOKOLL.TXT"

Tables

4.1 Operations

Note

Cycles

The list of operations contains all cycles, which occur in the NC program (G code), i.e. can be programmed in the program editor using masks - or must be programmed for loops without programming support. Cycles, which for reasons of compatibility, are still available in the control, however can no longer be edited using the SINUMERIK Operate program editor ("compatibility cycles") are not taken into account.

Operations A ... C

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
^{1) 2) 3) 4) 5)} for explanations, see legend (Page 1272).						
:	O	NC main block number, jump label termination, concatenation operator		+		PGAsI
*	O	Operator for multiplication		+		PGAsI
+	O	Operator for addition		+		PGAsI
-	O	Operator for subtraction		+		PGAsI
<	O	Comparison operator, less than		+		PGAsI
<<	O	Concatenation operator for strings		+		PGAsI
<=	O	Comparison operator, less than or equal to		+		PGAsI
=	O	Assignment operator		+		PGAsI
>=	O	Comparison operator, greater than or equal to		+		PGAsI
/	O	Operator for division		+		PGAsI
/0		block is skipped (1st skip level)		+		PGsI
...		...				
...		...				
/7		block is skipped (8th skip level)				
A	A	Axis name	m/s	+		PGAsI
A2	A	Tool orientation: RPY or Euler angle	s	+		PGAsI
A3	A	Tool orientation: 1st component of the direction vector	s	+		PGAsI
A4	A	Tool orientation: 1st component of the surface normal vector at start of block	s	+		PGAsI
A5	A	Tool orientation: 1st component of the surface normal vector at end of block	s	+		PGAsI
A6	A	Tool orientation: 1st component of the direction vector for taper's axis of rotation	s	+		PGAsI

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
A7	A	Tool orientation: 1st Vector component for intermediate orientation on peripheral surface of taper	s	+		PGAsI
ABS	F	Absolute value (amount)		+	+	PGAsI
AC	K	Absolute dimensions of coordinates/positions	s	+		PGsI
ACC	K	Effect of current axial acceleration	m	+	+	PGsI
ACCLIMA	K	Effect of current maximum axial acceleration	m	+	+	PGAsI
ACN	K	Absolute dimensions for rotary axes, approach position in negative direction	s	+		PGsI
ACOS	F	Arc cosine (trigon. function)		+	+	PGAsI
ACP	K	Absolute dimensions for rotary axes, approach position in positive direction	s	+		PGsI
ACTBLOCNO	P	Output of current block number of an alarm block, even if "current block display suppressed" (DISPLOF) is active!		+		PGAsI
ADDFRAME	F	Inclusion and possible activation of a measured frame		+	-	PGAsI, FB1sI (K2)
ADIS	A	Rounding clearance for path functions G1, G2, G3, ...	m	+		PGsI
ADISPOS	A	Rounding clearance for rapid traverse G0	m	+		PGsI
ADISPOSA	P	Size of the tolerance window for IPOBRKA	m	+	+	PGAsI
ALF	A	LIFTFAST angle	m	+		PGAsI
AMIRROR	G	Programmable mirroring	s	+		PGsI
AND	K	Logical AND		+		PGAsI
ANG	A	Contour angle	s	+		PGsI
AP	A	Polar angle	m/s	+		PGsI
APR	K	Read/show access protection		+		PGAsI
APRB	K	Read access right, OPI		+		PGAsI
APRP	K	Read access right, part program		+		PGAsI
APW	K	Write access protection		+		PGAsI
APWB	K	Write access right, OPI		+		PGAsI
APWP	K	Write access right, part program		+		PGAsI
APX	K	Definition of the access right for executing the specified language element		+		PGAsI
AR	A	Opening angle	m/s	+		PGsI
AROT	G	Programmable rotation	s	+		PGsI
AROTS	G	Programmable frame rotations with solid angles	s	+		PGsI
AS	K	Macro definition		+		PGAsI
ASCALE	G	Programmable scaling	s	+		PGsI
ASIN	F	Arithmetic function, arc sine		+	+	PGAsI
ASPLINE	G	Akima spline	m	+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
ATAN2	F	Arc tangent 2		+	+	PGAsI
ATOL	A	Axis-specific tolerance for compressor functions, orientation smoothing and smoothing types	m	+		PGAsI
ATRANS	G	Additive programmable work offset	s	+		PGsI
AUXFUDEL	P	Delete auxiliary function channel-specifically from the global list		+	-	FB1sI (H2)
AUXFUDELG	P	Delete all auxiliary functions of an auxiliary function group channel-specifically from the global list		+	-	FB1sI (H2)
AUXFUMSEQ	P	Determine output sequence of M auxiliary functions		+	-	FB1sI (H2)
AUXFUSYNC	P	Generate a complete part program block for the channel-specific SERUPRO end ASUB as string from the global list of auxiliary functions		+	-	FB1sI (H2)
AX	K	Variable axis identifier	m/s	+		PGAsI
AXCTSWE	P	Rotate axis container		+	-	PGAsI
AXCTSWEC	P	Cancel enable for axis container rotation		+	+	PGAsI
AXCTSWED	P	Rotating axis container (command variant for commissioning!)		+	-	PGAsI
AXIS	K	Axis identifier, axis address		+		PGAsI
AXNAME	F	Converts input string into axis identifier		+	-	PGAsI
AXSTRING	F	Converts string spindle number		+	-	PGAsI
AXTOCHAN	P	Request axis for a specific channel. Possible from NC program and synchronized action.		+	+	PGAsI
AXTOSPI	F	Converts axis identifier into a spindle index		+	-	PGAsI
B	A	Axis name	m/s	+		PGAsI
B2	A	Tool orientation: RPY or Euler angle	s	+		PGAsI
B3	A	Tool orientation: component of the direction vector	s	+		PGAsI
B4	A	Tool orientation: 2nd component of the surface normal vector at start of block	s	+		PGAsI
B5	A	Tool orientation: 2nd component of the surface normal vector at end of block	s	+		PGAsI
B6	A	Tool orientation: 2nd component of the direction vector for taper's axis of rotation	s	+		PGAsI
B7	A	Tool orientation: 2nd Vector component for intermediate orientation on peripheral surface of taper	s	+		PGAsI
B_AND	O	Bit-by-bit AND		+		PGAsI
B_OR	O	Bit-by-bit OR		+		PGAsI
B_NOT	O	Bit-by-bit negation		+		PGAsI
B_XOR	O	Bit-by-bit exclusive OR		+		PGAsI
BAUTO	G	Definition of the first spline section by means of the next 3 points	m	+		PGAsI

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
BLOCK	K	Together with the keyword TO defines the program part to be processed in an indirect subprogram call		+		PGAsI
BLSYNC	K	Processing of interrupt routine is only to start with the next block change		+		PGAsI
BNAT ⁶⁾	G	Natural transition to first spline block	m	+		PGAsI
BOOL	K	Data type: Boolean value TRUE/FALSE or 1/0		+		PGAsI
BOUND	F	Tests whether the value falls within the defined value range. If the values are equal, the test value is returned.		+	+	PGAsI
BRISK ⁶⁾	G	Fast non-smoothed path acceleration	m	+		PGAsI
BRISKA	P	Switch on brisk path acceleration for the programmed axes		+	-	PGAsI
BSPLINE	G	B spline	m	+		PGAsI
BTAN	G	Tangential transition to first spline block	m	+		PGAsI
C	A	Axis name	m/s	+		PGAsI
C2	A	Tool orientation: RPY or Euler angle	s	+		PGAsI
C3	A	Tool orientation: 3rd component of the direction vector	s	+		PGAsI
C4	A	Tool orientation: 3rd component of the surface normal vector at start of block	s	+		PGAsI
C5	A	Tool orientation: 3rd component of the surface normal vector at end of block	s	+		PGAsI
C6	A	Tool orientation: 3rd component of the direction vector for taper's axis of rotation	s	+		PGAsI
C7	A	Tool orientation: 3rd Vector component for intermediate orientation on peripheral surface of taper	s	+		PGAsI
CAC	K	Absolute position approach		+		PGAsI
CACN	K	Absolute approach of the value listed in the table in negative direction		+		PGAsI
CACP	K	Absolute approach of the value listed in the table in positive direction		+		PGAsI
CADAPTOF	P	Deactivate load adjustment		+	-	PGAsI
CADAPTON	P	Activate load adjustment		+	-	PGAsI
CALCDAT	F	Calculates radius and center point of circle from 3 or 4 points		+	-	PGAsI
CALCPOSI	F	Checking for protection area violation, working area limitation and software limits		+	-	PGAsI
CALL	K	Indirect subprogram call		+		PGAsI
CALLPATH	P	Programmable search path for subprogram calls		+	-	PGAsI
CANCEL	P	Cancel modal synchronized action		+	-	FBSYsI
CANCELSUB	P	Cancel current subprogram level		+	+	FBSYsI
CASE	K	Conditional program branch		+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CDC	K	Direct approach of a position		+		PGAsI
CDOF ⁶⁾	G	Switch off collision monitoring	m	+		PGsI
CDOF2	G	Switch off collision monitoring during 3D circumferential milling	m	+		PGsI
CDON	G	Activate collision monitoring	m	+		PGsI
CFC ⁶⁾	G	Constant feedrate on contour	m	+		PGsI
CFIN	G	Constant feedrate for internal radius only, not for external radius	m	+		PGsI
CFINE	F	Assignment of fine offset to a FRAME variable		+	-	PGAsI
CFTCP	G	Constant feedrate in tool center point (center point path)	m	+		PGsI
CHAN	K	Specify validity range for data		+		PGAsI
CHANDATA	P	Set channel number for channel data access		+	-	PGAsI
CHAR	K	Data type: ASCII character		+		PGAsI
CHF	A	Chamfer; value = length of chamfer	s	+		PGsI
CHKDM	F	Uniqueness check within a magazine		+	-	FBWsI
CHKDNO	F	Check for unique D numbers		+	-	PGAsI
CHR	A	Chamfer; value = length of chamfer in direction of movement		+		PGsI
CIC	K	Approach position by increments		+		PGAsI
CIP	G	Circular interpolation through intermediate point	m	+		PGsI
CLEARM	P	Reset one/several markers for channel coordination		+	+	PGAsI
CLRINT	P	Deselect interrupt		+	-	PGAsI
CMIRROR	F	Mirror on a coordinate axis		+	-	PGAsI
COARSEA	K	Motion end when "Exact stop coarse" reached	m	+		PGAsI
COLLPAIR	F	Check whether part of a collision pair		+		PGAsI
COMPCAD	G	Activate the compressor function COMPCAD	m	+		PGAsI
COMP CURV	G	Activate the compressor function COMP-CURV	m	+		PGAsI
COMPLETE		Control instruction for reading and writing data		+		PGAsI
COMPOF ⁶⁾	G	Deactivate NC block compression	m	+		PGAsI
COMPON	G	Activate the compressor function COMPON	m	+		PGAsI
COMPSURF	G	Activate the compressor function COMPSURF	m	+		PGAsI
CONTD CON	P	Activate tabular contour decoding		+	-	PGAsI
CONTPRON	P	Activate reference preprocessing		+	-	PGAsI
CORROF	P	All active overlaid movements are deselected.		+	-	PGsI
CORRTC	F	Modify offset vectors or direction vectors of orientable tool carriers according to machine measurement.		+	-	PGAsI

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CORRTRAF0	F	Modifying offset vectors or direction vectors for the orientation axes in the kinematic model of the machine		+	-	PGAsI
COS	F	Cosine (trigon. function)		+	+	PGAsI
COUPDEF	P	Definition ELG group/synchronous spindle group		+	-	PGAsI
COUPDEL	P	Delete ELG group		+	-	PGAsI
COUPOF	P	Deactivate ELG group / synchronous spindle pair		+	-	PGAsI
COUPOFS	P	Deactivate ELG group/synchronous spindle pair with stop of following spindle		+	-	PGAsI
COUPON	P	Activate ELG group / synchronous spindle pair		+	-	PGAsI
COUPONC	P	Transfer activation of ELG group/synchronous spindle pair with previous programming		+	-	PGAsI
COUPRES	P	Reset ELG group		+	-	PGAsI
CP ⁶⁾	G	Path motion	m	+		PGAsI
CPBC	K	Generic coupling: Block change criterion		+	+	FB3sl (M3)
CPDEF	K	Generic coupling: Creating a coupling module		+	+	FB3sl (M3)
CPDEL	K	Generic coupling: Deletion of a coupling module		+	+	FB3sl (M3)
CPFMOF	K	Generic coupling: Behavior of the following axis at complete switch-off		+	+	FB3sl (M3)
CPFMON	K	Generic coupling: Behavior of the following axis when switching on		+	+	FB3sl (M3)
CPFMSON	K	Generic coupling: Synchronization mode		+	+	FB3sl (M3)
CPFPOS	K	Generic coupling: Synchronized position of the following axis		+	+	FB3sl (M3)
CPFRS	K	Generic coupling: Coordinate reference system		+	+	FB3sl (M3)
CPLA	K	Generic coupling: Definition of a leading axis		+	-	FB3sl (M3)
CPLCTID	K	Generic coupling: Number of the curve table		+	+	FB3sl (M3)
CPLDEF	K	Generic coupling: Definition of a leading axis and creation of a coupling module		+	+	FB3sl (M3)
CPLDEL	K	Generic coupling: Deleting a leading axis of a coupling module		+	+	FB3sl (M3)
CPLDEN	K	Generic coupling: Denominator of the coupling factor		+	+	FB3sl (M3)
CPLINSC	K	Generic coupling: Scaling factor of the input value of a leading axis		+	+	FB3sl (M3)
CPLINTR	K	Generic coupling: Offset value of the input value of a leading axis		+	+	FB3sl (M3)
CPLNUM	K	Generic coupling: Numerator of the coupling factor		+	+	FB3sl (M3)

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
^{1) 2) 3) 4) 5)} for explanations, see legend (Page 1272).						
CPLOF	K	Generic coupling: Switching off a leading axis of a coupling module		+	+	FB3sl (M3)
CPLON	K	Generic coupling: Switching on a leading axis of a coupling module		+	+	FB3sl (M3)
CPLOUTSC	K	Generic coupling: Scaling factor for the output value of a coupling		+	+	FB3sl (M3)
CPLOUTTR	K	Generic coupling: Offset value for the output value of a coupling		+	+	FB3sl (M3)
CPLPOS	K	Generic coupling: Synchronized position of the leading axis		+	+	FB3sl (M3)
CPLSETVAL	K	Generic coupling: Coupling reference		+	+	FB3sl (M3)
CPMALARM	K	Generic coupling: Suppression of special coupling-related alarm outputs		+	+	FB3sl (M3)
CPMBRAKE	K	Generic coupling: Response of the following axis to certain stop signals and stop commands		+	-	FB3sl (M3)
CPMPRT	K	Generic coupling: Coupling response at part program start under block search run via program test		+	+	FB3sl (M3)
CPMRESET	K	Generic coupling: Coupling behavior for RESET		+	+	FB3sl (M3)
CPMSTART	K	Generic coupling: Coupling behavior at part program start		+	+	FB3sl (M3)
CPMVDI	K	Generic coupling: Response of the following axis to certain NC/PLC interface signals		+	+	FB3sl (M3)
CPOF	K	Generic coupling: Switching off a coupling module		+	+	FB3sl (M3)
CPON	K	Generic coupling: Switching on a coupling module		+	+	FB3sl (M3)
CPRECOF ⁶⁾	G	Deactivate programmable contour accuracy	m	+		PGAsl
CPRECON	G	Activate programmable contour accuracy	m	+		PGAsl
CPRES	K	Generic coupling: Activates the configured data of the synchronous spindle coupling		+	-	FB3sl (M3)
CPROT	P	Activate / deactivate channel-specific protection zone		+	-	PGAsl
CPROTDEF	P	Definition of a channel-specific protection area		+	-	PGAsl
CPSETTYPE	K	Generic coupling: Coupling type		+	+	FB3sl (M3)
CPSYNCOP	K	Generic coupling: Threshold value of position synchronism "Coarse"		+	+	FB3sl (M3)
CPSYNCOP2	K	Generic coupling: Threshold value of position synchronism "Coarse" 2		+	+	FB3sl (M3)
CPSYNCOV	K	Generic coupling: Threshold value of velocity synchronism "Coarse"		+	+	FB3sl (M3)
CPSYNFIP	K	Generic coupling: Threshold value of position synchronism "Fine"		+	+	FB3sl (M3)

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CPSYNFIP2	K	Generic coupling: Threshold value of position synchronism "Fine" 2		+	+	FB3sl (M3)
CPSYNFIV	K	Generic coupling: Threshold value of velocity synchronism "Fine"		+	+	FB3sl (M3)
CR	A	Circle radius	s	+		PGsl
CROT	F	Rotation of the current coordinate system		+	-	PGAsl
CROTS	F	Programmable frame rotations with solid angles (rotation in the specified axes)	s	+	-	PGsl
CRPL	F	Frame rotation in any plane		+	-	FB1sl (K2)
CSCALE	F	Scale factor for multiple axes		+	-	PGAsl
CSPLINE	F	Cubic spline	m	+		PGAsl
CT	G	Circle with tangential transition	m	+		PGsl
CTAB	F	Define following axis position according to leading axis position from curve table		+	+	PGAsl
CTABDEF	P	Activate table definition		+	-	PGAsl
CTABDEL	P	Clear curve table		+	-	PGAsl
CTABEND	P	Deactivate table definition		+	-	PGAsl
CTABEXISTS	F	Checks the curve table with number n		+	+	PGAsl
CTABFNO	F	Number of curve tables still possible in the memory		+	+	PGAsl
CTABFPOL	F	Number of polynomials still possible in the memory		+	+	PGAsl
CTABFSEG	F	Number of curve segments still possible in the memory		+	+	PGAsl
CTABID	F	Returns table number of the nth curve table		+	+	PGAsl
CTABINV	F	Define leading axis position according to following axis position from curve table		+	+	PGAsl
CTABISLOCK	F	Returns the lock state of the curve table with number n		+	+	PGAsl
CTABLOCK	P	Delete and overwrite, lock		+	+	PGAsl
CTABMEMTYP	F	Returns the memory in which curve table number n is created.		+	+	PGAsl
CTABMPOL	F	Max. number of polynomials still possible in the memory		+	+	PGAsl
CTABMSEG	F	Max. number of curve segments still possible in the memory		+	+	PGAsl
CTABNO	F	Number of defined curve tables in SRAM or DRAM		+	+	FB3sl (M3)
CTABNOMEM	F	Number of defined curve tables in SRAM or DRAM		+	+	PGAsl
CTABPERIOD	F	Returns the table periodicity of curve table number n		+	+	PGAsl
CTABPOL	F	Number of polynomials already used in the memory		+	+	PGAsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CTABPOLID	F	Number of the curve polynomials used by the curve table with number n		+	+	PGAsl
CTABSEG	F	Number of curve segments already used in the memory		+	+	PGAsl
CTABSEGID	F	Number of the curve segments used by the curve table with number n		+	+	PGAsl
CTABSEV	F	Returns the final value of the following axis of a segment of the curve table		+	+	PGAsl
CTABSSV	F	Returns the initial value of the following axis of a segment of the curve table		+	+	PGAsl
CTABTEP	F	Returns the value of the leading axis at curve table end		+	+	PGAsl
CTABTEV	F	Returns the value of the the following axis at curve table end		+	+	PGAsl
CTABTMAX	F	Returns the maximum value of the following axis of the curve table		+	+	PGAsl
CTABTMIN	F	Returns the minimum value of the following axis of the curve table		+	+	PGAsl
CTABTSP	F	Returns the value of the leading axis at curve table start		+	+	PGAsl
CTABTSV	F	Returns the value of the following axis at curve table start		+	+	PGAsl
CTABUNLOCK	P	Revoke delete and overwrite lock		+	+	PGAsl
CTOL	A	Contour tolerance for compressor functions, orientation smoothing and smoothing types	m	+		PGAsl
CTRANS	F	Work offset for multiple axes		+	-	PGAsl
CUT2D ⁶⁾	G	2D TRC	m	+		PGsl
CUT2DD	G	2½ D TRC in relation to the differential tool	m	+		PGsl
CUT2DF	G	2D TRC relative to the current frame (inclined plane)	m	+		PGsl
CUT2DFD	G	2½D TRC in relation to a differential tool relative to the current frame (inclined plane)	m	+		PGsl
CUT3DC	G	3D TRC for circumferential milling	m	+		PGAsl
CUT3DCC	G	3D TRC for circumferential milling taking into account a limitation surface with 3D radius compensation Contour on the machining surface	m	+		PGAsl
CUT3DCCD	G	3D TRC for circumferential milling taking into account a limitation surface with differential tool on the tool center-point path: Infeed to the limitation surface	m	+		PGAsl
CUT3DCD	G	3D TRC in relation to a differential tool for circumferential milling	m	+		PGAsl
CUT3DF	G	3D TRC for face milling with change in orientation	m	+		PGAsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CUT3DFD	G	3D TRC in relation to a differential tool for face milling with change in orientation	m	+		PGAsI
CUT3DFF	G	3D TRC for face milling with constant orientation. The tool orientation is the direction defined by G17 - G19 and, in some cases, rotated by a frame.	m	+		PGAsI
CUT3DFS	G	3D TRC for face milling with constant orientation. The tool orientation is defined by G17 - G19 and is not influenced by frames.	m	+		PGAsI
CUTCONOF ⁶⁾	G	Deactivate tool radius compensation	m	+		PGsI
CUTCONON	G	Activate tool radius compensation	m	+		PGsI
CUTMOD	A	Activate Modification of the offset data for rotatable tools (in connection with orientable tool carriers)	m	+		PGAsI
CUTMODK	A	Activate Modification of the offset data for rotatable tools (in connection with orientation transformations defined by kinematic chains)	m	+		PGAsI
CYCLE60	C (T)	Engraving cycle		+		PGAsI
CYCLE61	C (T)	Face milling		+		PGAsI
CYCLE62	C (T)	Contour call		+		PGAsI
CYCLE63	C (T)	Contour pocket milling		+		PGAsI
CYCLE64	C (T)	Contour pocket predrilling		+		PGAsI
CYCLE70	C (T)	Thread milling		+		PGAsI
CYCLE72	C (T)	Path milling		+		PGAsI
CYCLE76	C (T)	Milling the rectangular spigot		+		PGAsI
CYCLE77	C (T)	Circular spigot milling		+		PGAsI
CYCLE78	C (T)	Mill cutting thread		+		PGAsI
CYCLE79	C (T)	Multiple edge		+		PGAsI
CYCLE81	C (T)	Drilling, centering		+		PGAsI
CYCLE82	C (T)	Drilling, counterboring		+		PGAsI
CYCLE83	C (T)	Deep-hole drilling		+		PGAsI
CYCLE84	C (T)	Tapping without compensating chuck		+		PGAsI
CYCLE85	C (T)	Reaming		+		PGAsI
CYCLE86	C (T)	Boring		+		PGAsI
CYCLE92	C (T)	Parting		+		PGAsI
CYCLE95	C (T)	Stock removal along the contour		+		PGAsI
CYCLE98	C (T)	Thread chain		+		PGAsI
CYCLE99	C (T)	Thread cutting		+		PGAsI
CYCLE116	C (M)	Calculation of center point and radius of a circle		+		BNMsl
CYCLE119	C (M)	Determining position in space		+		BNMsl
CYCLE150	C (M)	Displaying/logging measurement results		+		BNMsl
CYCLE435	C (T)	Calculate dressing tool position		+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
CYCLE495	C (T)	Form-truing		+		PGAsl
CYCLE750	C (A)	Internal operating cycle for CYCLE751 ... CYCLE759 (contains the MMC command for the actual function call)		-		FB3sl (T4)
CYCLE751	C (A)	Open / perform / close an optimization session		M		FB3sl (T4)
CYCLE752	C (A)	Add axis to an optimization session		M		FB3sl(T4)
CYCLE753	C (A)	Select optimization mode		M		FB3sl (T4)
CYCLE754	C (A)	Add / remove language block		M		FB3sl (T4)
CYCLE755	C (A)	Backing up/restoring data block		M		FB3sl (T4)
CYCLE756	C (A)	Activate optimization results		M		FB3sl (T4)
CYCLE757	C (A)	Store optimization data		M		FB3sl (T4)
CYCLE758	C (A)	Changing the parameter value		M		FB3sl (T4)
CYCLE759	C (A)	Read parameter value		M		FB3sl (T4)
CYCLE782	C (T)	Adapt to load		+		PGAsl
CYCLE800	C (T)	Swiveling		+		PGAsl
CYCLE801	C (T)	Grid or frame		+		PGAsl
CYCLE802	C (T)	Arbitrary positions		+		PGAsl
CYCLE830	C (T)	Deep-hole drilling 2		+		PGAsl
CYCLE832	C (T)	High-Speed Settings		+		PGAsl
CYCLE840	C (T)	Tapping with compensating chuck		+		PGAsl
CYCLE899	C (T)	Open slot milling		+		PGAsl
CYCLE930	C (T)	Groove		+		PGAsl
CYCLE940	C (T)	Undercut forms		+		PGAsl
CYCLE951	C (T)	Stock removal		+		PGAsl
CYCLE952	C (T)	Contour grooving		+		PGAsl
CYCLE961	C (M)	Determine the position of a workpiece corner (inner or outer) and insert as work offset.		+		BNMsl
CYCLE971	C (M)	Calibrate tool probe, measure tool length and/or tool radius (only for milling)		+		BNMsl
CYCLE973	C (M)	Calibrate a workpiece probe on a surface on the workpiece or in a groove (only for turning)		+		BNMsl
CYCLE974	C (M)	Determine the workpiece zero in the selected measuring axis, determine tool offset with 1-point measurement (only for turning).		+		BNMsl
CYCLE976	C (M)	Calibrate a workpiece probe in a calibration ring or on a calibration ball completely in the working plane or at an edge for a particular axis and direction		+		BNMsl
CYCLE977	C (M)	Determine the center in the plane as well as the width or the diameter		+		BNMsl
CYCLE978	C (M)	Measure the position of an edge in the workpiece coordinate system		+		BNMsl
CYCLE979	C (M)	Determine center in the plane, measure radius of circle segment.		+		BNMsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
CYCLE982	C (M)	Calibrate tool probe, measure turning drilling and milling tools (only for turning)		+		BNMsl
CYCLE994	C (M)	Determine the workpiece zero in the selected measuring axis with 2-point measurement (only for turning).		+		BNMsl
CYCLE995	C (M)	Measure the angularity of the spindle on a machine tool		+		BNMsl
CYCLE996	C (M)	Determine transformation-relevant data for kinematic transformations with rotary axes		+		BNMsl
CYCLE997	C (M)	Determine center and diameter of a ball, measure center of three distributed balls		+		BNMsl
CYCLE998	C (M)	Determine the angular position of a surface (plane) referred to the working plane, determine angle of edges in the workpiece coordinate system.		+		BNMsl
CYCLE4071	C (T)	Longitudinal grinding with infeed at the reversal point		+		PGAsl
CYCLE4072	C (T)	Longitudinal grinding with infeed at the reversal point and cancel signal		+		PGAsl
CYCLE4073	C (T)	Longitudinal grinding with continuous infeed		+		PGAsl
CYCLE4074	C (T)	Longitudinal grinding with continuous infeed and cancel signal		+		PGAsl
CYCLE4075	C (T)	Surface grinding with infeed at the reversal point		+		PGAsl
CYCLE4077	C (T)	Surface grinding with infeed at the reversal point and cancel signal		+		PGAsl
CYCLE4078	C (T)	Surface grinding with continuous infeed		+		PGAsl
CYCLE4079	C (T)	Surface grinding with intermittent infeed		+		PGAsl
CYCLE9960	C (M)	Measure kinematics completely		+		BNMsl

Operations D ... F

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
D	A	Tool offset number		+		PGsl
D0	A	With D0, offsets for the tool are ineffective		+		PGsl
DAC	K	Absolute non-modal axis-specific diameter programming	s	+		PGsl
DC	K	Absolute dimensions for rotary axes, approach position directly	s	+		PGsl
DCI	K	Assign data class I (= Individual) (only SINUMERIK 828D)		+		PGAsl
DCM	K	Assign data class M (= Manufacturer) (only SINUMERIK 828D)		+		PGAsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
¹⁾²⁾³⁾⁴⁾⁵⁾ for explanations, see legend (Page 1272).						
DCU	K	Assign data class U (= User) (only SINUMER- IK 828D)		+		PGAsl
DEF	K	Variable definition		+		PGAsl
DEFAULT	K	Branch in CASE branch		+		PGAsl
DEFINE	K	Keyword for macro definitions		+		PGAsl
DELAYFSTOF	P	Define the end of a stop delay section	m	+	-	PGAsl
DELAYFSTON	P	Define the start of a stop delay section	m	+	-	PGAsl
DELDL	F	Delete additive offsets		+	-	PGAsl
DELDTG	P	Delete distance-to-go		-	+	FBSYsl
DELETE	P	Delete the specified file. The file name can be specified with path and file identifier.		+	-	PGAsl
DELMOWNER	F	Delete owner magazine location of the tool		+	-	FBWsl
DELMRES	F	Delete magazine location reservation		+	-	FBWsl
DELMT	P	Delete multitool		+	-	FBWsl
DELOBJ	F	Deletion of elements from kinematic chains, protection areas, protection area elements, collision pairs and transformation data		+		PGAsl
DELT	P	Delete tool		+	-	FBWsl
DELTC	P	Delete toolholder data record		+	-	FBWsl
DELTOLENV	F	Delete data records describing tool environ- ments		+	-	PGAsl
DIACYCOFA	K	Axis-specific modal diameter programming: OFF in cycles	m	+		FB1sl (P1)
DIAM90	G	Diameter programming for G90, radius pro- gramming for G91	m	+		PGAsl
DIAM90A	K	Axis-specific modal diameter programming for G90 and AC, radius programming for G91 and IC	m	+		PGsl
DIAMCHAN	K	Transfer of all axes from MD axis functions to diameter programming channel status		+		PGsl
DIAMCHANA	K	Transfer of the diameter programming chan- nel status		+		PGsl
DIAMCYCOF	G	Channel-specific diameter programming: OFF in cycles	m	+		FB1sl (P1)
DIAMOF ⁶⁾	G	Diameter programming: OFF Normal position, see machine manufacturer	m	+		PGsl
DIAMOFA	K	Axis-specific modal diameter programming: OFF Normal position, see machine manufacturer	m	+		PGsl
DIAMON	G	Diameter programming: ON	m	+		PGsl
DIAMONA	K	Axis-specific modal diameter programming: ON Activation, see machine manufacturer	m	+		PGsl
DIC	K	Relative non-modal axis-specific diameter programming	s	+		PGsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
DILF	A	Retraction path (length)	m	+		PGsI
DISABLE	P	Interrupt OFF		+	-	PGAsI
DISC	A	Transition circle overshoot tool radius compensation	m	+		PGsI
DISCL	A	Clearance between the end point of the fast infeed motion and the machining plane		+		PGsI
DISPLOF	PA	Suppress current block display		+		PGAsI
DISPLON	PA	Revoke suppression of the current block display		+		PGAsI
DISPR	A	Path differential for repositioning	s	+		PGAsI
DISR	A	Distance for repositioning	s	+		PGAsI
DISRP	A	Distance between the retraction plane and the machining plane during smooth approach and retraction		+		PGsI
DITE	A	Thread run-out path	m	+		PGsI
DITS	A	Thread run-in path	m	+		PGsI
DIV	K	Integer division		+		PGAsI
DL	A	Select location-dependent additive tool offset (DL, total set-up offset)	m	+		PGAsI
DO	K	Synchronized action: Triggering of actions when condition fulfilled		-	+	FBSYsI
DRFOF	P	Deactivation of handwheel offsets (DRF)	m	+	-	PGsI
DRIVE	G	Velocity-dependent path acceleration	m	+		PGAsI
DRIVEA	P	Activate knee-shaped acceleration characteristic for the programmed axes		+	-	PGAsI
DYNFINISH	G	Dynamic response for finishing	m	+		PGAsI
DYNNORM ⁶⁾	G	Standard dynamic response	m	+		PGAsI
DYNPOS	G	Dynamic response for positioning mode, tapping	m	+		PGAsI
DYNPREC	G	Dynamic response for smooth finishing	m	+		PGAsI
DYNROUGH	G	Dynamic response for roughing	m	+		PGAsI
DYNSEMIFIN	G	Dynamic response for semi-finishing	m	+		PGAsI
DZERO	P	Marks all D numbers of the TO unit as invalid		+	-	PGAsI
EAUTO	G	Definition of the last spline section by means of the last 3 points	m	+		PGAsI
EGDEF	P	Definition of an electronic gear		+	-	PGAsI
EGDEL	P	Delete coupling definition for the following axis		+	-	PGAsI
EGOFC	P	Turn off electronic gear continuously		+	-	PGAsI
EGOFS	P	Turn off electronic gear selectively		+	-	PGAsI
EGON	P	Turn on electronic gear		+	-	PGAsI
EGONSYN	P	Turn on electronic gear		+	-	PGAsI
EGONSYNE	P	Turn on electronic gear, with specification of approach mode		+	-	PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
¹⁾²⁾³⁾⁴⁾⁵⁾ for explanations, see legend (Page 1272).						
ELSE	K	NC program: Program branch if the IF condition is not fulfilled.		+	-	PGAsl
ELSE	K	Synchronized action: Triggering of actions when condition unfulfilled		-	+	FBSYsl
ENABLE	P	Interrupt ON		+	-	PGAsl
ENAT ⁶⁾	G	Natural transition to next traversing block	m	+		PGAsl
ENDFOR	K	End line of FOR counter loop		+		PGAsl
ENDIF	K	End line of IF branch		+		PGAsl
ENDLABEL	K	End label for part program repetitions with REPEAT		+		PGAsl, FB1sl (K1)
ENDLOOP	K	End line of endless program loop LOOP		+		PGAsl
ENDPROC	K	End line of program with start line PROC		+		
ENDWHILE	K	End line of WHILE loop		+		PGAsl
ESRR	P	Parameterizing drive-autonomous ESR retraction in the drive		+		PGAsl
ESRS	P	Parameterizing drive-autonomous ESR shutdown in the drive		+		PGAsl
ETAN	G	Tangential transition to next traversing block at spline begin	m	+		PGAsl
EVERY	K	Execute synchronized action on transition of condition from FALSE to TRUE		-	+	FBSYsl
EX	K	Keyword for value assignment in exponential notation		+		PGAsl
EXECSTRING	P	Transfer of a string variable with the executing part program line		+	-	PGAsl
EXECTAB	P	Execute an element from a motion table		+	-	PGAsl
EXECUTE	P	Program execution ON		+	-	PGAsl
EXP	F	Exponential function ex		+	+	PGAsl
EXTCALL	A	Execute external subprogram		+	+	PGAsl
EXTCLOSE	P	Closing external device / file that was opened for writing		+	-	PGAsl
EXTERN	K	Declaration of a subprogram with parameter transfer		+		PGAsl
EXTOPEN	P	Opening external device / file for the channel for writing		+	-	PGAsl
F	A	Feedrate value (in conjunction with G4 the dwell time is also programmed with F)		+	+	PGsl
FA	K	Axial feedrate	m	+	+	PGsl
FAD	A	Infeed rate for soft approach and retraction		+		PGsl
FALSE	K	Logical constant: Incorrect		+	+	PGAsl
FB	A	Non-modal feedrate		+		PGsl
FCTDEF	P	Define polynomial function		+	-	PGAsl
FCUB	G	Feedrate variable according to cubic spline	m	+		PGAsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
FD	A	Path feedrate for handwheel override	s	+		PGsl
FDA	K	Axis feedrate for handwheel override	s	+		PGsl
FENDNORM ⁶⁾	G	Corner deceleration OFF	m	+		PGAsl
FFWOF ⁶⁾	G	Feedforward control OFF	m	+		PGAsl
FFWON	G	Feedforward control ON	m	+		PGAsl
FGREF	K	Reference radius for rotary axes or path reference factors for orientation axes (vector interpolation)	m	+		PGsl
FGROUP	P	Definition of axis/axes with path feedrate		+	-	PGsl
FI	K	Parameter for access to frame data: Fine offset		+		PGAsl
FIFOCTRL	G	Control of preprocessing buffer	m	+		PGAsl
FILEDATE	P	Returns date of most recent write access to file		+	-	PGAsl
FILEINFO	P	Returns summary information listing FILEDATE, FILESIZE, FILESTAT, and FILETIME		+	-	PGAsl
FILESIZE	P	Returns current file size		+	-	PGAsl
FILESTAT	P	Returns file status of rights for read, write, execute, display, delete (rwxsd)		+	-	PGAsl
FILETIME	P	Returns time of most recent write access to file		+	-	PGAsl
FINEA	K	End of motion when "Exact stop fine" reached	m	+		PGAsl
FL	K	Limit velocity for synchronized axis	m	+		PGsl
FLIN	G	Feed linear variable	m	+		PGAsl
FMA	K	Multiple feedrates axial	m	+		PGsl
FNORM ⁶⁾	G	Feedrate normal to DIN 66025	m	+		PGAsl
FOC	K	Non-modal torque/force limitation	s	-	+	FBSYsl
FOCOF	K	Switch off modal torque/force limitation	m	-	+	FBSYsl
FOCON	K	Switch on modal torque/force limitation	m	-	+	FBSYsl
FOR	K	Counter loop with fixed number of passes		+		PGAsl
FP	A	Fixed point: Number of fixed point to be approached	s	+		PGsl
FPO	K	Feedrate characteristic programmed via a polynomial		+		PGAsl
FPR	P	Rotary axis identifier		+	-	PGsl
FPRAOF	P	Deactivate revolutional feedrate		+	-	PGsl
FPRAON	P	Activate revolutional feedrate		+	-	PGsl
FRAME	K	Data type for the definition of coordinate systems		+		PGAsl
FRC	A	Feedrate for radius and chamfer	s	+		PGsl
FRCM	A	Feedrate for radius and chamfer, modal	m	+		PGsl
FROM	K	The action is executed if the condition is fulfilled once and as long as the synchronized action is active		-	+	FBSYsl
FTOC	P	Change fine tool offset		-	+	FBSYsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
FTOCOF ⁶⁾	G	Online fine tool offset OFF	m	+		PGAsl
FTOCON	G	Online fine tool offset ON	m	+		PGAsl
FXS	K	Travel to fixed stop ON	m	+	+	PGsl
FXST	K	Torque limit for travel to fixed stop	m	+	+	PGsl
FXSW	K	Monitoring window for travel to fixed stop		+	+	PGsl
FZ	K	Tooth feedrate	m	+		PGsl

Operations G ... L

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1)2)3)4)5) for explanations, see legend (Page 1272).						
G0	G	Linear interpolation with rapid traverse (rapid traverse motion)	m	+		PGsl
G1 ⁶⁾	G	Linear interpolation with feedrate (linear interpolation)	m	+		PGsl
G2	G	Circular interpolation clockwise	m	+		PGsl
G3	G	Circular interpolation counter-clockwise	m	+		PGsl
G4	G	Dwell time, preset	s	+		PGsl
G5	G	Oblique plunge-cut grinding	s	+		PGAsl
G7	G	Compensatory motion during oblique plunge-cut grinding	s	+		PGAsl
G9	G	Exact stop - deceleration	s	+		PGsl
G17 ⁶⁾	G	Selection of working plane X/Y	m	+		PGsl
G18	G	Selection of working plane Z/X	m	+		PGsl
G19	G	Selection of working plane Y/Z	m	+		PGsl
G25	G	Lower working area limitation	s	+		PGsl
G26	G	Upper working area limitation	s	+		PGsl
G33	G	Thread cutting with constant lead	m	+		PGsl
G34	G	Thread cutting with linear increasing lead	m	+		PGsl
G35	G	Thread cutting with linear decreasing lead	m	+		PGsl
G40 ⁶⁾	G	Tool radius compensation OFF	m	+		PGsl
G41	G	Tool radius compensation left of contour	m	+		PGsl
G42	G	Tool radius compensation right of contour	m	+		PGsl
G53	G	Suppression of current zero offset (non-modal)	s	+		PGsl
G54	G	1st settable zero offset	m	+		PGsl
G55	G	2nd settable zero offset	m	+		PGsl
G56	G	3rd settable zero offset	m	+		PGsl
G57	G	4th settable zero offset	m	+		PGsl
G58 (840D sl)	G	Absolute programmable work offset (coarse offset)	s	+		PGsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
G58 (828D)	G	5th settable zero offset	m	+		PGsl
G59 (840D sl)	G	Additive programmable work offset (fine offset)	s	+		PGsl
G59 (828D)	G	6th settable zero offset	m	+		PGsl
G60 ⁶⁾	G	Exact stop - deceleration	m	+		PGsl
G62	G	Corner deceleration at inside corners when tool radius offset is active (G41, G42)	m	+		PGAsl
G63	G	Tapping with compensating chuck	s	+		PGsl
G64	G	Continuous-path mode	m	+		PGsl
G70	G	Inch dimensions for geometric specifications (lengths)	m	+	+	PGsl
G71 ⁶⁾	G	Metric dimensions for geometric specifications (lengths)	m	+	+	PGsl
G74	G	Search for reference	s	+		PGsl
G75	G	Fixed point approach	s	+		PGsl
G90 ⁶⁾	G	Absolute dimensions	m/s	+		PGsl
G91	G	Incremental dimensions	m/s	+		PGsl
G93	G	Inverse-time feedrate rpm	m	+		PGsl
G94 ⁶⁾	G	Linear feedrate F in mm/min or inch/min and degree/min	m	+		PGsl
G95	G	Revolutional feedrate F in mm/rev or inch/rev	m	+		PGsl
G96	G	Revolutional feedrate (as for G95) and constant cutting rate	m	+		PGsl
G97	G	Revolutional feedrate and constant spindle speed (constant cutting rate OFF)	m	+		PGsl
G110	G	Pole programming relative to the last programmed setpoint position	s	+		PGsl
G111	G	Pole programming relative to zero of current workpiece coordinate system	s	+		PGsl
G112	G	Pole programming relative to the last valid pole	s	+		PGsl
G140 ⁶⁾	G	SAR approach direction defined by G41/G42	m	+		PGsl
G141	G	SAR approach direction to left of contour	m	+		PGsl
G142	G	SAR approach direction to right of contour	m	+		PGsl
G143	G	SAR approach direction tangent-dependent	m	+		PGsl
G147	G	Soft approach with straight line	s	+		PGsl
G148	G	Soft retraction with straight line	s	+		PGsl
G153	G	Suppression of current frames including basic frame	s	+		PGsl
G247	G	Soft approach with quadrant	s	+		PGsl
G248	G	Soft retraction with quadrant	s	+		PGsl
G290 ⁶⁾	G	Switch over to SINUMERIK mode ON	m	+		FBWsl
G291	G	Switch over to ISO2/3 mode ON	m	+		FBWsl
G331	G	Rigid tapping, positive lead, clockwise	m	+		PGsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
^{1) 2) 3) 4) 5)} for explanations, see legend (Page 1272).						
G332	G	Rigid tapping, negative lead, counter-clockwise	m	+		PGsl
G335	G	Turning a convex thread in clockwise direction	m	+		PGsl
G336	G	Turning a convex thread in counter-clockwise direction	m	+		PGsl
G340 ⁶⁾	G	Spatial approach block (depth and in plane at the same time (helix))	m	+		PGsl
G341	G	Initial infeed on perpendicular axis (z), then approach in plane	m	+		PGsl
G347	G	Soft approach with semicircle	s	+		PGsl
G348	G	Soft retraction with semicircle	s	+		PGsl
G450 ⁶⁾	G	Transition circle	m	+		PGsl
G451	G	Intersection of equidistances	m	+		PGsl
G460 ⁶⁾	G	Activation of collision detection for the approach and retraction block	m	+		PGsl
G461	G	Insertion of a circle into the TRC block	m	+		PGsl
G462	G	Insertion of a straight line into the TRC block	m	+		PGsl
G500 ⁶⁾	G	Deactivation of all adjustable frames, basic frames are active	m	+		PGsl
G505 ... G599	G	5 ... 99 Settable work offset	m	+		PGsl
G601 ⁶⁾	G	Block change at exact stop fine	m	+		PGsl
G602	G	Block change at exact stop coarse	m	+		PGsl
G603	G	Block change at IPO block end	m	+		PGsl
G621	G	Corner deceleration at all corners	m	+		PGAsl
G641	G	Continuous-path mode with smoothing as per distance criterion (= programmable rounding clearance)	m	+		PGsl
G642	G	Continuous-path mode with smoothing within the defined tolerances	m	+		PGsl
G643	G	Continuous-path mode with smoothing within the defined tolerances (block-internal)	m	+		PGsl
G644	G	Continuous-path mode with smoothing with maximum possible dynamic response	m	+		PGsl
G645	G	Continuous-path mode with smoothing and tangential block transitions within the defined tolerances	m	+		PGsl
G700	G	Inch dimensions for geometric and technological specifications (lengths, feedrate)	m	+	+	PGsl
G710 ⁶⁾	G	Metric dimensions for geometric and technological specifications (lengths, feedrate)	m	+	+	PGsl
G810 ⁶⁾ , ..., G819	G	G group reserved for the OEM user		+		PGAsl
G820 ⁶⁾ , ..., G829	G	G group reserved for the OEM user		+		PGAsl
G931	G	Feedrate specified by means of traversing time, deactivate constant path velocity	m	+		

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
G942	G	Freeze linear feedrate and constant cutting rate or spindle speed	m	+		
G952	G	Freeze revolutional feedrate and constant cutting rate or spindle speed	m	+		
G961	G	Linear feedrate (as for G94) and constant cutting rate	m	+		PGsI
G962	G	Linear feedrate or revolutional feedrate and constant cutting rate	m	+		PGsI
G971	G	Linear feedrate and constant spindle speed (constant cutting rate OFF)	m	+		PGsI
G972	G	Linear feedrate or revolutional feedrate and constant spindle speed (constant cutting rate OFF)	m	+		PGsI
G973	G	Revolutional feedrate without spindle speed limitation and constant spindle speed (G97 without LIMS for ISO mode)	m	+		PGsI
GEOAX	P	Assign new channel axes to geometry axes 1 - 3		+	-	PGAsI
GET	P	Replace enabled axis between channels		+	+	PGAsI
GETACTT	F	Gets active tool from a group of tools with the same name		+	-	FBWsl
GETACTTD	F	Gets the T number associated with an absolute D number		+	-	PGAsI
GETD	P	Replace axis directly between channels		+	-	PGAsI
GETDNO	F	Returns the D number of a cutting edge (CE) of a tool (T)		+	-	PGAsI
GETEXET	P	Reading of the loaded T number		+	-	FBWsl
GETFREELOC	P	Find a free space in the magazine for a given tool		+	-	FBWsl
GETSELT	P	Return selected T number		+	-	FBWsl
GETT	F	Get T number for tool name		+	-	FBWsl
GETTCOR	F	Read out tool lengths and/or tool length components		+	-	PGAsI
GETTENV	F	Read T, D and DL numbers		+	-	PGAsI
GETVARAP	F	Read access rights to a system/user variable		+	-	PGAsI
GETVARDFT	F	Read default value of a system/user variable		+	-	PGAsI
GETVARLIM	F	Read limit values of a system/user variable		+	-	PGAsI
GETVARPHU	F	Read physical unit of a system/user variable		+	-	PGAsI
GETVARTYP	F	Read data type of a system/user variable		+	-	PGAsI
GFRAME0 ... GFRAME100	G	Activation of the grinding frame <n> of the data management in channel	m	+		PGsI
GOTO	K	Jump operation first forward then backward (direction initially to end of program and then to beginning of program)		+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
GOTOB	K	Jump backward (toward the beginning of the program)		+		PGAsI
GOTOC	K	As GOTO, but suppress alarm 14080 "Jump destination not found"		+		PGAsI
GTOF	K	Jump forward (toward the end of the program)		+		PGAsI
GOTOS	K	Jump back to beginning of program		+		PGAsI
GP	K	Keyword for the indirect programming of position attributes		+		PGAsI
GROUP_ADDEND	C (T)	End of trial cut addition		+		PGAsI
GROUP_BEGIN	C (T)	Beginning of program group		+		PGAsI
GROUP_END	C (T)	End of program group		+		PGAsI
GWPSOF	P	Deselect constant grinding wheel peripheral speed (GWPS)	s	+	-	PGsI
GWPSON	P	Select constant grinding wheel peripheral speed (GWPS)	s	+	-	PGsI
H...	O	Auxiliary function output to the PLC		+	+	PGsI/FB1sI (H2)
HOLES1	C (T)	Row of holes		+		PGAsI
HOLES2	C (T)	Circle of holes		+		PGAsI
I	O	Interpolation parameters	s	+		PGsI
I1	O	Intermediate point coordinate	s	+		PGsI
IC	K	Incremental dimensions	s	+		PGsI
ICYCOF	P	All blocks of a technology cycle are processed in one interpolation cycle following ICYCOF		+	+	FBSYsI
ICYCON	P	Each block of a technology cycle is processed in a separate interpolation cycle following ICYCON		+	+	FBSYsI
ID	K	Identifier for modal synchronized actions	m	-	+	FBSYsI
IDS	K	Identifier for modal static synchronized actions		-	+	FBSYsI
IF	K	Introduction of a conditional jump in the part program/technology cycle		+	+	PGAsI
INDEX	F	Define index of character in input string		+	-	PGAsI
INICF	K	Initialization of variables for NEWCONF		+		PGAsI
INIPO	K	Initialization of variables at POWER ON		+		PGAsI
INIRE	K	Initialization of variables at reset		+		PGAsI
INIT	P	Selection of a particular NC program for execution in a particular channel		+	-	PGAsI
INITIAL		Generation of an INI file across all areas		+		PGAsI
INT	K	Data type: Integer with sign		+		PGAsI
INTERSEC	F	Calculate intersection between two contour elements		+	-	PGAsI
INVCCW	G	Trace involute, counter-clockwise	m	+		PGsI
INVCW	G	Trace involute, clockwise	m	+		PGsI
INVFRAME	F	Calculate the inverse frame from a frame		+	-	FB1sI (K2)

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
IP	K	Variable interpolation parameter		+		PGAsI
IPOBRKA	P	Motion criterion from braking ramp activation	m	+	+	
IPOENDA	K	End of motion when "IPO stop" reached	m	+		PGAsI
IPTRLOCK	P	Freeze start of the untraceable program section at next machine function block.	m	+	-	PGAsI
IPTRUNLOCK	P	Set end of untraceable program section at current block at time of interruption.	m	+	-	PGAsI
IR	O	Center of circle coordinate (X axis) when turning a convex thread		+		PGsI
ISAXIS	F	Check if geometry axis 1 specified as parameter		+	-	PGAsI
ISD	O	Insertion depth	m	+		PGAsI
ISFILE	F	Check whether the file exists in the NC application memory		+	-	PGAsI
ISNUMBER	F	Check whether the input string can be converted to a number		+	-	PGAsI
ISOCALL	K	Indirect call of a program programmed in an ISO language		+		PGAsI
ISVAR	F	Check whether the transfer parameter contains a variable declared in the NC		+	-	PGAsI
J	O	Interpolation parameters	s	+		PGsI
J1	O	Intermediate point coordinate	s	+		PGsI
JERKA	P	Activate acceleration response set via MD for programmed axes		+	-	
JERKLIM	K	Reduction or overshoot of maximum axial jerk	m	+		PGAsI
JERKLIMA	K	Reduction or overshoot of maximum axial jerk	m	+	+	PGAsI
JR	O	Center of circle coordinate (Y axis) when turning a convex thread		+		PGsI
K	O	Interpolation parameters	s	+		PGsI
K1	O	Intermediate point coordinate	s	+		PGsI
KONT	G	Travel around contour on tool offset	m	+		PGsI
KONTC	G	Approach/retract with continuous-curvature polynomial	m	+		PGsI
KONTT	G	Approach/retract with continuous-tangent polynomial	m	+		PGsI
KR	O	Center of circle coordinate (Z axis) when turning a convex thread		+		PGsI
L	O	Subprogram number	s	+	+	PGAsI
LEAD	O	Lead angle 1st basic tool orientation 2nd orientation polynomials	m	+		PGAsI
LEADOF	P	Axial master value coupling OFF		+	+	PGAsI
LEADON	P	Axial master value coupling on		+	+	PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
LENTOAX	F	Provides information about the assignment of tool lengths L1, L2, and L3 of the active tool to the abscissa, ordinate and applicate		+	-	PGAsI
LFOF ⁶⁾	G	Fast retraction for thread cutting OFF	m	+		PGsI
LFON	G	Fast retraction for thread cutting ON	m	+		PGsI
LFPOS	G	Retraction of the axis declared with POLF-MASK or POLFMLIN to the absolute axis position programmed with POLF	m	+		PGsI
LFTXT ⁶⁾	G	The plane of the retraction movement for fast retraction is determined from the path tangent and the current tool direction	m	+		PGsI
LFWP	G	The plane of the retraction movement for fast retraction is determined by the current working plane (G17/G18/G19)	m	+		PGsI
LIFTFAST	K	Fast retraction		+		PGsI
LIMS	K	Speed limitation for G96/G961 and G97	m	+		PGsI
LLI	K	Lower limit value of variables		+		PGAsI
LN	F	Natural logarithm		+	+	PGAsI
LOCK	P	Disable synchronized action with ID (stop technology cycle)		-	+	FBSysI
LONGHOLE	C (T)	Elongated hole		+		PGAsI
LOOP	K	Introduction of an endless loop		+		PGAsI

Operations M ... R

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
M0		Programmed stop		+	+	PGsI
M1		Optional stop		+	+	PGsI
M2		End of program, main program (as M30)		+	+	PGsI
M3		CW spindle rotation		+	+	PGsI
M4		CCW spindle rotation		+	+	PGsI
M5		Spindle stop		+	+	PGsI
M6		Tool change		+	+	PGsI
M17		End of subprogram		+	+	PGsI
M19		Spindle positioning to the position entered in SD43240		+	+	PGsI
M30		End of program, main program (as M2)		+	+	PGsI
M40		Automatic gear change		+	+	PGsI
M41 ... M45		Gear stage 1 ... 5		+	+	PGsI
M70		Transition to axis mode		+	+	PGsI

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
MASLDEF	P	Define master/slave axis grouping		+	+	PGAsI
MASLDEL	P	Uncouple master/slave axis grouping and clear grouping definition		+	+	PGAsI
MASLOF	P	Deactivation of a temporary coupling		+	+	PGAsI
MASLOFS	P	Deactivation of a temporary coupling with automatic slave axis stop		+	+	PGAsI
MASLON	P	Activation of a temporary coupling		+	+	PGAsI
MATCH	F	Search for string in string		+	-	PGAsI
MAXVAL	F	Larger value of two variables (arithm. function)		+	+	PGAsI
MCALL	K	Modal subprogram call		+		PGAsI
MEAC	K	Continuous axial measurement without delete distance-to-go	s	+	+	PGAsI
MEAFRAME	F	Frame calculation from measuring points		+	-	PGAsI
MEAS	O	Measurement with deletion of distance-to-go	s	+		PGAsI
MEASA	K	Axial measurement with delete distance-to-go	s	+	+	PGAsI
MEASURE	F	Calculation method for workpiece and tool measurement		+	-	FB1sI (M5)
MEAW	O	Measurement without delete distance-to-go	s	+		PGAsI
MEAWA	K	Axial measurement without delete distance-to-go	s	+	+	PGAsI
MI	K	Access to frame data: Mirroring		+		PGAsI
MINDEX	F	Define index of character in input string		+	-	PGAsI
MINVAL	F	Smaller value of two variables (arithm. function)		+	+	PGAsI
MIRROR	G	Programmable mirroring	s	+		PGAsI
MMC	P	Call the dialog window interactively from the part program on the HMI		+	-	PGAsI
MOD	K	Modulo division		+		PGAsI
MODAXVAL	F	Determine modulo position of a modulo rotary axis		+	-	PGAsI
MOV	K	Start positioning axis		-	+	FBSYsI
MOVTT	O	Specify end point of a traversing motion in the tool direction				FB1(K2)
MSG	P	Programmable messages	m	+	-	PGsI
MVTOOL	P	Language command to move tool		+	-	FBWsl
N	O	NC auxiliary block number		+		PGsI
NAMETOINT	F	Determining the system variable index		+		PGAsI
NC	K	Specify validity range for data		+		PGAsI
NEWCONF	P	Apply modified machine data (corresponds to "Activate machine data")		+	-	PGAsI
NEWMT	F	Create new multitool		+	-	FBWsl
NEWT	F	Create new tool		+	-	FBWsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
NORM ⁶⁾	G	Standard setting in starting point and end point with tool offset	m	+		PGsI
NOT	K	Logic NOT (negation)		+		PGAsI
NPROT	P	Machine-specific protection area ON/OFF		+	-	PGAsI
NPROTDEF	P	Definition of a machine-specific protection area		+	-	PGAsI
NUMBER	F	Convert input string to number		+	-	PGAsI
OEMIPO1	G	OEM interpolation 1	m	+		PGAsI
OEMIPO2	G	OEM interpolation 2	m	+		PGAsI
OF	K	Keyword in CASE branch		+		PGAsI
OFFN	O	Allowance on the programmed contour	m	+		PGsI
OMA1	O	OEM address 1	m	+		PGAsI
OMA2	O	OEM address 2	m	+		PGAsI
OMA3	O	OEM address 3	m	+		PGAsI
OMA4	O	OEM address 4	m	+		PGAsI
OMA5	O	OEM address 5	m	+		PGAsI
OR	K	Logic operator, OR operation		+		PGAsI
ORIXES	G	Linear interpolation of machine axes or orientation axes	m	+		PGAsI
ORIXPOS	G	Orientation angle via virtual orientation axes with rotary axis positions	m	+		PGAsI
ORIC ⁶⁾	G	Orientation changes at outside corners are superimposed on the circle block to be inserted	m	+		PGAsI
ORICONCCW	G	Interpolation on a circular peripheral surface in CCW direction	m	+		PGAsI/FB3sI (F3)
ORICONCW	G	Interpolation on a circular peripheral surface in CW direction	m	+		PGAsI/FB3sI (F4)
ORICONIO	G	Interpolation on a circular peripheral surface with intermediate orientation setting	m	+		PGAsI/FB3sI (F4)
ORICONTO	G	Interpolation on circular peripheral surface in tangential transition (final orientation)	m	+		PGAsI/FB3sI (F5)
ORICURVE	G	Interpolation of orientation with specification of motion of two contact points of tool	m	+		PGAsI/FB3sI (F6)
ORID	G	Orientation changes are performed before the circle block	m	+		PGAsI
ORIEULER ⁶⁾	G	Orientation angle via Euler angle	m	+		PGAsI
ORIMKS	G	Tool orientation in the machine coordinate system	m	+		PGAsI
ORIPATH	G	Tool orientation in relation to path	m	+		PGAsI
ORIPATHS	G	Tool orientation in relation to path, blips in the orientation characteristic are smoothed	m	+		PGAsI

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
ORIPLANE	G	Interpolation in a plane (corresponds to ORIVECT), large-radius circular interpolation	m	+		PGAsI
ORIRESET	P	Initial tool orientation with up to 3 orientation axes		+	-	PGAsI
ORIROTA ⁶⁾	G	Angle of rotation to an absolute direction of rotation	m	+		PGAsI
ORIROTC	G	Tangential rotational vector in relation to path tangent	m	+		PGAsI
ORIROTR	G	Angle of rotation relative to the plane between the start and end orientation	m	+		PGAsI
ORIROTT	G	Angle of rotation relative to the change in the orientation vector	m	+		PGAsI
ORIRPY	G	Orientation angle via RPY angle (XYZ)	m	+		PGAsI
ORIRPY2	G	Orientation angle via RPY angle (ZYX)	m	+		PGAsI
ORIS	O	Change in orientation	m	+		PGAsI
ORISOF ⁶⁾	G	Smoothing of the orientation characteristic OFF	m	+		PGAsI
ORISOLH	F	Calculate orientations		+		PGAsI
ORISON	G	Smoothing of the orientation characteristic ON	m	+		PGAsI
ORIVECT ⁶⁾	G	Large-circle interpolation (identical to ORIPLANE)	m	+		PGAsI
ORIVIRT1	G	Orientation angle via virtual orientation axes (definition 1)	m	+		PGAsI
ORIVIRT2	G	Orientation angle via virtual orientation axes (definition 1)	m	+		PGAsI
ORIWKS ⁶⁾	G	Tool orientation in the workpiece coordinate system	m	+		PGAsI
OS	K	Oscillation on/off		+		PGAsI
OSB	K	Oscillating: Starting point	m	+		FB1sl (P5)
OSC	G	Continuous tool orientation smoothing	m	+		PGAsI
OSCILL	K	Axis: 1 - 3 infeed axes	m	+		PGAsI
OSCTRL	K	Oscillation options	m	+		PGAsI
OSD	G	Smoothing of tool orientation by specifying smoothing distance with SD	m	+		PGAsI
OSE	K	Oscillation end position	m	+		PGAsI
OSNSC	K	Oscillating: Number of spark-out cycles	m	+		PGAsI
OSOF ⁶⁾	G	Tool orientation smoothing OFF	m	+		PGAsI
OSP1	K	Oscillating: Left reversal point	m	+		PGAsI
OSP2	K	Oscillation right reversal point	m	+		PGAsI
OSS	G	Tool orientation smoothing at end of block	m	+		PGAsI
OSSE	G	Tool orientation smoothing at start and end of block	m	+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
^{1) 2) 3) 4) 5)} for explanations, see legend (Page 1272).						
OST	G	Smoothing of tool orientation by specifying angular tolerance in degrees with SD (maximum deviation from programmed orientation characteristic)	m	+		PGAsl
OST1	K	Oscillating: Stopping point in left reversal point	m	+		PGAsl
OST2	K	Oscillating: Stopping point in right reversal point	m	+		PGAsl
OTOL	A	Orientation tolerance for compressor functions, orientation smoothing and smoothing types	m	+		PGAsl
OVR	K	Speed offset	m	+		PGAsl
OVRA	K	Axial speed offset	m	+	+	PGAsl
OVRRAP	K	Rapid traverse override	m	+		PGAsl
P	O	Number of subprogram repetitions		+		PGAsl
PAROT	G	Align workpiece coordinate system on workpiece	m	+		PGsl
PAROTOF ⁶⁾	G	Deactivate frame rotation in relation to workpiece	m	+		PGsl
PCALL	K	Call subprograms with absolute path and parameter transfer		+		PGAsl
PDELAYOF	G	Punching with delay OFF	m	+		PGAsl
PDELAYON ⁶⁾	G	Punching with delay ON	m	+		PGAsl
PHI	K	Angle of rotation of the orientation around the direction axis of the taper		+		PGAsl
PHU	K	Physical unit of a variable		+		PGAsl
PL	O	1. B spline: Node clearance 2. Polynomial interpolation Length of the parameter interval for polynomial interpolation	s	+		PGAsl
PM	K	Per minute		+		PGsl
PO	K	Polynomial coefficient for polynomial interpolation	s	+		PGAsl
POCKET3	C (T)	Milling the rectangular pocket		+		PGAsl
POCKET4	C (T)	Milling the circular pocket		+		PGAsl
POLF	K	LIFTFAST retraction position	m	+		PGsl/PGAsl
POLFA	P	Start retraction position of single axes with \$AA_ESR_TRIGGER	m	+	+	PGsl
POLFMASK	P	Enable axes for retraction without a connection between the axes	m	+	-	PGsl
POLFMLIN	P	Enable axes for retraction with a linear connection between the axes	m	+	-	PGsl
POLY	G	Polynomial interpolation	m	+		PGAsl
POLYPATH	P	Polynomial interpolation can be selected for the AXIS or VECT axis groups	m	+	-	PGAsl
PON	G	Punching ON	m	+		PGAsl
PONS	G	Punching ON in interpolation cycle	m	+		PGAsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
POS	K	Axis positioning		+	+	PGsl
POSA	K	Position axis across block boundary		+	+	PGsl
POSM	P	Position magazine		+	-	FBWsl
POSMT	P	Position multitool on toolholder at location number		+	-	FBWsl
POSP	K	Positioning axis in parts (oscillation)		+		PGsl
POSRANGE	F	Determine whether the currently interpolated position setpoint of an axis is located in a window at a predefined reference position		+	+	FBSYsl
POT	F	Square (arithmetic function)		+	+	PGAsl
PR	K	Per revolution		+		PGsl
PREPRO	PA	Identify subprograms with preparation		+		PGAsl
PRESETON	P	Actual value setting with loss of the referencing status		+	+	PGAsl
PRESETONS	P	Actual value setting with loss of the referencing status		+	+	PGAsl
PRIO	K	Keyword for setting the priority for interrupt processing		+		PGAsl
PRLOC	K	Initialization of variables at reset only after local change		+		PGAsl
PROC	K	First operation in a program		+		PGAsl
PROTA	P	Request for a recalculation of the collision model		+		PGAsl
PROTD	F	Calculating the distance between two protection areas		+		PGAsl
PROTS	P	Setting the protection area status		+		PGAsl
PSI	K	Opening angle of the taper		+		PGAsl
PTP	G	Point-to-point motion (PTP travel)	m	+		PGAsl
PTPG0	G	Point-to-point motion only with G0, otherwise path motion CP	m	+		PGAsl
PTPWOC	G	Point-to-point motion without compensation movements caused by changes in orientation	m	+		PGAsl
PUNCHACC	P	Travel-dependent acceleration for nibbling		+	-	PGAsl
PUTFTOC	P	Tool fine offset for parallel dressing		+	-	PGAsl
PUTFTOCF	P	Tool fine offset dependent on a function for parallel dressing defined with FCTDEF		+	-	PGAsl
PW	O	B spline, point weight	s	+		PGAsl
QU	K	Fast additional (auxiliary) function output		+		PGsl
R...	O	Arithmetic parameter also as settable address identifier and with numerical extension		+		PGAsl
RAC	K	Absolute non-modal axis-specific radius programming	s	+		PGsl
RDISABLE	P	Read-in disable		-	+	FBSYsl

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
^{1) 2) 3) 4) 5)} for explanations, see legend (Page 1272).						
READ	P	Reads one or more lines in the specified file and stores the information read in the array		+	-	PGAsI
REAL	K	Data type: Floating-point variable with sign (real numbers)		+		PGAsI
REDEF	K	Redefinition of system variables, user variables, and NC language commands		+		PGAsI
RELEASE	P	Release machine axes for axis exchange		+	+	PGAsI
REP	K	Keyword for initialization of all elements of an array with the same value		+		PGAsI
REPEAT	K	Repetition of a program loop		+		PGAsI
REPEATB	K	Repetition of a program line		+		PGAsI
REPOSA	G	Linear repositioning with all axes	s	+		PGAsI
REPOSH	G	Repositioning with semicircle	s	+		PGAsI
REPOSHA	G	Repositioning with all axes; geometry axes in semicircle	s	+		PGAsI
REPOSL	G	Linear repositioning	s	+		PGAsI
REPOSQ	G	Repositioning in a quadrant	s	+		PGAsI
REPOSQA	G	Linear repositioning with all axes, geometry axes in quadrant	s	+		PGAsI
RESETMON	P	Language command for setpoint activation		+	-	FBWsl
RET	P	End of subprogram		+	+	PGAsI
RETB	P	End of subprogram		+	+	PGAsI
RIC	K	Relative non-modal axis-specific radius programming	s	+		PGsl
RINDEX	F	Define index of character in input string		+	-	PGAsI
RMB	G	Repositioning to start of block	m	+		PGAsI
RMBBL	G	Repositioning to start of block	s	+		PGAsI
RME	G	Repositioning to end of block	m	+		PGAsI
RMEBL	G	Repositioning to end of block	s	+		PGAsI
RMI ⁶⁾	G	Repositioning to interrupt point	m	+		PGAsI
RMIBL ⁶⁾	G	Repositioning to interrupt point	s	+		PGAsI
RMN	G	Repositioning to the nearest path point	m	+		PGAsI
RMNBL	G	Repositioning to the nearest path point	s	+		PGAsI
RND	O	Round the contour corner	s	+		PGsl
RNDM	O	Modal rounding	m	+		PGsl
ROT	G	Programmable rotation	s	+		PGsl
ROTS	G	Programmable frame rotations with solid angles	s	+		PGsl
ROUND	F	Rounding of decimal places		+	+	PGAsI
ROUNDUP	F	Rounding up of an input value		+	+	PGAsI
RP	O	Polar radius	m/s	+		PGsl
RPL	O	Rotation in the plane	s	+		PGsl
RT	K	Parameter for access to frame data: Rotation		+		PGAsI

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
RTLIOF	G	G0 without linear interpolation (single-axis interpolation)	m	+		PGsI
RTLION ⁶⁾	G	G0 with linear interpolation	m	+		PGsI

Operations S ... Z

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
S	A	Spindle speed (with G4, G96/G961 different meaning)	m/s	+	+	PGsI
SAVE	PA	Attribute for saving information when subprograms are called		+		PGAsI
SBLOF	P	Suppress single block		+	-	PGAsI
SBLON	P	Revoke suppression of single block		+	-	PGAsI
SC	K	Parameter for access to frame data: Scaling		+		PGAsI
SCALE	G	Programmable scaling	s	+		PGsI
SCC	K	Selective assignment of transverse axis to G96/G961/G962. Axis identifiers may take the form of geometry, channel or machine axes.		+		PGsI
SCPARA	K	Program servo parameter set		+	+	PGAsI
SD	A	Spline degree	s	+		PGAsI
SET	K	Keyword for initialization of all elements of an array with listed values		+		PGAsI
SETAL	P	Set alarm		+	+	PGAsI
SETDNO	F	Assign the D number of a cutting edge (CE) of a tool (T)		+	-	PGAsI
SETINT	K	Define which interrupt routine is to be activated when an NC input is present		+		PGAsI
SETM	P	Setting of markers in dedicated channel		+	+	PGAsI
SETMS	P	Reset to the master spindle defined in machine data		+	-	PGsI
SETMS(n)	P	Set spindle n as master spindle		+		PGsI
SETMTH	P	Set master toolholder number		+	-	FBWsl
SETPIECE	P	Set piece number for all tools assigned to the spindle		+	-	FBWsl
SETTA	P	Activate tool from wear group		+	-	FBWsl
SETTCOR	F	Modification of tool components taking all supplementary conditions into account		+	-	PGAsI
SETTIA	P	Deactivate tool from wear group		+	-	FBWsl
SF	A	Starting point offset for thread cutting	m	+		PGsI
SIN	F	Sine (trigon. function)		+	+	PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
SIRELAY	F	Activate the safety functions parameterized with SIRELIN, SIRELOUT, and SIRELTIME		-	+	FBSIsl
SIRELIN	P	Initialize input variables of function block		+	-	FBSIsl
SIRELOUT	P	Initialize output variables of function block		+	-	FBSIsl
SIRELTIME	P	Initialize timers of function block		+	-	FBSIsl
SLOT1	C (T)	Longitudinal groove		+		PGAsl
SLOT2	C (T)	Circumferential groove		+		PGAsl
SOFT	G	Soft path acceleration	m	+		PGAsl
SOFTA	P	Activate jerk-limited axis acceleration for the programmed axes		+	-	PGAsl
SON	G	Nibbling ON	m	+		PGAsl
SONS	G	Nibbling ON in interpolation cycle	m	+		PGAsl
SPATH ⁶⁾	G	Path reference for FGROUP axes is arc length	m	+		PGAsl
SPCOF	P	Switch master spindle or spindle(s) from position control to speed control	m	+	-	PGsl
SPCON	P	Switch master spindle or spindle(s) from speed control to position control	m	+	-	PGAsl
SPI	F	Converts spindle number into axis identifier		+	-	PGAsl
SPIF1 ⁶⁾	G	Fast NC inputs/outputs for punching/nibbling byte 1	m	+		FB2sl (N4)
SPIF2	G	Fast NC inputs/outputs for punching/nibbling byte 2	m	+		FB2sl (N4)
SPLINEPATH	P	Define spline grouping		+	-	PGAsl
SPN	A	Number of path sections per block	s	+		PGAsl
SPOF ⁶⁾	G	Stroke OFF, nibbling, punching OFF	m	+		PGAsl
SPOS	K	Spindle position	m	+	+	PGsl
SPOSA	K	Spindle position across block boundaries	m	+		PGsl
SPP	A	Length of a path section	m	+		PGAsl
SPRINT	F	Returns an input string formatted		+		PGAsl
SQRT	F	Square root (arithmetic function)		+	+	PGAsl
SR	A	Oscillation retraction path for synchronized action	s	+		PGsl
SRA	K	Oscillation retraction path with external input axial for synchronized action	m	+		PGsl
ST	A	Oscillation sparking-out time for synchronized action	s	+		PGsl
STA	K	Oscillation sparking-out time axial for synchronized action	m	+		PGsl
START	P	Start selected programs simultaneously in several channels from current program		+	-	PGAsl
STARTFIFO ⁶⁾	G	Execute; fill preprocessing memory simultaneously	m	+		PGAsl

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
STAT		Position of joints	s	+		PGAsI
STOLF	A	G0 tolerance factor	m	+		PGAsI
STOPFIFO	G	Stop machining; fill preprocessing memory until STARTFIFO is detected, preprocessing memory is full or end of program	m	+		PGAsI
STOPRE	P	Preprocessing stop until all prepared blocks in the main run are executed		+	-	PGAsI
STOPREOF	P	Revoke preprocessing stop		-	+	FBSYsI
STRING	K	Data type: Character string		+		PGAsI
STRINGIS	F	Checks the present scope of NC language and the NC cycle names, user variables, macros, and label names belonging specifically to this command to establish whether these exist, are valid, defined or active.		+	-	PGAsI
STRLEN	F	Define string length		+	-	PGAsI
SUBSTR	F	Define index of character in input string		+	-	PGAsI
SUPA	G	Suppression of current work offset, including programmed offsets, system frames, hand-wheel offsets (DRF), external work offset, and overlaid movement	s	+		PGsI
SVC	K	Tool cutting rate	m	+		PGsI
SYNFCT	P	Evaluation of a polynomial as a function of a condition in the motion-synchronous action		-	+	FBSYsI
SYNR	K	The variable is read synchronously, i.e. at the time of execution		+		PGAsI
SYNRW	K	The variable is read and written synchronously, i.e. at the time of execution		+		PGAsI
SYNW	K	The variable is written synchronously, i.e. at the time of execution		+		PGAsI
T	A	Call tool (only change if specified in machine data; otherwise M6 command necessary)		+		PGsI
TAN	F	Tangent (trigon. function)		+	+	PGAsI
TANG	P	Tangential control: Define coupling		+	-	PGAsI
TANGDEL	P	Tangential control: Delete coupling		+	-	PGAsI
TANGOF	P	Tangential control: Deactivate coupling		+	-	PGAsI
TANGON	P	Tangential control: Activate coupling		+	-	PGAsI
TCA (828D: _TCA)	P	Tool selection/tool change irrespective of tool status		+	-	FBWsI
TCARR	A	Request toolholder (number "m")		+		PGAsI
TCI	P	Load tool from buffer into magazine		+	-	FBWsI
TCOABS ⁶⁾	G	Determine tool length components from the current tool orientation	m	+		PGAsI
TCOFR	G	Determine tool length components from the orientation of the active frame	m	+		PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
TCOFRX	G	Determine tool orientation of an active frame on selection of tool, tool points in X direction	m	+		PGAsl
TCOFRY	G	Determine tool orientation of an active frame on selection of tool, tool points in Y direction	m	+		PGAsl
TCOFRZ	G	Determine tool orientation of an active frame on selection of tool, tool points in Z direction	m	+		PGAsl
THETA	A	Angle of rotation	s	+		PGAsl
TILT	A	Tilt angle	m	+		PGAsl
TLIFT	P	Tangential control: Activate intermediate block generation		+	-	PGAsl
TML	P	Tool selection with magazine location number		+	-	FBWsl
TMOF	P	Deselect tool monitoring		+	-	PGAsl
TMON	P	Activate tool monitoring		+	-	PGAsl
TO	K	Designates the end value in a FOR counter loop		+		PGAsl
TOFF	A	Tool length offset in the direction of the tool length component that is effective parallel to the geometry axis specified in the index.	m	+		PGsl
TOFFL	A	Tool length offset in the direction of the tool length component L1, L2 or L3	m	+		PGsl
TOFFLR	A	Simultaneous tool length offset and tool radius offset	m	+		PGsl
TOFFOF	P	Deactivate online tool offset		+	-	PGAsl
TOFFON	P	Activate online tool length offset		+	-	PGAsl
TOFFR	A	Tool radius offset	m	+		PGsl
TOFRAME	G	Align Z axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl
TOFRAMEX	G	Align X axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl
TOFRAMEY	G	Align Y axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl
TOFRAMEZ	G	As TOFRAME	m	+		PGsl
TOLOWER	F	Convert the letters of a string into lowercase		+	-	PGAsl
TOOLENV	F	Save current states which are of significance to the evaluation of the tool data stored in the memory		+	-	PGAsl
TOOLGNT	F	Determine number of tools of a tool group		+	-	FBWsl
TOOLGT	F	Determine T number of a tool from a tool group		+	-	FBWsl
TOROT	G	Align Z axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl
TOROTOF ⁶⁾	G	Frame rotations in tool direction OFF	m	+		PGsl
TOROTX	G	Align X axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl
TOROTY	G	Align Y axis of the WCS by rotating the frame parallel to the tool orientation	m	+		PGsl

Tables

4.1 Operations

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
TOROTZ	G	As TOROT	m	+		PGsI
TOUPPER	F	Convert the letters of a string into uppercase		+	-	PGAsI
TOWBCS	G	Wear values in the basic coordinate system (BCS)	m	+		PGAsI
TOWKCS	G	Wear values in the coordinate system of the tool head for kinetic transformation (differs from machine coordinate system through tool rotation)	m	+		PGAsI
TOWMCS	G	Wear values in machine coordinate system	m	+		PGAsI
TOWSTD ⁶⁾	G	Initial setting value for offsets in tool length	m	+		PGAsI
TOWTCS	G	Wear values in the tool coordinate system (toolholder ref. point T at the tool holder)	m	+		PGAsI
TOWWCS	G	Wear values in workpiece coordinate system	m	+		PGAsI
TR	K	Offset component of a frame variable		+		PGAsI
TRAANG	P	Transformation inclined axis		+	-	PGAsI
TRACON	P	Cascaded transformation		+	-	PGAsI
TRACYL	P	Cylinder: Peripheral surface transformation		+	-	PGAsI
TRAFOOF	P	Deactivate active transformations in the channel		+	-	PGAsI
TRAFOON	P	Activate a transformation defined with kinematic chains		+	-	PGAsI
TRAILOF	P	Asynchronous coupled motion OFF		+	+	PGAsI
TRAILON	P	Asynchronous coupled motion ON		+	+	PGAsI
TRANS	G	Absolute programmable work offset	s	+		PGsI
TRANSMIT	P	Pole transformation (face machining)		+	-	PGAsI
TRAORI	P	4-axis, 5-axis transformation, generic transformation		+	-	PGAsI
TRUE	K	Logical constant: True		+		PGAsI
TRUNC	F	Truncation of decimal places		+	+	PGAsI
TU		Axis angle	s	+		PGAsI
TURN	A	Number of turns for helix	s	+		PGsI
ULI	K	Upper limit value of variables		+		PGAsI
UNLOCK	P	Enable synchronized action with ID (continue technology cycle)		-	+	FBSYsI
UNTIL	K	Condition for end of REPEAT loop		+		PGAsI
UPATH	G	Path reference for FGROU axes is curve parameter	m	+		PGAsI
VAR	K	Keyword: Type of parameter transfer		+		PGAsI
VELOLIM	K	Reduction of the maximum axial velocity	m	+		PGAsI
VELOLIMA	K	Reduction or increase of the maximum axial velocity of the following axis	m	+	+	PGAsI
WAITC	P	Wait for the coupling block change criterion to be fulfilled for the axes/spindles		+	-	PGAsI
WAITE	P	Wait for end of program in another channel.		+	-	PGAsI

Operation	Type ¹⁾	Meaning	W ²⁾	TP ³⁾	SA ⁴⁾	Description see ⁵⁾
1) 2) 3) 4) 5) for explanations, see legend (Page 1272).						
WAITENC	P	Wait for synchronized or restored axis positions		+	-	PGAsl
WAITM	P	Wait for marker in specified channel; terminate previous block with exact stop.		+	-	PGAsl
WAITMC	P	Wait for marker in specified channel; exact stop only if the other channels have not yet reached the marker.		+	-	PGAsl
WAITP	P	Wait for end of travel of the positioning axis		+	-	PGsl
WAITS	P	Wait for spindle position to be reached		+	-	PGsl
WALCS0 ⁶⁾	G	Workpiece coordinate system working area limitation deselected	m	+	-	PGsl
WALCS1	G	WCS working area limitation group 1 active	m	+	-	PGsl
WALCS2	G	WCS working area limitation group 2 active	m	+	-	PGsl
WALCS3	G	WCS working area limitation group 3 active	m	+	-	PGsl
WALCS4	G	WCS working area limitation group 4 active	m	+	-	PGsl
WALCS5	G	WCS working area limitation group 5 active	m	+	-	PGsl
WALCS6	G	WCS working area limitation group 6 active	m	+	-	PGsl
WALCS7	G	WCS working area limitation group 7 active	m	+	-	PGsl
WALCS8	G	WCS working area limitation group 8 active	m	+	-	PGsl
WALCS9	G	WCS working area limitation group 9 active	m	+	-	PGsl
WALCS10	G	WCS working area limitation group 10 active	m	+	-	PGsl
WALIMOF	G	BCS working area limitation OFF	m	+	-	PGsl
WALIMON ⁶⁾	G	BCS working area limitation ON	m	+	-	PGsl
WHEN	K	The action is executed once whenever the condition is fulfilled.		-	+	FBSYsl
WHENEVER	K	The action is executed cyclically in each interpolator cycle when the condition is fulfilled.		-	+	FBSYsl
WHILE	K	Start of WHILE program loop		+		PGAsl
WRITE	P	Write text to file system. Appends a block to the end of the specified file.		+	-	PGAsl
WRTPR	P	Write string in OPI variable		+	-	PGsl
X	A	Axis name	m/s	+	+	PGsl
XOR	O	Logic exclusive OR		+		PGAsl
Y	A	Axis name	m/s	+	+	PGsl
Z	A	Axis name	m/s	+	+	PGsl

Legend

1) Type of operation:

A Address

Identifier to which a value is assigned (e.g. OVR=10). There are also some addresses that switch on or off a function without value assignment (e.g. CPLON and CPLOF).

C (A) AST cycle

Predefined NC program for automatic post optimization (tuning) with AST (= Automatic Servo Tuning). Parameters are used to adapt to the specific optimization situation; these parameters are transferred at the call.

C (M) Measuring cycle

Predefined NC program in which a specific, generally valid, measuring operation, such as determining the inner diameter of a cylindrical workpiece, is programmed. Parameters are used to adapt to the specific measurement situation; these parameters are transferred at the call.

C (T) Technological cycle

Predefined NC program in which a specific, generally valid, machining operation, such as tapping of a thread or milling a pocket, is programmed. The adaptation to a specific machine situation is realized via parameters that are transferred to the cycle during the call.

F Predefined function (supplies a return value)

The call of the predefined function can be an operand in an expression.

G G command

The G commands are divided into G groups. Only one G command of a group can be programmed in a block. A G command can be either modal (until it is canceled by another command of the same group) or only effective for the block in which it is programmed (non-modal).

K Keyword

Identifier that defines the syntax of a block. No value is assigned to a keyword, and no NC function can be switched on/off with a keyword.

Examples: Control structures (IF, ELSE, ENDIF, WHEN, ...), program execution (GOTOB, GOTO, RET ...)

O Operator

Operator for a mathematical, comparison or logical operation

P Predefined procedure (does not supply a return value)

PA Program attribute

Program attributes are at the end of the definition line of a subprogram:

```
PROC <program name>(…) <program attribute>
```

They determine the behavior during execution of the subprogram.

2) Effectiveness of the operation:

m Modal

s Non-modal

3) Programmability in part program:

+ Programmable

- Not programmable

M Programmable only by the machine manufacturer

- 4) Programmability in synchronized actions:
- + Programmable
 - Not programmable
 - T Programmable only in technology cycles
- 5) Reference to the document containing the detailed description of the operation:
- | | |
|------------------|--|
| <i>PGsl</i> | Programming Manual, Fundamentals |
| <i>PGAsl</i> | Programming Manual, Job Planning |
| <i>BNMsl</i> | Programming Manual Measuring Cycles |
| <i>BHDsl</i> | Operating Manual, Turning |
| <i>BHFsl</i> | Operating Manual, Milling |
| <i>FB1sl</i> () | Function Manual, Basic Functions (with the alphanumeric abbreviation of the corresponding function description in brackets) |
| <i>FB2sl</i> () | Function Manual, Extended Functions (with the alphanumeric abbreviation of the corresponding function description in brackets) |
| <i>FB3sl</i> () | Function Manual, Special Functions (with the alphanumeric abbreviation of the corresponding function description in brackets) |
| <i>FBSsl</i> | Function Manual, Safety Integrated |
| <i>FBSYsl</i> | Function Manual, Synchronized Actions |
| <i>FBWsl</i> | Function Manual, Tool Management |
- 6) Default setting at beginning of program (factory settings of the control, if nothing else programmed).

Figure 4-1 Meaning of footnotes in the tables of operations

4.2 Addresses

4.2.1 Address letters

Letter	Meaning	Numeric extension
A	Settable address identifier	x
B	Settable address identifier	x
C	Settable address identifier	x
D	Selection/deselection of tool length compensation, tool cutting edge	
E	Settable address identifier	x
F	Feedrate Dwell time in seconds	x
G	G command	
H	H function	x
I	Settable address identifier	x
J	Settable address identifier	x
K	Settable address identifier	x
L	Subprogram name, subprogram call	
M	M function	x
N	Subblock number	
O	Unassigned	
P	Number of program runs	
Q	Settable address identifier	x
R	Variable identifier (R parameter) Settable address identifier (without numeric extension)	x
S	Spindle value Dwell time in spindle revolutions	x x
T	Tool number	x
U	Settable address identifier	x
V	Settable address identifier	x
W	Settable address identifier	x
X	Settable address identifier	x
Y	Settable address identifier	x
Z	Settable address identifier	x
%	Start character and separator for file transfer	
:	Main block number	
/	Skip identifier	

4.2.2 Fixed addresses

Fixed addresses without axial extension

Address identifier	Address type	Modal/non-modal	G70/G71	G700/G710	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
D	Offset number	m								x	Unsigned INT
F	Feed, dwell time	m, s	x							x	Unsigned REAL
G	G command	See list of the G functions									Unsigned INT
H	Auxiliary functions	s								x	M: unsigned INT H: REAL
L	Subprogram number	s									Unsigned INT
M	Auxiliary functions	s								x	M: unsigned INT H: REAL
N	Block number	s									Unsigned INT
OVR	Override	m									Unsigned REAL
OVRRAP	Override for rapid traverse velocity	m									Unsigned REAL
P	Number of subprogram repetitions	s									Unsigned INT
S	Spindle, dwell time	m, s								x	Unsigned REAL
SCC	Assignment of a transverse axis to G96 /G961/G962	m									REAL
SPOS	Spindle position	m				x	x	x			REAL

4.2 Addresses

Address identifier	Address type	Modal/non-modal	G70/G71	G700/G710	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
SPOSA	Spindle position across block boundaries	m				x	x	x			REAL
T	Tool number	m								x	Unsigned INT

Fixed addresses with axial extension

Address identifier	Address type	Modal/non-modal	G70/G71	G700/G710	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
ACC	Axial acceleration	m									Unsigned REAL
ACCLIMA	Axial acceleration limitation of following axis	m									Unsigned REAL
AX	Variable axis identifier	¹⁾	x	x	x	x	x	x			REAL
FA	Axial feedrate	m	x							x	Unsigned REAL
FDA	Axis feedrate for handwheel override	s	x								Unsigned REAL
FGREF	Reference radius	m	x	x							Unsigned REAL
FL	Axial feedrate limit	m	x								Unsigned REAL
FMA	Axial synchronized feedrate	m									Unsigned REAL
FOC	Non-modal traversing with limited torque	s									REAL
FOCOF	Modal traversing with limited torque OFF	m									REAL

Address identifier	Address type	Modal/non-modal	G70/G71	G700/G710	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
FOCON	Modal traversing with limited torque ON	m									REAL
FXS	Travel to fixed stop ON	m									Unsigned INT
FXST	Torque limit for travel to fixed stop	m									REAL
FXSW	Monitoring window for travel to fixed stop	m									REAL
IP	Variable interpolation parameter	s	x	x	x	x	x				REAL
JERKLIM	Axial jerk limitation	m									Unsigned REAL
JERKLIMA	Axial jerk limitation of following axis	m									Unsigned REAL
MEAC	Cyclic measuring	s									INT Mode and 1 - 4 trigger events
MEASA	Axial measurement with delete distance-to-go	s									INT Mode and 1 - 4 trigger events
MEAWA	Axial measurement without delete distance-to-go	s									INT Mode and 1 - 4 trigger events
MOV	Start positioning axis	m	x	x	x	x	x	x	x		REAL
OS	Oscillation ON/OFF	m									Unsigned INT
OSB	Oscillation starting point	m	x	x	x	x	x	x			REAL

Tables

4.2 Addresses

Address identifier	Address type	Modal/non-modal	G70/G71	G700/G710	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
OSCILL	Axis assignment for oscillation, activate oscillation	m									Axis: 1 - 3 infeed axes
OSCTRL	Oscillation options	m									Unsigned INT: Setting options, unsigned INT: Reset options
OSE	Oscillation end position	m	x	x	x	x	x	x			REAL
OSNSC	Number of spark-out cycles (oscillation)	m									Unsigned INT
OSP1	Left reversal point (oscillation)	m	x	x	x	x	x	x			REAL
OSP2	Right reversal point (oscillation)	m	x	x	x	x	x	x			REAL
OST1	Stopping time at left reversal point (oscillation)	m									REAL
OST2	Stopping time at right reversal point (oscillation)	m									REAL
OVRA	Axial override	m	x								Unsigned REAL
PO	Polynomial coefficient	s	x	x		x	x	x			Unsigned REAL
POLF	LIFTFAST position	m	x	x							Unsigned REAL
POS	Positioning axis	m	x	x	x	x	x	x	x		REAL
POSA	Positioning axis across block boundaries	m	x	x	x	x	x	x	x		REAL

Address identifier	Address type	Modal/ non- modal	G70/ G71	G700/ G710	G90/ G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	QU	Data type of the assigned value
POSP	Positioning axis in parts (oscillation)	m	x	x	x	x	x	x			REAL: End position Real: Partial length INT: Option
STA	Sparking out time (axial)	m									Unsigned REAL
SRA	Retraction path on external input (axial)	m									Unsigned REAL
VELOLIM	Axial velocity limitation	m									Unsigned REAL
VELOLIMA	Axial velocity limitation of following axis	m									Unsigned REAL

¹⁾ Absolute end points: Modal, incremental end points: Non-modal, otherwise modal/non-modal depending on the G function that determines the syntax.

4.2.3 Settable addresses

Address identifier (default setting)	Address type	Modal/ non- modal	G90/ G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
Axis values and end points											
X, Y, Z, A, B, C	Axis	¹⁾	x	x	x	x				8	REAL
AP	Polar angle	m/s ¹⁾	x	x	x					1	REAL
RP	Polar radius	m/s ¹⁾	x	x	x					1	Unsigned REAL
Tool orientation											
A2, B2, C2	Euler angle or RPY angle	s								3	REAL
A3, B3, C3	Components of the directional vector	s								3	REAL

Tables

4.2 Addresses

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
A4, B4, C4	Components of the surface normal vector at the start of the block	s								3	REAL
A5, B5, C5	Components of the surface normal vector at the end of the block	s								3	REAL
A6, B6, C6	Components of the direction vector for the rotary axis of the taper	s								3	REAL
A7, B7, C7	Vector components for the intermediate orientation on the peripheral surface of a taper	s								3	REAL
LEAD	Lead angle	m								1	REAL
THETA	Angle of rotation, rotation around the tool direction	m		x	x					1	REAL
TILT	Tilt angle	m								1	REAL
ORIS	Orientation change (in relation to the path)	m								1	REAL
Interpolation parameters											
I, J, K	Interpolation parameter intermediate point coordinate	s		x ²	x ²					3	REAL
I1, J1, K1		s	x	x	x					3	REAL
RPL	Rotation in the plane	s								1	REAL
CR	Circle radius	s								1	Unsigned REAL
AR	Opening angle	s								1	Unsigned REAL
TURN	Number of turns for helix	s								1	Unsigned INT
PL	Parameter interval length	s								1	Unsigned REAL
PW	weight	s								1	Unsigned REAL

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
SD	Spline degree	m								1	Unsigned INT
TU	Axis angle	s								1	Unsigned INT
STAT	Position of joints	m								1	Unsigned INT
SF	Starting point offset for thread cutting	m								1	REAL
DISCL	Safety clearance SAR	s								1	Unsigned REAL
DISR	Repositioning clearance / SAR clearance	s								1	Unsigned REAL
DISPR	Path differential for repositioning	s								1	Unsigned REAL
ALF	Rapid lift angle	m								1	Unsigned INT
DILF	Rapid lift length	m								1	REAL
FP	Fixed point: Number of fixed point to be approached	s								1	Unsigned INT
RNDM	Modal rounding	m								1	Unsigned REAL
RND	Non-modal rounding	s								1	Unsigned REAL
CHF	Chamfer non-modal	s								1	Unsigned REAL
CHR	Chamfer in original direction of motion	s								1	Unsigned REAL
ANG	Contour angle	s								1	REAL
ISD	Insertion depth	m								1	REAL
DISC	Transition circle overshoot tool radius compensation	m								1	Unsigned REAL
OFFN	Offset contour normal	m								1	REAL
DITS	Thread run-in path	m								1	REAL
DITE	Thread run-out path	m								1	REAL

Tables

4.2 Addresses

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
Corner rounding criteria											
ADIS	Rounding clearance	m								1	Unsigned REAL
ADISPOS	Rounding clearance for rapid traverse	m								1	Unsigned REAL
Measurement											
MEAS	Measurement with touch-trigger probe	s								1	Unsigned INT
MEAW	Measurement with touch-trigger probe without deletion of distance-to-go	s								1	Unsigned INT
Axis, spindle behavior											
LIMS	Spindle speed limitation	m								1	Unsigned REAL
COARSEA	Block change behavior: Exact stop coarse axial	m									
FINEA	Block change behavior: Exact stop fine axial	m									
IPOENDA	Block change behavior: Interpolator stop axial	m									
DIACYCOFA	Transverse axis: Axial diameter programming OFF in cycles	m									
DIAM90A	Transverse axis: Axial diameter programming for G90	m									
DIAMCHAN	Transverse axis: Transfer of all transverse axes in the diameter programming channel status	m									

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
DIAMCHANA	Transverse axis: Transfer of the diameter programming channel status	m									
DIAMOFA	Transverse axis: Axial diameter programming OFF	m									
DIAMONA	Transverse axis: Axial diameter programming ON	m									
GP	Position: Indirect programming of position attributes	m									
Feedrates											
FAD	Speed of the slow feed movement	s						x		1	Unsigned REAL
FD	Path feedrate for handwheel override	s								1	Unsigned REAL
FRC	Feedrate for radius and chamfer	s								1	Unsigned REAL
FRCM	Feedrate for radius and chamfer, modal	m								1	Unsigned REAL
FB	Non-modal feedrate	s								1	Unsigned REAL
Nibbling/punching											
SPN	Number of path sections per block	s								1	INT
SPP	Length of a path section	m								1	REAL
Grinding											
ST	Sparking-out time	s								1	Unsigned REAL
SR	Retraction path	s								1	Unsigned REAL

Tables

4.2 Addresses

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
Tool selection											
TCARR	Tool carrier	m								1	INT
Tool management											
DL	Total tool offset	m								1	INT
OEM addresses											
OMA1	OEM address 1	m		x	x	x				1	REAL
OMA2	OEM address 2	m		x	x	x				1	REAL
OMA3	OEM address 3	m		x	x	x				1	REAL
OMA4	OEM address 4	m		x	x	x				1	REAL
OMA5	OEM address 5	m		x	x	x				1	REAL
Miscellaneous											
CUTMOD	Modification of the offset data for rotatable tools (in combination with orientable tool carriers)	m									INT
CUTMODK	Modification of the offset data for rotatable tools (in combination with orientation transformations that have been defined by means of kinematic chains)	m									STRING
TOFF	Tool length offset parallel to the specified geometry axis	m									REAL
TOFFL	Tool length offset in the direction of the tool length component L1, L2 or L3	m									REAL

Address identifier (default setting)	Address type	Modal/non-modal	G90/G91	IC	AC	DC, ACN, ACP	CIC, CAC, CDC, CACN, CACP	PR, PM	QU	Max. number	Data type of the assigned value
TOFFR	Tool radius offset	m									REAL
TOFFLR	Simultaneous tool length offset and tool radius offset	m									REAL

- 1) Absolute end points: Modal, incremental end points: non-modal, otherwise modal/non-modal depending on the G command that determines the syntax.
- 2) As circle center points, IPO parameters act incrementally. They can be programmed in absolute mode with AC. The address modification is ignored when the parameters have other meanings (e.g. thread lead).

4.3 G commands

4.3.1 G commands

The G commands are divided into G groups. In part programs or synchronized actions, in a block, only a G command of a G group can be written. A G command can be modal or non-modal.

Modal: up to programming another G command of the same G group.

4.3.2 G group 1: Modally valid motion commands

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G0	1	Rapid traverse	+	m		
G1	2	Linear interpolation (linear interpolation)	+	m	x	
G2	3	Circular interpolation clockwise	+	m		
G3	4	Circular interpolation counter-clockwise	+	m		
CIP	5	Circular interpolation through intermediate point	+	m		
ASPLINE	6	Akima spline	+	m		
BSPLINE	7	B spline	+	m		
CSPLINE	8	Cubic spline	+	m		
POLY	9	Polynomial interpolation	+	m		
G33	10	Thread cutting with constant lead	+	m		
G331	11	Tapping	+	m		
G332	12	Retraction (tapping)	+	m		
OEMIPO1	13	Reserved	+	m		
OEMIPO2	14	Reserved	+	m		
CT	15	Circle with tangential transition	+	m		
G34	16	Thread cutting with linear increasing lead	+	m		
G35	17	Thread cutting with linear decreasing lead	+	m		
INVCW	18	Involute interpolation clockwise	+	m		
INVCCW	19	Counter-clockwise involute interpolation	+	m		
G335	20	Turning a convex thread in clockwise direction	+	m		
G336	21	Turning a convex thread in counter-clockwise direction	+	m		

4.3.3 G group 2: Non-modally valid motion, dwell time

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G4	1	Dwell time, preset	-	s		
G63	2	Tapping without synchronization	-	s		
G74	3	Reference point approach with synchronization	-	s		
G75	4	Fixed-point approach	-	s		
REPOSL	5	Linear repositioning	-	s		
REPOSQ	6	Repositioning in a quadrant	-	s		
REPOSH	7	Repositioning in semicircle	-	s		
REPOSA	8	Linear repositioning with all axes	-	s		
REPOSQA	9	Linear repositioning with all axes, geometry axes in quadrant	-	s		
REPOSHA	10	Repositioning with all axes; geometry axes in semicircle	-	s		
G147	11	Approach contour with straight line	-	s		
G247	12	Approach contour with quadrant	-	s		
G347	13	Approach contour with semicircle	-	s		
G148	14	Leave contour with straight line	-	s		
G248	15	Leave contour with quadrant	-	s		
G348	16	Leave contour with semicircle	-	s		
G5	17	Oblique plunge-cut grinding	-	s		
G7	18	Compensatory motion during oblique plunge-cut grinding	-	s		

4.3.4 G group 3: Programmable frame, working area limitation and pole programming

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
TRANS	1	TRANSLATION: Programmable offset	-	s		
ROT	2	ROTATION: Programmable rotation	-	s		
SCALE	3	SCALE: Programmable scaling	-	s		
MIRROR	4	MIRROR: Programmable mirroring	-	s		
ATRANS	5	Additive TRANSLATION: Additive programmable translation	-	s		
AROT	6	Additive ROTATION: Programmable rotation	-	s		
ASCALE	7	Additive SCALE: Programmable scaling	-	s		
AMIRROR	8	Additive MIRROR: Programmable mirroring	-	s		
-	9	Unassigned	-	-		
G25	10	Minimum working area limitation/spindle speed limitation	-	s		

4.3 G commands

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G26	11	Maximum working area limitation/spindle speed limitation	-	s		
G110	12	Pole programming relative to the last programmed set-point position	-	s		
G111	13	Polar programming relative to origin of current work-piece coordinate system	-	s		
G112	14	Pole programming relative to the last valid pole	-	s		
G58	15	Absolute programmable work offset	-	s		
G59	16	Additive programmable work offset	-	s		
ROTS	17	Rotation with solid angle	-	s		
AROTS	18	Additive rotation with solid angle	-	s		

4.3.5 G group 4: FIFO

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
STARTFIFO	1	Start FIFO Execute and simultaneously fill preprocessing memory	+	m	x	
STOPFIFO	2	STOP FIFO Stop machining; fill preprocessing memory until STARTFIFO is detected, FIFO is full or end of program	+	m		
FIFOCTRL	3	Activation of automatic preprocessing memory control	+	m		

4.3.6 G group 6: Plane selection

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G17	1	Plane selection 1. – 2. Geometry axis	+	m	x	
G18	2	Plane selection 3. – 1. Geometry axis	+	m		
G19	3	Plane selection 2. – 3. Geometry axis	+	m		

4.3.7 G group 7: Tool radius compensation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G40	1	No tool radius compensation	+	m	x	
G41	2	Tool radius compensation left of the contour	-	m		
G42	3	Tool radius compensation right of the contour	-	m		

4.3.8 G group 8: Settable work offset

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G500	1	Deactivation of settable work offset (G54 to G57, G505 to G599)	+	m	x	
G54	2	1st settable work offset	+	m		
G55	3	2nd settable work offset	+	m		
G56	4	3rd settable work offset	+	m		
G57	5	4th settable work offset	+	m		
G505	6	5th settable work offset	+	m		
...	+	m		
G599	100	99th settable work offset	+	m		

Each of the G commands in this G group is used to activate an adjustable user frame \$P_UIFR[]. G54 corresponds to frame \$P_UIFR[1], G505 corresponds to frame \$P_UIFR[5]. The number of adjustable user frames and therefore the number of G commands in this G group can be set using machine data MD28080 \$MC_MM_NUM_USER_FRAMES.

4.3.9 G group 9: Frame suppression

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G53	1	Suppression of current frames: Programmable frame including system frame for TOROT and TOFRAME and active adjustable frame (G54 to G57, G505 to G599)	-	s		
SUPA	2	As for G153 including suppression of system frames for actual-value setting, scratching, ext. work offset, PAROT including handwheel offsets (DRF), [external work offset], overlaid movement	-	s		
G153	3	As for G53 including suppression of all channel-specific and/or NCU-global basic frames	-	s		

4.3.10 G group 10: Exact stop - continuous-path mode

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G60	1	Exact stop	+	m	x	
G64	2	Continuous-path mode	+	m		
G641	3	Continuous-path mode with smoothing according to distance criterion (= programmable rounding clearance)	+	m		

4.3 G commands

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G642	4	Continuous-path mode with smoothing within the defined tolerances	+	m		
G643	5	Continuous-path mode with smoothing within the defined tolerances (block-internal)	+	m		
G644	6	Continuous-path mode with smoothing with maximum possible dynamic response	+	m		
G645	7	Continuous-path mode with smoothing and tangential block transitions within defined tolerances	+	m		

4.3.11 G group 11: Exact stop, non-modal

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G9	1	Exact stop	-	s		

4.3.12 G group 12: Block change criteria at exact stop (G60/G9)

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G601	1	Block change at exact stop fine	+	m	x	
G602	2	Block change at exact stop coarse	+	m		
G603	3	Block change at IPO block end	+	m		

4.3.13 G group 13: Workpiece measuring inch/metric

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G70	1	Input system inches (length)	+	m		
G71	2	Input system metric mm (lengths)	+	m	x	
G700	3	Input system inch, inch/min (lengths + velocity + system variable)	+	m		
G710	4	Input system metric mm, mm/min (lengths + velocity + system variable)	+	m		

4.3.14 G group 14: Workpiece measuring absolute/incremental

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G90	1	Absolute dimension	+	m	x	
G91	2	Incremental dimensions	+	m		

4.3.15 G group 15: Feed type

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G93	1	Inverse-time feedrate rpm	+	m		
G94	2	Linear feedrate in mm/min, inch/min	+	m	x	
G95	3	Revolutional feedrate in mm/rev, inch/rev	+	m		
G96	4	Revolutional feedrate (as for G95) and constant cutting rate	+	m		
G97	5	Revolutional feedrate and constant spindle speed (constant cutting rate OFF)	+	m		
G931	6	Feedrate specified by means of traversing time, deactivate constant path velocity	+	m		
G961	7	Linear feedrate (as for G94) and constant cutting rate	+	m		
G971	8	Linear feedrate and constant spindle speed (constant cutting rate OFF)	+	m		
G942	9	Linear feedrate and constant cutting rate or constant spindle speed	+	m		
G952	10	Revolutional feedrate and constant cutting rate or constant spindle speed	+	m		
G962	11	Linear feedrate or revolutional feedrate and constant cutting rate	+	m		
G972	12	Linear feedrate or revolutional feedrate and constant spindle speed (constant cutting rate OFF)	+	m		
G973	13	Revolutional feedrate without spindle speed limitation and constant spindle speed (G97 without LIMS for ISO mode)	+	m		

4.3.16 G group 16: Feedrate override at inside and outside curvature

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CFC	1	Constant feedrate at contour effective for internal and external radius	+	m	x	
CFTCP	2	Constant feedrate in tool center point (center point path)	+	m		
CFIN	3	Constant feedrate for internal radius only, acceleration for external radius	+	m		

4.3.17 G group 17: Approach and retraction response, tool offset

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
NORM	1	Normal position at starting and end points	+	m	x	
KONT	2	Travel around contour at starting and end points	+	m		
KONTT	3	Approach/retraction with constant tangent	+	m		
KONTC	4	Approach/retraction with constant curvature	+	m		

4.3.18 G group 18: Corner behavior, tool offset

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G450	1	Transition circle (tool travels around workpiece corners on a circular path)	+	m	x	
G451	2	Intersection of equidistant paths (tool backs off from the workpiece corner)	+	m		

4.3.19 G group 19: Curve transition at beginning of spline

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
BNAT	1	Natural transition to first spline block	+	m	x	
BTAN	2	Tangential transition to first spline block	+	m		
BAUTO	3	Definition of the first spline section by means of the next 3 points	+	m		

4.3.20 G group 20: Curve transition at end of spline

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ENAT	1	Natural transition to next traversing block	+	m	x	
ETAN	2	Tangential transition to next traversing block	+	m		
EAUTO	3	Definition of the last spline section by means of the last 3 points	+	m		

4.3.21 G group 21: Acceleration profile

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
BRISK	1	Fast non-smoothed path acceleration	+	m	x	
SOFT	2	Soft smoothed path acceleration	+	m		
DRIVE	3	Velocity-dependent path acceleration	+	m		

4.3.22 G group 22: Tool offset type

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CUT2D	1	2½D TRC	+	m	x	
CUT2DF	2	2½D TRC relative to the current frame (inclined plane)	+	m		
CUT2DD	9	2½ D TRC in relation to the differential tool	+	m		
CUT2DFD	10	2½D TRC in relation to a differential tool relative to the current frame (inclined plane)	+	m		

4.3.23 G group 23: Collision monitoring at inside contours

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CDOF	1	Collision detection OFF	+	m	x	
CDON	2	Collision detection ON	+	m		
CDOF2	3	Collision detection OFF for 3D circumferential milling	+	m		

4.3 G commands

4.3.24 G group 24: Precontrol

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
FFWOF	1	Feedforward control OFF	+	m	x	
FFWON	2	Feedforward control ON	+	m		

4.3.25 G group 25: Tool orientation reference

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORIWKS	1	Tool orientation in workpiece coordinate system (WCS)	+	m	x	
ORIMKS	2	Tool orientation in machine coordinate system (MCS)	+	m		

4.3.26 G group 26: Repositioning mode for REPOS (modal)

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
RMB	1	Repositioning to start of block	-	m		
RMI	2	Repositioning to interrupt point	-	m	x	
RME	3	Repositioning to end of block	-	m		
RMN	4	Repositioning to the nearest path point	-	m		

4.3.27 G group 27: Tool offset for change in orientation at outside corners

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORIC	1	Orientation changes at outside corners are superimposed on the circle block to be inserted	+	m	x	
ORID	2.	Orientation changes are performed before the circle block	+	m		

4.3.28 G group 28: Working area limitation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
WALIMON	1	Working area limitation ON	+	m	x	
WALIMOF	2	Working area limitation OFF	+	m		

4.3.29 G group 29: Radius/diameter programming

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
DIAMOF	1	Modal channel-specific diameter programming OFF Deactivation activates channel-specific radius programming.	+	m	x	
DIAMON	2	Modal independent channel-specific diameter programming ON The effect is independent of the programmed dimensions mode (G90/G91).	+	m		
DIAM90	3	Modal dependent channel-specific diameter programming ON The effect is dependent on the programmed dimensions mode (G90/G91).	+	m		
DIAMCYCOF	4	Modal channel-specific diameter programming during cycle processing OFF	+	m		

4.3.30 G group 30: NC block compression

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
COMPOF	1	NC block compression OFF	+	m	x	
COMPON	2	Compressor function COMPON ON	+	m		
COMPCURV	3	Compressor function COMPCURV ON	+	m		
COMPCAD	4	Compressor function COMPCAD ON	+	m		
COMPSURF	5	COMPSURF EIN compressor function	+	m		

4.3 G commands

4.3.31 G group 31: OEM G commands

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G810	1	OEM G command	-	m		
G811	2	OEM G command	-	m		
G812	3	OEM G command	-	m		
G813	4	OEM G command	-	m		
G814	5	OEM G command	-	m		
G815	6	OEM G command	-	m		
G816	7	OEM G command	-	m		
G817	8	OEM G command	-	m		
G818	9	OEM G command	-	m		
G819	10	OEM G command	-	m		

Two G groups are reserved for the OEM user. This enables the OEM to program functions that can be customized.

4.3.32 G group 32: OEM G commands

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G820	1	OEM G command	-	m		
G821	2	OEM G command	-	m		
G822	3	OEM G command	-	m		
G823	4	OEM G command	-	m		
G824	5	OEM G command	-	m		
G825	6	OEM G command	-	m		
G826	7	OEM G command	-	m		
G827	8	OEM G command	-	m		
G828	9	OEM G command	-	m		
G829	10	OEM G command	-	m		

Two G groups are reserved for the OEM user. This enables the OEM to program functions that can be customized.

4.3.33 G group 33: Settable fine tool offset

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
FTOCOF	1	Online fine tool offset OFF	+	m	x	
FTOCON	2	Online fine tool offset ON	-	m		

4.3.34 G group 34: Tool orientation smoothing

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
OSOF	1	Tool orientation smoothing OFF	+	m	x	
OSC	2	Continuous tool orientation smoothing	+	m		
OSS	3	Tool orientation smoothing at end of block	+	m		
OSSE	4	Tool orientation smoothing at start and end of block	+	m		
OSD	5	Block-internal smoothing with specification of path length	+	m		
OST	6	Block-internal smoothing with specification of angular tolerance	+	m		

4.3.35 G group 37: Feedrate profile

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
FNORM	1	Feedrate normal to DIN 66025	+	m	x	
FLIN	2	Feed linear variable	+	m		
FCUB	3	Feedrate variable according to cubic spline	+	m		

4.3.36 G group 39: Programmable contour accuracy

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CPRECOF	1	Programmable contour accuracy OFF	+	m	x	
CPRECON	2	Programmable contour accuracy ON	+	m		

4.3.37 G group 40: Tool radius compensation constant

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CUTCONOF	1	Constant tool radius compensation OFF	+	m	x	
CUTCONON	2	Constant tool radius compensation ON	+	m		

4.3 G commands

4.3.38 G group 41: Interruptible thread cutting

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
LFOF	1	Interruptible thread cutting OFF	+	m	x	
LFON	2	Interruptible thread cutting ON	+	m		

4.3.39 G group 42: Tool carrier

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
TCOABS	1	Determine tool length components from the current tool orientation	+	m	x	
TCOFR	2	Determine tool length components from the orientation of the active frame	+	m		
TCOFRZ	3	Determine tool orientation of an active frame on selection of tool, tool points in Z direction	+	m		
TCOFRY	4	Determine tool orientation of an active frame on selection of tool, tool points in Y direction	+	m		
TCOFRX	5	Determine tool orientation of an active frame on selection of tool, tool points in X direction		m		

4.3.40 G group 43: SAR approach direction

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G140	1	SAR approach direction defined by G41/G42	+	m	x	
G141	2	SAR approach direction to left of contour	+	m		
G142	3	SAR approach direction to right of contour	+	m		
G143	4	SAR approach direction tangent-dependent	+	m		

4.3.41 G group 44: SAR path segmentation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G340	1	Spatial approach block; in other words, infeed depth and approach in plane in one block	+	m	x	
G341	2	Start with infeed on perpendicular axis (Z), then approach in plane	+	m		

4.3.42 G group 45: Path reference for FGROUP axes

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
SPATH	1	Path reference for FGROUP axes is arc length	+	m	x	
UPATH	2	Path reference for FGROUP axes is curve parameter	+	m		

4.3.43 G group 46: Plane selection for fast retraction

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
LFTXT	1	The plane is determined from the path tangent and the current tool orientation	+	m	x	
LFWP	2	The plane is determined by the current working plane (G17/G18/G19)	+	m		
LFPOS	3	Axial retraction to a position	+	m		

4.3.44 G group 47: Mode switchover for external NC code

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G290	1	Activate SINUMERIK language mode	+	m	x	
G291	2	Activate ISO language mode	+	m		

4.3.45 G group 48: Approach and retraction response with tool radius compensation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
G460	1	Collision detection for approach and retraction block ON	+	m	x	
G461	2	Extend border block with arc if no intersection in TRC block	+	m		
G462	3	Extend border block with straight line if no intersection in TRC block	+	m		

4.3 G commands

4.3.46 G group 49: Point-to-point motion

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
CP	1	Path motion	+	m	x	
PTP	2	Point-to-point motion (synchronized axis motion)	+	m		
PTPG0	3	Point-to-point motion only with G0, otherwise path motion CP	+	m		
PTPWOC	4	Point-to-point motion without compensatory motion, which is caused by orientation changes	+	m		

4.3.47 G group 50: Orientation programming

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORIEULER	1	Orientation angle via Euler angle	+	m	x	
ORIRPY	2	Orientation angle via RPY angle (rotation sequence XYZ)	+	m		
ORIVIRT1	3	Orientation angle via virtual orientation axes (definition 1)	+	m		
ORIVIRT2	4	Orientation angle via virtual orientation axes (definition 2)	+	m		
ORIXPOS	5	Orientation angle via virtual orientation axes with rotary axis positions	+	m		
ORIRPY2	6	Orientation angle via RPY angle (rotation sequence ZYX)	+	m		

4.3.48 G group 51: Interpolation type for orientation programming

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORIVECT	1	Large-circle interpolation (identical to ORIPLANE)	+	m	x	
ORIXES	2	Linear interpolation of machine axes or orientation axes	+	m		
ORIPATH	3	Tool orientation trajectory referred to path	+	m		
ORIPLANE	4	Interpolation in plane (identical to ORIVECT)	+	m		
ORICONCW	5	Interpolation on the peripheral surface of a taper in the clockwise direction	+	m		
ORI- CONCCW	6	Interpolation on the peripheral surface of a taper in the counter-clockwise direction	+	m		
ORICONIO	7	Interpolation on a conical peripheral surface with intermediate orientation setting	+	m		

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORICONTO	8	Interpolation on a peripheral surface of the cone with tangential transition	+	m		
ORICURVE	9	Interpolation with additional space curve for orientation	+	m		
ORIPATHS	10	Tool orientation in relation to the path, kinks in the orientation characteristic are smoothed	+	m		

4.3.49 G group 52: Frame rotation in relation to workpiece

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
PAROTOF	1	Frame rotation in relation to workpiece OFF	+	m	x	
PAROT	2	Frame rotation in relation to workpiece ON The workpiece coordinate system is aligned on the workpiece.	+	m		

4.3.50 G group 53: Frame rotation in relation to tool

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
TOROTOF	1	Frame rotation in relation to tool OFF	+	m	x	
TOROT	2	Align Z axis of the WCS by rotating the frame parallel to the tool orientation	+	m		
TOROTZ	3	As TOROT	+	m		
TOROTY	4	Align Y axis of the WCS by rotating the frame parallel to the tool orientation	+	m		
TOROTX	5	Align X axis of the WCS by rotating the frame parallel to the tool orientation	+	m		
TOFRAME	6	Align Z axis of the WCS by rotating the frame parallel to the tool orientation	+	m		
TOFRAMEZ	7	As TOFRAME	+	m		
TOFRAMEY	8	Align Y axis of the WCS by rotating the frame parallel to the tool orientation	+	m		
TOFRAMEX	9	Align X axis of the WCS by rotating the frame parallel to the tool orientation	+	m		

4.3 G commands

4.3.51 G group 54: Vector rotation for polynomial programming

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORIROTA	1	Vector rotation absolute	+	m	x	
ORIROTR	2	Vector rotation relative	+	m		
ORIROTT	3	Vector rotation tangential	+	m		
ORIROTC	4	Tangential rotational vector in relation to path tangent	+	m		

4.3.52 G group 55: Rapid traverse with/without linear interpolation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
RTLION	1	Rapid traverse motion with linear interpolation ON	+	m	x	
RTLIOF	2	Rapid traverse motion with linear interpolation OFF Rapid traverse motion is achieved with single-axis interpolation.	+	m		

4.3.53 G group 56: Taking into account tool wear

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
TOWSTD	1	Initial setting value for offsets in tool length	+	m	x	
TOWMCS	2	Wear values in the machine coordinate system (MCS)	+	m		
TOWWCS	3	Wear values in the workpiece coordinate system (WCS)	+	m		
TOWBCS	4	Wear values in the basic coordinate system (BCS)	+	m		
TOWTCS	5	Wear values in the tool coordinate system (toolholder ref. point T at the toolholder)	+	m		
TOWKCS	6	Wear values in the coordinate system of the tool head for kinetic transformation (differs from machine coordinate system through tool rotation)	+	m		

4.3.54 G group 57: Corner deceleration

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
FENDNORM	1	Corner deceleration OFF	+	m	x	
G62	2	Corner deceleration at inside corners when tool radius compensation is active (G41/G42)	+	m		
G621	3	Corner deceleration at all corners	+	m		

4.3.55 G group 59: Dynamic response mode for path interpolation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
DYNNORM	1	Standard dynamic response	+	m	x	
DYNPOS	2	Positioning mode, tapping	+	m		
DYNROUGH	3	Roughing	+	m		
DYNSEMIFIN	4	Rough finishing	+	m		
DYNFINISH	5	Finishing	+	m		
DYNPREC	6	Smooth finishing	+	m		

4.3.56 G group 60: Working area limitation

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
WALCS0	1	Workpiece coordinate system working area limitation OFF	+	m	x	
WALCS1	2	WCS working area limitation group 1 active	+	m		
WALCS2	3	WCS working area limitation group 2 active	+	m		
WALCS3	4	WCS working area limitation group 3 active	+	m		
WALCS4	5	WCS working area limitation group 4 active	+	m		
WALCS5	6	WCS working area limitation group 5 active	+	m		
WALCS6	7	WCS working area limitation group 6 active	+	m		
WALCS7	8	WCS working area limitation group 7 active	+	m		
WALCS8	9	WCS working area limitation group 8 active	+	m		
WALCS9	10	WCS working area limitation group 9 active	+	m		
WALCS10	11	WCS working area limitation group 10 active	+	m		

4.3.57 G group 61: Tool orientation smoothing

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
ORISOF	1	Tool orientation smoothing OFF	+	m	x	
ORISON	2	Tool orientation smoothing ON	+	m		

4.3.58 G group 62: Repositioning mode for REPOS (non-modal)

G command	No. ¹⁾	Meaning	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
RMBBL	1	Repositioning to start of block	-	s		
RMIBL	2	Repositioning to interrupt point	-	s	x	
RMEBL	3	Repositioning to end of block	-	s		
RMNBL	4	Repositioning to the nearest path point	-	s		

4.3.59 G group 64: Grinding frames

G command	No. ¹⁾	Meaning Active grinding frame in the channel \$P_GFRAME =	MD20150 ²⁾	W ³⁾	STD ⁴⁾	
					SAG	MH
GFRAME[0]	1	Grinding frame of the data management \$P_GFR[0] (null frame)	+	m	x	
GFRAME[1]	2	Grinding frame of the data management \$P_GFR[1]	+	m		
GFRAME[2]	3	Grinding frame of the data management \$P_GFR[2]	+	m		
...	...		+	m		
GFRAME[100]	101	Grinding frame of the data management \$P_GFR[100]	+	m		

Legend

- 1) Internal number (e.g. for PLC interface)
 - 2) Configurability of the G command as a reset setting for the G group on power up, reset or end of part program (with MD20150 \$MC_GCODE_RESET_VALUES):
 - + Configurable
 - Not configurable
 - 3) Effectiveness of the G command:
 - m modal
 - s Non-modal
 - 4) Reset setting, see the following machine data:
 - MD20149GCODE_RESET_S_VALUES (reset position of G groups (fix))
 - MD20150 \$MC_GCODE_RESET_VALUES (reset position of the G groups)
 - MD20151GCODE_RESET_S_MODE (reset behavior of G groups (fix))
 - MD20152 \$MC_GCODE_RESET_MODE (reset behavior of G groups)
 - MD20154 \$MC_EXTERN_GCODE_RESET_VALUES (reset position of the G groups in ISO mode)
 - MD20156 \$MC_EXTERN_GCODE_RESET_MODE (reset behavior of external G groups)
- SAG Default setting **Siemens AG**
- MM Default setting **Machine Manufacturer** (see machine manufacturer's specifications)

4.4 Predefined procedures

4.4 Predefined procedures

The call of a predefined procedure triggers the execution of a predefined NC function. A predefined procedure does **not** supply a return value in contrast to a predefined function.

Coordinate system					
Identifier	Parameter				Explanation
	1.	2.	3. - 15.	4. - 16.	
PRESETON	AXIS *): Axis identifier of machine axis	REAL: Preset offset G700/G710 context	As 1 ...	As 2 ...	Set actual value for the programmed axes with loss of the referencing status
PRESETONS	AXIS *): Axis identifier of machine axis	REAL: Preset offset G700/G710 context	As 1 ...	As 2 ...	Set actual value for the programmed axes without loss of the referencing status
DRFOF					Deletes the DRF offset for all axes assigned to the channel.

-) As a general rule, geometry or special axis identifiers can also be used instead of the machine axis identifier, as long as the reference is unambiguous.

Axis groupings					
Identifier	Parameter				Explanation
GEOAX	1. INT: Geometry axis number 1 ... 3	2. AXIS: Channel axis identifier	3. / 5. As 1	4. / 6. As 2	Selection of a parallel coordinate system
FGROUP	1. - 8. AXIS: Channel axis identifier				Variable F value reference: Definition of the axes to which the path feed refers Maximum number of axes: 8 The default setting for the F value reference is activated with FGROUP () without parameters
SPLINEPATH	1. INT: Spline grouping (must be 1)	2. - 9. AXIS: Geometry of additional identifier			Definition of the spline grouping Maximum number of axes: 8
POLYPATH	1. STRING	2. STRING			Activation of the polynomial interpolation for selective axis groups

Coupled motion							Explanation
Identifier	Parameter						
	1.	2.	3.	4.	5.	6.	
TANG	AXIS: Axis name following axis	AXIS: Leading axis 1	AXIS: Leading axis 2	REAL: Coupling factor	CHAR: Option: "B": Tracking in the BCS "W": Tracking in the WCS	CHAR optimization: "S": Standard "P": Autom. with rounding clearance, angle tolerance	Tangential control: Define coupling The tangent for the follow-up is determined by the two master axes specified. The coupling factor specifies the relationship between a change in the angle of tangent and the following axis. It is usually 1.
TANGON	AXIS: Axis name following axis	REAL: Offset angle	REAL: Rounding clearance	REAL: Angular tolerance			Tangential control: Activate coupling
TANGOF	AXIS: Axis name following axis						Tangential control: Deactivate coupling
TLIFT	AXIS: Tracked axis						Tangential control: Activate intermediate block generation
TRAILON	AXIS: Following axis	AXIS: Leading axis	REAL: Coupling factor				Asynchronous coupled motion OFF
TRAILOF	AXIS: Following axis	AXIS: Leading axis					Deactivate coupled-axis motion
TANGDEL	AXIS: Following axis						Tangential control: Delete coupling

4.4 Predefined procedures

Curve tables						
Identifier	Parameter					Explanation
	1.	2.	3.	4.	5.	
CTABDEF	AXIS: Following axis	AXIS: Leading axis	INT: Table number	INT: Behavior at edges of the definition range	STRING: Specification of the storage location	Table definition ON The following motion blocks determine the curve table
CTABEND	AXIS: Following axis	AXIS: Leading axis	INT: Table number	INT: Behavior at edges of the definition range		Table definition OFF
CTABDEL	INT: Table number n	INT: Table number m	STRING: Specification of the storage location			Clear curve table
CTABLOCK	INT: Table number n					Locks the curve table with number n, i.e. this table cannot be deleted/overwritten
CTABUNLOCK	INT: Table number n					Releases the table with the number n protected with CTABLOCK again
LEADON	AXIS: Following axis	AXIS: Leading axis	INT: Table number			Master value coupling ON
LEADOF	AXIS: Following axis	AXIS: Leading axis				Master value coupling OFF

Axial acceleration profile			
Identifier	Parameter		Explanation
	1. – 8.		
BRISKA	AXIS		Activate stepped axis acceleration for the programmed axes
SOFTA	AXIS		Activate jerk-limited axis acceleration for the programmed axes
DRIVEA	AXIS		Activate knee-shaped acceleration characteristic for the programmed axes
JERKA	AXIS		The acceleration behavior set in machine data \$MA_AX_JERK_ENABLE is active for the programmed axes

Revolutional feedrate				
Identifier	Parameter			Explanation
	1.	2.		
FPRAON	1.	2.		Axial revolutional feedrate ON
	AXIS: Axis for which revolutional feedrate is activated	AXIS: Axis/spindle from which revolutional feedrate is derived. If no axis has been programmed, the revolutional feedrate is derived from the master spindle.		
FPRAOF	1. - n.			Axial revolutional feedrate OFF The revolutional feedrate can be deactivated for several axes simultaneously. You can program as many axes as are permitted in a block.
	AXIS: Axes for which revolutional feedrate is deactivated			
FPR	1.			Selection of a rotary axis or spindle from which the revolutional feedrate of the path is derived for G95. The setting made with FPR is modal.
	AXIS: Axis/spindle from which revolutional feedrate is derived. If no axis has been programmed, the revolutional feedrate is derived from the master spindle.			

Transformations				
Identifier	Parameter			Explanation
	1.	2.	3.	
TRACYL	REAL: Working diameter	INT: Number of the transformation		Cylinder: Peripheral surface transformation Several transformations can be set per channel. The transformation number specifies which transformation is to be activated. If the 2nd parameter is omitted, the transformation grouping set via MD is activated.
TRANSMIT	INT: Number of the transformation			Transmit: Polar transformation Several transformations can be set per channel. The transformation number specifies which transformation is to be activated. If the parameter is omitted, the transformation group defined in the MD is activated.

4.4 Predefined procedures

Transformations				
Identifier	Parameter			Explanation
	1.	2.	3.	
TRAANG	REAL: Angle	INT: Number of the transformation		Transformation inclined axis Several transformations can be set per channel. The transformation number specifies which transformation is to be activated. If the 2nd parameter is omitted, the transformation grouping set via MD is activated. If the angle is not programmed (TRAANG (,2) or TRAANG) the last angle applies modally.
TRAORI	INT: Number of the transformation			4-axis, 5-axis transformation Several transformations can be set per channel. The transformation number specifies which transformation is to be activated.
TRACON	INT: Number of the transformation	REAL: Further parameters, MD-dependent		Cascaded transformation The meaning of the parameters depends on the type of cascading.
TRAFOOF				Deactivate transformation
TRAFOON	STRING: Name of the transformation data set	REAL: Reference or working diameter (TRACYL only)	BOOL: With/without groove side offset (TRACYL only)	Activate a transformation defined with kinematic chains

Spindle			
Identifier	Parameter		Explanation
	1	2. - n.	
SPCON	INT: Spindle number	INT: Spindle number	Switch to position-controlled spindle operation.
SPCOF	INT: Spindle number	INT: Spindle number	Switch to speed-controlled spindle operation.
SETMS	INT: Spindle number		Declaration of spindle as master spindle for the current channel With SETMS(), the machine data default applies automatically without any need for parameterization.

Grinding			
Identifier	Parameter		Explanation
	1.		
GWPSON	INT: Spindle number	Constant grinding wheel peripheral speed ON If the spindle number is not programmed, the grinding wheel peripheral speed for the spindle of the active tool is selected.	
GWPSOF	INT: Spindle number	Constant grinding wheel peripheral speed OFF If the spindle number is not programmed, the grinding wheel peripheral speed for the spindle of the active tool is deselected.	
TMON	INT: T number	Grinding-specific tool monitoring ON If no T number is programmed, monitoring is activated for the active tool.	
TMOF	INT: T number	Tool monitoring OFF If no T number is programmed, monitoring is deactivated for the active tool.	

Stock removal					
Identifier	Parameter				Explanation
	1.	2.	3.	4.	
CONTPRON	REAL [, 11]: Contour table	CHAR: Ma- chining type	INT: Number of re- lief cuts	INT: Status of the calculation	Activate reference preprocessing The contour programs or NC blocks which are called in the following steps are divided into individual movements and stored in the contour table. The number of relief cuts is returned.
CONTDCON	REAL [, 6]: Contour table	INT: Machining di- rection			Contour decoding The blocks for a contour are stored in a named table with one table line per block and coded to save memory.
EXECUTE	INT: Error sta- tus				Activate program execution This switches back to normal program execution from reference point editing mode or after setting up a protection area.

Execute table			
Identifier	Parameter		Explanation
	1.		
EXECTAB	REAL [11]: Element from motion table	Execute an element from a motion table	

4.4 Predefined procedures

Protection areas						
Identifier	Parameter					Explanation
	1.	2.	3.	4.	5.	
CPROTDEF	INT: Number of the protection area	BOOL: TRUE: Tool-related protection area	INT: 0: 4th and 5th parameters are not evaluated 1: 4th parameter is evaluated 2: 5th parameter is evaluated 3: 4th and 5th parameters are evaluated	REAL: Limit in plus direction	REAL: Limit in minus direction	Definition of a channel-specific protection area
NPROTDEF	INT: Number of the protection area	BOOL: TRUE: Tool-related protection area	INT: 0: 4th and 5th parameters are not evaluated 1: 4th parameter is evaluated 2: 5th parameter is evaluated 3: 4th and 5th parameters are evaluated	REAL: Limit in plus direction	REAL: Limit in minus direction	Definition of a machine-specific protection area

Protection areas						
Identifier	Parameter					Explanation
	1.	2.	3.	4.	5.	
CPROT	INT: Number of the protection area	INT: Option 0: Protection area OFF 1: Preactivate protection area 2: Protection area ON 3: Preactivate protection area with conditional stop, only with protection areas active	REAL: Offset of the protection area in the first geometry axis	REAL: Offset of the protection area in the second geometry axis	REAL: Offset of the protection area in the third geometry axis	Channel-specific protection area ON/OFF
NPROT	INT: Number of the protection area	INT: Option 0: Protection area OFF 1: Preactivate protection area 2: Protection area ON 3: Preactivate protection area with conditional stop, only with protection areas active	REAL: Offset of the protection area in the first geometry axis	REAL: Offset of the protection area in the second geometry axis	REAL: Offset of the protection area in the third geometry axis	Machine-specific protection area ON/OFF

Preprocessing / single block		
Identifier	Parameter	Explanation
STOPRE		Preprocessing stop until all prepared blocks in the main run are executed
SBLOF		Suppress single-block processing
SBLON		Cancel suppression of the single-block processing

4.4 Predefined procedures

Interrupts			
Identifier	Parameter		Explanation
	1.		
DISABLE	INT: Number of the interrupt input		Deactivates the interrupt routine assigned to the specified hardware input. Fast retraction is not executed. The assignment between the hardware input and the interrupt routine made with SETINT remains valid and can be reactivated with ENABLE.
ENABLE	INT: Number of the interrupt input		Reactivation of the interrupt routine assignment deactivated with DISABLE.
CLRINT	INT: Number of the interrupt input		Delete assignment of interrupt routines and attributes to an interrupt input. The interrupt routine is deactivated and no reaction occurs when the interrupt is generated.

Synchronized actions			
Identifier	Parameter		Explanation
	1. - n.		
CANCEL	INT: Number of the synchronized action		Aborts the modal synchronized action with the specified ID. Several IDs, separated by commas, can be specified.
CANCELSUB			Cancel current subprogram level

Function definition					
Identifier	Parameter				Explanation
	1.	2.	3.	4.-7.	
FCTDEF	INT: Function number	REAL: Lower limit value	REAL: Upper limit value	REAL: Coefficients a0 - a3	Define polynomial function This is evaluated in SYFCT or PUTFTOCF.

Communication			
Identifier	Parameter		Explanation
	1.	2.	
MMC	STRING: Command	CHAR: Acknowledgement mode*) "N": Without acknowledgement "S": Synchronous acknowledgement "A": Asynchronous acknowledgement	Command to HMI command Interpreter for the configuration of windows via NC program

) Commands are acknowledged on request from the executing component (channel, NC, etc.).

Program coordination				
Identifier	Parameter			Explanation
INIT	1.	2.	3.	Selection of an NC program for execution in a channel
	INT: Channel number or channel name from MD20000*)	STRING: Path specification	CHAR: Acknowledgement mode**)	
	1. - n.			
START	INT: Channel number or channel name from MD20000*)			Start selected programs simultaneously in several channels from current program This command has no effect for the own channel
WAITE	INT: Channel number or channel name from MD20000*)			Wait for end of program in one or more other channels
	1.	2. - n.		
WAITM	INT: Marker number	INT: Channel number or channel name from MD20000*)		Wait until a marker is reached in the specified channels The previous block is terminated with exact stop
WAITMC	INT: Marker number	INT: Channel number or channel name from MD20000*)		Wait until a marker is reached in the specified channels An exact stop is initiated only if the other channels have not yet reached the marker
	1. - n.			
SETM	INT: Marker number			Set one or more markers for the channel coordination The processing in own channel is not affected by this.
CLEARM	INT: Marker number			Delete one or more markers for the channel coordination The processing in own channel is not affected by this.
	1. - n.			
WAITP	AXIS: Axis identifier			Wait until the specified positioning axes that were previously programmed with POSA, reach their programmed end point

4.4 Predefined procedures

Program coordination					
Identifier	Parameter				Explanation
WAITS	INT: Spindle number				Wait until the specified spindles that were previously programmed with SPOSA, reach their programmed end point
RET	1. INT (or STRING): Jump target (block no./ marker) for return	2. INT: 0: Return jump to jump destination from 1st par. > 0: Return to the following block	3. INT: Number of subprogram levels to be skipped	4. BOOL: Return to first block in the main program	End of subprogram with no function output to the PLC If the 1st parameter (jump destination) is specified, the return jump is first made to the block after the calling block. The target is then sought depending on the programming (RET or RETB) according to the following strategy: <ul style="list-style-type: none"> RET: Search in the direction of the end of the program. A search is made toward the start of the program if the search was not successful. RETB: Search in the direction of the start of the program. A search is made toward the end of the program if the search was not successful.
RETB	INT (or STRING): Jump target (block no./ marker) for return	INT: 0: Return jump to jump destination from 1st par. > 0: Return to the following block	INT: Number of subprogram levels to be skipped	BOOL: Return to first block in the main program	
	1. - n.				
GET	AXIS: Axis identifier ***)				Assign machine axis(axes) The specified axes must be released in the other channel with RELEASE
GETD	AXIS: Axis identifier ***)				Assign machine axis(axes) directly The specified axes must not be released with RELEASE
RELEASE	AXIS: Axis identifier ***)				Release machine axis(axes)
	1.	2.	3.	4.	
PUTFTOC	REAL: Offset value	INT: Parameter number	INT: Channel number or channel name from MD20000*)	INT: Spindle number	Change of fine tool compensation

Program coordination					
Identifier	Parameter				Explanation
PUTFTOCF	INT: No. of the function	VAR REAL: Reference value	INT: Pa- rameter number	INT: Channel number or channel name from MD20000*)	Change of fine tool compensation depending on a function defined with FCTDEF (max. 3rd degree polynomial) The number used here must be specified in FCTDEF
AXTOCHAN	1. AXIS: Axis identifi- er	2. INT: Channel number or channel name from MD20000*)	3. - n. As 1 ...	4. - m. As 2 ...	Axes transferred to other channels

) Instead of channel numbers, the channel names defined via MD20000 \$MC_CHAN_NAME can also be programmed.

**) Commands are acknowledged on request from the executing component (channel, NC, etc.).

***) The SPI function can be used to program a spindle instead of an axis. E.g. GET(SPI(1))

Data access		
Identifier	Parameter	Explanation
CHANDATA	1. INT: Channel num- ber	Set channel number for channel data access (only permitted in the initialization block). The following access refers to the channel set with CHANDATA.
NEWCONF		Accept changed machine data

Messages			
Identifier	Parameter		Explanation
	1.	2.	
MSG	STRING: Message	INT: Execution	Output arbitrary character string as message on the user interface
WRTPR	STRING: Character string	INT: Execution	Write string in OPI variable

4.4 Predefined procedures

File access						
Identifier	Parameter					Explanation
READ	1.	2.	3.	4.	5.	Read blocks from file system
	VAR INT: Error	CHAR[160]: File name	INT: Start line of the file section to be read	INT: Number of lines to be read	VAR CHAR[255]: Variable array in which the read information is stored	
WRITE	1.	2.	3.	4.		Write block to file system (or to an external device/file)
	VAR INT: Error	CHAR[160]: File name	STRING: Device/file for external output	CHAR[200]: Block		
DELETE	1.	2.				Delete file
	VAR INT: Error	CHAR[160]: File name				

Alarms			
Identifier	Parameter		Explanation
	1.	2.	
SETAL	INT: Alarm number (cycle alarms)	STRING: Character string	Set alarm A character string with up to four parameters can be specified in addition to the alarm number. The following predefined parameters are available: %1 = channel number %2 = block number, label %3 = text index for cycle alarms %4 = additional alarm parameters

Tool management				
Identifier	Parameter			Explanation
	1.	2.		
DELDL	INT: T no.	INT: D no.	Delete all additive offsets of the tool edge (or of a tool if D is not specified)	
DELT	STRING[32]: Tool identifier	INT: Duplo no.	Delete tool Duplo number can be omitted	

4.4 Predefined procedures

Tool management							
Identifier	Parameter						Explanation
DELTC	INT: Data set no. n	INT: Data set no. m					Delete tool carrier data set number n to m
DZERO							Set D numbers of all tools of the TO unit assigned to the channel to invalid
	1.	2.	3.	4.	5.	6.	
GETFREELOC	VAR INT: Magazine no. (return value)	VAR INT: Location no. (return value)	INT: T no.	INT: Reference magazine no.	CHAR: Specification dep. on 4th parameter	INT: Reservation mode	Find empty location for a tool
	1.	2.					
GETSELT	VAR INT: T no. (return value)	INT: Spindle no.					Returns the T number of the tool preselected for the spindle
GETEXET	VAR INT: T no. (return value)	INT: Spindle no.					Returns the T number of the tool active from the point of view of the NC program
GETTENV	STRING: Name of the tool environment	INT AR- RAY[3]: Return values					Reads the T, D and DL numbers stored in a tool environment
	1.	2.	3.	4.			
POSM	INT: No. of the location for positioning	INT: No. of the magazine to be moved	INT: Location no. of the internal magazine	INT: Magazine no. of the internal magazine			Position magazine
RESETMON	VAR INT: Status = result of the operation (return value)	INT: Internal T no.	INT: D no. of the tool	INT: Optional bit-coded parameter			Set actual value of tool to setpoint
	1.	2.	3.				
SETDNO	INT: T no.	INT: Cutting edge no.	INT: D no.				Set offset number (D) of the cutting edge of the tool (T)

4.4 Predefined procedures

Tool management						
Identifier	Parameter					Explanation
SETMTH	1.					Set tool carrier no.
	INT: Tool carrier no.					
SETPIECE	1.	2.				Decrement workpiece counter of the spindle Update the count monitoring data of the tools associated with the machining process
	INT: Value used when decrementing	INT: Spindle no.				
	1.	2.	3.	4.		
SETTA	VAR INT: Status = result of the operation (return value)	INT: Magazine no.	INT: Wear group no.	INT: Tool sub-group		Activate tool from wear group
SETTIA	VAR INT: Status = result of the operation (return value)	INT: Magazine no.	INT: Wear group no.	INT: Tool sub-group		Deactivate tool from wear group
TCA	1.	2.	3.			Tool selection/change irrespective of the tool status
	STRING[32]: Tool identifier	INT: Duplo no.	INT: Tool carrier no.			
TCI	1.	2.				Load tool from buffer into the magazine
	INT: No. of the buffer	INT: Tool carrier no.				
MVTOOL	1.	2.	3.	4.	5.	Language command to move tool
	INT: Status	INT: Magazine no.	INT: Location no.	INT: Magazine no. after moving	INT: Target location no. after moving	

Tool orientation				
Identifier	Parameter			Explanation
	1.	2.	3.	
ORIRESET	REAL: Initial setting, 1st geometry axis	REAL: Initial setting, 2nd geometry axis	REAL: Initial setting, 3rd geometry axis	Initial setting of the tool orientation

Synchronous spindle							
Identifier	Parameter						Explanation
	1.	2.	3.	4.	5.	6.	
COUPDEF	AXIS: Follow- ing spin- dle	AXIS: Leading spindle	REAL: Numerator of transmis- sion ratio	REAL: Denomina- tor of trans- mission ra- tio	STRING[8]: Block change be- havior	STRING[2]: Coupling type	Define synchronous spindle grouping
COUPDEL	AXIS: Follow- ing spin- dle	AXIS: Leading spindle					Delete synchronous spindle grouping
COUPRES	AXIS: Follow- ing spin- dle	AXIS: Leading spindle					Reset coupling param- eters to configured MD and SD values
COUPON	AXIS: Follow- ing spin- dle	AXIS: Leading spindle	REAL: Switch-on position of the follow- ing spindle				Switch-on synchro- nous spindle coupling If a switch-on position is specified for the fol- lowing spindle (angu- lar offset between FS and LS that refers -- absolutely or incre- mentally -- to the zero degree position of the LS in the positive direc- tion of rotation), the coupling is only switch- ed on when the speci- fied position is crossed.
COUPONC	AXIS: Follow- ing spin- dle	AXIS: Leading spindle					Switch-on synchro- nous spindle coupling With COUPONC, the currently active speed of the following spindle is taken over when switching on the cou- pling (M3/M4 S...).

4.4 Predefined procedures

Synchronous spindle							
Identifier	Parameter						Explanation
	1.	2.	3.	4.	5.	6.	
COUPOF	AXIS: Following spindle	AXIS: Leading spindle	REAL: Switch-off position of the following spindle (absolute)	REAL: Switch-off position of the leading spindle (absolute)			Switch-off synchronous spindle coupling If positions are specified, the coupling is only cancelled when all the specified positions have been overtraveled The following spindle continues to revolve at the last speed programmed before deactivation of the coupling
COUPOFS	AXIS: Following spindle	AXIS: Leading spindle	REAL: Switch-off position of the following spindle (absolute)				Switch off the synchronous spindle coupling with stop of the following spindle If a position is specified, the coupling is only cancelled when the specified position is crossed
WAITC	AXIS: Following spindle	STRING [8]: Block change behavior	AXIS: Following spindle	STRING[8]: Block change behavior			Wait until the coupling block change criterion for the spindles (max. 2) has been fulfilled If the block change behavior is not specified, the block change behavior specified in the definition with COUP-DEF applies

Electronic gear							
Identifier	Parameter						Explanation
EGDEL	1.						Delete coupling definition for the following axis
	AXIS: Following axis						
EGDEF	1.	2. / 4. / 6. / 8. / 10.	3. / 5. / 7. / 9. / 11.				Definition of an electronic gear
	AXIS: Following axis	AXIS: Leading axis	INT: Coupling type				

Electronic gear										
Identifier	Parameter								Explanation	
EGON	1.	2.	3. / 6. / 9. / 12. / 15.	4. / 7. / 10. / 13. / 16.	5. / 8. / 11. / 14. / 17.				Electronic gear ON without synchronization	
	AXIS: Following axis	STRING: Block change behavior	AXIS: Leading axis	REAL: Numerator of the coupling factor	REAL: Denominator of the coupling factor					
EGONSYN	1.	2.	3.	4. / 8. / 12. / 16. / 20.	5. / 9. / 13. / 17. / 21.	6. / 10. / 14. / 18. / 22.	7. / 11. / 15. / 19. / 23.			Electronic gear ON with synchronization
	AXIS: Following axis	STRING: Block change behavior	REAL: Synchronized position of the following axis	AXIS: Leading axis	REAL: Synchronized position of the leading axis	REAL: Numerator of the coupling factor	REAL: Denominator of the coupling factor			
EGONSYNE	1.	2.	3.	4.	5. / 9. / 13. / 17. / 21.	6. / 10. / 14. / 18. / 22.	7. / 11. / 15. / 19. / 23.	8. / 12. / 16. / 20. / 24.	Electronic gear ON with synchronization and specification of the approach mode	
	AXIS: Following axis	STRING: Block change behavior	REAL: Synchronized position of the following axis	STRING: Approach mode	AXIS: Leading axis	REAL: Synchronized position of the leading axis	REAL: Numerator of the coupling factor	REAL: Denominator of the coupling factor		
EGOFS	1.	2. - n.							Turn off electronic gear selectively	
	AXIS: Following axis	AXIS: Leading axis								
EGOFC	1.								Switch off electronic gear (version only for spindles)	
	AXIS: Following spindle									

4.4 Predefined procedures

Nibbling					
Identifier	Parameter				Explanation
	1.	2.	3.	4.	
PUNCHAAC	REAL: Minimum hole spacing	REAL: Initial acceleration	REAL: Maximum hole spacing	REAL: Final acceleration	Activate travel-dependent acceleration

Information functions in the passive file system					
Identifier	Parameter			Explanation	
	1.	2.	3.		
FILEDATE	VAR INT: Error message	CHAR[160]: File name	VAR CHAR[8]: Date in the format "dd.mm.yy"	Returns the date of the last write access to a file	
FILETIME	VAR INT: Error message	CHAR[160]: File name	VAR CHAR[8]: Time in the format "hh.mm.ss"	Returns the time of the last write access to a file	
FILESIZE	VAR INT: Error message	CHAR[160]: File name	VAR INT: File size	Returns the current size of a file	
FILESTAT	VAR INT: Error message	CHAR[160]: File name	VAR CHAR[5]: Date in the format "rwxsd"	Returns the status of a file with respect to the following rights: <ul style="list-style-type: none"> • Read (r: read) • Write (w: write) • Execute (x: execute) • Show (s: show) • Delete (d: delete) 	
FILEINFO	VAR INT: Error message	CHAR[160]: File name	VAR CHAR[32]: Date in the format "rwxsd nnnnnnnn dd.mm.yy hh:mm:ss"	Returns the sum of the information for a file that can be read out via FILEDATE, FILETIME, FILESIZE, and FILESTAT	

Axis container			
Identifier	Parameter		Explanation
	1. - n.		
AXCTSWE	AXIS: Axis container		Rotate axis container
AXCTSWED	AXIS: Axis container		Rotating axis container (command variant for commissioning!)
AXCTSWEC:	AXIS: Axis container		Cancel enable for axis container rotation

Master/slave coupling			
Identifier	Parameter		Explanation
	1. - n.		
MASLON	AXIS: Axis identifier		Switch on master/slave coupling
MASLOF	AXIS: Axis identifier		Separate master/slave coupling
MASLOFS	AXIS: Axis identifier		Separate master/slave coupling and automatically brake slave spindles
MASLDEF	AXIS: Axis identifier		Define master/slave coupling The last axis is the master axis
MASLDEL	AXIS: Axis identifier		Separate master/slave coupling and delete the definition of the grouping

Online tool length offset			
Identifier	Parameter		Explanation
	1.	2.	
TOFFON	AXIS: Offset direction	REAL: Offset value in offset direction	Activate online tool length offset in the specified offset direction
TOFFOF	AXIS: Offset direction		Reset online tool length offset in the specified offset direction

SERUPRO		
Identifier	Parameter	Explanation
IPTRLOCK		Start of untraceable program section
IPTRUNLOCK		End of search-suppressed program section

Retraction		
Identifier	Parameter	Explanation
	1. - n.	
POLFMASK	AXIS: Geometry or machine axis name	Enable axes for rapid retraction (without a connection between the axes)
POLFMLIN	AXIS: Geometry or machine axis name	Enable axes for linear rapid retraction

Tables

4.4 Predefined procedures

Retraction				
Identifier	Parameter			Explanation
POLFA	1.	2.	3.	Retraction position for single axes
	AXIS: Channel axis identifier	INT: Type	REAL: Value	

Collision avoidance			
Identifier	Parameter		Explanation
	1.		
PROTA	STRING: "R"		Request for a recalculation of the collision model
	1.	2. - n.	Set protection area status
PROTS	CHAR: Status	STRING: Protection zone name	

Intelligent load adjustment					
Identifier	Parameter				Explanation
CADAPTON	1.	2.	3.	4.	Activate load adjustment
	INT: Status	AXIS: machine axis name	INT: input variable	REAL: input value (optional)	
CADAPTOF	1.	2.	3.		Deactivate load adjustment
	INT: Status	AXIS: machine axis name	INT: input variable		

4.5 Predefined procedures in synchronized actions

The following predefined procedures are only available in synchronized actions.

Synchronous procedures		
Identifier	Parameter	Explanation
STOPREOF		Revoke preprocessing stop A synchronized action with a STOPREOF command causes a preprocessing stop after the next output block (= block for the main run). The preprocessing stop is canceled with the end of the output block or when the STOPREOF condition is fulfilled. All synchronized action operations with the STOPREOF command are therefore interpreted as having been executed.
RDISABLE		Read-in disable
DELDTG	1. AXIS: Axis for axial delete distance-to-go (optional). If the axis is omitted, delete distance-to-go is triggered for the path distance.	Delete distance-to-go A synchronized action with a DELDTG command causes a preprocessing stop after the next output block (= block for the main run). The preprocessing stop is canceled with the end of the output block or when the first DELDTG condition is fulfilled. The axial distance to the destination point on an axial delete distance-to-go is stored in \$AA_DELT[axis]; the distance-to-go is stored in \$AC_DELT.

Program coordination of technology cycles		
Identifier	Parameter	Explanation
	1.	
LOCK	INT: ID of the synchronized action to be disabled	Lock synchronized action with ID or stop technology cycle One or more IDs can be programmed
UNLOCK	INT: ID of the synchronized action to be unlocked	Unlock synchronized action with ID or continue technology cycle One or more IDs can be programmed
ICYCON		Each block of a technology cycle is processed in a separate interpolation cycle following ICYCON
ICYCOF		All blocks of a technology cycle are processed in one interpolation cycle following ICYCOF

4.5 Predefined procedures in synchronized actions

Polynomial functions						
Identifier	Parameter					Explanation
SYNFCT	1.	2.	3.			If the condition in the motion-synchronous action is fulfilled, the polynomial determined by the first expression is evaluated at the input variable. The upper and lower range of the value is limited and the result variable is assigned.
	INT: Number of the polynomial function defined with FCTDEF	VAR REAL: Result variable *)	VAR REAL: Input variable **)			
FTOC	1.	2.	3.	4.	5.	Change of fine tool compensation depending on a function defined with FCTDEF (max. 3rd degree polynomial). The number used here must be specified in FCTDEF.
	INT: Number of the polynomial function defined with FCTDEF	VAR REAL: Input variable **)	INT: Length 1, 2, 3	INT: Channel number	INT: Spindle number	

*) Only special system variables are permissible as a result variable (see Function Manual Synchronized Actions).

***) Only special system variables are permissible as input variable (see Function Manual Synchronized Actions).

4.6 Predefined functions

The call of a predefined function triggers the execution of a predefined NC function, which in contrast to the predefined procedure, supplies a return value. The call of the predefined function can be an operand in an expression.

Coordinate system						
Identifier	Return value	Parameter				Explanation
		1.	2.	3. - 15.	4. - 16.	
CTTRANS	FRAME	AXIS: Axis identifier	REAL: Offset	AXIS: Axis identifier	REAL: Offset	Translation: Zero offset COARSE for multiple axes
CFINE	FRAME	AXIS: Axis identifier	REAL: Offset	AXIS: Axis identifier	REAL: Offset	Translation: Zero offset for FINE multiple axes
CSCALE	FRAME	AXIS: Axis identifier	REAL: Scale factor	AXIS: Axis identifier	REAL: Scale factor	Scale: Scale factor for multiple axes
		1.	2.	3. and 5.	4. and 6.	
CROT	FRAME	AXIS: Axis identifier	REAL: Rotation	AXIS: Axis identifier	REAL: Rotation	Rotation: Rotation of the current coordinate system Maximum number of parameters: 6 (one axis identifier and one value per geometry axis)
CROTS	FRAME	AXIS: Axis identifier	REAL: Rotation with solid angle	AXIS: Axis identifier	REAL: Rotation with solid angle	Rotation: Rotation of the current coordinate system with solid angle Maximum number of parameters: 6 (one axis identifier and one value per geometry axis)
CMIRROR		1.	2. - 8.			Mirror: Mirror on a coordinate axis
	FRAME	AXIS	AXIS			

4.6 Predefined functions

Coordinate system					
Identifier	Return value	Parameter			Explanation
		1.	2.		
CRPL	FRAME	INT: Rotary axis	REAL: Angle of rotation		Frame rotation in any plane
ADDFRAME	INT: 0: OK 1: Specified target (string) is wrong 2: Target frame is not configured 3: Rotation in frame is not permitted	FRAME: Additively measured or calculated frame	STRING: Specified target frame		Calculates the target frame specified by the string The target frame is calculated in such a way that the new complete frame appears as a chain of the old complete frame and the transferred frame.
INVFRAME	FRAME	1. FRAME			Calculates the inverse frame from a frame The frame chaining of a frame with its inverse frame always results in a zero frame
MEAFRAME	FRAME	1. REAL[3,3]: Coordinates of the measured spatial points	2. REAL[3,3]: Coordinates of the specified points	3. VAR REAL: Variable with which the information on the quality of FRAME calculation is returned	Frame calculation from 3 measuring points in space

Geometry functions					
Identifier	Return value	Parameter			Explanation
		1.	2.	3.	
CALCDAT	BOOL: Error status	VAR REAL [n, 2]: Table (abscissa, ordinate) of points 1 to n	INT: Number of points	VAR REAL [3]: Result: Abscis- sa, ordinate and radius of calcula- ted circle center point	Calculates the center point coordi- nates and the radius of the circle from 3 or 4 points The points must be different.
INTERSEC	BOOL: Error status	VAR REAL [11]: First contour ele- ment	VAR REAL [11]: Second contour element	VAR REAL [2]: Result vector for the intersection coordinates: Ab- scissa and ordi- nate	Calculates the intersection coordi- nates between two contour ele- ments. The error status indicates wheth- er an intersection was found.

Curve table functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
CTAB	REAL: Follow- ing axis position	REAL: Leading axis posi- tion	INT: Table number	VAR RE- AL[]: Pitch re- sult	AXIS: Follow- ing axis for scal- ing	AXIS: Leading axis for scaling		Determines the follow- ing axis position to the specified leading axis position from the curve table. If parameters 4/5 are not programmed, cal- culation is with stand- ard scaling.
CTABINV	REAL: Leading axis posi- tion	REAL: Follow- ing axis position	REAL: Leading position	INT: Table number	VAR RE- AL[]: Pitch re- sult	AXIS: Follow- ing axis for scal- ing	AXIS: Leading axis for scaling	Determines the lead- ing axis position to the specified following ax- is position from the curve table. If parameters 5/6 are not programmed, cal- culation is with stand- ard scaling.
CTABID	INT: Curve ta- ble num- ber	INT: Entry number in memo- ry	STRING: Storage location: "SRAM", "DRAM"					Determines the curve table number entered under the specified number in the memory.

4.6 Predefined functions

Curve table functions									
Identifier	Return value	Parameter						Explanation	
		1.	2.	3.	4.	5.	6.		
CTABISLOCK	INT: Lock state	INT: Table number							Determines the lock state of the curve table: > 0: Table is locked 1: CTABLOCK 2: Active coupling 3: CTABLOCK and active coupling 0: Table is not locked -1: Table does not exist
CTABEXISTS	INT: Existence	INT: Table number							Determines the existence of the curve table in the static or dynamic NC memory: 0: FALSE 1: TRUE
CTABMEMTYP	INT: Storage location	INT: Table number							Determines the storage location of the curve table: 1: DRAM 0: SRAM -1: Table does not exist
CTABPERIOD	INT: Periodicity	INT: Table number							Determines the periodicity of the curve table: 0: Not periodic 1: Periodic in leading axis 2: Periodic in leading and following axis -1: Table does not exist
CTABNO	INT: Number of curve tables								Determines the number of defined curve tables (in static and dynamic NC memory)
CTABNOMEM	INT: Number of curve tables	STRING: Storage location: "SRAM", "DRAM"							Determines the number of defined curve tables in the specified memory
CTABFNO	INT: Number of tables	STRING: Storage location: "SRAM", "DRAM"							Determines the number of curve tables still possible in the specified memory

Curve table functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
CTABSEG	INT: Number of curve segments	STRING: Storage location: "SRAM", "DRAM"	STRING: Segment type: "L": Linear "P": Polynomial					Determines the number of curve segments used of the specified segment type in the specified memory >=0: Number -1: Invalid memory type If parameter 2 is not programmed, the sum of the linear and polynomial segments is output.
CTABFSEG	INT: Number of curve segments	STRING: Storage location: "SRAM", "DRAM"	STRING: Segment type: "L": Linear "P": Polynomial					Determines the number of still possible curve segments of the specified segment type in the specified memory >=0: Number -1: Invalid memory type
CTABSEGID	INT: Number of curve segments	INT: Table number	STRING: Segment type: "L": Linear "P": Polynomial					Determines the number of curve segments of the specified segment type that are used by the curve table >=0: Number -1: Table does not exist
CTABMSEG	INT: Number of curve segments	STRING: Storage location: "SRAM", "DRAM"	STRING: Segment type: "L": Linear "P": Polynomial					Determines the maximum possible number of curve segments of the specified segment type in the specified memory >=0: Number -1: Table does not exist
CTABPOL	INT: Number of curve polynomials	STRING: Storage location: "SRAM", "DRAM"						Determines the number of used curve polynomials in the specified memory >=0: Number -1: Table does not exist

4.6 Predefined functions

Curve table functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
CTABPOLID	INT: Number of curve polynomials	INT: Table number						Determines the number of curve polynomials used by the curve table >=0: Number -1: Table does not exist
CTABFPOL	INT: Number of curve polynomials	STRING: Storage location: "SRAM", "DRAM"						Determines the maximum possible number of curve polynomials in the specified memory: >=0: Number -1: Table does not exist
CTABMPOL	INT: Number of curve polynomials	STRING: Storage location: "SRAM", "DRAM"						Determines the maximum possible number of curve polynomials in the specified memory: >=0: Number -1: Table does not exist
CTABSSV	REAL: Following axis position	REAL: Leading axis position	INT: Table number	VAR REAL[]: Pitch result	AXIS: Following axis for scaling	AXIS: Leading axis for scaling		Determines the following axis position at the start of the curve segment belonging to the specified leading axis value
CTABSEV	REAL: Following axis position	REAL: Leading axis position	INT: Table number	VAR REAL[]: Pitch result	AXIS: Following axis for scaling	AXIS: Leading axis for scaling		Determines the following axis position at the end of the curve segment belonging to the specified leading axis value
CTABTSV	REAL: Following axis position	INT: Table number	VAR REAL[]: Pitch result at start of the table	AXIS: Following axis				Determines the following axis position at the start of the curve table.
CTABTEV	REAL: Following axis position	INT: Table number	VAR REAL[]: Pitch result at end of the table	AXIS: Following axis				Determines the following axis position at the end of the curve table.
CTABTSP	REAL: Leading axis position	INT: Table number	VAR REAL[]: Pitch result at start of the table	AXIS: Leading axis				Determines the leading axis position at the start of the curve table.

Curve table functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
CTABTEP	REAL: Leading axis position	INT: Table number	VAR REAL []: Pitch result at end of the table	AXIS: Leading axis				Determines the leading axis position at the end of the curve table.
CTABTMIN	REAL: Minimum value	INT: Table number	REAL: Leading value interval lower limit	REAL: Leading value interval upper limit	AXIS: Following axis	AXIS: Leading axis		Determines the minimum value of the following axis in the entire definition range of the curve table or in a defined interval
CTABTMAX	REAL: Maximum value	INT: Table number	REAL: Leading value interval lower limit	REAL: Leading value interval upper limit	AXIS: Following axis	AXIS: Leading axis		Determines the maximum value of the following axis in the entire definition range of the curve table or in a defined interval
Note: The curve table functions can also be programmed in synchronized actions.								

Axis functions						
Identifier	Return value	Parameter				Explanation
		1.	2.	3.	4.	
AXNAME	AXIS: Axis identifier	STRING []: Input string				Converts input string into axis identifier
AXSTRING	STRING []: Axis name	AXIS: Axis identifier				Converts axis identifier into string
ISAXIS	BOOL: Axis present (TRUE) or not (FALSE)	INT: Number of the geometry axis (1 to 3)				Checks whether the geometry axes 1 to 3 specified as parameters are present in accordance with machine data MD20050 \$MC_AXCONF_GEO-AX_ASSIGN_TAB
SPI	AXIS: Axis identifier	INT: Spindle number				Converts spindle number into axis identifier
AXTOSPI	INT: Spindle number	AXIS: Axis identifier				Converts axis identifier into spindle number

4.6 Predefined functions

Axis functions						
Identifier	Return value	Parameter				Explanation
		1.	2.	3.	4.	
MODAXVAL	REAL: modulo value	AXIS: Axis identifier	REAL: Axis position			From the entered axis position, calculates the modulo rest If the specified axis is not a modulo axis, the axis position is returned unchanged.
POSRANGE	BOOL: Position setpoint within the position window (TRUE) or not (FALSE)	AXIS: Axis identifier	REAL: Reference position in the coordinate system	REAL: Position window width	INT: Coordinate system	Determines whether the position setpoint of an axis is located in a window at a predefined reference position

Tool management						
Identifier	Return value	Parameter			Explanation	
		1.	2.	3.		
CHKDM	INT: Status: Result of the check:	INT: Magazine number	INT: D number		Checks the uniqueness of the D number within a magazine	
CHKDNO	INT: Status: Result of the check:	INT: T number of the 1st tool	INT: T number of the 2nd tool	INT: D number	Checks the uniqueness of the D number	
GETACTT	INT: Status	INT: T number	STRING [32]: Tool name		Determines the active tool from a group of tools with the same name	
GETACTTD	INT: Status: Result of the check:	VAR INT: T number found (return value)	INT: D number		Determines the T number associated with an absolute D number	
GETDNO	INT: D number	INT: T number	INT: Cutting edge number		Determines the D number of the cutting edge of tool T	
GETT	INT: T number	STRING [32]: Tool name	INT: Duplo number		Determines the T number for the tool name	
NEWT	INT: T number	STRING [32]: Tool name	INT: Duplo number		Sets up a new tool (provides the tool data) The duplo number can be omitted.	
TOOLENV	INT: Status	STRING: Name			Stores the tool environment with the specified name in the static NC memory	

Tool management					
Identifier	Return value	Parameter			Explanation
		1.	2.	3.	
DELTOOLENV	INT: Status	STRING: Name			Deletes the tool environment with the specified name in the static NC memory Deletes all tool environments if no name is specified.
GETTENV	INT: Status	STRING: Name	VAR INT: T number [0] D number [1] DL number [2]		Determines the T number, D number, and DL number from a tool environment with the specified name

Arithmetic					
Identifier	Return value	Parameter			Explanation
		1.	2.	3.	
SIN	REAL	REAL			Sine
ASIN	REAL	REAL			Arc sine
COS	REAL	REAL			Cosine
ACOS	REAL	REAL			Arc cosine
TAN	REAL	REAL			Tangent
ATAN2	REAL	REAL	REAL		Arc tangent 2
SQRT	REAL	REAL			Square root
POT	REAL	REAL			Square
TRUNC	REAL	REAL			Integer component
ROUND	REAL	REAL			Round down
ROUNDUP	REAL	REAL			Round up
ABS	REAL	REAL			Absolute value
LN	REAL	REAL			Natural logarithm
EXP	REAL	REAL			Exponential function e^x
MINVAL	REAL	REAL	REAL		Determines the smaller value of two parameters
MAXVAL	REAL	REAL	REAL		Determines the larger value of two parameters
BOUND	REAL: Check status	REAL: Lower limit	REAL: Upper limit	REAL: Reference value	Determines whether the reference value is within the limits.

Note:

The arithmetic functions can also be programmed in synchronized actions. These arithmetic functions are calculated and evaluated in the main run. The synchronized action parameter \$AC_PARAM[<n>] can also be used for calculations and as buffer.

4.6 Predefined functions

String functions					
Identifier	Return value	Parameter			Explanation
		1.	2.	3.	
ISNUMBER	BOOL	STRING: Input string			Checks whether the input string can be converted to a number.
NUMBER	REAL	STRING: Input string			Converts the input string into a number.
TOUPPER	STRING	STRING: Input string			Converts the input string into upper case
TOLOWER	STRING	STRING: Input string			Converts the input string into lower case
STRLEN	INT	STRING: Input string			Determines the length of the input string up to the end of the string (/0)
INDEX	INT	STRING: Input string	CHAR: Search characters		Determines the position of the character in the input string from left to right. The 1st character of the string from the left has the index 0.
RINDEX	INT	STRING: Input string	CHAR: Search characters		Determines the position of the character in the input string from right to left. The 1st character of the string from the right has the index 0.
MINDEX	INT	STRING: Input string	STRING: Search character		Determines the position of a character specified in the 2nd parameter in the input string from left to right. The 1st character of the input string from the left has the index 0.
SUBSTR	STRING	STRING: Input string	INT	INT	Determines the substring of the input string, defined by the start character (2nd parameter) and number of characters (3rd parameter).
SPRINT	STRING	STRING: Input string			Determines the formatted input string

4.6 Predefined functions

Functions for measuring cycles								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
CALCPOSI	INT: Status	REAL[3]: Starting position in the WCS	REAL[3]: Incremental path specification in relation to the starting position	REAL[5]: Minimum distances to the monitoring limits	REAL[3]: Return array for the poss. incr. distance	BOOL: Conversion of the measuring system Yes/No	INT: Type of limit monitoring	Checks whether the geometry axes can traverse a defined path without violating the axis limits starting from a specified starting point. If the defined path cannot be traversed without violating limits, the maximum permissible value is returned.
GETTCOR	INT: Status	REAL [11]:	STRING: Tool length component: Coordinate system	STRING: Name of the tool environment	INT: Internal T no. of the tool	INT: Cutting-edge number (D no.) of the tool	INT: Number of the location-dependent offset (DL no. of the tool)	Determines the tool lengths and tool length components from tool environment or current environment
LENTOAX	INT: Status	INT[3]: Axis assignment of the geometry axes	REAL[3]: Matrix for mapping the tool lengths in the coordinate system	STRING: Coordinate system for the assignment				Determines information about the assignment of the tool lengths L1, L2, L3 of the active tool to abscissa, ordinate, applycate. The assignment to the geometry axes is affected by frames and the active plane (G17 - 19).

SETTCOR	INT: Status	1.	2.	3.	4.	5.	6.	7.	8.	9.	
		REAL [3]: Offset vector in space	STR.: Component identifier	INT: Component(s) to be corrected 0 - 11	INT: Type of write operation 0 - 3	INT: Index of the geometry axis	STRIN G: Name of the tool environment	INT: int. T No. of the tool	INT: D no. of the tool	INT: DL no. of the tool	Changes the tool components, considering all supplementary conditions that are included in the evaluation of the individual components

4.6 Predefined functions

Other functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
STRINGIS	INT: Information about the string	STRING: Name of the element to be checked						Checks whether the specified string is available as element of the NC programming language in the current language scope.
ISVAR	BOOL: Variable known Yes/No	STRING: Name of the variable						Checks whether the transfer parameter contains a variable known in the NC (machine data, setting data, system variable, general variables such as GUDs).
GETVARTYP	INT: Data type	STRING: Name of the variable						Determines the data type of a system/user variable
GETVARPHU	INT: Numeric value of the physical unit	STRING: Name of the variable						Determines the physical unit of a system/user variable
GETVARAP	INT: Protection level for access	STRING: Name of the variable	STRING: Type of access					Determines the access right to a system/user variable
GETVARLIM	INT: Status	STRING: Name of the variable	CHAR: Specifies which limit value should be read out	VAR REAL: Return of the limit value				Determines the lower/upper limit value of a system/user variable
GETVARDFT	INT: Status	STRING: Name of the variable	VAR REAL / STRING/ FRAME: Return of the default value	INT: Index to the first dimension (optional)	INT: Index to the second dimension (optional)	INT: Index to the third dimension (optional)		Determines the default value of a system/user variable
COLLPAIR	INT: Check result	STRING: Name of the 1st protection area	STRING: Name of the 2nd protection area	BOOL: Alarm suppression (optional)				Checks whether part of a collision pair

4.6 Predefined functions

Other functions								
Identifier	Return value	Parameter						Explanation
		1.	2.	3.	4.	5.	6.	
PROTD	REAL: Clearance of the two protection zones	STRING: Name of the 1st protection area	STRING: Name of the 2nd protection area	VAR REAL: Return value: 3-dimensional clearance vector	BOOL: Measuring system for clearance and clearance vector (optional)			Determines the clearance of the two specified protection areas.
DELOBJ	INT: Error number	STRING: Component type to be deleted	INT: Start index of the components to be deleted (optional)	INT: End index of the components to be deleted (optional)	BOOL: Alarm suppression (optional)			Deletes elements from kinematic chains, protection areas, protection area elements, collision pairs and transformation data
NAMETOINT	INT: System variable index	STRING: Name of the system variable array	STRING: Character string / name	BOOL: Alarm suppression (optional)				Determines the associated system variable index based on the character string
ORISOLH	INT: Error number	INT: Controls the behavior of the function	REAL: First angle	REAL: Second angle				Helps the user to set the rotary axis positions of a machine so that a turning tool can be brought into a defined, kinematic-independent position relative to the workpiece. Requirement: A 6-axis transformation is active that has been parameterized with kinematic chains.
CORRTRAF0	INT: Error number	REAL: Correction vector	INT: Element to be modified	INT: Correction mode	BOOL: Alarm suppression (optional)			Modifies offset vectors or direction vectors of the orientation axes in the kinematic model of the machine.
CORRTC	INT: Error number	REAL: Correction vector	INT: Element to be modified	INT: Correction mode	BOOL: Alarm suppression (optional)			Modify offset vectors or direction vectors of orientable tool carriers according to machine measurement.

Appendix

A

A.1 List of abbreviations

A	
O	Output
ADI4	(Analog drive interface for 4 axes)
AC	Adaptive Control
ALM	Active Line Module
ARM	Rotating induction motor
AS	Automation system
ASCII	American Standard Code for Information Interchange: American coding standard for the exchange of information
ASIC	Application-Specific Integrated Circuit: User switching circuit
ASUB	Asynchronous subprogram
AUXFU	Auxiliary function: Auxiliary function
STL	Statement List
UP	User Program

B	
OP	Operating Mode
BAG	Mode group
BCD	Binary Coded Decimals: Decimal numbers encoded in binary code
BERO	Contact-less proximity switch
BI	Binector Input
BICO	Binector Connector
BIN	BINARY files: Binary files
BIOS	Basic Input Output System
BCS	Basic Coordinate System
BO	Binector Output
OPI	Operator Panel Interface

C	
CAD	Computer-Aided Design
CAM	Computer-Aided Manufacturing
CC	Compile Cycle: Compile cycles
CEC	Cross Error Compensation
CI	Connector Input
CF Card	Compact Flash Card

C	
CNC	Computerized Numerical Control: Computer-Supported Numerical Control
CO	Connector Output
CoL	Certificate of License
COM	Communication
CPA	Compiler Projecting Data: Configuring data of the compiler
CRT	Cathode Ray Tube: picture tube
CSB	Central Service Board: PLC module
CU	Control Unit
CP	Communication Processor
CPU	Central Processing Unit: Central processing unit
CR	Carriage Return
CTS	Clear To Send: Ready to send signal for serial data interfaces
CUTCOM	Cutter radius Compensation: Tool radius compensation

D	
DAC	Digital-to-Analog Converter
DB	Data Block (PLC)
DBB	Data Block Byte (PLC)
DBD	Data Block Double word (PLC)
DBW	Data Block Word (PLC)
DBX	Data block bit (PLC)
DDE	Dynamic Data Exchange
DDS	Drive Data Set: Drive data set
DIN	Deutsche Industrie Norm
DIO	Data Input/Output: Data transfer display
DIR	Directory: Directory
DLL	Dynamic Link Library
DO	Drive Object
DPM	Dual Port Memory
DPR	Dual Port RAM
DRAM	Dynamic memory (non-buffered)
DRF	Differential Resolver Function: Differential revolver function (handwheel)
DRIVE-CLiQ	Drive Component Link with IQ
DRY	Dry Run: Dry run feedrate
DSB	Decoding Single Block: Decoding single block
DSC	Dynamic Servo Control / Dynamic Stiffness Control
DW	Data Word
DWORD	Double Word (currently 32 bits)

E	
I	Input
EES	Execution from External Storage
I/O	Input/Output
ENC	Encoder: Actual value encoder
EFP	Compact I/O module (PLC I/O module)
ESD	Electrostatic Sensitive Devices
EMC	ElectroMagnetic Compatibility
EN	European standard
ENC	Encoder: Actual value encoder
EnDat	Encoder interface
EPROM	Erasable Programmable Read Only Memory: Erasable, electrically programmable read-only memory
ePS Network Services	Services for Internet-based remote machine maintenance
EQN	Designation for an absolute encoder with 2048 sine signals per revolution
ES	Engineering System
ESR	Extended Stop and Retract
ETC	ETC key ">"; softkey bar extension in the same menu

F	
FB	Function Block (PLC)
FC	Function Call: Function Block (PLC)
FEPROM	Flash EPROM: Read and write memory
FIFO	First In First Out: Memory that works without address specification and whose data is read in the same order in which they was stored
FIPO	Fine interpolator
FPU	Floating Point Unit: Floating Point Unit
CRC	Cutter Radius Compensation
FST	Feed Stop: Feedrate stop
FBD	Function Block Diagram (PLC programming method)
FW	Firmware

G	
GC	Global Control (PROFIBUS: Broadcast telegram)
GDIR	Global part program memory
GEO	Geometry, e.g. geometry axis
GIA	Gear Interpolation dAta: Gear interpolation data
GND	Signal Ground
GP	Basic program (PLC)
GS	Gear Stage
GSD	Device master file for describing a PROFIBUS slave

Appendix

A.1 List of abbreviations

G	
GSDML	Generic Station Description Markup Language: XML-based description language for creating a GSD file
GUD	Global User Data: Global user data

H	
HEX	Abbreviation for hexadecimal number
AuxF	Auxiliary function
HLA	Hydraulic linear drive
HMI	Human Machine Interface: SINUMERIK user interface
MSD	Main Spindle Drive
HW	Hardware

I	
IBN	Commissioning
ICA	Interpolatory compensation
IM	Interface Module: Interconnection module
IMR	Interface Module Receive: Interface module for receiving data
IMS	Interface Module Send: Interface module for sending data
INC	Increment: Increment
INI	Initializing Data: Initializing data
IPO	Interpolator
ISA	Industry Standard Architecture
ISO	International Standardization Organization

J	
JOG	Jogging: Setup mode

K	
K_v	Gain factor of control loop
K_p	Proportional gain
K_U	Transformation ratio
LAD	Ladder Diagram (PLC programming method)

L	
LAI	Logic Machine Axis Image: Logical machine axes image
LAN	Local Area Network
LCD	Liquid Crystal Display: Liquid crystal display
LED	Light Emitting Diode: Light-emitting diode
LF	Line Feed

L	
PMS	Position Measuring System
LR	Position controller
LSB	Least Significant Bit: Least significant bit
LUD	Local User Data: User data (local)

M	
MAC	Media Access Control
MAIN	Main program: Main program (OB1, PLC)
MB	Megabyte
MCI	Motion Control Interface
MCIS	Motion Control Information System
MCP	Machine Control Panel: Machine control panel
MD	Machine Data
MDA	Manual Data Automatic: Manual input
MDS	Motor Data Set: Motor data set
MSGW	Message Word
MCS	Machine Coordinate System
MM	Motor Module
MPF	Main Program File: Main program (NC)
MCP	Machine control panel

N	
NC	Numerical Control: Numerical control with block preparation, traversing range, etc.
NCU	Numerical Control Unit: NC hardware unit
NRK	Name for the operating system of the NC
IS	Interface Signal
NURBS	Non-Uniform Rational B-Spline
WO	Work Offset
NX	Numerical Extension: Axis expansion board

O	
OB	Organization block in the PLC
OEM	Original Equipment Manufacturer
OP	Operator Panel: Operating equipment
OPI	Operator Panel Interface: Interface for connection to the operator panel
OPT	Options: Options
OLP	Optical Link Plug: Fiber optic bus connector
OSI	Open Systems Interconnection: Standard for computer communications

Appendix

A.1 List of abbreviations

P	
PIQ	Process Image Output
PII	Process Image Input
PC	Personal Computer
PCIN	Name of the SW for data exchange with the control
PCMCIA	Personal Computer Memory Card International Association: Plug-in memory card standardization
PCU	PC Unit: PC box (computer unit)
PG	Programming device
PKE	Parameter identification: Part of a PIV
PIV	Parameter identification: Value (parameterizing part of a PPO)
PLC	Programmable Logic Control: Adaptation control
PN	PROFINET
PNO	PROFIBUS user organization
PO	POWER ON
POU	Program Organization Unit
POS	Position/positioning
POSMO A	Positioning Motor Actuator: Positioning motor
POSMO CA	Positioning Motor Compact AC: Complete drive unit with integrated power and control module as well as positioning unit and program memory; AC infeed
POSMO CD	Positioning Motor Compact DC: Like CA but with DC infeed
POSMO SI	Positioning Motor Servo Integrated: Positioning motor, DC infeed
PPO	Parameter Process data Object: Cyclic data telegram for PROFIBUS DP transmission and "Variable speed drives" profile
PPU	Panel Processing Unit (central hardware for a panel-based CNC, e.g SINUMERIK 828D)
PROFIBUS	Process Field Bus: Serial data bus
PRT	Program Test
PSW	Program control word
PTP	Point-To-Point: Point-To-Point
PUD	Program global User Data: Program-global user variables
PZD	Process data: Process data part of a PPO

Q	
QEC	Quadrant Error Compensation

R	
RAM	Random Access Memory: Read/write memory
REF	REfERENCE point approach function
REPOS	REPOSition function
RISC	Reduced Instruction Set Computer: Type of processor with small instruction set and ability to process instructions at high speed
ROV	Rapid Override: Input correction

R	
RP	R Parameter, arithmetic parameter, predefined user variable
RPA	R Parameter Active: Memory area in the NC for R parameter numbers
RPY	Roll Pitch Yaw: Rotation type of a coordinate system
RTL	Rapid Traverse Linear Interpolation: Linear interpolation during rapid traverse motion
RTS	Request To Send: Control signal of serial data interfaces
RTCP	Real Time Control Protocol

S	
SA	Synchronized Action
SBC	Safe Brake Control: Safe Brake Control
SBL	Single Block: Single block
SBR	Subroutine: Subprogram (PLC)
SD	Setting Data
SDB	System Data Block
SEA	Setting Data Active: Identifier (file type) for setting data
SERUPRO	SEArch RUn by PROgram test: Block search, program test
SFB	System Function Block
SFC	System Function Call
SGE	Safety-related input
SGA	Safety-related output
SH	Safe standstill
SIM	Single in Line Module
SK	Softkey
SKP	Skip: Function for skipping a part program block
SLM	Synchronous Linear Motor
SM	Stepper Motor
SMC	Sensor Module Cabinet Mounted
SME	Sensor Module Externally Mounted
SMI	Sensor Module Integrated
SPF	Sub Routine File: Subprogram (NC)
PLC	Programmable Logic Controller
SRAM	Static RAM (non-volatile)
TNRC	Tool Nose Radius Compensation
SRM	Synchronous Rotary Motor
LEC	Leadscrew Error Compensation
SSI	Serial Synchronous Interface: Synchronous serial interface
SSL	Block search
STW	Control word
GWPS	Grinding Wheel Peripheral Speed
SW	Software
SYF	System Files: System files
SYNACT	SYNchronized ACTION: Synchronized Action

Appendix

A.1 List of abbreviations

T	
TB	Terminal Board (SINAMICS)
TCP	Tool Center Point: Tool tip
TCP/IP	Transport Control Protocol / Internet Protocol
TCU	Thin Client Unit
TEA	Testing Data Active: Identifier for machine data
TIA	Totally Integrated Automation
TM	Terminal Module (SINAMICS)
TO	Tool Offset: Tool offset
TOA	Tool Offset Active: Identifier (file type) for tool offsets
TRANSMIT	Transform Milling Into Turning: Coordination transformation for milling operations on a lathe
TTL	Transistor-Transistor Logic (interface type)
TZ	Technology cycle

U	
UFR	User Frame: Work offset
SR	Subprogram
USB	Universal Serial Bus
UPS	Uninterruptible Power Supply

V	
VDI	Internal communication interface between NC and PLC
VDI	Verein Deutscher Ingenieure [Association of German Engineers]
VDE	Verband Deutscher Elektrotechniker [Association of German Electrical Engineers]
VI	Voltage Input
VO	Voltage Output
FDD	Feed Drive

W	
SAR	Smooth Approach and Retraction
WCS	Workpiece Coordinate System
T	Tool
TLC	Tool Length Compensation
WOP	Workshop-Oriented Programming
WPD	Workpiece Directory: Workpiece directory
TRC	Tool Radius Compensation
T	Tool
TO	Tool Offset
TM	Tool Management
TC	Tool change

X	
XML	Extensible Markup Language

Z	
WOA	Work Offset Active: Identifier for work offsets
ZSW	Status word (of drive)

Index

-

- End of trial cut addition - GROUP_ADDEND
External programming, 1193

\$

\$A_INA, 960
\$A_PROBE, 591, 598, 1000
\$A_PROBE_LIMITED, 599
\$AA_ACC, 129
\$AA_ATOL, 826
\$AA_AXCHANGE_STAT, 976
\$AA_AXCHANGE_TYP, 976, 979
\$AA_COUP_ACT
 during coupled motion, 847
 for axial master value coupling, 869
\$AA_FGREF, 114
\$AA_FGROUP, 114
\$AA_G0MODE, 183
\$AA_JERK_COUNT, 931
\$AA_JERK_TIME, 931
\$AA_JERK_TOT, 931
\$AA_LEAD_SP, 869
\$AA_LEAD_SV, 869
\$AA_MEA_ACT, 1000
\$AA_MM, 592
\$AA_MM1 ... 4, 1000
\$AA_MM1...4, 599
\$AA_MW, 592
\$AA_MW1...4, 599
\$AA_OFF, 934
\$AA_OFF_LIMIT, 935
\$AA_OVR, 926
\$AA_PLC_OVR, 926
\$AA_TOFF, 937
\$AA_TOFF_VAL, 938
\$AA_TOTAL_OVR, 927
\$AA_TRAVEL_COUNT, 931
\$AA_TRAVEL_COUNT_HS, 931
\$AA_TRAVEL_DIST, 931
\$AA_TRAVEL_DIST_HS, 931
\$AA_TRAVEL_TIME, 931
\$AA_TRAVEL_TIME_HS, 931
\$AC_ACT_PROG_NET_TIME, 1027
\$AC_ACTUAL_PARTS, 1029
\$AC_AXCTSWA, 981
\$AC_BLOCKTYPE, 925, 941
\$AC_BLOCKTYPEINFO, 941
\$AC_CTOL, 826
\$AC_CTOL_G0_ABS, 186
\$AC_CUT_INV, 762
\$AC_CUTMOD, 762
\$AC_CUTMOD_ANG, 762
\$AC_CUTMODK, 762
\$AC_CUTTING_TIME, 1026
\$AC_CYCLE_TIME, 1026
\$AC_DELAYFST, 810
\$AC_DTEB, 965
\$AC_F_TYPE, 145
\$AC_FCT0, 932
\$AC_FCT1, 932
\$AC_FCT2, 932
\$AC_FCT3, 932
\$AC_FCTLL, 932
\$AC_FCTUL, 932
\$AC_FGROUP_MASK, 114
\$AC_FIFO, 920
\$AC_FZ, 145
\$AC_MARKER, 915
\$AC_MEA, 591, 599, 1000
\$AC_OLD_PROG_NET_TIME, 1027
\$AC_OLD_PROG_NET_TIME_COUNT, 1027
\$AC_OPERATING_TIME, 1026
\$AC_OTOL, 826
\$AC_OTOL_G0_ABS, 186
\$AC_OVR, 925
\$AC_PARAM, 916
\$AC_PLC_OVR, 926
\$AC_PROG_NET_TIME_TRIGGER, 1027
\$AC_REPOS_PATH_MODE, 818
\$AC_REQUIRED_PARTS, 1029
\$AC_S_TYPE, 99
\$AC_SMAXVELO, 822
\$AC_SMAXVELO_INFO, 822
\$AC_SPECIAL_PARTS, 1029
\$AC_SPLITBLOCK, 942
\$AC_STOLF, 185
\$AC_SVC, 99
\$AC_SYNA_STATE, 946
\$AC_SYNC_ACT_LOAD, 927
\$AC_SYNC_AVERAGE_LOAD, 927
\$AC_SYNC_MAX_LOAD, 927
\$AC_TANEB, 925
\$AC_TIMER, 919
\$AC_TOFF, 90

\$AC_TOFFCR, 90
\$AC_TOFFL, 90
\$AC_TOFFR, 90
\$AC_TOTAL_OVR, 926
\$AC_TOTAL_PARTS, 1029
\$AC_TRAFO_CORR_ELEM_P, 710
\$AC_TRAFO_CORR_ELEM_T, 710
\$AC_TRAFO_ORIAX_LOC, 711
\$AN_AXCTSWA, 981
\$AN_IPO_ACT_LOAD, 927
\$AN_IPO_LOAD_LIMIT, 928
\$AN_IPO_LOAD_PERCENT, 927
\$AN_IPO_MAX_LOAD, 927
\$AN_IPO_MIN_LOAD, 927
\$AN_POWERON_TIME, 1026
\$AN_SERVO_ACT_LOAD, 927
\$AN_SERVO_MAX_LOAD, 927
\$AN_SERVO_MIN_LOAD, 927
\$AN_SETUP_TIME, 1026
\$AN_SYNC_ACT_LOAD, 927
\$AN_SYNC_MAX_LOAD, 927
\$AN_SYNC_TO_IPO, 927
\$NT_CLOSE_CHAIN_T, 711
\$NT_CNTRL, 710
\$NT_CORR_ELEM_P, 710
\$NT_CORR_ELEM_T, 710
\$NT_NAME, 703
\$NT_ROT_AX_NAME, 759
\$NT_TRAFO_INDEX, 703
\$P_ACTBFRAME, 628
\$P_AD, 761
\$P_AEP, 277
\$P_APDV, 277
\$P_APR, 277
\$P_BFRAME, 628
\$P_CHBFRAME, 628
\$P_CHBFRMASK, 629
\$P_CTOL, 827
\$P_CTOL_G0_ABS, 186
\$P_CUT_INV, 762
\$P_CUTMOD, 762
\$P_CUTMOD_ANG, 762
\$P_CUTMOD_ERR, 763
\$P_CUTMODK, 762
\$P_DELAYFST, 810
\$P_F_TYPE, 145
\$P_FGROUP_MASK, 114
\$P_FZ, 145
\$P_GWPS, 105
\$P_IFRAME, 629
\$P_IS_EES_PATH, 550
\$P_NCBFRAME, 628
\$P_NCBFRMASK, 629
\$P_ORI_DIFF, 755
\$P_ORI_POS, 755
\$P_ORI_SOL, 756
\$P_ORI_STAT, 758
\$P_OTOL, 827
\$P_OTOL_G0_ABS, 186
\$P_PATH, 549
\$P_PFRAME, 630
\$P_PROG, 549
\$P_PROGPATH, 549
\$P_S_TYPE, 99
\$P_SIM, 602
\$P_STACK, 549
\$P_STOLF, 185
\$P_SUBPAR, 485
\$P_SVC, 99
\$P_TECCYCLE, 1010
\$P_TOFF, 89
\$P_TOFFCR, 89
\$P_TOFFL, 89
\$P_TOFFR, 89
\$P_TOOLENV, 771
\$P_TOOLENVN, 771
\$P_WORKAREA_CS_COORD_SYSTEM, 350
\$P_WORKAREA_CS_LIMIT_MINUS, 351
\$P_WORKAREA_CS_LIMIT_PLUS, 351
\$P_WORKAREA_CS_MINUS_ENABLE, 350
\$P_WORKAREA_CS_PLUS_ENABLE, 350
\$PA_ATOL, 827
\$PA_FGREF, 114
\$PA_FGROUP, 114
\$SA_LEAD_TYPE, 869
\$SA_WORKAREA_MINUS_ENABLE, 929
\$SA_WORKAREA_PLUS_ENABLE, 929
\$SC_CONTPREC, 804
\$SC_MINFEED, 804
\$SC_PA_ACTIV_IMMED, 570
\$SN_PA_ACTIV_IMMED, 570
\$SN_SW_CAM_MINUS_POS_TAB_1, 930
\$SN_SW_CAM_MINUS_POS_TAB_2, 930
\$SN_SW_CAM_MINUS_TIME_TAB_1, 930
\$SN_SW_CAM_MINUS_TIME_TAB_2, 930
\$SN_SW_CAM_PLUS_POS_TAB_1, 930
\$SN_SW_CAM_PLUS_POS_TAB_2, 930
\$SN_SW_CAM_PLUS_TIME_TAB_1, 930
\$SN_SW_CAM_PLUS_TIME_TAB_2, 930
\$TC_CARR_CORR_ELEM, 747
\$TC_CARR1...14, 737
\$TC_CARR18...23, 737
\$TC_CARR18[m], 741
\$TC_DP1 ... 25, 712

- \$TC_ECPxy, 716
 \$TC_SCPxy, 716
 \$TC_TP_MAX_VELO, 96
- ***
 * (arithmetic function), 431
- /**
 / (arithmetic function), 431
- +**
 + (arithmetic function), 431
- <**
 < (comparison operator), 433
 << (concatenation operator), 440
 <= (relational operator), 433
 <> (comparison operator), 433
- =**
 == (comparison operator), 433
- >**
 > (comparison operator), 433
 >= (relational operator), 433
- 0**
 0 character, 437
- A**
 ABS, 431
 Absolute dimensions, 31
 AC, 151
 ACC, 128
 Acceleration mode, 798
 ACCLIMA, 800
 ACN, 158
 ACOS, 431
 ACP, 158
 Acquiring and finding untraceable sections, 811
 ACTBLOCNO, 497
 ACTFRAME, 608
 Actual value coupling, 879
 Address
 Value assignment, 49
 Address letters, 1274
 Addresses, 371
 Addressing, 544
 ADIS, 290
 ADISPOS, 290
 ADISPOSA, 603
 Alarms
 set in the NC program, 1044
 ALF
 for fast retraction from contour, 535
 For rapid retraction during thread cutting, 226
 AMIRROR, 323
 AND, 433
 ANG, 206
 ANG1, 206
 ANG2, 206
 AP, 176
 Approach point/angle, 258
 APR, 402
 APRB, 402
 APRP, 402
 APW, 402
 APWB, 402
 APWP, 402
 AR
 Circular-path programming, 194
 Arbitrary positions - CYCLE802
 External programming, 1139
 Arithmetic parameters
 Channel-specific, 384
 Global, 385
 AROT, 311
 AROTS, 317
 Array, 407
 definition, 407
 element, 408
 Array index, 410
 AS, 477
 ASCALE, 320
 ASIN, 431
 Asynchronous oscillation, 1013
 ATAN2, 431
 ATOL, 823
 ATRANS, 305
 Automatic interrupt pointer, 812
 Auxiliary function output
 High-speed, 338

In continuous-path mode, 339
 Properties of the auxiliary functions, 337

AV, 876

AX, 835

AXCTSWEC, 981

Axes

- Channel, 368
- Command, 369
- Coupled-motion, 846
- Geometry, 365
- Machine, 367
- Main, 365
- Path, 368
- PLC, 370
- Positioning, 368
- Special, 366
- Synchronized, 369

Axial master value coupling, 864

Axis,

- replacement, 829
- types, 365

AXNAME, 438

AXSTRING, 835

AXTOCHAN, 833, 979

AXTOSPI, 835

B

B_AND, 433

B_NOT, 433

B_OR, 433

B_XOR, 433

Basic coordinate system, 39

Basic offset, 41

Basic zero system, 41

BCS, 39

Beginning of program block - GROUP_BEGIN, 1192

BFRAME, 608

Binary constant, 376

Blank definition, 1045

Block, 45

- End, 48
- end LF, 54
- Length, 48
- number, 48
- Order of the statements, 48
- Skip, 50

Block display

- suppress, 497

Blocking point, 35

BLSYNC, 530

BOOL, 387

Boolean operations, 908

Boring - CYCLE86

External programming, 1118

BOUND, 414

BRISK, 798

BRISKA, 798

BZS, 41

C

CAC, 581

CACN, 581

CACP, 581

CALCPOSI, 349

CALL, 519

CALLPATH, 523

CANCEL, 1011

Cancels the current subprogram level

CANCELSUB, 1005

CANCELSUB, 1005

Cartesian coordinates, 28

Cartesian PTP travel, 680

CASE, 457

Case-insensitive, 543

CDC, 581

CDOF, 280

CDOF2, 280

CDON, 280

Centering - CYCLE81

External programming, 1107

CFC, 133

CFIN, 133

CFINE, 617

CFTCP, 133

Chamfer, 240

CHAN, 387

CHANDATA, 550

Channel

axes, 368

CHAR, 387

Character set, 53

Check

structures, 464

CHF, 240

CHKDNO, 734

CHR, 240

CIC, 581

CIP, 198

Circle data

calculating, 1064

Circle or pitch circle position pattern – HOLES2

External programming, 1070

- Circular interpolation
 - Helical interpolation, 204
 - with intermediate and end points, 198
- Circular pocket - POCKET4
 - External programming, 1075
- Circular spigot - CYCLE77
 - External programming, 1101
- Circular-path programming
 - Interpolation types, 189
 - With center and end points, 189
 - With opening angle and center point, 194
 - With polar coordinates, 196
 - With radius and end point, 192
- Circumferential slot - SLOT2
 - External programming, 1080
- Clamping torque
 - fixed stop, 360
- CLEARM, 471, 1004
- CLRINT, 532
- COARSE, 876
- COARSEA, 603
- Collision detection, 280
- COLLPAIR, 698
- Command, 45
 - Axes, 369
- Comments, 49
- Comparison operators, 433
- COMPCAD, 582
- COMPCURV, 582
- Compensation
 - Plane, 283
 - Tool length, 70
 - Tool radius, 71
- COMPLETE, 550
- COMPOF, 582
- COMPON, 582
- COMPSURF, 582
- Concatenation
 - of strings, 440
- Constant, 375
- Constraints for transformations, 691
- CONTDCON, 1058
- Continuous-path mode, 290
- Contour
 - Approach/leave, 255
 - Calculator, 207
 - coding, 1058
 - element, 172
 - preparation, 1052
 - reposition, 812
 - table, 1052
- Contour accuracy
 - Programmable, 804
- Contour call - CYCLE62
 - External programming, 1089
- Contour corner
 - Chamfering, 240
 - Round, 240
- Contour cutting - CYCLE95
 - External programming, 1121
- Contour definition programming, 206
- Contour element
 - travel, 1063
- Contour pocket milling / contour pocket residual material / contour spigot milling / contour spigot residual material – CYCLE63
 - External programming, 1089
- Contour preparation
 - Error feedback signal, 1066
- CONTPRON, 1052
- Convex thread, 229
- Coordinate system
 - Basic, 39
 - Overview, 37
- Coordinate transformations (frames), 42
- Coordinates
 - Cartesian, 28
 - Cylindrical, 177
 - Polar, 30
- Corner deceleration at all corners, 603
- Corner deceleration at inside corners, 603
- CORROF, 331
- CORRTC, 744
- CORRTRAFO, 704
- COS, 431
- Count loop, 468
- COUPDEF, 876
- COUPDEL, 876
- Coupled motion, 844
- Coupled-axis combinations, 844
- Coupled-motion axes, 846
- coupling
 - Generic, 886
- Coupling factor, 844
- Coupling status
 - during coupled motion, 847
 - for axial master value coupling, 869
- COUPOF, 876
- COUPOFS, 876
- COUPON, 876
- COUPONC, 876
- COUPRES, 876
- CP, 681

CP..., 994
 CPBC, 888
 CPDEF, 887
 CPDEL, 887
 CPFMOF, 890
 CPFMON, 890
 CPFMSON, 889
 CPFPOS + CPOF, 890
 CPFPOS + CPON, 888
 CPFRS, 887
 CPLA, 887
 CPLCTID, 887
 CPLDEF, 887
 CPLDEL, 887
 CPLDEN, 887
 CPLINSC, 892
 CPLINTR, 892
 CPLNUM, 887
 CPLOF, 887
 CPLON, 887
 CPLOUTSC, 892
 CPLOUTTR, 892
 CPLPOS, 888
 CPLSETVAL, 887
 CPMALARM, 893
 CPMBRAKE, 893
 CPMPRRT, 892
 CPMRESET, 891
 CPMSTART, 892
 CPMVDI, 893
 CPOF, 887
 CPON, 887
 CPRECOF, 804
 CPRECON, 804
 CPROT, 567
 CPROTDEF, 564
 CPSETTYPE, 893
 CPSYNCOF, 892
 CPSYNCOF2, 892
 CPSYNCOV, 892
 CPSYNFIP, 892
 CPSYNFIP2, 892
 CPSYNFIV, 892
 CR, 192
 CROTS, 317
 CT, 200
 CTAB, 858
 CTAB..., 994
 CTABDEF, 848
 CTABDEL, 855
 CTABEND, 848
 CTABEXISTS, 854
 CTABFNO, 863
 CTABFPOL, 863
 CTABFSEG, 863
 CTABID, 857
 CTABINV, 858
 CTABISLOCK, 857
 CTABLOCK, 856
 CTABMEMTYP, 857
 CTABMPOL, 863
 CTABMSEG, 863
 CTABNO, 863
 CTABNOMEM, 863
 CTABPERIOD, 857
 CTABPOL, 863
 CTABPOLID, 863
 CTABSEG, 863
 CTABSEGID, 863
 CTABSEV, 858
 CTABSSV, 858
 CTABTEP, 858
 CTABTEV, 858
 CTABTMAX, 858
 CTABTMIN, 858
 CTABTSP, 858
 CTABTSV, 858
 CTABUNLOCK, 856
 CTOL, 823
 CTRANS, 617
 CUT2D, 282
 CUT2DD, 282
 CUT2DF, 282
 CUT2DFD, 282
 CUTCONOF, 284
 CUTCONON, 284
 CUTMOD, 759
 CUTMODK, 759
 Cut-off - CYCLE92
 External programming, 1119
 Cutting edge
 center point, 72
 number, 84
 Number of contour tools, 283
 position, 72
 radius, 72
 Cutting edge number, 734
 Cutting edges
 -reference point, 286
 -relevant position,
 Cutting speed, 94
 Cutting speed (constant), 100
 Cycle alarms, 1044

- CYCLE4071
External programming, 1170
- CYCLE4072
External programming, 1172
- CYCLE4073
External programming, 1176
- CYCLE4074
External programming, 1177
- CYCLE4075
External programming, 1180
- CYCLE4077
External programming, 1183
- CYCLE4078
External programming, 1187
- CYCLE4079
External programming, 1189
- CYCLE435 - Set dresser coordinate system
External programming, 1132
- CYCLE495 - form-truing
External programming, 1132
- CYCLE60 - Engraving
External programming, 1084
- CYCLE61 - Face milling
External programming, 1087
- CYCLE62- contour call
External programming, 1089
- CYCLE63 – contour pocket milling / contour pocket residual material / contour spigot milling / contour spigot residual material
External programming, 1089
- CYCLE64 - Predrilling contour pocket
External programming, 1092
- CYCLE70 - thread milling
External programming, 1094
- CYCLE72 - Path milling
External programming, 1095
- CYCLE76 - rectangular spigot
External programming, 1098
- CYCLE77 - circular spigot
External programming, 1101
- CYCLE78 - Drill thread milling
External programming, 1103
- CYCLE79 - multi-edge
External programming, 1105
- CYCLE800 – swivel plane / swivel tool / align tool
External programming, 1134
- CYCLE801 – grid or frame position pattern
External programming, 1137
- CYCLE802 - arbitrary positions
External programming, 1139
- CYCLE81 - centering
External programming, 1107
- CYCLE82 - drilling
External programming, 1108
- CYCLE83 – deep-hole drilling 1
External programming, 1111
- CYCLE830 - deep-hole drilling 2
External programming, 1141
- CYCLE832 - High-Speed Settings
External programming, 1147
- CYCLE84 - tapping without compensating chuck
External programming, 1114
- CYCLE840 - tapping with compensating chuck
External programming, 1150
- CYCLE85 - reaming
External programming, 1117
- CYCLE86 - boring
External programming, 1118
- CYCLE899 – open slot
External programming, 1153
- CYCLE92 - cut-off
External programming, 1119
- CYCLE930 - groove
External programming, 1156
- CYCLE940 – undercut form E and F / undercut thread
External programming, 1159
- CYCLE95 - contour cutting
External programming, 1121
- CYCLE951 - stock removal
External programming, 1161
- CYCLE952 – stock removal / residual stock removal / plunge cutting / residual plunge cutting / plunge turning / residual plunge turning
External programming, 1164
- CYCLE98 - thread chain
External programming, 1123
- CYCLE99 - thread turning
External programming, 1127
- Cylinder surface transformation, 636
- Cylinder thread, 220
- Cylindrical coordinates, 177
- D**
- D number
Freely assigned, 734
- D numbers
Check, 734
Renaming, 735
- D..., 83
- D0, 83
- DAC, 166
- DB21
DBX1.2, 1011

DBX280.1, 1012
 DBX281.1, 1011
 DBX300.0 - 307.7, 1012
 DBX308.0 - 315.7, 1011
 DB21,DBX6.4, 1006
 DB31, ...
 DBX28.7, 970
 DC, 158
 Decimal constant, 375
 Deep-hole drilling 1 – CYCLE83
 External programming, 1111
 Deep-hole drilling 2 - CYCLE830
 External programming, 1141
 DEF, 387
 DEFAULT, 457
 DEFINE ... AS, 477
 DELAYFSTOF, 808
 DELAYFSTON, 808
 DELDL, 716
 DELDTG, 965
 DELETE, 557
 DELOBJ, 694
 DELTOOLENV, 769
 Denominator polynomial, 587
 DIACYCOFA, 166
 DIAM90, 164
 DIAM90A, 166
 DIAMCHAN, 166
 DIAMCHANA, 166
 DIAMCYCOF, 164
 Diameter programming, 164
 DIAMOF, 164
 DIAMOFA, 166
 DIAMON, 164
 DIAMONA, 166
 DIC, 166
 DILF, 226
 Dimensions
 For rotary axes and spindles, 158
 in the diameter, 164
 in the radius, 164
 Options, 151
 DIN 66217, 37
 DIN subprogram name, 548
 Direction of rotation, 38
 Direction vector, 648
 Directory path, 546
 DISABLE, 532
 DISC, 263
 DISCL, 266
 DISPLOF, 497
 DISPLON, 497

DISPR, 812
 DISR, 266
 DISRP, 266
 DITE, 224
 DITS, 224
 DIV, 431
 DL, 714
 DO, 909
 DRFOF, 334
 Drill, 76
 Drill thread milling - CYCLE78
 External programming, 1103
 Drilling - CYCLE82
 External programming, 1108
 DRIVE, 798
 Drive name, 545
 DRIVEA, 798
 DV, 876
 Dwell time, 362
 DYNFINISH, 801
 DYNNORM, 801
 DYNPOS, 801
 DYNPREC, 801
 DYNROUGH, 801
 DYNSEMIFIN, 801

E

Easy XML, 1035
 EES, 542
 EES notation, 544
 EG
 Electronic gear, 870
 EGDEF, 870
 EGDEL, 875
 EGOFC, 874
 EGOFCS, 874
 EGON, 871
 EGONSYN, 871
 EGONSYNE, 871
 Electronic gear, 870
 Elongated hole - LONGHOLE
 External programming, 1082
 ELSE, 466, 909
 ENABLE, 532
 End of program block - GROUP_END
 External programming, 1192
 ENDFOR, 468
 ENDIF, 466
 ENDLABEL, 459
 Endless loop, 467
 ENDLOOP, 467

- End-of-motion criterion
 - Programmable, 603
- ENDWHILE, 469
- Engraving - CYCLE60
 - External programming, 1084
- Euler angles, 647
- EVERY, 906
- Exact stop, 288
- EXECSTRING, 429
- EXECTAB, 1063
- EXECUTE, 1066
- EXP, 431
- EXTCALL
 - for SINUMERIK 840D sl, 524
- EXTCLOSE, 1040
- Extended address notation, 372
- EXTERN, 514
- External programming, 1192
- External zero offset, 618
- EXTOPEN, 1040

- F**
- F...
 - For feedrate, 107
 - For linear interpolation, 186
 - For thread cutting G34 G35, 222
- FA, 124, 974
- Face milling, 651
- Face milling - CYCLE61
 - External programming, 1087
- Face thread, 221
- FAD, 266
- FALSE, 387
- Fast retraction from the contour, 533
- FB, 139
- FCTDEF, 724
- FCUB, 793
- FD, 130
- FDA, 130
- Feedrate
 - For path axes, 109
 - for positioning axes, 124
 - For synchronized axes, 111
 - Inverse-time, 110
 - Override, 132
 - override, 127
 - rate, 186
 - Rules, 107
 - Units, 112
 - with handwheel override, 130
- FENDNORM, 602
- FFWOF, 803
- FFWON, 803
- FGREF, 107
- FGROUP, 107
- FIFOCTRL, 805
- File
 - information, 561
- File name, 547
- FILEDATE, 561
- FILEINFO, 561
- FILESIZE, 561
- FILESTAT, 561
- FILETIME, 561
- FINE, 876
- FINEA, 603
- Fixed point
 - Approach, 353
- Fixed stop, 358
- FL, 107
- FLIN, 793
- FMA, 136
- FNORM, 793
- FOC, 1002
- FOCOF, 1002
- FOCON, 1002
- Following axis
 - for axial master value coupling, 864
- FOR, 468
- Form-truing - CYCLE495
 - External programming, 1132
- FP, 353
- FPO, 793
- FPR, 124
- FPRAOF, 124
- FPRAON, 124
- Frame,
 - Call, 614
 - chaining, 631
 - Deselect, 330
 - mirroring, 323
 - scaling, 320
 - Statements, 302
- Frame component
 - FI, 613
 - MI, 613
 - RT, 613
 - SC, 613
 - TR, 613
- Frame variable
 - Assigning values, 611
 - Calling coordinate transformations, 606
 - Predefined frame variable, 608

- Frames, 300
 - Assign, 615
 - Channel-specific, 627
 - Frame chains, 616
 - Global, 626
 - System, 627
- FRC, 240
- FRCM, 240
- FROM, 906
- FTOC, 962
- FTOCOF, 727
- FTOCON, 727
- Function
 - Predefined, 1329
- FXS, 1002
- FXST, 1002
- FXSW, 1002

- G**
- G code
 - Indirect programming, 425
- G commands, 1286
- G functions
 - Action, 908
 - Condition, 907
- G group
 - Technology, 801
- G0 tolerance, 183
- G1, 186
- G110, 175
- G111, 175
- G112, 175
- G140, 266
- G141, 266
- G142, 266
- G143, 266
- G147, 266
- G148, 266
- G153
 - For deselect frame, 330
 - For work offset, 146
- G17, 148
- G18, 148
- G19, 148
- G2, 189
- G247, 266
- G248, 266
- G25, 929
 - Spindle speed limitation, 106
 - Working area limitation, 346
- G26, 929
 - Spindle speed limitation, 106
 - Working area limitation, 346
- G290, 1049
- G291, 1049
- G3, 189
- G33, 216
- G335, 229
- G336, 229
- G34, 222
- G340, 266
- G341, 266
- G347, 266
- G348, 266
- G35, 222
- G4, 362
- G40, 246
- G41, 246
- G42, 246
- G450, 263
- G451, 263
- G460, 277
- G461, 277
- G462, 277
- G5, 678
- G500
 - For work offset, 146
- G505 ... G599, 146
- G53
 - For deselect frame, 330
 - For work offset, 146
- G54 ... G57, 146
- G58, 309
- G59, 309
- G60, 288
- G601, 288
- G602, 288
- G603, 288
- G62, 602
- G621, 602
- G64, 290
- G641, 290
- G642, 290
- G643, 290
- G644, 290
- G645, 290
- G7, 678
- G70, 160, 971
- G700, 160, 971
- G71, 160, 971
- G710, 160, 971
- G74, 352

G75, 353
 G810 ... G819, 601
 G820 ... G829, 601
 G9, 288
 G90, 151
 G91, 154
 G93, 107
 G94, 107
 G95, 107
 G96, 100
 G961, 100
 G962, 100
 G97, 100
 G971, 100
 G972, 100
 G973, 100
 GEOAX, 836
 Geometry
 -axes, 365
 Geometry axis
 Switching, 836
 GET, 829, 975
 GETACTTD, 735
 GETD, 829
 GETDNO, 735
 GETTCOR, 771
 GETTENV, 770
 GETVARAP, 418
 GETVARDFT, 420
 GETVARDIM, 419
 GETVARLIM, 419
 GETVARPHU, 417
 GETVARTYP, 421
 GFRAME0 ... GFRAME100, 335
 Global part program memory (GDIR), 542
 GOTO, 454
 GOTOB, 454
 GOTOC, 454
 GOTOF, 454
 GOTOS, 453
 GP, 427
 Grid or frame position pattern – CYCLE801
 External programming, 1137
 Grinding tools, 77
 Groove - CYCLE930
 External programming, 1156
 GROUP_ADDEND - End of trial cut addition
 External programming, 1193
 GROUP_BEGIN - beginning of program block
 External programming, 1192
 GROUP_END - end of program block
 External programming, 1192

GUD, 387, 947
 GWPS, 105
 GWPSOF, 105
 GWPSON, 105

H

Handwheel
 Override, 130
 Helix interpolation, 204
 Hexadecimal constant, 376
 High Speed Settings - CYCLE832
 External programming, 1147
 Hold block, 811
 HOLES1 – row position pattern
 External programming, 1070
 HOLES2 – circle or pitch circle position pattern
 External programming, 1070

I

I...
 For circular interpolation, 189
 For thread cutting G33, 216
 For thread cutting G34 G35, 222
 IC, 154
 ICYCOF, 1008
 ICYCON, 1008
 ID, 905
 Identification number, 906
 Identifier, 44
 for character string, 54
 for special numerical values, 54
 for system variables, 54
 IDS, 905
 IF, 466
 IFRAME, 608
 Incremental dimension, 33
 Incremental dimensions, 33, 154
 INDEX, 442
 Indirect programming
 of addresses, 423
 of G codes, 425
 of part program lines, 429
 of position attributes, 427
 INICF, 387
 INIPO, 387
 INIRE, 387
 INIT, 471
 INITIAL, 550
 Initial tool orientation setting ORIRESET, 644

INITIAL_INI, 550
 Initialization
 of arrays, 408
 Initialization program, 551
 INT, 387
 INTEGER constant, 375
 Internal preprocessing stop, 364
 Interpolation of the rotation vector, 663
 Interrupt routine
 Deactivating/activating, 532
 Delete, 532
 Fast retraction from the contour, 533
 Newly assign, 531
 Programmable traverse direction, 535
 Retraction movement, 535
 INTERSEC, 1062
 IPOBRKA, 603
 IPOENDA, 603
 IPOSTOP, 876
 IPTRLOCK, 810
 IPTRUNLOCK, 810
 IR, 229
 ISAXIS, 835
 ISFILE, 560
 ISNUMBER, 438
 ISOCALL, 521
 ISVAR, 415

J

J...
 For circular interpolation, 189
 For thread cutting G34 G35, 222
 Jerk
 Limitation, 798
 offset, 820
 JERKLIM, 820
 JERKLIMA, 800
 JR, 229
 Jump
 to beginning of program, 453
 to jump labels, 454
 Jump label
 for program jumps, 455
 Jump marker
 For program section repetitions, 459

K

K...
 For circular interpolation, 189

 For thread cutting G33, 216
 For thread cutting G34 G35, 222
 Kinematic type, 741
 Kinematics
 Resolved, 741
 KONT, 255
 KONTC, 255
 KONTT, 255
 KR, 229

L

L..., 512
 Label, 459
 Language mode, 1049
 LEAD, 645
 LEAD..., 994
 Leading axis
 for axial master value coupling, 864
 LEADOF, 864
 LEADON, 864
 Left-hand thread, 218
 LENTOAX, 789
 LF, 48
 LFOF, 226
 LFON, 226
 LFPOS, 226
 LFTXT, 226
 LFWP, 226
 LIFTFAST, 533
 LIMS, 100
 LINE FEED, 48
 LLI, 399
 LN, 431
 LOCK, 1011
 Logic operators, 433
 LONGHOLE - elongated hole
 External programming, 1082
 Longitudinal slot - SLOT1
 External programming, 1077
 LookAhead, 295
 LOOP, 467
 LUD, 387

M

M, 980
 M functions, 339
 M..., 339
 M0, 339
 M1, 339

- M17, 500
- M19
 - For spindle positioning, 119
 - M functions, 339
- M2, 339
- M3, 91
- M30, 500
- M4, 91
- M40, 339
- M41, 339
- M42, 339
- M43, 339
- M44, 339
- M45, 339
- M5, 91
- M6, 64
- M70, 119
- Machine
 - zero point, 35
- Machine coordinate system, 37
- Machines
 - axes, 367
- Macro, 477
- Main entry, 169
- MASLDEF, 900
- MASLDEL, 900
- MASLOF, 900
- MASLOFS, 900
- MASLON, 900
- Master spindle, 367
- Master value coupling
 - Actual value and setpoint coupling, 868
 - Synchronization of leading and following axis, 867
- Master value simulation, 869
- MATCH, 442
- MAXVAL, 414
- MCALL, 517
- MCS, 37
- MD10010, 471
- MD10240, 162
- MD10260, 160
- MD10280, 471
- MD10651, 230
- MD10710, 225
- MD10722, 976
- MD11110, 956
- MD11510, 928
- MD15800, 386
- MD18104, 768
- MD18116, 769
- MD18156, 386
- MD18660, 947
- MD18661, 947
- MD18662, 947
- MD18663, 947
- MD18664, 948
- MD18665, 948
- MD20110, 939
- MD20360, 775
- MD21190, 937
- MD21194, 937
- MD21196, 937
- MD22200, 956
- MD22210, 956
- MD22230, 956
- MD24558, 776
- MD24658, 776
- MD28050, 917, 923, 1000
- MD28254, 916
- MD28255, 916
- MD28256, 915
- MD28257, 915
- MD28258, 919, 1000
- MD28260, 923, 1000
- MD28262, 923, 1000
- MD28264, 923, 1000
- MD28266, 923, 1000
- MD30450, 970
- MD30460, 989
- MD32060, 974
- MD32070, 934
- MD32074, 969
- MD32420, 934
- MD32430, 934
- MD36750, 935
- MEAC, 592, 999
- MEAFRAME, 622
- MEAS, 590
- MEASA, 592
- Measuring cycle parameters
 - CYCLE961, 1215
 - CYCLE971, 1233
 - CYCLE973, 1195
 - CYCLE974, 1197
 - CYCLE976, 1204
 - CYCLE977, 1211
 - CYCLE978, 1206
 - CYCLE979, 1218
 - CYCLE982, 1230
 - CYCLE994, 1201
 - CYCLE995, 1224
 - CYCLE996, 1226
 - CYCLE9960, 1228

CYCLE997, 1221
 CYCLE998, 1209
 MEAW, 590
 MEAWA, 592, 999
 Memory
 Preprocessing, 805
 Program, 540
 Working, 550
 Messages, 343
 Milling tools, 74
 MINDEX, 442
 MINVAL, 414
 MIRROR, 323
 MMC, 1035
 MOD, 431
 Modal synchronized action, 905
 Modally effective, 47
 MODAXVAL, 835
 MOV, 973
 MPF, 541
 MSG, 343
 Multi-edge - CYCLE79
 External programming, 1105

N

NAMETOINT, 697
 NC high-level language, 46
 NC program
 Creating, 52
 NC programming
 Character set, 53
 NCK, 387
 NCK notation, 544
 Nesting depth
 of check structures, 465
 NEWCONF, 1031
 NOC, 876
 Non-modal, 47
 Non-modal synchronized action, 905
 NORM, 255
 NOT, 433
 NPROT, 567
 NPROTDEF, 564
 NUMBER, 438
 Numeric extension, 372
 NUT, 656

O

Oblique plunge-cut grinding, 678

OEM addresses, 601
 OEM functions, 601
 OEMIPO1/2, 601
 OFFN, 246
 Offset
 Tool length, 85, 86
 Tool radius, 85
 Offset memory, 712
 OMA1 ... OMA5, 601
 Online tool length offset, 747
 Open slot – CYCLE899
 External programming, 1153
 Operation, 45
 Optional stop, 342
 OR, 433
 ORIXES, 654
 ORIC, 728
 ORICONCCW, 656
 ORICONCW, 656
 ORICONIO, 656
 ORICONTO, 656
 ORICURVE, 659
 ORID, 728
 Orientation axes, 654
 Orientation programming, 654
 Orientation transformation TRAORI
 Generic 5/6-axis transformation, 635
 Machine kinematics, 635
 Orientation movements, 634
 Orientation programming,
 Variants of orientation programming,
 Orientation vector THETA, 663
 ORIEULER, 654
 ORIMKS, 652
 ORIPATH, 667
 ORIPATHS, 667
 ORIPLANE, 656
 ORIRESET(A, B, C), 643
 ORIROTA, 663
 ORIROTC
 during interpolation the tool rotation, 668
 for rotation of the tool orientation, 663
 ORIROTR, 663
 ORIROTT, 663
 ORIRPY, 654
 ORIRPY2, 654
 ORIS, 728
 ORISOF, 674
 ORISOLH, 750
 ORISON, 674
 ORIVECT, 654
 ORIVIRT1, 654

- ORIVIRT2, 654
 ORIWKS, 652
 OS, 1013
 OSB, 1013
 OSC, 728
 OSCILL, 1017
 Oscillating motion
 Infeed at reversal point, 1022
 Reversal point, 1020
 Reversal range, 1020
 Oscillation
 Asynchronous, 1013
 Asynchronous oscillation, 1013
 Control via synchronized action, 1017
 Partial infeed, 1020
 Synchronous oscillation, 1017
 OSCTRL, 1013
 OSD, 728
 OSE, 1013
 OSNSC, 1013
 OSOF, 728
 OSP1, 1013
 OSP2, 1013
 OSS, 728
 OSSE, 728
 OST, 728
 OST1, 1013
 OST2, 1013
 OTOL, 823
 Output
 to external device/file, 1040
 OVR, 127
 OVRA, 127
 OVERRAP, 127
- P**
- P..., 516
 P_ACTFRAME, 630
 Parameter
 Actual, 484
 Formal, 483
 transfer for subprogram call, 514
 Transfer on subprogram call, 484
 Parameters
 Machine, 712
 PAROT, 328
 PAROTOF, 328
 Path axes, 368
 Path calculation, 370
 Path milling - CYCLE72
 External programming, 1095
 Path specification, 545
 PCALL, 522
 PFRAME, 608
 PHI
 For orientation along the peripheral surface of a taper, 656
 Orientation polynomials, 662
 PHU, 400
 PL
 for polynomial interpolation, 583
 PLC
 -axes, 370
 PM, 266
 PO, 583
 PO[PHI]
 For orientation along the peripheral surface of a taper, 656
 for rotation of the tool orientation, 667
 Orientation polynomials, 662
 PO[PSI]
 For orientation along the peripheral surface of a taper, 656
 for rotation of the tool orientation, 667
 Orientation polynomials, 662
 PO[THT]
 for rotation of the tool orientation, 667
 Orientation polynomials, 662
 PO[XH]
 for orientation specification of two contact points, 659
 Orientation polynomials, 662
 PO[YH]
 for orientation specification of two contact points, 659
 Orientation polynomials, 662
 PO[ZH]
 for orientation specification of two contact points, 659
 Orientation polynomials, 662
 POCKET3 - rectangular pocket
 External programming, 1072
 POCKET4 - circular pocket
 External programming, 1075
 Point-to-point travel, 680
 Polar angle, 30
 Polar coordinates, 30
 Polar radius, 30
 Polar transformation, 636
 Pole, 175
 POLF
 For rapid retraction during thread cutting, 226

- POLFMASK
 - For rapid retraction during thread cutting, 226
 - POLFMLIN
 - For rapid retraction during thread cutting, 226
 - POLY, 583
 - Polynomial coefficient, 584
 - Polynomial interpolation, 583
 - POLYPATH, 583
 - POS, 115, 967
 - POSA, 115
 - POSFS, 876
 - Position attributes
 - Indirect programming, 427
 - Position synchronism, 876
 - Position synchronism with angular offset, 876
 - Positioning axes, 368
 - POSP, 115
 - POSRANGE, 972
 - POT, 431
 - PR, 266
 - Predrilling a contour pocket – CYCLE64
 - External programming, 1092
 - PREPRO, 500
 - Preprocessing
 - memory, 805
 - Preprocessing stop
 - Internal, 364
 - PRESETON, 619, 984
 - PRESETONS, 621, 989
 - PRIO, 530
 - PRLOC, 387
 - Procedure
 - Predefined, 1306
 - Process DataShare, 1040
 - Processing time, 1026
 - Program
 - addressing, 544
 - Branch, 457
 - End, 47
 - Header, 54
 - Initialization, 551
 - Jumps, 454
 - memory, 541
 - Name, 44
 - repetition, 516
 - Runtimes, 1026
 - Program loop
 - Count loop, 468
 - End of loop, 467
 - IF loop, 466
 - REPEAT loop, 470
 - WHILE loop, 469
 - Program memory
 - File types, 541
 - Standard directories, 541
 - Program section
 - repetition, 459
 - Program section repetition
 - with indirect programming CALL, 520
 - Programmed stop, 341
 - PROTA, 699
 - PROTD, 700
 - Protection zones, 564
 - PROTS, 700
 - PSI
 - For orientation along the peripheral surface of a taper, 656
 - Orientation polynomials, 662
 - PTP, 680
 - PTPG0, 680
 - PTPWOC, 681
 - PUD, 387
 - Punched tape format, 45
 - PUTFTOC, 726
 - PUTFTOCF, 725
- ## Q
- QU, 338
- ## R
- RAC, 166
 - Radius
 - Effective, 113
 - Radius programming, 164
 - Rapid retraction
 - Thread cutting, 226
 - RDISABLE, 964
 - READ, 558
 - REAL, 387
 - REAL constant, 375
 - Reaming - CYCLE85
 - External programming, 1117
 - Rectangular pocket - POCKET3
 - External programming, 1072
 - Rectangular spigot - CYCLE76
 - External programming, 1098
 - REDEF, 392
 - Reference point, 36
 - Reference points, 35
 - Reference radius, 113
 - RELEASE, 829, 975

- REP, 407, 943
 REPEAT, 459
 REPEATB, 459
 REPOSA, 812
 REPOSH, 812
 REPOSHA, 812
 REPOSL, 812
 REPOSQ, 812
 REPOSQA, 812
 Residual time
 for a workpiece, 1028
 RET, 501
 RET (parameterizable), 502
 RETB (parameterizable), 508
 Retraction
 Direction for thread cutting, 227
 RG, 385
 RIC, 166
 Right-hand thread, 218
 RINDEX, 442
 RMBBL, 812
 RMEBL, 812
 RMIBL, 812
 RMNBL, 812
 RND, 240
 RNDM, 240
 ROT, 311
 Rotary axes
 Angle of rotation, 737
 Direction vectors, 737
 Distance vectors, 737
 Rotation
 of the orientation vector, 663
 Programmable, 311
 ROTS, 317
 ROUND, 431
 Round up, 436
 Rounding, 240
 ROUNDUP, 436
 Row position pattern – HOLES1
 External programming, 1070
 RP, 176
 RPL, 311
 RPY, 648
 Run MyScreens, 1035
 Runtime
 Response of check structures, 465
- S**
- S, 91, 980
 SAR, 266
 SAVE, 490
 SBLOF, 492
 SBLON, 492
 SCALE, 320
 Scale factor, 320
 SCC, 100
 SCPARA, 842
 SD41610, 711
 SD41611, 711
 SD42010, 225
 SD42122, 925
 SD42440, 155
 SD42442, 155
 SD42465, 296
 SD42466, 296
 SD42475, 672
 SD42476, 672
 SD42477, 672
 SD42900, 719
 SD42910, 719
 SD42920, 719
 SD42930, 720
 SD42935, 722
 SD42940, 723
 SD42984, 761
 SD43240, 121
 SD43250, 121
 SD43300, 974
 SD43350, 935
 Search for reference, 352
 Search path
 for subprogram call, 548
 Programmable search path, 523
 Sequence of execution, 906
 SET, 407, 943
 Set dresser coordinate system - CYCLE435
 External programming, 1132
 SETAL, 1044
 SETDNO, 735
 SETINT, 530
 SETM, 471, 1004
 SETMS, 91
 Setpoint value coupling, 879
 SETTCOR, 777
 Setup value, 716
 SF, 216
 SIN, 431
 Single-block
 suppression, 492
 Singular positions, 653
 Skip levels, 51

- SLOT1 - longitudinal slot
 - External programming, 1077
- SLOT2 - circumferential slot
 - External programming, 1080
- Slotting saw, 82
- Smoothing
 - of the orientation characteristic, 674
- SOFT, 798
- SOFTA, 798
- SPCOF, 118
- SPCON, 118
- Special axes, 366
- Special characters, 53, 54
- Special tools, 81
- Speed coupling, 879
- Speed synchronism, 876
- SPF, 541
- SPI, 835
- Spindle
 - direction of rotation, 91
 - M functions, 342
 - Main, 367
 - Positioning, 119
 - replacement, 829
 - speed, 91
 - Speed limitation, 106
- SPOS, 119, 980
- SPOSA, 119
- SPRINT, 445
- SQRT, 431
- SR, 136
- SRA, 136
- ST, 136
- STA, 136
- START, 471
- Start point offset
 - For thread cutting, 217
- STARTFIFO, 805
- Starting point, 36
- Starting point - target point, 172
- STAT, 681
- Static synchronized action, 905
- Stock removal
 - supporting functions, 1052
- Stock removal - CYCLE951
 - External programming, 1161
- Stock removal / residual stock removal / plunge cutting / residual plunge cutting / plunge turning / residual plunge turning – CYCLE952
 - External programming, 1164
- STOLF, 183
- Stop
 - At the end of the cycle, 342
 - Optional, 342
 - Programmed, 341
- STOPFIFO, 805
- STOPRE, 805, 967
- STOPREOF, 965
- Straight lines
 - interpolation, 186
- String,
 - concatenation, 440
 - formatting, 445
 - length, 441
 - operations, 437
- STRINGIS, 1032
- STRLEN, 441
- Subprogram
 - Application, 480
 - call with parameter transfer, 514
 - call without parameter transfer, 512
 - call, indirect, 519
 - call, modal, 517
 - Name, 481
 - Programmable search path, 523
 - repetition, 516
 - return, parameterizable (RET ...), 502
 - return, parameterizable (RETB...), 508
- Subprogram level is canceled
 - CANCELSUB, 1005
- Subprogram with path specification and parameters, 522
- SUBSTR, 443
- SUPA
 - For deselect frame, 330
 - For work offset, 146
- S-value
 - Interpretation, 93
- SVC, 94
- Switchable geometry axes, 836
- Swivel plane / swivel tool / align tool – CYCLE800
 - External programming, 1134
- Synchronism
 - coarse, 879
 - Fine, 879
- Synchronized
 - Axes, 369
- Synchronized actions
 - Additive adjustment via SYNFACT, 958
- Synchronous oscillation
 - Assignment of oscillating and infeed axes, 1021
 - Define infeeds, 1021
 - Evaluation, IPO cycle, 1023

- Infeed in reversal point range, 1022
- Infeed movement, 1022
- Next partial infeed, 1024
- Synchronized actions, 1021
- Synchronous spindle
 - Coupling, 876
 - pair definition, 882
- SYNFCT, 957
- SYNR, 387
- SYNRW, 387
- SYNW, 387
- System frames, 627
- System of units, 160
- SZS, 42

- T**
- T0, 62
- TAN, 431
- TANG, 893
- TANGDEL, 898
- TANGOF, 898
- TANGON, 896
- Tapered thread, 222
- Tapping with compensating chuck - CYCLE840
 - External programming, 1150
- Tapping without compensating chuck - CYCLE84
 - External programming, 1114
- Target point, 172
- TCARR, 742
- TCOABS, 742
- TCOFR, 742
- TCOFRX, 742
- TCOFRY, 742
- TCOFRZ, 742
- Technology cycle, 909
- Technology cycles, 1006
- THETA
 - during interpolation the tool rotation, 668
 - for rotation of the tool orientation, 663
- Thread
 - Chain, 217
 - cutting G33, 216
 - cutting G34 G35, 222
 - direction of rotation, 218
 - lead, 222
 - multiple, 217
- Thread chain - CYCLE98
 - External programming, 1123
- Thread milling - CYCLE70
 - External programming, 1094
- Thread turning - CYCLE99
 - External programming, 1127
- Three-finger rule, 37
- TILT, 645
- TLIFT, 895
- TMOF, 1025
- TMON, 1025
- TOFF, 85
- TOFFL, 85
- TOFFLR, 85
- TOFFOF, 748
- TOFFON, 748
- TOFFR, 85
- TOFRAME, 328
- TOFRAMEX, 328
- TOFRAMEY, 328
- TOFRAMEZ, 328
- TOLOWER, 441
- Tool
 - change point, 36
 - change with M6, 64
 - change with T command, 62
 - cutting edge, 83
 - Group, 73
 - length compensation, 70
 - Offset memory, 72
 - orientation, 728
 - orientation for frame change, 744
 - parameters, 712
 - radius compensation, 71
 - tip, 72
 - Type, 73
 - Type number, 73
- Tool chain, 709, 746
- Tool offset
 - Coordinate system for wear values, 720
 - Offset, 85
 - Offset memory, 712
- Tool offsets
 - additive, 714
- Tool orientation
 - relative to the path, 665
- Tool orientation relative to the path, 665
- Tool radius compensation
 - At outside corners, 263
 - Corner deceleration, 602
 - CUT2DF, 283
- Tool speed
 - maximum, 96
- TOOLENV, 766
- Toolholder
 - kinematics, 737

- orientable, 742
- reference point, 36
- Toolholder with orientation capability, 737
- TOROT, 328
- TOROTOF, 328
- TOROTX, 328
- TOROTY, 328
- TOROTZ, 328
- TOUPPER, 441
- TOWBCS, 720
- TOWKCS, 720
- TOWMCS, 720
- TOWSTD, 720
- TOWTCS, 720
- TOWWCS, 720
- TRACYL, 675
- TRAFOOF, 692
- TRAFOON, 703
- TRAIL..., 994
- TRAILOF, 844
- TRAILON, 844
- TRANS, 305
- Transformation types
 - General function, 632
- Transformation with a swiveling linear axis, 641
- Transformations
 - Chained transformations, 634
 - Initial tool orientation setting regardless of kinematics, 633
 - Kinematic transformations, 633
 - Orientation transformation, 632
 - Three-, four- and five-axis transformation, 642
- TRANSMIT, 675
- Transverse axis, 171
- TRAORI, 642
- Travel command, 172
- TRUE, 387
- TRUNC, 431
- TU, 685
- TURN, 204
- Turning tools, 79
- Type of coupling, 879

U

- ULI, 399
- Undercut forms E and F / undercut thread – CYCLE940
 - External programming, 1159
- UNLOCK, 1011
- UNTIL, 470
- User XML, 1035

V

- Value assignment, 49
- Variable
 - Type conversion, 422
- Variables
 - Type conversion, 438
 - User-defined, 387
- VELOLIM, 821
- VELOLIMA, 800

W

- WAITC, 876
- WAITE, 471
- WAITENC, 841
- WAITM, 471
- WAITMC, 471
- WAITP, 115
- WAITS, 119
- WALCS<n>, 349
- WALCS0, 349
- WALIMOF, 346
- WALIMON, 346
- WCS, 43
 - Align on workpiece, 328
- Wear value, 716
- WHEN, 906
- WHEN-DO, 1021
- WHENEVER, 906
- WHENEVER-DO, 1021
- WHILE, 469
- Work offset
 - Settable, 146
- Working area limitation
 - in BCS, 346
- Working memory, 550
- Working plane, 34
- WORKPIECE, 1045
 - Contour,
 - counter,
 - directories,
 - main directory,
 - zero point,
- Workpiece chain, 709, 746
- Workpiece coordinate system, 43
- WRITE, 554
- WRTPR, 344

X

X..., 173
XOR, 433

Y

Y..., 173

Z

Z..., 173
Zero frame, 146
Zero offset
 External, 618
 Programmable, 305
Zero points
 For turning, 170
Zero system
 Basic, 41
 Settable, 42

