

SIEMENS

SIPART

Electropneumatic positioners SIPART PS100

Operating Instructions


<u>Getting started</u>	1
<u>Introduction</u>	2
<u>Safety notes</u>	3
<u>Installing/mounting</u>	4
<u>Connecting</u>	5
<u>Local operation</u>	6
<u>Commissioning</u>	7
<u>Parameter assignment and addressing</u>	8
<u>Troubleshooting</u>	9
<u>Service and maintenance</u>	10
<u>Technical specifications</u>	11
<u>Dimension drawings</u>	12
<u>Product documentation and support</u>	A
<u>Bluetooth</u>	B


6DR710. SIPART PS100 Polycarbonate
6DR711. SIPART PS100 Aluminum without window


Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.

 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.

 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.

NOTICE
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Getting started	7
2	Introduction	9
2.1	Purpose of this documentation	9
2.2	Scope of documentation	9
2.3	Document history	10
2.4	Product compatibility	10
2.5	Designated use	11
2.6	Checking the consignment.....	11
2.7	Nameplate layout.....	12
2.8	Security information	13
2.9	Security note	13
2.10	Transportation and storage	14
2.11	Notes on warranty	14
3	Safety notes	15
3.1	Prerequisites for safe use.....	15
3.1.1	Warning symbols on the device	15
3.1.2	Laws and directives	15
3.1.3	Conformity with European directives	16
3.1.4	Conformity with UK directives	16
3.1.5	Product approval and UL compliance	16
3.2	Use in hazardous areas.....	17
4	Installing/mounting	19
4.1	Basic safety notes.....	19
4.1.1	Proper mounting.....	20
4.2	Mounting to linear actuator	21
4.3	Mounting to part-turn actuator	24
5	Connecting	29
5.1	Basic safety notes.....	29
5.2	Grounding	32
5.3	Electrical connection	33
5.4	Pneumatic connection	33
5.4.1	Structure of pneumatic connection	34
5.4.2	Behavior in case of failure of the electrical auxiliary power and/or the supply pressure PZ.....	34

6	Local operation	37
7	Commissioning	39
7.1	Basic safety notes.....	39
7.2	Initialize in "NO INIT" operating mode.....	41
8	Parameter assignment and addressing	43
8.1	Overview of the menu structure.....	43
8.2	QUICK START [01]	44
8.3	SETUP [02]	45
8.4	MAINT/DIAGS [03]	46
9	Troubleshooting	49
9.1	Device status symbols	49
9.2	Info IDs, error messages and corrective measures	50
10	Service and maintenance	53
10.1	Basic safety notes.....	53
10.1.1	Maintenance.....	53
10.2	Cleaning	53
10.3	Maintenance and repair work.....	54
10.4	Return procedure	55
10.5	Replacing electronics	55
10.6	Replacing the pneumatic block.....	58
10.7	Disposal.....	59
11	Technical specifications	61
11.1	Input	61
11.2	Output.....	61
11.3	Rated conditions	62
11.4	Pneumatic data.....	63
11.5	Mechanical construction	63
11.6	Controller	64
11.7	Explosion protection	65
12	Dimension drawings	67
A	Product documentation and support	69
A.1	Product documentation	69
A.2	Technical support.....	70
B	Bluetooth	71
B.1	Connecting SIPART PS100 with SITRANS AW050 Bluetooth adapter	71

B.2	Connecting a field device using the SITRANS mobile IQ app.....	74
B.3	Preset password	75
B.4	Reset Password	75
B.5	Technical specifications	76
B.5.1	SITRANS mobile IQ	76
B.5.2	SITRANS AW050 Bluetooth adapter.....	76
B.5.3	Information for radio approval FCC and IC	77
B.6	Dimension drawing SITRANS AW050 Bluetooth adapter	78
Index	79

Getting started

Requirement

You have read the following safety instructions:

- General safety notes (Page 15)
- Basic safety notes: Installing/mounting (Page 19)
- Basic safety notes: Connecting (Page 29)
- Basic safety notes: Commissioning (Page 39)

Read the entire document for information on getting the best performance from your device.

Procedure




Figure 1-1 Overview of device components, open cover

1. Mount the positioner.
Mounting to linear actuator (Page 21)
Mounting to part-turn actuator (Page 24)
2. Connect the positioner.
Electrical connection (Page 33)
Pneumatic connection (Page 33)
3. Ground the positioner.
Grounding (Page 32)
4. Remove the enclosure cover.
5. Commission the positioner.
Initialize in "NO INIT" operating mode (Page 41)
Local operation (Page 37)
6. Remove the enclosure cover.

Introduction

2.1 Purpose of this documentation

These instructions are a brief summary of important features, functions and safety information, and contain all information required for safe use of the device. Read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons who install and commission the device.

To realize optimum performance from the device, read the complete operating instructions.

2.2 Scope of documentation

Article no.	Product
6DR710.	SIPART PS100, Polycarbonate
6DR711.	SIPART PS100, Aluminum without window
7MP3210-0AA01	SITRANS AW050 Bluetooth adapter kit for SIPART PS100

2.3 Document history

The most important changes in the documentation when compared with the respective previous edition are given in the following table.

Edition	Comment
06/2023	<ul style="list-style-type: none"> Section "Technical specifications" revised Section "Bluetooth" revised Information on UKCA has been inserted
05/2021	<ul style="list-style-type: none"> Changes for FW 1.03.00, HART device revision 1 HART communication in various sections Explosion protection in various sections "Troubleshooting" section: New Info-ID 6Y (Page 50) "Technical specifications" section New "Explosion protection" "Service and maintenance" section New "Replacing electronics (Page 55)" and "Replacing a pneumatic block (Page 58)" New section "Bluetooth (Page 71)"
03/2020	<ul style="list-style-type: none"> Changes for FW 1.02.00, HART device revision 1 Changed parameter IDs In "QUICK START" menu: New parameter "VALVE TYPE" [06] In "SETUP" menu: <ul style="list-style-type: none"> For "BEHAVIOR DO" [01] new function "POS" For "BEHAVIOR DO" [01] function "NONE" changed to "ERR M" New parameter "DO POS LIMIT" [03] In "MAINT/DIAG" menu: <ul style="list-style-type: none"> The parameters "PIEZO 1" [56] and "PIEZO 2" [57] were renamed to "PILOT 1" [04] and "PILOT 2" [05]. New parameter "HW Version" [06] "Troubleshooting" section: Addition info IDs are displayed for the status of the digital input (DI) in the "AUTO" operating mode: 6E, 6F, 6H

2.4 Product compatibility

The following table describes the compatibility between the edition of the manual, device revision, engineering system and associated Electronic Device Description (EDD).

Manual edition	Comments	Device revision	Compatible version of device integration package
06/2023	Manual revised	FW: 1.03.00 or higher	EDD: 1.00.00
05/2021	New device features	Device revision 1 or higher	
03/2020	New device features	FW: 1.02.00 or higher Device revision 1 or higher	-

2.5 Designated use

Use the device in accordance with the information on the nameplate and in the Technical specifications (Page 61).


2.6 Checking the consignment

1. Check the packaging and the delivered items for visible damages.
2. Report any claims for damages immediately to the shipping company.
3. Retain damaged parts for clarification.
4. Check the scope of delivery by comparing your order to the shipping documents for correctness and completeness.

 WARNING
Using a damaged or incomplete device
Risk of explosion in hazardous areas.
<ul style="list-style-type: none">• Do not use damaged or incomplete devices.


2.7 Nameplate layout

Example of manufacturer nameplate



- ① Manufacturer
- ② Conformity with country-specific directives
- ③ Note operating instructions, certificates and approvals under Product documentation (Page 69)
- ④ Serial number
- ⑤ QR code to the mobile website with device-specific product information
- ⑥ Firmware version and hardware version
- ⑦ Country of origin
- ⑧ Supply pressure PZ
- ⑨ Degree of protection
- ⑩ Ordering supplement (Order code)
- ⑪ Article number
- ⑫ Product name

Example of explosion protection nameplate



- ① Approvals
- ② ATEX/IECEX marking for hazardous area
- ③ FM/CSA marking for hazardous area
- ④ Permissible ambient temperature for operation in hazardous areas

2.8 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit

<https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

<https://www.siemens.com/cert>.

2.9 Security note

NOTICE

Unauthorized product information or software

Use only authorized Siemens websites when accessing any product information or software, including firmware updates, device integration files (EDD, for example), as well as other product documentation. Using unauthorized product information or software could result in a security incident, such as breach of confidentiality, or loss of integrity and availability of the system.

For more information, see Product documentation and support (Page 69).

2.10 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly packaged to provide sufficient protection during transport. Siemens cannot assume liability for any costs associated with transportation damages.

NOTICE
Insufficient protection during storage The packaging only provides limited protection against moisture and infiltration. <ul style="list-style-type: none">• Provide additional packaging as necessary.

Special conditions for storage and transportation of the device are listed in Technical specifications (Page 61).

2.11 Notes on warranty

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.

The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.


Safety notes

3.1 Prerequisites for safe use

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

3.1.1 Warning symbols on the device

Symbol	Explanation
	Consult operating instructions

3.1.2 Laws and directives

Observe the test certification, provisions and laws applicable in your country during connection, assembly and operation. These include, for example:

- National Electrical Code (NEC - NFPA 70) (USA)
- Canadian Electrical Code (CEC) (Canada)

Further provisions for hazardous area applications are for example:

- IEC 60079-14 (international)
- EN 60079-14 (EU)
- For Korea only:
이 기기는 업무용(A 급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며 가정 외의

지역에서사용하는 것을 목적으로 합니다

3.1 Prerequisites for safe use

3.1.3 Conformity with European directives

The CE marking on the device shows conformity with the regulations of the following European guidelines:

Electromagnetic compatibility EMC 2014/30/EU	Directive of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to electromagnetic compatibility.
Atmosphère explosive ATEX 2014/34/EU	Directive of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to equipment and protective systems intended for use in potentially explosive atmospheres.
2011/65/EU RoHS	Directive of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment

The directives applied can be found in the EU declaration of conformity for the associated device.

3.1.4 Conformity with UK directives


The UKCA marking on the device shows conformity with the following UK directives:

Electromagnetic Compatibility SI 2016/1091	Electromagnetic Compatibility Directives 2016
Explosive Atmospheres SI 2016/1107	Directives for Equipment and Protective Systems Intended for use in Potentially Explosive Atmospheres 2016
Directive on the Restriction of the Use of Certain Hazardous Substances SI 2012/3032	Directives on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment 2012

The applicable directives can be found in the UKCA declaration of conformity of the specific device.

3.1.5 Product approval and UL compliance

Classification according to pressure equipment directive (PED 2014/68/EU)	For fluid group 1 gases; fulfills requirements according to article 4, paragraph 3 (good engineering practice SEP)
CE conformity	The applicable directives and applied standards can be found in the EU declaration of conformity on the Internet.
UL conformity	Conformity has been proven based on US and Canadian safety requirements. For applicable safety requirements, refer to the UL CERTIFICATE OF COMPLIANCE on the Internet at: Certificates (http://www.siemens.com/processinstrumentation/certificates)


 WARNING
Improper device modifications
Risk to personnel, system and environment can result from modifications to the device, particularly in hazardous areas.
<ul style="list-style-type: none">• Only carry out modifications that are described in the instructions for the device. Failure to observe this requirement cancels the manufacturer's warranty and the product approvals.


3.2 Use in hazardous areas

Qualified personnel for hazardous area applications

Persons who install, connect, commission, operate, and service the device in a hazardous area must have the following specific qualifications:

- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures, aggressive, and hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.


 WARNING
Use in hazardous area
Risk of explosion.
<ul style="list-style-type: none">• Only use equipment that is approved for use in the intended hazardous area and labeled accordingly.• Do not use devices that have been operated outside the conditions specified for hazardous areas. If you have used the device outside the conditions for hazardous areas, make all Ex markings unrecognizable on the nameplate.


 WARNING
Loss of safety of device with type of protection "Intrinsic safety Ex i"
If the device or its components have already been operated in non-intrinsically safe circuits or the electrical specifications have not been observed, the safety of the device is no longer ensured for use in hazardous areas. There is a risk of explosion.
<ul style="list-style-type: none">• Connect the device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.• Observe the specifications for the electrical data on the certificate and/or in Technical specifications (Page 61).


3.2 Use in hazardous areas


Installing/mounting


4.1 Basic safety notes

 WARNING
High operating force with pneumatic actuators Risk of injury when working on control valves due to the high operating force of the pneumatic actuator. <ul style="list-style-type: none">• Please observe the corresponding safety instructions for the pneumatic actuator in use.

 WARNING
Exceeded maximum permissible operating pressure Risk of injury or poisoning. The maximum permissible operating pressure depends on the device version, pressure limit and temperature rating. The device can be damaged if the operating pressure is exceeded. Hot, toxic and corrosive process media could be released. Ensure that maximum permissible operating pressure of the device is not exceeded. Refer to the information on the nameplate and/or in Technical specifications (Page 61).

 WARNING
Electrostatic charging of nameplates The nameplates used on the device can reach a charging capacity of 5 pF. <ul style="list-style-type: none">• Keep the device and the cables at a distance from strong electromagnetic fields.

 CAUTION
Unsuitable compressed air Device damage. As a general rule, the positioner must only be operated with dry and clean compressed air. <ul style="list-style-type: none">• Use the customary water separators and filters. An additional dryer is required in extreme cases.• Use dryers, especially if you operate the positioner at low ambient temperatures.

 CAUTION
Adhere to the following instructions before working on the control valve and when attaching the positioner
Danger of injury.
<ul style="list-style-type: none">• Prior to working on the control valve, you must move the actuator and the process valve into a completely pressureless state. Proceed as follows:<ul style="list-style-type: none">– Depressurize the actuator chambers.– Switch off the supply pressure PZ.– Secure the process valve.• Make sure that the actuator has reached the pressureless state.• If you interrupt the supply pressure PZ to the positioner, the pressureless position can only be reached after a certain waiting time.• When mounting, adhere strictly to the following order to avoid injuries or mechanical damage to the positioner/mounting kit:<ul style="list-style-type: none">– Mount the positioner mechanically.– Electric connection.– Connect supply pressure PZ.– Commission the positioner.

NOTICE
Torque with NPT screwed gland
Device damage. The maximum torque of the cable gland must not be exceeded.
<ul style="list-style-type: none">• To avoid damage to the device, the NPT adapter must be held in place while the NPT gland is screwed into the NPT adapter. Refer to the section "Technical specifications > Mechanical construction (Page 63)" for the torque value.


4.1.1 Proper mounting

NOTICE
Incorrect mounting
The device can be damaged, destroyed, or its functionality impaired through improper mounting.
<ul style="list-style-type: none">• Before installing ensure there is no visible damage to the device.• Make sure that process connectors are clean, and suitable gaskets and glands are used.• Mount the device using suitable tools. Refer to the information in Technical specifications (Page 61).

NOTICE**Freezing of the exhaust air outlets**

The exhaust air outlets ② can ice up. The function of the device is impaired.

- Do **not** install the positioner with the base plate ① pointing up.



- ① Base plate
- ② Exhaust air outlets

Figure 4-1 Exhaust air outlets, base plate

4.2 Mounting to linear actuator

Requirements

Depending on the stroke height, you will need the following mounting kit:

- 3 to 35 mm mounting kit 6DR4004-8V
- 35 to 130 mm mounting kit 6DR4004-8V and additional 6DR4004-8L

Procedure

Sr. no. *)	Quan- tity	Name	Note
6DR4004-8L:			
①	1	Lever	For the range of stroke from 10 to 130 mm
6DR4004-8V:			
①	1	NAMUR mounting bracket IEC 60534	Standardized connection point for mount with fin, column or plane surface
②	1	Pick-up bracket	Guides the pulley with the carrier pin and rotates the lever arm.
③	2	Clamping piece	Installs the pick-up bracket on the actuator spindle
④	1	Carrier pin	Installation with pulley ⑤ on lever ⑥

4.2 Mounting to linear actuator

Sr. no. *)	Quantity	Name	Note
⑤	1	Pulley	Installation with carrier pin ④ on lever ⑥
⑥	1	Lever	For the range of stroke from 3 to 35 mm
⑦	2	U-bolts	Only for actuators with columns
⑧	4	Hexagon bolt	M8x20 DIN 933-A2
⑨	2	Hexagon bolt	M8x16 DIN 933-A2, torque, section "Technical specifications > Mechanical construction (Page 63)"
⑩	6	Spring lock washer	A8 - DIN 127-A2
⑪	6	Washer	B8.4 - DIN 125-A2
⑫	2	Washer	B6.4 - DIN 125-A2
⑬	1	Spring	VD-115E 0.70 x 11.3 x 32.7 x 3.5
⑭	1	Spring lock washer	A6 - DIN 137A-A2
⑮	1	Lock washer	3.2 - DIN 6799-A2
⑯	3	Spring lock washer	A6 - DIN 127-A2
⑰	3	cylinder head screw	M6x25 DIN 7984-A2
⑱	1	Hexagon nut	M6 - DIN 934-A4
⑲	1	Square nut	M6 - DIN 557-A4
⑳	4	Hexagon nut	M8 - DIN 934-A4

*) The numbers refer to the images of the description of the installation steps below.

1. Install the clamping pieces ③ on the actuator spindle. Use spring lock washers ⑯ and cylinder head screws ⑰ for this.
2. Slide the pick-up bracket ② into the milled recesses of the clamping pieces ③.




Figure 4-2 Pick-up bracket

3. Tighten the screws ⑰ so that you can still shift the pick-up bracket ②.

- If you use a short lever, the carrier pin is already premounted. If you use the long lever 6DR4004-8L, fasten the carrier pin ④ with the existing parts to the long lever.




Figure 4-3 Short lever




Figure 4-4 Long lever 6DR4004-8L with mounted carrier pin ④ and cylinder head screw ⑰

- Position the carrier pin on the stroke value of the upper scale (90) of the lever ⑥. For strokes greater than 35 mm, use the long lever, article number 6DR4004-8L.
- Push the pre-installed lever ⑥ up to the end stop on the positioner shaft. Fasten the lever ⑥ with cylinder head screw ⑰.
- Install the mounting bracket ① at the rear side of the positioner. Use 2 hexagon bolts ⑨, 2 spring lock washers ⑩ and 2 flat washers ⑪ for this.




Figure 4-5 Installation with mounting bracket

- Select the row of holes. The selection of the row of holes depends on the yoke width of the actuator. Select the row of holes in such a way that the carrier pin ④ meshes with the pick-up bracket ② near the spindle. Ensure that the pick-up bracket ② does not touch the clamping pieces ③.

4.3 Mounting to part-turn actuator

9. Keep the positioner and the mounting bracket on the actuator. Ensure that the carrier pin ④ is guided inside the pick-up bracket ②.
10. Fasten the positioner on the yoke.




Figure 4-6 Fastening to various yoke types

4.3 Mounting to part-turn actuator

Requirements

- An actuator-specific VDI/VDE 3845 mounting console
- Mounting kit 6DR4004-8D

Procedure

"Part-turn actuator" mounting kit 6DR4004-8D			
Sr. no. *)	Quantity	Name	Note
①	1	Coupling wheel	Installation on positioner shaft
②	1	Carrier	Installing on the actuator shaft
③	1	Multiple plate	Display of the position, consisting of scale and pointer mark
	8	Scale	Different divisions
	2	Pointer mark	Reference point for scale
④		Mount	Actuator-specific, VDI/VDE 3845
⑤	4	Hexagon bolt	M6x12 DIN 933, torque see the section "Technical specifications > Mechanical construction (Page 63)"
⑥	4	Lock washer	S6
⑦	1	Socket cap screw	M6x16 DIN 84
⑧	1	Washer	6.4 DIN 125
⑨	1	Hex socket-head screw	M4 for coupling wheel
⑩	1	Square nut	M4 for coupling wheel
	1	Machinist's wrench	For hexagon socket-head screw ⑨

*) The numbers refer to the images of the description of the installation steps below.

1. Rest the actuator-specific VDI/VDE 3845 mount (4) on the rear side of the positioner.
2. Tighten the mount using the hexagon bolts (5) and lock washers (6).




Figure 4-7 Mount

3. Insert the square nut (10) into the coupling wheel. Insert the hex socket head screw (9) into the square nut (10).





Figure 4-8 Coupling wheel



4. Push the coupling wheel (1) or the stainless steel coupling up to the endstop on the positioner shaft.
5. Move the coupling wheel or the stainless steel coupling back by approximately 1 mm.
6. Tighten the hexagon socket-head screw (9) using the machinist's wrench provided. Maximum tightening torque = 1 Nm. If you are using the stainless steel coupling, omit the next step.

Note

Coupling wheel

Instead of the plastic (PBT) coupling wheel (1), it is possible to use a stainless steel coupling (article number TGX: 16300-1556).

7. Place the carrier (2) on the actuator shaft.

8. Tighten the carrier ② using the cylinder head screw ⑦ and the washer ⑧.




Figure 4-9 Carrier

9. Place the positioner and the mount on the actuator carefully. One of the two pins ⑫ of the coupling wheel ① must fit in the carrier ② when you do this.




Figure 4-10 Orientation of mount

When using the stainless steel coupling (article number TGX: 16300-1556): Place the positioner and the mount on the actuator carefully. Place the stainless steel coupling on the actuator shaft.

10. Align the positioner/mount at the center of the actuator.

11. Tighten the positioner/mount unit.







Figure 4-11 Positioner with mount attached to the part-turn actuator

5.1 Basic safety notes

 WARNING
Lever for position detection Danger of crushing and shearing with mounting kits which use a lever for position detection. During commissioning and ongoing operation, severing or squeezing of limbs could occur as a result of the lever. Risk of injury when working on control valves due to the high operating force of the pneumatic actuator. <ul style="list-style-type: none">• Do not reach into the range of motion of the lever following mounting of the positioner and mounting kit.

 WARNING
With intrinsically device version (Ex i) Risk of explosion in hazardous areas. For intrinsically safe device versions only the certified circuits may be connected as auxiliary power supply, control and signal circuits. <ul style="list-style-type: none">• Make sure that the power source of the used circuits is marked as intrinsically safe.


 WARNING
Unsuitable cables, cable glands and/or plugs Risk of explosion in hazardous areas. <ul style="list-style-type: none">• Use only cable glands/plugs that comply with the requirements for the relevant type of protection.• Tighten the cable glands in accordance with the torques specified in Technical specifications (Page 61).• Close unused cable inlets for the electrical connections.• When replacing cable glands, only use cable glands of the same type.• After installation, check that the cables are seated firmly.

NOTICE
Torque with NPT screwed gland
Device damage. The maximum torque of the cable gland must not be exceeded.
<ul style="list-style-type: none">• To avoid damage to the device, the NPT adapter must be held in place while the NPT gland is screwed into the NPT adapter. Refer to the section "Technical specifications > Mechanical construction (Page 63)" for the torque value.

NOTICE
Standard cable gland/torque
Device damage.
<ul style="list-style-type: none">• Owing the reasons pertaining to tightness (IP enclosure rating) and the required tensile strength, only use the cables having a diameter ≥ 8 mm for standard M20x1.5 cable gland, or use a suitable seal insert in case of smaller diameters.• In the NPT version, the positioner is delivered with a coupling. When inserting a counter piece in the coupling, ensure that the maximum permissible torque of 10 Nm is not exceeded.

NOTICE
Condensation in the device
Damage to device through formation of condensation if the temperature difference between transportation or storage and the mounting location exceeds 20 °C (36 °F).
<ul style="list-style-type: none">• Before taking the device into operation, let the device adapt for several hours in the new environment.

NOTICE
Ambient temperature too high
Damage to cable sheath.
<ul style="list-style-type: none">• At an ambient temperature ≥ 60 °C (140 °F), use heat-resistant cables suitable for an ambient temperature at least 20 °C (36 °F) higher.

 WARNING
Eliminating or reducing the sources of ignition within the equipment
Potential fire hazard.
<ul style="list-style-type: none">• The product must be connected to an energy-limited circuit.• Connect the device according to the information in Input (Page 61).

 **WARNING****Improper power supply**

Risk of explosion in hazardous areas as result of incorrect power supply.

- Connect the device in accordance with the specified power supply and signal circuits. The relevant specifications can be found in the certificates, in Technical specifications (Page 61) or on the nameplate.

 **WARNING****Lack of equipotential bonding**

Risk of explosion through compensating currents or ignition currents through lack of equipotential bonding.

- Ensure that the device is potentially equalized.

Exception: It may be permissible to omit connection of the equipotential bonding for devices with type of protection "Intrinsic safety Ex i".

 **WARNING****Unprotected cable ends**

Risk of explosion through unprotected cable ends in hazardous areas.

- Protect unused cable ends in accordance with IEC/EN 60079-14.

 **WARNING****Improper laying of shielded cables**

Risk of explosion through compensating currents between hazardous area and the non-hazardous area.

- Shielded cables that cross into hazardous areas should be grounded only at one end.
- If grounding is required at both ends, use an equipotential bonding conductor.

 **WARNING****Connecting or disconnecting device in energized state**

Risk of explosion in hazardous areas.

- Connect or disconnect devices in hazardous areas only in a de-energized state.

Exceptions:

- Devices having the type of protection "Intrinsic safety Ex i" may also be connected in energized state in hazardous areas.

**WARNING****Incorrect selection of type of protection**

Risk of explosion in areas subject to explosion hazard.

This device is approved for several types of protection.

1. Decide in favor of one type of protection.
2. Connect the device in accordance with the selected type of protection.
3. In order to avoid incorrect use at a later point, make the types of protection that are not used permanently unrecognizable on the nameplate.

Two-wire mode**NOTICE****Connection of voltage source to current input**

Device damage if a voltage source is connected to the current input I_w (terminals 6 and 7).

- Never connect the current input I_w to a low-resistance voltage source, otherwise the positioner may be destroyed.
- Always use a high-impedance power source.
- Observe the static destruction limit specified in the "Technical specifications (Page 61)".

Note**Improvement of interference immunity**

- Lay signal cables separate from cables with voltages > 60 V.
- Use cables with twisted wires.
- Keep the device and the cables at a distance from strong electromagnetic fields.
- Observe the communication conditions described in the section Technical specifications (Page 61).
- Use shielded cable to guarantee the full specification according to HART.

5.2 Grounding

The positioner is grounded via the mounting kit or via grounding with thread M4 on the enclosure, ⑨ in the figure "Overview of the device components (Page 7)".

5.3 Electrical connection




Figure 5-1 Wiring diagram

5.4 Pneumatic connection

⚠ WARNING
Supply pressure PZ
For safety reasons, the supply pressure PZ can be fed after installation only if the positioner is switched to the "NO INIT" mode when an electrical signal is available.

Note

Specifications regarding air quality

Observe the specifications regarding the air quality, see section "Technical specifications > Pneumatic data (Page 63)".

Note

Leakage

Besides continuous air consumption, a leakage can cause the positioner to try to compensate the position deviation. This will result in premature wear in the entire control device.

- Check if there is leakage with "LEAKAGE TEST".
- If there is leakage, check the pneumatic connections for leaks.

Structure of pneumatic connection (Page 34)

Behavior in case of failure of the electrical auxiliary power and/or the supply pressure PZ
(Page 34)

5.4.1 Structure of pneumatic connection




Figure 5-2 Pneumatic connection, example

5.4.2 Behavior in case of failure of the electrical auxiliary power and/or the supply pressure PZ

Overview

CAUTION

Note the following before working on the control valve

Note that, before working on the control valve, you must first move it to the safety position. Make sure that the process valve has reached the safety position. If you only interrupt the supply pressure PZ to the positioner, the safety position can in some cases only be attained after a certain delay period.


The difference between a failure of supply pressure PZ and a failure of electrical auxiliary power:





- Failure of **electrical auxiliary power** means the failure of the signal source at the analog input 4 to 20 mA.
- Failure of the **supply pressure PZ**

Actuator type	Behavior in case of failure: The actuator moves into safety position	
	Failure of electrical auxiliary power	Failure of supply pressure PZ
Single-acting	Y1 = depressurized	Y1 = depressurized
Double-acting	Y1 = pressurized Y2 = depressurized	Y1 = closed Y2 = closed

Local operation

Navigating in "NO INIT" operation mode




Initializing     Configuring
 Valve
 open / close

- ① Operation mode and setpoint in percent
- ② Angle of position detection in degrees
- ③ Info (Page 50)
- ④ Symbols for device status (Page 49)


Navigating in "AUTO" and "MANUAL" operation mode

AUTO



MANUAL     Configuring
 No
 function


MANUAL



AUTO     Configuring
 Valve
 open / close

- ① Operation mode and setpoint in percent
- ② Valve position as a percentage
- ③ Info (Page 50)
- ④ Symbols for device status (Page 49)

Navigating in parameter view and edit view



- ① In the parameter view: Parameter name
In the Edit view: Name and unit of the parameter (alternating)
- ② Parameter value
- ③ Parameter ID
- ④ EDIT permanently enabled
- ⑤ EDIT flashes

Commissioning

7.1 Basic safety notes

WARNING

Risk of crushing through lever of position detection

When the positioner is commissioned, immediate movement of the valve may occur.

If the positioner is in "NO INIT" mode, the movement of the valve starts immediately as soon as you press the left button on the positioner.

Danger of crushing and shearing with mounting kits which use a lever for position detection. During commissioning and during ongoing operation, severing or squeezing of limbs could occur as a result of the lever. Risk of injury when working on control valves due to the high operating force of the pneumatic actuator.

- Do not reach into the range of motion of the lever following mounting of the positioner and mounting kit.

WARNING

Improper commissioning in hazardous areas

Device failure or risk of explosion in hazardous areas.


- Do not commission the device until it has been mounted completely and connected in accordance with the information in Installing/mounting (Page 19).
- Before commissioning take the effect on other devices in the system into account.


WARNING

Commissioning and operation with pending error

If an error message appears, correct operation in the process is no longer guaranteed.


- Check the gravity of the error.
- Correct the error.
- If the error still exists:
 - Take the device out of operation.
 - Prevent renewed commissioning.

 WARNING
Loss of explosion protection Risk of explosion in hazardous areas if the device is open or not properly closed. <ul style="list-style-type: none">• Close the device as described in Technical specifications (Page 61).

 WARNING
Opening device in energized state Risk of explosion in hazardous areas <ul style="list-style-type: none">• Only open the device in a de-energized state.• Check prior to commissioning that the cover, cover locks, and cable inlets are assembled in accordance with the directives. Exception: Devices having the type of protection "Intrinsic safety Ex i" may also be opened in energized state in hazardous areas.

7.2 Initialize in "NO INIT" operating mode

If "NO INIT" appears in the display this means that the device is not initialized, Info ID (Page 50) [6C]. Commission the device by initializing it with "NO INIT".




Parameter assignment and addressing

8.1 Overview of the menu structure

Note

Parameter ID in the local display

The overview of the menu structure contains not only the menus and parameters but also the parameter IDs. These parameter IDs are added to the further explanations of the menus and parameters in []. Example "AUTO INIT" [01]



¹⁾ Visible if valve types have been stored at the factory.

²⁾ Visible with installed device option 1 with digital input (DI) and digital output (DO).

8.2 QUICK START [01]



	③	①	②	Meaning
	01	AUTO INIT	WIZ	Enables automatic initialization of the valve. The end positions are determined automatically.
	02	MANUAL INIT	WIZ	Provides a step-by-step procedure for manual initialization of the valve. Define the end positions manually.
	03	LEAKAGE TEST	WIZ	Enables the determination of the pneumatic leakage. The result is a stroke movement as a %/minute caused by leakage.
	04	SPEED TEST	WIZ	Speed test Enables the determination of travel times in seconds.
	05	OVERSHOOT	WIZ	Enables the determination of an overshoot as a % in relation to the total stroke. An overshoot of less than 3 % is displayed as "Ok".
1)	06	VALVE TYPE	WIZ	Sets the valve type. If "NONE" is displayed, no valve type is selected. When a valve type is selected, the positioner is adapted to this valve type.
2)	07	APPLICATION		Selection of the application profile
			AUTO	Enables the default setting, suitable for all applications.
			TIGHT	Activates a control of the valve moves with maximum actuating force in the end positions (close tight).
			FAST	Enables dynamic control of the valve, optimized to a fast control response.
			EXACT	Enables precise control of the valve.
			ONOFF	Enables an open/closed behavior of the valve. The valve moves to the end positions with maximum actuating force (close tight).
			BOOST	Enables control of the valve with pneumatic booster.
		SMALL	Enables control of a small valve with damped control response.	

WIZ = wizard

1) visible if valve types have been stored at the factory.

2) not visible if a valve type was selected for "VALVE TYPE" [06].

8.3 SETUP [02]

Setting the device parameters.



Factory-set parameter values are printed in bold in the table.

	③	①	②	Meaning	
01		DIGITAL IN		Digital input (DI)	
			MENU	Menu for setting the digital input (DI)	
	01	• BEHAVIOR DI		Behavior at digital input	
			NONE	Sets the digital input to inactive.	
			HOLD	Sets the digital input to keep the valve position.	
			BUTTN	Sets the digital input to button lock.	
			MSG	Enables the digital output.	
			GO CL	Moves to the valve position when digital input is activated, as set in parameter "CLOSE LIMIT" [05].	
			GO OL	Moves to the valve position when digital input is activated, as set in parameter "OPEN LIMIT" [07].	
	02	• POLARITY DI		Polarity of the digital input	
			HIGH	Normally Open: Normally open contact	
			LOW	Normally Close: Normally closed contact	
	02		DIGITAL OUT		Digital output (DO)
				MENU	Menu for setting the digital output (DO)
		01	• BEHAVIOR DO		Behavior at digital output
NONE				Sets the digital output to inactive.	
ERR				Enables the digital output in case of control deviation or device error.	
ERR M				Enables the digital output in case of manual operation, control deviation or device error.	
POS				Enables the digital output when the value of the "DO POS LIMIT" [03] parameter is reached.	
02		• POLARITY DO		Polarity of the digital output	
			HIGH	Normally Open: Normally open contact	
			LOW	Normally Close: Normally closed contact	
03		• DO POS LIMIT	0.0 ... 10.0 ... 100.0	Specifies the value as a percentage at which the digital output is enabled. Values < 50 correspond to a low limit value. Values ≥ 50 correspond to a high limit value.	
03		DIRECTION	AUTO	Sets the operating direction of the valve defined during initialization.	
	INVRT		Inverts the operating direction of the valve defined during initialization.		

8.4 MAINT/DIAGS [03]

	③	①	②	Meaning
*)	04	CLOSE TYPE	FAST	Sets the valve to precise behavior at endstop.
			TIGHT	Sets the valve to behavior with maximum actuating force at endstop.
			SLOW	Sets the valve to precise behavior at endstop.
			LIMIT	Limits the control range to the value set in the parameter "CLOSE LIMIT" [05].
*)	05	CLOSE LIMIT	0.0 ... 100.0	Sets the value in % up to which the valve closes.
*)	06	OPEN TYPE	FAST	Sets the valve to precise behavior at endstop.
			TIGHT	Sets the valve to behavior with maximum actuating force at endstop.
			SLOW	Sets the valve to precise behavior at endstop.
			LIMIT	Limits the control range to the value set in the parameter "OPEN LIMIT" [07].
*)	07	OPEN LIMIT	0.0 ... 100.0	Sets the value in % up to which the valve opens.
*)	08	DBAND LIMIT	0.1 ... 3.0	Sets the maximum range of the deadband in %.
*)	09	DBAND VALUE	x.x	Displays the current value of the deadband.
	10	LEAKAGE COMP	ON	Enables the leakage compensation.
			OFF	Disables the leakage compensation. The function is reset by disabling.
	11	MOUNTING	AUTO	Sets the positioner to mounting to standard actuator.
			LEVER	Sets the positioner to mounting on linear actuator, carrier pin mounted on lever.
STEM			Sets the positioner to mounting to linear actuator, carrier pin mounted on spindle.	
			TURN	Sets the positioner to mounting to part-turn actuator.

*) visible when "AUTO" is selected in "QUICK START [01] > APPLICATION [07]".

8.4 MAINT/DIAGS [03]

Service menu







③	①	②	Meaning	
01	SETPOINT	##.##	Displays the setpoint in mA. Status bar ① alternately displays the parameter name or the set unit.	
02	COUNTER	MENU		
	01	• OPERATE TIME	####	Displays the number of operating hours.
	02	• DIRECTN CHNG	####	Displays the number of direction changes.
	03	• STROKES	####	Displays the totalized distances. A distance corresponds to a sum of 200 %.
	04	• PILOT 1	####	Displays the number of switching cycles of pilot valve 1.
05	• PILOT 2	####	Displays the number of switching cycles of pilot valve 2.	
03	PEAK VALUES	MENU		
	01	• TIME OPEN	##.#	Displays the duration in seconds until the valve is open.
	02	• TIME CLOSE	##.#	Displays the duration in seconds until the valve is closed.
	03	• ELEC TMP MIN	##.##	Displays the lowest measured electronics temperature in °C.
04	• ELEC TMP MAX	##.##	Displays the highest measured electronics temperature in °C.	
04	RESET	FACT	Resets the device to the factory settings.	
05	FW VERSION	#####	Displays the FW version of the device.	
06	HW VERSION	#####	Displays the HW version of the device.	
07	REPLACE ELEC	WIZ	Provides a step-by-step procedure to synchronize new electronics. PIN LOCK is 2457.	

Troubleshooting

9.1 Device status symbols









The device status is displayed on the display with the help of symbols. Alarms are displayed on the display in the measurement view as symbol in the bottom line of the display. If multiple diagnostic states are pending at the same time, the symbol for the most critical status is displayed. The table below shows the possible causes for the device status and measures for the user or service. The order of the symbols in the table corresponds to the priority of the device status, starting with the most critical message.







Display symbols - NAMUR NE 107			Meaning
Symbol	Device status	Priority *	Priority *
	Failure	1	Cause: Output signal invalid due to fault in the field device or in the peripherals. Measure: Maintenance is required immediately.
	Function test	2	Cause: Output signal temporarily invalid (e.g. frozen) due to work being performed on the device. Measure: Manual mode over HMI or disable the engineering system.
	Out of specification	3	Cause: Deviations from permissible ambient or process conditions detected by the device (by means of self-monitoring or based on warnings/errors in the device) indicate that the measured value is unreliable or that deviations from the set value in the actuators are most likely greater than anticipated under normal operating conditions. Process or ambient conditions can damage the device or result in unreliable results.
	Maintenance required	4	Cause: The output signal is still valid but the wear reserve is coming to an end and/or functional restrictions will occur soon. Measure: Maintenance is recommended as soon as possible.

* The smallest number indicates the highest level of error severity.

9.2 Info IDs, error messages and corrective measures

The following table shows the IDs of diagnostic messages and possible causes and instructions for corrective actions.

Messages on the local display (Page 37)			Meaning / cause	Remedy
ID	Symbol	Status line		
6A		NO MOVEMENT	<ul style="list-style-type: none"> • Errors during initialization • Insufficient supply of compressed air • Mounting kit not correctly mounted. • Valve blocked 	Eliminate the cause. Start the initialization process.
6C		NO INIT + set-point as percentage	Positioner is not initialized	Press left button to start the initialization of the positioner.
6d		-	<ul style="list-style-type: none"> • Measuring range of position detection exceeded • Swivel area of the valve is larger than 110°. • Positioner installed on a different actuator without re-initialization. • End positions of valve are worn. 	Check the mounting kit and the wear. Start the initialization process.
6E		DI-HOLD + set-point as percentage	Maintain valve position is enabled through digital input (DI).	Configured response. If required, adjust setting in parameter "DIGITAL IN" [01].
6F		DI-GO CL + set-point as percentage	Approach valve position is enabled through digital input (DI).	Configured response. If required, adjust setting in parameter "CLOSE LIMIT" [05].
6H		DI-GO OL + set-point as percentage	Approach valve position is enabled through digital input (DI).	Configured response. If required, adjust setting in parameter "OPEN LIMIT" [07].
6L	-	-	Digital input (DI) is enabled. This status is reported via the digital output (DO). Setting in parameter "BEHAVIOR DI [01] > MSG"	Not necessary.
6N		SPAN TO HIGH	<ul style="list-style-type: none"> • Maximum angle span exceeded. • Effective lever arm is not adjusted to the actuator travel. • Mounting kit not correctly mounted. 	Position the carrier pin at a larger stroke value. Check the mounting kit. Use the electropneumatic positioner SIPART PS2 from Siemens with a swivel area of 185° (special design).
6P		SPAN TO LOW	<ul style="list-style-type: none"> • Minimum angle span underrun. • Effective lever arm is not adjusted to the actuator travel. • Mounting kit not correctly mounted. 	Position the carrier pin at a smaller stroke value. Check the mounting kit.

Messages on the local display (Page 37)			Meaning / cause	Remedy
ID	Symbol	Status line		
6r		-	A pneumatic leakage is present.	Remedy the pneumatic leakage of the actuator and the piping.
6t		-	<ul style="list-style-type: none"> • Control deviation • Insufficient supply of compressed air • Mounting kit not correctly mounted. • Valve blocked 	Eliminate the cause.
6U		MANUAL	Device in manual mode.	Use the left button to switch the positioner to the "AUTO" operation mode.
6Y		-	Wizard started	A wizard has been started. Wait until the wizard is completed.
L		-	Button lock is enabled. Digital input (DI) is enabled. Configured response. Setting in parameter "BEHAVIOR DI [01] > BUTTN"	Connect the digital input (DI).
LP		-	Parameters and device functions are write-protected with a user PIN.	Disable the write protection with user PIN LOCK 2457.

See also

QUICK START [01] (Page 44)

SETUP [02] (Page 45)

Service and maintenance

10.1 Basic safety notes

10.1.1 Maintenance

The device is maintenance-free. However, a periodic inspection according to pertinent directives and regulations must be carried out.

An inspection can include, for example, check of:

- Ambient conditions
- Seal integrity of the process connections, cable entries, and cover
- Reliability of power supply, lightning protection, and grounds

 WARNING
--

Dust layers above 5 mm

Risk of explosion in hazardous areas.

Device may overheat due to dust build up.

- | |
|---|
| <ul style="list-style-type: none">• Remove dust layers in excess of 5 mm. |
|---|

NOTICE

Penetration of moisture into the device
--


Damage to device.

- | |
|---|
| <ul style="list-style-type: none">• Make sure when carrying out cleaning and maintenance work that no moisture penetrates the inside of the device. |
|---|

10.2 Cleaning


Cleaning the enclosure


- Clean the outside of the enclosure with the inscriptions and the display window using a cloth moistened with water or a mild detergent.
- Do not use any aggressive cleansing agents or solvents, e.g. acetone. Plastic parts or the painted surface could be damaged. The inscriptions could become unreadable.


 WARNING
Electrostatic charge Risk of explosion in hazardous areas if electrostatic charges develop, for example, when cleaning plastic surfaces with a dry cloth. <ul style="list-style-type: none">• Prevent electrostatic charging in hazardous areas.

10.3 Maintenance and repair work

Send defective devices to the repairs department, together with information on the malfunction and the cause of the malfunction. When ordering replacement devices, please provide the serial number of the original device. You can find the serial number on the nameplate.

 WARNING
Impermissible repair of the device <ul style="list-style-type: none">• Repair must be carried out by Siemens authorized personnel only.

 WARNING
Maintenance during continued operation in a hazardous area There is a risk of explosion when carrying out repairs and maintenance on the device in a hazardous area. <ul style="list-style-type: none">• Isolate the device from power. - or - <ul style="list-style-type: none">• Ensure that the atmosphere is explosion-free (hot work permit).

 WARNING
Impermissible accessories and spare parts Risk of explosion in areas subject to explosion hazard. <ul style="list-style-type: none">• Only use original accessories or original spare parts.• Observe all relevant installation and safety instructions described in the instructions for the device or enclosed with the accessory or spare part.

 **WARNING****Improper connection after maintenance**

Risk of explosion in areas subject to explosion hazard.

- Connect the device correctly after maintenance.
- Close the device after maintenance work.

Refer to Electrical connection (Page 33).

10.4 Return procedure

Enclose the bill of lading, return document and decontamination certificate in a clear plastic pouch and attach it firmly to the outside of the packaging. Any devices/replacement parts which are returned without a decontamination declaration will be cleaned at your expense before further processing. For further details, refer to the operating instructions.

See also

Return document (<http://www.siemens.com/processinstrumentation/returngoodsnote>)

Decontamination declaration (<http://www.siemens.com/sc/declarationofdecontamination>)


10.5 Replacing electronics

 **WARNING****Use of incorrect module cover in hazardous areas**

Risk of explosion in hazardous areas. The metalized module cover, colored silver on the inside, **cannot** be used in hazardous areas.

- Only use the non-metalized, **transparent** module cover for positioners in hazardous areas.

Overview screen



- ① Module cover
- ② Fixing screws with large screw head
- ③ Electronics
- ④ Pneumatic block
- ⑤ Metal cover (only for device design with HART and Ex)
- ⑥ Fixing screws with small screw head
- ⑦ Bar

Figure 10-1 Replace electronics

Procedure

1. Loosen the 4 fixing screws of the enclosure lid. Remove the enclosure lid.
2. Disconnect the power supply cables or de-energize the cables.
3. Disconnect all other electrical connections of the device.
4. Remove the module cover ① by gripping the module cover at the bars ⑦ and lifting it over the terminals. The module cover detaches from the electronics.

5. Unscrew the 4 fixing screws ② and ⑥.
The following applies for the device version with HART and/or explosion protection: Remove the metal cover ⑤.
6. Remove the electronics.
7. Snap the new electronics ③ onto the 4 latches.
The following applies for the device version with HART and/or explosion protection: Place the metal cover on the device ⑤. Make sure that the metal cover is undamaged and not bent. The metal cover must be put on without force.
8. Screw in the 4 fixing screws ② and ⑥. Tighten the screws.
9. Place the module cover on the side opposite the terminals. Then press the module cover ① over the terminals. The module cover snaps in noticeably.
10. Connect the power supply cables. Supply the lines with voltage.
11. The following step is necessary in addition for linear actuators:
 - In the "MAINT/DIAGS" menu, select the parameter "07 REPLACE ELEC".
 - Configure the PIN "2457".
 - Use the two center buttons to move the lever of the mounting kit to the horizontal position.
 - Confirm the setting with the right-hand button. The display shows "COMPL".
12. Initialize the positioner as described in the section "Commissioning".
13. Put on the enclosure lid. Tighten the fixing screws of the enclosure lid.

See also

Commissioning (Page 39)

10.6 Replacing the pneumatic block

Procedure




Figure 10-2 Removing the pneumatic block


Removing

1. Switch off the supply pressure PZ and depressurize the actuator.
2. Remove the electronics as described in the section "Replacing electronics (Page 55)".
3. Unscrew the fixing screws ③ of the pneumatic block ②.
The single-acting pneumatic block has 4 screws and the double-acting pneumatic block has 5 screws.
4. Remove the pneumatic block ② and the cord seal ①.
5. Blow any dirt off the surface on which the pneumatic block was placed.

Installation

1. Insert the new cord seal ① into the new pneumatic block ②.
2. Press the cord seal ① evenly into the groove on the pneumatic block ②.
3. Place the new pneumatic block on the base plate.
Make sure that the pneumatic block engages with the centering elements ④ on the base plate.
4. Screw the supplied fixing screws ③ into the pneumatic block.
5. Tighten the fixing screws with a torque of 1.1 Nm.
6. Install the electronics as described in the section "Replacing electronics (Page 55)".
7. Switch on the supply pressure PZ.
8. Initialize the positioner using the "AUTO INIT (Page 44)" parameter in the QUICK START [01] menu.

10.7 Disposal



Devices described in this manual should be recycled. They may not be disposed of in the municipal waste disposal services according to the Directive 2012/19/EC on waste electronic and electrical equipment (WEEE).

Devices can be returned to the supplier within the EC and UK, or to a locally approved disposal service for eco-friendly recycling. Observe the specific regulations valid in your country.

Further information about devices containing batteries can be found at: Information on battery/product return (WEEE) (<https://support.industry.siemens.com/cs/document/109479891/>)

Technical specifications

11.1 Input

Analog input (AI), terminal 6 and 7	
Nominal signal range	4 ... 20 mA
Minimum current to maintain the operation	3.8 mA
Maximum load voltage 4 ... 20 mA	6.5 V corresponds to 325 Ω at 20 mA
Maximum load voltage HART	8.4 V corresponds to 420 Ω at 20 mA
Static destruction limit	\pm 40 mA
Type of communication	HART 7
Digital input (DI), terminals 9 and 10	
Galvanic isolation	Galvanically connected to analog input Galvanically isolated from the outputs
Signal status 0, floating contact open	> 300 k Ω
Signal status 1, floating contact closed	< 3 k Ω
Contact load	Can only be used for floating contact; Max. contact load < 20 μ A, 3 V

11.2 Output

Analog output (AO), terminals 61 and 62	
Wiring configuration	2-wire connection
Nominal signal range	4 ... 20 mA
Fault current	< 3.6 mA
Supply voltage U_H	12 ... 30 V
External load R_B [k Ω]	$\leq (U_H [V] - 12 V)/20 \text{ mA}$
Resolution in relation to the nominal signal range	0.05%
Maximum transmission error in relation to the nominal signal range	\pm 0.3%
Maximum effect of ambient temperature	\pm 0.1 %/10 K
Maximum residual ripple	\pm 0.5%
Galvanic isolation	Galvanically isolated from the other electrical inputs and outputs

11.3 Rated conditions

Digital output (DO), terminals 31 and 32	
Maximum supply voltage U_H	35 V
"Conductive" state	<ul style="list-style-type: none"> • Permissible rated current 50 mA • Maximum terminal voltage 3 V • Overload-proof
"Locked" state	$I < 60 \mu A$
"Locked" is also the status if the device is faulty or analog input (AI) is = 0 mA.	

11.3 Rated conditions

Rated conditions	
Ambient conditions for operation according to IEC 60068-2	For use indoors and outdoors.
<ul style="list-style-type: none"> • Ambient temperature 	-20 ... +80 °C (-4 ... +176 °F)
<ul style="list-style-type: none"> • Maximum permissible height above sea level 	Up to 2000 m
<ul style="list-style-type: none"> • Relative humidity 	0 ... 100%
Pollution degree according to IEC 61010-1	2
Overvoltage category according to IEC 61010-1	II
Enclosure degree of protection	
<ul style="list-style-type: none"> • In accordance with IEC 60529 	IP66
<ul style="list-style-type: none"> • In accordance with NEMA 250 	Type 4X
Corrosion protection according to EN ISO 9227 and EN ISO 12944	
<ul style="list-style-type: none"> • 6DR710 polycarbonate enclosure 	C5-M medium durability
<ul style="list-style-type: none"> • 6DR711 aluminum enclosure 	C5-M medium durability
Vibration resistance	
<ul style="list-style-type: none"> • Harmonic oscillations (sine) according to IEC 60068-2-6 	3.5 mm (0.14"), 2 ... 27 Hz, 3 cycles/axis 98.1 m/s ² (321.84 ft/s ²), 27 ... 300 Hz, 3 cycles/axis
<ul style="list-style-type: none"> • Bump (half-sine) according to IEC 60068-2-27 	150 m/s ² (492 ft/s ²), 6 ms, 1000 shocks/axis
<ul style="list-style-type: none"> • Noise (controlled digitally) according to IEC 60068-2-64 	10 ... 200 Hz; 1 (m/s ²) ² /Hz (3.28 (ft/s ²) ² /Hz) 200 ... 500 Hz; 0.3 (m/s ²) ² /Hz (0.98 (ft/s ²) ² /Hz) 4 hours/axis
Climate class	
<ul style="list-style-type: none"> • Storage 	1K23, -40 ... +80 °C (-40 ... +176 °F)
<ul style="list-style-type: none"> • Transport 	2K13, -40 ... +80 °C (-40 ... +176 °F)

11.4 Pneumatic data

Pneumatic data	
Pneumatic operating medium	Compressed air, carbon dioxide (CO ₂), nitrogen (N ₂), noble gases
• Operating pressure	1.4 ... 7 bar (20.3 ... 101.5 psi)
Quality class compressed air according to ISO 8573-1	
• Solid impurities	Class 3
• Pressure dew point	Min. 20 K (36 °F) below ambient temperature
• Oil content	Class 3
Flow rate	
• Aerate process drive	
Supply pressure 4 bar (58 psi)	7.1 Nm ³ /h (4.4 scfm)
Supply pressure 6 bar (87 psi)	9.8 Nm ³ /h (6.1 scfm)
• Depressurize process drive	
Actuating pressure 4 bar (58 psi)	13.7 Nm ³ /h (8.5 scfm)
Actuating pressure 6 bar (87 psi)	19.2 Nm ³ /h (12.0 scfm)
Leakage actuator chamber (positioner portion)	< 6·10 ⁻⁴ Nm ³ /h (3.7·10 ⁻⁴ scfm)
Typical auxiliary power consumption in the controlled state	0.01 Nm ³ /h (0.006 scfm)
Sound pressure level	L _{A eq} < 75 dB L _{A max} < 80 dB

11.5 Mechanical construction

Mechanical construction	
Supported actuator types	
• Linear actuator, range of stroke	10 to 130 mm (0.39 to 5.12")
• Part-turn actuator, angle-of-rotation range	10 to 100°
Weight, positioner without accessories	Approx. 1.0 kg (2.20 lb)
Material	
• Lid	• Aluminum • Polycarbonate
• Base plate	Aluminum
Torques	
• Lid fixing screws	1.5 Nm (1.1 ft lb)
• Part-turn actuator fixing screws DIN 933 M6x12-A2	5 Nm (3.7 ft lb)
• Linear actuator fixing screws DIN 933 M8x16-A2	12 Nm (8.9 ft lb)
• Gland pneumatic G ¹ / ₄	15 Nm (11.1 ft lb)
• Pneumatic gland 1/4-18 NPT	
Without sealant	12 Nm (8.9 ft lb)

11.6 Controller

Mechanical construction	
With sealant	6 Nm (4.4 ft lb)
• M20 cable gland, plastic	4 Nm (3 ft lb)
• M20 cable gland, metal	6 Nm (4.4 ft lb)
• Cable gland 1/2-14 NPT metal	15 Nm (11.1 ft lb)
• Cable gland for NPT bushing in the NPT adapter NOTE: To avoid damage to the device, the NPT adapter must be held in place while the NPT gland is screwed into the NPT adapter.	68 Nm (50 ft lb)
• Screw cap made of plastic	2.5 Nm (1.8 ft lb)
• Screw cap made of metal	4 Nm (3 ft lb)
• Pressure gauge block fixing screws	6 Nm (4.4 ft lb)
Pressure gauge	
• Material pressure gauge	Plastic, Mechanics brass
	Stainless steel, Mechanics brass nickel-plated
	Stainless steel, Mechanics stainless steel 316
• Material pressure gauge block	Anodised aluminium
	Stainless steel 316
• Degree of protection	
Plastic, Mechanics brass, Pressure gauge block anodised aluminium	IP31
Stainless steel, Mechanics brass nickel-plated, Pressure gauge block anodised aluminium	IP44
Stainless steel, Mechanics stainless steel 316, Pressure gauge block stainless steel 316	IP54
Connections, electrical	
• Screw terminals	2.5 mm ² AWG30-14
• Cable gland	M20x1.5 or 1/2-14 NPT with NPT adapter
Connections, pneumatic	
	G¼ or ¼-18 NPT

11.6 Controller

Controller	
Control unit	
• Five-point controller	Adaptive
• Deadband	
Adjustable peak value	± 0.1 to 3%, plus hysteresis (half of the deadband, but at least 0.2%)
Minimization of the peak value	Always active
Analog input (AI), terminal 6 and 7	
• Sampling interval	50 ms

Controller	
• Resolution	0.05%
Position detection	
• Sampling interval	10 ms
• Resolution at 10 mm stroke height	0.1%
• Effect of ambient temperature	0.1%/10 K

11.7 Explosion protection

You can find technical details on explosion protection in the SIPART PS100 compact operating instructions (A5E50188940) and the explosion protection certificates.

Dimension drawings




Figure 12-1 Dimension drawing, dimensions in mm (inch)

Product documentation and support

A.1 Product documentation

Process instrumentation product documentation is available in the following formats:

- Certificates (<http://www.siemens.com/processinstrumentation/certificates>)
- Downloads (firmware, EDDs, software) (<http://www.siemens.com/processinstrumentation/downloads>)
- Catalog and catalog sheets (<http://www.siemens.com/processinstrumentation/catalogs>)
- Manuals (<http://www.siemens.com/processinstrumentation/documentation>)
You have the option to show, open, save, or configure the manual.
 - "Display": Open the manual in HTML5 format
 - "Configure": Register and configure the documentation specific to your plant
 - "Download": Open or save the manual in PDF format
 - "Download as html5, only PC": Open or save the manual in the HTML5 view on your PC

You can also find manuals with the Mobile app at Industry Online Support (<https://support.industry.siemens.com/cs/ww/de/sc/2067>). Download the app to your mobile device and scan the device QR code.

Product documentation by serial number

Using the PIA Life Cycle Portal, you can access the serial number-specific product information including technical specifications, spare parts, calibration data, or factory certificates.

Entering a serial number

1. Open the PIA Life Cycle Portal (<https://www.pia-portal.automation.siemens.com>).
2. Select the desired language.
3. Enter the serial number of your device. The product documentation relevant for your device is displayed and can be downloaded.

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

Scanning a QR code

1. Scan the QR code on your device with a mobile device.
2. Click "PIA Portal".

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

A.2 Technical support

Technical support

If this documentation does not completely answer your technical questions, you can enter a Support Request (<http://www.siemens.com/automation/support-request>).

For help creating a support request, view this video here (www.siemens.com/opensr).

Additional information on our technical support can be found at Technical Support (<http://www.siemens.com/automation/csi/service>).

Service & support on the Internet

In addition to our technical support, Siemens offers comprehensive online services at Service & Support (<http://www.siemens.com/automation/serviceandsupport>).

Contact

If you have further questions about the device, contact your local Siemens representative at Personal Contact (<http://www.automation.siemens.com/partner>).

To find the contact for your product, go to "all products and branches" and select "Products & Services > Industrial automation > Process instrumentation".

Contact address for business unit:

Siemens AG
Digital Industries
Process Automation
Östliche Rheinbrückenstr. 50
76187 Karlsruhe, Germany


Bluetooth

B

B.1 Connecting SIPART PS100 with SITRANS AW050 Bluetooth adapter

NOTICE
Adherence to the degree of protection
If the SITRANS AW050 Bluetooth adapter is used with a field device, the lowest degree of protection in the overall system applies.


You need the mounting kit SITRANS AW050 (7MP3210-0AA01)





- A SITRANS AW050 Bluetooth adapter
- B Flat cable
- C M20-M20 adapter; not for cable gland 1/2-14 NPT

Procedure


1. Remove the lid from the positioner by unscrewing the 4 screws.
2. Remove the cable gland.
In the following, the cable gland is shown in blue as an example.
The tightening torques of the cable glands differ depending on the type. You can find the tightening torques in the Technical specifications (Page 61) section




3. Assemble the adapter (C) and the cable gland as follows:




4. Open the cable gland as follows:




5. Push in the SITRANS AW050 Bluetooth adapter as far as it will go into the cable gland.




6. Insert the plug of the flat cable into the socket of the SITRANS AW050 Bluetooth adapter. The socket is marked with a white label ①.




7. Guide the flat cable into the interior of the enclosure.



8. Insert the socket on the flat cable onto the service port.



9. Tighten the cable gland.



10. Place the lid on the positioner. Screw the lid in place.

B.2 Connecting a field device using the SITRANS mobile IQ app

SITRANS mobile IQ is an app for mobile devices that enables authorized service technicians to monitor and configure compatible field devices over a Bluetooth interface. You can find information and the app for download at: SITRANS mobile IQ in the app store (<https://support.industry.siemens.com/cs/ww/de/sc/2067>)

Requirements for establishing the first connection

1. Field device is in operation.
2. There is a line of sight to the field device.
3. You are less than 10 meters away from the field device.
4. LED on the SITRANS AW050 Bluetooth adapter flashes every 2 seconds.

Requirement for connection setup

1. Android: "Location" access is enabled in the mobile device.
2. SITRANS mobile IQ is authorized to access the location.

Procedure

NOTICE
Unauthorized access
It is your responsibility to prevent unauthorized access to the field device.

1. Start the SITRANS mobile IQ app.
The smartphone or tablet automatically searches for Bluetooth field devices in the vicinity. The field devices found are listed. Select the desired field device in the device list.
2. Enter the delivery password "**Sitrans AW050!**". The delivery password must be changed during the first connection setup.
3. Assign a new password.
 - Before assigning a password, make sure that no 2 field devices with the same serial number are displayed in the selection list.
 - Assign a new password that is not the same as the default password. The new password must consist of at least 12 (arbitrary) characters.
 - If the mobile end device, e.g. smartphone or tablet, has access protection, the SITRANS mobile IQ automatically saves the passwords of the connected field devices. You can delete individual, stored device passwords in the app.

When the connection is established, the LED on the SITRANS AW050 Bluetooth adapter blinks once a second.

B.3 Preset password

The delivery password set in the factory must be changed during the first connection setup.

The preset password is "Sitrans AW050!".

Please note that this password

- is used in the procedure used to connect the field device to SITRANS Mobile IQ
- The default value is the one used when resetting the password.

B.4 Reset Password

Procedure

1. Select "Reset password".
2. Once you have selected "Reset password", disconnect the ribbon cable between the SITRANS AW050 and the device within 60 seconds.
3. Wait for 30 seconds.
4. Insert the ribbon cable again.

The password is reset to the default password.

B.5 Technical specifications

B.5.1 SITRANS mobile IQ

Software requirements	
Required Android version	7.0 or higher
Required iOS version	12.0 or higher
Bluetooth	BLE 4.2 or higher

B.5.2 SITRANS AW050 Bluetooth adapter

Operating conditions and structural design	
Ambient conditions	For use indoors and outdoors.
Ambient temperature	Observe the maximum permissible ambient temperature for the field device.
<ul style="list-style-type: none"> Permissible ambient temperature for operation Relative humidity 	-40 ... +80 °C (-40 ... +176 °F) 0 ... 100%
Degree of pollution standard IEC 61010-1	2
Overvoltage category	II
Weight	60 g
Degree of protection	<ul style="list-style-type: none"> Type 4X, Type 6 according to NEMA IP66, IP68 according to IEC 60529
EMC	EN 61326
Input voltage range	2.2 ... 3.4 V DC
Maximum current consumption	2.5 mA
Material	Polycarbonate
Torque for cable gland	Corresponds to the specifications in the technical specifications in the section Mechanical construction (Page 63)
Communication, interface	BLE 4.2
Range	Class 2; approx. 10 m depending on mounting position
Radio approval	Europe: CE UK: UKCA USA: Contains FCC ID RYYEYSHJN Canada: Contains IC: 4389B-EYSHJN China: CMIIT ID: 2020DJ15120

See also

Information for radio approval FCC and IC (Page 77)

Certificates (<http://www.siemens.com/processinstrumentation/certificates>)

B.5.3 Information for radio approval FCC and IC

Canada Regulatory Information

1. This device complies with Industry Canada's applicable licence-exempt RSSs. Operation is subject to the following two conditions:
 - (1) This device may not cause interference; and
 - (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

 - (1) l'appareil ne doit pas produire de brouillage;
 - (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
2. This product is certified as type of the portable device with Industry Canada Rules. To maintain compliance with RF Exposure requirement, please use within specification of this product.

Ce produit est certifié comme type de l'appareil portable avec Industrie Règles de Canada. Pour maintenir l'acquiescement avec exigence Exposition de RF, veuillez utiliser dans spécification de ce produit. -IC: 4389B-EYSHJN
3. Please notify certified ID by either one of the following method on your product.

-Contains IC: 4389B-EYSHJN
Spécifiez ID certifiée dans votre produit par une de méthode suivante.
-Contains IC: 4389B-EYSHJN

FCC Regulatory Information

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Please notify certified ID by either one of the following methods on your product.

-Contains Transmitter Module FCC ID: RYYEYSHJN
-Contains FCC ID: RYYEYSHJN
3. CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. This product is certified as type of the portable device with FCC Rules. To maintain compliance with RF Exposure requirement, please use within specification of this product.
5. The antenna used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
6. This module can change the output power depending on the circumstances by the application software which is developed by module installer. Any end user cannot change the output power.

B.6 Dimension drawing SITRANS AW050 Bluetooth adapter




Figure B-1 Dimension drawing SITRANS AW050 Bluetooth adapter, dimensions in mm (inch)

Index

A

- Actuating pressure
 - Figure, 34
 - Position, 7
- Article number
 - on the nameplate, 12

B

- Bluetooth
 - Preset password, 75
- Bluetooth adapter
 - SITRANS AW050, 71
- Buttons
 - Position, 7

C

- Cable gland
 - Technical data, 64
- Carrier, 24
- Catalog
 - catalog sheets, 69
- Certificates, 15, 69
- Circuit diagram
 - Position, 7
- Cleaning, 53
- Compressed air, 19
- Conformity with UK directives, 16
- Connecting terminals, 7
- Connection
 - Pneumatic, 34
- Customer Support, (Refer to Technical support)

D

- Display
 - Position, 7
- Disposal, 59
- Documentation
 - Edition, 10
- Downloads, 69

E

- Exhaust air outlet
 - Position, 7
- Explosion protection, 65

F

- Freezing
 - Exhaust air outlet, 21

H

- Hazardous area
 - Laws and directives, 15
 - Laws and directives for Korea, 15
 - Qualified personnel, 17
- History, 10
- Hotline, (Refer to Support request)

I

- I/Os
 - Technical data, 64

L

- Laws and directives, 15

M

- Maintenance, 53
 - Device status symbols, 49
- Manuals, 69
- Material
 - Technical data, 63
- Material adapter
 - Technical specifications, 76
- Mechanical construction
 - Technical data, 63, 64
 - Technical specifications, 76
- Modifications
 - correct usage, 17
 - improper, 17

Mounting kit
Linear actuator, 21

O

Order code, 12
Ordering supplement, 12

P

Part-turn actuator
Mounting, 24
Password, 75
Reset, 75
Pneumatic block
Replacing, 58
Pressure gauge
Technical data, 64
Pressure gauge block
Torque, 64
Product name, 12

Q

Qualified personnel, 17

R

Return procedure, 55

S

Safety position, 34
Scope of delivery, 11
Service, 70
Service and support
Internet, 70
SITRANS AW050
Bluetooth adapter, 71
Sound absorber
Position, 7
Supply pressure
Position, 7
Support, 70
Support request, 70
Symbol
Device status, 49
Maintenance, 49
Operation mode, 49

T

Technical support, 70
partner, 70
personal contact, 70
Test certificates, 15
Tightening torque
Technical data, (Torque)
Torque, 63, 76

W

Warranty, 14
Weight
Technical data, 63