

# SIEMENS

## SINUMERIK




### SINUMERIK 808D ADVANCED

## Commissioning Manual

### Legal information

#### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.
 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.
 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.
<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

#### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

#### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

# Preface

## Applicable products

This manual is applicable to the following control systems:

Control system	Software version
SINUMERIK 808D ADVANCED T (Turning)	V4.6.2
SINUMERIK 808D ADVANCED M (Milling)	V4.6.2

## Documentation components and target groups

Document	Recommended target group
Programming and Operating Manual (Turning)	Programmers and operators of turning machines
Programming and Operating Manual (Milling)	Programmers and operators of milling machines
Programming and Operating Manual (ISO Turning/Milling)	Programmers and operators of turning/milling machines
Programming and Operating Manual (Manual Machine Plus (MM+), Turning)	Programmers and operators of turning machines
Diagnostics Manual	Mechanical and electrical designers, commissioning engineers, machine operators, and service and maintenance personnel
<b>Manufacturer/service documentation</b>	
Commissioning Manual	Installation personnel, commissioning engineers, and service and maintenance personnel
Function Manual	Mechanical and electrical designers, technical professionals
Parameter Manual	Mechanical and electrical designers, technical professionals
Service Manual	Mechanical and electrical designers, technical professionals, commissioning engineers, and service and maintenance personnel

## My Documentation Manager (MDM)

Under the following link you will find information to individually compile your documentation based on the Siemens content:

[www.siemens.com/mdm](http://www.siemens.com/mdm)

## Standard scope

This manual only describes the functionality of the standard version. Extensions or changes made by the machine tool manufacturer are documented by the machine tool manufacturer.

## Technical support

Country	Hotline <sup>1)</sup>	Further service contact information:
Germany	+49 911 895 7222	<ul style="list-style-type: none"><li>Global Web site: <a href="https://support.industry.siemens.com/sc/us/en/sc/list-of-countries/oid2044">https://support.industry.siemens.com/sc/us/en/sc/list-of-countries/oid2044</a></li><li>Chinese Web site: <a href="http://www.siemens.com.cn/808D">http://www.siemens.com.cn/808D</a></li></ul>
China	+86 400 810 4288	

<sup>1)</sup> You can find more hotline information at the global Web site given above.

## EC Declaration of Conformity

The EC Declaration of Conformity for the EMC Directive can be found on the Internet at <http://www.siemens.com/automation/service&support>.

Here, enter the number **67385845** as the search term or contact your local Siemens office.

# Table of contents

	<b>Preface.....</b>	<b>2</b>
<b>1</b>	<b>Safety instructions .....</b>	<b>7</b>
1.1	Fundamental safety instructions .....	7
1.1.1	General safety instructions .....	7
1.1.2	Handling electrostatic sensitive devices (ESD) .....	10
1.1.3	Industrial security .....	11
1.1.4	Residual risks of power drive systems.....	11
1.1.5	Residual risks during the operation of electric motors .....	12
1.2	Carrying out of repairs .....	13
<b>2</b>	<b>Scope of delivery .....</b>	<b>13</b>
2.1	System overview .....	13
2.2	PPU and MCP .....	16
2.3	Drives and motors .....	17
2.4	Cables .....	21
2.5	Options .....	22
<b>3</b>	<b>Mounting .....</b>	<b>25</b>
3.1	Mounting the PPU and MCP .....	26
3.2	Mounting the drive .....	31
3.2.1	Mounting orientation and clearance .....	31
3.2.2	Drill patterns and outline dimensions.....	32
3.2.3	Mounting the drive .....	33
3.2.4	Electrical cabinet design.....	34
3.2.4.1	Correct installation of fans .....	34
3.2.4.2	Correct installation of cooling units .....	35
3.3	Mounting the motor.....	35
3.3.1	Mounting orientation and outline dimensions .....	35
3.3.2	Mounting the motor.....	39
3.4	Notes on the laying of cables in drag chains .....	40
<b>4</b>	<b>Connecting .....</b>	<b>41</b>
4.1	Interfaces on the PPU and MCP .....	41
4.1.1	Digital input interfaces - X100, X101, X102 .....	43
4.1.2	Digital output interfaces - X200, X201 .....	44
4.1.3	Fast input/output - X21 .....	45
4.1.4	Distributed I/O - X301, X302.....	46
4.1.5	Handwheel inputs - X10 .....	49
4.1.6	Drive Bus interface - X126.....	50
4.1.7	Analog spindle interface - X54, spindle encoder interface - X60 .....	51
4.1.8	Ethernet interface - X130.....	53
4.1.9	RS232 interface - X2 .....	54
4.1.10	Power supply interface - X1 .....	55
4.1.11	USB interface on the front cover of the PPU .....	55
4.1.12	USB interface - X30.....	55
4.1.13	Slot for the system CF card .....	56
4.2	Interfaces on the SINAMICS V70 servo system .....	57
4.2.1	Main circuit wiring .....	59
4.2.1.1	Main circuit interfaces.....	59
4.2.1.2	Main circuit wiring .....	60
4.2.2	Connecting the 24 V power supply/STO - X6 .....	60
4.2.3	Connecting the holding brake - X7 .....	63
4.2.4	Connecting the encoder - X9.....	63
4.2.5	Connecting an external braking resistor - DCP, R1 .....	65

4.3	System connection overview.....	66
4.3.1	Connecting the CNC controller .....	66
4.3.2	Connecting the drive and motor .....	67
<b>5</b>	<b>Toolbox software.....</b>	<b>70</b>
5.1	Installing the software tools.....	70
5.2	Overview of PLC Programming Tool.....	73
<b>6</b>	<b>Initial commissioning .....</b>	<b>75</b>
6.1	Switching on the SINAMICS V70 drive .....	75
6.1.1	Jog test .....	75
6.1.2	Configuring Drive Bus addresses.....	78
6.2	Switching on the control system.....	79
6.3	Synchronizing drive data files between NC and drive .....	79
6.4	Setting the password.....	81
6.5	Setting the date and time .....	82
6.6	Activating the optional functions.....	83
6.7	Loading system languages .....	85
6.8	Overview on commissioning and operation wizards.....	86
<b>7</b>	<b>Commissioning the prototype machine.....</b>	<b>88</b>
7.1	Commissioning the PLC.....	88
7.1.1	Setting PLC related parameters .....	88
7.1.2	Downloading and commissioning PLC programs.....	90
7.1.3	Checking I/O address assignment .....	91
7.1.4	Editing PLC alarm texts.....	91
7.2	Configuring the drives .....	92
7.3	Setting basic parameters .....	94
7.3.1	Setting feed axis parameters .....	94
7.3.2	Commissioning the referencing function .....	95
7.3.3	Setting spindle parameters .....	97
7.4	Creating series archives.....	99
7.5	Setting compensation data.....	100
7.5.1	Setting software limit switch data .....	100
7.5.2	Setting backlash compensation data .....	101
7.5.3	Setting leadscrew error compensation data .....	102
7.6	Tuning drive performance .....	103
7.7	Creating prototype machine commissioning archives .....	105
<b>8</b>	<b>Series machine commissioning.....</b>	<b>106</b>
8.1	Loading series commissioning archives.....	106
8.2	Setting software limit switch data .....	107
8.3	Setting backlash compensation data .....	107
8.4	Setting leadscrew error compensation data .....	107
8.5	Tuning drive performance .....	107
8.6	Backing up series machine archives.....	107
<b>9</b>	<b>Other frequently used functions .....</b>	<b>108</b>
9.1	Playing a slide show.....	108
9.2	Defining the service planner.....	110
9.3	Using the machine manufacturer startup screen and machine logo .....	112
9.4	Creating user cycles.....	116
9.4.1	Creating the extended user text file.....	116



9.4.2	Creating the user cycle softkey index file .....	116
9.4.3	Creating the user cycle parameter file .....	117
9.4.4	Creating the user cycle file .....	118
9.4.5	Creating the user cycle alarm file .....	119
9.4.6	Creating the user cycle bitmap file .....	120
9.4.7	Transferring the desired files to the control system .....	120
9.4.8	Call the created user cycle .....	123
9.4.9	Editing the user cycle screens .....	124
9.5	Loading machine manufacturer's MD description files .....	124
9.6	Loading machine manufacturer's R variable name files .....	126
<b>10</b>	<b>Technical data .....</b>	<b>127</b>
10.1	SINUMERIK 808D ADVANCED .....	127
10.2	SINAMICS V70 servo drives .....	128
10.3	SIMOTICS S-1FL6 servo motors.....	130
10.4	Cables .....	134
10.4.1	Drive Bus cable/Drive Bus trailing cable for the SINUMERIK 808D ADVANCED .....	134
10.4.2	Technical data - cables for the SINAMICS V70 servo system.....	134
<b>A</b>	<b>Appendix .....</b>	<b>135</b>
A.1	Operation and display.....	135
A.1.1	Elements on the PPU .....	135
A.1.2	Elements on the MCP.....	136
A.1.3	Operating the SINAMICS V70 Basic Operator Panel (BOP) .....	138
A.1.3.1	BOP overview.....	138
A.1.3.2	Parameter structure.....	141
A.1.3.3	Actual status display.....	142
A.1.3.4	Basic operations.....	142
A.1.3.5	Auxiliary functions.....	144
A.1.4	Status indicators .....	148
A.2	Configuring the additional axis .....	150
A.2.1	Setting parameters for the additional axis (turning) .....	150
A.2.2	Setting parameters for the additional axis (milling) .....	151
A.2.3	Configuring the drive and motor .....	152
A.2.4	Tuning drive performance.....	153
A.3	Cutting reserved holes in the MCP .....	154
A.4	MCP strips.....	155
A.5	Parameter list .....	157
A.5.1	Recommended machine data.....	157
A.5.2	SINAMICS V70 parameters.....	161
A.6	Diagnostics.....	169
A.6.1	SINUMERIK 808D ADVANCED alarms .....	169
A.6.2	SINAMICS V70 faults and alarms .....	169
A.6.2.1	General information about faults and alarms .....	169
A.6.2.2	List of faults and alarms.....	170
A.7	PLC program design and adjustment.....	181
A.7.1	PLC Programming Tool.....	181
A.7.1.1	Renaming the default program .....	181
A.7.1.2	Changing the display language .....	182
A.7.1.3	Selecting a target system .....	183
A.7.1.4	Establishing a connection between the control system and the PC .....	184
A.7.1.5	Downloading/uploading/comparing PLC applications.....	191
A.7.1.6	Compiling and monitoring programs.....	200
A.7.2	PLC user interface.....	203
A.7.2.1	Signals from/to the MCP.....	205
A.7.2.2	Reading/Writing NC data.....	206
A.7.2.3	PI Service .....	207
A.7.2.4	Retentive data area .....	207
A.7.2.5	User Alarms.....	208
A.7.2.6	Signals from/to HMI .....	209

A.7.2.7	Auxiliary functions transfer from NC channel .....	213
A.7.2.8	NCK signals .....	215
A.7.2.9	Channel signals .....	218
A.7.2.10	Axis/spindle signals.....	223
A.7.2.11	PLC machine data.....	228
A.7.2.12	Signals, synchronized actions.....	229
A.7.2.13	Axis actual values and distance-to-go.....	230
A.7.2.14	Maintenance scheduler: User interface.....	230
A.7.2.15	User interface for ctrl energy.....	231
A.7.3	Operation symbols of PLC programming languages.....	233
A.7.4	PLC subroutine library.....	237
A.7.4.1	PLC machine data.....	240
A.7.4.2	Conventions for the symbols used in the subroutines.....	241
A.7.4.3	Subroutine 20 - AUX_MCP (machine auxiliary functions) .....	242
A.7.4.4	Subroutine 21 - AUX_LAMP (working lamp) .....	242
A.7.4.5	Subroutine 22 - AUX_SAFE_DOOR (safety door) .....	243
A.7.4.6	Subroutine 23 - AUX_CHIP (chip conveyor) .....	243
A.7.4.7	Subroutine 31 - PLC_ini_USR_ini (user initialization).....	244
A.7.4.8	Subroutine 32 - PLC_INI (PLC initialization) .....	244
A.7.4.9	Subroutine 33 - EMG_STOP.....	245
A.7.4.10	Subroutine 37 - MCP_NCK (MCP and HMI signal processing).....	246
A.7.4.11	Subroutine 38 - MCP_Tool_Nr (display tool number on the MCP) .....	248
A.7.4.12	Subroutine 39 - HANDWHL (selecting a handwheel according to HMI interface signals).....	248
A.7.4.13	Subroutine 40 - AXIS_CTL (controlling the spindle and axes) .....	249
A.7.4.14	Subroutine 41 - MINI_HHU (handwheel on hand-held unit) .....	251
A.7.4.15	Subroutine 42 - SPINDLE (spindle control).....	253
A.7.4.16	Subroutine 43 - MEAS_JOG (measurement in the JOG mode) .....	254
A.7.4.17	Subroutine 44 - COOLING (cooling control).....	255
A.7.4.18	Subroutine 45 - LUBRICAT (control of lubricate) .....	256
A.7.4.19	Subroutine 46 - PI_SERVICE.....	257
A.7.4.20	Subroutine 47 - PLC_Select_PP (PLC selects a subroutine) .....	258
A.7.4.21	Subroutine 48 - ServPlan (service planner) .....	259
A.7.4.22	Subroutine 49 - GearChg1_Auto (automatic spindle gear change).....	260
A.7.4.23	Subroutine 50 - GearChg2_Virtual (virtual spindle gear change) .....	261
A.7.4.24	Subroutine 51 - Turret1_HED_T (turret with Hall effect device position sensor) .....	262
A.7.4.25	Subroutine 52 - TURRET2_BIN_T (turret with binary coding function).....	264
A.7.4.26	Subroutine 53 - Turret3_CODE_T (tool change control for turret with coding function) .....	266
A.7.4.27	Subroutine 54 - Turret2_3_ToolDir (tool change direction).....	267
A.7.4.28	Subroutine 55 - Tail_stock_T (Tailstock control program for turning machines).....	268
A.7.4.29	Subroutine 56 - Lock_unlock_T (clamping control for turning machine).....	269
A.7.4.30	Subroutine 58 (MM_MAIN).....	270
A.7.4.31	Subroutine 59 (MM_MCP_808D) .....	273
A.7.4.32	Subroutine 60 - Disk_MGZ_M (disk-style tool magazine used for milling).....	273
A.7.4.33	Subroutines 34 to 36, 57, and 61 .....	275
A.7.4.34	Subroutine 62 - Trg_key_OR.....	275
A.7.4.35	Subroutine 63 - TOGGLES .....	277
A.7.5	PLC alarms .....	278
A.7.5.1	Alarm cancel/reset and reaction.....	280
A.7.5.2	Alarm texts .....	280
A.7.6	PLC sample applications.....	282
A.7.6.1	PLC sample application (turning) .....	282
A.7.6.2	PLC sample application (milling).....	284
A.8	AMM communication tool.....	287
A.8.1	Establishing an Ethernet connection.....	287
A.8.2	File management and transfer .....	290
A.8.3	Remote control.....	291
A.8.3.1	Operating the HMI via remote control .....	293
A.8.3.2	Saving the remote control screen as a picture .....	293

# 1 Safety instructions

## 1.1 Fundamental safety instructions

### 1.1.1 General safety instructions



#### **DANGER**

##### **Danger to life due to live parts and other energy sources**

Death or serious injury can result when live parts are touched.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Generally, six steps apply when establishing safety:

1. Prepare for shutdown and notify all those who will be affected by the procedure.
2. Disconnect the machine from the supply.
  - Switch off the machine.
  - Wait until the discharge time specified on the warning labels has elapsed.
  - Check that it really is in a no-voltage condition, from phase conductor to phase conductor and phase conductor to protective conductor.
  - Check whether the existing auxiliary supply circuits are de-energized.
  - Ensure that the motors cannot move.
3. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water.
4. Isolate or neutralize all hazardous energy sources by closing switches, grounding or short-circuiting or closing valves, for example.
5. Secure the energy sources against switching on again.
6. Ensure that the correct machine is completely interlocked.

After you have completed the work, restore the operational readiness in the inverse sequence.



#### **WARNING**

##### **Danger to life through a hazardous voltage when connecting an unsuitable power supply**

Touching live components can result in death or severe injury.

- Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV- (Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.



#### **WARNING**

##### **Danger to life when live parts are touched on damaged motors/devices**

Improper handling of motors/devices can damage them.

For damaged motors/devices, hazardous voltages can be present at the enclosure or at exposed components.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- Do not use any damaged motors/devices.



#### **WARNING**

##### **Danger to life through electric shock due to unconnected cable shields**

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

- As a minimum, connect cable shields and the cores of cables that are not used at one end at the grounded housing potential.



### **! WARNING**

#### **Danger to life due to electric shock when not grounded**

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

- Ground the device in compliance with the applicable regulations.



### **! WARNING**

#### **Danger to life due to electric shock when opening plug connections in operation**

When opening plug connections in operation, arcs can result in severe injury or death.

- Only open plug connections when the equipment is in a no-voltage state, unless it has been explicitly stated that they can be opened in operation.

### **! WARNING**

#### **Danger to life due to fire spreading if housing is inadequate**

Fire and smoke development can cause severe personal injury or material damage.

- Install devices without a protective housing in a metal control cabinet (or protect the device by another equivalent measure) in such a way that contact with fire is prevented.
- Ensure that smoke can only escape via controlled and monitored paths.

### **! WARNING**

#### **Danger to life through unexpected movement of machines when using mobile wireless devices or mobile phones**

Using mobile wireless devices or mobile phones with a transmit power > 1 W closer than approx. 2 m to the components may cause the devices to malfunction, influence the functional safety of machines therefore putting people at risk or causing material damage.

- Switch the wireless devices or mobile phones off in the immediate vicinity of the components.

### **! WARNING**

#### **Danger to life due to the motor catching fire in the event of insulation overload**

There is higher stress on the motor insulation through a ground fault in an IT system. If the insulation fails, it is possible that death or severe injury can occur as a result of smoke and fire.

- Use a monitoring device that signals an insulation fault.
- Correct the fault as quickly as possible so the motor insulation is not overloaded.

### **! WARNING**

#### **Danger to life due to fire if overheating occurs because of insufficient ventilation clearances**

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

- Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

### **! WARNING**

#### **Danger of an accident occurring due to missing or illegible warning labels**

Missing or illegible warning labels can result in accidents involving death or serious injury.

- Check that the warning labels are complete based on the documentation.
- Attach any missing warning labels to the components, in the national language if necessary.
- Replace illegible warning labels.

## NOTICE

### Device damage caused by incorrect voltage/insulation tests

Incorrect voltage/insulation tests can damage the device.

- Before carrying out a voltage/insulation check of the system/machine, disconnect the devices as all converters and motors have been subject to a high voltage test by the manufacturer, and therefore it is not necessary to perform an additional test within the system/machine.



## WARNING

### Danger to life when safety functions are inactive

Safety functions that are inactive or that have not been adjusted accordingly can cause operational faults on machines that could lead to serious injury or death.

- Observe the information in the appropriate product documentation before commissioning.
- Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.
- Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.
- Perform a function test.
- Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.

## Note

### Important safety notices for Safety Integrated functions

If you want to use Safety Integrated functions, you must observe the safety notices in the Safety Integrated manuals.



## WARNING

### Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).



## WARNING

### Danger to life from permanent magnet fields

Even when switched off, electric motors with permanent magnets represent a potential risk for persons with heart pacemakers or implants if they are close to converters/motors.

- If you are such a person (with heart pacemaker or implant) then keep a minimum distance of 2 m.
- When transporting or storing permanent magnet motors always use the original packing materials with the warning labels attached.
- Clearly mark the storage locations with the appropriate warning labels.
- IATA regulations must be observed when transported by air.



## WARNING

### Injury caused by moving parts or those that are flung out

Touching moving motor parts or drive output elements and loose motor parts that are flung out (e.g. feather keys) in operation can result in severe injury or death.

- Remove any loose parts or secure them so that they cannot be flung out.
- Do not touch any moving parts.
- Safeguard all moving parts using the appropriate safety guards.

### **WARNING**

#### **Danger to life due to fire if overheating occurs because of insufficient cooling**

Inadequate cooling can cause overheating resulting in death or severe injury as a result of smoke and fire. This can also result in increased failures and reduced service lives of motors.

- Comply with the specified coolant requirements for the motor.

### **WARNING**

#### **Danger to life due to fire as a result of overheating caused by incorrect operation**

When incorrectly operated and in the case of a fault, the motor can overheat resulting in fire and smoke. This can result in severe injury or death. Further, excessively high temperatures destroy motor components and result in increased failures as well as shorter service lives of motors.

- Operate the motor according to the relevant specifications.
- Only operate the motors in conjunction with effective temperature monitoring.
- Immediately switch off the motor if excessively high temperatures occur.



### **CAUTION**

#### **Risk of injury due to touching hot surfaces**

In operation, the motor can reach high temperatures, which can cause burns if touched.

- Mount the motor so that it is not accessible in operation.
- When maintenance is required, allow the motor to cool down before starting any work.
- Use the appropriate personnel protection equipment, e.g. gloves.



### **WARNING**

#### **Danger to life from electromagnetic fields**

Electromagnetic fields (EMF) are generated by the operation of electrical power equipment such as transformers, converters or motors.

People with pacemakers or implants are at a special risk in the immediate vicinity of these devices/systems.

- Ensure that the persons involved are the necessary distance away (minimum 2 m).

## 1.1.2 Handling electrostatic sensitive devices (ESD)

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



### **NOTICE**

#### **Damage through electric fields or electrostatic discharge**

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g. conductive foam rubber or aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
  - Wearing an ESD wrist strap
  - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

### 1.1.3 Industrial security

#### Note

##### Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (<http://www.siemens.com/industrialsecurity>).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (<http://support.automation.siemens.com>).



#### WARNING

##### Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.  
You will find relevant information and newsletters at this address (<http://support.automation.siemens.com>).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.  
You will find further information at this address (<http://www.siemens.com/industrialsecurity>).
- Make sure that you include all installed products into the holistic industrial security concept.

### 1.1.4 Residual risks of power drive systems

The control and drive components of a drive system are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety instructions on the components and in the associated technical user documentation.

When assessing the machine's risk in accordance with the respective local regulations (e.g., EC Machinery Directive), the machine manufacturer must take into account the following residual risks emanating from the control and drive components of a drive system:

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware and/or software errors in the sensors, control system, actuators, and cables and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Parameterization, programming, cabling, and installation errors
  - Use of wireless devices/mobile phones in the immediate vicinity of the control system
  - External influences/damage
2. In the event of a fault, exceptionally high temperatures, including an open fire, as well as emissions of light, noise, particles, gases, etc. can occur inside and outside the inverter, e.g.:
  - Component failure
  - Software errors
  - Operation and/or environmental conditions outside the specification
  - External influences/damage

Inverters of the Open Type/IP20 degree of protection must be installed in a metal control cabinet (or protected by another equivalent measure) such that contact with fire inside and outside the inverter is not possible.

3. Hazardous shock voltages caused by, for example,
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly

---

**Note**

The components must be protected against conductive contamination (e.g. by installing them in a control cabinet with degree of protection IP54 according to IEC 60529 or NEMA 12).

Assuming that conductive contamination at the installation site can definitely be excluded, a lower degree of cabinet protection may be permitted.

---

For more information about residual risks of the components in a drive system, see the relevant sections in the technical user documentation.

### 1.1.5 Residual risks during the operation of electric motors

The motors may be operated only when all protective equipment is used.

Motors may be handled only by qualified and instructed qualified personnel that knows and observes all safety instructions for the motors that are explained in the associated technical user documentation.

When assessing the machine's risk in accordance with the respective local regulations (e.g., EC Machinery Directive), the machine manufacturer must take into account the following residual risks emanating from the control and drive components of a drive system:

1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware and/or software errors in the sensors, control system, actuators, and cables and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Errors during the assembly, installation, programming and parameterization
  - Use of wireless devices/mobile phones in the immediate vicinity of the control system
  - External influences/damage
2. In case of failure, unusually high temperatures inside and outside the motor, including open fire as well as the emission of light, noise, particles, gases, etc. can result, for example in
  - Component failure
  - Software errors in converter operation
  - Operation and/or environmental conditions outside the specification
  - External influences/damage
3. Hazardous shock voltages caused by, for example,
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
5. Release of noxious substances and emissions in the case of improper operation and/or improper disposal of components



## 1.2 Carrying out of repairs



### Carrying out of repairs

Anywhere in the automation equipment where faults might cause physical injury or major material damage, in other words, where faults could be dangerous, additional external precautions must be taken, or facilities must be provided, that guarantee or enforce a safe operational state, even when there is a fault (e.g. using an independent limit value switch, mechanical locking mechanisms, EMERGENCY STOP/EMERGENCY OFF devices).

## 2 Scope of delivery

### 2.1 System overview

The SINUMERIK 808D ADVANCED control system is an economic numerical control system for milling or turning machines. The SINUMERIK 808D ADVANCED controller, coupled with the high performance SINAMICS V70 drive and the SIMOTICS S-1FL6 motor, is able to control up to five axes including one spindle.

#### Control system versions

- SINUMERIK 808D ADVANCED T (turning version)
  - The SINUMERIK 808D ADVANCED T control system is able to control up to two feed axes, two additional axes (software licenses required), and one spindle.
- SINUMERIK 808D ADVANCED M (milling version)
  - The SINUMERIK 808D ADVANCED M control system is able to control up to three feed axes, one additional axis (software licenses required), and one spindle.

#### Controller versions

Both the SINUMERIK 808D ADVANCED T and SINUMERIK 808D ADVANCED M controllers are available in the following versions:


- PPU161.2 (horizontal operator panel, English version)
- PPU161.2 (horizontal operator panel, Chinese version)
- PPU160.2 (vertical operator panel, English version)
- PPU160.2 (vertical operator panel, Chinese version)

Configurable MCPs are available in the following versions:

- Horizontal MCP (English version)
- Horizontal MCP (Chinese version)
- Vertical MCP with a reserved slot for the handwheel (English version)
- Vertical MCP with a reserved slot for the handwheel (Chinese version)
- Vertical MCP with an override switch for the spindle (English version)
- Vertical MCP with an override switch for the spindle (Chinese version)

## System configuration

The following configuration shows a typical example of the SINUMERIK 808D ADVANCED M controller with the SINAMICS V70 servo system. Note that the devices with an asterisk ("\*") are not included in the scope of delivery.



1), 2): For detailed information on cable shield connection, refer to Section "Analog spindle interface - X54, spindle encoder interface - X60 (Page 51)".

3): For detailed information on cable shield connection, refer to Section "Connecting the drive and motor (Page 67)".


## ⚠ CAUTION

### Personal injury and damage to property from inadequate protection


Inadequate protection may cause minor personal injury or damage to property.

- Using a copper protective earth conductor with a cross section of 10 mm<sup>2</sup> to connect the PE terminal of V70 to the protective earth. For the NC and 24 VDC power supply, there are no special requirements of the cross section of the copper protective earth conductor. For the inverter or servo spindle drive, it is recommended to refer to the relevant specifications to confirm the cross section of the copper protective earth conductor.
- Terminals for equipotential bondings that exist in addition to terminals for PE conductors must not be used for looping-through the PE conductors.
- To ensure protective separation, an isolating transformer must be used for the 380 VAC line supply system.

### Cabinet grounding guide







Note that the PE/PEN busbar in the cabinet must connect to the ground through a grounding cable with a cross section  $\geq 10 \text{ mm}^2$  as illustrated below.









## 2.2 PPU and MCP

### Components in the panel processing unit (PPU) package

Component	Quantity (pieces)	Illustration		Order number	
PPU (PPU161.2/PPU160.2)	1	Horizontal variant (PPU161.2)		Turning	6FC5370-2AT02-0AA0 (English) 6FC5370-2AT02-0CA0 (Chinese)
				Milling	6FC5370-2AM02-0AA0 (English) 6FC5370-2AM02-0CA0 (Chinese)
		Vertical variant (PPU160.2)		Turning	6FC5370-2BT02-0AA0 (English) 6FC5370-2BT02-0CA0 (Chinese)
				Milling	6FC5370-2BM02-0AA0 (English) 6FC5370-2BM02-0CA0 (Chinese)
Drive Bus terminator	1			6FC5548-0BA21-0AA0	
Mounting clamps with screws	<ul style="list-style-type: none"><li>PPU161.2: 8</li><li>PPU160.2: 10</li></ul>				
Connectors	<ul style="list-style-type: none"><li>I/O connectors: 7</li><li>24 V power input connector: 1</li></ul>				
User documentation	1	SINUMERIK 808D ADVANCED Operating and Programming - Turning (Chinese)			
		SINUMERIK 808D ADVANCED Operating and Programming - Milling (Chinese)			






### Components in the machine control panel (MCP) package

Component	Quantity (pieces)	Illustration		Order number
MCP	1	Horizontal MCP		6FC5303-0AF35-0AA0 (English) 6FC5303-0AF35-0CA0 (Chinese)
		Vertical MCP, with an override switch for the spindle		6FC5303-0AF35-2AA0 (English) 6FC5303-0AF35-2CA0 (Chinese)
				Vertical MCP, with a reserved slot for the handwheel
MCP connection cable	1 (for connecting the MCP to the PPU)			
Mounting clamps with screws	<ul style="list-style-type: none"><li>Horizontal MCP: 6</li><li>Vertical MCP: 8</li></ul>			

Component	Quantity (pieces)	Illustration	Order number
Pre-printed MCP strip, Milling	1		
Blank strip paper, A4 size	1		
User documentation	1	Product Information for the MCP	

## 2.3 Drives and motors

### Components in the drive package

Component	Quantity (pieces)	Illustration	Outline dimension (Width x Height x Depth, mm)	Frame size <sup>1)</sup>	Rated output current (A)	Order number
SINAMICS V70 drive	1		80 x 180 x 200	FSA	1.2	6SL3210-5DE12-4UA0
					3.0	6SL3210-5DE13-5UA0
			100 x 180 x 220	FSB	4.6	6SL3210-5DE16-0UA0
					5.3	6SL3210-5DE17-8UA0
					7.8	6SL3210-5DE21-0UA0
			140 x 260 x 240	FSC	11.0	6SL3210-5DE21-4UA0
Shielding plate	1	FSA:				
						
		FSB/FSC:				
						
Cable clamp (FSB and FSC only)	1					
Connectors	<ul style="list-style-type: none"> <li>FSA: 4</li> <li>FSB/FSC: 2</li> </ul>					
User documentation	1	Safety Instructions				

<sup>1)</sup> For more information about the different frame sizes, see Section "Drill patterns and outline dimensions (Page 32)".

## Drive rating plate

Drive name —

Mains input —

Motor output —

Rated motor power and IP protection class —

Order number —

Product serial number —

Part number —

SIEMENS

● SINAMICS V70

● INPUT: 3AC 380-480V 1.5A 50/60Hz

● OUTPUT: 3AC 0-inputV 1.2A 0-330Hz

● IP CLASS: IP20 MOTOR: 0.4kW

● 1P 6SL3210-5DE12-4UA0

● S ZVXXXXXXXXXX

● SNC-A5E03662004

FS: 01

Refer to user manual

KCC-REM-S49-SINAMICS

Made in China


Siemens Numerical Control Ltd.

No. 18 Siemens Rd, Jiangning Dev. Zone, Nanjing, 211100, P.R.C

## Explanation of drive order numbers


Data position of the order number	1	2	3	4	5	6	7		8	9	10	11	12		13	14	15	16
Order number	6	S	L	3	2	1	0	-	5	D	•	□	□	-	□	U	A	0
Mains voltage: 3 AC 380 V to 480 V											E							
Motor output power																		
0.4 kW												1	2		4			
0.75 kW/1 kW												1	3		5			
1.5 kW												1	6		0			
1.75 kW												1	7		8			
2 kW/2.5 kW												2	1		0			
3.5 kW												2	1		4			
5 kW/7 kW												2	1		8			

## Components in the motor package

Component	Illustration	Shaft height (mm)	Stall torque (Nm)	Order number <sup>1)</sup>
SIMOTICS S-1FL6 motor		45	1.9	1FL6042-1AF61-0□□1
			3.5	1FL6044-1AF61-0□□1
		65	4	1FL6061-1AC61-0□□1
			6	1FL6062-1AC61-0□□1
			8	1FL6064-1AC61-0□□1
			11	1FL6066-1AC61-0□□1
			15	1FL6067-1AC61-0□□1
		90	15	1FL6090-1AC61-0□□1
			22	1FL6092-1AC61-0□□1
			30	1FL6094-1AC61-0□□1
			40	1FL6096-1AC61-0□□1
User documentation	SIMOTICS S-1FL6 Servo Motors Installation Guide			

<sup>1)</sup> For more information about order numbers, see motor order number explanation described later in this section.

## Motor rating plate



- |                 |                               |                 |
|-----------------|-------------------------------|-----------------|
| ① Motor type    | ⑦ Rated power                 | ⑬ Rated current |
| ② Order number  | ⑧ Encoder type and resolution | ⑭ Holding brake |
| ③ Serial number | ⑨ Thermal class               | ⑮ Motor ID      |
| ④ Rated torque  | ⑩ Degree of protection        | ⑯ Weight        |
| ⑤ Stall torque  | ⑪ Motor operating mode        | ⑰ Maximum speed |
| ⑥ Rated voltage | ⑫ Stall current               | ⑱ Rated speed   |

## Explanation of motor order numbers

Data position of the order number	1	2	3	4	5	6	7		8	9	10	11	12		13	14	15	16
Order number	1	F	L	6	□	□	□	-	●	●	□	●	●	-	●	□	□	●
Shaft height																		
45 mm					0	4												
65 mm					0	6												
90 mm					0	9												
Stall torque																		
15 Nm, SH90							0											
4 Nm, SH65							1											
1.9 Nm, SH45; 6 Nm, SH65; 22 Nm, SH90							2											
3.5 Nm, SH45; 8 Nm, SH65; 30 Nm, SH90							4											
11 Nm, SH65; 40 Nm, SH90							6											
15 Nm, SH65							7											
High inertia variant								1										
Natural cooling									A									

<b>Rated speed</b>																		
2000 rpm										C								
3000 rpm										F								
<b>400 V supply voltage</b>											6							
<b>IM B5, flange mounting</b>												1						
<b>Straight connectors with a fixed outlet direction</b>														0				
<b>Encoder type</b>																		
Incremental encoder, 2500 ppr																A		
Absolute encoder, 20 bit single turn + 12 bit multi-turn																L		
<b>Mechanics</b>																		
Plain shaft, without brake																	G	
Plain shaft, with brake																	H	
Shaft with key, without brake																	A	
Shaft with key, with brake																	B	
<b>Protection level IP65, with a shaft oil seal</b>																		1







#### Device combination


The table below lists ordering data of drives and configurable motors. You can select the desired servo drive according to the motor configured:

SIMOTICS S-1FL6 servo motor				SINAMICS V70 servo drive	
Stall torque (Nm)	Rated speed (rpm)	Shaft height (mm)	Order number	Order number	Frame size
1.9	3,000	45	1FL6042-1AF61-0□□1	6SL3210-5DE12-4UA0	FSA
3.5			1FL6044-1AF61-0□□1	6SL3210-5DE13-5UA0	
4	2,000	65	1FL6061-1AC61-0□□1	6SL3210-5DE13-5UA0	FSB
6			1FL6062-1AC61-0□□1	6SL3210-5DE13-5UA0	
8			1FL6064-1AC61-0□□1	6SL3210-5DE16-0UA0	
11			1FL6066-1AC61-0□□1	6SL3210-5DE17-8UA0	
15			1FL6067-1AC61-0□□1	6SL3210-5DE21-0UA0	
15	2,000	90	1FL6090-1AC61-0□□1	6SL3210-5DE21-0UA0	FSC
22			1FL6092-1AC61-0□□1	6SL3210-5DE21-4UA0	
30			1FL6094-1AC61-0□□1	6SL3210-5DE21-8UA0	
40			1FL6096-1AC61-0□□1	6SL3210-5DE21-8UA0	



## 2.4 Cables

Component	Used for	Order number	Length (m)
<b>Drive Bus cable</b> 	PPU to SINAMICS V70 drive	6FC5548-0BA20-1AA2	0.25
		6FC5548-0BA20-1AA3	0.35
		6FC5548-0BA20-1AD0	3
		6FC5548-0BA20-1AF0	5
		6FC5548-0BA20-1AH0	7
		6FC5548-0BA20-1BA0	10
		6FC5548-0BA20-1BF0	15
		6FC5548-0BA20-1CA0	20
<b>Drive Bus trailing cable</b> 	PPU to SINAMICS V70 drive	6FC5548-0BA21-1AD0	3
		6FC5548-0BA21-1AF0	5
		6FC5548-0BA21-1AH0	7
		6FC5548-0BA21-1BA0	10
		6FC5548-0BA21-1BF0	15
		6FC5548-0BA21-1CA0	20
<b>Spindle setpoint cable</b> 	PPU (analog spindle interface) to Siemens inverter or third-party drive (with analog input)	6FC5548-0BA05-1AD0	3
		6FC5548-0BA05-1AE0	4
		6FC5548-0BA05-1AF0	5
		6FC5548-0BA05-1AH0	7
		6FC5548-0BA05-1BA0	10
		6FC5548-0BA05-1BF0	15
<b>MOTION-CONNECT 300 power cable</b> 	SINAMICS V70 FSA to motor	6FX3002-5CL01-1AD0	3
		6FX3002-5CL01-1AF0	5
		6FX3002-5CL01-1AH0	7
		6FX3002-5CL01-1BA0	10
		6FX3002-5CL01-1BF0	15
		6FX3002-5CL01-1CA0	20
	SINAMICS V70 FSB/FSC to motor	6FX3002-5CL11-1AD0	3
		6FX3002-5CL11-1AF0	5
		6FX3002-5CL11-1AH0	7
		6FX3002-5CL11-1BA0	10
		6FX3002-5CL11-1BF0	15
		6FX3002-5CL11-1CA0	20
<b>MOTION-CONNECT 300 brake cable</b> 	SINAMICS V70 to motor holding brake interface	6FX3002-5BL02-1AD0	3
		6FX3002-5BL02-1AF0	5
		6FX3002-5BL02-1AH0	7
		6FX3002-5BL02-1BA0	10
		6FX3002-5BL02-1BF0	15
		6FX3002-5BL02-1CA0	20
<b>MOTION-CONNECT 300 incremental encoder cable</b> 	SINAMICS V70 to incremental encoder interface of the motor	6FX3002-2CT10-1AD0	3
		6FX3002-2CT10-1AF0	5
		6FX3002-2CT10-1AH0	7
		6FX3002-2CT10-1BA0	10
		6FX3002-2CT10-1BF0	15
		6FX3002-2CT10-1CA0	20

Component	Used for	Order number	Length (m)
MOTION-CONNECT 300 absolute encoder cable 	SINAMICS V70 to absolute encoder interface of the motor	6FX3002-2DB10-1AD0	3
		6FX3002-2DB10-1AF0	5
		6FX3002-2DB10-1AH0	7
		6FX3002-2DB10-1BA0	10
		6FX3002-2DB10-1BF0	15
		6FX3002-2DB10-1CA0	20

#### Note

The MOTION-CONNECT 300 cable, spindle setpoint cable, and Drive Bus trailing cable given above are suitable for use in drag chains. For more information on how to lay cables properly in drag chains, see Section "Notes on the laying of cables in drag chains (Page 40)".

## 2.5 Options

### External 24 VDC power supply

A 24 VDC power supply is used to supply the 808D ADVANCED and V70 servo drive. Consider the following technical specification requirements when selecting a 24 VDC power supply:

- 24 VDC supplying the SINUMERIK 808D ADVANCED:
  - Rated input voltage: 24 V
  - Max. input voltage: 28.8 V
  - Min. input voltage without output derating: 20.4 V
  - Rated input current: 2.25 A
- 24 VDC supplying the SINAMICS V70 drive:

Without a holding brake		With a holding brake	
Rated voltage (V)	Maximum current (A)	Rated voltage (V)	Maximum current (A)
24 (-15% to +20%)	1	24 (-10% to +10%) <sup>1)</sup>	3

<sup>1)</sup> The minimum voltage of 24 VDC -10% must be available at the connector on the motor side in order to guarantee that the brake reliably opens. If the maximum voltage of 24 VDC +10% is exceeded, then the brake could re-close. The voltage drop along the brake feeder cable must be taken into consideration. The voltage drop  $\Delta U$  for copper cables can be approximately calculated as follows:

$$\Delta U [V] = 0.042 \cdot (l/q) \cdot I_{\text{Brake}}$$

Where:  $l$  = Cable length [m],  $q$  = Brake core cross section [mm<sup>2</sup>],  $I_{\text{Brake}}$  = DC current of brake [A]


### Fuse/circuit breaker

The fuse/circuit breaker is used to protect the control system. Refer to the table below for the selection of fuses and circuit breakers:

SINAMICS V70		Standard fuse		Circuit breaker
Frame size	Order number	Rated current (A)	Order number	Order number
FSA	6SL3210-5DE12-4UA0	6	3NA3 801-6	3RV 1021-1DA10
	6SL3210-5DE13-5UA0	10	3NA3 803-6	3RV 1021-1FA10
FSB	6SL3210-5DE16-0UA0	10	3NA3 803-6	3RV 1021-1JA10
	6SL3210-5DE17-8UA0	16	3NA3 805-6	3RV 1021-1JA10
	6SL3210-5DE21-0UA0	16	3NA3 805-6	3RV 1021-4AA10
FSC	6SL3210-5DE21-4UA0	20	3NA3 807-6	3RV 1021-4BA10
	6SL3210-5DE21-8UA0	25	3NA3 810-6	3RV 1021-4DA10

## Braking resistor


A braking resistor is used for the SINAMICS V70. When the internal braking resistor cannot meet the braking requirements, an external braking resistor can be used to "dump" the regenerative energy produced by the motor, thus giving greatly improved braking and deceleration capabilities. Select a standard braking resistor according to the table below:

Frame size	Illustration	Resistance ( $\Omega$ )	Max. power (kW)	Rated power (W)	Max. energy (kJ)
FSA		160	4	100	8
FSB		70	9.1	229	18.3
FSC		27	23.7	1185	189.6


## Filter

Siemens recommends you to use a filter to protect the system from high frequency noise.

The table below lists all the filters recommended by Siemens:

Frame size	Illustration	Rated current (A)	Protection class	Order number
FSA		5	IP20	6SL3203-0BE15-0VA0
FSB		12	IP20	6SL3203-0BE21-2VA0
FSC		20	IP20	6SL3203-0BE22-0VA0

## Outline dimensions



Rated current (A)	W	D	W2	H1	H	H2	W1	Ø1	Screw
5	55	130	38	158	170	145	8.5	5	M6
12	75	140	58	158	170	145	8.5	5	M6
20	60	130	40	240	250	220	10	5.5	M6

## Basic technical data


Rated current	5 A	12 A	20 A
Rated voltage	3-phase 380 VAC to 480 VAC (-15% to +10%)		
Line frequency	50/60 Hz (-10% to +10%)		
Product standard	IEC 61800-5-1		

## Insertion loss

Rated current	5 A						12 A						20 A					
Noise frequency (MHz)	0.1	0.5	1.0	5.0	10	30	0.1	0.5	1.0	5.0	10	30	0.1	0.5	1.0	5.0	10	30
CM (dB)	5						5						5					
DM (dB)	60	65	55	45	35	20	60	70	70	55	45	15	60	60	60	55	35	15
DM (dB)	50	60	55	50	50	40	60	65	60	50	45	30	40	55	55	50	45	30

## Connecting

The figure below provides a connection example. It shows how to connect a line filter to a SINAMICS V70 drive.



## SD card

An SD card can be used to copy drive parameters or perform a firmware update. You are recommended to use the Siemens SD card (order number: **6ES7954-8LB01-0AA0**).

You can also select other high quality SD cards with a maximum capacity of 2 GB from manufacturers such as KINGMAX, Kingston or SanDisk, which are not tested by Siemens.

## Toolbox DVD

Under the Toolbox DVD root directory, it contains a file setup.exe. After starting this file the program guides you installing the following software to the PC:

- SinuComPCIN
  - SinuComPCIN is a tool that allows the commissioning engineer to exchange files between the PC and the control through RS232 interface.
- Access MyMachine
  - Access MyMachine (AMM) is a tool that allows the commissioning engineer to exchange files between the PC and the control very easily through the Ethernet interface. For data transmission, the control can be connected to the PC directly or via the local network.
- PLC Programming Tool
  - PLC Programming Tool makes a connection between the programming tool and the control system. The commissioning engineer can program and debug the PLC inside the SINUMERIK 808D ADVANCED.
- Config DATA
  - Config\_DATA contains the configuration data setup. The setup will install the configuration data for SINUMERIK 808D ADVANCED to your PC. The configuration data consist of the Siemens examples, and the user documents.

---

### Note

For more information about the connection of the filter, fuse/circuit breaker, and braking resistor, see Section "Connecting the drive and motor (Page 67)".

---

### Note

#### Non-Siemens products

This document contains recommendations relating to non-Siemens products. The fundamental suitability of the non-Siemens products is familiar to us. It goes without saying that equivalent products from other manufacturers may be used. Our recommendations are to be seen as helpful information, not as requirements or dictates. We cannot accept any liability for the quality and properties/features of non-Siemens products.

---

## 3 Mounting



### DANGER

#### **Danger to life when live parts are touched**

Death or serious injury can result when live parts are touched.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Before installing or removing the components of the control system, make sure that the system is disconnected from the mains.



### DANGER

#### **Death or serious injury from fire or electric shock**

If the equipment operates in an area subject to inflammables or combustibles, water or corrosion hazards, it contains high risk of fire or electric shock.

The fire or electric shock may lead to death or serious injury.

Make sure that the control system is installed in a control cabinet with an adequate protection class.

---

### Note

When dimensioning the control cabinet, make sure that the installed components do not exceed the permissible surrounding air temperature, even if the outside temperature is high.


---

### 3.1 Mounting the PPU and MCP


#### Cut-out dimensions and mounting clearance (mm)

To make maintenance easy, keep sufficient clearance (recommended distance: 80 mm) between the maintenance door on the PPU and the cabinet wall. The recommended depth of the cabinet is greater than 155 mm.

#### Horizontal PPU and MCP



#### Vertical PPU and MCP



---

**Note**

Make sure there is enough space around the PPU and the MCP for tightening the screws in the control cabinet.

---

**Note**



All vertical MCP versions share the same requirements for cut-out dimensions and mounting clearance. The illustration above takes the MCP with a reserved slot for the handwheel for example.

---


**Note**

When mounting a horizontal PPU together with a vertical MCP or vice versa, follow the requirement for the clearance between a vertical PPU and a vertical MCP shown above.


---

**Outline dimensions (mm)****PPU161.2****PPU160.2**

## Horizontal MCP



## Vertical MCP (Example: MCP variant with an override switch for the spindle)



### Note

All vertical MCP versions have the same outline dimensions.




## Mounting the PPU and MCP with the companion clamps

Use the companion clamps (8 for PPU161.2, 10 for PPU160.2, 6 for the horizontal MCP, and 8 for the vertical MCP) to fix the PPU and MCP to the cabinet panel. You can find the mounting position marks (black triangles) on the back of the PPU and MCP. See the mounting illustration below:




The following figures show all mounting position marks on the back of the PPU and the MCP. They also show distances between a clamp and the edge of the PPU or MCP and between two holes of a clamp to make a hole for fixing the screw of a clamp.

### Horizontal PPU and MCP



## Vertical PPU and MCP



### Note

The clamp mounting position marks on the back of all vertical MCP versions are the same. The figure above takes the MCP version with a reserved slot for the handwheel for example.

## 3.2 Mounting the drive

### WARNING

#### Death or severe personal injury from harsh installation environment

A harsh installation environment will jeopardize personal safety and equipment. Therefore,

- Do not install the drive and the motor in an area subject to inflammables or combustibles, water or corrosion hazards.
- Do not install the drive and the motor in an area where it is likely to be exposed to constant vibrations or physical shocks.
- Do not keep the drive exposed to strong electro-magnetic interference.



### WARNING

#### Hot surface


During operation and for a short time after switching-off the drive, the surfaces of the drive can reach a high temperature. Avoid coming into direct contact with the drive surface.

### Note

For mounting conditions, see Section "Technical data -servo drives".


### 3.2.1 Mounting orientation and clearance

Mount the drive vertically to the back plate of a shielded cabinet (non-painted) and observe the mounting clearances specified in the illustration below:




### 3.2.2 Drill patterns and outline dimensions


Frame size A (unit: mm)



Frame size B (unit: mm)




Frame size C (unit: mm)



### 3.2.3 Mounting the drive

Tightening torque: max. 2.0 Nm



#### Note

##### EMC instructions

- To comply with the EMC standards, all cables connected with the SINAMICS V70 system must be shielded cables, which include cables from the line supply to the line filter and from the line filter to the SINAMICS V70 drive.
- The SINAMICS V70 drives have been tested in accordance with the emission requirements of the category of C2 (domestic) environment. The conducted emissions and radiated emissions are in compliance with the standard of EN 55011 and reached Class A.
- In a residential environment, this product can cause high-frequency interferences that may necessitate suppression measures.
- For a radiated emission test, an external AC filter (between the 380 VAC power supply and the drive) will be used to meet the EMC requirement and the drive will be installed inside the shielded metallic chamber, other parts of the motion control system (including the PLC, DC power supply, spindle drive, motor) will be put inside the shielded chamber.
- For a conductive emission test, an external AC filter (between the 380 VAC power supply and the drive) will be used to meet the EMC requirement.
- For the radiated emission and conductive emission test, the length of the line supply cable between the line filter and the drive must be shorter than 1 m.

---

**Note****Screw tightening**

Make sure you fix the screw to the terminal door of the drive after you have completed the installation work.

---

### 3.2.4 Electrical cabinet design

It may be preferable to always use cooling units as this allows the cabinet to be sealed which is the best option for stopping the entry of contaminants. Within the cabinets it may also be necessary to install fans to ensure the air is circulated and prevent "hot spots" from forming.

The technical specifications of the individual hardware component will provide details of the power loss measured in Watts.

Calculations are made to see if the cabinet can dissipate the heat naturally.

The cabinet manufacturer can supply details of the heat-loss of the cabinet.

Natural heat dissipation occurs through the cabinet walls providing the wall is in free air and not against a wall for example.


A general rule is that the energy dissipated is approximately 50 Watts/m<sup>2</sup> of free cabinet wall assuming a 10 °C temperature difference between the cabinet and the outside air.

#### 3.2.4.1 Correct installation of fans

For cabinets it is possible that the cooling can be achieved with fans drawing air from the outside via a filter. Natural convection causes the warm air to exit via a filter.

The fact that air is being drawn directly from the outside means that this system can never be airtight. Having a fan for the inlet side only ensures that the cabinet is positively pressurized which helps keep contaminants from entering.

It is extremely important that the filters are service regularly to avoid ingress of contaminants and to maintain the efficiency of the cooling process.




### 3.2.4.2 Correct installation of cooling units

The cool air should be directed to the bottom of the drive. The natural convection will draw the air through the drives.

The cool air from the cooling unit should not be directed straight onto/into the drives, it should be allowed to mix with the warmer air already in the cabinet, this will minimise the risk of condensation forming.

Cabinet top mounted cooling units require a method of directing the cool air from the cooling unit to the bottom of the drives.

In the case of a door mounted unit it may be necessary to direct the cool air with the use of a baffle.



## 3.3 Mounting the motor


### Note

For more information about the mounting conditions, see Section "Technical data - servo motors".

### 3.3.1 Mounting orientation and outline dimensions


#### Mounting orientation

The SIMOTICIS S-1FL6 motor supports flange mounting only and it can be used in the following three types of construction:



When configuring the IM V3 type of construction, pay particular attention to the permissible axial force (weight force of the drive elements) and the necessary degree of protection.

**Shaft height 45 mm, with incremental encoder (unit: mm)**


[illegible]

Stall torque	k	k1	a	b	b1
1.9 Nm	157	203.5	172	15	61.5
3.5 Nm	204	250.5	219		




[illegible]

**Shaft height 65 mm, with absolute encoder (unit: mm)**


37

Shaft height 90 mm, with incremental encoder (unit: mm)



Stall torque	k	k1	a	b	b1
15 Nm	189.5	255	210.5	33	98.5
22 Nm	211.5	281	236.5		
30 Nm	237.5	307	262.5		
40 Nm	289.5	359	314.5		

Shaft height 90 mm, with absolute encoder (unit: mm)



Stall torque	k	k1	a	b	b1
15 Nm	197	263	218	33	98.5
22 Nm	223	289	244		
30 Nm	249	315	270		
40 Nm	301	367	322		

### 3.3.2 Mounting the motor

#### WARNING

##### Personal injury and material damage

Some motors, especially the 1FL609□ are heavy. The excessive weight of the motor should be considered and any necessary assistance required for mounting should be sought.

Otherwise, the motor can fall down during mounting. This can result in serious personal injury or material damage.

#### NOTICE

##### Damage to the motor

If the liquid enters the motor, the motor may be damaged

During motor installation or operation, make sure that no liquid (water, oil, etc.) can penetrate into the motor. Besides, when installing the motor horizontally, make sure that the cable outlet faces downward to protect the motor from ingress of oil or water.

#### NOTICE

##### Damage to the encoder



Do not exert any shock at the shaft end; otherwise, the encoder may be damaged.


#### Note

##### Using the eyebolts

The 1FL609□ motor (90 mm shaft height) has two M8 screw holes for screwing in two eyebolts. Lift the 1FL609□ motor only at the eyebolts.

Eyebolts that have been screwed in must be either tightened or removed after mounting.

To ensure better heat dissipation, install a flange between the machine and the motor. You can install the motor onto the flange with four screws as shown in the following figure.



Motor	Screw	Recommended flange size (mm)	Tightening torque (Nm)	Flange material
1FL604□	4 x M6	270 x 270 x 10	8	Aluminum alloy
1FL606□	4 x M8	390 x 390 x 15	20	
1FL609□	4 x M12	420 x 420 x 20	85	


### 3.4 Notes on the laying of cables in drag chains

The MOTION-CONNECT cables between the drive and the motor, and setpoint cables and Drive Bus trailing cables between the drive and the controller satisfy requirements for use in drag chains.

Observe the following notes when laying these cables in drag chains:


#### Laying cables separately in the drag chain

- To ensure a long service life of the drag chain and cable, lay cables made of different materials separately with separating webs in the drag chain.
- Fill the webs evenly to ensure that the position of cables does not change during operation.
- Distribute cables as symmetrically as possible according to their weights and dimensions.
- Use webs to separate cables with different outer diameters.
- Keep cables untwisted in the drag chain.




#### Observing minimum bending radius requirements

- Cables must be able to move without constraint, especially in the bending radii of the chain.
- Observe the specified minimum bending radii.



#### Fixing cables

- Make sure that cables in the drag chain are unattached and movable.
- Place the cable fixture in a "dead" zone at each end, suitably far away from each end point of the moving parts.



## 4 Connecting

### NOTICE

#### Damage to the control system

The high-voltage components have strong interference on 24 VDC power supplies.

If the 24 VDC power supply is not isolated from high-voltage components, the control system may be damaged.

The 24 VDC protective extra-low voltage **must** be generated as a protective extra-low voltage with safe electrical isolation (according to IEC 204-1, Section 6.4, PELV), and grounded by with a PELV M signal connection to the central grounding point of the system.


### 4.1 Interfaces on the PPU and MCP

### NOTICE

#### Failing to connect PE terminals to the ground will cause safety problems

The PE terminals on the PPU and MCP must be connected to the ground; otherwise, it will cause safety problems and unexpected system conditions.

#### Interfaces on the PPU




Legend	Interface	Description
PPU back		
①	X100, X101, X102	Digital inputs
②	X200, X201	Digital outputs
③	X21	FAST I/O
④	X301, X302	Distributed I/O
⑤	X10	Handwheel inputs

⑥	X60	Spindle encoder interface
⑦	X54	Analog spindle interface
⑧	X2	RS232 interface
⑨	X130	Ethernet interface
⑩	X126	Drive Bus interface
⑪	X30	USB interface, for connection with the MCP
⑫	X1	Power supply interface, +24 VDC power supply
⑬	-	Slot for the system CompactFlash Card (CF card)
⑭	-	PE terminal, for connection with the ground

#### PPU front

⑮	-	USB interface
---	---	---------------

#### Interfaces on the MCP



Legend	Interface	Description
①	X10	USB interface, for connection with the PPU
②	-	PE terminal, for connection with the ground
③	-	Reserved hole for plastic tie which is used to fix the USB cable connecting the PPU with the MCP
④	-	Reserved hole for fixing the USB cable connecting the PPU and the MCP

#### Note

The two kinds of vertical MCP, with a reserved hole for the handwheel and with an override switch for the spindle, have the same mechanical interfaces design for the USB cable, PE terminal and reserved hole for fixing the USB cable on the back. The illustration above takes the version with a spindle override switch for example.

## 4.1.1 Digital input interfaces - X100, X101, X102


### Pin assignment

Type	Mini Combicon 10-pin		
Cable	Max. length: 10 m		
	Max. cross-section: 1.5 mm <sup>2</sup> (when using one cable per connection)		
Inputs	Permissible level (including ripple)		
	High level: 20.4 V to 28.8 V		Low level: -3 V to +5 V


Pin	X100 (DIN0)	X101 (DIN1)	X102	Remarks
1	N.C.	N.C.	N.C.	Not assigned
2	I0.0	I1.0	I2.0	Digital input
3	I0.1	I1.1	I2.1	Digital input
4	I0.2	I1.2	I2.2	Digital input
5	I0.3	I1.3	I2.3	Digital input
6	I0.4	I1.4	I2.4	Digital input
7	I0.5	I1.5	I2.5	Digital input
8	I0.6	I1.6	I2.6	Digital input
9	I0.7	I1.7	I2.7	Digital input
10	M	M	M	External ground

### Connecting according to the default PLC program

#### Turning



#### Milling



### Note

End sleeves are necessary if you use two cables per connection.

Fasten the cables to the screw terminals and plug the terminals into interfaces X100, X101 and X102 correctly.

## 4.1.2 Digital output interfaces - X200, X201


### Pin assignment

Type	Mini Combicon 10-pin
Cable	Max. length: 10 m
	Max. cross-section: 1.5 mm <sup>2</sup> (when using one cable per connection)
Outputs	Rated digital output current: 250 mA


Pin	X200 (DOUT0)	X201 (DOUT1)	Remarks
1	+24 V	+24 V	+24 V input (20.4 V to 28.8 V)
2	Q0.0	Q1.0	Digital output
3	Q0.1	Q1.1	Digital output
4	Q0.2	Q1.2	Digital output
5	Q0.3	Q1.3	Digital output
6	Q0.4	Q1.4	Digital output
7	Q0.5	Q1.5	Digital output
8	Q0.6	Q1.6	Digital output
9	Q0.7	Q1.7	Digital output
10	M	M	External ground

### Connecting according to the default PLC program

#### Turning



#### Milling



### Note

End sleeves are necessary if you use two cables per connection.


Fasten the cables to the screw terminals and plug the terminals into interfaces X200, X201 correctly.



### 4.1.3 Fast input/output - X21


#### Pin assignment

Type	Mini Combicon 10-pin		
Cable	Shielded cable		
	Max. length: 10 m		
	Max. cross-section: 1.5 mm <sup>2</sup> (when use one cable per connection)		
Inputs	Permissible level (including ripple)		
	High level: 20.4 V to 28.8 V	Low level: -3 V to +5 V	


Illustration	Pin	Signal	Comment
 <p>X21 FAST I/O</p>	1	+24 V	+24 V input (20.4 V to 28.8 V)
	2	NCRDY_1	NC ready signal contact 1
	3	NCRDY_2	NC ready signal contact 2
	4	DI1	Digital input, for connection to probe 1
	5	DI2	Digital input, for connection to probe 2
	6	BERO_SPINDLE or DI3	Spindle bero or digital input
	7	DO1	Fast output
	8	CW	Spindle rotating clockwise
	9	CCW	Spindle rotating counter-clockwise
	10	M	Ground

#### Connecting

You can connect the fast I/O to the inverter to control the spindle rotating direction (unipolar):



NC readiness is in the form of a relay contact (NO). It must be integrated into an EMERGENCY STOP circuit. The connection diagram is shown as follows:



1) When the NC is not ready, the contact is open; otherwise, the contact is closed.

## Connection cables

End sleeves are necessary if you use two cables per connection.

Fasten the cables to the screw terminals and plug the terminal into the interface X21.

You can buy the shielded cables from a third-party manufacturer.


### Note


To ensure optimum interference immunity, use only the shielded cable to connect the FAST I/O terminals (X21).

## 4.1.4 Distributed I/O - X301, X302

### Pin assignment

Type	50-pin socket
Inputs	Permissible level (including ripple) High level: 20.4 V to 28.8 V Low level: -3 V to +5 V
Outputs	Rated digital output current: 250 mA

Pin	Signal	Comment	Pin	Signal	Comment
 X301 DISTRIBUTED I/O 1					
1	M	External ground	26	I5.7	Digital input
2	+24 V	+24 V output <sup>1)</sup>	27	-	Not assigned
3	I3.0	Digital input	28	-	Not assigned
4	I3.1	Digital input	29	-	Not assigned
5	I3.2	Digital input	30	-	Not assigned
6	I3.3	Digital input	31	Q2.0	Digital output
7	I3.4	Digital input	32	Q2.1	Digital output
8	I3.5	Digital input	33	Q2.2	Digital output
9	I3.6	Digital input	34	Q2.3	Digital output
10	I3.7	Digital input	35	Q2.4	Digital output
11	I4.0	Digital input	36	Q2.5	Digital output
12	I4.1	Digital input	37	Q2.6	Digital output
13	I4.2	Digital input	38	Q2.7	Digital output
14	I4.3	Digital input	39	Q3.0	Digital output
15	I4.4	Digital input	40	Q3.1	Digital output
16	I4.5	Digital input	41	Q3.2	Digital output
17	I4.6	Digital input	42	Q3.3	Digital output
18	I4.7	Digital input	43	Q3.4	Digital output
19	I5.0	Digital input	44	Q3.5	Digital output
20	I5.1	Digital input	45	Q3.6	Digital output
21	I5.2	Digital input	46	Q3.7	Digital output
22	I5.3	Digital input	47	+24 V	+24 V input
23	I5.4	Digital input	48	+24 V	+24 V input
24	I5.5	Digital input	49	+24 V	+24 V input
25	I5.6	Digital input	50	+24 V	+24 V input

Pin	Signal	Comment	Pin	Signal	Comment
					
X302 DISTRIBUTED I/O 2					
1	M	External ground	26	I8.7	Digital input
2	+24 V	+24 V output <sup>1)</sup>	27	-	Not assigned
3	I6.0	Digital input	28	-	Not assigned
4	I6.1	Digital input	29	-	Not assigned
5	I6.2	Digital input	30	-	Not assigned
6	I6.3	Digital input	31	Q4.0	Digital output
7	I6.4	Digital input	32	Q4.1	Digital output
8	I6.5	Digital input	33	Q4.2	Digital output
9	I6.6	Digital input	34	Q4.3	Digital output
10	I6.7	Digital input	35	Q4.4	Digital output
11	I7.0	Digital input	36	Q4.5	Digital output
12	I7.1	Digital input	37	Q4.6	Digital output
13	I7.2	Digital input	38	Q4.7	Digital output
14	I7.3	Digital input	39	Q5.0	Digital output
15	I7.4	Digital input	40	Q5.1	Digital output
16	I7.5	Digital input	41	Q5.2	Digital output
17	I7.6	Digital input	42	Q5.3	Digital output
18	I7.7	Digital input	43	Q5.4	Digital output
19	I8.0	Digital input	44	Q5.5	Digital output
20	I8.1	Digital input	45	Q5.6	Digital output
21	I8.2	Digital input	46	Q5.7	Digital output
22	I8.3	Digital input	47	+24 V	+24 V input
23	I8.4	Digital input	48	+24 V	+24 V input
24	I8.5	Digital input	49	+24 V	+24 V input
25	I8.6	Digital input	50	+24 V	+24 V input

<sup>1)</sup> Make sure that the current at pin 2 of X301 or X302 does not exceed the maximum current  $I_{out} = 0.25 \text{ A}$ ; otherwise, the controller could be damaged.

## Connecting

### DANGER

The 24 V power supply must be protective extra-low voltage in accordance with EN60204-1, Section 6.4, PELV (with M ground).

### CAUTION

Be sure not to connect the pin 2 of X301/302 to ground; otherwise, the CNC controller of the power supply could be damaged!

## Note

The 24 V output of X301/302 pin 2 comes from pins 47 to 50.

---

**Note****Addressing ranges**

X301: IB3, IB4, IB5, QB2, QB3

X302: IB6, IB7, IB8, QB4, QB5

---


**Note**

The connecting cable between the power source, load current supply connection, and associated reference potential M must **not** exceed the maximum permissible length of 10 m.

---

**Digital inputs**

The diagram below shows you how to connect the connector pins of the digital inputs at interface X301 (example). You can connect connector X302 in the same way.



---


**Note**

When using an external power supply, you must connect the 24 V (permissible range: 20.4 V to 28.8 V) power supply for the digital outputs to **all the four power input pins** (X301, X302: pins 47, 48, 49, 50).

---


**Digital outputs**

The diagram below shows you how to connect the connector pins of the digital outputs at interface X301 (example). You can connect connector X302 in the same way.



To supply the digital outputs, you must connect an external 24 VDC power supply (X301, X302: pins 47, 48, 49, 50).

You must also connect the reference ground of the external power supply to X301, X302: Pin 1 (M).

 <b>CAUTION</b> You must ensure that the max. current consumption at pin 47, pin 48, pin 49 or pin 50 does <b>not</b> exceed 1 A.
---

#### Note


You must connect the 24 V power supply for the digital outputs to **all the four power input pins** (X301, X302: **pins 47, 48, 49, 50**).

#### External power supply

When using an external power supply for the digital inputs, you must connect the reference ground to X301, X302: Pin 1 (M).

#### Connecting according to the default PLC program


The control system has integrated with a default PLC application. If you perform the commissioning work with the default PLC application, arrange wiring as follows.



### 4.1.5 Handwheel inputs - X10


#### Pin assignment

Type Mini Combicon 10-pin  
Cable Max. length: 3 m

Illustration	Pin	Signal	Comment
 X10 HAND WHEEL	1	1A	Track A, handwheel 1
	2	-1A	Negative Track A, handwheel 1
	3	1B	Track B, handwheel 1
	4	-1B	Negative Track B, handwheel 1
	5	+5 V	+5 V power output
	6	M	Ground
	7	2A	Track A, handwheel 2
	8	-2A	Negative Track A, handwheel 2
	9	2B	Track B, handwheel 2
	10	-2B	Negative Track B, handwheel 2

## Connecting

You are allowed to connect at most two electronic handwheels at connector X10 on the PPU.



The handwheels must meet the following requirements:

Transmission procedure

5 V square wave signals (TTL level or RS422)

Signals

Track A as a true and negative signal ( $U_{a1}U_{a1}$ )

Track B as a true and negative signal ( $U_{a2}U_{a2}$ )

Max. input frequency

500 kHz

Phase shift between Track A to Track B

$90^\circ \pm 30^\circ$

Supply

5 V, max. 250 mA


## 4.1.6 Drive Bus interface - X126

### Pin assignment

Type IEEE 1394, 6-pin, female



Cable Type: Drive Bus cable/Drive Bus trailing cable

Max. length: 20 m


Illustration	Pin	Signal	Comment
 X126 Drive BUS	1	PB_N	Negative RxD/TxD of Drive Bus
	2	1P5	+5 V
	3	PB	Positive RxD/TxD of Drive Bus
	4	NULL	Not connected
	5	PB_RTS	Request to send
	6	1M5	Ground

## Connecting

### Drive Bus interfaces on the SINAMICS V70 - X10, X11

Illustration	Pin No.	Signal	Description
 X11  X10	1	A	Differential signal A
	2	P5PB	+ 5 V
	3	B	Differential signal B
	4	NC	Not assigned
	5	RTS	Request to send
	6	MPB	0 V

## Connecting example



### Note


You must install the Drive Bus terminator (that ships with the PPU) on X11 of the last servo drive; otherwise, the servo system cannot work properly.

## 4.1.7 Analog spindle interface - X54, spindle encoder interface - X60

Interface X54 is for connecting the PPU to the inverter or servo spindle drive. Interface X60 is for connecting the PPU to the spindle encoder.


### Pin assignment - X54

Type Sub-D, 9-pin, female  
Cable Max. length: 10 m

Illustration	Pin	Signal	Comment
 X54 SPINDLE	1	AO	Analog voltage
	2	-	not assigned
	3	-	not assigned
	4	-	not assigned
	5	SE1	Analog drive enable (contact: electrically isolated n.o. contact)
	6	SE2	Analog drive enable (contact: electrically isolated n.o. contact)
	7	-	not assigned
	8	-	not assigned
	9	AGND	Ground


## Pin assignment - X60

Type Sub-D, 15-pin, female  
 Cable Type: encoder cable  
 Max. length: 10 m

Illustration	Pin	Signal	Comment
 X60 SP ENCODER	1	-	Not assigned
	2	-	Not assigned
	3	-	Not assigned
	4	+5 V	+5 V power supply
	5	-	Not assigned
	6	+5 V	+5 V power supply
	7	M	Ground
	8	-	Not assigned
	9	M	Ground
	10	Z	Zero mark
	11	Z_N	Zero mark, negative
	12	B_N	Track B, negative
	13	B	Track B
	14	A_N	Track A, negative
	15	A	Track A

## Connecting


### Connecting the inverter or servo spindle drive (unipolar)



- 1) 10 V analog voltage
- 2) 0 V signal
- 3) Use twisted pair cables for signals A/A\_N, B/B\_N, Z/Z\_N, and +5 V/M.



### Connecting the inverter or servo spindle drive (bipolar)




- 1) +/- 10 V analog voltage  
 2) 0 V signal  
 3) Use twisted pair cables for signals A/A\_N, B/B\_N, Z/Z\_N, and +5 V/M.

## 4.1.8 Ethernet interface - X130

### Pin assignment

Type 8-pin RJ45 socket  
 Cable Type: Ethernet cable

Illustration	Pin	Signal	Comment
 X130 ETHERNET	1	MX1+	Data 1
	2	MX1-	Data 1
	3	MX2+	Data 2
	4	MX3+	Data 3
	5	MX3-	Data 3
	6	MX2-	Data 2
	7	MX4+	Data 4
	8	MX4-	Data 4

### Note


The length of the Ethernet cable must be less than 30 m or the communication will be unstable.

## 4.1.9 RS232 interface - X2

You can connect a PC to the PPU version 161.2/160.2 via an RS232 port to establish communication between the PC and the control system.

### Pin assignment

Type Sub-D, 9-pin, male  
Cable Type: RS232  
Max. length: 10 m

Illustration	Pin	Signal name	Signal type	Comment
 <p>X2 RS232</p>	1	-	-	Not assigned
	2	RxD	I	Receive data
	3	TxD	O	Transmit data
	4	DTR	O	Data terminal ready
	5	M	VO	Ground
	6	DSR	I	Request set ready
	7	RTS	O	Request to send
	8	CTS	I	Clear to send
	9	-	-	Not assigned

PPU (9-pin Sub-D)		PC (9-pin Sub-D)	
2	RxD	2	RxD
3	TxD	3	TxD
4	DTR	4	DTR
5	M	5	M
6	DSR	6	DSR
7	RTS	7	RTS
8	CTS	8	CTS
	Shielding		Shielding

PPU (9-pin Sub-D)		PC (25-pin Sub-D) Field PG P3 (6ES7710-xx....)	
2	RxD	2	TxD
3	TxD	3	RxD
4	DTR	20	DTR
5	M	7	M
6	DSR	6	DSR
7	RTS	4	RTS
8	CTS	5	CTS
	Shielding		Shielding

### Note



Use only shielded twisted pair cables; You must connect the cable shield to the metal or metalized connector casing of the control system.

#### 4.1.10 Power supply interface - X1

The PPU uses a 24 VDC power supply. You can connect the 24 VDC power supply via interface X1. For more information about the 24 VDC power supply, see Section "Options (Page 22)".

##### Pin assignment


Type Combicon 4-pin  
Cable Max. length: 10 m

Illustration	Pin1	Signal	Name	Comment
	1	0 V	M24	0 V
	2	24 V	P24	+24 V
	3	0 V	M24	0 V
	4	24 V	P24	+24 V
 <p><b>Note:</b> The 0 V terminals as well as the 24 V terminals are internally connected in parallel. This means that you can connect the 24 V power supply to either of the terminal pairs.</p>				

#### 4.1.11 USB interface on the front cover of the PPU

##### Pin assignment

Type USB socket, type A  
Cable Type: USB 1.1 cable  
Max. length: 3 m


Illustration	Pin	Signal name	Signal type	Comment
	1	P5_USB0	VO	5 V power supply
	2	DM_USB0	I/O	USB data-
	3	DP_USB0	I/O	USB data+
	4	M	VO	Ground

#### 4.1.12 USB interface - X30

There is a USB interface on the back of the PPU. This USB interface is used for connecting with the MCP.


##### Pin assignment

Type USB socket, type A Combicon 4-pin  
Cable Type: USB cable (0.5 m)

Illustration	Pin	Signal name	Signal type	Comment
 <p>X30 MCP</p>	1	P5_USB0	VO	5 V power supply
	2	DM_USB0	I/O	USB data-
	3	DP_USB0	I/O	USB data+
	4	M	VO	Ground


## Connecting

The illustration below shows the connection between the PPU and the MCP with the MCP connection cable.



### 4.1.13 Slot for the system CF card

The system CF card is installed on the PPU at the factory.



---

#### Note


The maintenance door is accessible only by the Siemens service personnel.  
Do not touch or remove the system CF card under any conditions.

---


## 4.2 Interfaces on the SINAMICS V70 servo system

The SINAMICS V70 servo system, consisting of the SINAMICS V70 servo drive and SIMOTICS S-1FL6 servo motor, is an economical closed-loop servo drive solution for machine tool applications. It is designed to be used with the SINUMERIK 808D ADVANCED controller. The SINAMICS V70 is available in three frame sizes (FS) including FSA, FSB, and FSC.

### Interfaces on the SINAMICS V70 FSA (with detachable terminal blocks)




## Interfaces on the SINAMICS V70 FSB/FSC (with screw terminals)



### Note

For more information about the connection of the X10 and X11, see Section "Drive Bus interface - X126 (Page 50)".




## Interfaces on the SIMOTICS S-1FL6 motor



## 4.2.1 Main circuit wiring

### 4.2.1.1 Main circuit interfaces


#### Main circuit interfaces (drive side)

Type	Illustration	Signal	Description
Line supply input interface	<div>FSB, FSC <sup>1)</sup>:</div>  <div>FSA <sup>2)</sup>:</div> 	Line phase L1 Line phase L2 Line phase L3	3 phase 380 VAC to 480 VAC
Motor power interface		Motor phase U Motor phase V Motor phase W	Connects to the SIMOTICS S-1FL6 motor
Internal/external braking resistor interface		Digitally controlled potentiometer (DCP) Resistor 2 (R2) Resistor 1 (R1)	DCP is connected to R2 at the factory
Grounding connector		-	For connecting the power supply grounding connector and the servo motor grounding connector
Maximum cable cross-section: 2.5 mm <sup>2</sup>			

1) The screw type for FSB and FSC is M4 and the recommended tightening torque is 2.25 Nm.


2) The screw type for FSA is M2.5 and the recommended tightening torque is 0.4 Nm to 0.5 Nm.

#### Main circuit interface (motor side)

Type	Illustration	Signal	Description
Power connector		1: U	Phase U
		2: V	Phase V
		3: W	Phase W
		4: PE	Protective earthing

### 4.2.1.2 Main circuit wiring

Wiring diagram for SINAMICS V70 main circuit (example):



#### Note

For more information about the wiring of the external braking resistor, see Section "Connecting an external braking resistor - DCP, R1 (Page 65)".

#### Note

##### Filter

A line filter is required so that the system can pass the CE certification (radiated emission test or conducted emission test).


##### Circuit breaker

You can install a circuit breaker to protect the system.

For more information about the order number of Siemens recommended filters and circuit breakers, see Section "Options (Page 22)".

### 4.2.2 Connecting the 24 V power supply/STO - X6

#### Control circuit interfaces - drive side

Type	Illustration
Safe Torque Off (STO) interfaces	
Control power input interfaces <sup>1)</sup>	
Maximum connectable cross-section: 1.5 mm <sup>2</sup>	

<sup>1)</sup> Maximum current consumption values without a brake power supply and with a brake power supply are respectively 1 A and 3 A.

For more information about the 24 VDC power supply, see Section "Options (Page 22)".



## Wiring

### WARNING

#### Material damages and personal injuries by the drop of a hanging axis

When the servo system is used as a hanging axis, the axis will drop if the positive and negative poles of the 24 V power supply are connected inversely. Unexpected drop of the hanging axis may cause material damages and personal injuries. Make sure that the 24 V power supply is correctly connected.

### WARNING

#### Material damages and personal injuries by the drop of a hanging axis

It is not allowed to use the STO with a hanging axis because the axis may drop. Unexpected drop of the hanging axis may cause material damages and personal injuries.


## Note

### Using the STO function


The STO1, STO+ and STO2 are short-circuited at the factory.

When the STO function is to be used, you must remove the short-circuit stick before connecting the STO interfaces. The safety function of the servo drive is SIL 2 (EN61800-5-2). If you do not need to use it any more, you must reinsert the short-circuit stick. Otherwise, the motor will not run.

The wiring for factory setting and using the STO function is shown as follows:



If you use the STO function with the SINUMERIK 808D ADVANCED control system, perform the wiring as illustrated below:



### STO function

In conjunction with a machine function or in the event of a fault, the "Safe Torque Off" (STO) function is used to safely disconnect the torque-generating energy feed to the motor.

When the function is selected, the drive unit is in a "safe status". The switching on inhibited function prevents the drive unit from being restarted.

The two-channel pulse suppression function integrated in the module is a basis for this function.

#### Functional features of "Safe Torque Off"

- This function is integrated in the drive; this means that a higher-level controller is not required.
- The function is drive-specific, i.e. it is available for each drive and must be individually commissioned.
- When the "Safe Torque Off" function is selected, the following applies:
  - The motor cannot be started accidentally.
  - The pulse suppression safely disconnects the torque-generating energy feed to the motor.
  - The power unit and motor are not electrically isolated.
- By selecting/deselecting STO, in addition to the fault messages, the safety messages are also automatically withdrawn.

The STO function can be used wherever the drive naturally reaches a standstill due to load torque or friction in a sufficiently short time or when "coasting down" of the drive will not have any relevance for safety.

---

#### Note

##### Closing delay of the holding brake

The closing signal (low level) of the holding brake is output 30 ms after the STO is triggered.

---

#### Preconditions for using the STO function

When use the STO function, the following preconditions should be fulfilled:

- Each monitoring channel (STO1 and STO2) triggers safe pulse suppression with its switch off signal path.
- If a motor holding brake is connected and configured, the connected brake is not safe because there is no safety function for brake, such as safe brake.


## Behaviors of the STO function

Terminal		State	Action
STO1	STO2		
High level	High level	Safe	The servo motor can normally run when you power on the servo drive.
Low level	Low level	Safe	The servo drive starts up normally but the servo motor cannot run.
High level	Low level	Unsafe	Alarm occurs and servo motor coasts down.
Low level	High level	Unsafe	Alarm occurs and servo motor coasts down.


For more information about the STO function, see the SINUMERIK 808D ADVANCED Function Manual.

## 4.2.3 Connecting the holding brake - X7


### Holding brake (drive side)

Type	Illustration	Signal	Description
Brake interfaces		Phase B+	B+: + 24 V, motor brake voltage positive
		Phase B-	B-: 0 V, motor brake voltage negative
Maximum cable cross-section: 1.5 mm <sup>2</sup> Input voltage tolerance: 24 V ± 10%			

### Holding brake (motor side)

Type	Illustration	Signal	Description
Brake connector		1: B+	Phase Brake +
		2: B-	Phase Brake -

### Wiring



## 4.2.4 Connecting the encoder - X9


The SINAMICS V70 servo drive supports two types of encoders:

- Incremental encoder
- Absolute encoder

<b>NOTICE</b>
<b>Cable shielding</b> The encoder cable must be shielded to meet the EMC requirements.

## Encoder connector - drive side

14-pin socket connector, incremental/absolute encoder feedback interface X9


Illustration	Pin No.	Signal	Description
	1	Biss_DataP	Absolute encoder data signal, positive
	2	Biss_DataN	Absolute encoder data signal, negative
	3	Biss_ClockN	Absolute encoder clock signal, negative
	4	Biss_ClockP	Absolute encoder clock signal, positive
	5	P5V	Encoder power supply, +5V
	6	P5V	Encoder power supply, +5V
	7	M	Encoder power supply, grounding
	8	M	Encoder power supply, grounding
	9	Rp	Encoder R phase positive signal
	10	Rn	Encoder R phase negative signal
	11	Bn	Encoder B phase negative signal
	12	Bp	Encoder B phase positive signal
	13	An	Encoder A phase negative signal
	14	Ap	Encoder A phase positive signal

### Note

The screw type is UNC 4-40 (plug-in terminal block) and the recommended tightening torque is 0.5 Nm to 0.6 Nm.


## Encoder connector - motor side

8-pin connector, incremental encoder and absolute encoder


Illustration	Pin No.	Incremental encoder		Absolute encoder	
		Signal	Description	Signal	Description
	1	P_Supply	Power supply 5 V	P_Supply	Power supply 5 V
	2	M	Power supply 0 V	M	Power supply 0 V
	3	A+	Phase A+	n. c.	Not connected
	4	A-	Phase A-	Clock_N	Inverted clock
	5	B+	Phase B+	Data_P	Data
	6	B-	Phase B-	Clock_P	Clock
	7	R+	Phase R+	n. c.	Not connected
	8	R-	Phase R-	Data_N	Inverted data

## Wiring

### Incremental encoder




### Absolute encoder



### Shielded encoder cable grounding

When making an encoder cable, you should strip the outer insulation sheath for a maximum distance of 3 cm and connect the cable shield to ground, as shown in the following figure:



### 4.2.5 Connecting an external braking resistor - DCP, R1

The SINAMICS V70 has been designed with an internal braking resistor to absorb regenerative energy from the motor. When the internal braking resistor cannot meet the braking requirements, you can connect an external braking resistor. For more information about the selection of braking resistors, see Section "Options (Page 22)".


#### Connecting an external braking resistor

##### NOTICE

##### Damage to the drive


Before connecting an external resistor to DCP and R1, remove the connection between terminals DCP and R2; otherwise, the drive may be damaged.

Connect the external braking resistor as follows:



## 4.3 System connection overview

### 4.3.1 Connecting the CNC controller




\* For the SINUMERIK 808D ADVANCED T control system, connecting to the third and fourth drives is optional and depends upon whether you activate the software option "additional axis". If you desire to configure the control system to control an additional linear axis, connect the additional axis to the third or fourth SINAMICS V70 which connects to a servo motor. For the SINUMERIK 808D ADVANCED M control system, connecting to the fourth drive is optional and depends upon whether you activate the software option "additional axis". If you desire to configure the control system to control an additional linear axis, connect the additional axis to the fourth SINAMICS V70 which connects to a servo motor.

## 4.3.2 Connecting the drive and motor

### Connection overview

The connection illustration below shows you a system connection example where the SINUMERIK 808D ADVANCED controls one drive.



### Note

- The line supply cable, Drive Bus cable/Drive Bus trailing cable, power cable, and encoder cable are shielded.
- The part of the line supply cable between the line filter and the drive must be shielded and shorter than 1 m.
- The maximum length for all cables must be shorter than 30 m.
- For more information about the connection of the external braking resistor, see Section "Connecting an external braking resistor - DCP, R1 (Page 65)".
- For more information about the connection of the STO terminals, see Section "Connecting the 24 V power supply/STO - X6 (Page 60)".



## ⚠ WARNING

### Personal injury and damage to property from improper connections

Improper connections have high risks of electrical shock and short circuit, which will jeopardize personal safety and equipment.


- The drive must be directly connected with the motor. It is not permissible to connect a capacitor, inductor or filter between them.
- The line supply voltage must be within the allowable range (refer to the drive rating plate). Never connect the line supply cable to the motor terminals U, V, W or connect the motor power cable to the line input terminals L1, L2, L3.
- Never wire up the U, V, W terminals in an interchanged phase sequence.
- If the CE marking for cables is mandatory in some cases, the motor power cable, line supply cable and brake cable used must all be shielded cables.
- For terminal box connection, make sure that the clearances between non-insulated live parts are at least 5.5 mm.
- Route signal cables and power cables separately in different cable conduits. The signal cables shall be at least 10 cm away from the power cables.
- Cables connected may not come into contact with rotating mechanical parts.

### Connecting the cable shields with the shielding plate


To achieve EMC-compliant installation of the drive, use the shielding plate that is shipped with the drive to connect the cable shields. See the following example for steps to connect cable shields with the shielding plate:

- ① Mount the shielding plate with two M4 screws.

- ② Connect the line supply cable, the power cable and the brake cable.



- ③ Fix the cables.







### **! WARNING**

#### **Danger to life due to fire or electric shock when using unsuitable residual current protection devices**

The drive can cause a current to flow in the protective conductor.

This current can cause the residual current device (RCD) or residual current monitoring (RCM) to incorrectly trip (nuisance trip).

In the case of a fault (ground fault), the fault current can contain a DC component, which prevents the RCD/RCM from tripping, with the risk of subsequent fault or electric shock.

Use only the type B RCD in the supply system for the SINAMICS V70 drive.



### **! DANGER**


#### **Death or severe personal injury from electrical shock**

The earth leakage current for the drive can be greater than AC 3.5 mA, which may cause death or severe personal injury due to electrical shock.

A fixed earth connection is required to eliminate the dangerous leakage current. In addition, the minimum size of the protective earth conductor shall comply with the local safety regulations for high leakage current equipment.

### **Adjusting cable orientations from the motor side**

From the motor side, you can adjust the orientation of the power cable, encoder cable, and brake cable to facilitate cable connection.



### **Note**

#### **Rotating the connectors**

All the three motor-side connectors can be rotated only within 360°.

## 5 Toolbox software

### 5.1 Installing the software tools

#### Software components

In order to integrate the control system into a machine tool, software tools are required. These tools, including service tools are supplied on a DVD. The DVD is called the Toolbox DVD and is provided at delivery.

The following software tools are included on the Toolbox DVD:

Software	Description	See-also
AccessMyMachine (AMM)	AMM is a multifunctional tool used for data transfer, service, commissioning tasks and remote control.	AMM communication tool (Page 287)
PLC Programming Tool	The tool provides a user-friendly environment for commissioning the PLC. With this tool, you can develop, edit, and observe the logic to control your applications.	PLC Programming Tool (Page 181)
SinuComPCIN	SinuComPCIN is a tool that allows you to transfer data between the PC and the control system through RS232 interface.	For more information, see Section "Executing/transferring a part program through the RS232 interface" in the SINUMERIK 808D ADVANCED Programming and Operating Manual (Turning)/(Milling).
Config DATA	Config DATA contains some PLC example files including default PLC programs for turning/milling machines.	-

#### Supported operating systems


The software tools above support the following operating systems:

- Windows Vista (both 32-bit and 64-bit versions)
- Windows 7 (both 32-bit and 64-bit versions)


#### Installing the software

To install the software on your PC, proceed through the following steps:


1. Double-click the "Setup.exe" in the folder.




2. Read the welcome information and continue with "Next".




3. You can click the "Readme" button to read the indication information then close it and continue with "Next" or you can skip the reading and click "Next" directly.




4. Accept the software license agreement and continue with "Next".



5. Select desired languages you want to install.



6. If you have installed an earlier version of a program, un-install the program first, then start the installation again and select the required software from the list.



7. During the installation, various dialog boxes will appear. Acknowledge the dialog boxes and enter and confirm the installation information where necessary. Installing all the software packages will take approximately 30 minutes. When the installation finishes, shortcuts will be created on the desktop.

## 5.2 Overview of PLC Programming Tool


In order to edit the PLC program, use PLC Programming Tool V3.2.4 or higher.

By using PLC Programming Tool, you can perform the following operations:


- Creating the PLC program
- Editing the PLC program
- Making a connection between the programming tool and the system
- Compiling the PLC program
- Downloading the PLC program
- Uploading the PLC program
- Monitoring the PLC

### PLC instructions


Various instructions are available in PLC Programming Tool. You can view them in the instruction branch of the instruction tree.



You can right-click an instruction or directly press the F1 key to view its help information.



The address of each instruction can be edited at any time by highlighting the instruction.



## Data management

The data can be broken down into three areas:

- Non-retentive data
- Retentive data
- Machine data for the PLC (all active at POWER ON)

Most data, such as the process image, timer, and counter, is non-retentive and cleared each time the control system is restarted.

For the retentive data, there is a data range of 1400 0000 to 1400 0127. This location can be used to save all the data which is to remain valid after POWER OFF/ON.

With the aid of the PLC machine data (see the user interface), you can pre-assign your program with data or parameterize various parts of the program.

## Program organization

During the PLC programming, you must structure your program into finished program parts (subroutines). The programming language for the S7-200 offers you the capability to set up your user program in a structured manner.

There are the following two types of programs:

- Main program
- Subroutine

Eight levels of programming are possible.

## 6 Initial commissioning

### NOTICE

#### Plugging or unplugging the SD card will cause startup failure.

Do not plug or unplug the SD card during startup; otherwise, the drive will fail to start up.

### NOTICE

#### Firmware damage due to drive power-off during data transfer

Switching off the 24 VDC power supply for the drive during data transfer from the SD card to the drive can cause damage to the drive firmware.

- Do not switch off the drive power supply when the data transfer from the SD card to the drive is in process.

### NOTICE

#### Existing setting data may be overwritten by the setting data on the SD card during startup.

- When a drive is switched on with an SD card containing user setting data, the existing setting data on the drive will be overwritten.
- When a drive is switched on with an SD card containing no user setting data, the drive will automatically save the existing user setting data onto the SD card.

Before starting up the drive with an SD card, check whether the SD card contains user setting data. Otherwise, the existing data on the drive may be overwritten.

### Note

- Make sure that all cables are correctly connected and the connected servo system is in good condition with no faults before switching on.
- Prior to commissioning or operation, read carefully "Safety instructions (Page 7)" and "Operating the SINAMICS V70 Basic Operator Panel (BOP) (Page 138)".
- See Chapters "Diagnostics (Page 169)" and "Parameter list (Page 157)" for detailed information about any possible alarms and parameters used during commissioning.

## 6.1 Switching on the SINAMICS V70 drive


### 6.1.1 Jog test

To implement Jog test for the SINAMICS V70 drive, proceed through the following steps:

1. Switch on the 24 VDC power supply to the drive.
2. Switch on the 3 phase 380 VAC line supply to the drive.
3. To configure a motor with an incremental encoder, proceed as follows; otherwise, skip Steps 3 and 4 and go to Step 5 directly.

Configure the motor ID p29000 = 18 or 19. You can find the motor ID of the connected motor on its rating plate.


Operating display



\* The dot means that at least one parameter is changed without saving. To save the parameter changes, see Step 6.

4. Configure the motor brake p1215 as follows. For a motor without a holding brake, skip this step and go to Step 5 directly.
  - = 0 (default): No motor holding brake available
  - = 1: Motor holding brake under sequence control
  - = 2: Motor holding brake always open
  - = 3: Motor holding brake under sequence control by the SINUMERIK 808D ADVANCED

Operating display



#### Note

For a motor with incremental encoder, the operating principle of the holding brake is configured during motor selection; for a motor with absolute encoder, it is configured automatically.

#### NOTICE

##### Shortening the service life of motor brake


The motor brake is used for holding the load in position only. Frequent emergency stops with the motor brake can shorten its service life.

Unless absolutely necessary, do not apply the motor brake as an emergency stop or deceleration mechanism.

5. Set the Jog speed p1058 with a value between 0 and the rated speed of the connected motor. If you want to use the default Jog speed (100 rpm), skip this step.



Operating display




#### Note


For more information about the rated speed of a motor, see section "SIMOTICS S-1FL6 servo motors (Page 130)".

- Save the parameter settings as follows. For a motor with an absolute encoder and without a holding brake, if you use the default Jog speed (100 rpm), you can skip this step.

Operating display



- Run the connected motor with the Jog function and check the Jog speed or Jog torque.



---

**Note**


When you run the servo motor with an incremental encoder in JOG mode, the servo motor makes a short buzzing sound indicating that it is identifying the magnetic pole position of the rotor.

---

### 6.1.2 Configuring Drive Bus addresses

To configure the Drive Bus addresses on the SINAMICS V70 drive, set parameter p0918 (default = 10) with the drive BOP as required. You must set a proper address according to the actual application of the drive.

- 11: X axis
- 12: Y axis (or additional axis for the turning variant of the control system)
- 13: Z axis
- 15: Additional axis



---

**Note**

Do not switch on the 24 VDC power supply for the SINUMERIK 808D ADVANCED before you finish setting the Drive Bus addresses for all connected drives.

After setting a proper address, you must save the parameter and then restart the drive to apply your setting.

---

**Note**

After the Drive Bus communication is established for the first time, the internal communication parameters are automatically changed and hence a dot appears on the display as follows:

**P.R. R**

You must perform a save operation to remove the dot.

---

**Note**

After the Drive Bus communication is established, the BOP is protected from any operation except clearing alarms and acknowledging faults.

---

## 6.2 Switching on the control system


### Preparation before switch-on

Make sure the following before switching on the control system:

- You have finished the mechanical installation of the whole system based on the information included in Chapter "Mounting (Page 25)".
- You have completed the wiring of the whole system according to the information included in Chapter "Connecting (Page 41)" (if you use the default PLC program).

### Operating sequence

1. Switch on the 24 VDC power supply for the control system.  
When the control system starts up for the first time, the following two alarms appear.



2. Press this key or the key combination to clear the alarms. For more information about the alarms and system responses, refer to the SINUMERIK 808D ADVANCED Diagnostics Manual.
3. When the control system enters the main screen, check the status LEDs on the PPU.
  - **POK**: green
  - **RDY**: green
  - **TEMP**: off
4. Check the status LEDs on the SINAMICS V70 drive:
  - **RDY**: green
  - **COM**: slow flashing green every two seconds


### Note

The control system constantly creates restoring points during operation. In case of data loss due to power failure or other problems, the control system automatically restores the last autosaved system data upon startup with an alarm appearing on the screen.

## 6.3 Synchronizing drive data files between NC and drive

The NC always compares its data backup with the drive data upon every startup.

- If no data backup files can be found, the NC creates a new backup file automatically with the following dialog displaying on the screen:




- If the drive data differs from the NC data backup, a data synchronization is required for synchronizing the drive data files between the NC and the drives.

## Operating sequence

OK

1. Press this softkey to enter the setting window when the following data synchronization dialog appears.



**Note:** a password input field appears in this dialog if you have not set an access level on the control system. For more information, see Section "Setting the password (Page 81)".


If you cancel the data synchronization with the following softkey, this dialog appears again on next NC startup.

Cancel

2. Select a drive for which you desire to perform the data synchronization.




3. Press this key to choose a synchronization method for the selected drive.



4. Press this softkey to confirm your settings and start the data synchronization.
5. After the synchronization finishes successfully, the following dialog displays on the screen.

Accept  
all




6. Press this softkey to exit the dialog.

OK

## Checking the status LEDs on the SINAMICS V70 drives

When the data synchronization is completed, the LEDs on the drive indicate the drive is in ready state (**RDY**: green; **COM**: slow flashing green every two seconds). The drive BOP displays S-off or a fault depending on the type of connected encoder.



## 6.4 Setting the password

The control system provides a concept of protection levels for enabling data areas. Different protection levels control different access rights.

The control system delivered from Siemens is set by default to the lowest protection level 7 (without password). If the password is no longer known, you must reinitialize the control system with the default machine/drive data. All passwords are then reset to default passwords for this software release.

### Note

Before you boot the control system with default machine/drive data, make sure that you have backed up your machine/drive data; otherwise, all data are lost after rebooting with default machine/drive data.

Protection level	Locked by	Area	Access right
0	Siemens password	Siemens, reserved	-
1	Manufacturer password (Default password: "SUNRISE")	Machine manufacturers	<ul style="list-style-type: none"><li>• Entering or changing part of the machine data and drive data</li><li>• Conducting NC and drive commissioning</li></ul>
2	Reserved	-	-
3-6	End user password (Default password: "CUSTOMER")	End users	<ul style="list-style-type: none"><li>• Entering or changing part of the machine data</li><li>• Editing programs</li><li>• Setting offset values</li><li>• Measuring tools</li></ul>
7 *	No password	End users	-

\* Protection level 7 is set automatically if no password is set and no protection level interface signal is set. The protection level 7 can be set from the PLC user program by setting the bits in the user interface.


The number of machine data and drive data which can be read or modified depends on the protection level. You can set the protection level for these function areas with the display machine data (**USER\_CLASS...**).

The control system is delivered with no password. You must set the factory default manufacturer password "**SUNRISE**" to perform the commissioning work. Perform the following steps to enter the password:



**Set  
password**

1. Select the desired operating area.
2. Press this vertical softkey to open the following dialog.



 **Accept**

3. Enter "SUNRISE" with the PPU keyboard and press this softkey.  
A message now shows at the bottom of the screen, which indicates that you have successfully set the password.

**Access level:Manufacturer**

The following password operations are also available in this operating area:

**Change  
password**

To change the default password of the control system

**Delete  
password**

To delete the current password

#### Note

Clear the password before the machine is delivered; otherwise, end users can start the controller with the standard data, which can initialize the control system. As a consequence, the machine will not run.


## 6.5 Setting the date and time

At delivery, the system date and time remain at the factory settings, and thus you must manually modify the date and time.

#### Operating sequence



1. Select the desired operating area on the PPU.
2. Open the date and time setting window through the following softkey operations:



3. Enter the date and time in the specified format.

Current	2004/07/01	01:59:23
Format	YYYY/MM/DD	HH:MM:SS
New	2015 /02 /02	14 :50 :22

 **OK**

4. Press this softkey to confirm your settings.

## 6.6 Activating the optional functions

The following optional functions can be purchased for the control system:

- Additional axes
- Contour handwheel
- Bidirectional leadscrew error compensation
- Manual Machine Plus (for turning variant only)
- Transmit/Tracyl
- Gantry (BASIC)

To use a purchased option, you must first activate it with a license key on the control system.

---

### Note


The control system supports up to two additional axes for the turning variant and one for the milling variant.

After you purchase the desired option(s), you can obtain the corresponding license key from the Web License Manager.

For more information about how to generate a license key via the Web License Manager, refer to the SINUMERIK 808D ADVANCED Function Manual.

---

### Operating sequence



1. Select the desired operating area.




2. Press this key to view the extended softkeys.

3. Open the dialog for entering the license key through the following softkey operations:



4. Enter the license key generated by the Web License Manager in the following dialog:

License key															
Enter the licence key to activate the option! The option is activated after Restart!															
CF card serial number:										SPG2012061600398					
Order No. of the NCU module:										6FC5812-1GY46-0YA0					



5. Press this softkey to confirm your entry.

## Options

- Press this softkey to enter the window of available options. You can find the licensing status in this window, for example:

Options		
Option	Set	Licensed
Additional axis, basic 6FC5800-0AK70-0YB0	1	2
Contour handwheel 6FC5800-0AM08-0YB0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Bidir. lead screw error comp. 6FC5800-0AM54-0YB0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Manual Machine Plus 6FC5800-0AP07-0YB0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Transmit/Tracyl 6FC5800-0ASS0-0YB0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Gantry (BASIC) 6FC5800-0ASS1-0YB0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

If you have licensed one or two additional axes, you can find a figure of "1" or "2" in the column of licensing status. For other licensed options, a "☑" symbol displays in this column.

**Note:** The last option displayed in this window indicates the variant information and the licensing status of your control system, for example:

System software PPU16x Turning (Export) 6FC5812-1GYxx-xYA0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
---	-------------------------------------	-------------------------------------

In case of any problems with respect to the licensing status of your control system, contact Siemens service personnel.

- Set the licensed options.
  - For the additional axes, enter "1" or "2" in the setting column and press the following key:



- For the other options, press the following key to select:



## NCK reset (po)

- Press this softkey to restart the NCK, so that the licensed options are activated.



## 6.7 Loading system languages

You can load a new system language or update an existing language on the control system. Siemens will provide each language in the form of an archive file. The file name format is as follows:

808\_lang\_<LANG>\_04060200yyy.arc

Where, <LANG> stands for the language code, for example, <chs> for Chinese, <eng> for English. "yyy" refers to the version code.

The following table provides different language codes for your reference.



Language	Code	Language	Code
Simplified Chinese	chs <sup>1)</sup>	Italian	ita
Traditional Chinese	cht	Korean	kor
Czech	csy	Dutch	nld
Denish	dan	Polish	plk
German	deu	Portuguese	ptb
English	eng <sup>1)</sup>	Rumanian	rom
Spanish	esp	Russian	rus
Finnish	fin	Swedish	sve
French	fra	Turkish	trk
Hungarian	hun		

<sup>1)</sup> Factory default system languages that are already loaded on the control system at delivery.

### Operating sequence

Proceed through the following steps to load a system language:



1. Copy the system language file to a USB stick.
2. Insert the USB stick into the USB interface at the front of the PPU.
3. Select the desired operating area on the PPU.
4. Press this softkey to open the start-up archive window.
5. Use the cursor keys to select the following option to restore a start-up archive.



6. Press this softkey to confirm, and the file opening dialog appears.




7. Select the USB folder and press this key to enter it.




8. Navigate to the system language file you desire to load and press this softkey to confirm.



9. Press this softkey to confirm the archive information, and then the following message appears:



10. Press this softkey to confirm and start loading the archive. The control system restarts to complete restoring the system language archive.
11. Power off/on the control system to activate the loaded language. Then you can find the new system language and select it through the following operations:



## 6.8 Overview on commissioning and operation wizards

The control system has two commissioning wizards and one operation wizard.


- The commissioning wizards require a manufacturer access level. They are designed to help you commission the basic machine tool functions on the prototype machine and series machines.
- The operation wizard requires an end user access level. It is designed to help you learn about the basic operations of the machining process.

Three machine data areas are used in the wizards to commission the prototype machine: general machine data, axis machine data and NC basic list.

### Softkey functions



Pressing this key on the PPU allows you to enter the main screen of the wizards.



- ① Calls the commissioning wizard for the prototype machine
- ② Calls the commissioning wizard for series machines
- ③ Calls the operation wizard
- ④ Enters the currently selected task.
- ⑤ Starts commissioning from the current task

**Note:** This softkey becomes active when you move the cursor key to a completed or current task.

Pressing any operating area key on the PPU allows you to exit the wizard.


## Commissioning status

You can check the commissioning status via the status symbols from the main screens of the commissioning wizards.

Status symbol	Meaning
✓	Completed task
←	Current task
⊙	Partially completed task group
○	Uncompleted task

## Commissioning diagram

The diagram below shows the general commissioning procedure for the NC.



## 7 Commissioning the prototype machine

### Note

The control system constantly creates restoring points during operation. In case of data loss due to power failure or other problems, the control system automatically restores the last autosaved system data upon startup with an alarm appearing on the screen.

### Overview of commissioning procedure


The following shows you the basic commissioning procedure for prototype machines using the sample PLC:

- Step 1 → Checking the scope of delivery (Page 13)
- Step 2 → Mounting (Page 25)
- Step 3 → Wiring (Page 41)
- Step 4 → Installing the Toolbox software (Page 70)
- Step 5 → Switching on and preparation (Page 75)
- Step 6 → Activating software options (Page 83)
- Step 7 → Commissioning the prototype (Page 88)
- Step 8 → Cabinet design (Page 34)


## 7.1 Commissioning the PLC

### 7.1.1 Setting PLC related parameters

Use either of the following softkeys on the main screen of prototype commissioning wizard to enter the window for setting the PLC related parameters:



#### Softkey functions



- ① Activates the parameter changes. Note that the control system restarts to accept the new values.
- ② Resets the value of the selected parameter to default
- ③ Cancels the last change to the parameter
- ④ Proceeds to the next step

#### PLC related parameters

MD14510 Machine data - Integer	PLC interface	Unit	Range	Function
14510[12]	DB4500.DBW24	-	0 to 1	Layout of the traverse keys
14510[13]	DB4500.DBW26	0.1 s	5 to 200	Time for spindle braking

<b>MD14510</b> <b>Machine data - Integer</b>	<b>PLC interface</b>	<b>Unit</b>	<b>Range</b>	<b>Function</b>
14510[15]	DB4500.DBW30	0.1 s	5 to 30	Spindle override 50% key holding on time defined
14510[16]	DB4500.DBW32	0.1 s	1 to 30	Spindle override 100% key holding on time defined
14510[20]	DB4500.DBW40	-	2 to 64	Maximum number of tools
14510[21]	DB4500.DBW42	0.1 s	5 to 30	Turret clamping time
14510[22]	DB4500.DBW44	0.1 s	30 to 200	Monitoring time when searching for tools
14510[24]	DB4500.DBW48	1 min	5 to 300	Lubrication interval
14510[25]	DB4500.DBW50	0.01 s	100 to 2000	Lubrication duration

<b>MD14512</b> <b>Machine data - Hex</b>	<b>Function</b>
14512[16]	Bit 1: function of chip conveyor (milling) Bit 2: function of safety door (milling) Bit 3: when the function of safety door is active, it can be triggered by M01/M02 (milling) Bit 7: handwheel assignment with the MCP/HMI
14512[17]	Bit 0: turret (turning); tool magazine (milling) Bit 1: clamping function (turning) Bit 2: tail stock function (turning) Bit 3: selection between handwheel and hand-held unit (0: handwheel; 1: hand-held unit)
14512[18]	Special configurations for machines Bit 2: automatic lubrication at power-on Bit 4: external signal for spindle stop Bit 5: fixed spindle direction Bit 6: the hardware limit is independent from a PLC program Bit 7: each feed axis has a hardware limit switch (activated when Bit 6 = 0)
14512[19]	Bit 1: function of spindle braking Bit 2: password clearing by power-on (0: delete the password; 1: do not delete the password) Bit 7: manual machine function (this function becomes active if you have installed licensed turning machine system and called it with a PLC subroutine)
14512[20]	Bit 0: grey coded switch (0: spindle override controlled by the grey code; 1: spindle override controlled by triggering user keys) Bit 1: spindle disable mode (0: disable by pressing the spindle stop key; 1: disable when detecting the standstill speed) <sup>1)</sup> Bit 2: activate the first additional axis (0: disable the additional axis control; 1: enable the additional axis control) Bit 3: the first additional axis as the second spindle and does not need to be kept enabled (1: as the second spindle and does not need to be kept enabled) Bit 5: define the spindle override startup value (0: the startup spindle override is always 100%; 1: recode the spindle override value of the last machine turn off for the next startup) Bit 6/7: define the spindle override shift speed

**Note:**

When you set MD14512, you can use the following key to open the editor for bit setting:



<sup>1)</sup> When the position control mode is active, do not disable the spindle by detecting the standstill speed.

MD14514 Machine data - Float	PLC interface	Unit	Range	Function
14514[0]	DB4500.DBD2000	-	-3.40e38 to 3.40e38	Tool magazine: spindle poisoning angle
14514[1]	DB4500.DBD2004	-	-3.40e38 to 3.40e38	Tool magazine: preparation position of Z axis for tool change
14514[2]	DB4500.DBD2008	-	-3.40e38 to 3.40e38	Tool magazine: tool changing position of Z axis
14514[3]	DB4500.DBD2012	-	-3.40e38 to 3.40e38	Tool magazine: velocity of Z axis, go to tool changing position
14514[4]	DB4500.DBD2016	-	-3.40e38 to 3.40e38	Tool magazine: velocity of Z axis, back to tool change preparation position

#### Note

PLC interface signal addresses are represented with the V structure on the HMI while the manual shows them by the DB structure.

See the following table for the relationship between the two representations.


V Structure		DB Structure	
Access	Example	Example	Access
Bit	V38000002.1	DB3800.DBX2.1	Bit
Byte	VB38000002	DB3800.DBB2	Byte
Word	VW38000002	DB3800.DBW2	Word
Double Word	VD38000004	DB3800.DBD4	Double word

## 7.1.2 Downloading and commissioning PLC programs

To realize your own PLC functions, you can upload the default PLC program and edit it. With PLC Programming Tool installed on your PC, you can download customized PLC programs into the permanent memory of the control system. PLC Programming Tool is available in the Toolbox.

If you use the default PLC programs, you can skip this step and move to the next step.

#### Softkey functions



- ① Activates/deactivates the direct connection with PLC Programming Tool via the Ethernet interface.
- ② Returns to the previous step
- ③ Proceeds to the next step

For more information about the communication settings on the PC end as well as downloading and commissioning PLC programs with PLC Programming Tool, refer to Appendix "PLC Programming Tool (Page 181)".


## Note

You should upload the sample PLC blocks to the PC first, then make the modifications to achieve the required functionality. Upon completion, you must put the PLC into stop and download the modified PLC into the PPU. Then you need to restart the PLC.

### 7.1.3 Checking I/O address assignment

You must check the I/O address assignment in this step to ensure correct wiring.

#### Softkey functions



- |  |  |
|--|--|
| ① Selects the digital inputs               | ④ Shows the I/O addresses of the last byte |
| ② Selects the digital outputs              | ⑤ Returns to the previous step             |
| ③ Shows the I/O addresses of the next byte | ⑥ Proceeds to the next step                |


### 7.1.4 Editing PLC alarm texts

PLC user alarms can be used as one of the most effective diagnosis methods. The control system provides 128 PLC user alarms (700xxx). You can edit the PLC alarm texts as required.

#### Operating sequence



1. Select the alarm text you desire to edit.



2. Press this softkey to activate the input field at the bottom of the screen and enter the desired text, for example:

**Note: Modify the PLC alarm texts if they are inapplicable.**  
**700000 OVERHEAT**

Note that the text of each PLC user alarm must be limited to 50 characters; otherwise, the alarm cannot display properly.



3. Confirm your entry with this softkey or the following key:



Import

Export

Next  
step

4. You can also use these two softkeys to import / export the PLC user alarm texts from / to the following directories:

Start-up archive  
OEM files  
USB  
User files

5. After you finish editing the alarm texts, press this softkey to move on to the next step.

### Note

You can edit the alarm text either in English or in simplified Chinese. Editing in Chinese is only possible when the system language is simplified Chinese.

Pressing both the  key and the  key on the PPU calls the Chinese character editor.

You can find the PLC alarm text files in different languages in the HMI data area through the following operation:



If you use a system language rather than the four default languages (Simplified Chinese, English, Portuguese, and Russian), the PLC alarm text file in that language is visible only after you edit the PLC alarm texts.

You can copy and paste these files for backup or other customized purposes.

## 7.2 Configuring the drives

Before starting the drive configuration, you must ensure the Drive Bus addresses are properly set (p0918) via the drive BOPs. For more information about setting the Drive Bus address, refer to Section "Configuring Drive Bus addresses (Page 78)".

### Operating sequence

Start  
config.

1. Press this softkey on the main screen of drive configuration, and the controller starts to identify the drives and motors connected.

After the identification finishes, a drive list with motor information displays on the screen as follows:

Axis	Drive	Motor
MX1	11	not configured
MZ1	13	ID:10009(0.4KW/1.3A/3000r/min/Without brake)
MSP1	Ana. spindle	not configured

**Note:** For a motor with an absolute encoder, the motor ID can be identified automatically. For a motor with an incremental encoder, however, you must configure it manually.



Motor  
config.



2. Select the motor to be configured using the cursor keys.
3. Press this softkey to enter the motor configuration window.



4. Select the right motor ID according to the motor rating plate with the cursor keys.

Axis:MX1		Drive:11		
Motor ID	Power	Current	Speed	Brake type
18	0.4KW	1.3A	3000r/min	Without brake
19	0.4KW	1.3A	3000r/min	With brake

For example, you can find the motor ID on the following motor rating plate:

SIEMENS		
SIMOTICS S-1FL6 3~Servo Motor		
1P 1FL6042-1AF61-0AG1		
1S LMH-C90388899302		
		
M <sub>N</sub> 1.27 Nm	I <sub>N</sub> 1.2 A	n <sub>N</sub> 2000 r/min
M <sub>0</sub> 1.9 Nm	I <sub>0</sub> 1.7 A	n <sub>max</sub> 3000r/min
U <sub>N</sub> 222 V	IP65 S1	3.3 kg
P <sub>N</sub> 0.4 kW	Th.CL.130(B)	ID 18
ENCODER INC. 2500 ppr		BRAKE 24VDC
		
EN60034		
Siemens Standard Motors Ltd. Made in China		

Select

5. Press this softkey to confirm your selection. The selected motor information then displays in the drive list.

Axis	Drive	Motor
MX1	11	ID:18(0.4KW/1.3A/3000r/min/Without brake)
MZ1	13	ID:10009(0.4KW/1.3A/3000r/min/Without brake)
MSP1	Ana. spindle	not configured

Motor config.

6. For the analog spindle, you can use this softkey to set the relevant machine data as required.

32250[0]	RATED_OUTVAL	0	%	cf
32260[0]	RATED_VELO	3000	rpm	cf
36700	DRIFT_ENABLE	0		cf
Rated output voltage				
Name:RATED_OUTVAL		Unit:%		

It is recommended that you set the value of 32250 as 100%; otherwise, the spindle cannot rotate.

The following softkey operations are possible on this screen:

Resets the value of the selected parameter to default

Default

Cancels the last change to the parameter

Undo

Next step

7. After you finish configuring all motors, press this softkey to save the configuration results on both CNC and drives and proceed to the next step.


**Note:** The control system restarts after you press this softkey. In this case, for the drive connected to a motor with an incremental encoder, immediately after the "RDY" LED on the servo drive lights up green, the motor makes a short buzzing sound indicating that the motor is identifying the magnetic pole position of the rotor.

## Note

You can change the motor direction of rotation by setting the drive parameter p1821. The parameter p1821 is accessible on the PPU through the following operations:



Before changing the parameter p1821, first set the drive parameter p10 = 3 when the drive is in servo off state. Parameter p10 is accessible on the PPU through the following operations:



For detailed explanation about the drive parameters, you can call the online help by pressing the following key on the corresponding drive parameter screen:




## 7.3 Setting basic parameters

### 7.3.1 Setting feed axis parameters

You can set the axis-specific machine data for each feed axis under this commissioning step.

#### Softkey functions



- |   |  |
|---|--|
| ① Selects the next axis                                 | ⑤ Cancels the last change to the parameter |
| ② Selects the previous axis                             | ⑥ Returns to the last step                 |
| ③ Activates the modified values                         | ⑦ Proceeds to the next step                |
| ④ Resets the value of the selected parameter to default |  |

#### Axis-specific parameters

No.	Name	Unit	Range	Description
30130[0]	CTRLOUT_TYPE	-	0 to 3	Output type of setpoint
30240[0]	ENC_TYPE	-	0 to 5	Encoder type
31020[0]	ENC_RESOL	-	-	Encoder lines per revolution
31030	LEADSCREW_PITCH	mm	≥ 0	Pitch of leadscrew
31050[0]	DRIVE_AX_RATIO_DENOM	-	1 to 2147000000	Number of the gearbox teeth at drive end (denominator of the deceleration ratio)

No.	Name	Unit	Range	Description
31060[0]	DRIVE_AX_RATIO_NUMERA	-	1 to 2147000000	Number of the gearbox teeth at leadscrew end (numerator of the deceleration ratio)
32000	MAX_AX_VELO	mm/min	-	Maximum axis velocity
32010	JOG_VELO_RAPID	mm/min	-	Rapid traverse in jog mode
32020	JOG_VELO	mm/min	-	Jog axis velocity
32100	AX_MOTION_DIR	-	-1 to 1	Traversing direction (not control direction) <ul style="list-style-type: none"> <li>= 1: Motor runs clockwise</li> <li>= -1: Motor runs counter-clockwise</li> </ul>
32260[0]	RATED_VELO	rpm	0	Rated motor speed
34200[0]	ENC_REFP_MODE	-	0 to 8	Referencing mode
36200[0]	AX_VELO_LIMIT	mm/min	-	Threshold value for velocity monitoring
36300[0]	ENC_FREQ_LIMIT	Hz	-	Encoder limit frequency = Motor rated velocity/60 × Encoder resolution


#### Note

The value of MD36200 should be 10% higher than that of MD32000; otherwise, alarm 025030 occurs.


### 7.3.2 Commissioning the referencing function

#### Principles for referencing

- Zero mark is away from the reference cam (MD34050: REFP\_SEARCH\_MARKER\_REVERS = 0)



- Zero mark is above the reference point (MD34050: REFP\_SEARCH\_MARKER\_REVERS = 1)



- Vc Velocity for searching for the reference cam (MD34020: REFP\_VELO\_SEARCH\_CAM)  
V<sub>M</sub> Velocity for searching for the zero mark (MD34040: REFP\_VELO\_SEARCH\_MARKER)  
Vp Position velocity (MD34070: REFP\_VELO\_POS)  
Rv Shift of the reference point (MD34080: REFP\_MOVE\_DIST + MD34090: REFP\_MOVE\_DIST\_CORR)  
Rk Set position of the reference point (MD34100: REFP\_SET\_POS [0])

## Softkey functions

You can commission the axis referencing function and approach the reference point by setting relevant machine data in the following window:

MCS	Position	Speed	Help
MX1	0.000	0.000	1.Set the MDs as required, and then press 'Activate' and 'RESET'. 2.Press the corresponding axis traversing key for referencing.
MZ1	0.000	0.000	
MSP1	0.000	0.000	

MD	Name	Value	Unit	re
20700	REF_NC_START_LOCK	1		re
34010	REF_CAM_DIR_IS_MINUS	0		re
34020	REF_VELO_SEARCH_CAM	5000	nm/nin	re
34040	REF_VELO_SEARCH_MARKER	300	nm/nin	re
34050	REF_SEARCH_MARKER_REVE	0		re

Approach reference point in minus direction  
Name: REF\_CAM\_DIR\_IS\_MINUS Unit:

- ① Selects the next axis
- ② Selects the previous axis
- ③ Activates the modified values
- ④ Resets the value of the selected parameter to default
- ⑤ Cancels the last change to the parameter
- ⑥ Returns to the last step
- ⑦ Proceeds to the next step

## Approaching the reference point

To approach the reference point, you must follow the instructions on the screen:

- For an axis driven by a motor with an incremental encoder, the following instructions are displayed:

**Help**



1.Set the MDs as required, and then press 'Activate' and 'RESET'.  
2.Press the corresponding axis traversing key for referencing.

- For an axis driven by a motor with an absolute encoder, the following instructions are displayed:

**Help**

1.Switch to 'JOG' mode. Traverse the axis to a certain position.  
2.Enter the reference position value in 34100.  
3.Enter '1' in 34210 to activate the encoder debugging.  
4.Press in order 'REF. POINT', 'Activate' and 'RESET'.  
5.Press the corresponding axis traversing key for referencing.

If the axis is referenced, a symbol  appears next to the axis identifier, for example:

 MX1	0.000	0.000
 MZ1	0.000	0.000

## Relevant machine data

No.	Name	Unit	Default value	Description
20700	REFP_NC_START_LOCK	-	1	NC start disable without reference point
34010	REFP_CAM_DIR_IS_MINUS	-	0	Direction for approaching the reference point: <ul style="list-style-type: none"> <li>0: +</li> <li>1: -</li> </ul>
34020	REFP_VELO_SEARCH_CAM	mm/min	5000	Velocity for searching for the reference cam
34040[0]	REFP_VELO_SEARCH_MARKER	mm/min	300	Velocity for searching for the zero mark
34050[0]	REFP_SEARCH_MARKER_REVERSE	-	0	Direction for searching for the zero mark: <ul style="list-style-type: none"> <li>0: +</li> <li>1: -</li> </ul>
34060[0]	REFP_MAX_MARKER_DIST	mm	20	Checking the maximum distance from the reference cam
34070	REFP_VELO_POS	mm/min	10000	Positioning velocity for approaching the reference point
34080[0]	REFP_MOVE_DIST	mm	-2.0	Reference point distance (with marker)
34090[0]	REFP_MOVE_DIST_CORR	mm	0	Correction of reference point distance
34092[0]	REFP_CAM_SHIFT	mm	0	Shift of the reference cam
34093[0]	REFP_CAM_MARKER_DIST	mm	0	Distance between the reference cam and the first zero mark
34100[0]	REFP_SET_POS	mm	0	Reference point position for incremental system
34200[0]	ENC_REFP_MODE	-	1	Referencing mode
34210[0]	ENC_REFP_STATE	-	0	Adjustment status of absolute encoder
34220[0]	ENC_ABS_TURNS_MODULO	-	4096	Modulo range for rotary absolute encoder
34230[0]	ENC_SERIAL_NUMBER	-	0	Encoder serial number


## Note

You must set the length of the reference cam based on the velocity set by MD34020. An axis can stop above the cam after it approaches the cam at the velocity set by MD34020 and then decelerates to "0".

## 7.3.3 Setting spindle parameters

The control system controls one analog spindle. You can commission the spindle by setting the relevant machine data under this commissioning step.

## Softkey functions



- |   |   |
|---|---|
| ① Activates the modified values                         | ④ Switches to "MDA" mode for program test |
| ② Resets the value of the selected parameter to default | ⑤ Returns to the last step                |
| ③ Cancels the last change to the parameter              | ⑥ Proceeds to the next step               |

#### Relevant machine data

No.	Name	Unit	Default value	Description
30130[0]	CTRLOUT_TYPE	-	0	Output type of setpoint
30134[0]	IS_UNIPOLAR_OUTPUT	-	0	Setpoint output is unipolar
30240[0]	ENC_TYPE	-	0	Encoder type of actual value sensing (actual position value)
31020[0]	ENC_RESOL	-	2048	Encoder lines per revolution
31050[1...5]	DRIVE_AX_RATIO_DENUM	-	1	Denominator load gearbox
31060[1...5]	DRIVE_AX_RATIO_NUMERA	-	1	Numerator load gearbox
32020	JOG_VELO	rpm	30	Jog axis velocity
32100	AX_MOTION_DIR	-	1	Traversing direction (not control direction)
32110[0]	ENC_FEEDBACK_POL	-	1	Sign actual value (control direction)
32260[0]	RATED_VELO	rpm	3000	Rated motor speed
34200[0]	ENC_REFP_MODE	-	1	Referencing mode
34210[0]	ENC_REFP_STATE	-	0	Adjustment status of absolute encoder
34220[0]	ENC_ABS_TURNS_MODULO	-	4096	Modulo range for rotary absolute encoder
34230[0]	ENC_SERIAL_NUMBER	-	0	Encoder serial number
35010	GEAR_STEP_CHANGE_ENABLE	-	0	Parameterize gear stage change
35100	SPIND_VELO_LIMIT	rpm	10000	Maximum spindle speed
35110[1...5]	GEAR_STEP_MAX_VELO	rpm	[1]: 500 [2]: 1000 [3]: 2000 [4]: 4000 [5]: 8000	Maximum speed for gear stage change
35120[1...5]	GEAR_STEP_MIN_VELO	rpm	[1]: 50 [2]: 400 [3]: 800 [4]: 1500 [5]: 3000	Minimum speed for gear stage change
35130[1...5]	GEAR_STEP_MAX_VELO_LIMIT	rpm	[1]: 500 [2]: 1000 [3]: 2000 [4]: 4000 [5]: 8000	Maximum speed of gear stage
35140[1...5]	GEAR_STEP_MIN_VELO_LIMIT	rpm	[1]: 5 [2]: 10 [3]: 20 [4]: 40 [5]: 80	Minimum speed of gear stage
36200[1...5]	AX_VELO_LIMIT	rpm	31944	Threshold value for velocity monitoring
36300[0]	ENC_FREQ_LIMIT	Hz	333000	Encoder limit frequency = Motor rated velocity / 60 × Encoder resolution

## 7.4 Creating series archives

Creating series startup archives is a prerequisite for series machine commissioning. The series startup archives contain data from the prototype machine commissioning which bring the series machine to the same state.

REEPOINT 09:45:50 2015/02/09

Last: Set spindle parameters Step 9/14 Create ser. start-up archive Next: Set SW limit

Archive creator: MAX MUSTERMAN  
Archive version: 0.1  
Machine type: Turning machine  
Comment: My archive  
Archive content: Production data archive  
Creation date: 2015/02/09

Create archive

This step creates a series start-up archive which includes:

- Machine and setting data
- PLC data (e.g. PLC program, PLC alarm texts)
- User cycles and part programs
- Tool and work offset data
- R variables
- HMI data (e.g. OEM OnlineHelp, OEM Manual, ...)
- Drive and motor configuration

Note: Fill the archive information and press 'Create archive', a new archive with specified name will be generated.

Last step  
Next step

### Operating sequence

1. Specify the properties of the archive as required:

Archive creator: MAX MUSTERMAN  
Archive version: 0.1  
Machine type: Turning machine  
Comment: My archive  
Archive content: Production data archive  
Creation date: 2015/02/09




2. Press this softkey to open the window for saving the archive file. You must select a directory from this window:

Save file ...

arc\_product.arc

Start-up archive  
OEM files  
USB

The default name of the data archive is "arc\_product.arc". You can use your desired name for it.



3. Press this softkey to create the archive.

---

### Note

If you choose USB as the target directory, do not remove the USB stick during the data saving.

---


## 7.5 Setting compensation data

### 7.5.1 Setting software limit switch data

The software limit switches are used to limit the maximum traversing range on each individual axis.

You can set the software limit switches for each axis by configuring parameters 36100 and 36110 under this commissioning step.

#### Softkey functions



- ① Selects the next axis
- ② Selects the previous axis
- ③ Activates the modified values
- ④ Resets the value of the selected parameter to default
- ⑤ Cancels the last change to the parameter
- ⑥ Returns to the last step
- ⑦ Proceeds to the next step

#### Setting parameters

No.	Name	Unit	Default value	Description
36100	POS_LIMIT_MINUS	mm	-100000000	- software limit switch
36110	POS_LIMIT_PLUS	mm	100000000	+ software limit switch



## 7.5.2 Setting backlash compensation data

In the case of axes/spindle with indirect measuring systems, mechanical backlash results in corruption of the traverse path, causing an axis, for example, to travel too much or too little by the amount of the backlash when the direction of movement is reversed.

You can set the backlash compensation by configuring the parameter 32450[0].

### Softkey functions



- |   |  |
|---|--|
| ① Selects the next axis                                 | ⑤ Cancels the last change to the parameter |
| ② Selects the previous axis                             | ⑥ Returns to the last step                 |
| ③ Activates the modified values                         | ⑦ Proceeds to the next step                |
| ④ Resets the value of the selected parameter to default |  |


### Setting parameter

No.	Name	Unit	Default value	Description
32450[0]	BACKLASH	mm	0	Backlash compensation is active after reference point approach.

## 7.5.3 Setting leadscrew error compensation data

The principle of the leadscrew error compensation is to modify the axis-specific position actual value by the assigned compensation value at the particular compensation point and to apply this value to the machine axis for immediate traversal. A positive compensation value causes the corresponding machine axis to move in the negative direction.

### Softkey functions





- |  |   |
|--|---|
| ① Selects the next axis                  | ④ Opens the window for entering the compensation values |
| ② Selects the previous axis              | ⑤ Returns to the last step                              |
| ③ Switches to bidirectional compensation | ⑥ Proceeds to the next step                             |

### Operating sequence



1. You can press this softkey to switch to bidirectional compensation to realize more precise compensation, if required.  
The unidirectional compensation is used by default.

**Note:** This softkey is active only if the optional bidirectional leadscrew error compensation has been activated with the license key. For more information about this software option, refer to the SINUMERIK 808D ADVANCED Function Manual.



2. Use these softkeys to select an axis.

3. Specify the following parameters as desired.

Start point(MCS)	0.0000 mm	Number of runs	5
End point(MCS)	5000.000 mm	Pause time	4 s
Interval	1000.000 mm	Overrun step size	2 mm
Number of points	6	Feed speed	500 mm/min



4. Press this softkey to enter the compensation screen.

5. Follow the instructions in the help window to perform the compensation for the selected axis.




6. Press this softkey and repeat the above operations for the rest axis/axes until all axes are compensated.

## 7.6 Tuning drive performance

This commissioning step provides facilities to tune the drive performance for each axis by automatically modifying the control loop parameters. The tuning is performed based on frequency response measurements of the dynamic response of the machine.

### Softkey functions



- ① Saves the trace files during the tuning process to a USB flash disk (if inserted)
- ② Enters the window for selecting the tuning strategy
- ③ Starts the drive tuning process
- ④ Returns to the last step
- ⑤ Proceeds to the next step

### Operating sequence



1. Switch to "JOG" mode. Note that the drive tuning can be performed in "JOG" mode only.



2. You can select all axes or an individual axis for tuning.



3. Press this softkey to enter the window for selecting the tuning options.



4. Use this key to select a desired tuning objective. There are three objectives available for selection:

- For less rigid axes with motor feedback:

**Moderate responsiveness**

- For rigid axes and/or direct drive:

**Maximum responsiveness**

- For large machines with direct feedback:

**Conservative / robust**



5. Move the cursor and select the desired measurement and interpolation options for each axis.

For the first tuning, only the following measurement option is available, which enables a new measurement with all preliminary measurement steps.

**New meas. with prelim. steps** 

The following additional measurement options are available only if you have performed drive tuning for this axis:

- Performs a new measurement without carrying out the preliminary steps:

**New meas. with no prelim. steps** 

- Uses the existing measurement results:

**Retune with existing results** 

Besides, you can also specify the axis/axes for interpolation path tuning by selecting the corresponding interpolation option.

6. Press this softkey to confirm the selections and return to the main screen of drive tuning.



7. Press this softkey to enter the preparation screen before the tuning.




8. Use the axis traversing keys to move the axis/axes to be tuned to safe positions.

	Position	Direc.	Lim. -		Lim.
MX1	99.798	+, -	-1000	↓	1000
MZ1	200.002	+, -	-2000	↓	2000

9. Press this softkey and the drive tuning starts automatically.




10. Press this key on the MCP to start the measurement when the following message appears during the tuning process:




11. After the drive tuning finishes successfully, the tuning results appear on the screen in the form of a parameter list, for example:

MX1			
	Data before tuning	Data after tuning	
P1433[0]	0.000000	111.905155	
P1434[0]	1.000000	0.707071	
P1460[0]	0.016902	0.160459	
P1462[0]	50.000000	10.000000	
P1656[0]	0H	1H	
P1657[0]	2	1	
P1659[0]	0.707000	0.707100	
P1660[0]	1999.000000	2000.000000	
MD32200[0]	0.139684	4.000000	
MD32640[0]	0	1	
MD32810[0]	0.003000	0.002237	



You can check the tuning results of other tuned axis/axes (if any) with these softkeys.



12. Press this softkey to save the tuning results and write the modified parameters into the drives.




Pressing this softkey aborts the tuning and deletes the results.



13. After it returns automatically to the main screen of drive tuning, press this softkey to proceed to the next step.

The following softkey operation is also available on this screen:



Saves the trace files during the tuning process to a USB flash disk (if inserted)

## Note

For the machine data that are changeable only with a manufacturer password, the settings made during drive tuning cannot be restored after an NC restart in case of power failure or unexpected abortion of the tuning process.

## 7.7 Creating prototype machine commissioning archives

After commissioning the prototype machine, you must also create a commissioning archive for the data backup of the prototype itself.


To create a start-up archive for the prototype machine, proceed as follows:

1. Specify the properties of the archive as required:

Archive creator:	MAX MUSTERMAN
Archive version:	0.1
Machine type:	Turning machine
Comment:	My archive
Archive content:	Start-up data archive
Creation date:	2015/02/09



2. Press this softkey to open the window for saving the archive file. Select a directory from this window using the cursor keys:



The default name of the data archive is "arc\_startup.arc". You can use your desired name for it.




3. Press this key to open the selected directory. Select a folder using the cursor keys.



4. Press this softkey to create the archive.




5. After the archive is created successfully, press this softkey to finish commissioning the prototype machine and return to the main screen of the wizard.



6. Select the desired operating area.



7. Press this softkey to save data.



8. Press this softkey to complete the operation.

---

#### Note

If you choose USB as the target directory, do not remove the USB stick during the data saving.

---

## 8 Series machine commissioning

---

#### Note

The control system constantly creates restoring points during operation. In case of data loss due to power failure or other problems, the control system automatically restores the last autosaved system data upon startup with an alarm appearing on the screen.

---

### 8.1 Loading series commissioning archives

You can use the series commissioning archive to commission the machines for series production. The series archive is created during the commissioning of the prototype machine. For more information about creating a series archive, refer to Section "Creating series archives (Page 99)".

#### Operating sequence




1. Press this horizontal softkey on the main screen of wizards to call the commissioning wizard for series machines.




2. Use either softkey to enter the window for loading the series commissioning archive.





3. Press this softkey to open the dialog for loading the series archive.



4. Enter the backup directory and select the desired archive file.
5. Press this softkey to confirm your selection, and the archive information displays on the screen.



6. Check the archive information and press this softkey to start loading the series commissioning archive.



---

#### Note

Successful loading of the data archive can delete the password. You must set the password again before proceeding. For more information about setting a password, refer to Section "Setting the password (Page 81)".

---

## 8.2 Setting software limit switch data

Refer to Section "Setting software limit switch data (Page 100)".

## 8.3 Setting backlash compensation data

Refer to Section "Setting backlash compensation data (Page 101)".

## 8.4 Setting leadscrew error compensation data

Refer to Section "Setting leadscrew error compensation data (Page 102)".

## 8.5 Tuning drive performance

Refer to Section "Tuning drive performance (Page 103)".

## 8.6 Backing up series machine archives


Refer to Section "Creating prototype machine commissioning archives (Page 105)".

## 9 Other frequently used functions

### 9.1 Playing a slide show

The control system has a function of playing a slide show. It supports multiple languages besides two standard ones, Simplified Chinese and English. After installing the language package of a non-standard language, you can create the slide show in this language.

#### Playing a slide show



You can press this key combination on the PPU to play a slide show and press the key combination again to exit the slide show.

#### Creating a slide show

By default, the slide show of Siemens product information is provided. You can create the desired slide show as follows:

1. Prepare your own slides and save them in the respective language folders on a USB stick. Name each folder according to the following convention.

- Simplified Chinese: folder name = "chs";
- English: folder name = "eng".

The control system supports two kinds of image formats:

- \*.png
- \*.bmp

The image size is recommended to be **640\*480** pixels for the best display effect.


Name each slide according to the following syntax:

- **slide%u.png** or
- **slide%u.bmp**

Here "%u" is the number sequence starting with "1". For example, slide1.png, slide2.png, slide3.png ...

If your slides include both PNG-format images and BMP-format images, number them separately. During the slide show, the PNG-format images will have a higher priority over the BMP-format images.

2. Insert the USB stick into the USB interface on the front panel of the PPU.
3. Enter the desired operating area.




4. Locate the files on the USB stick through the following softkey operations:



Name	Type	Length
chs	DIR	
eng	DIR	


5. Select all the language folders for slide shows by using this softkey; or you can select the desired language folder by moving the cursor up and down.
6. Copy the selected language folders with this softkey.







7. Press this softkey to enter the main screen of HMI data.



8. Enter the folder related to HMI data.



9. Navigate to the folder highlighted as follows:

Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (alnc....txt)			
OEM MD description file (md_descr....txt)			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alcu....txt)			
OEM slideshow (*.bmp;*.png)			
OEM R variable name file (rparam_name....txt)			
Service planner task name file (svc_tasks....txt)			



10. Press this key to open the folder.



11. Paste the copied language folders with this softkey.



12. Press this key combination to play the slide show.

### Note

You can set the time interval between slides using MD9001 TIME\_BTWEEN\_SLIDES. This parameter can be found through the following operations:



For languages rather than Simplified Chinese and English, name the folder containing slide show files with the corresponding abbreviations. For more information, see Section "Loading system languages (Page 85)".

## 9.2 Defining the service planner

With the service planning function, you can specify the service timer and define your own service information. This section shows you how to define the OEM service planner.

### Creating a new service task

To create a new service task, perform the following steps:



1. Enter the desired operating area.



2. Press this key on the PPU to view the extended softkeys.




3. Enter the main screen of service planning.



4. Create a new task. Enter values in the respective fields.

Create new task ...	
Task description:	
①	TEST
②	Interval [h]: 10
③	First warning [h]: 1
④	Number of warnings: 1

- ① The description of the service task set by the user.
- ② Maximum time until the next maintenance in hours; if this value  $\neq 0$ , this data set is accepted by the PLC as a valid service task.
- ③ Time of the first warning is displayed since the user defined the task. This value must be less than that of the interval.
- ④ Number of warnings that are output by the PLC.



5. Confirm the above input to complete creating the new task.

### Viewing the service task

To view the created service task, proceed as follows:



1. Enter the desired operating area.



2. Enter the main screen of HMI data.



3. Enter the folder related to HMI data.

Name
Start-up archive
HMI data
NCK/PLC data
File for license key




4. Navigate to the highlighted folder shown below.

Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (alnc....txt)			
OEM MD description file (md_descr....txt)			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alnc....txt)			
OEM slideshow (*.bmp;*.png)			
OEM R variable name file (rparam_name....txt)			
Service planner task name file (svc_tasks....txt)			



5. Press this key to open the folder.

Name	Type
..	
svc_tasks_eng.txt	



6. Copy the desired service planner text.



7. Press this softkey to enter the screen form of user cycle.



8. Press this softkey to paste the copied text into the screen form of user cycle.



9. Press this key to view the service task.

### Editing the service task

To edit the created service task, proceed as follows:



1. Enter the desired operating area.



2. Press this key on the PPU to view the extended softkeys.



3. Enter the main screen of service planning.



4. Press this softkey to enter the screen form of task change.

5. Change the task description in the following box as desired.

change task ...

**Task description:**

**Interval [h]:**

**First warning [h]:**

**Number of warnings:**



6. Confirm the above input to complete changing the task.

#### Note

You can use the service planning function under different languages which are supported by the control system. For other languages, name the task files with the abbreviations corresponding to the languages. For example, the task files in Italian will be named as "svc\_tasks\_ita.txt". For more information about the language abbreviation, see Section "Loading system languages (Page 85)".

## 9.3 Using the machine manufacturer startup screen and machine logo

The control system uses the Siemens startup screen and machine logo by default. If necessary, you can use your own startup screen and machine logo.


### Using the machine manufacturer startup screen


The default startup screen is shown below:



To change it to your own startup screen, proceed as follows:


1. Prepare the image of the startup screen and save it on a USB stick.  
The control system supports a startup screen image in the BMP format with a maximum size of **600×360** pixels (W×H).  
Name the image as "**startup.bmp**".
2. Insert the USB stick into the USB interface on the front panel of the PPU.
3. Locate the startup screen file in the USB stick through the following softkey operations:





4. Copy the file with this softkey.

5. Press this softkey to enter the main screen of HMI data.



6. Enter the folder related to HMI data.

7. Navigate to the highlighted folder shown below.

Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (alnc....txt)			
OEM MD description file (md_descr....txt)			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alcu....txt)			
OEM slideshow (*.bmp;*.png)			
OEM R variable name file (rparam_name....txt)			
Service planner task name file (svc_tasks....txt)			

8. Enter the folder and the default startup screen and machine logo files are placed in this folder.

Name	Type	Length
..		
OEM machine logo (mtbico.bmp)		
OEM start-up splash screen (startup.bmp)		

9. Press this softkey to replace the default startup screen file with your own file.

10. Press these two keys to restart the HMI. You can see your own startup screen during the startup of the control system.




## Note

To restore the default startup screen, delete the customized bitmap file (startup.bmp) from the control system.


## Using the machine manufacturer machine logo

The default machine logo is displayed in the following operating area:



To use your own machine logo, proceed as follows:


1. Prepare your own machine logo and save it on a USB stick.  
The control system supports the machine manufacturer machine logo in the BMP format with a maximum size of **124×19** pixels (W×H).  
Name the image as **"mtbico.bmp"**.  
Note that a machine logo with the size of 124×19 pixels can make the best effect.
2. Insert the USB stick into the USB interface on the front panel of the PPU.
3. Locate the machine logo file in the USB stick through the following softkey operations:



Name	Type
mtbico	bmp



4. Copy the file with this softkey.



5. Press this softkey to enter the main screen of HMI data.

Name
Start-up archive
HMI data
NCK/PLC data
File for license key

6. Enter the folder related to HMI data.





7. Navigate to the highlighted folder shown below.

Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (alnc....txt)			
OEM MD description file (md_descr....txt)			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alncu....txt)			
OEM slideshow (*.bmp;*.png)			
OEM R variable name file (rparam_name....txt)			
Service planner task name file (svc_tasks....txt)			




8. Enter the folder and the default startup screen and machine logo files are placed in the folder.

Name	Type	Length
..		
OEM machine logo (mtbico.bmp)		
OEM start-up splash screen (startup.bmp)		



9. Press this softkey to replace the default machine logo file with your own machine logo file.



10. Press these two keys to restart the HMI. You can see your own machine logo in the following operating area.

MCS				T, F, S		15:35:26 2015/02/08	
MX1	0.000	0.000 mm	T	0	D	0	
MZ1	0.000	0.000 mm	F	0.000	70%	Axis feedrate	
			S1	0.0	80%		
G500(0)				G64			
						Act. val. REL	
						Act. val. Work (WCS)	
						Act. val. Mach (MCS)	
T, S, M				Set REL		Meas. tool	
						Sett.	

## Note

To restore the default "SIEMENS" logo display, delete the customized bitmap file (mtbico.bmp) from the control system.

## 9.4 Creating user cycles

The control system is integrated with standard Siemens cycles. If necessary, you can also create your own cycles.

To create a customized cycle, you must prepare the files shown below:

- User cycle file
- Extended user text file
- User cycle alarm file
- User cycle softkey index file
- User cycle parameter file
- User cycle bitmap file

### 9.4.1 Creating the extended user text file

The extended user text file is required for the display of respective screen texts, cycle messages and softkey texts.

#### Naming rule

**almc\_<LANG>.txt**

Here "<LANG>" refers to the language denotation, for example, eng.

For details on how to name an extended user text file, see Section "Multi-language support for the machine manufacturer's HMI data".

#### Text definition rules

When defining the texts, you must follow the rule below:

<Identifier> "<Text>" // <# chars & lines>

- <Identifier>: here you define the identifier with a number. The number ranges from 83000 to 84999.
- <Text>: here you define the actual text.
- <# chars & lines>: here you specify the available space for the text in the GUI in number of characters and lines. You can start a new line by inserting the character of "%n". A maximum of 2 lines with 9 characters each are available for softkey texts.

#### Examples

83000 "User%nCycles" // 2\*9 ⇒ two lines. Each line with nine characters space

83002 "CYCLE10" // 9 ⇒ one line with nine characters space

### 9.4.2 Creating the user cycle softkey index file

The user cycle softkey index file (cov.com) file is required to define the softkeys for the user cycle. You can create the cov.com file with a text editor like the WordPad or Notepad.

#### Text definition rules

Sx.y.z\\${identifier}\bitmap(cycle)

Parameters	Value range	Significance
X	5	The fifth horizontal key.
Y	1 to 8	The first to eighth vertical key in the first level.
Z	1 to 8	The first to eighth vertical key in the second level.
\\${identifier}	-	Defined in the cycle text file.
bitmap(cycle)	-	The bitmap for the user cycle. The bitmap name must be followed with name of the user cycle.



## Examples

S5.0.0\83000\ > define a softkey (identifier: 83000) at the horizontal key 5.

S5.1.0\83001\CN1(CYCLE100) > define a softkey (identifier: 83001) at the first vertical key of the first level when pressing the horizontal key 5.

M17

### 9.4.3 Creating the user cycle parameter file

The user cycle parameter file (sc.com) file is required to define the help information and the parameters for the user cycle. You can create the sc.com file with a text editor like the WordPad or Notepad.

#### Text definition rules

The "/" symbol indicates the beginning of a cycle description.

If you have created an image to display on the left of the screen at cycle start, call the image at the first line. The image is followed by the cycle name written in brackets.

Now define the parameters for the individual variables according to the format shown in the table below:

Line	Description of the parameters	Entry
1	Start of variable declaration	(
2	Variable type	R - REAL I - INTEGER C - CHAR S - STRING
3	Separator	/
4	<ul style="list-style-type: none"><li>Minimum value + space + maximum value</li><li>* + different values for selection</li></ul>	<ul style="list-style-type: none"><li>Minimum value + space + maximum value</li><li>* + different characters (use space to separate the different characters)</li></ul> <p>Note that you can also define different pictures for the characters.</p>
5	Separator	/
6	Default value	Value passed in the cycle if no entry is made.
7	Separator	/
8	Help information	\$ + the identifier defined in the cycle text file
9	End of variable declaration	)
10	Start of description	[
11	Short text	The text displayed in the parameter screen form (defined in the cycle text file).
12	Separator	/
13	Text in the screen	Text preceding the input screen. A maximum of 5 characters in length.
14	End of description	]
15	Line-specific image	/B name.bmp

#### Note

Separators, start and end identifiers must always be entered.

The lines 4, 6 and 15 can be left blank.

If no texts are stored with the \$identifier, three question marks appear in the associated fields on the screen.

### Example

```
//CN1(CYCLE100)
(R/0 99999.999//$83002)[$83003/DIA]
(R/0 99999.999//$83004)[$83005/DIAF]
(R/-9999.999 99999.999//$83004)[$83004/STAP]
(R/-9999.999 99999.999//$83025)[$83005/ENDP]
(R/0 99999.999//$83026)[$83006/MID]
(R/0 99999.999//$83027)[$83007/UX]
(I/*0 1 2/0/$83028)[$83008/MACH]/B CN1
(R/1 99999.999/1/$83029)[$83009/VRT]
M17
```

## 9.4.4 Creating the user cycle file

You can create a user cycle file according to different machining functions. It is a subroutine program that can be used at calling a cycle.

### Naming rule

CYCLExxx.SPF

Here "xxx" refers to the cycle number. It **must not** exceed four digits.

---

### Note

The name of a user cycle **must not** be same with that of a standard Siemens cycle. It is recommend to use a cycle number with the range of 100 to 800.

---

### Programming example

Create the program with a wordpad or notepad.

As a cycle screen always also transfers values as call parameters to the user cycle, the transfer interface is defined as follows.

```
PROC CYCLE100 (REAL DIA, REAL DIAF, REAL STAP, REAL ENDP, REAL MID, REAL UX, INT MACH, REAL VRT) SAVE SBLOF
DISPLOF
```

PROC is a keyword followed by the cycle name with the cycle number. All the transfer parameters for the screen are contained within brackets with the data type and name separated by commas.

```
PROC CYCLE100 (REAL DIA, REAL DIAF, REAL STAP, REAL ENDP, REAL MID, REAL
UX, INT MACH, REAL VRT) SAVE SBLOF DISPLOF
```

```
DEF REAL VAR1
IF $P_EP[X]<DIA GOTOF LL1
LL3:
IF DIAF>DIA GOTOF END2
START:
IF MACH==0 GOTOF ROUGHING1
IF MACH==1 GOTOF FINISHING
IF MACH==2 GOTOF ROUGHING1
DEF REAL VAR1
ROUGHING1:
R101=(DIA-DIAF)/2-UX
R102=R101/MID
R103=TRUNC(R102)
R104=0
VAR1=DIA
IF R103<=1 GOTOF ROUGHING2
LL2:
SBLON
G90 G0 X=VAR1 Z=STAP+2
```

```

G1 Z=ENDP
G91 X=MID
G0 G91 X=VRT Z=VRT
G90 G0 Z=STAP+2
SBLOF
VAR1=VAR1-2*MID
R104=R104+1
IF R104<=R103 GOTOB LL2
IF R104>R103 GOTOF ROUGHING2
ROUGHING2:
SBLON
G90 G0 X=DIAF+UX
G1 Z=ENDP
G0 G91X=VRT Z=VRT
G90 G0 X=DIA+2
Z=STAP+2
IF MACH==2 GOTOF FINISHING
SBLOF
RET
FINISHING:
SBLON
G0 X=DIAF
G1 Z=ENDP
G1 X=DIA+VRT
G0 G91X=VRT Z=VRT
G90 Z=STAP+2
SBLOF
RET
LL1:
IF $P_EP[Z]<STAP GOTOF END1
GOTOB LL3
END1:
SETAL(65000)
STOPRE
M0
RET
END2:
SETAL(65001)
STOPRE
M0
RET

```

### 9.4.5 Creating the user cycle alarm file

The user cycle alarm file is required to display alarm numbers and alarm messages for user cycles.

#### Naming rule

##### alc\_<LANG>.txt

Here "<LANG>" refers to the language denotation, for example, eng.

For details on how to name a user cycle alarm file, see Section "Multi-language support for the machine manufacturer's HMI data".

#### Text definition rules

When defining the texts, you must follow the rule below:

<AlarmNumber> "<Text>" // <# chars & lines>

- <AlarmNumber>: here you define the alarm number. The number ranges from 65000 to 79999.
- <Text>: here you define the actual alarm text.
- <# chars & lines>: here you specify the available space for the text in the GUI in number of characters and lines. You can start a new line by inserting the character of "%n".

## Examples

65000 "Current tool position is incorrect" // 34 ⇒ one lines with thirty-four characters space

65001 "DIAF is bigger than DIA" // 23 ⇒ one line with twenty-three characters space

### 9.4.6 Creating the user cycle bitmap file

The cycle icons **must** be stored as bitmap files (\*.bmp) with a maximum size of **224 \* 224** pixels in **16** colors.

The icon name **must** begin with an uppercase/lowercase "C" and its length **must not** exceed **32** characters including the file extension (e.g. CN1.bmp).

#### Note

If 16 colors are not sufficient for the display, you can also use 24-bit color depth bitmaps.

### 9.4.7 Transferring the desired files to the control system

Proceed as follows to transfer the required files to the control system.

#### Importing the cov.com file and sc.com file

1. Save the required file on a USB flash disk.
2. Insert the USB flash disk into the USB interface at the front of the PPU.
3. Select the desired operating area.
4. Press these two softkeys in succession.  
Then multi-select the cov.com and sc.com files with the following key:



→




Finally, copy them with the following key:



5. Press this softkey and access the folder "HMI data" > "User cycle files".  
Replace the empty files with the following:





→




#### Importing the user cycle alarm file

1. Save the required file on a USB flash disk.
2. Insert the USB flash disk into the USB interface at the front of the PPU.
3. Select the desired operating area.





→



- Press these two softkeys in succession.  
Then select a user cycle alarm file (for example, alc\_eng.txt) with the following key:



Finally, copy it with the following key:





- Press this softkey and access the folder "HMI data" > "User cycle files" > "User cycle alarm file".


Then paste the file with the following:



### Importing the bitmap file



→




- Save the required file on a USB flash disk.
- Insert the USB flash disk into the USB interface at the front of the PPU.
- Select the desired operating area.

- Press these two softkeys in succession.  
Then select a bitmap file (for example, cn1.bmp) with the following key:



Finally, copy it with the following key:



- Press this softkey and access the folder "HMI data" > "User cycle files" > "User cycle bitmap file".


Then paste the file with the following:




→

Name	Type	Length	Date	Time
..				
cn1	bmp	506.30 KB	11/04/19	03:16:43
ico1024	DIR		12/01/06	03:11:39
ico1280	DIR		12/01/06	03:11:39
ico1600	DIR		12/01/06	03:11:39
ico640	DIR		12/01/06	03:11:39
ico800	DIR		12/01/06	03:11:39

### Importing the user cycle file



- Save the required file on a USB flash disk.
- Insert the USB flash disk into the USB interface at the front of the PPU.
- Select the desired operating area.




→



4. Press these two softkeys in succession.  
Then select a user cycle file (for example, CYCLE100) with the following key:



Finally, copy it with the following key:




5. Press this softkey and then paste the file with the following:




→

Name	Type	Length	Date	Time
CYCLE100	SPF	944 B	12/03/05	10:55:00

### Importing the extended user text file




→



1. Save the required file on a USB flash disk.
2. Insert the USB flash disk into the USB interface at the front of the PPU.
3. Select the desired operating area.
4. Press these two softkeys in succession.  
Then select an extended user text file (for example, almc\_eng.txt) with the following key:




Finally, copy it with the following key:



5. Press this softkey and access the folder "HMI data" > "Extended user text file".  
Then paste the file with the following:



→



### Note

After you import the cov.com file, sc.com file, alc\_xxx.txt file, and almc\_xxx.txt file into the control, a message appears, prompting you to restart the HMI. Then press the following key to restart the HMI so that the new data can be active:



## 9.4.8 Call the created user cycle

After you transfer all the files necessary for your own cycle to the control system, the cycle is created successfully. Then you can use the cycle in the <PROGRAM> operating area.


Proceed as follows to call the created cycle, for example, CYCLE888.



1. Press this hardkey on the PPU, and the following horizontal softkey appears after you import the desired files into the control. Then press this softkey.


user  
Cycle

→



user  
Cycle888

2. Press this softkey to open the following window.




3. Set the parameters as desired, and then press one of the following two softkeys.

Cancel

: quit the cycle.

OK

: save the settings. Then the following screen appears, indicating that the user cycle is saved.



## 9.4.9 Editing the user cycle screens

You can edit the softkeys, identifiers, bitmaps or parameters for user cycles.

To do so, export the relevant files and edit them on a PC. After that, import them back to the respective folders and restart the control system.

## 9.5 Loading machine manufacturer's MD description files

Perform the following operations to access the "OEM MD description file" folder:



Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (alnc....txt)			
<b>OEM MD description file (md_descr....txt)</b>			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alnc....txt)			
OEM slideshow (*.bmp;*.png)			
OEM R variable name file (rparam_name....txt)			
Service planner task name file (svc_tasks....txt)			




In the factory setting, the MD description files in the two default languages are prepared on the control but invisible to the machine manufacturer.

The machine manufacturer can load files of this type only after modifying the description of at least one of their MDs.

The detailed procedure is as follows:

1. Select the desired operating area.
2. Press these two softkeys in succession.  
Then select a certain MD with the cursor keys and then press the following:





3. In the following dialog, edit the description text of the MD as desired, for example:

888
Name : USER_DATA_INT

Then save the modification with the following:



4. Access the "OEM MD description file" folder by performing the steps mentioned above. At this time, a file containing the change log in the corresponding language exists in the folder.

Name
..
md_descr_eng.txt

5. Press these two softkeys in succession to copy the file and then open the desired window. In the opened window, paste the file with the following:



→



→

Name
CYCLE888
MD_DESCR_CHS
MD_DESCR_ENG
RPARAM_NAME_ENG

6. Open the file with this hardkey. Then you can view the change that you made.



```

NC:\CMA\MD_DESCR_ENG.TXT
T_MN_USER_DATA_HEX_IDX4 "888" // 0f
T_MN_USER_DATA_INT_IDX0 "111" // 3f
T_MN_USER_DATA_INT_IDX1 "888" // 0f
T_MN_USER_DATA_INT_IDX2 "User data (INT" // 0f
==eof==

```


## 9.6 Loading machine manufacturer's R variable name files

Perform the following operations to access the "OEM R variable name file" folder:



→

Name	Type	Length	Date
..			
Customized bitmaps			
User cycle files			
EasyXLanguage scripts			
OEM online help (*.txt;*.png;*.bmp)			
Extended user text file (almc....txt)			
OEM MD description file (md_descr....txt)			
OEM manual (oemmanual.pdf)			
PLC alarm texts (alcu....txt)			
OEM slideshow (*.bmp;*.png)			
<b>OEM R variable name file (rparam_name....txt)</b>			
Service planner task name file (svc_tasks....txt)			



In the factory setting, the R variable name files in the two default languages are prepared on the control but invisible to the machine manufacturer.

The machine manufacturer can load files of this type only after defining the name of at least one of their R variables.

The detailed procedure is as follows:



1. Select the desired operating area.



2. Press these two softkeys in succession.  
Then select a certain R variable with the cursor keys.

→



3. In the following dialog, define the name of the R variable as desired, for example:


R variables		
No .	Name	Value
R0	111	111.000000
R1		0.000000

Then save your input with the following:



4. Access the "OEM R variable name file" folder by performing the steps mentioned above.  
At this time, a file containing the change log in the corresponding language exists in the folder.

Name
..
<b>rparam_name_eng.txt</b>




→



- Press these two softkeys in succession to copy the file and then open the desired window.  
In the opened window, paste the file with the following:



→



- Open the file with this hardkey.  
Then you can view the change that you made.



## 10 Technical data

### 10.1 SINUMERIK 808D ADVANCED




	PPU		MCP	
	Horizontal variant (161.2)	Vertical variant (160.2)	Horizontal variant	Vertical variant
Design data				
Dimensions (W x H x D) (in mm)	420 x 200 x 104	265 × 330 × 104	420 x 120 x 58	265 × 230 × 58
Weight (in kg)	2.985	2.865	0.86	0.795 (variant with a reserved slot for the handwheel)
				0.935 (variant with an override switch for the spindle)
Cooling method	Self-cooling		Self-cooling	
Degree of protection	Front side: IP65 Back side: IP20		Front side: IP65 Back side: IP00	
Electrical data				
Supply voltage	24 VDC (permissible range: 20.4...28.8 V)		Powered by PPU	
Ripple	3.6 Vpp		-	
Current consumption from 24 V	Basic configuration typically 1.5 A (inputs/outputs open)		-	
Non-periodic overvoltage	35 V (500 ms duration, 50 s recovery time)		-	
Total starting current	1 A		-	
Rated input current	2 A		0.5 A	
Power loss	max. 50 W		max. 5 W	
Interference immunity in accordance with EN 61800-3	≥ 20 μs		≥ 20 μs	
Overvoltage category	3		3	
Degree of pollution	2		2	





	PPU		MCP	
	Horizontal variant (161.2)	Vertical variant (160.2)	Horizontal variant	Vertical variant
Transport and storage conditions				
Temperature	-20 °C to +60 °C		-20 °C to +60 °C	
Vibration resistance (transport)	5 Hz to 9 Hz: 3.5 mm 9 Hz to 200 Hz: 1g		5 Hz to 9 Hz: 3.5 mm 9 Hz to 200 Hz: 1g	
Shock resistance (transport)	10 g peak value, 6 ms duration 100 shocks in each of the 3 axes vertical to one another			
Free fall	< 1 m		<1 m	
Relative humidity	5% to 95%, without condensation		5% to 95%, without condensation	
Atmospheric pressure	1060 hPa to 700 hPa (corresponds to an altitude of 3,000 m)			
Ambient operating conditions				
Temperature	0 °C to 45 °C			
Atmospheric pressure	From 1080 hPa to 795 hPa		From 1080 hPa to 795 hPa	
Vibration resistance (in operation)	10 Hz to 58 Hz: 0.35 mm 58 Hz to 200 Hz: 1g		10 Hz to 58 Hz: 0.35 mm 58 Hz to 200 Hz: 1g	
Shock resistance (in operation)	10 g peak value, 6 ms duration 6 shocks in each of the 3 axes vertical to each other			
Certification	CE, KCC <sup>1)</sup> , and EAC		CE and EAC	

<sup>1)</sup> The KCC certification is released along with Siemens inverter G120 and currently valid only for PPU161.2.

## 10.2 SINAMICS V70 servo drives

Order No.	6SL3210-5DE...	12-4UA0	13-5UA0	16-0UA0	17-8UA0	21-0UA0	21-4UA0	21-8UA0
Rated output current (A)		1.2	3.0	4.6	5.3	7.8	11.0	13.2
Max. output current (A)		3.6	9.0	13.8	15.9	23.4	33.0	39.6
Max. supported motor power (kW)		0.4	1.0	1.5	1.75	2.5	3.5	7.0
Output frequency (Hz)		0 to 330						
Power supply	Voltage/frequency	3 phase 380 VAC to 480 VAC, 50/60 Hz						
	Permissible voltage fluctuation	-15% to +10%						
	Permissible frequency fluctuation	-10% to +10%						
	Rated input current (A)	1.5	3.8	5.8	6.6	9.8	13.8	16.5
	Power supply capacity (kVA)	1.7	4.3	6.6	7.6	11.1	15.7	18.9
	Inrush current (A)	8.0	8.0	4.0	4.0	4.0	2.5	2.5
24 VDC power supply	Voltage (V) <sup>1)</sup>	24 (-15% to +20%)						
	Maximum current (A)	1 A (when using a motor without a brake) 3 A (when using a motor with a brake)						


Order No.	6SL3210-5DE...	12-4UA0	13-5UA0	16-0UA0	17-8UA0	21-0UA0	21-4UA0	21-8UA0
Overload capability			300%					
								
Control system			Servo control					
Braking resistor			Built-in					
Protective functions			Earthing fault protection, output short-cut protection, overvoltage/undervoltage protection, I²t detection, IGBT overtemperature protection					
Cooling method			Self-cooled		Fan-cooled			
Environmental conditions	Surrounding air temperature	Operation	0 °C to 45 °C: without power derating 45 °C to 55 °C: with power derating					
								
		Storage	-40 °C to +70 °C					
	Ambient humidity	Operation	< 90% (non-condensing)					
		Storage	90% (non-condensing)					
	Operating environment		Indoor (without direct sunlight), free from corrosive gas, combustible gas, oil gas, or dust					
	Altitude		< 1000 m (without derating)					
								
	Degree of protection		IP20					
	Degree of pollution		Class 2					
Vibration	Operation	Shock:	Operational area II Peak acceleration: 5 g Duration of shock: 30 ms					
		Vibration:	Operational area II 10 Hz to 58 Hz: 0.075 mm deflection 58 Hz to 200 Hz: 1g vibration					

Order No.	6SL3210-5DE...		12-4UA0	13-5UA0	16-0UA0	17-8UA0	21-0UA0	21-4UA0	21-8UA0
		Transport & storage	Vibration:	5 Hz to 9 Hz: 7.5 mm deflection 9 Hz to 200 Hz: 2 g vibration Vibration class: 2M3 transportation					
Certification	   								
Mechanical design	Outline dimensions (W x H x D, mm)		80 x180 x200		100 x 180 x 220			140 x 260 x240	
Weight (kg)			1.85		2.45			5.65	

1) When the SINAMICS V70 works with a motor with brake, the voltage tolerance of 24 VDC power supply must be -10% to +10% to meet the voltage requirement of the brake.

## 10.3 SIMOTICS S-1FL6 servo motors

### General technical data

Parameter		Description		
Type of motor		Permanent-magnet synchronous motor		
Cooling		Self-cooled		
Operating temperature [°C]		0 to 40 (without power derating)		
Storage temperature [°C]		-15 to +65		
Relative humidity [RH]		≤ 90% (non-condensing at 30°C)		
Installation altitude [m]		≤ 1000 (without power derating)		
Maximum noise level [dB]		1FL604□: 65 1FL606□: 70 1FL609□: 70		
Thermal class		B		
Vibration severity grade		A (Acc. to IEC 60034-14)		
Shock resistance [m/s²]		25 (continuous in axial direction); 50 (continuous in radial direction); 250 (in a short time of 6 ms)		
Holding brake	Rated voltage (V)	24 ± 10%		
	Rated current (A)	1FL604□: 0.88	1FL606□: 1.44	1FL609□: 1.88
	Holding brake torque [Nm]	1FL604□: 3.5	1FL606□: 12	1FL609□: 30
	Maximum brake opening time [ms]	1FL604□: 60	1FL606□: 180	1FL609□: 220
	Maximum brake closing time [ms]	1FL604□: 45	1FL606□: 60	1FL609□: 115
	Maximum number of emergency stops	2000 <sup>1)</sup>		
Bearing lifetime [h]		> 20000 <sup>2)</sup>		
Oil seal lifetime [h]		5000		
Encoder lifetime [h]		20000 to 30000 (when load factor ≤ 80% and at 30 °C) <sup>3)</sup>		
Paint finish		Black		
Degree of protection		IP65, with shaft oil seal		
Type of construction		IM B5, IM V1 and IM V3		
Positive rotation		 Clockwise (default setting in SINAMICS V70 servo drives)		

Parameter	Description
Certification	

- 1) Restricted emergency stop operation is permissible. Up to 2000 braking operations can be executed with 300% rotor moment of inertia as external moment of inertia from a speed of 3000 RPM without the brake being subject to an inadmissible amount of wear.
- 2) This lifetime is only for reference. When a motor keeps running at rated speed under rated load, replace its bearing after 20,000 hours to 30,000 hours of service time. Even if the time is not reached, the bearing must be replaced when unusual noise, vibration, or faults are found.
- 3) This lifetime is only for reference. When a motor keeps running at 80% rated value and the surrounding air temperature is 30 °C, the encoder lifetime can be ensured.

#### Specific technical data

Order No.	1FL60...	42	44	61	62	64	66	67	90	92	94	96
Rated power [kW]		0.40	0.75	0.75	1.00	1.50	1.75	2.00	2.5	3.5	5.0	7.0 <sup>1)</sup>
Stall torque [Nm]		1.9	3.5	4	6	8	11	15	15	22	30	40
Rated torque [Nm]		1.27	2.39	3.58	4.78	7.16	8.36	9.55	11.9	16.7	23.9	33.4
Maximum torque [Nm]		3.8	7.2	10.7	14.3	21.5	25.1	28.7	35.7	50.0	70.0	90.0
Rated speed [rpm]		3000		2000					2000			
Maximum speed [rpm]		4000		3000					3000		2500	2000
Rated frequency [Hz]		200		133					133			
Rated current [A]		1.2	2.1	2.5	3.0	4.6	5.3	5.9	7.8	11.0	12.6	13.2
Maximum current [A]		3.6	6.3	7.5	9.0	13.8	15.9	17.7	23.4	33.0	36.9	35.6
Stall current [A]		1.7	2.9	2.7	3.6	4.9	6.6	8.8	9.3	13.4	15	15
Moment of inertia [10 <sup>-4</sup> kgm <sup>2</sup> ]		2.7	5.2	8.0	15.3	15.3	22.6	29.9	47.4	69.1	90.8	134.3
Moment of inertia (with brake) [10 <sup>-4</sup> kgm <sup>2</sup> ]		3.2	5.7	9.1	16.4	16.4	23.7	31.0	56.3	77.9	99.7	143.2
Recommended load to motor inertia ration		< 1000%		< 500%					< 500%			
Weight of incremental encoder motor [kg]	With brake	4.6	6.4	8.6	11.3	11.3	14.0	16.6	21.3	25.7	30.3	39.1
	Without brake	3.3	5.1	5.6	8.3	8.3	11.0	13.6	15.3	19.7	24.3	33.2
Weight of absolute encoder motor [kg]	With brake	4.4	6.2	8.3	11.0	11.0	13.6	16.3	20.9	25.3	29.9	38.7
	Without brake	3.1	4.9	5.3	8.0	8.0	10.7	13.3	14.8	19.3	23.9	32.7

- 1) When the surrounding air temperature is higher than 30 °C, the 1FL6096 motors with brake will have a power derating of 10%.

#### Note

The data of stall torque, rated power, and maximum torque in the above table allow a tolerance of 10%.


#### Power derating

For deviating conditions (surrounding air temperature > 40 °C or installation altitude > 1000 m above sea level), the permissible torque/power must be determined from the following table. Surrounding air temperatures and installation altitudes are rounded off to 5 °C and 500 m respectively.

# Power derating as a function of the installation altitude and surrounding air temperature

Installation altitude above sea level (m)	Surrounding air temperature (°C)				
	< 30	30 to 40	45	50	55
1000	1.07	1.00	0.96	0.92	0.87
1500	1.04	0.97	0.93	0.89	0.84
2000	1.00	0.94	0.90	0.86	0.82
2500	0.96	0.90	0.86	0.83	0.78
3000	0.92	0.86	0.82	0.79	0.75
3500	0.88	0.82	0.79	0.75	0.71
4000	0.82	0.77	0.74	0.71	0.67

## Torque-speed characteristics







## Note

1. Continuous operating area is a series of states when a motor can operate continuously and safely. The effective torque must be located in this area.
2. Short-term operating area is a series of states when a motor can operate in a short duration if its effective torque is smaller than the rated torque.
3. For the motors with different rated and maximum speeds, the output torque will decline at a faster rate after the speed exceeds the rated speed.
4. The feature in short-term operating area varies with power supply voltages.
5. The continuous operating area becomes smaller and the voltage drop grows larger when the cables in the major loop exceed 20 meters.
6. For 1FL6096 motors, the maximum speed can be ensured when the line supply voltage is higher than 380 V.


## Permissible radial and axial forces



1FL604□



1FL606□



1FL609□

### Axial force:

When using, for example, helical toothed wheels as drive element, in addition to the radial force, there is also an axial force on the motor bearings. For axial forces, the spring-loading of the bearings can be overcome so that the rotor moves corresponding to the axial bearing present (up to 0.2 mm).

The permissible axial force can be approximately calculated using the following formula:

$$F_A = 0.35 \cdot F_R$$

Where  $F_A$  represents axial force and  $F_R$  radial force.

## Note

1FL604□ and 1FL609□ have a 5 mm of shaft sheltered in sleeves, and 1FL606□ has an 8 mm of shaft in sleeves. Therefore, the distances to flange in the above three figures begin respectively from 5 mm, 8 mm, and 5 mm.

## 10.4 Cables

### 10.4.1 Drive Bus cable/Drive Bus trailing cable for the SINUMERIK 808D ADVANCED

Parameter	Drive Bus cable	Drive Bus trailing cable
Jacket material	PVC	PUR
Degree of protection	IP20	IP20
Number of cores	2	2
Operation voltage (V)	100	100
Operation temperature, static (°C)	-40 to 80	
Operation temperature, dynamic (°C)	-	-25 to 80
Shielding	Yes	
Minimum bending radius, static (mm)	75	50
Minimum bending radius, dynamic (mm)	-	155
Bending cycles	-	3000000 (maximum acceleration: 5 m/s <sup>2</sup> ; maximum horizontal speed: 3 m/s)
Oil resistance	Limited mineral oil and fats resistance EN60811-2-1 fulfilled	
Flame-retardant	IEC60332-3-24 fulfilled	IEC60332-1-1 to 1-3 fulfilled
Certification	RoHS	

### 10.4.2 Technical data - cables for the SINAMICS V70 servo system

Parameter	MOTION-CONNECT 300 power cable	MOTION-CONNECT 300 encoder cable	MOTION-CONNECT 300 brake cable
Jacket material	PVC		
Degree of protection (motor-side only)	IP65		
Number of cores	4	10	2
Cross-section of cores (mm <sup>2</sup> )	4 x 1.5 (for FSA) 4 x 2.5 (for FSB/FSC)	6 x 0.22 + 4 x 0.25	2 x 0.75
Operation voltage (V)	600/1000	30	30
Operation temperature (°C)	-25 to 80		
Shielding	Yes		
Minimum bending radius, static (mm)	6 x outer diameter		
Minimum bending radius, dynamic (mm)	155		
Bending cycles	1000000 (maximum acceleration: 2 m/s <sup>2</sup> ; maximum speed: 15 m/min)		
Oil resistance	EN60811-2-1 fulfilled		
Flame-retardant	EN60332-1-1 to 1-3 fulfilled		
Certification	RoHS and CE	RoHS	RoHS

## A Appendix

### A.1 Operation and display

#### A.1.1 Elements on the PPU

The PPU for the control system is available in the following variants:

PPU version	Panel layout	Applicable control system
PPU161.2	Horizontal, English version Horizontal, Chinese version	SINUMERIK 808D ADVANCED T (turning)/M (milling)
PPU160.2	Vertical, English version Vertical, Chinese version	SINUMERIK 808D ADVANCED T (turning)/M (milling)

##### Horizontal panel layout (PPU161.2)




##### Vertical panel layout (PPU160.2)



## Elements on the PPU front

The following illustration uses PPU161.2 as an example to show control elements available on the PPU:




- ① **Vertical and horizontal softkeys**  
Calls specific menu functions
- ② **Return key**  
Returns to the next higher-level menu
- ③ **Menu extension key**  
Opens the next lower-level menu
- ④ **Alphabetic and numeric keys**
- ⑤ **Control keys**
- ⑥ **Alarm cancellation key**  
Cancels alarms and messages that are marked with this symbol
- ⑦ **On-board wizard key**  
Provides step-by-step guides on basic commissioning and operation procedures
- ⑧ **Help key**  
Calls help information
- ⑨ **Cursor keys**
- ⑩ **Operating area keys**
- ⑪ **USB interface**
- ⑫ **Status LEDs**

## A.1.2 Elements on the MCP


The MCP for the control system is available in the following variants:

MCP version	Applicable control system
<ul style="list-style-type: none"> <li>Horizontal MCP, English version</li> <li>Horizontal MCP, Chinese version</li> <li>Vertical MCP with a reserved slot for the handwheel, English version</li> <li>Vertical MCP with a reserved slot for the handwheel, Chinese version</li> <li>Vertical MCP with an override switch for the spindle, English version</li> <li>Vertical MCP with an override switch for the spindle, Chinese version</li> </ul>	SINUMERIK 808D ADVANCED T (Turning)/M (Milling)

## Horizontal MCP



## Vertical MCP (left: version with an override switch for the spindle; right: version with a reserved handwheel slot)




- ① **Reserved hole for emergency stop button**
- ② **Handwheel key**  
Controls the axis movement with external handwheels
- ③ **Tool number display**  
Displays the number of the currently active tool
- ④ **Operating mode keys**
- ⑤ **Program control keys**
- ⑥ **User-defined keys**
- ⑦ **Axis traversing keys**
- ⑧ **Spindle override switch**  
(unavailable for the vertical MCP with a reserved slot for the handwheel)
- ⑨ **Spindle state keys**
- ⑩ **Feedrate override switch**  
Traverses the selected axis at the specified feedrate override
- ⑪ **Keys for program start, stop, and reset**

## A.1.3 Operating the SINAMICS V70 Basic Operator Panel (BOP)

### A.1.3.1 BOP overview



The SINAMICS V70 servo drive has been designed with a Basic Operator Panel (BOP) located on the front of the drive:
















You can use the BOP for following operations:











- Standalone commissioning
- Diagnosis
- Parameter access
- Parameter settings
- SD card operations
- Drive restart



















#### Button functions

Button	Description	Remarks
	M button	<ul style="list-style-type: none"> <li>• Exits from current menu</li> <li>• Switches between operating modes in the top level menu</li> </ul>
	OK button	<p>Short-pressing:</p> <ul style="list-style-type: none"> <li>• Confirms selection or input</li> <li>• Enters sub menu</li> <li>• Acknowledges faults</li> </ul> <p>Long-pressing:</p> <ul style="list-style-type: none"> <li>• Activates auxiliary functions</li> <li>• Sets Drive Bus address</li> <li>• Jog</li> <li>• Saves parameter set in drive (RAM to ROM)</li> <li>• Sets parameter set to default</li> <li>• Transfers data (drive to SD card)</li> <li>• Transfers data (SD card to drive)</li> <li>• Updates firmware</li> </ul>

Button	Description	Remarks
	UP button	<ul style="list-style-type: none"> <li>• Navigates to next item</li> <li>• Increases a value</li> <li>• JOG in CW (clockwise)</li> </ul>
	DOWN button	<ul style="list-style-type: none"> <li>• Navigates to previous item</li> <li>• Decreases a value</li> <li>• JOG in CCW (counter-clockwise)</li> </ul>
	SHIFT button	Moves the cursor from digit to digit for single digit editing, including the digit of positive/negative signs
Button combinations		
 + 	Press this button combination for four seconds to restart the drive.	
 + 	Moves the current display to the left page when  is displayed at the upper right corner, for example  .	
 + 	Moves the current display to the right page when  is displayed at the lower right corner, for example  .	

#### BOP display

Display	Example	Description	Remarks
8.8.8.8.8.8.		Drive is in startup state	Takes 20 s to 30 s
-----		Drive is busy	In the case of a task being executed
Fxxxxx		Fault code	In the case of a single fault
F.xxxxx.		Fault code of the first fault	In the case of multiple faults
Fxxxxx.		Fault code	In the case of multiple faults
Axxxxx		Alarm code	In the case of a single alarm
A.xxxxx.		Alarm code of the first alarm	In the case of multiple alarms
Axxxxx.		Alarm code	In the case of multiple alarms
Rxxxxx		Parameter number	Read-only parameter
Pxxxxx		Parameter number	Editable parameter


Display	Example	Description	Remarks
P.xxxx		Parameter number	Editable parameter; the dot means that at least one parameter has been changed
In xx		Indexed parameter	Figure after "In" indicates the number of indices. For example, "In 01" means that this indexed parameter is 1.
xxx.xxx		Negative parameter value	-
xxx.xx<>		Current display can be moved to left or right	-
xxxx.xx>		Current display can be moved to right	-
xxxx.xx<		Current display can be moved to left	-
S Off		Operating display: servo off	-
Para		Editable parameter group	-
P.ara		Editable parameter group	The dot means that at least one parameter has been changed without saving
Data		Read-only parameter group	-
Func		Function group	Refer to Auxiliary functions (Page 144).
Addr		Set Drive Bus address	Refer to Setting Drive Bus address (Page 145).
Jog		Jog function	Refer to Jog (Page 145).
Save		Save data in drive	Refer to Saving parameter set in drive (RAM to ROM) (Page 146).
defu		Restore drive to default settings	Refer to Setting parameter set to default (Page 146).
dr--sd		Save data from drive to SD card	Refer to Transferring data (drive to SD card) (Page 147).
sd--dr		Upload data from SD card to drive	Refer to Transferring data (SD card to drive) (Page 147).
Update		Update firmware	Refer to Updating firmware (Page 148).



Display	Example	Description	Remarks
Con		The Drive Bus communication between the NC and the servo drive is established.  In this case, the BOP is protected from any operations except clearing alarms and acknowledging faults.	-

### A.1.3.2 Parameter structure

You can navigate through the parameter structure by pressing the keys as shown in the sequences below.



### A.1.3.3 Actual status display

You can monitor the following drive states by using the operating panel after power-on:

- Servo off
- Actual speed
- Torque
- Voltage

If the servo enable signal is available, actual drive speed is displayed by default; otherwise, "**S OFF**" (servo off) is displayed.

With p29002, you define which of the following drive operating status data is to be displayed on the BOP.

Value	Meaning
0 (default)	Actual speed
1	DC voltage
2	Actual torque

---

#### Note

Make sure you save p29002 after modification.

---

### A.1.3.4 Basic operations

#### Editable parameters

All **P** parameters under the "Para" menu are editable parameters.

#### Read-only parameters

All **r** parameters under the "Data" menu are read-only parameters.

#### Parameters with index

Some parameters have several indices. Each index has its own meaning and corresponding value.

#### Parameters without index

All parameters that do not have indices are parameters without index.


#### Editing parameters

You can edit a parameter value in two methods:

- Method 1: change the value directly with the **UP** or **DOWN** button
- Method 2: move the cursor to a digit with the **SHIFT** button, then change the digit value with the **UP** or **DOWN** button

If you change a parameter value with method 1, proceed as follows:


Operating display



For more information, see Section "Jog test (Page 75)".

To change a parameter value digit by digit, proceed as follows:

Operating display




#### Note

You cannot change parameters p1414 and p1656 with the **SHIFT** button.

## Viewing parameters


If a parameter has no index, view its value as follows:

Operating display




If a parameter has indices, view its value as follows:

Operating display



## A.1.3.5 Auxiliary functions

Seven BOP functions in total are available:



- |                                |   |
|--------------------------------|---|
| ① Set Drive Bus address        | ⑤ Copy parameter set from drive to an SD card |
| ② Jog                          | ⑥ Copy parameter set from an SD card to drive |
| ③ Save parameter set in drive  | ⑦ Update firmware                             |
| ④ Set parameter set to default |   |


## Setting Drive Bus address

When connecting the SINAMICS V70 to the SINUMERIK 808D ADVANCED, you must set the Drive Bus address with the BOP. Four addresses in total are available:

- 11: X axis
- 12: Y axis (or additional axis for the turning variant of the control system)
- 13: Z axis
- 15: Additional axis

You must set a proper address according to the actual application of the drive.

To set Drive Bus address with the BOP, proceed as follows.




### Note

After setting a proper address, you must restart the drive to apply your setting.

For more information, see Section "Configuring Drive Bus addresses (Page 78)".

## Jog

To run the connected motor with the Jog function and view the Jog speed or Jog torque, proceed as follows:




For more information, see Section "Jog test (Page 75)".

**Saving parameter set in drive (RAM to ROM)**

This function is used for saving a parameter set from drive RAM to drive ROM.

To use this function, proceed as follows:



**NOTICE**

Plugging or unplugging the SD card will cause saving failure.  
Do not plug or unplug the SD card during saving; otherwise, the saving operation will fail.

**Note**

If an SD card has been inserted, the parameter set will be saved onto the SD card simultaneously.


**Reference**

Editing parameters (Page 142)

**Setting parameter set to default**

This function is used to reset all parameters to their default values.

To reset all parameters to their default values, proceed as follows:



**Note**


You **must** save the parameter set after resetting it; otherwise, the default values will not be activated.

**Reference**

Saving parameter set in drive (RAM to ROM) (Page 146)

### Transferring data (drive to SD card)

You can transfer the parameter set from the drive to an SD card with the BOP. To do this, proceed as follows:



#### NOTICE

**It is forbidden to use this function when the servo is ON.**

Use this function when the servo is OFF.

#### NOTICE

**Plugging or unplugging the SD card will cause transferring failure.**


Do not plug or unplug the SD card during transferring; otherwise, the transferring operation will fail.

#### Note

Write protection function is not supported by the SINAMICS V70. Data in the SD card will be overwritten even if the write protection function of the SD card is enabled.

### Transferring data (SD card to drive)

You can also transfer the parameter set from an SD card to the drive. To do this, proceed as follows:



#### NOTICE

**It is forbidden to use this function when the servo is ON.**

Use this function when the servo is OFF.

#### NOTICE

**Plugging or unplugging the SD card will cause transferring failure.**

Do not plug or unplug the SD card during transferring; otherwise, the transferring operation will fail.


#### Note

##### Parameter inconsistency

If the parameters on the SD card are inconsistent with existing parameters in the drive memory, you **must** save and restart the servo drive to apply the changes.

## Updating firmware

With the firmware update function of the BOP, you can update drive firmware. To do this, you have to store proper firmware files on an SD card and insert it into the SD card slot. After that, proceed as follows:



### ! CAUTION

#### Improper firmware files will cause update failure.

When the update fails, the RDY indicator flashes red at 2 Hz and the COM indicator becomes red on. An update failure is probably caused by improper firmware files or files missing.

- If the firmware files on the SD card are corrupt, the servo drive **cannot** start up after power-on.
- If the firmware on the SD card is the same with the current firmware of the servo drive, **only** a restart is performed.

When a failure occurs, try to update the firmware again using proper firmware files. If the failure persists, contact your local distributor.

### Note


#### Update the firmware by restarting the drive.

After inserting the SD card with proper firmware files, you can also update the firmware by restarting the drive.

## A.1.4 Status indicators

### Status LEDs on the SINAMICS V70 drive

Two LED status indicators (RDY and COM) are available to indicate drive readiness status and communication status respectively.






You can find detailed information about the status indications in the table below:

Status indicator	Color	Status	Description
RDY	-	Off	24V control board power supply is missing
	Green	Continuously lit	Drive is ready
	Red	Continuously lit	Enable signal is missing or drive is in startup states
		Flashing at 1 Hz	Alarms or faults occur
COM	Red and Or-ange	Flashing alternatively at an interval of 0.5 s	The servo drive is located
	Green	Off	Communication with CNC is not active
		Flashing at 0.5 Hz	Communication with CNC is active
	Red	Flashing at 2 Hz	SD card operating (read or write)
		Continuously lit	Communication with CNC is in error

### Status LEDs on the PPU



The individual LEDs and their functions are described in the table below:

LED	Color	Status	Description
POK	Green	Continuously lit	The power supply for the CNC is switched on.
RDY	Green	Continuously lit	The CNC is ready and the PLC is in run mode.
		Continuously lit	The PLC is in stop mode.
	Orange	Flashing	The PLC is in power-up mode.
		Continuously lit	The CNC is in stop mode.
TEMP	Orange	Continuously lit	The CNC temperature is out of range.
	Unlit	Continuously lit	The CNC temperature is within the specified range.

















## A.2 Configuring the additional axis



The control system with PPU16x.2 supports up to two additional axes for the turning variant and one for the milling variant. Before the configuration, you must first activate the option for additional axis (Page 83). However, you need to configure the additional axis manually as you cannot proceed with the wizards.

### A.2.1 Setting parameters for the additional axis (turning)

#### Operating sequence

Proceed as follows to set the parameters for an additional axis (driven tooling axis):

1. Select the desired operating area on the PPU.  
 + 
2. Open the channel machine data window through the following softkey operations:  
 →  → 
3. Use this softkey or the cursor keys to search for the following machine data and assign the desired values:
  - 20070[3] = 5
  - 20080[3] = SP2
4. Open the general machine data window and make the following parameter settings:
  - 10000[4] = MSP2
  - 19100 = 4
5. Press this key to return to the next higher-level menu.  

6. Open the basic machine data window.  

7. Use this softkey or the cursor keys to search for "14512 USER\_DATA\_HEX[20]".  

8. Select "Bit2" by using this key and the cursor keys.  

9. Press this softkey to confirm your input.  

10. Press this softkey to activate the value changes. Note that the control system restarts to accept the new values and the additional axis can be used in the system.  

11. Configure the additional drive in the system. For more information, refer to "Configuring the drive and motor (Page 152)".
12. Select the desired operating area on the PPU.  
 + 
13. Open the axis machine data window through the following softkey operations:  
 →  → 



14. Use these softkeys to set  $35000 = 2$  for the MSP2 axis.

15. Press this softkey to activate the value changes. Note that the control system restarts to accept the new values.

---

### Note

The factory default PLC program only supports one additional axis.

---

## A.2.2 Setting parameters for the additional axis (milling)


### Operating sequence

Proceed as follows to set the parameters for an additional axis (rotary axis):



1. Select the desired operating area on the PPU.

2. Open the channel machine data window through the following softkey operations:



3. Use this softkey or the cursor keys to search for the following machine data and assign the desired values:

- $20070[4] = 5$
- $20080[4] = A$



4. Open the general machine data window and set  $19100 = 5$ .



5. Press this key to return to the next higher-level menu.



6. Open the basic machine data list.



7. Use this softkey or the cursor keys to search for "14512 USER\_DATA\_HEX[20]".



8. Select "Bit2" by using this key and the cursor keys.



9. Press this softkey to confirm your input.



10. Press this softkey to activate the value changes. Note that the control system restarts to accept the new values and the additional axis can be displayed in the system.

---

### Note

The factory default PLC program only supports one additional axis.

---

## A.2.3 Configuring the drive and motor

Before starting the drive and motor configuration, you must ensure the Drive Bus address is properly set (p0918) via the drive BOP. For more information about setting the Drive Bus address, see section "Configuring Drive Bus addresses (Page 78)".

The following steps are also applicable to configuring the feed axes or the analog spindle, if necessary.

### Operating sequence



1. Select the desired operating area on the PPU.



2. Press this horizontal softkey to open the window for drive configuration.



3. Press this softkey and the control system starts to identify the drives and motors connected.


After the identification finishes, a drive list with motor information displays on the screen, for example:

Axis	Drive	Motor
MX1	11	ID:10009(0.4KW/1.3A/3000U/min/Without brake)
MZ1	13	ID:18(0.4KW/1.3A/3000U/min/Without brake)
MSP1	Analog	Custom
MC1	15	Not configured

**Note:** For a motor with an absolute encoder, the motor ID can be identified automatically. For a motor with an incremental encoder, however, you must configure it manually.



4. Select the additional axis using the cursor keys.



5. Press this softkey to enter the motor configuration window.

6. Select the right motor ID according to the motor rating plate with the cursor keys.

**Note:** For a motor with an incremental encoder in this example, you need to select the right motor ID according to the motor rating plate.

Axis:MC1		Drive:15		
Motor ID	Power	Current	Speed	Brake typ
18	0.4KW	1.3A	3000U/min	Without brake
19	0.4KW	1.3A	3000U/min	With brake



7. Press this softkey to confirm your selection. The selected motor information then displays in the drive list.




8. After you finish the configuration, press this softkey to save the configuration results on both CNC and drive.

**Note:** The control system restarts after you press this softkey.



9. Press this softkey when the following dialog appears to exit the drive configuration window.




## A.2.4 Tuning drive performance

The control system provides facilities to tune the drive performance for the additional axis by automatically modifying the control loop parameters. The tuning is performed based on frequency response measurements of the dynamic response of the machine.

The following steps are also applicable to tuning the feed axes, if necessary.

### Operating sequence



1. Select the desired operating area on the PPU.



2. Press this horizontal softkey to open the window for drive tuning.



3. Switch to "JOG" mode. Note that the drive tuning can be performed in "JOG" mode only.




4. Select the additional axis using the cursor keys.



5. Press this softkey to enter the window for selecting the tuning options.



6. Use this key to select a desired tuning objective and measurement and interpolation options for the additional axis. For more information about the options, see section "Tuning drive performance (Page 103)".



7. Press this softkey to confirm the selections and return to the main screen of drive tuning.



8. Press this softkey to enter the preparation screen before the tuning.

9. Use the axis traversing keys to move the axis to a safe position.


	Position	Direc.	Lim. -		Lim.
MX1	3.500	+, -	-1000	↓	1000
MZ1	0.000	+, -	-3000	↓	3000
MA1	6.001	+, -	-1e+08	↓	1e+08



10. Press this softkey and the drive tuning starts automatically.



11. Press this key on the MCP to start the measurement when the following message appears during the tuning process:



12. After the drive tuning finishes successfully, the tuning results appear on the screen in the form of a parameter list.

Axis +

Axis -

Accept

Cancel

Export results

You can check the tuning results of the additional axis with these softkeys.

13. Press this softkey to save the tuning results and write the modified parameters into the drives.

Pressing this softkey aborts the tuning and deletes the results.



It returns automatically to the main screen of drive tuning after the tuning finishes. You can use this softkey to save the trace files during the tuning process to a USB flash disk (if inserted).

#### Note

For the machine data that are changeable only with a manufacturer password, the settings made during drive tuning cannot be restored after an NC restart in case of power failure or unexpected abortion of the tuning process.


### A.3 Cutting reserved holes in the MCP

There are three kinds of MCP, a horizontal variant and two vertical variants. On the horizontal MCP, there are three reserved holes with a standard diameter of **16 mm** and on the vertical variant there are four holes with a standard diameter of **16 mm**. They are available for you to install necessary devices according to your own needs:




To cut a reserved hole, proceed as follows:

- 1 Prise the plastic ring with a slotted screwdriver or cut it off with a diagonal cutting nippers.



- 2 Cut the film off with a paper knife. It is recommended to cut the center firstly, then cut the film off right around the hole edge.





## A.4 MCP strips

### Inserting the MCP strips

The MCP strips of the turning version are already pre-assembled into the MCP. If you are using the control system of milling version, you need to take these pre-defined insertion strips out firstly, and then insert the MCP strips of the milling version delivered in MCP package into the MCP by yourself.

To insert the MCP strips, follow the order shown as follows with reference to the marks (M1 to M6, T1 to T6) on the strips:





### Printing customized MCP strips

Siemens provides you a symbol library for customized MCP keys. You can print customized strips with the A4-size blank paper included in the delivered MCP package. You can find the symbol library in the Toolbox (...\\examples\\SINUMERIK\_808D\_ADVANCED\\MCP).

Siemens also provides you with a template file for printing customized strips. Key positions in the template accord with real key layout on the MCP. You can copy symbols from the symbol library and paste them to the key positions where you want to use customized symbols. You can find the template file in the Toolbox (...\\examples\\SINUMERIK\_808D\_ADVANCED\\MCP).

### Cutting customized MCP strips

The delivered A4-size paper has been pre-cut with boundaries. You just need to tear them off after printing customized symbols.



## A.5 Parameter list

### A.5.1 Recommended machine data

No.	Name	Default	Range	Type	Unit	Activating
11300	JOG_INC_MODE_LEVELTRIGGERD	1	-	BOOL	-	PO
	INC and REF in JOG mode					
14510 *	USER_DATA_INT[0] ... [31]	0	-62,768 to 32,767	DWORD	-	PO
	User data (INT)					
14512 *	USER_DATA_HEX[0] ... [31]	0H	0 to 0x0FFF	BYTE	-	PO
	User data (HEX)					
14514 *	USER_DATA_FLOAT[0] ... [7]	0.000000	-3.4e+038 to 3.4e+038	DOUBLE	-	PO
	User data (float)					
20360	TOOL_PARAMETER_DEFINITION_MASK	<ul style="list-style-type: none"> <li>Turning: 283H</li> <li>Milling: 0H</li> </ul>	0 to 0x1FFFFFF	DWORD	-	PO
	Definition of tool parameters					
20700	REF_NC_START_LOCK	1	-	BOOL	-	RE
	NC start disable without reference point					
30100	CTRLOUT_SEGMENT_NR[0]	-1	1 to 5	BYTE	-	PO
	Setpoint assignment: bus segment number					
30120	CTRLOUT_NR[0]	1		BYTE	-	PO
	Setpoint assignment: Setpoint output on drive submodule/module					
30130	CTRLOUT_TYPE	0	0 to 3	BYTE	-	PO
	Output type of setpoint					
30134	IS_UNIPOLAR_OUTPUT[0]	0	0 to 1	-	-	PO
	Setpoint output is unipolar					
30200	NUM_ENCS	-1	0 to 1	BYTE	-	PO
	Number of encoders					
30210	ENC_SEGMENT_NR[0]	-1	1 to 5	BYTE	-	PO
	Actual value assignment: Bus segment number					
30230	ENC_INPUT_NR[0]	-1	1 to 2	BYTE	-	PO
	Actual value assignment: Input on drive module/meas. circuit board					
30240	ENC_TYPE	0	0 to 5	BYTE	-	PO
	Encoder type of actual value sensing (actual position value)					
30350	SIMU_AX_VDI_OUTPUT	FALSE	-	BOOL	-	PO
	Axis signals output for simulation axes					

No.	Name	Default	Range	Type	Unit	Activating
30600	FIX_POINT_PO S[0] ... [3]	0.000000	-	DOUBLE	mm, degrees	PO
	Fixed-value positions of axis with G75					
31020	ENC_RESOL[0] ]	10,000		DWORD	-	PO
	Encoder lines per revolution					
31030	LEADSCREW_ PITCH	10.000000	≥ 0	DOUBLE	mm	PO
	Pitch of leadscrew					
31040	ENC_IS_DIRE CT	FALSE, FALSE	-	BYTE	-	PO
	Direct measuring system (no compilation to load position)					
31050	DRIVE_AX_RA TIO_DENOM[0] ... [5]	1	1 to 2,147,000,000	DWORD	-	PO
	Denominator load gearbox					
31060	DRIVE_AX_RA TIO_NUMERA [0] ... [5]	1	1 to 2,147,000,000	DWORD	-	PO
	Numerator load gearbox					
32000	MAX_AX_VEL O	10,000 (mm/min) 27.77 (rpm)	-	DOUBLE	mm/min, rpm	CF
	Maximum axis velocity					
32010	JOG_VELO_R APID	10,000 (mm/min) 27.77 (rpm)	-	DOUBLE	mm/min, rpm	RE
	Rapid traverse in JOG mode					
32020	JOG_VELO	<ul style="list-style-type: none"> <li>Feed axis: 2,000 (mm/min)</li> <li>Spindle: 100 (rpm)</li> </ul>	-	DOUBLE	mm/min, rpm	RE
	Jog axis velocity					
32060	POS_AX_VEL O	10,000 (mm/min) 27.77 (rpm)	-	DOUBLE	mm/min, rpm	RE
	Initial setting for positioning axis velocity					
32100	AX_MOTION_D IR	1	-1 to 1	DWORD	-	PO
	Traversing direction (not control direction)					
32110	ENC_FEEDBA CK_POL[0]	1	-1 to 1	DWORD	-	PO
	Sign actual value (control direction)					
32200	POSCTRL_GAI N[0] ... [5]	1.000000	0.000000 to 2000.000000	DOUBLE	User defined	CF
	Servo gain factor					
32250	RATED_OUTV AL[0]	100	0.0 to 200	DOUBLE	%	CF
	Rated output voltage					

No.	Name	Default	Range	Type	Unit	Activating
32260	<b>RATED_VELO[0]</b>	2,000.0	-	DOUBLE	rpm	CF
	Rated motor speed					
32300	<b>MAX_AX_ACCEL[0] ... [4]</b>	<ul style="list-style-type: none"> <li>Feed axis: 1.0</li> <li>Spindle: - [0]...[2]: 10</li> <li>- [3]...[4]: 2.778</li> </ul>	≥ 0.001	DOUBLE	mm/s <sup>2</sup> , rev/s <sup>2</sup>	CF
	Maximum axis acceleration					
32450	<b>Backlash[0]</b>	0.0	-	DOUBLE	mm	CF
	Backlash					
32700	<b>ENC_COMP_ENABLED[0]</b>	0	-	BOOL	-	CF
	Encoder/spindle error compensation					
34000	<b>REFP_CAM_IS_ACTIVE</b>	1	-	BOOL	-	RE
	Axis with reference point cam					
34010	<b>REFP_CAM_DIR_IS_MINUS</b>	0	-	BOOL	-	RE
	Approach reference point in minus direction					
34020	<b>REFP_VELO_SEARCH_CAM</b>	5,000.0 (mm/min) 13.88 (rpm)	-	DOUBLE	mm/min, rpm	RE
	Reference point approach velocity					
34040	<b>REFP_VELO_SEARCH_MARKER[0]</b>	300.0 (mm/min) 0.833 (rpm)	-	DOUBLE	mm/min, rpm	RE
	Creep velocity					
34050	<b>REFP_SEARCH_MARKER_REVERSE[0]</b>	0	-	BOOL	-	RE
	Direction reversal to reference cam					
34060	<b>REFP_MAX_MARKER_DIST[0]</b>	20.0	-	DOUBLE	mm, degrees	RE
	Maximum distance to reference mark					
34070	<b>REFP_VELO_POSITIONS</b>	10,000.00 (mm/min) 27.77 (rpm)	-	DOUBLE	mm/min, rpm	RE
	Reference point positioning velocity					
34080	<b>REFP_MOVE_DIST[0]</b>	-2.0	-	DOUBLE	mm, degrees	RE
	Reference point distance					
34090	<b>REFP_MOVE_DIST_CORR[0]</b>	0.0	-	DOUBLE	mm, degrees	RE
	Reference point offset/absolute offset					
34092	<b>REFP_CAM_SHIFT</b>	0.000000	-	DOUBLE	mm	RE

No.	Name	Default	Range	Type	Unit	Activating
	Electronic cam offset for incremental measuring system					
34093	REFP_CAM_MARKER_DIST[0]	0	-	DOUBLE	mm	PO
	Reference cam/reference mark distance					
34100	REFP_SET_POS[0] ... [3]	0.0	-	DOUBLE	mm, degrees	RE
	Reference point for incremental system					
34200	ENC_REFP_MODE[0]	1	0 to 8	BYTE	-	PO
	Referencing mode					
34210	ENC_REFP_STATUS[0]	0	0 to 3	BYTE	-	IM
	Adjustment status of absolute encoder					
34220	ENC_ABS_TURNS_MODULO[0]	-1	1 to 100000	DWORD	-	PO
	Modulo range for rotary absolute encoder					
34230	ENC_SERIAL_NUMBER[0]	0	-	DWORD	-	PO
	Encoder serial number					
35010	GEAR_STEP_CHANGE_ENABLE	0	-	BOOL	-	RE
	Parameterize gear stage change					
35100 *	SPIND_VELO_LIMIT	10,000.0	-	DOUBLE	rpm	PO
	Maximum spindle speed					
35110	GEAR_STEP_MAX_VELO[0] ... [5]	[0]...[1]: 500 [2]: 1,000 [3]: 2,000 [4]: 4,000 [5]: 8,000	-	DOUBLE	rpm	CF
	Maximum speed for gear stage change					
35120	GEAR_STEP_MIN_VELO[0] ... [5]	[0]...[1]: 50 [2]: 400 [3]: 800 [4]: 1,500 [5]: 3,000	-	DOUBLE	rpm	CF
	Minimum speed for gear stage change					
35130	GEAR_STEP_MAX_VELO_LIMIT[0] ... [5]	[0]...[1]: 500 [2]: 1,000 [3]: 2,000 [4]: 4,000 [5]: 8,000	-	DOUBLE	rpm	CF
	Maximum speed for gear stage					

No.	Name	Default	Range	Type	Unit	Activating
35140	GEAR_STEP_MIN_VELO_LIMIT[0] ... [5]	[0]...[1]: 5 [2]: 10 [3]: 20 [4]: 40 [5]: 80	-	DOUBLE	rpm	CF
	Minimum speed for gear stage					
36100	POS_LIMIT_MINUS	-100,000,000	-	DOUBLE	mm, degrees	RE
	1st software limit switch minus					
	Access level: Manufacturer					
36110	POS_LIMIT_PLUS	100,000,000	-	DOUBLE	mm, degrees	RE
	1st software limit switch plus					
36200	AX_VELO_LIMIT[0] ... [5]	11,500 (mm/min) 31,944 (rpm)	-	DOUBLE	mm/min, rpm	CF
	Threshold value for velocity monitoring					
36300	ENC_FREQ_LIMIT[0]	3.33e5	-	DOUBLE	-	PO
	Encoder limit frequency					
38000	MM_ENC_COMP_MAX_POINTS	<ul style="list-style-type: none"> <li>Turning: 125</li> <li>Milling: 200</li> </ul>	-	DWORD	-	PO
	Number of intermediate for interpolator compensation (SRAM)					

The machine data followed by an asterisk (\*) have the access level of "**Customer**", while those without an asterisk have the access level of "**Manufacturer**".

## A.5.2 SINAMICS V70 parameters

This chapter lists the parameters displayed on the BOP only. For more parameters about the servo drive, see SINUMERIK 808D ADVANCED HMI.

All parameters beginning with "p" are editable parameters, for example, p29000.

All parameters beginning with "r" are read-only parameters, for example, r0018.

### Effective

Indicates the conditions for making parameterization effective. Two conditions are possible:

- IM (**I**mmediately): Parameter value becomes effective immediately after changing.
- RE (**R**eset): Parameter value becomes effective after repower-on.

### Can be changed

Indicates the state in which a parameter is changeable. Two states are possible:

- U (**U**n): Can be changed in the "**Running**" state when the enable signal is available. The "RDY" LED indicator lights up green.
- T (**T**o run): Can be changed in the "**Ready**" state when the enable signal is missing. The "RDY" LED indicator lights up red.

### Note

When judging the state of the drive according to the "RDY" LED indicator, ensure that no faults or alarms exist.

## Data type

Type	Description
I16	16-bit integer
I32	32-bit integer
U16	16 bits without sign
U32	32 bits without sign
Uint16	16-bit unsigned integer
Uint32	32-bit unsigned integer
Float	32-bit floating point number

## Parameter list

The table below lists parameters visible on the BOP:

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
r0020	Speed setpoint smoothed	-	-	-	rpm	Float	-	-
	<b>Description:</b> Displays the currently smoothed speed setpoint at the input of the speed controller or U/f characteristic (after the interpolator). Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0021	Actual speed smoothed	-	-	-	rpm	Float	-	-
	<b>Description:</b> Displays the smoothed actual value of the motor speed. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0026	DC link voltage smoothed	-	-	-	V	Float	-	-
	<b>Description:</b> Displays the smoothed actual value of the DC link voltage. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0027	Absolute actual current smoothed	-	-	-	Arms	Float	-	-
	<b>Description:</b> Displays the smoothed absolute actual current value. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
	<b>Dependency:</b> r0068							
r0029	Current actual value field-generating smoothed	-	-	-	Arms	Float	-	-
	<b>Description:</b> Displays the smoothed field-generating actual current. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0030	Current actual value torque-generating smoothed	-	-	-	Arms	Float	-	-
	<b>Description:</b> Displays the smoothed torque-generating actual current. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0031	Actual torque smoothed	-	-	-	Nm	Float	-	-
	<b>Description:</b> Displays the smoothed torque actual value. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
r0032	Active power actual value smoothed	-	-	-	kW	Float	-	-
	<b>Description:</b> Displays the smoothed actual value of the active power. Significance for the drive: Power output at the motor shaft							
r0033	Torque utilization smoothed	-	-	-	%	Float	-	-
	<b>Description:</b> Displays the smoothed torque utilization as a percentage. Smoothing time constant = 100 ms The signal is not suitable as a process quantity and may only be used as a display quantity.							
r0037[0...19]	Servo drive temperatures	-	-	-	°C	Float	-	-
	<b>Description:</b> Displays the temperatures in the servo drive. <ul style="list-style-type: none"> <li>• [0] = Inverter, maximum value</li> <li>• [1] = Depletion layer maximum value</li> <li>• [2] = Rectifier maximum value</li> <li>• [3] = Air intake</li> <li>• [4] = Interior of servo drive</li> <li>• [5] = Inverter 1</li> <li>• [6] = Inverter 2</li> <li>• [7] = Inverter 3</li> <li>• [8] = Inverter 4</li> <li>• [9] = Inverter 5</li> <li>• [10] = Inverter 6</li> <li>• [11] = Rectifier 1</li> <li>• [12] = Rectifier 2</li> <li>• [13] = Depletion layer 1</li> <li>• [14] = Depletion layer 2</li> <li>• [15] = Depletion layer 3</li> <li>• [16] = Depletion layer 4</li> <li>• [17] = Depletion layer 5</li> <li>• [18] = Depletion layer 6</li> <li>• [19] = Cooling system liquid intake</li> </ul> The value of -200 indicates that there is no measuring signal. <ul style="list-style-type: none"> <li>• r0037[0]: Maximum value of the inverter temperatures (r0037[5...10]).</li> <li>• r0037[1]: Maximum value of the depletion layer temperatures (r0037[13...18]).</li> <li>• r0037[2]: Maximum value of the rectifier temperatures (r0037[11...12]).</li> </ul> The maximum value is the temperature of the hottest inverter, depletion layer, or rectifier.							
r0068	Absolute current actual value	-	-	-	Arms	Float	-	-
	<b>Description:</b> Displays actual absolute current. For A_INF, S_INF the following applies: <ul style="list-style-type: none"> <li>• The value is updated with the current controller sampling time.</li> </ul> The following applies for SERVO: <ul style="list-style-type: none"> <li>• The value is updated with a sampling time of 1 ms.</li> <li>• Absolute current value = <math>\sqrt{I_q^2 + I_d^2}</math></li> <li>• The absolute current actual value is available smoothed (r0027) and unsmoothed (r0068).</li> </ul> <b>Dependency:</b> r0027							
r0069[0...6]	Phase current actual value	-	-	-	A	Float	-	-

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
]	<b>Description:</b> Displays the measured actual phase currents as peak value. <ul style="list-style-type: none"> <li>• [0] = Phase U</li> <li>• [1] = Phase V</li> <li>• [2] = Phase W</li> <li>• [3] = Phase U offset</li> <li>• [4] = Phase V offset</li> <li>• [5] = Phase W offset</li> <li>• [6] = Total U, V, W</li> </ul> In indices 3 ... 5, the offset currents of the 3 phases, which are added to correct the phase currents, are displayed. The sum of the 3 corrected phase currents is displayed in index 6.							
r0079[0...1]	Torque setpoint total	-	-	-	Nm	Float	-	-
]	<b>Description:</b> Displays the torque setpoint at the output of the speed controller (before clock cycle interpolation). <ul style="list-style-type: none"> <li>• [0]: Unsmoothed</li> <li>• [1]: Smoothed</li> </ul>							
r0632	Motor temperature model, stator winding temperature	-	-	-	°C	Float	-	-
	<b>Description:</b> Displays the stator winding temperature of the motor temperature model.							
p0918	Drive Bus address	10	15	10	-	U16	RE	T
	<b>Description:</b> Displays or sets the Drive Bus address for Drive Bus interface on the servo drive. The address can be set as follows: Using p0918 <ul style="list-style-type: none"> <li>• Only if the address 00 hex, 7F hex, 80 hex, or FF hex has been set using the address switch.</li> <li>• The address is saved in a non-volatile fashion using the function "copy from RAM to ROM".</li> <li>• A change only becomes effective after a POWER ON.</li> </ul>							
p1058	Jog 1 speed setpoints	0	210000.000	100	rpm	Float	IM	T
	<b>Description:</b> Sets the speed/velocity for jog 1. Jogging is level-triggered and allows the motor to be incrementally moved.							
p1082	Maximum speed	0.000	210000.000	1500.000	rpm	Float	IM	T
	<b>Description:</b> Sets the highest possible speed.							
	<b>Dependency:</b> p0322							
p1083	Speed limit in positive direction of rotation	0.000	210000.000	210000.000	rpm	Float	IM	T, U
	<b>Description:</b> Sets the maximum speed for the positive direction.							
p1086	Speed limit in negative direction of rotation	-210000.000	0.000	-210000.000	rpm	Float	IM	T, U
	<b>Description:</b> Sets the speed limit for the negative direction.							
p1120	Ramp-function generator ramp-up time	0.000	999999.000	10.000	s	Float	IM	T, U
	<b>Description:</b> The ramp-function generator ramps-up the speed setpoint from standstill (setpoint = 0) up to the maximum speed (p1082) in this time.							
	<b>Dependency:</b> p1082							
p1121	Ramp-function generator ramp-down time	0.000	999999.000	10.000	s	Float	IM	T, U



Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
	<b>Description:</b> The ramp-function generator ramps-down the speed setpoint from the maximum speed (p1082) down to standstill (setpoint = 0) in this time. Further, the ramp-down time is always effective for OFF1.							
	<b>Dependency:</b> p1082							
p1215	Motor holding brake configuration	0	3	0	-	l16	IM	T
	<b>Description:</b> Sets the holding brake configuration. <ul style="list-style-type: none"> <li>0: No motor holding brake being used</li> <li>1: Motor holding brake according to sequence control</li> <li>2: Motor holding brake always open</li> <li>3: Motor holding brake like sequence control</li> </ul>							
	<b>Dependency:</b> p1216, p1217, p1226, p1227, p1228							
p1216	Motor holding brake, opening time	0	10000	100	ms	Float	IM	T, U
	<b>Description:</b> Sets the time to open the motor holding brake. After controlling the holding brake (opens), the speed/velocity setpoint remains at zero for this time. After this, the speed/velocity setpoint is enabled. This time should be set longer than the actual opening time of the brake, which ensures that the drive cannot accelerate when the brake is applied.							
	<b>Dependency:</b> p1215, p1217							
p1217	Motor holding brake closing time	0	10000	100	ms	Float	IM	T, U
	<b>Description:</b> Sets the time to apply the motor holding brake. After OFF1 or OFF3 and the holding brake is controlled (the brake closes), then the drive remains closed-loop controlled for this time stationary with a speed setpoint/velocity setpoint of zero. The pulses are suppressed when the time expires. This time should be set longer than the actual closing time of the brake, which ensures that the pulses are only suppressed after the brake has closed.							
	<b>Dependency:</b> p1215, p1216							
p1226	Threshold for zero speed detection	0.00	210000.00	20.00	rpm	Float	IM	T, U
	<b>Description:</b> Sets the speed threshold for the standstill identification. Acts on the actual value and setpoint monitoring. <ul style="list-style-type: none"> <li>When braking with OFF1 or OFF3, when the threshold is undershot, standstill is identified.</li> </ul> The following applies when the brake control is activated: <ul style="list-style-type: none"> <li>When the threshold is undershot, the brake control is started and the system waits for the brake closing time in p1217. The pulses are then suppressed.</li> </ul> If the brake control is not activated, the following applies: <ul style="list-style-type: none"> <li>When the threshold is undershot, the pulses are suppressed and the drive coasts down.</li> </ul>							
	<b>Dependency:</b> p1215, p1216, p1217, p1227							
p1227	Zero speed detection monitoring time	0.000	300.000	4.000	s	Float	IM	T, U
	<b>Description:</b> Sets the monitoring time for the standstill identification. When braking with OFF1 or OFF3, standstill is identified after this time has expired, after the setpoint speed has fallen below p1226. After this, the brake control is started, the system waits for the closing time in p1217 and then the pulses are suppressed.							
	<b>Dependency:</b> p1215, p1216, p1217, p1226							
p1228	Pulse suppression delay time	0.000	299.000	0.000	s	Float	IM	T, U

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
	<b>Description:</b> Sets the delay time for pulse suppression. After OFF1 or OFF3 and zero speed detection, the system waits for this time to expire and the pulses are then suppressed. Standstill is identified in the following cases: <ul style="list-style-type: none"> <li>The speed actual value falls below the speed threshold in p1226 and the time started after this in p1228 has expired.</li> <li>The speed setpoint falls below the speed threshold in p1226 and the time started after this in p1227 has expired.</li> </ul>							
	<b>Dependency:</b> p1226, p1227							
p1414	Speed setpoint filter activation	-	-	0000 bin	-	U16	IM	T, U
	<b>Description:</b> Setting for activating/de-activating the speed setpoint filter. If only one filter is required, filter 1 should be activated and filter 2 de-activated, to avoid excessive processing time.							
	<b>Dependency:</b> The individual speed setpoint filters are parameterized as of p1415.							
p1415	Speed setpoint filter 1 type	0	2	0	-	I16	IM	T, U
	<b>Description:</b> Sets the type for speed setpoint filter 1. <ul style="list-style-type: none"> <li>0: Low pass: PT1</li> <li>1: Low pass: PT2</li> <li>2: General 2nd-order filter</li> </ul>							
	<b>Dependency:</b> <ul style="list-style-type: none"> <li>PT1 low pass: p1416</li> <li>PT2 low pass: p1417, p1418</li> <li>General filter: p1417 ... p1420</li> </ul>							
p1416	Speed setpoint filter 1 time constant	0.00	5000.00	0.00	ms	Float	IM	T, U
	<b>Description:</b> Sets the time constant for the speed setpoint filter 1 (PT1). This parameter is only effective if the filter is set as a PT1 low pass.							
	<b>Dependency:</b> p1414, p1415							
p1417	Speed setpoint filter 1 denominator natural frequency	0.5	16000.0	1999.0	Hz	Float	IM	T, U
	<b>Description:</b> Sets the denominator natural frequency for speed setpoint filter 1 (PT2, general filter). This parameter is only effective if the speed filter is parameterized as a PT2 low pass or as general filter. The filter is only effective if the natural frequency is less than half of the sampling frequency.							
	<b>Dependency:</b> p1414, p1415							
p1418	Speed setpoint filter 1 denominator damping	0.001	10.000	0.700	-	Float	IM	T, U
	<b>Description:</b> Sets the denominator damping for velocity setpoint filter 1 (PT2, general filter). This parameter is only effective if the speed filter is parameterized as a PT2 low pass or as general filter.							
	<b>Dependency:</b> p1414, p1415							
p1419	Speed setpoint filter 1 numerator natural frequency	0.5	16000.0	1999.0	Hz	Float	IM	T, U
	<b>Description:</b> Sets the numerator natural frequency for speed setpoint filter 1 (general filter). This parameter is only effective if the speed filter is set as a general filter. The filter is only effective if the natural frequency is less than half of the sampling frequency.							
	<b>Dependency:</b> p1414, p1415							
p1420	Speed setpoint filter 1 numerator damping	0.000	10.000	0.700	-	Float	IM	T, U

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
	<b>Description:</b> Sets the numerator damping for speed setpoint filter 1 (general filter). This parameter is only effective if the speed filter is set as a general filter.							
	<b>Dependency:</b> p1414, p1415							
p1460	Speed controller P gain adaptation speed, lower	0.000	999999.000	0.300	Nms/rad	Float	IM	T, U
	<b>Description:</b> Sets the P gain of the speed controller before the adaptation speed range. This value corresponds to the basic setting of the P gain of the speed controller without adaptation.							
p1462	Speed controller integral time adaptation speed lower	0.00	100000.00	20.00	ms	Float	IM	T, U
	<b>Description:</b> Sets the integration time of the speed controller before the adaptation speed range. This value corresponds to the basic setting of the integral time of the speed controller without adaptation.							
p1520	Torque limit upper/motoring	-1000000.00	2000000.00	0.00	Nm	Float	IM	T, U
	<b>Description:</b> Sets the fixed upper torque limit or the torque limit when motoring.							
	<b>Note:</b> Negative values when setting the upper torque limit (p1520 < 0) can result in the motor accelerating in an uncontrollable fashion. The maximum value depends on the maximum torque of the connected motor.							
	<b>Dependency:</b> p1521							
p1521	Torque limit lower/regenerative	-20000000.00	1000000.00	0.00	Nm	Float	IM	T, U
	<b>Description:</b> Sets the fixed lower torque limit or the torque limit when regenerating.							
	<b>Note:</b> Positive values when setting the lower torque limit (p1521 > 0) can result in the motor accelerating in an uncontrollable fashion. The maximum value depends on the maximum torque of the connected motor.							
	<b>Dependency:</b> p1520							
p1656	Activates current setpoint filter	-	-	0001 bin	-	U16	IM	T, U
	<b>Description:</b> Setting for activating/de-activating the current setpoint filter. If not all of the filters are required, then the filters should be used consecutively starting from filter 1.							
	<b>Dependency:</b> The individual current setpoint filters are parameterized as of p1657.							
p1657	Current setpoint filter 1 type	1	2	1	-	I16	IM	T, U
	<b>Description:</b> Sets the current setpoint filter 1 as low pass (PT2) or as extended general 2nd-order filter. <ul style="list-style-type: none"> <li>1: Low pass: PT2</li> <li>2: General 2nd-order filter</li> </ul>							
	<b>Dependency:</b> Current setpoint filter 1 is activated via p1656.0 and parameterized via p1657 ... p1661.							
p1658	Current setpoint filter 1 denominator natural frequency	0.5	16000.0	1999.0	Hz	Float	IM	T, U
	<b>Description:</b> Sets the denominator natural frequency for current setpoint filter 1 (PT2, general filter).							
	<b>Dependency:</b> Current setpoint filter 1 is activated via p1656.0 and parameterized via p1657 ... p1661.							
p1659	Current setpoint filter 1 denominator damping	0.001	10.000	0.700	-	Float	IM	T, U
	<b>Description:</b> Sets the denominator damping for current setpoint filter 1.							
	<b>Dependency:</b> Current setpoint filter 1 is activated via p1656.0 and parameterized via p1657 ... p1661.							

Par. No.	Name	Min	Max	Factory setting	Unit	Data type	Effective	Can be changed
p1660	Current setpoint filter 1 numerator natural frequency	0.5	16000.0	1999.0	Hz	Float	IM	T, U
	<b>Description:</b> Sets the numerator natural frequency for current setpoint filter 1 (general filter)							
	<b>Dependency:</b> Current setpoint filter 1 is activated via p1656.0 and parameterized via p1657 ... p1661.							
p1661	Current setpoint filter 1 numerator damping	0.000	10.000	0.700	-	Float	IM	T, U
	<b>Description:</b> Sets the numerator damping for current setpoint filter 1.							
	<b>Dependency:</b> Current setpoint filter 1 is activated via p1656.0 and parameterized via p1657 ... p1661.							
r2114[0...1]	System runtime total	-	-	-	-	U32	-	-
	<b>Description:</b> Displays the total system runtime for the drive unit. The time comprises r2114[0] (milliseconds) and r2114[1] (days). After r2114[0] has reached a value of 86.400.000 ms (24 hours) this value is reset and r2114[1] is incremented. <ul style="list-style-type: none"> <li>• [0] = Milliseconds</li> <li>• [1] = Days</li> </ul>							
p2153	Speed actual value filter time constant	0	1000000	0	ms	Float	IM	T, U
	<b>Description:</b> Sets the time constant of the PT1 element to smooth the speed/velocity actual value. The smoothed actual speed/velocity is compared with the threshold values and is only used for messages and signals.							
p29000	Motor type selection	0	54251	-	-	U16	IM	T
	<b>Description:</b> Motor type number is printed on the motor rating plate as motor ID. For a motor with an incremental encoder, users need to manually input the parameter value, ranging from 18 to 39. For a motor with an absolute encoder, the drive automatically reads the parameter value, ranging from 10009 to 10048.							
p29002	BOP operating display selection	0	2	0	-	U16	IM	T, U
	<b>Description:</b> BOP operating display selection. <ul style="list-style-type: none"> <li>• 0: Actual speed</li> <li>• 1: DC voltage</li> <li>• 2: Actual torque</li> </ul>							
r29018	Firmware-Version	-	-	-	-	U32	-	-
	<b>Description:</b> Firmware version.							

## A.6 Diagnostics

### A.6.1 SINUMERIK 808D ADVANCED alarms

Some alarms may occur during the commissioning work. For more information about the alarms, see the SINUMERIK 808D ADVANCED Diagnostics Manual.

#### Calling help information for an alarm

You can call the help information for an alarm on the PPU by proceeding through the following steps:




1. Select the desired operating area.



2. Select the alarm using the cursor keys.



3. Press this key to call the help information for the selected alarm.



4. Pressing this softkey exits the help system.

### A.6.2 SINAMICS V70 faults and alarms

#### A.6.2.1 General information about faults and alarms

##### Differences between faults and alarms

The differences between faults and alarms are as follows:

Type	Description
Faults	<p><b>What happens when a fault occurs?</b></p> <ul style="list-style-type: none"><li>• If the servo motor is running, it stops running.</li><li>• If the servo motor is not running, it cannot run.</li></ul> <p><b>How to eliminate a fault?</b></p> <ul style="list-style-type: none"><li>• Remove the cause of the fault.</li><li>• Acknowledge the fault.</li></ul>
Alarms	<p><b>What happens when an alarm occurs?</b></p> <ul style="list-style-type: none"><li>• The servo motor can run normally.</li></ul> <p><b>How to eliminate an alarm?</b></p> <ul style="list-style-type: none"><li>• The alarm acknowledges itself. If the cause of the alarm is no longer present, it automatically resets itself.</li></ul>

## Fault reactions

The following fault reactions are defined:

Reaction	Description
NONE	No reaction when a fault occurs.
OFF1	Servo motor ramps down to stop.
OFF2	Servo motor coasts down to stop.
OFF3	Servo motor stops quickly (emergency stop).
ENCODER	Encoder fault causes OFF2.

## Fault acknowledgements

The acknowledgement methods for faults are specified as follows:

Acknowledgement	Description
POWER ON	The fault is acknowledged by a POWER ON (switch servo drive off and on again).  <b>NOTE:</b> If this action has not eliminated the fault cause, the fault is displayed again immediately after power-on.
IMMEDIATELY	Faults disappear immediately after the fault causes have been eliminated.  <b>NOTE:</b> <ul style="list-style-type: none"><li>These faults can also be acknowledged by a POWER ON operation.</li><li>If this action has not eliminated the fault cause, the fault will continue to be displayed after acknowledgment.</li></ul>
PULSE INHIBIT	The fault can only be acknowledged with a pulse inhibit. The same options are available for acknowledging as described under acknowledgment with IMMEDIATELY.

## A.6.2.2 List of faults and alarms

This section lists common faults and alarms that may occur on the SINAMICS V70.

### Fault list

Fault	Cause	Remedy
<b>F1000: Internal software error</b> Reaction: OFF2 Acknowledgement: POWER ON	An internal software error has occurred.	<ul style="list-style-type: none"><li>Evaluate fault buffer.</li><li>Carry out a POWER ON (power off/on) for all components.</li><li>Upgrade firmware to later version.</li><li>Contact the Hotline.</li><li>Replace the Control Unit.</li></ul>
<b>F1001: Floating Point exception</b> Reaction: OFF2 Acknowledgement: POWER ON	An exception occurred during an operation with the Floating Point data type.	<ul style="list-style-type: none"><li>Carry out a POWER ON (power off/on) for all components.</li><li>Upgrade firmware to later version.</li><li>Contact the Hotline.</li></ul>
<b>F1002: Internal software error</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	An internal software error has occurred.	<ul style="list-style-type: none"><li>Carry out a POWER ON (power off/on) for all components.</li><li>Upgrade firmware to the latest version.</li><li>Contact the Hotline.</li></ul>

Fault	Cause	Remedy
<b>F1003: Acknowledgement delay when accessing the memory</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	A memory area was accessed that does not return a "READY".	<ul style="list-style-type: none"> <li>Carry out a POWER ON (power off/on) for all components.</li> <li>Contact the Hotline.</li> </ul>
<b>F1015: Internal software error</b> Reaction: OFF2 Acknowledgement: POWER ON	An internal software error has occurred.	<ul style="list-style-type: none"> <li>Carry out a POWER ON (power off/on) for all components.</li> <li>Upgrade firmware to the latest version.</li> <li>Contact the Hotline.</li> </ul>
<b>F1018: Booting has been interrupted several times</b> Reaction: NONE Acknowledgement: POWER ON	Module booting was interrupted several times. As a consequence, the module boots with the factory setting. Possible reasons for booting being interrupted: <ul style="list-style-type: none"> <li>Power supply interrupted.</li> <li>CPU crashed.</li> <li>Parameterization invalid.</li> </ul> After this fault is output, then the module is booted with the factory settings.	<ul style="list-style-type: none"> <li>Carry out a POWER ON (power off/on). After switching on, the module reboots from the valid parameterization (if available).</li> <li>Restore the valid parameterization.</li> </ul> Examples: <ul style="list-style-type: none"> <li>Carry out a first commissioning, save, carry out a POWER ON (switch-off/switch-on).</li> <li>Load another valid parameter backup (e.g. from the memory card), save, carry out a POWER ON (switch-off/switch-on).</li> </ul> Note: If the fault situation is repeated, then this fault is again output after several interrupted boots.
<b>F1030: Sign-of-life failure for master control</b> Reaction: OFF3 Acknowledgement: IMMEDIATELY	For active PC master control, no sign-of-life was received within the monitoring time.	Contact the Hotline.
<b>F1611: SI CU: Defect detected</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The drive-integrated "Safety Integrated" (SI) function on the Control Unit (CU) has detected an error and initiated an STO	<ul style="list-style-type: none"> <li>Carry out a POWER ON (power off/on) for all components.</li> <li>Upgrade software.</li> <li>Replace the Control Unit.</li> </ul>
<b>F1910: Drive Bus: Setpoint timeout</b> Reaction: OFF3 Acknowledgement: IMMEDIATELY	The reception of setpoints from the Drive Bus interface has been interrupted. <ul style="list-style-type: none"> <li>Bus connection interrupted.</li> <li>Controller switched off.</li> <li>Controller set into the STOP state.</li> </ul>	Restore the bus connection and set the controller to RUN.
<b>F1911: Drive Bus clock cycle synchronous operation clock cycle failure</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The global control telegram to synchronize the clock cycles has failed - in cyclic operation - for several Drive Bus clock cycles or has violated the time grid specified in the parameterizing telegram over several consecutive Drive Bus clock cycles.	<ul style="list-style-type: none"> <li>Check the physical bus configuration (cable, connector, Drive Bus terminator, shielding, etc.).</li> <li>Check whether communication was briefly or permanently interrupted.</li> <li>Check the bus and controller for utilization level (e.g. bus cycle time was set too short).</li> </ul>

Fault	Cause	Remedy
<b>F1912: Clock cycle synchronous operation sign-of-life failure</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The maximum permissible number of errors in the controller sign-of-life (clock synchronous operation) has been exceeded in cyclic operation.	<ul style="list-style-type: none"> <li>Physically check the bus (cables, connectors, terminating resistor, shielding, etc.).</li> <li>Correct the interconnection of the controller sign-of-life.</li> <li>Check whether the controller correctly sends the sign-of-life.</li> <li>Check the permissible telegram failure rate.</li> <li>Check the bus and controller for utilization level (e.g. bus cycle time was set too short).</li> </ul>
<b>F7011: Motor overtemperature</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	<ul style="list-style-type: none"> <li>Motor overloaded</li> <li>Motor surrounding air temperature too high</li> <li>Wire breakage or sensor not connected</li> <li>Motor temperature model incorrectly parameterized</li> </ul>	<ul style="list-style-type: none"> <li>Reduce the motor load.</li> <li>Check the surrounding air temperature and the motor ventilation.</li> <li>Check the wiring and the connection.</li> <li>Check the motor temperature model parameters.</li> </ul>
<b>F7085: Open-loop/closed-loop control parameters changed</b> Reaction: NONE Acknowledgement: IMMEDIATELY	Open-loop/closed-loop control parameters have had to be changed for the following reasons: <ul style="list-style-type: none"> <li>As a result of other parameters, they have exceeded the dynamic limits.</li> <li>They cannot be used due to the fact that the hardware detected not having certain features.</li> </ul>	It is not necessary to change the parameters as they have already been correctly limited.
<b>F7403: Lower DC link voltage threshold reached</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The DC link voltage monitoring is active and the lower DC link voltage threshold was reached in the "Operation" state.	<ul style="list-style-type: none"> <li>Check the line supply voltage.</li> <li>Check the infeed.</li> <li>Reduce the lower DC link threshold.</li> <li>Switch out (disable) the DC link voltage monitoring.</li> </ul>
<b>F7404: Upper DC link voltage threshold reached</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The DC link voltage monitoring is active and the upper DC link voltage threshold was reached in the "Operation" state.	<ul style="list-style-type: none"> <li>Check the line supply voltage.</li> <li>Check the infeed module or the brake module.</li> <li>Increase the upper DC link voltage threshold.</li> <li>Switch out (disable) the DC link voltage monitoring.</li> </ul>
<b>F7410: Current controller output limited</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The condition " $I_{act} = 0$ and $U_{q\_set\_1}$ longer than 16 ms at its limit" is present and can be caused by the following: <ul style="list-style-type: none"> <li>Motor not connected or motor contactor open.</li> <li>No DC link voltage present.</li> <li>Motor Module defective.</li> </ul>	<ul style="list-style-type: none"> <li>Connect the motor or check the motor contactor.</li> <li>Check the DC link voltage.</li> <li>Check the Motor Module.</li> </ul>



Fault	Cause	Remedy
<b>F7412: Commutation angle incorrect (motor model)</b> Reaction: ENCODER Acknowledgement: IMMEDIATELY	An incorrect commutation angle was detected that can result in a positive coupling in the speed controller. Possible causes: <ul style="list-style-type: none"> <li>The motor encoder is incorrectly adjusted with respect to the magnet position.</li> <li>The motor encoder is damaged.</li> <li>Data to calculate the motor model has been incorrectly set.</li> <li>Pole position identification might have calculated an incorrect value when activated.</li> <li>The motor encoder speed signal is faulted.</li> <li>The control loop is instable due to incorrect parameterization.</li> </ul>	<ul style="list-style-type: none"> <li>If the encoder mounting was changed, re-adjust the encoder.</li> <li>Replace the defective motor encoder.</li> <li>Correctly set the motor stator resistance, cable resistance and motor-stator leakage inductance. Calculate the cable resistance from the cross-section and length, check the inductance and stator resistance using the motor data sheet, measure the stator resistance, e.g. using a multimeter - and if required, again identify the values using the stationary motor data identification.</li> <li>With pole position identification activated, check the procedure for pole position identification and force a new pole position identification procedure by means of de-selection followed by selection.</li> </ul>
<b>F7414: Encoder serial number changed</b> Reaction: ENCODER Acknowledgement: IMMEDIATELY	<ol style="list-style-type: none"> <li>The encoder was replaced.</li> <li>A third-party, build-in or linear motor was re-commissioned.</li> <li>The motor with integrated and adjusted encoder was replaced.</li> <li>The firmware was updated to a version that checks the encoder serial number.</li> </ol>	Re causes 1, 2: Carry out an automatic adjustment using the pole position identification routine. Acknowledge the fault. Initiate the pole position identification routine. Then check that the pole position identification routine is correctly executed. SERVO: If a pole position identification technique is selected, and if p0301 does not contain a motor type with an encoder adjusted in the factory, then p1990 is automatically activated. Mechanically adjust the encoder. Accept the new serial number. Re causes 3, 4: Accept the new serial number with p0440 = 1.
<b>F7420: Drive: Current setpoint filter natural frequency &gt; Shannon frequency</b> Reaction: NONE Acknowledgement: IMMEDIATELY	One of the filter natural frequencies is greater than the Shannon frequency(2KHz). Filter 1 (p1658, p1660) Filter 2 (p1663, p1665) Filter 3 (p1668, p1670) Filter 4 (p1673, p1675)	<ul style="list-style-type: none"> <li>Reduce the numerator or denominator natural frequency of the current setpoint filter involved at the control system side.</li> <li>Switch out the filter involved (p1656).</li> </ul>
<b>F7450: Standstill monitoring has responded</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	After the standstill monitoring time expired, the drive left the standstill window. <ul style="list-style-type: none"> <li>Position loop gain too low.</li> <li>Position loop gain too high (instability/oscillation).</li> <li>Mechanical overload.</li> <li>Connecting cable, motor/drive converter incorrect (phase missing, interchange).</li> </ul>	Check the causes and resolve.

<b>Fault</b>	<b>Cause</b>	<b>Remedy</b>
<b>F7452: Following error too high</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The difference between the position setpoint position actual value (following error dynamic model) is greater than the tolerance. <ul style="list-style-type: none"> <li>• The drive torque or accelerating capacity exceeded.</li> <li>• Position measuring system fault.</li> <li>• Position control sense incorrect.</li> <li>• Mechanical system locked.</li> <li>• Excessively high traversing velocity or excessively high position reference value (setpoint) differences.</li> </ul>	Check the causes and resolve.
<b>F7801: Motor overcurrent</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The permissible motor limit current was exceeded. <ul style="list-style-type: none"> <li>• Effective current limit set too low.</li> <li>• Current controller not correctly set.</li> <li>• Motor was braked with an excessively high stall torque correction factor.</li> <li>• Up ramp was set too short or the load is too high.</li> <li>• Short-circuit in the motor cable or ground fault.</li> <li>• Motor current does not match the current of Motor Module.</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce the stall torque correction factor.</li> <li>• Increase the up ramp or reduce the load.</li> <li>• Check the motor and motor cables for short-circuit and ground fault.</li> <li>• Check the Motor Module and motor combination.</li> </ul>
<b>F7802: Infeed or power unit not ready</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	After an internal power-on command, the infeed or drive does not signal ready because of one of the following reasons: <ul style="list-style-type: none"> <li>• Monitoring time is too short.</li> <li>• DC link voltage is not present.</li> <li>• Associated infeed or drive of the signaling component is defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure that there is a DC link voltage. Check the DC link busbar. Enable the infeed.</li> <li>• Replace the associated infeed or drive of the signaling component.</li> </ul>
<b>F7815: Power unit has been changed</b> Reaction: NONE Acknowledgement: IMMEDIATELY	The code number of the actual power unit does not match the saved number.	Connect the original power unit and power up the Control Unit again (POWER ON).
<b>F7900: Motor blocked/speed controller at its limit</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The servo motor has been operating at the torque limit longer than 1s and below the speed threshold of 120 rpm .  This signal can also be initiated if the speed actual value is oscillating and the speed controller output repeatedly goes to its limit.	<ul style="list-style-type: none"> <li>• Check whether the servo motor can rotate freely or not.</li> <li>• Check the torque limit.</li> <li>• Check the inversion of the actual value.</li> <li>• Check the motor encoder connection.</li> <li>• Check the encoder pulse number.</li> </ul>
<b>F7901: Motor overspeed</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The maximum permissible speed has been exceeded.	Check and correct the maximum speed (p1082).
<b>F7995: Pole position identification not successful</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The pole position identification routine was unsuccessful.	Contact the Hotline.

Fault	Cause	Remedy
<b>F30001: Power unit: Over-current</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The power unit has detected an overcurrent condition. <ul style="list-style-type: none"> <li>• Closed-loop control is incorrectly parameterized.</li> <li>• Motor has a short-circuit or fault to ground (frame).</li> <li>• Power cables are not correctly connected.</li> <li>• Power cables exceed the maximum permissible length.</li> <li>• Power unit defective.</li> <li>• Line phase interrupted.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the motor data - if required, carry out commissioning.</li> <li>• Check the motor circuit configuration (star-delta)</li> <li>• Check the power cable connections.</li> <li>• Check the power cables for short-circuit or ground fault.</li> <li>• Check the length of the power cables.</li> <li>• Replace power unit.</li> <li>• Check the line supply phases.</li> <li>• Check the external braking resistor connection.</li> </ul>
<b>F30002: DC link voltage, overvoltage</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The power unit has detected overvoltage in the DC link. <ul style="list-style-type: none"> <li>• Motor regenerates too much energy.</li> <li>• Device connection voltage too high.</li> <li>• Line phase interrupted.</li> </ul>	<ul style="list-style-type: none"> <li>• Increase the ramp-down time.</li> <li>• Activate the DC link voltage controller.</li> <li>• Use a braking resistor.</li> <li>• Increase the current limit of the infeed or use a larger module.</li> <li>• Check the device supply voltage.</li> <li>• Check the line supply phases.</li> </ul>
<b>F30003: DC link voltage, undervoltage</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The power unit has detected an undervoltage condition in the DC link. <ul style="list-style-type: none"> <li>• Line supply failure</li> <li>• Line supply voltage below the permissible value.</li> <li>• Line supply infeed failed or interrupted.</li> <li>• Line phase interrupted.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the line supply voltage.</li> <li>• Check the line supply infeed and observe the fault messages relating to it (if there are any).</li> <li>• Check the line supply phases.</li> <li>• Check the line supply voltage setting.</li> </ul>
<b>F30004: Drive heat sink overtemperature</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The temperature of the power unit heat sink has exceeded the permissible limit value. <ul style="list-style-type: none"> <li>• Insufficient cooling, fan failure.</li> <li>• Overload.</li> <li>• Surrounding air temperature too high.</li> <li>• Pulse frequency too high.</li> </ul>	<ul style="list-style-type: none"> <li>• Check whether the fan is running.</li> <li>• Check the fan elements.</li> <li>• Check whether the surrounding air temperature is in the permissible range.</li> <li>• Check the motor load.</li> <li>• Reduce the pulse frequency if this is higher than the rated pulse frequency.</li> </ul>
<b>F30005: Power unit: Overload I<sub>t</sub></b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The power unit was overloaded. <ul style="list-style-type: none"> <li>• The permissible rated power unit current was exceeded for an inadmissibly long time.</li> <li>• The permissible load duty cycle was not maintained.</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce the continuous load.</li> <li>• Adapt the load duty cycle.</li> <li>• Check the motor and power unit rated currents.</li> </ul>
<b>F30011: Line phase failure in main circuit</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	At the power unit, the DC link voltage ripple has exceeded the permissible limit value. Possible causes: <ul style="list-style-type: none"> <li>• A line phase has failed.</li> <li>• The 3 line phases are inadmissibly unsymmetrical.</li> <li>• The fuse of a phase of a main circuit has ruptured.</li> <li>• A motor phase has failed.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the main circuit fuses.</li> <li>• Check whether a single-phase load is distorting the line voltages.</li> <li>• Check the motor feeder cables.</li> </ul>

<b>Fault</b>	<b>Cause</b>	<b>Remedy</b>
<b>F30015: Phase failure motor cable</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	A phase failure in the motor feeder cable was detected.  The signal can also be output in the following case:  The motor is correctly connected, however the closed-speed control is instable and therefore an oscillating torque is generated.	<ul style="list-style-type: none"> <li>• Check the motor feeder cables.</li> <li>• Check the speed controller settings.</li> </ul>
<b>F30021: Ground fault</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	Power unit has detected a ground fault. <ul style="list-style-type: none"> <li>• Ground fault in the power cables.</li> <li>• Winding fault or ground fault at the motor.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the power cable connections.</li> <li>• Check the motor.</li> </ul>
<b>F30027: Precharging DC link time monitoring</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	<ul style="list-style-type: none"> <li>• The power unit DC link was not able to be pre-charged within the expected time. There is no line supply voltage connected.</li> <li>• The line contactor/line side switch has not been closed.</li> <li>• The line supply voltage is too low.</li> <li>• The pre-charging resistors are overheated as there were too many pre-charging operations per time unit</li> <li>• The pre-charging resistors are overheated as the DC link capacitance is too high.</li> <li>• The pre-charging resistors are overheated.</li> <li>• The pre-charging resistors are overheated as the line contactor was closed during the DC link fast discharge through the Braking Module.</li> <li>• The DC link has either a ground fault or a short-circuit.</li> <li>• The pre-charging circuit is possibly defective.</li> </ul>	Check the line supply voltage at the input terminals.
<b>F30036: Internal over-temperature</b> Reaction: OFF2 Acknowledgement: IMMEDIATELY	The temperature inside the drive converter has exceeded the permissible temperature limit. <ul style="list-style-type: none"> <li>• Insufficient cooling, fan failure.</li> <li>• Overload.</li> <li>• Surrounding air temperature too high.</li> </ul>	<ul style="list-style-type: none"> <li>• Check whether the fan is running.</li> <li>• Check the fan elements.</li> <li>• Check whether the surrounding air temperature is in the permissible range.</li> </ul> <p>Notice: This fault can only be acknowledged once the permissible temperature limit minus 5 K has been fallen below.</p>
<b>F30050: 24 V supply over-voltage</b> Reaction: OFF2 Acknowledgement: POWER ON	The voltage monitor signals an overvoltage fault on the module.	<ul style="list-style-type: none"> <li>• Check the 24 V power supply.</li> <li>• Replace the module if necessary.</li> </ul>

Fault	Cause	Remedy
<b>F30074: Communication error between the Control Unit and Power Module</b> Reaction: NONE Acknowledgement: IMMEDIATELY	<p>Communications between the Control Unit (CU) and Power Unit (PU) via the interface no longer possible. The CU may have been withdrawn or is incorrectly inserted.</p> <p>Fault value (r0949, interpret hexadecimal):</p> <p>0 hex:</p> <ul style="list-style-type: none"> <li>a Control Unit with external 24 V supply was withdrawn from the Power Unit during operation.</li> <li>with the Power Unit switched off, the external 24 V supply for the Control unit was interrupted for some time.</li> </ul> <p>1 hex:</p> <p>The Control Unit was withdrawn from the Power Unit during operation, although the encoderless safe motion monitoring functions are enabled. This is not supported. After reinserting the Control Unit in operation, communications to the Power Unit no longer possible.</p> <p>20A hex:</p> <p>The Control Unit was inserted on a Power Unit, which has another code number.</p> <p>20B hex:</p> <p>The Control Unit was inserted on a Power Unit, which although it has the same code number, has a different serial number.</p> <p>601 hex:</p> <p>The Control Unit was inserted on a Power Unit, whose power/performance class (chassis unit) is not supported.</p>	<p>Reinsert the Control Unit (CU) or the Control Unit adapter (CUAxx) onto the original Power Unit (PU) and continue operation. If required, carry out a POWER ON for the CU and/or the CUA.</p>
<b>F31100: Zero mark distance error</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	<p>The measured zero mark distance does not correspond to the parameterized zero mark distance.</p> <p>For distance-coded encoders, the zero mark distance is determined from zero marks detected pairs. This means that if a zero mark is missing, depending on the pair generation, this cannot result in a fault and also has no effect in the system.</p>	<ul style="list-style-type: none"> <li>Check that the encoder cables are routed in compliance with EMC.</li> <li>Check the plug connections.</li> <li>Check the encoder type (encoder with equidistant zero marks).</li> <li>Replace the encoder or encoder cable.</li> </ul>
<b>F31110: Serial communications error</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	<p>Serial communication protocol transfer error between the encoder and evaluation module.</p>	<ul style="list-style-type: none"> <li>Check the encoder cable and shielding connection.</li> <li>Replace the motor.</li> </ul>
<b>F31112: Error bit set in the serial protocol</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	<p>The encoder sends a set error bit via the serial protocol.</p>	<ul style="list-style-type: none"> <li>Check the encoder cable and shielding connection.</li> <li>Replace the motor.</li> </ul>

Fault	Cause	Remedy
<b>F31117: Inversion error signals A/B/R</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	For a square-wave encoder (bipolar, double ended) signals A*, B* and R* are not inverted with respect to signals A, B and R.	<ul style="list-style-type: none"> <li>Check the encoder/cable.</li> <li>Does the encoder supply signals and the associated inverted signals?</li> </ul>
<b>F31130: Zero mark and position error from the coarse synchronization</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	After initializing the pole position using track C/D, Hall signals or pole position identification routine, the zero mark was detected outside the permissible range. For distance-coded encoders, the test is carried out after passing 2 zero marks. Fine synchronization was not carried out.	<ul style="list-style-type: none"> <li>Check that the encoder cables are routed in compliance with EMC.</li> <li>Check the plug connections.</li> <li>If the Hall sensor is used as an equivalent for track C/D, check the connection.</li> <li>Check the connection of track C or D.</li> <li>Replace the encoder or encoder cable.</li> </ul>
<b>F31150: Initialization error</b> Reaction: ENCODER Acknowledgement: PULSE INHIBIT	Encoder functionality is not operating correctly.	<ul style="list-style-type: none"> <li>Check the encoder type used (incremental/absolute) and the encoder cable.</li> <li>If relevant, note additional fault messages that describe the fault in detail.</li> </ul>
<b>F52980: Absolute encoder motor changed</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The servo motor with absolute encoder is changed. Actual motor ID is different from commissioned motor ID.	The servo motor will be automatically configured after the acknowledgement of this fault.
<b>F52981: Absolute encoder motor mismatched</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	Connected absolute encoder motor cannot be operated. The servo drive in use does not support the Motor ID.	Use a suitable absolute encoder motor.
<b>F52983: No encoder detected</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	The servo drive in use does not support encoderless operation.	<ul style="list-style-type: none"> <li>Check the encoder cable connection between the servo drive and the servo motor.</li> <li>Use a servo motor with encoder.</li> </ul>
<b>F52984: Incremental encoder motor not configured</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	<ul style="list-style-type: none"> <li>Commissioning of the servo motor has failed.</li> <li>The incremental encoder motor is connected but fails to commission.</li> </ul>	Configure the motor ID by setting the parameter p29000.
<b>F52985: Absolute encoder motor wrong</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	<ul style="list-style-type: none"> <li>Motor ID is downloaded wrong during manufacture.</li> <li>The software of the servo drive does not support the Motor ID.</li> </ul>	<ul style="list-style-type: none"> <li>Update the software.</li> <li>Use a correct absolute encoder motor.</li> </ul>
<b>F52987: Absolute encoder replaced</b> Reaction: OFF1 Acknowledgement: IMMEDIATELY	Incorrect absolute encoder data.	Contact the Hotline.

## Alarm list

<b>A1009: Control module over-temperature</b>	The temperature of the control module (Control Unit) has exceeded the specified limit value.	<ul style="list-style-type: none"> <li>Check the air intake for the Control Unit.</li> <li>Check the Control Unit fan.</li> </ul> <p>Note: The alarm automatically disappears after the limit value has been undershot.</p>
<b>A1019: Writing to the removable data medium unsuccessful</b>	The write access to the removable data medium was unsuccessful.	Remove and check the removable data medium. Then run the data backup again.
<b>A1032: All parameters must be saved</b>	The parameters of an individual drive object were saved, although there is still no backup of all drive system parameters. The saved object-specific parameters are not loaded the next time that the system powers up. For the system to successfully power up, all of the parameters must have been completely backed up.	Save all parameters.
<b>A1045: Configuring data invalid</b>	An error was detected when evaluating the parameter files saved in the non-volatile memory. Because of this, under certain circumstances, several of the saved parameter values were not able to be accepted.	Save the parameterization using the "SAVE" function on the BOP. This overwrites the incorrect parameter files in the non-volatile memory and the alarm is withdrawn.
<b>A1920: Drive Bus: Receive setpoints after To</b>	Output data of Drive Bus master (setpoints) received at the incorrect instant in time within the Drive Bus clock cycle.	<ul style="list-style-type: none"> <li>Check bus configuration.</li> <li>Check parameters for clock cycle synchronization (ensure <math>T_o &gt; T_{dx}</math>).</li> </ul> <p>Note: <math>T_o</math>: Time of setpoint acceptance <math>T_{dx}</math>: Data exchange time</p>
<b>A1932: Drive Bus clock cycle synchronization missing for DSC</b>	There is no clock synchronization or clock synchronous sign of life and DSC is selected.  Note: DSC: Dynamic Servo Control	Set clock synchronization across the bus configuration and transfer clock synchronous sign-of-life.
<b>A5000: Drive heat sink over-temperature</b>	<b>Cause:</b> The alarm threshold for overtemperature at the inverter heat sink has been reached. If the temperature of the heat sink increases by an additional 5 K, then fault F30004 is initiated.	<p>Check the following:</p> <ul style="list-style-type: none"> <li>Is the surrounding air temperature within the defined limit values?</li> <li>Have the load conditions and the load duty cycle been appropriately dimensioned?</li> <li>Has the cooling failed?</li> </ul>
<b>A7012: Motor temperature model 1/3 overtemperature</b>	The motor temperature model 1/3 identified that the alarm threshold was exceeded.	<ul style="list-style-type: none"> <li>Check the motor load and reduce it if required.</li> <li>Check the motor surrounding air temperature.</li> </ul>
<b>A7565: Encoder error in encoder interface</b>	An encoder error was signaled for encoder via the encoder interface (G1_ZSW.15).	Acknowledge the encoder error using the encoder control word (G1_STW.15 = 1).
<b>A7576: Encoderless operation due to a fault active</b>	Encoderless operation is active due to a fault.	<ul style="list-style-type: none"> <li>Remove the cause of a possible encoder fault.</li> <li>Carry out a POWER ON (power off/on) for all components.</li> </ul>

<b>A7965: Save required</b>	The angular commutation offset was re-defined and has still not been saved. In order to permanently accept the new value, it must be saved in a non-volatile fashion.	This alarm automatically disappears after the data has been saved.
<b>A7971: Angular commutation offset determination activated</b>	The automatic determination of the angular commutation offset (encoder adjustment) is activated. The automatic determination is carried out at the next power-on command.	The alarm automatically disappears after determination.
<b>A7991: Motor data identification activated</b>	The motor data identification routine is activated. The motor data identification routine is carried out at the next power-on command.	The alarm automatically disappears after the motor data identification routine has been successfully completed. If a POWER ON or a warm restart is performed with motor data identification selected, the motor data identification request will be lost. If motor data identification is required, it will need to be selected again manually following ramp-up.
<b>A30016: Load supply switched off</b>	The DC link voltage is too low.	<ul style="list-style-type: none"> <li>• Switch on the load supply.</li> <li>• Check the line supply if necessary.</li> </ul>
<b>A30031: Hardware current limiting in phase U</b>	<p>Hardware current limit for phase U responded. The pulsing in this phase is inhibited for one pulse period.</p> <ul style="list-style-type: none"> <li>• Closed-loop control is incorrectly parameterized.</li> <li>• Fault in the motor or in the power cables.</li> <li>• The power cables exceed the maximum permissible length.</li> <li>• Motor load too high.</li> <li>• Power unit defective.</li> </ul> <p>Note: Alarm A30031 is always output if, for a Power Module, the hardware current limiting of phase U, V or W responds.</p>	<p>Check the motor data. As an alternative, run a motor data identification.</p> <ul style="list-style-type: none"> <li>• Check the motor circuit configuration (star-delta).</li> <li>• Check the motor load.</li> <li>• Check the power cable connections.</li> <li>• Check the power cables for short-circuit or ground fault.</li> <li>• Check the length of the power cables.</li> </ul>
<b>A31411: Absolute encoder signals internal alarms</b>	The absolute encoder fault word includes alarm bits that have been set.	Replace the encoder.
<b>A31412: Error bit set in the serial protocol</b>	The encoder sends a set error bit via the serial protocol.	<ul style="list-style-type: none"> <li>• Carry out a POWER ON (power off/on) for all components.</li> <li>• Check that the encoder cables are routed in compliance with EMC.</li> <li>• Check the plug connections.</li> <li>• Replace the encoder.</li> </ul>
<b>A52900: Failure during data copying</b>	<ul style="list-style-type: none"> <li>• Copying is halted.</li> <li>• The SD card was plugged out.</li> <li>• The drive is not in the stop state.</li> </ul>	<ul style="list-style-type: none"> <li>• Re-plug in the SD card.</li> <li>• Make sure the drive is in the stop state.</li> </ul>




## A.7 PLC program design and adjustment


### A.7.1 PLC Programming Tool


#### A.7.1.1 Renaming the default program

PLC Programming Tool contains a default PLC program. You can give this program a new name by performing the following operations:




1. Start the software by double-clicking the icon on your desktop.

2. Click the  button in the toolbar or select from the main window menu as follows to select and open the default PLC program from the Toolbox:



3. Select the following menu command to save this file under a new name to a desired folder so that the default program will not be overwritten:




### A.7.1.2 Changing the display language

You can select the languages to be installed when installing the software. Then you can change the display language as desired in PLC Programming Tool.


Perform the following steps to change the display language.

1. Choose from the main menu as follows:




OK

2. In the appeared dialog, select the desired display language, and then click this button to confirm.




The following message box pops up, prompting that the software will restart to make the setting effective.



OK

3. Click this button to restart the software. Then the display language is changed successfully.


### A.7.1.3 Selecting a target system

In PLC Programming Tool, you can select the PLC type as preset. In the instruction tree, the instructions that cannot be used for the target system are marked with a red × (for example, .


After the PLC type is preset, an error check of the program takes place when the program is written.

#### Operating sequence


1. Start PLC Programming Tool on your PC.
2. Choose from the main screen menu as follows:





Then the following dialog opens:



You can alternatively call this dialog by right-clicking the project name in the instruction tree and choosing from the context menu.



3. Select a desired target system from the drop-down list in the dialog.  
If an active communication has been established between PLC Programming Tool and the control system, you can alternatively click the following button to read the information directly from the target system:



4. Click this button to exit the dialog.

## A.7.1.4 Establishing a connection between the control system and the PC


### Establishing a connection via the Ethernet interface

You can establish a connection between the control system and a PC installed with PLC Programming Tool via the Ethernet interface. The following Ethernet connections are possible:

- Direct connection: direct connection between the control system and a PC
- Network connection: integrating the control system into an existing Ethernet network

### Establishing a direct connection

Proceed through the following steps to establish a direct connection:



1. Connect the control system with the PC using an Ethernet cable.
2. Select the desired operating area on the PPU.
3. Press this key to view the extended softkeys.

4. Set up a direct connection on the control system through the following softkey operations:



The following dialog pops up on the screen:

Link set up	
IP address :	169.254.11.22
Subnet mask :	255.255.0.0



5. Start PLC Programming Tool on your PC, and click this button in the navigation bar to open the following dialog:

**Communications Setup**

Double click the icon representing the PLC to communicate with.

Double click the interface icon to change communication parameters.

Double click the modem icon to setup the modem parameters or dial to start modem communications.

**Communication Parameters**


Remote Address	2
Local Address	
Module	(COM 1)
Protocol	PPI
Transmission Rate	
Mode	11-bit

None Address: 0

Double-Click to Refresh

None Address: 0

6. Double-click the access point symbol, and the following "Set PG/PC Interface" dialog is displayed.




Select "TCP/IP" with the Ethernet card name of your PC and click the "OK" button.

**Note:** You can find the name of your Ethernet card in the local area connection status under Control Panel on your PC.

7. Enter the IP address for the control system that displays in the above link setup dialog in the communication settings dialog.


#### Communication Parameters

Remote Address 169 . 254 . 11 . 22

 Double-Click to Refresh

8. Double-click this symbol in the communication setting window to establish a connection to the specified IP address.

Wait until the information of the connected control system is identified as follows, and then the connection is ready.




### Establishing a network connection

Proceed through the following steps to establish a network connection:



1. Connect the control system with the local network using an Ethernet cable.
2. Select the desired operating area on the PPU.
3. Press this key to view the extended softkeys.

- Enter the main screen of the service control options through the following softkey operations:



- Press this softkey to enter the window for the network configuration.

**Note:** make sure the following vertical softkey is deactivated:



- Configure the network as required in the following window:

Network configuration	
Local data	
Protocol:	TCP / IP
DHCP:	Yes
Cmpt. name:	NONAME_NCU
IP address:	176 16 202 200
Subnet mask	255 255 255 0
Gateway:	

You can configure DHCP with the following key:



**Note:** If you select "No" for DHCP, you must enter the IP address (which must belong to the same network as that of your PC) and subnet mask manually.

- Press this softkey to save the configuration. If you select "Yes" for DHCP, you also need to restart the control system to activate the network configuration.
- Start PLC Programming Tool on your PC, and click this button in the navigation bar to open the following dialog:

**Communications Setup**

Double click the icon representing the PLC to communicate with.

Double click the interface icon to change communication parameters.

Double click the modem icon to setup the modem parameters or dial to start modem communications.

**Communication Parameters**

Remote Address	2
Local Address	
Module	(COM 1)
Protocol	PPI
Transmission Rate	
Mode	11-bit


None Address: 0

Double-Click to Refresh



None Address: 0

9. Double-click the access point symbol, and the following "Set PG/PC Interface" dialog is displayed.



Select "TCP/IP" with the Ethernet card name of your PC and click the "OK" button.

**Note:** You can find the name of your Ethernet card in the local area connection status under Control Panel on your PC.

10. Enter the IP address for the control system in the communication setting window, for example:


#### Communication Parameters


Remote Address 172 . 16 . 202 . 200

Note that the IP address entered here must be the same as that you have set on the PPU.

11. Double-click this symbol in the communication setting window to establish a connection to the specified IP address.


Wait until the information of the connected control system is identified as follows, and then the connection is ready.



 Double-Click  
to Refresh

## Establishing a connection via the RS232 interface


Proceed through the following steps to establish a connection between the control system and a PC:



↓




1. Connect the control system with the PC using an RS232 cable.
2. Select the desired operating area on the PPU.
3. Press these two softkeys in succession to open the following communication setting window.



4. Use this softkey to select a communication baud rate. The control system supports the following baud rates:
  - 9.6 kbps
  - 19.2 kbps
  - 38.4 kbps
  - 57.6 kbps
  - 115.2 kbps





5. Activate the RS232 connection with this softkey.  
No modifications to the settings are possible in this state.  
The active or inactive state is retained even after a power-on (except when you start the system with the default data).  
In the lower right corner of the screen, the  icon shows that the connection to the PC via the RS232 interface is active.






6. Start PLC Programming Tool on your PC, and click this button in the navigation bar to open the following dialog:




Alternatively, you can call this dialog by double-clicking the  Communications icon in the project tree or choosing from the main screen menu:



7. Double-click the access point symbol.


None Address: 0

Then the following "Set PG/PC Interface" dialog is displayed.



Check the interface being used. For RS232 communication, you must assign the interface "PLC802.PPI.1" to PLC programming tool.




8. Double click the interface "PLC802.PPI.1" or click the "Properties" button, and the following property dialog is displayed.



On the "PPI" tab page, set the baud rate for the transmission rate, which PLC Programming Tool will use for communication.


**Note:** The baud rate you select must be the same as what you have set on the control.

9. Open the "Local connection" tab to specify the COM port to which the RS232 (V24) cable is connected.



Double-Click  
to Refresh

10. Click this button twice to exit the "Set PG/PC Interface" dialog.
11. Double-click this icon on the right side of the communication setting window. It will take several minutes to search for a valid address.
12. Wait until the information on the connected control system is identified as follows, and then the connection is ready.



#### Note

Before configuring communications in PLC Programming Tool, make sure the connection is already enabled on the control system.


### A.7.1.5 Downloading/uploading/comparing PLC applications

You can save, copy, or overwrite a PLC project or PLC application on the control system by using the following:

- PLC Programming Tool
- USB stick

The **PLC project** contains the PLC user program, including all of the important information (symbols, comments, ...).


You can upload/download a PLC project from/to the control system with PLC Programming Tool. Also with this tool, you can import/export the PLC project in the ".pte" format. Additionally, you can read/write the PLC project in the ".pte" format from/to a USB stick directly on the control system.





## Download

You can write the transferred data into the permanent memory (load memory) of the control system with PLC Programming Tool or a USB stick.


To download a PLC application with PLC Programming Tool, proceed as follows:

1. Establish the communication between the control system and PLC Programming Tool. You can establish the connection by using the following methods:
  - Establishing a connection via the Ethernet interface (Page 184)
  - Establishing a connection via the RS232 interface (Page 188)
2. Select from the main screen menu as follows or click the toolbar button  to start the download:






- Click this button on the download dialog to proceed directly. You can also select the following checkbox for data blocks to include the actual values of the data blocks, and then click this button.





- Choose to download the PLC application when the PLC is in the **run** mode or in the **stop** mode.




**Caution:** You are recommended to download the PLC application when the PLC is in the **stop** mode. Downloading the PLC application when the PLC is in the **run** mode can cause machine damages or even human injuries.

- Start the download which will take several seconds.
- The download finishes when the following message appears. Then click this button to end your operations.



---


#### Note

If you have chosen to download when the PLC is in the **stop** mode, you can place the PLC at the **run** mode again with PLC Programming Tool (click the button ).


---

To download a machine manufacturer's PLC application with a USB stick, perform as follows:


1. Select from the main screen menu as follows to export the PLC application created with PLC Programming Tool to a USB stick:



2. Save the PLC application as a .pte file with a desired file name (e.g., plc\_app.pte) onto the USB stick.  
3. Insert the USB stick into the USB interface at the front of the PPU.  
4. Select the desired operating area on the PPU.



5. Open the USB stick through the following softkey operations:



6. Select the .pte file and then press this softkey to copy the file.

Name	Type	Length
808D on PC	DIR	
MultiLanguage	DIR	
user cycle	DIR	
1	txt	0 B
808Dsys_te	img	125.01 MB
Help1	txt	0 B
Help2	png	21.67 KB
SinumerikArchitectureT...	ppt	20.98 MB
alc	txt	0 B
alcu_eng	txt	5.75 KB
almc	txt	311 B
almc_chs	txt	305 B
arc_product	arc	36.00 KB
cov	com	314 B
keys	bak	41 B
oemmanual	pdf	1.74 MB
plc_app	pte	208.22 KB
sc	com	544 B



7. Press this softkey, and then access the folder for the NCK/PLC data by pressing the following key.



8. Press this softkey.




9. A warning note appears warning you that the original .pte file will be overwritten. Press this softkey to continue.


The download has been completed when the progress bar disappears.


## Upload


You can back up a PLC application from the permanent memory of the control system using PLC Programming Tool or a USB stick.

To upload a PLC application using PLC Programming Tool, proceed as follows:

1. Establish the communication between the control system and PLC Programming Tool.  
You can establish the connection by using the following methods:
  - Establishing a connection via the Ethernet interface (Page 184)
  - Establishing a connection via the RS232 interface (Page 188)
2. Select from the main screen menu as follows or click the toolbar button  to create a new and empty PLC application:




3. Select from the main screen menu as follows or click the toolbar button  to start the upload:





OK


4. Click this button to proceed directly. You can also select the checkbox for data blocks to include the actual values of the data blocks, and then click this button.



5. The upload has been completed when the following message appears.




6. Click this button and you can view the upload results.



To upload a PLC application using a USB stick, proceed as follows:



1. Insert the USB stick into the USB interface at the front of the PPU.
2. Select the desired operating area on the PPU.
3. Access the screen for the 808D data through the following softkey operations:



4. Access the folder for the NCK/PLC data by pressing this hardkey. Then select the machine manufacturer's PLC application file (.pte).

Name	Type
..	
Leadscrew error compensation	
Global user data	
Machine data	
<b>OEM PLC application (*.pte)</b>	
R variables	
Setting data	
Tool data	
Work offset	




5. Press this softkey to copy the selected file.







6. Press this softkey and paste the **.pte** file into the USB stick with the following softkey:

**Paste**

7. Unplug the USB stick and plug it into the USB interface of your PC.  
 8. Select from the main screen menu as follows or click the toolbar button  to create a new and empty PLC application:




9. Import the **.pte** file from the USB stick by selecting from the main screen menu as follows:




**Open**

10. Click this button or double-click the **.pte** file in the following dialog. It will take several seconds to import the **.pte** file.




11. After successfully importing the PLC application, you can view the import results.




## Compare

You can compare the project in PLC Programming Tool with the project on the control system by performing the following steps:

1. Select from the main screen menu as follows:




You can also select the checkbox for data blocks to include the actual values of the data blocks.




Begin

2. Click this button and the comparing begins. Wait for a few seconds, and then you can view the compare results.




### Version display

The transferred PLC application will be active in the working memory of the control after the system is started up. Then you can view the detailed information about the currently active PLC application in the version display through the following softkey operations:



In PLC Programming Tool, right-click the OB1 block and choose "Properties". In the comment text box of the opened OB1 property dialog, you can add your own additional information for the PLC application.



Then in the version display on the control, the added information is visible.


### PLC\_Application:


turning.ptp 10:20 09/10/2014  
Subroutine Library Falcon II V00.01.16 for turning 09/10/2014

## A.7.1.6 Compiling and monitoring programs

### Compiling PLC programs

You can check for syntax errors after editing or modifying a PLC project using the compile function of PLC Programming Tool. Proceed through the following steps to compile a PLC program:

1. Open an existing or new PLC project in PLC Programming Tool, and save it after editing or modifying as desired.
2. Start compiling by clicking the toolbar button  or choosing from the main screen menu as follows:




3. Wait for several seconds until the compiling finishes. Then you can check the results in the message window at the bottom of the main screen.


### Monitoring a PLC program with the HMI



There are three ways for program monitoring in this operating area.



You can enter an operand to view its status.




Use these softkeys to respectively increase and decrease the bit of the operand.

Change

Pressing this softkey changes the value of the operand.

Delete  
all

To delete all the entered operands, press this softkey.




You can view the status of a PLC signal. By default, three signal status lists (inputs, flags, and outputs) are displayed in three columns.

Edit  
pad

You can change column sequence or assign a new signal status list (variables) with this softkey.

Change

You can also change the status of a PLC signal via this softkey.



Two windows are available for you to view the program.

Program  
block

You can use this softkey to view the status of a subroutine.

## PLC info

You can use this softkey to check the PLC operating status and data.

## Cross reference



You can use this softkey to look for the target address in the cross-reference table.


## Monitoring a PLC program with PLC Programming Tool

### Prerequisite:


Before you can collect status to monitor or debug your program, make sure you have performed the following operations:

- Successfully compiling your program
- Establishing communications between PLC Programming Tool and the control system
- Successfully downloading your program to the control system

You can use the toolbar button  or the following menu command to monitor the online status of your PLC program when the PLC is in the run mode (toolbar button ).



The blue color in the program editing window indicates the online connection status.



### Note


Please confirm the Step 7 connection has been deactivated after the PLC commissioning is complete.

For how to deactivate this connection, see Section "Establishing a connection via the Ethernet interface (Page 184)".


## A.7.2 PLC user interface

This part describes the PLC interface signals and I/O signals.

The PLC program exchanges information among the NCK, HMI, MCP, and I/O through the signals of the PLC interface and signals of the input and output cards.



Signal overview of the PLC interface




Operand identifier

Address identifier	Description	Range
DB	Data	DB1000 to DB7999 DB9900 to DB9906
T	Timers	T0 to T15 (100 ms) T16 to T63 (10 ms)

Address identifier	Description	Range
C	Counters	C0 to C63
I	Image of digital inputs	I0.0 to I8.7
Q	Image of digital outputs	Q0.0 to Q5.7
M	Bit memory	M0.0 to M255.7
SM	Special bit memory	SM0.0 to SM0.6 ()
AC	ACCU	AC0 to AC3

#### Structure of the DB-range address



Access	Example	Description
Bit	DB3801.DBX1000.7	Bit 7 of the byte with offset 0 in subrange 1 for axis 2, user range 38
Byte	DB3801.DBB0	Byte with offset 0 in subrange 0 for axis, user range 38
Word	DB4500.DBW2	Word with offset 2 in subrange 0, range 0, user range 45
Double Word	DB2500.DBD3004	Double word with offset 4 in subrange 3, range 0, user range 25

#### Note

The permitted offset for an address depends on the access as follows:

- Bit or byte access: any offset  
Byte-size variables are placed one beside another seamlessly in a DB.
- Word access: the offset must be divisible by 2.  
Word-size variables (2 bytes) are always saved on straight offsets.
- Double word access: the offset must be divisible by 4.  
Double word-size variables (4 bytes) are always saved on offsets that are divisible by 4.

#### Notes on the PLC interface signal address representation

Currently, PLC interface signal addresses are represented by the V structure on the HMI while the manual shows them by the DB structure.

See the following table for the relationship between the two representations.


V Structure		DB Structure	
Access	Example	Example	Access
Bit	V38000002.1	DB3800.DBX2.1	Bit
Byte	VB38000002	DB3800.DBB2	Byte
Word	VW38000002	DB3800.DBW2	Word
Double Word	VD38000004	DB3800.DBD4	Double word



### A.7.2.1 Signals from/to the MCP

The figure below shows the front view of the horizontal MCP for the turning variant of the control system.

Note that labels K13, K15, K19, and K21 are not included in the pre-defined MCP insertion strips. The figure includes these labels so that when you read the information in the following two tables, you know which keys on the MCP it refers to.



#### From the MCP

DB1000	From the MCP [r]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
DBB0	M01	PROGRAM TEST	MDA	SINGLE BLOCK	AUTO	REF. POINT	JOG	HAND WHEEL
DBB1	Key 7	TAIL STOCK	INT. EXT.	CHUCK	TOOL CHANGE	COOLANT	LAMP	ROV
DBB2	100 (INC)	10 (INC)	1 (INC)	Key 12	Key 11	Key 10	Key 9	Key 8
DBB3	Axis traversing key (↑x)	Key 13	CYCLE START	CYCLE STOP	RESET	SPINDLE RIGHT	SPINDLE STOP	SPINDLE LEFT
DBB4		Key 21	Axis traversing key (↓x)	Key 19	Axis traversing key (→z)	RAPID	Axis traversing key (←z)	Key 15
DBB8				Feed override value (in Gray code)				
DBB9					Spindle override value (in Gray code)			

#### To the MCP

DB1100	To MCP [r/w]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
DBB0	M01	PROGRAM TEST	MDA	SINGLE BLOCK	AUTO	REF. POINT	JOG	HAND WHEEL
DBB1	Key 7	TAIL STOCK	INT. EXT.	CHUCK	TOOL CHANGE	COOLANT	LAMP	ROV
DBB2	100 (INC)	10 (INC)	1 (INC)	Key 12	Key 11	Key 10	Key 9	Key 8
DBB3	Axis traversing key (↑x)	Key 13	CYCLE START	CYCLE STOP	RESET	SPINDLE RIGHT	SPINDLE STOP	SPINDLE LEFT
DBB4		Key 21	Axis traversing key (↓x)	Key 19	Axis traversing key (→z)	RAPID	Axis traversing key (←z)	Key 15

DBB8			1 <sup>1)</sup>	1 <sup>1)</sup>	7 SEG LED1 <sup>2)</sup>
DBB9			1 <sup>1)</sup>	1 <sup>1)</sup>	7 SEG LED2 <sup>2)</sup>

1) To ensure the correct display of the active tool number, make sure that you set Bit 4 and Bit 5 to 1.

2) You can set only values 0 to 9 for each 7-segment LED (LED1 and LED2).

### A.7.2.2 Reading/Writing NC data

#### Reading/writing NC data: Job

<b>DB1200</b>	<b>Reading / writing NC data [r/w]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0							Write variable	Start
1	Number of variables							
2								
3								

<b>DB1200 ... 1203</b>	<b>Reading / writing NC data [r/w]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
1000	Variable index							
1001	Area number							
1002	Column index for the NCK variable x (WORD)							
1003	Line index for the NCK variable x (WORD)							
1006								
1008	Writing: data to NCK variable x (data type of the variables: 1 to 4 bytes)							

#### Reading/writing NC data: Result

<b>DB1200</b>	<b>Reading / writing NC data [r]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
2000							Error in job	Job completed
2001								
2002								

<b>DB1200 ... 1203</b>	<b>Reading / writing NC data [r]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
3000							Error has occurred	Valid variable
3001	Access result <sup>1)</sup>							
3002								
3004	Reading: data from NCK variable x (data type of the variables: 1 to 4 bytes)							

1) 0: no error; 3: illegal access to object; 5: invalid address; 10: object does not exist

### A.7.2.3 PI Service

#### PI service: Job

<b>DB1200</b>	<b>PI service [r/w]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
4000								Start
4001	PI index							
4002								
4003								
4004	PI parameter 1							
4006	PI parameter 2							
4008	PI parameter 3							
4010	PI parameter 4							
4012	PI parameter 5							
4014	PI parameter 6							
4016	PI parameter 7							
4018	PI parameter 8							
4020	PI parameter 9							
4022	PI parameter 10							

#### PI service: Result

<b>DB1200</b>	<b>Reading / writing NC data [r]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
5000							Error in job	Job completed
5001								
5002								

### A.7.2.4 Retentive data area

<b>DB1400</b>	<b>Retentive data [r/w]</b>							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
	User data							
0								
	User data							
1								
	User data							
2								
	...							
...								
32								
	...							
...								
	User data							

126								
	User data							
127								

### A.7.2.5 User Alarms

#### User alarms: Activating

<b>DB1600</b>	<b>Activating alarm [r/w]</b> PLC -> HMI interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Activation of alarm no.							
	700007	700006	700005	700004	700003	700002	700001	700000
1	Activation of alarm no.							
	700015	700014	700013	700012	700011	700010	700009	700008
2	Activation of alarm no.							
	700023	700022	700021	700020	700019	700018	700017	700016
3	Activation of alarm no.							
	700031	700030	700029	700028	700027	700026	700025	700024
4	Activation of alarm no.							
	700039	700038	700037	700036	700035	700034	700033	700032
5	Activation of alarm no.							
	700047	700046	700045	700044	700043	700042	700041	700040
...	...							
15	Activation of alarm no.							
	700127	700126	700125	700124	700123	700122	700121	700120

#### Variables for user alarms

<b>DB1600</b>	<b>Variables for user alarms [r32/w32]</b> PLC -> HMI interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
DBD1000	Variable for alarm 700000							
DBD1004	Variable for alarm 700001							
DBD1008	Variable for alarm 700002							
...	...							
DBD1500	Variable for alarm 700125							
DBD1504	Variable for alarm 700126							
DBD1508	Variable for alarm 700127							

#### Active alarm response

<b>DB1600</b>	<b>Active alarm response [r]</b> PLC -> HMI interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
2000	Acknowledge POWER ON	Acknowledge with DB1600DBX3 000.0		PLC STOP	EMERGENCY STOP	Feedrate disable all axes	Read-in disable	NC start disable

2001	
2002	
2003	

#### Alarm acknowledgement

<b>DB1600</b>	<b>Alarm acknowledgement [r/w]</b> PLC -> HMI interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
3000								Ack
3001								
3002								
3003								

### A.7.2.6 Signals from/to HMI

#### Program control signals from the HMI (retentive area)

<b>DB1700</b>	<b>Signals, HMI [r/w]</b> HMI -> PLC interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0		Dry run feedrate selected	M01 selected		DRF selected			
1	Program test selected				Feedrate override selected for rapid traverse			
2	Skip block 7 selected	Skip block 6 selected	Skip block 5 selected	Skip block 4 selected	Skip block 3 selected	Skip block 2 selected	Skip block 1 selected	Skip block 0 selected
3	Measurement in JOG active	Calculation of measurement value not finished					Skip block 9 selected	Skip block 8 selected
4								
5								
6								
7	Reset				NC stop		NC start	

#### Program selection from PLC (retentive area)

<b>DB1700</b>	<b>Program selection [r/w]</b> PLC -> HMI interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
1000	Program selection from the PLC: Program number							
1001	Command job from the PLC: Command							
1002								
1003								

### Checkback signal: Program selection from HMI (retentive area)

DB1700	Program selection [r] HMI -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000							Error program selection	Program selected
2001							Error command execution	Execute command
2002								
2003								

### Signals from HMI

DB1800	Signals from HMI [r] HMI -> PLC interface (signals are only present for PLC cycle)							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reset	Start measurement in JOG				JOG	Mode MDI	AUTOMATIC
1						Active the machine function		
						REF		
2								
3								

### Signals from PLC

DB1800	Signals from PLC [r]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000		Commissioning archive has been read in					Boot with saved data	Boot with default values
1001								
1002								
1003								
1004	PLC cycle in $\mu$ s [DINT]							
1008	Year: Tens digit, BCD				Year: Units digit, BCD			
1009	Month: Tens digit, BCD				Month: Units digit, BCD			
1010	Day: Tens digit, BCD				Day: Units digit, BCD			
1011	Hour: Tens digit, BCD				Hour: Units digit, BCD			
1012	Minute: Tens digit, BCD				Minute: Units digit, BCD			
1013	Second: Tens digit, BCD				Second: Units digit, BCD			
1014	Millisecond: Hundreds digit, BCD				Millisecond: Tens digit, BCD			
1015	Millisecond: Units digit, BCD				Weekday, BCD {1, 2, ... 7} (1 = Sunday)			

### Signals to maintenance planners

DB1800	Deactivation [r/w]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Deactivation 8	Deactivation 7	Deactivation 6	Deactivation 5	Deactivation 4	Deactivation 3	Deactivation 2	Deactivation 1
2001	Deactivation 16	Deactivation 15	Deactivation 14	Deactivation 13	Deactivation 12	Deactivation 11	Deactivation 10	Deactivation 9
2002	Deactivation 24	Deactivation 23	Deactivation 22	Deactivation 21	Deactivation 20	Deactivation 19	Deactivation 18	Deactivation 17
2003	Deactivation 32	Deactivation 31	Deactivation 30	Deactivation 29	Deactivation 28	Deactivation 27	Deactivation 26	Deactivation 25

DB1800	Deactivation [r/w]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000	Acknowledgement 8	Acknowledgement 7	Acknowledgement 6	Acknowledgement 5	Acknowledgement 4	Acknowledgement 3	Acknowledgement 2	Acknowledgement 1
4001	Acknowledgement 16	Acknowledgement 15	Acknowledgement 14	Acknowledgement 13	Acknowledgement 12	Acknowledgement 11	Acknowledgement 10	Acknowledgement 9
4002	Acknowledgement 24	Acknowledgement 23	Acknowledgement 22	Acknowledgement 21	Acknowledgement 20	Acknowledgement 19	Acknowledgement 18	Acknowledgement 17
4003	Acknowledgement 32	Acknowledgement 31	Acknowledgement 30	Acknowledgement 29	Acknowledgement 28	Acknowledgement 27	Acknowledgement 26	Acknowledgement 25

DB1800	Deactivation [r/w]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	Acknowledgement 8	Acknowledgement 7	Acknowledgement 6	Acknowledgement 5	Acknowledgement 4	Acknowledgement 3	Acknowledgement 2	Acknowledgement 1
5001	Acknowledgement 16	Acknowledgement 15	Acknowledgement 14	Acknowledgement 13	Acknowledgement 12	Acknowledgement 11	Acknowledgement 10	Acknowledgement 9
5002	Acknowledgement 24	Acknowledgement 23	Acknowledgement 22	Acknowledgement 21	Acknowledgement 20	Acknowledgement 19	Acknowledgement 18	Acknowledgement 17
5003	Acknowledgement 32	Acknowledgement 31	Acknowledgement 30	Acknowledgement 29	Acknowledgement 28	Acknowledgement 27	Acknowledgement 26	Acknowledgement 25

### Signals from maintenance planners

DB1800	Warnings/Alarms [r]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Alarm 8	Alarm 7	Alarm 6	Alarm 5	Alarm 4	Alarm 3	Alarm 2	Alarm 1
3001	Alarm 16	Alarm 15	Alarm 14	Alarm 13	Alarm 12	Alarm 11	Alarm 10	Alarm 9
3002	Alarm 24	Alarm 23	Alarm 22	Alarm 21	Alarm 20	Alarm 19	Alarm 18	Alarm 17
3003	Alarm 32	Alarm 31	Alarm 30	Alarm 29	Alarm 28	Alarm 27	Alarm 26	Alarm 25

#### Signals from operator panel (retentive area)

DB1900	Signals from operator panel [r/w] HMI -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Switch over Machine/Work	Simulation active						
1								
2								
3								
4								
6								
7								

#### General selection/status signals from HMI (retentive area)

DB1900	Signals from HMI [r] HMI -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000								
1001								
1002								
1003					Axis number for handwheel 1			
	Machine axis	Handwheel selected	Contour handwheel			C	B	A
1004					Axis number for handwheel 2			
	Machine axis	Handwheel selected	Contour handwheel			C	B	A
1005								
1006								
1007								

#### General selection/status signals to HMI (retentive area)

DB1900	Signals to HMI [r/w] PLC -> HMI interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000						OP key block		
5001								
5002								Enable measurement in JOG
5003								
5004 ... 5007	T-number for tool measurement in JOG (DINT)							
5008 ... 5011								



5012 ... 5015	
5016 ... 5019	

### A.7.2.7 Auxiliary functions transfer from NC channel

#### Overview

DB2500	Auxiliary functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								
1								
2								
3								
4				M fct. 5 change	M fct. 4 change	M fct. 3 change	M fct. 2 change	M fct. 1 change
5								
6								S fct. 1 change
7								
8								T fct. 1 change
9								
10								D fct. Change
11								
12						H fct. 3 change	H fct. 2 change	H fct. change
13								
14								
15								
16								
17								
18								
19								

#### Decoded M signals (M0 to M99)

#### Note

The signals are output for the duration of a PLC cycle.

DB2500	M functions from NCK channel [r] <sup>1) 2)</sup> NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Dynamic M functions							
	M7	M6	M5	M4	M3	M2	M1	M0
1001	Dynamic M functions							
	M15	M14	M13	M12	M11	M10	M9	M8

1002	Dynamic M functions							
	M23	M22	M21	M20	M19	M18	M17	M16
...	...							
1012	Dynamic M functions							
					M99	M98	M97	M96
1013								
1014								
1015								

1) As the PLC user, you must generate basic functions yourself from the dynamic M functions.

2) The basic program decodes dynamic M functions (M0 to M99).

#### Transferred T functions

DB2500	T functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	T function 1 (DINT)							
2004								
2005								
2006								
2007								

#### Transferred M functions

DB2500	M functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	M function 1 (DINT)							
3004	Extended address M function 1 (byte)							
3008	M function 2 (DINT)							
3012	Extended address M function 2 (byte)							
3016	M function 3 (DINT)							
3020	Extended address M function 3 (byte)							
3024	M function 4 (DINT)							
3028	Extended address M function 4 (byte)							
3032	M function 5 (DINT)							
3036	Extended address M function 5 (byte)							

#### Transferred S functions

DB2500	S functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000	S function 1 (REAL) (DINT)							
4004	Extended address S function 1 (byte)							
4008	S function 2 (REAL)							
4012	Extended address S function 2 (byte)							
4016								
4020								

### Transferred D functions

DB2500	D functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000	D function 1 (DINT)							
5004								

### Transferred H functions

DB2500	H functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
6000	H function 1 (REAL) (DINT)							
6004	Extended address H function 1 (byte)							
6008	H function 2 (REAL)							
6012	Extended address H function 2 (byte)							
6016	H function 3 (REAL)							
6020	Extended address H function 3 (byte)							

## A.7.2.8 NCK signals

### General signals to NCK

DB2600	General signals to NCK [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Protection level Keyswitch position 0 to 3					Acknowledged ge EMERGEN CY STOP	Acknowledged ge EMERGEN CY STOP	Braking along the contour in case of EMERGEN CY STOP
	4	5	6	7				
1						Request axis dis- tances to go	Request axis actual values	INC inputs in mode signal range ac- tive <sup>1)</sup>
2								
3								

<sup>1)</sup> Refer to mode signals

### General signals from NCK

DB2700	General signals from NCK [r/w] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0							EMERGEN CY OFF active	
1	Inch meas- uring sys- tem						Probe actuated	
							Probe 2	Probe 1

2	NC ready	Drive ready	Drives in cyclic operation					
3		Air temperature alarm						NCK alarm is active
4								
5								
6								
7								
8								
9								
10								
11								
12	Change counter for motion, handwheel 1							
13	Modification counter for motion, handwheel 2							
14								
15	Change counter , inch/metric measuring system							
16								
17								
18								
19								

#### Signals at fast inputs and outputs

<b>DB2800</b>	<b>Signals at fast inputs and outputs [r/w]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
1000	Block digital NCK inputs							
	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
1001	Value from PLC for NCK inputs							
	Input 8	Input 7	Input 6	Input 5	Input 4	Input 3	Input 2	Input 1
1008	Block digital NCK outputs							
	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
1009	Overwrite mask for digital NCK outputs							
	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
1010	Value from PLC for digital NCK outputs							
	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1
1011	Setting mask for NCK outputs							
	Output 8	Output 7	Output 6	Output 5	Output 4	Output 3	Output 2	Output 1

<b>DB2800</b>	<b>Signals at fast inputs and outputs [r/w]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
1000	Block external digital NCK inputs							
	Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9
1001	Value from PLC for external digit NCK inputs							
	Input 16	Input 15	Input 14	Input 13	Input 12	Input 11	Input 10	Input 9
1008	Block external digital NCK outputs							

	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
1009	Overwrite mask for external digital NCK outputs							
	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
1010	Value from PLC for external digital NCK outputs							
	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9
1011	Setting mask for external NCK outputs							
	Output 16	Output 15	Output 14	Output 13	Output 12	Output 11	Output 10	Output 9

#### Signals from fast inputs and outputs

<b>DB2900</b>	<b>Signals from the fast inputs and outputs [r]</b> PLC -> NCK interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Actual value for digital NCK inputs							
						Input 3	Input 2	Input 1
4	Setpoint for digital NCK outputs							
								Output 1

<b>DB2900</b>	<b>Signals from fast inputs and outputs [r]</b> NCK -> PLC interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
1000	Actual value for external digital NCK inputs							
						Input 3	Input 2	Input 1
1004	NCK setpoint for external digital NCK outputs							
								Output 1

DB3000	Mode signals to NCK [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reset			Mode change block		Mode		
						JOG	MDI	AUTO
1	Single block					Machine function		
	Type A	Type B				REF		
2	Machine function <sup>1)</sup>							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
3								

<sup>1)</sup> To use the machine function signals in DB3000.DBB2, you must set the "INC inputs in the operating-mode signal range active" signal (DB2600.DBX1.0) to "1".

<b>DB3100</b>	<b>Mode signals from NCK [r]</b> NCK -> PLC interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Reset				808 READY	Mode		
						JOG	MDI	AUTO

1						Active machine function		
						REF		
2	Machine function							
		Continuous traversing active	Var. INC active	10000 INC active	1000 INC active	100 INC active	10 INC active	1 INC active
3								

### A.7.2.9 Channel signals

#### Signals to NC channel

#### Control signals to NC channel

DB3200	Signals to NCK channel [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0		Activate test run feedrate	Activate M01	Activate single block <sup>1)</sup>	Activate DRF	Activate traverse forwards	Activate traverse backwards	
1	Activate program test						Enable protection zones	Activate referencing
2	Activate skip block							
	7	6	5	4	3	2	1	0
3								
4	Feedrate offset <sup>2)</sup>							
	H	G	F	E	D	C	B	A
5	Rapid traverse override							
	H	G	F	E	D	C	B	A
6	Feedrate override active <sup>3)</sup>	Rapid traverse override active	Path velocity limiting	Program level abort	Delete number of subroutine cycles	Delete distance - to-go	Read-in disable	Federate disable
7			Suppress start lock	NC stop axes plus spindle	NC stop	NC stop at block limit	NC start	NC start disable
8	Activate machine-related protection zone							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
9	Activate machine-related protection zone							
							Area 10	Area 9
10	Activate channel-specific protection zone							
	Area 5	Area 5	Area 5	Area 5	Area 5	Area 5	Area 5	Area 5
11	Activate channel-specific protection zone							
							Area 10	Area 9
12								
13	Do not block tool		Deactivate workpiece counter		Activate fixed feedrate			
					Feed 4	Feed 3	Feed 2	Feed 1

14	No tool change commands	JOG circle	Activate associated M01	Negative direction for contour handwheel simulation	Simulate contour handwheel	Activate contour handwheel (bit/binary coded)		
							Handwheel 2	Handwheel 1
15	Activate skip block 9	Activate skip block 8	Invert contour handwheel direction					
16								Program branches (GOTOS) control
17								
18								
19								

1) Select single-block type selection using the softkey.

2) 31 positions (Gray code)

#### Controls signals to axes in Work

DB3200	Signals to NCK channel [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Axis 1 in Work							
	Traversing keys		Rapid traverse over-ride	Traversing key distance disable	Feedrate stop	Activate handwheel (bit/binary coded) <sup>1)</sup>		
	Plus	Minus					2	1
1001	Axis 1 in Work Machine function <sup>2)</sup>							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1002								
1003								
								Handwheel direction of rotation inverted
1004	Axis 2 in Work							
	Traversing keys		Rapid travers over-ride	Traversing key disable	Feedrate stop	Activate handwheel (bit/binary coded)		
	Plus	Minus					2	1
1005	Axis 2 in Work Machine function							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1006								
1007								
								Invert handwheel direction

1008	Axis 3 in Work							
	Traversing keys		Rapid traverse override	Traversing key disable	Feedrate stop	Activate handwheel (bit/binary coded)		
	Plus	Minus					2	1
1009	Axis 3 in Work							
	Machine function							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1010								
1011								Invert handwheel direction

- 1) The handwheel number is represented according to the \$MD\_HANDWH\_VDI\_REPRESENTATION machine data in a bit-coded (=0) or binary-coded (=1) manner.
- 2) Machine function: the machine function is only entered if the "INC inputs in the operating-mode signal range active" signal (DB2600DBX1.0) is not set.

### Signals from NC channel

#### Status signals from NC channel

DB3300	Signals from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0		Last action block active	M0/M1 active	Approach block active	Action block active	Forwards traverse active	Backwards traverse active	Execution from external active
1	program test active		M2/M30 active	Block search active	Handwheel override active	Rev. federate active		Referencing active
2								
3	Channel status			Program status				
	Reset	Interrupted	Active	Aborted	Interrupted	Stopped	Waiting	Running
4	NCK alarm with processing stop present	Channel specific NCK alarm is active	Channel operational		All axes		Stop request	Start request
					Stationary	Referenced		
5						Contour handwheel active (bit/binary coded)		
							Handwheel 2	Handwheel 1
6								
7			Invert contour handwheel direction					Protection zone not guaranteed
8	Machine-related protection zone pre-activated							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
9	Machine-related protection zone pre-activated							
							Area 10	Area 9
10	Channel-specific protection zone pre-activated							



	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
11	Channel-specific protection zone pre-activated							
							Area 10	Area 9
12	Machine-related protection zone violated							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
13	Machine-related protection zone violated							
							Area 10	Area 9
14	Channel-specific protection zone violated							
	Area 8	Area 7	Area 6	Area 5	Area 4	Area 3	Area 2	Area 1
15	Channel-specific protection zone violated							
							Area 10	Area 9

#### Status signals, axes in Work

DB3300	Signals from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Axis 1 in Work							
	Travel command		Travel request			Handwheel active (bit/binary coded) <sup>1)</sup>		
	Plus	Minus	Plus	Minus			2	1
1001	Axis 1 in Work Machine function <sup>2)</sup>							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1002								
1003								
								Contour handwheel direction of rotation inverted
1004	Axis 2 in Work							
	Traversing command		Travel request			Handwheel active (bit/binary coded)		
	Plus	Minus	Plus	Minus			2	1
1005	Axis 2 in Work Machine function							
		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1006								
1007								
								Contour handwheel direction of rotation inverted
1008	Axis 3 in Work							
	Traversing command		Travel request			Handwheel active (bit/binary coded)		
	Plus	Minus	Plus	Minus			2	1
1009	Axis 3 in Work Machine function							

		Continuous traversing	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
1010								
1011								Contour handwheel direction of rotation inverted

#### Additional status signals from NC channel

DB3300	Signals from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000								G00 active
4001			Travel request, drive test present				Workpiece setpoint reached	External language mode active
4002		Dry run feedrate Active	Associated M01/M00 Active	STOP_DELAYED				ASUB is stopped
4003	No tool change command active	DELAY FST SUPPRESS		DELAY FST				
4004	ProgEvent display							
				Start after block search	Boot	Operator panel Reset	Part program End	Part program Start from RESET
4005		Jog circle Active					Stop condition	StopByColl Danger
4006							Dormant ASUB Active	ASUB active
4007								
4008	Active transformation number							
4009	Reserved							
4010	Reserved							
4011	Reserved							

### Asynchronous subroutines (ASUBs): Job

DB3400	ASUB: Result [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0								INT1 Start
1								INT2 Start
2								
3								

### Asynchronous subroutines (ASUBs): Result

DB3400	ASUB: Result [r] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	INT1							
					ASUB execution not possible	Interrupt no. not allocated	ASUB is being executed	ASUB ended
1001	INT2							
					ASUB execution not possible	Interrupt no. not allocated	ASUB is being executed	ASUB ended
1002								
1003								

### G functions from NCK channel

DB3500	G functions from NCK channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Active G function of group 1 (8 bit int)							
1	Active G function of group 2 (8 bit int)							
2	Active G function of group 3 (8 bit int)							
...	...							
62	Active G function of group 63 (8 bit int)							
63	Active G function of group 64 (8 bit int)							

## A.7.2.10 Axis/spindle signals

### Transferred M and S functions, axis specific

DB3700 ... 3703	M, S functions [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	M function for spindle (DINT)							
4	S function for spindle (REAL)							

## Signals to axis/spindle

### Common signals to axis/spindle

DB3800 ... 3803	Signals to axis/spindle [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Feedrate override							
	H	G	F	E	D	C	B	A
1	Override active	Position measuring system 2	Position measuring system 1	Follow up mode	Axis spindle disable			
2	Reference point value				Clamping in progress	Distance-to-go/spindle reset	Drive enable	
	4	3	2	1				
3	Axis/spindle enable program test	Velocity/spindle speed limiting	Activate fixed feedrate				Enable approach to fixed stop	
			Feed 4	Feed 3	Feed 2	Feed 1		
4	Traversing keys		Rapid traverse override	Traverse key disable	Feedrate stop/spindle stop	Activate handwheel		
	Plus	Minus					2	1
5	Machine function <sup>1)</sup>							
		Continuous traversing	Var. INC	1000 INC	1000 INC	100 INC	10 INC	1 INC
6								
7								Contour-handwheel direction of rotation inverted
8								
9								
10								
11								

<sup>1)</sup> The machine function is only entered if the signal "INC inputs in the operating-mode signal range active" (DB2600.DBX1.0) is set.

### Signals to axis

DB3800 ... 3803	Signals to axis [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Delay Ref. pt. approach			Module limit enabled	Software limit switch		Hardware limit switch	
					Plus	Minus	Plus	Minus
1001								
1002							Activate program test	Suppress program test
1003								

### Signals to spindle

DB3800 ... 3803	Signals to axis [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Delete S value	No speed monitoring for gear change	Resynchronize spindle		Gear changed	Actual gear stage		
			2	1		C	B	A
2001		Invert M3/M4		Resynchro- nize during positioning				Feedrate override for spindle valid
2002	Setpoint direction of rota- tion		Oscillation speed	Oscillation controlled by PLC				
	Counter- clockwise	Clockwise						
2003	Spindle override							
	H	G	F	E	D	C	B	A

### Signals to drive

DB3800 ... 3803	Signals to axis/spindle [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000			Holding brake					
4001	Pulse enable	Integrator disable speed controller						
4002								
4003								

### Signals to technology functions

DB3800 ... 3803	Signals to axis/spindle [r/w] PLC -> NCK interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000				Torque equalization controller on				
5001								
5002								
5003	Stop HIAxMove							Resume DEPMCS
5004								
5005								
5006 (spindle)				Spindle positioning	Automatic gear stage change	Setpoint direction of rotation		Spindle stop
						Counter-clockwise	Clockwise	

5007 (couplings)	Delete synchronism override							
5008 (SISI-TECH)								
5009 (SISI-TECH)								
5010								
5011								

## Signals from axis/spindle

### General signals from axis/spindle

DB3900 ... 3903	Signals from axis/spindle [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Position reached		Referenced		Encoder limit freq. exceeded			Spindle/no axis
	With exact/stop, fine	With exact/stop, coarse	Synchronized 2	Synchronized 1	2	1		
1	Current controller active	Speed controller active	Position controller active	Axis/spindle stationary (n < n <sub>mm</sub> )	Follow up mode active	Axis ready for operation		Traversing requests
2		Force fixed stop limited	Fixed stop reached	Activate travel to fixed stop	Measurement active		Handwheel override active	
3						AxStop active		
4	Travel command		Travel request			Handwheel active (bit/binary coded)		
	Plus	Minus	Plus	Minus			2	1
5	Active machine function							
		Continuous	Var. INC	10000 INC	1000 INC	100 INC	10 INC	1 INC
6								
7								Contour-handwheel direction of rotation inverted
8								
9								
10								
11			POS_RESTO					
			RED 2	RED 1				

### Signals from axis

DB3900 ... 3903	Signals from axis [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000				Module limit enabled active				
1001								
1002	Rotary axis in position	Indexing axis in position	Positioning axis	Path axis				Lubrication pulse
1003								

### Signals from spindle

DB3900 ... 3903	Signals from spindle [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000					Change gear stage	Setpoint gear stage		
						C	B	A
2001	Actual direction of rotation, clockwise	Speed monitoring	Spindle in setpoint range	Overlay range limit violated		Setpoint		Speed limit exceeded
						Increased	Limited	
2002	Active spindle mode				Rigid tap- ping		GWPS active	Const. Cutting velocity active
	Control mode	Oscillation mode	Positioning mode					
2003		Spindle in position reached						Tool with dynamic limiting

### Signals from drive

DB3900 ... 3903	Signals from axis/spindle [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4000			Holding brake opened	RLI active				
4001	Pulse ena- bled	Speed controller integrator disabled	Drive ready					
4002		$n_{act} = n_{set}$	$n_{act} < n_x$	$n_{act} < n_{min}$	$M_d < M_{dx}$	Ramp-up completed		
4003					Generator operation, minimum speed falled below			VDCLink < alarm threshold

## Signals from technology functions

DB3900 ... 3903	Signals from axis/spindle [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
5000								
5001								
5002		Accelera- tion warn- ing threshold reached	Velocity warning threshold reached	Superim- posed mo- tion		Actual value cou- pling	Synchronous operation	
							Coarse	Fine
5003		Max. accel- eration reached	Max. veloci- ty reached	Synchroni- zation in progress	Axis is accelerat- ing	Synchro- nism over- ride travel		
5004								
5005								
5006								
5007								Synchro- nism over- ride is factored in
5008 (grinding)	Active special axis							
			Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1

## A.7.2.11 PLC machine data

### INT values (MD 14510 USER\_DATA\_INT)

DB4500	Signals from NCK [r16] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Int value (WORD/2 byte)							
2	Int value (WORD/2 byte)							
4	Int value (WORD/2 byte)							
6	Int value (WORD/2 byte)							
...	...							
60	Int value (WORD/2 byte)							
62	Int value (WORD/2 byte)							

### HEX values (MD 14512 USER\_DATA\_HEX)

DB4500	Signals from NCK [r8] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1000	Hex value (BYTE)							
1001	Hex value (BYTE)							
1002	Hex value (BYTE)							
1003	Hex value (BYTE)							
...	...							
1030	Hex value (BYTE)							
1031	Hex value (BYTE)							



**FLOAT values (MD 14514 USER\_DATA\_FLOAT)**

DB4500	Signals from NCK [r32] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
2000	Float value (REAL/4 byte)							
2004	Float value (REAL/4 byte)							
2008	Float value (REAL/4 byte)							
2012	Float value (REAL/4 byte)							
2016	Float value (REAL/4 byte)							
2020	Float value (REAL/4 byte)							
2024	Float value (REAL/4 byte)							
2028	Float value (REAL/4 byte)							

**User alarm: Configuring (MD 14516 USER\_DATA\_PLC\_ALARM)**

DB4500	Signals from NCK [r8] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
3000	Alarm response/cancel criteria, alarm 700000							
3001	Alarm response/cancel criteria, alarm 700001							
3002	Alarm response/cancel criteria, alarm 700002							
...	...							
3247	Alarm response/cancel criteria, alarm 700247							

**Note**

For more information about how to configure user alarms, see Section "Editing PLC alarm texts (Page 91)".

**A.7.2.12 Signals, synchronized actions****Signals, synchronized actions to channel**

DB4600	Signals, synchronized actions to channel [r/w] PLC -> HMI interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Deactivate synchronized action with ID...							
	ID8	ID7	ID6	ID5	ID4	ID3	ID2	ID1
1	Deactivate synchronized action with ID...							
	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9
2	Deactivate synchronized action with ID...							
	ID24	ID23	ID22	ID21	ID20	ID19	ID18	ID17

**Signals, synchronized actions from channel**

DB4700	Signals, synchronized actions from channel [r] NCK -> PLC interface							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Synchronized action with ID...can be blocked from the PLC							
	ID8	ID7	ID6	ID5	ID4	ID3	ID2	ID1
1	Synchronized action with ID...can be blocked from the PLC							

	ID16	ID15	ID14	ID13	ID12	ID11	ID10	ID9
2	Synchronized action with ID...can be blocked from the PLC							
	ID24	ID23	ID22	ID21	ID20	ID19	ID18	ID17

#### Reading and writing PLC variables

<b>DB4900</b>	<b>PLC variables [r/w]</b> PLC interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Offset [0]							
1	Offset [1]							
2	Offset [2]							
...	...							
4094	Offset [4094]							
4095	Offset [4095]							

#### Note

The programming engineer (NCK and PLC) is responsible for organizing (structuring) this memory area. Every storage position in the memory can be addressed provided that the limit is selected according to the appropriate data format (i.e. a 'DWORD' for a 4byte limit, a WORD for a 2byte limit, etc.). The memory area is always accessed with the information about the data type and the position offset within the memory area.

#### A.7.2.13 Axis actual values and distance-to-go

<b>DB5700 ... 5704</b>	<b>Signals from axis/spindle [r]</b> NCK -> PLC interface							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Axis actual value (REAL)							
4	Axis distance-to-go (REAL)							

#### Note

The axis actual values and distances-to-go can be separately requested:

- DB2600.DBX0001.1 Request axis actual values
- DB2600.DBX0001.2 Request axis distances-to-go

If the particular request is set, then the NCK supplies these values for all axes.

#### A.7.2.14 Maintenance scheduler: User interface

##### Initial (start) data

<b>DB9903</b>	<b>Initial data table [r16]</b>							
<b>Byte</b>	<b>Bit 7</b>	<b>Bit 6</b>	<b>Bit 5</b>	<b>Bit 4</b>	<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>
0	Interval 1 [h]							
2	Time of first warning 1 [h]							
4	Number of warnings to be output 1							
6	Reserved 1							
8	Interval 2 [h]							
10	Time of first warning 2 [h]							
11	Number of warnings to be output 2							
14	Reserved 2							

...	...
248	Interval 32 [h]
250	Time of first warning 32 [h]
252	Number of warnings to be output 32
254	Reserved 32

#### Actual data

DB9904	Actual data table [r16]							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Interval 1 [h]							
2	Number of warnings to be output 1							
4	Reserved_1 1							
6	Reserved_2 1							
8	Interval 2 [h]							
10	Number of warnings to be output 2							
11	Reserved_1 2							
14	Reserved_2 2							
...	...							
248	Interval 32 [h]							
250	Number of warnings to be output 32							
252	Reserved_1 32							
254	Reserved_2 32							

### A.7.2.15 User interface for ctrl energy

#### Energy saving profile


DB9906	Ctrl energy							
Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Control signals							
							Set time to pre-warning limit	Immediately activate energy saving profile
1	Control signals (HMI -> PLC)							
								Immediately activate energy saving profile
2	Signals to check/test the energy-saving profile							
							PLC user signal	Master computer signal
3	Reserved							

4	Status signal							
							Activation time T1 expired	Energy saving profile active
5	Reversed							
6	Actual value: actual value T1							
8	Actual value: actual value T2							
10	Effectiveness, profile							
							Disable energy saving profile	Energy saving profile configured
11	State conditions (HMI -> PLC)							
						Screen change	Data transfer	Operator panel
12	State conditions (HMI -> PLC)							
								Machine control panel
13	State conditions (HMI -> PLC)							
								NC channel 1 in reset
14								
15	State conditions (HMI -> PLC)							
							PLC user signal	Master computer signal
16	State conditions (HMI -> PLC) Activation time T1							
18	State conditions (HMI -> PLC) Activation time T2							

### A.7.3 Operation symbols of PLC programming languages

Special bit memory SM bit definition (read-only)

Special markers



Variable access rights

[r]	You can "read only" the designated area.
[r/w]	You can "read and write" the designated area.

Data format information

1	BIT
8	BYTE
16	INT/WORD
32	DINT/DWORD/REAL

#### Note

All of the empty fields in the user interface are "reserved for Siemens" and may neither be written to nor be evaluated. Fields designated with "0" always have the value "logical 0". If there is no data format information, you can read or write to all the specified data formats.


## Signal of input and output

Address

Input; I	Output; Q
----------	-----------

Form

bit	I0.0, I4.6;	Q2.1, Q1.7
byte	IB4, IB12;	QB3, QB7
word	IW2, IW4;	QW0, QW6
double word	ID2, ID8;	QD0, QD4




## Accumulator

Accumulator: AC (max 4 accumulators)

Form; arithmetic accumulators AC0 and AC1; logical accumulators AC2 and AC3.
---

Flag register: M

bit	M0.1;	M124.5
byte	MB21;	MB12
word	MW22;	MW106
double word	MD4;	MD28



## Counter

Counter: C

Form;  
condition of counter bit C3, C25; - represents the  
comparison result of the counter and present value.


Style:

plus counter CTU count: counter value + 1;  
R = 1 counter resets; counter value > preset value  
Cn = 1

minus counter CTD count: counter value - 1;  
LD counter value = preset; value = counter value = 0  
Cn = 1

plus and minus counter CTUD plus counter:  
counter value + 1;

minus counter: counter value R = 1 counter  
resets: counter value > preset value C = 1



## Timers

Timer: T

Form;  
condition of timer bit T3, T25; - represents the comparison result of timer value and preset value

timer value T3, T25; - represents timer value

Style;


open delay timer TON IN=1 begin timing ; IN=0 timer resetting ; count value>preset value Tn=1

close delay timer TOF IN=1 timer resetting ; IN=0 begin timing; count value>preset value Tn=0

keep delay timer CTUD IN=1 begin timing; IN=0 timer stops; count value>preset value Tn1

Assign word constant0" to T to make counter composite





## A.7.4 PLC subroutine library

In order to simplify the PLC design, we provide refined PLC functions which have generality, such as initialization, machine panel signal processing, emergency stop processing, axis enable control, hard limit, and reference point etc. By adding the desired subroutine module to the main procedure, plus other supplementary procedures, you can complete the PLC procedure design easily.

The PLC subroutine library consists of the following files:

- PLC project file: SAMPLE\_TURN.PTP (application program as examples for a turning machine)
- PLC project file: SAMPLE\_MILL.PTP (application program as examples for a milling machine)

### Note

Through these examples, you can clearly realize how to create or invoke PLC subroutines. You can reorganize PLC subroutines or modify networks to realize most machine functions, test and debug subroutines of the library.

### System resource

	Resource	
PLC system resource	Input	I0.0 to I2.7 (24 inputs on X100, X101, and X102) I3.0 to I8.7 (48 distributed inputs on X301 and X302)
	Output	Q0.0 to Q1.7 (16 outputs on X200 and X201) Q2.0 to Q5.7 (32 distributed outputs on X301 and X302)
	RAM	M0.0 to M255.7 (256 bytes)
	Non-volatile memory	DB1400.DBX0.0 to DB14000.DBX127.7 (128 bytes)
	PLC user alarm	DB1600.DBX0.0 to DB16000.DBX15.7 (128 user alarms)
	Timer	T0 to T15 (100 ms timer) T16 to T32 (10 ms timer)
	Counter	C0 to C63 (64 counters)
NC resource	Parameter MD14510(32)	Statistic INT: DB4500.DBW0 to DB4500.DBW62 (32 double words)
	Parameter MD14514(32)	Statistic HEX: DB4500.DBB1000 to DB4500.DBB1031 (32 bytes)
	Parameter MD14514(8)	Statistic REAL: DB4500.DBD2000 to DB4500.DBD2028 (8 double words)
Programming tool resource	Subroutine (64)	SBR0 to SBR63 (64 subroutines)
	Symbol table (32)	SYM1 to SYM32 (32 symbol tables)

### Constant definition

Constant input	Symbol	Address
Constant "1"	ONE	SM0.0
Constant "2"	ZERO	M251.0

## Zero output definition

Data type	Symbol	Address
bit	NULL_b	M255.7
byte	NULL_B	M255
word	NULL_W	M254
double-word	NULL_DW	M252

## Structure of symbol tables

All the addresses in the PLC subroutine library are programmed with symbols. All the signals of interfaces are named by symbols and arranged in different symbol tables.

The name of a symbol follows some conventions. For details, see the topic Conventions for the symbols used in the subroutines (Page 241).

Symbol table	Table name	Descriptions
1	IO_1	Module I/O are defined by the manufacturer
2	IO_2	Distributed I/O are defined by the manufacturer
3, 5, 7, 13		Reserved for the manufacturer
6	MANMACH	JOG function
14	ASUP	ASUP function
15	PLC_sel_PP	PLC selects part programs
16	IS_MCP	Signals from/to the MCP
17	IS_HMI	Signals from/to the HMI
18	IS_AUX	Auxiliary functions from the NCK
19	IS_NCK	Signals from/to the NCK
20	IS_CHA	Signals from/to the channel
21	IS_AX1	Signals to/from axis 1
22	IS_AX2	Signals to/from axis 2
23	IS_AX3	Signals to/from axis 3
24	IS_AX4	Signals to/from axis 4
27	MD_PLC	PLC machine data
28	ALARM	User alarms
29	NV_MEM	Non-volatile memory
30	SPC_MEM	Special memory bit
31	SBR_MEM	Global memory used in the sample applications and subroutines
32	RESVD1	Reserved for the sample applications and subroutines

## Structure of subroutines

PLC sample subroutines offer PLC functions for the machine tool.

Subroutine No.	Name	Description
0 to 19	-	Reserved for the manufacturer
20	AUX_MCP	Auxiliary function
21	AUX_LAMP	Working lamp control, called in the subroutine "AUX_MCP".
22	AUX_SAFE_DOOR	Safety door control, called in the subroutine "AUX_MCP" for a milling application
23	AUX_CHIP	Chip conveyor control, called in the subroutine "AUX_MCP" for a milling application
31	PLC_ini_USR_INI	Reserved for initialization functions of the manufacturer (this subroutine is automatically called by subroutine 32)
32	PLC_INI	PLC initialization, executed at the first PLC cycle (SM0.1)

Subroutine No.	Name	Description
33	EMG_STOP	Emergency Stop
37	MCP_NCK	Signals from the MCP and HMI are sent to NCK interfaces
38	MCP_Tool_Nr	Display tool numbers via the 7-segment LED of the MCP
39	HANDWHL	Handwheel selection via the HMI
40	AXIS_CTL	Control of feed axis enable and spindle enable
41	MINI_HHU	Handwheel on hand-held unit
42	SPINDLE	Spindle control, including the spindle braking function
43	MEAS_JOG	Tool measurement in the JOG mode
44	COOLING	Coolant control (Manual Machine key and M code: M07, M08, M09)
45	LUBRICATE	Lubrication control (interval and time)
46	PI_SERVICE	ASUP (Asynchronous Subroutine Program)
47	PLC_Select_PP	PLC selects a subroutine
48	ServPlan	Service planner
49	Gear_Chg1_Auto	Automatic gear change of the spindle
50	Gear_Chg2_Virtual	Virtual gear change of the spindle
51	Turret1_HED_T	Turret control for turning machine (turret type: Hall element transistor, 4/6 position)
52	Turret2_BIN_T	Turret control for turning machine (turret type: position detection with encodings)
53	Turret3_CODE_T	Hydraulic turret control for turning machine (turret type: position detection with encodings)
54	Turret2_3_ToolDir	Evaluate tool direction and calculate tool position (called by Turret2_BIN_T, Turret3_CODE_T)
55	Tail_stock_T	Tailstock control for turning machine
56	Lock_unlock_T	Clamp or release control for turning machine
58	MM_MAIN	Manual machine
59	MM_MCP_808D	Spindle signal processing for the manual machine
60	Disk_MGZ_M	Disk tool magazine for a milling machine
63	TOGGLE	Six key-operated switches: K1 to K6 Two delay switches: K7, K8
34-36/57/61/62		Reserved for the OEM

### Lathe and milling functions

PLC sample subroutines for lathe functions:

For turning only		
SBR 51	Turret1_HED_T	HED turret control
SBR 52	Turret2_BIN_T	Bi-direction turret (binary coded)
SBR 53	Turret3_CODE_T	Bi-direction turret (coded by turret supplier)
SBR 55	Tail_stock_T	Tailstock control
SBR 56	Lock_unlock_T	Chuck control

PLC sample subroutines for milling functions:

For milling only		
SBR 60	Disk_MGZ_M	Disk magazine control (w/o automatic tool changer)

### A.7.4.1 PLC machine data

#### USER\_DATA\_INT

No.	Unit	Description
14510 [12]	-	Layout of the traverse keys
14510 [13]	0.1s	Time for spindle braking
14510 [15]	0.1s	Spindle override 50% key holding on time defined
14510 [16]	0.1s	Spindle override 100% key holding on time defined
14510 [20]	-	Maximum number of tools
14510 [21]	0.1s	Turret clamping time
14510 [22]	0.1s	Monitoring time when searching for tools
14510 [24]	1 min	Lubricating interval
14510 [25]	0.01s	Lubricating duration

#### USER\_DATA\_HEX

No.	Descriptions
14512 [16]	Bit 1: function of chip conveyor (milling) Bit 2: function of safety door (milling) Bit 3: when the function of safety door is active, it can be triggered by M01/M02 (milling) Bit 7: handwheel assignment with the MCP/HMI
14512 [17]	Bit 0: turret (turning); tool magazine (milling) Bit 1: clamping function (turning) Bit 2: tailstock function (turning) Bit 3: selection between handwheel and hand-held unit (0: handwheel; 1: hand-held unit)
14512 [18]	Special configurations for machines Bit 2: automatic lubrication at power-on Bit 4: external signal for spindle stop Bit 5: fixed spindle direction Bit 6: the hardware limit is independent from a PLC program Bit 7: each feed axis has a hardware limit switch (activated when Bit 6 = 0)
14512 [19]	Bit 1: function of spindle braking Bit 2: password clearing by power-on (0: delete the password; 1: do not delete the password) Bit 3: selection between normal mode and maintenance mode (0: normal mode; 1: maintenance mode) Bit 7: manual machine function (this function become active if you have installed licensed turning machine system and called it with a PLC subroutine)
14512 [20]	Bit 0: grey coded switch (0: spindle override controlled by the grey mode; 1: spindle override controlled by trigger user keys) Bit 1: spindle disable mode (0: disable by pressing the spindle stop key; 1: disable when detecting the standstill speed) <sup>1)</sup> Bit 2: activate the first additional axis (0: disable the additional axis control; 1: enable the additional axis control) Bit 3: the first additional axis as the second spindle and does not need to be kept enabled (1: as the second spindle and does not need to be kept enabled) Bit 5: define the spindle override startup value (0: the startup spindle override is always 100%; 1: re-code the spindle override value of the last machine turn off for the next startup) Bit 6/7: define the spindle override shift speed

<sup>1)</sup> When the position control mode is active, do not disable the spindle by detecting the standstill speed.

## USER\_DATA\_FLOAT

No.	PLC interface	Range	Function
14514[0]	DB4500.DBD2000	-3.40e38 to 3.40e38	Tool magazine: spindle positioning angle
14514[1]	DB4500.DBD2004	-3.40e38 to 3.40e38	Tool magazine: preparation position of axis Z for tool change
14514[2]	DB4500.DBD2008	-3.40e38 to 3.40e38	Tool magazine: tool change position of axis Z
14514[3]	DB4500.DBD2012	-3.40e38 to 3.40e38	Tool magazine: velocity of axis Z, go to the tool change position
14514[4]	DB4500.DBD2016	-3.40e38 to 3.40e38	Tool magazine: velocity of axis Z, back to the tool change preparation position

### A.7.4.2 Conventions for the symbols used in the subroutines

The symbols used in the subroutines follow the conventions listed below:

- Leading characters designate the destinations of interface signals.
  - P\_: to PLC interface
  - H\_: to HMI interface
  - N\_: to NCK interface
  - M\_: to MCP interface
- Subsequent characters are for areas.
  - N\_: NCK
  - C\_: Channel
  - 1\_: Axes
  - M\_: MCP
- Other short forms of the symbols are as follows.
  - HWL: **H**ardware **L**imit
  - HW: **H**and**w**heel
  - RT: **R**apid **T**raverse
  - TK: **T**raverse **k**ey
  - ACT: **A**ctive
  - SEL: **S**elect**e**d
- Symbols consist of a maximum of 11 upper case characters and numbers (including the leading character). Except for underlines, you cannot use any other special symbols like =, +, -, [ ], etc.

### A.7.4.3 Subroutine 20 - AUX\_MCP (machine auxiliary functions)

#### Purpose

Subroutine 20 is used to call the Auxiliary function Subroutines AUX\_LAMP, AUX\_CHIP, and AUX\_SAFETY\_DOOR.


#### Local variable definition

None

#### Relevant PLC machine data

None

#### Example for calling subroutine 20



### A.7.4.4 Subroutine 21 - AUX\_LAMP (working lamp)

#### Purpose

Subroutine 21 is used to control working lamp and can be called in AUX\_MCP. One-time pressing of the "**LAMP**" key activates the working lamp while double pressing de-activates the working lamp.

#### Local variable definition

##### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
LampK	BOOL	Lamp on/off key


##### Outputs

Variable	Type	Description
LampLED	BOOL	Lamp status
LampOut	BOOL	Lamp output

#### Relevant PLC machine data

None

#### Example for calling subroutine 21



#### A.7.4.5 Subroutine 22 - AUX\_SAFE\_DOOR (safety door)

##### Purpose

Subroutine 22 is used to control the safety door and can be called in AUX\_MCP.

##### Local variable definition

##### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
DoorK	BOOL	Door control key
IsDoorCls	BOOL	Signal: door is closed
M1_2_OpDoor	BOOL	Open door when M01/M02 is active


##### Outputs

Variable	Type	Description
DoorOp	BOOL	Door open output
DoorLED	BOOL	Door status
MsgDoorNotCls	BOOL	Message for door open

##### Relevant PLC machine data

No.	Description
14512 [16].2	Selection of safety door function (0: do not use; 1: use)
14512 [16].3	Safety door function is activated by M01/M02 (0: deactivate; 1: activate)

##### Example for calling subroutine 22



#### A.7.4.6 Subroutine 23 - AUX\_CHIP (chip conveyor)

##### Purpose

Subroutine 23 is used to control the chip conveyor and can be called in AUX\_MCP. At first-time pressing of the "Chip Forward" key the output "ChipFwd" is high; at second-time pressing of the "Chip Forward" key the output "ChipFwd" becomes low. When the output "ChipFwd" is low, the output "ChipRev" becomes high at pressing "Chip Reverse" key and becomes low at releasing the "Chip Reverse" key.

##### Local variable definition

##### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
ChipFwdK	BOOL	Chip forward key
ChipRevK	BOOL	Chip reverse key


## Outputs

Variable	Type	Description
ChipFwdLED	BOOL	Chip forward led
ChipFwd	BOOL	Chip forward output
ChipRevLED	BOOL	Chip reverse led
ChipRev	BOOL	Chip reverse output

## Relevant PLC machine data

No.	Description
14512 [16].1	Selection of chip conveyor function (0: do not use; 1: use)

## Example for calling subroutine 23



## A.7.4.7 Subroutine 31 - PLC\_ini\_USR\_ini (user initialization)

### Purpose

Subroutine 31 is used for user initialization and should be called in subroutine PLC\_INI. Since the subroutine PLC\_INI is called only during the first PLC cycle, the subroutine PLC\_ini\_USER\_ini is also only called during the first PLC cycle.


### Local variable definition

None

### Relevant PLC machine data

None

## Example for calling subroutine 31



## A.7.4.8 Subroutine 32 - PLC\_INI (PLC initialization)

### Purpose

Subroutine 32 is executed at the first PLC cycle (SM0.1). This subroutine sets NCK interface signals according to the machine settings defined by PLC machine data. In this subroutine, the following interface signals are set:

- DB3200.DBX6.7: feed override of the NCK channel becomes active
- DB380x.DBX1.5: measurement system 1 of the axes is active



- DB380x.DBX1.7: feed override of the axes is active
- DB1700.DBX1.3: active ROV

The following signals are reset:

- DB1700.DBX0.6: reset DRY

At the end of this subroutine, subroutine 31 (**PLC\_ini\_USR\_ini**) is called. You can program the initialization of customer PLC project in the subroutine 31.


#### Local variable definition

None

#### Relevant PLC machine data

None

#### Example for calling subroutine 32



### A.7.4.9 Subroutine 33 - EMG\_STOP

<b>NOTICE</b>
<b>Program safety</b>
Check whether this subroutine complies with the relevant safety requirements or not.


#### Purpose

Subroutine 33 handles emergency stop. Pressing down the Emergency Stop button produces an emergency stop alarm and disables the drive enable signal (DB380x.DBX2.1). If you want to clear the emergency stop alarm, you must first release the Emergency Stop button and then press the **RESET** key on the MCP.

This subroutine activates the alarm below:

Alarm 700016: DRIVE NOT READY

#### Timing diagram



## Local variable definition

### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
E_KEY	BOOL	Emergency stop key (NC)
HWL_ON	BOOL	Any one of the hardware limit switches is active (NO) <sup>1)</sup>
SpStop	BOOL	Spindle stopped (NO) <sup>2)</sup>
NO: Normal Open NC: Normal Close		

<sup>1)</sup> This input can come from signal OVlmt of subroutine 40, and triggers emergency stop when the hardware limit appears.

<sup>2)</sup> Before the drive system disables the control enable signal, the PLC detects the spindle stop signal from NCK to ensure that the spindle has stopped.


### Outputs

Variable	Type	Description
NC_Ready	BOOL	NC being in the cyclic state and able to enable the drive

## Relevant PLC machine data

No.	Value	Description
14512 [18].4	1	Spindle has an external stop signal
	0	Spindle has no external stop signal

## Example for calling subroutine 33



## A.7.4.10 Subroutine 37 - MCP\_NCK (MCP and HMI signal processing)

### Purpose

Subroutine 37 is used to transfer the interface signals from the MCP and HMI to the NCK interfaces, and thus to activate the specific operating mode and control sequences. It has the following main functions:

- Selecting specific operating mode
- Selecting override
- Transferring signals from the HMI to NCK interfaces (for instance, program control, handwheel, etc.)
- Controlling the axis traversing signal according to the PLC machine data

## Local variable definition

### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
AFL_Key	BOOL	Define the Auxiliary Function Lock at the MCP key <sup>1)</sup>
ConHw_Key	BOOL	Define the Contour Handwheel at the MCP key

Variable	Type	Description
SimConHw_Key	BOOL	Define the simulation contour handwheel at the MCP key
NegDir-SimConHw_Key	BOOL	Define the negative direction for simulation contour handwheel at the MCP key
INCvar_Key	BOOL	Define the INCvar at the MCP key

<sup>1)</sup> When the Auxiliary Function Lock function is active, all the outputs caused by auxiliary functions (like T, M, or S code) are disabled, only with the axis moving as usual.


#### Outputs

Variable	Type	Description
AFL_LED	BOOL	Define the Auxiliary Function Lock at the MCP LED
ConHw_LED	BOOL	Define the Contour Handwheel at the MCP LED
SimConHw_LED	BOOL	Define the simulation contour handwheel at the MCP LED
NegDir-SimConHw_LED	BOOL	Define the negative direction for simulation contour handwheel at the MCP LED
INCvar_LED	BOOL	Define the INCvar at the MCP LED

#### Relevant PLC machine data

No.	Description
14512 [20].0	Grey coded switch (0: spindle override controlled by the grey mode; 1: spindle override controlled by trigger user keys)
14512 [20].2	Activate the first additional axis (0: disable the additional axis control; 1: enable the additional axis control)
14510 [12]	Layout of the traverse keys <ul style="list-style-type: none"> <li>For a turning variant, 0: horizontal version; 1: inclined version</li> <li>For a milling variant, 0: vertical milling; 1: knee-type</li> </ul>

#### Example for calling subroutine 37



#### A.7.4.11 Subroutine 38 - MCP\_Tool\_Nr (display tool number on the MCP)

##### Purpose

Subroutine 38 is used to display active tool number (< 100) with the 7-segment LED on the MCP. For a tool number ≥ 100, it displays "FF".

##### Local variable definition

None


##### Assigned global variables

None

##### Relevant PLC machine data

None

##### Example for calling subroutine 38



#### A.7.4.12 Subroutine 39 - HANDWHL (selecting a handwheel according to HMI interface signals)

##### Purpose

Subroutine 39 is used to select one of the two handwheels to control an axis (X, Y or Z) in the machine coordinate system or the workpiece coordinate system according to the HMI signals. With the HANDWHEEL key and axis selection key on the MCP, you can assign the handwheel 1 in the workpiece coordinate system to any axis.

##### Note

You cannot use subroutine 39 together with subroutine 41 - MINI\_HHU.

##### Local variable definition

None


##### Assigned global variable

None

##### Relevant PLC machine data

No.	Value	Description
14512 [16].7	1	Handwheel assignment with the HMI
	0	Handwheel assignment with the MCP

##### Example for calling subroutine 39



### A.7.4.13 Subroutine 40 - AXIS\_CTL (controlling the spindle and axes)

#### Purpose

Subroutine 40 is used to control the drive pulse enable (DB380xDBX4001.7) and controller enable (DB380xDBX2.1), monitoring the hardware limits and the reference cam signals, and controlling the enable signal for the spindle according to a spindle command (for example, SPINDLE CW, SPINDLE CCW, M03, M04, SPOS, etc.). The motor brake is automatically controlled by the SINAMICS V70 drives.

This subroutine provides two ways to realize the hardware limit control:


- PLC solution (MD14512 [18] bit 6 = 0)

Each feed axis has one (MD14512 [18] bit 7 = 1) or two (MD14512 [18] bit 7 = 0) hardware limit switches. This subroutine activates the NCK hardware limit function via the NCK interface DB380xDBX1000.0 or DB380xDBX1000.1 according to the configurations of the hardware limit switches, and thus makes the NCK produce a feed stop signal to an over-distance axis.

Furthermore, you can also connect the output **OVInt** of this subroutine with the input **HWL\_ON** of subroutine 33 to activate the Emergency Stop automatically once the hardware limit of any axis has been reached.

- Hardware solution (MD14512 [18] bit 6 = 1)

This solution is independent of the PLC and thus is much safer:



Encoding the hardware limit switches					Result
E_Key	_1LMTp	_2LMTp	_3LMTp	Direction	
0	1	1	1	-	EMERGENCY STOP active
0	0	1	1	DB3900.DBX4.7	1st + over limit
0	0	1	1	DB3900.DBX4.6	1st - over limit
0	0	0	1	DB3901.DBX4.7	2nd + over limit
0	0	0	1	DB3901.DBX4.6	2nd - over limit
0	0	0	0	DB3902.DBX4.7	3rd + over limit
0	0	0	0	DB3902.DBX4.6	3rd - over limit

In the hardware solution above, the feed stop signals for all axes can be activated via the hardware limit switches when any of the hardware limits is reached or an EMERGENCY STOP happens. You can check the information of the PLC diagnostics from the encoding of the hardware limit switches shown in the table above, and identify the cause (Emergency Stop button or a hardware limit switch of an axis) of the EMERGENCY STOP signal.

---

**Note**

When using the hardware solution, you must take below information into consideration:

- You must assign the axes one by one; for example, X axis, Z axis, spindle or X axis, Y axis, Z axis, spindle. You must not assign the axes like X axis, Y axis, spindle, Z axis.
  - You must set constant "1" (i.e. SM0.0) to the input signals of the hardware limits for undefined axes; otherwise, the hardware limits of the undefined axes can be activated.
- 

**Local variable definition****Inputs**

Name	Type	Description
nodef	WORD	Reserved
NC_Ready	BOOL	NC being in the cyclic state and able to enable the drive
_1LMTp	BOOL	Positive hardware limit switch of 1st axis (NC) <sup>1)</sup>
_1LMTn	BOOL	Negative hardware limit switch of 1st axis (NC)
_1REF	BOOL	Reference cam of 1st axis (NO)
_2LMTp	BOOL	Positive hardware limit switch of 2nd axis (NC) <sup>1)</sup>
_2LMTn	BOOL	Negative hardware limit switch of 2nd axis (NC)
_2REF	BOOL	Reference cam of 2nd axis (NO)
_3LMTp	BOOL	Positive hardware limit switch of 3rd axis (NC) <sup>1)</sup>
_3LMTn	BOOL	Negative hardware limit switch of 3rd axis (NC)
_3REF	BOOL	Reference cam of 3rd axis (NO)
_5REF	BOOL	Reference Cam of 5th axis (NO)

- <sup>1)</sup> The hardware limit + is used for the input if there is only one hardware limit switch or when the hardware solution is used.

**Outputs**

Name	Type	Description
OVImlt	BOOL	Any of the axis over hardware limits

**Assigned global variables**

SP_CMD	M138.1	Spindle start command (CW or CCW)
--------	--------	-----------------------------------

**Relevant PLC machine data**

No.	Value	Description
14512 [18].6	1	Overtravel employs the hardware solution
	0	Overtravel employs the PLC solution
14512 [18].7	1	Each axis has only one hardware limit switch
	0	Each axis direction has an hardware limit switch
14512 [20].1	0	Disable by pressing the spindle stop key
	1	Disable when detecting the standstill speed <sup>1)</sup>

- <sup>1)</sup> When setting bit 1 to 1, make sure that the speed control mode is active.


---

**Note**

By default, the value of MD30350 is 0, indicating that the NC will run in the real axis mode. When performing the axis control related operations on a stand-alone controller without any connection to the motor or drive, you need to set MD30350 to 1 for each axis, which indicates that the axis will run in the simulated state and thus the PLC will not detect the drive ready signal; otherwise, an alarm will be thrown out, indicating axis enable missing.

---

### Example for calling subroutine 40



### A.7.4.14 Subroutine 41 - MINI\_HHU (handwheel on hand-held unit)

#### Purpose

Subroutine 41 is used to support the customer's handheld units. With a handheld unit, you can assign the handwheels to X axis, Y axis and Z axis, and select incremental override X1, X10, X100 at the same time. You can then use the handwheels to control the movements of your machine.

#### Local variable definition

##### Inputs

Variable	Type	Description
nodef	BYTE	Reserved
X_Sel	BOOL	Select X axis
Y_Sel	BOOL	Select Y axis
Z_Sel	BOOL	Select Z axis
_4th_Sel	BOOL	Select 4th axis
INC1	BOOL	Select INC 1
INC10	BOOL	Select INC 10
INC100	BOOL	Select INC 100
HHU_EN	BOOL	HHU enable signal
HHU_EmgStop	BOOL	Emergency stop in HHU
Key_Tp	BOOL	+direction move key
Key_Tn	BOOL	-direction move key

##### Outputs

Variable	Type	Description
X1_LED	BOOL	Inc 1 is active
X10_LED	BOOL	Inc 10 is active
X100_LED	BOOL	Inc 100 is active
HHU_ACT_LED	BOOL	HHU is active


#### Assigned global variables

None

# Relevant PLC machine data

No.	Value	Description
14512 [17].3	1	Choose to use a hand-held unit
	0	Choose to use a handwheel

## Example for calling subroutine 41





### A.7.4.15 Subroutine 42 - SPINDLE (spindle control)

#### Purpose

Subroutine 42 is used for spindle control, including the spindle braking function. When the braking function is activated (MD14512 [19].1 = 1), the spindle brakes in the following cases:

- In the JOG mode, after you perform the following operations:



- In the AUTO or MDA mode, when the spindle changes the rotating direction or is stopped with M05/M02 during rotation

When the spindle brakes, the corresponding output becomes active; meanwhile, the spindle does not accept any rotary command until the braking completes.

#### Local variable definition

##### Inputs

Name	Type	Description
DELAY	WORD	Spindle brake delay time (unit: 0.1 s)
DrvEn	BOOL	Drive enable
SP_EN	BOOL	Condition for spindle operation (1: allowed; 0: not allowed)
IsBrake	BOOL	Brake for spindle (1: enabled; 0: forbidden)

##### Outputs

Name	Type	Description
SP_brake	BOOL	Spindle brake contactor
SP_LED	BOOL	Spindle operating status LED


#### Assigned global variables

SP_B_CMD	BOOL	Spindle braking command
T11	TIMER	Spindle braking timer

#### Relevant PLC machine data

No.	Type	Description
14510 [13]	BOOL	Spindle braking duration (unit: 0.1 s)
14512 [19].1	BOOL	Selection of spindle braking function (1: enabled; 0: forbidden)

#### Example for calling subroutine 42



#### A.7.4.16 Subroutine 43 - MEAS\_JOG (measurement in the JOG mode)

##### Purpose

Subroutine 43 is used to process the measuring probe signal and realize the "measuring in the JOG mode" function. You can use this subroutine to calibrate the probe and measure a tool.

The precondition for calling this subroutine is to call subroutine MCP\_NCK (SBR38) in the main program. The "measuring in the JOG mode" function is automatically deactivated if you have changed the operating mode when the function becomes active.

##### Local variable definition

##### Inputs

Name	Type	Description
T_ACT	DWORD	Transfer the active tool into interface


##### Assigned global variables

MEAS_OPAUT	M240.0	Measuring in the AUTO mode
CHL_HMI	M240.2	From HMI signals: mode changes during measurement
NO_KEY	M240.3	No JOG key available for the axes
FDI_MEASJOG	M240.5	Meas_JOG forbidden for feed
ON_MEASJOG	M240.6	Meas_JOG activated
PROBE_ON	M240.7	Probe signal released
JOG_MEASJOG	M241.0	Operating mode manually output to Meas_JOG
AUT_MEASJOG	M241.1	Operating mode manually output to Meas_JOG
CHL_MEASJOG	M241.2	Operating mode change forbidden to Meas_JOG
KEY_MEASJOG	M241.3	JOG key Meas_JOG
RES_MEASJOG	M241.4	Reset Meas_JOG
ESC_MEASJOG	M241.5	Interrupt Meas_JOG
DRY_MEASJOG	M241.6	Dry run Meas_JOG
SBL_MEASJOG	M241.7	Single block Meas_JOG

##### Relevant PLC machine data

None

##### Example for calling subroutine 43



### A.7.4.17 Subroutine 44 - COOLING (cooling control)

#### Purpose

Subroutine 44 is used to start/stop cooling using the buttons on the MCP in the JOG mode, or to start (using the auxiliary function M07/M08 in the part program) or to stop (using the M09 in the part program) cooling in the AUTO/MDA mode. Cooling is forbidden in case of EMERGENCY STOP, cooling motor overload, program test or under the simulation mode.

This subroutine can activate the following alarms:

- Alarm 700018: motor overload for the cooling pump
- Alarm 700019: low coolant level

#### Local variable definition

##### Inputs

Name	Type	Description
nodef	BYTE	Reserved
C_key	BOOL	Switch key (holding signal)
OVload	BOOL	Cooling motor overload (NC)
C_low	BOOL	Coolant level low (NC)

##### Outputs

Name	Type	Description
C_out	BOOL	Cooling control output
C_LED	BOOL	Cooling output status display


#### Assigned global variables

COOLon	MB150.0	Coolant on/off status
--------	---------	-----------------------

#### Relevant PLC machine data

None

#### Example for calling subroutine 44



#### A.7.4.18 Subroutine 45 - LUBRICAT (control of lubricate)

##### Purpose

Subroutine 45 is used to control the lubrication according to specific time interval and duration (independent of the distance that the axis has travelled). Meanwhile, a manual button is available to start the lubrication, and you can configure that the lubrication starts automatically each time that the machine is powered up. Normally, lubricating starts automatically and cyclically according to specified time interval **Lintv**, and operates for a specific time **Ltime** at each cycle. Lubrication stops in case of an Emergency Stop, lubrication motor overload, low lubricant level.

This subroutine can activate following alarms:

- Alarm 700020: lubrication motor overload
- Alarm 700021: low lubricant level

##### Local variable definition

##### Inputs

Name	Type	Description
Lintv	WORD	Lubricating time interval
Ltime	WORD	Lubricating output time
L_key	BOOL	Manual lubricating key
L1st	BOOL	Lubricating by 1 PLC cycle (Power on)
Ovload	BOOL	Lubricating motor overload (NC)
L_low	BOOL	Lubricant level low (NC)

##### Outputs

Name	Type	Description
L_out	BOOL	Lubricating output
L_LED	BOOL	For lubricating status display


##### Assigned global variables

L_interval	C24	Timer for the lubricating time intervals (unit: min)
L_time	T27	Timer for very lubricating time duration (unit: 0.01s, max. 327.67 s)

##### Relevant PLC machine data

No.	Unit	Range	Description
14510 [24]	Min.	-	Lubricating time interval
14510 [25]	0.01 s	100 to 2,000	Lubricating time duration

##### Example for calling subroutine 45



## A.7.4.19 Subroutine 46 - PI\_SERVICE

### Purpose

Subroutine 46 is for realizing functions like ASUP (Asynchronous Subroutine Program) and deleting a password.

- **ASUP function**

The ASUP function means the execution of PLCASUP1.SPF or PLCASUP2.SPF called by the PLC. The control system provides two ASUPs for the PLC. The two ASUPs cannot be simultaneously executed, and the PLCASUP1.SPF has a higher priority over the PLCASUP2.SPF.

In a program, firstly you can initialize the ASUP1 and ASUP2 by setting "PI index" (DB1200.DBB4001) and "NCK read/write start" (DB1200.DBX4000.0), and then use a rising edge to trigger "ASUP1 start" (DB3400.DBX0.0) and "ASUP2 start" (DB3400.DBX1.0).

---

### Note

#### Important!

The control system provides two user ASUPs. In the sample application, ASUP1 is used for manual tool change and ASUP2 is used for the MANUAL MACHINE of the workpiece on a turning machine with the Manual Machine Plus function.


---

- **Deleting a password**

To use this function, you need to only execute the PI service. Here, no initialization of the PI service is required.

By default, MD14512 [19].2 = 0, which indicates that the control system will automatically delete the password after NC restart. If you want the control system to remember the last used password every time the NC restarts, you need to set MD14512 [19].2 = 1.

### Timing diagram



### Local variable definition

#### Inputs

Name	Type	Description
nodef	BYTE	Reserved
ASUP1_trigger	BOOL	Start ASUP1 (rise edge)
ASUP2_trigger	BOOL	Start ASUP2 (rise edge)

#### Outputs

Name	Type	Description
ASUP1Run	BOOL	Indicates whether ASUP1 is running
ASUP2Run	BOOL	Indicates whether ASUP2 is running

Name	Type	Description
Err1	BOOL	ASUP1 error
Err2	BOOL	ASUP2 error

#### Occupied global variables


IniASUP1	M229.0	Mark of ASUP1 initialization
IniASUP2	M229.1	Mark of ASUP2 initialization
DelPswStart	M228.0	Start to delete password
DelPswSel	M228.1	Delete password select

#### Relevant machine data

No.	Name
10702	IGNORE_SINGLEBLOCK_MASK
11602	ASUP_START_MASK
11604	ASUP_START_PRIO_LEVEL
20116	IGNORE_INHIBIT_ASUP

No.	Value	Description
14512 [19].2	1	The control system will not delete the password after NC restart
	0	The control system will delete the password after NC restart

#### Example for calling subroutine 46



### A.7.4.20 Subroutine 47 - PLC\_Select\_PP (PLC selects a subroutine)

#### Purpose

Subroutine 47 is used to select a part program.

You firstly need to create a PLC program-calling table, and assign a program index to each part program in this table. In subroutine 47 you can assign DB1700.DBB1000 to the "Program index" to select the corresponding part program.

#### Local variable definition

##### Inputs

Name	Type	Description
PP_num	BOOL	Part program number, 1-100: user; 101-200: OEM; 201-255: Siemens

##### Outputs

Name	Type	Description
Finish	BOOL	PLC selects a part program successfully
Error	BOOL	PLC selects a part program incorrectly


#### Assigned global variables

SelPP_FinOm	BOOL	M239.6	Indicates that a part program has been selected
SelPP_ErrOm	BOOL	M239.7	Indicates that an error occurs when selecting a part program

#### Relevant PLC machine data

None

#### Example for calling subroutine 47



### A.7.4.21 Subroutine 48 - ServPlan (service planner)

#### Purpose

To use subroutine 48, you must have created a service plan on the control system. When the pre-alarm time arrives, the machine outputs a notification message. When the final alarm time arrives, the machine outputs an alarm message.

#### Note

To perform a service plan on the PLC, you need to download DB9903(SP\_INI) and DB9904(SP\_ACT).

#### Local variable definition

##### Inputs

Name	Type	Description
nodef	BYTE	Reserved
Deact0	BOOL	Deactive 1st service plan
AckMsg0	BOOL	Acknowledge message of 1st service plan

##### Outputs

Name	Type	Description
HintMsg0	BOOL	Hint message for 1st service plan
Alarm0	BOOL	Alarm message for 1st service plan


#### Assigned global variables

ServPlan_msg0	BOOL	Notification message of the first service plan
ServPlan_alm0	BOOL	Alarm message for 1st service plan

#### Relevant PLC machine data

None

### Example for calling subroutine 48



### A.7.4.22 Subroutine 49 - GearChg1\_Auto (automatic spindle gear change)

#### Purpose

Subroutine 49 is used to automatically change the gear for the analog spindle with 2-level gear detection signals.

During a gear change, the spindle oscillates and the PLC outputs the gear change signal. When the PLC detects that the desired gear level has been reached, the gear change has been completed.

You cannot use this subroutine together with subroutine 50.

#### Local variable definition

##### Inputs

Name	Type	Description
D_CHG	WORD	Delay time for gear changing
D_MON	WORD	Monitor time for gear-change in position
D_S0	WORD	Delay time for the spindle to come to standstill
T_GC	WORD	Monitor time for the whole gear change process, must > D_CHG + D_MON + D_S0
S_hold	BOOL	Spindle stopped (NO)
S_alarm	BOOL	Spindle alarm (NO)
LGi	BOOL	Low gear level in position (NO)
HGi	BOOL	High gear level in position (NO)

##### Outputs

Name	Type	Description
LGo	BOOL	Low gear level output
HGo	BOOL	High gear level output
LG_LED	BOOL	Low gear level inposition indicator
HG_LED	BOOL	High gear level inposition indicator

#### Assigned global variables

HGom	BOOL	M248.0	Signal indication of high gear stage output
LGom	BOOL	M248.1	Signal indication of low gear stage output
HGcmd	BOOL	M248.2	High gear level command
LGcmd	BOOL	M248.3	Low gear level command
SPhold	BOOL	M248.4	Spindle stops and ready for oscillation
Dstill	BOOL	M248.5	Signal for spindle stop
Dchg	BOOL	M248.6	Spindle gear change delay
Dmon	BOOL	M248.7	Monitoring for the gear change
Req_SP_G_CH G	BOOL	M244.0	Request for spindle gear change




Req_Low_G	BOOL	M244.1	Request to change to the low gear stage
Req_High_G	BOOL	M244.2	Request to change to the high gear stage
D_S0	TIMER	T13	Spindle stop delay
Td_GearChg	TIMER	T24	Gear change delay
Tm_GearChg	TIMER	T25	Delay for monitoring the gear change

#### Relevant PLC machine data

None

#### Example for calling subroutine 49



### A.7.4.23 Subroutine 50 - GearChg2\_Virtual (virtual spindle gear change)

#### Purpose

Using subroutine 50, you can requests the system to switch to the corresponding gear after changing the gear manually. The corresponding gear is set when M41-M45 are executed.

This subroutine must not be used together with GearChg1\_Auto (SBR 49).

#### Local variable definition

#### Outputs

Name	Type	Description
HL_gear	BOOL	:=0, low gear level; :=1, high gear level


#### Assigned global variables

None

#### Relevant PLC machine data

None

#### Example for calling subroutine 50



#### A.7.4.24 Subroutine 51 - Turret1\_HED\_T (turret with Hall effect device position sensor)

##### Purpose

Subroutine 51 is used to control the turret with a Hall effect device positioning sensor, and the turret motor is controlled by the PLC.


The turret rotates clockwise to search for a tool, and rotates counter-clockwise after positioning the desired tool to clamp it (the turret CCW rotation time can be adjusted). An alarm occurs if the turret fails to position the desired tool after the duration expires. The subroutine verifies the time that the turret rotates CCW, and sets a limit of maximum 3 seconds for this rotation time to prevent the turret motor from being broken.

In the AUTO and MDA modes, the T function starts a tool change operation. In the JOG mode, a short press on the MCP key changes a turret position.

During a tool change, the NC interface signals "Read-in disable" (DB3200.DBX6.1) and "Feedhold" (DB3200.DBX6.0) are set; this means that the part program can only continue to run after the tool change.

The turret positioning is prohibited in the case of an Emergency Stop, turret motor overload or program test/simulation.


The timing diagram for positioning a tool in the turret using the Hall effect device positioning sensor is shown as follows:



This subroutine can activate the following alarms:

- Alarm 700022: Turret motor overload
- Alarm 700023: Programmed tool number higher than the max. tool number of the turret
- Alarm 700024: Wrong setting of the max. tool number for the turret
- Alarm 700025: No turret positioning signals available
- Alarm 700026: Tool positioning time out

##### Timing diagram



## Local variable definition

### Inputs

Name	Type	Description
Tmax	WORD	Number of tool on the turret, only 4, 6 are permitted
C_time	WORD	Turret clamping delay time (unit: 0.1 s)
M_time	WORD	Monitor time for searching for a tool (unit: 0.1s)
T_polar	BOOL	Tool position signal: NC/NO
T_key	BOOL	Manual tool change key
T_01 to T_06	BOOL	Tool position sensor (low active)
OVload	BOOL	Turret motor overload (NC)

### Outputs

Name	Type	Description
T_cw	BOOL	Turret CW for tool change
T_ccw	BOOL	Turret CCW for turret clamping
T_LED	BOOL	Turret change status display
ERR1	BOOL	Error1: no turret position signal available
ERR2	BOOL	Error2: programmed tool exceeds turret range
ERR3	BOOL	Error3: tool searching time monitor time out
ERR4	BOOL	Error4: turret overload
ERR5	BOOL	Error5: max tool number setting error
ERR6	BOOL	Reserved


### Assigned global variables

T_cw_m	M156.0	Position marking for turret CW rotation
T_ccw_m	M156.1	Position marking for turret CCW rotation
CcwDelay	M156.2	Turret CCW rotation delay
K_active	M156.3	Manual key active
Tpos_C	M156.4	Turret position changed
Tp_eq_Tc	M156.5	Programmed tool number equal to the current tool number
Tp_eq_0	M156.6	Programmed tool number equal to zero
T_P_INDX	MD160	Monitoring the tool change buffer zone in the JOG mode
T_CHL	M168.4	Operating mode locked
Tm1_FindT	T15	Monitoring timer for tool searching
T_CLAMP	T13	Clamping timer for turret 1

### Relevant PLC machine data

No.	Unit	Description
14510 [20]	-	Max. tool number (4 or 6)
14510 [21]	0.1 s	Turret clamping time
14510 [22]	0.1 s	Monitoring time for tool searching
14512[17].0	-	Activating the turret function of a turning machine

#### Example for calling subroutine 51



#### A.7.4.25 Subroutine 52 - TURRET2\_BIN\_T (turret with binary coding function)

##### Purpose

Subroutine 52 is used to control the turret with encoder positioning signals and function of dual-direction adjacent tool change. Contact the turret vendor for the working theory and the timing diagram of a tool change.

During a tool change, the NC interface signals "Read-in disable" (**DB3200.DBX6.1**) and "Feedhold" (**DB3200.DBX6.0**) are set, so the part program can continue running only after the tool change action.

The turret position action is forbidden in case of an emergency stop, turret motor overload or program test/simulation.

This subroutine can activate the following alarms:

- Alarm 700022: Turret motor overload
- Alarm 700023: Programmed tool number higher than the max. tool number of the turret
- Alarm 700024: Wrong setting of the max. tool number for the turret
- Alarm 700026: Not able to find expected tool in monitor time
- Alarm 700011: Not able to lock tool in expected time

##### Local variable definition

##### Inputs

Name	Type	Description
Tmax	WORD	Total tools on the turret
Tm_Lck	WORD	Tool lock monitor time (unit: 0.01s)
Tm_Chg	WORD	Tool change monitor time (unit: 0.1s)
T_1	BOOL	T code A
T_2	BOOL	T code B
T_3	BOOL	T code C
T_4	BOOL	T code D
Parity	BOOL	Parity bit
Strobe	BOOL	Tool on position signal
OVload	BOOL	Turret motor overload (NC)
P_Indx	BOOL	Turret pre-indexing sensor
T_key	BOOL	Manual key for tool change

## Outputs

Name	Type	Description
T_cw	BOOL	Turret CW rotation output
T_ccw	BOOL	Turret CCW rotation output
Magent	BOOL	Solenoid for clamping
T_LED	BOOL	Display for tool changing
ERR1	BOOL	Error1: turret motor overload
ERR2	BOOL	Error2: programmed tool no. > max tool no.
ERR3	BOOL	Error3: max tool no. setting error
ERR4	BOOL	Error4: not able to find pre-indexing signal in expected time
ERR5	BOOL	Error5: not able to lock in expected time


## Assigned global variables

T_CURRENT	VD14000064	Current tool (retentive data)
T_cw_m	M156.0	Position marking for turret CW rotation
T_ccw_m	M156.1	Position marking for turret CCW rotation
T_P_INDX	MD160	Monitoring the tool change buffer zone in the JOG mode
T_DES	M164	Desired tool number
T_DIR	M168.0	Direction of adjacent tool change
T_POS	M168.1	Turret tool positioning finished
T_LOCK	M168.2	Turret clamping command
T_MAG	M168.3	Turret magnetic clamping

## Relevant PLC machine data

No.	Unit	Description
14510 [20]	-	Max. tool number (4 or 6)
14510 [21]	0.1 s	Turret clamping time
14510 [22]	0.1 s	Monitoring time for tool searching
14512[17].0	-	Activating the turret function of a turning machine

## Example for calling subroutine 52



#### A.7.4.26 Subroutine 53 - Turret3\_CODE\_T (tool change control for turret with coding function)

##### Purpose

Subroutine 53 is used to control the turret with coded tool positions and function of adjacent tool change. The difference between the subroutine 52 and the subroutine 53 is that the subroutine 52 uses binary tool position codes while the subroutine 53 uses tool position codes made according to a specific common turret.

During a tool change, the NC interface signal "Feedhold" (DB3200.DBX6.0) is set; this means that the part program can only continue to run only after the tool change.

The turret positioning is prohibited in the case of an Emergency Stop, turret motor overload or program test/simulation.

##### Local variable definition

##### Inputs

Name	Type	Description
M_time	WORD	Monitor time for searching for a tool
T_key	BOOL	Tool change key
A	BOOL	Tool position code 1
B	BOOL	Tool position code 2
C	BOOL	Tool position code 3
D	BOOL	Tool position code 4
Strobe	BOOL	Tool on position signal
Lock_i	BOOL	Lock tool signal
OVload	BOOL	Turret overload

Tool position	Tool position code A	Tool position code B	Tool position code C	Tool position code D
1	0	1	0	0
2	0	0	0	1
3	1	0	0	0
4	0	0	1	0
5	1	1	1	0
6	1	0	1	1
7	1	1	0	1
8	0	1	1	1

##### Outputs

Name	Type	Description
T_UNCLAMP	BOOL	Turret release
T_CLAMP	BOOL	Turret clamping
T_CW	BOOL	Turret CW rotation
T_CCW	BOOL	Turret CCW rotation
T_LED	BOOL	Status display during the tool change


##### Assigned global variables

Tpos_C	BOOL	M156.4	Tool searching finished
T_cwm	BOOL	M235.6	Mark for turret CW rotation
T_ccwm	BOOL	M235.7	Mark for turret CCW rotation
TK_act	BOOL	M236.4	Mark for manual tool change
Tc_ne_0	BOOL	M237.0	Current tool number is not 0
T_dir	BOOL	M237.1	Direction for searching for an adjacent tool

#### Relevant PLC machine data

No.	Unit	Description
14510 [22]	0.1 s	Monitoring time for searching for a tool

#### Example for calling subroutine 53




#### A.7.4.27 Subroutine 54 - Turret2\_3\_ToolDir (tool change direction)

##### Purpose

Subroutine 54 is used to find out the direction of searching for an adjacent tool and the pre-indexing position (this is, the previous position of the desired tool in the direction of an adjacent tool). To find out the direction, you need to know the max. tool number of the turret and the programmed tool number.

You can use this subroutine to control the turret to search for an adjacent tool on a turning machine or a machine centre. The turret tool position ranges from 2 to 64.

For example:



Tool position number	Current position	Programmed tool number	Pre-indexing position	Direction
1	7	2	1	CCW
2	7	5	6	CW
3	3	8	1	CW
4	1	4	3	CCW
5	6	8	7	CCW

#### Local variable definition

##### Inputs

Name	Type	Description
Tmax	DWORD	Possible positions of the turret
Pnum	DWORD	Programmed tool number
Tcurr	DWORD	Current tool number

##### Outputs

Name	Type	Description
P_INDEXo	DWORD	Pre-indexing position: the previous tool position of the desired tool in the direction of an adjacent tool
DIR	BOOL	Direction for tool change 1: for turret CW; 0: for turret CCW

#### Assigned global variables


None

#### Relevant PLC machine data

None

#### Example for calling subroutine 54

This subroutine is called by subroutine 52 and subroutine 53.



### A.7.4.28 Subroutine 55 - Tail\_stock\_T (Tailstock control program for turning machines)

#### Purpose

Subroutine 55 is used to control forward or backward movement of the tailstock on a turning machine.

In the JOG mode, press the "Tailstock" key to move the tailstock forward or backward. Pressing "Tailstock" moves the tailstock forward, and one more pressing moves the tailstock backward.

In the AUTO mode, you can use M20 or M21 to control the forward or backward movement of the tailstock.

#### Local variable definition

##### Inputs

Name	Type	Description
nodef	BYTE	Reserved
TailCtrl_K	BOOL	Tailstock control key: press 1st time, advance; 2nd time, retract
SP_status	BOOL	Spindle status



## Outputs

Name	Type	Description
TailAdv_O	BOOL	Tailstock advance output
TailRet_O	BOOL	Tailstock retract output
AdvRet_LED	BOOL	Tail advance/retract flag


## Assigned global variables

SP_RUNm	BOOL	M236.0	Indicate that the spindle is running
TailAdv_m	BOOL	M229.2	Indicates that the tailstock is moving forward
TailRet_m	BOOL	M229.3	Indicates tailstock is moving backward

## Relevant PLC machine data

No.	Value	Description
14512 [17].2	1	Enable tailstock in turning
	0	Disable tailstock in turning

## Example for calling subroutine 55



## A.7.4.29 Subroutine 56 - Lock\_unlock\_T (clamping control for turning machine)

### Purpose

Subroutine 56 is used to control the clamping or release for the chuck for a turning machine.

In the JOG mode, press the "**External/Inside clamping**" key to select either external clamping or inside clamping, and press "Clamp" or "Unclamp" key to clamp or release the chuck. Furthermore, you can also use the "Foot switch" to clamp or release the chuck. Pressing the "Foot switch" for once release the chuck, and one more pressing clamps the chuck.

In the AUTO mode, you can execute M10/M11 to control the clamping or release of the chuck.

### Note

The chuck status should be kept when clamping outputs are zero.

## Local variable definition

### Inputs

Name	Type	Description
Delay	WORD	Delay if no in position sensor
LckRel_k	BOOL	Lock/release toggle signal
ExtIn_k	BOOL	External/internal lock key
S_velo	BOOL	Spindle velocity 0: 0 speed; 1: spindle running
Foot_switch	BOOL	Foot switch for clamp/unclamp chuck

## Outputs

Name	Type	Description
Lck1_O	BOOL	Clamping output 1
Lck2_O	BOOL	Clamping output 2
Lck_LED	BOOL	Clamping output indicate
ExtIn_LED	BOOL	External/internal lock LED
Err1	BOOL	Error 1: clamp/unclamp not possible while spindle is operating


## Assigned global variables

ChuckLcked	BOOL	M229.4	Chuck clamped
ChuckLckLED	BOOL	M239.2	Chuck at released state
ExtInLED_Om	BOOL	M239.5	External/inside clamping state
TR_Status	BOOL	M237.6	Chuck release command

## Relevant PLC machine data

No.	Value	Description
14512 [17].1	1	Enable chuck in turning
	0	Disable chuck in turning

## Example for calling subroutine 56



## A.7.4.30 Subroutine 58 (MM\_MAIN)

### Purpose

To use subroutine 58, you must have licensed the optional Manual Machine Plus function for the SINUMERIK 808D ADVANCED T (Turning). The subroutines 46, 58 and 59 must be used together. This subroutine is used to control the manual machine function after the manual machine interface is activated.

### Local variable definition

#### Inputs

Name	Type	Description
TK_X_P	BOOL	Traverse key X plus
TK_X_M	BOOL	Traverse key X minus
TK_Z_P	BOOL	Traverse key Z plus
TK_Z_M	BOOL	Traverse key Z minus
RAPID	BOOL	Rapid traverse key
SP_CW	BOOL	Start signal spindle CW
SP_CCW	BOOL	Start signal spindle CWW

Name	Type	Description
SP_STOP	BOOL	Stop signal spindle
NC_START	BOOL	NC start signal
NC_STOP	BOOL	NC stop signal
AUTO_ENABLE	BOOL	Switching to AUTO is enabled in Manual Machine Mode
MDA_ENABLE	BOOL	Switching to MDA is enabled in Manual Machine Mode
ROV	BOOL	ROV in Manual Machine Mode

#### Outputs

Name	Type	Description
AL_03	BOOL	Not approaching the reference point on axis X (user alarm 03)
AL_04	BOOL	Not approaching the reference point on axis Z (user alarm 04)
AL_09	BOOL	Incorrect start in the spindle direction (user alarm 09)
AL_11	BOOL	JOG program timeout (user alarm 11)
AL_12	BOOL	Spindle rate not 100% (user alarm 12)
AL_13	BOOL	Spindle not being started (user alarm 13)
AL_14	BOOL	Feed rate 0% (user alarm 14)
AL_16	BOOL	Spindle direction change in a thread not allowed (user alarm 16)


#### Assigned global variables

Byte	Signal	Byte 7	Byte 6	Byte 5	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0
MB170	HMI<->MM						Request for MM HMI startup	MM HMI enabled	MM HMI started
MB171	HMI<->MM								
MB172	HMI<->MM								
MB173	HMI<->MM								
MB174	HMI<->MM	Cone angle 270°-360°	Cone angle 270°	Cone angle 180°-270°	Cone angle 180°	Cone angle 90°-180°	Cone angle 90°	Cone angle 0°-90°	Cone angle 0°
MB175	HMI<->MM						Direction key enabled		Spindle rotated
MB176	HMI<->MM		Working step enabled	Groove enabled	Thread chaining enabled	Drilling enabled	Arc enabled	Cutting enabled	Thread enabled
MB177	HMI<->MM								
MB178									
MB179									
MB180							Recutting canceled	Recutting performed	Recut the thread or not?

#### Relevant PLC machine data

No.	Unit	Range	Description
MD14512[19].7	-	-	1: to enable the manual machine function 0: to disable the manual machine function

Example for calling subroutine 58



### A.7.4.31 Subroutine 59 (MM\_MCP\_808D)

#### Purpose

To use subroutine 59, you must have licensed the optional Manual Machine Plus function for the SINUMERIK 808D ADVANCED T (Turning). The subroutines 46, 58 and 59 must be used together. Normally, the spindle will be stopped after you press the NC reset key. However, when a manual machine is started, you do not want to stop the spindle after pressing the NC reset key. In this case, call subroutine 59 (MM\_MCP\_808D) after executing subroutine 37 (MCP\_NCK). Then you do not need to rewrite subroutine 37 (MCP\_NCK).

#### Local variable definition

#### Inputs

Name	Type	Description
SP_STOP_K	BOOL	Spindle stop


#### Assigned global variables

None

#### Relevant PLC machine data

No.	Unit	Range	Description
MD14512[19].7	-	-	1: to enable the manual machine function 0: to disable the manual machine function

#### Example for calling subroutine 59



### A.7.4.32 Subroutine 60 - Disk\_MGZ\_M (disk-style tool magazine used for milling)

#### Purpose

You can use subroutine 60 to control the disk-style tool magazine on a milling machine.

In the reference point mode, initialize the tool magazine by pressing the "Original position of the tool magazine" key.

In the manual mode, you can rotate the tool magazine clockwise or counter-clockwise, and enable the tool magazine to reach the spindle or tool change position respectively through the "Clockwise rotation of the magazine", "Counter-clockwise rotation of the magazine", "Tool magazine reaching the spindle", and "Tool magazine reaching the tool change position" keys.

In the auto mode, you need to execute M06 to call the tool change subroutine when compiling a part program. Subroutine 60 and the tool change subroutine must be used together during the tool change process. Three operations are involved in the tool change control, that is, tool return, tool retrieval, and tool change.

1. The tool return operation is to return the tool on the spindle back to the tool magazine disk when compiling T0 and a tool is located on the spindle.
2. The tool retrieval operation is to get the desired tool from the tool magazine disk and install it on the spindle when compiling Tx (x ≠ 0) and no tool is on the spindle.
3. The tool change operation is to first return the tool on the spindle back to the tool magazine disk and then get the desired tool from the tool magazine disk when compiling Tx (x ≠ 0; x ≠ number of the tool on the spindle).

For details, please refer to the tool change subroutine.

When setting 14512[19].3 to 1, the maintenance mode is enabled, in which you can perform the following operations:

- When the tool magazine is in the spindle position, axis Z only moves upward to the tool change position.
- When axis Z is under the tool change position, the tool magazine cannot move to the spindle position.
- When the tool magazine is rotating, the tool magazine needs to go home if the emergency stop button is pressed.

The following machine data is involved in this subroutine:

MD10715: M\_NO\_FCT\_CYCLE[0]

MD10716: M\_NO\_FCT\_CYCLE\_NAME[0]

MD22550: TOOL\_CHANGE\_MODE

MD22560: TOOL\_CHANGE\_M\_CODE

#### Local variable definition

##### Inputs

Name	Type	Description
nodef	BYTE	Reserved
MgzCnt	BOOL	Magazine counter
MgzRef_k	BOOL	Set curret tool no. to 1 in magazine via this key
MgzCW_k	BOOL	Magazine CW rotate key
MgzCCW_k	BOOL	Magazine CCW rotate key
MgzSp_k	BOOL	Magazine enter spindle position key
MgzOrg_k	BOOL	Magazine original position key
MgzSp_pos	BOOL	Magazine reaches SP position
MgzOrg_pos	BOOL	Magazine reaches original position
T_rel_pos	BOOL	Spindle releases tool position
T_lck_pos	BOOL	Spindle locks tool position
T_rel_k	BOOL	Spindle release-tool key
T_rel_EnK	BOOL	Release-tool enable key

##### Outputs

Name	Type	Description
MgzCW_o	BOOL	Magazine CW rotate output
MgzCCW_o	BOOL	Magazine CCW rotate output
MgzSp_o	BOOL	Magazine approaching spindle position output
MgzOrg_o	BOOL	Magazine original position output
SpRelT_o	BOOL	Spindle releases a tool
RelT_En_o	BOOL	Release tool enable lamp
MgzSp_LED	BOOL	Magazine reaches spindle position
MgzOrg_LED	BOOL	Magazine reaches original position
MgzRef_LED	BOOL	Set curret tool no. to 1 in mag. output

##### Assigned global variables


MgzCW_cmd	BOOL	M230.0	Command for clockwise rotation of the tool magazine
MgzCCW_cmd	BOOL	M230.1	Command for counter-clockwise rotation of the tool magazine
Mgz_rot_CMD	BOOL	DB4900.DBB24	Tool change command from the tool change subroutine

### Relevant PLC machine data

No.	Unit	Range	Description
MD14512[19].3	-	-	1: to enable the maintenance mode 0: to enable the normal mode
MD14514[2] <sup>1)</sup>	-	-3.40e38 to 3.40e38	Tool magazine: tool change position of axis Z

1) For the first-time commissioning, set MD14514[2] to an appropriate value so that axis Z can move freely during the commissioning. When the commissioning is finished, set MD14514 [2] to the normal value.

### Example for calling subroutine 60



#### A.7.4.33 Subroutines 34 to 36, 57, and 61

### Explanation

Subroutines 34 to 36, 57, and 61 are reserved for users.

#### A.7.4.34 Subroutine 62 - Trg\_key\_OR

## Purpose

Subroutine 62 is used for the spindle override control via three trigger user keys in the vertical MCP with the handwheel.

### Local variable definition

## Inputs

Name	Type	Description
noder	WORD	Reserved
IncS_Key	BOOL	Increase key of spindle override
DecS_Key	BOOL	Decrease key of spindle override
S_100_Key	BOOL	Spindle override 100% key
Noder1	BYTE	Reserved
Noder2	BYTE	Reserved

## Outputs

Name	Type	Description
LED1_S	BOOL	Lights, spindle override < 100%; flashing, 50%
LED2_S	BOOL	Lights, spindle override 100%
LED3_S	BOOL	Lights, spindle override 105-115%; flashing, 120%


## Assigned global variables

SP_OV_Switch	BYTE	MB202	Spindle override switch buffer
USB_MCP_SP_OV	BYTE	MB209	USB MCP single: spindle override

## Relevant PLC machine data

No.	Unit	Range	Description
14510 [15]	0.1s	0.5 s to 3 s	Spindle override 50% key holding on time defined
14510 [16]	0.1s	0.1 s to 3 s	Spindle override 100% key holding on time defined
14512 [20]	-	-	<p>Bit 0: Grey coded switch (0: spindle override controlled by the grey mode; 1: spindle override controlled by trigger user keys)</p> <p>Bit 5: define the spindle override startup value (0: the startup spindle override is always 100%; 1: recode the spindle override value of the last machine turn off for the next startup)</p> <p>Bit 6/7: define the spindle override shift speed</p> <ul style="list-style-type: none"> <li>bit 6 = 0, bit 7 = 0 Standard speed. The steps are 50%, 55%, 60%, 65%, 70%, 75%, 80%, 85%, 90%, 95%, 100%, 105%, 110%, 115%, 120%</li> <li>bit 6 = 1, bit 7 = 0 Two times the standard speed. The steps are 50%, 60%, 70%, 80%, 90%, 100%, 110%, 120%</li> <li>bit 6 = 0, bit 7 = 1 About three times the standard speed. The steps are 50%, 60%, 70%, 85%, 100%, 110%, 120%</li> <li>bit 6 = 1, bit 7 = 1 About four times the standard speed. The steps are 50%, 60%, 80%, 100%, 120%</li> </ul>

## Example for calling subroutine 62





### A.7.4.35 Subroutine 63 - TOGGLES

#### Purpose

Two types of switches are provided in subroutine 63, more specifically, a hold switch for switching a circuit on (press) and off (press again), and a delay switch for switching on a circuit and automatically switching it off after a certain time period. A total of six hold switches and two delay switches are available in this subroutine, with the delay duration being configurable. The key inputs or outputs of the subroutine can be connected with any physical inputs or outputs. The inputs and outputs of all idle switches are respectively "ZERO" and "NULL\_b" (M255.7).

#### Local variable definition

##### Inputs

Name	Type	Description
Delay7	WORD	For switch 7; unit: 10 ms; max delay = 5 min
Delay8	WORD	For switch 8; unit: 10 ms; max delay = 5 min
Ki_1...Ki_6	BOOL	Input of hold switch 1...input of hold switch 6
Ki_7...Ki_8	BOOL	Inputs of delay switches 7 and 8

##### Outputs

Name	Type	Description
Ko_1...Ko_8	BOOL	Output of switch 1...output of switch 8


#### Assigned global variables

K1st1 ... K8st1	MB245	State 1 of the hold switch
K1st2 ... K8st2	MB246	State 2 of the hold switch
K1on ... K8on	MB247	"On" state of the hold switch

#### Relevant PLC machine data


None

#### Example for calling subroutine 63



## A.7.5 PLC alarms

Diagnosing the machine is important. Complete diagnosis of the external electrics can help users understand the cause and location of breakdown immediately.



### User alarms in the PLC subroutines

System provides users with 128 PLC user alarms. Every user alarm has a corresponding NCK address bit: DB1600.DBX0.0 to DB1600.DBX15.7. The address bit "1" can activate the corresponding alarm, and reset "0" can cancel the alarm.

In the PLC cross reference, you can find the reason for the PLC alarm through looking up reference addresses to make the corresponding modification.

Some user alarms are activated in a subroutine. In the case that such an alarm is generated, you can search the following list for the subroutine wherein the alarm is activated.

Alarm No.	Interface Address	Alarm Description	From SBR
700010	DB1600.DBX1.2	Handheld unit active	SBR41: MINI_HHU
700011	DB1600.DBX1.3	Tool clamping timeout	
700012	DB1600.DBX1.4	Spindle being braked	SBR42: SPINDLE
700013	DB1600.DBX1.5	Operation not allowed: chuck unclamped	SBR56: Lock_unlock_T
700014	DB1600.DBX1.6	Gear stage change timeout	SBR49: GearChg1_Auto
700015	DB1600.DBX1.7	Gear position signal error	
700016	DB1600.DBX2.0	Drives not ready	SBR33: EMG_STOP
700017	DB1600.DBX2.1	Chuck operation not allowed: spindle/prog. running	SBR56: Lock_unlock_T
700018	DB1600.DBX2.2	Cooling motor overload	SBR44: COOLING
700019	DB1600.DBX2.3	Coolant level too low	

Alarm No.	Interface Address	Alarm Description	From SBR
700020	DB1600.DBX2.4	Lubricating motor overload	SBR45: LUBRICAT
700021	DB1600.DBX2.5	Lubricant level too low	
700022	DB1600.DBX2.6	Turret motor overload	SBR51: Turret1_HED_T
700023	DB1600.DBX2.7	Prog. tool pos. number > max. tool pos. number	SBR52: Turret2_BIN_T
700024	DB1600.DBX3.0	Max. tool position number illegal	SBR53: Turret3_CODE_T
700025	DB1600.DBX3.1	No tool position signal from turret	
700026	DB1600.DBX3.2	Tool change timeout	
700028	DB1600.DBX3.4	Tool unclamped	
700029	DB1600.DBX3.5	Warning: the 1st maintenance task will expire	SBR48: ServPlan
700030	DB1600.DBX3.6	Alarm: the 1st maintenance task has expired	
700031	DB1600.DBX3.7	Magazine not in spindle pos. or original pos.	SBR60: Disk_MGZ_M
700032	DB1600.DBX4.0	Magazine in spindle pos. and original pos.	SBR60: Disk_MGZ_M
700033	DB1600.DBX4.1	Magazine rot. failed: magazine/spindle not ready	SBR60: Disk_MGZ_M
700034	DB1600.DBX4.2	Blk search finds tool on spindle <> tool programmed	SBR60: Disk_MGZ_M
700035	DB1600.DBX4.3	Spindle positioning to unclamping position timeout	SBR60: Disk_MGZ_M
700036	DB1600.DBX4.4	Spindle positioning to clamping position timeout	SBR60: Disk_MGZ_M
700049	DB1600.DBX6.1	Reference point of X axis not reached	SBR58: MM_MAIN
700050	DB1600.DBX6.2	Reference point of Z axis not reached	SBR58: MM_MAIN
700051	DB1600.DBX6.3	Spindle direction illegal	SBR58: MM_MAIN
700052	DB1600.DBX6.4	Monitoring time for JOG operation exceeded	SBR58: MM_MAIN
700053	DB1600.DBX6.5	Spindle override not 100%	SBR58: MM_MAIN
700054	DB1600.DBX6.6	Spindle not started	SBR58: MM_MAIN
700055	DB1600.DBX6.7	Feed override = 0%	SBR58: MM_MAIN
700056	DB1600.DBX7.0	Spindle dir. change not allowed in thread mach.	SBR58: MM_MAIN
700059	DB1600.DBX7.3	NC start not possible: safety door not closed	SBR22: AUX_SAFE_DOOR
700060	DB1600.DBX7.4	PRT/AFL change not possible: channel not reset	SBR37: MCP_NCK
700061	DB1600.DBX7.5	Mgz. in maint. Read-in & rapid traverse disabled	SBR60: Disk_MGZ_M
700062	DB1600.DBX7.6	Tool on spindle <> tool prgd. mgz. must be referenced	SBR60: Disk_MGZ_M

### A.7.5.1 Alarm cancel/reset and reaction

#### Conditions of alarm cancel/reset

After the cancel of an alarm, you need to press one of the following two keys to clear the alarm finally.

Then the alarm displayed will disappear by itself.



or




#### Alarm reaction

There are the following two ways for alarm reaction.


PLC reaction: the PLC program detects the reaction through the corresponding PLC interface, such as canceling the axis enable when giving an alarm.

NC reaction: every alarm has an eight-bit configuration MD14516[0] to [127]. You can set the cancelation condition and alarm reaction for every alarm according to the actual condition. The system then makes the corresponding reaction when the alarm begins.



### A.7.5.2 Alarm texts


Creating or editing alarm texts correctly and reasonably can make users clearly realize and understand the reason of a PLC alarm and then locate and resolve breakdown.



You can edit a PLC user alarm by using the following two methods:

- Editing via the USB
- Editing via the HMI

## Editing a PLC user alarm via the USB



1. Select the desired operating area.



2. Press this softkey.



3. Locate the HMI data folder and then open it with the following key.



4. Locate the PLC alarm text folder and then open it through the same method as the above.

Name	Type	Length
..		
alcu_chs.txt		
alcu_deu.txt		
alcu_eng.txt		
alcu_ptb.txt		
alcu_rus.txt		




5. Copy the PLC alarm text in the desired language by pressing this softkey.



6. Press this softkey and then paste the copied alarm text via the following softkey.



7. Connect the USB stick with your PC, find the PLC alarm text that is downloaded, and then open it with the WordPad.



8. Find the alarm number that needs to be edited and type your own text. Save and close the file after editing the alarm text.
9. Remove the USB stick from the PC and connect it with the USB interface on the front panel of the PPU again.
10. Copy the edited alarm text back to the PLC alarm text folder and overwrite the original file.



11. Select the desired operating area.

12. You can check the editing result through the following PPU operations.



### Editing a PLC user alarm via the HMI

For how to edit a PLC user alarm via the HMI, see the topic Editing PLC alarm texts (Page 91).

## A.7.6 PLC sample applications

### A.7.6.1 PLC sample application (turning)

This sample application is applicable to machines with the following configurations:

- Two axes: axes X and Z, with a hardware limit switch respectively in the positive and negative directions of each axis
- An analog spindle: SP
- HALL effect device turret with six working stations
- PLC-controlled timely and quantitatively lubrication system
- PLC-controlled cooling system

#### Assignment of inputs and outputs

Signal	Description	Remark
I0.0	Emergency Stop button	Normally closed
I0.1	Limit switch in the "+" direction of axis X	Normally closed
I0.2	Limit switch in the "-" direction of axis X	Normally closed
I0.3		
I0.4		
I0.5	Limit switch in the "+" direction of axis Z	Normally closed
I0.6	Limit switch in the "-" direction of axis Z	Normally closed
I0.7	Reference point switch of axis X	Normally open
I1.0		
I1.1	Reference switch of axis Z	Normally open
I1.2	Tool path detecting signal T1	Valid at a low level
I1.3	Tool path detecting signal T2	Valid at a low level
I1.4	Tool path detecting signal T3	Valid at a low level
I1.5	Tool path detecting signal T4	Valid at a low level
I1.6	Tool path detecting signal T5	Valid at a low level
I1.7	Tool path detecting signal T6	Valid at a low level
I2.0	Turret motor overload	Normally closed
I2.1	Reserved for other types of turrets	Reserved
I2.2		
I2.3	Chuck foot switch	Normally open
I2.4	Coolant level too low	Normally closed
I2.5	Cooling pump motor overload	Normally closed
I2.6	Lubricant level to low	Normally closed
I2.7	Lubrication pump motor overload	Normally closed
I3.0		Reserved
I3.1		Reserved
I3.2		Reserved

Signal	Description	Remark
I3.3		Reserved
I3.4		Reserved
I3.5		Reserved
I3.6		Reserved
I3.7		Reserved
I4.0	Handheld unit: axis X selected	Valid at a high level
I4.1	Handheld unit: axis Y selected	Valid at a high level
I4.2	Handheld unit: axis Z selected	Valid at a high level
I4.3	Handheld unit: fourth axis selected	Reserved
I4.4	Handheld unit: increment X1	Valid at a high level
I4.5	Handheld unit: increment X10	Valid at a high level
I4.6	Handheld unit: increment X100	Valid at a high level
I4.7	Handheld unit: enabled	Valid at a high level
Q0.0	Working lamp	
Q0.1		
Q0.2	Tailstock forward	
Q0.3	Tailstock backward	
Q0.4	Cooling pump	
Q0.5	Lubrication pump	
Q0.6	Chuck output 1	
Q0.7	Chuck output 2	
Q1.0	Turret motor rotating clockwise	
Q1.1	Turret motor rotating counter-clockwise	
Q1.2	Reserved for other types of turrets	
Q1.3	Reserved for other types of turrets	
Q1.4	Gear shift: low gear level (SBR49: GearChg1_Auto) / Gear level status (SBR50: GearChg2_Virtual)	
Q1.5	Gear shift: high gear level (SBR49: GearChg1_Auto)	
Q1.6		
Q1.7	Handheld unit valid	

#### Definition of user-defined keys on the MCP

User-defined key 1	Working lamp
User-defined key 2	Manual cooling
User-defined key 3	Manual tool change
User-defined key 4	Manual chuck clamping and unclamping
User-defined key 5	Chuck clamping internally/externally
User-defined key 6	Tailstock

#### Structure of the sample application (OB1)

Call Conditions	Subroutine Name	Description
Each scan (SM0.0)	AUX_MCP (SBR20)	Auxiliary function
First scan (SM0.1)	PLC_INI (SBR32)	PLC initialization
Each scan (SM0.0)	EMG_STOP (SBR33)	Emergency Stop control
Each scan (SM0.0)	MCP_NCK (SBR37)	Transferring MCP and HMI signals to the NCK interface
Each scan (SM0.0)	HANDWHL (SBR39)	Selecting a hand wheel through the interface signal DB1900.DBB1xxx
Each scan (SM0.0)	AXIS_CTL (SBR40)	Coordinate enabling control, hardware limit, etc.

Call Conditions	Subroutine Name	Description
Each scan (SM0.0)	SPINDLE (SBR42)	Spindle control
Each scan (SM0.0)	COOLING (SBR44)	Cooling control
Each scan (SM0.0)	TURRET1 (SBR46)	HALL effect device turret control
Each scan (SM0.0)	ServPlan (SBR48)	Maintenance plan example: first task

#### Setting the relevant PLC machine data

Machine data	Corresponding function	
14510[12]	JOG key layout	
14510[13]	Time for spindle braking	
14510[20]	Maximum number of tools	
14510[21]	Time for locking a turret (in 0.1 s)	
14510[22]	Monitoring time when searching tools (in 0.1 s)	
14510[24]	Lubrication interval (in 1 min)	
14510[25]	Lubrication duration (in 0.01 s)	
14512[16]	Bit 7	Handwheel assignment with the MCP / HMI
14512[17]	Bit 0	Turret function
	Bit 1	Clamping function
	Bit 2	Tailstock function
	Bit 3	Selection between handwheel and hand-held unit (0: handwheel; 1: hand-held unit)
14512[18]	Bit 2	One time automatic lubrication after the power-on
	Bit 4	External signal for spindle stop
	Bit 5	Fixing the direction of a spindle
	Bit 6	Hardware limit is independent of the PLC application
	Bit 7	One hardware limit triggered per axis (enabled when bit 6=0)
14512[19]	Bit 1	Function of spindle braking
	Bit 2	Password clearing by power-on (0: delete the password; 1: do not delete the password)
	Bit 7	MM+ (Manual Machine Plus) function (enabled when the MM+ has been licensed and corresponding PLC subroutine has been called)
14512[20]	Bit 1	Spindle disable mode

#### A.7.6.2 PLC sample application (milling)

This sample application is applicable to machines with the following configurations:

- Three axes: axes X, Y and Z, with a hardware limit switch respectively in the positive and negative directions of each axis
- An analog spindle: SP (the fourth axis)
- PLC-controlled timely and quantitatively lubrication system
- PLC-controlled cooling system

#### Assignment of inputs and outputs

Signal	Description	Remark
I0.0	Emergency Stop button	Normally closed
I0.1	Limit switch in the "+" direction of axis X	Normally closed
I0.2	Limit switch in the "-" direction of axis X	Normally closed
I0.3	Limit switch in the "+" direction of axis Y	
I0.4	Limit switch in the "-" direction of axis Y	
I0.5	Limit switch in the "+" direction of axis Z	Normally closed
I0.6	Limit switch in the "-" direction of axis Z	Normally closed
I0.7	Reference point switch of axis X	Normally open
I1.0	Reference point switch of axis Y	



Signal	Description	Remark
I1.1	Reference point switch of axis Z	Normally open
I1.2	Disk-style tool magazine: tool magazine count	Valid at a low level
I1.3	Disk-style tool magazine: tool magazine at the spindle position	Valid at a low level
I1.4	Disk-style tool magazine: tool magazine at the original position	Valid at a low level
I1.5	Disk-style tool magazine: tool at the release position	Valid at a low level
I1.6	Disk-style tool magazine: tool at the clamping position	Valid at a low level
I1.7		Valid at a low level
I2.0		Normally closed
I2.1		Reserved
I2.2		
I2.3		Normally open
I2.4	Coolant level too low	Normally closed
I2.5	Cooling pump motor overload	Normally closed
I2.6	Lubricant level too low	Normally closed
I2.7	Lubrication pump motor overload	Normally closed
I3.0		Reserved
I3.1		Reserved
I3.2		Reserved
I3.3		Reserved
I3.4		Reserved
I3.5		Reserved
I3.6		Reserved
I3.7		Reserved
I4.0	Handheld unit: axis X selected	Valid at a high level
I4.1	Handheld unit: axis Y selected	Valid at a high level
I4.2	Handheld unit: axis Z selected	Valid at a high level
I4.3	Handheld unit: fourth axis selected	Reserved
I4.4	Handheld unit: increment X1	Valid at a high level
I4.5	Handheld unit: increment X10	Valid at a high level
I4.6	Handheld unit: increment X100	Valid at a high level
I4.7	Handheld unit: enabled	Valid at a high level
Q0.0	Working lamp	
Q0.1		
Q0.2	Chip forward	
Q0.3	Chip backward	
Q0.4	Cooling pump	
Q0.5	Lubrication pump	
Q0.6	Safety door open	
Q0.7		
Q1.0	Magazine rotating clockwise	
Q1.1	Magazine rotating counter-clockwise	
Q1.2	Magazine approaching spindle position	
Q1.3	Magazine approaching original position	
Q1.4	Tool release from the spindle	
Q1.5		
Q1.6		
Q1.7	Handheld unit valid	

## Definition of user-defined keys on the MCP

User-defined key 1	Working lamp
User-defined key 2	Manual cooling
User-defined key 3	Safety door
User-defined key 4	Manual clockwise rotation of the tool magazine
User-defined key 5	Manual reset of the tool magazine
User-defined key 6	Manual counter-clockwise rotation of the tool magazine
User-defined key 7	Removing chip forward
User-defined key 8	Removing chip backward

## Structure of the sample application (OB1)

Call Conditions	Subroutine Name	Description
Each scan (SM0.0)	AUX_MCP (SBR20)	Auxiliary function
First scan (SM0.1)	PLC_INI (SBR32)	PLC initialization
Each scan (SM0.0)	EMG_STOP (SBR33)	Emergency Stop control
Each scan (SM0.0)	MCP_NCK (SBR37)	Transferring MCP and HMI signals to the NCK interface
Each scan (SM0.0)	HANDWHL (SBR39)	Selecting a hand wheel through the interface signal DB1900.DBB1xxx
Each scan (SM0.0)	AXIS_CTL (SBR40)	Coordinate enabling control, hardware limit, etc.
Each scan (SM0.0)	SPINDLE (SBR42)	Spindle control
Each scan (SM0.0)	COOLING (SBR44)	Cooling control
Each scan (SM0.0)	LUBRICAT (SBR45)	Lubrication control

## Setting the relevant PLC machine data

Machine data	Corresponding function	
14510[12]	JOG key layout	
14510[13]	Time for spindle braking	
14510[20]	Maximum number of tools	
14510[24]	Lubrication interval (in 1 min)	
14510[25]	Lubrication duration (in 0.01 s)	
14512[16]	Bit 1	Function of chip conveyor
	Bit 2	Function of safety door
	Bit 3	When the function of safety door is active, it can be triggered by M01/M02
	Bit 7	Handwheel assignment with the MCP / HMI
14512[17]	Bit 0	Tool magazine function
	Bit 3	Selection between handwheel and hand-held unit (0: handwheel; 1: hand-held unit)
14512[18]	Bit 2	One time automatic lubrication after the power-on
	Bit 4	External signal for spindle stop
	Bit 5	Fixing the direction of a spindle
	Bit 6	Hardware limit is independent of the PLC application
	Bit 7	One hardware limit triggered per axis (enabled when bit 6=0)
14512[19]	Bit 1	Function of spindle braking
	Bit 2	Password clearing by power-on (0: delete the password; 1: do not delete the password)
	Bit 7	MM+ (Manual Machine Plus) function (enabled when the MM+ has been licensed and corresponding PLC subroutine has been called)
14512[20]	Bit 1	Spindle disable mode

## A.8 AMM communication tool

With the communication tool Access MyMachine P2P (AMM), you can establish an Ethernet connection and realize data transfer between the control system and a PC. This tool is available in the Toolbox and is supported by Windows Vista/Win 7.

### Ethernet connections

The following Ethernet connections are possible between the control system and the AMM tool on the PC:






- Direct connection: direct connection between the control system and PC
- Network connection: integrating the control system into an existing Ethernet network


After an active Ethernet connection is established, the AMM tool provides the possibility of data exchange between the control system and a PC, as well as remote control of the HMI from a PC. For more information about the tool functionality, see the Online Help of the tool.

### A.8.1 Establishing an Ethernet connection

#### Establishing a direct connection


Proceed as follows to establish a direct connection between the control system and a PC (AMM tool):

1. Connect the control system with the PC using an Ethernet cable.
2. Select the desired operating area on the PPU.
3. Press this key to view the extended softkeys.  

4. Set up a direct connection on the control system through the following softkey operations:  
  
The following dialog pops up on the screen:  

5. Start the Access MyMachine P2P (PC) on your PC. A password setting dialog appears when the tool is started for the first time.
6. Enter a desired password in the input fields and then click this button to save.  
  
This password ensures that all the connection data for AMM is encrypted. The password can be subsequently changed at any time from the menu bar.
7. Select the direct connection option in the following dialog and then click this button.  




An attempt is made to establish a direct connection.


8. If you have not established any authentication data, the following dialog appears:



Select the log-on details and enter the corresponding password or alternatively select a key file in the dialog.

If the authentication data for the direct connection has already been saved, a connection to the control system will be set up immediately.

9. Click this button and the AMM tool connects to the control system selected.



### Establishing a network connection

Proceed as follows to establish a network connection:

1. Connect the control system with the local network using an Ethernet cable.
2. Select the desired operating area on the PPU.
3. Press this key to view the extended softkeys.



4. Enter the main screen of the service control options through the following softkey operations:



5. Press this softkey to enter the window for the network configuration.

**Note:** make sure the following vertical softkey is not selected:



6. Configure the network as required in the following window:

Network configuration	
Local data	
Protocol:	TCP / IP
DHCP:	Yes
Cmpt. name:	NONAME_NCU
IP address:	176 16 202 200
Subnet mask	255 255 255 0
Gateway:	[ ] [ ] [ ] [ ]


You can configure DHCP with the following key:




**Note:** If you select "No" for DHCP, you must enter the IP address (which must belong to the same network as that of your PC) and subnet mask manually.


Save

7. Press this softkey to save the configuration. If you select "Yes" for DHCP, you also need to restart the control system to activate the network configuration.
8. Start the AMM on your PC.
9. Select the new network connection option in the following dialog:




This dialog can also be called with the  button from the toolbar.


10. The dialog for setting the new network connection appears. Assign the parameters for a new network connection in this dialog:



11. Select the following button to save the settings:




12. Select the following button and the AMM tool connects to the control system selected.



## A.8.2 File management and transfer

After an active Ethernet connection is established, you can have a remote access to the control system's NC file system from your PC. In this case, you can easily manage the NC files with the AMM tool and transfer files between the control system and your PC.




You can edit, rename, copy, or delete part programs, workpiece programs, cycles, and so on directly in the NC file system of the AMM tool.



### Example of transferring a file to the control system


The file transfer between the control system and a PC is possible by means of simple copy and paste/drag and drop operations.

Proceed as follows to transfer a program file from PC to the control system:

1. Open the main screen of the AMM tool on your PC.
2. Select a desired program file to be transferred (for example, Test.mpf) from the PC file system.



3. Copy the program file with the toolbar button , keyboard shortcuts (Ctrl + C), or from the context menu.
4. Select the program directory in the NC file system.
5. Paste the copied file into the current directory with the toolbar button , keyboard shortcuts (Ctrl + V), or from the context menu.



Alternatively, you can transfer the file by simply dragging and dropping it from the PC file system to the NC file system.

After the file is successfully pasted, you can find it in the corresponding directory on the control system.

### A.8.3 Remote control

With the remote control function you can:

- Operate the HMI remotely from a PC.
- Generate screenshots of the HMI and save them onto a PC.

#### Configuring the remote access rights

Proceed through the following steps to configure the remote access rights on the HMI:



1. Select the desired operating area on the PPU.



2. Press this softkey to change the settings, if desired.



3. Press this softkey to make the settings changeable. Note that this softkey is visible only with a system password.



4. Use this key to select the desired right for remote access. You can choose to allow the remote operation/monitoring of the HMI, or forbid the remote access to the HMI.

#### Remote access right

Select in HMI

Permit remote operation

5. Set the behavior of the control system when it receives a remote access request.

#### Behavior for remote access confirmation

- ① Confirmation dialog display duration 10 s
- ② Afterwards remote access is automatically Permitted

- ① Specify the duration of the following dialog displaying on the HMI:



The following operations on the HMI are possible when this dialog appears:



Press this softkey to reject the request.




Press this softkey to permit the request.

- ② Use the following key to select the automatic response for the control system after the above dialog disappears with no softkey operations.





6. Press this softkey to save the settings.




### Starting/stopping remote control


Proceed through the following steps to start/stop the remote control of the HMI:

1. Start the AMM tool and establish an Ethernet connection to the control system (see section "Establishing an Ethernet connection (Page 287)").
2. Click the  button in the toolbar or select from the main window menu as follows to start the remote control.



Once the remote control has been started, a monitoring window opens showing the HMI screen contents of the connected control system. You can find a  symbol in the tip area of the HMI screen.


3. Closing the monitoring window or selecting from the main window menu as follows stops the remote control.





### A.8.3.1 Operating the HMI via remote control

If the remote control has been started, you can use your mouse to operate the HMI by clicking on the softkeys displayed in the monitoring window.




You can perform the return operation by clicking the  icon in the screen when possible.


### A.8.3.2 Saving the remote control screen as a picture

#### Operating sequence

1. After the remote control is started, select from the AMM main window menu as follows:



2. Select the target directory on your PC.
3. Specify the picture name and type.
4. Click this button to save the picture.



---

## **Trademarks**

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

## **Disclaimer of Liability**

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Siemens AG  
Division Digital Factory  
Postfach 48 48  
90026 NÜRNBERG

Commissioning Manual  
6FC5397-4EP10-0BA4, 08/2015