

## SIMATIC NET

### Industrial Wireless LAN SCALANCE W770/W730 to IEEE 802.11n Web Based Management

Configuration Manual

<u>Introduction</u>	<b>1</b>
<u>Description</u>	<b>2</b>
<u>Security recommendations</u>	<b>3</b>
<u>Technical basics</u>	<b>4</b>
<u>IP addresses</u>	<b>5</b>
<u>Configuring with Web Based Management</u>	<b>6</b>
<u>Upkeep and maintenance</u>	<b>7</b>
<u>Troubleshooting/FAQ</u>	<b>8</b>
<u>Appendix A</u>	<b>A</b>
<u>Appendix B</u>	<b>B</b>
<u>Appendix C</u>	<b>C</b>
<u>Appendix D</u>	<b>D</b>

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

#### **DANGER**

indicates that death or severe personal injury **will** result if proper precautions are not taken.

#### **WARNING**

indicates that death or severe personal injury **may** result if proper precautions are not taken.

#### **CAUTION**

indicates that minor personal injury can result if proper precautions are not taken.

#### **NOTICE**

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

#### **WARNING**

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Table of contents

<b>1</b>	<b>Introduction.....</b>	<b>9</b>
1.1	Information on the Configuration Manual.....	9
1.2	Type designations.....	14
<b>2</b>	<b>Description.....</b>	<b>15</b>
2.1	Network structures.....	16
2.2	Possible applications of SCALANCE W700 devices.....	21
2.3	Product characteristics.....	22
2.4	IEEE 802.11n.....	24
2.5	Requirements for installation and operation of SCALANCE W devices.....	28
2.6	C-PLUG and KEY-PLUG.....	29
2.7	Power over Ethernet (PoE).....	31
<b>3</b>	<b>Security recommendations.....</b>	<b>35</b>
<b>4</b>	<b>Technical basics.....</b>	<b>41</b>
4.1	Configuration limits for WBM and CLI.....	41
4.2	Interfaces and system functions.....	43
4.3	EtherNet/IP.....	47
4.4	PROFINET.....	48
4.5	VLAN.....	49
4.6	MAC-based communication.....	50
4.7	iPCF / iPCF-HT / iPCF-MC.....	51
4.8	iREF.....	55
4.9	iPRP.....	57
4.10	AeroScout.....	60
4.11	NAT/NAPT.....	62
4.12	SNMP.....	63
4.13	Spanning Tree.....	66
4.13.1	RSTP, MSTP, CIST.....	67
4.14	User management.....	69
<b>5</b>	<b>IP addresses.....</b>	<b>71</b>
5.1	IPv4 / IPv6.....	71
5.2	IPv4 address.....	73
5.2.1	Structure of an IPv4 address.....	73

5.2.2	Initial assignment of an IPv4 address .....	74
5.2.3	Address assignment via DHCPv4 .....	75
5.2.4	Address assignment with the Primary Setup Tool .....	76
5.2.5	Address assignment with STEP 7 .....	76
5.3	IPv6 address .....	77
5.3.1	IPv6 terms .....	77
5.3.2	Structure of an IPv6 address .....	79
<b>6</b>	<b>Configuring with Web Based Management.....</b>	<b>81</b>
6.1	Web Based Management .....	81
6.2	Login .....	83
6.3	"Wizard" menu .....	87
6.3.1	Basic Wizard .....	87
6.3.1.1	System Settings .....	88
6.3.1.2	Country Settings.....	90
6.3.1.3	IP Address Settings .....	91
6.3.1.4	Management Interfaces .....	92
6.3.1.5	Antenna Settings.....	94
6.3.1.6	Radio Settings.....	96
6.3.1.7	Access Point Settings .....	98
6.3.1.8	Client Settings.....	99
6.3.1.9	Client Setting Allowed Channels.....	101
6.3.1.10	Security Settings .....	103
6.3.1.11	Dot1x Supplicant Settings.....	105
6.3.1.12	Dot1x RADIUS Server Settings .....	106
6.3.1.13	Summary of the settings .....	108
6.4	"Information" menu.....	109
6.4.1	Start page.....	109
6.4.2	Versions .....	115
6.4.3	I&M.....	117
6.4.4	ARP / neighbors .....	118
6.4.4.1	ARP table .....	118
6.4.4.2	IPv6 Neighbor Table .....	119
6.4.5	Log Tables .....	120
6.4.5.1	Event log .....	120
6.4.5.2	WLAN authentication log .....	122
6.4.6	Faults .....	123
6.4.7	Redundancy .....	124
6.4.8	Ethernet Statistiken.....	129
6.4.8.1	Interface statistics .....	129
6.4.8.2	Packet Size .....	130
6.4.8.3	Frame Type.....	131
6.4.8.4	Packet Error .....	131
6.4.9	Learning Table .....	132
6.4.10	IPv6 routing .....	133
6.4.11	DHCP-Server .....	134
6.4.12	SNMP .....	135
6.4.13	Security .....	136
6.4.13.1	Overview .....	136
6.4.13.2	Supported Function Rights .....	139

6.4.13.3	Roles .....	140
6.4.13.4	Groups .....	141
6.4.13.5	Inter AP Blocking .....	142
6.4.14	WLAN .....	143
6.4.14.1	Overview AP .....	143
6.4.14.2	Client List .....	145
6.4.14.3	WDS List .....	147
6.4.14.4	Overlap AP .....	148
6.4.14.5	Force Roaming .....	150
6.4.14.6	Overview Client .....	151
6.4.14.7	Available AP .....	154
6.4.14.8	IP mapping table .....	156
6.4.14.9	Background noise .....	157
6.4.15	WLAN Statistics .....	158
6.4.15.1	Errors .....	158
6.4.15.2	Management Sent .....	160
6.4.15.3	Management Received .....	161
6.4.15.4	Data Sent .....	162
6.4.15.5	Data Received .....	164
6.4.16	WLAN iFeatures .....	165
6.4.16.1	iREF Client List .....	165
6.4.16.2	iREF WDS List .....	167
6.4.16.3	AeroScout .....	168
6.4.16.4	iPRP .....	170
6.5	"System" menu .....	172
6.5.1	System Configuration .....	172
6.5.2	General .....	175
6.5.2.1	Device .....	175
6.5.2.2	Coordinates .....	176
6.5.3	Agent IPv4 .....	178
6.5.4	Agent IPv6 .....	179
6.5.4.1	IPv6 default routes .....	182
6.5.5	DNS .....	183
6.5.6	Restart .....	185
6.5.7	Commit Control .....	188
6.5.8	Load & Save .....	189
6.5.8.1	HTTP .....	193
6.5.8.2	TFTP .....	196
6.5.8.3	SFTP .....	199
6.5.8.4	Passwords .....	202
6.5.9	Events .....	204
6.5.9.1	Configuration .....	204
6.5.9.2	Severity Filters .....	206
6.5.10	SMTP client .....	208
6.5.11	DHCPv4 .....	210
6.5.11.1	DHCP client .....	210
6.5.11.2	DHCP Server .....	211
6.5.11.3	DHCP Options .....	214
6.5.11.4	Static Leases .....	216
6.5.12	SNMP .....	218
6.5.12.1	General .....	218
6.5.12.2	Traps .....	221

6.5.12.3	v3 Groups .....	222
6.5.12.4	v3 Users .....	225
6.5.13	System Time .....	227
6.5.13.1	Manual Setting .....	228
6.5.13.2	DST Overview .....	230
6.5.13.3	DST Configuration .....	232
6.5.13.4	SNTP Client .....	235
6.5.13.5	NTP Client .....	238
6.5.13.6	SIMATIC Time Client .....	240
6.5.14	Auto Logout .....	242
6.5.15	Syslog Client .....	243
6.5.16	Fault Monitoring .....	244
6.5.16.1	Power Supply .....	244
6.5.16.2	Link Change .....	246
6.5.17	PROFINET .....	247
6.5.18	EtherNet/IP .....	249
6.5.19	PLUG .....	251
6.5.19.1	Configuration .....	251
6.5.19.2	License .....	254
6.5.20	Ping .....	257
6.6	"Interfaces" menu .....	259
6.6.1	Ethernet .....	259
6.6.1.1	Overview .....	259
6.6.1.2	Configuration .....	261
6.6.2	WLAN .....	263
6.6.2.1	Basic .....	263
6.6.2.2	Advanced .....	268
6.6.2.3	Antennas .....	271
6.6.2.4	Allowed Channels .....	274
6.6.2.5	802.11n .....	276
6.6.2.6	AP .....	277
6.6.2.7	AP WDS .....	281
6.6.2.8	AP 802.11a/b/g Rates .....	283
6.6.2.9	AP 802.11n Rates .....	285
6.6.2.10	Client .....	288
6.6.2.11	Force Roaming .....	292
6.6.2.12	Signal recorder .....	295
6.6.2.13	Spectrum Analyzer .....	306
6.6.3	Remote Capture .....	313
6.7	"Layer 2" menu .....	317
6.7.1	VLAN .....	317
6.7.1.1	General .....	317
6.7.1.2	Port-based VLAN .....	320
6.7.2	Dynamic MAC Aging .....	323
6.7.3	Spanning Tree .....	324
6.7.3.1	General .....	324
6.7.3.2	CIST General .....	326
6.7.3.3	CIST Port .....	328
6.7.3.4	MST General .....	332
6.7.3.5	MST Port .....	334
6.7.4	DCP Forwarding .....	336

6.7.5	LLDP .....	337
6.8	"Layer 3" menu .....	339
6.8.1	NAT .....	339
6.8.1.1	Basic .....	339
6.8.1.2	NAPT.....	342
6.9	"Security" menu .....	345
6.9.1	Users.....	345
6.9.1.1	Local Users .....	345
6.9.1.2	Roles .....	348
6.9.1.3	Groups .....	350
6.9.2	Passwords .....	352
6.9.2.1	Passwords .....	352
6.9.2.2	Options.....	354
6.9.3	AAA .....	355
6.9.3.1	General .....	355
6.9.3.2	RADIUS client.....	356
6.9.4	WLAN.....	360
6.9.4.1	Basic (Access Point) .....	360
6.9.4.2	Basic (Client).....	364
6.9.4.3	AP Communication .....	367
6.9.4.4	AP RADIUS Authenticator .....	369
6.9.4.5	Client Radius Supplicant.....	371
6.9.4.6	Keys .....	373
6.9.5	MAC ACL .....	374
6.9.5.1	Rules Configuration .....	374
6.9.5.2	Ingress Rules .....	376
6.9.5.3	Egress Rules.....	378
6.9.6	IP ACL.....	380
6.9.6.1	Rules Configuration .....	380
6.9.6.2	Protocol Configuration .....	381
6.9.6.3	Ingress Rules .....	383
6.9.6.4	Egress Rules.....	386
6.9.7	Management ACL .....	389
6.9.8	Inter AP blocking.....	392
6.9.8.1	Basic .....	392
6.9.8.2	Allowed Addresses .....	394
6.10	"iFeatures" menu .....	396
6.10.1	iPCF .....	396
6.10.2	iPCF-HT .....	400
6.10.3	iPCF-MC .....	404
6.10.4	iPRP .....	407
6.10.5	iREF .....	411
6.10.6	AeroScout .....	412
<b>7</b>	<b>Upkeep and maintenance .....</b>	<b>415</b>
7.1	Firmware update - via WBM .....	415
7.2	Device configuration with PRESET-PLUG .....	417
7.3	Embedding firmware in ConfigPack.....	420
7.4	Restoring the factory settings .....	422

<b>8</b>	<b>Troubleshooting/FAQ.....</b>	<b>425</b>
8.1	Firmware update via WBM or CLI not possible .....	425
8.2	Disrupted data transmission due to the received power being too high .....	427
8.3	Compatibility with predecessor products .....	428
8.4	Instructions for secure network design .....	429
8.5	WLAN client Trigger handover via SNMP.....	430
8.6	Configuring the device using the TIA Portal .....	431
8.6.1	Message: SINEMA configuration not yet accepted .....	432
<b>A</b>	<b>Appendix A .....</b>	<b>435</b>
A.1	MIB files supported by SCALANCE W700 device .....	435
<b>B</b>	<b>Appendix B .....</b>	<b>437</b>
B.1	Private MIB variables of the SCALANCE W700 .....	437
<b>C</b>	<b>Appendix C .....</b>	<b>439</b>
C.1	Underlying standards .....	439
<b>D</b>	<b>Appendix D .....</b>	<b>441</b>
D.1	Messages in the event log .....	441
D.2	Messages in the WLAN Authentication Log .....	446
	<b>Index .....</b>	<b>447</b>

# Introduction

## 1.1 Information on the Configuration Manual

### Validity of the configuration manual

This Configuration Manual covers the following products:

- SCALANCE W774-1 RJ45
- SCALANCE W774-1 M12 EEC
- SCALANCE W734-1 RJ-45
- SCALANCE W778-1 M12
- SCALANCE W778-1 M12 EEC
- SCALANCE W738-1 M12

This Configuration Manual applies to the following software version:

- SCALANCE W700 firmware as of version V 6.3

### Purpose of the Configuration Manual

This Configuration Manual is intended to provide you with the information you require to commission and operate SCALANCE W700 devices correctly. It explains how to configure the SCALANCE W700 devices and how to integrate them in a WLAN network.

The operating instructions for the corresponding SCALANCE W700 devices describe how to install and connect up the devices correctly.

## Orientation in the documentation

Apart from the Configuration Manual you are currently reading, the following documentation is also available from SIMATIC NET on the topic of Industrial Wireless LANs:

- **Configuration Manual: SCALANCE W770 / W730 Command Line Interface**  
This document contains the CLI commands that are supported by SCALANCE W700 devices.
- **Performance data 802.11 abgn SCALANCE W770/W730**  
This document contains information about the frequency, modulation, transmit power and receiver sensitivity.
- **Operating instructions SCALANCE W774-1 /W734-1**  
This document contains information on installing and connecting up the following products and their approvals.
  - SCALANCE W734-1 RJ-45
  - SCALANCE W774-1 RJ45
  - SCALANCE W774-1 M12 EEC
- **Operating Instructions SCALANCE W778-1/W738-1**
  - SCALANCE W778-1 M12
  - SCALANCE W778-1 M12 EEC
  - SCALANCE W738-1 M12
- **System Manual Structure of an Industrial Wireless LAN**  
Apart from the description of the physical basics and a presentation of the main IEEE standards, this also contains information on data security and a description of the industrial applications of wireless LAN.  
You should read this manual if you want to set up WLAN networks with a more complex structure (not simply a connection between two devices).
- **System manual RCoax**  
This system manual contains both an explanation of the fundamental technical aspects as well as a description of the individual RCoax components and their functionality. Installation/commissioning and connection of RCoax components and their operating principle are explained. The possible applications of the various SIMATIC NET components are described.
- **System manual - Passive Network Components IWLAN**  
This system manual explains the entire IWLAN cabling that you require for your IWLAN application. For a flexible combination and installation of the individual IWLAN components both indoors and outdoors, a wide ranging selection of compatible coaxial accessories are available. The system manual also covers connecting cables as well as a variety of plug-in connectors, lightning protectors, a power splitter and an attenuator.

## Terms used

The designation . . .	stands for . . .
IPv4 address	IPv4 address
IPv6 address	IPv6 address
IP address	IPv4/IPv6 address
IPv4 interface	Interface that supports IPv4.
IPv6 interface	Interface that supports IPv6. The interface can have more than one IPv6 address. The IPv6 addresses have different ranges (scope), e.g. link local
IP interface	Interface that supports both IPv4 and IPv6. As default the IPv4 support is already activated. The IPv6 support needs to be activated extra.

## SIMATIC NET manuals

You will find SIMATIC NET manuals on the Internet pages of Siemens Industry Online Support:

- Using the search function:  
Siemens Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/>)  
Enter the entry ID of the relevant manual as the search item.
- In the navigation panel on the left-hand side in the area "Industrial Communication":  
Industrial communication (<https://support.industry.siemens.com/cs/ww/en/ps/15247/man>)  
Go to the required product group and make the following settings:  
tab "Entry list", Entry type "Manuals"

## Further documentation

The "SIMATIC NET Industrial Ethernet Network Manual" contains information on other SIMATIC NET products that you can operate along with the devices of this product line in an Industrial Ethernet network. There, you will find among other things optical performance data of the communications partners that you require for the installation.

The "SIMATIC NET Industrial Ethernet Network Manual" can be found on the Internet pages of Siemens Industry Online Support under the following entry ID:  
27069465 (<https://support.industry.siemens.com/cs/ww/en/view/27069465>)

## Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is

necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

Additionally, Siemens' guidance on appropriate security measures should be taken into account. For additional information on industrial security measures that may be implemented, please visit

Link (<https://www.siemens.com/industrialsecurity>)

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customers' exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

Link (<https://www.siemens.com/industrialsecurity>)

## SIMATIC NET glossary

Explanations of many of the specialist terms used in this documentation can be found in the SIMATIC NET glossary.

You will find the SIMATIC NET glossary here:

- SIMATIC NET Manual Collection or product DVD  
The DVD ships with certain SIMATIC NET products.
- On the Internet under the following address:  
50305045 (<https://support.industry.siemens.com/cs/ww/en/view/50305045>)

## License conditions

---

### Note

#### Open source software

Read the license conditions for open source software carefully before using the product.

---

You will find license conditions in the following documents on the supplied data medium:

- OSS\_Scalance-W700\_86.pdf

## **Trademarks**

The following and possibly other names not identified by the registered trademark sign ® are registered trademarks of Siemens AG:

SIMATIC NET, SCALANCE, C-PLUG, RCoax

## **Firmware**

The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.

1.2 Type designations

Abbreviations used

The information in the manuals for the SCALANCE W700 product family often applies to more than one product variant. In such situations, the designations of the products are shortened to avoid having to list all the type designations. The following table shows how the abbreviations relate to the product variants.

Product group	The designation . . . stands for . . .	Product name
Access point	W774  W778	SCALANCE W774-1 RJ-45 SCALANCE W774-1 M12 EEC SCALANCE W778-1 M12 SCALANCE W778-1 M12 EEC
Client	W734 W738	SCALANCE W734-1 RJ-45 SCALANCE W738-1 M12
<div><div><div>W774-1 RJ-45</div><div>W774-1 M12 EEC</div><div>W778-1 M12</div><div>W778-1 M12 EEC</div><div>W734-1 RJ-45</div><div>W738-1 M12</div></div><div><div>EEC: Enhanced Environmental Condition</div><div>M12: Socket</div><div>RJ45: Socket</div><div>Number of WLAN interfaces</div><div>4: IP30</div><div>8: IP65</div><div>7 Access Point</div><div>3 Client</div></div></div>		

## Description

---

**Note****Interruption of the WLAN communication**

The WLAN communication can be influenced by high frequency interference signals and can be totally interrupted.

Remember this and take suitable action.

---

## 2.1 Network structures


The following article deals with the setting up of various network structures using access points and clients. A client is also an access point in client mode.

### Standalone configuration with access point

This configuration does not require a server and the access point does not have a connection to a wired Ethernet. Within its transmission range, the access point forwards data from one WLAN node to another.

The wireless network has a unique name. All the SCALANCE W700 devices exchanging data within this network must be configured with this name.

The gray area in the graphic symbolizes the wireless range of the access point.



## Wireless access to a wired Ethernet network

If one (or more) access points have access to wired Ethernet, the following applications are possible:

- A single device as gateway:


A wireless network can be connected to a wired network via an access point.

- Span of wireless coverage for the wireless network with several access points:

The access points are all configured with the same unique SSID (network name). All nodes that want to communicate over this network must also be configured with this SSID.

If a mobile station moves from the area covered by one access point to the area covered by another access point, the wireless link is maintained (roaming).

The following graphic shows the wireless connection of a mobile station over two wireless cells (roaming).




### Multichannel configuration

If neighboring access points use the same frequency channel, this can lead to longer response times due to any collisions that may occur. If the configuration shown in the figure is implemented as a single-channel system, computers A and B cannot communicate at the same time with the access points in their wireless cells.

If neighboring access points are set up for different frequencies, this leads to a considerable improvement in performance. As a result, neighboring wireless cells each have their own medium available and the delays resulting from time-offset transmission no longer occur.

The channel spacing should be as large as possible; a practical value is 25 MHz. Even in a multichannel configuration, all access points can be configured with the same network name.

The following graphic shows a multichannel configuration on channels 1 and 2 with four access points.




## Wireless Distribution System (WDS)

WDS allows direct links between access points and or between access points and other WDS-compliant devices. These are used to create a wireless backbone or to connect an individual access point to a network that cannot be connected directly to the cable infrastructure due to its location.

Two alternative configurations are possible. The WDS partner can be configured using the WDS ID or using its MAC address.


The following graphic shows the implementation of WDS with four access points.



### **Network access with a client or an access point in client mode**

The SCALANCE W700 device can be used to integrate wired Ethernet devices (for example SIMATIC S7 PLC) in a wireless network.

The following graphic shows the connection of a SIMATIC S7 PLC to a wireless LAN.



## 2.2 Possible applications of SCALANCE W700 devices

---

### Note

The SIMATIC NET WLAN products use OpenSSL.

This is open source code with license conditions (BSD).

Please refer to the current license conditions.

Since the driver includes encryption software, you should also adhere to the appropriate regulations for your specific country.

---

### Possible applications of the SCALANCE W774/W778

The SCALANCE W774/W778 is equipped with two Ethernet interfaces and a WLAN interface. This makes the device suitable for the following applications:

- The SCALANCE W774/W778 forwards data within its transmission range from one node to another without a connection to wired Ethernet being necessary.
- The SCALANCE W774/W778 can be used as a gateway from a wired to a wireless network.
- The SCALANCE W774/W778 can be used as a wireless bridge between two networks.
- The SCALANCE W774/W778 can be used as a bridge between two different frequencies.
- The SCALANCE W774 supports protection class IP30  
Two versions of the access point exist: M12 and RJ-45
- The SCALANCE W778 supports protection class IP65. The access point is available in version M12.

### Possible applications of the SCALANCE W734/W738

The SCALANCE W734/W738 is equipped with two Ethernet interfaces and a WLAN interface. This makes the device suitable for the following applications:

- The SCALANCE W734/W738 forwards data within its transmission range from one node to another without a connection to wired Ethernet being necessary.
- The SCALANCE W734/W738 can be used as a gateway from a wired to a wireless network.
- The SCALANCE W734/W738 can be used as a wireless bridge between two networks.
- The SCALANCE W734 supports protection class IP30 and the SCALANCE W734/W738 supports protection class IP65.

## 2.3 Product characteristics

### Properties of the SCALANCE W700 devices

- The Ethernet interface supports the following:
  - 10 Mbps and 100 Mbps both in full and half duplex
  - Autocrossing
  - Autopolarity
- Operating the WLAN interface in the frequency bands 2.4 GHz and 5 GHz.
- The WLAN interface is compatible with the standards IEEE 802.11a , IEEE 802.11b , and IEEE 802.11g. In the 802.11a and 802.11g mode, the gross transmission rate is up to 54 Mbps.
- IEEE 802.11n
  - High-speed WLAN standard (wireless LAN)
  - Can operate in the 2.4 GHz and in the 5 GHz range
- IEEE 802.11h - Supplement to IEEE 802.11a  
In the 802.11h mode, the methods "Transmit Power Control (TPC)" as well as "Dynamic Frequency Selection (DFS)" are used in the range 5.25 - 5.35 and 5.47 - 5.75 GHz. In some countries, this allows the frequency subband of 5.47 - 5.725 GHz to be used in the outdoor area even with higher transmit powers.  
TPC is a method of adapting the transmit power.  
With DFS, the access point searches for primary users for 60 seconds before starting communication on the selected channel. During this time the access point does not send beacons. If signals are found on the channel, the channel is blocked for 30 minutes, the access point changes channel and repeats the check. Primary users are also searched for during operation.
- Support of the authentication standards WPA, WPA-PSK, WPA2, WPA2-PSK and IEEE 802.1x and the encryption methods WEP, AES and TKIP.

---

**Note**

With devices operated in WLAN mode IEEE802.11n only WPA2 (WPA2-PSK and WPA2 Radius) encryption is possible.

---

- For better transmission via WLAN, the function WMM (wireless multimedia) is enabled. The frames are evaluated according to their priority and sent prioritized via the WLAN interface.
- Suitable for inclusion of a RADIUS server for authentication.
- Device-related and application-related monitoring of the wireless connection.
- The interoperability of the SCALANCE W700 devices with Wi-Fi devices of other vendors was tested thoroughly.
- Before commissioning the SCALANCE W700, check the wireless conditions on site. If you intend to use Industrial Wireless LAN systems and WirelessHART systems in the 2.4 GHz band, you will need to plan the use of the channels. At all costs, avoid parallel use of

overlapping frequency ranges. The following overlaps exist with Industrial Wireless LAN and WirelessHART:

IWLAN channel IEEE 802.11 b/g/n	WHART channel IEEE 802.15.4
1	11 - 16
6	15 - 20
7	16 - 21
11	20 - 25
13	21 - 25

#### Note

All SCALANCE W700 access points can be reconfigured for client mode.

### Features of the SCALANCE W700

Type	Number of WLAN ports	Antennas	Number and type of Ethernet interface	Degree of protection	Article number
SCALANCE W774-1 RJ-45	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP30	6GK5774-1FX00-0AA0 6GK5774-1FX00-0AB0 <sup>(1)</sup> 6GK5774-1FX00-0AC0 <sup>(2)</sup>
SCALANCE W774-1 M12 EEC	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP30	6GK5774-1FY00-0TA0 6GK5774-1FY00-0TB0 <sup>(1)</sup>
SCALANCE W734-1 RJ-45	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP30	6GK5734-1FC00-0AA0 6GK5734-1FC00-0AB0 <sup>(1)</sup>
SCALANCE W778-1 M12	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP65	6GK5778-1GY00-0AA0 6GK5778-1GY00-0AB0 <sup>(1)</sup>
SCALANCE W778-1 M12 EEC	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP65	6GK5778-1GY00-0TA0 6GK5778-1GY00-0TB0 <sup>(1)</sup>
SCALANCE W738-1 M12	1	external	2 x 10/100 Mbps Ethernet (cop- per)	IP65	6GK5738-1GY00-0AA0 6GK5738-1GY00-0AB0 <sup>(1)</sup>

(1) US variant

(2) Israel variant

## 2.4 IEEE 802.11n

### Overview


The standard IEEE 802.11n is an expansion of the 802.11 standard and was approved in 2009.

Previous standards worked either in the 2.4 GHz frequency band (IEEE 802.11g /b) or in the 5 GHz frequency band (IEEE 802.11a). IEEE 802.11n can operate in both frequency band. In the IEEE 802.11n standard, there are mechanisms implemented in PHY and MAC layers that increase the data throughput and improve the wireless coverage.

- MIMO antenna technology
- Maximum ratio combining (MRC)
- Spatial multiplexing
- Channel bonding
- Frame aggregation
- Accelerated guard interval
- Modulation and coding scheme
- Data throughput rates up to 450 Mbps (gross)  
This is not possible on all SCALANCE W700 devices.

## MIMO antenna technology

MIMO (Multiple Input - Multiple Output) is based on an intelligent multiple antenna system. The transmitter and the receiver have several spatially separate antennas. The spatially separate antennas transmit the data streams at the same time. Up to four data streams are possible. The data streams are transmitted over spatially separate paths and return over different paths due to diffraction, refraction, fading and reflection (multipath propagation). The multipath propagation means that at the point of reception a complex, space- and time-dependent pattern results as a total signal made up of the individual signals sent. MIMO uses this unique pattern by detecting the spatial position of characteristic signals. Here, each spatial position is different from the neighboring position. By characterizing the individual senders, the recipient is capable of separating several signals from each other.



## Maximum ratio combining (MRC)

In a multiple antenna system, the wireless signals are received by the individual antennas and combined to form one signal. The MRC method is used to combine the wireless signals. The MRC method weights the wireless signals according to their signal-to-noise ratio and combines the wireless signals to form one signal. The signal-to-noise ratio is improved and the error rate is reduced.

## Spatial multiplexing


With spatial multiplexing, different information is sent using the same frequency. The data stream is distributed over  $n$  transmitting antennas; in other words, each antenna sends only  $1/n$  of the data stream. The division of the data stream is restricted by the number of antennas. At the receiver end, the signal is reconstructed.

Due to the spatial multiplexing, there is a higher signal-to-noise ratio and a higher data throughput.

## Channel bonding

With IEEE 802.11n, data can be transferred via two directly neighboring channels. The two 20 MHz channels are put together to form one channel with 40 MHz. This allows the channel bandwidth to be doubled and the data throughput to be increased.

To be able to use channel bonding, the recipient must support 40 MHz transmissions. If the recipient does not support 40 MHz transmissions, the band is automatically reduced to 20 MHz. This means that IEEE 802.11n can also communicate with IEEE 802.11a/b/g devices. The channel bonding is set on the "AP" WBM page with the "HT Channel Width [MHz]" parameter.



## Frame aggregation

With IEEE 802.11n, it is possible to group together individual data packets to form a single larger packet; this is known as frame aggregation. There are two types of frame aggregation:

- Aggregated MAC Protocol Data Unit (A-MPDU)

With A-MPDU, multiple MPDU data packets with the same destination address are bundled and sent as one large A-MPDU.

- Aggregated Mac Service Data Unit (A-MSDU)

With A-MSDU, multiple MSDU data packets with the same destination address are chained together and sent.

The SCALANCE W devices support both types of frame aggregation. You make the settings on the WBM page "AP 802.11n".

## Accelerated guard interval

The guard interval prevents different transmissions being mixed together. In telecommunications, this mixing is also known as intersymbol interference (ISI). When the send time has elapsed, a send pause (guard interval) must be kept to before the next transmission begins.

The guard interval of IEEE 802.11a /b/g is 800 ns. IEEE 802.11n can use the reduced guard interval of 400 ns. You specify the guard interval on the WBM page "AP 802.11n".

## Modulation and coding schemes

The IEEE 802.11n standard supports different data rates. The data rates are based on the number of spatial streams, the modulation method and the channel coding. The various combinations are described in modulation and coding schemes.

## **2.5 Requirements for installation and operation of SCALANCE W devices**

A PG/PC with network connection must be available in order to configure the SCALANCE W devices. If no DHCP server is available, a PC on which the Primary Setup Tool (PST) is installed is necessary for the initial assignment of an IP address to the SCALANCE W devices. For the other configuration settings, a computer with Telnet or a Web browser is necessary.

## 2.6 C-PLUG and KEY-PLUG

### Configuration information on the C-PLUG / KEY-PLUG

The C-PLUG or KEY-PLUG stores the configuration of a device and can therefore transfer the configuration of the old device to the new device.

#### NOTICE

##### **Do not remove or insert a C-PLUG / KEY-PLUG during operation!**

A PLUG may only be removed or inserted when the device is turned off. The device checks whether or not a PLUG is present at one second intervals. If it is detected that the PLUG was removed, there is a restart. If a valid KEY-PLUG was inserted in the device, the device changes to a defined error state following the restart. With SCALANCE W, the available wireless interfaces are deactivated in this case.

If the device was configured at some time with a PLUG, the device can no longer be used without this PLUG. To be able to use the device again, reset the device to the factory settings.

When the new device starts up with the PLUG, it then continues automatically with exactly the same configuration as the old device. One exception to this can be the IP configuration if it is set using DHCP and the DHCP server has not been reconfigured accordingly.

A reconfiguration is necessary if you use functions based on MAC addresses.

#### Note

In terms of the PLUG, the SCALANCE devices work in two modes:

- **Without PLUG**  
The device stores the configuration in internal memory. This mode is active when no PLUG is inserted.
- **With PLUG**  
The configuration stored on the PLUG is displayed over the user interfaces. If changes are made to the configuration, the device stores the configuration directly on the PLUG and in the internal memory. This mode is active as soon as a PLUG is inserted. As soon as the device is started with a PLUG inserted, the SCALANCE W700 starts up with the configuration data on the PLUG.

#### Note

##### **Incompatibility with previous versions with PLUG inserted**

During the installation of a previous version of the firmware, the configuration data can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "NOT ACCEPTED" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data. If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using "System > PLUG".

### **License information on the KEY-PLUG**

In addition to the configuration, the KEY-PLUG also contains a license that allows the use of the iFeatures.

### **PLUG with preset function (PRESET-PLUG)**

With PRESET-PLUG it is possible to install the same configuration and the firmware belonging to it on several devices.

---

#### **Note**

##### **Using configurations with DHCP**

Create a PRESET-PLUG only from device configurations that use DHCP. Otherwise disruptions will occur in network operation due to multiple identical IP addresses.

You assign fixed IP addresses extra following the basic installation.

---

In a PLUG that was configured as a PRESET-PLUG, the device configuration, user accounts, certificates and the firmware are stored.

---

#### **Note**

##### **Restore factory defaults and restart with a PRESET PLUG inserted**

If you reset a device to the factory defaults, when the device restarts an inserted PRESET PLUG is formatted and the PRESET PLUG functionality is lost. You then need to create a new PRESET PLUG.

We recommend that you remove the PRESET PLUG before you reset the device to the factory settings.

---

For more detailed information on creating and using a PRESET PLUG refer to the section Upkeep and maintenance (Page 415).

## 2.7 Power over Ethernet (PoE)

### General

"Power over Ethernet" (PoE) is a power supply technique for network components according to IEEE 802.3af or IEEE 802.3at. The power is supplied over the Ethernet cables that connect the individual network components together. This makes an additional power cable unnecessary. PoE can be used with all PoE-compliant network components that require little power (max. 12.95 W).

Which Ethernet connectors of a device are capable of PoE can be found in the operating instructions of the relevant device.

### Cable used for the power supply

- **Variant 1 (redundant wires)**  
In Fast Ethernet, the wire pairs 1, 2 and 3, 6 are used to transfer data. Pairs 4, 5 and 7, 8 are then used to supply power. If there are only four wires available, the voltage is modulated onto the wires 1, 2 and 3, 6 (see variant 2). This alternative is suitable for a data transmission rate of 10/100 Mbps. This type of power supply is not suitable for 1 Gbps since with gigabit all 8 wires are used for data transfer.
- **Variant 2 (phantom power)**  
With phantom power, the power is supplied over the pairs that are used for data transfer, in other words, all eight (1 Gbps) or four (10/100 Mbps) wires are used both for the data transfer and the power supply.

Whether a device supports variant 1 and variant 2 or only variant 2 can be found in the operating instructions of the relevant device.

A PoE-compliant switch can supply the end device either using:

- Variant 1 or
- Variant 2 or
- Variant 1 and variant 2.

### Endspan

With endspan, the power is supplied via a switch that can reach a device over an Ethernet cable. The switch must be capable of PoE, for example a SCALANCE X108PoE, SCALANCE X308-2M POE, SCALANCE XR552-12M.

### Midspan

Midspan is used when the switch is not PoE-compliant. The power is supplied by an additional device between the switch and end device. In this case, only data rates of 10/100 Mbps can be achieved because the power is supplied on redundant wires.

## 2.7 Power over Ethernet (PoE)

A Siemens power insert can also be used as the interface for the power input. Since a power insert supports a power supply of 24 VDC, it does not conform with 802.3af or IEEE 802.3at. The following restrictions relating to the use of power inserts should be noted:

**WARNING**

**Operate the power insert only when the following conditions apply:**

- with extra low voltages SELV, PELV complying with IEC 60364-4-41
- in USA/CAN with power supplies complying with NEC class 2
- in USA/CAN, the cabling must meet the requirements of NEC/CEC
- Power load maximum 0.5 A.

## Cable lengths

Table 2- 1 Permitted cable lengths (copper cable - Fast Ethernet)

Cable type	Accessory (plug, outlet, TP cord)	Permitted cable length
IE TP torsion cable	with IE FC Outlet RJ-45 + 10 m TP cord	0 to 45 m + 10 m TP cord
	with IE FC RJ-45 Plug 180	0 to 55 m
IE FC TP Marine Cable IE FC TP Trailing Cable IE FC TP Flexible Cable	with IE FC Outlet RJ-45 + 10 m TP cord	0 to 75 m + 10 m TP cord
	with IE FC RJ-45 Plug 180	0 to 85 m
IE FC TP standard cable	with IE FC Outlet RJ-45 + 10 m TP cord	0 to 90 m + 10 m TP cord
	with IE FC RJ-45 Plug 180	0 to 100 m

Table 2- 2 Permitted cable lengths (copper cable - gigabit Ethernet)

Cable type	Accessory (plug, outlet, TP cord)	Permitted cable length
IE FC standard cable, 4x2, 24 AWG	with IE FC RJ-45 Plug 180, 4x2	0 to 90 m
IE FC flexible cable, 4x2, 24 AWG	with IE FC RJ-45 Plug 180, 4x2	0 to 60 m
IE FC standard cable, 4x2, 22 AWG	with IE FC Outlet RJ-45 + 10 m TP cord	0 to 100 m + 10 m TP cord

Table 2- 3 Fitting connectors

PIN	Color of the wire CAT5	Color of the wire CAT6a	Use	
			Power over unused wires (10/100 Mbps only)	Phantom power
1	Yellow	Green/white	Data	Data/power
2	Orange	Green	Data	Data/power
3	White	Orange/white	Data	Data/power
6	Blue	Orange	Data	Data/power
4		Blue	Power	unused at 10/100 Mbps
5		Blue/white	Power	unused at 10/100 Mbps
7		Brown/white	Power	unused at 10/100 Mbps
8		Brown	Power	unused at 10/100 Mbps

### LEDs for PoE on the SCALANCE W700 device

When the SCALANCE W700 device is supplied by PoE, the green "PoE" LED is lit on the SCALANCE W700 device.

## *Description*

---

### *2.7 Power over Ethernet (PoE)*

# Security recommendations

To prevent unauthorized access, note the following security recommendations.

## General

- You should make regular checks to make sure that the device meets these recommendations and/or other security guidelines.
- Evaluate your plant as a whole in terms of security. Use a cell protection concept with suitable products (<https://www.industry.siemens.com/topics/global/en/industrial-security/pages/default.aspx>).
- When the internal and external network are disconnected, an attacker cannot access internal data from the outside. Therefore operate the device only within a protected network area.
- For communication via non-secure networks use additional devices with VPN functionality to encrypt and authenticate the communication.
- Terminate management connections correctly (WBM, Telnet, SSH etc.).

## Physical access

- Restrict physical access to the device to qualified personnel.
- The memory card or the PLUG (C-PLUG, KEY-PLUG, security PLUG) contains sensitive data such as certificates, keys etc. that can be read out and modified.

## Software (security functions)

- Keep the firmware up to date. Check regularly for security updates of the product. You will find information on this on the Internet pages "Industrial Security (<https://www.siemens.com/industrialsecurity>)".
- Inform yourself regularly about security advisories and bulletins published by Siemens ProductCERT (<https://www.siemens.com/cert/en/cert-security-advisories.htm>).
- Only activate protocols that you really require to use the device.
- Use the security functions such as address translation with NAT (Network Address Translation) or NAPT (Network Address Port Translation) to protect receiving ports from access by third parties.
- Restrict access to the device with a firewall or rules in an access control list (ACL - Access Control List).
- If RADIUS authentication is via remote access, make sure that the communication is within the secured network area or is via a secure channel.
- The option of VLAN structuring provides good protection against DoS attacks and unauthorized access. Check whether this is practical or useful in your environment.

- Use a central logging server to log changes and access operations. Operate your logging server within the protected network area and check the logging information regularly.
- Use WPA2/ WPA2-PSK with AES to protect the WLAN. If iPCF or iPCF-MC is used, use the AES encryption.

## Passwords

- Define rules for the use of devices and assignment of passwords.
- Regularly update passwords and keys to increase security.
- Change all default passwords for users before you operate the device.
- Only use passwords with a high password strength. Avoid weak passwords for example password1, 123456789, abcdefgh.
- Make sure that all passwords are protected and inaccessible to unauthorized personnel.
- Do not use the same password for different users and systems or after it has expired.

## Keys and certificates

This section deals with the security keys and certificates you require to set up HTTPS (HyperText Transfer Protocol Secured Socket Layer).

- We strongly recommend that you create your own HTTPS certificates and make them available.

There are preset certificates and keys on the device. The preset and automatically created HTTPS certificates are self-signed.

We recommend that you use HTTPS certificates signed either by a reliable external or by an internal certification authority. The HTTPS certificate checks the identity of the device and controls the encrypted data exchange. You can install the HTTPS certificate via the WBM (System > Load and Save).

- Handle user-defined private keys with great caution if you use user-defined SSH or SSL keys.
- Use the certification authority including key revocation and management to sign the certificates.
- Verify certificates and fingerprints on the server and client to avoid "man in the middle" attacks.
- We recommend that you use certificates with a key length of 2048 bits.
- Change keys and certificates immediately, if there is a suspicion of compromise.

## Secure/non-secure protocols and services

- Avoid and disable non-secure protocols, for example Telnet and TFTP. For historical reasons, these protocols are still available, however not intended for secure applications. Use non-secure protocols on the device with caution.
- Check whether use of the following protocols and services is necessary:
  - Non-authenticated and unencrypted ports
  - LLDP
  - Syslog
  - DHCP options 66/67
  - TFTP
- The following protocols provide secure alternatives:
  - SNMPv1/v2 → SNMPv3  
Check whether use of SNMPv1 is necessary. SNMPv1 is classified as non-secure. Use the option of preventing write access. The product provides you with suitable setting options.  
If SNMP is enabled, change the community names. If no unrestricted access is necessary, restrict access with SNMP.  
Use SNMPv3 in conjunction with passwords.
  - HTTP → HTTPS
  - Telnet → SSH
- Use secure protocols when access to the device is not prevented by physical protection measures.
- To prevent unauthorized access to the device or network, take suitable protective measures against non-secure protocols.
- If you require non-secure protocols and services, operate the device only within a protected network area.
- Restrict the services and protocols available to the outside to a minimum.
- For the DCP function, enable the "Read Only" mode after commissioning.

## Available protocols per port

The following list provides you with an overview of the open ports on this device.

The table includes the following columns:

- **Protocol**

All protocols that the device supports

- **Port number**

Port number assigned to the protocol

- **Port status**

- Open

The port is always open and cannot be closed.

- Open (when configured)

The port is open if it has been configured.

- **Factory setting**

- Open

The factory setting of the port is "Open".

- Closed

The factory setting of the port is "Closed".

- **Authentication**

Specifies whether the protocol authenticates the communications partner during access.

Protocol	Port number	Port status	Factory setting of the port	Authentication
SSH	TCP/22	Open (when configured)	Open	Yes
TELNET	TCP/23	Open (when configured)	Open	Yes
HTTP	TCP/80	Open (when configured)	Open	Yes
HTTPS	TCP/443	Open (when configured)	Open	Yes
SNTP NTP	UDP/123	Open (when configured)	Closed	No
SNMP	UDP/161	Open (when configured)	Open	Yes
PROFINET	UDP/34964, UDP/49154, 49155	Open	Open	No
Syslog	UDP/514	Open (when configured)	Open	No
EtherNet/IP	TCP/44818, UDP/2222,44818	Open (when configured)	Open	No
DHCP	UDP/67,68	Open (when configured)	Closed	No
RADIUS	UDP/1812,1813	Open (when configured)	Closed	No
TFTP	UDP/69	Open (when configured)	Closed	No



## Technical basics

### 4.1 Configuration limits for WBM and CLI

#### Configuration limits of the device

The following table lists the configuration limits for Web Based Management and the Command Line Interface of the device.

Depending on your device, some functions are not available.

	Configurable function		Maximum number
<b>System</b>	Syslog server		3
	DNS server	manual (IPv4/IPv6)	3
		learned (IPv4/IPv6)	2
		in total	7
	SMTP server		3
	SNMPv1 trap recipient		10
	SNTP server		2
	NTP server		1
	DHCP pools		1
	IPv4 addresses managed by the DHCP server (dynamic + static)		100
	DHCP static assignments per DHCP pool		20
	DHCP options		20
<b>Inter-faces</b>	Force destination addresses for roaming		10
	Connected clients per VAP		126
<b>Layer 2</b>	Virtual LANs (port-based; including VLAN 1)		16
	Multiple Spanning Tree instances		16

4.1 Configuration limits for WBM and CLI

	Configurable function	Maximum number
<b>Security</b>	IP addresses from RADIUS servers	<ul style="list-style-type: none"> <li>• AAA: 4</li> <li>• WLAN: 2</li> </ul>
	Management ACLs (access rules for management)	10
	MAC ACL rule configuration	20
	Ingress and egress rules for MAC ACL (total)	40 per interface (20 ingress rules / 20 egress rules) <ul style="list-style-type: none"> <li>• Client: 80 (P1, WLAN)</li> <li>• Access point: 680 (P1, WDS 1.Y, VAP 1.Y)</li> </ul>
	IP ACL rule configuration	20
	Ingress and egress rules for port ACL IP (total)	40 per interface (20 ingress rules / 20 egress rules) <ul style="list-style-type: none"> <li>• Client: 120 (P1, WLAN, management VLAN)</li> <li>• Access point: 720 (P1, WDS 1.Y, VAP 1.Y, management VLAN)</li> </ul>
	User roles	28
	User groups	32
	Users	28

## 4.2 Interfaces and system functions

### Availability of the interfaces

The following table shows the availability of the physical and logical interfaces. Note that in this table all interfaces are listed. Depending on the system function, some interfaces are not available. On the WBM pages you can only select the available interfaces.

We reserve the right to make technical changes.

	<b>Client device</b> SCALANCE W734-1 RJ-45 SCALANCE W738-1 M12	<b>Access points</b> SCALANCE W774-1 RJ45 SCALANCE W774-1 M12 EEC SCALANCE W778-1 M12 SCALANCE W778-1 M12 EEC
Wireless interface (WLAN)	WLAN 1	WLAN 1
IP interface: LAN interface VLAN	P1 ManagementVLAN	P1 ManagementVLAN
VAP interface <sup>1)</sup>	-	VAP 1.Y Y = 1 ... 8
WDS interface <sup>1)</sup>	—	WDS 1.Y Y = 1 ... 8
VLAN	16	16

<sup>1)</sup> only in access point mode

### Availability of the system functions

The following table shows the availability of the system functions on the devices. Note that all functions are described in this configuration manual and in the online help. Depending on the mode and the KEY-PLUG, some functions are not available.

We reserve the right to make technical changes.

			Access point mode	Access points in client mode Client devices
Information	Security	Inter AP blocking	✓ W780 iFeatures (MLFB 6GK5 907-8PA00) W700 Security (MLFB 6GK5907-0PA00)	-
	WLAN	Overview AP	✓	-
		Client List	✓	-
		WDS List	✓	-
		Overlap AP	✓	-
		Force Roaming	✓	-
		Overview Client	-	✓
		Available AP	-	✓
		IP Mapping	-	✓
	WLAN Statistics	Faults	✓	✓
		Management Sent	✓	✓
		Management Received	✓	✓
		Data Sent	✓	✓
		Data Received	✓	✓
	WLAN iFeatures	iREF Client List	✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	-
		iREF WDS List	✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	-
		AeroScout	✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	-
System		PROFINET	✓	-✓
		EtherNet/IP	✓	✓

			Access point mode	Access points in client mode Client devices
<b>Interfaces</b>	<b>WLAN</b>	Basic	✓	~✓
		Expansions	✓	✓
		Antennas	✓	✓
		Allowed Channels	✓	✓
		802.11n	✓	✓
		AP	✓	-
		AP WDS	✓	-
		AP 802.11a/b/g Rates	✓	-
		AP 802.11n Rates	✓	-
		Client 802.11a/b/g Rates	-	✓
		Client 802.11n Rates	-	✓
		Force Roaming	✓	✓
		Signal recorder	-	✓
		Spectrum Analyzer	✓	-
<b>Layer 3</b>	<b>NAT</b>	Basic	-	✓
		NAPT	-	✓
<b>Security</b>	<b>WLAN</b>	Basic	✓	✓
		AP Communication	✓	-
		AP RADIUS Authenticator	✓	-
		Client RADIUS Supplicant	-	✓
		Keys	✓	✓
	<b>Inter AP Blocking</b>	Basic	✓ W780 iFeatures (MLFB 6GK5 907-8PA00) W700 Security (MLFB 6GK5907-0PA00)	-
		Allowed Addresses	✓ W780 iFeatures (MLFB 6GK5 907-8PA00) W700 Security (MLFB 6GK5907-0PA00)	-

			Access point mode	Access points in client mode Client devices
iFeatures	IPCF	iPCFv1	✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	✓ Access point in client mode: W780 iFeatures (MLFB 6GK5 907-8PA00) Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
	IPCF-MC		✓ Only dual APs W780 iFeatures (MLFB 6GK5 907-8PA00)	✓ Access point in client mode: W780 iFeatures (MLFB 6GK5 907-8PA00) Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
	IPRP		✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	✓ Access point in client mode: W780 iFeatures (MLFB 6GK5 907-8PA00) Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
	IREF		✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	-
	AeroScout		✓ W780 iFeatures (MLFB 6GK5 907-8PA00)	-

## Support of IPv6

The following system functions do not support IPv6 addresses:

- Inter AP blocking
- Force roaming
- IP ACL

## 4.3 EtherNet/IP

### EtherNet/IP

EtherNet/IP (Ethernet/Industrial Protocol) is an open industry standard for industrial real-time Ethernet based on TCP/IP and UDP/IP. With EtherNet/IP, Ethernet is expanded by the Common Industrial Protocol (CIP) at the application layer. In EtherNet/IP, the lower layers of the OSI reference model are adopted by Ethernet with the physical, network and transport functions.

You configure EtherNet/IP in "System > EtherNet/IP".

### Common Industrial Protocol

The Common Industrial Protocol (CIP) is an application protocol for automation that supports transition of the field buses in Industrial Ethernet and in IP networks. This industry protocol is used by field buses/industrial networks such as DeviceNet, ControlNet and EtherNet/IP at the application layer as an interface between the deterministic fieldbus world and the automation application (controller, I/O, HMI, OPC, ...). The CIP is located above the transport layer and expands the pure transport services with communications services for automation engineering. These include services for cyclic, time-critical and event-controlled data traffic. CIP distinguishes between time-critical I/O messages (implicit messages) and individual query/response frames for configuration and data acquisition (explicit messages). CIP is object-oriented; all data "visible" from the outside is accessible in the form of objects. CIP has a common configuration basis: EDS (Electronic Data Sheet).

### Electronic Data Sheet

Electronic Data Sheet (EDS) is an electronic datasheet for describing devices.

The EDS required for EtherNet/IP operation can be found in "System > Load&Save (Page 189)".

## 4.4 PROFINET

### PROFINET

PROFINET is an open standard (IEC 61158/61784) for industrial automation based on Industrial Ethernet. PROFINET uses existing IT standards and allows end-to-end communication from the field level to the management level as well as plant-wide engineering. PROFINET also has the following features:

- Use of TCP/IP
- Automation of applications with real-time requirements
  - Real-Time (RT) communication
  - Isochronous Real-Time (IRT) communication
- Seamless integration of fieldbus systems

You configure PROFINET in "System > PROFINET (Page 247)".

### PROFINET IO

Within the framework of PROFINET, PROFINET IO is a communications concept for implementing modular, distributed applications. PROFINET IO is implemented by the PROFINET standard for programmable controllers (IEC 61158-x-10).

## 4.5 VLAN

### Network definition regardless of the spatial location of the nodes

VLAN (Virtual Local Area Network) divides a physical network into several logical networks that are shielded from each other. Here, devices are grouped together to form logical groups. Only nodes of the same VLAN can address each other. Since multicast and broadcast frames are only forwarded within the particular VLAN, they are also known as broadcast domains.

The particular advantage of VLANs is the reduced network load for the nodes and network segments of other VLANs.

For the identifier which frame is assigned to which VLAN, the frame is expanded by 4 bytes (VLAN tagging). Apart from the VLAN-ID this expansion also includes priority information.


### Options for the VLAN assignment

There are various options for the assignment to VLANs:

- Port-based VLAN  
Each port of a device is assigned a VLAN ID. You configure port-based VLAN in "Layer 2 > VLAN (Page 320)".
- Protocol-based VLAN  
Each port of a device is assigned a protocol group.
- Subnet-based VLAN  
The IP address of the device is assigned a VLAN ID.

### Doubly tagged frame (Q-in-Q)

There are devices e.g. SCALANCE XR500 that support the Q-in-Q function. With the Q-in-Q function the incoming data traffic is treated as if it were untagged. With frames that are already tagged ①, this means they are expanded by a second VLAN tag, the outer VLAN tag ②.



When a SCALANCE W device receives a doubly tagged frame, it uses the VLAN ID from the outer VLAN tag ②. The frame is then forwarded to the relevant VLAN.

## 4.6 MAC-based communication

Frames sent by the client to the access point always have the MAC address of the WLAN client as the source MAC address. In the "learning table" of the access point there is therefore only the MAC address of the WLAN client.

### MAC mode "Automatic", "Manual" and "Own"

If the MAC address of a device connected to the client is adopted (Automatic) or is set manually (Manual), both the MAC-based and the IP-based frames find their destination for precisely this device. If the MAC address of the Ethernet interface of the WLAN client is used (Own), the MAC-based and IP-based frames only reach the WLAN client.

The access point checks whether the destination MAC address matches the MAC addresses of the connected clients. Since a WLAN client can only use a MAC address, communication at the MAC address level (ISO/OSI layer 2) can be to a maximum of one node downstream from the client or the client itself.

With IP Mapping, several nodes downstream from a client can be addressed based on the IP protocol. The IP packets are broken down according to an internal table and forwarded to the connected devices.

Maximum possible number of Ethernet nodes with layer 2 communication downstream from the client: 1

Notes on the "Automatic" setting:

- As long as there is no link on the Ethernet interface, the device uses the MAC address of the Ethernet interface so that it can be reached in this status. In this status, the device can be found using the Primary Setup Tool and configured with WBM or CLI.
- As soon as there is a link on the Ethernet interface, the device adopts the source MAC address of the first received frame.

---

#### Note

From the moment that the device adopts another MAC address (manually or automatically), the device no longer responds to queries of the Primary Setup Tool when the query is received over the WLAN interface. Queries of the PST over the Ethernet interface continue to be replied to.

---

### MAC mode "Layer 2 Tunnel"

The WLAN client uses the MAC address of the Ethernet interface for the WLAN interface.

The access point is also informed of the MAC addresses connected to the Ethernet interface of the WLAN client. This makes it possible to enter the MAC addresses of these devices in the "learning table" of the access point. The access point can forward MAC-based frames for the devices downstream from the client to the appropriate client.

In much the same way as with WDS, a separate port is created for the L2T client over which the Ethernet frames are sent without changing the destination MAC address.

Maximum possible number of Ethernet nodes downstream from the client: 8

## 4.7 iPCF / iPCF-HT / iPCF-MC

The wireless range of an IWLAN system can be expanded by using multiple access points. If a client moves from the area covered by one access point to the area covered by another access point, the wireless link is maintained after a short interruption (roaming).

If very fast update times are required, for example for PROFINET communication, access points and client modules need to be used that use the proprietary methods iPCF / iPCF-HT or iPCF-MC for fast roaming and deterministic data traffic.

iPCF / iPCF-HT / iPCF-MC can only be operated alone. A combination with each other is not possible, e.g. iPCF with iPCF-HT or iPCF-MC.

### How it works

#### iPCF

With iPCF the access point checks all nodes in the wireless cell cyclically. At the same time, the scan includes the downlink traffic for this node. In the reply, the node sends the uplink data. The access point scans a new node at least every 5 ms.

The scan of a node is seen by all other nodes in the cell. This allows a client to detect the quality of the wireless link to the access point even when it is not communicating with the access point itself. If the client does not receive any frames from the access point for a certain time, it starts to search for a new access point.

In iPCF mode, both the search for a new access point and the registration with this access point have been optimized in terms of time. Handover times significantly below 50 ms are achieved.

The "Legacy Free (iPCF-LF)" setting is available to prevent the performance from being slowed down by the IEEE 802.11 a/b/g device generation. When enabled, only the devices that communicate with the IEEE 802.11n standard and have the "Legacy Free (iPCF-LF)" setting enabled are accepted. WLAN mode IEEE 802.11n need not be enabled for this, however.

Stable PROFINET communication is only possible when a WLAN client is in a wireless cell with more than 60 % or -65 dBm signal strength at all times. This can be checked by activating and deactivating the various wireless cells.

This does not mean that the client needs to change when there is a signal strength < 60 % (< -65 dBm). Make sure that access points are available with adequate signal strength.

You configure iPCF in "iFeatures > iPCF > iPCF (Page 396)".

#### iPCF-HT

If a higher data throughput is required for iPCF, iPCF-HT is used. With this you can, for example, alongside PROFINET also transfer video data. This is achieved by more effective transfer of data packets using frame-bursting (A-MPDU). The individual data packets are grouped together that are intended for the same receiver station (client) and that have the same prioritization.

You configure iPCF-HT in "iFeatures > iPCF > iPCF-HT (Page 400)".

#### iPCF-MC

For freely moving nodes that communicate independently of a RCoax cable or directional antennas, iPCF-MC should be used. With iPCF-MC, the client also searches for potentially


suitable access points when it receives iPCF queries from the access point and the existing connection to an access point is working problem-free. This means that if a change to a different access point is necessary, this is achieved extremely quickly. In contrast to iPCF, the handover times for iPCF-MC are not dependent on the number of wireless channels being used.

It is necessary to use an access point with two wireless interfaces a so-called dual access point. The one interface operates as management channel and sends short frames (beacons) with administrative information (e.g. channel setting of the data channel and SSID). The other interface (data channel) exclusively transfers the user data.

The "Legacy Free (iPCF-LF)" setting is available to prevent the performance from being slowed down by the IEEE 802.11 a/b/g device generation. When enabled, only the devices that communicate with the IEEE 802.11n standard and have the "Legacy Free (iPCF-LF)" setting enabled are accepted. WLAN mode IEEE 802.11n need not be enabled for this, however.

You configure iPCF-MC in "iFeatures > iPCF > iPCF-MC (Page 404)".

The following graphic shows a configuration example for iPCF-MC.



## Restrictions

- iPCF / iPCF-HT and iPCF-MC are developments of Siemens AG and function only with nodes on which iPCF / iPCFv2 / iPCF-MC is implemented.
- With an access point with several WLAN interfaces, it is possible to use both iPCF / iPCF-HT as well as standard WLAN at the same time.
- Access points with a WLAN interface cannot take part in the iPCF-MC procedures, iPCF is, however, possible.
- iPCF-HT is available only on WLAN interface 1 and can only be used in the 5 GHz band with WLAN mode "(only) IEEE 802.11n".

## Requirements for iPCF-MC

iPCF-MC uses the two wireless interface of the access point in different ways: One interface works as the management interface and sends a beacon every five milliseconds. The other interface transfers the user data.

The following requirements must be met before you can use iPCF-MC:

- Only SCALANCE W700 devices with two WLAN interfaces can be used as access points
- The data interface (WLAN1) and management interface (WLAN2) must be operated in the same frequency band and must match in terms of their wireless coverage. iPCF-MC will not work if the two wireless interfaces are equipped with directional antennas that cover different areas.
- The management interfaces of all access points to which a client can change must use the same channel. A client scans only this one channel to find accessible access points.
- Transmission based on IEEE 802.11h (DFS) cannot be used for the management interface. 802.11h (DFS) is possible for the data interface.
- A client must support this feature on its WLAN interface.

## 4.8 iREF

### How it works

If an access point has several activated antennas, the transmit power is distributed equally on these antennas. The transmit power is subject to country-specific legal restrictions. The maximum permitted power depends on the gain of the connected antennas. If the connected antennas have different gains, the maximum antenna gain effectively restricts the permitted transmit power.

iREF (industrial Range Extension Function) ensures that the data traffic from the access point to each individual client is handled via the most suitable antenna. Which antenna is most suitable is determined by the access point based on the RSSI values of received packets.


Taking into account antenna gain and possible cable losses, packets are only sent via the antennas with which the maximum signal strength at the client end can be expected.

During this time the other antennas are inactive and the legally permitted transmit power is available for the selected antenna. The inactive antennas do not restrict the permitted transmit power.


In particular in applications in which MIMO cannot be used or brings no advantage, this allows data to be transmitted at the highest possible data transmission rate.

You configure iREF in "iFeatures > iREF (Page 411)"

without iREF



where iREF



### Requirement

- To be able to use iREF, the SCALANCE W700 device must have at least 2 activated antennas.

### Restrictions

- A maximum data rate of only up to 150 Mbps (MCS 0 - 7 or 1 x spatial stream) is possible
- iREF cannot be used along with other iFeatures (for example iPCF or iPCF-MC)

### Advantages

- Due to the directional data transmission and dynamic deactivation of antennas that do not radiate in the direction of the particular client, interference can be reduced.
- The signal strength is improved because the active antenna always has the maximum permitted transmit power available.

## 4.9 iPRP

The "Parallel Redundancy Protocol" (PRP) is a redundancy protocol for cabled networks. It is defined in Part 3 of the IEC 62439 standard.


With the "industrial Parallel Redundancy Protocol" (iPRP) the PRP technology can be used in wireless networks. This improves the availability of wireless communication.

### How it works

A PRP network consists of two completely independent networks. If one network is disrupted, the frames are sent without interruption/reconfiguration via the parallel redundant network. To achieve this the Ethernet frames are sent to the recipient in duplicate via both networks. Devices capable of PRP have at least two separate Ethernet interfaces that are connected to independent networks.

With devices not capable of PRP a redundancy box (RedBox) is connected upstream. This allows access for so-called Single Attached Nodes (SAN) to PRP networks. The RedBox duplicates every Ethernet frame to be sent and adds a PRP trailer to the frame that among other things contains a sequence number. The RedBox simultaneously sends a copy of the frame to the PRP A and PRP B network. At the receiving end the duplicate frame is discarded by the RedBox. For this the RedBox requires certain transfer times designed for Ethernet networks. For this reason using PRP in WLAN networks results in duplicate and delayed frames.

With iPRP this problem is solved and the use of PRP in WLAN with SCALANCE W700 devices becomes possible



The access points (AP 1, AP 2 and AP 3) and the RedBox at the AP end are connected to each other via a switch. PRP network A und B are separated from each other via VLANs.

If SAN1 sends a frame to SAN2, the frame is duplicated by the RedBox at the AP end and the two redundant frames are transferred via the switch to the access points. Via the two different wireless paths the redundant PRP frames are transferred to the RedBox at the client end. The clients are also connected to their RedBox via a switch. This forwards the first PRP frame to arrive to SAN2 and discards the second one.

### Note

On the interfaces of the switches to the SCALANCE W700 devices, only the VLANs that are also set on the VAP or WLAN interfaces of the SCALANCE W700 devices may be configured.

With iPRP the redundant partners (here: AP1 and AP3 or client A and client B) communicate with each other via a switch to prevent the two redundant PRP frames from arriving at the RedBox with too great a time difference.

If for example the communication between AP1 and client A is very slow, the slower frame is discarded at the receiving end.

You configure iPRP in "iFeatures > iPRP".

**Requirement**

- The base bridge mode "802.1Q VLAN Bridge" is set.
- The VLANs have been created.
- Access point mode: The VAP interface is enabled.
- Client mode: In MAC mode "Layer 2 Tunnel" is set.
- Depending on the configuration the clients can communicate with every access point.

## 4.10 AeroScout

### AeroScout tags

SCALANCE W700 devices support tags of the AeroScout company. Tags are battery-operated RFID sensors that send their data cyclically as multicast frames.

Among other things, AeroScout tags have the following features:

- **Ambient temperature**

If a tag is fitted to a SCALANCE W700 device or material, it is possible to monitor whether a selected ambient temperature is being maintained.

- **Motion**

Here, a tag can also supply information indicating whether it is in motion or stationary. The areas of material flow and material handling engineering represent possible applications for this function.

- **Button**

Regardless of the frames sent cyclically, a user can also send a message by pressing a button.

- **LED**

This provides information on the operating status of the tag.

---

**Note**

For more detailed information, please refer to the AeroScout documentation ([www.aeroscout.com](http://www.aeroscout.com)).

---

### How it works

The tag sends its data as AeroScout frames. The tags and the access points communicate in the 2.4 GHz band.

If the WLAN interface of the access point receives the AeroScout frame, this is converted into a UDP datagram. The SCALANCE W700 device forwards the UDP datagram along with the information about the signal strength (RSSI) to a PC. The AeroScout Engine runs on the PC and evaluates the received information.

---

**Note**

It is **not** advisable to use PROFINET communication and AeroScout together on one wireless interface.

---

### **Accuracy of localization**

To achieve optimum precision in the localization of AeroScout Tags,

- we recommend the use of antennas with omnidirectional characteristics
- if the signals should be received by at least three access points.

## 4.11 NAT/NAPT

### What is NAT?

With Network Address Translation (NAT), the IPv4 address in a data packet is replaced by another. NAT is normally used on a gateway between a private LAN and an external network with globally valid IPv4 addresses. A local IPv4 address of the internal LAN is changed to an external global IPv4 address by a NAT device at the gateway.

To translate the internal into the global IPv4 address, the NAT device maintains a translation list. The address assignment is automatic. You configure the address assignment in "Layer 3 > NAT > Basic (Page 339)".

### What is NAPT?

In "Network Address Port Translation" (NAPT) or "Port Address Translation" (PAT), several internal source IPv4 addresses are translated into the same external source IPv4 address. To identify the individual source nodes, the port of the source device is also stored in the translation list of the NAT gateway and translated for the external address.

If several local clients send a query to the same external destination IPv4 address via the NAT gateway, the gateway enters its own external source IPv4 address in the header of these data packets. Since the forwarded data packets have the same global source IPv4 address, the NAT gateway assigns the data packets to the clients using different port number.

---

#### Note

NAT/NAPT is possible only on layer 3 of the ISO/OSI reference model. To use the NAT function, the networks must use the IP protocol.

When using the ISO protocol that operates at layer 2, it is not possible to use NAT.

---

If a client from the global network wants to use a service in the internal network, the translation list for the static address assignment needs to be configured. You configure the translation list for NAPT in "Layer 3 > NAT > NAPT (Page 342)".

## 4.12 SNMP

### Introduction

With the aid of the Simple Network Management Protocol (SNMP), you monitor and control network components from a central station, for example routers or switches. SNMP controls the communication between the monitored devices and the monitoring station.

Tasks of SNMP:

- Monitoring of network components
- Remote control and remote parameter assignment of network components
- Error detection and error notification

In versions v1 and v2c, SNMP has no security mechanisms. Each user in the network can access data and also change parameter assignments using suitable software.

For the simple control of access rights without security aspects, community strings are used.

The community string is transferred along with the query. If the community string is correct, the SNMP agent responds and sends the requested data. If the community string is not correct, the SNMP agent discards the query. Define different community strings for read and write permissions. The community strings are transferred in plain text.

Standard values of the community strings:

- public  
has only read permissions
- private  
has read and write permissions

---

#### Note

Because the SNMP community strings are used for access protection, do not use the standard values "public" or "private". Change these values following the initial commissioning.

---

Further simple protection mechanisms at the device level:

- Allowed Host  
The IP addresses of the monitoring systems are known to the monitored system.
- Read Only  
If you assign "Read Only" to a monitored device, monitoring stations can only read out data but cannot modify it.

SNMP data packets are not encrypted and can easily be read by others.

The central station is also known as the management station. An SNMP agent is installed on the devices to be monitored with which the management station exchanges data.

The management station sends data packets of the following type:

- GET  
Request for a data record from the SNMP agent
- GETNEXT  
Calls up the next data record.
- GETBULK (available as of SNMPv2c)  
Requests multiple data records at one time, for example several rows of a table.
- SET  
Contains parameter assignment data for the relevant device.

The SNMP agent sends data packets of the following type:

- RESPONSE  
The SNMP agent returns the data requested by the manager.
- TRAP  
If a certain event occurs, the SNMP agent itself sends traps.

SNMPv1/v2c/v3 use UDP (User Datagram Protocol) and use the UDP ports 161 and 162. The data is described in a Management Information Base (MIB).

## SNMPv3

Compared with the previous versions SNMPv1 and SNMPv2c, SNMPv3 introduces an extensive security concept.

SNMPv3 supports:

- Fully encrypted user authentication
- Encryption of the entire data traffic
- Access control of the MIB objects at the user/group level

With the introduction of SNMPv3 you can no longer transfer user configurations to other devices without taking special action, e.g. by loading a configuration file or replacing the C-PLUG.

According to the standard, the SNMPv3 protocol uses a unique SNMP engine ID as an internal identifier for an SNMP agent. This ID must be unique in the network. It is used to authenticate access data of SNMPv3 users and to encrypt it.

Depending on whether you have enabled or disabled the "SNMPv3 User Migration" function, the SNMP engine ID is generated differently.

### Restriction when using the function

Use the "SNMPv3 User Migration" function only to transfer configured SNMPv3 users to a substitute device when replacing a device.

Do not use the function to transfer configured SNMPv3 users to multiple devices. If you load a configuration with created SNMPv3 users on several devices, these devices use the same SNMP engine ID. If you use these devices in the same network, your configuration contradicts the SNMP standard.

**Compatibility with predecessor products**

You can only transfer SNMPv3 users to a different device if you have created the users as migratable users. To create a migratable user the "SNMPv3 User Migration" function must be activated when you create the user.

## 4.13 Spanning Tree

### Avoiding loops

The Spanning Tree algorithm detects redundant physical network structures and prevents the formation of loops by disabling redundant paths. It evaluates the distance and performance of a connection or bases the decisions on settings made by the user. Data is then exchanged only over the remaining connection paths.

If the preferred data path fails, the Spanning Tree algorithm then searches for the most efficient path possible with the remaining nodes.

### Root bridge and bridge priority

The identification of the most efficient connection is always related to the root bridge, a network component that can be considered as a root element of a tree-like network structure. With the "Bridge Priority" parameter, you can influence the selection of the root bridge. The computer with the lowest value set for this parameter automatically becomes the root bridge. If two computers have the same priority value, the computer with the lower MAC address becomes the root bridge.

### Response to changes in the network topology

If nodes are added to a network or drop out of the network, this may affect the optimum path selection for data packets. To be able to respond to such changes, the root bridge sends configuration messages (BPDUs) at regular intervals. You can set the interval between two configuration messages with the "Hello Time" parameter.

### Keeping configuration information up to date

With the "Max Age" parameter, you set the maximum age of configuration information. If a bridge has information that is older than the time set in Max Age, it discards the message and initiates recalculation of the paths.

New configuration data is not used immediately by a bridge but only after the period specified in the "Forward Delay" parameter. This ensures that operation is started with the new topology only after all the bridges have the required information.

## 4.13.1 RSTP, MSTP, CIST

### Rapid Spanning Tree Protocol (RSTP)

One disadvantage of STP is that if there is a disruption or a device fails, the network needs to reconfigure itself: The devices start to negotiate new paths only when the interruption occurs. This can take up to 30 seconds. For this reason, STP was expanded to create the "Rapid Spanning Tree Protocol" (RSTP, IEEE 802.1w). This differs from STP essentially in that the devices are already collecting information about alternative routes during normal operation and do not need to gather this information after a disruption has occurred. This means that the reconfiguration time for an RSTP controlled network can be reduced to a few seconds.

This is achieved by using the following functions:

- Edge ports (end node port)  
Edge ports are ports connected to an end device.  
A port that is defined as an edge port is activated immediately after connection establishment. If a spanning tree BPDU is received at an edge port, the port loses its role as edge port and it takes part in (R)STP again. If no further BPDU is received after a certain time has elapsed (3 x hello time), the port returns to the edge port status.
- Point-to-point (direct communication between two neighboring devices)  
By directly linking the devices, a status change (reconfiguration of the ports) can be made without any delays.
- Alternate port (substitute for the root port)  
A substitute for the root port is configured. If the connection to the root bridge is lost, the device can establish a connection over the alternate port without any delay due to reconfiguration.
- Reaction to events  
Rapid spanning tree reacts to events, for example an aborted connection, without delay. There is no waiting for timers as in spanning tree.
- Counter for the maximum bridge hops  
The number of bridge hops a package is allowed to make before it automatically becomes invalid.

In principle, therefore with rapid spanning tree, alternatives for many parameters are preconfigured and certain properties of the network structure taken into account to reduce the reconfiguration time.

### **Multiple Spanning Tree Protocol (MSTP)**

The Multiple Spanning Tree Protocol (MSTP) is a further development of the Rapid Spanning Tree Protocol. Among other things, it provides the option of operating several RSTP instances within different VLANs or VLAN groups and, for example, making paths available within the individual VLANs that the single Rapid Spanning Tree Protocol would globally block.

### **Common and Internal Spanning Tree (CIST)**

CIST identifies the internal instance used by the switch that is comparable in principle with an internal RSTP instance.

## 4.14 User management

### Overview of user management

Access to the device is managed by configurable user settings. Set up users with a password for authentication. Assign a role with suitable rights to the users.

The authentication of users can either be performed locally by the device or by an external RADIUS server. You configure how the authentication is handled on the "Security > AAA > General" page.

### Local logon

The local logging on of users by the device runs as follows:

1. The user logs on with user name and password on the device.
2. The device checks whether an entry exists for the user.
  - If an entry exists, the user is logged in with the rights of the associated role.
  - If no corresponding entry exists, the user is denied access.

### Login via an external RADIUS server

RADIUS (Remote Authentication Dial-In User Service) is a protocol for authenticating and authorizing users by servers on which user data can be stored centrally.

Depending on the RADIUS authorization mode you have selected on the "Security > AAA > RADIUS Client" page, the device evaluates different information of the RADIUS server.

#### **RADIUS authorization mode "Standard"**

If you have set the authorization mode "conventional", the authentication of users via a RADIUS server runs as follows:

1. The user logs on with user name and password on the device.
2. The device sends an authentication request with the login data to the RADIUS server.
3. The RADIUS server runs a check and signals the result back to the device.
  - The RADIUS server reports a successful authentication and returns the value "Administrative User" to the device for the attribute "Service Type".
    - The user is logged in with administrator rights.
  - The RADIUS server reports a successful authentication and returns a different or even no value to the device for the attribute "Service Type".
    - The user is logged in with read rights.
  - The RADIUS server reports a failed authentication to the device:
    - The user is denied access.

#### **RADIUS authorization mode "SiemensVSA"**

##### **Requirement**

For the RADIUS authorization mode "Siemens VSA" the following needs to be set on the RADIUS server:

- Manufacturer code: 4196
- Attribute number: 1
- Attribute format: Character string (group name)

#### Procedure

If you have set the authorization mode "SiemensVSA", the authentication of users via a RADIUS server runs as follows:

1. The user logs on with user name and password on the device.
2. The device sends an authentication request with the login data to the RADIUS server.
3. The RADIUS server runs a check and signals the result back to the device.

**Case A:** The RADIUS server reports a successful authentication and returns the group assigned to the user to the device.

- The group is known on the device and the user is not entered in the table "External User Accounts"
  - The user is logged in with the rights of the assigned group.
- The group is known on the device and the user is entered in the table "External User Accounts"
  - The user is assigned the role with the higher rights and logged in with these rights.
- The group is not known on the device and the user is entered in the table "External User Accounts"
  - The user is logged in with the rights of the role linked to the user account.
- The group is not known on the device and the user is not entered in the table "External User Accounts"
  - The user is logged in with the rights of the role "Default".

**Case B:** The RADIUS server reports a successful authentication but does not return a group to the device.

- The user is entered in the table "External User Accounts":
  - The user is logged in with the rights of the linked role "".
- The user is not entered in the table "External User Accounts":
  - The user is logged in with the rights of the role "Default".

**Case C:** The RADIUS server reports a failed authentication to the device:

- The user is denied access.

# IP addresses

## 5.1 IPv4 / IPv6

What are the essential differences?

	IPv4	IPv6
IP configuration	<ul style="list-style-type: none"> <li>DHCP server</li> <li>Manual</li> </ul>	<ul style="list-style-type: none"> <li>Stateless Address Autoconfiguration (SLAAC): Stateless autoconfiguration using NDP (Neighbor Discovery Protocol)               <ul style="list-style-type: none"> <li>Creates a link local address for every interface that does not require a router on the link.</li> <li>Checks the uniqueness of the address on the link that requires no router on the link.</li> <li>Specifies whether the global addresses are obtained via a status-free mechanism, a mechanism with status or via both mechanisms. (Requires a router on the link.)</li> </ul> </li> <li>Manual</li> <li>DHCPv6 (status dependent)</li> </ul>
Available IP addresses	32-bit: $4,294,967,296$ addresses	128-bit: $3,402,823,669,209,384,639,693,996,766,900,000,000,000,000,000$ addresses
Address format	Decimal: 192.168.1.1 with port: 192.168.1.1:20	Hexadecimal: 2a00:ad80::0123 with port: [2a00:ad80::0123]:20
Loopback	127.0.0.1	::1
IP addresses of the interface	4 IP addresses	Multiple IP addresses <ul style="list-style-type: none"> <li>LLA: A link local address (formed automatically) fe80::/128 per interface</li> <li>ULA: Several unique local unicast addresses per interface</li> <li>GUA: Several global unicast addresses per interface</li> </ul>
Header	<ul style="list-style-type: none"> <li>Checksum</li> <li>Variable length</li> <li>Fragmentation in the header</li> <li>No security</li> </ul>	<ul style="list-style-type: none"> <li>Checking at a higher layer</li> <li>Fixed size</li> <li>Fragmentation in the extension header</li> </ul>
Fragmentation	Host and router	Only endpoint of the communication
Quality of service	Type of Service (ToS) for prioritization	The prioritization is specified in the header field "Traffic Class".
Types of frame	Broadcast, multicast, unicast	Multicast, unicast, anycast

	IPv4	IPv6
Identification of DHCP clients/server	Client ID: MAC address	DUID + IAID(s) = exactly one interface of the host DUID = DHCP unique identifier Identifies server and clients uniquely and should not change, not even when replacing network components! IAID = Identity Association Identifier At least one per interface is generated by the client and remains unchanged when the DHCP client restarts Three methods of obtaining the DUID <ul style="list-style-type: none"> <li>• DUID-LLT</li> <li>• DUID-EN</li> <li>• DUID-LL</li> </ul>
DHCP	via UDP with broadcast	via UDP with unicast RFC 3315, RFC 3363 <b>Stateful DHCPv6</b> Status-dependent configuration in which the IPv6 address and the configuration settings are transferred. Four DHCPv6 messages are exchanged between client and server: <ol style="list-style-type: none"> <li>1. SOLICIT: Sent by the DHCPv6 client to localize DHCPv6 servers.</li> <li>2. ADVERTISE The available DHCPv6 servers reply to this.</li> <li>3. REQUEST The DHCPv6 client requests an IPv6 address and the configuration settings from the DHCPv6 server.</li> <li>4. REPLY The DHCPv6 server sends the IPv6 address and the configuration settings.</li> </ol> If the client and server support the function "Rapid commit" the procedure is shortened to two DHCPv6 messages SOLICIT and REPLY . <b>Stateless DHCPv6</b> In stateless DHCPv6, only the configuration settings are transferred. <b>Prefix delegation</b> The DHCPv6 server delegates the distribution of IPv6 prefixes to the DHCPv6 client. The DHCPv6 client is also known as PD router.
Resolution of IP addresses in hardware addresses	ARP (Address Resolution Protocol)	NDP (Neighbor Discovery Protocol)

## 5.2 IPv4 address

### 5.2.1 Structure of an IPv4 address

#### Address classes

IP address range	Max. number of networks	Max. number of hosts/network	Class	CIDR
1.x.x.x through 126.x.x.x	126	16777214	A	/8
128.0.x.x through 191.255.x.x	16383	65534	B	/16
192.0.0.x through 223.255.255.x	2097151	254	C	/24
224.0.0.0 - 239.255.255.255	Multicast applications		D	
240.0.0.0 - 255.255.255.255	Reserved for future applications		E	

An IP address consists of 4 bytes. Each byte is represented in decimal, with a dot separating it from the previous one. This results in the following structure, where XXX stands for a number between 0 and 255:

XXX.XXX.XXX.XXX

The IP address is made up of two parts, the network ID and the host ID. This allows different subnets to be created. Depending on the bytes of the IP address used as the network ID and those used for the host ID, the IP address can be assigned to a specific address class.

#### Subnet mask

The bits of the host ID can be used to create subnets. The leading bits represent the address of the subnet and the remaining bits the address of the host in the subnet.

A subnet is defined by the subnet mask. The structure of the subnet mask corresponds to that of an IP address. If a "1" is used at a bit position in the subnet mask, the bit belongs to the corresponding position in the IP address of the subnet address, otherwise to the address of the computer.

Example of a class B network:

The standard subnet address for class B networks is 255.255.0.0; in other words, the last two bytes are available for defining a subnet. If 16 subnets must be defined, the third byte of the subnet address must be set to 11110000 (binary notation). In this case, this results in the subnet mask 255.255.240.0.

To find out whether two IP addresses belong to the same subnet, the two IP addresses and the subnet mask are ANDed bit by bit. If both logic operations have the same result, both IP addresses belong to the same subnet, for example, 141.120.246.210 and 141.120.252.108.

Outside the local area network, the distinction between network ID and host ID is of no significance, in this case packets are delivered based on the entire IP address.

---

**Note**

In the bit representation of the subnet mask, the "ones" must be set left-justified; in other words, there must be no "zeros" between the "ones".

---

## 5.2.2 Initial assignment of an IPv4 address

### Configuration options

An initial IP address for a SCALANCE W device cannot be assigned using Web Based Management (WBM) or the Command Line Interface (CLI) over Telnet because these configuration tools require that an IP address already exists.

The following options are available to assign an IP address to an unconfigured device currently without an IP address:

- DHCP (default)
- Primary Setup Tool
- STEP 7
- NCM PC

---

**Note**

When the product ships and following "Restore Memory Defaults and Restart", DHCP is enabled. If a DHCP server is available in the local area network, and this responds to the DHCP request of a SCALANCE W700, the IP address, subnet mask and gateway are assigned automatically when the device first starts up. "Restore Factory Defaults and Restart" does not delete an IP address assigned either by DHCP or by the user.

---

### 5.2.3 Address assignment via DHCPv4

#### Properties of DHCP

DHCP (Dynamic Host Configuration Protocol) is a method for automatic assignment of IP addresses. It has the following characteristics:

- DHCP can be used both when starting up a device and during ongoing operation.
- The assigned IP address remains valid only for a limited time known as the lease time. When half the period of validity has elapsed, the DHCP client can extend the period of the assigned IPv4 address. When the entire time has elapsed, the DHCP client needs to request a new IPv4 address.
- There is normally no fixed address assignment; in other words, when a client requests an IP address again, it normally receives a different address from the previous address. It is possible to configure the DHCP server so that the DHCP client always receives the same fixed address in response to its request. The parameter with which the DHCP client is identified for the fixed address assignment is set on the DHCP client. The address can be assigned via the MAC address, the DHCP client ID, PROFINET device name or the device name. You configure the parameter in "System > DHCP Client".
- The following DHCP options are supported:
  - DHCP option 3: Assignment of a router address
  - DHCP option 6: Assignment of a DNS server address
  - DHCP option 66: Assignment of a dynamic TFTP server name
  - DHCP option 67: Assignment of a dynamic boot file name

---

#### Note

DHCP uses a mechanism with which the IP address is assigned for only a short time (lease time). If the device does not reach the DHCP server with a new request on expiry of the lease time, the assigned IP address, the subnet mask and the gateway continue to be used.

The device therefore remains accessible under the last assigned IP address even without a DHCP server. This is not the standard behavior of office devices but is necessary for problem-free operation of the plant.

---

## 5.2.4 Address assignment with the Primary Setup Tool

### Introduction

The PST (Primary Setup Tool) is capable of assigning such an address to unconfigured devices that do not yet have an IP address.

### Requirement

The devices can be reached via Ethernet.

---

#### Note

For more detailed information, refer to the Primary Setup Tool configuration manual.

You will find the PST at Siemens Industry Automation and Drives Service & Support on the Internet under the entry ID 19440762. You can access this entry at the following URL: PSTTool (<https://support.industry.siemens.com/cs/ww/en/view/19440762>)

---

## 5.2.5 Address assignment with STEP 7

In STEP 7, you can configure the topology, the device name and the IP address; in other words, an IP address is specified for the MAC address of the device. If you connect the unconfigured device to the controller, the controller assigns the configured device name and the IP address to the device automatically.

### STEP 7 V5.x and earlier

For further information on the assignment of the IP address using STEP 7 V5.x and earlier, refer to the documentation "Configuring Hardware and Communication Connections STEP 7", in the section "Steps for Configuring a PROFINET IO System".

### STEP 7 as of V13

For further information on assigning the IP address using STEP 7 as of V13, refer to the online help "Information system", section "Addressing PROFINET devices".

## **5.3 IPv6 address**

### **5.3.1 IPv6 terms**

#### **Network node**

A network node is a device that is connected to one or more networks via one or more interfaces.

#### **Router**

A network node that forwards IPv6 packets.

#### **Host**

A network node that represents an end point for IPv6 communication relations.

#### **Link**

A link is, according to IPv6 terminology, a direct layer 3 connection within an IPv6 network.

#### **Neighbor**

Two network nodes are called neighbors when they are located on the same link.

#### **IPv6 interface**

Physical or logical interface on which IPv6 is activated.

#### **Path MTU**

Maximum permitted packet size on a path from a sender to a recipient.

#### **Path MTU discovery**

Mechanism for determining the maximum permitted packet size along the entire path from a sender to a recipient.

#### **LLA**

Link local address FE80::/10

As soon as IPv6 is activated on the interface, a link local address is formed automatically. Can only be reached by nodes located on the same link.

#### **ULA**

Unique Local Address

Defined in RFC 4193. Via this address, the IPv6 interface can be reached in the LAN.

#### **GUA**

Global Unicast Address Via this address, the IPv6 interface can be reached, e.g. via the Internet.

#### **Interface ID**

The interface ID is formed with the EUI-64 method or manually.

#### **EUI-64**

Extended Unique Identifier (RFC 4291); method for forming the interface ID. In Ethernet, the interface ID is formed from the MAC address of the interface. Divides the MAC address into the manufacturer-specific part (OUI) and the network-specific part (NIC) and inserts FFFE between the two parts.

Example:

MAC address = AA:BB:CC:DD:EE:FF

OUI = AA:BB:CC

NIC = DD:EE:FF

EUI-64 = OUI + **FFFE** + NIC = AA:BB:CC:**FF:FE**:DD:EE:FF

**Scope**

Defines the range of the IPv6 address.

## 5.3.2 Structure of an IPv6 address

### IPv6 address format - notation

IPv6 addresses consist of 8 fields each with four-character hexadecimal numbers (128 bits in total). The fields are separated by a colon.

Example:

fd00:0000:0000:ffff:02d1:7d01:0000:8f21

Rules / simplifications:

- If one or more fields have the value 0, a shortened notation is possible.

The address fd00:**0000:0000**:ffff:02d1:7d01:0000:8f21 can also be shortened and written as follows:

fd00::ffff:02d1:7d01:0000:8f21

To ensure uniqueness, this shortened form can only be used once within the entire address.

- Leading zeros within a field can be omitted.

The address fd00:0000:0000:ffff:**02d1**:7d01:0000:8f21 can also be shortened and written as follows:

fd00::ffff:**2d1**:7d01:0000:8f21

- Decimal notation with periods

The last 2 fields or 4 bytes can be written in the normal decimal notation with periods.

Example: The IPv6 address fd00::ffff.125.1.0.1 is equivalent to fd00::ffff:7d01:1

### Structure of the IPv6 address

The IPv6 protocol distinguishes between three types of address: Unicast, anycast and multicast. The following section describes the structure of the global unicast addresses.

IPv6 prefix		Suffix
Global prefix: n bits	Subnet ID m bits	Interface ID 128 - n - m bits
Assigned address range	Description of the location, also subnet prefix or subnet	Unique assignment of the host in the network. The ID is generated from the MAC address.

The prefix for the link local address is always fe80:0000:0000:0000. The prefix is shortened and noted as follows: fe80::

## **IPv6 prefix**

Specified in: RFC 4291

The IPv6 prefix represents the subnet identifier.

Prefixes and IPv6 addresses are specified in the same way as with the CIDR notation (Classless Inter-Domain Routing) for IPv4.

### **Design**

IPv6 address / prefix length

### **Example**

IPv6 address: 2001:0db8:1234::1111/48

Prefix: 2001:0db8:1234::/48

Interface ID: ::1111

## **Entry and appearance**

The entry of IPv6 addresses is possible in the notations described above. IPv6 addresses are always shown in the hexadecimal notation.

# Configuring with Web Based Management

## 6.1 Web Based Management

### How it works

The device has an integrated HTTP server for Web Based Management (WBM). If a device is addressed with a Web browser, it returns HTML pages to the client PC depending on the user input.

The user enters the configuration data in the HTML pages sent by the device. The device evaluates this information and generates reply pages dynamically.

The advantage of this method is that only a Web browser is required on the client.

---

#### Note

##### Secure connection

WBM also allows you to establish a secure connection via HTTPS.

Use HTTPS for protected data transmission. If you wish to access WBM only via a secure connection, activate the option "HTTPS Server only" in "System > Configuration".

---

### Requirements

#### WBM display

- The device has an IP address
- There is a connection between the device and the client device. With the Windows ping command, you can check whether or not a connection exists.
- Access via HTTPS is enabled.
- JavaScript is activated in the Web browser.
- The Web browser must not be set so that it reloads the page from the server each time the page is accessed. The updating of the dynamic content of the page is ensured by other mechanisms. In the Internet Explorer, you can make the appropriate setting in the "Options > Internet Options > General" menu in the section "Browsing history" with the "Settings" button. Under "Check for newer versions of stored pages:", select "Automatically".

- If a firewall is used, the relevant ports must be opened.
  - For access using HTTP: Port 80
  - For access using HTTPS: Port 443
- The display of the WBM was tested with the following desktop Web browsers:
  - Microsoft Internet Explorer 11

---

**Note**

**Compatibility view**

In Microsoft Internet Explorer, disable the compatibility view to ensure correct display and to allow problem-free configuration using WBM.

---

- Mozilla Firefox 38 ESR
- Chrome V46

**Display of the WBM on mobile devices**

For mobile devices, the following minimum requirements must be met:

Resolution	Operating system	Internet browser
960 x 640 pixels	Android as of version 4.2.1 iOS as of version 6.0.2	Chrome as of version 18 on Android Safari as of version 6 on iOS

- Tested with the following Internet browsers for mobile devices:
  - Safari as of version 8 on iOS as of V8.1.3 (iPad Mini Model A1432)
  - Chrome as of version 46 on Android as of version 5.0.2 (Nexus 7C Asus)
  - Firefox as of version 35 on Android as of version 5.0.2

---

**Note**

**Display of the WBM and working with it on mobile devices**

The display on the WBM pages and how you work with them on mobile devices may differ compared with the same pages on desktop devices. Some pages also have an optimized display for mobile devices.

---

## 6.2 Login

### Establishing a connection to a device

Follow the steps below to establish a connection to a device using an Internet browser:

1. There is a connection between the device and the client PC. With the ping command, you can check whether or not a connection exists.
2. In the address box of the Internet browser, enter the IP address or the URL of the device. If there is a problem-free connection to the device, the logon page of Web Based Management (WBM) is displayed.

## Logging in using the Internet browser

### Selecting the language of the WBM

1. From the drop-down list at the top right, select the language version of the WBM pages.
2. Click the "Go" button to change to the selected language.

---

### Note

#### Available languages

As of version 5.2 English and German are available. Other languages will follow in a later version.

---

SIEMENS

English Go

Name:

Password:

[Login](#)

[Switch to secure HTTP](#)

For information about browser compatibility please refer to the manual

## Logon with HTTP

There are two ways in which you can log on via HTTP. You either use the logon option in the center of the browser window or the logon option in the upper left area of the browser window.

The following steps apply when logging on, whichever of the above options you choose:

1. Enter the following in the "Name" input box:
  - "admin": With this user type, you can change the settings of the device (read and write access to the configuration data).
2. Enter your password in the "Password" input box.

When you log in for the first time or following a "Restore Factory Defaults and Restart", enter the standard password in the "Password" input box.

  - "admin": Standard password "admin"

---

### Note

The password for the "admin" user has been changed for devices with the US version. Specialist personnel for professional WLAN installations can obtain the password from Siemens support.

---

3. Click the "Login" button or confirm your input with "Enter".

When you log in with the default user "admin" for the first time or following a "Restore Memory Defaults and Restart", you will be prompted to change the password.

You need to repeat the password as confirmation. The password entries must match. Click the "Set Values" button to complete the action and activate the new password.

Once you have logged in successfully, the start page appears.

## Logon with HTTPS

Web Based Management also allows you to connect to the device over the secure connection of the HTTPS protocol. Follow these steps:

1. Click on the link "Switch to secure HTTP" on the login page or enter "https://" and the IP address of the device in the address box of the Internet browser.
2. Check the displayed certificate warning and confirm it if applicable.  
The logon page of Web Based Management appears.
3. Enter the following in the "Name" input box:
  - "admin": With this user type, you can change the settings of the device (read and write access to the configuration data).
4. Enter your password in the "Password" input box.  
When you log in for the first time or following a "Restore Factory Defaults and Restart", enter the standard password in the "Password" input box.
  - "admin": Standard password "admin"

---

### Note

The password for the "admin" user has been changed for devices with the US version. Specialist personnel for professional WLAN installations can obtain the password from Siemens support.

---

5. Click the "Login" button or confirm your input with "Enter".  
When you log in with the default user "admin" for the first time or following a "Restore Memory Defaults and Restart", you will be prompted to change the password.  
  
You need to repeat the password as confirmation. The password entries must match.  
Click the "Set Values" button to complete the action and activate the new password.

Once you have logged in successfully, the start page appears.

## 6.3 "Wizard" menu

### 6.3.1 Basic Wizard

#### Introduction

With the Basic Wizard, menus guide you through the configuration of the most important parameters.

On the Basic Wizard pages, you can only configure the parameters important for the basic functionality. You make further settings when you have finished with the Basic Wizard.

#### Requirement

- The device is in the status it was when it was shipped and can be reached via the Ethernet interface.
- You have assigned an IP address to the device. For more detailed information, refer to the section "IP addresses (Page 71)".
- You are logged on in WBM as the "admin" user. For more detailed information, refer to the section "Login (Page 83)".





#### Starting the Basic Wizard

Click on "Wizard > Basic Wizard" in the navigation area to start the Basic Wizard.

If you log on the first time or log on after a "Restore Memory Defaults and Restart", the Basic wizard is always started automatically after you have changed the default password.

#### Buttons you require often

The WBM pages of the Basic Wizard contain the following buttons:

Button	Description
	Goes to the next page
	Goes back to the previous page
	The Basic Wizard is closed without adopting the settings.
	Saves the configuration and exits the Wizard.

Navigation within the pages of the Basic Wizard is possible only with the "Prev" and "Next" buttons.

### 6.3.1.1 System Settings

#### Introduction

On this Basic Wizard page, you specify the mode of the device. After changing the mode, a message is displayed.



If you confirm the message with "OK", the device restarts with the factory-set configuration settings. Log in again and start the Basic Wizard to continue the configuration of the device for the selected mode.

#### Note

Because only access points can work in client mode as well, the mode can only be selected for these devices.

**Basic Wizard: System Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1x RADIUS	Summary
--------	---------	----	-----------------------	---------	-------	----	----------	--------------	---------

The Wizard will guide you through the initial setup of the device. If you have already set some of the configuration parameters and want to start the Wizard with the default settings of the device, you can click the 'Memory Defaults' button to restore the factory configuration settings except the IP parameters, SNMP MIB-2 parameters and the mode of the device. The device will restart automatically during the restore operation.

**Restore Memory Defaults and Restart**

Select the required mode of the device. Access point mode (AP) is the typical choice if the device's Ethernet port is directly connected to a wired distribution system (e.g. the factory or automation network). On the other hand, the Client mode (Client) allows data traffic to be relayed between the wired distribution system and a device connected to the Client's Ethernet port via a wireless network (for example a mobile application). The device will restart automatically if the mode is changed.

Device Mode:  ▼

**Abort** **Next**

## Description

The Basic Wizard page contains the following boxes:

- **Restore Memory Defaults and Restart**

If you click this button, the factory configuration settings are restored with the exception of the parameters below followed by a restart.

- IP address
- Subnet mask
- IP address of the default gateway
- DHCP client ID
- DHCP
- System name
- System location
- System contact
- User names and passwords
- Mode of the device

After restarting the device, you will need to log in again and start the Basic wizard again to configure the device.

- **Device Mode**

Select the mode of the device. This selection is available only for access points. The following operating modes are possible:

- AP: Access point mode
- Client: Client mode

### 6.3.1.2 Country Settings

#### Introduction

On this Basic Wizard page, you configure the country and the system name.

#### Description

The Basic Wizard page contains the following boxes

- **Country Code**

From this drop-down list, select the country in which the device will be deployed. You do not need to know the data for the specific country, the channel division and output power are set by the device according to the country you select.

---

#### Note

##### Locale setting

The correct country setting is mandatory for operation complying with the approvals. Selecting a country different from the country of use can lead to legal prosecution.

---

- **System Name**

You can enter the name of the device. If you configure this box, this configuration is adopted and displayed in the selection area. A maximum of 255 characters are possible. The system name is also displayed in the CLI input prompt. The number of characters in the CLI input prompt is limited. The system name is truncated after 16 characters.

### 6.3.1.3 IP Address Settings

#### Introduction

One of the basic steps in configuration of a device is setting the IP address. The IP address identifies a device in the network uniquely.

The screenshot shows the 'Basic Wizard: IP Address Settings' web interface. At the top, there is a navigation bar with tabs: System, Country, IP, Management Interfaces, Antenna, Radio, AP, Security, Dot1x RADIUS, and Summary. The 'IP' tab is currently selected. Below the navigation bar, there is a text box that reads: 'Select this option if you want to use the DHCP client, i.e. when IP address settings within the subnet are managed centrally by a DHCP server'. Below this text box is a checkbox labeled 'DHCP Client'. Below the checkbox, there is another text box that reads: 'As an alternative, you can make static IP address settings. Enter the IP address and the subnet mask via which the management is accessible. If the device is intended for communication with devices (diagnostics stations, e-mail servers etc.) in another subnet, also enter the IP address of the default gateway.' Below this text box, there are three input fields: 'IP Address: 192.168.16.107', 'Subnet Mask: 255.255.255.0', and 'Default Gateway: 0.0.0.0'. At the bottom of the form, there are three buttons: 'Previous', 'Abort', and 'Next'.

#### Description

The Basic Wizard page contains the following boxes

- **DHCP Client**

Specify how the IP address will be assigned. There are two methods of assigning IP addresses.

- Enabled  
The device obtains a dynamic IP address from a DHCP server.
- Disabled  
You enter the IP settings in the input boxes "IP Address" and "Subnet Mask".

- **IP Address**

Enter an IP address that is unique within your network.

- **Subnet Mask**

Enter the subnet mask of the device.

- **Default gateway**

Enter the IP address of the default gateway so that the device can communicate with devices in other subnets, for example diagnostics stations, e-mail server.

### 6.3.1.4 Management Interfaces

#### System configuration

On this Basic Wizard page, you specify the services with which the device can be accessed. With some services, there are further configuration pages on which more detailed settings can be made. Configure these services after completing the Basic Wizard.

**Basic Wizard: Management Interfaces**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1x RADIUS	Summary
--------	---------	----	-----------------------	---------	-------	----	----------	--------------	---------

Please check whether the enabled access options match the required security policy: The 'Telnet Server' allows unencrypted access while the 'SSH Server' allows encrypted access to the CLI. Select the 'HTTPS Server only' check box if you only want encrypted access to the WBM. DCP is a widely used protocol in automation networks that allows device discovery and configuration, but lacks advanced security options. From the list, select the SNMP protocol version for which you want to allow access to the device. As SNMPv1 and SNMPv2c are inherently non-secure protocols, you may want to restrict these protocols to read-only access.

☒ Telnet Server  
☒ SSH Server  
☐ HTTPS Server only

DCP Server: Read/Write

SNMP: SNMPv1/v2c/v3

☐ SNMPv1/v2 Read-Only  
☒ SINEMA Configuration Interface

#### Description

The page contains the following boxes:

- **Telnet Server**  
enable or disable the "Telnet Server" service for unencrypted access to the CLI.
- **SSH Server**  
Enable or disable the "SSH Server" service for encrypted access to the CLI.
- **HTTPS Server only**  
Enable or disable access using HTTPS.

- **DCP Server**

Specify whether or not the device can be accessed with DCP (Discovery and Configuration Protocol):

- "-" (disabled)  
DCP is disabled. Device parameters can neither be read nor modified.
- Read/Write  
With DCP, device parameters can be both read and modified.
- Read Only  
With DCP, device parameters can be read but cannot be modified.

- **SNMP**

Select the protocol from the drop-down list. The following settings are possible:

- "-" (SNMP disabled)  
Access to device parameters via SNMP is not possible.
- SNMPv1/v2c/v3  
Access to device parameters is possible with SNMP versions 1, 2c or 3. You can configure other settings in "System > SNMP > General".
- SNMPv3  
Access to device parameters is possible with SNMP version 3. You can configure other settings in " System > SNMP > General".

- **SNMPv1/v2 Read-Only**

Enable or disable write access to SNMP variables with SNMPv1/v2c.

- **SINEMA configuration interface**

If the SINEMA configuration interface is enabled, you can download configurations to the device via the TIA Portal.

### 6.3.1.5 Antenna Settings

#### Introduction

On this Basic Wizard page, you configure the settings for the external antenna.

**Basic Wizard: Antenna Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1X RADIUS	Summary
--------	---------	----	-----------------------	---------	-------	----	----------	--------------	---------

On this page, you select the type of external antenna connected to the device. If you terminate an antenna connection using a 50 ohm resistor, select the entry 'Not used (Connect 50 Ohm Termination)'. If the type of external antenna is not available, select the 'User defined' entry and enter the antenna gain for each frequency band manually. Enter the length of flexible antenna connecting cable in meters between the device and the external antenna. An attenuation of 0.6 dB is assumed per meter. Also enter the attenuation caused by other elements, e.g. power splitters, where applicable.

Connector	Antenna Type	Antenna Gain 2.4 GHz [dBi]	Antenna Gain 5 GHz [dBi]	Cable Length [m]	Additional Attenuation [dB]
R1 A1	Omni-Direct-Mount: ANT795-4MC ▼	3	5	0	0
R1 A2	Not used (Connect 50 Ohm Termination) ▼	-	-	-	-

Previous Abort Next

#### Description

This table contains the following columns:

- **Connector**

Shows the name of the relevant antenna connector.

- **Antenna Type**

Select the type of external antenna connected to the device. If the type of your antenna is not available, select the entry "User defined".

Connectors that are not used must have a 50  $\Omega$  terminating resistor fitted. Select the entry "Not used (Connect 50 Ohm Termination)".

#### Note

##### 50 $\Omega$ terminating resistor

Each WLAN interface has three antenna connectors. The antennas R1A1 and R2A1 must be always be connected as soon as the associated WLAN Interface is turned on. If no antenna is connected, the relevant interface must also be disabled for RX and TX. Otherwise, there may be transmission disruptions.

- **Antenna Gain [dBi]**

If you select the "User defined" entry for the "Antenna Type", enter the antenna gain manually in the "dBi" unit.

- **Antenna Gain 2.4 GHz [dBi]**

Enter the antenna gain the antenna has in the 2.4 GHz frequency band.

- **Antenna Gain 5 GHz [dBi]** Enter the antenna gain the antenna has in the 5 GHz frequency band.

- **Cable length [m]**

Enter the length of the flexible antenna connecting cable in meters between the device and the external antenna.

- **Additional Attenuation [dB]**

Here, specify the additional attenuation caused, for example, by an additional splitter.

---

**Note**

If you use other WLAN interfaces, make sure that you have adequate channel spacing.

---

### 6.3.1.6 Radio Settings

#### Introduction

On this Basic Wizard page, you specify the configuration for the WLAN interfaces.

**Basic Wizard: Radio Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1x RADIUS	Summary
<p>Select the check box to enable the required WLAN interface. Specify the frequency band and the required transmission standard to be used for each WLAN interface. Enable or disable the 'Dynamic Frequency Selection (DFS)' function and 'Outdoor Mode' as required. Both settings influence the number of channels and the maximum legal transmit power depending on the country in which the device is deployed. To control the size of the radio cell, and to avoid exceeding the maximum legal transmit power, it may be necessary to reduce the transmit power. The text shown in the 'Tx Power Check' column will help you to find a legal limit.</p>									
Radio	Enabled	Radio Mode	Frequency Band	WLAN Mode 2.4 GHz	WLAN Mode 5 GHz	DFS (802.11h)	Outdoor Mode	max. Tx Power	Tx Power Check
WLAN 1	<input type="checkbox"/>	AP	2.4 GHz	802.11 n	802.11 n	<input type="checkbox"/>	<input type="checkbox"/>	20 dBm	Not Allowed (All Channels)
<p>Previous      Abort      Next</p>									

#### Description

This table contains the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **Enabled**  
Enable or disable the WLAN interface. The WLAN interfaces are disabled when the device is supplied.
- **Radio Mode**  
Shows the mode of the WLAN interface.
- **Frequency Band**  
Specify the frequency band. In client mode, dual-frequency operation is also possible.
- **WLAN Mode**  
Select the required transmission standard for the configured frequency band.
  - WLAN Mode 2.4 GHz  
Specify the transmission standard for the 2.4 GHz frequency band.
  - WLAN Mode 5 GHz  
Specify the transmission standard for the 5 GHz frequency band. The selection depends on the country setting.

- **DFS (802.11h)**
  - Enabled  
If the access point discovers a disruption on the current channel, for example due to a primary user, it automatically switches to an alternative channel. You specify the alternative channel on the "Access Point Settings" Basic Wizard page. DFS is also the requirement for the use of certain wireless channels. This can only be enabled in the 5 GHz band.
  - Disabled  
The DFS function is not used.
- **Outdoor Mode**
  - Enabled  
In outdoor mode, the selection of country-dependent channels and the transmit power for operation are extended for outdoor use.
  - Disabled  
The device is being operated in indoor mode. In indoor mode, the selection of country-dependent channels and the transmit power for operation in a building are restricted.
- **max. Tx Power**  
Specify the transmit power of the device. It may be necessary to reduce the transmit power depending on the antennas being used to avoid exceeding the maximum legal transmit power. Reducing the transmit power effectively reduces cell size

---

**Note**

The maximum possible transmit power varies depending on the channel and data rate. For more detailed information on transmit power, refer to the documentation "Characteristics radio interface".

---

---

**Note**

If both interfaces of access points with two WLAN interfaces are operated in the same frequency range, this may cause wireless interference on one or both interfaces at a transmit power higher than 15 dBm.

---

- **Tx power check**  
Indicates whether the settings that have been made will violate the permitted transmit power restrictions of the selected country. The following parameters influence this calculation:  
max. Tx Power, Antenna Gain, Additional Attenuation.  
The following displays can appear:
  - Allowed  
The channels can be used with the current settings.
  - Not Allowed (Some Channels)  
Among the channels, there are some on which the current transmit power exceeds the maximum permitted transmit power.
  - Not Allowed (All Channels)  
No permitted operation is possible. The transmit power is too high.

### 6.3.1.7 Access Point Settings

#### Introduction

On this Basic Wizard page, you specify the configuration for the access point.

#### Note

This page is available only in access point mode.

**Basic Wizard: Access Point Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1x RADIUS	Summary
--------	---------	----	-----------------------	---------	-------	----	----------	--------------	---------

On this page, you specify the configuration for the access point. Specify the main channel, or allow the AP itself to find a free channel by selecting 'Auto'. If you enabled the 'DFS' function previously to support the IEEE 802.11h standard and obtain more channels due to radar detection, specify the alternative channel as well. With the IEEE 802.11n transmission standard, you may extend the channel bandwidth by using either the neighboring channel '40 up' above or below '40 down'.

Radio	Channel	Alternative DFS Channel	HT Channel Width [MHz]
WLAN 1	Auto	-	20

Enter the name of the wireless network (SSID). A client that will connect to the wireless network must be configured to use the same name. The length of the character string for an SSID is 1 to 32 characters. Use only ASCII codes in the range 'A'..'Z', 'a'..'z', '0'..'9' and special characters !\$#%&'()\*+,-./:;=?@[\\]^\_`{|}~ and the space. This means the hexadecimal character codes 0x20 to 0x7e.

Port	SSID
VAP 1.1	Siemens Wireless Network

Warning: The approval process may not be finished in current country for channels denoted by a '\*' character.

Please check the following website for more detailed information:  
<http://www.siemens.com/wireless-approvals>

Previous

Abort

Next

#### Description of the displayed boxes

Table 1 contains the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Channel**

Specify the main channel. If you want the access point to search for a free channel itself, use "Auto". If you want to use a fixed channel, select the required channel from the drop-down list.

- **Alternative DFS Channel**

If you have enabled the DFS function on the Basic Wizard page "Radio", specify the alternative channel here. If you want the access point to search for a free channel itself, use "Auto". If you want to use a fixed channel, select the required channel from the drop-down list.

- **HT Channel Width [MHz]**

You can specify the channel bandwidth with the IEEE 802.11n transmission standard. The following settings are possible.

- 20  
Channel bandwidth 20 MHz
- 40 up  
Channel bandwidth 40 MHz. The configured channel and the neighboring channel above it are used.
- 40 down  
Channel bandwidth 40 MHz. The configured channel and the neighboring channel below it are used.

Table 2 contains the following columns:

- **Port**

Shows the first VAP interface per WLAN interface.

- **SSID**

Enter the SSID. The length of the character string for SSID it is 1 to 32 characters. The ASCII code 0x20 to 0x7e is used for the SSID.

After completing the Basic Wizard, you can define further SSIDs with "Interfaces > WLAN > Access Point Settings".

### 6.3.1.8 Client Settings

#### Introduction

On this Basic Wizard page, you specify the configuration for clients, for example the assignment of the MAC address.

---

**Note**

This page is only available in client mode.

---

**Basic Wizard: Client Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	Client	Channels	Security	Dot1x Supplicant	Summary
--------	---------	----	-----------------------	---------	-------	--------	----------	----------	------------------	---------

On this page, you specify the configuration for a client. If you only want to enable IP-based (OSI layer 3) communication with devices attached to the Ethernet port, use 'Own' to make the client use the MAC address of the Ethernet interface for the WLAN interface as well. Similarly, selecting 'Manual' allows you to enter any MAC address in the 'MAC Address' column. If MAC-based (OSI layer 2) communication is intended with a single device, use 'Automatic' to make the client automatically adopt the source MAC address of the first frame that it receives over the Ethernet interface. For multiple devices, 'Layer 2 Tunnel' makes the client use the MAC address of the Ethernet interface for the WLAN interface. But the network will also be informed of up to eight MAC addresses connected to the Ethernet interface of the client. If the 'Any SSID' check box is selected, the device attempts to connect to the network with the best transmission quality and that has suitable security settings.

Radio	MAC Mode	MAC Address	Any SSID
WLAN 1	Automatic	00-00-00-00-00-00	<input checked="" type="checkbox"/>

If the 'Any SSID' check box is not selected, you will need to enter the SSID of the access point with which the client will connect to have better control over the behavior of the device. The length of the character string for an SSID is 1 to 32 characters. Use only ASCII codes in the range of 'A'..'Z', 'a'..'z', '0'..'9' and special characters !\$#%&'()\*+,-./:;=?@[\\^\_`{}~ and the space. This means the hexadecimal character codes 0x20 to 0x7e.

Radio	SSID	Security Context
WLAN 1		1

Previous    Abort    Next

## Description

Table 1 contains the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **MAC mode**  
Specify how the MAC address is assigned to the client. The following are possible:
  - Automatic  
The client automatically adopts the source MAC address of the first frame that it receives over the Ethernet interface.
  - Manual  
If you select "Manual", enter the MAC address in the "MAC Address" column.
  - Own  
The client uses the MAC address of the Ethernet interface for the WLAN interface.
  - Layer 2 Tunnel  
The client uses the MAC address of the Ethernet interface for the WLAN interface. The network is also informed of the MAC addresses connected to the Ethernet interface of the client. Up to eight MAC addresses can be used.

- **MAC Address**

Enter the MAC address of the client. The input box can only be edited if you have set "Manual" for the "MAC Mode".

- **Any SSID**

- Enabled

In client mode, the device attempts to connect to the network with the best transmission quality and that has suitable security settings.

- Disabled

The client attempts to connect to the network from the SSID list that has the best transmission quality.

Table 2 contains the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **SSID**

Enter the SSID of the access point with which the client connects. In the Basic Wizard, you can only specify one SSID. After completing the Basic Wizard, you can define further SSIDs with "Interfaces > WLAN > Client".

- **Security Context**

Shows the assigned security context. In the Basic Wizard only one security context is available. After completing the Basic Wizard, you can create and configure further security contexts in "Security > WLAN > Basic".

### 6.3.1.9 Client Setting Allowed Channels

#### Introduction

For communication, a specific channel within a frequency band is used. On this page, you can either set this channel specifically or configure so that the channel is selected automatically.

---

**Note**

This page is only available in client mode.

---

**Basic Wizard: Client Allowed Channel Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	Client	Channels	Security	Dot1x Supplicant	Summary
--------	---------	----	-----------------------	---------	-------	--------	----------	----------	------------------	---------

On this page, you specify which channels may be used for communication with an AP, for example to reduce the amount of time required to scan for a new AP while roaming. If you enable the option 'Allowed Channels', you restrict the selection of channels via which a device is allowed to establish the connection, and the channels on which the client searches for an AP. To specify the valid channels for the required frequency band, select the appropriate check box for the channel number.

Radio ☐ Use Allowed Channels only

WLAN 1 ☐

Frequency Band: 2.4 GHz

☒ Select / Deselect all

Radio	Radio Mode	1	2	3	4	5	6	7	8	9	10	11	12	13
WLAN 1	Client	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Frequency Band: 5 GHz

☒ Select / Deselect all

Radio	Radio Mode	36	40	44	48	52	56	60	64	100	104	108	112	116	132	136	140
WLAN 1	Client	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Previous Abort Next

## Description

Table 1 contains the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **Use Allowed Channels only**  
If you enable the option, you restrict the selection of channels via which the client is allowed to establish the connection.  
In the following tables, you define the channels on which the client searches for an AP. The tables are divided up according to frequency bands.  
If the option is disabled, the channels available based on the settings (country code, antennas, transmit power etc.) are used.

Above the tables for the frequency bands, you will find the following check box:

- **Select / Deselect all**
  - Enabled  
If you enable the check box, all channels are selected.
  - Disabled  
If you deselect the check box, only the first valid channel of the frequency band remains enabled.

The tables of the frequency bands have the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Radio Mode**

Shows the operating mode of the device.

- **Channel number**

To specify the valid channels for the required frequency band, select the appropriate check box for the channel number.

The table displays the permitted channels of the country. Only the valid channels can be enabled. Invalid channels are grayed out and cannot be enabled.

---

**Note**

To specify the channels, the setting "Use Allowed Channels only" must be enabled.

---

### 6.3.1.10 Security Settings

#### Introduction

To make the network secure, authentication and encryption are used. You specify the security levels with the type of authentication and the encryption procedure.

Use WPA2/AES, to prevent misuse of a password WPA2 (RADIUS) / WPA2-PSK with AES provides the greatest security. You will find further information on security in the configuration manual under "Instructions for secure network design".

The security settings on both devices must match to allow a client to communicate with an access point.

**Basic Wizard: Security Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	Client	Channels	Security	Dot1x Supplicant	Summary
--------	---------	----	-----------------------	---------	-------	--------	----------	----------	------------------	---------

To make the network secure, authentication and encryption are used to verify a communication partner's identity and to protect the transferred data from eavesdropping. Selecting an entry with 'PSK' from the list requires you to enter a password and to confirm the password to catch mistyped characters. Other settings require additional configuration steps to be performed later on. It is not advisable to select 'Open system', as this represents no security at all. With WPA-PSK you can achieve a low level of security, but also compatibility with certain legacy systems. With WPA2-PSK you can achieve a moderate level of security, while WPA2-RADIUS will give you the highest level of security but requires extra network infrastructure. If you are unsure about the proper security settings, simply accept the default values and enter the passwords to achieve a reasonable level of security. Make sure that you note down the passwords, as you will need to configure the other devices in the same way.

Security Context	Authentication Type	Cipher	WPA(2) Pass Phrase	WPA(2) Pass Phrase Confirmation
1	Open System	WEP		

Previous
Abort
Next

## Description

This table contains the following columns:

- **Interface** (only in Access Point mode)  
Shows the interface to which the settings relate.
- **Security Context** (in client mode only)  
Shows the security context to which the settings relate.
- **Authentication Type**  
Select the type of authentication.

---

### Note

#### WLAN mode IEEE 802.11 n

With devices operated in WLAN mode IEEE802.11n only WPA2 (WPA2-PSK and WPA2 Radius) encryption is possible.

---

- Open System  
Without authentication
- **WEP**
- WPA-PSK  
WPA authentication with WPA key. Enter the WPA key in ""WPA(2) Pass Phrase.
- WPA (RADIUS)  
WPA authentication with RADIUS server. You configure the access data on the next Basic Wizard page.
- WPA2-PSK  
WPA2 authentication with WPA2 key. Enter the WPA2 key in ""WPA(2) Pass Phrase.
- WPA2 (RADIUS)  
WPA2 authentication with RADIUS server. You configure the access data on the next Basic Wizard page.
- iPCF authentication  
This authentication type is shown when iPCF, iPCF-HT or iPCF-MC mode is enabled at the corresponding WLAN interface.  
You can enable iPCF authentication in the "iFeatures (Page 396)" menu.
- **Cipher**  
Select the encryption method.
  - AUTO  
AES or TKIP is selected automatically depending on the capability of the other station.
  - TKIP (Temporal Key Integrity Protocol)  
A symmetrical encryption method with the RC4 algorithm (Ron's Code 4). In contrast to the weak WEP encryption, TKIP uses changing keys derived from a main key. TKIP can also recognize corrupted data frames.
  - AES (Advanced Encryption Standard)  
Strong symmetrical block encryption method based on the Rijndael algorithm that further improves the functions of TKIP.

- **WPA(2) Pass Phrase**

Enter a WPA(2) key. The key can be 8 to 63 ASCII characters or exactly 64 hexadecimal characters long. This WPA(2) key must be known on both the client and the access point and is entered by the user at both ends.

---

**Note**

The WPA(2) key can be 8 to 63 ASCII characters or exactly 64 hexadecimal characters long. It should be selected so that is complex for example consisting of random numbers, letters (upper-/lowercase), have few repetitions and special characters. Do not use known names, words or terms that could be guessed. If a device is lost or if the key becomes known, change the key on all devices to maintain security.

---

- **WPA(2) Pass Phrase Confirmation**

Confirm the entered WPA(2) pass phrase.

### 6.3.1.11 Dot1x Supplicant Settings

#### Introduction

On this Basic Wizard page, you configure the user name and the password with which the client will be logged on with the RADIUS server.

If you require additional authentication methods, you can configure them after completing the Basic Wizard with "Security > WLAN > Client Radius Supplicant".

---

**Note**

This page is only available in client mode.

---

**Basic Wizard: Dot1x Supplicant Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	Client	Channels	Security	Dot1x Supplicant	Summary
--------	---------	----	-----------------------	---------	-------	--------	----------	----------	------------------	---------

On this page, you specify the logon procedure for the client. Enter the user name and passwords with which you want to log on via the RADIUS server. You are restricted to non-certificate based authentication when using the Wizard. If you want to configure EAP-TLS, you need to upload a certificate file and configure the Supplicant settings using the regular

Security Context	Dot1x User Name	Dot1x User Password	Dot1x User Password Confirmation
1			

Previous

Abort

Next

## Description

Table 1 contains the following columns:

- **Security Context**  
Shows the available security contexts.
- **Dot1x User Name**  
Enter the user name with which the client will log on with the RADIUS server.
- **Dot1x User Password**  
Enter the password for the user name selected above. The client is logged on with the RADIUS server using this combination.  
For password assignment, ASCII code 0x20 to 0x7e is used.
- **Dot1x User Password Confirmation**  
Enter the password again in this input box.

### 6.3.1.12 Dot1x RADIUS Server Settings

#### Introduction

On this Basic Wizard page, you configure the settings for the primary RADIUS Server.

After completing the Basic Wizard, you can configure a backup server and other settings, for example the number of logon attempts with "Security> WLAN > AP Radius Authenticator."

---

#### Note

This page is available only in access point mode.

---

**Basic Wizard: Dot1x RADIUS Server Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	AP	Security	Dot1x RADIUS	Summary
--------	---------	----	-----------------------	---------	-------	----	----------	--------------	---------

On this page, you make the settings for the RADIUS server. Enter the IP address and set the input port of the RADIUS server if this is different from the default value. Then enter the shared secret of the RADIUS server and confirm it to catch mistyped characters.

Server Role	Server IP Address	Server Port	Shared Secret	Shared Secret Confirmation
Primary		1812		

Previous

Abort

Next

## Description

This table contains the following columns:

- **Server Role**  
Shows the role of the server.
- **Server IP Address**  
Enter the IP address of the RADIUS server. The use of the computer name (name resolution using DNS) instead of the IP address is not supported.
- **Server Port**  
Enter the port of the RADIUS server.
- **Shared Secret**  
Enter the password of the RADIUS server.
- **Shared Secret Conf**  
Enter the password again in this input box.

### 6.3.1.13 Summary of the settings

#### Introduction

The settings are summarized on this page. The content of the page depends on the set parameters and the mode of the device.

Check the settings before you exit the Basic Wizard with the "Set Values" button. If settings are incorrect, go back using the "Prev" button and change the settings to the required ones.

**Basic Wizard: Summary of Settings**

System	Country	IP	Management Interfaces	Antenna	Radio	Client	Channels	Security	Dot1x Supplicant	Summary
<div style="padding: 10px;"> <p>Device Mode: Client</p> <p>Country: Andorra</p> <p>System Name: sysName Not Set</p> <p>IP Assignment Method: Static</p> <p>IP Address: 192.168.16.107</p> <p>Subnet Mask: 255.255.255.0</p> <p>Default Gateway: 0.0.0.0</p> <p>Interface WLAN1: Enabled</p> <p>WLAN Mode: 802.11n (2.4 GHz), 20 dBm Tx Power</p> <p>Scan Channels: 1,2,3,4,5,6,7,8,9,10,11,12,13</p> <p>Antenna 1: Type ANT795-4MC, Gain 3 dBi, Additional Attenuation 0 dB, Cable Length 0 m</p> <p>Antenna 2: Type ANT795-4MA, Gain 3 dBi, Additional Attenuation 0 dB, Cable Length 0 m</p> <p>SSID: Any SSID</p> <p>MAC Mode: Automatic</p> <p>Security: Open System</p> <p style="text-align: center; margin-top: 20px;">Click the 'Set Values' button to apply the changes!</p> </div>										

#### Set Values

Click the "Set Values" button to exit the Basic Wizard. The WLAN settings are adopted.

## **6.4 "Information" menu**

### **6.4.1 Start page**

#### **View of the Start page**

When you enter the IP address of the device, the start page is displayed after a successful login. You cannot configure anything on this page.

#### **General layout of the WBM pages**

The following areas are generally available on every WBM page:

- Selection area (1): Top area
- Display area (2): Top area
- Navigation area (3): Left-hand area
- Content area (4): Middle area

The screenshot displays the web-based management interface for a Siemens SCALANCE W774-1 RJ45 device. The interface is organized into three main sections:

- Top Header:** Contains the Siemens logo (1), the device IP address (192.168.16.107/SCALANCE W774-1 RJ45), the date and time (08/02/2017 11:07:36), and a language selector (English) with a 'Go' button.
- Left Sidebar:** A navigation menu with categories like 'Welcome admin', 'Logout' (2), 'Wizards', 'Information', 'System', 'Interfaces', 'Layer 2', 'Security', and 'iFeatures'. The 'Information' category is expanded, showing sub-items like 'Start Page' (3), 'Versions', 'I&M', 'ARP / Neighbors', 'Log Tables', 'Faults', 'Redundancy', 'Ethernet Statistics', 'Learning Table', 'IPv6 Routing', 'DHCP Server', 'SNMP', 'Security', 'WLAN', 'WLAN Statistics', 'WLAN iFeatures', and 'System'.
- Main Content Area:** Displays a message 'Please select one item of the menu on the left' and a list of menu items. The 'Start Page' (4) is highlighted. Below the list, a table shows the device's status and configuration details.

PROFINET Name of Station:	cl-w770
Diagnostics Mode:	PROFINET
System Name:	sysName Not Set
Device Type:	SCALANCE W774-1 RJ45
PROFINET AR Status:	Offline
Power Line 1:	Down
Power Line 2:	Down
Power over Ethernet:	Up
PLUG Configuration:	ACCEPTED
PLUG License:	ACCEPTED
Fault Status:	No Fault
Remote Capture:	disabled

A 'Refresh' button is located at the bottom of the status table.

## Selection area (1)

The following is available in the selection area:

- Logo of Siemens AG




When you click on the logo, you arrive at the Internet page of the corresponding basic device in Siemens Industry Online Support.

- Display of: "System Location/System Name".
  - "System Location" contains the location of the device.  
With the settings when the device ships, the IP address of the Ethernet interface is displayed.
  - "System Name" is the device name. With the settings when the device ships, the device type is displayed.

You can change the content of this display with "System > General > Device.

- Drop-down list for language selection
- System time and date



You can change the content of this display with "System > System Time".

If the system time is not set, the status is . If the system time is configured, but the system time cannot be synchronized, a yellow warning triangle  can be seen. Check whether the time server can be reached. If necessary adapt your configuration. If the system time is set and/or can be synchronized, the status is .

## Display area (2)

In the upper part of the display area, you can see name of the currently logged in user and the full title of the currently selected menu item.

In the lower part of the display area, you will find:

- **Logging out**  
You can log out from any WBM page by clicking the "Logout" link.
- **Device name**  
Shows the name of the device.
- **Mode**  
Shows whether the device is an access point or a client.
- **LED simulation**   
Each device has one or more LEDs that provide information on the operating state of the device. Depending on its location, direct access to the device may not always be possible. Web Based Management therefore displays simulated LEDs. Unused connectors are displayed as gray LEDs. The meaning of the LED displays is described in the operating instructions.  
  
If you click this button, you open the window for the LED simulation. You can show this window during a change of menu and move it as necessary. To close the LED simulation, click the close button in the LED simulation window.
- **Help**   
When you click this button, the help page of the currently selected menu item is opened in a new browser window.

- **Printer** 

If you click this button, a popup window opens. The popup window contains a view of the page content optimized for printers.

---


**Note**


**Printing larger tables**


If you want to print large tables, please use the "Print preview" function of your Internet browser.

---

- **Favorites**

When the product ships, the button is disabled on all pages .

If you click this button, the symbol  changes and the currently open page or currently open tab is marked as favorite. Once you have enabled the button once, the navigation area is divided into two tabs. The first tab "Menu" contains all the available menus as previously. The second tab "Favorites" contains all the pages/tabs that you selected as favorites. On the "Favorites" tab the pages/tabs are arranged according to the structure in the "Menu" tab.

If you disable all the favorites you have created, the "Favorites" tab is removed again. To do this, click the  button on the relevant pages/tabs.

You can save, upload and delete the favorites configuration of a device on the "System > Load&Save" page using HTTP or TFTP.

- **Update on**  On / **Update off**  Off

WBM pages with overview lists can also have the additional "Update" button.

With this button, you can enable or disable updating of the content area. If updating is turned on, the display is updated every 2 seconds. To disable the update, click "On". Instead of "On", "Off" is displayed. As default, updating is always enabled on the WBM page.

## Navigation area (3)

In the navigation area, you have various menus available. Click the individual menus to display the submenus. The submenus contain pages on which information is available or with which you can create configurations. These pages are always displayed in the content area.

## Content area (4)

The content area shows a graphic of the device. The graphic always shows the device whose WBM you have called up.

The following is displayed below the picture of the device:

- **PROFINET Name of Station**

Shows the PROFINET device name.

- **Diagnostics Mode**

Shows whether EtherNet/IP or PROFINET is enabled.

- **System Name**  
Shows the name of the device.
- **Device Type**  
Shows the type designation of the device.
- **PROFINET AR Status**  
Shows the PROFINET application relation status.
  - Online  
There is a connection to a PROFINET controller. The PROFINET controller has downloaded its configuration data to the device. The device can send status data to the PROFINET controller.  
In this status, the parameters set by the PROFINET controller cannot be configured on the device.
  - Offline  
There is no connection to a PROFINET controller.
- **Power Line 1 / Power Line 2 / Power over Ethernet**  
Status of the power supplies 1 and 2 or power over Ethernet. The power line 2 and Power over Ethernet are only displayed if they are supported by the hardware. You will find further information on this in the compact operating instructions.
- **PLUG Configuration**  
Shows the status of the configuration data on the PLUG, refer to the section "System > PLUG > Configuration".
- **Fault Status**  
Shows the fault status of the device.
- **Remote Capture**  
Shows whether or not the function is enabled.

#### Buttons you require often

The pages of the WBM contain the following standard buttons:

- **Refresh the display with "Refresh"**  
Web Based Management pages that display current parameters have a "Refresh" button at the lower edge of the page. Click this button to request up-to-date information from the device for the current page.

---

#### Note

If you click the "Refresh" button, before you have transferred your configuration changes to the device using the "Set Values" button, your changes will be deleted and the previous configuration will be loaded from the device and displayed here.

---

- **Save entries with "Set Values"**

Pages in which you can make configuration settings have a "Set Values" button at the lower edge. The button only becomes active if you change at least one value on the page. Click this button to save the configuration data you have entered on the device. Once you have saved, the button becomes inactive again.

---

**Note**

Changing configuration data is possible only with the "admin" login.

---

- **Create entries with "Create"**

Pages in which you can make new entries have a "Create" button at the lower edge. Click this button to create a new entry.

- **Delete entries with "Delete"**

Pages in which you can delete entries have a "Delete" button at the lower edge. Click this button to delete the previously selected entries from the device memory. Deleting also results in an update of the page in the WBM.

- **Cancel with "Cancel"**

The Basic Wizard pages have the "Cancel" button at the lower edge of the page. Click this button to close the Basic Wizard without applying the settings.

- **Page down with "Next"**

The number of data records that can be displayed on a page is limited. Click the "Next" button to page down through the data records.

- **Page back with "Prev"**

The number of data records that can be displayed on a page is limited. Click the "Prev" button to page back through the data records.

- **Delete the display with "Clear"**

In pages with sequence logs, you can delete all table entries at the same time regardless of whether filters are selected. The display is cleared in this process. The restart counter is only reset after you have restored the device to the factory settings and restarted the device.

Click the "Clear" button to completely delete the data record.

- **Button "Show all"**

You can show all entries in pages with a large number of data records. Click "Show all" to display all entries on the page. Note that displaying all messages can take some time.

- **Drop-down list for page change**

In pages with a large number of data records, you can navigate to the desired page. From the drop-down list, select the affected page to display it.

- **"Reset Counters" button**

Click "Reset Counters" to reset all counters. The counters are reset by a restart.

## Messages

If you have enabled the "Automatic Save" mode and you change a parameter the following message appears in the display area "Changes will be saved automatically in x seconds. Press 'Write Startup Config' to save the changes immediately."

---

### Note

#### Interrupting the save

Saving starts only after the timer in the message has elapsed. How long saving takes depends on the device.

During the save, the message "Saving configuration data in progress. Please do not switch off the device" is displayed.

- Do not switch off the device immediately after the timer has elapsed.
- 

## 6.4.2 Versions

### Versions of hardware and software

This page shows the versions of the hardware and software of the device. You cannot configure anything on this page.

#### Version Information

Hardware	Name	Revision	Order ID
Basic Device	SCALANCE W774-1 RJ45	1	6GK5 774-1FX00-0AA0
WLAN 1	WLAN 1 Radio Card	-	-
Software	Description	Version	Date
Firmware	SCALANCE W700 Firmware	V06.03.00	06/18/2018 20:00:00
Bootloader	SCALANCE W700 Bootloader	V01.23.00	06/11/2018 20:00:00
Firmware_Running	Current running Firmware	V06.03.00	06/18/2018 20:00:00

Refresh

## Description

Table 1 has the following columns:

- **Hardware**
  - Basic Device  
Shows the basic device
  - WLAN1  
Shows the available wireless card
- **Name**  
Shows the name of the device or module.
- **Revision**  
Shows the hardware version of the device. For the wireless card, only one version is then displayed if the WLAN interface is enabled.
- **Article number**  
Shows the article number of the device or described module.


Table 2 has the following columns:

- **Software**
  - Firmware  
Shows the current firmware version. If a new firmware file was downloaded and the device has not yet restarted, the firmware version of the downloaded firmware file is displayed here. After the next restart, the downloaded firmware is activated and used.
  - Bootloader  
Shows the version of the boot software stored on the device.
  - Firmware\_Running  
Shows the firmware version currently being used on the device.
- **Description**  
Shows the short description of the software.
- **Version**  
Shows the version number of the software version.
- **Date**  
Shows the date on which the software version was created.

### 6.4.3 I&M

#### Identification and maintenance data

This page contains information about device-specific vendor and maintenance data such as the article number, serial number, version numbers etc. You cannot configure anything on this page.



The screenshot shows a web interface titled "Identification & Maintenance". It contains a list of fields with their corresponding values:

Field	Value
Manufacturer ID	42
Order ID	6GK5 786-2FC00-0AA0
Serial Number	VPC3544970
Hardware Revision	1
Software Revision	V06.01.00
Revision Counter	0
Revision Date	00/00/0 00:00:00
Function Tag	
Location Tag	
Date	
Descriptor	

At the bottom left of the form is a "Refresh" button.

#### Description of the displayed values

The table has the following rows:

- **Manufacturer ID**  
Shows the manufacturer ID.
- **Article number**  
Shows the article number.
- **Serial Number**  
Shows the serial number.
- **Hardware Revision**  
Shows the hardware version.
- **Software Revision**  
Shows the software version.
- **Revision Counter**  
As of firmware version 4.0, the value "0" is always shown here regardless of the version change.
- **Revision Date**  
Date of the revision: Date and time of the last revision

- **Function tag**  
Shows the function tag (plant designation) of the device. The plant designation (HID) is created during configuration of the device with HW Config of STEP 7.
- **Location tag**  
Shows the location tag of the device. The location identifier (LID) is created during configuration of the device with HW Config of STEP 7.
- **Date**  
Shows the date created during configuration of the device with HW Config of STEP 7.
- **Descriptor**  
Shows the description created during configuration of the device with HW Config of STEP 7.

#### 6.4.4 ARP / neighbors

##### 6.4.4.1 ARP table

#### Assignment of MAC address and IPv4 address

With the Address Resolution Protocol (ARP), there is a unique assignment of MAC address to IPv4 address. This assignment is kept by each network node in its own separate ARP table. The WBM page shows the ARP table of the device.

Address Resolution Protocol (ARP) Table			
ARP Table		IPv6 Neighbor Table	
Interface	MAC Address	IP Address	Media Type
vlan1	68-05-ca-36-39-0d	192.168.16.20	Dynamic
vlan1	68-05-ca-25-e8-62	192.168.16.55	Dynamic
2 entries.			
<input type="button" value="Refresh"/>			

#### Description of the displayed values

The table has the following columns:

- **Interface**  
Shows the interface via which the row entry was learnt.
- **MAC Address**  
Shows the MAC address of the destination or source device.

- **IP Address**  
Shows the IP address of the destination device.
- **Media Type**  
Shows the type of connection.
  - Dynamic  
The device recognized the address data automatically.
  - Static  
The addresses were entered as static addresses.

#### 6.4.4.2 IPv6 Neighbor Table

##### Assignment of MAC address and IPv6 address

Via the IPv6 neighbor table, there is a unique assignment of MAC address to IPv6 address. This assignment is kept by each network node in its own separate neighbor table.

Address Resolution Protocol (ARP) Table			
Interface	MAC Address	IP Address	Media Type
vlan1	00-13-ce-63-59-bf	192.168.0.97	Dynamic
vlan1	6c-62-6d-6f-38-31	192.168.0.100	Dynamic
2 entries.			
<input type="button" value="Refresh"/>			

##### Description of the displayed values

The table has the following columns:

- **Interface**  
Displays the interface via which the row entry was learnt.
- **MAC Address**  
Shows the MAC address of the destination or source device.

- **IP Address**

Shows the IPv6 address of the destination device.

- **Media Type**

Shows the type of connection.

- Dynamic

The device recognized the address data automatically.

- Static

The addresses were entered as static addresses.

## 6.4.5 Log Tables

### 6.4.5.1 Event log

#### Logging events

The device allows you to log occurring events, some of which you can specify on the page of the System > Events menu. This, for example, allows you to record when an authentication attempt failed or when the connection status of a port has changed.

The content of the events log table is retained even when the device is turned off.

You cannot configure anything on this page.

Log Table

Event Log

WLAN Authentication Log

Severity Filters

☐ Info
 ☐ Warning
 ☐ Critical

Restart	System Up Time	System Time	Severity	Log Message
5	00:31:26	Date/time not set	6 - Info	Device configuration changed
5	00:25:47	Date/time not set	6 - Info	Device configuration changed
5	00:23:56	Date/time not set	2 - Critical	Error by reconfiguration of Wlan Config Daemon.
5	00:16:05	Date/time not set	6 - Info	Device configuration changed
5	00:00:14	Date/time not set	6 - Info	Spanning Tree: topology change detected.
5	00:00:11	Date/time not set	6 - Info	Link up on P2.
5	00:00:09	Date/time not set	2 - Critical	Error by reconfiguration of Wlan Config Daemon.
5	00:00:09	Date/time not set	6 - Info	Link down on P1.
5	00:00:00	Date/time not set	6 - Info	Cold start performed, Ver: T01.00.00.00_20.01.01 - event/status summary after startup:
5	00:00:00	Date/time not set	6 - Info	Startup configuration: Internal storage PLUG: Not present

1 - 10 of 62 entries [Show all](#)

1

Next

Clear

Refresh

## Description

- **Severity Filters**

You can filter the entries in the table according to severity. To display all the entries, enable or disable all parameters.

---

### Note

For each severity, a maximum of 400 entries in the table are possible. If the maximum number of entries is reached for a severity, the oldest entries of this severity are overwritten in the table. The table remains permanently in the memory.

---

- Info

Information

When this parameter is enabled, all entries of the category "Info" are displayed.

- Warning

Warnings

When this parameter is enabled, all entries of the category "Warning" are displayed.

- Critical

Critical

When this parameter is enabled, all entries of the category "Critical" are displayed.

The table has the following columns:

- **Restart**

Counts the number of restarts since you last reset to factory settings and shows the device restart after which the corresponding event occurred.

- **System Up Time**

Shows the time the device has been running since the last restart when the described event occurred.

- **System Time**

Shows the date and time when the described event occurred.

- **Severity**

Shows the severity of the message.

- **Log Message**

Displays a brief description of the event that has occurred. You will find the list of possible messages in Appendix D (Page 441) of the configuration manual.

If the system time is set, the time is also displayed at which the event occurred.

### 6.4.5.2 WLAN authentication log

#### Logging authentication attempts

This page shows a table with information on successful or failed authentication attempts.

**WLAN Authentication Log**

Event Log | **WLAN Authentication Log**

Severity Filters

☐ Info

☐ Warning

☐ Critical

Restart	System Up Time	System Time	Severity	Log Message
0 entries.				

You cannot configure anything on this page.

#### Description

- **Severity Filters**

You can filter the entries in the table according to severity. To display all the entries, enable or disable all parameters.

---

#### Note

For each severity, a maximum of 400 entries in the table are possible. If the maximum number of entries is reached for a severity, the oldest entries of this severity are overwritten in the table. The table remains permanently in the memory.

---

- Info  
Information  
When this parameter is enabled, all entries of the category "Info" are displayed.
- Warning  
Warnings  
When this parameter is enabled, all entries of the category "Warning" are displayed.
- Critical  
Critical  
When this parameter is enabled, all entries of the category "Critical" are displayed.

The table has the following columns:

- **Restart**

Counts the number of restarts since you last reset to factory settings and shows the device restart after which the corresponding event occurred.

- **System Up Time**

Shows the time the device has been running since the last restart when the described event occurred.

- **System Time**

Shows the date and time when the described event occurred.

- **Severity**

Shows the severity of the message.

- **Log Message**

Displays a brief description of the event that has occurred. You will find the list of possible messages in Appendix D of the configuration manual.

If the system time is set, the time is also displayed at which the event occurred.

## 6.4.6 Faults

### Error status

If a fault occurs, it is shown on this page. On the device, faults are indicated by the red fault LED lighting up.

Internal faults of the device and faults that you configure on the following pages are indicated:

- "System > Events"
- "System > Fault Monitoring"

The calculation of the time of a fault always begins after the last system start. If there are no faults present, the fault LED switches off.

### Faults

No. of Signaled Faults: 1

[Reset Counters](#)

Fault Time	Fault Description	Clear Fault State
16s	Link down on P1	<a href="#">Clear Fault State</a>
17s	Warm start performed.	<a href="#">Clear Fault State</a>

[Refresh](#)

## Description

The page contains the following boxes:

- **No. of Signaled Faults**

Indicates how often the fault LED lit up and not how many faults occurred.

- **"Reset Counters" button**

The number is reset with this button. The counter is reset when there is a restart.

The table contains the following columns:

- **Fault Time**

Shows the time the device has been running since the last restart when the described fault occurred.

- **Fault Description**

Displays a brief description of the error/fault that has occurred.

- **Clear Fault State**

Some faults can be acknowledged and thus removed from the fault list, e.g. a fault of the event "Cold/Warm Start". You can acknowledge these faults or remove them from the fault list with the "Clear Fault State" button.

## 6.4.7 Redundancy

### Introduction

The page shows the current information about the Spanning Tree and the settings of the root bridge.

If Spanning Tree is turned off, only the basic information about this device is displayed.

### Spanning Tree

Spanning Tree Mode: MSTP

Instance ID: 0

Bridge Priority: 32768

Bridge Address: 00-1b-1b-a5-5d-98

Root Priority: 32768

Root Address: 00-1b-1b-a5-5d-98

Root Cost: 0

Bridge Status: This bridge is the root

Regional Root Priority: 32768

Regional Root Address: 00-1b-1b-a5-5d-98

Regional Root Cost: 0

If Spanning Tree is turned on, the information about the status of the instance selected in the "Instance ID" drop-down list is displayed and the information about the configured ports is shown in the table. The information shown depends on the Spanning Tree mode.

### Spanning Tree

Spanning Tree Mode: MSTP

Instance ID: 0

Bridge Priority: 32768

Bridge Address: 00-1b-1b-a5-5d-98

Root Priority: 32768

Root Address: 00-1b-1b-a5-5d-98

Root Cost: 0

Bridge Status: This bridge is the root

Regional Root Priority: 32768

Regional Root Address: 00-1b-1b-a5-5d-98

Regional Root Cost: 0

Port	Role	State	Oper. Version	Priority	Path Cost	Edge Type	P.t.P. Type
P1	Designated	Forwarding	MSTP	128	200000	No Edge Port	P.t.P

## Description

The page contains the following boxes:

- **Spanning Tree Mode**

Shows the set mode. You specify the mode in "Layer 2 > Configuration" and in "Layer 2 > MSTP > General".

The following values are possible:

- 'L'
- STP
- RSTP
- MSTP

- **Instance ID**

Shows the number of the instance. The parameter depends on the configured mode.

- **Bridge Priority / Root Priority**

Which device becomes the root bridge is decided based on the bridge priority. The bridge with the highest priority (in other words, with the lowest value for this parameter) becomes the root bridge. If several devices in a network have the same priority, the device whose MAC address has the lowest numeric value will become the root bridge. Both parameters, bridge priority and MAC address together form the bridge identifier. Since the root bridge manages all path changes, it should be located as centrally as possible due to the delay of the frames. The value for the bridge priority is a whole multiple of 4096 with a range of values from 0 to 32768.

- **Bridge Address / Root Address**

The bridge address shows the MAC address of the device and the root address shows the MAC address of the root bridge.

- **Root Cost**

The path costs from this device to the root bridge.

- **Bridge Status**

Shows the status of the bridge, e.g. whether or not the device is the root bridge.

- **Regional root priority** (available only with MSTP)

For a description, see Bridge priority / Root priority

- **Regional root address** (available only with MSTP)

Shows the MAC address of the regional root bridge.

- **Regional Root Cost** (available only with MSTP)

Shows the path costs from this device to the regional root bridge.

The table contains the following boxes:

- **Port**

Shows the port via which the device communicates.

- **Role**

Shows the status of the port. The following values are possible:

- Disabled  
The port was removed manually from the spanning tree and will no longer be taken into account by the spanning tree.
- Designated  
The ports leading away from the root bridge.
- Alternate  
The port with an alternative route to a network segment
- Backup  
If a switch has several ports to the same network segment, the "poorer" Port becomes the backup port.
- Root  
The port that provides the best route to the root bridge.
- Master  
This port points to a root bridge located outside the MST region.

- **State**

Displays the current state of the port. The values are only displayed. The parameter depends on the configured protocol. The following statuses are possible:

- Discarding  
The port receives BPDU frames. Other incoming or outgoing frames are discarded.
- Listening  
The port receives and sends BPDU frames. The port is involved in the spanning tree algorithm. Other outgoing and incoming frames are discarded.
- Learning  
The port actively learns the topology; in other words, the node addresses. Other outgoing and incoming frames are discarded.
- Forwarding  
Following the reconfiguration time, the port is active in the network. The port receives and sends data frames.

- **Oper. Version**

Describes the type of spanning tree in which the port operates

- **Priority**

If the path calculated by the spanning tree is possible over several ports of a device, the port with the highest priority (in other words the lowest value for this parameter) is selected. A value between 0 and 240 can be entered for the priority in steps of 16. If you enter a value that cannot be divided by 16, the value is automatically adapted. The default is 128.

- **Path Cost**

This parameter is used to calculate the path that will be selected. The path with the lowest value is selected as the route. If several ports of a device have the same value, the port with the lowest port number will be selected.

If the value "Cost Calc." box is "0", the automatically calculated value is shown.

Otherwise, the value of the "Cost Calc." box is displayed.

The calculation of the path costs is largely based on the transmission speed. The higher the achievable transmission speed is, the lower the value of the path costs.

Typical values for path costs with rapid spanning tree:

- 10,000 Mbps = 2,000
- 1000 Mbps = 20,000
- 100 Mbps = 200,000
- 10 Mbps = 2,000,000.

- **Edge Type**

Shows the type of the connection. The following values are possible:

- Edge Port  
An edge port is connected to this port.
- No Edge Port  
There is a spanning tree or rapid spanning tree device at this port.

- **P.t.P. Type**

Shows the type of the point-to-point link. The following values are possible:

- P.t.P.  
With half duplex, a point-to-point link is assumed.
- Shared Media  
With a full duplex connection, a point-to-point link is not assumed.

---

**Note**

Point-to-point link means a direct connection between two devices. A shared media connection is, for example, a connection to a hub.

---

## 6.4.8 Ethernet Statistiken

### 6.4.8.1 Interface statistics

#### Interface statistics

The page shows the statistics from the interface table of the Management Information Base (MIB).

Ethernet Statistics: Interface Statistics							
Interface Statistics	Packet Size	Packet Type	Packet Error				
	In Octet	Out Octet	In Unicast	In Non-Unicast	Out Unicast	Out Non-Unicast	In Errors
P1	711533	1677547	3753	717	4214	297	0
<input type="button" value="Reset Counter"/>							
<input type="button" value="Refresh"/>							

#### Displayed values

The table has the following columns:

- **In Octet**  
Shows the number of received bytes.
- **Out Octet**  
Shows the number of sent bytes.
- **In Unicast**  
Shows the number of received unicast frames.
- **In Non Unicast**  
Shows the number of received frames that are not of the type unicast.
- **Out Unicast**  
Shows the number of sent unicast frames.
- **Out Non Unicast**  
Shows the number of sent frames that are not of the type unicast.
- **In Errors**  
Shows the number of all possible RX errors, refer to the "Packet Error" tab.

### 6.4.8.2 Packet Size

#### Frames sorted by length

This page displays how many frames of which size were received at each port. You cannot configure anything on this page.

Ethernet Statistics: Packet Size						
Interface Statistics	Packet Size	Packet Type	Packet Error			
Port	64	65-127	128-255	256-511	512-1023	1024-max
P1	6941	1474	1467	2230	19	0
Reset Counter						
Refresh						

#### Description

The table has the following columns:

- **Port**  
Shows the available ports.
- **Frame lengths**  
The other columns after the port number contain the absolute numbers of incoming frames according to their frame length.  
The following frame lengths are distinguished:
  - 64 bytes
  - 65 - 127 bytes
  - 128 - 255 bytes
  - 256 - 511 bytes
  - 512 - 1023 bytes
  - 1024 - max.

### 6.4.8.3 Frame Type

#### Received frames sorted by type

This page displays how many frames of the type "UnicastUnicast", "MulticastMulticast", and "BroadcastBroadcast" were received at each port. You cannot configure anything on this page.

Ethernet Statistics: Packet Type				
Interface Statistics		Packet Size	Packet Type	Packet Error
Port	Unicast	Multicast	Broadcast	
P1	9378	2052	16	
Reset Counter				
Refresh				

#### Description

The table has the following columns:

- **Port**  
Shows the available ports.
- **Unicast/Multicast /Broadcast**  
The other columns after the port number contain the absolute numbers of the incoming frames according to their frame type "Unicast", "Multicast" and "Broadcast"

### 6.4.8.4 Packet Error

#### Bad received frames

This page shows how many bad frames were received per port. You cannot configure anything on this page.

Ethernet Statistics: Packet Error						
Interface Statistics		Packet Size	Packet Type	Packet Error		
Port	CRC	Undersize	Oversize	Fragments	Jabbers	Collisions
P1	0	0	0	0	0	0
Reset Counter						
Refresh						

## Description

The table has the following columns:

- **Port**  
Shows the available ports.
- **Error types**  
The other columns after the port number contain the absolute numbers of the incoming frames according to their error type.  
  
In the columns of the table, a distinction is made according to the following error types:
  - **CRC (Cyclic Redundancy Code)**  
The packet length is between 64 and 1518 bytes. The CRC of the packet is invalid.
  - **Undersize**  
The packet length is less than 64 bytes. The CRC of the packet is valid.
  - **Oversize**  
The packet length is more than 1518 bytes. The CRC of the packet is valid.
  - **Fragments**  
The packet length is less than 64 bytes. The CRC of the packet is invalid.
  - **Jabbers**  
The frame length is more than 1518 bytes. The CRC of the packet is invalid.
  - **Collisions**  
Frames in which a collision event was detected.

## 6.4.9 Learning Table

### Address filtering

This WBM page shows the current content of the learning table. This table lists the source addresses of unicast address frames.

Learning Table			
VLAN ID	MAC Address	Status	Port
1	00-1b-1b-40-91-23	Learnt	P1
1	00-1b-1b-a5-5d-98	Learnt	P1
1	00-1b-1b-c7-f5-a2	Learnt	P1
1	00-1b-1b-c8-70-3b	Learnt	P1
1	08-00-06-70-56-00	Learnt	P1
1	68-05-ca-19-40-bb	Learnt	P1
1	68-05-ca-36-39-0d	Learnt	P1
1	94-b8-c5-41-b3-5d	Learnt	P1

8 entries.

## Description

This table contains the following columns:

- **VLAN ID**

Shows the VLAN ID of the node.

---

### Note

This column appears in the table only if a VLAN is configured.

---

- **MAC Address**

Shows the MAC address of the node.

- **State**

Shows the status of each address entry:

- **Learnt**

The specified address was learned by receiving a frame from this node and will be deleted when the aging time expires if no further packets are received from this node.

- **Invalid**

These values are not evaluated.

- **Port**

Shows the port via which the node with the specified address can be reached. Frames received by the device whose destination address matches this address will be forwarded to this port.

## 6.4.10 IPv6 routing

### Introduction

This page shows the IPv6 routes currently being used.

Layer 3: IPv6 Routing Table					
Destination Network	Prefix Length	Gateway	Interface	Metric	Routing Protocol
2002::C0A8:1296::	48	::	vlan1	1	connected
1 entry.					
<a href="#">Refresh</a>					

## Description

The table has the following columns:

- **Destination Network**

Shows the destination address of this route.

- **Prefix Length**

Shows the prefix length of this route.

- **Gateway**  
Shows the gateway for this route.
- **Interface**  
Shows the interface for this route.
- **Metric**  
Shows the metric of the route. The higher value, the longer packets require to their destination.
- **Routing Protocol**  
Shows the routing protocol from which the entry in the routing table originates. The following entries are possible:
  - Connected: Connected routes
  - Static: Static routes
  - RIPng: Routes via RIPng
  - OSPFv3: Routes via OSPFv3
  - Other: Other routes

#### 6.4.11 DHCP-Server

This page shows which IPv4 addresses were assigned to the devices by the DHCP server.

DHCP Server Bindings						
IP Address	Pool ID	Identification Method	Identification Value	Allocation Method	Binding State	Expire Time
192.168.16.90	1	Client ID	OS-EC74BA03FED2	dynamic	assigned	01/01/2000 05:21:03
1 entry.						
<input type="button" value="Refresh"/>						

#### Description

- **IP Address**  
Shows the IPv4 address assigned to the DHCP client.
- **Pool ID**  
Shows the number of the IPv4 address band.
- **Identification Method**  
Shows the method according to which the DHCP client is identified.
- **Identification value**  
Shows the MAC address or the client ID of the DHCP client.

- **Allocation Method**

Shows whether the IPv4 address was assigned statically or dynamically. You configure the static entries in "System > DHCP > Static Leases".

- **Binding State**

Shows the status of the assignment.

- Assigned  
The assignment is used.
- Not used  
The assignment is not used.
- Probing  
The assignment is being checked.
- Unknown  
The status of the assignment is unknown.

- **Expire Time**

Shows until when the assigned IPv4 address is still valid. Up to this time, the DHCP client must either request a new IPv4 address or extend the lease time of the assigned IPv4 address.

## 6.4.12 SNMP

This page displays the created SNMPv3 groups. You configure the SNMPv3 groups in "System > SNMP".

Simple Network Management Protocol v3 (SNMPv3) Groups Overview	
Group Name	User Name
Service	Mueller
Wartung	Peterson
Refresh	

### Description

The table has the following columns:

- **Group Name**

Shows the group name.

- **User Name**

Shows the user that is assigned to the group.

## 6.4.13 Security

### 6.4.13.1 Overview

#### Note

The values displayed depend on the rights of the logged-on user.

This page shows the security settings and the local and external user accounts.

**Security Overview**

Overview | Supported Function Rights | Roles | Groups

**Services**

SSH Server: enabled

Web Server: HTTP/HTTPS

SNMP: SNMPv1v2cv3

Management ACL: enabled: no access restriction

Login Authentication: Local

Password Policy: high

**Local User Accounts**

User Account	Role
admin	admin

**External User Accounts**

User Account	Role
admin	admin

Refresh

## Description

### Services

The "Services" list shows the security settings.

- **SSH Server**

You configure the setting in "System > Configuration".

- Enabled: Encrypted access to the CLI.
- Disabled: No encrypted access to the CLI.

- **Web Server**

You configure the setting in "System > Configuration".

- HTTP/HTTPS: Access to the WBM is possible with HTTP and HTTPS.
- HTTPS: Access to the WBM is now only possible with HTTPS.

- **SNMP**

You can configure setting in "System > SNMP > General".

- "-" (SNMP disabled)  
Access to device parameters via SNMP is not possible.
- SNMPv1/v2c/v3  
Access to device parameters is possible with SNMP versions 1, 2c or 3.
- SNMPv3  
Access to device parameters is possible only with SNMP version 3.

- **Management ACL**

You configure the setting in "Security > Management ACL".

- Enabled: Restricted access only: Access is restricted using an Access Control List (ACL).
- Disabled: No access restriction: Management ACL is not enabled.
- Enabled: No access restriction: Management ACL is enabled, but access is not restricted using an Access Control List (ACL).

- **Login Authentication**

You configure the setting in "Security > AAA > General".

- Local  
The authentication must be made locally on the device.
- RADIUS  
The authentication must be handled via a RADIUS server.
- Local and RADIUS  
The authentication is possible both with the users that exist on the device (user name and password) and via a RADIUS server.  
The user is first searched for in the local database. If the user does not exist there, a RADIUS query is sent.
- RADIUS and fallback local  
The authentication must be handled via a RADIUS server.  
A local authentication is performed only when the RADIUS server cannot be reached in the network.

- **Password Policy**

Shows which password policy is currently being used.

**Local and external user accounts**

You configure local user accounts and roles in "Security > User Accounts"

When you create a local user account an external user account is generated automatically.

Local user accounts involve users each with a password for logging in on the device.

In the table "External User Accounts" a user is linked to a role. In this example the user "Observer" is linked to the "user" role. The user is defined on a RADIUS server. The roll is defined locally on the device. When a RADIUS server authenticates a user, the corresponding group however is unknown or does not exist, the device checks whether or not there is an entry for the user in the table "External User Accounts". If an entry exists, the user is logged in with the rights of the associated role. If the corresponding group is known on the device, both tables are evaluated. The user is assigned the role with the higher rights.

---

**Note**

The table "External User Accounts" is only evaluated if you have set "SiemensVSA" in the RADIUS Authorization Mode".

---

With CLI you can access external user accounts.

The table "Local User Accounts" has the following columns:

- **User Account**

Shows the name of the local user.

- **Role**

Shows the role of the user. You can obtain more information on the function rights of the role in "Information > Security > Roles".

### 6.4.13.2 Supported Function Rights


---

**Note**

The values displayed depend on the role of the logged-on user.

---

The page shows the function rights available locally on the device.



Supported Function Rights	
Overview Supported Function Rights Roles Groups Inter AP Blocking	
Function Right	Description
1	Read-only access to configuration data.
15	Read/write access to configuration data.

Refresh

#### Description of the displayed values

- **Function Right**

Shows the number of the function right. Different rights relating to the device parameters are assigned to the numbers.

- **Description**

Shows the description of the function right.

### 6.4.13.3 Roles

#### Note

The values displayed depend on the role of the logged-on user.

The page shows the roles valid locally on the device.

User Roles		
Overview	Supported Function Rights	Roles
Role	Function Right	Description
user	1	System defined role, with readonly access to configuration data of this component.
admin	15	System defined role, with read/write access to configuration data of this component.
default	1	Internal role, for authenticated users without group/role mapping in this component.
everybody	0	Internal role, assigned to users when authentication failes. Access will be denied.
Maintenance	15	User defined role, with read/write access
Refresh		

#### Description of the displayed values

This table contains the following columns:

- **Role**  
Shows the name of the role.
- **Function Right**  
Shows the function right of the role:
  - 1  
Users with this role can read device parameters but cannot change them.
  - 15  
Users with this role can both read and change device parameters.
  - 0  
This is a role that the device assigns internally when a user could not be authenticated. The user is denied access to the device.
- **Description**  
Shows a description of the role.

### 6.4.13.4 Groups


---

**Note**

The values displayed depend on the role of the logged-on user.

---

This page shows which group is linked to which role. The group is defined on a RADIUS server. The roll is defined locally on the device.



User Groups		
Overview	Supported Function Rights	Roles
Groups	Inter AP Blocking	
Group	Role	Description
Administrators	admin	Mapping group "Administrators" (RADIUS) to role "admin" (device)
<input type="button" value="Refresh"/>		

#### Description of the displayed values

The table has the following columns:

- **Group**  
Shows the name of the group. The name matches the group on the RADIUS server.
- **Role**  
Shows the name of the role. Users who are authenticated with the linked group on the RADIUS server receive the rights of this role locally on the device.
- **Description**  
Shows a a description for the link.

### 6.4.13.5 Inter AP Blocking

#### Note

- This WBM page is only available in access point mode.
- This WBM page is enabled with the following KEY-PLUGs:
  - W780 iFeatures (MLFB 6GK5 907-8PA00)
  - W700 Security (MLFB 6GK5907-0PA00)

The WBM page shows a list of the SCALANCE W700 devices with which the clients are allowed to communicate.

WLAN Inter AP Blocking Allowed Addresses				
Overview	Supported Function Rights	Roles	Groups	Inter AP Blocking
Radio	Port	MAC Address	IP Address	Resolver IP Address
WLAN 1	VAP 1.1	00-00-00-00-00-00	192.168.16.177	192.168.16.111
<input type="button" value="Refresh"/>				

#### Description

The table has the following columns:

- **Radio**  
Shows the available WLAN interfaces to which the settings relate.
- **Port**  
Shows the VAP interface to which the settings relate.
- **MAC Address**  
Shows the MAC address of the SCALANCE W device with which the client may communicate.
- **IP Address**  
Shows the IPv4 address of the SCALANCE W device with which the client may communicate.
- **Resolver IP Address**  
Shows the IPv4 address with which the permitted IPv4 address is resolved.

## 6.4.14 WLAN

### 6.4.14.1 Overview AP

#### Overview of the configuration

This page shows these settings/properties of the WLAN or the WLAN interface.

#### Note

This tab is available only in access point mode.

Overview AP

Overview AP

Client List

WDS List

Overlap AP

Force Roaming

Noise Floor

Radio	WLAN Mode	Configured Channel	Alternative DFS Channel	Operative Channel	HT Channel Width [MHz]	iFeatures	Status
WLAN 1	802.11n (2.4 GHz)	Auto	-	-	20	iPCF	disabled

Radio	Port	MAC Address	SSID	Security	Status
WLAN 1	VAP 1.1	00-1b-1b-38-5c-98	Siemens Wireless Network	iPCF Authentication	enabled
WLAN 1	VAP 1.2	00-1b-1b-38-5c-99	Siemens Wireless Network 1.2	iPCF Authentication	disabled
WLAN 1	VAP 1.3	00-1b-1b-38-5c-9a	Siemens Wireless Network 1.3	iPCF Authentication	disabled
WLAN 1	VAP 1.4	00-1b-1b-38-5c-9b	Siemens Wireless Network 1.4	iPCF Authentication	disabled
WLAN 1	VAP 1.5	00-1b-1b-38-5c-9c	Siemens Wireless Network 1.5	iPCF Authentication	disabled
WLAN 1	VAP 1.6	00-1b-1b-38-5c-9d	Siemens Wireless Network 1.6	iPCF Authentication	disabled
WLAN 1	VAP 1.7	00-1b-1b-38-5c-9e	Siemens Wireless Network 1.7	iPCF Authentication	disabled
WLAN 1	VAP 1.8	00-1b-1b-38-5c-9f	Siemens Wireless Network 1.8	iPCF Authentication	disabled

Refresh

#### Description

Table 1 has the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **Port**  
Shows the available VAP interfaces.
- **WLAN Mode**  
Shows the transmission standard. If DFS is activated, the transmission standard "802.11h" is not shown additionally but only the configured transmission standard "802.11a".
- **Configured Channel**  
Shows the configured channel. If "Auto" is displayed, the access point searches for a free channel itself.

- **Alternative DFS Channel**

If the DFS function is enabled, the configured alternative channel of the access point is displayed.

If "Auto" is displayed, the access point searches for an alternative channel itself.

If the DFS function is activated and the access point browses for primary users for 60 seconds before starting communication with the selected channel, the text "scanning ..." is displayed instead of the channel.

- **Operational channel**

Shows the channel of the access point via which the access point communicates.

- **HT Channel Width [MHz]**

Shows the channel bandwidth.

- 20  
Channel bandwidth 20 MHz
- 40up  
Channel bandwidth 40 MHz. The configured channel and the neighboring channel above it are used.
- 40down  
Channel bandwidth 40 MHz. The configured channel and the neighboring channel below it are used.

---

**Note**

**Channel bandwidth 40 MHz and frequency band 2.4 GHz**

If the access point detects another access point on the configured channel or on neighboring channels, the access point changes the channel bandwidth from 40 MHz to 20 MHz. If you set a "free" channel on the access point, the access point uses the channel bandwidth 40 MHz.

---

- **iFeatures**

Shows which iFeatures are used.

- -  
iFeatures are not used.
- iPCF
- iPCF-HT
- iPCF-MC
- iPRP
- iREF
- AeroScout

- **State**

Shows the status of the WLAN interface.

- enabled  
The WLAN interface is enabled.
- disabled  
The WLAN interface is disabled.

Table 2 has the following columns:

- **Radio**  
Shows the available WLAN interfaces in this column.
- **Port**  
Shows the port of the virtual access point.
- **MAC Address**  
Shows the MAC address of the virtual access point.
- **SSID**  
Shows the SSID.
- **Security**  
Shows which authentication method is used.
  - If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.
  - If iPCF, iPCF-HT or iPCF-MC mode is enabled on the WLAN interface, the following is displayed depending on the encryption status:  
iPCF Encrypted (AES): Encryption is enabled.  
iPCF authentication: Encryption is disabled.
- **State**  
Shows the status of the WLAN interface.
  - enabled  
The WLAN interface is enabled.
  - disabled  
The WLAN interface is disabled.

#### 6.4.14.2 Client List

##### Logged-on clients

The WBM page shows the clients logged on to the access point as well as additional information, for example status, signal strength, MAC address.

##### Note

This WBM page is only available in access point mode.

WLAN Clients

Overview AP

Client List

WDS List

Overlap AP

Force Roaming

Noise Floor

Associated stations: 1

AID	Radio	Port	Type	MAC Address	System Name	Channel	Signal Strength [dBm]	Signal Strength [%]	Age [s]	Security	WLAN Mode	Max. Data Rate [Mbps]	State
1	WLAN 1	VAP 1.2	Station	00-1b-1b-c7-f5-a2	Client	36	-41	100	0	WPA2-PSK	-	-	-

Refresh

## Description

- **Logged-on clients**

Shows the number of clients logged on to the access point.

The table has the following columns:

- **AID (Associated ID)**

Shows the connection ID of the client. If the client connects to the access point via the VAP interface, the client is assigned a connection ID. The connection ID is unique within a VAP interface. If two clients log on at different VAP interfaces, both clients can receive the same ID.

- **Radio**

Shows the available WLAN interfaces.

- **Port**

Shows the VAP interface.

- **Type**

Shows the client type, for example "Sta" stands for IEEE 802.11 standard client.

- **MAC Address**

Shows the MAC address of the client.

- **System Name**

Shows the system name of the client if the client communicates this to the access point. Not all clients support this parameter.

- **Channel**

Shows the channel over which the client communicates with the access point.

- **Signal Strength [dBm]**

Shows the signal strength of the connected client in decibel milliwatts.

- **Signal strength [%]**

Shows the signal strength of the connected client as a percentage.

- **Age [s]**

Shows the time that has elapsed since the last client activity.

- **Security**

Shows which authentication method is used.

- If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.
- If iPCF, iPCF-HT or iPCF-MC mode is enabled on a WLAN interface, the following is displayed depending on the encryption status:
  - iPCF Encrypted (AES): Encryption is enabled.
  - iPCF authentication: Encryption is disabled.

- **WLAN Mode**

Shows the transmission standard. If DFS is activated, the transmission standard "802.11h" is not shown additionally but only the configured transmission standard "802.11a".

- **Max. Data Rate (Mbps)**

Shows the maximum data transmission speed in megabits per second.

- **State**

Shows the current status of the connection, for example connected means that the client is connected to the access point and is ready to communicate with the AP.

### 6.4.14.3 WDS List

#### Communication between access points

In normal operation, the access point is used as an interface to a network and communicates with clients. There are, however, situations in which several access points need to communicate with each other, for example to extend wireless coverage or to set up a wireless backbone. This mode is possible with WDS (Wireless Distributed System).

As default, the list is updated every 2 seconds. To disable the update, click "On". Instead of "On", "Off" is displayed. As default, updating is always enabled on the WBM page.

---

#### Note

This WBM page is only available in access point mode.

---

This page shows information about the WDS connections of the access point.

WDS List										Access Point
										Off
Overview AP	Client List	WDS List	Overlap AP							
Radio	Port	BSSID	WDS ID	Channel	Signal Strength [dBm]	Signal Strength [%]	Security	Max. Data Rate [Mbps]	State	
WLAN 1	WDS 1.1	00-1b-1b-38-81-88	DIMA_WDS_PARTNER	7	-69	51	Open System	195.0	connected	
<input type="button" value="Refresh"/>										

#### Description

The table has the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Port**

Shows the port.

- **BSSID**

- Shows the MAC address of the WDS partner.

- **WDS ID**  
Shows the name of the WDS partner.
- **Channel**  
Shows the channel over which the access point communicates with the WDS partner.
- **Signal Strength [dBm]**  
Shows the signal strength of the connected access point in dBm.
- **Signal strength [%]**  
Shows the signal strength of the connected access point as a percentage.
- **Security**  
Shows which authentication method is used.
  - If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.
  - If iPCF, iPCF-HT or iPCF-MC mode is enabled on a WLAN interface, the following is displayed depending on the encryption status:  
iPCF Encrypted (AES): Encryption is enabled.  
iPCF authentication: Encryption is disabled.
- **Max. Data Rate (Mbps)**  
Shows the maximum data transmission speed for the relevant WDS partner.
- **State**  
Shows the current status of the WDS connection.

#### 6.4.14.4 Overlap AP

##### Overlapping channels

---

**Note**

This WBM page is only available in access point mode.

---

For optimum data throughput, it is important that the set wireless channel is not used by other access points. In the 2.4 GHz band (802.11b or 802.11g), there is overlapping of the channels so that an access point occupies not only the set channel but also the two or three adjacent channels. You should therefore make sure that there is adequate channel spacing to neighboring access points.

This WBM page shows all access points that are visible on the set or adjacent channels (at 2.4 GHz). If entries exist here, the maximum data throughput of the access point and the availability of the communication link to the access point is potentially impaired.

Overlap APs List

Overview AP

Client List

WDS List

Overlap AP

Force Roaming

Radio

Aging Time [min]

WLAN 1

120

Radio	Type	SSID	BSSID	System Name	Channel	Signal Strength [dBm]	Signal Strength [%]	Age [s]	Security	WLAN Mode
-------	------	------	-------	-------------	---------	-----------------------	---------------------	---------	----------	-----------

Set Values

Refresh

## Description

Table 1 has the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **Aging Time [min]**  
Specify the life time of the entries in the list. If an access point is inactive for longer than the set time, it is removed from the list.

---

### Note

#### Changing the aging time

The aging time is a WLAN setting. For this reason, if a change is made, the WLAN connection is briefly interrupted to accept the new value.

---

The table has the following columns:

- **Radio**  
Shows the available WLAN interfaces in this column.
- **Type**  
Shows the mode of the WLAN interface.
- **SSID**  
Shows the SSID of the access point.
- **BSSID**  
Shows the MAC address of the access point.
- **System Name**  
Shows the system name of the SCALANCE W700-Geräts. The entry depends on the access point. Not all access points support this parameter.
- **Channel**  
Shows the channel over which the client communicates with the access point.
- **Signal Strength [dBm]**  
Shows the signal strength of the client in dBm.
- **Signal strength [%]**  
Shows the signal strength of the client as a percentage.

- **Age [s]**  
Shows the time that has elapsed since the last access point activity.
- **Security**  
Shows which authentication method is used.
  - If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.
  - If iPCF, iPCF-HT or iPCF-MC mode is enabled on the WLAN interface, the following is displayed depending on the encryption status:  
iPCF Encrypted (AES): Encryption is enabled.  
iPCF authentication: Encryption is disabled.
- **WLAN Mode**  
Shows the transmission standard. If DFS is activated, the transmission standard "802.11h" is not shown additionally but only the configured transmission standard "802.11a" or "802.11n".

#### 6.4.14.5 Force Roaming

Force Roaming		
Overview AP	Client List	WDS List
Overlap AP	Force Roaming	
Port	Destination Address / Status	Force Roaming on IP down
VAP 1.1	not configured	inactive
VAP 1.2	not configured	inactive
VAP 1.3	not configured	inactive
VAP 1.4	not configured	inactive
VAP 1.5	not configured	inactive
VAP 1.6	not configured	inactive
VAP 1.7	not configured	inactive
VAP 1.8	192.168.100.1 / idle	inactive
Refresh		

In client mode:

Force Roaming		
Overview Client	Available AP	IP Mapping
Force Roaming	Noise Floor	
Port	Destination Address / Status	Force Roaming on IP down
WLAN 1	192.111.20.20 / down	active
Refresh		

This WBM page shows the current status of the connection. It also shows whether there is roaming.

The device monitors the connection to certain addresses cyclically. To achieve this, the device sends echo messages (pings) to the configured destination addresses at regular intervals.

## Description

The table has the following columns:

- **Port**

Shows the available interfaces.

- VAP X.Y (in access point mode)
- WLAN 0/X (in client mode)

- **Destination Address / State**

Shows which destination address is monitored and the status of the connection. You configure the destination address in "Interfaces > WLAN > Force Roaming".

- not configured: No destination address is configured.
- idle: The configuration is incomplete.
- up: The destination address is reachable.
- down: The destination address is unreachable.

- **Force Roaming on IP down**

Indicates whether roaming is currently being performed.

- Inactive: No roaming is being performed. No change to the WLAN interface.
- Active: None of the destination addresses is reachable. To force the logged on clients / connected access points to roam, the device has disabled the corresponding interface.

### 6.4.14.6 Overview Client

#### Overview of the configuration

---

##### Note

This page is only available for clients or access points in client mode.

---

The page shows an overview of the existing clients and their configuration.

Overview Client

Overview Client

Available AP

IP Mapping

Force Roaming

Noise Floor

Radio	WLAN Mode	MAC Mode	MAC Address	Operative Channel	HT Channel Width [MHz]
WLAN 1	802.11n (2.4 GHz)	Layer 2 Tunnel	00-1b-1b-38-5c-90	-	-

Refresh

Connected BSSID	Connected SSID	Security	Context	iFeatures	Max. Data Rate [Mbps]	Status
-	-	-	-	IPCF	-	disabled

## Description

- **Radio**  
Shows the available WLAN interfaces.
- **WLAN Mode**  
Shows the transmission standard.
- **MAC Mode**  
Shows how the MAC address is assigned to the interface.
  - Automatic  
The client automatically adopts the source MAC address of the first frame that it receives over the Ethernet interface.
  - Manual  
The address was entered manually.
  - Own  
The client uses the MAC address of the Ethernet interface for the WLAN interface.
  - Layer 2 Tunnel  
The client uses the MAC address of the Ethernet interface for the WLAN interface. The network is also informed of the MAC addresses connected to the Ethernet interface of the client. Up to eight MAC addresses can be used.

- **MAC Address**

Shows the MAC address of the WLAN interface.

- **Operational channel**

Shows the channel of the access point to which the client is connected.

- **HT Channel Width [MHz]**

Shows the channel bandwidth.

- 20

Channel bandwidth 20 MHz

- 40up

Channel bandwidth 40 MHz. The configured channel and the neighboring channel above it are used.

- 40down

Channel bandwidth 40 MHz. The configured channel and the neighboring channel below it are used.

---

**Note**

**Channel bandwidth 40 MHz and frequency band 2.4 GHz**

If the access point detects another access point on the configured channel or on neighboring channels, the access point changes the channel bandwidth from 40 MHz to 20 MHz. If you set a "free" channel on the access point, the access point uses the channel bandwidth 40 MHz.

---

- **Connected BSSID**

Shows the MAC address of the access point to which the client is connected.

- **Connected SSID**

Shows the SSID of the access point to which the client is connected.

- **Security**

Shows which authentication method is used.

- If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.

- If iPCF, iPCF-HT or iPCF-MC mode is enabled, the following is displayed depending on the encryption status:

iPCF Encrypted (AES): Encryption is enabled.

iPCF authentication: Encryption is disabled.

- **Context**

Shows which security context is used.

- **iFeatures**  
Shows which iFeatures are used.
  - -  
iFeatures are not used.
  - iPCF
  - iPCF-HT
  - iPCF-MC
  - iPRP
  - iREF
  - AeroScout
- **State**  
Shows the status of the WLAN interface.
  - enabled  
The WLAN interface is enabled.
  - disabled  
The WLAN interface is disabled.

#### 6.4.14.7 Available AP

##### Available access points

###### Note

This page is only available for clients or access points in client mode.

This page shows all the access points visible to the client. The list also includes the access points to which the client cannot connect due to its configuration.

###### Note

###### Display when iPCF mode is activated

If the iPCF mode is active with a SCALANCE W700, the display is different. Since the client does not run a background scan in this case, only the access point with which the client is currently connected is displayed.

Available APs List										
Overview Client Available AP IP Mapping Force Roaming Noise Floor										
Radio	SSID	BSSID	System Name	Channel	Signal Strength [dBm]	Signal Strength [%]	Type	Security	WLAN Mode	State
Refresh										

## Description

The table has the following columns:

- **Radio**  
Shows the WLAN interface visible to the access point.
- **SSID**  
Shows the SSID of the access point.
- **BSSID**  
Shows the MAC address of the access point.
- **System Name**  
Shows the system name of the access point. The entry depends on the access point. Not all access points support this parameter.
- **Channel**  
Shows the channel on which the access point transmits or communicates.
- **Signal Strength [dBm]**  
Shows the signal strength of the access point in dBm.
- **Signal strength [%]**  
Shows the signal strength of the access point as a percentage.
- **Type**  
Shows the mode of the WLAN interface.
- **Security**  
Shows which authentication method is used.
  - If the authentication method "Open System + Encryption" or "Shared Key" is used, the "Encrypted (WEP/AES)" is displayed for both authentication methods.
  - If iPCF, iPCF-HT or iPCF-MC mode is enabled on a WLAN interface, the following is displayed depending on the encryption status:  
iPCF Encrypted (AES): Encryption is enabled.  
iPCF authentication: Encryption is disabled.
- **WLAN Mode**  
Shows the transmission standard. If DFS is activated, the transmission standard "802.11h" is not shown additionally but only the configured transmission standard "802.11a" or "802.11n".
- **State**  
Shows the status of the access point, for example whether or not the access point is available.

#### 6.4.14.8 IP mapping table

##### WLAN access for several SCALANCE W700 devices via a client

---

**Note**

This WBM page is only available for clients or access points in client mode.

---

You can make WLAN access available for several SCALANCE W700 devices with one client if you use IP mapping. This means that you do not need to equip every SCALANCE W700 device with its own WLAN client. This is possible only if the connected SCALANCE W700 devices are addressed only by IP frames. Communication at MAC address level (ISO/OSI layer 2) can

- be established with one component whose MAC address is configured on the client,
- be established with a maximum of eight components if the "Layer 2 Tunnel" function is selected.

The "Layer 2 Tunnel" setting meets the requirements of industrial applications in which MAC address-based communication takes place with several SCALANCE W700 devices downstream from the client. Clients with this setting cannot connect on standard Wifi access points.

The client maintains a table with the assignment of MAC address and IP address to send incoming IP frames to the correct MAC address. This WBM page shows this table.

---

**Note****IP mapping table**

If "Layer 2 Tunnel" is configured for a client, the IP mapping table is not displayed.

---

IP Mapping Table		
Overview Client	Available AP	IP Mapping
Force Roaming	Noise Floor	
MAC Address	IP Address	Type
0 entries.		
Refresh		

## Description

The table has the following columns

- **MAC Address**

The MAC address of a device located downstream from the WLAN client from the perspective of the access point.

- **IP Address**

The IP address managed for this device by the WLAN client.

- **Type**

There are two options for the type:

- system

The information relates to the WLAN client itself.

- learned

The information relates to a device downstream from the WLAN client.

## MAC mode

Frames sent by the client to the access point always have the MAC address of the WLAN client as the source MAC address. In the "learning table" of the access point there is therefore only the MAC address of the WLAN client.

If there are further SCALANCE W700 devices downstream from the client, the "Automatic" option should not be enabled. In this case, the MAC address would be assigned indiscriminately to the first SCALANCE W700 device that signals over Ethernet. If there is only IP communication between the access point and the client, the default setting "Own" can be retained. If MAC address-based frames are also to be sent by SCALANCE W700 devices downstream from the client, you need to select the settings "Automatic", "Manual" or "Layer 2 Tunnel".

### 6.4.14.9 Background noise

Noise Floor		
Connector	Channel [dBm]	Extended Channel [dBm]
R1 A1	-	-
R1 A2	-	-
R1 A3	-	-
R2 A1	-	-
R2 A2	-	-
R2 A3	-	-

Refresh

The page displays the background noise of the channel.

**Description**

- **Connector**  
Shows the name of the relevant antenna connector.
- **Channel [dBm]**  
Shows the background noise of the set channel.
- **Extended Channel [dBm]**  
Shows the background noise of the extended channel (HT-40).

**6.4.15 WLAN Statistics****6.4.15.1 Errors**

The WBM page show how many bad frames were received or sent per WLAN interface. If an increased number of errors occurs, you should check the settings for the WLAN interface(s), the setup of the SCALANCE W devices and the connection quality.

WLAN Errors Statistic

ErrorsManagement SentManagement ReceivedData SentData Received

Sent Errors

Interface	Transmission Errors	Dropped Frames	Retry Count
WLAN 1	0 (0%)	0 (0%)	0 (0%)

Received Errors

Interface	Received Errors	Duplicated Frames	Decryption Errors	FCS Errors
WLAN 1	11 (0%)	0 (0%)	11 (0%)	272 (10%)

Reset Counter

Refresh

Refresh

## Description

The Sent Errors table has the following columns:

- **Interface**

Shows the WLAN interface to which the entries apply.

- **Error types**

The other columns after the WLAN interface contain the absolute numbers of the frames sent according to their error type.

The columns of the table distinguish the following error types:

- Transmission Errors

Shows the number and percentage of bad frames that were sent.

- Dropped Frames

Shows the number and percentage of frames that were discarded.

Despite all the retries, the frame could not be successfully sent.

The frame has not yet been sent and the recipient has logged off in the meantime.

- Send Retries

Shows the number and percentage of frames sent successfully that required one or more retries.

The Received Errors table has the following columns:

- **Interface**

Shows the WLAN interface to which the entries apply.

- **Error types**

The other columns after the WLAN interface contain the absolute numbers of the frames received according to their error type.

The columns of the table distinguish the following error types:

- Received Errors

Shows the number and percentage of bad frames that were received.

- Duplicated Frames

Shows the number and percentage of frames that were received twice.

- Decryption Errors

Shows the number and percentage of incorrectly encrypted frames.

- FCS Errors

Shows the number and percentage of frames in which the checksum was incorrect.

### 6.4.15.2 Management Sent

The WBM page shows how many frames in response to logging on or logging off were counted per VAP interface.

#### Note

This WBM page is only available in access point mode.

WLAN Management Traffic Sent Statistics							
Errors	Management Sent	Management Received	Data Sent	Data Received			
Interface	Management Frames	Association Requests	Association Responses	Disassociation Requests	Authentication Requests	Authentication Responses	Deauthentication Requests
VAP 1.1	0	0	0	0	0	0	0
VAP 1.2	0	0	0	0	0	0	0
VAP 1.3	0	0	0	0	0	0	0
VAP 1.4	0	0	0	0	0	0	0

### Description

The table has the following columns:

- **Interface**  
Shows the VAP interface to which the entries apply.
- **Frame**
  - Management Frames  
Shows the number of management frames
  - Association Requests  
Shows the number of requesting association frames relevant for a logon.
  - Association Responses  
Shows the number of responding association frames relevant for a logon.
  - Disassociation Requests  
Shows the number of requesting disassociation frames relevant for a logoff.
  - Authentication Requests  
Shows the number of requesting authentication frames relevant for a logon.
  - Authentication Responses  
Shows the number of responding authentication frames relevant for a logon.
  - Deauthentication Requests  
Shows the number of deauthentication frames relevant for a logoff.

### 6.4.15.3 Management Received

The WBM page shows how many frames in response to logging on or logging off were counted per VAP interface.

#### Note

This WBM page is only available in access point mode.

WLAN Management Traffic Received Statistics							
Errors	Management Sent	Management Received	Data Sent	Data Received			
Interface	Management Frames	Association Requests	Association Responses	Disassociation Requests	Authentication Requests	Authentication Responses	Deauthentication Requests
VAP 1.1	0	0	0	0	0	0	0
VAP 1.2	0	0	0	0	0	0	0
VAP 1.3	0	0	0	0	0	0	0
VAP 1.4	0	0	0	0	0	0	0

### Description

The table has the following columns:

- **Interface**

Shows the VAP interface to which the entries apply.
- **Frame**
  - Management Frames
 

Shows the number of management frames
  - Association Requests
 

Shows the number of requesting association frames relevant for a logon.
  - Association Responses
 

Shows the number of responding association frames relevant for a logon.
  - Disassociation Requests
 

Shows the number of requesting disassociation frames relevant for a logoff.
  - Authentication Requests
 

Shows the number of requesting authentication frames relevant for a logon.
  - Authentication Responses
 

Shows the number of responding authentication frames relevant for a logon.
  - Deauthentication Requests
 

Shows the number of deauthentication frames relevant for a logoff.

#### 6.4.15.4 Data Sent

The WBM page shows how many frames were sent per VAP interface.

WLAN Data Traffic Sent Statistics				
Errors	Management Sent	Management Received	Data Sent	Data Received
Interface	Data Frames	Multicast/Broadcast Frames	Unicast Frames	Average Rate [kbps]
VAP 1.1	0	0	0	0
VAP 1.2	0	0	0	0
VAP 1.3	0	0	0	0
VAP 1.4	0	0	0	0
VAP 1.5	0	0	0	0
VAP 1.6	0	0	0	0
VAP 1.7	0	0	0	0
VAP 1.8	0	0	0	0
VAP 2.1	0	0	0	0
VAP 2.2	0	0	0	0
VAP 2.3	0	0	0	0
VAP 2.4	0	0	0	0
VAP 2.5	0	0	0	0
VAP 2.6	0	0	0	0
VAP 2.7	0	0	0	0
VAP 2.8	0	0	0	0

Reset Counter

Refresh

## Description

The table has the following columns:

- **Interface**

Shows the VAP interface to which the entries apply.

- **Frame types**

The other columns after the VAP interface contain the absolute numbers of the sent frames according to the frame types.

In the columns of the table, a distinction is made according to the following frame types:

- Data Frames

Shows the number of sent data frames.

- Multicast/Broadcast Frames

Shows the number of sent multicast and broadcast frames.

- Unicast Frames

Shows the number of sent unicast frames.

- Average Data Rate

Shows the average data rate of the last data frames sent.

### 6.4.15.5 Data Received

The WBM page shows how many frames were received per VAP interface.

WLAN Data Traffic Received Statistics				
Errors	Management Sent	Management Received	Data Sent	Data Received
Interface	Data Frames	Multicast/Broadcast Frames	Unicast Frames	Average Rate [kbps]
VAP 1.1	0	0	0	0
VAP 1.2	0	0	0	0
VAP 1.3	0	0	0	0
VAP 1.4	0	0	0	0
VAP 1.5	0	0	0	0
VAP 1.6	0	0	0	0
VAP 1.7	0	0	0	0
VAP 1.8	0	0	0	0
VAP 2.1	0	0	0	0
VAP 2.2	0	0	0	0
VAP 2.3	0	0	0	0
VAP 2.4	0	0	0	0
VAP 2.5	0	0	0	0
VAP 2.6	0	0	0	0
VAP 2.7	0	0	0	0
VAP 2.8	0	0	0	0

[Reset Counter](#)

[Refresh](#)

**Description**

The table has the following columns:

- **Interface**

Shows the VAP interface to which the entries apply.

- **Frame types**

The other columns after the VAP interface contain the absolute numbers of the received frames according to the frame types.

In the columns of the table, a distinction is made according to the following frame types:

- Data Frames

Shows the number of sent data frames.

- Multicast/Broadcast Frames

Shows the number of sent multicast and broadcast frames.

- Unicast Frames

Shows the number of sent unicast frames.

- Average Data Rate

Shows the average data rate of the last data frames sent.

## 6.4.16 WLAN iFeatures

### 6.4.16.1 iREF Client List

The WBM page shows the antenna connector via which the clients logged on to the access point communicate. Other information such as the signal strength and the MAC address of the WLAN interface is also shown.

---

**Note**

- This WBM page is only available in access point mode.
  - This WBM page can only be configured with the following KEY-PLUG:
    - Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
-

**industrial Range Extension Function Clients**

iREF Client List
iREF WDS List
AeroScout
iPRP

Associated stations: -

AID	Radio	Port	MAC Address	System Name	TX Chain	Signal Strength [dBm]	Signal Strength [%]	Age [s]
<div>Refresh</div>								

## Description

The page contains the following box:

- **Logged-on Clients**

Shows the number of clients logged on to the access point

The table has the following columns:

- **AID (Associated ID)**

Shows the connection ID of the client. If the client connects to the access point via the VAP interface, the client is assigned a connection ID. The connection ID is unique within a VAP interface. If two clients log on at different VAP interfaces, both clients can receive the same ID.

- **Radio**

Shows the available WLAN interfaces.

- **Port**

Shows the VAP interface.

- **MAC Address**

Shows the MAC address of the client.

- **System Name**

Shows the system name of the client if the client communicates this to the access point. Not all clients support this parameter.

- **Tx Chain**

Shows the antenna connector over which the client communicates with the access point.

- **Signal Strength [dBm]**

Shows the signal strength of the connected client in decibel milliwatts.

- **Signal strength [%]**

Shows the signal strength of the connected client as a percentage.

- **Age [s]**

- Shows the age of the listed client.

### 6.4.16.2 iREF WDS List

The WBM page shows the access points logged on to the access point via a WDS link. This page shows information such as the antenna used and the signal strength of the WLAN interface.

#### Note

- This WBM page is only available in access point mode.
- This WBM page can only be configured with the following KEY-PLUG:
  - Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)

**Industrial Range Extension Function WDS Partners**

iREF Client List iREF WDS List AeroScout iPRP

Connected WDS Partners: -

Radio	Port	BSSID	WDS ID	TX Chain	Signal Strength [dBm]	Signal Strength [%]
<div>Refresh</div>						

## Description

The page contains the following box:

- **Connected WDS partners**

Shows the number of access points logged on to the access point

The table has the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Port**

Shows the WDS interface.

- **BSSID**

Shows the MAC address of the WDS partner.

- **WDS ID**

Shows the name of the WDS partner.

- **Tx Chain**

Shows the antenna connector over which the two access points communicate with each other.

- **Signal Strength [dBm]**

Shows the signal strength of the connected access point in decibel milliwatts.

- **Signal strength [%]**

Shows the signal strength of the connected access point as a percentage.

### 6.4.16.3 AeroScout

This page shows information on forwarding AeroScout frames.

---

#### Note

- This WBM page is only available in access point mode.
  - This WBM page can only be configured with the following KEY-PLUG:  
Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
- 

#### Note

The AeroScout function cannot be combined with other iFeatures (iPCF, iPCF-MC,, iREF). AeroScout can only be used in the 2.4 GHz band according to IEEE 802.11g, IEEE 802.11n and IEEE 802.11n-only.

For more detailed information, please refer to the documentation of the AeroScout company ([www.aeroscout.com](http://www.aeroscout.com)).

---

## Description

- **Tag Information Forwarding**

In the management program that evaluates the AeroScout frames, you can specify whether or not a SCALANCE W700 device will forward frames. Here, you can see which setting was made in the management program.

---

### Note

With a suitable configuration, the SCALANCE W700 forwards AeroScout frames but does not process or evaluate them itself. This is done only in the "AeroScout System Manager" program.

---

- **AeroScout status**

Shows whether AeroScout is enabled or disabled.

- **Engine port**

The SCALANCE W700 device expects UDP packets from the management program at port 1144.

- **Response IP**

The IP address of the computer on which the management program for evaluation of the AeroScout frames is running.

- **Multicast address**

The tag sends frames as multicast. This multicast address is configured in the management program and displayed here.

- **Sent confirmations**

The number of confirmations sent by the SCALANCE W700 device to the management program as a result of cyclic queries or manual configuration changes in the management program (UDP packets).

- **Discarded messages**

The number of frames not forwarded. If, for example, an AeroScout tag is configured so that it sends on channel 1, the SCALANCE W700 device does not forward a frame received on channel 6.

#### 6.4.16.4 iPRP

On this WBM page you can check whether the settings for iPRP are correct. You can, for example, see which device is the partner client.

##### Note

This WBM page can only be configured with the following KEY-PLUGs:

- Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
- Client: W740 iFeatures (MLFB 6GK5 907-4PA00)

Display in access point mode

iPRP Information								
iPRP								
Radio	Port	iPRP Client	Activity State	Partner Client	Partner BSS	Delete Frames Sent	Delete Frames Received	Frames Deleted
WLAN 1	VAP 1.1	00-1b-a5-2c-d8	active	00-1b-1b-8e-61-31	00-1b-1b-19-03-10	64759	53532	921
WLAN 2	VAP 2.1	00-1b-1b-8e-61-31	active	00-1b-a5-2c-d8	00-1b-1b-19-03-08	3574	6385	2929
Refresh								

Display in client mode

iPRP Information								
iPRP								
Radio	iPRP Client	Activity State	Partner Client	Partner BSS	Delete Frames Sent	Delete Frames Received	Frames Deleted	Scanning Sync. State
WLAN 1	00-1b-1b-a5-2c-d8	active	00-1b-1b-8e-61-31	00-1b-1b-19-03-10	25424	19956	4817	idle
Refresh								

## Description

The table has the following columns:

- **Radio**  
Shows the WLAN interfaces via which the client is connected to the access point
- **Port** (only in access point mode)  
Shows the VAP interface on which the iPRP clients are logged on.
- **iPRP Client**  
Shows the MAC address of the iPRP client.
- **ActivationState**  
Shows whether or not iPRP is enabled.
- **Partner Client**  
Shows the MAC address of the partner client.
- **Partner BSS**  
Shows the MAC address of the access point to which the partner client is connected.
- **Delete Frames Sent**  
Shows the number of iPRP delete frames that the device (access point / client) has sent to its partner device.
- **Delete Frames Received**  
Shows the number of iPRP delete frames that the device (access point / client) has received from its partner device.
- **Frames Deleted**  
Shows the number of frames not yet sent that were deleted from the queue due to the iPRP delete frame.
- **Scanning Sync State** (in client mode only)  
So that both clients do not search for an access point and change to the scan mode at the same time they synchronize with each other.  
Synchronization can have the following statuses:
  - idle: Idling No scanning
  - requested: Query to the partner client whether scanning is possible.
  - pending: Scanning is possible. Waits for the start of scanning and then changes to the status "foreground" or "background".
  - background: Background scan is performed.
  - foreground: The client has, for example, just started up and is running a foreground scan.

## 6.5 "System" menu

### 6.5.1 System Configuration

#### System configuration

The WBM page contains the configuration overview of the access options of the device.

Specify the services that access the device. With some services, there are further configuration pages on which more detailed settings can be made.

**System Configuration**

☒ Telnet Server  
☒ SSH Server  
☐ HTTPS Server only  
☒ DNS Client  
☐ SMTP Client  
☐ Syslog Client

DCP Server: Read/Write ▼  
Time: Manual ▼  
SNMP: SNMPv1/v2c/v3 ▼

☐ SNMPv1/v2 Read-Only  
☐ SNMPv1 Traps  
☐ DHCP Client  
☒ DHCPv6 Client  
☒ SINEMA Configuration Interface

Configuration Mode: Automatic Save ▼  
Write Startup Config

Set Values Refresh

#### Description of the displayed boxes

The page contains the following boxes:

- **Telnet Server**  
Enable or disable the "Telnet Server" service for unencrypted access to the CLI.
- **SSH Server**  
Enable or disable the "SSH Server" service for encrypted access to the CLI.
- **HTTPS Server only**  
Enable or disable access using HTTPS.

- **DNS Client**

Enable or disable the DNS client. You can configure other settings in "System > DNS".

- **SMTP Client**

Enable or disable the SMTP client. You can configure other settings in "System > SMTP Client".

- **Syslog Client**

Enable or disable the Syslog client. You can configure other settings in "System > Syslog Client".

- **DCP Server**

Specify whether or not the device can be accessed with DCP (Discovery and Configuration Protocol):

- "-" (disabled)  
DCP is disabled. Device parameters can neither be read nor modified.
- Read/Write  
With DCP, device parameters can be both read and modified.
- Read Only  
With DCP, device parameters can be read but cannot be modified.

- **Time**

Select the setting from the drop-down list. The following settings are possible:

- Manual  
The system time is set manually. You can configure other settings in "System > System Time > Manual Setting".
- SIMATIC Time  
The system time is set using a SIMATIC time transmitter. You can configure other settings in "System > System Time > SIMATIC Time Client".
- SNTP Client  
The system time is set via an SNTP server. You can configure other settings in "System > System Time > SNTP Client".
- NTP Client  
The system time is set via an NTP server. You can configure other settings in "System > System Time > NTP Client".

- **SNMP**

Select the protocol from the drop-down list. The following settings are possible:

- "-" (SNMP disabled)  
Access to device parameters via SNMP is not possible.
- SNMPv1/v2c/v3  
Access to device parameters is possible with SNMP versions 1, 2c or 3. You can configure other settings in "System > SNMP > General".
- SNMPv3  
Access to device parameters is possible only with SNMP version 3. You can configure other settings in "System > SNMP > General".

- **SNMPv1/v2 Read-Only**

Enable or disable write access to SNMP variables with SNMPv1/v2c.

- **SNMPv1 Traps**

Enable or disable the sending of traps (alarm frames). You can configure other settings in "System > SNMP > Traps".

- **DHCP Client**

Enable or disable the DHCP client. You can configure other settings in "System > DHCP".

- **DHCPv6 Client**

Enable or disable the DHCPv6 client.

- **SINEMA configuration interface**

If the SINEMA configuration interface is enabled, you can download configurations to the device via the TIA Portal.

- **Configuration Mode**

Select the mode from the drop-down list. The following modes are possible:

- **Automatic Save**

Automatic backup mode. Approximately 1 minute after the last parameter change or when you restart the device, the configuration is automatically saved. In addition to this, the following message appears in the display area "Changes will be saved automatically in x seconds. Press 'Write Startup Config' to save immediately.

---

**Note**

**Interrupting the save**

Saving starts only after the timer in the message has elapsed. How long saving takes depends on the device.

During the save, the message "Saving configuration data in progress. Please do not switch off the device" is displayed.

- Do not switch off the device immediately after the timer has elapsed.
- 

- **Trial**

Trial mode. In Trial mode, although changes are adopted, they are not saved in the configuration file (startup configuration).

To save changes in the configuration file, use the "Write startup config" button. The "Write startup config" button is displayed when you set trial mode. In addition to this after every parameter change the following message is displayed in the display area: "Trial Mode Active – Press "Write Startup Config" button to make your settings persistent" as soon as there are unsaved modifications. This message can be seen on every WBM page until the changes made have either been saved or the device has been restarted.

## Procedure

1. To use the required function, select the corresponding check box.
2. Select the options you require from the drop-down lists.
3. Click the "Set Values" button.

## 6.5.2 General

### 6.5.2.1 Device

#### General device information

This page contains the general device information.

The screenshot shows a web interface titled "Device". Below the title is a tabbed interface with two tabs: "Device" (selected) and "Coordinates". The "Device" tab displays the following information:

- Current System Time: 07/21/2015 13:06:01
- System Up Time: 4h 56m 25s
- Device Type: SCALANCE
- System Name: sysName Not Set
- System Contact: sysContact Not Set
- System Location: sysLocation Not Set

At the bottom of the form are two buttons: "Set Values" and "Refresh".

The boxes "Current System Time", "System Up Time" and "Device Type" cannot be changed.

## Description

The page contains the following boxes:

- **Current System Time**  
Shows the current system time. The system time is either set by the user or by a time-of-day frame: either SINEC H1 time-of-day frame, NTP or SNTP. (readonly)
- **System Up Time**  
Shows the operating time of the device since the last restart. (readonly)
- **Device Type**  
Shows the type designation of the device. (readonly)
- **System Name**  
You can enter the name of the device. The entered name is displayed in the selection area. A maximum of 255 characters are possible.

The system name is also displayed in the CLI input prompt. The number of characters in the CLI input prompt is limited. The system name is truncated after 16 characters.

- **System Contact**

You can enter the name of a contact person responsible for managing the device. A maximum of 255 characters are possible.

- **System Location**

You can enter the location where the device is installed. The entered installation location is displayed in the selection area. A maximum of 255 characters are possible.

---

**Note**

The ASCII code 0x20 to 0x7e is used in the input boxes.

---

**Procedure**

1. Enter the contact person responsible for the device in the "System Contact" input box.
2. Enter the identifier for the location at which the device is installed in the "System Location" input box.
3. Enter the name of the device in the "System Name" input box.
4. Click the "Set Values" button.

**6.5.2.2 Coordinates****Information on geographic coordinates**

In the "Geographic Coordinates" window, you can enter information on the geographic coordinates. The parameters of the geographic coordinates (latitude, longitude and the height above the ellipsoid according to WGS84) are entered directly in the input boxes of the "Geographic Coordinates" window.

**Getting the coordinates**

Use suitable maps for obtaining the geographic coordinates of the device.

The geographic coordinates can also be obtained using a GPS receiver. The geographic coordinates of these devices are normally displayed directly and only need to be entered in the input boxes of this page.

**Geographic Coordinates**

Device | Coordinates

Latitude: e.g. DD°MM'SS"

Longitude: e.g. DDD°MM'SS"

Height: e.g. dddd m

Set Values Refresh

## Description

The page contains the following input boxes with a maximum length of 32 characters.

- **"Latitude" input box**

Geographical latitude: Here, enter the value for the northerly or southerly latitude of the location of the device.

For example, the value +49° 1'31.67" means that the device is located at 49 degrees, 1 arc minute and 31.67 arc seconds northerly latitude.

A southerly latitude is shown by a preceding minus character.

You can also append the letters N (northerly latitude) or S (southerly latitude) to the numeric information (49° 1'31.67" N).

- **"Longitude" input box**

Geographic longitude: Here, you enter the value of the eastern or western longitude of the location of the device.

The value +8° 20'58.73" means that the device is located at 8 degrees, 20 minutes and 58.73 seconds east.

A western longitude is indicated by a preceding minus sign.

You can also add the letter E (easterly longitude) or W (westerly longitude) to the numeric information (8° 20'58.73" E).

- **Input box: "Height"**

Height Here, you enter the value of the geographic height above sea level in meters.

For example, 158 m means that the device is located at a height of 158 m above sea level.

Heights below sea level (for example the Dead Sea) are indicated by a preceding minus sign.


## Procedure

1. Enter the calculated latitude in the "Latitude" input box.
2. Enter the calculated longitude in the "Longitude" input box.
3. Enter the height above sea level in the "Height" input box.
4. Click the "Set Values" button.

### 6.5.3 Agent IPv4

#### Configuration of the IP addresses

On this WBM page, you configure the IPv4 address for the device.



**Agent Internet Protocol v4 (IPv4)**

IP Assignment Method: **Static**

IP Address: 192.168.16.177

Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

Agent VLAN ID: VLAN1 ▼

MAC Address: 00-1b-1b-38-5c-90

#### Description

The page contains the following boxes:

- **IP Assgn. Method**
  - Shows how the IPv4 address is assigned.
    - Static  
The IPv4 address is static. You enter the IP settings in the input boxes "IP Address" and "Subnet Mask".
    - Dynamic (DHCP)  
The device obtains a dynamic IPv4 address from a DHCP server.
- **IP Address**

Enter the IPv4 address of the device.  
After clicking the "Set Values" button, this IPv4 address is also displayed in the address bar of the Web browser. If this does not take place automatically, you will need to enter the IPv4 address in the address bar of the Web browser manually.
- **Subnet Mask**

Enter the subnet mask of the device.
- **Default Gateway**

Enter the IPv4 address of the default gateway to be able to communicate with devices in another subnet, for example diagnostics stations, e-mail server.
- **Agent VLAN ID**

Select the VLAN ID from the drop-down list. The drop-down list is available only if the "Base Bridge Mode" parameter is set to "802.1 Q VLAN Bridge". You configure the

parameter in "Layer 2 > VLAN > General". You can only select VLANs that have already been configured.

#### Note

#### Changing the Agent VLAN ID

If the configuration PC is connected directly to the device via Ethernet and you change the agent VLAN ID, the device is no longer reachable via Ethernet following the change.

- **MAC Address**

Shows the MAC address of the device. The MAC address is linked to the hardware and cannot be modified.

## Procedure

1. In the input boxes, enter the IP address, subnet mask and the default gateway.
2. Select the assigned VLAN ID from the "Agent VLAN ID" drop-down list. If the drop-down list cannot be enabled, check whether the "Base Bridge Mode" parameter is set to "802.1 Q VLAN Bridge". You configure the parameter in "Layer 2 > VLAN > General".
3. Click the "Set Values" button.

## 6.5.4 Agent IPv6

### Configuration of the IP addresses

On this page, enable IPv6 on the management VAN. This VLAN interface is also called an IPv6 interface. An IPv6 interface can have several IPv6 addresses.

### Agent Internet Protocol v6 (IPv6)

Agent IPv6

IPv6 Default Routes

Interface: vlan1

☒ IPv6 Enable

IPv6 Address: 
Prefix Length: 
IPv6 Address Type: Unicast
Address Configuration: Automatic

☐ DHCPv6 Rapid Commit

Select	Interface Name	IPv6 Address	Prefix Length	IPv6 Address Type	Loopback
<input type="checkbox"/>	vlan1	FE80::21B:1BFF:FE38:5C90	64	Link Local	

1 entry.

Create

Delete

Set Values

Refresh

## Description

The page contains the following:

- **Interface**

Shows the VLAN interface on which IPv6 will be enabled.

- **IPv6 Enable**

Enable or disable IPv6 on the interface. When you enable the setting and accept it, the link local address is created automatically.

- **IPv6 Address**

Enter the IPv6 address. The entry depends on the selected address type.

- **Prefix Length**

Enter the number of left-hand bits belonging to the prefix

- **IPv6 Address Type**

Select the address type:

- Unicast
- Link Local: IPv6 address is only valid on the link.

- **Address Configuration**

Specify the mechanism for the address configuration:

- Automatic (default)  
The IPv6 address is created using a stateless mechanism or a stateful mechanism.
- DHCPv6  
Status dependent: Obtains the IPv6 address and the configuration file from the DHCPv6 server.
- SLAAC (Stateless Address Auto Configuration)  
Stateless autoconfiguration using NDP (Neighbor Discovery Protocol)
- Static  
Enter a static IPv6 address.

- **DHCPv6 Rapid Commit**

When enabled the procedure for the IPv6 address assignment is shortened. Instead of 4 DHCPv6 messages (SOLICIT, ADVERTISE, REQUEST, REPLY) only 2 DHCPv6 messages (SOLICIT, REPLY) are used. You will find further information on the messages in RFC 3315.

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Interface Name**

Shows the name of the VLAN interface.

- **IPv6 Address**  
Shows the IPv6 address.
- **Prefix Length**  
Shows the prefix length.
- **IPv6 Address Type**  
Displays the address type. The following values are possible:
  - Unicast
  - Link Local
- **Loopback**  
Shows whether or not the "loopback" property is enabled.

## Procedure

### Forming a link local address automatically

1. Enable IPv6.
2. Click the "Create" button. In the table an entry with the interface is created and the automatically formed link local IPv6 address is displayed.

### Assigning link local address

1. Enable IPv6.
2. In "IPv6 Address" enter the link local address, e.g. FE80::21B:1BFF:FE40:9155
3. Enter "128" in "Prefix Length".
4. For "IPv6 Address Type" select the entry "Link Local".
5. For "Address Configuration" select the entry "Static".
6. Click the "Create" button. In the table an entry with the interface is created and the IPv6 address is displayed.  
The automatically created local address is overwritten.

### 6.5.4.1 IPv6 default routes

On this page, you configure the IPv6 default route. The IPv6 default route is an IPv6 route, that applies to all IPv6 addresses. The device only needs to know the default gateway and sends all IPv6 packets to it.

The default gateway either knows all routes itself or has a default route to another default gateway.

Internet Protocol v6 (IPv6) Default Routes

Agent IPv6 IPv6 Default Routes

Destination Network: ::  
 Prefix Length:   
 Gateway:   
 Administrative Distance: 1  
 Interface:

Select	Destination Network	Prefix Length	Gateway	Interface	Administrative Distance	Status
<input type="checkbox"/>	::	96	2222:4::2222	vlan1	1	active

1 entry.

## Description

The page contains the following:

- **Destination Network**

Destination Network (:: or 0:0:0:0:0:0:0:0:0:0:0:0:0:0:0:0) applies to all IPv6 addresses.

- **Prefix Length**

Enter the number of left-hand bits belonging to the prefix

- **Gateway**

Enter the IPv6 address of the gateway to which the IPv6 packets will be sent.

- **Administrative Distance**

Enter the metric for the route. The metric corresponds to the quality of a connection, based for example on speed or costs. If there are several equal routes, the route with the lowest metric value is used.

Range of values: 1 - 254

- **Interface**

Specify the interface via which the network address of the destination is reached.

This table contains the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Destination Network**

Shows the network address of the destination.

- **Prefix Length**  
Shows the prefix length.
- **Gateway**  
Shows the IPv6 address of the next gateway.
- **Interface**  
Shows the Interface of the route.
- **Administrative Distance**  
Enter the metric for the route. When creating the route, "not used" is entered automatically. The metric corresponds to the quality of a connection, based for example on speed or costs. If there are several equal routes, the route with the lowest metric value is used.  
Range of values: 1 - 254
- **Status**  
Shows whether or not the route is active.

### Steps in configuration

1. Enter the prefix length.
2. Enter the IPv6 address of the gateway.
3. Select the required interface.
4. Enter the metric of the route.
5. Click the "Create" button. A new entry is generated in the table.
6. Click the "Set Values" button.

## 6.5.5 DNS

On this page, you can manually configure up to 3 DNS servers with IPv4 or IPv6 addresses. Manually configured DNS servers are each assigned an index from 1 to 3. Using DHCP, the device can learn 2 DNS servers with IPv4 addresses. An index from 4 to 7 is automatically assigned to learned DNS servers.

If there is more than one DNS server, the order in the table specifies the order in which the servers are queried. The top server is queried first. A total of 7 DNS servers can be configured on the device. Manually configured DNS servers are given preference.

The DNS server (Domain Name System) assigns a domain name to an IP address so that a device can be uniquely identified.

If this function is enabled, the device can communicate with a DNS server as a DNS client. You have the option of entering names in IP address boxes.

---

**Note**

The "DNS client" function can only be used if there is a DNS server in the network.

---

**Domain Name System (DNS) Client**

☒ DNS Client

Used DNS Servers: all ▼

DNS Server Address:

Select	DNS Server Address	Origin
<input type="checkbox"/>	192.1.1.1	manual

1 entry.

Create Delete Set Values Refresh

**Description**

The page contains the following boxes:

- **DNS client**

If the check box is enabled, the "DNS client" function is enabled.

- **Used DNS Servers**

Here you specify which DNS server the device uses:

- learned only

The device uses only the DNS servers assigned by DHCP.

- manual only

The device uses only the manually configured DNS servers. The DNS servers must be connected to the Internet. A maximum of three DNS servers can be configured.

- all

The device uses all available DNS servers.

- **DNS Server Address**

Enter the IP address of the DNS server.

The table for the DNS servers with the following columns:

- **Select**  
Select the check box in the row to be deleted.
- **DNS Server Address**  
Shows the IP address of the DNS server.
- **Origin**  
This shows whether the DNS server was configured manually or was assigned by DHCP.

## Procedure

### Activating DNS

1. Enable the "DNS Client" check box.
2. Click the "Set Values" button.

### Creating a DNS server

1. In the "DNS Server Address" box, enter the IP address of the DNS server.
2. Click the "Create" button.

### Filtering DNS servers

1. In the "Used DNS Servers" drop-down list, select which DNS servers are to be used.
2. Click the "Set Values" button.


### Deleting a DNS server

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

## 6.5.6 Restart

### Resetting to the defaults

In this screen, there is a button with which you can restart the device and various options for resetting to the device defaults.



---

**Note**

Note the following points about restarting a device:

- You can only restart the device with administrator privileges.
  - A device should only be restarted with the buttons of this menu or with the appropriate CLI commands and not by a power cycle on the device.
  - Any modifications you have made only become active on the device after clicking the "Set values" button on the relevant WBM page. If the device is in "Trial" mode, configuration modifications must be saved manually before a restart. In "Automatic Save" mode, the last changes are saved automatically before a restart.
-

## Description

To restart the device, the buttons on this page provide you with the following options:

- **Restart**

Click this button to restart the system. You must confirm the restart in a dialog box. During a restart, the device is reinitialized, the internal firmware is reloaded, and the device runs a self-test. The learned entries in the address table are deleted. You can leave the browser window open while the device restarts. You then need to log in again.

- **Restore Memory Defaults and Restart**

Click this button to restore the factory configuration settings with the exception of the following parameters and to restart:

- IP addresses
- Subnet mask
- IP address of the default gateway
- DHCP client ID
- DHCP
- System name
- System location
- System contact
- User names and passwords
- Mode of the device
- DHCPv6 Rapid Commit

- **Restore Factory Defaults and Restart**

Click this button to restore the factory defaults for the configuration. The protected defaults are also reset.

An automatic restart is triggered.

---

### Note

By resetting all the defaults to the factory configuration settings, the IP address is also lost. Following this, the device can only be accessed using the Primary Setup Tool or using DHCP.

With the appropriate connection, a previously correctly configured device can cause circulating frames and therefore the failure of the data traffic.

---

## 6.5.7 Commit Control

### Change management

On this page, you specify when the WLAN settings become effective on the SCALANCE W device.

If you change a WLAN setting and confirm the change with "Set Values", this change is adopted and takes effect immediately. To do this, the WLAN connection is briefly interrupted. This means that you can lose the WLAN connection to your SCALANCE W device before it is fully configured.

With the "Manual Commit" setting, you have the opportunity of first fully configuring the SCALANCE W device. The changes are accepted, but are not active immediately. The changes only take effect when you confirm the changes with the "Commit Changes" button.

---

#### Note

If you configure the SCALANCE W device via the WLAN interface, we recommend that you use the "Manual Commit" setting. Check the parameters again before you confirm the changes with the "Commit Changes" button.

---



### Description

The page contains the following boxes:

- **Commit Mode**

Select the required setting from the drop-down list.

- Automatic Commit

Each change in the WLAN settings is adopted and is immediately effective when you click the "Set Values" button. In the default setting, the SCALANCE W device is set to "Automatic Commit".

- Manual Commit

The changes are accepted, but are not effective immediately. The changes only take effect when you click the "Commit Changes" button. The "Commit Changes" button is displayed when you set "Manual Commit". In addition to this the message "Manual Commit Mode active - Press 'Commit Changes' button to provide current configuration to driver." appears as soon as there are WLAN changes. This message can be seen

on every WBM page until either the changes made have taken effect or the SCALANCE W device has been restarted.

#### Note

When the changes take effect, the WLAN connections to all WLAN interfaces will be interrupted for a short time. The WLAN driver is started with the new settings.

## 6.5.8 Load & Save

#### Note

The files that can be loaded from the device depends on the role of the logged-on.

### Overview of the file types

Table 6- 1 HTTP

File type	Description	Down-load	Save	Delete
Config	This file contains the start configuration. Among other things, this file contains the definitions of the users, roles, groups and function rights. The passwords are stored in the "Users" file.	X	X	--
ConfigPack	Detailed configuration information. for example, start configuration, users, certificates, favorites, firmware of the device (if saved as well). For more detailed information on creating and using the ConfigPack incl. firmware, refer to the section "Maintenance (Page 415)".	X	X	--
CountryList	The zip file contains the country list as a csv and as a pdf file.	--	X	--
Debug	This file contains information for Siemens Support. It is encrypted and can be sent by e-mail to Siemens Support without any security risk.	--	X	X
EDS	Electronic Data Sheet (EDS) Electronic data sheets for describing devices in the EtherNet/IP mode	--	X	--
Firmware	The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.	X	X	--
GSDML	Information on the device properties (PROFINET)	--	X	--
HTTPS Cert	HTTPS certificate Maximum file size: 8192 bits	X	X	X
LogFile	File with entries from the event log table	--	X	--

File type	Description	Down-load	Save	Delete
MIB	Private MSPS MIB file "Scalance_w_msp.mib"	--	X	--
RunningCLI	Text file with CLI commands This file contains an overview of the current configuration in the form of CLI commands. Passwords are masked in this file as follows: [PASSWORD] You can download the text file. The file is not intended to be uploaded again unchanged.	--	X	--
Script	Text file with CLI commands	X	--	--
StartupInfo	Startup log file This file contains the messages that were entered in the log file during the last startup.	--	X	--
Users	File with user names and passwords	X	X	--
WBMFav	WBM favorites This file contains the favorites that you created in the WBM. You can download this file and upload it to other devices.	X	X	X
WLANAuthlog	File with entries from the WLAN Authentication Log (information on successful or failed authentication attempts)	--	X	--
WLANCert (in client mode only)	User certificate. You can specify a password for the user certificate on the WBM page "Load&Save > Password". Maximum file size: 8192 bits	X	X	X
WLANServCert (in client mode only)	Server certificate Maximum file size: 8192 bits	X	X	X
WLANSigRec (in client mode only)	The zip file contains the following: <ul style="list-style-type: none"> <li>csv file with the measured values of the signal recorder</li> <li>pdf file with the measured values and an additional graphic representation of the measured values.</li> </ul> You will find information about the measured values and their graphic representation in the section "Signal recorder (Page 295)".	--	X	X
WLANSpectrumAnalyzer (Only in access point mode)	The Zip file contains a csv file with the measured values of the spectrum analyzer. You will find information about the measured values and their graphic representation in the section "Spectrum analyzer (Page 306)".	--	X	X

Table 6- 2 TFTP/SFTP

File type	Description	Save	Down-load
Config	This file contains the start configuration. Among other things, this file contains the definitions of the users, roles, groups and function rights. The passwords are stored in the "Users" file.	X	X
ConfigPack	Detailed configuration information. for example, start configuration, users, certificates, firmware of the device (if saved as well). For more detailed information on creating and using the ConfigPack incl. firmware, refer to the section "Maintenance (Page 415)".	X	X
CountryList	The zip file contains the country list as a csv and as a pdf file.	X	--
Debug	This file contains information for Siemens Support. It is encrypted and can be sent by e-mail to Siemens Support without any security risk.	X	--
EDS	Electronic Data Sheet (EDS) Electronic data sheets for describing devices in the EtherNet/IP mode	X	--
Firmware	The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.	X	X
GSDML	Information on the device properties (PROFINET)	X	--
HTTPS Cert	Preset HTTPS certificates including key The preset and automatically created HTTPS certificates are self-signed. We strongly recommend that you create your own HTTPS certificates and make them available. We recommend that you use HTTPS certificates signed either by a reliable external or by an internal certification authority. The HTTPS certificate checks the identity of the device and controls the encrypted data exchange. There are files to which access is password-protected. To successfully load the file into the device, enter the password specified for the file on the WBM page "Passwords (Page 352)". Maximum file size: 8192 bits	X	X
LogFile	File with entries from the event log table	X	--
MIB	Private MSPS MIB file "Scalance_w_msps.mib"	X	--
RunningCLI	Text file with CLI commands This file contains an overview of the current configuration in the form of CLI commands. Passwords are masked in this file as follows: [PASSWORD] You can download the text file. The file is not intended to be uploaded again unchanged.	X	--

File type	Description	Save	Down-load
Script	Text file with CLI commands You can upload a script file in a device. The CLI commands it contains are executed accordingly. CLI commands for saving and loading files cannot be executed with the CLI script file.	--	X
StartupInfo	Startup log file This file contains the messages that were entered in the log file during the last startup.	X	--
Users	File with user names and passwords	X	X
WBM Fav	WBM favorites This file contains the favorites that you created in the WBM. You can download this file and upload it to other devices.	X	X
WLANAuthlog	File with entries from the WLAN Authentication Log (information on successful or failed authentication attempts)	X	--
WLANCert (in client mode only)	User certificate. You can specify a password for the user certificate on the WBM page "Load&Save > Password". Maximum file size: 8192 bits	X	X
WLANServerCert (in client mode only)	Server certificate Maximum file size: 8192 bits	X	X
WLANSigRec (in client mode only)	The zip file contains the following: <ul style="list-style-type: none"> <li>csv file with the measured values of the signal recorder</li> <li>pdf file with the measured values and an additional graphic representation of the measured values.</li> </ul> You will find information about the measured values and their graphic representation in the section "Signal recorder (Page 295)".	X	--
WLANSpectru- mAnalyzer (Only in access point mode)	The Zip file contains a csv file with the measured values of the spectrum analyzer. You will find information about the measured values and their graphic representation in the section "Spectrum analyzer (Page 295)".	X	--

### 6.5.8.1 HTTP

#### Loading and saving data via HTTP

The WBM allows you to store device data in an external file on your client PC or to load such data from an external file from the PC to the devices. This means, for example, that you can also load new firmware from a file located on your client PC.

---

##### Note

This WBM page is available both for connections using HTTP and for connections using HTTPS.

---

##### Firmware

The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.

---

##### Note

##### Incompatibility with predecessor versions

During the installation of a previous version, the configuration data and log files can be lost. In this case, the device starts up with the factory settings after the firmware has been installed.

##### Incompatibility with previous versions with PLUG inserted

During the installation of a previous version, the configuration data and log files can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "Not Accepted" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data. If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using the WBM page "System > PLUG".

---

##### Configuration files

---

##### Note

##### Configuration files and trial mode/Automatic Save mode

In Automatic Save mode, the data is saved automatically before the configuration files (ConfigPack and Config) are transferred.

In Trial mode, although the changes are adopted, they are not saved in the configuration files (ConfigPack and Config). Use the "Write Startup Config" button on the "System > Configuration" WBM page to save changes in the configuration files.

---

##### CLI script file

You can download existing CLI configurations (RunningCLI) and upload your own CLI scripts (Script).

### Note

The downloadable CLI script (RunningCLI) is not intended to be uploaded again unchanged.

Load and Save via HTTP

HTTP

TFTP

SFTP

Passwords

Type	Description	Load	Save	Delete
Config	Startup Configuration	Load	Save	
ConfigPack	Startup Config, Users, Certificates and WBM favourites	Load	Save	
CountryList	WLAN Country List		Save	
Debug	Debug Information for Siemens Support		Save	Delete
EDS	EtherNet/IP Device Description		Save	
Firmware	Firmware Update	Load	Save	
GSDML	PROFINET Device Description		Save	
HTTPSCert	HTTPS Certificate	Load	Save	Delete
LogFile	Event Log (ASCII)		Save	
MIB	SCALANCE W MSPS MIB		Save	
RunningCLI	'show running-config all' CLI settings		Save	
Script	Script	Load		
StartupInfo	Startup Information		Save	
Users	Users and Passwords	Load	Save	
WBM Fav	WBM favourite pages	Load	Save	Delete
WLANAuthLog	Authentication Log (ASCII)		Save	
WLANCert	WLAN User Certificate	Load	Save	Delete
WLANServCert	WLAN Server Certificate	Load	Save	Delete
WLANSigRec	Signal Recorder		Save	Delete

Refresh

Example of a device in client mode

## Description

The table has the following columns:

- File type**

Shows the name of the file.

### Note

#### Size of certificate files

With certificate files only certificates with a maximum of 8192 bits are supported.

- Description**

Shows the short description of the file type.

- **Load**

With this button, you can load files on the device. The button can be enabled, if this function is supported by the file type.

- **Save**

With this button, you can save files from the device. The button can only be enabled if this function is supported by the file type and the file exists on the device.

- **Delete**

With this button, you can delete files from the device. The button can only be enabled if this function is supported by the file type and the file exists on the device.

---

**Note**

Following a firmware update, delete the cache of the Web browser.

---

## Procedure

### Loading files using HTTP

1. Start the load function by clicking the one of the "Load" buttons.

The dialog for loading a file opens.

2. Go to the file you want to load.
3. Click the "Open" button in the dialog.

The file is now loaded.

Whether or not a restart is necessary, depends on the loaded file. If a restart is necessary, a message to this effect will be output. Other files are executed immediately, for example the CLI script file and new settings are applied without a restart.

### Saving files using HTTP

1. Start the save function by clicking the one of the "Save" buttons. Depending on the size of the file this may take some time.
2. Depending on your browser configuration you will be prompted to select a storage location and a name for the file. Or you accept the proposed file name. To make the selection, use the dialog in your browser. After making your selection, click the "Save" button.

### Deleting files using HTTP

1. Start the delete function by clicking the one of the "Delete" buttons.

The file will be deleted.

### Reusing configuration data

If several devices are to receive the same configuration and the IP addresses are assigned using DHCP, the effort for configuration can be reduced by saving and reading in the configuration data.

Follow the steps below to reuse configuration data:

1. Save the configuration data of a configured device on your PC.
2. Download this configuration file to all other devices you want to configure.
3. If individual settings are necessary for specific devices, these must be made online on the relevant device.

---

**Note**

Configuration data has a checksum. If you edit the files, you can no longer upload them to the device.

---

### 6.5.8.2 TFTP

#### Loading and saving data via a TFTP server

On this page, you can configure the TFTP server and the file names. The WBM also allows you to store device data in an external file on your client PC or to load such data from an external file from the PC to the devices. This means, for example, that you can also load new firmware from a file located on your client PC.

#### Firmware

The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.

---

**Note**

#### Incompatibility with predecessor versions

During the installation of a previous version, the configuration data and log files can be lost. In this case, the device starts up with the factory settings after the firmware has been installed.

#### Incompatibility with previous versions with PLUG inserted

During the installation of a previous version, the configuration data and log files can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "Not Accepted" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data. If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using the WBM page "System > PLUG".

---

## Configuration files

### Note

#### Configuration files and trial mode/Automatic Save mode

In Automatic Save mode, the data is saved automatically before the configuration files (ConfigPack and Config) are transferred.

In Trial mode, although the changes are adopted, they are not saved in the configuration files (ConfigPack and Config). Use the "Write Startup Config" button on the "System > Configuration" WBM page to save changes in the configuration files.

### CLI script file

You can download existing CLI configurations (RunningCLI) and upload your own CLI scripts (Script).

### Note

The downloadable CLI script (RunningCLI) is not intended to be uploaded again unchanged.

Load and Save via TFTP

HTTP
TFTP
SFTP
Passwords

TFTP Server Address: 0.0.0.0  
TFTP Server Port: 69

Type	Description	Filename	Actions
Config	Startup Configuration	config_SCALANCE_W700.conf	Select action ▼
ConfigPack	Startup Config, Users, Certificates and WBM favourites	configpack_SCALANCE_W700.zip	Select action ▼
CountryList	WLAN Country List	countrylist_SCALANCE_W700.zip	Select action ▼
Debug	Debug Information for Siemens Support	debug_SCALANCE_W700.bin	Select action ▼
EDS	EtherNet/IP Device Description	eds_SCALANCE_W700.zip	Select action ▼
Firmware	Firmware Update	firmware_SCALANCE_W700.sfw	Select action ▼
GSDML	PROFINET Device Description	gsdml_SCALANCE_W700.zip	Select action ▼
HTTPSCert	HTTPS Certificate	https_cert	Select action ▼
LogFile	Event Log (ASCII)	logfile_SCALANCE_W700.csv	Select action ▼
MIB	SCALANCE W MSPS MIB	scalance_w_mspms.mib	Select action ▼
RunningCLI	'show running-config all' CLI settings	RunningCLI.txt	Select action ▼
Script	Script	Script.txt	Select action ▼
StartupInfo	Startup Information	startup_SCALANCE_W700.log	Select action ▼
Users	Users and Passwords	users.enc	Select action ▼
WBM Fav	WBM favourite pages	wbmfav.txt	Select action ▼
WLANAuthLog	Authentication Log (ASCII)	wlan_auth_log_SCALANCE_W700.csv	Select action ▼
WLANCert	WLAN User Certificate	wlan_user_cert	Select action ▼
WLANServCert	WLAN Server Certificate	wlan_serv_cert	Select action ▼
WLANSigRec	Signal Recorder	signal_recorder_SCALANCE_W700.zip	Select action ▼

Set Values
Refresh

Example of a device in client mode

## Description

The page contains the following boxes:

- **TFTP Server Address**

Here, enter the IP address or the FQDN (Fully Qualified Domain Name) of the TFTP server with which you exchange data.

- **TFTP Server Port**

Here, enter the port of the TFTP server via which data exchange will be handled. If necessary, you can change the default value 69 to your own requirements.

The table has the following columns:

- **Type**

Shows the name of the file.

---

**Note****Size of certificate files**

With certificate files only certificates with a maximum of 8192 bits are supported.

---

- **Description**

Shows the short description of the file type.

- **Filename**

Enter a file name.

- **Actions**

Select the action from the drop-down list. The selection depends on the selected file type, for example the log file can only be saved.

The following actions are possible:

- **Save file**

With this selection, you save a file on the TFTP server.

- **Load file**

With this selection, you load a file from the TFTP server.

## Procedure

### Loading or saving data using TFTP

1. Enter the IP address or the FQDN of the TFTP server in the "TFTP Server Address" input box.
2. Enter the server port to be used in the in the "TFTP server port" input box.
3. Enter the name of a file in which you want to save the data or take the data from in the "File name" input box.
4. Select the action you want to execute from the "Actions" drop-down list.

5. Click the "Set Values" button to start the selected actions. Depending on the size of the file this may take some time.
6. After loading the configuration and the SSL certificate, restart the device. The changes only take effect a restart.

#### **Reusing configuration data**

If several devices are to receive the same configuration and the IP addresses are assigned using DHCP, the effort for configuration can be reduced by saving and reading in the configuration data.

Follow the steps below to reuse configuration data:

1. Save the configuration data of a configured device on your PC.
2. Download this configuration file to all other devices you want to configure.
3. If individual settings are necessary for specific devices, these must be made online on the relevant device.

Note that the configuration data is coded when it is saved. This means that you cannot edit the files with a text editor.

### **6.5.8.3 SFTP**

#### **Loading and saving data via a SFTP server**

SFTP (SSH File Transfer Protocol) transfers the files encrypted. On this page, you configure the access data for the SFTP server.

The WBM also allows you to store device data in an external file on your client PC or to load such data from an external file from the PC to the devices. This means, for example, that you can also load new firmware from a file located on your Admin PC.

On this page, the certificates required to establish a secure VPN connection can also be loaded.

#### **Firmware**

The firmware is signed and encrypted. This ensures that only firmware created by Siemens can be downloaded to the device.

#### **Configuration files**

---

#### **Note**

##### **Configuration files and Trial mode /Automatic Save**

In "Automatic Save" mode, the data is saved automatically before the configuration files (ConfigPack and Config) are transferred.

In "Trial" mode, although the changes are adopted, they are not saved in the configuration files (ConfigPack and Config). Use the "Write Startup Config" button on the "System > Configuration" WBM page to save changes in the configuration files.

---

#### **CLI script file**

You can download existing CLI configurations (RunningCLI) and upload your own CLI scripts (Script).

**Note**

The downloadable CLI script is not intended to be uploaded again unchanged.

Load and Save via SFTP

HTTP TFTP SFTP Passwords

SFTP Server Address: 0.0.0.0

SFTP Server Port: 22

SFTP User:

SFTP Password:

SFTP Password Confirmation:

Type	Description	Filename	Actions
Config	Startup Configuration	config_SCALANCE_W700.conf	Select action
ConfigPack	Startup Config, Users, Certificates and WBM favourites	configpack_SCALANCE_W700.zip	Select action
ConfigPackBackup	ConfigPackBackup	configbackup_SCALANCE_W700.zip	Select action
CountryList	WLAN Country List	countrylist_SCALANCE_W700.zip	Select action
Debug	Debug Information for Siemens Support	debug_SCALANCE_W700.bin	Select action
EDS	EtherNet/IP Device Description	eds_SCALANCE_W700.zip	Select action
Firmware	Firmware Update	firmware_SCALANCE_W700.sfw	Select action
GSDML	PROFINET Device Description	gsdml_SCALANCE_W700.zip	Select action
HTTPSCert	HTTPS Certificate	https_cert	Select action
LogFile	Event Log (ASCII)	logfile_SCALANCE_W700.csv	Select action
MIB	SCALANCE W MSPS MIB	scalance_w_mspms.mib	Select action
RunningCLI	'show running-config all' CLI settings	RunningCLI.txt	Select action
Script	Script	Script.txt	Select action
StartupInfo	Startup Information	startup_SCALANCE_W700.log	Select action
Users	Users and Passwords	users.enc	Select action
WBM Fav	WBM favourite pages	wbmfav.txt	Select action
WLANAuthLog	Authentication Log (ASCII)	wlan_auth_log_SCALANCE_W700.csv	Select action
WLANCert	WLAN User Certificate	wlan_user_cert	Select action
WLANServCert	WLAN Server Certificate	wlan_serv_cert	Select action
WLANSigRec	Signal Recorder	signal_recorder_SCALANCE_W700.zip	Select action

Set Values Refresh

Example of a device in client mode

**Description**

The page contains the following boxes:

- **SFTP Server Address**  
Enter the IP address or the FQDN of the SFTP server with which you exchange data.
- **SFTP Server Port**  
Enter the port of the SFTP server via which data exchange will be handled. If necessary, you can change the default value 22 to your own requirements.
- **SFTP User**  
Enter the user for access to the SFTP server. This assumes that a user with the corresponding rights has been created on the SFTP server.
- **SFTP Password**  
Enter the password for the user
- **SFTP Password Confirmation**  
Confirm the password.

The table has the following columns:

- **Type**  
Shows the file type.
- **Description**  
Shows the short description of the file type.
- **Filename**  
A file name is preset here for every file type.

---

#### Note

##### Changing the file name

You can change the file name preset in this column. After clicking the "Set Values" button, the changed name is saved on the device and can also be used with the Command Line Interface.

---

- **Actions**  
Select the action from the drop-down list. The selection depends on the selected file type, for example you can only save the log file.  
The following actions are possible:
  - **Save file**  
With this selection, you save a file on the SFTP server.
  - **Load file**  
With this selection, you load a file from the SFTP server.

## Procedure

### Loading or saving data using SFTP

1. Enter the address of the SFTP server in "SFTP Server Address".
2. Enter the port of the SFTP server to be used in "SFTP Server Port".
3. Enter the user data (user name and password) required for access to the SFTP server.
4. If applicable, enter the name of a file in which you want to save the data or take the data from in "Filename".

---

#### Note

##### Files whose access is password protected

To be able to load these files on the device successfully, you need to enter the password specified for the file in "System" > "Load&Save" > "Passwords".

---

5. Select the action you want to execute from the "Actions" drop-down list.
6. Click "Set Values" to start the selected action.
7. If a restart is necessary, a message to this effect will be output. Click the "OK" button to run the restart. If you click the "Abort" button, there is no device restart. The changes only take effect after a restart.

### Reusing configuration data

If several identical devices are to receive the same configuration and the IP addresses are assigned using DHCP, the effort for reconfiguration can be reduced by saving and reading in the configuration data.

Follow the steps below to reuse configuration data:

1. Save the configuration data of a configured device on your PC.
2. Load these configuration files on all other devices you want to configure in this way.
3. If individual settings are necessary for specific devices, these must be made online on the relevant device.

---

#### Note

Configuration data has a checksum. If you change the data, you can no longer upload it to the IE switch.

---

### 6.5.8.4 Passwords

#### Password for certificates

With this menu item, you can enter a password for encrypted certificates.

User, server or HTTPS certificates can exist as PKCS#12 certificates (.p12 and .pfx) and PEM certificates (.pem).

---

#### Note

##### User and server certificate in one file

If the user and the server certificate are located in the same file, load this file on the device as the user certificate and as the server certificate.

---



---

#### Note

In Access Point mode, only the HTTPS certificate is available.

---

**Passwords**

HTTP TFTP SFTP Passwords

Type	Description	Enabled	Password	Password Confirmation	Status
HTTPSCert	HTTPS Certificate	<input type="checkbox"/>			-
WLANCert	WLAN User Certificate	<input type="checkbox"/>			-
WLANServCert	WLAN Server Certificate	<input type="checkbox"/>			-

Set Values Refresh

## Description

The table has the following columns:

- **Type**  
Shows the certificate.
- **Description**  
Shows a short description of the certificate.
- **Enabled**  
Specifies whether the certificate needs a password. If you enable the setting, specify the password in "Password".
- **Password**  
Enter the password for the certificate.

---

### Note

When assigning the password, you can only use the following readable ASCII characters: 0x20 - 0x7e.

---

- **Password Confirmation**  
Confirm the password.
- **State**  
Shows whether the current settings for the file match the device.
  - Valid  
the "Enabled" check box is selected and the password matches the certificate.
  - Invalid  
the "Enabled" check box is selected but the password does not match the certificate or no certificate has been loaded yet.
  - '-'  
The password cannot be evaluated or is not yet being used. The "Enabled" check box is not selected.

## Procedure

### Assigning the password

1. Enter the password in "Password".
2. To confirm the password, enter the password again in "Password Confirmation".
3. Select the "Enabled" option.
4. Click the "Set Values" button.

## 6.5.9 Events

### 6.5.9.1 Configuration

#### Selecting system events

On this page, you specify how a device reacts to system events. To enable or disable the options, click the relevant check boxes of the columns.

**Event Configuration**

Configuration
Severity Filters

	E-mail	Trap	Log Table	Syslog	Fault	Copy To Table
All Events	No Change ▼	No Change ▼	No Change ▼	No Change ▼	No Change ▼	Copy To Table

Event	E-mail	Trap	Log Table	Syslog	Fault
Cold/Warm Start	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Link Change	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Authentication Failure	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Power Change	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Spanning Tree Change	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Fault State Change	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Overlap AP Detection	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
WDS	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DFS	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
WLAN Authentication Log				<input checked="" type="checkbox"/>	
iPCF Cycle Time	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
iPCF Poll Size	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WLAN General	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Configuration Change	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Set Values
Refresh

#### Description

With Table 1, you can enable or disable all check boxes of a column of Table 2 at once. Table 1 has the following columns:

- **All Events**

Shows that the settings are valid for all events of table 2.

- **E-mail / Trap / Log Table / Syslog / Faults**

Enable or disable the required type of notification for all events. If "No Change" is selected, the entries of the corresponding column in table 2 remain unchanged.

- **Copy to table**

If you click the button, the setting is adopted for all events of table 2.

Table 2 has the following columns:

- **Event**

The column contains the following values:

- **Cold/warm restart**  
The device was turned on or restarted by the user.
- **Link Change**  
This event occurs only when the port status is monitored and has changed, see "System > Fault Monitoring > Link Change".
- **Authentication error**  
This event occurs when attempting access with a bad password.
- **Power Change**  
This event occurs only when power supply lines 1 and 2 are monitored. It indicates that there was a change to line 1 or line 2. The event occurs when the PoE power supply has failed, see "System > Fault Monitoring > Power Supply".
- **Spanning Tree Change**  
The STP or RSTP or MSTP topology has changed.
- **Fault State Change**  
The fault status has changed. The fault status can relate to the activated port monitoring, the response of the signaling contact or the power supply monitoring.
- **Overlap AP Detection (only in access point mode)**  
This event is triggered when there is an entry in the Overlap AP list.
- **WDS (Only in access point mode)**  
The connection status of a WDS link has changed.
- **DFS (Only in access point mode)**  
This event occurs if a radar signal was received or the DFS scan was started or stopped.
- **WLAN Authentication Log**  
Forwarding of the entries from the WLAN authentication log to the system protocol server.
- **WLAN De/Authentication(Only in client mode)**  
With successful or failed WLAN authentication attempts.
- **iPCF Cycle Time (Only in access point mode)**  
Only available when the KEY-PLUG is inserted.  
This event occurs if too many clients are logged on for the set iPCF cycle time or if some clients were not reached in one cycle.
- **iPCF Poll Size**  
Only available when the KEY-PLUG is inserted.  
This event occurs if the PROFINET data size is too large for transfer.
- **WLAN General (Only in access point mode)**  
This event occurs if a the channel bandwidth has changed.
- **Configuration Change**  
This event occurs when the configuration of the device has changed.

- **E-mail**  
The device sends an e-mail. This is only possible if the SMTP server is set up and the "SMTP client" function is enabled.
- **Trap**  
The device sends an SNMP trap. This is only possible if "SNMPv1 Traps" is enabled in "System > Configuration".
- **Log Table**  
The device writes an entry in the event log table.
- **Syslog**  
The device writes an entry to the system log server. This is only possible if the system log server is set up and the "Syslog client" function is enabled.
- **Faults**  
The device triggers an error. The error LED lights up.

## Procedure

Follow the steps below to change entries:

1. Select the check box in the row of the required event. Select the event in the column under the following actions:
  - E-mail
  - Trap
  - Log table
  - Syslog
  - Error
2. Click the "Set Values" button.

### 6.5.9.2 Severity Filters

On this page, you configure the severity for the sending of system event notifications.

Event Severity Filters	
Configuration   Severity Filters	
Client Type	Severity
E-mail	Info ▼
Log Table	Info ▼
Syslog	Info ▼
WLAN Authentication Log	Info ▼

Set Values Refresh

## Description

The table has the following columns:

- **Client Type**  
Select the client type for which you want to make settings:
  - **E-mail**  
Sending system event messages by e-mail
  - **Log Table**  
Entry of system events in the log table
  - **Syslog**  
Entry of system events in the Syslog file
  - **WLAN Authentication Log**  
Entry of system events in the WLAN authentication log
- **Severity**  
Select the required level. The following settings are possible:
  - **Critical**  
System events are processed as of the severity level "Critical".
  - **Warning**  
System events are processed as of the severity level "Warning".
  - **Info**  
System events are processed as of the severity level "Info".

## Procedure

Follow the steps below to configure the required level:

1. Select the required values from the drop-down lists of the second table column after the client types.
2. Click the "Set Values" button.

## 6.5.10 SMTP client

### Network monitoring with e-mails

The device provides the option of automatically sending an e-mail if an alarm event occurs (for example to the network administrator). The e-mail contains the identification of the sending device, a description of the cause of the alarm in plain language, and a time stamp. This allows centralized network monitoring to be set up for networks with few nodes based on an e-mail system. When an e-mail error message is received, the WBM can be started by the Internet browser using the identification of the sender to read out further diagnostics information.

On this page, you can configure up to three SMTP servers and the corresponding e-mail addresses.

**Simple Mail Transfer Protocol (SMTP) Client**

☐ SMTP Client

Sender Email Address: device@scalance

SMTP Port: 25

SMTP Server Address:

Select	SMTP Server Address	Receiver Email Address
<input type="checkbox"/>	192.168.16.20	service@scalance

1 entry.

### Description

The page contains the following boxes:

- **SMTP Client**  
Enable or disable the SMTP client.
- **Sender Email Address**  
Enter the name of the sender to be included in the e-mail, for example the device name.  
This setting applies to all configured SMTP servers.
- **Send Test Mail**  
Send a test e-mail to check your configuration.

- **SMTP Port**

Enter the port via which your SMTP server can be reached.

Factory settings: 25

This setting applies to all configured SMTP servers.

- **SMTP Server Address**

Enter the IP address, the FQDN (Fully Qualified Domain Name) or the host name of the SMTP server.

The table contains the following columns:

- **Select**

Select the check box in a row to be deleted.

- **SMTP Server Address**

Shows the IP address, the FQDN (Fully Qualified Domain Name) or the host name of the SMTP server.

- **Receiver Email Address**

Enter the e-mail address to which the device sends an e-mail if a fault occurs.

## Procedure

1. Enable the "SMTP Client" option.
2. Enter the IP address, the FQDN or the host name of the SMTP server in the "SMTP Server Address" input box.
3. Click the "Create" button. A new entry is generated in the table.
4. In the "Receiver Email Address" input box, enter the e-mail address to which the device sends an e-mail if a fault occurs.
5. Click the "Set Values" button.

---

### Note

Depending on the properties and configuration of the SMTP server, it may be necessary to adapt the "Sender E-Mail Address" input box for the e-mails. Check with the administrator of the SMTP server.

---

## 6.5.11 DHCPv4

### 6.5.11.1 DHCP client

#### Setting of the DHCP mode

If the device is configured as a DHCP client, it starts a DHCP query. As the reply to the query the device receives an IPv4 address from the DHCP server. The server manages an address range from which it assigns IPv4 addresses. It is also possible to configure the server so that the client always receives the same IPv4 address in response to its request.

Dynamic Host Configuration Protocol (DHCP) Client

DHCP Client | DHCP Server | DHCP Options | Static Leases

☒ DHCP Client Configuration Request (Opt.66, 67)

DHCP Mode: via MAC Address ▼

Interface	DHCP
vlan1	<input type="checkbox"/>
vlan2	<input type="checkbox"/>

Set Values Refresh

#### Description

The page contains the following boxes:

- **DHCP client configuration file request (opt. 66, 67)**  
Select this option if you want the DHCP client to use options 66 and 67 to download and then enable a configuration file.
- **DHCP Mode**  
Select the DHCP mode from the drop-down list. The following modes are possible:
  - via MAC Address  
Identification is based on the MAC address.
  - via DHCP Client ID  
Identification is based on a freely defined DHCP client ID.
  - via System Name  
Identification is based on the system name. If the system name is 255 characters long, the last character is not used for identification.
  - via PROFINET Name of Station  
The identification is made using the PROFINET device name.

The table has the following columns:

- **Interface**  
Interface to which the setting relates.
- **DHCP**  
Enable or disable the DHCP client for the relevant interface.

## Procedure

1. Select the required mode from the "DHCP Mode" drop-down list. If you select the DHCP mode "via DHCP Client ID" an input box appears.
  - In the enabled input box "DHCP client ID" enter a string to identify the device. This is then evaluated by the DHCP server.
2. Select the "DHCP Client Configuration Request (Opt. 66, 67)", if you want the DHCP client to use options 66 and 67 to download and then enable a configuration file.
3. Enable the "DHCP" option in the table.
4. Click the "Set Values" button.

---

### Note

If a configuration file is downloaded, this can trigger a system restart. If the currently running configuration and the configuration in the downloaded configuration file differ, the system is restarted.

Make sure that the option "DHCP Client Configuration Request (Opt. 66, 67)" is no longer set.

---

## 6.5.11.2 DHCP Server

You can operate the device as a DHCP server. This allows IPv4 addresses to be assigned automatically to the connected devices. The IPv4 addresses are either distributed dynamically from an address band you have specified or a specific IPv4 address (static) can be assigned to a particular device.

On this page, specify the IPv4 address band from which the device receives any IPv4 address.

You configure the static assignment of the IPv4 addresses in "Static Leases".

---

### Note

#### Maximum number of IP addresses

The maximum number of IPv4 addresses that the DHCP server supports is 100. In other words, a total of 100 IPv4 addresses (dynamic + static).

With the static assignments, you can create a maximum of 20 entries.

---

**Dynamic Host Configuration Protocol (DHCP) Server**

**DHCP Client** | **DHCP Server** | **Port Range** | **DHCP Options** | **Relay Agent Information** | **Static Leases**

☐ DHCP Server  
☐ Probe address with ICMP Echo before offer

Select	Pool ID	Interface	Enable	Subnet	Lower IP Address	Upper IP Address	Lease Time [sec]
<input type="checkbox"/>	1	vlan1	<input type="checkbox"/>	0.0.0.0/0	0.0.0.0	0.0.0.0	3600

1 entry.

### Requirements for the DHCP server

- In access point mode
  - The connected devices are configured so that they obtain the IPv4 address from a DHCP server.
- In client mode
  - The connected devices are configured so that they obtain the IPv4 address from a DHCP server.
  - NAT is enabled. You enable NAT in "Layer 3 > NAT"

## Description

The page contains the following boxes:

- **DHCP Server**

Enable or disable the DHCP server on the device.

---

**Note**

To avoid conflicts with IPv4 addresses, only one device may be configured as a DHCP server in the network.

---

**Note**

**Access point**

With an access point, the "DHCP Server" function is only possible on the VLAN assigned to the management (agent VLAN ID).

---

- **Probe address with ICMP Echo before offer**

When selected, the DHCP server checks whether or not the IP address has already been assigned. To do this the DHCP server sends ICMP echo messages (ping) to the IPv4 address. If no reply is received, the DHCP server can assign the IPv4 address.

---

**Note**

If there are devices in your network on which the echo service is disabled as default, there may be conflicts with the IPv4 addresses. To avoid this, assign these devices an IPv4 address outside the IPv4 address band.

---

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Pool ID**

Shows the number of the IPv4 address band. If you click the "Create" button, a new row with a unique number is created (pool ID).

---

**Note**

Only one Pool ID (ID = 1) can be created.

---

- **Interface**

Specify the interface via which the IPv4 addresses are dynamically assigned.

The requirement for the assignment is that the IPv4 address of the interface is located within the IPv4 address band. If this is not the case, the interface does not assign any IPv4 addresses.

- **Enable**

Specify whether or not this IPv4 address band will be used.

---

**Note**

If you enable the IPv4 address band, the settings in this and the other DHCP tabs are grayed out and can no longer be edited.

---

- **Subnet**

Enter the network address range that will be assigned to the devices. Use the CIDR notation.

- **Lower IP address**

Enter the IPv4 address that specifies the start of the dynamic IPv4 address band. The IPv4 address must be within the network address range you configured for "Subnet".

- **Upper IP address**

Enter the IPv4 address that specifies the end of the dynamic IPv4 address band. The IPv4 address must be within the network address range you configured for "Subnet".

- **Lease Time (sec)**

Specify for how many seconds the assigned IPv4 address remains valid. When half the lease time has elapsed, the DHCP client can extend the period of the assigned IPv4 address. When the entire time has elapsed, the DHCP client needs to request a new IPv4 address.

## 6.5.11.3

**DHCP Options**

On this page you specify which DHCP options the DHCP server supports. The various DHCP options are defined in RFC 2132.

Dynamic Host Configuration Protocol (DHCP) Options

DHCP Client
DHCP Server
DHCP Options
Static Leases

Pool ID: 1 ▼

Option Code:

Select	Pool ID	Option Code	Use Interface IP	Value
<input type="checkbox"/>	1	1		255.255.255.255
<input type="checkbox"/>	1	3	<input checked="" type="checkbox"/>	192.168.16.178
<input type="checkbox"/>	1	6		0.0.0.0
<input type="checkbox"/>	1	12		
<input type="checkbox"/>	1	66		
<input type="checkbox"/>	1	67		Bootfile name not set

6 entries.

Create
Delete
Set Values
Refresh

## Description

The page contains the following boxes:

- **Pool ID**

Select the required IPv4 address band.

- **Option Code**

Enter the number of the required DHCP option. A maximum of 20 DHCP options are possible.

The various DHCP options are defined in RFC 2132. The DHCP options 1, 3, 6, 12, 66 and 67 are created automatically when the IPv4 address band is created. With the exception of option 1, the options can be deleted.

With the DHCP option 3, the internal IPv4 address of the device is automatically set as a DHCP parameter

---

**Note****DHCP options not supported**

The DHCP options 50 - 60 and 255 are not supported.

---

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Pool ID**

Shows the number of the IPv4 address band.

- **Option Code**

Shows the number of the DHCP option.

- **Use Interface IP**

Specify whether or not the internal IPv4 address of the device will be used.

- **Value**

Enter the DHCP parameter that is transferred to the DHCP client. The content depends on the DHCP option.

- DHCP option 67 (boot file name)

Enter the name of the boot file in the string format.

- DHCP options 3 (Router) and 6 (DNS):

Enter the DHCP parameter as an IPv4 address, e.g. 192.168.100.2. With DHCP option 6, you can specify several IPv4 addresses separated by commas.

- DHCP option 12 (host name):

Enter the host name in the string format.

- DHCP option 66 (TFTP Server):

Enter the TFTP server as an IPv4 address, e.g. 192.168.100.2 or the FQDN name.

- All other DHCP options

Enter the DHCP parameter in hexadecimal, e.g. the IPv4 address 192.168.100.2 corresponds to "C0A86402".

#### 6.5.11.4 Static Leases

On this page you specify that devices with a certain MAC address are assigned to the selected IPv4 address.

### Static Leases

DHCP Client	DHCP Server	Port Range	DHCP Options	Relay Agent Information	Static Leases										
<div> Pool ID: <input type="text" value="1"/> </div> <div> Client Identification Method: <input type="text" value="Client ID"/> </div> <div> Value: <input type="text"/> </div> <table border="1"> <thead> <tr> <th>Select</th> <th>Pool ID</th> <th>Identification Method</th> <th>Value</th> <th>IP Address</th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td>2</td> <td>Client ID</td> <td>65756767</td> <td>0.0.0.0</td> </tr> </tbody> </table> <div>1 entry.</div> <div> <input type="button" value="Create"/> <input type="button" value="Delete"/> <input type="button" value="Set Values"/> <input type="button" value="Refresh"/> </div>						Select	Pool ID	Identification Method	Value	IP Address	<input type="checkbox"/>	2	Client ID	65756767	0.0.0.0
Select	Pool ID	Identification Method	Value	IP Address											
<input type="checkbox"/>	2	Client ID	65756767	0.0.0.0											

## Description

The page contains the following boxes:

- **Pool ID**

From the drop-down list, select the required IPv4 address band.

- **Hardware Type**

Select the method according to which a client is identified.

- Ethernet MAC

The client is identified by its MAC address.

- Client ID

The client is identified by a freely defined DHCP client ID. The client ID can be up to a maximum of 254 characters long.

- **Value**

Enter the MAC address or the client ID and click the "Create" button to create the entry.

---

**Note**

A maximum of 20 entries are possible.

---

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Pool ID**

- Shows the number of the IPv4 address band.

---

**Note**

Only Pool ID = 1 is supported.

---

- **Hardware Type**

Shows whether the client is identified by its MAC address or the client ID.

- **Value**

Shows the MAC address to which the IPv4 address is assigned.

- **IP Address**

Specify the IPv4 address. The IPv4 address must match the subnet of the IPv4 address band.

## 6.5.12 SNMP

### 6.5.12.1 General

#### Configuration of SNMP

On this page, you make the basic settings for SNMP. Enable the check boxes according to the function you want to use.

The screenshot shows the 'Simple Network Management Protocol (SNMP) General' configuration page. It features a tabbed interface with 'General', 'Traps', 'v3 Groups', and 'v3 Users' tabs. The 'General' tab is active. The configuration includes a dropdown menu for 'SNMP' set to 'SNMPv1/v2c/v3', a checkbox for 'SNMPv1/v2c Read Only' which is unchecked, text input fields for 'SNMPv1/v2c Read Community String' (public), 'SNMPv1/v2c Read/Write Community String' (private), and 'SNMPv1/v2c Trap Community String' (public). There is also a checkbox for 'SNMPv1 Traps' which is unchecked, a checked checkbox for 'SNMPv3 User Migration', and a text field for 'SNMP Engine ID' containing the value '80.00.10.e9.05.00.1b.1b.40.91.23'. At the bottom, there are 'Set Values' and 'Refresh' buttons.

Simple Network Management Protocol (SNMP) General

General Traps v3 Groups v3 Users

SNMP: SNMPv1/v2c/v3

☐ SNMPv1/v2c Read Only

SNMPv1/v2c Read Community String: public

SNMPv1/v2c Read/Write Community String: private

☐ SNMPv1 Traps

SNMPv1/v2c Trap Community String: public

☒ SNMPv3 User Migration

SNMP Engine ID: 80.00.10.e9.05.00.1b.1b.40.91.23

Set Values Refresh

## Description

The page contains the following boxes:

- **SNMP**

Select the SNMP protocol from the drop-down list. The following settings are possible:

- "-" (disabled)  
SNMP is disabled.
- SNMPv1/v2c/v3  
SNMPv1/v2c/v3 is supported.

---

**Note**

Note that SNMP in versions 1 and 2c does not have any security mechanisms.

---

- SNMPv3  
Only SNMPv3 is supported.

- **SNMPv1/v2c Read-Only**

If you enable this option, SNMPv1/v2c can only read the SNMP variables.

---

**Note****Community String**

For security reasons, do not use the standard values "public" or "private". Change the community strings following the initial installation.

The recommended minimum length for community strings is 6 characters.

For security reasons, only limited access to objects of the SNMPCommunityMIB is possible with the SNMPv1/v2c Read Community String. With the SNMPv1/v2c Read/Write Community String, you have full access to the SNMPCommunityMIB.

---

- **SNMPv1/v2c Read Community String**

Enter the community string for read access of the SNMP protocol.

- **SNMPv1/v2c Read/Write Community String**

Enter the community string for read and write access of the SNMP protocol.

- **SNMPv1 Traps**

Enable or disable the sending of SNMPv1 traps (alarm frames). On the "Trap" tab, specify the IP addresses of the devices to which SNMPv1 traps will be sent.

- **SNMPv1/v2c Trap Community String**

Enter the community string for sending SNMPv1/v2c messages.

- **SNMPv3 User Migration**

- Enabled

If the function is enabled, an SNMP engine ID is generated that can be migrated. You can transfer configured SNMPv3 users to a different device.

If you enable this function and load the configuration of the device on another device, configured SNMPv3 users are retained.

- Disabled

If the function is disabled, a device-specific SNMP engine ID is generated. To generate the ID, the agent MAC address of the device is used. You cannot transfer this SNMP user configuration to other devices.

If you load the configuration of the device on another device, all configured SNMPv3 users are deleted.

- **SNMP Engine ID**

Shows the SNMP engine ID.

## Procedure

1. Select the required option from the "SNMP" drop-down list:
  - "-" (disabled)
  - SNMPv1/v2c/v3
  - SNMPv3
2. Enable the "SNMPv1/v2c Read Only" check box if you only want read access to SNMP variables with SNMPv1/v2c.
3. Enter the required character string in the "SNMPv1/v2c Read Community String" input box.
4. Enter the required character string in the "SNMPv1/v2c Read/Write Community String" input box.
5. If necessary, enable the SNMPv3 User Migration.
6. Click the "Set Values" button.

### 6.5.12.2 Traps

#### SNMP traps for alarm events

If an alarm event occurs, a device can send SNMP traps (alarm frames) to up to ten different management stations at the same time. Traps are only sent if the events specified in the "Events" menu occur.

#### Note

Traps are only sent if you have enabled the option "SNMPv1 Traps" in the "General" tab or in "System > Configuration".

Simple Network Management Protocol (SNMP) v1 Traps

General Traps v3 Groups v3 Users

Trap Receiver Address:

Select

0 entries.

#### Description

- **Trap Receiver Address**  
Enter the IP address or the FQDN (Fully Qualified Domain Name) of the station to which the device sends SNMP traps. You can specify up to ten different recipients servers.

The table has the following columns:

- **Select**  
Select the row you want to delete.
- **Trap Receiver Address**  
If necessary, change the IP address or the FQDN (Fully Qualified Domain Name) of the stations.
- **Trap**  
Enable or disable the sending of traps. Stations that are entered but not selected do not receive SNMP traps.

#### Procedure

##### Creating a trap entry

1. In "Trap Receiver Address", enter the IP address or the FQDN of the station to which the device will send traps.
2. Click the "Create" button to create a new trap entry.

3. Select the check box in the required row "Trap".
4. Click the "Set Values" button.

#### Deleting a trap entry

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

### 6.5.12.3 v3 Groups

#### Security settings and assigning permissions

SNMP version 3 allows permissions to be assigned, authentication, and encryption at protocol level. The security level and read/write permissions are assigned according to groups. The settings automatically apply to every member of a group.

**Simple Network Management Protocol (SNMP) v3 Groups**

General Traps v3 Groups v3 Users

Group Name:

Security Level:

Select	Group Name	Security Level	Read	Write	Persistence
<input type="checkbox"/>	Service	no Auth/no Priv	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	yes
<input type="checkbox"/>	Wartung	no Auth/no Priv	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	yes

2 entries.

Create Delete Set Values Refresh

#### Description

The page contains the following boxes:

- **Group Name**  
Enter the name of the group. The maximum length is 32 characters.
- **Security Level**  
Select the security level (authentication, encryption) valid for the selected group. The available options are as follows:
  - No Auth/no Priv  
No authentication enabled/no encryption enabled.
  - Auth/no Priv  
Authentication enabled/no encryption enabled.
  - Auth/Priv  
Authentication enabled/encryption enabled.

The table has the following columns:

- **Select**  
Select the row you want to delete.
- **Group Name**  
Shows the defined group names.
- **Security Level**  
Shows the configured security level.
- **Read**  
Enable or disable read access for the required group.
- **Write**  
Enable or disable write access for the required group.

---

**Note**

For write access to work, you also need to enable read access.

---

- **Persistence**  
Shows whether or not the group is assigned to an SNMPv3 user. If the group is not assigned to an SNMPv3 user, no automatic saving is triggered and the configured group is deleted after restarting the device.
  - Yes  
The group is assigned to an SNMPv3 user.
  - No  
The group is not assigned to an SNMPv3 user.

## Procedure

### Creating a new group

1. Enter the required group name in "Group Name".
2. Select the required security level from the "Security Level" drop-down list.
3. Click the "Create" button to create a new entry.
4. Specify the required read rights for the group in "Read".
5. Specify the required write rights for the group in "Write".
6. Click the "Set Values" button.

### Modifying a group

1. Specify the required read rights for the group in "Read".
2. Specify the required write rights for the group in "Write".
3. Click the "Set Values" button.

---

#### Note

Once a group name and the security level have been specified, they can no longer be modified after the group is created. If you want to change the group name or the security level, you will need to delete the group and recreate it and reconfigure it with the new name.

---

### Deleting a group

1. Enable "Select" in the row to be deleted.  
Repeat this for all groups you want to delete.
2. Click the "Delete" button. The entries are deleted.

### 6.5.12.4 v3 Users

#### User-specific security settings

On the WBM page, you can create new SNMPv3 users and modify or delete existing users. The user-based security model works with the concept of the user name; in other words, a user ID is added to every frame. This user name and the applicable security settings are checked by both the sender and recipient.

**Simple Network Management Protocol (SNMP) v3 Users**

General Traps v3 Groups v3 Users

User Name:

Select	User Name	Group Name	Authentication Protocol	Privacy Protocol
<input type="checkbox"/>	Miller	Service	MD5	DES

1 entry.

Create Delete Set Values Refresh

SNMPv3 Users - first part of the table

Authentication Password	Authentication Password Confirmation	Privacy Password	Privacy Password Confirmation	Persistence
				yes

SNMPv3 Users - second part of the table

#### Description

The page contains the following boxes:

- **User Name**  
Enter a freely selectable user name. After you have entered the data, you can no longer modify the name.

The table has the following columns:

- **Select**  
Select the row you want to delete.
- **User Name**  
Shows the created users.

- **Group Name**  
Select the group which will be assigned to the user.
- **Authentication Protocol**  
Specify the authentication protocol for which a password will be stored.  
The following settings are available:
  - None
  - MD5
  - SHA
- **Encryption Protocol**  
Specify whether or not a password should be stored for encryption with the DES algorithm. Can only be enabled when an authentication protocol has been selected.
- **Authentication Password**  
Enter the authentication password in the first input box. This password must have at least 1 character, the maximum length is 32 characters.

---

**Note**

**Length of the password**

As an important measure to maximize security, we recommend that the password has a minimum length of 6 characters and that it contains special characters, uppercase/lowercase letters, numbers.

---

- **Authentication Password Confirmation**  
Confirm the password by repeating the entry.
- **Privacy Password**  
Enter your encryption password. This password must have at least 1 character, the maximum length is 32 characters.

---

**Note**

**Length of the password**

As an important measure to maximize security, we recommend that the password has a minimum length of 6 characters and that it contains special characters, uppercase/lowercase letters, numbers.

---

- **Privacy Password Confirmation**  
Confirm the encryption password by repeating the entry.
- **Persistence**  
Shows whether or not the user is assigned to an SNMPv3 group. If the user is not assigned to an SNMPv3 group, no automatic saving is triggered and the configured user is deleted after restarting the device.
  - Yes  
The user is assigned to an SNMPv3 group.
  - No  
The user is not assigned to an SNMPv3 group.

## Procedure

### Create a new user

1. Enter the name of the new user in the "User Name" input box.
2. Click the "Create" button. A new entry is generated in the table.
3. In "Group Name", select the group to which the new user will belong.  
If the group has not yet been created, change to the "v3 Groups" page and make the settings for this group.
4. If an authentication is necessary for the selected group, select the authentication algorithm in "Authentication Protocol".  
In the relevant input boxes, enter the authentication password and its confirmation.
5. If encryption was specified for the group, select the algorithm in "Privacy Protocol". In the relevant input boxes, enter the encryption password and the confirmation.
6. Click the "Set Values" button.

### Delete user

1. Enable "Select" in the row to be deleted.  
Repeat this for all users you want to delete.
2. Click the "Delete" button. The entry is deleted.

## 6.5.13 System Time

There are different methods that can be used to set the system time of the device. Only one method can be active at any one time.

If one method is activated, the previously activated method is automatically deactivated.

### 6.5.13.1 Manual Setting

#### Manual setting of the system time

On this page, you set the date and time of the system yourself. For this setting to be used, enable "Time Manually".

The screenshot shows a web interface titled "Manual System Time Setting". It has a navigation bar with tabs: "Manual Setting", "DST Overview", "DST Configuration", "SNTP Client", "NTP Client", and "SIMATIC Time Client". The "Manual Setting" tab is active. The main content area includes a checkbox labeled "Time Manually" which is checked. Below it is a text input field for "System Time" containing "01/01/2000 00:39:58". There is a button labeled "Use PC Time". Below the button are three read-only fields: "Last Synchronization Time" showing "Date/time not set", "Last Synchronization Mechanism" showing "Not set", and "Daylight Saving Time" showing "inactive (offset + 0h)". At the bottom are two buttons: "Set Values" and "Refresh".

#### Description

The page contains the following boxes:

- **Time Manually**  
Enable the manual time setting. If you enable the option, the "System Time" input box can be edited.
- **System Time**  
Enter the date and time in the format "MM/DD/YYYY HH:MM:SS".  
After a restart, the time of day begins at 01/01/2000 00:00:00.
- **Use PC Time**  
Click the button to use the time setting of the PC.
- **Last Synchronization Time**  
Shows when the last time-of-day synchronization took place. If no time-of-day synchronization was possible, the box displays "Date/time not set".

- **Last Synchronization Mechanism**  
Shows how the last time synchronization was performed.
  - Not set  
The time was not set.
  - Manual  
Manual time setting
  - SNTP  
Automatic time-of-day synchronization with SNTP
  - NTP  
Automatic time-of-day synchronization with NTP
  - SIMATIC  
Automatic time-of-day synchronization using the SIMATIC time frame
- **Daylight Saving Time (DST)**  
Shows whether the daylight saving time changeover is active.
  - active (offset +1 h)  
  
The system time was changed to daylight saving time; in other words an hour was added. You can see the current system time at the top right in the selection area of the WBM.  
  
The current time including daylight saving time is displayed in the "System Time" box.
  - inactive (offset +0 h)  
The current system time is not changed.

## Procedure

1. Enable the "Time Manually" option.
2. In the "System Time" input box, enter the date and time in the format "MM/DD/YYYY HH:MM:SS".
3. Click the "Set Values" button.  
The date and time are adopted and "Manual" is entered in "Last Synchronization Mechanism" box.

### 6.5.13.2 DST Overview

On this page, you can create new entries for the daylight saving time changeover.

The table provides an overview of the existing entries.

## Settings

Daylight Saving Time (DST) Overview								
Manual Setting DST Overview DST Configuration SNTP Client NTP Client SIMATIC Time Client								
Select	DST No	Name	Year	Start Date	End Date	Recurring Date	State	Type
<input type="checkbox"/>	1	CEST	-	03/26 02:00	10/29 03:00	Last Sunday March 02 Last Sunday October 03	enabled	Recurring
<input type="checkbox"/>	2	DST 2017	2017	03/30 02:00	11/15 03:00	-	enabled	Date

2 entries.

Create Delete Refresh

- **Select**  
Select the row you want to delete.
- **DST No.**  
Shows the number of the entry.  
If you create a new entry, a new line with a unique number is created.
- **Name**  
Shows the name of the entry.
- **Year**  
Shows the year for which the entry was created.
- **Start Date**  
Shows the month, day and time for the start of daylight saving time.
- **End Date**  
Shows the month, day and time for the end of daylight saving time.
- **Recurring Date**  
With an entry of the type "Rule", the period in which daylight saving time is active is displayed consisting of week, day, month and time of day.  
With an entry of the type "Date" a "-" is displayed.

- **State**

Shows the status of the entry:

- Enabled

The entry was created correctly.

- Invalid

The entry was created new and the start and end date are identical.

- **Type**

Shows how the daylight saving time changeover is made:

- Date

A fixed date is entered for the daylight saving time changeover.

- Rule

A rule was defined for the daylight saving time changeover.

## Procedure

### Creating an entry

1. Click the "Create" button.

A new entry is created in the table.

2. Click on the required entry in the "DST No column.

You change to the "DST Configuration" page.

3. Select the required type in the "Type" drop-down list.

Depending on the selected type, various settings are available.

4. Enter a name name in the "Name" box.

5. If you have selected the type "Date", fill in the following boxes.

- Year
- Day (for start and end date)
- Hour (for start and end date)
- Month (for start and end date)

6. If you have selected the type "Rule", fill in the following boxes.

- Hour (for start and end date)
- Month (for start and end date)
- Week (for start and end date)
- Day (for start and end date)

7. Click the "Set Values" button.

#### Deleting an entry

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

### 6.5.13.3 DST Configuration

On this page, you can configure the entries for the daylight saving time changeover. As result of the changeover to daylight saving or standard time, the system time for the local time zone is correctly set.

You can define a rule for the daylight saving time changeover or specify a fixed date.

## Settings

---

#### Note

The content of this page depends on the selection in the "Type" box.

The boxes "DST No.", "Type" and "Name" are always shown.

---

- **DST No.**

Select the type of the entry.

- **Type**

Select how the daylight saving time changeover is made:

- Date

You can set a fixed date for the daylight saving time changeover.

This setting is suitable for regions in which the daylight saving time changeover is not governed by rules.

- Rule

You can define a rule for the daylight saving time changeover.

This setting is suitable for regions in which the daylight saving time always begins or ends on a certain weekday.

- **Name**

Enter a name for the entry.

The name can be a maximum of 16 characters long.

#### Settings with "Date" selected

You can set a fixed date for the start and end of daylight saving time.

- **Year**

Enter the year for the daylight saving time changeover.

- **Start Date**

Enter the following values for the start of daylight saving time:

- Day  
Specify the day.
- Hour  
Specify the hour.
- Month  
Specify the month.

- **End Date**

Enter the following values for the end of daylight saving time:

- Day  
Specify the day.
- Hour  
Specify the hour.
- Month  
Specify the month.

### Settings with "Rule" selected

**DST Configuration**

Manual Setting | DST Overview | **DST Configuration** | SNTP Client | NTP Client | SIMATIC Time Client

DST No: 1 ▼

Type: Recurring ▼

Name: DST 2016

Start Date      End Date

Hour: 00:00 ▼      Hour: 00:00 ▼

Month: September ▼      Month: September ▼

Week: Third ▼      Week: Fourth ▼

Day: Monday ▼      Day: Tuesday ▼

Set Values   Refresh

You can create a rule for the daylight saving time changeover.

- **Start Date**

Enter the following values for the start of daylight saving time:

- Hour  
Specify the hour.
- Month  
Specify the month.
- Week  
Specify the week.  
You can select the first to fifth or the last week of the month.
- Day  
Specify the weekday.

- **End Date**

Enter the following values for the end of daylight saving time:

- Hour

Specify the hour.

- Month

Specify the month.

- Week

Specify the week.

You can select the first to fifth or the last week of the month.

- Day

Specify the weekday.

#### 6.5.13.4 SNTP Client

##### Time-of-day synchronization in the network

SNTP (Simple Network Time Protocol) is used for synchronizing the time in the network. The appropriate frames are sent by an SNTP server in the network.

---

##### Note

To avoid time jumps, make sure that there is only one time server in the network.

---

**Simple Network Time Protocol (SNTP) Client**

Manual Setting | DST Overview | DST Configuration | **SNTP Client** | NTP Client | SIMATIC Time Client

☐ SNTP Client

Current System Time: 01/11/2018 12:27:41

Last Synchronization Time: 01/11/2018 11:13:56

Last Synchronization Mechanism: Manual

Time Zone: +00:00

Daylight Saving Time: active (offset + 1h)

SNTP Mode: Poll ▼

Poll Interval[s]: 64

SNTP Server Address:

Select	SNTP Server Address	SNTP Server Port	Primary
<input type="checkbox"/>	192.168.1.255	123	<input checked="" type="checkbox"/>

1 entry.

Create Delete Set Values Refresh

## Description

The page contains the following boxes:

- **SNTP Client**  
Enable or disable automatic time-of-day synchronization using SNTP.
- **Current System Time**  
Shows the current date and current normal time received by the device. If you specify a time zone, the time information is adapted accordingly.
- **Last Synchronization Time**  
Shows when the last time-of-day synchronization took place.
- **Last Synchronization Mechanism**  
Shows how the last time synchronization was performed. The following methods are possible:
  - Not set  
The time was not set.
  - Manual  
Manual time setting
  - SNTP  
Automatic time-of-day synchronization with SNTP
  - NTP  
Automatic time-of-day synchronization with NTP
  - SIMATIC  
Automatic time-of-day synchronization using the SIMATIC time frame
- **Time Zone**  
In this box, enter the time zone you are using in the format "+/- HH:MM". The time zone relates to UTC standard world time.  
  
The time in the "Current System Time" box is adapted accordingly.
- **Daylight Saving Time (DST)**  
Shows whether the daylight saving time changeover is active.
  - active (offset +1 h)  
  
The system time was changed to daylight saving time; in other words an hour was added. You can see the current system time at the top right in the selection area of the WBM.  
  
The current time including daylight saving time is displayed in the "System Time" box.
  - inactive (offset +0 h)  
The current system time is not changed.

- **SNTP Mode**

Select the synchronization mode from the drop-down list. The following types of synchronization are possible:

- Listen

With this mode, the device is passive and receives SNTP frames that deliver the time of day. Settings in the input boxes "SNTP Server Address" and "SNTP Server Port" have no effect in this mode.

In this mode, only IPv4 addresses are supported.

- Poll

If you select this mode, the input box "Poll Interval[s]" is displayed to allow further configuration. In this mode, the settings in the input boxes "SNTP Server Address" and "SNTP Server Port" are taken into account. With this type of synchronization, the device is active and sends a time query to the SNTP server.

In this mode, IPv4 and IPv6 addresses are supported.

- **Poll Interval[s]**

Here, enter the interval between two time queries. In this box, you enter the query interval in seconds. Possible values are 16 to 16284 seconds.

- **SNTP Server Address**

Enter the IP address or the FQDN (Fully Qualified Domain Name) of the SNTP server.

- **SNTP Server Port**

Enter the port of the SNTP server.

The following ports are possible:

- 123 (standard port)
  - 1025 to 36564

- **Primary**

The check mark is set for the SNTP server that you create first. If several SNTP servers have been created, the primary server is queried first.

## Procedure

1. Click the "SNTP Client" check box to enable the automatic time setting.
2. In the "Time Zone" input box, enter the local time difference to world time (UTC). The input format is "+/-HH:MM" (for example +02:00 for CEST), because the SNTP server always sends the UTC time. This time is then recalculated and displayed as the local time based on the specified time zone. You configure the daylight saving time switchover on the pages "System > System Time > DST Overview" and "System > System Time > DST Configuration". You also need to take this into account when completing the "Time Zone" input box.
3. Select one of the following options from the "SNTP Mode" drop-down list:
  - Poll  
For this mode, you need to configure the following:
    - Time zone difference (step 2)
    - Query interval (step 4)
    - Time server (step 5)

- Port (step 7)
- Complete the configuration with step 8.
- Listen
  - For this mode, you need to configure the following:
    - Time difference to the time sent by the server (step 2)
    - Complete the configuration with step 8.
- 4. In the "Poll Interval[s]" input box, enter the time in seconds after which a new time query is sent to the time server.
- 5. In the "SNTP Server Address" input box, enter the IP address or the FQDN of the SNTP server whose frames will be used to synchronize the time of day.
- 6. Click the "Create" button.
 

A new row is inserted in the table for the SNTP server.
- 7. In the "SNTP Server Port" column, enter the port via which the SNTP server is available. The port can only be modified if the IPv4 address or the FQDN name of the SNTP server is entered.
- 8. Click the "Set Values" button to transfer your changes to the device.

### 6.5.13.5 NTP Client

#### Automatic time-of-day setting with NTP

If you require time-of-day synchronization using NTP, you can make the relevant settings here.

#### Note

To avoid time jumps, make sure that there is only one time server in the network.

Network Time Protocol (NTP) Client

Manual Setting
DST Overview
DST Configuration
SNTP Client
NTP Client
SIMATIC Time Client

☒ NTP Client  
☐ Secure NTP Client only  
Current System Time: 01/01/2000 04:29:46  
Last Synchronization Time: Date/time not set  
Last Synchronization Mechanism: Not set  
Time Zone: +00:00  
Daylight Saving Time: inactive (offset + 0h)  
  
NTP Server Index: 1

Select	NTP Server Index	NTP Server Address	NTP Server Port	Poll Interval	Key ID	Hash Algorithm	Key	Key Confirmation
<input type="checkbox"/>	1	192.168.1.250	123	64	1	DES		

1 entry.

Create
Delete
Set Values
Refresh

## Description

The page contains the following boxes:

- **NTP Client**  
Select this check box to enable automatic time-of-day synchronization with NTP.
- **Current System Time**  
Shows the current date and current normal time received by the IE switch. If you specify a time zone, the time information is adapted accordingly.
- **Last Synchronization Time**  
Shows when the last time-of-day synchronization took place.
- **Last Synchronization Mechanism**  
Shows how the last time synchronization was performed. The following methods are possible:
  - Not set  
The time was not set.
  - Manual  
Manual time setting
  - SNTP  
Automatic time-of-day synchronization with SNTP
  - NTP  
Automatic time-of-day synchronization with NTP
  - SIMATIC  
Automatic time-of-day synchronization using the SIMATIC time frame
- **Time Zone**  
In this box, enter the time zone you are using in the format "+/- HH:MM". The time zone relates to UTC standard world time.  
  
The time in the "Current System Time" box is adapted accordingly.
- **Daylight Saving Time (DST)**  
Shows whether the daylight saving time changeover is active.
  - active (offset +1 h)  
  
The system time was changed to daylight saving time; in other words an hour was added. You can see the current system time at the top right in the selection area of the WBM.  
  
The normal time including the time zone continues to be displayed in the "Current System Time" box.
  - inactive (offset +0 h)  
The current system time is not changed.
- **NTP Server Address**  
Enter the IPv4 address or the FQDN (Fully Qualified Domain Name) of the NTP server.

- **NTP Server Port**  
Enter the port of the NTP server.  
The following ports are possible:
  - 123 (standard port)
  - 1025 to 36564
- **Poll Interval[s]**  
Here, enter the interval between two time queries. In this box, you enter the query interval in seconds. Possible values are 64 to 1024 seconds.

## Procedure

1. Click the "NTP Client" check box to enable the automatic time setting using NTP.
2. Enter the necessary values in the following boxes:
  - Time zone
  - IPv4 address or FQDN of the NTP server
  - NTP server port
  - Query interval
3. Click the "Set Values" button.

### 6.5.13.6 SIMATIC Time Client

#### Time setting via SIMATIC time client

---

##### Note

To avoid time jumps, make sure that there is only one time server in the network.

---

The screenshot shows the 'Siemens Automatic (SIMATIC) Time Client' web interface. At the top, there is a navigation bar with tabs: 'Manual Setting', 'DST Overview', 'DST Configuration', 'SNTP Client', 'NTP Client', and 'SIMATIC Time Client'. The 'SIMATIC Time Client' tab is currently selected. Below the navigation bar, there is a checkbox labeled 'SIMATIC Time Client' which is unchecked. Underneath the checkbox, there are three lines of text: 'Current System Time: 01/01/2000 20:47:03', 'Last Synchronization Time: Date/time not set', and 'Last Synchronization Mechanism: Not set'. At the bottom of the interface, there are two buttons: 'Set Values' and 'Refresh'.

## Description

The page contains the following boxes:

- **SIMATIC Time Client**  
Select this check box to enable the device as a SIMATIC time client.
- **Current System Time**  
Shows the current system time.
- **Last Synchronization Time**  
Shows when the last time-of-day synchronization took place.
- **Last Synchronization Mechanism**  
Shows how the last time synchronization was performed. The following methods are possible:
  - Not set  
The time was not set.
  - Manual  
Manual time setting
  - SNTP  
Automatic time-of-day synchronization with SNTP
  - NTP  
Automatic time-of-day synchronization with NTP
  - SIMATIC  
Automatic time-of-day synchronization using the SIMATIC time frame

## Procedure

1. Click the "SIMATIC Time Client" check box to enable the SIMATIC Time Client.
2. Click the "Set Values" button.

## 6.5.14 Auto Logout

### Setting the automatic logout

On this page, set the times after which there is an automatic logout from WBM or the CLI following user in activity.

If you have been logged out automatically, you will need to log in again.

---


#### Note

##### No automatic logout from the CLI

If the connection is not terminated after the set time, check the "Keep alive" setting on the Telnet client.

If the interval is shorter than the configured time, the connection is kept alive although no user data is transferred. You have set, for example, 300 seconds for the automatic logoff and the "Keep alive" function is set to 120 seconds. In this case, a packet is sent every 120 seconds that keeps the connection up.

- Turn off the "Keep alive" (interval time=0)  
or
  - Set the interval high enough so that the underlying connection is terminated when there is inactivity.
- 



Automatic Logout

Web Based Management[s]: 900

CLI (TELNET, SSH) [s]: 300

Set Values Refresh

### Procedure

1. Enter a value of 60-3600 seconds in the "Web Base Management [s]" input box. If you enter the value 0, the automatic logout is disabled.
2. Enter a value of 60-600 seconds in the "CLI (TELNET, SSH) [s]" input box. If you enter the value 0, the automatic logout is disabled.
3. Click the "Set Values" button.

## 6.5.15 Syslog Client

### System event agent

Syslog according to RFC 3164 is used for transferring short, unencrypted text messages over UDP in the IP network. This requires a Syslog server.

#### Requirements for sending log entries:

- The Syslog function is enabled on the device.
- The Syslog function is enabled for the relevant event.
- There is a Syslog server in your network that receives the log entries. (Since this is a UDP connection, there is no acknowledgment to the sender)
- The IP address or the FQDN (Fully Qualified Domain Name) of the Syslog server is entered in the device.

**System Logging (Syslog) Client**

☐ Syslog Client

Syslog Server Address:

Select	Syslog Server Address	Server Port
0 entries.		

### Description

The page contains the following boxes:

- **Syslog Client**  
Enable or disable the Syslog function.
- **Syslog Server Address**  
Enter the IP address, the FQDN (Fully Qualified Domain Name) or the host name of the Syslog server.

This table contains the following columns

- **Select**  
Select the row you want to delete.
- **Syslog Server Address**  
Shows the IP address, the FQDN (Fully Qualified Domain Name) or the host name of the Syslog server.
- **Server Port**  
Enter the port of the Syslog server being used.

## Procedure

### Enabling function

1. Select the "Syslog Client" check box.
2. Click the "Set Values" button.

### Creating a new entry

1. In the "Syslog Server Address" input box, enter the IP address, the FQDN or the host name of the Syslog server on which the log entries will be saved.
2. Click the "Create" button. A new row is inserted in the table.
3. In the "Server Port" input box, enter the number of the UDP port of the server.
4. Click the "Set Values" button.

---

### Note

The default setting of the server port is 514.

---

### Changing the entry

1. Delete the entry.
2. Create a new entry.

### Deleting an entry

1. Select the check box in the row to be deleted.
2. Click the "Delete" button. All selected entries are deleted and the display is refreshed.

## 6.5.16 Fault Monitoring

### 6.5.16.1 Power Supply

#### Settings for monitoring the power supply

Configure whether or not the power supply should be monitored by the messaging system. Depending on the hardware variant, there are one or two power connectors (Supply 1 / Supply 2) and a PoE power supply. With a redundant power supply, configure the monitoring separately for each individual feed-in line.

A fault is then signaled by the message system when there is no power on a monitored connection (Power Line 1, Power Line 2 or PoE) or when the applied voltage is too low.

---

### Note

You will find the permitted operating voltage limits in the operating instructions of the device.

---

If a fault occurs, the error LED lights up on the device. The currently pending error is displayed under "Information > Errors".

In addition, the corresponding error message is entered in the result log table. The content of the event log table is displayed in "Information > Log Tables > Event Log".

### Note

This WBM page is not available on the SCALANCE W786-2 SFP.

### Procedure

1. Click the check box in front of the line name you want to monitor to enable or disable the monitoring function.
2. Click the "Set Values" button.

### Monitoring of the redundant power supply by PROFINET

With the following devices, you can also configure which power supply will be monitored by PROFINET:

- SCALANCE W788-x (RJ-45 variants)
- SCALANCE W748-1 RJ-45
- SCALANCE W774-1 (RJ-45 and M12 variant)
- SCALANCE W734-1 RJ-45

## Procedure

1. Click the check box in front of the line name you want to monitor to enable or disable the monitoring function.
2. From the "PROFINET Redundancy" drop-down list, select the desired entry for redundant power supply to be monitored by PROFINET.
3. Click the "Set Values" button.

### 6.5.16.2 Link Change

#### Configuration of fault monitoring of status changes on connections

On this page, you configure whether or not an error message is triggered if there is a status change on a network connection.

If connection monitoring is enabled, an error is signaled

- when there should be a link on a port and this is missing.
- or when there should not be a link on a port and a link is detected.

If a fault occurs, the error LED lights up on the device. The currently pending error is displayed under "Information > Errors".

In addition, the corresponding error message is entered in the result log table. The content of the event log table is displayed in "Information > Log Tables > Event Log".

Port	Setting
P1	-

Set Values Refresh

## Description

The table has the following columns:

- **Port**  
Shows the available ports.

- **Setting**

Select the setting from the drop-down list. You have the following options:

- Up  
Error handling is triggered when the port changes to the active status.  
(From "Link down" to "Link up")
- Down  
Error handling is triggered when the port changes to the inactive status.  
(From "Link up" to "Link down")
- "-" (disabled)  
The error handling is not triggered.


### Procedure

1. From the relevant drop-down list, select the options of the slots / ports whose connection status you want to monitor.
2. Click the "Set Values" button.

## 6.5.17 PROFINET

### Settings for PROFINET

This page shows the PROFINET AR status and the device name.



The screenshot displays the PROFINET configuration interface. At the top, the title "PROFINET" is shown in a grey header. Below this, the "PROFINET Device Diagnostics" are set to "On". The "PROFINET Device Diagnostics for next boot" is set to "On" with a dropdown arrow. The "PROFINET AR Status" is currently "Offline". The "PROFINET Name of Station" field is empty. At the bottom, there are two buttons: "Set Values" and "Refresh".

## Description of the displayed boxes

The page contains the following boxes:

- **PROFINET Device Diagnostics**

Shows whether PROFINET is enabled ("On") or disabled ("Off").

- **PROFINET runtime mode for next boot**

Set whether PROFINET will be enabled ("On") or disabled ("Off") after the next device restart.

---

**Note**

**PROFINET and EtherNet/IP**

When PROFINET is turned on, EtherNet/IP is turned off. The switchover from PROFINET and EtherNet/IP has no effect on DCP.

---

**Note**

**PROFINET AR Status**

If a PROFINET connection is established; in other words the PROFINET AR status is "Online", you cannot disable PROFINET.

---

- **PROFINET AR Status**

This box shows the status of the PROFINET connection; in other words whether the device is connected to a PROFINET controller "Online" or "Offline".

Here, online means that a connection to a PROFINET IO controller exists, that this has downloaded its configuration data to the device and that the device can send status data to the PROFINET IO controller. In this status known as "in data exchange", the parameters set via the PROFINET controller cannot be configured.

- **PROFINET Name of Station**

This box displays the PROFINET device name according to the configuration in HW Config of STEP 7.

---

**Note**

**Devices with two Ethernet ports**

With devices that have two Ethernet interfaces, only interface P1 should be used for the PROFINET configuration because LLDP frames can only be sent and received via interface 1. They are blocked at interface P2 and are also not forwarded between the interfaces.

This applies to the following devices:

- SCALANCE W786-2 SFP
  - SCALANCE W774-1 RJ45
  - SCALANCE W774-1 M12 EEC
  - SCALANCE W778-1 M12
  - SCALANCE W778-1 M12 EEC
  - SCALANCE W734-1 RJ-45
  - SCALANCE W738-1 M12
-

## SCALANCE W700 and STEP 7

The Ethernet interface can be configured in STEP 7 if the following requirements are met:

- STEP 7 V13 Update 3 with HSP0107 or
- STEP7 version 5.5.4 with GSDML version 2.31

The diagnostics functions can also be used. The WLAN interface cannot be configured with STEP 7.

## PROFINET for client devices

If a client is to be used as a PROFINET device, the MAC address of the client must be specified as follows (MAC Mode):

- Own

In the network beyond the device, only IP communication and no PROFINET is possible.

- Layer 2 Tunnel

The client and the devices downstream from it can be used as PROFINET devices.

---

### Note

If "Automatic" or "Manual" is configured as the MAC mode for a client, this device cannot be used as a PROFINET device.

---

## 6.5.18 EtherNet/IP

### EtherNet/IP

On this page, you configure the mode of EtherNet/IP.



**EtherNet Industrial Protocol (EtherNet/IP)**

EtherNet/IP Device Diagnostics: Off

EtherNet/IP Device Diagnostics for next boot: Off ▼

---

**Note**

**Devices with two Ethernet ports**

On devices with two Ethernet interfaces only one of the interfaces (P1 or P2) may be used for the Ethernet configuration.

This applies to the following devices:

- SCALANCE W786-2 SFP
  - SCALANCE W774-1 RJ45
  - SCALANCE W774-1 M12 EEC
  - SCALANCE W778-1 M12
  - SCALANCE W778-1 M12 EEC
  - SCALANCE W734-1 RJ-45
  - SCALANCE W738-1 M12
- 

**Description**

The page contains the following boxes:

- **EtherNet/IP Device Diagnostics**

Shows whether EtherNet/IP is enabled ("On") or disabled ("Off").

- **EtherNet/IP Device Diagnostics for next boot**

Set whether EtherNet/IP will be enabled ("On") or disabled ("Off") after the next device restart.

---

**Note**

**EtherNet/IP and PROFINET**

When EtherNet/IP is turned on, PROFINET is turned off. The switchover from EtherNet/IP and PROFINET has no effect on DCP.

---

**Note**

**PROFINET AR Status**

If a PROFINET connection is established; in other words the PROFINET AR status is "Online", you cannot enable EtherNet/IP.

---

## 6.5.19 PLUG

### 6.5.19.1 Configuration

**NOTICE****Do not remove or insert a C-PLUG / KEY-PLUG during operation!**

A PLUG may only be removed or inserted when the device is turned off. The device checks whether or not a PLUG is present at one second intervals. If it is detected that the PLUG was removed, there is a restart. If a valid KEY-PLUG was inserted in the device, the device changes to a defined error state following the restart. With SCALANCE W, the available wireless interfaces are deactivated in this case.

If the device was configured at some time with a PLUG, the device can no longer be used without this PLUG. To be able to use the device again, reset the device to the factory settings.

### Information about the configuration of the C-PLUG / KEY-PLUG

This page provides detailed information about the configuration stored on the C-PLUG or KEY-PLUG. It is also possible to reset the PLUG to "factory defaults" or to load it with new contents.

**Note**

The action is only executed after you click the "Set Values" button.

The action cannot be undone.

If you decide against executing the function after making your selection, click the "Refresh" button. As a result the data of this page is read from the device again and the selection is canceled.

**Note****Incompatibility with previous versions with PLUG inserted**

During the installation of a previous version, the configuration data can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "NOT ACCEPTED" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data.

If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using "System > PLUG".

**PLUG Configuration (KEY-PLUG)**

Configuration | License

State: ACCEPTED

Device Group: SCALANCE W700

Device Type: SCALANCE W774-1 RJ45

Configuration Revision: 1

File System: UBIFS

File System Size: 261144576

File System Usage: 14095

Info String: 6GK5 774-1FX00-0AA0  
SCALANCE W774-1 RJ45  
HW: 1  
SW: T06.00.00.00\_09.01.01  
Firmware on PLUG not present

☐ Firmware on PLUG

Modify PLUG: Select action ▼

Set Values Refresh

## Description

The table has the following rows:

- **Status**  
Shows the status of the PLUG. The following are possible:
  - ACCEPTED  
There is a PLUG with a valid and suitable configuration in the device.
  - NOT ACCEPTED  
Invalid or incompatible configuration on the inserted PLUG.
  - NOT PRESENT  
There is no C-PLUG or KEY-PLUG inserted in the device.
  - FACTORY  
PLUG is inserted and does not contain a configuration. This status is also displayed when the PLUG was formatted during operation.
  - MISSING  
There is no PLUG inserted. Functions are configured on the device for which a license is required.
- **Device Group**  
Shows the SIMATIC NET product line that used the C-PLUG or KEY-PLUG previously.
- **Device Type**  
Shows the device type within the product line that used the C-PLUG or KEY-PLUG previously.
- **Configuration Revision**  
The version of the configuration structure. This information relates to the configuration

options supported by the device and has nothing to do with the concrete hardware configuration. This revision information does not therefore change if you add or remove additional components (modules or extenders), it can, however, change if you update the firmware.

- **File System**

Displays the type of file system on the PLUG.

<b>NOTICE</b>
---------------

<p><b>New file system UBI</b></p>
-----------------------------------

<p>As of SCALANCE W firmware version 2.0, UBI is the standard file system for the C-PLUG or KEY-PLUG. If a C-PLUG with the previous file system IECP is detected in such a device, this C-PLUG will be formatted for the UBI file system and the data will be rewritten to the C-PLUG.</p>
--

<p>The file system is also changed following a firmware update to V2.0 with SCALANCE W. A downgrade to the previous version of the corresponding software is then a problem. The firmware can neither read nor write the C-PLUG or KEY-PLUG and it is not even possible to "Restore factory defaults".</p>
--

<b>NOTICE</b>
---------------

<p><b>Replacing a device with C-PLUG with firmware V1.0</b></p>
---

<p>The device in the plant has firmware V1.0. The C-PLUG was created with this firmware. The device in this plant is defective and will be replaced by a new device. The defective device can only be replaced by a device with firmware V6.0 or older.</p>
---

<p>When required, after the replacement, the device can be updated to the current firmware version.</p>
---

- **File System Size [bytes]**

Shows the maximum storage capacity of the file system on the PLUG.

- **File System Usage**

Displays the storage space in use in the file system of the PLUG.

- **Info String**

Shows additional information about the device that used the PLUG previously, for example, article number, type designation, and the versions of the hardware and software. The displayed software version corresponds to the version in which the configuration was last changed. With the "NOT ACCEPTED" status, further information on the cause of the problem is displayed.

If a PLUG was configured as a PRESET PLUG, this is shown here as additional information in the first row. For more detailed information on creating and using a PRESET PLUG refer to the section "Maintenance".

- **Firmware on PLUG**

When enabled, the firmware will be stored on the PLUG. This means that automatic firmware updates/downgrades can be made with the PLUG.

- **Drop-down list "Modify PLUG"**

Select the required setting from the drop-down list. You have the following options for changing the configuration on the C-PLUG or KEY-PLUG:

- Write current configuration to PLUG  
This option is available only if the status of the PLUG is "NOT ACCEPTED" or FACTORY.  
The configuration in the internal flash memory of the device is copied to the PLUG.
- Erase PLUG to factory default  
Deletes all data from the C-PLUG and triggers low-level formatting.

## Procedure

1. You can only make settings in this box if you are logged on as "Administrator". Here, you decide how you want to change the content of the PLUG.
2. Select the required option from the "Modify PLUG" drop-down list.
3. Click the "Set Values" button.

### 6.5.19.2 License

#### NOTICE

##### **Do not remove or insert a C-PLUG / KEY-PLUG during operation!**

A PLUG may only be removed or inserted when the device is turned off.

The device checks whether or not a PLUG is present at one second intervals. If it is detected that the PLUG was removed, there is a restart. If a valid KEY-PLUG was inserted in the device, the device changes to a defined error state following the restart. With SCALANCE W, the available wireless interfaces are deactivated in this case.

If the device was configured at some time with a PLUG, the device can no longer be used without this PLUG. To be able to use the device again, reset the device to the factory settings.

**Note****Incompatibility with previous versions with PLUG inserted**

During the installation of a previous version, the configuration data can be lost. In this case, the device starts up with the factory settings after the firmware has been installed. In this situation, if a PLUG is inserted in the device, following the restart, this has the status "Not Accepted" since the PLUG still has the configuration data of the previous more up-to-date firmware. This allows you to return to the previous, more up-to-date firmware without any loss of configuration data.

If the original configuration on the PLUG is no longer required, the PLUG can be deleted or rewritten manually using "System > PLUG".

**Information about the license of the KEY-PLUG**

A C-PLUG can only store the configuration of a device. In addition to the configuration, a KEY-PLUG also contains a license that enables certain functions of your SIMATIC NET device.

This page provides detailed information about the license on the KEY-PLUG. In this example, the KEY-PLUG contains the data for enabling the layer 3 functions of the device.

Configuration	License
State: ACCEPTED	
Order ID: 6GK5 907-0PA00	
Serial Number: VPE6128019	
Info String: KEY-PLUG W700: Security	
<input type="button" value="Refresh"/>	

## Description

- **Status**  
Shows the status of the KEY-PLUG. The following are possible:
  - ACCEPTED  
The KEY-PLUG in the device contains a suitable and valid license.
  - NOT ACCEPTED  
The license of the inserted KEY-PLUG is not valid.
  - NOT PRESENT  
No KEY-PLUG is inserted in the device.
  - MISSING  
There is no KEY-PLUG or a C-PLUG with the status "FACTORY" inserted in the device. Functions are configured on the device for which a license is required.
  - WRONG  
The inserted KEY-PLUG is not suitable for the device.
  - UNKNOWN  
Unknown content of the KEY-PLUG.
  - DEFECTIVE  
The content of the KEY-PLUG contains errors.
- **Article number**  
Shows the article number of the KEY-PLUG. The KEY-PLUG is available for various functional enhancements and for various target systems.
- **Serial Number**  
Shows the serial number of the KEY-PLUG.
- **Info String**  
Shows additional information about the device that used the KEY-PLUG previously, for example, order number, type designation, and the versions of the hardware and software. The displayed software version corresponds to the version in which the configuration was last changed. With the "NOT ACCEPTED" status, further information on the cause of the problem is displayed.

---

## Note

When you save the configuration, the information about whether or not a KEY-PLUG was inserted in the device at the time is also saved. This configuration can then only work if a KEY-PLUG with the same order number / license is inserted. This applies regardless of whether or not iFeatures are configured.

---

## 6.5.20 Ping

### Reachability of an address in an IP network

With the ping function, you can check whether a certain IP address is reachable in the network.

The screenshot shows a web interface titled "Ping". It contains the following elements:

- Destination Address:** A text input field.
- Repeat:** A text input field with the value "3".
- Ping:** A button to execute the ping command.
- DNS Resolution:** A dropdown menu currently set to "Auto".
- Out Interface for IPv6:** A dropdown menu currently set to "-".
- Out Interface is required only when pinging IPv6 multicast and link-local addresses:** A note below the IPv6 interface dropdown.
- Ping Output:** A large text area for displaying the results of the ping command.
- Clear:** A button to clear the output area.

### Description

The page contains the following boxes:

- **Destination Address**  
Enter the IPV4, IPv6 address or the FQDN (Fully Qualified Domain Name) of the device.
- **Repeat**  
Enter the number of ping requests.
- **DNS Resolution**  
Select the IP address type in which an entered FQDN will be resolved.
  - Auto  
In this mode, the IP address type is selected automatically.
  - IPv4  
The entered FQDN will be resolved in an IPv4 address.
  - IPv6  
The entered FQDN will be resolved in an IPv6 address.

- **Out Interface for IPv6**

This selection is only required when the destination address is a multicast or a link local address.

- "-" (factory setting)
- Select the relevant IPv6 interface.

- **Ping**

Click this button to start the ping function.

- **Ping Output**

This box shows the output of the ping function.

## 6.6 "Interfaces" menu

### 6.6.1 Ethernet

#### 6.6.1.1 Overview

#### Overview of the port configuration

The page shows the configuration for the data transfer for all ports of the device. You cannot configure anything on this page.

Ports Overview								
Overview	Configuration							
Port	Port Name	Status	OperState	Link	Mode	MTU	Negotiation	MAC Address
P1		enabled	up	up	100M FD	1500	enabled	00-1b-1b-a5-5d-98
Refresh								

#### Description

The table has the following columns:

- **Port**  
Shows the configurable ports. If you click on the link, the corresponding configuration page is opened.
- **Port name**  
Shows the name of the port.
- **State**  
Shows whether the port is on or off. Data traffic is possible only over an enabled port.
- **OperState**  
Displays the current operational status. The operational status depends on the configured "Status" and the "Link". The available options are as follows:
  - up  
You have configured the status "enabled" for the port and the port has a valid connection to the network.
  - down  
You have configured the status "disabled" or "Link down" for the port or the port has no connection.

- **Link**

Shows the connection status to the network. With the connection status, the following is possible:

- up

The port has a valid link to the network, a link integrity signal is being received.

- down

The link is down, for example because the connected device is turned off.

- **Mode**

Shows the transmission speed and the transmission method of the port.

- **MTU (Maximum Transmission Unit)**

Shows the packet size.

- **Negotiation**

Shows whether the automatic configuration is enabled or disabled.

- **MAC Address**

Shows the MAC address of the port.

### 6.6.1.2 Configuration

#### Configuring ports

With this page, you configure the Ethernet ports of the device.

##### Note

The two Ethernet ports of a SCALANCE W770/W730 cannot be assigned parameters or diagnosed individually.

**Ports Configuration**

**Overview** **Configuration**

Port: P1

Status: enabled

Port Name:

MAC Address: 00-1b-1b-a5-5d-98

Mode Type:

Mode: 100M FD

Negotiation: enabled

MTU: 1500

OperState: up

Link: up

#### Description

The table has the following rows:

- **Port**  
Select the port to be configured from the drop-down list.
- **Status**  
Specify whether the port is enabled or disabled.
  - enabled  
The port is enabled. Data traffic is possible only over an enabled port.
  - disabled  
The port is disabled.
- **Port Name**  
Enter a name for the port here.
- **MAC Address**  
Shows the MAC address of the port.

- **Mode Type**

---

**Note**

This parameter cannot be configured for the SCALANCE W770/W730 devices. The value is preset to "Autonegotiation" for both ports.

---

- **Mode**

Shows the transmission speed and the transmission method of the port.

- **Negotiation**

Shows whether the automatic configuration of the connection to the partner port is enabled or disabled.

- **MTU(Maximum Transmission Unit)**

Enter the packet size above which packets are fragmented.

- **OperState**

Displays the current operational status. The operational status depends on the configured "Status" and the "Link". The available options are as follows:

- up  
You have configured the status "enabled" for the port and the port has a valid connection to the network.
- down  
You have configured the status "disabled" or "Link down" for the port or the port has no connection.

- **Link**

Shows the connection status to the network. The available options are as follows:

- up  
The port has a valid link to the network, a link integrity signal is being received.
- down  
The link is down, for example because the connected device is turned off.

## Procedure

---

**Note**

**Changing the port configuration**

With various automatic functions, the device prevents or reduces the effect on other ports and priority classes (Class of Service) if a port is overloaded. This can mean that frames are discarded even when flow control is enabled.

Port overload occurs when the device receives more frames than it can send, for example as the result of different transmission speeds.

---

To change the configuration of a port, follow these steps:

1. Click the appropriate box to change the configuration.
2. Click the "Set Values" button.

## 6.6.2 WLAN

### 6.6.2.1 Basic

#### Basic settings

On this page, you make several basic settings for the device, for example the country setting and mode.

#### Note

To configure the WLAN interface, you must always specify the country code first. Some parameters are dependent on the country setting, for example the transmission standard.

**WLAN Basic Radio Settings**

Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
Country Code: <input type="text" value="Not defined"/>									
Device Mode: <input type="text" value="AP"/>									
Radio	Enabled	Radio Mode	Frequency Band	WLAN Mode 2.4 GHz	WLAN Mode 5 GHz	DFS (802.11h)	Outdoor Mode	max. Tx Power	Tx Power Check
WLAN 1	<input type="checkbox"/>	AP	2.4 GHz	802.11 n	802.11 n	<input type="checkbox"/>	<input type="checkbox"/>	20 dBm	Allowed
Warning: The device may not be permitted for use in countries denoted by a "*" character. Please check the following website for more detailed information: <a href="http://www.siemens.com/wireless-approvals">http://www.siemens.com/wireless-approvals</a>									
<input type="button" value="Set Values"/> <input type="button" value="Refresh"/>									

#### Description

- **Country Code**

Select the country in which the device will be operated from the drop-down list. You do not need to know the data for the specific country, the channel division and output power are set by the device according to the country you select.

#### Note

#### Locale setting

The correct country setting is mandatory for operation complying with the approvals. Selecting a country different from the country of use can lead to legal prosecution.

- **Device Mode**

Select the mode of the device. This selection is available only for access points. The following operating modes are possible:

- AP: Access point mode
- Client: Client mode

---

**Note**

After changing the mode, a message is displayed. If you confirm the message with "OK", the device restarts in the changed mode with the factory-set configuration settings.

---



If you have restarted the device after changing the mode, you will need to log on again to be able to continue the configuration.

The table has the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Enabled**

Status of the WLAN interface. To enable the WLAN interface, select the check box.

---

**Note**

**Enabling the WLAN interface**

The WLAN interfaces are disabled when the device is supplied. The WLAN interfaces are can be enabled once the country and the antenna settings are configured.

---

- **Radio Mode**

Shows the mode of the WLAN interface.

- **Frequency Band**

Specify the frequency band. In client mode, dual-frequency operation is also possible.

- 2.4 GHz
- 5 GHz
- 2.4 GHz + 5 GHz (only in client mode)

---

**Note**

**Configuring WLAN interfaces of the W786-2IA RJ-45 for different frequency bands**

If both WLAN interfaces are configured for the same frequency band on this device, there may be mutual influence or interference. This applies in particular when there is a high data throughput.

---

- **WLAN Mode 2.4 GHz/WLAN Mode 5 GHz**

Select the required transmission standard for the configured frequency band. The selection depends on the country setting.

- Auto (only in client modeModus)  
The transmission standard is determined automatically (2.4 GHz + 5 GHz).
- 802.11a  
The transmission standard IEEE 802.11a (5 GHz) is set.
- 802.11g  
The transmission standard IEEE 802.11g (2.4 GHz) is set. This transmission standard is downwards compatible with IEEE 802.11b
- 802.11n  
The transmission standard IEEE 802.11n (2.4 GHz and 5 GHz) is set. This transmission standard is downwards compatible with IEEE 802.11a and IEEE 802.11g.
- 802.11n only  
the transmission standard IEEE 802.11n (2.4 GHz and 5 GHz) is set. This transmission standard is downwards compatible with IEEE 802.11a and IEEE 802.11g.

---

**Note**

If you select the transmission standard "802.11n", "802.11n only" or "Auto" (only in client mode), you cannot set the threshold value of the fragmentation length see "Fragmentation Length Threshold" in "Interfaces > WLAN > Advanced".

---

- **DFS (802.11h)**

Enables or disables the "Dynamic Frequency Selection (DFS)" function.

- Enabled

if you have enabled this function, additional DFS channels from the 5 GHz band are available to you. These channels are country-specific and are subject to certain DFS regulations.

If the access point discovers a disturbance on the current channel, it changes automatically to an alternative channel and the current channel is blocked for 30 minutes. The disturbance can originate from a primary user or radar interference.

- Before the access point starts the communication on a channel it searches 60 seconds for primary users on the channel. During this time the access point does not send beacons. If signals are found on the channel, the access point changes channel and repeats the check. Only when no signals from primary users are detected after 60 seconds does the access point send on a channel.

The access point also searches for primary users during operation.

- Disabled

The DFS function is not used.

---

**Note**

**RCoax 5 GHz and DFS**

In the USA and in countries that follow the FCC (Federal Communication Commission) when operating with DFS (Dynamic Frequency Selection), the IWLAN RCoax Cable 5 GHz may not be used. The current status of the approvals can be found on the Internet at:

<http://www.siemens.com/wireless-approvals>

---

- **Outdoor Mode**

- Enabled

If you have enabled the outdoor mode, you only have the channels available that are permitted for outdoor operation.

- Disabled

If you have enabled the outdoor mode, you only have the channels available that are permitted for outdoor operation.

- **max. Tx Power**

Specify the maximum possible transmit power of the device.

If the transmit power is set too high the received signal at the client may be overmodulated. Check the received signal strength at the client (dBm).

It may be necessary to reduce the transmit power depending on the antennas being used to avoid exceeding the maximum legal transmit power. Reducing the transmit power effectively reduces cell size.

---

**Note**

The maximum possible transmit power varies depending on the channel and data rate. For more detailed information on transmit power, refer to the documentation "Characteristics radio interface".

---

**Note**

If both interfaces of access points with two WLAN interfaces are operated in the same frequency range, this may cause wireless interference on one or both interfaces at a transmit power higher than 15 dBm.

---

- **Tx power check**

Indicates whether the settings that have been made will violate the permitted transmit power restrictions of the selected country. The following parameters influence this calculation:

max. Tx Power, Antenna Gain, Additional Attenuation.

The following displays can appear:

- Allowed  
The channels can be used with the current settings.
- Not Allowed (Some Channels)  
Among the channels, there are some on which the current transmit power exceeds the maximum permitted transmit power.
- Not Allowed (All Channels)  
No permitted operation is possible. The transmit power is too high.
- Controlled automatically by iREF (only when iREF feature is available)  
Controlled by the iREF function.

## Procedure

1. To configure the WLAN interface, you must always specify the country first. Select the country in which the device will be operated from the "Country Code" drop-down list.
2. Select the required frequency band from the "Frequency Band" drop-down list.
3. From the "WLAN Mode" drop down list, select the required transmission standard for the configured frequency band.
4. Click the "Set Values" button.

## 6.6.2.2 Advanced

## Further possible settings

On this page, you can specify details of the transmission characteristics. You only need to adapt the parameters on this page if the SCALANCE W700 device cannot be used as it is intended with the default settings.

WLAN Advanced Radio Settings										
Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	Force Roaming	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
Radio	Beacon Interval [ms]	DTIM	RTS/CTS Threshold [Bytes]	Fragmentation Length Threshold [Bytes]		HW Retries	Multi Radar Detection	Prefer Configured DFS Channel		
WLAN 1	100	1	2346	2346		16	<input type="checkbox"/>	<input type="checkbox"/>		
<a href="#">Set Values</a> <a href="#">Refresh</a>										

## Description

The table has the following columns:

- **Radio**

Shows the available WLAN interfaces in this column.

- **Beacon Interval [ms] (only in access point mode)**

Specify the interval (40 - 1000 ms) at which the access point sends beacons. Beacons are packets that are sent cyclically by an access point to inform clients of its existence.

- **DTIM (only in access point mode)**

The DTIM interval (1-15) specifies the number of beacons to be sent before the access point sends the collected packets (broadcast, unicast, multicast) to the client.

- If you enter a "1" in this box, the access point transmits broadcast, unicast and multicast packets directly after each beacon (recommended setting for normal network environments).
- If you entered a "5" in this field, this would mean that the access point collects the packets and sends them after every fifth beacon.

Increasing this value allows a longer sleep mode for the clients but means a greater delay for packets.

- **RTS/CTS Threshold [Bytes]**

RTS/CTS (Request To Send/Clear To Send) is a method for avoiding collisions. The method is based on the exchange of status information prior to sending the actual data (hidden node problem). To minimize the network load due to additional protocol traffic, this method is used only as of a certain packet size. You specify the packet size with the "RTS/CTS Threshold" parameter.

- **Fragmentation Length Threshold [Bytes]**

Specify the maximum packet size transferred on the wireless link. Large packets are divided up into small packets prior to transmission and then reassembled into the original size after they have been received. This can be beneficial if the transmission quality is

poor because larger packets are more difficult to transmit. However fragmentation into smaller packets means a poorer throughput.

---

**Note**

You can only edit this value if the you have set the transmission standard "802.11g" (2.4 GHz) or "802.11 a" (5 GHz), see "WLAN Mode" in "Interfaces > WLAN > Basic".

---

- **HW Retries**

Specify the number of hardware retries. The hardware repetition is performed by the WLAN chip itself when it tries to repeat an unacknowledged packet immediately.

If all hardware repetitions were unsuccessful, the packet is deleted.

- **Multi Radar Detection (only in access point mode)**

- Enabled

This function is only available if you have enabled the "DFS" function on the "Basic" page.

This function is suitable for systems with several access points connected via an Ethernet network and that send on the same channel.

When an access point detects a radar signal it distributes this information to all connected access points. If at least one further access point verifies the radar signal within 40 ms, all connected access points are informed. All the devices sending on this channel change to a different channel. The channel is blocked for 30 minutes for the access points in the network.

If you have configured "Auto" for the channel on the "Interfaces > WLAN > AP" page, the function cannot be used reliably. In this case the verification of the radar signals is only possible when at least two connected access points happen to transmit on the same channel. If only one access point detects a signal on a channel, it treats this as a valid radar signal.

- Disabled

The function is not used. When an access point detects a radar signal it changes to another channel.. The configured channel is no longer taken into account.

- **Prefer Configured DFS Channel (only in access point mode)**

- Enabled

This function is only available if you have enabled the "DFS" function on the "Basic" page.

If the configured channel of a WLAN interface was blocked due to radar detection and is released again after 30 minutes the access point changes automatically to the configured channel.

Before the access point starts the communication on the configured channel it searches 60 seconds for primary users on the channel. During this time the access point does not send beacons. If signals are found on the channel, the access point changes channel and repeats the check. Only when no signals from primary users are detected after 60 seconds does the access point send on the channel.

If you have configured "Auto" for the channel on the "Interfaces > WLAN > AP" page, the device does not have a configured channel to which it can return.

- Disabled

The function is not used.
























## Procedure

1. Enter the values to be set in the input boxes as follows.
2. Select the option checkmarks of the required functions.
3. Click the "Set Values" button.


### 6.6.2.3 Antennas

#### Overview

Overview of IWLAN antennas:

Type of antenna	Frequency (GHz)	Antennas	SCALANCE W780/W740	SCALANCE W770/W730	SCALANCE W760/W720	SCALANCE W1780/W1740
Omnidirectional	2.4	 ANT792-6MN	•	•	•	•
	2.4 and 5	 ANT795-4MA	•	•	•	•
		 ANT795-4MB	•	•	•	•
		 ANT795-4MC	•	•		•
		 ANT795-4MD	•	•		•
		 ANT795-4MX	•	•		•
		 ANT795-6MN	•	•	•	•
		 ANT795-6MT	•			•
		 ANT795-6MP	•	•	•	•
	5	 ANT793-6MN	•	•	•	•
Sector	2.4 and 5	 ANT795-6DC	•	•	•	•
	5	 ANT793-6DG	•	•		•
		 ANT793-6DT	•			•
Type of antenna	Frequency (GHz)	Antennas	SCALANCE W780/W740	SCALANCE W770/W730	SCALANCE W760/W720	SCALANCE W1780/W1740
Directional	2.4	 ANT792-8DN	•			•
	5	 ANT793-8DP	•	•	•	•
		 ANT793-8DJ	•	•		•
		 ANT793-8DK	•	•		•
		 ANT793-8DL	•	•		•
		 RCoax waveguide 2.4 GHz	•	•	•	•
RCoax	2.4	 ANT792-4DN	•	•	•	•
	5	 RCoax waveguide 5 GHz	•	•	•	•
		 ANT793-4MN	•	•	•	•
Mobile wireless for GSM	2.4 and 5	 ANT896-6MM				•

The antenna name provides information about the properties of the antennas listed in the IWLAN antenna overview:

Antennas for SCALANCE W devices									
									
ANT79	2	–	4	–	D	x			
	↑		↑		↑				
Frequency	2	2.4 GHz	Gain	4	Medium gain	Directivity	D	Directional antenna	
	3	5 GHz		6	High gain		M	Omnidirectional antenna	
	5	2.4 + 5 GHz		8	Very high gain				

## Antennas

### Configuration of external antennas

On this page, you configure the settings for the connected external antennas.

#### Note

##### 50 Ω terminating resistor

Each WLAN interface has up to two antenna connectors. Connectors that are not used must have a 50 Ω terminating resistor fitted.

The antenna R1A1 must always be connected as soon as the associated WLAN Interface is turned on. If no antenna is connected, the relevant interface must also be disabled for Rx and Tx. Otherwise, there may be transmission disruptions.

Antennas							Access Point	
<div>Basic Advanced Antennas Allowed Channels 802.11n AP AP WDS AP 802.11a/b/g Rates AP 802.11n Rates Force Roaming</div>								
Spectrum Analyzer								
Connector	Antenna Type	Antenna Gain 2.4 GHz [dBi]	Antenna Gain 5 GHz [dBi]	Cable Length [m]	Additional Attenuation [dB]	Antenna Mode		
R1 A1	Omnidirectional: ANT795-6MT ▼	5	7	0	0	RX/TX ▼		
<div>Set Values Refresh</div>								

## Description

The table has the following columns:

- **Connector**

Shows the name of the relevant antenna connector.

- **Antenna Type**

Select the type of external antenna connected to the device. If the type of your external antenna is not available, select the entry "User defined".

If you terminate an antenna connection using a 50  $\Omega$  terminating resistor, select the entry "Not used (Connect 50 Ohm Termination)".

- **Antenna Gain**

If you select the "User defined" entry for the "Antenna Type", enter the antenna gain manually in the "dBi" unit.

- **Antenna Gain 2.4 GHz [dBi]**

Here, enter the antenna gain the antenna has in the 2.4 GHz frequency band.

- **Antenna Gain 5 GHz [dBi]**

Here, enter the antenna gain the antenna has in the 5 GHz frequency band.

- **Cable Length [m]**

Enter the length of the flexible antenna connecting cable in meters between the device and the external antenna.

- **Additional Attenuation [dB]**

Here, specify the additional attenuation caused, for example, by an additional splitter.

- **Antenna Mode**

Specify the use of the antenna. For antenna connector 1 (R1 A1 and R2 A1), the entry cannot be changed.

- Tx

For sending only

- Rx

For receiving only

- Rx\Tx

For receiving and sending

The following table shows which combinations are possible:

R1 A1 R2 A1	R1 A2 R2 A2
Rx\Tx	Rx\Tx
Rx\Tx	Rx
Rx\Tx	Tx
Rx\Tx	-- 1)

1) Antenna type "50 Ohms Termination Impedance"

## Steps in configuration

To configure one or more antennas, follow the steps below:

1. For the first antenna connector (R1 A1) in the "Antenna Type" drop-down list, select the type of antenna.
2. In the "Cable Length" input box, enter the length of the connecting cable you are using in meters. For antenna connector 1 (R1 A1 and R2 A1), the "Antenna Mode" cannot be changed.
3. For further antenna connectors (e.g. R1 A2), select the type of antenna from the "Antenna Type" drop-down list.
4. In the "Cable Length" input box, enter the length of the connecting cable you are using in meters.
5. Select the use of the antenna from the "Antenna Mode" drop-down list.
6. Repeat steps 3 to 5 for further antenna connectors.
7. Click the "Set Values" button.

### 6.6.2.4 Allowed Channels

#### Channel settings

For communication, a specific channel within a frequency band is used. You can either set this channel specifically or configure so that the channel is selected automatically.

On this page, you specify which channels may be used for communication.

**Allowed Channels Settings**

Basic | Advanced | Antennas | **Allowed Channels** | 802.11n | AP | AP WDS | AP 802.11a/b/g Rates | AP 802.11n Rates | Spectrum Analyzer

Radio: WLAN 1 Use Allowed Channels only: ☐

Frequency Band: 2.4 GHz

☒ Select / Deselect all

Radio	Radio Mode	1	2	3	4	5	6	7	8	9	10	11	12	13
WLAN 1	AP	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Frequency Band: 5 GHz

☒ Select / Deselect all

Radio	Radio Mode	184	188	192	196	8	12	16	36	40	44	48	52	56	60	64	100	104	108
WLAN 1	AP	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

#### Description

Table 1 contains the following columns:

- **Radio**  
Shows the available WLAN interfaces.

- **Use Allowed Channels only**

If you enable the option, you restrict the selection of channels via which the AP or the client is allowed to establish the connection.

In the following tables, you define the

- channels that the AP can use to establish a wireless cell when the "Auto" channel setting is enabled.
- the channels on which the client searches for an AP.

The tables are divided up according to frequency bands.

If the option is disabled, the channels available based on the settings (country code, antennas, transmit power etc.) are used.

Above the tables for the frequency bands, you will find the following check box:

- **Select / Deselect all**

- Enabled

If you enable the check box, all channels are selected.

- Disabled

If you deselect the check box, the first valid channel of the frequency band remains enabled. Enable the required channel.

The tables of the frequency bands have the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Radio Mode**

Shows the mode.

- **Channel number**

To specify the valid channels for the required frequency band, select the appropriate check box for the channel number.

The table displays the permitted channels of the country. Only the valid channels can be enabled. Invalid channels are grayed out and cannot be enabled.

---

**Note**

To specify the channels, the setting "Use Allowed Channels only" must be enabled.

---

## Procedure

1. Select the "Use Allowed Channels only" option for the required WLAN interface.
2. Deselect the check box "Select / Deselect all".
3. Select the relevant check box for the required channel number.
4. Click the "Set Values" button.

## 6.6.2.5 802.11n

## Properties of 802.11n

With the IEEE 802.11n standard, it is possible to put together individual data packets in one larger data packet, the A-MPDU and A-MSDU data packets. This achieves a higher data throughput.

On this page, you make the settings for the A-MPDU and A-MSDU data packets. Some of the settings depend on the set transmission standard and the selected channel width.

802.11n Advanced Radio Settings									
Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
Radio	A-MPDU	A-MPDU Limit [Frames]	A-MPDU Limit [Bytes]	A-MSDU	A-MSDU Packet Size [Bytes]	Guard Interval [ns]			
WLAN 1	<input checked="" type="checkbox"/>	32	50000	<input checked="" type="checkbox"/>	100	800 (long)			
Set Values		Refresh							

## Description

The table has the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **A-MPDU**  
Aggregated MAC Protocol Data Unit (A-MPDU)  
Enables or disables that several MPDUs with the same destination address are sent as a large A-MPDU. This allows the total throughput to be increased.  
If this check box is disabled, A-MPDU data packets are received but not sent.
- **A-MPDU Limit [Frames]**  
Specify the number of individual data packets grouped together in one A-MPDU data packet.  
Range of values: 2 - 64 frames
- **A-MPDU Limit [Bytes]**  
Specify the maximum size of the A-MPDU data packet. Range of values: 1024 - 65535 bytes
- **A-MSDU**  
Aggregated MAC Service Data Unit (A-MSDU)  
Enables or disables that several MSDUs with the same destination address are bundled into an A-MSDU and are sent together. This reduces the network load. Due to their shorter maximum length A-MSDUs are more suitable for the bundling of several shorter frames.  
If this check box is disabled, A-MSDU data packets are received but not sent.

- **A-MSDU Packet Size [Bytes]**

Specify the maximum size of the A-MSDU data packet.

Range of values: 50 - 200

- **Guard Interval [ns] (only in access point mode)**

Select the send pause that must be kept to between two transmitted OFDM symbols.

The following settings are possible. The selection depends on the selected transmission standard.

- 400 (short): The send pause is 400 ns
- 800 (long): The send pause is 800 ns.

## Procedure

### Configure 802.11n settings on the access point

1. Enable the "A-MPDU" option.
2. Enter the required values in the "A-MPDU Limit [Frames]" and "A-MPDU Limit [Bytes]" input boxes.
3. Select the "A-MSDU" option.
4. Enter the required value in the "A-MSDU Packet Size" input box.
5. Select the required value from the "Guard Interval [ns]" drop-down list.
6. Click the "Set Values" button.

### Configure 802.11n settings on the client

1. Enable the "A-MPDU" option.
2. Enter the required values in the "A-MPDU Limit [Frames]" and "A-MPDU Limit [Bytes]" input boxes.
3. Select the "A-MSDU" option.
4. Enter the required value in the "A-MSDU Packet Size" input box.
5. Click the "Set Values" button.

## 6.6.2.6 AP

### Configuration

On this page, you specify the configuration for the access point.

---

**Note**

This tab is available only in access point mode.

---

Access Point Settings

Basic
Advanced
Antennas
Allowed Channels
802.11n
AP
AP WDS
Force Roaming
AP 802.11a/b/g Rates
AP 802.11n Rates
Spectrum Analyzer

Radio	Channel	Alternative DFS Channel	HT Channel Width [MHz]
WLAN 1	Auto	Auto	20

Radio	Available Channels
WLAN 1	100,104,108,112,116,132,136,140

Radio	Port	Enabled	SSID	Broadcast SSID	WDS only	WDS ID
WLAN 1	VAP 1.1	<input checked="" type="checkbox"/>	Siemens Wireless Network	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.2	<input type="checkbox"/>	Siemens Wireless Network 1.2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.3	<input type="checkbox"/>	Siemens Wireless Network 1.3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.4	<input type="checkbox"/>	Siemens Wireless Network 1.4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.5	<input type="checkbox"/>	Siemens Wireless Network 1.5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.6	<input type="checkbox"/>	Siemens Wireless Network 1.6	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.7	<input type="checkbox"/>	Siemens Wireless Network 1.7	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
WLAN 1	VAP 1.8	<input type="checkbox"/>	Siemens Wireless Network 1.8	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Warning: The approval process may not be finished in current country for channels denoted by a "\*" character.

Please check the following website for more detailed information:  
<http://www.siemens.com/wireless-approvals>

Set Values
Refresh

## Description

Table 1 has the following columns:

- Radio**  
Shows the available WLAN interfaces in this column.
- Channel**  
Specify the main channel.  
If you want the access point to search for a free channel itself, use "Auto". The selection of channels used by an access point when establishing a wireless cell can be restricted. To do this, select the "Use Allowed Channels only" check box on the "Allowed Channels" tab.  
".If you want to use a fixed channel, select the required channel from the drop-down list.

### Note

#### Channel spacing with WLAN interfaces

If you use a second WLAN interface, make sure that you have adequate channel spacing.

- **Alternative DFS Channel**

If you have enabled the "DFS" function, on the "Basic" page, specify the alternative channel here. If you want the access point to search for a free channel itself, use "Auto". If a primary user was detected both on the main and alternative channel, the access point automatically searches for a free channel.

If you want to use a fixed channel, select the required channel from the drop-down list.

- **HT Channel Width [MHz]**

You can specify the channel bandwidth only with the IEEE 802.11n transmission standard.

The following settings are possible.

- 20

Channel bandwidth 20 MHz

- 40 up

Channel bandwidth 40 MHz The configured channel and the neighboring channel above it are used.

- 40down

Channel bandwidth 40 MHz. The configured channel and the neighboring channel below it are used.

---

**Note**

**Channel bandwidth 40 MHz and frequency band 2.4 GHz**

If the access point detects another access point on the configured channel or on neighboring channels, the access point changes the channel bandwidth from 40 MHz to 20 MHz. If you set a "free" channel on the access point, the access point uses the channel bandwidth 40 MHz.

---

Table 2 has the following columns:

- **Radio**

Shows the available WLAN interfaces in this column.

- **Available Channels**

This box displays the permitted channels. The display depends on the wireless approvals of the currently selected country and the settings for "Allowed Channels".

Table 3 has the following columns:

- **Radio**

Shows the WLAN interface.

- **Port**

Shows the VAP interface.

- **Enabled**

To use the required VAP interface, select this check box.

- **SSID**

Enter the SSID of the WLAN. The length of the character string for SSID it is 1 to 32 characters.

The ASCII code 0x20 to 0x7e is used for the SSID.

- **Broadcast SSID**

- disabled

The SSID is no longer sent in the beacon frame of the access point. This means that the SSID is not visible for other SCALANCE W700 devices. Only clients that know the SSID of the access point and that are configured with it can connect to the access point. The "Any SSID" option must be disabled on these clients.

- enabled

The SSID is sent in the Beacon frame of the access point and is visible for other SCALANCE W700 devices. This means that clients on which the "Any SSID" option is enabled can also connect to the access point.

---

**Note**

Since no encryption is used for the SSID transfer, this function can only provide basic protection against unauthorized access. The use of an authentication method (for example WPA2 (RADIUS) or WPA2-PSK if this is not possible) provides higher security. You must also expect that certain end devices may have problems with access to a hidden SSID.

---

- **WDS only**

If you enable this option, the access point only supports communication via WDS. In WDS mode, all access points must use the same channel.

- **WDS ID**

Enter the WDS ID. The WDS ID can be a maximum of 32 characters long. To establish a WDS connection, enter this WDS ID on the WDS Partner. ASCII code 0x20 to 0x7e is used for the WDS ID.

## Procedure

1. Select the required channel from the "Channel" drop-down list.
2. Enter network name in the "SSID" input box for the corresponding WLAN interface and port.
3. For the relevant WLAN interface and the port, select the "Enabled" check box.
4. Click the "Set Values" button.

### 6.6.2.7 AP WDS

#### Communication between access points

In normal operation, the access point is used as an interface to a network and communicates with clients. There are, however, situations in which several access points need to communicate with each other, for example to extend wireless coverage or to set up a wireless backbone. This mode is possible with WDS (Wireless Distributed System).

#### Note

This tab is available only in access point mode.

Wireless Distribution System Settings										
Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	Force Roaming	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
Radio	Port	Port enabled	Connection over		Partner ID Type		Partner MAC		Partner WDS ID	
WLAN 1	WDS 1.1	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.2	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.3	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.4	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.5	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.6	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.7	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 1	WDS 1.8	<input type="checkbox"/>	VAP 1.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.1	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.2	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.3	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.4	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.5	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.6	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.7	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			
WLAN 2	WDS 2.8	<input type="checkbox"/>	VAP 2.1	▼	WDS ID	▼	00-00-00-00-00-00			

#### Description

The table has the following columns:

- **Radio**  
Shows the available WLAN interfaces in this column.
- **Port**  
Shows the port.
- **Port enabled**  
Enables the WDS interface.

- **Connection over**  
Specify the VAP interface via which the WDS connection is established. Both the MAC address of the VAP as well as security settings (for example WPA2) are used.
- **Partner ID Type**  
Specify the type of WDS communication.
  - MAC Address  
The MAC address is used. The "Partner WDS ID" input box is grayed out. For "Partner MAC", enter the MAC address of the WDS partner.
  - WDS ID  
The WDS ID is used. The "Partner MAC" input box is grayed out. For "Partner WDS ID" enter the WDS ID of the WDS partner. Use this option if you want to replace the access point later using the C-PLUG or KEY-PLUG.
- **Partner MAC**  
Enter the MAC address of the WDS partner.
- **Partner WDS ID**  
Enter the WDS ID of the WDS partner.  
For the WDS ID ASCII code 0x20 to 0x7e is used.

---

**Note**

**Matching security settings in WDS mode**

In WDS mode, make sure that the security settings match up for all SCALANCE W700 devices involved. If settings are incorrect or not compatible on the individual SCALANCE W700 devices, no data exchange is possible due to incorrect authentication. Avoid the "Auto" setting in the "Security Settings" tab of the Basic Wizard, because with this setting, synchronization of the security settings between the access points is not possible.

---

---

**Note**

In WDS operation, the following restrictions apply to all access points involved:

- All access points that will communicate with each other must use the same channel, the same transmission procedure and the same data rate.
  - You can select either WEP or WPA(2)-PSK as the encryption method.  
You configure the security settings in the assigned VAP interface: "Security > WLAN > Basic"  
You cannot use authentication with a RADIUS server for a WDS connection.
  - In the IEEE 802.11h transmission mode, it is not practical to select the WDS mode. In WDS mode, all access points must use the same channel. If a signal from a primary user is detected by an access point, the channel is changed automatically and the existing connection is then terminated.
- 

**Procedure**

1. Select the required VAP interface from the "Connection over" drop-down list.
2. Select the entry "WDS ID" in the "Partner ID Type" drop-down list.

3. In the "WDS ID" input box, enter the WDS ID of the WDS partner. The "Partner MAC" input box is grayed out.
4. Click the "Set Values" button.

### 6.6.2.8 AP 802.11a/b/g Rates

#### Data transmission speeds with IEEE 802.11a/b/g

##### Note

The tab is available only in access point mode.

The WBM page can only be configured if "802.11a", "802.11g" or "802.11n" is set for WLAN Mode.

The WBM page shows the available data transmission speeds for the WLAN mode 802.11a/b/g. If necessary, you can change the data transmission speeds. Otherwise, we recommend that you retain the default setting for data transmission speeds. The access point will then use only the selected data transmission speeds for communication with the clients.

**AP 802.11 a/b/g Data Rates Settings**

Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
-------	----------	----------	------------------	---------	----	--------	----------------------	------------------	-------------------

Radio

Use selected data rates only

WLAN 1

Radio: WLAN 1 ▼

		Enabled	Basic	Copy to Table
All data rates settings		No Change	▼	No Change
		▼	▼	Copy to Table
Radio	Data Rate [Mbps]	Enabled	Basic	
WLAN 1	1.0	✓	✓	
WLAN 1	2.0	✓	✓	
WLAN 1	5.5	✓	✓	
WLAN 1	6.0	✓	□	
WLAN 1	9.0	✓	□	
WLAN 1	11.0	✓	✓	
WLAN 1	12.0	✓	□	
WLAN 1	18.0	✓	□	
WLAN 1	24.0	✓	□	
WLAN 1	36.0	✓	□	
WLAN 1	48.0	✓	□	
WLAN 1	54.0	✓	□	

Default Values

Set Values
Refresh

**Description**

Table 1 has the following columns:

- **Radio**  
Specifies the WLAN interface to which the information relates.
- **Use selected data rates only**  
If you select this option, you can specify the data transmission speeds for the required WLAN interface.  
If this option is disabled, the default values are used. As default, this option is disabled.

**Radio"drop down list"**

In this drop-down list, select the WLAN interfaces displayed in Table 3 (Data Rate).

With Table 2, you can enable or disable all check boxes of a column of Table 3 (Data Rate) at once. Table 2 has the following columns:

- **All data rate settings**  
Shows that the setting is valid for all entries in Table 3.
- **Enabled / Basic**  
In the drop-down list, select the setting for all entries. If "No Change" is selected, the entry in table 3 remains unchanged.
- **Copy to table**  
If you click the button, the setting is adopted for all entries of table 3.

Table 3 (Data Rate) consists of the following columns:

- **Radio**  
Specifies the WLAN interface to which the information relates.
- **Data Rate [Mbps]**  
Shows the supported data transmission speeds in megabits per second.
- **Enabled**  
Enable the option to assign the required data transmission speed to the WLAN interface.

---

**Note**

You need to enable at least one data transmission speed.

---

- **Basic**  
Enable the option to declare the required data transmission speed as "Basic". The "Basic" parameter specifies that a client must be capable of this speed to be able to connect to the Access Point. The "Basic" option can only be enabled if an available data transmission speed has been selected.

---

**Note**

At least one data transmission speed needs to be specified as "Basic".

---

## Procedure

### To configure a certain data transmission speed on WLAN 1:

1. Enable the "Use selected data rates only" option for "WLAN 1".
2. From the "Radio" drop-down list, select the entry "WLAN 1".
3. Select the appropriate check box in the "Enabled" column and in the "Basic" column for the required data transmission speed.
4. Click the "Set Values" button.

### To reset the selection:

1. Click the "Default Values" button. The selection is reset to the default setting.

## 6.6.2.9 AP 802.11n Rates

### Data transmission speeds in IEEE 802.11n

---

#### Note

This WBM page is only available in access point mode.

The WBM page can only be configured if "802.11n only" or 802.11n is set for WLAN mode.

---

The WBM page shows the available data transmission speeds (MCS = Modulation and Coding Schemes) for the WLAN mode 802.11n. You can select any combination of these data transmission speeds. The access point will then use only the selected data transmission speeds for communication with the clients.

### AP 802.11 n Data Rates Settings

Basic	Advanced	Antennas	Allowed Channels	802.11n	AP	AP WDS	Force Roaming	AP 802.11a/b/g Rates	AP 802.11n Rates	Spectrum Analyzer
-------	----------	----------	------------------	---------	----	--------	---------------	----------------------	------------------	-------------------

Radio

Use selected data rates only

WLAN 1 ☐

WLAN 2 ☐

Radio: WLAN 1

				Enabled	Copy to Table
All data rates settings				No Change	<input type="button" value="v"/> Copy to Table

Radio	MCS Index	Streams	Data Rate [Mbps]	Enabled
WLAN 1	0	1	6.5	<input checked="" type="checkbox"/>
WLAN 1	1	1	13.0	<input checked="" type="checkbox"/>
WLAN 1	2	1	19.5	<input checked="" type="checkbox"/>
WLAN 1	3	1	26.0	<input checked="" type="checkbox"/>
WLAN 1	4	1	39.0	<input checked="" type="checkbox"/>
WLAN 1	5	1	52.0	<input checked="" type="checkbox"/>
WLAN 1	6	1	58.5	<input checked="" type="checkbox"/>
WLAN 1	7	1	65.0	<input checked="" type="checkbox"/>
WLAN 1	12	2	78.0	<input checked="" type="checkbox"/>
WLAN 1	13	2	104.0	<input checked="" type="checkbox"/>
WLAN 1	14	2	117.0	<input checked="" type="checkbox"/>
WLAN 1	15	2	130.0	<input checked="" type="checkbox"/>
WLAN 1	21	3	156.0	<input checked="" type="checkbox"/>
WLAN 1	22	3	175.5	<input checked="" type="checkbox"/>
WLAN 1	23	3	195.0	<input checked="" type="checkbox"/>

Default Values

Set Values Refresh

## Description

Table 1 has the following columns:

- **Radio**

Specifies the WLAN interface to which the information relates.

- **"Use selected data rates only"**.

If you enable this option, you can specify the data transmission speeds for the required WLAN interface.

If this option is disabled, the default values are used. As default, this option is disabled.

**"Radio" drop-down list**

In this drop-down list, select the WLAN interfaces displayed in Table 3 (MCS Index).

With Table 2, you can enable or disable all check boxes of a column of Table 3 (MCS Index) at once. Table 2 has the following columns:

- **All data rates settings**

Shows that the setting is valid for all entries of Table 3.

- **Enabled**

In the drop-down list, select the setting for all entries. If "No Change" is selected, the entry in table 3 remains unchanged.

- **Copy to table**

If you click the button, the setting is adopted for all entries of Table 3.

Table 3 (MCS Index) consists of the following columns:

- **Radio**

Specifies the WLAN interface to which the information relates.

- **MCS Index**

Shows the supported MCS indexes. The displayed MCS indexes depend on the settings "Antenna Type" and "Antenna Mode". You will find the settings in "Interfaces > WLAN > Antennas". If, for example, you only use one antenna, only the MCS 0 to 7 are displayed.

- **Streams**

Shows the maximum possible number of parallel data streams that can be transmitted with the selected MCS index.

- **Data Rate [Mbps]**

Shows the supported data transmission speeds in megabits per second. The displayed data transmission speeds depend on the settings "Guard Interval" and "HT Channel Width". You will find the setting "HT Channel Width" in "Interfaces > WLAN > AP". The "Guard Interval" setting can be found in "Interfaces > WLAN > 802.11n".

- **Enabled**

Enable the option to assign the required data transmission speed to the WLAN interface.

---

**Note**

You need to enable at least one MCS index.

---

## Procedure

### To configure a certain data transmission speed on WLAN 1:

1. Enable the "Use selected data rates only" option for "WLAN 1".
2. From the "Radio" drop-down list, select the entry "WLAN 1".
3. Select the corresponding check box in the "Enabled" column for the selected MCS index.
4. Click the "Set Values" button.

### To reset the selection:

1. Click the "Default Values" button. The selection is reset to the default setting.

Or

1. Disable the "Use selected data rates only" option in Table 1.
2. Click the "Set Values" button.

### 6.6.2.10 Client

#### Connecting to a network

On this WBM page, you can specify how the device connects to a network as client.

#### Note

This WBM page is only available in client mode.

Client Settings

Basic

Advanced

Antennas

Allowed Channels

802.11n

Client

Signal Recorder

Force Roaming

Radio	MAC Mode	MAC Address	Any SSID	DHCP Renew After Roaming	min. AP Signal Strength [dBm]
WLAN 1	Automatic	00-00-00-00-00-00	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0

Radio	Roaming Threshold	Background Scan Mode	Background Scan Interval [ms]	Background Scan Threshold [dBm]
WLAN 1	medium	idle	5000	0

Radio	Scan Channels
WLAN 1	1,2,3,4,5,6,7,8,9,10,11,12,13

Radio	Enabled	SSID	Security
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1
WLAN 1	<input type="checkbox"/>		Context 1

Warning: The approval process may not be finished in current country for channels denoted by a "\*" character.

Please check the following website for more detailed information:  
<http://www.siemens.com/wireless-approvals>

Set Values

Refresh

#### Note

##### WLAN interface disabled

The WLAN interface will be disabled unless at least one SSID is configured or the setting "Any SSID" is enabled.

## Description

Table 1 has the following columns:

- **Radio**  
Shows the available WLAN interfaces.
- **MAC Mode**  
Specify how the MAC address is assigned to the client. The following are possible:
  - Automatic  
The client automatically adopts the source MAC address of the first frame that it receives over the Ethernet interface.
  - Manual  
If you select "Manual", enter the MAC address in the "MAC Address" column.
  - Own  
The client uses the MAC address of the Ethernet interface for the WLAN interface.
  - Layer 2 Tunnel  
The client uses the MAC address of the Ethernet interface for the WLAN interface. The network is also informed of the MAC addresses connected to the Ethernet interface of the client. Up to eight MAC addresses can be used.
- **MAC Address**  
If you have selected "Manual" for "MAC Mode", enter the MAC address of the client.
- **Any SSID**
  - Enabled  
In client mode, the SCALANCE W device attempts to connect to the access point that corresponds to the security settings of security context 1. The clients can only connect to the access point on which the "Broadcast SSID" option is enabled.
  - Disabled  
The client attempts to connect to the access point from the SSID list whose security settings match one of the defined security contexts.
- **DHCP Renew After Roaming**
  - Enabled  
After changing to a different access point, a check is made to find out whether the IPv4 address of the client is still valid. If the IPv4 address is invalid, a new IPv4 address is requested from the DHCP server.
  - Disabled  
If the client changes to a different access point the IPv4 address is not checked.

- **min. AP signal strength**

The client has a signal strength set.

---

**Note**

**IPCF / IPCF-HT / IPCF-MC enabled**

When IPCF / IPCF-HT / IPCF-MC is enabled, the signal strength cannot be set.

---

The client must receive the signal coming from the access point with at least the specified signal strength to be able to connect to this access point.

The signal strength can fluctuate briefly, e.g. due to the client moving or other disruptive factors. To filter out fluctuations of the signal a hysteresis is used to specify a range around this value, in which the client does not change access points before this range is undershot.

If the signal coming from the access point falls below this range, the client disconnects from the connected access point and searches for a new access point.

- **Roaming Threshold**

Specify the threshold after which the client roams to the new access point.

- High  
Changes only at a significantly higher field strength to the AP with the stronger signal.
- Medium  
Changes at a moderately higher field strength to the AP with the stronger signal.
- Low  
Changes at a slightly higher field strength to the AP with the stronger signal.

- **Background Scan Mode**

While the client is connected to an access point, it scans for other access points in the background with which it can connect when necessary. Specify the mode for the scan.

The following options are available:

- Always  
If the background scan threshold is undershot, the client searches continuously for access points.
- Idle  
If there is no data transfer for a certain time, a scan is started for further access points.

- Disabled  
As long as the client is connected, there is no scan for further access points.
- Current channel  
The client updates its scan list based on the beacons (management frames) that it has received on the current channel. The scan list is evaluated within the background scan interval. If beacons from a better access point are included, the client switches to that access point after evaluation without changing the current channel.

---

**Note****iPRP enabled**

When iPRP is enabled, the client sends special roaming advertisement frames to its redundant partner for each roaming operation. The redundant partner may not perform roaming itself for 500 ms after receiving this.

---

- **Background Scan Interval [ms]**

Specify the interval at which further access points are scanned.

- **Background Scan Threshold [dBm]**

Specify the threshold. If the threshold is undershot, the client searches for further access points.

Table 2 has the following columns:

- **Radio**

Shows the WLAN interface.

- **Scan Channels**

Shows the channels on which the client searches for an access point. The display depends on the wireless approvals of the selected country and the settings for "Allowed Channels".

Table 3 has the following columns:

- **Radio**

Shows the WLAN interface.

- **Enabled**

Enables or disables the relevant SSID.

- **SSID**

Enter the SSID of the access point with which the client will connect.  
For the SSID, ASCII code 0x20 to 0x7e is used.

- **Security**

Select a security context. You create and configure a security context in "Security > WLAN > Basic".

Default setting: Context 1

---

**Note**

**iPCF / iPCF-HT / iPCF-MC enabled**

If the iPCF, iPCF-HT or iPCF-MC mode is enabled, you can only select security context 1.

---

## Procedure

1. From the "MAC Mode" drop-down list, select the required assignment of the MAC address.
2. In table 3, enter an SSID for "SSID".
3. Select a security context.
4. Enable the required SSID.  
The "Any SSID" function is disabled.
5. Click the "Set Values" button.

### 6.6.2.11 Force Roaming

If an interface is no longer available (cable break, network component failure, connector removed), a client connected over the wireless network is not aware of this. The access point can force the logged-on clients to roam by deactivating the relevant interface.

On this page you specify when roaming is performed.

- On connection termination **(only in access point mode)**

If the wired Ethernet interface is no longer available the WLAN interface is turned off. The clients roam and then connect to a different access point. As soon as the first access point reaches the server again it switches its WLAN interfaces active again.

- When the destination address is unreachable.

Roaming depends on destination addresses. To monitor the device sends pings to the configured destination addresses at regular intervals.

- Interface monitored using a destination address

If no ping response is received from this destination address, the access point or the client switches off the corresponding interface.

- Interface monitored using several destination addresses

Only when no ping response is received from any of these destination addresses does the access point or client switch off the corresponding interface. As long as at least one destination address is reachable, the interface remains active.

The device sends a disassociation frame, for example, to the WLAN clients connected via this VAP interface. The WLAN clients roam and connect to a different VAP interface. If the address becomes reachable again, the connection can be established again via this VAP interface.

The possible settings differ for access point and client.

In access point mode

**Force Roaming**

Basic | **Advanced** | Antennas | Allowed Channels | 802.11n | AP | AP WDS | AP 802.11a/b/g Rates | AP 802.11n Rates | Force Roaming | Spectrum Analyzer

Radio Force Roaming on link down

WLAN 1	<input type="checkbox"/>
WLAN 2	<input type="checkbox"/>

Force Roaming on IP down

Select	Destination Address	Interval [ms]	Max. Lost Packets	VAP 1.1	VAP 1.2	VAP 1.3	VAP 1.4	VAP 1.5	VAP 1.6	VAP 1.7	VAP 1.8	VAP 2.1	VAP 2.2	VAP 2.3	VAP 2.4
<input type="checkbox"/>	0.0.0.0	1000	3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Create Delete Set Values Refresh

In client mode

**Force Roaming**

Basic | Advanced | Antennas | Allowed Channels | 802.11n | **Client** | Signal Recorder | Force Roaming

Force Roaming on IP down

Select	Destination Address	Interval [ms]	Max. Lost Packets	WLAN 1
<input type="checkbox"/>	192.111.20.20	2000	2	<input checked="" type="checkbox"/>
<input type="checkbox"/>	0.0.0.0	1000	3	<input type="checkbox"/>

2 entries.

Create Delete Set Values Refresh

## Description

Table 1 is only available in access point mode and is divided into the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Force roaming on link down**

When enabled if there is a connection abort via the Ethernet interface, the WLAN interface is turned off.

The table "Force Roaming on IP down" has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Destination Address**

Enter the IPv4 address or the FQDN (Fully Qualified Domain Name) of the destination whose reachability will be checked.

---

**Note****Destination address not in the agent IP subnet**

If the destination address is not in the agent IP subnet, a gateway must be entered for "Layer 2 > Agent IP".

**The Base Bridge mode "802.1Q VLAN Bridge"**

If you have configured the "Based Bridge Mode" "802.1Q VLAN Bridge" in "Layer 2 > VLAN", pings are sent into the management VLAN.

---

- **Interval [ms]**

Specify the interval at which pings are sent.

- **Max. Lost Packets**

Specify the maximum number of consecutive lost ping responses. When this number is reached for a destination address, this destination address counts as being unreachable (down).

- **VAP X.Y** (in access point mode)

Specify which VAP interface will be monitored.

- **WLAN 0/X** (in client mode)

Specify which WLAN interface will be monitored.

## Procedure

### Creating force roaming

1. Click the "Create" button.
2. Make the following settings:
  - Destination address
  - Interval
  - Max. Lost Packets
3. Specify through which destination address the following interface will be monitored:
  - VAP interface (in access point mode)
  - WLAN interface (in client mode).
4. Click the "Set Values" button.

### Deleting force Roaming

1. Select the check box in the row to be deleted.
2. Click the "Delete" button. The entries are deleted and the page is updated.

## 6.6.2.12 Signal recorder

### Recording the effective user signal

The signal recorder is used to record the effective user signal between access point and client. Using this data, you can locate areas with an inadequate user signal. The signal recorder can be particularly useful when the client moves along a fixed path.


---

#### Note

This WBM page is only available in client mode.

The WLAN interface of the SCALANCE W700 device must be enabled, otherwise no recording is possible.

---



Description

The display is divided into two areas.

- Client  
Represents the measurement of the client.
- Access point  
Displays the measurement of the access point with which the client is currently connected. This requires that the setting "Bidirectional Recording" is enabled and that a firmware version > 6.1 is installed on the access point. The access point sends its data to a maximum of 3 clients on which signal recorders are running. The access point data is not displayed on other clients.

Both areas each contain two graphics.

The first graphic contains the following elements:

- Scroll bar

With the scroll bar, you can look through the entire measurement. To do this you can use the "<<" and ">>" buttons or the arrow keys on the keyboard.

- Bar (left)

In the bar on the left-hand side the user signal of the client / access point is displayed in real time according to the color scheme. The gray line shows the background noise.

If the client has an iPCF-MC connection, the user signal of the management channel is shown with a black line.

- Color scheme

The range > -35 dBm (blue) is the overmodulation range, in other words the WLAN signal is too strong and is received overmodulated. As of approximately -60 dBm (yellow) the WLAN signal is weaker.

- x axis

The x axis shows the course of the measurement in random samples and seconds.

- Measurement data

- Client

The measurement data shows the value of the effective user signal according to the color scheme shown. The gray line shows the background noise.

If the client changes access points during a measurement (roaming) or reconnects, this is displayed by a vertical black line. On the line the new AP system name and the BSSID are shown.

If during a measurement the client has no connection to an access point, no user signal is displayed. To make it clear that there is no connection to an access point, the BSSID is set to 00:00:00:00:00:00 and shown in red.

If the client has an iPCF-MC connection, the user signal of the management channel is shown with an additional black line.

- Access point

The measurement data shows the value of the effective user signal according to the color scheme shown. The gray line shows the background noise.

If the client changes access points during a measurement (roaming) or reconnects, this is displayed by a vertical black line.

If the access point does not support the setting "Bidirectional Recording" no user signal is displayed

The second graphic contains the following elements:

- Bar (left)

In the bar on the left-hand side the transfer attempts and the data rate of the client / access point are displayed according to the color scheme.

- Color scheme

The range > -35 dBm (blue) is the overmodulation range, in other words the WLAN signal is too strong and is received overmodulated. As of approximately -60 dBm (yellow) the WLAN signal is weaker. The individual colors are described again under the graphic.

- x axis

The x axis shows the course of the measurement in random samples and seconds.

- Measurement data

- Client

The measurement data shows the transfer attempts according to the color scheme shown. The transfer attempts are shown as a bar. The data rate of the sent data packets is represented as a line. If the client changes access points during a measurement (roaming) or reconnects, this is displayed by a vertical black line.

- Access point

The measurement data shows the transfer attempts according to the color scheme shown. The transfer attempts are shown as a bar. The data rate of the sent data packets is represented as a line.

If the client changes access points during a measurement (roaming) or reconnects, this is displayed by a vertical black line. If the access point does not support the setting "Bidirectional Recording" no data is displayed.

Beside the graphics the following values are displayed:

- Status

Shows whether or not the signal recorder is recording values.

- Current Sample

The number of the current measurement

- CL RX-Signal [dBm] / AP RX-Signal [dBm]

The effective user signal of the client / access point in dBm

- CL NF [dBm] / AP NF [dBm]

The background noise of the client / access point in dBm

- CL Retries [%] / AP Retries [%]

The transfer repetitions of the client / access point as a percentage.

- CL RSSI / AP RSSI

The raw value of the RSSI (Received Signal Strength Indication) of the client / access point

- CL TX-Rate [Mbps] / AP TX-Rate [Mbps]

The average data rate of the sent data packets during the current random test

- **CL M-Signal [dBm]**  
If the client has an iPCF-MC connection, the user signal of the management channel is displayed.
- **Roaming Counter**  
The roaming counter shows how often the client has changed access points during the recording. After 4 294 967 295 changes the counter is reset.
- **Operative Channel**  
The current channel or the channel on which the client is connected to the access point
- **AP System Name**  
The system name of the access point
- **BSSID**  
The BSSID (Basic Service Set Identification) of the access point.
- **Connected Stations**  
Number of clients connected to the access point.
- **Bidirectional Status**  
Shows whether the data of the access point are also being recorded.

The table below the graphic contains the following columns:

- **Radio**  
Shows the WLAN interface to which the information applies. Since a client has a WLAN interface, there is only ever one row for "WLAN 1" in this table.
- **Interval [ms]**  
Specify the time interval between acquiring two measured values in milliseconds. The first measured value is displayed only after the set time interval has elapsed.
- **Samples**  
Specify how many measurements should be made.
- **Endless**  
If you enable the option check mark, the number of measurements is unlimited. The "Samples" box is grayed out. The signal recorder runs until it is stopped manually or the device is reconfigured.  
  
You can only select this option starting at a time interval  $\geq 100$  milliseconds.  
  
If the recording contains more than 10000 measurements, the last 10000 measurements are listed in the csv file and the PDF file.
- **Bidirectional Recording**  
If you enable the setting the values of the access point as of a time interval of  $\geq 10$  milliseconds.  
  
The setting is supported by access points with the following versions: SCALANCE W700 11n > V6.1 and SCALANCE W1700 11ac > V1.0.

- **Start**

Click the button in this column to start recording the wanted signal.

---

**Note**

- If you start a new recording, the previous recording will be overwritten.
  - If the recording has lasted less than 10 minutes and has not yet been completed (e.g. due to a restart or power down), the measured values are deleted.
- 

The signal recorder saves the recorded data automatically every 10 minutes. Following a restart, the recording contains all the values up to the last save action.

- **Stop**

Click the button in this column to stop recording the wanted signal prematurely. If the specified number of measurements has been made, recording of the user data signal stops automatically.

- **Displayed Samples**

Select how many measurements will be shown in the graphic.

## Notes on usage

Note the following tips that will help you to obtain useful measurements with the signal recorder:

- Set a fixed data rate on the access point.
- If you have activated iPCF, set as low a cycle time on the access point as possible for the measurements.
- Make sure that there is enough data communication during the measurement because the statistics functions evaluate incoming data frames.
- The measurement path should be traveled 2 to 3 times with the same parameters to find out whether losses of the user data signal always occur at the same position.
- Selective measurements at a fixed position should be made over a longer period of time.

## Procedure

1. Enter the time interval between two measurements.
2. In "Samples" enter the number of measurements.
3. In "Displayed Samples" select how many measurements will be shown in the graphic.
4. Click the "Start" button.

The status (to the right of the graphic) indicates whether the signal recorder is running. The first measured value is displayed only after the set time interval has elapsed.

5. To stop the recording, click the "Stop" button.

6. Change to one of the following menu items to call up the result of the recording:
  - System > Load&Save > HTTP  
Click the "Save" button in the "WLANSigRec" table row to save the file "signal\_recorder\_SCALANCE\_W700.zip" in the file system of the connected PC.
  - System > Load&Save > TFTP  
If necessary, change the file name "signal\_recorder\_SCALANCE\_W700.zip" in the "WLANSigRec" table row. In the table row "WLANSigRec", select the "Save file" entry from the drop-down list of the last column and click the "Save Values" button.
7. The ZIP file contains two files with the results of the recording:
  - A PDF file: The output is limited to 300 pages.
  - A CSV file: Complete listing of the recording.

## Measurement results

### PDF file


The PDF file contains a graphic representation of the course of the effective user data signal in dBm and the course of the data rate in Mbps. In terms of color, the graphic corresponds to the appearance in the Web Based Management. If the client changes the access point (roaming) during the measurement, this is indicated by vertical black bars with a black square at the tip.


The display is divided into two areas:

- Client  
Represents the measurement of the client.
- Access point  
Displays the measurement of the access point with which the client is currently connected. This requires that the setting "Bidirectional Recording" is enabled and that a firmware version > 6.1 is installed on the access point. The access point sends its data to a maximum of 3 clients on which signal recorders are running. The access point data is not displayed on other clients.

If the client has an iPCF-MC connection, the user signal of the management channel is shown with an additional black line.

Below the graphic, the configuration data of the client is displayed.





Example of a generated PDF file

The following pages contain the detailed information of all individual measurements in the form of a table.

The header row shows the IP address of the client and the BSSID and system name of the access point.

Per measurement the table contains two rows. The data of the client is in the first row and the data belonging to the access point in the second.

Sample	Timestamp	Sig%	dBm	NF	RSSI	Roam	Ch	Retry%	HT-40	TX-Rate	RX-Rate	Con-St	M-Sig	M-ChM-NF
1	01:09:20:090	76	-56	-110	39	0	161	11	-	130.00	121.50	1	---	---
		63	-63	-112	32			8						

Page 2 shows a legend of the abbreviations in the table. The data starts on a new page when the client changes access points.

Note

Note the description of the individual columns in the CSV file. These also apply to the columns of the PDF file.

CSV file

The CSV file contains information on the configuration of the SCALANCE W700 device and detailed information on all individual measurements and is divided into two areas. The first area contains the configured settings:

- System Name  
The system name of the client
- Device IP  
The IP address of the client
- Device MAC  
The MAC address of the client
- Recording Interval  
The interval between acquisition of two measured values
- Max TX Power  
Maximum transmit power of the device
- Begin Recording  
Start of the recording
- End Recording  
End of the recording
- Recorded Samples  
The total number of measurements
- Max. TX Rate  
The maximum data rate of the sent data packets.
- Max. RX Rate  
The maximum data rate of the received data packets.
- Rx Antenna x type  
The setting of the external antennas

The second area is a table. The table contains the following for each measured value:

- Sample  
The current number of the measurement on the client (CL) / on the access point (AP)
- Timestamp  
The time stamp
- BSSID  
The BSSID (Basic Service Set Identification) of the access point
- CL / AP RX-Signal [%]  
The effective user data signal of the client (CL) / access point (AP) in %
- CL / AP RX-Signal [dBm]  
The effective user data signal of the client (CL) / access point (AP) in dBm

- CL / AP NF [dBm]  
The background noise in dBm
- CL / AP RSSI  
The raw value of the RSSI (Received Signal Strength Indication)
- Roam  
The roaming counter shows how often the client has changed access points during the recording. After 4 294 967 295 changes the counter is reset.
- CL / AP Retry  
The transfer repetitions of the client (CL) / access point (AP)
- Con Stations  
Number of clients connected to the access point.
- Operating Ch.  
The current channel or the channel on which the client is connected to the access point
- HT-40  
The channel bandwidth 40 MHz
- Scan CH  
The channel on which the client is currently scanning.
- TX-Rate  
The average data rate of the sent data packets
- RX-Rate  
The average data rate of the received data packets

---

**Note**

The columns that relate to the management channel only contain a value if there is an iPCF-MC connection.

---

- M-Ch  
The management channel
- M-Sig  
The effective user data signal of the management channel
- M-NF  
The background noise of the management channel
- AP System Name  
The system name of the access point

## 6.6 "Interfaces" menu

System Name: 104  
 Device IP: 192.168.1.104  
 Device MAC: 00:1b:1b:e6:29:d0  
 Device Type: SCALANCE W788-2 RJ45  
 Version: V06.01.01.00\_06.01.01 03/16/2017  
 Recording Interval: 00100 ms  
 Max TX Power: 20 dBm  
 Begin Recording: Sat Jan 1 01:09:20 2000  
 End Recording: Sat Jan 1 01:11:10 2000  
 Recorded Samples: 01100  
 Max TX Rate: 130.00 Mbps  
 Max RX Rate: 130.00 Mbps

R1 Antenn Gain: 3 dBi Add. Attenua Cable length: 0 m  
 R1 Antenn Gain: 3 dBi Add. Attenua Cable length: 0 m  
 R1 Antenn Gain: 0 dBi Add. Attenua Cable length: 0 m

Sample	Timestamp	BSSID	CL RX-Signal	AP RX-Sign	CL RX-Sign	AP RX-Sign	CL NF	AP NF	CL RSSI	AP RSSI	Roam	CL Retry	AP Retry	Con Stations	Operati ng Ch.	HT- 40	Scan Ch	TX-Rate	RX-Rate	M-Ch	M-Sig	M-NF	AP System Name
1	01:09:20:090	00:1b:1b:e6:29:d0	76	63	-56	-63	-110	-112	39	32	0	11	8	1	161	-	161	130	121	---	---	---	106
2	01:09:20:190	00:1b:1b:e6:29:d0	80	63	-54	-63	-110	-112	41	32	0	0	0	1	161	-	161	130	121	---	---	---	106
3	01:09:20:290	00:1b:1b:e6:29:d0	76	63	-56	-63	-110	-112	39	32	0	0	0	1	161	-	161	130	121	---	---	---	106
4	01:09:20:390	00:1b:1b:e6:29:d0	78	63	-55	-63	-110	-112	40	32	0	0	0	1	161	-	161	130	121	---	---	---	106
5	01:09:20:490	00:1b:1b:e6:29:d0	78	63	-55	-63	-110	-112	40	32	0	0	0	1	161	-	161	130	121	---	---	---	106

Example of a generated CSV file

## 6.6.2.13 Spectrum Analyzer

## Technical information

The frequency range depends on the configuration.

Parameters		Value
Amplitude accuracy	In 2.4 GHz	3 dBm
	In 5 GHz	7 dBm
Resolution bandwidth		330 KHz
Min. signal strength		-100 dBm
Max. signal strength		0 dBm
Analysis time	At 40 MHz	120 ms
	At 20 MHz	95 ms
Update time		1 s.

## Representing signals of the frequency range

With the spectrum analyzer you can recognize and represent the electromagnetic signals of a frequency range. You can measure the strength of all signals located in the environment of the access point.

---

### Note

This WBM page is only available in access point mode.

The WLAN interface of the device must be enabled, otherwise the frequency ranges cannot be scanned.

---

### Note

We recommend that you do not use the spectrum analyzer in the change mode "Manual Commit".

---

### Note

When the spectrum analyzer is started, all WLAN connections are terminated on both WLAN interfaces. The access point then also does not send any beacons.

---

### Note


Do not enable the spectrum analyzer if the device is operating productively. This can influence the performance of the device.

---

### Note

The functionality of the spectrum analyzer does not replace a dedicated spectrum analyzer.

---




Description

The page contains the following graphics:

In all graphics, the lower x axis shows the channels around the selected center frequency for which the measurements are made. The upper x axis shows the frequency range. The display of the y axis depends on the selected graphic.

- Realtime




The y axis shows the signal strength in dBm.

The graphic shows the strength of all signals that the access point receives in its environment in the configured frequency range.

The red line shows the maximum values since the start of the measurement. The white line shows the current values. The green line shows the average values.

- Spectrogram




The y axis shows the course of the measured values over time from current (0 s) to the values received before 500 s.

The graphic shows the strength of all signals that the access point receives in its environment in the configured frequency range.

The color depends on the setting for "Color Scheme".

- Density Chart




The y axis shows the signal strength in dBm.


The graphic shows how often signals occur with a certain strength in the configured frequency range.

The color goes from the lowest value (0%) in black to the highest value (100%) in red.

The page contains the following buttons:

- Zoom in 

With this icon you only show one graphic type in large format on the page.

- Zoom out 

With this icon you return to the view with all three graphic types.

- Color Scheme 

With this icon, you change the color scheme for the graphic type "Spectrogram":

- The color goes from the lowest value (-100 dBm) in black to the highest value (0 dBm) in red.
- The color goes from the lowest value (-100 dBm) in red to the highest value (0 dBm) in black.

- Reset 

With this icon you reset the maximum and average values of the graphic type "Realtime".

This table contains the following columns:

- **Radio**

Shows the WLAN interface to which the information applies.

- **State**

Shows the status of the measurement. The following values are possible:

- stopped  
The measurement was stopped.
- running  
The measurement is running.

- **Frequency Band**

Specify the frequency band.

- **Center Frequency**

Select the center frequency.

- **Start**

Click the button in this column to start the measurement.

- **Stop**

Click the button in this column to end the measurement.

## Procedure

1. Select the required frequency band from the "Frequency Band" drop-down list.
2. Select the required center frequency from the "Center Frequency" drop-down list.
3. Click the "Start" button.
4. To stop the measurement, click the "Stop" button.
5. You can adapt the settings in the second table during the measurement.

6. Change to one of the following menu items to call up the result of the measurement:
  - System > Load&Save > HTTP  
Click the "Save" button in the "WLANSpectrumAnalyzer" table row to save the file "wlan\_spectrum\_analyzer\_SCALANCE\_W700.zip" in the file system of the connected PC.
  - System > Load&Save > TFTP  
If necessary, change the file name "wlan\_spectrum\_analyzer\_SCALANCE\_W700.zip" in the "WLANSpectrumAnalyzer" table row. In the table row "WLANSpectrumAnalyzer", select the "Save file" entry from the drop-down list of the last column and click the "Save Values" button.
7. The ZIP file contains a CSV file with the results of the measurement..

## Measurement results

### CSV file

The CSV file contains information on the configuration of the device and detailed information on all individual measurements and is divided into two areas. The first area contains the configured settings:

- System Name  
The system name of the access point
- Device IP  
The IP address of the device
- Device MAC  
The MAC address of the device
- Recording Interval  
The interval between acquisition of two measured values

The second area is a table. The table contains the following for each measured value:

- Sample  
The consecutive number of the measurement
- Timestamp  
The time stamp
- The following columns show all frequencies of the selected frequency band. The cells are only filled for the frequencies for which a value was measured. The measured values show the signal strength in dBm.

### 6.6.3 Remote Capture

On this WBM page activate the function "Remote Capture" on the interface (Ethernet, WLAN). The function is for network diagnostics via a connected PC, e.g. to detect transfer errors.

You can also enable the function on several interfaces at the same time. When the function is enabled the interface can be linked in Wireshark. For a period Wireshark record the data traffic over the interface. Afterwards from the recording you can see the content of the frames or filter according to certain contents.

Interface	Enable
P1	<input type="checkbox"/>
WLAN 1	<input type="checkbox"/>

WLAN Capture Mode: Own Traffic

☐ Activate after System Restart

Information: The wireless communication is not possible in WLAN Capture Mode 'All Traffic'. WLAN Capture Mode 'Own Traffic' may influence the wireless communication.

Set Values Refresh

## Description

This table contains the following columns:

- **Interface**

The interface to which the entry relates.

- **Enable**

Enable or disable the "Remote Capture" function. As default, the function is disabled.

---

### Note

### Performance

Enable the function only for diagnostics purposes. The increased data traffic could influence the performance of the device.

---

The page contains the following boxes:

- **WLAN Capture Mode (only in access point mode)**

Specify the recording mode for the WLAN interface:

- Own Traffic

In this case, the frames are recorded that were received and sent by the device.

Exception: The data packets dealt with directly by the hardware are not displayed, for example hardware repetitions, acknowledgment frames.

- All Traffic

The access point sends no more frames but records all incoming data packets.

---

**Note**

**No WLAN communication between access point and clients**

If the setting "All Traffic" is used, the access point is no longer reachable for other nodes and loses the connected clients.

---

- **Activate after System Restart**

- Disabled

After a restart the configuration is reset to the default settings.

- Enabled

The configuration is saved and retained after a restart.

## Linking in the interface in Wireshark

### Requirement:

- Wireshark V2.0.0 is installed on the PC.
- The PC and device must be reachable via IP (layer 3).

### Procedure

To analyze the data traffic e.g. of the WLAN interface 1 in Wireshark, follow the steps below:

1. Activate the function "Remote Capture" on the device on the WLAN interface.
2. As the receive mode, select "Own Traffic".
3. Click "Set Values" to enable the function.
4. Start Wireshark.
5. Click "Options" in the "Capture" menu. The window "Wireshark - Capture Interfaces" opens.
6. Click the "Manage Interfaces..." button on the "Input" tab. In the following dialog, click on the "Remote Interfaces" tab.
7. To add the interface click on the Plus character in the "Remote Interfaces" tab.
8. In the following dialog for "Host" enter the IPv4 address of the device and for "Port" 2002.
9. Enable "Null authentication" for "Authentication" and click the "OK" button.
10. On the "Remote Interfaces" tab, the host and the interfaces on which the function "Remote Capture" was previously enabled are displayed.
11. Select the interface and click the "OK" button.
12. To start the recording click "Start". You can obtain further information about handling the program in Wireshark.

If you analyze several interfaces you can use a Wireshark instance for each interface.

## 6.7 "Layer 2" menu

### 6.7.1 VLAN

#### 6.7.1.1 General

#### VLAN configuration page

On this page you specify whether or not the device forwards frames with VLAN tags transparently (IEEE 802.1D/VLAN-unaware mode) or takes VLAN information into account (IEEE 802.1Q/VLAN-aware mode). If the device is in the "802.1Q VLAN Bridge" mode, you can define VLANs and specify the use of the ports .

#### Note

##### Changing the agent VLAN ID

If the configuration PC is connected directly to the device via Ethernet and you change the agent VLAN ID, the device is no longer reachable via Ethernet following the change.

Virtual Local Area Network (VLAN) General

General
Port Based VLAN

Base Bridge Mode: 802.1Q VLAN Bridge

VLAN ID:

Select	VLAN ID	Name	Status	P1	VAP 1.1	VAP 1.2	VAP 1.3	VAP 1.4	VAP 1.5
<input type="checkbox"/>	1		Static	U	U	U	U	U	
<input type="checkbox"/>	2		Static	-	-	-	-	-	
<input type="checkbox"/>	3		Static	-	-	-	-	-	

3 entries.

Create Delete Set Values Refresh

## Description

The page contains the following boxes:

- **Base Bridge mode**

Select the required mode from the drop-down list. The following modes are possible:

---

**Note****Changing Base bridge mode**

Note the section "Changing Base bridge mode". This section describes how a change affects the existing configuration.

---

- 802.1Q VLAN Bridge

Sets the mode "VLAN-aware" for the device. In this mode, VLAN information is taken into account. In this mode, you can create additional VLANs.

- 802.1D Transparent Bridge

Sets the mode "VLAN-unaware" for the device. In this mode, VLAN tags are not changed but are forwarded transparently. The VLAN priority is evaluated for CoS. In this mode, you cannot create any VLANs. Only a management VLAN is available: VLAN 1.

- **VLAN ID**

Enter the VLAN ID in the "VLAN ID" input box.

Range of values: 1 ... 4094

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **VLAN ID**

Shows the VLAN ID. The VLAN ID (a number between 1 and 4094) can only be assigned once when creating a new data record and can then no longer be changed. To make a change, the entire data record must be deleted and created again. Up to 8 VLANs can be defined.

- **Name**

Enter a name for the VLAN. The name only provides information and has no effect on the configuration. The length is a maximum of 32 characters.

- **Status**

Shows the status type of the entry in the port filter table. Here, static means that the address was entered as a static address by the user.

- **List of ports**

Specify the use of the port. The following options are available:

- "-"  
The port is not a member of the specified VLAN.  
With a new definition, all ports have the identifier "-".
- M  
The port is a member of the VLAN. Frames sent in this VLAN are forwarded with the corresponding VLAN tag.
- U (uppercase)  
The port is an untagged member of the VLAN. Frames sent in this VLAN are forwarded without the VLAN tag. Frames without a VLAN tag are sent from this port.
- u (lowercase)  
The port is an untagged member of the VLAN, but the VLAN is not configured as a port VLAN. Frames sent in this VLAN are forwarded without the VLAN tag.
- F  
The port is not a member of the specified VLAN. You can configure other settings in "Layer 2 > VLAN > Port Based VLAN".
- T  
This option is only displayed and cannot be selected in the WBM.  
This port is a trunk port, making it a member in all VLANs.  
You configure this function in the CLI (Command Line Interface) using the "`switchport mode trunk`" command.

## Changing Base bridge mode

### VLAN-unaware (802.1D transparent bridge) → VLAN-aware (802.1Q VLAN bridge)

If you change the Base Bridge mode from VLAN-unaware to VLAN aware, this has the following effects:

- All static and dynamic unicast entries are deleted.

### VLAN-aware (802.1Q VLAN bridge) → VLAN-unaware (802.1D transparent bridge)

If you change the Base Bridge mode from VLAN-aware to VLAN-unaware, this has the following effects:

- All VLAN configurations are deleted.
- A management VLAN is created: VLAN 1.
- All static and dynamic unicast entries are deleted.

## 802.1Q VLAN Bridge: Important rules for VLANs

Make sure you keep to the following rules when configuring and operating your VLANs:

- Frames with the VLAN ID "0" are handled as untagged frames but retain their priority value.
- As default, all ports on the device send frames without a VLAN tag to ensure that the end node can receive these frames.
- With SCALANCE W devices, the VLAN ID "1" is the default on all ports.
- If an end node is connected to a port, outgoing frames should be sent without a tag (static access port). If, however, there is a further switch at this port, the frame should have a tag added (trunk port).
- With a trunk port, the VLAN assignment is dynamic. Static configurations can only be created if, in addition to the trunk port property, the port is also entered statically as a member in the VLANs involved. An example of a static configuration is the assignment of multicast groups in certain VLANs.

## Procedure

### Requirement:

In Base Bridge mode "802.1Q VLAN Bridge" is set.

### Creating a new VLAN

1. Enter an ID in the "VLAN ID" input box.
2. Click the "Create" button. A new entry is generated in the table. As default, the boxes have "-" entered.
3. Enter a name for the VLAN under Name.
4. Specify the use of the port in the VLAN. If, for example you select M, the port is a member of the VLAN. The frame sent in this VLAN is forwarded with the corresponding VLAN tag.
5. Specify the mode of the device.
6. Click the "Set Values" button.

## 6.7.1.2 Port-based VLAN

### Processing received frames

On this page, you specify the configuration of the port properties for receiving frames.

### Requirement:

- On the "General" page, "802.1Q VLAN Bridge" is set for "Base Bridge Mode".

### Port Based Virtual Local Area Network (VLAN) Configuration

General
Port Based VLAN

	Priority	Port VID	Acceptable Frames	Ingress Filtering	Copy to Table
All ports	No Change	No Change	No Change	No Change	Copy to Table

Port	Priority	Port VID	Acceptable Frames	Ingress Filtering
P1	0	VLAN1	All	<input type="checkbox"/>
VAP 1.1	0	VLAN1	All	<input type="checkbox"/>
VAP 1.2	0	VLAN1	All	<input type="checkbox"/>
VAP 1.3	0	VLAN1	All	<input type="checkbox"/>
VAP 1.4	0	VLAN1	All	<input type="checkbox"/>
VAP 1.5	0	VLAN1	All	<input type="checkbox"/>
VAP 1.6	0	VLAN1	All	<input type="checkbox"/>
VAP 1.7	0	VLAN1	All	<input type="checkbox"/>
VAP 1.8	0	VLAN1	All	<input type="checkbox"/>
VAP 2.1	0	VLAN1	All	<input type="checkbox"/>
VAP 2.2	0	VLAN1	All	<input type="checkbox"/>

Set Values
Refresh

## Description

Table 1 has the following columns:

### Note

Table 1 is only available if at least one VLAN is configured.

- Port**  
Shows that the settings are valid for all ports of table 2.
  - Priority / Port VID / Acceptable Frames / Ingress Filtering**  
In the drop-down list, select the setting for all ports. If "No Change" is selected, the entries of the corresponding column in Table 2 remain unchanged.
  - Copy to Table**  
If you click the button, the setting is adopted for all ports of table 2.
- Table 2 has the following columns:
- Port**  
Shows the available ports and interfaces.
  - Priority**  
From the drop-down list, select the priority given to untagged frames.  
The CoS priority (Class of Service) used in the VLAN tag. If a frame is received without a tag, it will be assigned this priority. This priority specifies how the frame is further

processed compared with other frames.

There are a total of eight priorities with values 0 to 7, where 7 represents the highest priority (IEEE 802.1p Port Priority).

- **Port VID**

Select the VLAN ID from the drop-down list. Only VLAN IDs defined on the "VLAN > General" page can be selected.

If a received frame does not have a VLAN tag, it has a tag with the VLAN ID specified here added to it and is sent according to the rules at the port.

- **Acceptable Frames**

Specify which types of frames will be accepted. The following alternatives are possible:

- Tagged Frames Only  
The device discards all untagged frames. Otherwise, the forwarding rules apply according to the configuration.
- All  
The device forwards all frames.
- No Change  
If "No Change" is selected, the entries of the corresponding column in table 2 remain unchanged.

- **Ingress Filtering**

Specify whether the VID of received frames is evaluated.

You have the following options:

- Enabled  
The VLAN ID of received frames decides whether they are forwarded: To forward a VLAN tagged frame, the receiving port must be a member in the same VLAN. Frames from unknown VLANs are discarded at the receiving port.
- Disabled  
All frames are forwarded.
- No Change  
If "No Change" is selected, the entries of the corresponding column in table 2 remain unchanged.

## Procedure

1. In the row of the port to be configured, click on the relevant cell in the table to configure it.
2. Enter the values to be set in the input boxes as follows.
3. Select the values to be set from the drop-down lists.
4. Click the "Set Values" button.


## 6.7.2 Dynamic MAC Aging

### Protocol settings and switch functionality

The device automatically learns the source addresses of the connected nodes. This information is used to forward frames to the nodes specifically involved. This reduces the network load for the other nodes.

If a device does not receive a frame whose source address matches a learnt address within a certain time, it deletes the learnt address. This mechanism is known as "Aging". Aging prevents frames being forwarded incorrectly, for example when an end device (for example a programming device) is connected to a different port.

If the check box is not enabled, a device does not delete learnt addresses automatically.



### Description

The page contains the following boxes:

- **Dynamic MAC Aging**  
Enable or disable the function for automatic aging of learned MAC addresses:
- **Aging Time [s]**  
Enter the time in seconds. After this time, a learned address is deleted if the device does not receive any further frames from this sender address. The range of values is from 10 seconds to 630 seconds

### Procedure

1. Select the "Dynamic MAC Aging" check box.
2. Enter the time in seconds in the "Aging Time [s]" input box.
3. Click the "Set Values" button.

## 6.7.3 Spanning Tree

### 6.7.3.1 General

#### General settings of spanning tree

This is the basic page for spanning tree. Select the compatibility mode from the drop-down list. As default, Multiple Spanning Tree is enabled.

On the configuration pages of these functions, you can make detailed settings.

Depending on the compatibility mode, you can configure the corresponding function on the relevant configuration page.


---

#### Note

##### Client device not as root

Using the configuration of priorities and path costs, make sure that a client device can never become the root node. If a client device becomes the root node the Rapid Spanning Tree function no longer works.

---



Spanning Tree Protocol (STP) General

General CIST General CIST Port MST General MST Port

☒ Spanning Tree Protocol Compatibility: RSTP ▼

Set Values Refresh

#### Description

The page contains the following boxes:

- **Spanning Tree**

Enable or disable MSTP.

- **Protocol Compatibility**

Select the compatibility mode of MSTP. For example if you select RSTP, MSTP behaves like RSTP.

The following settings are available:

- STP
- RSTP
- MSTP

---

**Note**

If iPCF mode is enabled, only the compatibility modes STP and RSTP are supported.

---

**Procedure**

1. Select the "MSTP" check box.
2. Select the compatibility mode from the "Protocol Compatibility" drop-down list.
3. Click the "Set Values" button.

### 6.7.3.2 CIST General

#### MSTP-CIST configuration

The page consists of the following parts.

- The left-hand side of the page shows the configuration of the device.
- The central part shows the configuration of the root bridge that can be derived from the spanning tree frames received by an device.
- The right-hand side shows the configuration of the regional root bridge that can be derived from the MSTP frames received by an device. The displayed data is only visible if you have enabled "Spanning Tree" on the "General" page and when "Protocol Compatibility" is set to "MSTP". This also applies to the "Bridge Max Hop Count" parameter. If the device is a root bridge, the information on the left and right matches.

Common Internal Spanning Tree (CIST) General				
General	CIST General	CIST Port	MST General	MST Port
Bridge Priority: 32768	Root Priority: 0			
Bridge Address: 00-00-00-00-00-00	Root Address: 00-00-00-00-00-00			
Root Port: -	Root Cost: 0			
Topology Changes: 0	Last Topology Change: -			
Bridge Hello Time[s]: 2	Root Hello Time[s]: 2			
Bridge Forward Delay[s]: 15	Root Forward Delay[s]: 15			
Bridge Max Age[s]: 20	Root Max Age[s]: 20			
<input type="button" value="Reset Counters"/>				
<input checked="" type="checkbox"/> Layer-2 Tunnel Admin Edge Port				
<input checked="" type="checkbox"/> Layer-2 Tunnel Auto Edge Port				
<input type="button" value="Set Values"/> <input type="button" value="Refresh"/>				

#### Description

The page contains the following boxes:

- **Bridge Priority / Root Priority**

Which device becomes the root bridge is decided based on the bridge priority. The bridge with the highest priority becomes the root bridge. The lower the value, the higher the priority. If several devices in a network have the same priority, the device whose MAC address has the lowest numeric value will become the root bridge. Both parameters, bridge priority and MAC address together form the bridge identifier. Since the root bridge manages all path changes, it should be located as centrally as possible due to the delay of the frames. The value for the bridge priority is a whole multiple of 4096 with a range of values from 0 to 61440.

- **Bridge Address / Root Address**

The bridge address shows the MAC address of the device and the root address shows the MAC address of the root bridge.

- **Root port**

Shows the port via which the switch communicates with the root bridge.
- **Root Cost**

The path costs from this device to the root bridge.
- **Topology Changes / Last Topology Change**

The entry for the device shows the number of reconfiguration actions due to the spanning tree mechanism since the last startup. For the root bridge, the time since the last reconfiguration is displayed as follows:

  - Seconds: sec unit after the number
  - Minutes: min unit after the number
  - Hour: hr unit after the number
- **Topology Changes / Last Topology Change**

Each bridge regularly sends configuration frames (BPDUs). The interval between two such frames is the Hello time. The default for this parameter is 2 seconds.
- **Bridge Forward Delay[s] / Root Forward Delay[s]**
- New configuration data is not used immediately by a bridge but only after the period specified in the forward delay parameter. This ensures that operation is started with the new topology only after all the bridges have the required information. The default for this parameter is 15 seconds.
- **Bridge Max Age / Root Max Age**

Bridge Max Age defines the maximum "age" of a received BPDU for it to be accepted as valid by the switch. The default for this parameter is 20.
- **Bridge Max Hop Count**

This parameter specifies how many MSTP nodes a BPDU may pass through. If an MSTP BPDU is received and has a hop count that exceeds the value configured here, it is discarded. The default for this parameter is 20.
- **Regional root priority**

For a description of the displayed values, see Bridge priority / Root priority
- **Regional root address**

Shows the MAC address of the regional root bridge.
- **Regional Root Cost**

Shows the path costs from this device to the regional root bridge.
- **Region Name**

Enter the name of the MSTP region to which this device belongs. As default, the MAC address of the device is entered here. This value must be the same on all devices that belong to the same MSTP region.
- **Region Version**

Enter the version number of the MSTP region in which the device is located. This value must be the same on all devices that belong to the same MSTP region.

- **Reset Counters**

Click this button to reset the counters on this page.

- **Layer-2 Tunnel Admin Edge Port (Only available in access point mode)**

Select this check box if there can be an end device on a layer 2 tunnel port. Otherwise a reconfiguration of the network will be triggered whenever a link to this port is modified. The L2T clients should be interconnected.

- **Layer-2 Tunnel Auto Edge Port (Only available in access point mode)**

Select this check box if you want to detect automatically whether or not an end device is connected at all layer 2 tunnel ports.

## Procedure

1. Enter the data required for the configuration in the input boxes.
2. Click the "Set Values" button.

### 6.7.3.3 CIST Port

#### MSTP-CIST port configuration

When the page is called, the table displays the current status of the configuration of the port parameters.

To configure them, click the relevant cells in the port table.

Common Internal Spanning Tree (CIST) Port Access Poi

General | CIST General | CIST Port | MST General | MST Port

Spanning Tree Status Copy to Table

All ports No Change Copy to Table

Port	Spanning Tree Status	Priority	Cost Calc.	Path Cost	State	Fwd. Trans.	Edge Type	Edge	P.t.P. Type	P.t.P.	Hello Time
P1	<input checked="" type="checkbox"/>	128	0	20000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.1	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.2	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.3	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.4	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.5	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.6	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.7	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 1.8	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2
VAP 2.1	<input checked="" type="checkbox"/>	128	0	200000000	Disabled	0	Auto	<input type="checkbox"/>	-	<input checked="" type="checkbox"/>	2

Set Values Refresh

## Description

Table 1 has the following columns:

- **Column 1**

Shows that the settings are valid for all ports of table 2.

- **Spanning Tree Status**

In the drop-down list, select the setting for all ports. If "No Change" is selected, the entries of the corresponding column in table 2 remain unchanged.

- **Copy to table**

If you click the button, the settings are adopted for all ports of table 2.

Table 2 has the following columns:

- **Port**

Shows the available ports and interfaces.

- Port X
- WLAN X
- VAP X.Y
- WDS X.Y

- **Spanning Tree Status**

Specify whether the port is integrated in the spanning tree or not.

---

**Note**

If you disable the "Spanning Tree Status" option for a port, this may cause the formation of loops. The topology must be kept in mind.

---

- **Priority**

Enter the priority of the port. The priority is only evaluated when the path costs are the same.

The value must be divisible by 16. If the value that cannot be divided by 16, the value is automatically adapted.

Range of values: 0 - 240.

The default is 128.

- **Cost Calc.**

Enter the path cost calculation. If you enter the value "0" here, the automatically calculated value is displayed in the "Path Cost" box.

- **Path Cost**

The path costs from this port to the root bridge. The path with the lowest value is selected as the path. If several ports of a device have the same value, the port with the lowest port number will be selected.

If the "Cost Calc." box has the value "0", the automatically calculated value is shown.

Otherwise, the value of the "Cost Calc." box is displayed.

The calculation of the path costs is largely based on the transmission speed. The higher the achievable transmission speed is, the lower the value of the path costs.

Typical values for path costs with rapid spanning tree:

- 1000 Mbps = 20,000
- 100 Mbps = 200,000
- 10 Mbps = 2,000,000

The values can, however, also be set individually.

- **State**

Displays the current state of the port. The values are only displayed and cannot be configured. The "State" parameter depends on the configured protocol. The following is possible for status:

- Disabled  
The port only receives and is not involved in STP, MSTP and RSTP.
- Discarding  
In the "Discarding" mode, BPDU frames are received. Other incoming or outgoing frames are discarded.
- Listening  
In this status, BPDUs are both received and sent. The port is involved in the spanning tree algorithm.
- Learning  
Stage prior to the forwarding status, the port is actively learning the topology (in other words, the node addresses).
- Forwarding  
Following the reconfiguration time, the port is active in the network; it receives and forwards data frames.

- **Fwd. Trans**

Specifies the number of changes from the "Discarding" status to the "Forwarding" status.

- **Edge Type**

Specify the type of edge port. You have the following options:

- "-"  
Edge port is disabled. The port is treated as a "no EdgePort".
- Admin  
Select this option when there is always an end device on this port. Otherwise a reconfiguration of the network will be triggered each time a connection is changed.
- Auto  
Select this option if you want a connected end device to be detected automatically at

this port. When the connection is established the first time, the port is treated as a "no Edge Port".

- Admin/Auto

Select these options if you operate a combination of both on this port. When the connection is established the first time, the port is treated as an Edge Port.

- **Edge**

Shows the status of the port.

- Enabled

An end device is connected to this port.

- Disabled

There is a spanning tree or rapid spanning tree device at this port.

With an end device, a switch can change over the port faster without taking into account spanning tree frames. If a spanning tree frame is received despite this setting, the port automatically changes to the "Disabled" setting for switches.

- **P.t.P. type**

Select the required option from the drop-down list. The selection depends on the port that is set.

- P.t.P.

Even with half duplex, a point-to-point link is assumed.

- Shared Media

Even with a full duplex connection, a point-to-point link is not assumed.

---

**Note**

Point-to-point link means a direct connection between two devices. A shared media connection is, for example, a connection to a hub.

---

- "\_"

Point to point is determined automatically. If the port is set to half duplex, a point-to-point link is not assumed.

- **P.t.P.**

- Enabled

Shows that a point-to-point link exists.

- Disabled

Shows that no point-to-point link exists

- **Hello Time**

Enter the interval after which the bridge sends configuration BPDUs. As default, 2 seconds is set.

Range of values: 1-2 seconds

---

**Note**

The port-specific setting of the Hello time is only possible in MSTP compatible mode.

---

Procedure

- 1. In the input cells of the table row, enter the values of the port you are configuring.
- 2. From the drop-down lists of the cells of the table row, select the values of the port you are configuring.
- 3. Click the "Set Values" button.

6.7.3.4 MST General

Multiple Spanning Tree configuration

With MSTP, in addition to RSTP, several VLANs can be managed in a LAN with separate RSTP trees.

Multiple Spanning Tree (MST) General

GeneralCIST GeneralCIST PortMST GeneralMST Port

MSTP Instance ID:

Select	MSTP Instance ID	Root Address	Root Priority	Bridge Priority	VLAN ID
0 entries.					

CreateDeleteRefresh

Description

The page contains the following box:

- **MSTP Instance ID**  
Enter the number of the MSTP instance.  
Permitted values: 1 - 64  
You can define up to 16 MSTP instances.

The table has the following columns:

- **Select**  
Select the row you want to delete.
- **MSTP Instance ID**  
Shows the number of the MSTP instance.
- **Root Address**  
Shows the MAC address of the root bridge
- **Root Priority**  
Shows the priority of the root bridge.

- **Bridge Priority**

Enter the bridge priority in this box. The value for the bridge priority is a whole multiple of 4096 with a range of values from 0 to 61440.

- **VLAN ID**

Enter the VLAN ID. Here, you can also specify ranges with Start ID, "-", End ID. Several ranges or IDs are separated by ",".

Permitted values: 1- 4094

## Procedure

### Creating a new entry

1. Enter the number of the MSTP instance in the "MSTP Instance ID" box.
2. Click the "Create" button.
3. Enter the identifier of the virtual LAN in the "VLAN ID" input box.
4. Enter the priority of the bridge in the "Bridge Priority" box.
5. Click the "Set Values" button.

### Deleting entries

1. Use the check box at the beginning of the relevant row to select the entries to be deleted.
2. Click the "Delete" button to delete the selected entries from memory. The entries are deleted from the memory of the device and the display on this page is updated.

### 6.7.3.5 MST Port

#### Configuration of the Multiple Spanning Tree port parameters

On this page, you set the parameters for the ports of the configured multiple spanning tree instances.

Multiple Spanning Tree (MST) Port

General

CIST General

CIST Port

MST General

MST Port

MSTP Instance ID: 1

MSTP Status

Copy to Table

All ports

No Change

Copy to Table

Port	MSTP Instance ID	MSTP Status	Priority	Cost Calc.	Path Cost	State	Fwd. Trans.
P1	1	<input checked="" type="checkbox"/>	128	0	200000	Forwarding	1
VAP 1.1	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
VAP 1.2	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
VAP 1.3	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
VAP 1.4	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
WDS 1.1	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
WDS 1.2	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
WDS 1.3	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0
WDS 1.4	1	<input checked="" type="checkbox"/>	128	0	200000000	Discarding	0

Set Values

Refresh

#### Description

The page contains the following box:

- **MSTP Instance ID**

In the drop-down list, select the ID of the MSTP instance.

Table 1 has the following columns:

- **Column 1**

Shows that the settings are valid for all ports of table 2.

- **MSTP Status**

In the drop-down list, select the setting for all ports. If "No Change" is selected, the entries of the corresponding column in table 2 remain unchanged.

- **Copy to table**

- If you click the button, the setting is adopted for all ports of table 2.

Table 2 has the following columns:

- **Port**

Shows all available ports and interfaces.

- **MSTP instance ID**

Shows the ID of the MSTP instance.

- **MSTP Status**

Click the check box to enable or disable this option.

- **Priority**

Enter the priority of the port. The priority is only evaluated when the path costs are the same.

The value must be divisible by 16. If the value that cannot be divided by 16, the value is automatically adapted.

Range of values: 0 - 240.

The default is 128.

- **Cost Calc.**

Enter the path cost calculation in the input box. If you enter the value "0" here, the automatically calculated value is displayed in the next box "Path Costs".

- **Path Cost**

The path costs from this port to the root bridge. The path with the lowest value is selected as the path. If several ports of a device have the same value, the port with the lowest port number will be selected.

If the "Cost Calc." box has the value "0", the automatically calculated value is shown.

Otherwise, the value of the "Cost Calc." box is displayed.

The calculation of the path costs is largely based on the transmission speed. The higher the achievable transmission rate, the lower the value for the path costs will be.

Typical values for rapid spanning tree are as follows:

- 1000 Mbps = 20,000
- 100 Mbps = 200,000
- 10 Mbps = 2,000,000

The values can, however, also be set individually.

- **Status**

Displays the current status of the port. The values are only displayed and cannot be configured. The following is possible for status:

- Discarding  
The port exchanges MSTP information but is not involved in the data traffic.
- Blocked  
In the blocking mode, BPDU frames are received.
- Forwarding  
The port receives and sends data frames.

- **Fwd. Trans.**

Specifies the number of status changes Discarding - Forwarding or Forwarding - Discarding.

## Procedure

1. In the input cells of the table row, enter the values of the port you are configuring.
2. From the drop-down lists of the cells of the table row, select the values of the port you are configuring.
3. Click the "Set Values" button.

### 6.7.4 DCP Forwarding

#### Applications

The DCP protocol is used by STEP 7 and the PST Tool for configuration and diagnostics. When shipped, DCP is enabled on all ports; in other words, DCP frames are forwarded at all ports. With this option, you can disable the sending of these frames for individual ports, for example to prevent individual parts of the network from being configured with the PST Tool or to divide the full network into smaller parts for configuration and diagnostics.

All the ports of the device are displayed on this WBM page.


---

#### Note

##### Empty table

If you have enabled NAT on the device, the table is empty or will be emptied.

---



Port	Setting
P1	Forward

Set Values Refresh

## Description

The table has the following columns:

- **Port**

Shows the available Ethernet ports.

- **Setting**

Specify whether the port should block or forward outgoing DCP frames. You have the following options available:

- **Block**

No outgoing DCP frames are forwarded via this port. It is nevertheless still possible to receive via this port.

- **Forward**

The DCP frames are forwarded via this port.

## Procedure

1. Specify whether the port blocks or forwards the DCP frames.
2. Click the "Set Values" button.

## 6.7.5 LLDP

### Identifying the network topology


LLDP (Link Layer Discovery Protocol) is defined in the IEEE 802.1AB standard.

LLDP is a method used to discover the network topology. Network components exchange information with their neighbor devices using LLDP.

Network components that support LLDP have an LLDP agent. The LLDP agent sends information about itself and receives information from connected devices at periodic intervals. The received information is stored in the MIB.

## Applications

PROFINET uses LLDP for topology diagnostics. In the default setting, LLDP is enabled for all ports; in other words, LLDP frames are sent and received on all ports. With this function, you have the option of enabling or disabling sending and/or receiving per port.



Port	Setting
P1	Rx & Tx

Set Values Refresh

## Description

The table has the following columns:

- **Port**  
Shows the port.
- **Setting**  
Specify the LLDP functionality. The following options are available:
  - Tx  
This port can only send LLDP frames.
  - Rx  
This port can only receive LLDP frames.
  - Rx & Tx  
This port can receive and send LLDP frames.
  - "-" (Disabled)  
This port can neither receive nor send LLDP frames.

## Procedure

1. Select the required LLDP functionality from the drop-down list.
2. Click the "Set Values" button.

## 6.8 "Layer 3" menu

### 6.8.1 NAT

#### 6.8.1.1 Basic

---

**Note**

This page is only available in client mode.

---

On this page, you specify the basic settings for NAT.

---

**Note**

You can find an application example for NAT and NAPT at the following address:  
<https://support.industry.siemens.com/cs/ww/en/view/37593580>

---

**IP Network Address Translation (NAT) Settings**

Basic | **NAPT**

Interface: P1 ▼

☐ Enable NAT

TCP Idle Timeout [s]: 86400

UDP Idle Timeout [s]: 300

Local Interface IP address: 10.10.10.10

Local Interface Subnet Mask: 0.0.0.0

☐ IPv6 Transparent Mode

**IPv4 Multicast Forwarding**

☒ From Global to Local Interface

☐ From Local to Global Interface

☐ PROFINET Transparent Mode

PROFINET Station Name: station\*;pumpe\*

## Description

The page contains the following boxes:

- **Interface**

Select the required Ethernet interface from the drop-down list.

- **Enable NAT**

Enable or disable NAT for the Ethernet interface.

- **TCP Idle Timeout [s]**

Enter the required time in seconds. If no data exchange takes place, the TCP connection is deleted from the translation table when this time has elapsed.

The range of values is 1 to 2147483.

Default setting: 86400 seconds

- **UDP Idle Timeout [s]**

Enter the required time in seconds. If no data exchange takes place, the UDP connection is deleted from the translation table when this time has elapsed.

The range of values is 1 to 2147483.

Default setting: 300 seconds

- **Local Interface IP address**

Enter the local IP address of the Ethernet interface. This IP address is the gateway address of the local device.

- **Local Interface Subnet Mask**

Enter the subnet mask for the local Ethernet.

- **IPv6 Transparent Mode**

When enabled, IPv6 frames are forwarded unchanged between Ethernet and WLAN.

This requires that "Own" is not set for MAC mode and IPv6 is turned off.

If you have set "Manual" for the MAC mode, you need to enter the MAC address of the IPv6 device that receives or sends the IPv6 frames.

- **IPv4 Multicast Forwarding**

Specify whether or not the incoming multicast frames will be forwarded.

- From Global to Local Interface

The multicast frames incoming on the WLAN interface are forwarded via the Ethernet interface into the internal network.

- From Local to Global Interface

The multicast frames incoming on the local Ethernet interface are forwarded via the WLAN interface into the external network.

- **PROFINET Transparent Mode**

Only available when the KEY-PLUG iFeatures is inserted.

With NAT, communication with connected PROFINET devices via WLAN is not possible because they are not visible to the outside.

If you select this setting, you can make individual PROFINET devices visible again. Frames are also forwarded transparently. The exceptions are made with the PROFINET device names.

"Layer 2 tunnel" must be set in MAC mode for PROFINET transparent mode.

---

**Note**

**PROFINET devices**

When PROFINET transparent mode is activated, the connected PROFINET devices cannot obtain the IP address from a DHCP server. Use a fixed IP address for these devices.

---

- **PROFINET device name**

The PROFINET device name determines which PROFINET devices are allowed to communicate with the outside world despite NAT.

Maximum length: 240 characters. The box must not be empty.

The following characters are permitted: [a ... z] [0 ... 9] and [ . ; - \* ]. Uppercase letters are not allowed.

For device names, you can replace any number of characters with the wildcard asterisk (\*). The asterisk can be anywhere, but may occur only once per device name.

You can specify multiple device names separated by a semicolon.

Examples:

- \* (asterisk)

Communication is possible with all connected PROFINET devices.

- pump1

Communication is only possible with this PROFINET device.

- pump\*

Stands for the device names that begin with "pump" e.g. pump1, pump2.

There are two pumping stations in a plant, for example. Station 1 contains "pump1" and station 2 contains "pump2". If you use this input, you can import the configuration on both WLAN clients.

- pump\*,controller\*

Stands for all device names that begin with "pump" or "controller".

## Procedure

1. In the "Local Interface IP address" input box, enter the local IP address of the Ethernet interface.
2. In the "Local Interface Subnet Mask" input box, enter the subnet mask for the local Ethernet.
3. Enable NAT for the Ethernet interface.
4. Enter the PROFINET device name.
5. Click the "Set Values" button.

### 6.8.1.2 NAT

#### Note

This page is only available in client mode.

On this WBM page, you define the translation list for communication from the global to the local network. Per WLAN client (NAT gateway), 60 entries are possible.

**IP Network Address Port Translation (NAPT)**

Basic
**NAPT**

Interface: P1

Traffic Type: TCP

Global Port: 100

Local IP Address:

Local Port: 100

Select	Enable	Interface	Traffic Type	Dynamic Global IP	Global IP Address	Global Port	Local IP Address	Local Port
0 entries.								

Create
Delete
Refresh

## Description

The page contains the following boxes:

- **Interface**  
Interface to which the settings relate. Can only be selected if the device has several interfaces.
- **Traffic Type**  
Specify the protocol for which the address assignment is valid. TCP and UDP frames must have parameters set separately.

- **Global Port**

Enter the global port. Incoming frames with this port as the destination port are forwarded. If the setting is intended to apply to a port range, enter the range with start port "-" end port, for example 30 - 40.

---

**Note**

If the port is already occupied by a local service, for example Telnet, a warning is displayed. In this case, avoid using TCP port 23 (Telnet), port 22 (SSH), ports 80/443 (http/https: reachability of the client with the WBM) and UDP port 161 (SNMP) as global port.

---

- **Local IP Address**

Enter the IP address of the node in the local network.

- **Local Port**

Enter the number of the port. This is the new destination port to which the incoming frame will be forwarded. If the setting is intended to apply to a port range, enter the range with start port "-" end port, for example 30 - 40.

If the local port and global port are the same, the frames will be forwarded without port translation.

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Activate**

Select the check box in the required row. The entry is used for the address assignment

- **Interface**

Shows the interface to which the settings relate.

- **Dynamic Global IP**

Shows whether or not dynamic address translation is used.

- **Traffic Type**

Shows whether UDP or TCP frames are assigned to the global port.

- **Global IP Address**

Shows the global IP address to which the local IP address will be translated.

- **Global Port**

Shows the global port.

- **Local IP Address**

Shows the IP address of the node in the local network.

- **Local Port**

Shows the number of the local port.

## **Procedure**

1. From the "Traffic Type" drop-down list, select the protocol for which the address assignment is valid.
2. Enter the number of the global port or a port range in "Global Port".
3. Enter the IP address of the node in the local network in ""Local IP Address".
4. Enter the number of the local port or a port range in "Local Port".
5. Click the "Create" button. A new entry is generated in the table.
6. Click the "Set Values" button. The device is restarted.

## 6.9 "Security" menu

### 6.9.1 Users

#### 6.9.1.1 Local Users

##### Local users

On this page, you create local users with the corresponding rights.

When you create or delete a local user this change is also made automatically in the table "External User Accounts". If you want to make change explicitly for the internal or external user table, use the CLI commands.

##### Note

The values displayed depend on the rights of the logged-in user.

Local Users

Local Users Roles Groups

User Account:

Password Policy: high

Password:

Password Confirmation:

Role: user

Select	User Account	Role	Description
<input type="checkbox"/>	admin	admin	System defined local user
<input type="checkbox"/>	User	user	User defined local user

2 entries.

Create Delete Set Values Refresh

##### Description

The page contains the following:

- **User Account**

Enter the name for the user. The name must meet the following conditions:

- It must be unique.
- It must be between 1 and 250 characters long.
- The following characters must not be included: | ? " ; :

The characters for Space and Delete must also not be included.

---

**Note**

**User name cannot be changed**

After creating a user, the user name can no longer be modified.

If a user name needs to be changed, the user must be deleted and a new user created.

---

**Note**

**Default user "user" set in the factory**

As of firmware version 6.0 the default user set in the factory "user" is no longer available when the product ships.

If you update a device to the firmware V6.0 the default user set in the factory "user" is initially still available. If you reset the device to the factory settings ("Restore Factory Defaults and Restart") the default user set in the factory "user" is deleted.

You can create new users with the role "user".

---

- **Password Policy**

Shows which password policy is being used.

- High

- Password length: at least 8 characters, maximum 128 characters

- At least 1 uppercase letter

- At least 1 special character

- At least 1 number

- Low

- Password length: at least 6 characters, maximum 128 characters

You configure the password policy on the page "Security > Passwords > Options".

- **Password**

Enter the password. The strength of the password depends on the set password policy.

- **Password Confirmation**

Enter the password again to confirm it.

- **Role**

Select a role.

You can choose between system-defined and self-defined roles, refer to the page "Security > Users > Roles".

The table contains the following columns:

- **Select**

Select the check box in the row to be deleted.

---

**Note**

The preset users as well as logged in users cannot be deleted or changed.

---

- **User Account**

Shows the user name.

- **Role**

Shows the role of the user.

- **Description**

Displays a description of the user account. The description text can be up to 100 characters long.

## Procedure

---

**Note**

**Changes in "Trial" mode**

Even if the device is in "Trial" mode, changes that you carry out on this page are saved immediately.

---

### Creating users

1. Enter the name for the user.
2. Enter the password for the user.
3. Enter the password again to confirm it.
4. Select the role of the user.
5. Click the "Create" button.
6. Enter a description of the user.
7. Click the "Set Values" button.

### Deleting users

1. Select the check box in the row to be deleted.
2. Click the "Delete" button. The entries are deleted and the page is updated.

### 6.9.1.2 Roles

#### Roles

On this page, you create roles that are valid locally on the device.

---

#### Note

The values displayed depend on the rights of the logged-in user.

---

User Roles

Local Users Roles Groups

Role Name:

Select	Role	Function Right	Description
<input type="checkbox"/>	user	1	System defined role, with readonly access to configuration data of this component.
<input type="checkbox"/>	admin	15	System defined role, with read/write access to configuration data of this component.
<input type="checkbox"/>	default	1	Internal role, for authenticated users without group/role mapping in this component.
<input type="checkbox"/>	everybody	0	Internal role, assigned to users when authentication fails. Access will be denied.
<input type="checkbox"/>	Maintenance	15	User defined role, with read/write access

5 entries.

Create Delete Set Values Refresh

#### Description

The page contains the following:

- **Role Name**

Enter the name for the role. The name must meet the following conditions:

- It must be unique.
- It must be between 1 and 64 characters long.

---

#### Note

##### Role name cannot be changed

After creating a role, the name of the role can no longer be changed.

If a name of a role needs to be changed, the role must be deleted and a new role created.

---

The table contains the following columns:

- **Select**

Select the check box in the row to be deleted.

---

**Note**

Predefined roles and assigned roles cannot be deleted or modified.

---

- **Role**

Shows the name of the role.

- **Function Right**

Select the function rights of the role.

- 1

Users with this role can read device parameters but cannot change them. Users with this role can change their own password.

- 15

Users with this role can both read and change device parameters.

---

**Note**

**Function right cannot be changed**

If you have assigned a role, you can no longer change the function right of the role.

If you want to change the function right of a role, follow the steps outlined below:

1. Delete all assigned users.
  2. Change the function right of the role:
  3. Assign the role again.
- 

- **Description**

Enter a description for the role. With predefined roles a description is displayed. The description text can be up to 100 characters long.

## Procedure

### Creating a role

1. Enter the name for the role.
2. Click the "Create" button.
3. Select the function rights of the role.
4. Enter a description of the role.
5. Click the "Set Values" button.

### Deleting a role

1. Select the check box in the row to be deleted.
2. Click the "Delete" button. The entries are deleted and the page is updated.

6.9.1.3 Groups

User Groups

On this page you link a group with a role.

In this example the group "Administrators" is linked to the "admin" role: The group is defined on a RADIUS server. The role is defined locally on the device. When a RADIUS server authenticates a user and assigns the user to the "Administrators" group, this user is given rights of the "admin" role.

Note

The values displayed depend on the rights of the logged-in user.

User Groups

Local UsersRolesGroups

Group Name:

Select	Group	Role	Description
<input type="checkbox"/>	Administrators	admin	Mapping group Administrators (RADIUS) to role admin (device)

1 entry.

CreateDeleteSet ValuesRefresh

Description

The page contains the following:

- Group Name**  
Enter the name of the group. The name must match the group on the RADIUS server.  
The name must meet the following conditions:
  - It must be unique.
  - It must be between 1 and 64 characters long.

The table contains the following columns:

- Select**  
Select the check box in the row to be deleted.
- Group**  
Shows the name of the group.

- **Role**

Select a role. Users who are authenticated with the linked group on the RADIUS server receive the rights of this role locally on the device.

You can choose between system-defined and self-defined roles, refer to the page "Security > Users > Roles."

- **Description**

Enter a description for the link of the group.to a role. The description text can be up to 100 characters long.

## Procedure

### Linking a group to a role.

1. Enter the name of a group.
2. Click the "Create" button.
3. Select a role.
4. Enter a description for the link of a group.to a role.
5. Click the "Set Values" button.

### Deleting the link between a group and a role

1. Select the check box in the row to be deleted.
2. Click the "Delete" button. The entries are deleted and the page is updated.

## 6.9.2 Passwords

### 6.9.2.1 Passwords

#### Configuration of the passwords of users


---

##### Note

If you are logged in via a RADIUS server, you cannot change any passwords.

---

On this page, you can change passwords of users. If you are logged in with the right to change device parameters, you can change the passwords for all user accounts. If you are logged on as user, you can only change your own password.



The screenshot shows a web interface titled "Account Passwords". It has two tabs: "Passwords" (selected) and "Options". Below the tabs, there are several input fields and a dropdown menu. The "Current User" field is set to "admin". The "Current User Password" field is empty. The "User Account" dropdown menu is set to "admin". The "Password Policy" field is set to "high". The "New Password" and "Password Confirmation" fields are empty. At the bottom, there are two buttons: "Set Values" and "Refresh".

#### Description

- **Current User**  
Shows the user that is currently logged in.
- **Current User Password**  
Enter the password for the currently logged in user.
- **User Account**  
Select the user whose password you want to change.

- **Password Policy**

Shows which password policy is being used when assigning new passwords.

---

**Note**

**Checking the password policy of existing users**

Up to now there was no special password policy. As of version V6.0 you can now assign passwords that correspond to the password policy "high".

The set password policy is used when assigning new passwords. Existing passwords are not checked. If you change the password policy from "Low" to "High", the previously used passwords remain valid. As an important measure for increasing security, change the passwords used up to now.

---

- High

    Password length: at least 8 characters, maximum 128 characters

    at least 1 uppercase letter

    at least 1 special character

    at least 1 number

- Low

    Password length: at least 6 characters, maximum 128 characters

- **New Password**

Enter the new password for the selected user.

- **Password Confirmation**

Enter the new password again to confirm it.

## Procedure

1. In the "Current User Password" enter the valid password of the currently logged in user.
2. From the "User Account" drop-down list, select the user whose password you want to change.
3. Enter the new password for the selected user in the "New Password" input box.

4. Repeat the new password in the "Password Confirmation" input box.
5. Click the "Set Values" button.

---

**Note**

The factory settings for the passwords when the devices ship are as follows:

- admin: admin

When you log in for the first time or following a "Restore Factory Defaults and Restart", with the preset user "admin" you will be prompted to change the password.

---

**Note**

**Changing the password in Trial mode**

Even if you change the password in Trial mode, this change is saved immediately.

---

### 6.9.2.2 Options

On this page, you specify which password policy will be used when assigning new passwords.

#### Description

- **Password Policy**  
Shows which password policy is currently being used.
- **New Password Policy**  
Select the required setting from the drop-down list.
  - High  
Password length: at least 8 characters, maximum 128 characters  
At least 1 uppercase letter  
At least 1 special character  
At least 1 number
  - Low  
Password length: at least 6 characters, maximum 128 characters


## 6.9.3 AAA

### 6.9.3.1 General

#### Login of network nodes

The designation "AAA" stands for "Authentication, Authorization, Accounting". This feature is used to identify and allow network nodes, to make the corresponding services available to them and to specify the range of use.

On this page, you configure the login.



General

General RADIUS Client

Login Authentication: Local

Set Values Refresh

#### Description

The page contains the following boxes:

---

##### Note

To be able to use the login authentication "RADIUS", "Local and RADIUS" or "RADIUS and fallback Local" a RADIUS server must be stored and configured for user authentication.

---

- **Login Authentication**

Specify how the login is made:

- Local

The authentication must be made locally on the device.

- RADIUS

The authentication must be handled via a RADIUS server.

- Local and RADIUS

The authentication is possible both with the users that exist on the device (user name and password) and via a RADIUS server.

The user is first searched for in the local database. If the user does not exist there, a RADIUS request is sent.

- RADIUS and fallback Local

The authentication must be handled via a RADIUS server.

A local authentication is performed only when the RADIUS server cannot be reached in the network.

### 6.9.3.2 RADIUS client

#### Authentication over an external server

The concept of RADIUS is based on an external authentication server.

Each row of the table contains access data for one server. In the search order, the primary server is queried first. If the primary server cannot be reached, secondary servers are queried in the order in which they are entered.

If no server responds, there is no authentication.

Remote Authentication Dial In User Service (RADIUS) Client

General | RADIUS Client

RADIUS Authorization Mode: Vendor Specific

Select	Auth. Server Type	RADIUS Server Address	Server Port	Shared Secret	Shared Secret Conf.	Max. Retrans.	Primary Server	Test	Test Result
<input type="checkbox"/>	Login	192.168.16.2	1812	*****	*****	3	no	<input type="button" value="Test"/>	Not reachable

1 entry.

## Description of the displayed boxes

The page contains the following boxes:

- **RADIUS Authorization Mode**

For the login authentication, the RADIUS authorization mode specifies how the rights are assigned to the user with a successful authentication.

- Conventional

In this mode the user is logged in with administrator rights if the server returns the value "Administrative User" to the device for the attribute "Service Type". In all other cases the user is logged in with read rights.

- SiemensVSA

In this mode the assignment of rights depends on whether and which group the server returns for the user and whether or not there is an entry for the user in the table "External User Accounts".

The table has the following columns:

- **Select**

Select the row you want to delete.

- **RADIUS Server Address**

Enter the IPv4 address or the FQDN (Fully Qualified Domain Name) of the RADIUS server.

- **Server Port**

Here, enter the input port on the RADIUS server. As default, input port 1812 is set. The range of values is 1 to 65535.

- **Shared Secret**

Enter your access ID here. The range of values is 1...128 characters

- **Shared Secret Conf.**

Enter your access ID again as confirmation.

- **Max. Retrans.**

Here, enter the maximum number of retries for an attempted request.

The initial connection attempt is repeated the number of times specified here before another configured RADIUS server is queried or the login counts as having failed. As default 3 retries are set, this means 4 connection attempts. The range of values is 1 to 5.

- **Primary Server**

Using the options in the drop-down list, specify whether or not this server is the primary server. You can select one of the options "yes" or "no".

- **Test**

With this button, you can test whether or not the specified RADIUS server is available. The test is performed once and not repeated cyclically.

- **Test Result**

Shows whether or not the RADIUS server is available:

- Not reachable

The IP address is not reachable.

The IP address is reachable, the RADIUS server is, however, not running.

- Reachable, key not accepted

The IP address is reachable, the RADIUS server does not, however accept the shared secret.

- Reachable, key accepted

The IP address is reachable, the RADIUS server accepts the specified shared secret.

## Steps in configuration

### Entering a new server

1. Click the "Create" button. A new entry is generated in the table.

The following default values are entered in the table:

- RADIUS Server Address: 0.0.0.0
- Server Port: 1812
- Max. Retrans.: 3
- Primary server: No

2. In the relevant row, enter the following data in the input boxes:

- RADIUS Server Address
- Server Port
- Shared Secret
- Shared Secret Conf
- Max. Retrans.: 3
- Primary server: No

3. If necessary check the reachability of the RADIUS server.

4. Click the "Set Values" button.

Repeat this procedure for every server you want to enter.

**Modifying servers**

1. In the relevant row, enter the following data in the input boxes:

- RADIUS Server Address
- Server Port
- Shared Secret
- Shared Secret Conf
- Max. Retrans.
- Primary Server

2. If necessary check the reachability of the RADIUS server.

3. Click the "Set Values" button.

Repeat this procedure for every server whose entry you want to modify

**Deleting servers**

1. Click the check box in the first column before the row you want to delete to select the entry for deletion.

Repeat this for all entries you want to delete.

2. Click the "Delete" button. The data is deleted from the memory of the device and the page is updated.

## 6.9.4 WLAN

### 6.9.4.1 Basic (Access Point)

#### Security levels

To make the network secure, authentication and encryption are used. On this page, you specify the security settings.

#### Note

##### WLAN mode IEEE 802.11 n

With devices operated in WLAN mode IEEE802.11n, only WPA2 (WPA2-PSK and WPA2 Radius) encryption is possible.

##### iPCF, iPCF-HT or iPCF-MC mode activated

If iPCF, iPCF-HT or iPCF-MC mode is enabled, only "iPCF authentication" with or without the AES encryption is supported with security context 1.

WLAN Security Settings						
Basic	AP Communication	AP RADIUS Authenticator	Keys			
Port	Authentication Type	Encryption	Cipher	WPA(2) Pass Phrase	WPA(2) Pass Phrase Confirmation	Default Key
VAP 1.1	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.2	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.3	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.4	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.5	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.6	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.7	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼
VAP 1.8	iPCF Authentication ▼	<input type="checkbox"/>	AES ▼			Key 1 ▼

#### Description

The table has the following columns:

- **Interface**

Shows the available interfaces.

- **Authentication Type**

Select the type of authentication. The selection depends on the operating mode and the transmission standard.

- Open System

There is no authentication. Encryption with a fixed (unchanging) WEP key can be selected as an option. To use the key, enable "Encryption". You define the WEP key on the "Keys" page.

If iPCF or iPCF-MC mode is enabled, only the encryption method AES with 128 bit key length is supported.

- **Shared Key**

In Shared Key authentication, a fixed key is stored on the client and access point. This WEP key is then used for authentication and encryption. You define the WEP key on the "Keys" page.

---

**Note**

If you use "Open System" with "Encryption" or "Shared Key", Key 1 must always be set on the "Keys" page.

---

- **WPA (RADIUS)**

Wi-Fi Protected Access (WPA) is a method specified by the Wi-Fi Alliance to close security gaps in WEP. Authentication using a server is stipulated (802.1x). The dynamic exchange of keys at each data frame introduces further security.

- **WPA-PSK**

WPA Pre Shared Key (WPA-PSK) is a weakened form of WPA. In this method, authentication is not established by a server but is based on a password. This password is configured manually on the client and server.

- **WPA2 (RADIUS)**

WPA2 (Wi-Fi Protected Access 2) is a further development of WPA and implements the functions of the IEEE 802.11i security standard. WPA authentication works, however, without the RADIUS server.

- **WPA2-PSK**

WPA2-PSK is based on the 802.11i standard. WPA authentication works, however, without a RADIUS server. Instead of this, a WPA(2) key (WPA(2) pass phrase) is stored on each client and access point. The WPA(2) pass phrase is used for authentication and further encryption.

- **WPA/WPA2-Auto-PSK**

Setting with which an access point can process both the "WPA-PSK" as well as the "WPA2-PSK" type of authentication. This is necessary when the access point communicates with different clients, some using "WPA-PSK" and others "WPA2-PSK". The same encryption method is set on the clients.

- **WPA/WPA2-Auto**

Setting with which an access point can process both the "WPA" as well as the "WPA2" type of authentication. This is necessary when the access point communicates with different clients, some using "WPA" and others "WPA2". The same encryption method is set on the clients

- **iPCF authentication**

Authentication with optional AES encryption. Authentication is set automatically if iPCF, iPCF-HT or iPCF-MC mode is enabled on the WLAN interface. If you want encryption with AES, only keys with a 128 bit key length are supported.

- **Encryption**

Encryption protects the transferred data from eavesdropping and corruption. You can only disable encryption if you have selected "Open System" for authentication. All other security methods include both authentication and encryption.

- **Cipher**

Select the encryption method. The selection depends on the transmission standard.

- **AUTO**  
AES or TKIP is selected automatically depending on the capability of the other station.
- **WEP**  
WEP (Wired Equivalent Privacy)  
A symmetrical stream encryption method with only 40- or 104-bit long keys based on the RC4 algorithm (Ron's Code 4).
- **TKIP (Temporal Key Integrity Protocol)**  
A symmetrical encryption method with the RC4 algorithm (Ron's Code 4). In contrast to the weak WEP encryption, TKIP uses changing keys derived from a main key. TKIP can also recognize corrupted data frames.
- **AES (Advanced Encryption Standard)**  
Strong symmetrical block encryption method based on the Rijndael algorithm that further improves the functions of TKIP.

---

**Note**

To provide better protection of your data against attacks, use WPA2/ WPA2-PSK with AES.

---

- **WPA(2) Pass Phrase**

Enter a WPA(2) pass phrase here. This WPA(2) key must be known on both the client and the access point and is entered by the user at both ends.

For a key with 8 to 63 characters, you can only use the following readable ASCII characters: 0x20 - 0x7e.

For a key with precisely 64 characters, you can use the following ASCII characters: 0 - 9, a - f and A - F.

- **WPA(2) Pass Phrase Confirmation**

Confirm the entered WPA(2) pass phrase.

- **Default Key**

Specify the WEP key used to encrypt the data. You define the WEP key on the "Keys" page.

## Procedure

1. Select the required security settings. The settings that are possible depend on the "Authentication Type" you have selected.

Authentication Type	Encryption	Cipher	Encryption key source
Open System	disabled	--	--
Open System	enabled	WEP	Default Key
Shared Key	enabled	WEP	Default Key
WPA (RADIUS)	enabled	Auto/TKIP/AES	RADIUS Server
WPA-PSK	enabled	Auto/TKIP/AES	WPA(2) Pass Phrase
WPA2 (RADIUS)	enabled	Auto/TKIP/AES	RADIUS Server
WPA2-PSK	enabled	Auto/TKIP/AES	WPA(2) Pass Phrase
WPA/WPA2-AutoPSK	enabled	Auto/TKIP/AES	WPA(2) Pass Phrase
WPA/WPA2-Auto (RADIUS)	enabled	Auto/TKIP/AES	RADIUS Server
iPCF authentication <sup>1)</sup>	enabled	AES	Default Key (128-bit)

<sup>1)</sup> only when iPCF with iPCF-HT or with iPCF-MC is selected: Preset authentication with optional encryption

2. Click the "Set Values" button.

### 6.9.4.2 Basic (Client)

#### Safety levels

To make the network secure, authentication and encryption are used. On this page, you specify the security settings.

#### Note

##### WLAN mode IEEE 802.11 n

With devices operated in WLAN mode IEEE802.11n only WPA2 (WPA2-PSK and WPA2 Radius) encryption is possible.

##### iPCF, iPCF-HT or iPCF-MC mode activated

If iPCF, iPCF-HT or iPCF-MC mode is enabled, only "iPCF authentication" with or without the AES encryption is supported with security context 1.

**WLAN Security Settings**

Basic Client RADIUS Supplicant Keys

Security Context	Authentication Type	Encryption	Cipher	WPA(2) Pass Phrase	WPA(2) Pass Phrase Confirmation	Default Key
1	Open System	<input type="checkbox"/>	WEP			Key 1

1 entry.

Create Delete Set Values Refresh

#### Description

The table has the following columns:

- Select**  
 Select the row you want to delete. Select a check box in this column and click the "Delete" button to delete an entry in the list.
- Security Context**  
 Shows the number of the entry. If you create a new entry, a new row with a unique number is created.  
  
 You can create up to 8 security contexts. The security context 1 cannot be deleted.

- **Authentication Type**

Select the type of authentication. The selection depends on the operating mode and the transmission standard.

- **Open System**

There is no authentication. Encryption with a fixed (unchanging) WEP key can be selected as an option. To use the key, enable "Encryption". You define the WEP key on the "Keys" page.

- **Shared Key**

In Shared Key authentication, a fixed key is stored on the client and access point. This WEP key is then used for authentication and encryption. You define the WEP key on the "Keys" page.

- **WPA (RADIUS)**

Wi-Fi Protected Access is a method specified by the Wi-Fi Alliance to close security gaps in WEP. Authentication using a server is stipulated (802.1x). The dynamic exchange of keys at each data frame introduces further security.

---

**Note**

Make the relevant RADIUS settings initially on the page "Security > WLAN > Client Radius Supplicant".

---

- **WPA-PSK**

WPA Pre Shared Key (WPA-PSK) is a weakened form of WPA. In this method, authentication is not established by a server but is based on a password. This password is configured manually on the client and server.

- **WPA2 (RADIUS)**

WPA2 (Wi-Fi Protected Access 2) is a further development of WPA and implements the functions of the IEEE 802.11i security standard. WPA authentication works, however, without the RADIUS server.

---

**Note**

Make the relevant RADIUS settings initially on the page "Security > WLAN > Client Radius Supplicant".

---

- **WPA2-PSK**

WPA2-PSK is based on the 802.11i standard. WPA authentication works, however, without a RADIUS server. Instead of this, a WPA(2) key (WPA(2) pass phrase) is stored on each client and access point. The WPA(2) pass phrase is used for authentication and further encryption.

- **WPA/WPA2-Auto-PSK**

Setting with which an access point can process both the "WPA-PSK" as well as the "WPA2-PSK" type of authentication. This is necessary when the access point communicates with different clients, some using "WPA-PSK" and others "WPA2-PSK". The same encryption method is set on the clients.

- **WPA/WPA2-Auto**

Setting with which an access point can process both the "WPA" as well as the "WPA2" type of authentication. This is necessary when the access point communicates with

different clients, some using "WPA" and others "WPA2". The same encryption method is set on the clients.

- **iPCF authentication**

Authentication with optional AES encryption. Authentication is set automatically if iPCF, iPCF-HT or iPCF-MC mode is enabled on the WLAN interface. If you want encryption with AES, only keys with a 128 bit key length are supported.

- **Encryption**

Encryption protects the transferred data from eavesdropping and corruption. You can only disable encryption if you have selected "Open System" for authentication. All other security methods include both authentication and encryption.

- **Cipher**

Select the encryption method. The selection depends on the transmission standard.

- **AUTO**

AES or TKIP is used depending on the capability of the other station.

- **WEP**

WEP (Wired Equivalent Privacy)

A symmetrical stream encryption method with only 40- or 104-bit long keys based on the RC4 algorithm (Ron's Code 4).

- **TKIP (Temporal Key Integrity Protocol)**

A symmetrical encryption method with the RC4 algorithm (Ron's Code 4). In contrast to the weak WEP encryption, TKIP uses changing keys derived from a main key. TKIP can also recognize corrupted data frames.

- **AES (Advanced Encryption Standard)**

Strong symmetrical block encryption method based on the Rijndael algorithm that further improves the functions of TKIP.

---

**Note**

To provide better protection of your data against attacks, use WPA2/ WPA2-PSK with AES.

---

- **WPA(2) Pass Phrase**

Enter a WPA(2) key here. This WPA(2) key must be known on both the client and the access point and is entered by the user at both ends.

For a key with 8 to 63 characters, you can only use the following readable ASCII characters: 0x20 - 0x7e.

For a key with precisely 64 characters, you can use the following ASCII characters: 0 - 9, a - f and A - F.

- **WPA(2) Pass Phrase Confirmation**

Confirm the entered WPA(2) pass phrase.

- **Default Key**

Specify the WEP key used to encrypt the data. You define the WEP key on the "Keys" page.

## Procedure

1. To create a new security context, click the "Create" button.
2. Select the required security settings. The settings that are possible depend on the "Authentication Type" you have selected.  
When iPCF, iPCF-HT or iPCF-MC mode is enabled, it is not possible to select the "Authentication Type".
3. Click the "Set Values" button.

### 6.9.4.3 AP Communication

#### Communications options

On this page, you specify the type of communication allowed by the access point.

#### Note

This tab is available only in access point mode.

**Access Point Communication Filters**

**Basic** | **AP Communication** | **AP RADIUS Authenticator** | **Keys**

	within own VAP	with other VAPs	with Ethernet	Client Limiter	Copy to Table
All ports	No Change ▾	No Change ▾	No Change ▾	No Change ▾	Copy to Table

Radio	Port	within own VAP	with other VAPs	with Ethernet	Client Limiter	max. Clients
WLAN 1	VAP 1.1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	64
WLAN 1	VAP 1.2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	64
WLAN 1	VAP 1.3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	64
WLAN 1	VAP 1.4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	64

**Description**

Table 1 has the following columns:

- **Column 1**

Shows that the settings are valid for all ports of table 2.

- **within own VAP / with other VAPs / with Ethernet / Client Limiter**

In the drop-down list, select the setting for all ports. If "No Change" is selected, the entry in table 2 remains unchanged.

- **Copy to Table**

If you click the button, the setting is adopted for all ports of table 2.

Table 2 has the following columns:

- **Radio**

Shows the available WLAN interfaces.

- **Port**

Shows the VAP interface.

- **within own VAP**

- Enabled

Clients logged on to the same VAP interface of an access point can communicate with each other.

- Disabled

Option is disabled.

- **with other VAPs**

- Enabled

Clients logged on to different VAP interfaces of an access point can communicate with each other.

---

**Note**

For an access point, "with other VAPs" needs to be enabled on all WLAN interfaces or on all VAP interfaces to allow communication between clients logged on at different VAP interfaces of the access point.

---

- Disabled

Option is disabled.

---

**Note**

**"within own VAP" or "with other VAPs" function disabled**

If the "within own VAP" or "with other VAPs" function is disabled the various WLAN clients can no longer see each other. This means that Address Collision Detection (ACD) also no longer works reliably.

---

- **with Ethernet**
  - Enabled  
Clients can communicate via the Ethernet interface of the access point.
  - Disabled  
Option is disabled.
- **Client limiter**
  - Enabled  
The number of WLAN clients that can be logged on simultaneously is limited.
  - Disabled  
Option is disabled.
- **Max. clients**  
Set the maximum number of clients that can connect to this interface at the same time. If the number is exceeded, additional clients are rejected.

#### 6.9.4.4 AP RADIUS Authenticator

##### Configuration of the RADIUS server

On this WBM page, you define the RADIUS servers and the RADIUS authentication of the access point. You can enter data for two RADIUS servers.

##### Note

This WBM page is only available in access point mode.

**AP 802.1x Authenticator**

**Basic** | **AP Communication** | **AP RADIUS Authenticator** | **Keys**

Reauthentication Mode: - v  
 Reauthentication Interval [s]: 3600

Server IP Address	Server Port	Shared Secret	Shared Secret Confirmation	Max. Retransmissions	Primary Server	Status
	1812			2	no	v <input type="checkbox"/>
	1812			2	no	v <input type="checkbox"/>

Set Values
Refresh

## Description

The page contains the following boxes:

- **Reauthentication Mode**

Specify who sets the time after which the clients are forced to reauthenticate.

- - (disabled)  
Reauthentication mode is disabled.
- Server  
Enables time management on the server.
- Local  
Enables local time management. In "Reauthentication Interval", specify the time of validity.

- **Reauthentication Interval [s]**

If time management is local, enter the period of validity of the authentication in seconds. The minimum time is 1 minute (enter 60), the maximum time is 12 hours (enter 43200). The default is one hour (3,600 seconds).

The table has the following columns:

- **Server IP Address**

Here, enter the IP address or the FQDN name of the RADIUS server.

- **Server Port**

Here, enter the input port on the RADIUS server.

- **Shared Secret**

Enter the password of the RADIUS server.  
For the password, ASCII code 0x20 to 0x7e is used.

- **Shared Secret Conf**

Confirm the password.

- **Max. Retransmissions**

Enter the maximum number of connection attempts.

- **Primary Server**

Specify whether or not this server is the primary server.

- Yes: Primary server
- No: Backup server.

- **State**

With this check box, you can enable or disable the RADIUS server

## Procedure

### Entering a new server

To display a new server, follow the steps below:

1. In the relevant row, enter the following data in the input boxes:
  - IP address or FQDN name of the RADIUS server.
  - Port number of the input port
  - Password
  - Confirmation of the password
  - Maximum number of transmission retries
  - Primary server
2. Click the "Set Values" button.

#### **Modifying servers**

1. In the relevant row, enter the following data in the input boxes:
  - Server IP address
  - Port number of the input port
  - Password
  - Confirmation of the password
  - Maximum number of transmission retries
  - Primary server
2. Click the "Set Values" button.

Repeat this procedure for every server whose entry you want to modify.

### **6.9.4.5 Client Radius Supplicant**

#### **Client Supplicant**

On this WBM page, you configure the settings for the RADIUS authorization of the client.

---

#### **Note**

This WBM page is only available in client mode.

---

---

#### **Note**

##### **Dot1X user name and Dot1X user password**

With WPA (RADIUS), WPA2 (RADIUS), EAP-TLS, EAP-TTLS and PEAP the Dot1X user name and the Dot1X user password must be configured.

With the setting "Auto" either the certificate must be loaded or the Dot1X user name and the Dot1X user passport must be configured.

---

Client 802.1x Supplicant					
Basic Client RADIUS Supplicant Keys					
Security Context	Dot1x User Name	Dot1x User Password	Dot1x User Password Confirmation	Dot1x Check Server Certificate	Dot1x EAP Types
1				<input type="checkbox"/>	AUTO
<input type="button" value="Set Values"/> <input type="button" value="Refresh"/>					

## Description

The table has the following columns:

- **Security context**  
Shows the security context.
- **Dot1x User Name**  
Enter the user name with which you want to log on to the RADIUS server.
- **Dot1x User Password**  
Enter the password for the user name selected above. The client logs on with the RADIUS server using this combination.  
For password assignment, ASCII code 0x20 to 0x7e is used.
- **Dot1x User Password Confirmation**  
Confirm the password.
- **Dot1X Server Certificate**  
Specify whether or not the RADIUS server identifies itself to the client using a certificate.
- **Dot1x EAP Types**  
Specify the authentication methods. The following methods exist:
  - Auto  
Client offers RADIUS server all methods.
  - EAP-TLS  
Extensible Authentication Protocol - Transport Layer Security  
Uses certificates for authentication.
  - EAP-TTLS  
Extensible Authentication Protocol - Tunnel Transport Layer Security  
After setting up the TLS tunnel, MS-CHAPv2 is used for internal authentication.
  - PEAP  
Protected Extensible Authentication Protocol  
Alternative draft protocol of IETF for EAP-TTLS

## Procedure

1. Enter the necessary values in the input boxes.
2. Select the required entry in the "Dot1x EAP Types" drop-down list.
3. Click the "Set Values" button.

### 6.9.4.6 Keys

#### Specifying the WEP key

To allow you to enable the encryption for the "Open System" and "Shared Key" authentication methods, you must first enter at least one key in the key table.

Key Table							
Basic		Client RADIUS Supplicant		Keys			
Key 1	Key 1 Confirmation	Key 2	Key 2 Confirmation	Key 3	Key 3 Confirmation	Key 4	Key 4 Confirmation
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

## Description

The table has the following columns:

- **Key 1 - 4**

Enter the WEP key or the AES key.

For the WEP key, characters of the ASCII code from 0x20 to 0x7E or hexadecimal characters from 0x00 to 0xFF are permitted.

If iPCF or iPCF-MC mode is enabled, only the encryption method AES with 128-bit key length is supported.

You can choose between the following key lengths:

- 5 or 13 ASCII or 10 or 26 hexadecimal characters (40/104 bits)
- 16 ASCII or 32 hexadecimal characters (128 bits)

#### Note

The hexadecimal characters are entered without being preceded by "0x". One hexadecimal character codes four bits. The entries "ABCDE" (ASCII characters) and "4142434445" (hexadecimal characters) are therefore the same because the ASCII character "A" has hexadecimal code "0x41".

- **Key 1 - 4 Confirmation**

Confirm the WEP key.

**Procedure**

1. Enter at least one WEP key.
2. Click the "Set Values" button.

**6.9.5 MAC ACL****6.9.5.1 Rules Configuration**

On this page, you specify the access rules for the MAC-based Access Control List. Using the MAC-based ACL, you can specify whether frames of certain MAC addresses are forwarded or discarded.

**MAC Access Control List Configuration**

Rules Configuration | Ingress Rules | Egress Rules

Select	Rule Number	Source MAC	Dest. MAC	Action	Ingress Interfaces	Egress Interfaces
<input type="checkbox"/>	1	00-00-00-00-00-00	00-00-00-00-00-00	Forward		

1 entry.

Create Delete Set Values Refresh

**Description**

The table has the following columns:

- **Select**  
Select the row you want to delete. If this entry is used, this is grayed out and you cannot delete it.
- **Rule Number**  
Shows the number of the ACL rule. If you create a new entry, a new line with a unique number is created.
- **Source MAC Address**  
Enter the MAC address of the source.
- **Dest. MAC Address**  
Enter the MAC address of the destination.
- **Action**  
Select whether the frame is forwarded or rejected when it corresponds to the ACL rule.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.

- **Ingress Interfaces**

Shows a list of all ingress interfaces to which this rule applies.

- **Egress Interfaces**

Shows a list of all egress interfaces to which this rule applies.

---

**Note****Entering the MAC addresses**

You can configure access rules for MAC addresses.

Only if you enter the address "00-00-00-00-00-00" for the source and/or destination MAC address, the rule created in this way applies to all source or destination MAC addresses.

---

**Note****Loop detection**

Activating loop detection can prevent rules for Multicast MAC addresses from being applied.

---

**Note****No ACL rules for locally supported protocols**

ACL rules are not applied to packets from locally supported protocols. This restriction applies to the following protocols:

- DCP
- LLDP
- RSTP
- MRP

Make the specifications for receiving and sending packets for these protocols directly on the configuration page of the respective protocol.

---

## Configuration procedure

1. Click the "Create" button. A new row with a unique number (rule number) is created in the table.
2. Enter the MAC address of the source in "Source MAC Address".
3. Enter the MAC address of the destination in "Dest. MAC Address".
4. In the "Action" drop-down list select whether the frame is forwarded or rejected when it corresponds to the ACL rule.
5. Click the "Set Values" button.

## Deleting an entry

You cannot delete active entries.

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

### 6.9.5.2 Ingress Rules

#### Introduction

On this page, you specify the ACL rule according to which incoming frames are filtered at interfaces. You specify the ACL rules in the "Rules Configuration" tab.

### MAC ACL Ingress Rules

Rules Configuration
Ingress Rules
Egress Rules

Interface: P1.1
Add Rule: -
Add
Remove Rule: Rule 1
Remove

Rule Order	Rule Number	Source MAC	Dest. MAC	Action
1	1	00-00-00-00-00-00	00-00-00-00-00-00	Forward

1 entry.

Refresh

#### Description of the displayed boxes

The page contains the following boxes:

- **Interface**  
Select the required interface from the drop-down list. The available interfaces (Page 43) depend on your device.
- **Add Rule**  
In the drop-down list select the ACL rule to be assigned to the interface.
- **Add**  
To assign the ACL rule to the interface, click the "Add" button. The configuration is shown in the table.
- **Remove Rule**  
From the "Remove rule" drop-down list, select the ACL rule to be deleted.
- **Remove**  
To remove the ACL rule from the interface, click the "Remove" button.

The table has the following columns:

- **Rule Order**  
Shows the order of the ACL rules.
- **Rule Number**  
Shows the number of the ACL rule.
- **Source MAC address**  
Shows the MAC address of the source.
- **Dest. MAC Address**  
Shows the MAC address of the destination.
- **Action**  
Shows the action.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.

### Configuration procedure

Follow the steps below to assign an ACL rule to an interface:

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Add Rule" drop-down list.
3. Click the "Add" button. A new entry is generated in the table.

Follow the steps below to remove an ACL rule from an interface:

---

#### **Note**

##### **active rules**

You cannot delete active rules.

---

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Remove Rule" drop-down list.
3. Click the "Remove" button. The corresponding entry is removed in the table.

### 6.9.5.3 Egress Rules

#### Introduction

On this page, you specify the ACL rule according to which outgoing frames are filtered at interfaces. You specify the ACL rule in the "Rules Configuration" tab.

### MAC ACL Egress Rules

Rules Configuration
Ingress Rules
Egress Rules

Interface: P1.1
Add Rule: -
Add
Remove Rule: Rule 1
Remove

Rule Order	Rule Number	Source MAC	Dest. MAC	Action
1	1	00-00-00-00-00-00	00-00-00-00-00-00	Forward

1 entry.

Refresh

#### Description of the displayed boxes

The page contains the following boxes:

- **Interface**  
Select the required interface from the drop-down list. The available interfaces (Page 43) depend on your device.
- **Add Rule**  
In the drop-down list select the ACL rule to be assigned to the interface.
- **Add**  
To assign the ACL rule to the interface, click the "Add" button. The configuration is shown in the table.
- **Remove Rule**  
From the "Remove rule" drop-down list, select the ACL rule to be deleted.
- **Remove**  
To remove the ACL rule from the interface, click the "Remove" button.

The table has the following columns:

- **Rule Order**  
Shows the order of the ACL rules.
- **Rule Number**  
Shows the number of the ACL rule.

- **Source MAC address**  
Shows the MAC address of the source.
- **Dest. MAC Address**  
Shows the MAC address of the destination.
- **Action**  
Shows the action.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.

### Configuration procedure

Follow the steps below to assign an ACL rule to an interface:

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Add Rule" drop-down list.
3. Click the "Add" button. A new entry is generated in the table.

Follow the steps below to remove an ACL rule from an interface:

---

#### **Note**

##### **active rules**

You cannot delete active rules.

---

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Remove Rule" drop-down list.
3. Click the "Remove" button. The corresponding entry is removed in the table.

## 6.9.6 IP ACL

### 6.9.6.1 Rules Configuration

#### Introduction

On this page, you specify the rules for the IP-based Access Control List. Using the IP-based ACL, you can specify whether frames of certain IPv4 addresses are forwarded or discarded.

**IP Access Control List Configuration**

Rules Configuration | Protocol Configuration | Ingress Rules | Egress Rules

Select	Rule Number	Source IP	Source Subnet Mask	Dest. IP	Dest. Subnet Mask	Action	Ingress Interfaces	Egress Interfaces
<input type="checkbox"/>	1	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	Forward	P1	VAP 1.1

1 entry.

Create Delete Refresh

#### Description of the displayed boxes

The table has the following columns:

- **Select**  
Select the row you want to delete. If this entry is used, this is grayed out and you cannot delete it.
- **Rule Number**  
Shows the number of the ACL rule. If you create a new entry, a new line with a unique number is created.
- **Source IP**  
Enter the IPv4 address of the source.
- **Source Subnet Mask**  
Enter the subnet mask of the source.
- **Dest. IP**  
Enter the IPv4 address of the destination.
- **Dest. Subnet Mask**  
Enter the subnet mask of the destination.
- **Action**  
Select whether the frame is forwarded or rejected when it corresponds to the ACL rule.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.

- **Ingress Interfaces**

Shows a list of all ingress interfaces to which this rule applies.

- **Egress Interfaces**

Shows a list of all egress interfaces to which this rule applies.

---

**Note**
**Subnet mask for individual hosts**

If you create the rule for a single system (one IPv4 address), specify the subnet mask "255.255.255.255".

---

### Steps in configuration

1. Click the "Create" button. A new row with a unique number (rule number) is created in the table.
2. Enter the data of the source in "Source IP" and in "Source Subnet Mask".
3. Enter the data of the destination in "Dest. IP" and in "Dest. Subnet Mask".
4. In the "Action" drop-down list select whether the frame is forwarded or rejected when the frame corresponds to the ACL rule.
5. Click the "Set Values" button.

### Deleting an entry

You cannot delete active entries.

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

## 6.9.6.2 Protocol Configuration

On this page, you specify the rules for protocols.

IP ACL Protocol Configuration

Rules Configuration
Protocol Configuration
Ingress Rules
Egress Rules

Rule Number	Protocol	Protocol Number	Source Port Min.	Source Port Max.	Dest. Port Min.	Dest. Port Max.	Message Type	Message Code	DSCP
1	Any	255	0	65535	0	65535	255	255	

1 entry.

Refresh

## Description

The table has the following columns:

- **Rule Number**

Shows the number of the protocol rule. When you create a rule, a new row with a unique number is created.

- **Protocol**

Select the protocol for which this rule is valid.

- **Protocol Number**

Enter a protocol number to define further protocols.

This box can only be edited if you have set "Other Protocol" for the protocol .

- **Source Port Min.**

Enter the lowest possible port number of the source port.

This box can only be edited if you have set "TCP" or "UDP" for the protocol.

- **Source Port Max.**

Enter the highest possible port number of the source port.

This box can only be edited if you have set "TCP" or "UDP" for the protocol.

- **Dest. Port Min.**

Enter the lowest possible port number of the destination port.

This box can only be edited if you have set "TCP" or "UDP" for the protocol.

- **Dest. Port Max.**

Enter the highest possible port number of the destination port.

This box can only be edited if you have set "TCP" or "UDP" for the protocol.

- **Message Type**

Enter a message type to decide the format of the message.

This box can only be edited if you have set "ICMP" for the protocol.

- **Message Code**

Enter a message code to specify the function of the message.

This box can only be edited if you have set "ICMP" for the protocol.

- **DSCP**

Enter a value for classifying the priority.

This box cannot be edited if you have set "ICMP" for the protocol.

### 6.9.6.3 Ingress Rules

#### Introduction

On this page, you specify the ACL rules according to which incoming frames are handled by interfaces. You specify the ACL rules in the "Rules Configuration" tab.

IP ACL ingress rules - first part of the table:

The screenshot shows the "IP ACL Ingress Rules" configuration page. The "Rules Configuration" tab is selected. The interface is set to "P1.1". The "Add Rule" dropdown is set to "-". The "Remove Rule" dropdown is set to "Rule 1". The table below shows the first part of the rule configuration:

Rule Order	Rule Number	Protocol	Protocol Number	Source IP	Source Subnet Mask	Dest. IP	Dest. Subnet Mask
1	1	Any	255	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0

1 entry.

Refresh

IP ACL ingress rules - second part of the table:

The screenshot shows the "IP ACL Ingress Rules" configuration page. The "Rules Configuration" tab is selected. The interface is set to "P1.1". The "Add Rule" dropdown is set to "-". The "Remove Rule" dropdown is set to "Rule 1". The table below shows the second part of the rule configuration:

Action	Source Port Min.	Source Port Max.	Dest. Port Min.	Dest. Port Max.	Message Type	Message Code	DSCP
Forward	0	65535	0	65535	255	255	

1 entry.

Refresh

#### Description of the displayed boxes

The page contains the following boxes:

- **Interface**  
Select the required interface from the drop-down list. The available interfaces (Page 43) depend on your device.  
To select a VLAN interface, an IP interface must be configured.

#### Note

If you use a VLAN interface, the ACL rule applies to all ports that belong to the VLAN.

- **Add Rule**  
In the drop-down list select the ACL rule to be assigned to the interface.

- **Add**  
To permanently assign the ACL rule to the interface, click the "Add" button. The configuration is shown in the table.
- **Remove Rule**  
From the "Remove rule" drop-down list, select the ACL rule to be deleted.
- **Remove**  
To remove the ACL rule from the interface, click the "Remove" button.

The table has the following columns:

- **Rule Order**  
Shows the order of the ACL rules.
- **Rule Number**  
Shows the number of the ACL rule.
- **Protocol**  
Shows the protocol for which this rule is valid.
- **Protocol Number**  
Shows the protocol number.
- **Source IP**  
Shows the IPv4 address of the source.
- **Source Subnet Mask**  
Shows the subnet mask of the source.
- **Dest IP**  
Shows the IP address of the destination.
- **Dest. Subnet Mask**  
Shows the subnet mask of the destination.
- **Action**  
Select whether the frame is forwarded or rejected when it corresponds to the ACL rule.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.
- **Source Port Min.**  
Shows the lowest possible port number of the source port.
- **Source Port Max.**  
Shows the highest possible port number of the source port.
- **Dest. Port Min.**  
Shows the lowest possible port number of the destination port.
- **Dest. Port Max.**  
Shows the highest possible port number of the destination port.

- **Message Type**  
Shows a message type to decide the format of the message.
- **Message Code**  
Shows a message code to specify the function of the message.
- **DSCP**  
Shows a value for classifying the priority.

### Steps in configuration

Follow the steps below to assign an ACL rule to an interface:

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Add Rule" drop-down list.
3. Click the "Add" button. A new entry is generated in the table.

Follow the steps below to assign an ACL rule to an interface:

---

**Note****active rules**

You cannot delete active rules.

---

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Remove Rule" drop-down list.
3. Click the "Remove" button. The corresponding entry is deleted.

6.9.6.4 Egress Rules

Introduction

On this page, you specify the ACL rules according to which outgoing frames are handled by interfaces. You specify the ACL rules in the "Rules Configuration" tab.

IP ACL Egress Rules

Rules Configuration | Protocol Configuration | Ingress Rules | Egress Rules

Interface: 

vlan1

Add Rule: 

-

Add

Remove Rule: 

Rule 1

Remove

Rule Order	Rule Number	Protocol	Protocol Number	Source IP	Source Subnet Mask	Dest. IP	Dest. Subnet Mask
1	1	<div>Any</div>	255	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0

1 entry.

Refresh

IP ACL egress rules - first part of the table

IP ACL Egress Rules

Rules Configuration | Protocol Configuration | Ingress Rules | Egress Rules

Interface: 

vlan1

Add Rule: 

-

Add

Remove Rule: 

Rule 1

Remove

Action	Source Port Min.	Source Port Max.	Dest. Port Min.	Dest. Port Max.	Message Type	Message Code	DSCP
<div>Forward</div>	0	65535	0	65535	255	255	

1 entry.

Refresh

IP ACL egress rules - second part of the table

## Description of the displayed boxes

The page contains the following boxes:

- **Interface**

Select the required interface from the drop-down list. The available interfaces (Page 43) depend on the device.

To select a VLAN interface, an IP interface must be configured.

---

**Note**

If you use a VLAN interface, the ACL rule applies to all ports that belong to the VLAN.

---

- **Add Rule**

In the drop-down list select the ACL rule to be assigned to the interface.

- **Add**

To assign the ACL rule to the interface, click the "Add" button. The configuration is shown in the table.

---

**Note**

An ACL rule with the content "deny any any" must not be applied to outgoing frames.

---

- **Remove Rule**

From the "Remove rule" drop-down list, select the ACL rule to be deleted.

- **Remove**

To remove the ACL rule from the interface, click the "Remove" button.

The table has the following columns:

- **Rule Order**

Shows the order of the ACL rules.

- **Rule Number**

Shows the number of the ACL rule.

- **Protocol**

Shows the protocol for which this rule is valid.

- **Protocol Number**

Shows the protocol number.

- **Source IP**

Shows the IPv4 address of the source.

- **Source Subnet Mask**

Shows the subnet mask of the source.

- **Dest IP**

Shows the IP address of the destination.

- **Dest. Subnet Mask**

Shows the subnet mask of the destination.

- **Action**  
Select whether the frame is forwarded or rejected when it corresponds to the ACL rule.
  - Forward  
If the frame complies with the ACL rule, the frame is forwarded.
  - Discard  
If the frame complies with the ACL rule, the frame is not forwarded.
- **Source Port Min.**  
Shows the lowest possible port number of the source port.
- **Source Port Max.**  
Shows the highest possible port number of the source port.
- **Dest. Port Min.**  
Shows the lowest possible port number of the destination port.
- **Dest. Port Max.**  
Shows the highest possible port number of the destination port.
- **Message Type**  
Shows a message type to decide the format of the message.
- **Message Code**  
Shows a message code to specify the function of the message.
- **DSCP**  
Shows a value for classifying the priority.

## Configuration procedure

Follow the steps below to assign an ACL rule to an interface:

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Add Rule" drop-down list.
3. Click the "Add" button. A new entry is generated in the table.

Follow the steps below to remove an ACL rule from an interface:

---

### Note

#### active rules

You cannot delete active rules.

---

1. Select the interface from the "Interface" drop-down list.
2. Select the ACL rule in the "Remove Rule" drop-down list.
3. Click the "Remove" button. The corresponding entry is removed in the table.

## 6.9.7 Management ACL

### Description of configuration

On this page, you can increase the security of your device. To specify which station with which IP address is allowed to access your device, configure the IP address or an entire address range.

You can select the protocols and the ports of the station with which it is allowed to access the device. You define the VLAN in which the station may be located. This ensures that only certain stations within a VLAN have access to the device.

#### Note

##### If you enable this function, note the following

A bad configuration on the "Management Access Control List" page can result in you being unable to access the device. You should therefore configure an access rule that allows access to the management before you enable the function.

Management Access Control List

☐ Management ACL

IP Address:

Subnet Mask / Prefix Length:

Select	Rule Order	IP Address	Subnet Mask / Prefix Length	VLANs Allowed	SNMP	TELNET	HTTP	HTTPS	SSH	P1	P2	VAP 1.1
<input type="checkbox"/>	1	192.168.100.10	255.255.255.255	1-4094	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

1 entry.

## Description

The page contains the following boxes:

- **Management ACL**

Enable or disable the function.

---

**Note**

If the function is disabled, there is unrestricted access to the management of the device. The configured access rules are only taken into account when the function is enabled.

---

- **IP Address**

Enter the IP address or the network address to which the rule will apply.

- If you use the IPv4 address 0.0.0.0, the settings apply to all IPv4 addresses.
- If you use the IPv6 address :: the settings apply to all IPv6 addresses.

- **Subnet Mask / Prefix Length**

Enter the subnet mask or the prefix length.

The subnet mask 255.255.255.255 is for a specific IPv4 address. If you want to allow a subnet, for example a C subnet, enter 255.255.255.0. The subnet mask 0.0.0.0 applies to all subnets.

The table has the following columns:

- **Select**

Select the check box in the row to be deleted.

- **Rule Order**

Shows the number of the rule. If you click the "Create" button, a new row with a unique number is created.

- **IP Address**

Shows the IP address.

- **Subnet Mask / Prefix Length**

Shows the subnet mask or the prefix length.

- **VLANs Allowed**

Only available if 802.1Q VLAN Bridge is set for "Layer 2 > VLAN > General".

Enter the number of the VLAN in which the device is located. The station can only access the device if it is located in this configured VLAN. If this input box remains empty, there is no restriction relating to the VLANs.

- **SNMP**

Specify whether the station (or the IP address) accesses the device using the SNMP protocol.

- **TELNET**

Specify whether the station (or the IP address) accesses the device using the TELNET protocol.

- **HTTP**  
Specify whether the station (or the IP address) accesses the device using the HTTP protocol.
- **HTTPS**  
Specify whether the station (or the IP address) accesses the device using the HTTPS protocol.
- **SSH**  
Specify whether the station (or the IP address) accesses the device using the SSH protocol.
- **Px**  
Specify whether the station (or the IP address) accesses the device via this port.
- **VAP X.Y**  
Specify whether the station (or the IP address) accesses the device via the VAP interface.
- **WDS X.Y**  
Specify whether the station (or the IP address) accesses the device via the WDS interface.

## Procedure

---

### Note

Note that a bad configuration may mean that you can no longer access the device.

You can then only remedy this by resetting the device to the factory defaults and then reconfiguring.

---

### Changing the entry

1. Configure the data of the entry you want to modify.
2. Click the "Set Values" button to transfer the changes to the device.

### Creating new entry

1. In the "IP Address" input box, enter the IP address of the device and in the "Subnet Mask / Prefix Length" input box the corresponding subnet mask.
2. Click the "Create" button to create a new row in the table.
3. Configure the entries of the new row.
4. Click the "Set Values" button to transfer the new entry to the device.

### Deleting entries

1. Select the check box in the row to be deleted.
2. Repeat this procedure for every entry you want to delete.
3. Click the "Delete" button. The entries are deleted and the page is updated.

## 6.9.8 Inter AP blocking

### 6.9.8.1 Basic

#### Note

- This WBM page is only available in access point mode.
- This WBM page can only be configured with the following KEY-PLUGs:
  - W780 iFeatures (MLFB 6GK5 907-8PA00)
  - W700 Security (MLFB 6GK5907-0PA00)

#### When should Inter AP blocking be used?

The clients connected to an access point can normally communicate with all SCALANCE W700 devices of the layer 2 network.

With inter AP blocking, the communication of the clients connected to the access point can be restricted. Only the SCALANCE W700 devices whose IP addresses are configured in "Allowed Addresses" on the access point are accessible to the clients. Communication with other nodes in the network is therefore prevented.

**WLAN Inter AP Blocking Basic Settings**

**Basic** | **Allowed Addresses**

Refresh Interval [s]:

Radio	Port	SSID	Enable	Block Gratuitous ARP Requests	Block Non-IP Frames
WLAN 1	VAP 1.1	Siemens Wireless Network	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.2	Siemens Wireless Network 1.2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.3	Siemens Wireless Network 1.3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.4	Siemens Wireless Network 1.4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.5	Siemens Wireless Network 1.5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.6	Siemens Wireless Network 1.6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.7	Siemens Wireless Network 1.7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 1	VAP 1.8	Siemens Wireless Network 1.8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.1	Siemens Wireless Network 2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.2	Siemens Wireless Network 2.2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.3	Siemens Wireless Network 2.3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.4	Siemens Wireless Network 2.4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.5	Siemens Wireless Network 2.5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.6	Siemens Wireless Network 2.6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.7	Siemens Wireless Network 2.7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WLAN 2	VAP 2.8	Siemens Wireless Network 2.8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

## Description

The page contains the following box:

- **Update interval [s]**

Enter the update interval for the ARP table.

The table has the following columns:

- **Radio**

Specifies the WLAN interface to which the settings relate.

- **Port**

Specifies the VAP interface to which the settings relate.

- **SSID**

Specifies the SSID to which the settings relate.

- **Activate**

When enabled, the access restriction is used. You configure which devices are accessible to the clients in "Security > Inter AP Blocking > Allowed Addresses".

- **Block Gratuitous ARP Requests**

When enabled, gratuitous ARP packets are not forwarded.

- **Block Non-IP Frames**

When enabled, there is no exchange of non-IP packets, for example layer 2 packets between the client and the devices configured on the access point as permitted communications partners.

### 6.9.8.2 Allowed Addresses

#### Note

- This WBM page is only available in access point mode.
- This WBM page can only be configured with the following KEY-PLUGs:
  - W780 iFeatures (MLFB 6GK5 907-8PA00)
  - W700 Security (MLFB 6GK5907-0PA00)

On this WBM page you specify which SCALANCE W700 devices are accessible to the clients.

**WLAN Inter AP Blocking Allowed Addresses**

Basic Allowed Addresses

Port: VAP 1.1

IP Address:

Select	Radio	Port	IP Address	Resolver IP Address
<input type="checkbox"/>	WLAN 1	VAP 1.1	192.168.16.100	0.0.0.0

1 entry.

Create Delete Set Values Refresh

#### Description

The page contains the following boxes:

- **Port**  
Select the required port from the drop-down list.
- **IP Address**  
Enter the IP address of the devices accessible to the client.

The table has the following columns:

- **Select**  
Select the check box in the row to be deleted
- **Radio**  
Specifies the WLAN interface to which the settings relate
- **Port**  
Specifies the VAP interface to which the settings relate

- **IP Address**

The IP Address of the devices accessible to the client. If necessary, you can change the IP address.

- **Resolver IP Address**

The IP address with which the allowed IP address is resolved. The entry is necessary when the management IP address is located in a different subnet.

If the IP address "0.0.0.0" is configured for "Resolver IP Address", the management IP address is used for resolution.

## Procedure

### Creating an entry

1. Select a port from the "Port" drop-down list.
2. In the "IP Address" box, enter the IP address accessible for the client.
3. Click the "Create" button. A new entry is created in the table.

### Deleting an entry

1. Enable "Select" in the row to be deleted.
2. Click the "Delete" button. The entry is deleted.

## 6.10 "iFeatures" menu

### 6.10.1 iPCF

---

#### Note

This WBM page can only be configured with the following KEY-PLUGs:

- Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
  - Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
- 

### When should iPCF be used?

---

#### Note

##### Use of iPCF with other iFeatures

iPCF and other iFeatures (e.g. iPCF-MC, iPCF-HT, iPRP) are not compatible with each other and cannot be used at the same time on one device.

---

The use of iPCF is advisable particularly if you have a large number of nodes and want to implement highly deterministic operation. This is necessary, for example with PROFINET or other cyclic protocols. You will find a more detailed description of iPCF in the section "Technical basics" in the section "iPCF / iPCF-HT / iPCF-MC".

The possible settings differ for access point and client. Both are described below:

In access point mode

**Industrial Point Coordination Function (iPCF)**

Radio	Enable iPCF	Legacy Free (iPCF-LF)	Protocol Support	iPCF Cycle Time [ms]	Scanning Mode	Signal Quality Threshold
WLAN 1	<input type="checkbox"/>	<input type="checkbox"/>	PROFINET	16	All Channels	Level 3 - 60%
WLAN 2	<input type="checkbox"/>	<input type="checkbox"/>	PROFINET	16	All Channels	Level 3 - 60%

Set Values Refresh

In client mode

**Industrial Point Coordination Function (iPCF)**

Radio	Enable iPCF	Legacy Free (iPCF-LF)
WLAN 1	<input type="checkbox"/>	<input type="checkbox"/>

Set Values Refresh

## Description

In both modes, the table has the following columns:

- **Radio**

Specifies the WLAN interface to which the settings relate.

- **Enable iPCF**

Enable or disable the iPCF mode. For PROFINET communication, we recommend that you enable the iPCF mode. By enabling iPCF, the data rates provided by the access point are adapted. We strongly recommend that you retain the default setting for the data rates (802.11 a/b/g = 12 Mbps and 802.11n = MCS 2).

- **Legacy Free (iPCF-LF)**

These settings determine which device generation can establish a connection to this device.

- Enabled

Only the devices that communicate with the IEEE 802.11n standard and have the "Legacy Free (iPCF-LF)" setting enabled are accepted. WLAN mode IEEE 802.11n need not be enabled for this, however.

This setting prevents performance from being slowed down by the IEEE 802.11 a/b/g device generation.

- Disabled

All device generations (IEEE 802.11 a/b/g/n) are accepted.

In access point mode, the table has the following additional columns:

- **Protocol Support**

Specify which protocol is handled with priority by the WLAN interface.

- PROFINET

if you set PROFINET, there must be no PROFINET controller downstream from the client.

- EtherNet/IP

If you set Ethernet/IP, there must be no scanner downstream from the client.

- Disabled

The function is disabled.

- **iPCF Cycle Time [ms]**

Select the required cycle time from the drop-down list.

The following points need to be taken into account when setting the cycle time. Otherwise it may not be possible to establish stable communication.

- There is only one access point in the system; in other words, the clients move only in one wireless cell. In this case, update times  $\geq 16$  ms are supported.
- There are several access points in the system that communicate over different channels. The clients roam between the access points. In this case, select update times  $\geq 32$  ms.

In addition to the guide values shown above, remember that the shortest cycle time to be set is calculated according to the formula "2 ms \* max. number of nodes".

- **Scanning Mode**

The selected setting affects the scanning of the logged-on clients.

The following settings are available:

- All Channels  
The client scans all permitted channels and selects the access point with the best signal strength and connects to it.
- Next Channel  
The client scans the next channel from its permitted channel list. If an access point is there, it connects to it. If it does not find an access point on this channel, it scans the next channel.

- **Signal Quality Threshold**

Can only be configured if "Next Channel" is set for "Scanning Mode".

The access point specifies a signal quality for the client. When scanning the client must receive the signal coming from the access point with at least the specified signal quality. Only then is a connection established.

The signal quality is determined by the client based on the RSSI values (Received Signal Strength Indicator) of received packets. The RSSI value indicates how strong the arriving signal is and is displayed in the signal recorder.

The following threshold values apply to the signal strength:

Range	Signal quality in %	Signal quality in RSSI
1	40	20
2	50	25
3	60	30
4	70	35
5	80	40

## Procedure

### In access point mode

1. Select the "Enable iPCF" option for the required WLAN interface.
2. Enable the option "Legacy Free (iPCF-LF)" if desired.

## 6.10 "iFeatures" menu

3. Select the required cycle time for the access point from the "iPCF Cycle Time [ms]" drop-down list.
4. Select for example "All Channels" from the "Scanning Mode" drop-down list.
5. Click the "Set Values" button. You configure the security settings in "Security > WLAN > Basic".

### In client mode

1. Select the "Enable iPCF" option for the required WLAN interface.
2. If needed, enable the option "Legacy Free (iPCF-LF)".
3. Click the "Set Values" button.

You configure the security settings in "Security > WLAN > Basic". You configure the security settings in "Security > WLAN > Basic".

## 6.10.2 iPCF-HT

---

### Note

This WBM page can only be configured with the following KEY-PLUGs:

- Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
  - Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
- 

## When should iPCF-HT (High Throughput) be used?

---

### Note

#### Use of iPCF-HT

The function iPCF-HT

- and other iFeatures (e.g. iPCF, iPCF-MC, iPRP) are not compatible with each other and cannot be used at the same time on a device.
- Can only be used in the frequency band 5 GHz and with WLAN mode "(only) IEEE 802.11n".
- Is available only on the WLAN interface 1.

It is advisable only to use and MCS index.

---

The use of iPCF-HT is particularly advisable when a higher data throughput is required. If, for example, alongside PROFINET you also want to transfer video data. The real-time behavior for PROFINET is retained.

The possible settings differ for access point and client.

Display in access point mode

**Industrial Point Coordination Function High Throughput (iPCF-HT)**

Radio	Enable iPCF-HT	Protocol Support	iPCF-HT Cycle Time [ms]	Scanning Mode	Signal Quality Threshold
WLAN 1	<input type="checkbox"/>	PROFINET ▼	32	All Channels ▼	Level 3 - 60% ▼

Display in client mode

**Industrial Point Coordination Function High Throughput (iPCF-HT)**

Radio	Enable iPCF-HT
WLAN 1	<input type="checkbox"/>

## Description

In both modes, the table has the following columns:

- **Radio**

Specifies the WLAN interface to which the settings relate.

- **Enable iPCF-HT**

Enable or disable iPCF-HT. When enabled, the data rates provided by the access point are adapted. We strongly recommend that you retain the default setting for the data rates (802.11n = MCS 2).

In access point mode, the table has the following additional columns:

- **Protocol Support**

Specify which protocol is handled with priority by the WLAN interface.

- PROFINET

if you set PROFINET, there must be no PROFINET controller downstream from the client.

- EtherNet/IP

If you set Ethernet/IP, there must be no scanner downstream from the client.

- Disabled

The function is disabled.

- **IPCF-HT Cycle Time [ms]**

Specify the cycle time.

The following points need to be taken into account when setting the cycle time. Otherwise it may not be possible to establish stable communication.

- The range of values is 16 - 512. The set value should correspond the cycle time of PROFINET or EtherNet/IP.
- There is only one access point in the system; in other words, the clients move only in one wireless cell. In this case, update times  $\geq 16$  ms are supported.
- There are several access points in the system that communicate over different channels. The clients roam between the access points. In this case, select update times  $\geq 32$  ms.

In addition to the guide values shown above, remember that the shortest cycle time to be set is calculated according to the formula "4 ms \* max. number of nodes".

- **Scanning Mode**

The selected setting affects the scanning of the logged-on clients.

The following settings are available:

- All Channels

The client scans all permitted channels and selects the access point with the best signal strength and connects to it.

- Next Channel

The client scans the next channel from its permitted channel list. If an access point is there, it connects to it. If it does not find an access point on this channel, it scans the next channel.

- **Signal Quality Threshold**

Can only be configured if "Next Channel" is set for "Scanning Mode".

The access point specifies a signal quality for the client. When scanning the client must receive the signal coming from the access point with at least the specified signal quality. Only then is a connection established.

The signal quality is determined by the client based on the RSSI values (Received Signal Strength Indicator) of received packets. The RSSI value indicates how strong the arriving signal is and is displayed in the signal recorder.

The following threshold values apply to the signal strength:

Range	Signal quality in RSSI	Signal quality in %
1	20	40
2	25	50
3	30	60
4	35	70
5	40	80

## Procedure

### In access point mode

1. Select the "Enable iPCF-HT" option for the required WLAN interface.
2. For "iPCF-HT Cycle Time [ms]" enter the required cycle time.
3. Select for example "All Channels" from the "Scanning Mode" drop-down list.
4. Click the "Set Values" button. You configure the security settings in "Security > WLAN > Basic".

### In client mode

1. Select the "Enable iPCF-HT" option for the required WLAN interface.
2. Click the "Set Values" button.

You configure the security settings in "Security > WLAN > Basic".

### 6.10.3 iPCF-MC

---

#### Note

##### Use of iPCF with other iFeatures

The function iPCF-MC and other iFeatures (e.g. iPCF, iPCF-HT, iPRP) are not compatible with each other and cannot be used at the same time on a device.

##### Assignment of the interfaces

With 11n devices, remember that the assignment of the WLAN interfaces is fixed for iPCF-MC.

- WLAN1: Data interface
  - WLAN2: Management interface
- 

##### Requirements to be able to use iPCF-MC:

- The access point has at least two WLAN interfaces (dual AP).
- Access point mode: Only dual APs with KEY-PLUG W780 iFeatures (MLFB 6GK5 907-8PA00)
- Client mode: Client with KEY-PLUG W740 iFeatures (MLFB 6GK5 907-4PA00)
- The management interface and data interface must be operated in the same frequency band and mode and must match in terms of their wireless coverage. iPCF-MC will not work if both wireless interfaces are equipped with directional antennas that cover different areas.
- The management interfaces of all access points to which a client can change must use the same channel. A client scans only this one channel to find accessible access points.
- Transmission based on IEEE801.11h (DFS) cannot be used for the management interface. For the data interface 801.11h (DFS) is possible.
- The client cannot be operated with "Use Allowed Channels only".
- "Force roaming on link down" is automatically mirrored on the second interface.
- The following applies to clients: All configured and active SSIDs must be assigned security context 1. An SSID is active when the corresponding check box "Enabled" is selected on the "Interfaces > WLAN > Client" page.
- In Japan, iPCF-MC cannot be enabled if the data or management interface uses a frequency of the 4920 MHz - 5080 MHz frequency band.

## When should IPCF-MC be used?

IPCF was developed to achieve short handover times when roaming between cells. The IPCF-MC technique allows short handover times even for freely mobile clients and when a lot of cells are involved or a large number of channels is being used.

The possible settings differ for access point and client. Both are described below:

In access point mode

**Industrial Point Coordination Function with Management Channel (iPCF-MC)**

☐ Enable iPCF-MC

☐ Legacy Free (iPCF-MC-LF)

iPCF Cycle Time [ms]: 32 ▼

Protocol Support: PROFINET ▼

In client mode

**Industrial Point Coordination Function with Management Channel (iPCF-MC)**

☐ Enable iPCF-MC

☐ Legacy Free (iPCF-MC-LF)

Management Scan Period: 1 ▼

Roaming Filter: disabled ▼

## Description

The page contains the following boxes:

- **Enable iPCF-MC activated**

Enable or disable the iPCF-MC mode of the SCALANCE W700 device.

For PROFINET communication, we recommend enabling the iPCF-MC mode. By enabling iPCF-MC, the data rates provided by the access point are adapted.

We strongly recommend that you retain the default setting for the data rates (802.11 a/b/g = 6, 9 and 12 Mbps and 802.11n = MCS 2).

- **Legacy Free (iPCF-MC-LF)**

These settings determine which device generation can establish a connection to this device.

- Enabled

Only the devices that communicate with the IEEE 802.11n standard and have the "Legacy Free (iPCF-MC-LF)" setting enabled are accepted. WLAN mode IEEE 802.11n need not be enabled for this, however.

This setting prevents performance from being slowed down by the IEEE 802.11 a/b/g device generation.

- Disabled

All device generations (IEEE 802.11 a/b/g/n) are accepted.

- **iPCF Cycle Time** (only in access point mode)

Select the update time configured for the network to which the access point is connected. The lowest value for the update time is 32 ms.

- **Protocol Support** (only in access point mode)

Specify which protocol is handled with priority.

- PROFINET

if you set PROFINET, there must be no PROFINET controller downstream from the client.

- EtherNet/IP

If you set Ethernet/IP, there must be no scanner downstream from the client.

- **Management Scan Period** (in client mode only)

This parameter specifies the time between two management channel scans (specified in iPCF cycles). If, for example, you select two, the client runs a management channel scan only in every second iPCF cycle.

A lower value for the scan interval provides the basis for fast roaming, however this means that no high data throughput can be achieved. A higher value should be selected for a high data throughput.

- **Roaming Filter** (in client mode only)

With this setting you specify the number of RSSI single measurements from which the median is determined. With 5, the last 5 measured RSSI values are considered.

- Median with an odd number of measurements

The values are arranged in ascending order. The value exactly in the middle is the median.

- Median with an even number of measurements

The values are arranged in ascending order. The median is calculated from the average of the two middle numbers.

If occasionally there are extreme outliers of the incoming signal, you can filter out the worst fluctuations with this roaming filter. This prevents premature roaming of the client.

## 6.10.4 iPRP

---

### Note

This WBM page can only be configured with the following KEY-PLUGs:

- Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
  - Client: W740 iFeatures (MLFB 6GK5 907-4PA00)
- 

### Requirements for using iPCF

- The Base Bridge mode "802.1Q VLAN Bridge" is set.
- The VLANs are created
- Access point mode: The VAP interface is enabled.
- Client mode: For "MAC Mode", "Layer 2 Tunnel" is set.

## When should iPRP be used?

---

### Note

#### Use of iPRP with other iFeatures

iPRP and other iFeatures (e.g. iPCF, iPCF-HT, , iPCF-MC) are not compatible with each other and cannot be used at the same time on a device.

#### iPRP with oversize frames (jumbo frames)

To be able to use oversize frames, oversize frames (jumbo frames) must be configured for all devices in the network.

#### Agent VLAN (management VLAN) with iPRP

The iPRP VLAN can be used as the agent VLAN. This depends where the device is located.

- If the device is located in the PRP network A or PRP network B, as the agent VLAN use the VLAN that PRPA or PRPB is assigned to.
  - If the access points are located in both PRP networks, you can use one of the two VLANs as the agent VLAN. As an alternative you can also use other VLANs as agent VLANs. The division into PRP networks A and B must remain. A single management VLAN for all devices in network A and B is not possible without further measures.
- 

With the "industrial Parallel Redundancy Protocol" (iPRP) the PRP technology can be used in a wireless network. With iPRP the PRP frames are transferred parallel via two wireless links. The parallel transfer allows disruptions of the transfer on one wireless link to be compensated on the other.

### Industrial Parallel Redundancy Protocol (iPRP)

VLAN Assignment

PRP A:

PRP B:

Port	Enable iPRP	PRP Network
VAP 1.1	<input type="checkbox"/>	<input type="text" value="-"/>

## Industrial Parallel Redundancy Protocol (iPRP)

VLAN Assignment

PRP A: VLAN1 ▼

PRP B: - ▼

Port	Enable iPRP	PRP Network	AP Redundancy
WLAN 1	<input type="checkbox"/>	<span>- ▼</span>	<span>Radio ▼</span>

Set Values Refresh

The page contains the following:

- This table contains the following columns:

- ### Note

- **Enable iPRP**  
Enable or disable iPRP for the required port.

- **PRP Network**

Specify the PRP network in which the port is a member.

- **AP Radio Redundancy (in client mode only)**

- Radio

Prevents the two clients of a client pair connecting on the same WLAN interface of the access point.

- Disabled

When the best access point for a client is the same access point (same WLAN interface) as that of the partner client, a check is made as to whether there is another access point whose signal strength is < 10 dB worse than that of the best access point. In this case the client connects to this access point, otherwise it connects to the same, best access point as the partner client.

- Device

Prevents the two clients of a client pair from connecting to the same access point no matter which interface is used

## Procedure

1. Select the VLAN assignment for PRP A from the "PRP A" drop-down list.
2. Select the VLAN assignment for PRP B from the "PRP B" drop-down list.
3. Specify the PRP network in which the port is a member.
4. Make the setting for "AP Radio Redundancy".
5. Select the "Enable iPRP" setting. Click the "Set Values" button.

The appropriate VLAN settings are made automatically.

## 6.10.5 iREF

---

**Note**

- This WBM page is only available in access point mode.
  - This WBM page can only be configured with the following KEY-PLUG:
    - Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
- 

### When should iREF be used?

---

**Note****Use of iREF with other iFeatures**

iREF and other iFeatures (e.g. iPCF, iPCF-HT, iPCF-MC, iPRP) are not mutually compatible and cannot be used at the same time with one device.

---

With iREF, the data can be sent with the highest possible transmit power. In particular in applications in which MIMO cannot be used or brings no advantage, this allows data to be transmitted at the highest possible data transmission rate.

Radio	Enable iREF
WLAN 1	<input type="checkbox"/>
WLAN 2	<input type="checkbox"/>

## Description

The table has the following columns:

- **Radio**

Specifies the WLAN interface to which the settings relate.

- **Enable iREF**

Enable or disable iREF for the required WLAN interface. The result is shown in "Information > WLAN > iFeatures".

---

**Note**

To be able to use iREF, there must be at least two antennas.

The antennas are automatically switched to Mode RX/TX as soon as iREF is enabled.

---

## 6.10.6 AeroScout

---

**Note**

- This WBM page is only available in access point mode.
  - This WBM page can only be configured with the following KEY-PLUG:  
Access point: W780 iFeatures (MLFB 6GK5 907-8PA00)
- 

**Note****Using Aeroscout**

- AeroScout and other iFeatures (e.g. iREF, iPCF, iPCF-HT, iPCF-MC, iPRP) are not mutually compatible and cannot be used at the same time with one device.
- AeroScout can only be used in the 2.4 GHz band according to IEEE 802.11g, IEEE 802.11n and IEEE 802.11n only.

For more detailed information, please refer to the documentation of the AeroScout company ([www.aeroscout.com](http://www.aeroscout.com)).

---

Radio	Enable AeroScout
WLAN 1	<input type="checkbox"/>
WLAN 2	<input type="checkbox"/>

## Description

The table has the following columns:

- **Radio**

Specifies the WLAN interface to which the settings relate.

- **Enable AeroScout**

Enable or disable AeroScout for the required WLAN interface. The result is shown in "Information > WLAN iFeatures > AeroScout".



## Upkeep and maintenance

### 7.1 Firmware update - via WBM

#### Requirement

- The device has an IP address.
- The user is logged in with administrator rights.

#### Firmware update via HTTP

1. Click "System > Load&Save" in the navigation area. Click the "HTTP" tab.
2. Click the "Load" button in the "Firmware" table row.
3. Go to the storage location of the firmware file.
4. Click the "Open" button in the dialog. The file is uploaded.

#### Firmware update - via TFTP

1. Click "System > Load&Save" in the navigation area. Click the "TFTP" tab.
2. Enter the IP address of the TFTP server in the "TFTP Server Address" input box.
3. Enter the port of the TFTP server in the "TFTP Server Port" input box.
4. Click the "Load file" button in the "Firmware" table row.
5. Go to the storage location of the firmware file.
6. Click the "Open" button in the dialog. The file is uploaded.

#### Firmware update via SFTP

1. Click "System > Load&Save" in the navigation area. Click the "SFTP" tab.
2. Enter the IP address of the SFTP server in the "SFTP Server Address" input box.
3. Enter the port of the SFTP server in the "SFTP Server Port" input box.
4. Click the "Load file" button in the "Firmware" table row.
5. Go to the storage location of the firmware file.
6. Click the "Open" button in the dialog. The file is uploaded.

#### Result

The firmware is has been transferred completely to the device.

On the "Information > Versions" there are the entries "Firmware" and "Firmware Running". Firmware Running shows the version of the current firmware. "Firmware" shows the firmware version stored after loading the firmware. To activate this firmware, restart the device with "System > Restart".

## 7.2 Device configuration with PRESET-PLUG

Please not the additional information and security notes in the operating instructions of your device.

<b>NOTICE</b>
<b>Do not remove or insert a PLUG during operation</b>
A PLUG may only be removed or inserted when the device is turned off.

---

**Note****Support as of V6.0**

The PRESET-PLUG functionality is supported as of firmware version V6.0.

---

With the PRESET-PLUG, you can install the same device configuration (start configuration, user accounts, certificates) including the corresponding firmware on multiple devices.

The PRESET PLUG is write-protected.

You configure the PRESET PLUG using the Command Line Interface (CLI).

### Creating a PRESET-PLUG

You create the PRESET PLUG using the Command Line Interface (CLI). You can create a PRESET-PLUG from any PLUG. To do this, follow the steps outlined below:

---

**Note****Using configurations with DHCP**

Create a PRESET-PLUG only from device configurations that use DHCP. Otherwise disruptions will occur in network operation due to multiple identical IP addresses.

You assign fixed IP addresses extra following the basic installation.

---

**Requirement**

- A PLUG is inserted in the device on which you want to configure the PRESET-PLUG functionality.

**Procedure**

1. Start the remote configuration using Telnet (CLI) and log on with a user with the "admin" role.
2. Change to the Global configuration mode with the command "configure terminal".
3. You change to the PLUG configuration mode with the "plug" command.
4. Create the PRESET-PLUG with the "presetplug" command.  
The firmware version of the device and the current device configuration incl. user accounts and certificates are stored on the PLUG and the PLUG is then write protected.
5. Turn off the power to the device.

6. Remove the PRESET-PLUG.
7. Start the device either with a new PLUG inserted or with the internal configuration.

### Procedure for installation with the aid of the PRESET-PLUG

1. Turn off the power to the device.
2. If it exists, remove the PLUG from the slot. You will find further information on this in the operating instructions of your device.
3. Insert the PRESET-PLUG correctly oriented into the slot. The PRESET-PLUG is correctly inserted when it is completely inside the device and does not jut out of the slot.
4. Turn on the power to the device again.  
If there is a different firmware version on the device to be installed compared with that on the PRESET-PLUG, an upgrade/downgrade of the firmware is performed. You can recognize this by the red F-LED flashing (flashing interval: 2 sec on/0.2 sec off). Afterwards the device is restarted and the device configuration incl. users and certificates on the PRESET-PLUG is transferred to the device.
5. Wait until the device has fully started up.  
(the red F-LED is off)
6. Turn off the power to the device after the installation.
7. Remove the PRESET-PLUG.
8. Start the device either with a new PLUG inserted or with the internal configuration.

---

#### Note

##### KEY-PLUG

If you have created the PRESET-PLUG from a KEY-PLUG, for operation with this configuration, you require an inserted KEY-PLUG.

IN this case before recommissioning the device you need to insert the relevant KEY-PLUG.

---

---

#### Note

##### Restore factory defaults and restart with a PRESET PLUG inserted

If you reset the device to the factory defaults, when the device restarts an inserted PRESET PLUG is formatted and the PRESET PLUG functionality is lost. You then need to create a new PRESET PLUG. The keys stored on the KEY-PLUG for releasing functions are retained.

We recommend that you remove the PRESET PLUG before you reset the device to the factory settings.

---

**Formatting a PRESET-PLUG (resetting the preset function)**

You format the PRESET PLUG using the Command Line Interface (CLI) to reset the preset function. To do this, follow the steps outlined below:

1. Start the remote configuration using Telnet (CLI) and log on with a user with the "admin" role.
2. Change to the Global configuration mode with the command "configure terminal".
3. You change to the PLUG configuration mode with the "plug" command.
4. Enter the command "factoryclean".  
The PRESET-PLUG is formatted and the preset function is reset.
5. Write the current configuration of the device with the "write" command.

## 7.3 Embedding firmware in ConfigPack.

Please not the additional information and security notes in the operating instructions of your device.

With the the ConfigPack with embedded firmware file you can install a device configuration including the firmware belonging to it on one or more devices.

### Creating ConfigPack with embedded firmware

To embed the firmware in a ConfigPack, you need to make a setting in the Command Line Interface (CLI). To do this, follow the steps outlined below:

---

#### Note

##### Using configurations with DHCP

If you want to use the ConfigPack with embedded firmware to commission multiple devices with the same configuration and firmware create a ConfigPack only from device configurations that use DHCP. Otherwise, disruptions will occur in network operation due to multiple identical IP addresses.

You assign fixed IP addresses extra following the basic installation.

---

1. Start the remote configuration using Telnet (CLI) and log on with a user with the "admin" role.
2. Change to the global configuration mode with the command "configure terminal".
3. You change to the loadsave configuration mode with the "loadsave" command.
4. Enter the "firmware-in-configpack" command without parameters.  
The firmware currently on this device is now included as a separate file in the ConfigPack when you save it.

---

#### Note

##### Embedding firmware in ConfigPack.

When the device is restarted this functionality is lost again and must be reactivated.

---

If you save a ConfigPack in the WBM or CLI, the firmware is embedded.

Refer to the information in the section Load & Save (Page 189).

### Installing ConfigPack with embedded firmware

---

#### Note

##### Installing ConfigPack with DHCP options 66, 67

You can also install the ConfigPack using DHCP with options 66 and 67 activated.

You activate the options in the menu "System > DHCP > DHCP Client".

---

If you install a ConfigPack using WBM or CLI, firmware stored there is also installed.

#### **Procedure in the WBM**

1. Connect to the WBM of the device on which you want to install the ConfigPack as administrator.
2. Go to the menu "System > Load&Save".
3. In the row "ConfigPack", click the "Load" button
4. Select the ConfigPack you want to install.
5. Restart the device with "System > Restart".  
If there is a different firmware version on the device to be installed compared with that in the ConfigPack, an upgrade/downgrade of the firmware is performed. You can recognize this by the red F-LED flashing (flashing interval; 2 sec on/0.2 sec off). Afterwards the device is restarted and the device configuration incl. users and certificates stored in the ConfigPack is transferred to the device.
6. Wait until the device has fully started up.  
(the red F-LED is off)
7. You can log on the device again or exit the WBM.

## 7.4 Restoring the factory settings

<b>NOTICE</b>
<b>Previous settings</b> If you reset, all the settings you have made will be overwritten by factory defaults.
<b>NOTICE</b>
<b>Inadvertent reset</b> An inadvertent reset can cause disturbances and failures in a configured network with further consequences.

### With the reset button

When pressing the button, make sure you observe the information in the "Reset button" section in the operating instructions.

Follow the steps below to reset the device parameters to the factory settings:

1. Turn off the power to the device.
2. Loosen the screws of the cover.
3. Remove the cover.
4. Now press the Reset button and reconnect the power to the device while holding down the button.
5. Hold down the button until the red fault LED (F) stops flashing after approximately 10 seconds and is permanently lit.
6. Now release the button and wait until the fault LED (F) goes off again.
7. The device then starts automatically with the factory settings.

### With the Primary Setup Tool

Follow the steps below to reset the device parameters to the factory defaults with the Primary Setup Tool.

1. Select the device whose parameters you want to reset.
2. Click on the menu item "Reset" in the "Module" tab.
3. Confirm the prompt with "OK".

### **Via the configuration**

You will find detailed information on resetting the device parameters using the WBM and CLI in the configuration manuals:

- Web Based Management, section "Restart"
- Command Line Interface, section "Reset and Defaults"



## Troubleshooting/FAQ

### 8.1 Firmware update via WBM or CLI not possible

#### Cause

If there is a power failure during the firmware update, it is possible that the device is no longer accessible using Web Based Management or the CLI.

When pressing the button, make sure you adhere to the instructions in the section "Reset button".

#### Solution

You can then also assign firmware to a SCALANCE W using TFTP. Follow the steps below to load new firmware using TFTP:

1. Turn off the power to the device.
2. Now press the Reset button and reconnect the power to the device while holding down the button.
3. Hold down the button until the red fault LED (F) starts to flash after approximately 2 seconds.
4. Now release the button. The bootloader waits in this state for a new firmware file that you can download by TFTP.
5. Connect a PC to the SCALANCE W over the Ethernet interface.
6. Assign an IP address to the SCALANCE W with the Primary Setup Tool.
7. Open a DOS box and change to the directory where the file with the new firmware is located and then execute the command "tftp -i <ip address> PUT <firmware>". As an alternative, you can use a different TFTP client.
8. Close the cover to ensure that the device is closed and water and dust proof.

---

#### Note

##### Use of CLI and TFTP in Windows 7

If you want to access the CLI or TFTP in Windows 7, make sure that the relevant functions are enabled in Windows 7.

---

## **Result**

The firmware is transferred to the device.

---

### **Note**

Please note that the transfer of the firmware can take several minutes. During the transmission, the red error LED (F) flashes.

---

Once the firmware has been transferred completely to the device, the device is restarted automatically.

## 8.2 Disrupted data transmission due to the received power being too high

### Causes and effects of excessive received power

If the received power at the input of a SCALANCE W device is too high, this overdrives the amplifier circuit. Overdrive can occur on clients and access points. If the received power on the SCALANCE W device is greater than -35 dBm, this can result in disrupted communication.

Information about the signal strength [in dBm] is displayed in WBM in the following tabs:

Access point mode:

- Information > WLAN > Client List

Client mode:

- Information > WLAN > Available AP
- Interfaces > WLAN > Signal recorder

The power of the input signal on the SCALANCE W device is influenced by the following factors:

- Distance between the WLAN partners
- Reflections of the electromagnetic waves by parts of the building
- Setting of the "max. Tx Power" (transmit power) (Interfaces > WLAN > Basic) and the antenna settings used (Interfaces > WLAN > Antennas).

### Solution

If communication is disrupted by an excessive signal strength (greater than -35 dBm), you can eliminate the problem in the following ways:

- Increase the distance between the transmitter and receiver.
- Reduce the transmit power of the IWLAN partner with suitable settings in WBM or CLI.

## 8.3 Compatibility with predecessor products

### Mixed mode

Mixed operation with predecessor products (6GK57xx-xAA60-xAx0) is possible.

Further information about predecessor products can be found on the Internet at Siemens Industry Automation and Drives Service & Support, entry ID: 42784493 (<https://support.industry.siemens.com/cs/ww/en/view/42784493>)

Note the following points if you want to make mixed operation possible:

- **Transmission standard IEEE 802.11a/b/g/n**  
The transmission standards IEEE 802.11a/b/g/n are compatible with the predecessor products. The setting "802.11n only" is not compatible with the predecessor products. The transmission standards IEEE 802.11a/g/h Turbo of the predecessor products are not supported.
- **Security settings**  
The transmission standards IEEE 802.11a/b/g support the same security settings as the predecessor products.  
The transmission standard IEEE 802.11n with the setting "802.11n" or "802.11n only" only supports WPA2/ WPA2-PSK with AES in the security settings.
- **iPCF / iPCF-MC**  
The transmission method IEEE 802.11b is not supported along with iPCF.  
The devices SCALANCE W700-xRR must not be configured with the operating mode IEEE 802.11b in mixed operation.
- **SSID**  
For SSID, use only the characters that were supported by the previous products.
- **Management only over wired Ethernet interface**  
In the previous products, there was a function "Management only over wired Ethernet interface". In the new devices this function is covered by the "Management ACL" function.
- **WDS ID**  
With WDS ID, do not use the ASCII character 0x22 ( " ).
- **Key for WEP or AES**  
With devices with firmware up to version 3.2, the keys for WEP or AES may only contain ASCII characters or hexadecimal characters from 0x20 to 0x7E.
- **Key for WPA(2)-PSK**  
For devices with firmware version  $\leq 5.0$ , the keys for WPA(2)-PSK can only consist of ASCII characters or hexadecimal characters from 0x20 to 0x7E.  
For devices with firmware version  $\geq 5.1$ , the following specifications apply to WPA(2)-PSK keys:
  - For a key with 8 to 63 characters, you can only use the following readable ASCII characters: 0x20 - 0x7e.
  - For a key with precisely 64 characters, you can use the following ASCII characters: 0 - 9, a - f and A - F.

## 8.4 Instructions for secure network design

Note the information below to protect your network against attacks:

- **Use a secure connection with HTTPS**

In contrast to HTTP, HTTPS allows you secure access for configuring the WLAN clients and the access points using Web Based Management. For more detailed information, refer to the section "Load & Save (Page 189)".

- **Use WPA2/ WPA2-PSK with AES**

Use only WPA2/AES to prevent password misuse. WPA2/ WPA2-PSK with AES provides the greatest security. For more detailed information, refer to the section ""Security" menu (Page 345)".

- **Protect your network from man-in-the-middle attacks**

To protect your network from man-in-the-middle attacks, a network setup is recommended that makes it more difficult for the attacker to access the communications path between two end devices.

- You can, for example, protect devices by arranging so that the Agent IP is only accessible via a single management VLAN. For more detailed information, refer to the section "Agent IPv4 (Page 178)".
- A further option is to install a separate HTTPS certificate on the WLAN client / access point. The HTTPS certificate checks the identity of the device and controls the encrypted data exchange. You can install the HTTPS certificate via HTTP. For more detailed information, refer to the section "HTTP (Page 193)".

- **Use SNMPv3**

SNMPv3 provides you with highest possible security when accessing the devices via SNMP. For more detailed information, refer to the section "SNMP (Page 218)".

### NOTICE

#### Changing the default password after configuring with STEP 7

If a device in the default status is configured only with STEP 7, it is not possible to change the default password. This change must be made directly on the device using WBM or CLI. Otherwise the default password is retained and any user could log in using the default password.

## 8.5 WLAN client Trigger handover via SNMP

If the other handover mechanisms such as Roaming threshold value, Background Scan threshold value are inadequate, a specific handover can be triggered by setting the MIB variable snMspWlanForceHandover.

A WLAN client drives, for example along a stretch where there are several access points. When the WLAN client passes a certain point, the value of the MIB variable is changed from 0 to 1. The WLAN client logs off from the connected access point and searches for reachable access points. It logs on to the best reachable access point. The value of the MIB variable is reset to 0.

### Trigger handover

Using the private MIB variable snMspWlanForceHandover, you can force a handover.

---

#### Note

With Web Based Management (WBM) or using the Command Line Interface (CLI) you cannot configure this function.

---

OID of the private MIB variable snMspWlanForceHandover:

```
iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).siemens(4329).industrialCo
mProducts(20).iComPlatforms(1).simaticNet(1).snMsp(1).snMspCommon(1).snMspWlan(27)
.snMspWlanObjects(1). snMspWlanSmt(1). snMspWlanRoamingConfigTable(4). snMspWlanR
oamingConfigEntry(1). snMspWlanForceHandover(14)
```

values of the MIB variable

- 0: Function is disabled.
- 1: Triggers handover.

### MIB file

The MIB variable snMspWlanForceHandover can be found in the private MIB file "Scalance\_w\_msps.mib".

## 8.6 Configuring the device using the TIA Portal

Once you have inserted the network component, you can edit the properties and parameters offline, for example the device name. Offline means there is no connection to the device.

To be able to see the changes on the device, the change must first be compiled and then loaded on the device.

Compiling and loading can be started in different ways:

- with the shortcut menu "Download to device > Hardware configuration"
- with the "Download" button in the toolbar.

### Requirement

- The network component has been created in the project.
- The hardware configuration of the network component matches the hardware configuration of the device. If this is not case, the download will be aborted due to errors.
- The firmware version of the network component matches the firmware version of the device.
- The IP address has been set up.
- The device is connected to the configuration PC.
- The required properties and parameters have been configured.

---

### Note

#### Activating the SINEMA configuration interface

You can only configure a device using the TIA Portal if you have enabled "SINEMA configuration interface" in the WBM in the menu "System > Configuration".

---

### Downloading properties and parameters to the device

To download the change properties and parameters to the device, follow these steps:

1. Select the required network component in the project tree.
2. In the shortcut menu of the network component select the command "Download to device > Hardware configuration".

3. When the "Extended download to device" dialog opens, configure the "Settings for the download".
  - Select the protocol you are using, e.g. HTTPS.
  - Configure the relevant interface parameters on the configuration PC. When necessary, make interface or protocol specific settings on the operator panel. Click "Start search"

The network component is displayed in the "Compatible devices in target subnet" table with its detected IP address.

  - Select the address entry in the table and click the "Load" button.
4. The "Load preview" dialog opens. At the same time the hardware configurations compiled. In this dialog you see messages and proposed revisions necessary for loading, e.g. password required.
 

Check the messages and if necessary enable the actions in the "Action" column.

As soon as loading is possible the button becomes active.
5. Click the "Load" button.
 

Loading is performed and the dialog "Load results" is displayed.
6. If the loading is completed error-free, select "Save configuration" in "Action".
7. Click the "Finish" button.

#### Result

After successful loading, the project can be run on the network component.

### Updating the SCALANCE configuration of the network component

To update the SCALANCE configuration of the network component, follow these steps:

1. Open the "Devices & Networks" editor and set the network view.
2. Select the network component in the network view.
3. In the shortcut menu of the network component select the command "SCALANCE configuration > Upload to PG/PC".

#### Result

Once the connection to the device is established you will be prompted to log in to the device. If the login was successful, the SCALANCE configuration will be loaded from the device to the TIA Portal. Afterwards the properties and parameters are updated in the TIA Portal.

### 8.6.1 Message: SINEMA configuration not yet accepted

When the following message is displayed in the display area an error has occurred transferring the configuration from STEP 7 Basic / Professional as of V13 to the device:

"SINEMA Configuration not accepted yet. With restart of device, all configuration changes will be lost."

One possible cause is, for example, that during transfer the device was not reachable.

If you now change a parameter directly on the device (WBM/CLI/SNMP) these changes are lost when the device restarts.

## Solution

1. Open the relevant STEP 7 project in STEP 7 Basic / Professional
2. Open the project view.
3. Select the device in the project tree.
4. Select the "Go to network view" command in the shortcut menu.
5. Select the device in the network view.
6. In the shortcut menu of the selected device select the command "SCALANCE configuration > Save as start configuration".

## Result

The configuration is saved on the device. The message is no longer visible in the display area. A configuration change directly on the device is no longer lost due to a restart of the device.



## Appendix A

### A.1 MIB files supported by SCALANCE W700 device

#### MIB files available for the SCALANCE W device

The following table shows the MIB files available for a SCALANCE W device:

MIB	Root OID	Reference
AUTOMATION SNTP (Siemens) <sup>1) 2)</sup>	.1.3.6.1.4.1.4329.6.3.11	Vendor specific
AUTOMATION SYSTEM MIB (Siemens) <sup>1) 2)</sup>	.1.3.6.1.4.1.4329.6.3.2	Vendor specific
AUTOMATION TELNET (Siemens) <sup>1) 2)</sup>	.1.3.6.1.4.1.4329.6.3.8	Vendor specific
AUTOMATION TIME MIB (Siemens) <sup>1) 2)</sup>	.1.3.6.1.4.1.4329.6.3.3	Vendor specific
BRIDGE MIB	.1.3.6.1.2.1.17	RFC1493
ENTITY-MIB	.1.3.6.1.2.1.47	
EtherLike-MIB	.1.3.6.1.2.1.10.7.2	
IANA-MAU-MIB	.1.3.6.1.2.1.26.1.1	
IEEE8021-PAE-MIB	.1.0.8802.1.1.1	IEEE 802.1X
IEEE802dot11-MIB	.1.2.840.10036	IEEE 802.11
IF-MIB:	.1.3.6.1.2.1.2	RFC2233
P-BRIDGE-MIB	.1.3.6.1.2.1.17.4.5	
Q-BRIDGE-MIB	.1.3.6.1.2.1.17.7	
RADIUS-ACC-CLIENT-MIB	.1.3.6.1.2.1.67.2.2	
RADIUS-AUTH-CLIENT-MIB	.1.3.6.1.2.1.67.1.2	
RFC1213-MIB	.1.3.6.1.2.1.4	
RMON-MIB	.1.3.6.1.2.1.16	
SNMP-COMMUNITY-MIB	.1.3.6.1.6.3.18	
SNMP-FRAMEWORK-MIB	.1.3.6.1.6.3.10.2.1	RFC2571
SNMP NOTIFICATION MIB	.1.3.6.1.6.3.13	RFC2573
SNMP PROXY MIB	.1.3.6.1.6.3.14	
SNMP-TARGET-MIB	.1.3.6.1.6.3.12	RFC2573
SNMP USER-BASED SM MIB	.1.3.6.1.6.3.15	RFC2574
SNMPv2-MIB	.1.3.6.1.2.1.1	RFC1907
SNMP VIEW-BASED ACM MIB	.1.3.6.1.6.3.16	RFC2575
SN-MSPS-ACL-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.30	Vendor specific
SN-MSPS-CONFIG-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.1	Vendor specific
SN-MSPS-CPLUG-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.23	Vendor specific
SN-MSPS-DHCP-CLIENT-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.17.1	Vendor specific
SN-MSPS-DIGITAL-IO-MIB (Siemens) <sup>2)3)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.39	Vendor specific
SN-MSPS-GENERAL-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.2	Vendor specific

MIB	Root OID	Reference
SN-MSPS-HTTP-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.20	Vendor specific
SN-MSPS-IF-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.34	Vendor specific
SN-MSPS-IP-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.13	Vendor specific
SN-MSPS-KEY-PLUG-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.35	Vendor specific
SN-MSPS-LOAD-SAVE-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.26	Vendor specific
SN-MSPS-LOG-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.31	Vendor specific
SN-MSPS-MSTP-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.6	Vendor specific
SN-MSPS-NTP-MIB (Siemens)	.1.3.6.1.4.1.4329.20.1.1.1.1.33	Vendor specific
SN-MSPS-PNAC-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.10	Vendor specific
SN-MSPS-PORT-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.29	Vendor specific
SN-MSPS-RADIUS-SERVER-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.11.2	Vendor specific
SN-MSPS-REPORT-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.28	Vendor specific
SN-MSPS-RMON-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.12	Vendor specific
SN-MSPS-SINEMA-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.25	Vendor specific
SN-MSPS-SNMP-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.4	Vendor specific
SN-MSPS-SNTP-CLIENT-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.19.1	Vendor specific
SN-MSPS-STP-L2T-MIB (Siemens)	.1.3.6.1.4.1.4329.20.1.1.1.1.40	Vendor specific
SN-MSPS-SYSLOG-CLIENT-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.21.1	Vendor specific
SN-MSPS-VLAN-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.3	Vendor specific
SN-MSPS-WLAN-MIB (Siemens) <sup>2)</sup>	.1.3.6.1.4.1.4329.20.1.1.1.1.27	Vendor specific
SN-MSPS-NAT-MIB	.1.3.6.1.4.1.4329.20.1.1.1.1.45	Vendor specific
TCP-MIB	.1.3.6.1.2.1.6	
UDP-MIB	.1.3.6.1.2.1.7	

- 1) Part of the AUTOMATION.MIB

You can download the AUTOMATION.MIB for SCALANCE W700 from Siemens Industry Automation and Drives Service & Support under the following entry ID 67637278 (<https://support.industry.siemens.com/cs/ww/en/view/67637278>)

- 2) Part of the private MIB file "Scalance\_w\_mspms.mib". The file can be downloaded in WBM using "System > Load&Save > HTTP > MIB" and the "Save" button.
- 3) This MIB is not supported on devices without a digital input/output.

## Appendix B

### B.1 Private MIB variables of the SCALANCE W700

#### Downloading the MIB of the SCALANCE W via WBM

You can download the MIB of the SCALANCE W in WBM under "System > Load&Save > HTTP > MIB" using the "Save" button.

#### OID

The private MIB variables of the SCALANCE W have the following object identifier:

```
iso(1).org(3).dod(6).internet(1).private(4).enterprises(1)
siemens(4329).industrialComProducts(20).iComPlatforms(1)
simaticNet(1).snMsp(1).snMspCommon(1)
```

#### WLAN-specific MIB variables

The WLAN-specific MIB variables can be found in "snMspWlan". You will find further information about the settings and values in the MIB file.



## Appendix C

### C.1 Underlying standards

#### Standards met by SCALANCE W700 devices completely or partly

The following table lists some of the standards for SCALANCE W700 devices.

Name of the standard	Topic
IEEE 802.1AB	Link Layer Discovery Protocol (LLDP)
IEEE 802.1D-1998	Media Access Control (MAC), bridges
IEEE 802.1Q	Virtual Bridged LANs (VLAN Tagging, Port Based VLANs)
IEEE 802.1W-2004	Rapid Spanning Tree Protocol (RSTP)
IEEE 802.3-2002	Ethernet
IEEE 802.3af	Power over Ethernet (PoE)
IEEE 802.11	Wireless Local Area Network
IEEE 802.11a	Wireless standard for use of the 5 GHz frequency band
IEEE 802.11b/g	Wireless standard for use of the 2.4 GHz frequency band
IEEE 802.11e	Quality of Service (QoS)
IEEE 802.11 h	Expansion of the spectrum and transmit power for use of the 5 GHz frequency range in Europe.
IEEE 802.11i	Encryption of WLANs
IEEE 802.11n	Standard for high transmission rates



## Appendix D

### D.1 Messages in the event log

#### Messages during system startup (general)

Alarm	Description
Warm start performed, Ver: V02.00.00 - event/status summary after startup	Type of startup and the loaded firmware version.
Power supply: <ul style="list-style-type: none"> <li>L1 is connected</li> <li>L2 is not connected</li> </ul>	Status of the power supplies line 1 and line 2.
No line is monitored	Information about monitoring the power supply from the signaling system.
MSTP disabled MSTP enabled	Information on the status of the Spanning Tree protocol.
No Fault states pending after startup	Fault state following system start.

#### Status of the power supply

You enable or disable the "Power Change" event in "System > Events".

Alarm	Description
Power up on line 1 / 2 / PoE.	Power supply exists on line 1, line 2 or PoE..
Power down on line 1 / 2 / PoE.	Power supply interrupted on line 1, line 2 or PoE.

#### Status of the Ethernet interface

You enable or disable the "Link Change" event in "System > Events".

Alarm	Description
Link up on P1.	A connection exists on the Ethernet interface.
Link down on P1.	No connection exists on the Ethernet interface.

#### Status of the WLAN interface (in access point mode only)

Messages	
Link down up VAP X.Y.	The VAP interface Y on the WLAN interface X is enabled.
Link down on VAP X.Y.	The VAP interface Y on the WLAN interface X is disabled.
WDS Y at WLAN X is up.	A link exists on the WDS interface Y of WLAN interface X.

Messages	
WDS Y at WLAN X is down.	No link exists on the WDS interface Y of WLAN interface X.
Overlap-AP found on WLAN X: AP <System Name> <MAC> found on channel <channel number.> <RSSI value>	A further access point was detected on the channel set for the WLAN interface X or on a neighboring channel.
Overlap-AP aged out on WLAN X: AP <System Name> <MAC> on channel <channel number.> <RSSI value>	The overlapping access point could not be detected during the configured aging time and was removed from the "Overlap AP" list.
DFS: Radar interference detected on WLAN X at channel <channel number.> (frequency <frequency> MHz). Changing to channel <channel number> (frequency <frequency> MHz)	A primary user (e.g. radar or weather station) was detected on the channel set for WLAN interface X or on a neighboring channel. The channel will be blocked for 30 min. The access point changes to the configured alternative channel or to the next free channel on which there is no primary user.
DFS: channel <channel number> (frequency <frequency> MHz) aged out from NOL at WLAN X and can be used again.	No primary user detected on the channel any longer. The channel was removed from the list of blocked channels and can be used again
DFS: Radar interference detected on WLAN X at channel <channel number> (frequency <frequency> MHz). No more free channels to use!!	A primary user was found on all available channels. There is no free channel available, the WLAN interface X will be deactivated until one of the channels becomes available.

### Status of the WLAN interface (in client mode only)

Messages	Description
Link up on WLAN X.	The WLAN interface X is enabled.
Link down on WLAN X.	The WLAN interface X is disabled.

### Messages on configuration

Messages	Description
WBM: Authentication failure.	When logging in with Web Based Management (WBM), the wrong password was entered. The event can be enabled or disabled in "System -> Events" (authentication failure).
Telnet: Authentication failure.	When logging in via Telnet, the wrong password was entered. The event can be enabled or disabled in "System -> Events" (authentication failure).
Restart requested	Restart due to a user request. The event can be enabled or disabled in "System -> Events" (Cold/Warm Start).

### Messages about file upload or download

Messages	Description
File upload via HTTP(S): load of FileType <file type> OK → restart required	Loading the file via HTTP(S) was successful. A restart is required.
File upload via HTTP(S): load of FileType<file type> OK	Loading the file via HTTP(S) was successful.
File upload via HTTP(S): validation of FileType <file type> IDENTICAL	Loading the file via HTTP(S) was successful. The file is identical to the existing file.
File upload via HTTP(S): validation of FileType <file type> FAILED	Loading the file via HTTP(S) failed. The file contains errors or is invalid.

Messages	Description
File upload via TFTP: load of FileType <file type> OK → restart required	Loading the file using TFTP was successful. A restart is required.
File upload via TFTP: load of FileType <file type> OK	Loading the file using TFTP was successful.
File upload via TFTP: validation of FileType <file type> IDENTICAL	Loading the file using TFTP was successful. The file is identical to the existing file.
File upload via TFTP: validation of FileType <file type> FAILED	Loading the file using TFTP failed. The file contains errors or is invalid.
File upload via TFTP: file transfer of FileType <file type> FAILED	Loading the file using TFTP failed. The file name is incorrect or the file does not exist on the server.
File upload via TFTP: file transfer of FileType <file type> failed. Cannot connect to given IP address	Loading the file using TFTP failed. The TFTP server cannot be reached or the settings are incorrect.
File download via TFTP: file transfer of FileType <file type> failed. Cannot connect to given IP address	Saving the file using TFTP failed. The TFTP server cannot be reached or the settings are incorrect.

## Messages error status

Messages	Description
	You configure the events in "System > Events". You configure the monitoring of the power supply and the link on the Ethernet port in "System > Fault Monitoring".
New Fault state:<fault description> <fault description>:"Warm start performed." "Cold start performed." "Link down on P1." "Link up on P1." "Power down on line L1 (L2)" "DFS: No channels are available at WLAN2"	Incoming fault. Not all events automatically lead to a fault. On the "Events" WBM page, you specify which events will be logged, for example device restart, changed link on the Ethernet port.
Fault state gone: <fault description> <fault description>:"Warm start performed." "Cold start performed." "Link down on P1." "Link up on P1." "Power down on line L1 (L2)" "DFS: No channels are available at WLAN2" "C-PLUG not accepted. See System C-PLUG mask for details."	Outgoing fault
New Fault state (reconfiguration): <fault description> <fault description>:"Link down on P1." "Link up on P1." "Power down on line L1 (L2)"	Incoming fault. The event was triggered due to a change in the configuration.
Fault state gone (reconfiguration): <fault description> <fault description>:"Link down on P1." "Link up on P1." "Power down on line L1 (L2)"	Outgoing fault. The event was triggered due to a change in the configuration.
Fault state: <fault description> cleared. <fault description>:"Warm start performed" "Cold start performed".	Fault was acknowledged by the user.

**Messages about MSTP**

Messages	Description
	You enable or disable the "Spanning Tree" event in "System > Events"
Spanning Tree: topology change detected.	The topology of the network has changed; the network will be reorganized.
Spanning Tree: new root bridge xx:xx:xx:xx:xx:xx detected.	The topology of the network has changed; there is a new root bridge with MAC address xx:xx:xx:xx:xx:xx in the network.

**Messages about security**

Messages	Description
RADIUS: Access accepted / rejected for client <MAC>.	The authentication of the client was successful or not successful.

**Messages about message system**

Messages	Description
Syslog-Server not reachable!	The configured Syslog server is not accessible.
Unable to send messages to syslog server. Please check syslog socket configuration.	The syslog server configuration is incomplete.
Unable to send e-mail(s) because of IP connection failure.	Sending of e-mail(s) failed. SMTP server cannot be reached (e.g. network connection interrupted).
Unable to send e-mail(s) because of SMTP authentication failure.	Sending of e-mail(s) failed. Authentication of the client on the SMTP server incorrect.
Unable to send e-mail(s) because SMTP message transfer failed.	Sending of e-mail(s) failed. SMTP server can be reached, configuration incomplete or contains errors (e.g. receiver e-mail address wrong / does not exist).
SNMP: Authentication failure.	Authentication of an SNMP client failed; access not possible (e.g. SNMPv1/v2 read-only configured or Read Community String incorrectly configured).
IP communication is possible. Remote logging activated.	IP communication is possible. Remote logging is activated.
IP communication is not possible. Remote logging deactivated. Please check IP configuration and network connectivity.	IP communication is not possible. Remote logging is deactivated. Check whether or not the device has an IP address.

**Messages during system startup (PLUG)**

Alarm	Description
Startup configuration: Internal storage PLUG: Not present	There is no PLUG inserted.
Startup configuration: Internal storage PLUG: Missing PLUG: License missing	There is no PLUG inserted. There are functions configured on the device for which a license (KEY-PLUG) is required.

Alarm	Description
Startup configuration: Internal storage PLUG: Configuration not accepted PLUG: License missing	Invalid or incompatible configuration on the inserted PLUG. There are functions configured on the device for which a license (KEY-PLUG) is required.
Startup configuration: Internal storage PLUG: Factory clean → filled with internal configuration PLUG: Configuration accepted PLUG: License accepted	The internal configuration was written successfully to an empty KEY-PLUG.
Startup configuration: Internal storage PLUG: Factory clean → filled with internal configuration PLUG: Configuration accepted	The internal configuration was written successfully to an empty C-PLUG.
Startup configuration: PLUG storage PLUG: Configuration accepted PLUG: License accepted	The configuration was loaded successfully from the KEY-PLUG.
Startup configuration: PLUG storage PLUG: Configuration accepted	The configuration was loaded successfully from the C-PLUG.

## Messages about PLUG

Messages	Description
An empty PLUG was found.	There is an empty or formatted PLUG in the device.
PLUG: Filled PLUG was found. PLUG: Configuration Accepted	There is a valid PLUG with a valid configuration in the device.
PLUG: Removed at runtime.	The C-PLUG / KEY-PLUG was removed during operation.
PLUG accepted.	PLUG was accepted.

## D.2 Messages in the WLAN Authentication Log

### Messages in access point mode

Alarm	Description
Client <MAC address> <system name> associated successfully.	The client has logged in successfully on the access point.
Client <MAC address> <system name> disassociated with reason <reason description>	The client was logged off from the access point.
VAP<Num>: Client <MAC> failed to associated; status (<text>)	The connection of the client to the VAP has failed. The reason is displayed as text.
VAP<Num>: Client <MAC> disassociated with reason (<text>)	The client was successfully disconnected from the VAP. The reason is displayed as text.
VAP<Num>: Client <MAC> deauthenticated with reason (<text>)	The client was logged off from the AP. The reason is displayed as text.
VAP<number> Client <MAC> failed to authenticate; status (<status>)	The authentication of the client failed. The reason is displayed as text.
VAP<Num>: Client <MAC> failed to disassociated; status (<text>)	The connection of the client could not be terminated. The reason is displayed as text.
VAP<Num>: Client <MAC> associated successfully	The client has connected successfully to the VAP or the client has logged on successfully to the VAP.
RADIUS: Access rejected for client <MAC>	The RADIUS server denies the client access.
RADIUS: Access accepted for client <MAC>	The RADIUS server allows the client access.
WDS Connection is established to AP <MAC>	The WDS connection is successfully established to the access point.
WDS disconnect from AP <MAC>	The WDS connection to the access point is terminated.

### Messages in client mode

Alarm	Description
Associated successfully to AP <MAC address> <system name> at channel <channel number> (frequency <frequency> MHz)	The client has logged in successfully on the access point.
Disassociated from AP <MAC address> <'sys name'> with reason (Disassociated because sending STA is leaving (or has left) BSS)	The client was logged off from the access point.
Failed to authenticate to AP <MAC>; status (<Text>)	The authentication of the client with the access point failed. The reason is displayed as text.
Failed to disassociate from AP <MAC>; status (<Text>)	The connection of the client to the access point could not be terminated. The reason is displayed as text.
Failed to associate to AP <MAC>; status (<Text>)	The connection of the client to the access point has failed. The reason is displayed as text.

# Index

## A

- Access point
  - Overlapping channels, 148
  - Overview, 143
  - Overview of logged-on clients, 145
  - WDS list, 147
- AeroScout
  - Configuration, 412, 413
  - Display configuration, 168
  - Status code, 168
- Alarm events, 208
- Article number, 117
- Authentication, 226
- Available system functions, 44

## B

- Basic Wizard
  - Starting, 87
  - System configuration, 92
- Bridge priority, 66

## C

- Client
  - Available access points, 154
  - Overview, 151
- Client Supplicant, 371
- Collisions, 132
- Communications options, 367
- Configuration manuals, 423
- Configuration mode, 174
- C-PLUG, 29
  - Formatting, 254
  - Saving the configuration, 254
- CRC, 132

## D

- Data transmission speed, 283, 285
  - 802.11a/b/g, 283
  - 802.11n, 285
- DCP server, 93, 173, 336

- Default routes
  - IPv6 routes, 182
- DHCP
  - Client, 210
- DST
  - Daylight saving time, 230, 232

## E

- E-Mail function, 208
  - Alarm events, 208
  - Line monitoring, 208
- Error status, 123
- Ethernet statistics
  - Interface statistics, 129
- Event
  - Log table, 120
- Event log table, 120

## F

- Factory defaults, 422
- Factory setting, 422
- Fault monitoring
  - Connection status change, 246
- Forward Delay, 327
- Fragments, 132

## G

- Geographic coordinates, 176
- Glossary, 12
- Groups, 350

## H

- Hardware version, 117
- HTTPS
  - Server, 172

## I

- IEEE 802.11n, 24, 276
  - Channel bonding, 26
  - Frame aggregation, 27
  - Guard interval, 27

- Maximum ratio combining, 26
- MIMO, 25
- Spatial multiplexing, 26
- iFeatures
  - iREF, 56
- Information
  - ARP table, 118
  - Groups, 141
  - Inter AP blocking, 142
  - IPv6 Neighbor Table, 119
  - Log tables, 120
  - Role, 140
  - Security, 136, 139
  - SNMP, 135, 135
  - Spanning Tree, 124
  - Start page, 109
  - Versions, 115
- Inter AP blocking
  - Allowed Addresses, 394
  - Basic, 393
  - Configuration, 392
  - Information, 142
- IP address
  - Assignment with STEP 7, 76
- IP mapping, 156
- iPCF
  - Configuration, 396
  - How it works, 51
  - PROFINET communication, 51
  - Restriction, 54
- iPCF-HT
  - Configuration, 400
  - How it works, 51
- iPCF-MC
  - PROFINET communication, 51
- iPRP
  - Configuration, 408
  - Information, 171
- IPv6
  - Notation, 79
- IPv6 routing
  - Default routes, 182
  - Routing table, 133
- iREF, 56
  - Client list, 166
  - Configuration, 411
  - WDS list, 168

## J

- Jabbers, 132

## K

- KEY-PLUG, 29, 251, 255, 255
  - Formatting, 254

## L

- Layer 3, 255, 255
- Line monitoring, 208
- LLDP, 337
- Local users, 345
- Location, 176
- Log tables
  - WLAN authentication log, 122
- Logging on
  - via HTTP, 84
  - via HTTPS, 84
- Logout
  - Automatic, 242

## M

- MAC ACL, 376
  - Configuration, 376, 378
- Maintenance data, 117
- MSTP, 332
  - Port, 328
  - Port parameters, 334
- MSTP instance, 334, 334
- Multichannel configuration, 18
- Multiple Spanning Tree, 328, 332

## N

- NAPT, 62
  - Configuration, 342
- NAT, 62
  - Configuration, 340
- Negotiation, 260
- Network access, 20
- NTP
  - Client, 238

## O

- Oversize, 132
- Overview
  - Access point, 143
  - Available access points, 154
  - Clients, 151
  - Logged-on clients, 145

- Overlap APs, 148
- Overlapping channels, 148
- WDS partner, 147

## P

- Packet error statistics, 131
- Password, 352
  - Options, 354
- Ping, 257
- PLUG, 255, 255
  - C-PLUG, (C-PLUG)
  - KEY-PLUG, (KEY-PLUG)
- point-to-point, 67
- Port
  - Port configuration, 259, 262
- Port configuration, 262
- Power supply
  - Monitoring, 244
- PROFINET, 48, 247
- PROFINET IO, 48
- PST tool, 336

## R

- RADIUS, 356
- Reboot, 185
- Redundant networks, 326
- Reset, 185
- Reset device, 422
- Restore Factory Defaults, 422
- Roles, 348
- Root bridge, 66
- Routing
  - IPv6 routing table, 133
- Rule, 374, 376, 380
  - Configuration, 374, 380
  - Egress, 378, 380
  - Ingress, 376, 380
  - IP ACL, 380
  - MAC ACL, 374

## S

- Scope of the manual, 9
- Security settings, 222
- Serial number, 117
- SFTP
  - Load/save, 199
- SHA algorithm, 222
- Signal recorder, 295

- SIMATIC NET glossary, 12
- SMTP
  - Client, 173
- SNMP, 63, 93, 173, 218, 222
  - Groups, 222
  - Overview, 135
  - SNMPv1, 63
  - SNMPv2c, 63
  - SNMPv3, 63
  - Trap, 221
  - Users, 225

- Software version, 117
- Spanning Tree
  - Information, 124
  - Rapid Spanning Tree, 67
- Spectrum analyzer, 307
- SSH
  - Server, 172
- Standalone configuration, 16
- Start page, 109
- STEP 7, 336
- Subnet mask, 73
- Syslog, 243
  - Client, 173
- System
  - Configuration, 172
  - General information, 175
- System event log
  - Agent, 243
- System events
  - Configuration, 204
  - Severity filter, 206

## T

- Telnet
  - Server, 172
- TFTP
  - Load/save, 196
- Time, 173
- Time of day
  - Manual setting, 228
  - SIMATIC Time Client, 240
  - SNTP (Simple Network Time Protocol), 235
  - System time, 228
  - Time zone, 237
  - Time-of-day synchronization, 235
  - UTC time, 237
- Time setting, 173

## **U**

Undersize, 132  
User Groups, 350

## **V**

Vendor, 117  
Vendor ID, 117  
VLAN, 49  
    Port VID, 322  
    Priority, 321  
    Tag, 321

## **W**

WDS, 281  
Web Based Management, 81  
    Requirement, 81  
Wireless access, 17  
WLAN statistics  
    Bad frames, 158  
    Received frames, 163  
    Sent frames, 164