



Sending and receiving SMS with serial CP or CM and MODEM MD720

MODEM MD720, CP340, CP341, CP441-2, CM PtP,
1SI, STEP 7 V13 SP1, STEP 7 V14

<https://support.industry.siemens.com/cs/ww/en/view/25545680>

Siemens
Industry
Online
Support



Warranty and Liability

Note

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These Application Examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice.

If there are any deviations between the recommendations provided in these Application Examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document. Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of the Siemens AG.

Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks. In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions only form one element of such a concept.

Customer is responsible to prevent unauthorized access to its plants, systems, machines and networks. Systems, machines and components should only be connected to the enterprise network or the internet if and to the extent necessary and with appropriate security measures (e.g. use of firewalls and network segmentation) in place.

Additionally, Siemens' guidance on appropriate security measures should be taken into account. For more information about industrial security, please visit <http://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends to apply product updates as soon as available and to always use the latest product versions. Use of product versions that are no longer supported, and failure to apply latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under <http://www.siemens.com/industrialsecurity>.

Table of Contents

| | |
|--|-----------|
| Warranty and Liability | 2 |
| 1 Introduction | 4 |
| 1.1 Overview | 4 |
| 1.2 Mode of operation | 4 |
| 1.3 Components used | 7 |
| 2 Engineering | 10 |
| 2.1 Blocks of the Library | 10 |
| 2.2 Interface description | 12 |
| 2.2.1 FB "LMD720_SmsXxxx" | 12 |
| 2.2.2 FC "LMD720_StringToDtxx" | 14 |
| 2.2.3 PLC data type "LMD720_typeSendRcv" | 14 |
| 2.2.4 PLC data type "LMD720_typeSmsParamXx" | 15 |
| 2.2.5 PLC data type "LMD720_typeStatus" | 16 |
| 2.2.6 PLC data type "LMD720_typeStringStruct" | 16 |
| 2.3 Preparation | 17 |
| 2.3.1 Configuring the used communication module or communications processor | 17 |
| 2.3.2 Setting the baud rate of MODEM MD720 | 20 |
| 2.3.3 Connecting MODEM MD720 to the controller | 21 |
| 2.4 Integration into the user project | 22 |
| 2.4.1 Integrating library blocks in a STEP 7 V13 or STEP 7 V14 project | 22 |
| 2.4.2 Library resources and performance data | 26 |
| 2.5 Error handling | 27 |
| 3 Appendix | 30 |
| 3.1 Service and support | 30 |
| 3.2 Links and Literature | 31 |
| 3.3 Change documentation | 31 |

1 Introduction

1.1 Overview

A SIMATIC station (S7-300, S7-400 or S7-1500) is to send alarm messages, warning messages or important information on the system status autonomously via SMS to service staff or a service center using the library "LMD720". In addition, the SIMATIC station is also to receive and interpret messages.


1.2 Mode of operation

The SIMATIC station sends and receives the SMS messages via the serial CP or the serial CM and the MODEM MD720.

Schematic layout

The figure below shows all of the possible application cases of the library "LMD720" in the various SIMATIC S7 controllers with the appropriate serial communication modules/processors.

Figure 1-1



Functions

The appropriate function block "LMD720_SmsXxxx" from the library "LMD720" is used for data exchange between a SIMATIC S7-CPU and a serial communication module or a serial communication processor and the MODEM MD720.

The core functions of the "LMD720_SmsXxxx" function blocks of the library are described below:

"LMD720_SmsXxxx" function block

Initializing the MODEMs MD720 (INIT_STATE):

- Disable local echo
- Disable GPRS port read out
- Enter PIN
- Enter short message service center
- Set SMS memory
- Delete stored SMS messages from the buffer.

Note

Re-initialize MODEM MD720 after a power failure.

Sending SMS (SEND_STATE):

- Enter telephone number and text for die SMS message

Receiving SMS (POLLING_STATE):

- Read out SMS messages
- Delete stored SMS messages from the buffer

Note

Only messages with certain indices are evaluated. All other messages are deleted from the buffer (initialization) after a time out. It is not possible to browse the memory subsequently.

NOTICE

Do not send SMS messages containing the following:

- **Keyword "ERROR",**
- **Keyword "OK" or**
- **the character " _ "**

These keywords or characters cause faulty behavior when sending the message from MODEM MD720 to the communication module.

1.3 Components used

This library has been created with the following hardware and software components:

Hardware for the S7-1500 station

When you use a S7-1500 station to build this application example, the following components are required:

Table 1-1

| Component | Number | Article number | Note |
|--|--------|--|--|
| PS 25W 24VDC | 1 | 6ES7505-0KA00-0AB0 | - |
| CPU 1516-3 PN/DP | 1 | 6ES7516-3AN00-0AB0 | Alternatively, you can also employ a different S7-1500 CPU |
| CM PtP RS232 HF Alternatively: CM PtP RS232 BA | 1 | 6ES7541-1AD00-0AB0 Alternatively: 6ES7540-1AD00-0AA0 | - |

Hardware for the ET 200SP station

When you use a ET 200SP station to build this application example, the following components are required:

Table 1-2

| Component | Number | Article number | Note |
|------------------|--------|--------------------|---|
| PS 25W 24VDC | 1 | 6ES7505-0KA00-0AB0 | - |
| CPU 1516-3 PN/DP | 1 | 6ES7516-3AN00-0AB0 | Alternatively, you can also use a different S7 CPU. |
| IM 155-6 PN ST | 1 | 6ES7155-6AU00-0BN0 | Alternatively, you can use the PROFIBUS head of the ET 200SP. |
| Base Unit | 1 | 6ES7193-6BP20-0DA0 | - |
| CM PtP | 1 | 6ES7137-6AA00-0BA0 | - |
| Server module | 1 | 6ES7193-6PA00-0AA0 | - |

Hardware for the S7-300 station

When you use a S7-300 station to build this application example, the following components are required:

Table 1-3

| Component | Number | Article number | Note |
|-----------------|--------|--------------------|--|
| PS307 5A | 1 | 6ES7307-1EA01-0AA0 | - |
| CPU 315-2 PN/DP | 1 | 6ES7315-2EH14-0AB0 | Alternatively, you can also employ a different S7-300 CPU or an ET 200MP |

| Component | Number | Article number | Note |
|-----------|--------|--|------|
| CP 341 | 1 | 6ES7341-1AH01-0AE0 Alternatively: 6ES7340-1AH02-0AE0 | |

Hardware for the ET 200S station

The following components are necessary if you want to set up the example with an ET 200S station.

Table 1-4

| Component | Number | Article number | Note |
|--------------------------------------|--------|--------------------|---|
| PS307 5A | 1 | 6ES7307-1EA01-0AA0 | |
| CPU 315-2 PN/DP | 1 | 6ES7315-2EH14-0AB0 | Alternatively, you can also use a different S7 CPU. |
| Interface module IM151-3 PN STANDARD | 1 | 6ES7151-3AA23-0AB0 | Alternatively, you can also use a different head station. |
| PM-E DC24V | 1 | 6ES7138-4CA01-0AA0 | |
| ET 200S 1SI 3964/ASCII | 1 | 6ES7138-4DF01-0AB0 | |
| ET 200S, TERM.-MOD. TM-E15S24-01 | 1 | 6ES7193-4CB20-0AA0 | |
| ET 200S, TERM.-MOD. TM-P15S23-A0 | 1 | 6ES7193-4CC20-0AA0 | |

Hardware for the S7-400 station

The following components are necessary if you want to set up the example with an S7-400 station.

Table 1-5

| Component | Number | Article number | Note |
|---|--------|--|---|
| PS 407 4A | 1 | 6ES7407-0DA02-0AA0 | Alternatively, you can also use a different S7-400 power supply |
| CPU 416-3 | 1 | 6ES7416-3XR05-0AB0 | Alternatively, you can also use a different S7-400 CPU |
| CP 441-2 | 1 | 6ES7441-2AA04-0AE0 Alternatively: 6ES7441-1AA05-0AE0 | |
| IF 963, interface module RS232C, for CP 441 | 1 | 6ES7963-1AA00-0AA0 | |

GSM components

Table 1-6

| Component | Number | Article number | Note |
|--------------------|--------|--------------------|---------------|
| MODEM MD720 | 1 | 6NH9720-3AA01-0XX0 | Firmware V2.1 |
| Antenna ANT794-4MR | 1 | 6NH9860-1AA00 | |
| SIM card | 2 | | |

| Component | Number | Article number | Note |
|------------------------------|--------|----------------|---|
| SINAUT ST7, connecting cable | 1 | 6NH7701-5AN | For the station ET 200S and ET 200SP the cable should be connected as shown in Table 2-14 |
| Cell phone | 1 | | |

Software components

Table 1-7

| Component | Number | Article number | Note |
|--------------------------------|--------|--------------------|------|
| STEP 7 Professional V13 SP1 or | 1 | 6ES7822-1AA03-0YA5 | |
| STEP 7 Professional V14 | 1 | 6ES7822-1AA04-0YA5 | |

Example files and projects

This library consists of the following components:

Table 1-8

| Component | File name | Note |
|---------------------|-----------------------------------|------------------------------|
| Library Description | 25545680_SMS_MD720_LIB_V10_en.pdf | This document |
| Library | 25545680_SMS_MD720_LIB_V10.zip | Download \2\ |

2 Engineering

2.1 Blocks of the Library

The following table lists all elements of the "LMD720" library. The function blocks must each be called in a cyclic OB.

Function blocks

Table 2-1

| Function block | Description | Send and receive system function blocks used |
|----------------------|--|--|
| LMD720_SmsCMPtP | Coordinated data exchange between: <ul style="list-style-type: none"> · SIMATIC S7-1500, CM PtP communication module and MODEM MD720 or <ul style="list-style-type: none"> · SIMATIC ET 200SP, CM PtP communication module and MODEM MD720 | Send_P2P, Receive_P2P |
| LMD720_SmsCP340PtP | Coordinated data exchange between SIMATIC S7-300, CP 340 communication processor and MODEM MD720 | P_SEND, P_RCV |
| LMD720_SmsCP341PtP | Coordinated data exchange between SIMATIC S7-300, CP 341 communication processor and MODEM MD720 | P_SND_RK, P_RCV_RK |
| LMD720_SmsCP441PtP | Coordinated data exchange between SIMATIC S7-400, CP 441-2 communication processor and MODEM MD720 | BSEND, BRCV |
| LMD720_SmsET200S_1SI | Coordinated data exchange between SIMATIC DP, electronic module 1SI for ET 200S and MODEM MD720 | S_SEND, S_RCV |

Functions

Table 2-2

| Function | Description | Note |
|----------------------|--|--|
| LMD720_StringToDt300 | This function converts a character string of the "String" format with date components into the "DT" data type. | Applicable for SIMATIC S7-300: CP 340, CP 341, ET 200S 1SI |

| Function | Description | Note |
|-----------------------|---|---|
| LMD720_StringToDt400 | This function converts a character string of the "String" format with date components into the "DT" data type. | Applicable for SIMATIC S7-400: CP 441-2 |
| LMD720_StringToDt1500 | This function converts a character string of the "String" format with date components into the "DTL" data type. | Applicable for SIMATIC S7-1500: CM PtP, ET 200SP CM PtP |

PLC data types

Table 2-3

| PLC data type | Description | Note |
|-------------------------|---|--|
| LMD720_typeSendRcv | This PLC data type contains the components of an ANY pointer that are required for sending/receiving messages via the system functions. | Applicable for SIMATIC S7-300: CP 340, CP 341, ET 200S 1SI SIMATIC S7-400: CP 441-2 |
| LMD720_typeSmsParam300 | This PLC data type contains the parameters for initializing the modem and sending/receiving SMS messages. | Applicable for SIMATIC S7-300: CP 340, CP 341, ET 200S 1SI |
| LMD720_typeSmsParam400 | This PLC data type contains the parameters for initializing the modem and sending/receiving SMS messages. | Applicable for SIMATIC S7-400: CP 441-2 |
| LMD720_typeSmsParam1500 | This PLC data type contains the parameters for sending/receiving SMS messages. | Applicable for SIMATIC S7-1500: CM PtP, ET 200SP CM PtP |
| LMD720_typeStatus | This PLC data type contains the structure for the status of the function block. | Applicable for SIMATIC S7-300: CP 340, CP 341, ET 200S 1SI SIMATIC S7-400: CP 441-2 |
| LMD720_typeStringStruct | This PLC data type contains the structure of a character string. | Applicable for SIMATIC S7-300: CP 340, CP 341, ET 200S 1SI SIMATIC S7-400: CP 441-2 |

2.2 Interface description

2.2.1 FB "LMD720_SmsXxxx"

The following figure and table show the "LMD720_SmsXxxx" library blocks call interface. The call interface is identical for all function blocks of the library.

Figure 2-1




Table 2-4

| Name | | Data type | Description |
|-------|----------|---|---|
| Input | Init | Bool | Enables the initialization process. Responds only to a positive edge. |
| | sendSms | Bool | Starts the send process. Responds only to a positive edge. |
| InOut | smsParam | PLC data type "LMD720_typeSmsParamxx" (see chapter 2.2.4) | Parameters for initializing the modem and sending/receiving SMS messages. |

| | Name | Data type | Description |
|--------|-------------|-----------|---|
| Output | initialized | Bool | Set when the initialization process has been completed successfully. An SMS can only be send or received at TRUE. |
| | done | Bool | Set when the send process has been completed successfully. Only valid for one cycle. Default value: FALSE. |
| | busy | Bool | If the "LMD720_SmsXxxx" block is busy, busy=TRUE is set. The parameter "busy" is set to FALSE as soon as the process has been completed successfully or with an error. |
| | error | Bool | Gives feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE |
| | status | DWord | Returns the status to be able to localize the cause of the error if ERROR = TRUE. Only valid for one cycle (see chapter 2.5). |
| | polling | Bool | Indicates that receive buffer polling of the modem is active. |
| | ndr | Bool | Signals that an SMS message has been received. Is TRUE for one cycle only. |

Note

Make sure to back up the received data immediately after setting the "ndr" parameter.

2.2.2 FC "LMD720_StringToDttx"

This function converts a character string of the "String" format with date components into the "DT" or "DTL" data type. The function is called up in the "LMD720_SmsXxxx" function block.

The following figure and table show the call interface of the function.

Figure 2-2




Table 2-5

| Name | Data type | Description |
|-------------|---|---------------------------|
| stringInput | STRING | Date as character string |
| dateAndTime | DT (SIMATIC S7-300 and S7-400) DTL (SIMATIC S7-1500) | Returns the read in date. |

2.2.3 PLC data type "LMD720_typeSendRcv"

This PLC data type contains the components of an ANY pointer that are required for sending/receiving messages via the system functions for sending/receiving.

Figure 2-3

| LMD720_typeSendRcv | | | |
|--------------------|-------------|-----------|--|
| | Name | Data type | |
| 1 | dentifier | Byte | |
| 2 | typ | Byte | |
| 3 | number | Int | |
| 4 | dbNr | Int | |
| 5 | dataPointer | Dint | |

Table 2-6

| Name | Data type | Description |
|-------------|-----------|--|
| Identifier | Byte | Syntax ID |
| Type | Byte | Data type |
| number | Int | Repeat factor |
| dbNr | Int | DB number |
| dataPointer | Dint | Byte and bit address of the data block |

2.2.4 PLC data type "LMD720_typeSmsParamXx"

This PLC data type contains the parameters for initializing the modem and sending/receiving SMS messages. It must be created in a global data block and connected to the InOut parameters of the "LMD720_smsXxxx" FB.

Figure 2-4

| LMD720_typeSmsParam | | | |
|---------------------|-------------|---------------|-----------------|
| | Name | Data type | Default value |
| 1 | IAddr | Int | 0 |
| 2 | pinCode | String[8] | " |
| 3 | smsSCA | String[15] | " |
| 4 | phoneNumber | String[20] | " |
| 5 | smsText | String[160] | " |
| 6 | pollingTime | Time | T#30s |
| 7 | rcvData | Struct | |
| 8 | DateAndtime | Date_And_Time | DT#1990-01-01-0 |
| 9 | rcvPhoneNo | String[20] | " |
| 10 | rcvSms | String[160] | " |

Table 2-7

| Name | Data type | Description |
|-------------|-------------|--|
| IAddr | Int | SIMATIC S7-300 and ET 200S: This parameter is assigned with the first address of the input address of the communication module ("Device configuration > CP 340/ 1SI > Properties > IO addresses"). |
| conId | Word | SIMATIC S7-400: Addressing parameter ID. This information can be found in the device configuration under "Network view > Connections> PtP connection > Local ID" |
| hwID | HW_ANY | SIMATIC S7-1500: Hardware identifier of CM PtP (central at the S7-1500 or distributed as module of ET 200SP). The value of the HW identifier is available in the device configuration ("CM > Properties > HWID"). |
| pinCode | String[8] | PIN of the SIM card in the modem. |
| smsSCA | String[15] | The short message service center of your provider (enter with country code). |
| phoneNumber | String[20] | Receiver's telephone number of the device to which the SMS is to be sent (enter with country code). |
| smsText | String[160] | Content of the SMS to be sent. |
| pollingTime | Time | Timer for receive polling. Once this timer has elapsed, the polling of the received data is triggered. If this timer expires while a send operation is active, the received SMS messages will not be fetched before the next polling cycle. Start value: 30 s |

| Name | Data type | Description |
|---------|-----------|---|
| rcvData | Struct | Data received: <ul style="list-style-type: none"> Time stamp of the received SMS message Sender's telephone number Message of the receive SMS. |

2.2.5 PLC data type "LMD720_typeStatus"

This PLC data type contains the structure for the status of the function block.
Figure 2-5

| LMD720_typeStatus | | | |
|-------------------|----------|-----------|---------------|
| | Name | Data type | Default value |
| 1 | status_1 | Word | 16#0 |
| 2 | status_2 | Word | 16#0 |

Table 2-8

| Name | Data type | Description |
|----------|-----------|--|
| status_1 | Word | Shows the block that has triggered the message: 16#0000: "LMD720_SmsXxxx" function block (see Fehler! Unbekanntes Schalterargument.) 16#0001: Send system function block (see TIA Portal information system) 16#0011: Receive system function block (see TIA Portal information system) |
| status_2 | Word | Error message |

2.2.6 PLC data type "LMD720_typeStringStruct"

This PLC data type contains the structure of a character string.
Figure 2-6

| LMD720_typeStringStruct | | | |
|-------------------------|---------|-----------------------|---------------|
| | Name | Data type | Default value |
| 1 | maxChar | Byte | 16#0 |
| 2 | actChar | Byte | 16#0 |
| 3 | data | Array[1..254] of Byte | |

Table 2-9

| Name | Data type | Description |
|---------|-----------------------|---------------------------------------|
| maxChar | Byte | maximum length of the character chain |
| actChar | Byte | Current length of the character chain |
| data | Array[1..254] of Byte | Data |

2.3 Preparation

2.3.1 Configuring the used communication module or communications processor


The communication module or the communication processor must be configured as follows:


- Protocol ASCII/Freeport
- Transmission rate 9600 bps
- Parity check none
- Data bits 8
- Stop bits 1
- Data flow control none
- Character delay time until the end of telegram is recognized. 1000 ms (For S7-1500:1000 Bit times)

Configure the used communication module as described in the respective table.

S7-1500 and ET 200SP:


Table 2-10

| No. | Action |
|-----|--|
| 1. | Open your already existing STEP 7 V13 or V14 project. |
| 2. | <p>Configure the RS232 interface as shown in the figure below:</p> <p>S7-1500: "Device configuration> Device view> Double-click on CM PtP RS232> Properties> RS-232 interface".</p> <p>ET 200SP: Device Configuration > Network view > double click ET 200SP > double click CM PtP > Properties > port configuration".</p>  |

| No. | Action |
|-----|---|
| 3. | <p>Set the character delay time to 1000 Bit times, as shown in the figure below:</p>  |


S7-300 and ET 200S:

Table 2-11

| No. | Action |
|-----|--|
| 1. | Open your already existing STEP 7 V13 or V14 project. |
| 2. | <p>Configure the RS232 interface as shown in the figure below:</p> <p>S7-300: "Device Configuration > Device View > CP 340/ CP 341> Properties > Protocol> ASCII".</p> <p>ET 200S: "Device Configuration > Network view > double click ET 200S > 1 SI> Properties> Protocol".</p>  |

S7-400:


Table 2-12

| No. | Action |
|-----|---|
| 1. | Open your already existing STEP 7 V13 or V14 project. |
| 2. | <p>Configure the RS232 interface as shown in the figure below: "Device Configuration > Device View > IF 963_1 Module> Properties> Protocol"</p>  <p>The screenshot shows the 'Properties' window for the CP 441-2_1 [CP 441-2] device. The 'General' tab is selected, and the 'Protocol' section is expanded. The 'Protocol' dropdown is set to 'ASCII' and the 'Transmission rate' is set to '9600 bps'. The 'Character frame' section is also expanded, showing 'Data bits' set to '8', 'Stop bits' set to '1', and 'Parity' set to 'None'. The 'End detection of a received frame' section has three radio buttons: 'After character delay time elapses' (selected), 'On receipt of fixed number of characters', and 'On receipt of the end delimiter(s)'. Below this, the 'Character delay time' is set to '1000 ms'.</p> |

2.3.2 Setting the baud rate of MODEM MD720

Communication module and MODEM MD720 must use the same baud rate. The baud rate on the MODEM MD720 is changed using a terminal program.

Table 2-13

| No. | Action |
|-----|--|
| 1. | Connect your PC to the MODEM MD720 via the serial connecting cable. |
| 2. | Start a terminal program, for example HyperTerminal. |
| 3. | Select the appropriate COM interface to which the MODEM MD720 has been connected. |
| 4. | <p>Set the character format and baud rate to the same values as the serial interface of the MODEM MD720</p> <p>The factory settings of the MODEM MD720 are as follows: Baud rate: 19200 bits/s Character format: 8N1.</p> <p>The baud rate is changed via AT command: AT+IPR=<baud rate>. Enter this command in the terminal program and press the return key.</p>  <p>The screenshot shows a HyperTerminal window titled 'MD720-3 - HyperTerminal'. The window has a menu bar with 'File', 'Edit', 'View', 'Call', 'Transfer', and 'Help'. Below the menu bar is a toolbar with icons for file operations. The main text area contains the command 'at+ipr=9600' followed by the response 'OK' and a hyphen. At the bottom of the window, there are status indicators: 'Disconnected', 'Auto detect', 'TCP/IP', and a 'SCROLL' button.</p> |

Note The MODEM MD720 is only accessed by AT commands when it is in terminal mode. If this is not the case, reset the MODEM MD720 to factory settings (see [3](#)).

2.3.3 Connecting MODEM MD720 to the controller

Table 2-14

| No. | Action | | | | |
|---|--|---|--|---|--|
| 1. | Insert the SIM card into MODEM MD720. | | | | |
| 2. | Connect the antenna to the respective socket. | | | | |
| 3. | Connect the MODEM MD720 to a 24 V direct current source. | | | | |
| 4. | <p>S7-300, S7-400 and S7-1500: Connect the CP or the CM with MODEM MD720 using a serial connecting cable.</p> <table border="1"> <tr> <td> <p>ET 200S: Connect the serial cable to the 1SI module. Connect the other side to the MODEM MD720 (see 3).</p> </td> <td> </td> </tr> <tr> <td> <p>ET 200SP: Connect the serial cable to the CM PtP module of the ET 200SP. Connect the other side to the MODEM MD720 (see 3).</p> </td> <td> </td> </tr> </table> | <p>ET 200S: Connect the serial cable to the 1SI module. Connect the other side to the MODEM MD720 (see 3).</p> | | <p>ET 200SP: Connect the serial cable to the CM PtP module of the ET 200SP. Connect the other side to the MODEM MD720 (see 3).</p> | |
| <p>ET 200S: Connect the serial cable to the 1SI module. Connect the other side to the MODEM MD720 (see 3).</p> | | | | | |
| <p>ET 200SP: Connect the serial cable to the CM PtP module of the ET 200SP. Connect the other side to the MODEM MD720 (see 3).</p> | | | | | |



Note When installing the components, please always consider the general installation guidelines.

2.4 Integration into the user project

2.4.1 Integrating library blocks in a STEP 7 V13 or STEP 7 V14 project



In order that the functions of the "LMD720_SmsXxxx" function block can be used, it is necessary to integrate the library "LMD720" into the configuration software first:

Table 2-15



| No. | Action |
|-----|---|
| 1. | The library is available on the HTML page from which you downloaded this document (see https://support.industry.siemens.com/cs/ww/en/view/25545680). Save the library "25545680_SMS_MD720_LIB_V10.zip" to your hard drive. |
| 2. | Unzip the library. |
| 3. | Open an already existing STEP 7 V13 or V14 project. |
| 4. | <p>In the "Global Libraries" palette, click on "Open global library" in the toolbar.</p>  |
| 5. | <p>Select the global library "LMD720_V13.al13" for your STEP7 V13 project or "LMD720_V14.al14" for your STEP7 V14 project.</p>  |

Below, you will find the steps describing how to integrate the “LMD720” library blocks into your STEP 7 V13 or V14 project. Subsequently, you can use the blocks of library.

Table 2-16

| No. | Action |
|-----|---|
| 1. | <p>Use drag the "LMD720_SmsXxxx" block from the "Types" folder into the "Program blocks" folder of your device. The related "StringToDt_XX" function and PLC data types are added to the respective automatically.</p>  |
| 2. | <p>In the “Program blocks” folder of your device, open the organization block OB1 and use drag and drop to move the function block to any network.</p> |
| 3. | <p>Enter the name and number of the associated instance data block. Click “OK” to exit the dialog box.</p>  |

| No. | Action | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------|--|---------------------------|--|--|--|------|-----------|---|--------|--|---|----------|---------------------------|---|---------|------|---|------------|------|---|----------------|------|---|---------|------|---|---------|------|---|----------|------|---|-----------|-------|----|------------|------|----|--------|------|
| 4. | <p>Create a new global data block with the PLC data type "LMD720_typeSmsParamxx" and the tags for calling the FB in OB1. Save your configuration settings.</p> <table border="1"> <thead> <tr> <th colspan="3">SmsParamDB</th> </tr> <tr> <th></th> <th>Name</th> <th>Data type</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Static</td> <td></td> </tr> <tr> <td>2</td> <td>smsParam</td> <td>"LMD720_typeSmsParam1500"</td> </tr> <tr> <td>3</td> <td>initOB1</td> <td>Bool</td> </tr> <tr> <td>4</td> <td>sendSmsOB1</td> <td>Bool</td> </tr> <tr> <td>5</td> <td>initializedOB1</td> <td>Bool</td> </tr> <tr> <td>6</td> <td>doneOB1</td> <td>Bool</td> </tr> <tr> <td>7</td> <td>busyOB1</td> <td>Bool</td> </tr> <tr> <td>8</td> <td>errorOB1</td> <td>Bool</td> </tr> <tr> <td>9</td> <td>statusOB1</td> <td>DWord</td> </tr> <tr> <td>10</td> <td>pollingOB1</td> <td>Bool</td> </tr> <tr> <td>11</td> <td>ndrOB1</td> <td>Bool</td> </tr> </tbody> </table> <p>Note: The description of the parameters of "LMD720_typeSmsParamxx" can be found in chapter 2.2.4.</p> | SmsParamDB | | | | Name | Data type | 1 | Static | | 2 | smsParam | "LMD720_typeSmsParam1500" | 3 | initOB1 | Bool | 4 | sendSmsOB1 | Bool | 5 | initializedOB1 | Bool | 6 | doneOB1 | Bool | 7 | busyOB1 | Bool | 8 | errorOB1 | Bool | 9 | statusOB1 | DWord | 10 | pollingOB1 | Bool | 11 | ndrOB1 | Bool |
| SmsParamDB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Name | Data type | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Static | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | smsParam | "LMD720_typeSmsParam1500" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | initOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | sendSmsOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | initializedOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | doneOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | busyOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | errorOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | statusOB1 | DWord | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | pollingOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | ndrOB1 | Bool | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5. | <p>Assign values to all necessary parameters. The values are taken from the previously created data block.</p> <p>The diagram shows a function block (FB1) named "LMD720_SmsCMPtP" with the following connections:</p> <ul style="list-style-type: none"> EN (Enable) is connected to ENO (Enable Out). init (Bool) is connected to initOB1 (Bool) from %DB2.DBX414.0 ("SmsParamDB"). sendSms (Bool) is connected to sendSmsOB1 (Bool) from %DB2.DBX414.1 ("SmsParamDB"). smsParam (DWord) is connected to smsParam (DWord) from PIB2.DBX0.0 ("SmsParamDB"). initialized (Bool) is connected to initializedOB1 (Bool) from %DB2.DBX414.2 ("SmsParamDB"). done (Bool) is connected to doneOB1 (Bool) from %DB2.DBX414.3 ("SmsParamDB"). busy (Bool) is connected to busyOB1 (Bool) from %DB2.DBX414.4 ("SmsParamDB"). error (Bool) is connected to errorOB1 (Bool) from %DB2.DBX414.5 ("SmsParamDB"). status (DWord) is connected to statusOB1 (DWord) from %DB2.DB416 ("SmsParamDB"). polling (Bool) is connected to pollingOB1 (Bool) from %DB2.DBX420.0 ("SmsParamDB"). ndr (Bool) is connected to ndrOB1 (Bool) from %DB2.DBX420.1 ("SmsParamDB"). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Action |
|-----|--|
| 6. | <p>Compile the hardware and software of the S7 station.</p>  |
| 7. | <p>Connect the Ethernet interface of the PC with the PN/IE interface of the CPU and download the project into your controller.</p>  |
| 8. | <p>Set the "init" parameter. If "initialized"=TRUE, then set the "sendSms" parameter to send the SMS message.</p> |

2.4.2 Library resources and performance data

Memory requirements

The following table shows the size of the library blocks in the main memory.

Table 2-17

| Block | Main memory (bytes) | Load memory (bytes) |
|-----------------------|---------------------|---------------------|
| LMD720_SmsCMPtP | 7197 | 86363 |
| LMD720_SmsCP340PtP | 14602 | 16100 |
| LMD720_SmsCP341PtP | 14530 | 16154 |
| LMD720_SmsCP441PtP | 14662 | 16000 |
| LMD720_SmsET200S_1SI | 14522 | 15998 |
| LMD720_StringToDt300 | 1820 | 1936 |
| LMD720_StringToDt400 | 1820 | 1936 |
| LMD720_StringToDt1500 | 668 | 9679 |

Transfer time without an additional user program in OB1

The following table shows the average times measured for initializing the MODEM MD720 and sending an SMS message.

Table 2-18

| Function | Average time |
|----------------|----------------|
| Initialization | up to 3 min. |
| Sending SMS | approx. 7 sec. |

2.5 Error handling

The FB "LMD720_SmsXxxx" function block has a "status" output for error diagnostics. By reading the "status" output of the function block, you are provided with information on logical errors and error messages that may occur during communication.

The error message structure is such that the first word indicates the block that triggered this message. (see [Table 2-19](#))

Table 2-19

| status_1 | Description |
|----------|---|
| 16#0000 | "LMD720_SmsXxxx" function block |
| 16#0001 | Send system function block (see TIA Portal information system: Program blocks > System blocks > Select send block > Press F1) |
| 16#0011 | Receive system function block (see TIA Portal information system: Program blocks > System blocks > Select receive block > Press F1) |

The table below provides a list of possible error messages created by the library function blocks.

Table 2-20

| status_2 | Error description | Solution |
|----------|---|--|
| 16#8101 | Initialization: The watchdog timer has expired during modem initialization because the communication between controller and modem is interrupted during initialization. | <ol style="list-style-type: none"> 1. Check cable between controller and modem. 2. Check CM/CP settings and change, if required, as described in chapter 2.3.1. 3. Set the modem baud rate as described in chapter 2.3.2. 4. Restart initialization. |
| 16#8102 | Initialization, sending SMS: Previous order not yet completed. You have started a new operation, although "busy" was still active. | Restart initialization. |
| 16#8103 | Sending SMS: The modem must be initialized. This error occurs when the modem has not been initialized and you have started a send process. | Restart initialization. |
| 16#8104 | Sending SMS: The watchdog timer has expired during the send procedure because the communication between controller and modem is interrupted during sending. | <ol style="list-style-type: none"> 1. Check cable between controller and modem. 2. Restart the send procedure. |

| status_2 | Error description | Solution |
|----------|---|---|
| 16#8105 | <p>Polling: The watchdog timer has expired during polling. This may have the following causes:</p> <ul style="list-style-type: none"> · Communication between the controller and the modem is interrupted. · Many SMS messages are stored in the buffer. · An SMS with unknown index cannot be read. <p>Note: Only messages with certain indices are evaluated. All other messages are deleted from the buffer (initialization) after a time out – It is not possible to browse the memory subsequently.</p> | <ol style="list-style-type: none"> 1. Check cable between controller and modem. 2. If required, change the "statTimerCheckPollingPT" time in the instance DB of "LMD720_SmsXxx". 3. Restart initialization. |
| 16#8106 | <p>Initialization: Error when disabling echo.</p> | Restart initialization. |
| 16#8107 | <p>Initialization: Error when enabling the parameterization mode.</p> | Restart initialization. |
| 16#8108 | <p>Initialization: Error when querying the remote configuration port.</p> | Restart initialization. |
| 16#8109 | <p>Initialization: Error when disabling reading the remote configuration port.</p> | Restart initialization. |
| 16#8110 | <p>Initialization: Error when disabling the parameterization mode.</p> | Restart initialization. |
| 16#8111 | <p>Initialization: Error during PIN query: SIM card faulty / disabled or not inserted.</p> | <ol style="list-style-type: none"> 1. Insert the SIM card into the modem. 2. Restart initialization. |
| 16#8112 | <p>Initialization: Error during PIN query: The modem is waiting for the PUK entry.</p> | <ol style="list-style-type: none"> 1. Insert the SIM card into a normal cell phone. 2. Enter the PUK and then a PIN. 3. Check and change the "pinCode" parameter. 4. Restart initialization. <p>Note: As an alternative to steps 1 and 2, you can enter the PUK via a terminal program with the command: AT+CPIN= <PUK>, <PIN></p> |

| status_2 | Error description | Solution |
|----------|--|---|
| 16#8113 | Initialization: Incorrect PIN | 1. Check and change the "pinCode" parameter. 2. Restart initialization. |
| 16#8114 | Initialization, sending SMS, polling: Error during parameterization. | 1. Check the antenna cable. 2. Restart initialization. |
| 16#8115 | Initialization: Syntax error when entering the short message service center. | 1. Check and change "smsSCA" parameter. 2. Restart initialization. |
| 16#8116 | Initialization, polling: Error when selecting the SMS memory. | Restart initialization. |
| 16#8117 | Initialization: Error when transferring the SMS indicators. | Restart initialization. |
| 16#8118 | Initialization, polling: Error when deleting SMS messages. | Restart initialization. |
| 16#8119 | Sending SMS: Syntax error when entering the telephone number. | 1. Check and change "phoneNumber" parameter 2. Restart the send procedure. |
| 16#8120 | Sending SMS: Error while sending the SMS message. This may have the following causes: <ul style="list-style-type: none"> · Short message service center address is incorrect. · Telephone number of the recipient is incorrect. | 1. Check "smsSCA" parameter and change, if required. 2. Check "phoneNumber" parameter and change, if required. 3. Restart initialization. 4. Restart the send procedure. |
| 16#8121 | Polling: Error while reading the SMS message. | Restart initialization |

Note During the initialization of MODEM MD720 with the "LMD720_SmsXxxx" block, all SMS messages stored in the buffer will be deleted.

NOTE During the first initialization of MODEM MD720 with the "LMD720_SmsXxxx" block, the error 0011_81E2 occurs. In this case, please initialize the MODEM MD720 again.

3 Appendix

3.1 Service and support

Industry Online Support

Do you have any questions or need support?

Siemens Industry Online Support offers access to our entire service and support know-how as well as to our services.

Siemens Industry Online Support is the central address for information on our products, solutions and services.

Product information, manuals, downloads, FAQs and application examples – all information is accessible with just a few mouse clicks at

<https://support.industry.siemens.com>

Technical Support

Siemens Industry's Technical Support offers quick and competent support regarding all technical queries with numerous tailor-made offers – from basic support right up to individual support contracts.

Please address your requests to the Technical Support via the web form:

www.siemens.com/industry/supportrequest

Service offer

Our service offer comprises, among other things, the following services:

- Product Training
- Plant Data Services
- Spare Parts Services
- Repair Services
- On Site and Maintenance Services
- Retrofit & Modernization Services
- Service Programs and Agreements

Detailed information on our service offer is available in the Service Catalog:

<https://support.industry.siemens.com/cs/sc>

Industry Online Support app

Thanks to the "Siemens Industry Online Support" app, you will get optimum support even when you are on the move. The app is available for Apple iOS, Android and Windows Phone:

<https://support.industry.siemens.com/cs/ww/en/sc/2067>

3.2 Links and Literature

Table 3-1

| No. | Topic |
|------|--|
| \1\ | Siemens Industry Online Support https://support.industry.siemens.com |
| \2\ | Link to this entry page of this application example https://support.industry.siemens.com/cs/ww/en/view/25545680 |
| \3\ | Manual on MD720 https://support.industry.siemens.com/cs/ww/en/view/73513752 |
| \4\ | SIMATIC S7-300 Establishing and parameterizing point-to-point connection CP 340 http://support.automation.siemens.com/WW/view/en/1137332 |
| \5\ | SIMATIC CP 340 first steps to commissioning http://support.automation.siemens.com/WW/view/en/12108826 |
| \6\ | SIMATIC S7-300 Establishing and parameterizing point-to-point connection CP 341 http://support.automation.siemens.com/WW/view/en/1117397 |
| \7\ | CP 341 first steps to commissioning http://support.automation.siemens.com/WW/view/en/1188622 |
| \8\ | Establishing and parameterizing point-to-point connection CP 441 http://support.automation.siemens.com/WW/view/en/1137419 |
| \9\ | CP 441 First Steps http://support.automation.siemens.com/WW/view/en/1188835 |
| \10\ | SIMATIC ET 200S serial interface modules http://support.automation.siemens.com/WW/view/en/9260793 |
| \11\ | CM PtP Configurations for Point-to-Point Connections http://support.automation.siemens.com/WW/view/en/59057093 |
| \12\ | SIMATIC S7-1500 CM PtP RS232 BA http://support.automation.siemens.com/WW/view/en/59057152 |
| \13\ | SIMATIC S7-1500 CM PtP RS232 HF http://support.automation.siemens.com/WW/view/en/59057160 |
| \14\ | CM PtP operation with PROFINET http://support.automation.siemens.com/WW/view/en/68075812 |
| \15\ | SIMATIC S7-1500, ET 200MP, ET 200SP, ET 200AL, ET 200pro Communication http://support.automation.siemens.com/WW/view/en/59192925 |
| \16\ | SIMATIC ET 200SP CM Freeport/3964 http://support.automation.siemens.com/WW/view/en/59061378 |

3.3 Change documentation

Table 3-2

| Version | Date | Modifications |
|---------|---------|---------------|
| V1.0 | 08/2017 | First version |
| | | |