# **SIEMENS**

# **SIMATIC**

Bus links DP/PA coupler, active field distributors, DP/PA Link and Y Link

**Operating Instructions** 

Preface	
Product Overview	1
Description of the components	2
Active field distributor AFDiS in hazardous areas	3
Application planning	4
Mounting	5
Connecting	6
Commissioning: DP/PA coupler	7
Commissioning: DP/PA link	8
Commissioning: Y link	9
Operation of the DP/PA-Link and Y-Link	10
Maintenance and service	11
Functions	12
Interrupt, error and system messages	13
Technical specifications	14
Appendix	Α

### Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

### **A** DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.

# **A** WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.

# **A** CAUTION

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

#### **CAUTION**

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

#### NOTICE

indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### **Qualified Personnel**

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

#### ▲ WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

#### **Trademarks**

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### **Disclaimer of Liability**

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# **Preface**

### Purpose of the operating instructions

These operating instructions provide important information to configure, mount, wire, and commission the DP/PA coupler, the active field distributors AFD, AFS and AFDiS and the DP/PA link and Y link bus links.

# Basic knowledge required

To understand these operating instructions you should have general experience in the field of automation engineering.

When using the AFDiS you should be familiar with the fundamentals of explosion protection, the identification of explosion-protected equipment and the regulations regarding explosion protection.

# Range of validity of these operating instructions

These operating instructions apply for the following products:

- IM 153-2: 6ES7153-2BA02-0XB0
- IM 153-2 (Outdoor): 6ES7153-2BA82-0XB0
- DP/PA coupler FDC 157-0: 6ES7157-0AC83-0XA0
- DP/PA coupler Ex [i]: 6ES7157-0AD82-0XA0
- Y coupler: 6ES7197-1LB00-0XA0
- Bus modules
  - BM PS/IM: 6ES7195-7HA00-0XA0
  - BM PS/IM SIPLUS extreme: 6AG1195-7HA00-2XA0
  - BM IM/IM: 6ES7195-7HD10-0XA0
  - BM IM/IM (Outdoor): 6ES7195-7HD80-0XA0
  - BM FDC: 6ES7195-7HF80-0XA0
  - BM FDC/FDC (redundant): 6ES7195-7HG80-0XA0
  - BM Y coupler: 6ES7654-7HY00-0XA0

- Active field distributors
  - AFD (Active Field Distributors) product version 02: 6ES7157-0AF81-0XA0
  - AFS (Active Field Splitters), product version 02: 6ES7157-0AF82-0XA0
  - AFDiS (Active Field Distributor intrinsic safety): 6ES7157-0AG83-0XA0

These operating instructions contain a description of the components that was valid at the time the operating instructions were published. We reserve the right to include product information with information updates with new components and components with a new product status.

# Changes compared to the previous version

The following changes have been made to these operating instructions compared to the previous version (10/2006 edition):

- New: Active field distributor AFDiS for use in hazardous areas
- Integration of the product information 09/2008 and 11/2009

# Configuring with STEP 7

The DP/PA coupler FDC 157-0 can be configured with *STEP 7* from V5.3 SP3 and HSP0095 or optionally with SIMATIC PCS 7 V7.0 or higher for diagnostic purposes.

### Position in the overall information structure

Depending on the hardware used you require the following manuals in addition to these operating instructions:

- The manual for the implemented DP master, including the following special information:
  - Configuring and commissioning of a DP master system
  - Description of the DP master
- The manual SIMATIC NET, PROFIBUS network manual (http://support.automation.siemens.com/WW/view/en/35222591)
- The operating instructionsSIMATIC S7-300 CPU 31xC and CPU 31x: Installation (http://support.automation.siemens.com/WW/view/en/36305386)
- The manual Automation Systems S7-300, ET 200M Ex I/O modules (<a href="http://support.automation.siemens.com/WW/view/en/1096709">http://support.automation.siemens.com/WW/view/en/1096709</a>), including in particular information on the topics intrinsic safety and explosion protection.
- System manual Principles of Explosion Protection (http://support.automation.siemens.com/WW/view/en/12521844)

More information on explosion protection can be found in the corresponding directives and standards.

# Sign posts

These operating instructions are subdivided into the following subjects:

- Product overview and description of the components
- Install, connect and commission
- Operation and diagnostics
- Technical specifications
- Appendices
- Important terms are explained in the glossary.
- The index helps you to quickly find all texts relevant to your keyword.

# Recycling and disposal

The described components are ecologically compatible, and thus suitable for recycling. For environmentally sound recycling and disposal of your old devices please contact a certified disposal service company for electronic scrap.

# Additional support

If you have any questions relating to the products described in these operating instructions and do not find the answers in this document, please contact your local Siemens representative (http://www.siemens.com/automation/partners).

A guide to the technical documentation for the various SIMATIC products and systems is available on the Internet. (http://www.siemens.com/simatic-docu).

The online catalog and order system is available on the Internet (http://www.siemens.com/automation/mall).

### Training center

Siemens offers a series of courses that will help you getting started with the components and the SIMATIC S7 automation system. Please contact your regional training center or the central training center in D-90327, Nuremberg, Germany (http://www.siemens.com/sitrain).

### **Technical support**

You can contact Technical Support for all Industry Automation products by means of the Internet Web form for the Support Request.

(http://www.siemens.com/automation/csi\_en\_WW/support\_request)

Additional information on our technical support is available on the Internet (http://www.siemens.com/automation/csi\_en\_WW/service).

# Service & Support on the Internet

In addition to our documentation, we offer a comprehensive knowledge base on the Internet (http://www.siemens.com/automation/csi\_en\_WW/support).

There you will find:

- Our Newsletter, which constantly provides you with the latest information about your products.
- The documents you require, via our service & support search facility.
- Worldwide forum in which users and experts exchange ideas.
- Your local contact for Automation & Drives from our contact database.
- Information about on-site service, repairs, spare parts, and much more.

# Table of contents

	Preface	<b>9</b>	3
1	Product Overview		13
	1.1	Bus links	13
	1.2 1.2.1 1.2.2 1.2.3 1.2.4	Integration in the automation environment What are distributed I/O devices? DP/PA coupler FDC 157-0 with active field distributors DP/PA coupler / DP/PA Ex [i] coupler. DP/PA link	16 18 18
	1.2.5	Y link	20
2	Descrip	otion of the components	21
	2.1	DP/PA coupler FDC 157-0	21
	2.2	DP/PA coupler / DP/PA Ex [i] coupler	23
	2.3	Y coupler	24
	2.4 2.4.1 2.4.2 2.4.3	IM 153-2  Routing of frames of the slave initiative  Improved link behavior during commissioning  Which devices can be operated behind the Y Link?	25 26
	2.5	DP/PA link	27
	2.6	Y link	30
	2.7	Active field splitter (AFS)	32
	2.8	Active field distributor (AFD)	33
	2.9	Active field distributor AFDiS	34
	2.10	Compatibility with predecessor modules	37
3	Active f	field distributor AFDiS in hazardous areas	39
	3.1	Fundamentals of hazardous areas and intrinsic safety	39
	3.2	Configuration with AFDiS	42
	3.3	Mounting AFDiS	43
	3.4	Grounding	44
	3.5	Safety instructions for connection	46
	3.6	Connecting PROFIBUS PA to the AFDIS	50
	3.7	Grounding AFDiS	53
	3.8	AFDiS maintenance and cleaning	54
	3.9	Replacing/supplementing the AFDiS	56

4	Applicat	ion planning	57
	4.1 4.1.1 4.1.2 4.1.3 4.1.3.1 4.1.3.2 4.1.3.3 4.1.3.4 4.1.3.5 4.2 4.2.1	Installation variants with the DP/PA coupler FDC 157-0  Configuration variants  DP/PA coupler in non-redundancy mode  DP/PA coupler in redundancy mode  Ring redundancy with active field distributor (AFD)  Coupler redundancy with active field splitter (AFS)  Redundancy mode of the DP/PA coupler in the DP/PA link  Redundancy mode of the DP/PA coupler in the redundant DP/PA link  Combination of non-redundant and redundant DP/PA couplers  Installation variants with the IM 153-2  Configuration variants	57 58 59 62 64 66 68
	4.2.2	Detecting the configuration variant by means of the IM 153-2	
5	Mountin	Mounting	
	5.1	Mounting rules	73
	5.2 5.2.1 5.2.2 5.2.3	Mounting the DP/PA coupler  Mounting DP/PA coupler for non-redundant mode  Mounting the DP/PA coupler for redundancy mode  Swapping DP/PA couplers FDC 157-0	75 76
	5.3 5.3.1	Installing the active field distributor AFD and active field splitter AFS	
	5.4 5.4.1 5.4.2	Mounting the DP/PA link	79
	5.5	Mounting the Y link	83
	5.6	Setting the PROFIBUS address of the IM 153-2	85
6	Connecting		
	6.1 6.1.1 6.1.2 6.1.3 6.1.4	Electrical isolation and grounding General Rules and Regulations for Operation Grounding the active field distributor AFD / AFS Operating with grounded supply Operation with ungrounded reference potential	88 90 90
	6.2 6.2.1 6.2.2 6.2.2.1 6.2.2.2 6.2.3 6.2.3.1 6.2.3.2	Connecting DP/PA couplers Wiring the DP/PA coupler for stand-alone mode Connecting DP/PA couplers for ring redundancy Connections for ring redundancy Connecting the PROFIBUS PA to the active field distributor (AFD) Connecting DP/PA couplers for coupler redundancy Connections for coupler redundancy Connecting the PROFIBUS PA to the active field splitter (AFS)	93 94 95 98
	6.3 6.3.1 6.3.2	Connecting the DP/PA link	102
	6.4	Connecting Y link	104
	6.5	Connecting the power supply	105

	6.6	Connecting PROFIBUS DP	106
	6.7	Connecting PROFIBUS PA on the DP/PA coupler	107
7	Commis	ssioning: DP/PA coupler	111
	7.1	Commissioning the DP/PA coupler for stand-alone mode	111
	7.2	Commissioning the DP/PA coupler FDC 157-0	111
	7.3	Configuration with a GSD file	114
	7.4	Configuring with STEP 7	115
	7.5	DP/PA coupler FDC 157-0 in the redundant DP/PA link	117
	7.6	Parameters for diagnostic selection of the DP/PA coupler FDC 157-0	118
	7.7	Setting the PROFIBUS address and redundancy mode	119
8	Commis	ssioning: DP/PA link	121
	8.1	Commissioning DP/PA link	121
	8.2	Configuring for S7 standard or redundant mode	122
	8.2.1 8.2.2	Configuring DP/PA link Configuring the PROFIBUS PA master system	
	8.3	Configuring for DP standard master mode	
	6.3 8.3.1	GSD files	
	8.3.2	Configuring DP/PA link	126
	8.3.3	How to configure PROFIBUS PA field devices	
9	Commis	ssioning: Y link	129
	9.1	Commissioning Y link	129
	9.2	Configuring for the redundancy mode	130
	9.2.1	How to configure Y link	
	9.2.2	Configuring underlying DP slaves	
	9.3 9.3.1	Configuring for DP standard master mode	
	9.3.1	How to configure Y link	
	9.3.3	Configuring underlying DP slaves	136
10	Operation	on of the DP/PA-Link and Y-Link	139
	10.1	Start-up delay	139
	10.2	Behavior after certain events in the redundancy mode	140
	10.3	Startup characteristics	141
	10.3.1	Startup characteristics of the DP/PA link in non-redundant mode	
	10.3.2	Startup characteristics in redundancy mode	
	10.4	CP 342-5 behind a Y link in a redundant DP master system	143

11	Maintena	ance and service	145
	11.1	Replacing IM 153-2 or Y couplers	145
	11.2	Replacing DP/PA couplers	146
	11.3	Replacing the active field distributor AFD / AFS	147
	11.4	Firmware update	148
	11.4.1	When should you update the IM 153-2?	
	11.4.2	Update of the IM 153-2	
	11.5	Maintenance	
12	Function	s	153
	12.1	IM 153-2	
	12.1.1	Time synchronization on the underlying master system	
	12.1.2	Redundancy with IM 153-2	
	12.1.3 12.1.4	Reading and writing data records	
	12.1.4	System modification during operation.	
	12.1.5.1		
		System modification in redundancy mode	
	12.2	DP/PA coupler FDC 157-0	163
	12.2.1	Reading and writing the identification and maintenance data (I&M data)	
	12.2.2	Reading the local LifeList	
	12.2.3	Read out of the current value and voltage value	
	12.2.3.1	· · · · · · · · · · · · · · · · · · ·	
	12.2.3.2		
	12.2.4 12.2.5	Data records  Diagnostic record 62	
	12.2.6	Address space of the inputs	
13		, error and system messages	
-	13.1	Diagnostics by means of LED displays	
	13.1.1	The LED displays of the IM 153-2	
	13.1.2	LED displays of the DP/PA coupler FDC 157-0	
	13.1.3	LED displays of the DP/PA coupler	
	13.1.4	LED displays of the Y coupler	
	13.1.5	LED displays of the AFD	
	13.1.6	LED displays of the active field splitter (AFS)	
	13.1.7	LED displays of the active field distributor AFDiS	
	13.2	Diagnostics with STEP 7: IM 153-2	
	13.2.1 13.2.2	Structure of slave diagnostics	
	13.2.2	Structure of the diagnostic blocks	
		Default diagnosis	
		Identifier-related diagnostics	
	13.2.3.3	Module status	189
		Status message	
		H status	
	13.2.3.6	Interrupts	196

	13.2.4	Example of a diagnosis in redundant mode	
		Task specification	
		Solution with STEP 7	
	13.2.4.3	Evaluating the diagnostics data	201
	13.3	Diagnostics with STEP 7: DP/PA coupler FDC 157-0	204
	13.3.1	Structure of slave diagnostics	204
	13.3.2	Structure of the diagnostic blocks	205
	13.3.2.1	Station statuses 1 to 3	205
		Master PROFIBUS address	
		Manufacturer ID	
		PA status	
		Identifier-related diagnostics	
		Module status	
		Local LifeList	
		PA redundancy status	
		Channel-related diagnostics	
	13.3.2.10		
14	Technica	al specifications	215
	14.1	General technical data	215
	14.1.1	Standards and Approvals	215
	14.1.2	Standards and approvals of DP/PA Ex [i] coupler(6ES7157-0AD82-0XA0)	219
	14.1.3	Standards and approvals of the active field distributors (AFD) and active field splitters (AFS)	221
	14.1.4	Standards and approvals of active field distributor AFDiS	
	14.1.5	Use in zone 2 potentially explosive areas	
	14.1.6	Electromagnetic compatibility	
	14.1.7	Shipping and storage conditions	
	14.1.8	Mechanical and climatic ambient conditions for operation	
	14.1.9	Specifications for insulation tests, protection class and degree of protection	230
	14.1.10	Rated voltage	230
	14.2	Technical specifications of the IM 153-2 (6ES7153-2BAx2-0XB0)	231
	14.3	Technical data DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)	232
	14.4	Technical specifications of DP/PA coupler Ex [i] (6ES7157-0AD82-0XA0)	234
	14.5	Technical specifications Y coupler (6ES7197-1LB00-0XA0)	235
	14.6	Technical data - active field splitter (AFS) (6ES7157-0AF82-0XA0)	236
	14.7	Technical data - active field distributor (AFD) (6ES7157-0AF81-0XA0)	237
	14.8	Technical specifications of active field distributor AFDiS (6ES7157-0AG83-0XA0)	238
A	Appendi	x	241
	A.1	Dimension drawings	
	A.1.1	Active field distributor AFD/AFS	
	A.1.2	Active field distributor AFDiS	243
	A.2	Order numbers	245
	A.2.1	Components of the bus links	245
	A.2.2	Accessories for PROFIBUS DP	246
	Δ23	Accessories for PROFIBILS PA	247

A.3	Basics about PROFIBUS PA	248
A.3.1	Intrinsic safety	249
A.3.2	Field device supply via PROFIBUS PA	
	Configuration of PROFIBUS PA with the DP/PA link bus coupler	
A.3.4	Line and star-type topology	252
Glossary		
Index		263

Product Overview

# 1.1 Bus links

# DP/PA coupler

The DP/PA coupler is the physical link between PROFIBUS DP and PROFIBUS PA. In stand-alone operation it offers the possibility of addressing PA field devices via PROFIBUS DP. No other components are required for this.

The DP/PA coupler is also used for more advanced coupling tasks in the DP/PA link.

The DP/PA coupler Ex [i] is available for connecting PA field devices in explosion protected environments.

# DP/PA coupler FDC 157-0

The DP/PA coupler FDC 157-0, FDC stands for "Field Device Coupler" has PROFIBUS-DP diagnostic functions as DP slave.

Using a DP/PA coupler pair and field distributors enables redundant operation on an equipotential bonding line in 2 variants:

- Coupler redundancy with the active field splitter AFS
- · Ring redundancy with active field distributors AFD and AFDiS.

The DP/PA coupler FDC 157-0 can be used stand-alone or in the DP/PA link in this regard

# Active field distributors

Active field distributors distribute the PROFIBUS PA via spur lines to the PA field devices. You can connect up to 31 PA field devices to the active field distributors depending on the version, e.g. measuring instruments, sensors and actuators.

- AFS (Active Field Splitter): Connection of up to 31 PA field devices
- AFD (Active Field Distributor): Connection of up to 4 PA field devices
- AFDiS (Active Field Distributor): Connection of up to 6 PA field devices, use in hazardous areas is possible.

The active field distributors are suitable for the extended temperature range.

1.2 Integration in the automation environment

### DP/PA link

The DP/PA link consists of one or two IM 153-2 interface modules, and one to five DP/PA couplers that are either connected with one another via passive bus couplers or via bus modules.

The DP/PA link creates a network transition from a PROFIBUS DP master system to PROFIBUS PA. In this case the two bus systems are non-interacting through the IM 153-2 both physically (galvanically) and in terms of protocols and time.

By using two IM 153-2 interface modules, the entire lower-level PROFIBUS PA master system can be connected to a redundant DP master system of an S7-400H as switched peripherals. For this purpose installation is always executed with bus modules.

# Y link

The Y link comprises two IM 153-2 interface modules and a Y coupler that are connected to one another via bus modules.

The Y link creates a network transition from the redundant DP master system of an S7-400H to a non-redundant DP master system. This means that devices with only one PROFIBUS DP interface can be connected to a S7-400H as switched peripherals.

# 1.2 Integration in the automation environment

### 1.2.1 What are distributed I/O devices?

# Distributed I/O Devices - Field of Application

When a system is configured, the I/Os from and/or to the process are often integrated centrally in the automation system.

In the case of greater distances of the inputs and outputs from the automation system the wiring may be very extensive and confusing. Electromagnetic interference may be impair reliability.

Distributed I/O is suitable for use with systems of this kind.

- The PROFIBUS DP master is located in a central position.
- The distributed I/O devices (inputs and outputs) work at their decentral locations.
- With its high transmission speeds the high power PROFIBUS DP ensures that the control system CPU and the distributed I/O devices communicate smoothly.

# What is PROFIBUS DP?

PROFIBUS DP is an open bus system conforming to IEC 61784-1:2002 Ed1 CP 3/1 with the "DP" transmission protocol (DP stands for distributed I/O).

Physically PROFIBUS°DP is implemented either as an electrical network based on shielded twisted-pair cables, or as an optical network based on fiber optic cable.

The "DP" transmission protocol facilitates very fast cyclical data exchange between the control system CPU and the distributed I/O devices.

### What is PROFIBUS PA?

PROFIBUS PA is the communication-compatible extension of PROFIBUS DP to include a transmission technology that also permits applications in potentially explosive areas. Transmission from PROFIBUS PA conforms to the international IEC 61784-1:2002 Ed1 CP 3/2 standard.

PROFIBUS PA enables transducers and control devices in potentially explosive areas to communicate with the automation system over long distances. With the PROFIBUS PA the field devices can be fed via the data lead at the same time.

The following components are available for the transition of the transmission technology of PROFIBUS DP (IEC 61784-1:2002 Ed1 CP 3/1) to PROFIBUS PA (IEC 61784-1:2002 Ed1 CP 3/2):

- DP/PA coupler in stand-alone mode
- DP/PA link

# 1.2.2 DP/PA coupler FDC 157-0 with active field distributors

# DP/PA coupler FDC 157-0 with active field distributors

The DP/PA coupler FDC 157-0 with diagnostics function is a transition between PROFIBUS DP and PROFIBUS PA. Active field distributors combine the field devices with the main line and ensure a rugged field distribution.

Using a DP/PA coupler pair and field distributors also enables redundant operation on an equipotential bonding line in the following variants:

- Coupler redundancy with the active field splitter AFS
- Ring redundancy with a maximum 8 active field distributors (AFD)
- Ring redundancy with a maximum of 5 active field distributors with mixed use of AFD and AFDiS




Figure 1-1 Integration of the DP/PA coupler FDC 157-0 in the system environment

# DP/PA coupler FDC 157-0 with AFDiS

Up to 5 active field distributors AFDiS can be mounted in the hazardous area zone 1/21. You can connect intrinsically safe PA field devices, which may be located in Zone 0/20, to the AFDiS.




Figure 1-2 DP/PA coupler FDC 157-0 with AFDiS

1.2 Integration in the automation environment

# 1.2.3 DP/PA coupler / DP/PA Ex [i] coupler

# DP/PA coupler

The DP/PA coupler is a transition between PROFIBUS DP and PROFIBUS PA to which the PA field devices are connected. The following figure shows how the DP/PA coupler is integrated into the system.




Figure 1-3 Integration of the DP/PA coupler within the system environment

# 1.2.4 DP/PA link

# DP/PA link

In relation to higher level systems (towards the automation device) the DP/PA link is a DP slave and it is a DP master in relation to lower level systems. The following figure shows how the DP/PA link is integrated into the system.




Figure 1-4 Integration of the DP/PA coupler within the system environment

1.2 Integration in the automation environment

# 1.2.5 Y link

# Y link

In relation to higher level systems (towards the automation device) the Y link is a DP slave and it is a DP master in relation to lower level systems. The following figure shows how the Y link is integrated into the system.




Figure 1-5 Integration of the Y link within the system environment

Description of the components

# 2.1 DP/PA coupler FDC 157-0

# **Applications**

The DP/PA coupler FDC 157-0 is designed for the following applications:

- Non-redundant operation:
  - Stand-alone operation without additional components
  - Replacement for the DP/PA coupler with order number 6E7157-0AC82-0XA0
  - Operation in the DP/PA link on a simple DP master system or with two interface modules IM 153-2, for example on an S7-400H
- Redundant operation:
  - Ring redundancy when using the active field distributor AFD or AFDiS
  - Coupler redundancy when using the AFS
  - Operation in the DP/PA link on a simple DP master system or with two interface modules IM 153-2, for example on an S7-400H

### **Availability**

- Increased availability through ring redundancy and coupler redundancy
- Automatic isolation of defective partial segments including automatic bus terminator
- Repair and extension of the bus segment is possible in during operation

# Commissioning

 Simplified commissioning through extended diagnostic possibilities and automatic bus terminator.

### 2.1 DP/PA coupler FDC 157-0

# **Properties**

The DP/PA coupler FDC 157-0 is designed for the following applications:

- Electrical isolation between PROFIBUS DP and PROFIBUS PA
- Implementation of the transmission physics between RS 485 and symmetric bus physics in accordance with IEC IEC 61784-1:2002 Ed1 CP 3/2
- DP slave: adjustable PROFIBUS address 1 to 125 via DIL switch
- Diagnostics via LED displays
- Diagnostics function via PROFIBUS DP:
  - Current value or voltage value as user data
  - Local LifeList
  - Wire-break/short circuit
- Selection of the redundancy mode via DIL switch
- Transmission rate of 45.45 kBaud to PROFIBUS DP
- Transmission rate to 31.25 kBaud on PROFIBUS PA
- Integrated supply unit for PROFIBUS PA
- Integrated bus terminator for PROFIBUS PA
- Extended environmental conditions

# Configuration

The DP/PA coupler FDC 157-0 can be used as a stand-alone device on all DP masters that support 45.45 kBaud.

Configuration of the DP/PA coupler FDC 157-0 as a DP slave is necessary in the following situations:

- If the diagnostic functions will be effective.
- If you want to operate the DP/PA couplers with ring redundancy or coupler redundancy.

#### Note

If you use the IM 153-2 together with the DP/PA couplers as DP/PA link, in this case the PROFIBUS DP connections to the DP/PA couplers are not required. The IM 153-2 and the DP/PA couplers are connected via the S7 backplane bus.

# 2.2 DP/PA coupler / DP/PA Ex [i] coupler

### **Application**

The DP/PA coupler is intended for the following applications:

- Stand-alone operation without any other components
- Operation in the DP/PA link on a simple DP master system or on an S7-400H

### **Properties**

The DP/PA coupler has the following characteristics:

- Electrical isolation between PROFIBUS DP and PROFIBUS PA
- Implementation of the physical transmission system between RS 485 and synchroner the synchronous bus system conforming to IEC 61784-1:2002 Ed1 CP 3/2
- Diagnostics via LEDs
- Transmission rate of 45.45 kBaud to PROFIBUS DP
- Transmission rate of 31.25 kBaud to PROFIBUS PA
- Integrated supply unit for PROFIBUS PA
- Integrated bus terminator for PROFIBUS PA
- Extended environmental conditions

# Special features of the DP/PA Ex [i] coupler

The DP/PA Ex [i] coupler has the following additional characteristics:

- As a PROFIBUS node you can use the Ex [i] DP/PA coupler of device category 3G in zone 2-type potentially explosive areas.
- Intrinsic safety for the underlying PROFIBUS PA
- Integrated intrinsically safe supply unit for PROFIBUS PA interface and integrated barrier
- DP/PA Ex [i] coupler (6ES7157-0AD81-0XA0):

You may connect intrinsically safe electrical apparatus of the device category 1G, 2G and 3G for the Zone 0, 1 and 2 to the intrinsically safe PROFIBUS PA.

DP/PA Ex [i] coupler (6ES7157-0AD82-0XA0):

You may connect intrinsically safe electrical apparatus of the device category 1G, 2G and 3G for the Zone 0, 1 and 2 as well as of device category 1D, 2D and 3D for the zone 20, 21 and 22 to the intrinsically safe PROFIBUS PA.

### 2.3 Y coupler

# Configuration

The DP/PA coupler can be used as a stand-alone device on all DP masters that support 45.45 kBaud.

It is not necessary to configure the DP/PA coupler. You only have to set the transmission speed for the relevant DP at 45.45 kBaud and configure and parameterize the PA field devices.

#### Note

If you use the IM 153-2 together with the DP/PA couplers as a DP/PA link, the PROFIBUS DP connections to the DP/PA couplers are not required. The IM 153-2 and the DP/PA coupler are connected via the S7 back plane bus.

# 2.3 Y coupler

# **Application**

The Y coupler is only determined for operation in the Y link on a redundant DP master system, for example on an S7-400H

It is not possible to operate the Y coupler without IM 153-2.

### **Properties**

- Connection of DP standard slaves
- Transmission speeds ranging from 45.45 kBaud to 12 MBaud
- Potential isolation between IM 153-2 and the underlying PROFIBUS DP
- Power is supplied to the Y coupler via the backplane bus.

# Configuration

The Y coupler is an integral part of the Y link and is not configured separately.

# 2.4 IM 153-2

# **Application**

The IM 153-2 is intended for the following applications:

- Operation in the DP/PA link
  - link on a non-redundant DP master system
  - Operation on a redundant DP master system, for example on an S7-400H
- Operation in the Y link on a redundant DP master system, for example on an S7-400H

# **Properties**

- Any transmission speed between 9.6 kBaud to 12 MBaud for the higher-level DP master system
- Diagnostics via LEDs and the user program
- Bumpless switchover of active channel in redundancy mode
- Support of system modifications during operation, both in S7 standard mode and in redundancy mode.
- Depending on the higher level DP master it can be operated as DPV0 or DP V1 slave.
- Routing of frames of the slave initiative
- Improved link behavior during commissioning

# 2.4.1 Routing of frames of the slave initiative

The IM 153-2BAx2 support routing of frames of the slave initiative. In so doing, the frames of devices are passed behind the link to the higher-level controller.

This routing can be used, for example, to operate SINAMICS drives behind the Y Link if the trace function is being used with the STARTER commissioning tool.

# 2.4.2 Improved link behavior during commissioning

### Starting situation

The IM 153-2BAx2 interface modules are installed in one link and should be operated redundantly in an H System (e.g., SIMATIC S7-400H).

### Behavior of IM 153-2BAx2

If the IM 153-2BAx2 detects a redundancy partner that is not ready to be switched to or if there are no lower-level slaves, the interface module stops sending continuous diagnostic messages.

This behavior can also be implemented for the following interface modules by means of a firmware update:

- IM 157 (6ES7157-0AA82-0XA0)
- IM 153-2 (6ES7153-2BAx1-0XB0)

This "new" behavior of the IM 153-2BAx2 is not available for redundancy mode in accordance with the standard.

# 2.4.3 Which devices can be operated behind the Y Link?

Slaves at the lower-level DP master system cannot be operated in DPV1 mode unless they have been integrated and configured with GSD rev. ≥ 5.

The GSD must contain the following entries:

- Prm\_Block\_Structure\_supp=1
- PrmCmd\_supp=1
- Slave\_Redundancy\_supp=1

STEP 7 checks these entries during configuration.

If these entries are not found, the slave is then operated in DPV0 mode.

# 2.5 DP/PA link

# **Application**

The DP/PA link is intended for the following applications:

- S7 standard mode on S7-300 or S7-400
- Redundancy mode, for example on S7-400H
- DP standard master mode

The following information applies in part to both the S7 standard mode and the DP standard master mode. In such cases the term "non-redundancy mode" is used.

### Operating principle

- The DP/PA link is slave on the higher level DP master system and acts as a proxy for the nodes connected to the lower-level bus system (PA field devices).
- The DP/PA link forms an independent lower-level bus system that is decoupled from the higher level DP master system in terms of communication.
- The use of several DP/PA couplers serves to increase the current carrying capacity and availability of the PA master system.
- Together with the connected PA field devices all the DP/PA couplers of a DP/PA link forma single common bus system.

### Configuration options

A DP master system can be extended by means of DP/PA links in the following way:

- The number of DP/PA links on a DP master system is limited by the maximum number of bus nodes, which is 126.
- Up to five DP/PA couplers can be operated in each DP/PA link. Y couplers cannot be operated in the DP/PA link.
- The number of nodes in each PA master system is limited to 64. The total number of slots in each case is limited to (236 minus number of PA field devices).
- The configuration frame and the user data frame of the DP/PA link are both derived from the frame contents of the lower-level PA field devices.
- The maximum length of the frames for configuration data, parameter assignment data, diagnostics data and I/O data is 244 bytes in each case.
- Cascading of the DP/PA links is **not** permitted.

PA field devices on the lower-level PA master system are only operated in the DPV1 mode if they are suitable for bumpless switching when there is a modification of the system during operation.

STEP 7 identifies their suitability from an entry in the Device Data Base File (DDBF) of the PA field device

PrmCmd\_supp=1

If this entry is not to be found, the PA field device is operated in the DPV0 mode.

Furthermore, the Slave\_Redundancy\_supp=1 entry requirement must be met.

# Configuration

The DP/PA link can be configured with STEP 7 V5.4 and later.

# Parameter assignment for the PA field devices

The PA field device parameters are assigned by means of a suitable tool such as SIMATIC PDM SIMATIC PDM, from a PD / PC that is connected to the higher level PROFIBUS DP. For more detailed information please refer to the documentation of your parameter assignment tool.

### User data of the DP/PA link

The DP user data frame of the DP/PA link depends on the number of configured PA field devices. It comprises the data blocks of the configured PA field devices arranged one after the other. The data blocks are sorted in ascending order according to PA address.

According to *PROFIBUS PA Profile for Process Control Devices, General Requirements* each process variable is accompanied by one status byte that contains a statement about the status of the process variable.

In the case of failure on the part of one PA device, first of all the relevant input data, including the status byte in the user data frame of the DP/PA, are reset. Then the corresponding information is entered into the diagnostic frame.

When the PA field device is restored, the corresponding information is entered in the diagnostic frame. Virtually simultaneously the valid input data of the PA field device in the user data frame of the DP/PA link are again available. The status byte displays the valid data.

#### Note

To obtain the state of the PA field devices as quickly as possible, it is advisable to generally evaluate the status byte in the user program.

The Avanced Process Library automatically takes this into account with SIMATIC PCS 7.

# Update times of the process image for single and redundant mode

Both in single and redundant mode, the update time of the process image in the module is determined by the following times:

- Update time of the lower-level bus system (PROFIBUS PA)
- Internal update time of the module

The update time of the lower-level bus system depends on the configuration (baud rate, number of slaves and the number of I/O data). It is determined by the TargetRotationTime Ttr. In STEP 7 the Ttr is hereby calculated and specified.

In single mode, the internal processing of the process image is also included. This is 15 ms.

• Update time = 15 ms + Ttr

In redundant mode, three or four times the Ttr must also be expected, in addition to the time for detecting a PrmCMD of 30 ms (includes internal update time).

- Update time without configuration change (CFC) = 30 ms + 3\* Ttr
- Update time without configuration change (CFC) = 30 ms + 4\* Ttr

# Switchover time to PROFIBUS PA during redundancy mode

When there is a master-standby switchover or the active IM 153-2 fails, the PA field devices are processed via the standby IM 153-2.

Switchover is bumpless, that is the states of the I/Os are retained during switchover.

Switchover time is defined as the time between activating the standby IM and availability of new input data.

Condition / Requirement	Switchover time
Switchover time with unchanged PA	typically: 70 ms + number of PA field devices x 51 ms
configuration	max.: 820 ms + number of PA field devices x 50 ms
Switchover time if configuration is	typically: 80 ms + number of PA field devices x 67 ms *
changed during mode	max.: 800 ms + number of PA field devices x 130 ms *
* with unchanged PA field device address	ses

# Communication links from the PD / PC to the PA field devices

Up to 10 communication links to PA field devices can be set up simultaneously from a PD / PC via the DP/PA link.

During redundancy mode all the communication links from the PD / PC to the PA field devices remain intact when the active channel is switched over from one IM 153-2 to the other.

# 2.6 Y link

# **Application**

The Y link is intended for the redundancy mode, for example on S7-400H.

# Operating principle

- The Y link is slave on the higher level DP master system and acts as a proxy for the nodes connected on the underlying bus system (DP slaves).
- The Y link forms an independent underlying bus system that is decoupled from the higher level DP master system in terms of communication.

# Configuration options and limitations

A redundant DP master system can be extended by means of Y links in the following way:

- The number of Y links on an S7-400H is only limited by the maximum number of bus nodes, which is 126.
- Only one Y coupler can be operated in each Y link. DP/PA couplers cannot be operated
  in the Y link.
- The number of nodes in each DP master system is limited to 64. The total number of slots in each case is limited to (236 minus number of PA field devices).
- The configuration frame and the user data frame of the Y link are both derived from the frame contents of the lower level slaves.
- The maximum length of the frames for configuration data, parameter assignment data, diagnostics data and I/O data is 244 bytes in each case.
- Cascading of the Y links is not permitted.
- Direct data exchange and synchronism are not feasible in the underlying DP master system.

Slaves on the underlying DP master system are only operated in the DPV1 mode if they are suitable for bumpless switching when there is a modification of the system during operation.

STEP 7 identifies their suitability from an entry in the DDBF file of the slave:

PrmCmd\_supp=1

If this entry is not to be found, the slave is operated in the DPV0 mode.

Furthermore, the Slave\_Redundancy\_supp=1 entry requirement must be met.

# Configuration

The Y link can be configured with STEP 7V5.4 and later.

When *STEP 7* calculates the bus parameters, the connected nodes on the underlying DP master system as well as the Y link itself are taken into account.

# Parameter assignment for the DP slave

S7-400H assigns the parameters for the DP slaves in the underlying DP master system via the Y link.

### User data of the Y link

The DP user data frame of the Y link depends on the number of configured DP slaves. It comprises the data blocks of the configured DP slaves arranged one after the other. The data blocks are sorted in ascending order according to DP address.

If a DP slave fails, the relevant input data in the user data frame of the Y link are reset first. Then the corresponding information is entered into the diagnostic frame.

When the DP slave is restored, the corresponding information is entered in the diagnostic frame. Virtually simultaneously the valid input data of the DP slave in the user data frame of the Y link are again available.

# Diagnostics data of the DP slaves

The processing of diagnostic frames from DP slaves depends on whether the IM 153-2 is operated as a DPV0 slave or as a DPV1 slave.

With *STEP 7* the diagnostics frames of the underlying DP slaves can be displayed in the online view of HW Config.

### Communication links from the PD / PC to the DP slaves

Up to 10 communication links to DP slaves can be set up simultaneously from a PD / PC via the DP/PA link.

Communication links can only be passed on from the S7-400H to the underlying DP master system.

All the communication links from the PD / PC to the DP slaves remain intact when the active channel is switched over from one IM 153-2 to the other.

### See also

Identifier-related diagnostics (Page 187)

# 2.7 Active field splitter (AFS)

# Active field splitter (AFS)

The active field splitter (AFS) connects two DP/PA couplers FDC 157-0 with a PROFIBUS PA line. Thus it enables operation of **coupler redundancy** on the equipotential bonding line. The total number of PA field devices on the equipotential bonding line is 31 devices and it is limited by 1 A maximum current.

### **NOTICE**

Only use the active field splitter AFS with downstream field distributors AFD / AFDiS!

### **Functions**

· Automatic switchover of the PA main line to the active DP/PA coupler

### **Properties**

- 2 cable glands M12 for the PROFIBUS PA main line
- 1 cable gland M12 for the PROFIBUS PA line
- Optional: Center feed via a cable bushing
- Connection of the PROFIBUS PA main lines with screw-type terminals
- Reverse polarity protection connections
- · Connection of maximum 31 PA field devices
- Diagnostics via LEDs
- Power supply via the PA bus
- Screw gland on substrate
- IP65 degree of protection
- · Grounding terminal outside

### See also

Coupler redundancy with active field splitter (AFS) (Page 62)

Screwing down the active field distributor AFD and active field splitter AFS on substrate (Page 78)

Connecting the PROFIBUS PA to the active field splitter (AFS) (Page 99)

# 2.8 Active field distributor (AFD)

# Active field distributor (AFD)

PA field devices, e.g. measuring instruments, sensors and actuators, can be connected to the active field distributor (AFD).

In conjunction with 2 DP/PA couplers FDC 157-0 the active field distributor (AFD) enables operation of **ring redundancy**. You can use the following field distributors in a PA segment:

- Up to 8 field distributors when exclusively using AFD
- Up to 5 field distributor with mixed use of AFD and AFDiS

The total number of PA field devices on the equipotential bonding line is 31 devices and it is limited by a maximum of 60 A per spur line.

### **Functions**

- Connection of field devices for PROFIBUS PA in line or ring topology
- Automatic bus termination
- Isolation of defective PA segments
- Connection of isolated PA segments after fault rectification
- Extending a PA segment during operation
- Short-circuit-proof spur lines

# **Properties**

- 2 cable glands M12 for the PA main line
- 4 cable glands M12 for up to 4 PA field devices
- Connection of the PROFIBUS PA main line and the PA spur lines via screw-type terminals
- Reverse polarity protection connections
- Diagnostics via LED displays
- Power supply via the PA bus
- · Screw gland on substrate
- IP65 degree of protection
- Grounding terminal outside

### See also

Ring redundancy with active field distributor (AFD) (Page 59)

Screwing down the active field distributor AFD and active field splitter AFS on substrate (Page 78)


# 2.9 Active field distributor AFDiS

# Active Field Distributor AFDiS (Active Field Distributor intrinsic Safety)

The active field distributor AFDiS is an item of electrical equipment for Zone 1. Intrinsicallysafe PA field devices, e.g. measuring instruments, sensors and actuators, can be connected to the intrinsically-safe connections.

In conjunction with 2 DP/PA couplers FDC 157-0, the active field distributor (AFD) enables operation of **ring redundancy**. You can use the following field distributors in a PA segment:

- Up to 8 field distributors when exclusively using AFD
- Up to 5 field distributor with mixed use of AFD and AFDiS



# 1 LED displays

- 2 Ground terminals
- 3 Cable glands for the PA spur lines S1 to S6
- 4 Cable glands for the PA main line T1, T2

# Special properties of the AFDiS

### **CAUTION**

### Impairment of function of the field devices

Make sure that the field devices connected via the AFDiS comply with standard IEC 61158-2: 2007, Edition 4.0. Note the technical specifications in the manufacturer's documentation.

The AFDiS has the following additional properties:

- The AFDiS can be used in the device category 2G/2D in the hazardous area Zone 1/21.
- The intrinsically safe PA field devices of device categories 1G, 2G, 3G for the Zones 0, 1 and 2 as well as device categories 1D, 2D, 3D for the Zones 20, 21 and 22 may be connected to the intrinsically safe connections.
- The first spur line connection S1 can be operated optionally as a spur line or as a subsegment with a length of up to 500 m.
- The number of PA field devices on the equipotential bonding line is limited to 31 devices and to maximum 1 x 60 mA (on spur line S1) and 5 x 40 mA per spur line.

### **Functions**

- Connection of field devices for PROFIBUS PA in line or ring topology
- Automatic bus termination
- Isolation of defective PA segments
- Connection of isolated PA segments after fault rectification
- Extending a PA segment during operation
- FISCO field barrier with electrical isolation between main and spur lines
- Short-circuit-proof, intrinsically safe spur lines with bounce protection

### **Properties**

- 2 cable glands M16 for the PA main line
- 6 cable glands M16 for up to 6 PA field devices
- Connection of the PROFIBUS PA main line and the PA spur lines via screw-type terminals
- Reverse polarity protection connections
- Diagnostics via LED displays
- Power supply via the PA bus
- Screw gland on substrate
- Direct grounding via connection bar inside
- Degree of protection IP66
- Grounding terminals outside

# Integrated repeater function of the AFDiS

The AFDiS has an integrated repeater function:

- Length of the PA spur lines in accordance with IEC 61158-2 up to 120 m, in accordance with IEC/EN 60079-27 (FISCO) 60 m, irrespective of the number of field devices connected to the segment via spur lines (> 1 m).
- Length of the PROFIBUS PA main line up to 1900 m, without taking into account the sum of the spur lines, because these are to be considered separately from the main line via the repeater. This enables significantly greater network spans than in the case of devices without a repeater function.
- Electrical isolation and bi-directional signal reproduction ensure reaction-free transmission between PA main lines and spur lines. This will significantly increase the segment's resistance to faults.

# 2.10 Compatibility with predecessor modules

# Compatibility DP/PA coupler FDC 157-0:

The DP/PA coupler FDC 157-0 with order number 6E7157-0AC8**3**-0XA0 replaces the DP/PA coupler with order number 6E7157-0AC8**2**-0XA0. The bus module does not need to be replaced.

On the DP/PA coupler FDC 157-0 the PROFIBUS address is factory set to 0. Thus the diagnostic function is deactivated, the DP/PA coupler is transparent. This means that it is compatible to the predecessor module as a replacement part. Configuration is not required.

#### Note

#### **Diagnostics function**

If you would like to use the diagnostic function of the DP/PA coupler FDC 157-0 in existing systems as well, then set the PROFIBUS address on the DP/PA coupler and in the configuration > 0.

#### Note

#### Redundancy mode

If you would like to use the DP/PA coupler FDC 157-0 with ring redundancy or coupler redundancy, then you must use the BM FDC/FDC (redundant) bus module.

#### Bus module BM FDC/FDC (redundant)

The bus module BM FDC (redundant) with order number 6ES7195-7HG80-0XA0 can only be used together with the DP/PA coupler FDC 157-0 with order number 6ES7157-0AC83-0XA0.

## Compatibility of the IM 153-2 and the IM 157

You can find information on compatible versions of interface modules IM 153-2 and IM 157 on the Internet (http://support.automation.siemens.com/WW/view/en/23372259).

#### Compatibility of the Y coupler

Der Y coupler 6ES7197-1LB00-0XA0 **cannot** be used as a spare part for Y coupler 6ES7654-0YK00-0AB0.

## Compatibility of the bus modules

The bus module BM IM/IM 6ES7195-**7HD80**-0XA0 can only be used together with the following interface modules:

- IM 153-2BAx1-0XB0
- IM 153-2BAx2-0XB0
- IM 157-0AA82-0XA0

It can **not** be used as a spare part for 6ES7195-**7HE80**-0XA0.

2.10 Compatibility with predecessor modules

Active field distributor AFDiS in hazardous areas

# 3.1 Fundamentals of hazardous areas and intrinsic safety

# Properties of zones

Hazardous areas are classified into zones. The zones are distinguished according to the probability of the existence of an explosive atmosphere.

The active field distributor AFDiS can be used in hazardous areas up to Zone 1/21.

You can connect intrinsically safe PA field devices, which may be located in Zone 0/20, to the AFDiS. The PA field devices must be certified for operation in the corresponding hazardous areas.

You will find an overview of the zone divisions in the following table:

Table 3- 1 Classification of zones

Hazardous areas	Explosion hazard	Example
Zone 0/ 20	Long-term, frequent or permanent presence of explosive gas or dust atmosphere	Within containers.
Zone 1/ 21	Infrequent presence of potentially explosive gas or dust atmosphere	In the area of openings for filling and emptying.
Zone 2/ 22	Rare or short-term presence of potentially explosive gas or dust atmosphere	Areas bordering on zone 1/21

For additional information, refer to the Principles of Explosion Protection (http://support.automation.siemens.com/WW/view/en/12521844) system manual.

# Design types of protection on AFDiS


The types of protection include design and electrical measures relating to the equipment to achieve explosion protection in the hazardous areas. The following types of protection can be used for AFDiS:

Table 3- 2 Types of protection

Type of protection	Meaning	Representation
Intrinsic safety i	All voltages, currents, inductance and capacitance occurring are limited by electrical measures (intrinsically safe) - sparks or thermal effects capable of causing ignition cannot occur.  The spur line connections of AFDiS are designed to be intrinsically safe [ia].	
Increased-safety enclosure e	The enclosure and the main line terminals of the AFDiS have the <i>increased safety</i> Ex e type of protection.  This type of protection has additional features that provide an increased degree of safety against the occurrence of high temperatures, sparks and arcover.	
Encapsulation "m"	The internal electronics of the AFDiS are embedded in a casting compound. This means that an explosive atmosphere surrounding the equipment can be ignited neither by sparks nor by unacceptable heating.	4

## Marking of the AFDiS

Equipment for operation in hazardous areas is marked with an identifier indicating the hazardous environments in which the equipment can be used. The AFDiS has the following safety measures:



#### Certifications of the active field distributor AFDiS

The EC type-examination certificate and EC certificates of conformity for the active field distributor AFDiS can be found on the Internet

(http://www.siemens.com/automation/csi en WW/support) at Service & Support.

# Verification of intrinsic safety

The active field distributor limits the energy in hazardous areas on the spur line to the intrinsically safe PA field devices and electrically isolates them from the PA main line.

All spur lines have Ex [ia] type of protection and can therefore be installed in Zone 0/20. In addition to the following requirements, no further verification of the intrinsic safety in accordance with the FISCO model is required:

- PROFIBUS PA bus cable (6XV1830-5AH10) for the PA main lines and for the spur lines to the intrinsically-safe PA field devices
- Maximum spur line length 60 m or subsegment line length of 500 m at connection S1

# 3.2 Configuration with AFDiS

#### Introduction

The active field distributor AFDiS is designed for hazardous areas. It supplies up to six spur lines or five spur lines and a subsegment with a length of up to 500 meters. The subsegment is supplied with 60 mA for max. 6 devices.

To achieve the maximum availability for each port, connect only one device to each port.

# Active field distributor AFDiS with subsegment in hazardous areas

The following graphic shows an example of the configuration of a DP/PA system with several field distributors. The subsegment of an AFDiS with its connected devices extends into Zone 0. To prevent signal reflections, the subsegment must be terminated with a bus terminating resistor.




Figure 3-1 AFDiS with subsegment in hazardous areas

# 3.3 Mounting AFDiS

## Safety information



#### Explosion hazard in Zone 21 / 22

During mounting, observe the guidelines according to EN 60079-14.

When you mount the AFDiS in areas with dust (Zone 21, Zone 22), you must also observe EN 61241-14.



## **Explosion hazard**

Under some circumstances, sparks capable of ignition or unacceptable surface temperatures can occur during installation.

Never install when an explosive atmosphere is present!



Risk of injury due to high weight of the AFDiS

The weight of the AFDiS is 4.5 kg. During mounting, hold the device firmly in your hand.

## Mounting position

Mount the active field distributor AFDiS preferably with the connections facing downward.

#### **CAUTION**

### Damage to property

A tensile load on the screws is not permitted. Implement a fixed installation for the cable inlet.

## Requirement

- The substrate must be level, with load-bearing capacity, and it must be vibration free.
- Select appropriate fixing accessories for the substrate.
- Space of at least 60 mm below the modules for the connections of the PA main lines and spur lines.

#### 3.4 Grounding

### **Tools required**

- 2 fixing screws M8; dowels depending on the substrate
- Screwdriver suitable for the screws used

# **Mounting AFDiS**

Screw the lower part of the enclosure tightly to the substrate with two fixing screws. The torque depends on the fixing screws used. You can find the drill hole spacing on the back of the enclosure base.

#### Additional information

Important information can be found in the chapter *Mounting work in hazardous areas* in the System Manual Principles of Explosion Protection (http://support.automation.siemens.com/WW/view/en/12521844).

#### See also

Screwing down the active field distributor AFD and active field splitter AFS on substrate (Page 78)

# 3.4 Grounding

### Equipotential bonding EB

You must set up an equipotential bonding EB in hazardous areas. This should be in accordance with IEC 60079-14.

Shields of the PROFIBUS PA bus lines must be connected to the equipotential bonding EB.

The best EMC protection is achieved with direct grounding for the AFDiS active field distributor.

#### **Direct grounding**

The shield of the PROFIBUS PA bus cables is grounded directly in both the hazardous area and in the safe area. This is possible if the equipotential bonding EB ranges from the DP/PA couplers (in the safe area) to the field devices (in hazardous areas), i.e. if a corresponding equipotential bonding conductor was installed.

#### Note

# Direct grounding on the field distributor AFDiS

The braided shield of the PROFIBUS PA cable must be lead through under the shield clamps.

# Example of direct grounding




Figure 3-2 Example: Direct grounding

## See also

Principles of Explosion Protection

(http://support.automation.siemens.com/WW/view/en/12521844)

profibus.com (http://www.profibus.com)

# 3.5 Safety instructions for connection

## Safety information

# **DANGER**

When laying cables and wiring, make sure that you adhere to the installation regulations in accordance with EN 60079-14 and any regulations specific to your country.

Information on how to install the PROFIBUS PA can be found in the "Technical Guideline PROFIBUS PA, User and Installation Guideline". Available from PROFIBUS Nutzerorganisation e. V.

# DANGER

#### **Explosion hazard**

Ignitable sparks may be generated during connection.

Therefore use a non-magnetic screwdriver when connecting the cables!

# DANGER

#### **Explosion hazard**

A tensile load on the screws of AFDiS can impair the degree of protection and is not permitted.

Implement a fixed Installation for inlet of the cable!

# DANGER

#### **Explosion hazard**

In mixed operation with AFD, always disconnect the DP/PA couplers from the power supply before you replace active field distributors AFDiS.



### WARNING

#### Risk for intrinsic safety

If the wrong connection is made on the AFDiS (PA main line <--> spur lines) or the cables are incorrectly connected to the PA field devices, the intrinsic safety is put at risk:

Only connect Ex i circuits (intrinsically-safe PA field devices) to the spur lines!

Check the wiring to the PA field devices.

#### IP30 cover

The connections of the PA main cables inside the enclosure of the AFDiS are sealed with an IP30 cover. Opening the IP30 cover switches off the voltage supply to the terminals and the feed lines.

Depending on the zone in which the AFDiS is located, you are permitted to open the IP30 cover during operation for a visual inspection.




Figure 3-3 AFDiS with IP30 covers

# DANGER

#### **Explosion hazard**

In the potentially explosive area **Zone 1** you are not permitted to open the IP30 cover during operation.

Before opening the IP30 cover, disconnect the voltage supply to the relevant DP/PA couplers.

In the potentially explosive area **Zone 2**, you are permitted to open the IP30 cover during operation.

## Zone 1: Disconnecting the main line / connecting the main line to AFDiS



# **Explosion hazard**

In the potentially explosive area **Zone 1** it is not permitted to disconnect the main line to an AFDiS during operation.

Prior to starting work, disconnect the voltage supply to the DP/PA coupler(s).

## 3.5 Safety instructions for connection

## Zone 2: Disconnecting the main line / connecting the main line to AFDiS

# DANGER

## **Explosion hazard**

In the potentially explosive area **Zone 2**, you are not permitted to disconnect the main line to an AFDiS during operation if it is **directly** connected to a DP/PA coupler or an AFS.

Prior to starting work, disconnect the voltage supply to the DP/PA coupler(s).

In hazardous area **Zone 2**, it is permissible to disconnect a main line to a AFDiS during operation if you have connected 2 AFDiS.


#### Note


## Labelling the AFDiS


In your plant, label the field distributors AFDiS which are directly connected to the DP/PA coupler or AFS.

# Rules for connecting the cables

The following examples illustrate the rules which you must observe when connecting main lines:







The following applies to all configurations:

Zone 2: Connection of the cables (3) is possible during operation.

For mixed operation with AFD: Disconnect FDC from the power supply.

The spur lines S1 to S6 can always be connected during operation.

# 3.6 Connecting PROFIBUS PA to the AFDiS

#### Introduction

The PROFIBUS PA cables are introduced into the enclosure by means of cable glands.

- The PA main line via T1 and T2.
- The spur lines to the field devices via S1 to S6




Figure 3-4 Internal view of AFDiS

## Pin assignment

Connect the wiring of the PROFIBUS PA cable to the terminal block in the active field distributor via the screw-type terminals.

Table 3-3 Pin assignment on the active field distributor AFDiS



Connection		Terminal	Assignment
T1, T2	Main line	+	Data cable (red)
		-	Data cable (green)
S1 <sup>1</sup> to S6	Spur line to the field	+	Data cable (red)
	devices	-	Data cable (green)
Shield / bar Direct grounding for T1/T2; S1 to S6		unding for T1/T2; S1 to S6	
4.04 (* 11.6 )			

<sup>&</sup>lt;sup>1</sup> S1 optionally for a subsegment with a length of up to 500 m or for a spur line; line termination with bus terminating resistor

# **Basic procedure**

- 1. Prepare PROFIBUS PA cable.
- 2. Connect the PROFIBUS PA cable:
  - Open the field distributor.
  - Connect the spur lines and PA main lines to the terminal block.
- 3. Close field distributor

## Requirement

• Active field distributor is mounted.

#### Note

Before connecting the PROFIBUS PA, read the chapter "Safety instructions for connection"!

# **Tools required**

- Phillips screwdriver, size 4
- Open ring spanner 19 mm
- Screwdriver 3 mm
- Small knife, end-cutting nipper or FC stripping tool

## Required accessories

- PROFIBUS PA cable (cable type A)
- Sealing plugs for unused connections

# Stripping dimensions for PROFIBUS PA cable


For secure connection of the wires in the screw-type terminals, observe the following stripping dimensions of the PA cables for the main lines and spur lines.

Table 3-4 Stripping dimensions for PA cable

Type of grounding	Length of stripping	Main line T1, T2	Spur lines S1 to S3	Spur lines S4 to S6
Direct grounding	а	105 mm	120 mm	105 mm

## Direct grounding: Prepare PROFIBUS PA cable

- 1. Remove the union nut of the cable gland of the AFDiS using the ring spanner.
- 2. Thread the union nut onto the unprepared- PA cable.
- 3. Strip the PA cable as shown in the figure.



### Direct grounding: Connect the PROFIBUS PA cable to S1 to S6

- 1. Open the field distributor: Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Insert the cable under the shield clamp and tighten the screw.
- Connect the wires to the terminal block in accordance with the pin assignment.Torque 0.35 Nm.
- 4. Tighten the union nut of the cable gland. Torque 1.3 Nm.

# Direct grounding: Connect the PROFIBUS PA cable to T1/T2



#### Hazardous area - Zone 1

**Under no circumstances** connect the PA main line to the AFDiS during operation. Before connecting the PROFIBUS PA to the AFDiS, disconnect all the supply voltages of the bus segment!

- 1. Route the cable for the main line through the cable gland T1/T2 under the shield clamp and tighten the screw.
- 2. Open the IP30 cover T1/T2.
- 3. Connect the wires to the terminal block T1/T2 in accordance with the pin assignment.
- 4. Close the IP30 covers until you hear them engage.
- 5. Tighten the union nut of the cable gland. Torque 1.3 Nm.

#### NOTICE

#### Impairment of the degree of protection

The degree of protection can be impaired if you overtighten the union nut.

## Close field distributor

 Place the enclosure cover on the enclosure base and tighten the 4 screws. Torque 2.4 Nm.

#### NOTICE

#### Impairment of the degree of protection

The degree of protection IP66 will not be guaranteed if connections are not used.

Close unused connections with a **sealing cap**. The union nuts with the yellow dust protection caps are not sufficient protection.

#### See also

Grounding (Page 44)

Connecting the PROFIBUS PA to the active field distributor (AFD) (Page 95)

Components of the bus links (Page 245)

# 3.7 Grounding AFDiS

## Required accessories

Grounding cable, at least 4.0 mm<sup>2</sup>

## Grounding the active field distributor AFDiS

- 1. Strip the insulation of the grounding cable to 8 mm.
- 2. Fasten the grounding cable to the right-hand or left-hand grounding terminal of the AFDiS.



#### Active field distributor AFDiS

Connect the grounding cable with the equipotential bonding EB in accordance with EN 60079-14.

#### See also

Grounding the active field distributor AFD / AFS (Page 90)

# 3.8 AFDiS maintenance and cleaning

## Permitted activities in hazardous areas

The table below describes which maintenance activities on AFDiS are permitted during operation.



#### Hazardous areas

Zone 1 and Zone 2:

You may open the enclosure of the AFDiS briefly for the permitted maintenance work.

Zone 21 and Zone 22:

You may **not** open the enclosure of the AFDiS in areas with dust.

Table 3-5 Permitted activities in hazardous areas

Activities	Zone 1, Zone 2	Zone 21, Zone 22
Maintenance during operation (visual checks)	allowed	Warning: The enclosure of the AFDiS must <b>not</b> be opened for this activity in areas with dust .
Cleaning	allowed	Not permitted

## Maintenance during operation

Carry out maintenance every 6 months in the hazardous area.

Maintenance of the AFDiS is basically restricted to **visual inspections**. The AFDiS may be in operation during this.

Zone 1/ 2	Zone 21/ 22
Check that the cable entries and grounding terminal of the enclosure are sealed and intact.	Check that the cable entries and grounding terminal of the enclosure are sealed and intact.
	Warning: It is not permitted to open the enclosure of the AFDiS.
Check whether there is any water or dust inside the enclosure. If there is, find out how it got there.	
Check that the wiring is secure (connectors, cables).	

# Cleaning



### Hazardous areas - Zones 21 and 22

The dust layer on the enclosure of the AFDiS must not exceed a depth of 5 mm.

Remove the dust layer on the enclosure at regular intervals! During cleaning, make sure there is no risk of explosion! To do this, disconnect the unit from the voltage.

#### Note

Following cleaning, run a functional check of the AFDiS.

## See also

Safety instructions for connection (Page 46)

Connecting PROFIBUS PA to the AFDiS (Page 50)

# 3.9 Replacing/supplementing the AFDiS



#### **Explosion hazard**

In mixed operation with AFD, disconnect the DP/PA couplers from the power supply before you replace active field distributors AFDiS.

# **DANGER**

#### **Explosion hazard**

Observe the safety instructions in chapter "Safety instructions for connection (Page 46)".

# Replacing / supplementing an active field distributor AFDiS

Perform the following steps to replace a defective field distributor:

- 1. Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Loosen the black and blue union nuts.
- 3. Disconnect the PA field devices S1 to S6.
- 4. Open the IP30 covers T1/T2 and disconnect the PA main lines.
- 5. Replace the module.
- 6. Connect the PA field devices to the new AFDiS (refer to chapter entitled "Connecting PROFIBUS PA to the active field distributor AFDiS (Page 50)").
- 7. Connect the PA main cables T1/T2 to AFDiS and close the IP30 covers until you hear them engage.
- 8. Tighten the union nuts with 1.3 Nm.
- 9. Place the enclosure cover on the base and tighten the 4 screws with the plain washers on the enclosure with 2.4 Nm.

#### See also

Replacing the active field distributor AFD / AFS (Page 147)

LED displays of the active field distributor AFDiS (Page 181)

Application planning

# 4.1 Installation variants with the DP/PA coupler FDC 157-0

# 4.1.1 Configuration variants

#### Introduction

You can install a maximum of 5 DP/PA couplers FDC 157-0, of which one coupler pair is installed in redundancy mode at the end of the configuration. The bus module BM FDC/FDC is required for operation with ring redundancy and coupler redundancy.

# DP/PA couplers in the DP/PA link

If you use the IM 153-2 together with the DP/PA couplers as DP/PA link, in this case the PROFIBUS DP connections to the DP/PA couplers are not required. The IM 153-2 and the DP/PA couplers are connected via the S7 backplane bus.

### **Diagnostics function**

The diagnostic function of the DP/PA coupler FDC 157-0 is available if valid PROFIBUS addresses are set on the DP/PA couplers and in the configuration software.

## **Applications**

The following table lists the applications for the DP/PA coupler FDC 157-0 and the available functions.

Table 4-1 Applications DP/PA coupler FDC 157-0

Applications DP/PA	Functions				
coupler FDC 157-0	Replacement for DP/PA coupler 6ES7157- 0AC82-0XA0	Diagnostics function	Ring redundancy Bus module BM F	Coupler redundancy FDC/FDC required	
Stand-alone mode (without DP/PA link)					
Operation in the DP/PA link	Х	Х	Х	Х	
Operation in the redundant DP/PA link					

4.1 Installation variants with the DP/PA coupler FDC 157-0

## See also

Combination of non-redundant and redundant DP/PA couplers (Page 68)


Configuration variants (Page 70)

Setting the PROFIBUS address and redundancy mode (Page 119)


# 4.1.2 DP/PA coupler in non-redundancy mode

You can extend the equipotential bonding line in stand-alone mode as well as in the DP/PA link with AFDs.

# DP/PA coupler in stand-alone mode



# DP/PA coupler in the DP/PA link



# 4.1.3 DP/PA coupler in redundancy mode

## 4.1.3.1 Ring redundancy with active field distributor (AFD)

#### Ring redundancy

The use of a DP/PA coupler pair and of active field distributors increases the availability of the equipotential bonding line. Ring redundancy is created by configuring a ring structure with 2 FDC-157-0 DP/PA couplers and field distributors:

- Up to 8 field distributors when exclusively using AFD
- Up to 5 field distributor with mixed use of AFD and AFDiS

The active DP/PA coupler FDC 157-0 supplies the equipotential bonding line. In the event of short-circuit or wire break on the PA main line the active DP/PA coupler supplies the cut equipotential bonding line in both directions. PA field device function remains intact. Repairs can be executed during operation.


#### NOTICE

#### Power supply

To ensure availability in redundancy mode we recommend using an autonomous power supply module for each DP/PA coupler.

4.1 Installation variants with the DP/PA coupler FDC 157-0

# Installation with ring redundancy



# Ring redundancy: Component behavior in the event of errors

Table 4-2 Ring redundancy: Component behavior in the event of errors

Components	DP/PA coupler pair	Active field distributors	PA field devices	equipotential bonding line
Failure of the energizing DP/PA coupler	<ul> <li>Switchover to partner coupler.</li> <li>Partner coupler takes over the power supply of the equipotential bonding line.</li> </ul>	O. K.	O. K.	O. K.
Short circuit or wire break on the PA main line	<ul> <li>The active energizing DP/PA coupler supplies the cut equipotential bonding line in both directions.</li> <li>The partner coupler is active conducting.</li> </ul>	Insulate, and terminate adjacent AFD / ADFiS.	O. K.	Equipotential bonding line is cut but is still supplied.
Short-circuit on the spur line	O. K.	Current limit of the AFD / AFDiS is active. Field distributor reports failure on the AFD spur line: green LED flashes, AFDiS: blue LED flashes	<ul> <li>Non-participating field devices remain O.K.</li> <li>Field device on the affected spur line fails.</li> </ul>	O. K.

# See also

Connections for ring redundancy (Page 94)

4.1 Installation variants with the DP/PA coupler FDC 157-0


# 4.1.3.2 Coupler redundancy with active field splitter (AFS)

## Coupler redundancy

The use of a DP/PA coupler pair and of an active field splitter enables redundancy mode on the equipotential bonding line.

The active DP/PA coupler FDC 157-0 supplies the equipotential bonding line in this process. Failure of a DP/PA coupler results in switchover to the partner coupler. PA field device function remains intact.

# Installation with coupler redundancy




## **NOTICE**

## Power supply

To ensure availability in redundancy mode we recommend using an autonomous power supply module for each DP/PA coupler.

# Installation with coupler redundancy and center feed

A cable bushing for looping through the equipotential bonding line is available on the active field splitter (AFS).




## See also

Connections for coupler redundancy (Page 98)


4.1 Installation variants with the DP/PA coupler FDC 157-0

# 4.1.3.3 Redundancy mode of the DP/PA coupler in the DP/PA link

# DP/PA coupler with ring redundancy in the DP/PA link




# DP/PA coupler with coupler redundancy in the DP/PA link




4.1 Installation variants with the DP/PA coupler FDC 157-0

# 4.1.3.4 Redundancy mode of the DP/PA coupler in the redundant DP/PA link

# DP/PA coupler with ring redundancy in the redundant DP/PA link



# DP/PA coupler with coupler redundancy in the redundant DP/PA link



4.1 Installation variants with the DP/PA coupler FDC 157-0


# 4.1.3.5 Combination of non-redundant and redundant DP/PA couplers

#### Introduction


You can install a maximum of 5 DP/PA couplers FDC 157-0, of which one coupler pair is installed in redundancy mode at the end of the configuration. Mixed mode is possible with the following modules:

- DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)
- DP/PA coupler Ex [i] (6ES7157-0AD82-0XA0)

# DP/PA coupler with ring redundancy in the DP/PA link



# DP/PA coupler with coupler redundancy in the DP/PA link



# 4.2 Installation variants with the IM 153-2

# 4.2.1 Configuration variants

With 153-2BAx2 you can configure the following:

- a DP/PA link with a maximum of 5 DP/PA couplers
- a Y link with a Y coupler

The IM 153-2BA82 is a spare part for IM 153-2BA81 and IM 157 (6ES7157-0AA8x-0XA0).

Moreover, the IM 153-2BAxx can be used as an interface module for the distributed I/O device ET 200M. Information on this is to be found in the Distributed I/O device ET 200M operating instructions (http://support.automation.siemens.com/WW/view/en/1142798).

## Configuration variants in the non-outdoor sector

You can implement the combinations listed in the following table in the non-outdoor area using the existing hardware.

Table 4-3 Configuration variants for the links in the non-outdoor sector

non-redundant configuration	redundant configuration	
<ul> <li>DP/PA coupler</li> <li>IM 153-2 + bus couplers</li> <li>+ DP/PA couplers (max. 5 units)</li> </ul>	BM IM/IM (7HD10 / 7HD80) + 2x IM 153-2     + BM FDC (max. 5 units)     + DP/PA couplers (max. 5 units)	
BM PS/IM + PS + IM 153-2 + BM FDC (max. 5 units) + DP/PA couplers (max. 5 units)	BM IM/IM (7HD10 / 7HD80) + 2x IM 153-2     + BM Y coupler + Y coupler	
BM IM/IM (7HD10 / 7HD80) + IM 153-2     + BM DP/PA (max. 5 units)     + DP/PA couplers (max. 5 units)		
In the table IM 153-2 stands for:		
• IM 153-2 (6ES7153-2BA01-0XB0)		

- IM 153-2 (6ES7153-2BA02-0XB0)
- IM 153-2 (6ES7153-2BA81-0XB0)
- IM 153-2 (6ES7153-2BA82-0XB0)

### Configuration variants in the outdoor sector

You can implement the combinations listed in the following table in the outdoor area using the existing hardware.

Table 4-4 Configuration variants for the links in the outdoor sector

non-redundant configuration	redundant configuration
<ul> <li>DP/PA coupler</li> <li>IM 153-2 + bus couplers + DP/PA couplers (max. 5 units)</li> <li>BM IM/IM (7HD80) + IM 153-2 + BM DP/PA (max. 5 units) + DP/PA couplers (max. 5 units)</li> </ul>	BM IM/IM (7HD80) + 2x IM 153-2 + BM DP/PA (max. 5 units) + DP/PA couplers (max. 5 units)
In the table IM 153-2 stands for:	
• IM 153-2 (6ES7153-2BA81-0XB0)	

IM 153-2 (6ES7153-2BA82-0XB0)

#### References

- For detailed information on the functions and features of the IM 153-2, please refer to the chapters *Functions* and *Compatibilities*.
- The IM 153-2BAx2 is not only the interface module for the bus couplers DP/PA link and Y link, but also for ET 200M. For the configuration variant options please refer to the Distributed I/O device ET 200M operating instructions (http://support.automation.siemens.com/WW/view/en/1142798).

#### See also

Configuration variants (Page 57)

# 4.2.2 Detecting the configuration variant by means of the IM 153-2

During start-up, the IM 153-2 automatically detects which structure variant (ET 200M or DP/PA-link or Y-link) it is being used in. The IM 153 2 determines its functionality in accordance with this.

#### **NOTICE**

The following structure variants ("mixed structures") are **not** permissible:

- Input / output modules and coupler modules in one structure
- Bus modules BM 2 x 40 / BM 1 x 80 and BM FDC / BM Y coupler in one structure

4.2 Installation variants with the IM 153-2

Mounting

## 5.1 Mounting rules

### Mounting position

The IM 153-2, DP/PA coupler and Y coupler module can be mounted in a vertical or horizontal position.



#### Open equipment

The IM 153-2 DP/PA coupler and Y coupler modules are open equipment. This means that they may only be mounted in enclosures, cabinets. or electrical service rooms that can only be accessed by using a key or a tool. Only authorized personnel may have access to the enclosures, cabinets or electrical service rooms.

### Mounting system

The IM 153-2 DP/PA coupler and Y coupler modules are mounted on rails for the S7 mounting system. Free space of 40 mm must be maintained above and below the modules for trouble-free mounting.

Additional instructions for installing modules in the S7 mounting system are available in the operating instructions of the SIMATIC- S7-300 CPU 31xC and CPU 31x: Installation (http://support.automation.siemens.com/WW/view/en/36305386) manual.

5.1 Mounting rules

#### Installation location

The DP/PA FDC 157-0 coupler or the DP/PA-Koppler Ex [i] or the DP/PA link with DP/PA Ex [i] couplers can be operated in hazardous areas, Zone 2, if they are installed in a suitable enclosure. The bus cable for PROFIBUS PA may lead from the hazardous area zone 2, into the following zones:

- in the case of 6ES7157-0AD81-0XA0 into zone 0
- in the case of 6ES7157-0AD82-0XA0 into zone 0 /zone 20

## **A** DANGER

In the case of DP/PA coupler Ex [i] 6ES7157-0AD82-0XA0 the intrinsically safe PROFIBUS PA is approved for the following intrinsically safe electrical equipment:

- Device category 1G, 2G and 3G for zones 0, 1, and 2
- Device category 1D, 2D and 3D for zones 20, 21, and 22

As a PROFIBUS node you can use the DP/PA coupler Ex [i] of device category 3G in zone 2-type hazardous areas (or in the safe area).

If you want to use the DP/PA coupler Ex [i] in zone 21 or 22, then you must install it in an enclosure that is certified and approved for these zones.

#### Enclosure for zone 2

The DP/PA coupler Ex [i], or the DP/PA link with DP/PA coupler Ex [i] must be installed in an enclosure with minimum degree of protection IP 54. A manufacturer's declaration for zone 2 must be submitted for the enclosure (in accordance with EN 60079-15).

Use the following threaded cable glands:

- Power supply and PROFIBUS DP Ex i: Cable gland with manufacturer's declaration for zone 2
- PROFIBUS PA Ex i: Degree of protection Ex i

## **DANGER**

Under some circumstances, sparks capable of ignition or unacceptable surface temperatures can occur during installation.

Never install under explosive conditions!

Switch off the voltage supply to the plant and adhere to the safety regulations.

You can obtain enclosures for zone 2 from:

Siemens AG, I IA CE S EN Siemensallee 84 D-76187 Karlsruhe

E-mail: helmut.heib@siemens.com (mailto:<helmut.heib@siemens.com>)

## 5.2 Mounting the DP/PA coupler

## 5.2.1 Mounting DP/PA coupler for non-redundant mode

#### Components required

- Rail for the S7 mounting system
- DP/PA coupler

### Mounting the DP/PA coupler

#### Note

If you operate multiple DP/PA couplers in one rack in stand-alone mode without ring redundancy and coupler redundancy, then you cannot connect the DP/PA coupler via bus connector nor can you connect it via bus modules.

- 1. Hook the DP/PA coupler into the S7 mounting rails and swing it down.
- 2. Screw the DP/PA coupler tight.

### Dismantling the DP/PA coupler

Remove the DP/PA coupler in the reverse sequence.

If the DP/PA coupler is already in operation, switch off the 24 V DC power supply for the DP/PA coupler prior to removal.

#### 5.2.2 Mounting the DP/PA coupler for redundancy mode

#### Configuration with bus modules

For operation with ring redundancy or coupler redundancy the two FDC 157-0 DP/PA couplers must be installed with the BM FDC 157-0 bus module.

#### Combination with non-redundant DP/PA couplers

A combination of non-redundant and redundant DP/PA couplers is possible. You can install a maximum of 5 DP/PA couplers FDC 157-0, of which one coupler pair is installed in redundancy mode at the end of the configuration.

#### Components required

- Rail for configuration with active bus modules ("Rail for module change during operation")
- For ring redundancy or coupler redundancy:
  - Bus module BM FDC/FDC (redundant)
  - Maximum 2 DP/PA couplers FDC 157-0
- Optional for non-redundant DP/PA couplers:
  - Bus module BM FDC
  - Maximum 3 DP/PA couplers FDC 157-0

#### Installing bus modules and modules

- 1. Hang the *BM FDC* bus modules first, then the *BM FDC/FDC (redundant)* bus module on the mounting rail and press them into the rail.
- 2. Slide the bus modules together, so that the module connections have contact.
- 3. Insert the DP/PA couplers in the bus modules. To do so use the lateral guides of the bus module.
- 4. Screw the modules tight. This also fixes the bus modules to the rail.

#### Removing bus modules and modules

Remove the DP/PA coupler in the reverse sequence.

If the device is already in operation then disconnect its 24-V DC power supply beforehand.

## 5.2.3 Swapping DP/PA couplers FDC 157-0

#### Introduction

Swapping a DP/PA coupler 157-0 is possible during operation with ring redundancy or coupler redundancy. The PA field devices that are connected to the redundant DP/PA coupler remain in operation.

#### Requirement

The following prerequisites must be satisfied to remove a DP/PA coupler FDC 157-0 during operation.

- The ACT LED of the DP/PA coupler cannot be illuminated. If the ACT LED is illuminated, then multiple PA field devices can fail.
- The power supply of the DP/PA coupler FDC 157-0 must be disconnected.

#### Removing and inserting modules

#### **NOTICE**

#### Removing a DP/PA coupler FDC 157-0

It is only possible to remove a DP/PA coupler FDC 157-0 if it is de-energized.

Prior to removing an FDC 157-0 DP/PA coupler, disconnect its 24 V DC power supply.

#### **NOTICE**

#### Failure of a DP/PA coupler FDC 157-0

If you remove an FDC 157-0 DP/PA coupler under voltage then the overvoltage protection can permanently respond. You can reset this switch-off if you turn off the mains for at least 10 seconds.

Prior to removing an FDC 157-0 DP/PA coupler, disconnect its 24 V DC power supply.

## 5.3 Installing the active field distributor AFD and active field splitter AFS

# 5.3.1 Screwing down the active field distributor AFD and active field splitter AFS on substrate

#### Mounting position

The active field distributor AFD and active field splitter AFS can be screwed onto a level surface in any position.

#### Requirement

- The substrate must be level, with load-bearing capacity, and it must be vibration free.
- Select appropriate fixing accessories for the substrate.
- Ensure that there is at least 60 mm of free space both to the side and below the modules for connecting the PA main lines and spur lines.

#### **Tools required**

- Phillips screwdriver size 4
- 2 fixing screws M4; dowels depending on the substrate
- · Screwdriver suitable for the screws used

### **Procedure**

- 1. Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Screw the lower part of the enclosure tightly to the substrate with 2 fixing screws. The torque depends on the fixing screws used. You can find the drill hole spacing on the back of the enclosure base.
- 3. Screw the enclosure cover onto the upper part of the enclosure with the 4 Phillips-recess screws. Torque 2.0 Nm.

## 5.4 Mounting the DP/PA link

## 5.4.1 Mounting the DP/PA link for non-redundant mode

#### Components required

- Rail for the S7 mounting system
- IM 153-2
- 1 to 5 DP/PA couplers
- one bus connector for each DP/PA coupler (included with it)
- options for module exchange during operation
  - Bus module BM PS/IM or BM IM/IM
  - Bus module BM; DP/PA coupler

### Typical configuration of the DP/PA link

The following figure shows the typical configuration of the DP/PA link with two DP/PA couplers and with front doors open.




Figure 5-1 Typical configuration of the DP/PA link for non-redundant mode

#### 5.4 Mounting the DP/PA link

#### Installing the DP/PA link

- 1. Insert the bus connector that is included with the DP/PA coupler onto the IM 153-2.
- 2. Hook the IM 153-2 onto the S7 rail and swing it downward.
- 3. Screw the IM 153-2 tight.
- 4. If appropriate, insert the bus connector of the next DP/PA coupler onto the right-hand side on the DP/PA coupler.
- 5. Hook the DP/PA coupler onto the the right-hand side next to the IM 153-2 on the S7 rail and swing it downward.
- 6. Screw the DP/PA coupler tight.
- 7. Repeat steps 4 to 6 for the subsequent DP/PA couplers. For the last DP/PA coupler (of a maximum of 5), do not insert a bus connector prior to installation.

### Inserting / removing DP/PA couplers

If you wish to remove or insert DP/PA couplers during operation, you must use busmodules for configuration instead of the bus connectors.

#### Removing the DP/PA link

To remove the DP/PA link, proceed in the reverse order. Start with the DP/PA coupler installed on the far right.

If the DP/PA link is already in operation, switch off the 24 VDC power supplies prior to dismantling it.

#### See also

Accessories for PROFIBUS DP (Page 246)

Accessories for PROFIBUS PA (Page 247)

## 5.4.2 Mounting the DP/PA link for redundant operation

### Configuration with bus modules

For the redundancy mode, the DP/PA link must configured with bus modules.

#### Components required

- Rail for configuration with active bus modules ("Rail for module change during operation")
- 2 x IM 153-2
- Bus module BM IM/IM
- 1 to 5 DP/PA couplers
- One BM DP/PA coupler bus module per DP/PA coupler

### Typical configuration

The following figure shows the typical configuration of the DP/PA link for the redundancy mode with two power supply modules and with front doors open.





Figure 5-2 Typical configuration of the DP/PA link for the redundancy mode

#### 5.4 Mounting the DP/PA link

#### Installing bus modules and modules

1. Hook the lower edge of the BM IM/IM bus module onto the rail, press it into the rail (a) and push it to the left until it engages (b).

If you are using the 530 mm rail and position the BM IM/IM in the right-hand engaged position, you can install two additional PS 307; 2A or one PS 307; 5A to the left of the bus module.



- 2. Hook the BM DP/PA coupler bus modules onto the rail and press them down into the rail.
- 3. Push the bus modules together so that the module connections are in contact.
- 4. Insert the two IM 153-2 into the BM IM/IM bus module.
- 5. Inser the DP/PA coupler into the BM DP/PA coupler bus module. To do so use the lateral guides of the bus module.
- 6. Screw the modules tight. This also fixes the bus modules to the rail.

#### Removing and inserting modules

It is possible to remove and insert modules on S7-400H during operation. The following special characteristics should be noted:

- An IM 153-2 may only be removed and inserted if it is de-energized. Switch off the 24 VDC supply to the IM 153-2 for this purpose. To prevent the underlying master system from failing the DP/PA link should be configured with independently switchable voltage supplies to the two IM 153-2 (for example by using two power supply modules).
- There is no restriction on removing and inserting the DP/PA coupler, but it causes the nodes connected to it to fail.

#### Removing bus modules and modules

To remove the DP/PA link, proceed in the reverse order.

If the device is already in operation, switch off the 24 VDC power supplies prior to removing it.

#### See also

Accessories for PROFIBUS DP (Page 246)

Accessories for PROFIBUS PA (Page 247)

## 5.5 Mounting the Y link

## Configuration with bus modules

The Y link must always be configured with bus modules.

### Components required

- Rail for configuration with active bus modules ("Rail for module change during operation")
- 2 x IM 153-2
- Bus module BM IM/IM
- Y coupler
- Bus module BM Y coupler

## Typical configuration

The following figure shows the typical configuration of Y link with two power supply modules and with front doors open.





Figure 5-3 Typical configuration of the Y link

#### 5.5 Mounting the Y link

#### Installing bus modules and modules

1. Hook the lower edge of the BM IM/IM bus module onto the rail, press it into the rail (a) and push it to the left until it engages (b).

If you are using the 530 mm rail and position the BM IM/IM in the right-hand engaged position, you can install two additional PS 307; 2A or one PS 307; 5A to the left of the bus module.



- 2. Hook the BM Y coupler bus module onto the rail and press it down into the rail.
- 3. Push the bus modules together so that the module connections are in contact.
- 4. Insert the two IM 153-2 into the BM IM/IM bus module.
- 5. Insert the Y coupler into the BM Y coupler bus module. To do so use the lateral guides of the bus module.
- 6. Screw the modules tight. This also fixes the bus modules to the rail.

#### Removing and inserting modules

It is possible to remove and insert modules on S7-400H during operation. The following special characteristics should be noted:

- An IM 153-2 may only be removed and inserted if it is de-energized. Switch off the 24 VDC supply to the IM 153-2 for this purpose. To prevent the underlying master system from failing the Y link should be configured with independently switchable voltage supplies to the two IM 153-2 (for example by using two power supply modules).
- There is no restriction on removing and inserting the Y coupler, but it causes the nodes connected to it to fail.

#### Removing bus modules and modules

To remove the Y link, proceed in the reverse order.

If the device is already in operation, switch off the 24 VDC power supplies prior to removing it.

#### See also

Accessories for PROFIBUS DP (Page 246)

## 5.6 Setting the PROFIBUS address of the IM 153-2

#### **Definition**

For the purpose of unique identification on PROFIBUS DP, each node must be given a PROFIBUS address.

#### Rules

The following rules apply to the PROFIBUS address of the IM 153-2 in the higher level DP master system:

- Permitted PROFIBUS addresses: 1 to 125
- Each PROFIBUS address may only be assigned once in the DP master system.
- In the redundant mode the same PROFIBUS address must be set for both IM 153-2.

#### **Tools required**

To set the PROFIBUS address you require a 3 mm screwdriver.

#### **Procedure**

- 1. Open the front door of the IM 153-2
- Use a screwdriver to set the required PROFIBUS address. The PROFIBUS address is the sum of the values of all of the switches that are in the "ON" position (switch set to the right).




Figure 5-4 Example for setting the PROFIBUS address

#### Changing the PROFIBUS address

You can change the PROFIBUS address that has been set at any time. However, the IM 153-2 does not apply the new setting until the 24 VDC supply has been switched off / on.

5.6 Setting the PROFIBUS address of the IM 153-2

Connecting

## 6.1 Electrical isolation and grounding

#### Introduction

You can wire the 24 V power supply for the described modules as a grounded or ungrounded configuration, depending on the requirements of your system configuration.

#### Features of the IM 153-2

- The S7 backplane bus and the 24 V power supply are electrically bound
- PROFIBUS DP is electrically isolated from the 24 V power supply and from the S7 backplane

### Features of the DP/PA coupler

- PROFIBUS DP and PROFIBUS PA are electrically isolated from the 24 V power supply of the DP/PA coupler.
- PROFIBUS DP and PROFIBUS PA are electrically isolated from one another

#### Features of the Y coupler

• The PROFIBUS DPmaster system is electrically isolated from the S7 backplane

## 6.1.1 General Rules and Regulations for Operation

#### Introduction

If they are part of plants or systems the modules described require adherence to specific rules and regulations depending on the application.

This chapter gives an overview of the most important rules you have to obey in order to integrate them safely in a plant or system.

## Specific application

Please observe the safety and accident prevention regulations applying to specific applications, for example, the machine protection guidelines.

#### **EMERGENCY-OFF devices**

In all operating modes of the plant or system, EMERGENCY-OFF devices that conform to IEC 60204 *Safety of machinery – electrical equpment of machines* must remain effective.

### System startup after certain events

The table below shows what you have to observe when restarting a plant after specific events.

For	
Start-up following a power drop or failure     Start up after bus communication has been interrupted	Dangerous operating states must not be permitted to occur. If necessary force an emergency stop!
Start-up after unlocking the EMERGMENCY     OFF device	must not give rise to an uncontrolled or undefined start-up.
Start-up without the DP master addressing the slaves	

### 24 VDC supply

The table shows what you must pay attention to with regard to the 24 V supply.

For	You must give heed to	
Buildings	External lightning protection	Make provision for lightning
24 VDC supply lines, signalling lines	Internal lightning protection	protection (for example lightning arresters
24 VDC supply	Safe extra-low voltage with safe electrical isolation (SELV)	

#### Protection from external electrical influences

The table below shows how you must protect your system against electrical interference or faults.

For	You must ensure that
All plants or systems in which the modules are integrated	The plant or system is connected to the protective conductor so that the electromagnetic interference is discharged.
Connecting cables, signalling and bus lines	The arrangement of the wiring and installation are correct
Signalling and bus lines	Line or conductor breakage does not cause undefined plant or system states.

## Shielding braid of the PROFIBUS cable

The shielding braid of the PROFIBUS cable must be placed on a grounded shield bus.

- Affix the shielding braids with metal cable clamps
- The clamp must clasp around a large portion of the shield and provide good contact.
- Attach the screen to a shield bus directly after the point where the cable enters the cabinet.




Figure 6-1 Shielding braid of the PROFIBUS cable on a grounded shield bus

#### 6.1 Electrical isolation and grounding

## 6.1.2 Grounding the active field distributor AFD / AFS

#### **Tools required**

Allen key size 3

#### Required accessories

• Grounding cable 4.0 mm<sup>2</sup>

### Grounding the active field distributors

- 1. Strip the insulation of the grounding cable to 8 mm.
- 2. Use the Allen key to remove the Allen screws on the field distributor.
- 3. Use the cable clip to fix the grounding cable to the field distributor.
- 4. Tighten the two Allen screws.
- 5. Place the shielding on a shielding bus.

#### See also

Grounding AFDiS (Page 53)

### 6.1.3 Operating with grounded supply

#### **Definition: Grounded incoming supply**

In the case of grounded incoming supplies, the neutral conductor of the supply line is grounded. A single ground fault between a live conductor and ground or a grounded part of the installation results in the protective devices being tripped.

#### Components and protective measures

Various components and protective measures are specified for assembling a full installation. The type of components and the degree to which the protective measures are mandatory depend on which DIN VDE regulation applies to your system configuration.

Main switch: DIN VDE 0100 part 460

Isolator: DIN VDE 0113 part 1

## Operating with grounded supply

The figure below shows the position of the modules in the overall configuration with the supply from a TN-S system. In the case of a configuration with grounded reference potential, interference currents that occur are discharged to the protective conductor.

Comment: The arrangement of the power supply connections represented here does not correspond to the actual arrangment on the modules; it was selected for the purpose of clarity.




Figure 6-2 Configuration with a grounded supply

## 6.1.4 Operation with ungrounded reference potential

#### **Application**

In extensive plants (e.g. in the chemical industry or in power stations) it may become necessary to operate the modules with ungrounded reference potential, for example for the purpose of ground fault monitoring.

#### Discharging interference current

When operating with ungrounded reference potential, interference currents that arise are discharged via RC networks integrated into the IM 153-2 and DP/PA couplers to the protective conductor (refer to figure below).




Figure 6-3 Configuration with ungrounded reference potential

#### Power supply

If the IM 153-2 and the DP/PA coupler FDC 157-0 are operated from the same supply, then the electrical isolation of the DP/PA coupler FDC 157-0 between the 24 V supply and the S7 backplane bus is cancelled by the potential bonding of the IM 153-2 between the 24 V supply and backplane bus. The cancellation of the electrical isolation can only be prevented by two electrically isolated 24 V power supplies.

#### Note

In an ungrounded configuration with common power supply, observe that the DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0) has an additional internal 1 MOhm resistance that is active in parallel to the 10 MOhm resistance between electrical ground and earth on the IM 153-2.

## 6.2 Connecting DP/PA couplers

## 6.2.1 Wiring the DP/PA coupler for stand-alone mode

### Connections of the DP/PA coupler

The figure below shows all the connections you must create from and to the DP/PA coupler for stand-alone operation:




Figure 6-4 DP/PA coupler connections for stand-alone operation

## 6.2.2 Connecting DP/PA couplers for ring redundancy

## 6.2.2.1 Connections for ring redundancy

### Connections of the DP/PA coupler with ring redundancy

The following fig. shows all connections that you must establish for operation of the DP/PA coupler in ring redundancy in a redundant DP/PA link.




Figure 6-5 Connections - DP/PA coupler with ring redundancy in a redundant DP/PA link

#### See also


Ring redundancy with active field distributor (AFD) (Page 59)

### 6.2.2.2 Connecting the PROFIBUS PA to the active field distributor (AFD)

#### Introduction

The PROFIBUS PA cables are introduced into the enclosure by means of cable glands.

- The PA main line is introduced via PA1 and PA2.
- The spur lines to to PA field devices via X1 to X4.



### Pin assignment

Connect the wiring of the PROFIBUS PA cable to the terminal block in the active field distributor via the screw-type terminals.




Table 6-1 Pin assignment for active field distributor (AFD)

Connection	on	Terminal	Assignment
PA1,	PA main line to the DP/PA couplers	+	Data cable (red)
PA2		-	Data cable (green)
X1 to X4	Spur line to the PA field devices	+	Data cable (red)
		-	Data cable (green)

#### Basic procedure

- 1. Prepare PROFIBUS PA cable.
- 2. Connect the PROFIBUS PA cable:
  - Open the field distributor.
  - Connect the wires to the terminal block.
- 3. Close and ground the field distributor.

#### 6.2 Connecting DP/PA couplers

### Requirement

Active field distributor is mounted.

#### **Tools required**


- Phillips screwdriver size 4
- Open ring spanner 17 mm
- Screwdriver 3 mm
- Small knife, end-cutting nipper or FC stripping tool

### Required accessories

- PROFIBUS PA cable (cable type A)
- Sealing plugs for unused connections

#### Prepare PROFIBUS PA cable

- 1. Remove the cable gland from the field distributor with the open-end wrench.
- 2. Thread the clamping screw and the inside part of the gland with the conical nipple onto the unprepared PA cable.
- 3. Strip the PA cable as shown in the figure.



4. Push the screening braiding over the inner part of the gland. To ensure electrical contact to the enclosure, the screening braiding must fully cover the inner part.

#### Connect the PROFIBUS PA cable

- 1. Open the field distributor: Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Insert the PA cables through the cable glands.
- 3. Connect the wires to the terminal block in accordance with the pin assignment.
  - Ensure that the wires have the correct polarity. Torque 0.35 Nm.
- 4. Tighten the union nuts of the cable glands only until the sealing insert forms a **slight** bulge above the pressure nut.

#### **NOTICE**

#### Impairment of the degree of protection

The degree of protection can be impaired if you overtighten the union nuts.

### Close and ground the field distributor

- 1. Place the enclosure cover on the enclosure base and tighten the 4 screws on the enclosure cover. Torque 2.0 Nm.
- 2. Ground the field distributor using the ground connection provided for this purpose (cabel 4 mm²).

#### **NOTICE**

Impairment of the degree of protection

The IP65 degree of protection is not ensured if connections are not used.

Close unused connections with a suitable sealing cap.

## 6.2.3 Connecting DP/PA couplers for coupler redundancy

## 6.2.3.1 Connections for coupler redundancy

### Connections of the DP/PA couplers with ring redundancy

The following fig. shows all connections that you must establish for operation of the DP/PA coupler in ring redundancy in a redundant DP/PA link.




Figure 6-6 Connections - DP/PA coupler with ring redundancy in a redundant DP/PA link

#### See also


Coupler redundancy with active field splitter (AFS) (Page 62)

### 6.2.3.2 Connecting the PROFIBUS PA to the active field splitter (AFS)

#### Introduction

The PROFIBUS PA cables are introduced into the enclosure by means of cable glands.

- The PA main line to the DP/PA couplers via PA1 and PA2.
- The spur line to the equipotential bonding line via X1.
- Center feed: The cable gland X2 is available for looping through the equipotential bonding line. The cable gland is factory sealed with a blanking screws.



## Pin assignment

Connect the wiring of the PROFIBUS PA cable to the terminal block in the active field distributor via the screw-type terminals.




Table 6-2 Pin assignment for active field splitter (AFS)

Connection		Terminal	Assignment
PA1, PA2	PA main line to the DP/PA couplers	+	Data cable (red)
		-	Data cable (green)
X1	Spur line to the PA field devices (infeed)	+	Data cable (red)
		-	Data cable (green)
X2	Spur line to the PA field devices (center infeed)	+	Data cable (red)
		-	Data cable (green)

#### 6.2 Connecting DP/PA couplers

#### Basic procedure

- 1. Prepare PROFIBUS PA cable.
- 2. Connect the PROFIBUS PA cable:
  - Open the field distributor.
  - Connect the wires to the terminal block.
- 3. Close and ground the field distributor.

#### Requirement

· Active field distributor is mounted.

#### **Tools required**


- Phillips screwdriver size 4
- Open ring spanner 17 mm
- Screwdriver with 3 mm blade
- Small knife, end-cutting nipper or FC stripping tool

#### Required accessories

- PROFIBUS PA cable (cable type A)
- Sealing plugs for unused connections

### Prepare PROFIBUS PA cable.

- 1. Remove the cable glands from the field distributor with the open-end wrench.
- 2. Thread the clamping screw and the inside part of the gland with the conical nipple onto the unprepared PA cable.
- 3. Strip the PA cable as shown in the Fig.



4. Push the screening braiding over the inner part of the gland. To ensure electrical contact to the enclosure, the screening braiding must fully cover the inner part.

#### Connect the PROFIBUS PA cable

- 1. Open the field distributor: Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Insert the PA cables through the cable glands.
- 3. Connect the wires to the terminal block in accordance with the pin assignment.
  - Ensure that the wires have the correct polarity. Torque 0.35 Nm.
- 4. Tighten the union nuts of the cable glands only until the sealing insert forms a slight bulge above the pressure nut.

#### NOTICE

#### Impairment of the degree of protection

The degree of protection can be impaired if you overtighten the union nuts.

### Close and ground the field distributor

- 1. Place the enclosure cover on the enclosure base and tighten the 4 screws on the enclosure cover. Torque 2.0 Nm.
- 2. Ground the field distributor using the ground connection provided for this purpose (cabel 4 mm²).

#### NOTICE

Impairment of the degree of protection

The IP65 degree of protection is not ensured if connections are not used.

Close unused connections with a suitable sealing cap.

#### Center feed: Equipotential bonding line loop through

If you loop the equipotential bonding line on the active field splitter (AFS) over the X2 cable bushing, then set the PA bus terminator switch to OFF on both DP/PA couplers.

## 6.3 Connecting the DP/PA link

## 6.3.1 Wiring the DP/PA link for non-redundant mode

#### Connections of the DP/PA link

The figure below shows all the connections you must create from and to the DP/PA coupler for non-redundant mode:




Figure 6-7 DP/PA link connections for non-redundant operation

### **Power supply**

In the DP/PA link voltage supplies are required for the IM 153-2 and for each DP/PA coupler.

## 6.3.2 Wiring the DP/PA link for redundant operation

#### Connections of the DP/PA link

The figure below shows all the connections you must create from and to the DP/PA link for the redundant mode:




Figure 6-8 Connections of the DP/PA link for redundant mode

### **Power supply**

In the DP/PA link voltage supplies are required for the both IM 153-2 and for each DP/PA coupler.

#### **PROFIBUS DP**

PROFIBUS DP connections to the S7-400H are required on both IM 153-2 in the DP/PA link.

## 6.4 Connecting Y link

#### Y link connections

The figure below shows all the connections you must create from and to the Y link:




Figure 6-9 Y link connections

#### Power supply

In the Y link voltage supplies are required for the two IM 153-2.

#### **PROFIBUS DP**

The following PROFBUS DP connections are required in the Y link:

- To the S7-400H on both IM 153-2
- To the underlying DP master system on the Y coupler

#### Bus terminal resistors

The Y coupler possesses no integrated bus terminal resistors. If the Y coupler is arranged at the beginning or end of a bus segment, you must also connect in the bus terminal resistors on the bus connector.

## 6.5 Connecting the power supply

#### Introduction

For all modules described the power supply is connected in the same way.

#### **Tools required**

To connect the power supply you require a 3 mm screwdriver.

#### Power supply unit

You must only use SELV-type power supply units with protective extra-low voltage with safe electrical isolation (≤ DC 60 V).

The size of the power supply unit depends on the power consumption of the connected components.

#### Connection for power supply

The 4-pin screw-type terminal for the 24 V power supply is located behind the front door at the bottom on the IM 153-2. The connections have the following functions:




Figure 6-10 Power supply for the IM 153-2

The maximum cross-section of the connection is 2.5 mm<sup>2</sup>. There is no mains lead cleat.

#### See also

Wiring the DP/PA coupler for stand-alone mode (Page 93)

Wiring the DP/PA link for non-redundant mode (Page 102)

Wiring the DP/PA link for redundant operation (Page 103)

Connecting Y link (Page 104)

#### DP/PA coupler FDC 157-0 in redundancy mode

To ensure availability in redundancy mode we recommend using an separate power supply module for each DP/PA coupler.

## 6.6 Connecting PROFIBUS DP

#### Introduction

PROFIBUS DP is connected in the same way for all the modules described.

### **Tools required**

You require a 3 mm screwdriver to fix the bus connector to the IM 153-2.

#### Bus cable and connector

Use only the specified accessories for PROFIBUS DP.

#### **Procedure**

Connect the PROFIBUS DP as follows:

- 1. Plug the bus connector into the PROFIBUS socket.
- 2. Tighten the fixing screws of the bus connector.

#### Additional information

All the information required for handling bus cables and connectors can be found in the ET 200 Distributed I/O System manual (http://support.automation.siemens.com/WW/view/en/1142470).

## 6.7 Connecting PROFIBUS PA on the DP/PA coupler

#### Important instructions:

The following content is binding for the PROFIBUS°PA installation:

- Investigation of intrinsic safety for field bus systems; PTB Report W-53, Braunschweig, March 1993 (only applicable for installation in a hazardous area).
- PROFIBUS PA Commissioning Guide, Notes on Using the IEC 61158-2 Technology for PROFIBUS, (German art. no. 2.091, English art. no. 2.092)
   PROFIBUS-Nutzerorganisation e. V., (<a href="http://www.profibus.com">http://www.profibus.com</a>)
   Haid-und-Neu-Straße 7, D-76131 Karlsruhe
- Installation regulations in accordance with IEC 60079-14: Installing electrical installations in hazardous areas

#### **Tools required**

To connect the PROFIBUS PA you require a screwdriver with a 3 mm-wide blade.

To prepare the cable/wiring we recommend the tool PROFIBUS FastConnect.

#### Bus cable

Use the specified bus cable for PROFIBUS PA.

#### **PROFIBUS PA connection**

The 4-pin screw-type terminal for the PROFIBUS°PA connection is positioned under the right-hand front door at the top on the DP/PA coupler. The connections have the following functions:




Figure 6-11 PROFIBUS PA connection

# PA bus terminator switch

You can loop through the PROFIBUS PA on DP/PA couplers with a PA bus terminator switch. The PA bus terminator switch is available on the following DP/PA couplers:

- DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)
- DP/PA coupler (6ES7157-0AC82-0XA0)

#### Note

The PA bus terminator switch is used to operate the- DP/PA coupler with ring redundancy without function.

#### **NOTICE**

# DP/PA Ex [i] coupler (6ES7157-0AD82-0XA0)

In the DP/PA coupler Ex [i] the bus terminator cannot be switched off.

Consequently the DP/PA coupler Ex [i] must be located at the beginning or the end of a PA segment.


DP/PA coupler	PA bus terminator switch		
	ON	The bus terminating resistors are activated.	
		PROFIBUS PA may not be looped through.	
	OFF	The bus terminating resistors are deactivated.	
ON		You can loop PROFIBUS PA through and connect bus terminating resistors at both ends of the PA segment .	

# 6.7 Connecting PROFIBUS PA on the DP/PA coupler

# **Procedure**

# Connect the PROFIBUS PA as follows:

1. Strip the insulation from the bus cable as depicted and pull the braided shield over the insulation.



- 2. Clamp the shield of the bus cable under the cable grip and screw down the cable grip.
- 3. Fix the wires of the bus lead into the screw-type terminals P+ and P-. Ensure that the wires have the correct polarity.

Commissioning: DP/PA coupler

# 7.1 Commissioning the DP/PA coupler for stand-alone mode

# Requirement

When you have fully installed and wired the DP/PA coupler and switched on the power supply, the DP/PA coupler is ready to operate.

# Setting transmission speed

The transmission speed must be set at 45.45 kBaud for the DP master.

# 7.2 Commissioning the DP/PA coupler FDC 157-0

# Requirements

Before you commission the DP/PA coupler FDC 157-0 the following prerequisites must be satisfied:

- You must have completely installed and wired the DP/PA couplers.
- You have fully installed PROFIBUS DP. PROFIBUS DP is ready to operate.
- You have fully installed PROFIBUS PA. PROFIBUS PA is ready to operate.

# Configuring the DP/PA coupler FDC 157-0:

DP/PA coupler FDC 157-0 configuration as DP slave is required in the following cases:

- If the diagnostic functions will be effective.
- If you want to operate the DP/PA couplers with ring redundancy or coupler redundancy.

#### Note

If you use the DP/PA coupler FDC 157-0 in redundancy mode (ring redundancy or coupler redundancy), then check whether RETRY = 3 in the properties of the PA master system in the network settings / profile, or set a user-defined profile with a retry limit of 3.

# Commissioning the DP/PA coupler FDC 157-0

# Basic procedure:

- 1. Optional: Configuring the DP/PA coupler.
- 2. Set the PROFIBUS addresses in the DP/PA couplers.
- 3. Select the redundancy mode on the DP/PA couplers.
- 4. Switch on the power supply for the DP/PA couplers.
- 5. Download the configuration to the PLC.

# Applications DP/PA coupler FDC 157-0

The following table shows the applications and the available functions for the DP/PA coupler and the settings that are required For ring redundancy and coupler redundancy the settings are required on the DP/PA coupler pair.




Table 7-1 Applications DP/PA coupler FDC 157-0 and required settings

Applications - DP/PA coupler FDC 157-0 (standalone or in the DP/PA link)	Functions	Settings on the DP/PA coupler / on the DP/PA coupler pair	Settings in the configuration
Non-redundant operation of DP/PA coupler <sup>1</sup>	Diagnostic function deactivated <sup>2</sup>	PROFIBUS address = 0	PROFIBUS address = 0
Redundant operation of a DP/PA coupler pair	Diagnostic function activated	PROFIBUS address> 0 (1 to 125)	PROFIBUS address> 0 (1 to 125)
Redundant operation of a DP/PA coupler pair	Ring redundancy activated	ON OFF ON RING ON RING ON	Redundancy mode Ring redundancy
	Coupler redundancy activated	ON OFF OFF ON	Redundancy mode Coupler redundancy

<sup>1</sup> Also as replacement for the DP/PA coupler with order number 6E7157-0AC82-0XA0

<sup>2</sup> DP/PA couplers transparent in the DP/PA link.

# 7.3 Configuration with a GSD file

#### Introduction

With the GSD file you can configure the DP/PA coupler FDC 157-0 with COM PROFIBUS or using a different software program. For this you must install the GSD file via an appropriate import function of the configuration software.

The GSD file is available for download on the Internet (http://support.automation.siemens.com/).

# Configure the DP/PA coupler with COM PROFIBUS or other configuration software

- Copy the GSD file of the DP/PA coupler into the COM PROFIBUS directory ...COMPB5 \ GSD (preset). Copy the bitmap file into the directory ...COMPB5 \ BITMAPS.
- Start COM PROFIBUS, then select the menu item File > Read GSD file.
   Result: The DP/PA coupler will be displayed in the hardware catalog for the slave configuration.
- 3. Configure the DP/PA coupler with COM PROFIBUS or other configuration software
- 4. Assign the parameters for the DP/PA coupler with COM PROFIBUS or other configuration software.
- 5. Save the configuration or download the configuration to the DP master.

#### Note

For installation instructions when using other configuration software, refer to the corresponding documentation.

# 7.4 Configuring with STEP 7

#### Introduction

The HSP for the configuration of a DP/PA coupler is integrated as of STEP 7 V5.4 and in PCS 7 7.0.

Configuration with STEP 7 as of V5.3 SP3 is possible via HW update (HSP0095).

## Installing the HW update in STEP 7 V3.3 SP3

- 1. Start STEP 7 and select the menu item Extras > Install new GSD file in the HW Config.
- In the next dialog box, select the HW update file to install, and confirm with "OK."
   Result: The DP/PA coupler FDC 157-0 will be displayed in the hardware catalog in the directory "PROFIBUS DP / DP/PA-Link" and can be configured with STEP 7

# Configuring DP/PA couplers with STEP 7 (from STEP 7 V5.4)

- 1. Start STEP 7 and open your SIMATIC station in the HW Config.
- 2. Drag a DP/PA coupler FDC 157-0 out of the hardware catalog from the directory "PROFIBUS DP / DP/PA link" to a DP master system (for S7 standard mode).

Result: The properties dialog for the PROFIBUS interface of the DP/PA coupler will be displayed.

- 3. Change the suggested address of the DP/PA coupler if necessary.
- 4. Assign parameters to the DP/PA coupler and confirm with OK.
- 5. If the DP/PA coupler is used redundantly then configure the partner DP/PA coupler. To do this repeat steps 2 to 4.
- 6. Save the configuration or download the configuration to the DP master.

#### Note

#### **PROFIBUS address**

Set the PROFIBUS addresses in the DP/PA couplers via the DIL switches.




Figure 7-1 Integrating DP/PA couplers in HW Config

# Configuring PA field devices

If you use multiple DP/PA couplers FDC 157-0 in one link then a topological assignment is not possible in HW Config. However you can review the assignment online via the local LifeList.

#### Additional information

Additional information on configuring the PA field devices is available in the manual PDM V 6.0 The Process Device Manager

(http://support.automation.siemens.com/WW/view/en/21407212)

# See also

Configuring the PROFIBUS PA master system (Page 124)

# 7.5 DP/PA coupler FDC 157-0 in the redundant DP/PA link

#### Introduction

In addition to the ring redundancy and coupler redundancy functions on the PA side, the DP/PA-coupler FDC 157-0 also supports redundancy on the PROFIBUS DP side. For this it is necessary to configure a redundant DP master system of an S7-400H with a redundant DP/PA link IM 153-2.

# Settings in HW Config

#### Note

Only the following configuration ensures that the DP/PA coupler FDC 157-0 can change to the other side of the DP/PA link without bumps if there is a switchover on the overlaid PROFIBUS DP chain.

If the DP/PA coupler FDC 157-0 will work as DP slave with diagnostic function then the following settings are required in the HW Config:

- In the object properties of the DP interface of the H-CPU, select the mode DP master and the DP mode DPV1.
- In the object properties of the DP/PA coupler, in the station parameters, select the DP alarm mode **DPV1**.




Figure 7-2 HW Config: Configuration of an S7-400H with DP/PA link and DP/PA couplers FDC 157-0

#### See also

Configuring DP/PA link (Page 122)

# 7.6 Parameters for diagnostic selection of the DP/PA coupler FDC 157-0

# **Device-specific parameters**

Parameters	Value range	Default setting	Efficiency range
Module status	disable	enable	Module
	• enable		
Status LifeList	disable	disable	Module
	• enable		
Channel-related diagnostics	disable	enable	Module
	• enable		
Coupler diagnostics	disable	enable	Module
	• enable		
Signal level monitoring	disable	disable	Module
	• enable		

# See also

Structure of the current value and voltage value (Page 167)

# 7.7 Setting the PROFIBUS address and redundancy mode

#### Introduction

Activate diagnostic functions of the DP/PA coupler FDC 157-0 by means of the PROFIBUS address. The DP/PA coupler is transparent in the DP/PA link with PROFIBUS address 0.

Activate the redundancy mode, ring redundancy or coupler redundancy on the DP/PA coupler pair and in the configuration.

#### Rules


- Valid PROFIBUS addresses are 1 to 125.
- Each PROFIBUS address may only be assigned once in the DP master system.
- The PROFIBUS addresses of both DP/PA couplers must be different.
- The PROFIBUS addresses set on the DP/PA coupler and in the configuration software must match.
- The redundancy mode set on the DP/PA coupler pair and in the configuration software must match.
- DP/PA coupler in the DP/PA link:
   The configured and set PROFIBUS addresses of the IM 153-2 must match.

# **Tools required**

Screwdriver with 3 mm blade

# Setting the PROFIBUS address and redundancy mode

- 1. Open the front door of the DP/PA coupler.
- 2. Set the PROFIBUS address at the DIL switches.
- 3. Set the redundancy mode at the DIL switches.
- 4. For center feed: If you loop the equipotential bonding line on the active field splitter (AFS) over the X2 cable bushing, then set the PA bus terminator switch to OFF on both DP/PA couplers.
- 5. Close the front door of the DP/PA coupler.



- 1 PA bus terminal switch
  - ON: Bus terminating resistor switched on (default setting).
  - OFF: Bus terminating resistor switched off.
- Set the PROFIBUS address.
- 3 Redundancy mode

ON: Ring redundancy.

OFF: Coupler redundancy (default setting).

# Changing the PROFIBUS address

You can change the PROFIBUS address that has been set at any time. However, the DP/PA coupler does not apply the new setting until the 24 VDC supply has been switched off / on.

Commissioning: DP/PA link

#### **Overview of Contents**

In this chapter you will learn which steps you must perform to commission the DP/PA link. These steps are explained in detail in the individual sub-sections.

# 8.1 Commissioning DP/PA link

#### Requirements

The following requirements must be met before you commission the DP/PA link:

- You have fully installed and wired the DP/PA link.
- You have fully installed PROFIBUS DP. PROFIBUS DP is ready to operate.
- You have fully installed PROFIBUS PA. PROFIBUS PA is ready to operate.

# Commissioning DP/PA link

- 1. Configure the DP/PA link.
- 2. Set the PROFIBUS address of the IM 153-2.
- 3. Switch on the voltage supply for the DP/PA link.
- 4. Download the configuration to the PLC.

# Configuring the DP/PA link

- The DP/PA link is configured for the S7 standard and redundant mode with STEP 7.
- For DP standard master mode, the DP/PA link is configured via DDBF file, for example using COM PROFIBUS.

The DP/PA couplers are transitions between the S7 backplane bus of the IM 153-2 and PROFIBUS PA with the PA field devices. Hence it is not necessary to configure the DP/PA coupler.

#### See also

Setting the PROFIBUS address of the IM 153-2 (Page 85)

# 8.2 Configuring for S7 standard or redundant mode

#### **Overview of Contents**

The DP/PA link is configured for the S7 standard and redundant modes with STEP 7.

# 8.2.1 Configuring DP/PA link

# Configuring DP/PA link

- 1. Start *STEP 7* and in HW Config open your SIMATIC or SIMATIC H station (for redundant mode).
- 2. Drag an IM 153-2 (6ES7153-2BAx2-0XB0) from the PROFIBUS DP\DP/PA link folder in the hardware catalog to a DP master system (for S7 standard mode) or to the redundant DP master system of an S7-400H (for the redundant mode).

Result: The Properties dialog for the PROFIBUS interface of the IM 153-2 is displayed.

3. If necessary, change the proposed address of the IM 153-2 in the higher level DP master system.

Result: After closing this dialog a dialog is displayed in which you can select the lower-level master system.

4. Select PROFIBUS PA and confirm with OK.




Figure 8-1 Dialog for selecting the lower-level master system (PROFIBUS PA)

Result: The DP/PA link is inserted into the higher level DP master system together with the lower-level PA master system.

#### DPV0 or DPV1 slave

It is only possible to operate the IM 153-2 as a DPV1 slave in conjunction with a DPV1 master. Only then can the additional functions (acyclical services) of a DPV1 slave be used.

In *STEP 7*, HW Config, the mode for the DP master being used can be selected in the Object Properties, if required: "S7-compatible" or "DPV1")

#### Switchover time in the redundant mode



Injury to persons may result.

With *STEP 7*V5.2 modified bus parameters can lead to longer switchover times in the H system when the IM 153-2 is used as a redundant DP slave.

# Example for the configuration of a DP/PA link for the redundant mode




Figure 8-2 HW Config DP/PA link in the hardware catalog




Figure 8-3 HW Config Minimum configuration of an S7-400H with DP/PA link

### See also

DP/PA coupler FDC 157-0 in the redundant DP/PA link (Page 117)

# 8.2.2 Configuring the PROFIBUS PA master system

#### Introduction

The PA field devices can be integrated in *SIMATIC PDM* or in *STEP 7* as standard slaves via their DDBF files.

# Configuring with STEP 7

- 1. If you have not done so so far, start *STEP 7* and in HW Config open your SIMATIC or SIMATIC H station (for redundant mode).
- 2. If the desired PA field devices are not displayed in the **PROFIBUS PA** file in the hardware catalog:
  - Import the GSD files of the PA field devices using the **Options > Install new GSD** menu command.
- 3. Drag the desired PA field devices from the hardware catalog to the PA master system that is displayed behind the IM 153-2.

#### Result

During configuration of the PA field devices HW Config checks that the quantity structure is adhered to and displays a relevant error message if it is exceeded.

# PROFIBUS address of the IM 153-2 in the PA master system

- In S7 standard mode the IM 153-2 uses the address 2.
- In redundant mode the two IM 153-2 use the addresses 1 and 2. In addition, the address 125 is blocked for PA field devices.

The first possible address for a PA field devices is 3 in both cases.

#### Editing the PA field devices in the user program

The process data of the PA field devices should only be accessed via the process images in the user program.

# 8.3 Configuring for DP standard master mode

# 8.3.1 GSD files

For DP standard master mode, the DP/PA link and the PA field devices are configured via GSD files, for example with *COM PROFIBUS*.

#### **GSD** files

Module IDs must be entered into the respective GSD file for each PA field device you wish to use in the DP/PA link. The software tool "GSD-Tool for IM 157 / IM 153-2" is available for this. It is available for download free of charge from the Internet (http://support.automation.siemens.com/WW/view/en/26562190).

The GSD files for the PA field devices supplied by Siemens AG are also to be found at this Internet address. Enter the search term "GSD" and select the "Downloads" search area.

# Creating a GSD file

Download the GSD Tool from the aforementioned Internet address and follow the accompanying instructions.

#### Note

# Disclaimer

Siemens AG assumes no liability for damage arising from using the GSD Tool; in particular not for personal, material or financial damage that constitutes consequential damage directly or indirectly connected to the use of the GSD Tool.

We offer no support for the application of the GSD Tool.

The GSD Tool creates the following GSD file from the added GSD files of the PA field devices to be used for the DP/PA link: sip58052.gsd for IM 153-2.

#### See also

GSD files for PA field devices (http://support.automation.siemens.com/WW/view/en/1581624)

# 8.3.2 Configuring DP/PA link

#### **Procedure**

Configure the DP/PA link using your configuration tool (for example *COM PROFIBUS*) like any other DP slave on PROFIBUS DP.

For this purpose download the complete GSD file for the DP/PA link to your configuration tool.

#### **NOTICE**

#### When configuring with GSD file

If a DP/PA link with IM 153-2BA02 is configured using the GSD file, it will not start because the "MLFB" user parameter is set to "6ES7 153-2BA01(2)-0XB0" or "6ES7 153-2BA81(2)-0XB0" by default.

If you use an IM 153-2BA02 or an IM 153-2BA82, then set the user parameter to 6ES7153-2BA02-0XB0 or 6ES7153-2BA82-0XB0.

# Parameter assignment and configuration frame

The frame length for parameter assignment depends on the number of PA field devices in use and may amount to a maximum of 223 bytes.

The frame length for parameter assignment depends on the number of PA field devices in use and may amount to a maximum of 244 bytes.

The structure of the parameter assignment and configuration frame is available for download from the Internet (http://support.automation.siemens.com/WW/view/en/13406349).

#### Restrictions

Functions that are based on reading the configuration prior to initially assigning the parameters for the DP/PA link, are not supported. For this reason for example the CP 5431 cannot be used as DP master. It is equally not possible to control variables with *COM PROFIBUS* until the DP/PA link parameters have been assigned.

# 8.3.3 How to configure PROFIBUS PA field devices

#### Requirement

The product designations for the required PA field devices must have been entered in the GSD file of the IM 153-2.

#### **NOTICE**

For redundant operation only those PA field devices may be configured that have the entries "Begin of Device" or "Begin of Device h supported" in their GSD file.

# Configuration principle

To configure the DP/PA link select the manufacturer's specifications for the PA field devices in your configuration tool (Product and, where applicable module designation). The specifications for the PA field devices must be entered in ascending order corresponding to their addresses.

An example of a configuration is shown in the figure below.

#### **Procedure**

- 1. In your configuration tool move to the DP slave configuration.
- Enter the manufacturer designation (for example SIEMENS SITRANS P) for the first PA field device in the "Order number" or "Module" field and apply this in the first slot. Set the PROFIBUS address for the PA field device.
  - Repeat this procedure for all PA field devices in use.
- 3. Terminate the entries and complete the configuration. The further procedure (for example saving, compiling, ...) is identical to other DP slaves.

# PROFIBUS address of the IM 153-2 in the PA master system

In the PA master system the IM 153-2 uses the address 2. The first possible address for PA field devices is 3.

#### Deployable transducers

Transducers may be used that accept a 10-byte parameter assignment frame.

#### Configuring with COM PROFIBUS

For SIMATIC S5 PA field devices are integrated via their GSD files as standard slaves in *COM PROFIBUS* (V3.1 and later).

- 1. Copy the GSD file of the IM 153-2 into the COM PROFIBUS directory: ...COMPBxx\GSD.
- 2. Start COM PROFIBUS and select the File > Read in GSD file menu command.
  - Result: The IM 153-2 is displayed in the hardware catalog during slave configuration.
- 3. Configure the PA field devices with COM PROFIBUS

# Example: View of configuration in COM PROFIBUS

The figure below shows an example of the view of a configuration for the DP/PA link using *COM PROFIBUS*.




Figure 8-4 Example of a configuration with COM PROFIBUS

# How to enter a PROFIBUS address

- 1. In the "Module" column select the "Begin of Device" of the relevant PA field device and select the "Parameter..." button.
- 2. In the "Value" column enter the desired PROFIBUS address and confirm with "OK".




Figure 8-5 Entering the PROFIBUS address

Commissioning: Y link

#### **Overview of Contents**

In this chapter you will learn which steps you must perform to commission the Y link. These steps are explained in detail in the individual sub-sections.

# 9.1 Commissioning Y link

# Requirements

The following requirements must be met before you commission the Y link:

- You have fully installed and wired the Y link.
- You have fully installed the H system and the redundant DP master system.
   PROFIBUS DP is ready to operate.
- You have fully installed the underlying DP master system and connected it to the Y coupler. PROFIBUS DP is ready to operate.

#### Commissioning Y link

- 1. Configure the Y link.
- 2. Configure the underlying DP slaves
- 3. Switch on the voltage supply for the Y link.
- 4. Set the PROFIBUS address of the IM 153-2.
- 5. Download the configuration to the PLC.

# Configuring the Y link

- The Y link is configure using STEP 7 for the redundancy mode.
- For DP standard master mode, the Y link is configured via GSD file, for example with *COM PROFIBUS*.

The Y coupler is a transition between the S7 backplane bus of the IM 153-2 and the underlying PROFIBUS DP with the DP slaves. Hence it is not necessary to configure the Y coupler.

# See also

Setting the PROFIBUS address of the IM 153-2 (Page 85)

# 9.2 Configuring for the redundancy mode

#### **Overview of Contents**

The Y link is configure using STEP 7 for the redundancy mode.

# 9.2.1 How to configure Y link

# Configuring Y link

The Y link is configure in STEP 7.

- 1. Start STEP 7 and in HW Config open your SIMATIC H station.
- 2. Drag an IM 153-2 (6ES7153-2BAx2-0XB0) from the PROFIBUS-DP\DP/PA link directory from the hardware catalog to the redundant DP master system of an S7-400H.

Result: The Properties dialog for the PROFIBUS interface of the IM 153-2 is displayed.

3. If necessary, change the proposed address of the IM 153-2 in the higher level DP master system.

Result: After closing this dialog a dialog is displayed in which you can select the lower-level master system.

4. Select PROFIBUS DP and confirm with OK.




Figure 9-1 Dialog for selecting the lower-level master system (PROFIBUS DP)

Result: The Y link is inserted into the redundant DP system. The default transmission speed of the lower-level DP master system is 1.5 Mbaud.

5. If you want to change the transmission speed of the lower-level DP master system, double-click on it.

Result: The dialog with the properties for the lower-level master system is displayed.

- Select the "Properties..." button.
  - Result: The "Properties PROFIBUS" dialog is displayed.
- In the "Network settings" tab select a transmission rate ranging from 45.45 kBaud to 12 MBaud and confirm with OK.

9.2 Configuring for the redundancy mode

# DPV0 or DPV1 slave

It is only possible to operate the IM 153-2 as a DPV1 slave in conjunction with a DPV1 master. Only then can the additional functions (acyclical services) of a DPV1 slave be used.

#### Switchover time in the redundant mode



Injury to persons may result.

With STEP 7V5.2 modified bus parameters can lead to longer switchover times in the H system when the IM 153-2 is used as a redundant DP slave.

# Example of how to configure a Y link




Figure 9-2 HW Config Y link in the hardware catalog




Figure 9-3 HW Config Minimum configuration of an S7-400H with Y link

# 9.2.2 Configuring underlying DP slaves

# Configuring underlying DP slaves

The underlying DP slaves are configured in STEP 7.

- 1. If you have not done so, start STEP 7 and in HW Config open your SIMATIC H station.
- 2. If the required DP slaves cannot be configured directly, import the relevant GSD files using the **Options > Install new GSD** menu command.
  - Result: The DP slaves are displayed in the **PROFIBUS-DP\Additional Field Devices** directory in the hardware catalog.
- 3. Drag the required DP slaves from the subdirectories of **PROFIBUS-DP** out of the hardware catalog to the underlying DP master system.
- 4. Configure the DP slaves using STEP 7.

#### Result

During configuration of the underlying DP slaves HW Config checks that the quantity structure is adhered to and displays a relevant error message if it is exceeded.

# PROFIBUS address of the IM 153-2 in the underlying DP master system

In the underlying DP master system the two IM 153-2 use the addresses 1 and 2. In addition, the address 125 is blocked for DP slaves. The first possible address for an underlying DP slave is 3.

#### Editing the DP slaves in the user program

The process data of the DP slaves should only be accessed via the process images in the user program.

# 9.3 Configuring for DP standard master mode

# 9.3.1 GSD files

For DP standard master mode, the Y link and the DP slaves are configured via GSD files, for example with *COM PROFIBUS*.

#### **GSD files**

Module IDs must be entered into the respective GSD file for each DP slave you wish to use in the Y link. The software tool "GSD-Tool for IM 157 / IM 153-2" is available for this. It is available for download free of charge from the Internet (http://support.automation.siemens.com/WW/view/en/26562190).

The GSD files for the DP slaves supplied by Siemens AG are also to be found at this Internet address. Enter the search term "GSD" and select the "Downloads" search area.

# Creating a GSD file

Download the GSD Tool from the aforementioned Internet address and follow the accompanying instructions.

#### Note

#### Disclaimer

Siemens AG assumes no liability for damage arising from using the GSD Tool; in particular not for personal, material or financial damage that constitutes consequential damage directly or indirectly connected to the use of the GSD Tool.

We offer no support for the application of the GSD Tool.

The GSD Tool creates the following GSD file from the added GSD files of the DP slaves to be used for the Y link: si058052.gsd for IM 153-2.

# 9.3.2 How to configure Y link

#### **Procedure**

Configure the Y link using your configuration tool (for example *COM PROFIBUS*) just like any other DP slave on PROFIBUS DP.

For this purpose download the complete GSD file for the Y link to your configuration tool.

#### **NOTICE**

#### When configuring with GSD file

If a Y link with IM 153-2BA02 is configured using the GSD file, it will not start because the "MLFB" user parameter is set to "6ES7153-2BA01(2)-0XB0" or "6ES7153-2BA81(2)-0XB0" by default.

If you use an IM 153-2BA02 or an IM 153-2BA82, then set the user parameter to 6ES7153-2BA02-0XB0 or 6ES7153-2BA82-0XB0.

#### Parameter assignment and configuration frame

The frame length for parameter assignment depends on the number of PA field devices in use and may amount to a maximum of 223 bytes.

The frame length for parameter assignment depends on the number and configuration of the DP slaves in use and may amount to a maximum of 244 bytes.

The structure of the parameter assignment and configuration frame is available for download from the Internet (http://support.automation.siemens.com/WW/view/en/13406349).

## Restrictions

Functions that are based on reading the configuration prior to initially assigning the parameters for the Y link, are not supported. For this reason for example the CP 5431 cannot be used as DP master. It is equally not possible to control variables with *COM PROFIBUS* until the Y link parameters have been assigned.

# 9.3.3 Configuring underlying DP slaves

# Requirement

The product designations for the required DP slaves must have been entered in the GSD file of the IM 153-2.

#### **NOTICE**

For the redundancy mode only those DP slaves may be configured that have the entries "Begin of Device" or "Begin of Device h supported" in their GSD file.

# Configuration principle

To configure the Y link select the manufacturer's specifications for the SP slaves in your configuration tool (Product and, where applicable, module designation). The specifications for the DP slaves must be entered in ascending order corresponding to their addresses.

An example of a configuration is shown in the figure below.

#### **Procedure**

- 1. In your configuration tool move to the DP slave configuration.
- Enter the manufacturer designation (for example SIEMENS ET 200S (IM151 BASIC) for the first DP slave in the "Order number" or "Module" field and apply this in the first slot. Set the PROFIBUS address for the DP slave.
  - Repeat this procedure for all of the DP slaves in use.
- 3. Terminate the entries and complete the configuration. The further procedure (for example saving, compiling, ...) is identical to other DP slaves.

#### PROFIBUS address of the IM 153-2 in the underlying DP master system

In the underlying DP master system the two IM 153-2 use the addresses 1 and 2. In addition, the address 125 is blocked for DP slaves. The first possible address for an underlying DP slave is 3.

# Configuring with COM PROFIBUS

For SIMATIC S5 the DP slaves are integrated via their GSD files as a standard slave in *COM PROFIBUS* (V3.1 and later).

- 1. Copy the GSD file of the IM 153-2 into the COM PROFIBUS directory: ...COMPBxx\GSD.
- Start COM PROFIBUS and select the File > Read in GSD file menu command.
   Result: The IM 153-2 is displayed in the hardware catalog during slave configuration.
- 3. Configure the DP slaves using COM PROFIBUS.

# Example: View of configuration in COM PROFIBUS

The figure below shows an example of the view of a configuration for the Y link using *COM PROFIBUS*.




Figure 9-4 Example of a configuration with COM PROFIBUS

# How to enter a PROFIBUS address

- 1. In the "Module" column select the "Begin of Device" of the relevant DP slave and select the "Parameter..."button.
- 2. In the "Value" column enter the desired PROFIBUS address and confirm with "OK".




Figure 9-5 Entering the PROFIBUS address

9.3 Configuring for DP standard master mode

Operation of the DP/PA-Link and Y-Link

10

#### **Terms**

Some of the following information applies to both the DP/PA link with its PA field devices and to the Y link with its underlying DP slaves. In such instances, the following terminology will be used for the sake of clarity:

- "Link" stands for DP/PA Link and Y Link
- "Slaves" stands for PA field devices and underlying DP slaves.
- "Underlying master system" stands for PA master system and underlying DP master system.

# 10.1 Start-up delay

#### **Definition**

During start-up, the link includes the slaves of the underlying master system in the data cycle. The slaves are parameterized and configured and the inputs of the slaves are read in.

To ensure a reproducible start-up and to prevent inadvertent switching of outputs, the link issues CLEAR frames on the underlying master system during this phase, i.e. the outputs of the slaves are put into a safe state.

# Configured startup characteristics

The start-up behavior depends on the configured startup characteristics relating to the plant configuration.

Table 10-1 Configured startup characteristics

Configured startup characteristics	Output data are output by the link if	
Starting if required configuration ≠ actual configuration	<ul> <li>all of the slaves are parameterized and configured, or</li> <li>The start-up delay has expired and fewer slaves have been parameterized / configured than had been planned for.</li> </ul>	
Starting if required configuration = actual configuration	all of the slaves are parameterized and configured. Comment: If during the start-up delay not all slaves are configured or parameterized, the link automatically repeats the start-up.	

The status of the start-up delay can be evaluated in the "Status Message" diagnostic block of the diagnostic frame.

10.2 Behavior after certain events in the redundancy mode

# 10.2 Behavior after certain events in the redundancy mode

# Behavior of the IM 153-2

The table below shows the behavior of the IM 153-2 following certain events in the redundancy mode.

Table 10-2 Behavior after certain events in the redundancy mode

Event	Response
Master-reserve switchover with a modified configuration	The link is switched over bumpless from the active channel to the channel that has up to now been passive.
Failure of a CPU	If this causes the active channel of the redundant DP master system to fail: see failure of the active channel.
	Otherwise: see failure of the passive channel.
Failure of the active channel.	The link is switched over bumpless from the active channel to the channel that has up to now been passive.
	The channel that has failed is displayed with the relevant IM 153-2 by the "BF" 1 LED.
Failure of the passive channel.	No impact on the link.
	The channel that has failed is displayed with the relevant IM 153-2 by the "BF" 1 LED.
Failure of an IM 153-2	A diagnostic message is generated in the system.
	If the active IM 153-2 fails, there is a bumpless switchover to the channel that has been passive up till then.

# 10.3 Startup characteristics

# 10.3.1 Startup characteristics of the DP/PA link in non-redundant mode

#### Startup characteristics

The flow chart below shows the startup characteristics of the IM 153-2 after POWER ON.




Figure 10-1 Startup characteristics of the IM 153-2 after POWER ON

#### 10.3 Startup characteristics

# Prerequisite for start-up of the IM 153-2

- A valid PROFIBUS address is set on the IM 153-2.
- The DP master on the higher level PROFIBUS DP is in operation.
- The link is correctly configured.

The further startup characteristics of the DP/PA link depends on whether it is working in the non-redundant or redundancy mode.

# 10.3.2 Startup characteristics in redundancy mode

#### Starting diagram of the IM 153-2 on S7-400H

During start-up the two IM 153-2 respond independently of one another:

- Each DP master configures and patameterizes its IM 153-2 (independently from other DP masters) and sends the the corresponding configuration.
- In failure-free operation the IM 153-2 is activated that is connected to the subsystem of the master CPU.
- As soon as the other DP master has also configured and parameterized its IM 153-2 correctly and has sent the configuration in full, the IM 153-2 is available as a reserve.

The IM 153-2 on the subsystem of the reserve CPU is passive. If the active IM 153-2 the other is able to continue editing the slaves.

The figure below shows a simplified representation of the mutually independent behavior of the two IM 153-2.

·

IM 153-2 on the subsystem of the master CPU

IM 153-2 on the subsystem of the master CPU




Figure 10-2 Startup characteristics of the two IM 153-2 in the redundancy mode

# Starting of the IM 153-2 with flying redundancy

For flying redundancy only one IM 153-2 is configured and parameterized. The second IM 153-2 is not configured and parameterized; it is nevertheless ready for a switchover.

# 10.4 CP 342-5 behind a Y link in a redundant DP master system

# Validity

The following applies only if you have placed a CP342-5 behind a Y link, which in turn is part of a redundant DP master system.

# Reading and writing with the SFC 14/15 or SFC 24/25

If a CP 342-5 is operated behind a Y link in a redundant DP master system, you must make sure that the CP is always inserted in its rack.

If the CP is not inserted, the return values of the programming blocks SFC 14/15 and SFC 24/25 are defective.

. 10.4 CP 342-5 behind a Y link in a redundant DP master system Maintenance and service

# 11.1 Replacing IM 153-2 or Y couplers

### How to replace defective modules

Perform the following steps to replace a defective IM 153-2 or a defective Y coupler.

- 1. Disconnect the power supply of the faulty module.
- 2. Unplug the bus connector from the PROFIBUS DP interface of the defective module.
- 3. Replace the defective module.
- 4. Plug the bus connector into the PROFIBUS DP interface of the new module.
- 5. Connect the power supply of the new module,

#### In case of redundancy

#### Note

When replacing the active IM 153-2 ("ACT" LED ON), the link will only continue to run smoothly, if:

- on the passive IM 153-2 the BF LED is neither lit up or flashing, nor is the SF LED flashing in 0.5 Hz cycles
- it in a flying redundancy system it is apparent from the master diagnostics that both IMs are available. In this case, the BF LED can flash.

Have you replaced an active IM 153-2 ("ACT" LED on)?	Have you replaced a passive IM 153-2 ("ACT" LED off)?		
In this case in the link there was a switchover to the other IM 153-2 and this also upholds the data traffic to its DP master.	No change in data traffic The active IM 153-2 has upheld the data traffic to its DP master.		
Does the new IM 153-2 have a different product status than the other one that has not been			

# replaced?

If after replacement the IM 153-2 that has just been replaced goes "into STOP" (all LEDs flashing), then the versions are not compatible. In this case you must switch off the link and upgrade both IM 153-2 or use a compatible version.

Please contact your Siemens representative.

# 11.2 Replacing DP/PA couplers

### Requirement

If replacing a DP/PA coupler FDC 157-0, its ACT LED should not light up. If the ACT LED is illuminated, then multiple PA field devices can fail.

## Replacing DP/PA couplers

To replace a defective DP/PA coupler, perform the following steps:

- 1. Disconnect the power supply of the faulty module.
- 2. Disconnect the PROFIBUS PA connection of the defective module.
- 3. Unplug the bus connector from the PROFIBUS DP interface of the defective module.
- 4. Replace the defective module.
- 5. When using the diagnostic function of the DP/PA coupler FDC 157-0: Set the PROFIBUS address at the DIL switches.
- 6. When using the redundancy mode of the DP/PA coupler FDC 157-0: Set the redundancy mode at the DIL switches.
- 7. Connect the PROFIBUS PA to the new DP/PA coupler.
- 8. Plug the bus connector into the PROFIBUS DP interface of the new module.
- 9. Connect the power supply of the new module,

## Change systems to redundancy

To use the ring redundancy or coupler redundancy, you can upgrade an existing system by means of DP/PA couplers FDC 157-0. Install the redundant DP/PA coupler pair to the right of the remaining DP/PA couplers (max. 3).

Use the BM FDC 157-0 bus module for the redundant DP/PA coupler pair.

# 11.3 Replacing the active field distributor AFD / AFS



#### **Explosion hazard**

In mixed operation with AFDiS, disconnect the DP/PA coupler from the power supply before you replace active field distributors AFD or AFS.

## Replacing active field distributors (AFD)

You can replace the AFD during operation.

Perform the following steps to replace the defective field distributor:

- 1. Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Disconnect the PA1 and PA2 main lines from the AFD.
- 3. Disconnect the PA field devices from the AFD.
- 4. Replace the defective module.
- 5. Connect the PA field devices to the new AFD.
- 6. Connect the PA1 and PA2 main lines to the new AFD.
- 7. Tighten the 4 screws on the enclosure.

## Replacing active field splitter (AFS)

Perform the following steps to replace a defective active field splitter (AFS):

- 1. Remove the 4 screws of the enclosure cover using a Phillips screwdriver.
- 2. Disconnect the equipotential bonding line from the AFS.
- 3. Disconnect the PA1 and PA2 main lines from the AFS.
- 4. Replace the defective module.
- 5. Connect the equipotential bonding line to the new AFS.
- 6. Connect the PA1 and PA2 main lines to the new AFS.
- 7. Tighten the 4 screws on the enclosure.

#### See also

Replacing/supplementing the AFDiS (Page 56)

#### 11.4 Firmware update

# 11.4 Firmware update

## 11.4.1 When should you update the IM 153-2?

Following (compatible) functional extensions or improvements to performance you should update the IM 153-2 interface module to the respective most recent firmware version.

## 11.4.2 Update of the IM 153-2

#### Where can you obtain the most recent firmware version?

You can obtain the most recent firmware versions from your Siemens representative, or download it from the Internet for the following interface module:

- IM153-2BAx1 (http://support.automation.siemens.com/WW/view/en/15350678)
- IM153-2BAx2 (http://support.automation.siemens.com/WW/view/en/29230295)

#### Tip:

- Make a note of your current firmware version before you start the update.
- If you encounter problems with the new firmware, you can also download the previous (current) firmware from the Internet and transfer it to the interface module again.

## **Principle**

An update is possible with IM 153-2 as of order number 6ES7153-2BAx1-0XB0. For this you require *STEP 7*V5.4 and later.

There are two ways to update the module:

- directly via PROFIBUS DP
- from the PG / PC via PROFIBUS DP and CPU

After a successful update, a sticker with the updated status of the firmware should be affixed to cover the previous status of the firmware of the IM 153-2.

With the interface modules IM 153-2BAx2-0XB0 it is possible to update the firmware of both interface modules while the redundant mode is running. Updating takes place with the support of *STEP 7* and has no retroactive effect on the current application. The firmware in a redundant system is (directly) updated by the PG / PC via PROFIBUS DP.

### Requirements for updating via PROFIBUS DP

- The IM 153-2 in the station that is to be updated, must be accessible online.
- The files with the current (new) firmware version must be available in the file system of your PD / PC.

To update a redundant system there are two additional requirements:

- Both interface modules are IM 153-2BAx2-0XB0 and are configured as such.
- The link with redundant IM 153-2 is operated
  - on S7-400H
  - on any redundant DP masters with GSD as of rev. 5

An update of both interface modules in a redundant system supported by *STEP 7* is **not** possible if the IM 153-2Bxx2-0XB0 modules are operated as spare parts for older interface modules (for example IM 157).

## Sample configuration

#### Update directly via PROFIBUS DP

The PD / PC with the update files is connected directly to the PROFIBUS interface of the IM 153-2 (see figure below).

In the SIMATIC Manager select the **PLC > Accessible nodes** menu command. In the list that is displayed select the required IM 153-2 and select the **PLC > PROFIBUS > Update firmware** menu command. The remaining procedure is described in the *STEP 7* online help.




Figure 11-1 Update directly via PROFIBUS DP (PG / PC is directly connected to the IM 153-2)

#### 11.4 Firmware update

#### Update via MPI to the CPU and on via PROFIBUS DP

The PD / PC with the update files is connected to the MPI interface of the CPU. The IM 153-2 is connected to the 2nd interface of the CPU via PROFIBUS DP. The IM 153-2 has to be integrated into the STEP 7 project on the CPU.

Open HW Config and select the desired IM 153-2. Select the **PLC > Update firmware** menu command. The remaining procedure is described in the *STEP 7* online help.




Figure 11-2 Update via MPI to CPU and on via PROFIBUS DP (PG / PC is connected to CPU)

#### Restart after update

In the STEP 7 user interface it is possible to set whether

 the IM 153-2 automatically executes a reset after a successful update to start with the newly uploaded firmware.



If the "Activate firmware after downloading" box is ticked, there will be a brief link failure. If you have not made any provisions for this situation, the update will cause a CPU STOP as a result of rack failure.

• The IM 153-2 must be reset by switching off the supply voltage before the IM 153-2 starts up with the new firmware when the supply voltage is switched on.

If the update was concluded successfully, the start up of the IM 153-2BAx2 takes **around 60 seconds longer** with the first resetting or switching off/on of the power supply than it would with a normal start up.

All further start ups will take the usual time.

## Update not successful

If the update fails, after the supply voltage is switched on / off the IM 153-2 automatically starts with the ("old") firmware that was current up to that time.

# 11.5 Maintenance

### Maintenance

The transfer characteristics of the DP/PA couplers, the active field distributors (AFD) and active field splitters (AFS) are stable over long periods and regular maintenance is unnecessary.

11.5 Maintenance

Functions 12

## 12.1 IM 153-2

# 12.1.1 Time synchronization on the underlying master system

### **Properties**

The IM 153-2 interface module, 6ES7153-2BAx1-0XB0 and higher, supports time synchronization on the lower-level master system.

- The IM 153-2 sends the current time to the lower-level master system whenever
  - a time synchronization takes place on the higher level PROFIBUS DP,
  - if a valid configuration for the lower-level mastersystem is available in the IM 153-2,
     and
  - the lower-level master system is operating.
- Synchronization on the lower-level master system takes place at the synchronization intervals that have been set on the higher level PROFIBUS DP.
- Compared to the time received on the higher level PROFIBUS DP, accuracy deteriorates slightly. Accuracy within 10 ms is always guaranteed.

#### Operating steps for activation

You activate the time synchronization on the lower-level master system by performing the following steps:

- 1. Complete the higher level PROFIBUS DP with the time master.
- 2. Activate the time synchronization in the Properties of the DP master.

#### Note

In the H system you have to insert a time master in both higher level PROFIBUS DP systems and activate the time synchronization in the Properties of the DP master.

Time synchronization then takes place in the lower-level master system.

## Time-of-day format

The time-of-day is distributed to the lower-level system in the ISP format.

In this process the entire ISP frame is transferred in exactly the format that the IM 153-2 receives from the higher level PROFIBUS DP.

The configuration of the frame and the sequence are described in: InterOperable Systems ™ Project, Fieldbus Specification, System Management Services Rev. 3.0 dated 19.10.1993 (compiled by ISP Foundation) 12.1 IM 153-2

## 12.1.2 Redundancy with IM 153-2

#### Usage

You can operate the IM 153-2BAx2 redundantly

- on SIMATIC S7-400H (for example in the Y link on CPU 417-4H)
- according to standard Specification Slave Redundancy V1.2, Nov. 2004 of the PROFIBUS User Organization; Order No: 2.212
  - System Redundancy (SR)
  - Flying Redundancy (FR)

#### Requirements

Installation on active bus modules

The 6ES7195-7HD10-0XA0 and 6ES7195-7HD80-0XA0 bus modules ensure high availability of the link and shorter switchover times with redundancy.

2 x IM 153-2 on BM IM/IM bus module

The arrangement specifications on the Internet (<a href="http://support.automation.siemens.com/WW/view/en/23372259">http://support.automation.siemens.com/WW/view/en/23372259</a>) apply to the active bus modules and interface modules used.

- System Redundancy (SR) is possible with IM 153-2 as of 6ES7153-2BAx1-0XB0.
- Flying Redundancy (FR) is possible with IM 153-2 as of 6ES7153-2BAx1-0XB0.
  - The redundant master system must be configured according to the requirements made of H systems.
  - For configuring Flying Redundancy the current version of the Java GSD creation tool is required.

#### Note

STEP 7 provides no support for configuring an H system with flying redundancy.

The SYNC/FREEZE function must not be activated during the redundancy mode.

#### Note

If the SYNC / FREEZE in a redundant system is activated nevertheless the user bears the responsibility for the behavior of the H system (for example when switchovers take place).

 You can only use the IM 153-2 in a redundant system on DP masters that support the "Fail-safe" parameter. On DP masters that do not support this parameter, the IM 153-2 will not start and the BF LED flashes.

Tip: You can tell from the GSD file of the DP master whether it supports "Fail-safe".

### Compatible versions

If you use the DP/PA link or Y link in a redundant configuration you must use compatible versions for the two IM 153-2.

You can replace compatible versions of the IM 153-2 interface module with "System modification during operation".

Please refer to the chapter *Compatibility to precursor modules* for information on compatibilities and arrangement rules.

#### Note

The functionalities that can be used are limited to the respective lower order numbers or the earlier version.

#### S7-400H as DP Master

You require *STEP 7*V5.0 or later and the *SIMATIC S7 H Systems* software package to configure the S7-400H system. With *STEP 7*V5.3 or later you no longer require *SIMATIC S7 H-Systems* additionally.

DP master 1 and DP master 2:

- Execute the same user program
- Have the same parameter assignment and configuration for the IM 153-2.

### Availability in redundancy mode

## **CAUTION**

## Voltage supply for the IM 153-2

Set a separate power supply module for each IM 153-2. This ensures availability in redundant mode with 2 x IM 153-2.

#### See also

Compatibility with predecessor modules (Page 37)

12.1 IM 153-2

## 12.1.3 Reading and writing data records

## Procedure for reading and writing data records

Depending on the operating mode of the DP master (S7-compatible or DPV1), data records of the IM 153-2 and the underlying slaves can be read and written by different methods.

- Reading data records with SFC 59 "RD\_REC" or SFB 52 "RDREC"
- Writing data records with SFC 58 "WR\_REC" or SFB 53 "WRREC"
- Reading and writing data records with a PD / PC via communication links, for example with SIMATIC PDM

Table 12- 1 Procedure for reading and writing data records

	S7-compatible DP master	DPV1 master
Data records of the IM 153-2	<ul><li>SFC 59 "RD_REC"</li><li>Reading with PD / PC</li></ul>	<ul> <li>SFC 59 "RD_REC", SFB 52 "RDREC"</li> <li>SFC 58 "WR_REC", SFB 53 "WRREC"</li> <li>Writing / reading with PD / PC</li> </ul>
Data records of underlying slaves	<ul><li>SFC 58 "WR_REC"</li><li>SFC 59 "RD_REC"</li><li>Writing / reading with PD / PC</li></ul>	<ul> <li>SFC 59 "RD_REC", SFB 52 "RDREC"</li> <li>SFC 58 "WR_REC", SFB 53 "WRREC"</li> <li>Writing / reading with PD / PC</li> </ul>

## Data records of the IM 153-2

Depending on the operating mode of the DP master (S7-compatible or DPV1) the IM 153-2 supports reading and writing of the following data records:

- on the DPV1 master:
  - Data records 0 and 1 (diagnostics data, read only)
  - Data records 255 ...(I&M data)
- on the S7-compatible master
  - Data records 0 and 1 (diagnostics data, read only)

## Parameters for SFC 58 "WR\_REC" and SFC 59 "RD\_REC"

You will find the values required for the call parameters LADDR and REC\_NUM and possible error information in the return value RET\_VAL in the table below.

Table 12-2 Call parameters for SFC 58 "WR\_REC" and SFC 59 "RD\_REC"

	LADDR	REC_NUM	Access
Diagnostic data of the IM 153-2	Diagnostic address of the IM 153-2	0 or 1	read only
I&M data of the IM 153-2	Diagnostic address of the IM 153-2	255	read / write
buffered diagnostic data of an underlying slave (out of the IM 153-2) <sup>1</sup>	Diagnostic address of the IM 153-2	PROFIBUS address of the underlying slave	read only
random data record of an underlying DPV1 slave	logical address of the underlying slave or the underlying module <sup>3</sup>	Data record number <sup>2</sup>	read / write <sup>2</sup>

<sup>&</sup>lt;sup>1</sup> Only on the DPV1 master and for configured slaves

#### Error information of the IM 153-2

Table 12-3 Error information of the IM 153-2

RET_VAL (W#16#)	Description
0000	No error
80B6	The slave or module refuses to read / write a data record or does not recognize this data record.
	⇒ set mode of the DP master to DPV1
80BB	Requested service is not supported
80BC	Node not available
80BD	Data record number incorrect

The other functions of the SFC 58 "WR\_REC", SFC 59 "RD\_REC", SFB 52 "RDREC" and SFB 53 "WRREC" are described in the *STEP 7* online help.

<sup>&</sup>lt;sup>2</sup> depending on the type of the underlying slave or underlying module

<sup>&</sup>lt;sup>3</sup> specify data record of slot 0 ⇒ diagnostic address specify data record of slot 1 ⇒ address of slot 1 specify data record of slot 2 ⇒ address of slot 2 and so on.

12.1 IM 153-2

## 12.1.4 Identification and maintenance data (I&M data)

#### **Definition and features**

Identification and maintenance data (I&M) is information stored in a module to support you in

- Checking the plant configuration
- Locating hardware modifications in a plant
- Correcting errors in a plant

Identification data (I data) are information on the module, such as order number and serial number, some of which are printed onto the module enclosure. I data are manufacturer information about the module and are for reading only.

Maintenance data (M data) are system-related information, such as the installation location and installation date. M data are created during configuration and written onto the module.

Modules can be uniquely identified online by means of the I&M data. As of IM 153-2BAx1, this data is available on the DP/PA link and Y link.

#### Note

Only one DP master can access the I&M data of a DP/PA link or Y link at any given point in time.

#### Reading and writing the I&M data with STEP 7

In *STEP 7* the I&M data are displayed in the "Module status - IM 153-2" and "Properties - DP slave" tabs (please refer to the *STEP 7*) online help.

The M data of modules can be entered in HW Config (for example in a dialog box during configuration).

The I&M data are accessed in accordance with the IEC 61158-6 standard.

In the H system the interface module from which the I&M data are to be read must be accessible online.

### Reading and writing the I&M data without STEP 7

If you want to use the I&M data without using *STEP 7* you must access the data as specified in the PROFIBUS Guideline – Order No. 3.502, Version 1.1 of May 2003.

You must address the interface module (slot 245 or 246) from which the I&M data are to be read in theH system. Slot 245 identifies the left-hand interface module, slot 246 the right-hand interface module on the BM IM/IM.

# Example for reading the I&M data

The user can specifically access certain I&M data via **Read data record**. This requires a two-stage access:

1. A directory is stored in data record 248 containing the data record numbers belonging to the various indices (see table below).

Table 12- 4 DS 248 configuration for DP/PA link or Y link

Content	Length (bytes)	Coding (hex)
Header information		
ID of content directory	2	00 01
Index of content directory	2	00 00
Length of successive blocks in bytes	2	00 08
Number of blocks	2	00 05
Block information for I&M data		
SZL-ID	2	F1 11
relevant data record number	2	00 EA
Length of data record	2	00 40
Index	2	00 01
SZL-ID	2	F1 11
relevant data record number	2	00 EB
Length of data record	2	00 40
Index	2	00 02
SZL-ID	2	F1 11
relevant data record number	2	00 EC
Length of data record	2	00 40
Index	2	00 03
SZL-ID	2	F1 11
relevant data record number	2	00 ED
Length of data record	2	00 40
Index	2	00 04
8 bytes of block information for additional data	record objects	
	Σ: 48	

#### 12.1 IM 153-2

2. The section of the I&M data that is assigned to the corresponding index is to be found under the relevant data record number (see table below: *Structure of the I&M data*).

The length of all data records with I&M data is 64 bytes.

The data records are structured according to the principle shown in the following table.

Table 12-5 Structural principle of data records with I&M data

Content	Length (bytes)	Coding (hex)
Header information		
SZL-ID	2	F1 11
Index	2	00 0x
Length of the I&M data	2	00 38
Number of blocks with I&M data	2	00 01
I&M data		
Index	2	00 0x
I&M data relating to the respective index (see table below)	54	

### Structure of the I&M data

The data structures of the I&M data correspond to the specifications of the PROFIBUS Guideline – Order No. 3.502, Version 1.1 of May 2003.

Table 12- 6 Structure of the I&M data

I&M data	Access	Default setting	Explanation		
Identification data 0: Index 1	Identification data 0: Index 1 (data record 234)				
MANUFACTURER_ID	Read (2 bytes)	2A hex (= 42 dec)	The name of the manufacturer is stored here. (42 dec = SIEMENS AG)		
ORDER_ID	Read (20 bytes)	depending on the module	The order number of the module is stored here.		
SERIAL_NUMBER	Read (16 bytes)	depending on the module	The order number of the module is stored here. This facilitates unique identification of the module.		
HARDWARE_REVISION	Read (2 bytes)	depending on the module	The order version of the module is stored here. Is increased when the product release or the firmware of the module changes.		
SOFTWARE_REVISION	Read (4 bytes)	Firmware version	Gives information on the firmware version of the module If the firmware version number is increased, then the product release of the module (HARDWARE_REVISION) is also increased.		
REVISION_COUNTER	Read (2 bytes)	0000 hex	Reserved		
PROFILE_ID	Read (2 bytes)	F600 hex	Generic Device		
PROFILE_SPECIFIC_TYPE	Read (2 bytes)	0005 hex	on interface modules		
IM_VERSION	Read (2 bytes)	0101 hex	Gives information on the version of the I&M data. (0101 hex = Version 1.1)		
IM_SUPPORTED	Read (2 bytes)	000E hex	Gives information on the existing I&M data. (Index 2 bis 4)		

I&M data	Access	Default setting	Explanation	
Maintenance data 1: Index 2	(data record 235)			
TAG_FUNCTION	Read / write (32 bytes)	_	Enter a system-wide unique identification for the module here.	
TAG_LOCATION	read / write (22 bytes)	_	Enter the installation location of the module here.	
Maintenance data 2: Index 3	Maintenance data 2: Index 3 (data record 236)			
INSTALLATION_DATE	Read / write (16 bytes)	_	Enter the installation date for the module and, if necessary, the relevant time.	
RESERVED	Read / write (38 bytes)	_	Reserved	
Maintenance data 3: Index 4 (data record 237)				
DESCRIPTOR	Read / write (54 bytes)	_	Enter a comment on the module here.	

#### Changes compared to the I&A data up to now

To date the I&A data were extended to include some content in the identification data in accordance with the PROFIBUS Guideline. The mechanism for accessing I&M data was amended in accordance with the PROFIBUS Guideline.

#### See also

Reading and writing the identification and maintenance data (I&M data) (Page 163)

## 12.1.5 System modification during operation.

## 12.1.5.1 System modification in S7 standard mode

#### **Procedure**

Perform the following steps to add a complete new DP/PA link including the underlying PA master system to an existing system while it is operating.

- 1. Mount the new DP/PA link.
- 2. Connect the voltage supply of all of the modules,
- 3. Connect the PROFIBUS PA to the new DP/PA couplers.
- 4. Plug the bus connector of the DP master system into the PROFIBUS DP interface of the new IM 153-2.

The whole sequence of a system modification and the requirements that must be met for it are described in detail in the function manual *System modification during operation by means of CiR*.

You will find the manual on the Internet at this address (http://support.automation.siemens.com)

Search for the entry with the number 14044916.

12.1 IM 153-2

### 12.1.5.2 System modification in redundancy mode

#### **Procedure**

Perform the following steps to add a complete new DP/PA link or Y link including the underlying master system to an existing system while it is operating.

- 1. Mount the new link.
- 2. Connect the voltage supply of all of the modules,
- 3. DP/PA link only

Connect the PROFIBUS PA to the new DP/PA couplers.

#### Y link only

Plug the bus connector of the DP master system onto the PROFIBUS DP interface of the new Y coupler.

- 4. Plug the bus connector of the active channel of the redundant DP master system onto the PROFIBUS DP interface of one of the IM 153-2.
- 5. Plug the bus connector of the of the passive channel onto the PROFIBUS DP interface of the other IM 153-2.

This sequence is summarized as a single step "Reconfigure the hardware" in the manual: *Automation system S7-400H, high availability systems* in the chapter: *System modifications during operation*. It gives a detailed description of the entire sequence of a system modification.

You will find the manual on the Internet at this address (http://support.automation.siemens.com)

Search for the entry with the number 1186523.

# 12.2 DP/PA coupler FDC 157-0

# 12.2.1 Reading and writing the identification and maintenance data (I&M data)

## Procedure for reading I&M data

You can read and write the identification data in one of the following ways:

- with STEP 7
- Via user interfaces
- Via communication links
- With the upload / download mechanism

## Reading and writing the I&M data with STEP 7

HW Config shows the I&M data in the "Module status - DP/PA coupler" and "Properties - DP slave" tabs.

The I&M data are accessed in accordance with the IEC 61158-6 standard.

### Reading and writing the I&M data with STEP 7

Writing I&M data with a PD / PC via communication links, for example with *SIMATIC PDM* Write the parameters and I&M data via the following menu items:

- File > Read full upload to PG / PC.
- Device > Full download to device.

## Reading and writing the I&M data via user interfaces

Load data records 231 to 234 of the DP/PA coupler. Data record 231 is read-only.

- Reading data records with SFC 59 "RD\_REC" or SFB 52 "RDREC".
- Write data records with SFC 58 "WR REC" or SFB 53 "WRREC".

### Reading and writing the I&M data with the upload / download mechanism

Use data record 255 of the DP/PA coupler.

The I&M data is accessed in accordance with the standard *PROFIBUS Guideline, Profile Guidelines Part 1: Identification & Maintenance Functions*, March 2005.

#### Additional information

For additional information about SIMATIC PDM, refer to the *PDM V6.0 The Process Device Manager* manual at (Page 158):

#### See also

PDM V6.0 The Process Device Manager (http://support.automation.siemens.com/WW/view/en/21407212)

12.2 DP/PA coupler FDC 157-0

# 12.2.2 Reading the local LifeList

#### **Local LifeList**

The local LifeList renders the status of the PA field device on the equipotential bonding line.

If the DP/PA coupler is used in the DP/PA link, then connected PA field devices are only visible in the local LifeList if they are also configured.

#### Reading the local LifeList

To read the local LifeList, you have the following options:

- The local LifeList is displayed in graphical form using SIMATIC PDM.
- Via user interfaces:

Reading data records with SFC 59 "RD\_REC" or SFB 52 "RDREC".

Load data record 50 of the DP/PA coupler.

Via the PROFIBUS DP slave diagnostics

Every change to the equipotential bonding line leads to a PROFIBUS DP diagnosis.

#### Note

#### Updating the local LifeList

Updating the local LifeList depends on the number of PA field devices. Updating and configuring can take approx. 1 minute.

## Additional information

For Additional information about SIMATIC PDM, refer to the *PDM V6.0 The Process Device Manager* manual at:

Internet (http://support.automation.siemens.com/WW/view/en/21407212)

# 12.2.3 Read out of the current value and voltage value

## 12.2.3.1 User data of the DP/PA coupler

#### User data of the DP/PA coupler

The DP/PA coupler with diagnostics functions has input data only. The data contains the current value on the equipotential bonding line and optional voltage on the equipotential bonding line.

The variables are represented in IEEE 754 format with one byte quality code in accordance with PROFIBUS PA profiles. This is the Float Format to IEEE Standard 754 Short Real Number (floating point format).

## Reading the current values and voltage values

You can read the current values and voltages values in one of the following ways:

- PROFIBUS DP (PAE of the CPU)
- Reading data records with SFC 59 "RD\_REC" or SFB 52 "RDREC".
   Load data record 56 of the DP/PA coupler.
- Reading records with a PG / PC via communication links, for example with SIMATIC PDM.

12.2 DP/PA coupler FDC 157-0

#### User data frame structure

The presentation of a tag in IEEE 754 format requires 4 bytes + 1 status byte. The status byte informs you about the validity of the measured value.




Figure 12-1 User data frame structure

#### Note

#### Input data

- Only the actively energizing DP/PA coupler delivers a valid PA current vale to slot 1 in the redundant structure.
- If you insert slot 2 in HW Config, then the passive DP/PA coupler delivers a valid PA voltage value in the redundant structure.
- Only the PA current value is delivered in stand-alone mode.

## Voltage measurement on the equipotential bonding line


The optional configuration of slot 2 for voltage measurement on the equipotential bonding line is only possible in a setup with ring redundancy. The PA voltage can be measured on the end of the cable only, i.e. on the passive DP/PA coupler.

The maximum PA voltage on the actively energizing DP/PA coupler is about 31 V.

## 12.2.3.2 Structure of the current value and voltage value

## Measured values in IEEE format (byte x to byte x+3)

Below you can see the presentation of a measured value in IEEE format, and the conversion into a decimal value.



Example: Conversion of an IEEE value to decimal value





Figure 12-2 Conversion of an IEEE format to decimal value

## 12.2 DP/PA coupler FDC 157-0

## Syntax of an IEEE status byte (byte x+4)

The syntax of the status byte corresponds to the PROFIBUS PA profile. The following status codes are used with the DP/PA coupler:



Quality: describes the fundamental quality of the measured value

Status codes:	
00 0000 00 (0H)	bad, non-specific
00 1000 11 (23H)	uncertain (initial value), (non-measured value)
00 1001 00 (24H)	bad (maintenance alarm), (short circuit, wire break, PA redundancy fault, DP/PA coupler defect, bad signal level)
00 1001 01 (25H)	bad (maintenance alarm), Lower limit violated
00 1001 10 (26H)	bad (maintenance alarm), Upper limit violated
01 1010 00 (68H)	uncertain (maintenance demanded), Parameterization error, redundancy mode of partner incorrect
01 1010 01 (69H)	uncertain (maintenance demanded), Lower limit violated
01 1010 10 (6AH)	uncertain (maintenance demanded), Upper limit violated
10 0000 00 (80H)	good, O.K. (no error)
10 0000 01 (81H)	good, Lower limit violated
10 0000 10 (82H)	good, Upper limit violated

Figure 12-3 Syntax of an IEEE status byte

#### Note

#### Maintenance alarm / maintenance demanded

The status codes linked to "maintenance alarm" or "maintenance demanded" are only displayed if the diagnostics of the DP/PA coupler are activated.

The status codes influence the respective bits in the PA status of the diagnostics frame.

### Limits

The following limit values are preset:

• PA current: Lower/upper limit: 0 mA / 1000 mA

• PA voltage: Lower/upper limit: 15.5 V/35 V

You can change the limit values in data record 128 of the DP/PA coupler.

Errors when writing the data record mean that current or default limit values are not used. The data record is unacknowledged.

### 12.2.4 Data records

You need this information if you go beyond the standard applications from STEP 7 and SIMATIC PDM.

#### Requirements

The DP/PA coupler gives the user data records that are addressed via slot 0 or 1.

The PROFIBUS DP data records are based on the PROFIBUS PA profile.

The profile is available from PROFIBUS International (PI) on the Internet at:

Internet (http://www.profibus.com)

#### Data records on slot 0

Table 12-7 Data records from the DP/PA coupler on slot 0

Data record no.	Read / Write	Size in bytes	Description	
1	r	14	PA diagnostics (diagnostics frame bytes 1 to 14)	
18	r	32	TAG, determined from I&M list 1.	
24	r	16	Software revision	
26	r	2	Device Man ID, determined from I&M list 0.	
27	r	16	Device ID	
50	r	16 Local LifeList (1 bit status per station)		
	<ul> <li>1 bit per PA field device, the offset corresponds to the station number.</li> <li>Coding 0: PA field device not available.</li> <li>Coding 1: PA field device available on the local equipotential bonding line.</li> </ul>			
56	r	10 Mapping of the input data		
	See <i>User data frame</i> .  10 bytes of input data are also provided with a configuration with only one slot: PA current and PA voltage.			
60	r	Max. 72 Mapping the diagnostics frame		
	See Diagnostics frame.			
61	r	8	Mapping the PA redundancy status	

### 12.2 DP/PA coupler FDC 157-0

Data record no.	Read / Write	Size in bytes	Description
	See PA redundancy status.		
62	r	16	See Diagnostic record.
128	r/w	12	Parameter assignment of the limit value for PA current and PA voltage
231	r/w	64	I&M list 0 (rating plate)
232	r/w	64	I&M list 1 (TAG)
233	r/w	64 I&M list 2 (date)	
234	r/w	64 I&M list 3 (descriptor)	
	The data structures of the I&M data correspond to the specifications of the PROFIBUS Guideline – Order No. 3.502, Version 1.1 of May 2003.		
255	r/w	68 Upload / Download mechanism for I&M objects	
	This data set is structured according to the following standard: PROFIBUS Profile Guidelines Part 1: Identification & Maintenance Functions.		

### Data records on slot 1

Table 12-8 Data records from the DP/PA coupler on slot 1

Data record no.	Read / Write	Size in bytes	Description
0	r	12	Header (device management)
1	r	8	Composite List Directory Entries (device management)

## Reading and writing data records

To read and write records, use the following SFCs:

- Reading the data record with SFC 59 "RD\_REC" or SFB 52 "REC".
- Write the data record with SFC 58 "WR\_REC" or SFB 53 "WR\_REC".

### Additional information

For more detailed information on SFCs, refer to the *System Software for S7-300/400 System and Standard Functions* manual.

Internet (http://support.automation.siemens.com/WW/view/en/1214574)

## See also

Identification and maintenance data (I&M data) (Page 158)

# 12.2.5 Diagnostic record 62

# Structure of diagnostics record 62

Bytes 0 to 5 of data record 62 contain the standard diagnostics, bytes 6 to 15 the PA status.




Figure 12-4 Structure of diagnostics record 62

12.2 DP/PA coupler FDC 157-0

## 12.2.6 Address space of the inputs

### Introduction

The address range of the process input image that is occupied is dependent on the configuration, i.e. by the selection of the relevant entry in the configuring software.

### Assignment of the process input image (PII)

The DP/PA coupler FDC 157-0 has 5 or (optional) 10 bytes of input data.

These contain the current value on the equipotential bonding line, as well as (optional) the PA voltage in IEEE754 format (32 bit floating point number) with one byte quality code in accordance with the PROFIBUS PA profile.

## Structure of the configuration frame

The DP/PA coupler has slot modeling as the modular slave.

- Slot 0 is the proxy for the entire slave
- Slot 1 is always available
- Slot 2 can be configured (optional)

Module	I/O data in bytes	Consistency	DP ID
Slot 1	5/0	byte entire length	94н
Slot 2	5/0	byte entire length	94 н

Interrupt, error and system messages

13

# 13.1 Diagnostics by means of LED displays

# 13.1.1 The LED displays of the IM 153-2


#### Introduction

PA field devices and DP slaves communicate on the same basis. Hence the following simplified terminology is used in this section:

- "Slaves" stands for PA field devices and lower-level DP slaves.
- "Lower-level master system" stands for PA master system and lower-level DP master system.

### Status and error messages of the IM 153-2

Table 13-1 Status and error messages of the IM 153-2



# 13.1 Diagnostics by means of LED displays

		LEDs			Meaning	Remedy
SF	BF 1	BF 2	ACT	ON		
Off	Off	Off	Off	Off	<ul> <li>No voltage present on the IM 153-2.</li> <li>Applied supply voltage is not within permissible range.</li> <li>Hardware fault of the IM 153-2</li> </ul>	<ul> <li>Switch on the power supply module.</li> <li>Check the voltage applied</li> <li>Replace the IM 153-2.</li> </ul>
*	*	*	*	On	Supply voltage is applied to the IM 153-2.	-
On	On	On	On	On	All LEDs are switched on for approx. 1 s. IM 153-2 is starting.	-
Off	Off	Off	Off	On	In the non-redundant mode: The IM 153-2 is exchanging data with the DP master and the lower-level slaves.	_
					In the redundant mode: the IM 153-2 is passive and ready for switchover.	_
Off	Off	Off	On	On	Only in the redundant mode: The IM 153-2 is active and exchanging data with the DP master and the lower-level slaves.	_
Off	Off	Flashes rapidly	*	On	The start-up delay is active on the IM 153-2.	If the IM 153-2 does not fully start up within 20 s, then check in the configuration whether whether the start-up is enabled when desired layout ≠ actual layout.
*	Off	On	Off	On	In the non-redundant mode: The IM 153-2 has not been configured	Check whether the CPU or the DP master is in the RUN mode.
					In the redundant mode: the IM 153-2 is passive and not ready for switchover.	Check whether the H system is in the redundant system state.**
*	On	*	Off	On	No connection to the DP master.  Possible causes:  Bus communication to the	Check that the bus connector is correctly inserted.     Check if the bus cable to the
					<ul><li>IM 153-2 is interrupted.</li><li>The DP master is not in operation.</li></ul>	<ul> <li>DP master is interrupted.</li> <li>Switch the On / Off switch for 24 VDC on the power supply module off and on again.</li> </ul>
*	Flashes	*	Off	On	No data exchange is taking place between DP master and IM 153-2.	<ul><li>Check the configuration.</li><li>Check the PROFIBUS address.</li></ul>

		LEDs			Meaning	Remedy
SF	BF 1	BF 2	ACT	ON		
On	Off	Off	Off	On	In non-redundant mode: All slaves are exchanging data. At least one slave has reported an error. or Inadmissible PROFIBUS address	Evaluate the diagnosis of the IM 153-2 and control the reported slaves.  DP/PA link only: Check the status bytes in the slave user data. Read the slave device status using a configuration tool, for example SIMATIC PDM).  or  Set a valid PROFIBUS address for the IM 153-2.
					In the redundant mode: the IM 153-2 is passive and ready for switchover. There is an error on the active IM 153-2.	Evaluate the LED display on the active IM 153-2.
On	Off	Off	On	On	In the redundant mode: The IM 153-2 is active. All slaves are exchanging data. At least one slave has reported an error.	Evaluate the diagnosis of the IM 153-2 and control the reported slaves.  Evaluate the diagnoses of the lower-level slaves using the online view of HW Config.  DP/PA link only: Check the status bytes in the slave user data. Read the slave device status using a configuration tool, for example SIMATIC PDM).
On	Off	Flashes	*	On	The configured structure of the link does not correspond to the actual structure. or The IM 153-2 has no cyclical data exchange to at least one configured slave.	Check the configuration and structure of the link. or Evaluate the diagnosis of the IM 153-2 and control the reported slaves (connection, address, parameterization, configuration).
Flashes	Flashes	Flashes	Flashes	Flashes	In the current mode the IM 153-2 is not compatible with the redundant IM 153-2.	You will find information on compatibility between the versions of IM 153-2 and IM 157 in the chapter <i>Compatibility to precursor modules</i> .

Not relevant

## See also


Compatibility with predecessor modules (Page 37)

<sup>\*\*</sup> After the transition to the redundant system state the "SF" LED flashes for another 20 seconds.

# 13.1.2 LED displays of the DP/PA coupler FDC 157-0

## Status and error messages of the DP/PA coupler FDC 157-0

Table 13-2 Status and error messages of the DP/PA coupler FDC 157-0



	LEDs					Meaning	Remedy
SF	BF	DP	PA	ACT	ON		
*	*	*	*	*	On	Voltage is applied to the DP/PA coupler. The DP/PA coupler is ready to operate.	-
Off	Off	*	*	Off	On	DP/PA coupler without diagnostic message	-
On	Off	*	*	Off	On	DP/PA coupler with diagnostic message	-
*	*	*	*	Off	Off	<ul> <li>There is no voltage applied to the DP/PA coupler.</li> <li>Error in the DP/PA coupler.</li> </ul>	<ul> <li>Check the 24 V voltage supply of the DP/PA coupler,</li> <li>Contact your Siemens representative.</li> </ul>
*	*	*	*	*	Flashe s	PROFIBUS PA overloaded	Check the number of connected PA field devices and the total current.
*	Flashe s	*	*	*	On	DP/PA coupler not or not correctly configured. Causes:  PROFIBUS addresses do not match in the configuration and on the DP/PA coupler.  Redundancy mode	Check the PROFIBUS addresses in the configuration and on the DP/PA coupler.

		LI	EDs			Meaning	Remedy
SF	BF	DP	PA	ACT	ON		·
*	On	Off	Off	*	Flashe s	PROFIBUS DP frames are not being received. Causes:  The DP master is not in operation.	<ul> <li>Check that the bus connector is correctly inserted.</li> <li>Check if the bus cable to the DP master is</li> </ul>
						Bus cable is damaged.	interrupted.
						Bus modules are not connected correctly.	Check if the bus modules are correctly connected.
						Connector to backplane bus is defective.	Check the 24 V voltage supply of the DP/PA coupler.
Off	Off	On	Flashe s	On	On	PROFIBUS PA frames are being received	-
On	Off	On	Off	On	On	PROFIBUS PA frames are not being received, for example	Check the PA field devices on the PROFIBUS PA
						The voltage to PROFIBUS PA is not within the permissible range (short circuit, overload).	Check if the bus segments are terminated properly.
						No response from a PA field device. The PA field device is possibly not being addressed.	
Off	On	*	*	*	On	<ul> <li>No DP master available.</li> <li>Diagnostics not available / not possible</li> <li>Illegal PROFIBUS addresses of the DP/PA coupler</li> </ul>	Check the PROFIBUS addresses of the DP/PA coupler.
*	*	*	*	On	*	DP/PA coupler is the active energizing coupler. **	


<sup>\*</sup> Not relevant

<sup>\*\*</sup> If the ACT LED it illuminated for both DP/PA couplers, then both DP/PA couplers are active: one DP/PA coupler powers its equipotential bonding line, the other passes through.

# 13.1.3 LED displays of the DP/PA coupler

# Status and error messages of the DP/PA coupler

Table 13-3 Status and error messages of the DP/PA coupler




	Meaning	Remedy
ON		
On	Voltage is applied to the DP/PA coupler. The DP/PA coupler is ready to operate.	-
Off	There is no voltage applied to the DP/PA coupler, or Error in the DP/PA coupler.	Check the 24 V voltage supply of the DP/PA coupler, or Contact your Siemens representative.
Flashe s	PROFIBUS PA overloaded	Check the number of connected PA field devices and the total current.
On	PROFIBUS DP frames are being received	-
On	PROFIBUS DP frames are not being received Causes:  The DP master is not in operation.  Bus cable is damaged.  Bus modules are not connected correctly.  Connector to backplane bus is defective	<ul> <li>Check that the bus connector is correctly inserted.</li> <li>Check if the bus cable to the DP master is interrupted.</li> <li>Check if the bus modules are correctly connected.</li> <li>Check the 24 V voltage supply of the DP/PA coupler,</li> </ul>
On	PROFIBUS PA frames are being received	-
On	PROFIBUS PA frames are not being received, for example  the voltage to PROFIBUS PA is not within the permissible range (short circuit, overload).  No response from a PA field device. The PA field device is possibly not being addressed.	<ul> <li>Check the PA field devices on the PROFIBUS PA</li> <li>Check if the bus segments are terminated properly.</li> </ul>
	On Off Flashe s On On On	ON On Voltage is applied to the DP/PA coupler. The DP/PA coupler is ready to operate.  Off There is no voltage applied to the DP/PA coupler, or Error in the DP/PA coupler.  Flashe PROFIBUS PA overloaded S On PROFIBUS DP frames are being received Causes:  The DP master is not in operation.  Bus cable is damaged.  Bus modules are not connected correctly.  Connector to backplane bus is defective  On PROFIBUS PA frames are being received  On PROFIBUS PA frames are not being received, for example  the voltage to PROFIBUS PA is not within the permissible range (short circuit, overload).  No response from a PA field device. The PA field device is possibly not being

# 13.1.4 LED displays of the Y coupler

## Status and error messages of the Y coupler

Table 13-4 Status messages of the Y coupler



	LEDs		Meaning	Remedy
DP 1	DP 2	ON		
Off	Off	Off	No voltage is applied to the Y coupler	Switch on the power supply of the IM 153-2. If the LED ON does not light up when the power supply of the IM 153-2 is switched on: Replace IM 153-2 because the internal power supply is defective.
Off	Off	On	Voltage is applied to the Y coupler The Y coupler is ready to operate. No data exchange is taking place between the internal and the lower-level DP master system.	<ul> <li>Check that the bus connector is correctly inserted.</li> <li>Check if the bus cable to the lower-level DP master system is interrupted.</li> <li>Check if the bus modules are correctly connected.</li> </ul>
On	Off	On	Frames from the lower-level DP master system are not being received, for example:  The connection to the lower-level DP master system is interrupted.  DP slaves are not responding.	Check whether the lower-level DP master system is connected correctly (the bus connector is plugged in and the two bus terminal resistors are connected in if necessary).      Check the connected DP slaves
*	On	On	Data exchange taking place between internal	-
On	*	On	and lower-level DP master system (at high transmission speed).	
* Flashes	Flashes *	On	Data exchange is taking place between internal and lower-level DP master system (at low transmission speed).	-
* Not rele	vant	<u> </u>		1

## 13.1 Diagnostics by means of LED displays

## 13.1.5 LED displays of the AFD

## Status and field messages from the AFD

Table 13-5 Status and field messages from the AFD

PA1	PA2	)
• •	• 0	

LEDs P	A1 / PA2	X1 X4	Meaning	Remedy
Off	green		PA main line connected. Bus terminator inactive.	-
red	-		Automatic bus terminator active. Cause:	-
			For example, last AFD in the line	
			Short-circuit or no-load operation on the respective segment of the PA main line (PA1 or PA2)	
Off	-		Wires of a PA main line swapped	Correct the wiring.
-		Off	No field device is connected to the respective spur line.	-
		green	Field device is connected.	-
		Flashes slowly	Short-circuit on the PA spur line	Eliminate the cause of the error.

# 13.1.6 LED displays of the active field splitter (AFS)

## Status and field messages from the active field splitter (AFS)

Table 13-6 Status and field messages from the active field splitter (AFS)

PA1	PA2

LEDs F	PA1 / PA2	Remedy	
Off	green	PA main line connected. Bus terminator inactive.	-
red	Off	Short-circuit or no-load operation on the PA main line to a DP/PA coupler	Eliminate the cause of the error.
Off	Off	Wires of a PA main line swapped	Correct the wiring.

# 13.1.7 LED displays of the active field distributor AFDiS

# Status and field messages from the active field distributor AFDiS

Table 13-7 Status and field messages from the active field distributor AFDiS



LED T1, T2	LED S1 to S6	Meaning	Remedy
green		PA main line connected. Bus terminator inactive.	-
orange		Automatic bus terminator active. Cause:	-
		For example, last AFD or AFDiS in the line	
		Short-circuit or no-load operation on the respective segment of the PA main line (T1 or T2)	
Flashes orange		IP30 cover of the main line terminal is open.	Close the IP30 cover until you hear it engage.
Off		Wires of a PA main line swapped	Correct the wiring.
	Off	No field device is connected to the respective spur line.	-
	blue	Field device is connected.	-
	Flashes slowly	Short-circuit on the PA spur line	Eliminate the cause of the error.
	Flashes rapidly	Debounce function is active (3 s after changes to the spur lines, e.g. before or after a short-circuit)	wait for 3 s. One of the statuses "off", "blue" or "slow flashing" arises.

# 13.2 Diagnostics with STEP 7: IM 153-2

### **Terminology conventions**

Some of the following information applies to both the DP/PA link with its PA field devices and to the Y link with its underlying DP slaves. In such instances, the following terminology will be used for the sake of clarity:

- "Link" stands for DP/PA Link and Y Link
- "Slaves" stands for PA field devices and underlying DP slaves.
- "Underlying master system" stands for PA master system and underlying DP master system.

# Slave diagnostics

Slave diagnostics are performed in accordance with IEC 61784-1:2002 Ed1 CP 3/1. Depending on the DP master, they can be read out with *STEP 7*, *SIMATIC PDM* or other configuration tools.

With *STEP 7* the diagnostics frames of the underlying DP slaves can be displayed in the online view of HW Config.

### Additional information

For additional information, please refer to the *STEP 7* online help topic "How to diagnose hardware"

Please refer to the *SIMATIC Software; Programming with STEP 7 V5.x*. manual for further options for reading out diagnostic information.

You will find the manual on the Internet at this address (http://support.automation.siemens.com):

Search for the entry with the number 18652056.

# 13.2.1 Structure of slave diagnostics

# Influencing factors

The structure of the slave diagnostics depends on whether the IM 153-2 is working in S7 standard mode, redundancy mode on an S7-400H or in DP standard master mode.

# Diagnostic blocks in S7 standard mode and in the redundancy mode

The table below shows the lengths of the diagnostics blocks and the offset in the diagnostics frame.

Table 13-8 Length and offset of the diagnostic blocks in S7 standard mode and in redundancy mode

Diagnostic block	Length in bytes	Offset in the non- redundancy mode	Offset in the redundancy mode
Default diagnosis	6	0	0
Identifier-related diagnostics	31	6	6
Module status	63	37	37
Status message	60	100	100
H status	8	-	160
Interrupt section	(max. 63 *)	(160 *)	(168 *)
Total length		160 (max. 223 *)	168 (max. 231 *)
* only if interrupts are reported	-	,	,

# Diagnostic blocks in DP standard master mode

When configuring the IM 153-2 via GSD file with Revision 4 and later, each diagnostic block (with the exception of the default diagnosis) can be chosen to be available or not. The sequence of the diagnostic blocks is fixed. The offset of the individual diagnostic blocks in the diagnostics frame depend on which diagnostic blocks are selected.

The table below shows the lengths of the diagnostics blocks and examples of the offset in the diagnostics frame with specific configurations.

Table 13- 9 Length and offset of the diagnostic blocks in DP standard master mode

Diagnostic block	Length in bytes	Example 1		Example 2	
		Selected	Offset	Selected	Offset
Default diagnosis	6	Always	0	Always	0
Identifier-related diagnostics	31	Х	6	-	-
Module status	63	Х	37	Х	6
Status message	60	-	-	-	-
Interrupt section	(max. 63 *)	-	-	Х	(69 *)
Total length	160 (max. 223 *)	10	00	1	9 132 *)
* only if interrupts are reported					

# 13.2.2 Reading out the diagnostics of underlying slaves

# Introduction

The diagnostic data of the underlying diagnostics-capable slaves buffered in the IM 153-2 can be read via the SFC 59 "RD\_REC".

# Requirements

The link must be operated on a DPV1 master.

# Parameters for SFC 59 "RD\_REC"

The following table provides you with the necessary values for call parameters of the SFC 59 "RD\_REC".

Table 13- 10 Call parameters for SFC 59 "RD\_REC"

Parameters	Value, meaning
IOID	B#16#54 (I/O input IOI)
LADDR	Diagnostic address of the IM 153-2 from HW Config
RECNUM	Node number of the slave, whose diagnosis is to be read

The possible fault information in the return value RET\_VAL is listed in the chapter *Reading* and writing records.

# 13.2.3 Structure of the diagnostic blocks

# 13.2.3.1 Default diagnosis

# Structure of the default diagnosis

The default diagnosis consists of 6 bytes and is subdivided as follows:




Figure 13-1 Structure of the default diagnosis

# 13.2 Diagnostics with STEP 7: IM 153-2

# Station statuses 1 to 3

Station status 1 to 3 provides an overview of the state of the IM 153-2.

Table 13- 11 Structure of station status 1

Bit	Meaning	Cause / remedy
0	1: The IM 153-2 cannot be addressed by the DP master.	Is the correct PROFIBUS address set on the IM 153-2?
		Are the bus connectors connected?
		Voltage on the IM 153-2?
1	1: The IM 153-2 is not ready for data exchange.	Wait, because IM 153-2 is just starting.
2	1: The configuration data that the DP master has sent to the IM 153-2 do not match the structure of the IM 153-2.	Have you entered the right station type or right IM 153-2 structure into the configuration software?
3	1: External diagnostics available. (Group diagnostic display)	Evaluate the identifier-related diagnosis, the module status and / or the status message. As soon as all errors have been eliminated, bit 3 is reset. The bit is set again when there is a new diagnostic message in the bytes of the aforementioned diagnostics.
4	1: The required function is not supported by the IM 153-2.	Check the configuration.
5	1: DP master cannot interpret the response from the IM 153-2.	Check the bus configuration.
6	1: The station type configured does not correspond to the IM 153-2.	Correct station type entered in the configuration software?
7	1: The IM 153-2 was parameterized by a different DP master (not by the DP master that has access to the IM 153-2 at the moment).	Bit is always set to "1" when you are accessing the IM 153-2 using a PD or a different DP master.
	in 100 2 at the memory.	The PROFIBUS address of the DP master that parameterized the IM 153-2 is to be found in the "Master-PROFIBUS-address" diagnostic byte.

Table 13- 12 Structure of station status 2

Bit	Meaning		
0	1: The IM 153-2 must be parameterized again.		
1	0: The bit is always set to "0."		
2	1: The bit is always set to "1" if the IM 153-2 with this PROFIBUS address is present.		
3	1: The response monitor is enabled for IM 153-2.		
4	0: The bit is always set to "0."		
5	0: The bit is always set to "0."		
6	0: The bit is always set to "0."		
7	1: The IM 153-2 is disabled; this means that it is detached from current processing.		

Table 13-13 Structure of station status 3

Bit	Meaning	
0 to 7	0: Bits are always set to "0."	

### Master PROFIBUS address

The PROFIBUS address of the specific DP master that parameterized the IM 153-2 and that has reading and writing access to the IM 153-2 is stored in byte 3 of the default diagnosis.

#### Device identifier

The device identifier is a code that uniquely identifies the DP slave (PROFIBUS ID number).

Table 13- 14 Structure of the device identifier

Byte 4	Byte 5	Description
80н	52н	IM 153-2

# 13.2.3.2 Identifier-related diagnostics

### **Definition**

The identifier-related diagnosis specifies for which slots of the IM 153-2 a diagnosis is available.

### Terms: slave, module and slot

A slave is a bus node that is accessed via its own PROFIBUS address. It can physically or logically consist of one or more modules. The slaves and their modules are depicted in the identifier-related diagnosis in virtual slots:

- A non-modular slave always occupies two slots.
   The first slot represents a "virtual header module" and the second a "virtual module".
- A modular slave consisting of x modules occupies (x+1) slots.
   The first slot is assigned to the header module, the subsequent slots are assigned to the individual modules in ascending order.

# **Example of slot assignment**




Figure 13-2 Example of slot assignment

# Structure of the identifier-related diagnostics

The identifier-related diagnosis comprises 31 bytes.

Each slot of a slave is occupied by one bit. The slaves are arranged in ascending order according to their PROFIBUS addresses.

### One bit is set:

- if the associated slave for the slot concerned delivers an identifier-related diagnosis, or
- if the associated configured slave is not exchanging data with the DP master.




Figure 13-3 Structure of the identifier-related diagnostics

#### 13.2.3.3 Module status

#### **Definition**

The module status is part of the device-related diagnostics and reports the status of the configure modules.

# Structure of the module status

The modules status comprises 63 bytes.

The start address x is the equal to 37 for the S7 standard mode and redundant mode, in DP standard master mode it depends on the diagnostic blocks that are present.

The status of each slot is coded by 2 bits in the module status.

The following applies to the entry in the module status:

- If an underlying slave delivers its own module status in its diagnostics, this status is copied to the appropriate location.
- If an underlying slave delivers an identifier-related diagnosis but no module status, the status 01<sub>B</sub> "Module error" is entered for an incorrect identification.

### 13.2 Diagnostics with STEP 7: IM 153-2

- If an underlying slave delivers neither its own module status nor an identifier-related diagnosis, the status is entered as follows:
  - In case of faultless operation: 00<sub>B</sub> "Module OK"
  - In case of configuration errors: 10<sub>B</sub> "Wrong module"
  - If a slave is missing 11<sub>B</sub> "No module"
  - In case of other errors (for example "Prm\_Fault"): 01<sub>B</sub> "Module fault"




Figure 13-4 Structure of the module status

### See also

Structure of slave diagnostics (Page 183)

# 13.2.3.4 Status message

# **Definition**

The status message is part of the device-related diagnostics and delivers, among other things, the following information:

- Underlying slaves that have reported diagnostics
- Underlying slaves that are exchanging data
- State of the IM 153-2 as master of the underlying PROFIBUS

# Structure of the status message

The status message comprises 60 bytes.

The start address x is equal to 100 for the S7 standard mode and redundant mode, in DP standard master mode it depends on the diagnostic blocks that are present.




Figure 13-5 Structure of the status message




Figure 13-6 Structure of the status message, continuation

Table 13- 15 The meaning of byte x+36 in der status message

Byte x+36	Status	Meaning	
00н	OFF	No data are exchanged between IM 153-2 and the underlying slaves. The IM 153-2 can neither receive nor pass on the token.	
40н	STOP	No data are exchanged between IM 153-2 and the underlying slaves. The IM 153-2 can receive and forward the token.	
80н	CLEAR	The IM 153-2 reads the input data cyclically. Output data are held in a safe state or set to "0". The IM 153-2 can receive and forward the token.	
С0н	RUN (OPERATE)	The IM 153-2 reads the input data cyclically and forwards the output data to the slaves. The IM 153-2 can receive and forward the token.	

### See also

Structure of slave diagnostics (Page 183)

13.2 Diagnostics with STEP 7: IM 153-2

# 13.2.3.5 H status

# **Definition**

The IM 153-2 delivers the H status only

- if it is connected to the redundant DP system of an S7-400H or
- if it is operated redundantly according to the standard.

The H status gives information on the state of an active and passive IM 153-2. The H status consists of 8 bytes.

### Structure of the H status




Figure 13-7 Structure of the H status of the IM 153-2 in redundant mode

13.2 Diagnostics with STEP 7: IM 153-2

# 13.2.3.6 Interrupts

#### **Definition**

The interrupt section provides information on the type of interrupt and the cause leading to the interrupt being triggered. The interrupt section is only transmitted if there is an interrupt.

# Structure of the interrupt section

The structure of the interrupt section depends on the DP master on which the IM 153-2 is being operated:

- On a DPV1-capable DP master the interrupt section comprises at maximum 63 bytes
- On an S7 redundant master that is **not** DPV1-capable, the interrupt section comprises 20 bytes.

### Structure of the interrupt section on redundant S7 masters that are not DPV1-capable.




Figure 13-8 Structure of the interrupt section on redundant S7 masters that are not DPV1-capable.

# Structure of the Interrupt Section on a DPV1-capable DP Master

The interrupt section consists of an interrupt header and the additional interrupt information. The interrupt header always comprises 4 bytes. The structure of the additional interrupt information depends on the interrupt type; its length is 59 bytes maximum.




Figure 13-9 Structure of the interrupt headers on a DPV1-capable DP master

The start address x is equal to 168 in redundant mode and equal to 160 in DP standard master mode.

# Interrupt type

Table 13- 16 Interrupt type (bytes x+1 in the interrupt section)

IM 153-2 (Interrupt routing, see below).

Byte x+1	Interrupt type	Byte x+1	Interrupt type
00н	Reserved	05н	Status interrupt *
01н	Diagnostic interrupt	06н	Update interrupt *
02н	Process interrupt *	07 <sub>н</sub> to 1F <sub>н</sub>	Reserved
03н	Removal interrupt	20н to 7Ен	Manufacturer-specific interrupt *
04н	Insertion interrupt	7F <sub>H</sub>	Reserved
*These types		y are generated by a	n underlying DPV1 slave and are

# Diagnostic interrupt

If a DPV0 slave or a non-interrupt-capable DPV1 slave on the underlying master system reports a diagnosis, the IM 153-2 initiates a diagnostic interrupt on the higher level DP master system ("proxy diagnostic interrupt").

The diagnostic frame of the slave is stored in the additional interrupt information. If this frame is longer than 59 bytes, the information exceeding the 60th byte is discarded. In addition to this, bit 7.(Ext\_Diag\_Overflow) is set in the third forwarded byte (byte x+6).

The diagnosis of an interrupt-capable DPV1 slave operated in DPV1 mode does not cause a diagnostic interrupt.

# Removal / insert interrupt

When a slave on the underlying master system fails or is restored, the IM 153-2 initiates a remove or insert interrupt on the higher level DP master system.




Figure 13-10 Structure of the additional interrupt information for remove / insert interrupts

The start address x is equal to 168 in redundant mode and equal to 160 in DP standard master mode.

In the case of modular slaves the additional interrupt information relates to the entire slave and not to the individual modules.

Remove / insert interrupts are only reported after the start-up delay is finished. Insert interrupts that occur up to then are fetched later.

### Interrupt routing

When an interrupt-capable DPV1 slave on the underlying master system initiates an interrupt, the IM 153-2 forwards it to the higher level DP master system.

The interrupt header and additional interrupt information of the slave are stored in the interrupt section of the IM 153-2. With the exception of slot numbers and sequence numbers, this information remains unchanged.

# 13.2.4 Example of a diagnosis in redundant mode

### Introduction

This example the call of a typical diagnosis of the active IM 153-2 in redundant mode.

# 13.2.4.1 Task specification

### **Assumption**

The following assumptions apply to the example:

- The two IM 153-2 have the diagnostic address 3FE<sub>H</sub>.
- The underlying PROFIBUS master system consists of 4 configured slaves
- Slaves have the addresses: 4, 8, 12 and 20
- Structure of the slaves:
  - Salve 4 is a non-modular slave
  - Slave 8 consists of a header module and 6 modules
  - Slave 12 consists of a header module and 2 modules
  - Slave 20 consists of a header module and 3 modules
- All configure slaves are exchanging data with the active IM 153-2.
- Slave 8 reports the diagnosis:
  - Modules 1 and 3 report diagnoses
  - Module 1 reports a limit value violation
  - Module 3 reports an incorrect configuration

13.2 Diagnostics with STEP 7: IM 153-2

# 13.2.4.2 Solution with STEP 7

### Call of SFC 13

Call the SFC 13 (DPNRM\_DG) in the OB 1 and use it to read the diagnostics from the IM 153-2.

Table 13- 17 Call of the SFC 13 (DPNRM\_DG) in the OB 1

```
CALL SFC 13 //Request to read the diagnostics

REQ :=TRUE //Diagnostic address of the IM 153-2

LADDR :=W#16#3FE //RET_VAL of SFC 13

RET_VAL :=MW0 //Data mailbox for the diagnosis in the DB 10

RECORD :=P#DB10.DBX 0.0 BYTE 190 //Reading operation runs through several OB 1 cycles

BUSY :=M2.0
```

With this call, the diagnostics are stored in DB 10.

# Appearance of DB 10


Create the following structure for DB 10:


Address	Name	Туре	Initial value	Comment
0.0		STRUCT		
+0.0	Norm_Diag	ARRAY[16]		Standard diagnosis
*1.0		BYTE		
+6.0	Kenn_Diag	ARRAY[131]		Identifier-related diagnostics
*1.0		BYTE		
+38.0	Modul_Diag	ARRAY[163]		Module status
*1.0		BYTE		
+102.0	Status_Message	ARRAY[160]		Status message
*1.0		BYTE		
+162.0	H_Status	ARRAY[18]		H status
*1.0		BYTE		
+170.0	Interrupt section	ARRAY[120]		Interrupts
*1.0		BYTE		
=190.0		END_STRUCT		

# 13.2.4.3 Evaluating the diagnostics data


# Diagnostic data in DB 10


The relevant diagnostic data in DB 10 have the following meaning:








### 13.2 Diagnostics with STEP 7: IM 153-2














The SIMATIC H station always reads out only the active IM 153-2. Hence a change of active channel does not affect the H status.

# 13.3 Diagnostics with STEP 7: DP/PA coupler FDC 157-0

# 13.3.1 Structure of slave diagnostics

### Structure of slave diagnostics

The figure below shows the structure of the slave diagnostics.




Figure 13-11 Structure of slave diagnostics

# Rule

When using the GSD file for configuration, you can disable or enable the following diagnostics:

- Module status; default setting: enable
- Channel-related diagnostics; default setting: enable
- Local LifeList equipotential bonding line; default setting: disable

If you disable the diagnostics, they are removed from the diagnostics frame.

# 13.3.2 Structure of the diagnostic blocks

# 13.3.2.1 Station statuses 1 to 3

### **Definition**

The stations status 1 to 3 provides an overview of the status of a DP slave.

# **Station Status 1**

Table 13- 18 Structure of station status 1 (Byte 0)

Bit	Meaning	Cause / Remedy
0	1: The DP slave cannot be addressed by the DP master. The bit on the DP slave is always	Is the correct PROFIBUS address set on the DP slave?
	set to "0".	Are the bus connectors connected?
		Voltage at DP slave?
		RS-485 repeater set correctly?
		Has there been a RESET on the DP slave (off/on)?
1	1: The DP slave is not yet ready to exchange data.	Wait for the DP slave to complete its startup.
2	1: The configuration data sent to the DP slave from the DP master does not match the configuration of the DP slave.	The DP slave is O.K., but the configuration does not match the current configuration of the DP slave. Compare the preset and actual configurations.  Note:
		If the last slot is not used, install the slot cover. The cover is available in the bus termination module.

# 13.3 Diagnostics with STEP 7: DP/PA coupler FDC 157-0

Bit	Meaning	Cause / Remedy
3	1: External diagnosis available.	Evaluate the channel-related diagnostic information, the module status and/or the channel-related diagnostic information. As soon as all errors have been eliminated, bit 3 will be reset. The bit is set again when there is a new diagnostic message in the bytes of the aforementioned diagnostics.
4	1: The DP slave does not supports the requested function (for example, changing the PROFIBUS address using the software).	Check the configuration.
5	1: The DP master cannot interpret the response from the DP slave.	Check the bus configuration.
6	1: Faulty DP parameter assignment message (wrong slave type, parameter).	Correct the preset and actual configurations.
7	1: The DP slave has not been parameterized by the DP master that currently has access to the DP slave.	The bit is always set to 1, for example, if you access the DP slave with the programming device or another DP master.
		The "master PROFIBUS address" diagnostic byte contains the PROFIBUS address of the DP master that assigned parameters to the DP slave.

# Station Status 2

Table 13- 19 Structure of station status 2 (Byte 1)

Bit	Meaning		
0	1: The DP slave must be assigned new parameters.		
1	1: There is a diagnostic message. The DP slave freezes its functions until the fault has been corrected (static diagnostic message).		
2	1: The bit is always set to "1" at the DP slave.		
3	1: Response monitoring is enabled for this DP slave.		
4	1: The DP slave has received the "FREEZE" control command.		
5	1: The DP slave has received a "SYNC" control command.*		
6	0: The bit is always set to "0."		
7	1: The bit is always set to "0."  Note: When reading the station status from the DP master, the bit is 1 if the DP slave was deactivated in the DP master, i.e. it was isolated from the current process.		

# **Station Status 3**

Table 13- 20 Structure of station status 3 (Byte 2)

Bit	Meaning	
0 to 6	0: Bits are always set to "0."	
7	There are more channel-related diagnostic messages than can be shown in the diagnostics frame	

# 13.3.2.2 Master PROFIBUS address

# Master PROFIBUS address

The diagnostic byte master PROFIBUS address contains the PROFIBUS address of the DP master:

- Assigned parameters to the DP slave and
- has read / write access to the DP slave

The master PROFIBUS address is in byte 3 of the slave diagnostic information.

### 13.3.2.3 Manufacturer ID

### **Definition**

The manufacturer ID contains a code that describes the DP slave type.

### Manufacturer ID

Byte 4	Byte 5	Description	
81н	31 <sub>H</sub>	DP/PA coupler with diagnostics functions	

### 13.3.2.4 PA status

# Setup of the PA status

The PA status for the DP/PA coupler is setup as follows:




Figure 13-12 Setup of the PA status

#### Note

### Maintenance alarm / maintenance demanded

The "maintenance alarm" or "maintenance demanded" bits are set according to the IEEE status byte.

# See also

Structure of the current value and voltage value (Page 167)

# 13.3.2.5 Identifier-related diagnostics

#### **Definition**

The identifier-related diagnostic data states whether the DP/PA coupler reports an error or not. Identifier-related diagnostic data starts at byte 6 and is 2 bytes long.

# Structure of the identifier-related diagnostics

The identifier-related diagnostic data for the DP/PA coupler is setup as follows:




Figure 13-13 Structure of the identifier-related diagnostics

13.3 Diagnostics with STEP 7: DP/PA coupler FDC 157-0

#### 13.3.2.6 Module status

#### **Definition**

The module status indicates the status of the configured modules and expands on the module diagnosis as regards the configuration. The module status starts after the identifier-related diagnostic data and consists of 5 bytes.

### Structure of the module status

The module status for the DP/PA coupler is setup as follows:




Figure 13-14 Structure of the module status

#### Rule

### Note

# Operation of the DP/PA coupler in the DP/PA link

To obtain the complete diagnostic information via the DP/PA link, you must enable the module status in the configuration when operating the DP/PA coupler in the DP/PA link.


#### 13.3.2.7 Local LifeList

#### **Definition**

The local LifeList renders the status of the configured PA field devices on the equipotential bonding line. The local LifeList starts after the module status and consists of 20 bytes.

# Structure of the local LifeList

The local LifeList of the DP/PA coupler is setup as follows:



<sup>\*</sup> without deselection of the diagnoses in the configuration

Figure 13-15 Structure of the local LifeList

# Reading the local LifeList

The local LifeList is disabled in the default setting of the configuration. To read it out, you must enable the "Local LifeList equipotential bonding line" parameter.

You can read the local LifeList in data record 50 of the DP/PA coupler.

### See also

Structure of slave diagnostics (Page 204)


### 13.3.2.8 PA redundancy status

#### **Definition**

The PA redundancy status renders the status of the configured DP/PA coupler. A prerequisite is the use of bus module BM FDC/FDC (redundant). The PA redundancy status consists of 8 bytes.

# Setup of the PA redundancy status

The PA redundancy status for the DP/PA coupler is setup as follows:



\* without deselection of diagnostics during configuration

Figure 13-16 Setup of the PA redundancy status

# Reading out the PA redundancy status with data record 61

The PA redundancy status can also be read out with SIMATIC PDM. If the DP/PA coupler is not used redundantly, the redundancy status bytes 1 to 3 are "0".

# 13.3.2.9 Channel-related diagnostics

### **Definition**

Channel-related diagnostics provides information about channel faults in modules. It represents the details of the identifier-related diagnostic data. For each channel-related diagnostics, 3 bytes are added according to the IEC 61784 1:2002 Ed1 CP 3/1 standard.

The channel-related diagnostics do not affect the module status.

### Structure of the channel-related diagnostics

The number of channel-related diagnostics events is limited to 8. All channel diagnostics are reported via slot 1 with ID number 0.

#### Note

Messages that refer to the PA redundancy, e.g. "Partner DP/PA coupler removed or defective", are reported via the PA redundancy status.

The channel-related diagnostic data for the DP/PA coupler is setup as follows:




Figure 13-17 Structure of the channel-related diagnostics

# DP/PA coupler FDC 157-0 - fault types

Table 13- 21 DP/PA coupler FDC 157-0 - fault types

Fault type		Error text	Meaning	Remedy
00001 <sub>B</sub>	1 <sub>D</sub>	Short-circuit	Equipotential bonding line short-circuited	<ul> <li>Eliminate the fault on the equipotential bonding line.</li> <li>Check the process wiring.</li> </ul>
00110в	6 <sub>D</sub>	Wirebreak	Equipotential bonding line interrupted	Eliminate the fault on the equipotential bonding line.
01001 <sub>B</sub>	9 <sub>D</sub>	Defective coupler	-	Replace the DP/PA coupler.
10000 <sub>B</sub>	16 <sub>D</sub>	Parameter assignment error	Configured redundancy mode and redundancy mode set on the DP/PA coupler do not match.	Check the configured redundancy mode or the redundancy mode set on the DP/PA coupler.
10001 <sub>B</sub>	<b>17</b> <sub>□</sub>	Process voltage missing.	<ul> <li>24 V power supply PS voltage is missing or too low.</li> <li>Power Supply PS is faulty.</li> <li>Partner coupler power logic.</li> </ul>	<ul> <li>Check the power supply on the Power Supply PS.</li> <li>Check the process wiring.</li> </ul>
11000 <sub>B</sub>	24 <sub>D</sub>	PA redundancy fault	<ul> <li>Wire break or short-circuit between two active field distributors.</li> <li>Failure of a DP/PA coupler.</li> </ul>	<ul> <li>Check the processing wiring between the AFDs.</li> <li>Check the defective DP/PA coupler.</li> </ul>
11010 <sub>B</sub>	26 <sub>D</sub>	External fault	DP/PA coupler in redundancy mode: The redundancy modes of the DP/PA coupler pair do not match.	<ul> <li>Check the configured redundancy mode on the DP/PA coupler.</li> <li>Check the redundancy mode in the configuration.</li> </ul>
11011 <sub>B</sub>	27 <sub>D</sub>	Signal level poor (default setting: disabled)	Warning that the signal level on the equipotential bonding line is in the limit range.	Check the lead length of the equipotential bonding line and the process wiring.

# See also

PA redundancy status (Page 212)

### 13.3.2.10 H status

# H-status (only for operation of the DP/PA coupler in the redundant DP/PA link)

The H-status ensures fault-free operation on the equipotential bonding line even when switching over on the overlaid PROFIBUS DP chain. It is irrelevant for the user.

Technical specifications 14

# 14.1 General technical data

# What are general technical specifications?

The technical specifications contain:

- The standards and test values that observe and fulfil the described components.
- The test criteria used to test the described components.

# 14.1.1 Standards and Approvals

The components described in the manual meet the following standards and approvals.

### **Exceptions:**

- DP/PA coupler Ex [i]: Deviations from the standards and approvals listed here are available in the respective chapters.
- Active field distributors: The valid standards and approvals can be found in the respective chapters.

### Note

Currently valid certifications can be found on the rating of the relevant module.

#### 14.1 General technical data

### **CE Label**



The described components meet the requirements and protective aims of the following EC directives and comply with the harmonized European Standards (EN), published for programmable logic controllers (PLC) in the official gazettes of the European Union:

- 2006/95/EC "Electrical Equipment Designed for Use within Certain Voltage Limits" (Low-voltage Directive)
- 2004/108/EC "Electromagnetic Compatibility" (EMC Directive)
- 94/9/EC on "equipment and protective systems for use in hazardous areas" (explosion protection directive)

The EC Declarations of Conformity are available to the relevant authorities at the following address:

Siemens AG Automation and Drives I IA AS R&D ST TYPE TEST P.O. Box 1963 D-92209 Amberg

### **ATEX Approval**



#### KEMA 02ATEX1096 X

to EN 60079-15 (Electrical apparatus for potentially explosive atmospheres; Type of protection "n") and EN 60079-0 (Explosive atmospheres; General requirements).

⟨€x⟩ II 3 G Ex nA II T4 or T5 or T6



Personal injury and material damage can be incurred.

In hazardous areas, personal injury and material damage can be incurred if plug connections are disconnected during operation.

In hazardous areas, only disconnect the plug connections of all components when they are not under current.

# **UL / CSA Approval**



Underwriters Laboratories Inc. in accordance with

#### **Ordinary locations**

- UL 508 (Industrial Control Equipment)
- CSA C22.2 No. 142 (Process Control Equipment)

#### **Hazardous locations**

- UL 1604 or ANSI/ISA-12.12.01
- CSA C22.2 No. 213

APPROVED for use in Class I, Division 2, Group A, B, C, D Tx; Class I, Zone 2, Group IIC Tx

#### **FM Approval**



Factory Mutual Research (FM) in accordance with

Approval Standard Class Number 3611, 3600, 3810

Class I, Division 2, Group A, B, C, D Tx; Class I, Zone 2, Group IIC Tx

## Marking for Australia and New Zealand



The components described fulfill requirements to EN 61000-6-4.

#### **IEC 61131**

The described components meet the requirements and criteria of the IEC 61131-2 standard (programmable logic controllers, part 2 Equipment requirements and tests).

#### **PROFIBUS** standard

The described components are based on the IEC 61784-1:2002 Ed1 CP 3/1 standard.

#### **PROFIBUS PA**

The DP/PA coupler meets the requirements and criteria of the PROFIBUS PA directive.

#### 14.1 General technical data

## Use in industry

SIMATIC products are designed for industrial applications.

Table 14-1 Use in industry

Area of application	Requirements in respect of	
	Noise emission Noise immunity	
Industry	EN 61000-6-4: 2007	EN 61000-6-2: 2005

#### Use in residential areas

When operating any of the components mentioned above in residential areas, you must ensure that RF interference emission does not exceed Limit Class B to EN 61000-6-3.

Suitable measures for achieving RF interference Limit Class B include, for example:

- Installation of grounded switching cabinets / switchboxes
- Use of noise filters in the supply lines

#### See also

Standards and approvals of the active field distributors (AFD) and active field splitters (AFS) (Page 221)

# 14.1.2 Standards and approvals of DP/PA Ex [i] coupler(6ES7157-0AD82-0XA0)

The DP/PA Ex [i] coupler meets the following standards, certificates, and approvals:

#### **CE Label**



The described components meet the requirements and protective aims of the following EC directives and comply with the harmonized European Standards (EN), published for programmable logic controllers (PLC) in the official gazettes of the European Union:

- 2006/95/EC "Electrical Equipment Designed for Use within Certain Voltage Limits" (Low-voltage Directive)
- 2004/108/EC "Electromagnetic Compatibility" (EMC Directive)
- 94/9/EC on "equipment and protective systems for use in hazardous areas" (explosion protection directive)

The EC Declarations of Conformity are available to the relevant authorities at the following address:

Siemens AG Automation and Drives I IA AS R&D ST TYPE TEST P.O. Box 1963 D-92209 Amberg

#### **ATEX Approval**



KEMA 03ATEX1416 X conforming to EN 60079-0, EN 60079-11, EN 60079-15, EN 60079-26, EN 60079-27, EN

⟨€x⟩ II 3 (1) GD Ex nA [ia] [iaD] IIC T4



61241-11

#### WARNING

Injury to persons may result.

In hazardous areas, personal injury and material damage can be incurred if plug connections are disconnected during operation.

In hazardous areas, only disconnect the plug connections of all components when they are not under current.

#### 14.1 General technical data

#### **UL / CSA Approval**



Underwriters Laboratories Inc. in accordance with

#### **Ordinary locations**

- UL 508 (Industrial Control Equipment)
- CAN/CSA C22.2 No. 14 (Process Control Equipment)

#### **Hazardous locations**

- UL 1604, Third Edition
- UL 913, Fifth Edition
- UL 60079-0, UL 60079-11, UL 60079-15
- CAN/CSA C22.2 No. 213
- CAN/CSA C22.2 No. 157
- E60079-0, E60079-11, E60079-15

APPROVED for use in Class I, Division 2, Group A, B, C, D T4 Class I, Zone 1, Group IIC AIS Class I, Division 1, Group A, B, C, D AIS Class II, Division 1, Group E, F, G AIS Class III, Division 1 [AEx ib/ia] IIC, Class I, Zone 0, 1, 2, Group IIC

#### **FM Approval**



Factory Mutual Research (FM) in accordance with

Approval Standard Class Numbers 3600, 3610, 3611, 3810

Class I, Division 2, Group A, B, C, D T4
Class I, Zone 1, Group IIC
AIS Class I, Division 1, Group A, B, C, D
AIS Class II, Division 1, Group E, F, G
AIS Class III, Division 1
[AEx ib/ia] IIC, Class I, Zone 0, 1, 2, Group IIC

# 14.1.3 Standards and approvals of the active field distributors (AFD) and active field splitters (AFS)

#### **CE Label**



The described components meet the requirements and protective aims of the following EC directives and comply with the harmonized European Standards (EN), published for programmable logic controllers (PLC) in the official gazettes of the European Union:

- 2006/95/EC "Electrical Equipment Designed for Use within Certain Voltage Limits" (Low-voltage Directive)
- 2004/108/EC "Electromagnetic Compatibility" (EMC Directive)
- 94/9/EC on "equipment and protective systems for use in hazardous areas" (explosion protection directive)

The EC Declarations of Conformity are available to the relevant authorities at the following address:

Siemens AG Automation and Drives I IA AS R&D ST TYPE TEST P.O. Box 1963 D-92209 Amberg

#### **ATEX Approval**



II 3 G Ex nA II T4 II 3 D Ex tD A22 T72°C

KEMA 06 ATEX 0268 X in accordance with EN 60079-15 (Electrical apparatus for potentially explosive atmospheres; Type of protection "n")



#### Personal injury and material damage can be incurred.

In hazardous areas, personal injury and material damage can be incurred if plug connections are disconnected during operation.

In hazardous areas, only disconnect the plug connections of all components when they are not under current.

#### 14.1 General technical data

# **UL / CSA Approval**



Underwriters Laboratories Inc. in accordance with

#### **Ordinary locations**

- UL 508 (Industrial Control Equipment)
- CSA C22.2 No. 142 (Process Control Equipment)

#### Note

Currently valid certifications can be found on the rating of the relevant module.

# **FM Approval**



Factory Mutual Research (FM) in accordance with

Approval Standard Class Number 3611 (2004)

Class I, Division 2, Group A, B, C, D Tx;

Class I, Zone 2, Group IIC Tx

## Use in industry

SIMATIC products are designed for industrial applications.

Table 14-2 Use in industry

Area of application	Requirements in respect	of
	Noise emission	Noise immunity
Industry	EN 61000-6-4: 2007	EN 61000-6-2: 2005

# 14.1.4 Standards and approvals of active field distributor AFDiS

#### Note

Currently valid certifications can be found on the rating of the relevant module.

#### **CE Label**



The described components meet the requirements and protective aims of the following EC directives and comply with the harmonized European Standards (EN), published for programmable logic controllers (PLC) in the official gazettes of the European Union:

- 2006/95/EC "Electrical Equipment Designed for Use within Certain Voltage Limits" (Low-voltage Directive)
- 2004/108/EC "Electromagnetic Compatibility" (EMC Directive)
- 94/9/EC on "equipment and protective systems for use in hazardous areas" (explosion protection directive)

The EC Declarations of Conformity are available to the relevant authorities at the following address:

Siemens AG Automation and Drives I IA AS R&D ST TYPE TEST P.O. Box 1963 D-92209 Amberg

## **ATEX Approval**



II 2 G (1) GD II 3 G (1) GD II 2 D

Ex e ib mb [ia IIC Ga] [ia IIIC Da] IIC T4 Gb Ex nA ic [ia IIC Ga] [ia IIIC Da] IIC T4 Gc Ex t IIIC T80 °C Db IP66 KEMA 10 ATEX 0055

# **MARNING**

Personal injury and material damage can be incurred.

In hazardous areas, personal injury and material damage can be incurred if plug connections are disconnected during operation.

In hazardous areas, only disconnect the plug connections of all components when they are not under current.

#### 14.1 General technical data

# IEC Ex approval



**IECEx KEM 10.0026** 

#### Use in industry

SIMATIC products are designed for industrial applications.

Table 14-3 Use in industry

Area of application	Requirements in respect of	
	Noise emission	Noise immunity
Industry	EN 61000-6-4: 2007	EN 61000-6-2: 2005

# 14.1.5 Use in zone 2 potentially explosive areas

Refer to the product information: *Use of subassemblies / modules in a zone 2 Hazardous Area*.

The product information is available for download from the Internet (http://support.automation.siemens.com/WW/view/en/19692172).

## 14.1.6 Electromagnetic compatibility

#### Introduction

This chapter provides you with information on the immunity to interference of the described components as well as on radio interference suppression.

The described components meet, among others, the requirements of the EMC legislation of the European single market.

#### **Definition: EMC**

Electromagnetic compatibility (EMC) is the capacity of an electrical installation to function satisfactorily in its electromagnetic environment without affecting that environment.

## Pulse-shaped Interference

The table below shows the electromagnetic compatibility of the described components with regard to pulse-shaped interference. The prerequisite for this is that the system complies with the relevant requirements and guidelines relating to electrical equipment.

Table 14-4 Pulse-shaped Interference

Pulse-shaped disturbance	Tested at	Corresponds to severity		
Electrostatic discharge according to IEC 61000-4-2	8 kV 6 kV	3 (air discharge) 3 (contact discharge)		
Burst impulses (fast transient interference) according to IEC 61000-4-4	2 KV (power supply lines) 2 kV (signal cable)	3		
High-energy current surge according to IEC 61000-4-5				
External protective circuitry required (Refer to Instruction Manual SIMATIC S7-300 CPU 31xC and CPU 31x: Installation ( <a href="http://support.automation.siemens.com/WW/view/en/36305386">http://support.automation.siemens.com/WW/view/en/36305386</a> ), chapter Lightning and surge voltage protection)				
No external protective element is required for the PA bus.				
Asymmetric interference	2 kV (supply line) 2 kV (signal cable/data line)	3		
Symmetric interference	1 kV (supply line) 1 kV (signal line / data line)			

#### Sinusoidal disturbance

EMC performance of the described components in relation to sinusoidal disturbance variables:

- RF radiation to IEC 61000-4-3 Electromagnetic RF field, amplitude modulated
  - 80 MHz to 1000 MHz / 1.4 GHz to 2 GHz
  - 10 V/m
  - Modulated with 80% AM (1 kHz)
- RF coupling to IEC 61000-4-6
  - 0.15 to 80 MHz
  - Amplitude of unmodulated carrier: 10 V<sub>eff</sub>
  - Modulated with 80% AM (1 kHz)
  - 150  $\Omega$  source impedance

#### **Emission of Radio Interferences**

Noise emission of electromagnetic fields according to EN 61000-6-4: limit value class A, group 1

from 30 to 230 MHz	< 40 dB (μV/m)Q
from 230 to 1000 MHz	< 47 dB (μV/m)Q
measured at a distance of 10 m	

Noise emission via supply lines in accordance with EN 61000-6-4: limit value class A, group 1

from 0.15 to 0.5 MHz	< 79 dB (μV)Q < 66 dB (μV) M
from 0.5 to 5 MHz	< 73 dB (μV)Q < 60 dB (μV) M
from 5 to 30 MHz	< 73 dB (μV)Q < 60 dB (μV) M

# 14.1.7 Shipping and storage conditions

# **Transport and Storage of Modules**

With regard to their transport and storage conditions, the described components exceed the requirements according to IEC 61131, Part 2. The following specifications apply to modules transported and stored in the original packaging.

Table 14-5 Transport and storage conditions

Type of condition	Permitted range
Free fall (in transport packaging)	≤ 0.3 m
Temperature	from -40 °C to + 70 °C
Atmospheric pressure	from 1080 to 660 hPa (corresponds to an altitude of -1000 to 3500 m)
Relative humidity	of 10 to 95 %, without condensation
Sinusoidal vibrations according to IEC 60068-2-6	5 to 9 Hz: 3.5 mm
	9 to 150 Hz: 9.8 m/s <sup>2</sup>
Shock according to IEC 60068-2-29	250 m/s <sup>2</sup> , 6 ms, 1000 shocks

## 14.1.8 Mechanical and climatic ambient conditions for operation

#### Conditions of use

The described components are designed for use in a fixed, sheltered location. The operating conditions exceed the requirements of IEC 61131 Part 2.

The described components meet the operating conditions of Class 3C3 in accordance with DIN EN 60721-3-3.

#### Use with additional measures

The described components must not be operated without additional measures:

- at locations with a high degree of ionizing radiation
- in aggressive environments caused, for example, by
  - the development of dust
  - corrosive vapors or gases
  - strong electric or magnetic fields
- in installations requiring special monitoring, for example
  - elevators
  - electrical plants in potentially hazardous areas

An additional measure can be installation in a cabinet or in an enclosure, for instance.

#### Mechanical ambient conditions

The mechanical ambient conditions for the described components are specified in the table below for sinusoidal vibrations.

Table 14- 6 Mechanical ambient conditions

Frequency range in Hz	Continuous	Infrequently
10 ≤ f ≤ 58	0.0375 mm amplitude	0.075 mm amplitude
58 ≤ f ≤ 150	0.5 <i>g</i> constant acceleration	1g constant acceleration

#### Reduction of vibrations

If the described components are subject to big shocks or vibrations appropriate measures must be taken to reduce the acceleration or the amplitude.

We recommend fixing the described components on damping materials, for example on rubber-metal anti-vibration mountings.

## 14.1 General technical data

# Checking mechancial environmental conditions

The following table provides information on the type and scope of checks regarding mechanical environmental conditions.

Table 14-7 Checking Mechanical Environmental Conditions

Checking for	Test standard	Remarks
Vibrations	Vibration test in compliance with IEC 60068-2-6 (sine)	Type of vibration: Frequency sweeps with a sweep rate of 1 octave/minute.
		5 Hz ≤ f ≤ 9 Hz, constant amplitude 3.5 mm
		9 Hz ≤ f ≤ 150 Hz, constant acceleration 1 <i>g</i>
		Period of oscillation: 10 frequency sweeps per axis in each of the 3 axis which are vertical to each other.
Shock	Shock test in accordance	Type of shock: half-sine
	with IEC 60068-2-29	Strength of shock: 15 <i>g</i> peak value, 11 ms duration
		Shock direction: 3 shocks each in +/- direction in each of the 3 axes that are vertical to each other

# Climatic enviornmental conditions

The described components can be used in the following climatic environmental conditions:

Table 14-8 Climatic enviornmental conditions

Ambient conditions	Permitted range	Remarks
Temperature: Horizontal installation Vertical installation	from 0 to 60 °C from 0 to 40 °C	<ul> <li>IM 153-2 as of 6ES7153-2BA01-0XB0</li> <li>Y coupler 6ES7197-1LB00-0XA0</li> <li>Bus module BM IM/IM 6ES7195-7HD10-0XA0</li> <li>Bus module BM Y coupler 6ES7654-7HY00-0XA0</li> </ul>
Temperature: Horizontal installation Vertical installation	from -25 to 60 °C from -25 to 40 °C	<ul> <li>IM 153-2 Outdoor as of 6ES7153-2BA81-0XB0</li> <li>DP/PA coupler FDC157-0 6ES7157-0AC83-0XA0</li> <li>DP/PA coupler 6ES7157-0AC82-0XA0</li> <li>DP/PA Ex [i] coupler 6ES7157-0AD82-0XA0</li> <li>Bus module BM IM/IM 6ES7195 7HD80 0XA0</li> <li>Bus module BM FDC 6ES7195-7HF80-0XA0</li> <li>Bus module BM FDC/FDC (redundant) 6ES7195-7HG80-0XA0</li> </ul>
Temperature: any type of installation	from -25 to 70 °C	<ul><li>Active field distributor (AFD)</li><li>Active field splitter (AFS)</li></ul>
	from -40 to 70 °C	Active field distributor AFDiS
Relative humidity	from 10 to 95 %	Without condensation, corresponds to relative humidity (RH) stress class 2 in accordance with IEC 61131-2 With condensation:  Active field distributor (AFD)  Active field splitter (AFS)  Active field distributor AFDiS
Atmospheric pressure	from 1080 to 795 MHz	corresponds to a height of -1000 to 2000 m
Contaminant concentration	$SO_2$ : < 0.5 ppm; RH < 60 %, no condensation $H_2S$ : < 0.1 ppm; RH < 60 %, no condensation	Test: 10 ppm; 4 days Test: 1 ppm; 4 days

#### 14.1 General technical data

# 14.1.9 Specifications for insulation tests, protection class and degree of protection

#### Test voltages

The insulation stability is tested with the following voltages during product testing:

Table 14-9 Test voltages

Circuits with a rated voltage of U <sub>e</sub> relative to other circuits or ground	Test voltage
0 V < U <sub>e</sub> ≤ 50 V	DC 600 V, 1 s

#### **Protection class**

Protection class I in compliance with IEC 61140; this means that a grounding terminal to the rail is required!

#### Protection against foreign bodies and water

Degree of protection IP 20 according to IEC 60529; that is protection against contact with standard probes.

There is no protection from penetration by water.

## 14.1.10 Rated voltage

#### Rated voltage for operation

The described components work with a rated voltage of 24 V DC.

The tolerance range extends from 20.4 V DC to 28.8 V DC.

#### **Exceptions:**

The AFD , AFS and AFDiS active field distributors operate from a rated voltage of 16 VDC. The tolerance range extends from 16 VDC to 32 VDC.

# 14.2 Technical specifications of the IM 153-2 (6ES7153-2BAx2-0XB0)

Technical specifications		
Order number 6ES7153-2BAx2-0XB0		
Dimensions and weight		
Dimension W x H x D (mm)	40 x 125 x 117	
Weight	Approx. 360 g	
Module-specific data		
Transmission speed for the higher level DP master system	9.6; 19.2; 45.45; 93.75; 187.5; 500 kBaud 1.5; 3; 6; 12 MBaud	
Bus protocol	PROFIBUS DP	
Frame length I / O data	Max. 244 bytes	
Length of configuration frame	Max. 244 bytes	
Length of diagnostic frame	Max. 231 bytes	
Length of parameter assignment frame	Max. 223 bytes	
suitable for system modifications during operation	Yes	
Voltages, currents, potentials		
Rated supply voltage	24 VDC (20.4 V to 28.8 V)	
Polarity reversal protection	Yes	
Power failure bypass	20 ms	
Electrical isolation		
• to a high-level DP master system	Yes	
to the DP/PA or Y coupler	No	
Insulation tested with	500 VDC	
when used in the DP/PA link		
Power consumption (24 VDC)	Max. 200 mA (at 20.4 V)	
Power loss	Max. 2.6 W (at 28.8 V)	
when used in the Y link		
Power consumption (24 VDC)	Max. 400 mA (at 20.4 V)	
Power loss	Max. 3.6 W (at 28.8 V)	
Status, interrupts, diagnostics		
Status display	No	
Interrupts	Yes	
Diagnostics function	Yes	
Group error	Red LED "SF"	
Bus error on higher level DP master system	Red LED "BF 1"	
Bus error on lower-level bus system	Red LED "BF 2"	
IM has an active channel	Yellow LED "ACT"	
Monitoring 24 V power supply	Green "ON" LED	
Voltages, currents, potentials Rated supply voltage Polarity reversal protection Power failure bypass Electrical isolation to a high-level DP master system to the DP/PA or Y coupler Insulation tested with when used in the DP/PA link Power consumption (24 VDC) Power loss when used in the Y link Power consumption (24 VDC) Power loss Status, interrupts, diagnostics Status display Interrupts Diagnostics function Group error Bus error on higher level DP master system Bus error on lower-level bus system IM has an active channel	24 VDC (20.4 V to 28.8 V) Yes 20 ms  Yes No 500 VDC  Max. 200 mA (at 20.4 V) Max. 2.6 W (at 28.8 V)  Max. 400 mA (at 20.4 V) Max. 3.6 W (at 28.8 V)  No Yes Yes Red LED "SF" Red LED "BF 1" Red LED "BF 2" Yellow LED "ACT"	

# 14.3 Technical data DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)

Data for connecting lower-level bus components		
DP/PA coupler can be connected	Max. 5	
Y coupler can be connected	1	
Lower-level slaves can be connected	Max. 64	
Number of slots in lower-level slaves	(244 minus number of PA field devices), but not more than 236	
Delay Update for the I/O image		
Single mode	15 ms	
Redundancy mode     Detect PrmCMD primary side     Changeover without CFG changes     Changeover with CFG changes	30 ms 3 x Ttr 4 x Ttr	

# 14.3 Technical data DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)

Technical specifications		
Order number	6ES7157-0AC83-0XA0	
Dimensions and weight		
Dimension W x H x D (mm)	80 x 125 x 130	
Weight	Approx. 515 g	
Module-specific data		
Transmission speed on PROFIBUS DP	45.45 kBaud	
Transmission speed on PROFIBUS PA	31.25 kBaud	
Bus protocol	PROFIBUS DP	
Voltages, currents, potentials		
Rated supply voltage	24 VDC (20.4 V to 28.8 V)	
Polarity reversal protection	Yes	
Overvoltage protection	Yes	
Output voltage for PA section:	31 VDC ± 1 V	
Voltage monitoring	15.5 V	
Voltage monitoring	U > 35 V; latching cutoff	
Power failure bypass	Min. 5 ms	
Electrical isolation of the 24 V power supply		
PROFIBUS DP / PROFIBUS PA	Yes	
PROFIBUS DP / supply	Yes	
PROFIBUS PA / supply	Yes	
All electric circuits / FE	Yes	
Insulation tested with	500 VDC	

# 14.3 Technical data DP/PA coupler FDC 157-0 (6ES7157-0AC83-0XA0)

DP/PA coupler power consumption (24 VDC)	Max. 2.3 A
Output current PA section (for dimensioning the PA configuration)	1 A
Power loss of the module	Max. 13.4 W
Status, interrupts, diagnostics	
Status display	No
Interrupts	None
Diagnostics function	Yes
Group error	Red LED "SF"
Bus fault	Red LED "BF"
PROFIBUS DP bus monitoring	Yellow LED "DP"
PROFIBUS PA bus monitoring	Yellow LED "PA"
DP/PA coupler monitoring	Yellow LED "ACT"
Monitoring 24 V power supply	Green "ON" LED
Data for selecting the PA field devices	
Connection to DP/PA couplers	max. power consumption of the PA field devices together 1 A
	Field devices with certification for PROFIBUS PA
	Field devices are located <b>outside</b> the hazardous area
	max. 31 PA field devices can be connected

# 14.4 Technical specifications of DP/PA coupler Ex [i] (6ES7157-0AD82-0XA0)

Technical specifications		
6ES7157-0AD82-0XA0		
80 x 125 x 130		
Approx. 550 g		
45.45 kBaud		
31.25 kBaud		
PROFIBUS DP		
€x II 3G (1) GD Ex nA [ia] [iaD] IIC T4		
1		
24 VDC (20.4 V to 28.8 V)		
Yes		
Min. 5 ms		
13 VDC to 14 VDC		
Max. 110 mA		
Yes		
Yes		
500 VAC		
Max. 400 mA		
Typically 7 W		
No		
None		
Yes		
Yellow LED "DP"		
Yellow LED "PA"		
Green "ON" LED		
Ex [i] characteristic data		
= 15 V		
= 247 mA		
= 1.95 W		
= 250 V AC		
= -25 to +60 °C		

Connectable cables (PA)		
• R'	15 to 150 Ω/km	
• Ľ	0.4 to 1 mH/km	
• C'	80 to 200 nF/km	
• Length	max. 1000 m; for safety reasons (Ex protection)	
Data for selecting the PA field devices		
Connection to DP/PA couplers	Field devices with certification for PROFIBUS PA	
	max. 31 PA field devices can be connected	
	<ul> <li>Power consumption of all PA field devices: max. 110 mA</li> </ul>	
Approval data of the PA field devices must conform to the Ex [i] characteristic data of the DP/PA coupler:		
• U <sub>i</sub>	≥ 15 V	
• I <sub>i</sub>	≥ 247 mA	
• P <sub>i</sub>	≥ 1.95 W	

# 14.5 Technical specifications Y coupler (6ES7197-1LB00-0XA0)

Technical specifications		
Order number	6ES7197-1LB00-0XA0	
Dimensions and weight		
Dimension W x H x D (mm)	40 x 125 x 130	
Weight	Approx. 200 g	
Module-specific data		
Transmission speed for the lower-level DP master system	45.45; 93.75; 187.5; 500 kBaud 1.5; 3; 6; 12 MBaud	
Bus protocol	PROFIBUS DP	
Length of parameter assignment frame	Max. 244 bytes	
Voltages, currents, potentials		
Power supply	via bus module	
Power consumption	Max. 300 mA	
Power loss of the module	Typically 1 W	
Electrical isolation from lower-level DP master system	Yes	
Insulation tested with	500 VDC	

Status, interrupts, diagnostics		
Status display	No	
Interrupts	None	
Diagnostics function	Yes	
Bus monitoring of internal PROFIBUS DP	Yellow LED "DP 1"	
Bus monitoring of external PROFIBUS DP	Yellow LED "DP 2"	
Monitoring of the power supply	Green "ON" LED	
Data for connecting DP slaves		
DP slaves can be connected	max. 64, only if RS 485 repeaters or OLM / OBT are used, otherwise max. 31	
Termination of the lower-level DP master system	Active terminator resistor (BUS TERMINATOR)	
Use of RS 485 repeaters	Max. 8	
Use of OLM / OBT	Yes	

# 14.6 Technical data - active field splitter (AFS) (6ES7157-0AF82-0XA0)

Technical specifications	
Product version	02
Protection class	IP65
Dimensions and weight	
Dimension W x H x D (mm)	125 X 57 x 80; with screw gland 175 x 57 x 105
Weight	Approx. 700 g
Voltages, currents, potentials	
Rated supply voltage	16 VDC to 32 VDC
Polarity reversal protection	Yes
Overvoltage protection	Yes
Power failure bypass	5 ms
Internal power consumption	Max. 25 mA
Output current PA section (for dimensioning the PA configuration)	1 A
Power loss of the module	Max. 1 W
Status, interrupts, diagnostics	
Status display	No
Interrupts	None
Diagnostics function	Yes
Status PA main line PA1, PA2	Green LED
Fault PA main line PA1, PA2	Red LED
Data for selecting the PA field devices	
Connection to DP/PA couplers	max. power consumption of the PA field devices together 1 A
	Field devices with certification for PROFIBUS PA
	max. 31 PA field devices can be connected

# 14.7 Technical data - active field distributor (AFD) (6ES7157-0AF81-0XA0)

Technical specifications		
Product version	02	
Protection class	IP65	
Dimensions and weight		
Dimension W x H x D (mm)	125 X 57 x 80; with screw gland 175 x 57 x 105	
Weight	Approx. 700 g	
Voltages, currents, potentials		
Rated supply voltage	16 VDC to 32 VDC	
T <sub>max</sub>	35 V	
Polarity reversal protection	Yes	
Internal power consumption	Max. 25 mA; with an open main connection line 59 mA	
Status, interrupts, diagnostics		
Status display	No	
Interrupts	None	
Diagnostics function	Yes	
Status PA main line PA1, PA2	Green LED	
Fault PA main line PA1, PA2	Red LED	
Status / fault PA spur line X1 to X4	Green LED	
Data for selecting the PA field devices		
Connection	Field devices with certification for PROFIBUS PA	
	max. 4 PA field devices can be connected	
Current I <sub>max</sub> pro PA spur line X1 to X4	• 60 mA	

# 14.8 Technical specifications of active field distributor AFDiS (6ES7157-0AG83-0XA0)

Technical specifications		
Order number	6ES7157-0AG83-0XA0	
Product version	01	
Dimensions and weight		
Dimension W x H x D (mm)	380 x 85 x 170	
Weight	4500 g	
Supply voltages		
Description	Via bus; no auxiliary power necessary	
Nominal value		
Lower limit of permissible range (DC)	16 V	
Upper limit of permissible range (DC)	32 V	
Polarity reversal protection (only in connection with DP/PA coupler)	Yes; up to 1 A	
Overvoltage protection	No	
Current consumption/power loss		
Power consumption		
At 28 V input voltage	<= 64 mA + (0.838 * aggregate current of all the field devices)	
At 24 V input voltage	<= 67 mA + (1.008 * aggregate current of all the field devices)	
At 20 V input voltage	<= 74 mA + (1.246 * aggregate current of all the field devices)	
Short-circuit at all the spur lines		
At 28 V input voltage	92 mA	
At 24 V input voltage	100 mA	
At 20 V input voltage	110 mA	
Power loss, min.	1.4 W	
Power loss, max.	5.9 W	
Interfaces		
PROFIBUS DP	No	
PROFIBUS PA	Yes	
FOUNDATION Fieldbus H1	Yes	

Connections	
Main cables	
Number	2
Terminals (internal)	Screw-type terminals (3-pin)
Cable gland (enclosure)	M16
Cable type	Type A
Min. cable diameter	4 mm
Max. cable diameter	9 mm
Min. conductor cross-section	0.2 mm <sup>2</sup>
Max. conductor cross-section	2.5 mm <sup>2</sup>
Automatic bus terminator	Yes
Spur cables	
Number n	6
Connecting terminals	Screw-type terminals (3-pin)
Cable gland	M16
Cable type	Type A
Min. cable diameter	4 mm
Max. cable diameter	9 mm
Min. conductor cross-section	0.2 mm <sup>2</sup>
Max. conductor cross-section	2.5 mm <sup>2</sup>
Short-circuit-proof	Yes
Intrinsically-safe acc. to FISCO	Yes
Max. DC current of the field devices spur line 1	60 mA
Max. DC current of the field devices spur line 2 to 6	40 mA
Max. DC total current of all the field devices	180 mA
Short-circuit current (test current)	5 mA
Debounce logic	Yes
Max. no-load voltage	15.3 V
Max. current output to field devices	260 mA
Grounding	
Direct grounding	Via connection bar
Interrupts, diagnostics, status information	
Status display	Yes
Interrupts	None
Diagnostics function	Yes
Diagnostic indicator LED	Yes
Data transfer	
Between main line and spur lines	Repeater function
Electrical isolation	
Between main line and spur lines	Yes
Test voltage	2550 VDC 2s

# 14.8 Technical specifications of active field distributor AFDiS (6ES7157-0AG83-0XA0)

Environmental requirements		
Operating temperature		
• min.	-40 °C	
• max.	70 °C	
Storage/transport temperatures		
• min.	-40 °C	
• max.	85 °C	
Relative humidity		
Operation, max.	95%	
Degree of protection	IP66	
Installation		
Zone 2 / Zone 22	Yes	
Zone 1 / Zone 21	Yes	
Class I Zone 2 / Division 2	Yes	
Class I Zone 1	Yes	

# Appendix

# A.1 Dimension drawings

# A.1.1 Active field distributor AFD/AFS




Figure A-1 AFD / AFS dimension drawing

# A.1 Dimension drawings





Figure A-2 AFD / AFS dimension drawing side view

# A.1.2 Active field distributor AFDiS






Figure A-3 AFDiS dimension drawing front

# A.1 Dimension drawings




Figure A-4 AFDiS dimension drawing side view

# A.2 Order numbers

# A.2.1 Components of the bus links

# Components of the bus links

Table A- 1 Order numbers for the components of the bus couplers

Component	Order number
IM 153-2 High Feature	6ES7153-2BA02-0XB0
IM 153-2 High Feature Outdoor	6ES7153-2BA82-0XB0
DP/PA coupler FDC 157-0	6ES7157-0AC83-0XA0
DP/PA coupler Ex [i]	6ES7157-0AD82-0XA0
Y coupler	6ES7197-1LB00-0XA0
Bus module BM PS/IM	6ES7195-7HA00-0XA0
Bus module BM PS/IM SIPLUS extreme	6AG1195-7HA00-2XA0
Bus module BM IM/IM	6ES7195-7HD10-0XA0
Bus module BM IM/IM Outdoor	6ES7195-7HD80-0XA0
Bus module BM FDC	6ES7195-7HF80-0XA0
Bus module BM FDC/FDC (redundant)	6ES7195-7HG80-0XA0
Bus module BM Y coupler	6ES7654-7HY00-0XA0
Active field distributor (AFD)	6ES7157-0AF81-0XA0
Active field distributor AFDiS	6ES7157-0AG83-0XA0
Active field splitter (AFS)	6ES7157-0AF82-0XA0
Complete package Y link:	6ES7197-1LA04-0XA0
2 x IM 153-2 High Feature	
1 x bus module BM IM/IM	
1 x Y coupler	
1 x bus module BM Y coupler	
Complete package Y link:	6ES7197-1LA11-0XA0
2 x IM 153-2 High Feature Outdoor	
1 x bus module BM IM/IM	
1 x Y coupler	
1 x bus module BM Y coupler	

#### A.2 Order numbers

Table A- 2 Order number for configuration accessories

Component	Order number
Mounting rail for the "module exchange in operation" function	
• 482.6 mm	6ES7195 1GA00 0XA0
• 530 mm	6ES7195 1GF30 0XA0 6ES7195 1GG30 0XA0
• 620 mm	6ES7195 1GC00 0XA0
• 2000 mm	
Bus connector for S7 mounting rails (each DP/PA coupler includes one)	6ES7390 0AA00 0AA0
Covers (included are 4 backplane bus covers and 1 bus module cover)	6ES7195 1JA00 0XA0
Cable gland for active field splitter AFS	Can be ordered at: Jacob GmbH (http://www.jacob-gmbh.de/en/) order number 50.616 M/EMC
Fastener for HSK-Ex standard cable glands	Can be ordered from: Hummel Elektrotechnik GmbH (http://www.hummel-group.com/) order number 1.296.0901.11
Sealing caps for unused connections on AFDiS (10 units)	6ES7157-0AG80-1XA1

# A.2.2 Accessories for PROFIBUS DP

# Accessories for PROFIBUS DP

Table A- 3 Order numbers for PROFIBUS DP accessories

Accessories	Order number
PROFIBUS DP bus connector (up to 12 MBaud)	
without PD port	6ES7972-0BA12-0XA0
with PD port	6ES7972-0BB12-0XA0
PROFIBUS DP FastConnect connector	
without PD port	6ES7972-0BA50-0XA0
with PD port	6ES7972-0BB50-0XA0
PROFIBUS DP bus cable	
normal (flexible)	6XV1830-0AH10
Drum cable (strong)	6XV1830-3BH10
PROFIBUS DP terminator	6ES7972-0DA00-0XA0

#### A.2.3 Accessories for PROFIBUS PA

#### Accessories for PROFIBUS PA

Table A- 4 Order numbers for PROFIBUS PA accessories

Accessories	Order number
PROFIBUS PA bus cable (cable type A)	6XV1830-5AH10

#### Configuration With the SpliTConnect Connector System

Create the configuration with the SpliTConnect connector system. The SpliTConnect connection system permits an easy-to-install configuration of PROFIBUS PA segments conforming to IEC 61784-1:2002 Ed1 CP 3/2 with field device connection points in intrinsically safe and non-intrinsically safe areas. The SpliTConnect connector system consists of the following components:

Accessories	Description	Order number
SpliTConnect Tap	T-connector for PA field device	6GK1905-0AA00
SpliTConnect M12 Outlet	Connecting element for M12 connection	6GK1905-0AB10
SpliTConnect Coupler	Connecting element between the taps	6GK1905-0AC00
SpliTConnect M12 Terminator (Ex)	Terminator resistor for potentially explosive areas	6GK1905-0AD00
SpliTConnect M12 Terminator	Terminator resistor for non-explosion hazardous areas	6GK1905-0AE00
SpliTConnect M12 Jack	Connecting element for M12 connection	6GK1905-0AF00

#### Bus terminating element

The SpliTConnect tap can also be extended as a bus terminating element.

#### Wiring with the (FastConnect) fast installation cable

Wire the PROFIBUS PA segments with the fast installation cable (FastConnect cable):

Accessories	Description	Order number
FC PROFIBUS PA (blue)	Fast installation cable	6XV1830-5EH10
FC PROFIBUS PA (black)		6XV1830-5FH10

## Stripping

Strip the FastConnect cables with the FastConnect stripping tool. You can remove the outer covering and the braided shield with accurately to the millimeter in a single step with the FastConnect stripping tool

Accessories	Description	Order number
FastConnect Stripping Tool	Stripping tool	6GK1905-6AA00
Blade Cassettes	Spare blade cassettes	6GK1905-6AB00

#### Additional information

For additional information please refer to the STPI Catalog.

## A.3 Basics about PROFIBUS PA

#### **PROFIBUS PA**

PROFIBUS PA is the PROFIBUS for **P**rocess-**A**utomation (PA) and is based on IEC 61784-1:2002 Ed1 CP 3/2 for transmission technology and protocol and on the PA profile.

PROFIBUS PA = PROFIBUS DP communication protocol

+

synchronous transmission technology

+

Power supply to the PA field devices

#### Connectable field devices

You can connect any field device to the bus coupler DP/PA link that is suitable for PROFIBUS PA.

- Measuring transducers, valves, actuators etc.
- networked via a serial bus system
- for use in the chemicals industry and process engineering
- with field device feed via the data cable
- also for applications in the potentially explosive area (ignition protection type Ex [ia])

# A.3.1 Intrinsic safety

#### Intrinsic safety

The basis for the intrinsic safety type of ignition protection consists in the necessity for a specific amount of ignition energy for ignition to take place in a potentially explosive atmosphere. In an intrinsically safe power circuit this minimum ignition energy is not present, neither in normal operation nor in case of fault. The intrinsic safety of a power circuit is achieved by limiting current and voltage so as to avoid sparks and high temperatures as possible sources of ignition. This limits the intrinsic safety type of ignition protection to relatively low output power circuits.

### Spark ignition

So-called spark ignition is excluded because sparks that can normally occur owing to short circuit or ground fault during operation when a power circuit is opened or closed are excluded because current and voltage are limited as well as owing to the avoidance of major inductivities.

## Heat ignition

In normal operation and in case of failure heat ignition is not possible because excessive heating of the equipment and leads in the intrinsically safe power circuit is excluded.

#### Additional information

For additional information on the topics intrinsic safety and explosion protection please refer to:

- Automation Systems S7-300, ET 200M Ex I/O Modules manual (http://support.automation.siemens.com/WW/view/en/1096709)
- Investigation of intrinsic safety for field bus systems; PTB Report W-53, Braunschweig, March 1993
- PROFIBUS PA Commissioning Guide, Notes on using the IEC 61158-2 technology for PROFIBUS, (German art. no. 2.091, English art. no. 2.092)
   PROFIBUS-Nutzerorganisation e. V. (<a href="http://www.profibus.com">http://www.profibus.com</a>)
   Haid-und-Neu-Straße 7, D-76131 Karlsruhe

# A.3.2 Field device supply via PROFIBUS PA

#### Operating principle

When the DP/PA link bus coupler is used the field devices can be supplied via the data cable from PROFIBUS PA.

#### Installation

The aggregate current of all the field devices must not exceed the maximum output power of the DP/PA coupler. The maximum output power therefore limits the number of field devices that can be connected to the PROFIBUS PA.




Figure A-5 Remote supply to field devices

#### **Extension**

You must use a further DP/PA coupler if you exceed the maximum output current of the DP/PA coupler.


#### See also

Configuration of PROFIBUS PA with the DP/PA link bus coupler (Page 251)

# A.3.3 Configuration of PROFIBUS PA with the DP/PA link bus coupler

#### Configuration

The figure below describes the configuration of a PROFIBUS PA system with one DP master



#### Rules

The following rules apply when configuring PROFIBUS PA:

- a maximum of 31 PA field buses may be present in a physical PROFIBUS PA segment.
- Onlyone supply device (= DP/PA couplers) can be connected in a given physical PROFIBUS PA segment.
- a maximum of 64 PA field devices may be attached in a DP/PA link. The maximum number of connectable PA field devices per physical PROFIBUS PA segment or per DP/PA coupler is limited by the maximum output current of the DP/PA coupler and the I/O data to be transmitted.

#### See also

Technical specifications of DP/PA coupler Ex [i] (6ES7157-0AD82-0XA0) (Page 234)

# A.3.4 Line and star-type topology

#### **Topology**

The topology of PROFIBUS PA may be in linear or stellar form.




Figure A-6 Line and star-type topology

#### **Network extension**

The maximum length of the main line and the spur lines of a standard PROFIBUS PA cable (cable type A according to PNO) if the maximum current is drawn from DP/PA couplers is:

- 560 m for DP/PA couplers
- 920 m for DP/PA Ex [i] couplers

#### Note

If the aggregate power consumption is low and the PA field devices have a distributed arrangement, longer lines may be used.

#### Bus terminator for PROFIBUS PA

To ensure perfect operation the end of a PROFIBUS PA cable must definitely be equipped with a bus terminator.

An RC element connected in series must be used for the bus terminator (R = 100  $\Omega$  ± 2 %; C = 1  $\mu$ F ± 20 %).

# Spur lines

The maximum permissible length of a spur line can be found in the following table. Please pay attention to the maximum length of the aggregate line.

Table A- 5 Spur line length for the DP/PA couplers

Number of spur lines	maximum length of a spur line	
	DP/PA coupler	DP/PA coupler Ex [i]
1 to 12	max. 120 m	max. 60 m
13 to 14	max. 90 m	max. 60 m
15 to 18	max. 60 m	max. 60 m
19 to 24	max. 30 m	max. 30 m

### See also

Accessories for PROFIBUS DP (Page 246)

Accessories for PROFIBUS PA (Page 247)

A.3 Basics about PROFIBUS PA

# Glossary

#### **Address**

The address of a node is used for localising it in the network. It has to be unique in the entire network.

### Aggregate current

Total current of all PA field devices

### Automation system

An automation system is a programmable control system, consisting of at least one CPU, various input and output modules as well as operating and monitoring devices.

#### Bus

A common transfer route to which all nodes are connected; it has two defined ends.

#### **Bus connector**

Physical connection between bus node and bus line.

### Coupler

The DP/PA coupler connects a PROFIBUS PA segment to a PROFIBUS DP segment. PROFIBUS PA and PROFIBUS DP are coupled to one another in terms of data but are separate in terms of the transmission physics.

### Diagnostic interrupt

Diagnostics-capable components report system errors they have detected to the central CPU by means of diagnostic interrupts.

In SIMATIC S7: When an error is detected or disappears (e.g. wire break), provided the interrupt is enabled, the module initiates a diagnostic interrupt. The CPU interrupts the processing of the user program and lower priority priority classes and processes the diagnostic interrupt block (OB 82).

In SIMATIC S5: The diagnostic interrupt is shown within the device-related diagnostics You can identify errors, such as wire break, by cyclically scanning the diagnostic bits.

### **Diagnostics**

Diagnostics is the detection, localisation, classification, display and further evaluation of errors, faults and messages.

Diagnostics provides monitoring functions that run automatically while the plant is in operation. This increases the availability of plants by reducing commissioning times and downtimes.

### **DP** master

A master that behaves in conformity with IEC 61784-1:2002 Ed1 CP 3/1 is termed a DP master.

### **DP** slave

A slave that is operated on the PROFIBUS bus with the PROFIBUS DP protocol and that behaves in conformity with IEC 61784-1:2002 Ed1 CP 3/1 is termed a DP slave.

#### **DP** standard

is the bus protocol of the distributed I/O system in compliance with IEC 61784-1:2002 Ed1 CP 3/1

### DPV0

- Cyclical data exchange between the central control system and slaves
- Configuration using GSD files
- Diagnostics

### DPV1

#### Extension of DPV0:

- Acyclical data exchange between the central control system and slaves
- Integration in engineering systems via EDD or FDT / DTM
- Transferable PLC software function blocks (IEC 61131-3)
- Fail-safe communication (PROFIsafe)
- Interrupts

### Electromagnetic compatibility

Electromagnetic compatibility is the capacity of electrical equipment to function faultlessly in a specified environment without affecting the environment in an inadmissible manner.

### Equipment, associated

A piece of electrical equipment that contains both intrinsically safe and non-intrinsically safe power circuits and is configured so that the non-intrinsiclly safe power circuits cannot impede the intrinsically safe ones.

### Equipment, electrical

Components, power circuits or parts of power circuits that are normally to be found in their entirety in a single enclosure.

### Equipment, intrinsically safe, electrical

A piece of electrical equipment in which all power circuits are intrinsically safe.

### **Equipotential bonding**

Electrical connection (equipotential bonding conductor) that brings the bodies of electrical equipment and external conductive bodies to an equal or almost equal potential level to prevent disturbing or dangerous voltages between these bodies.

#### Field bus

The field bus is a serial bus system for the distributed integration of field devices in an automation system

### **Floating**

Having no conductive connection to ground

#### Ground

The conductive earth whose electrical potential can be set equal to zero at any point.

Ground refers to the entirety of all interconnected inactive parts of a piece of equipment that cannot possess a dangerous contact voltage, even in the event of a malfunction.

### Ground

The conductive earth whose electrical potential can be set equal to zero at any point.

Ground refers to the entirety of all interconnected inactive parts of a piece of equipment that cannot possess a dangerous contact voltage, even in the event of a malfunction.

#### **Ground terminal PE**

Name of the connector on electrical equipment used in hazardous areas and to which the equipotential bonding system is connected.

### Grounding

Grounding means connecting an electrically conductive part to a grounding system by means of the ground electrode.

#### GSD file

All slave-specific properties are stored in a Device Data Base File (DDBF file). The format of the DDBF file is to be found in the PROFIBUS guideline: Specification for PROFIBUS Device Description and Device Integration Vol.1: GSD V4.1, 07/2001 of the PROFIBUS-Nutzerorganisation (PNO).

### H system

High availability system consisting of at least two central modules or two separate devices, for example PCs (master / reserve). The user program is processed identically in the master and in ther reserve devices.

### Hazardous area (Ex area)

Area in which a potentially explosive gas atmosphere is present or expected in such quantities that special measures with regard to the design, installation and use of equipment are required.

### **HW Config**

Integral part of STEP 7 for configuring hardware.

#### Identification and maintenance data

Identification data (I data) is information on the module, some of which are printed onto the module enclosure. I data are for reading only.

Maintenance data (M data) is plant-dependent information such as installation location, installation date etc. M data are created during configuration and written onto the module.

Identification and maintenance data (I&M) is information stored in a module to support you in

- Checking the plant configuration
- Locating hardware modifications in a plant
- Correcting errors in a plant

Modules can be uniquely identified online by means of the I&M data.

#### Master

When a master is in possession of the token, it can send data to other nodes and request data from other nodes (= active node). DP master are, for example, the CPU 315-2 DP or the IM 308-C.

### Parameter assignment

Parameter assignment is the transfer of slave parameters from master to the slave.

#### **PNO**

PROFIBUS user organization

### Power supply unit

A power supply unit supplies power to the field devices and the distributed process I/Os connected to them.

#### **PROFIBUS**

PROcess Fleld BUS, process and field bus standard as defined in the field bus standard (IEC 61784-1:2002 Ed1 CPF 3 PROFIBUS and PROFINET). It specifies functional, electrical, and mechanical properties for a bit-serial field bus system.

PROFIBUS is available with the protocols: DP (=distributed I/O) and FMS (= Field bus Message Specification)

### **PROFIBUS address**

For the purpose of unique identification on PROFIBUS°DP, each node must be given a PROFIBUS address.

PC / PD or the ET 200 Handheld have the PROFIBUS address "0".

DP master and DP slaves have a PROFIBUS address from the 1 to 125 range.

### **PROFIBUS DP**

PROFIBUS bus system with the DP protocol. DP stands for the German equivalent of distributed I/O.

#### **PROFIBUS PA**

PA stands for Process Automation and increases the range of usage of the PROFIBUS DP family to include the field of process engineering. Process engineering refers to both the intrinsically safe sectors of the chemicals industry and to the non-intrinsically safe sectors, such as nuclear power plant automation, the food industry and waste water technology.

### Redundant systems

Redundant systems are characterized by the multiple (redundant) presence of important automation components. If a redundant component fails there the processing of the program is not interrupted.

### Reference potential

The potential to which voltages of participating circuits are referenced when they are viewed and/or measured.

### Segment

A segent or bus segment is a self-contained section of a serial bus system.

### **SELV**

Safety extra low voltage (SELV) is voltage < AC 30 V / DC 60 V that generates via a safety transformer, accumulator etc.

#### SIMATIC PDM

SIMATIC PDM (Process Device Manager) is a universal tool that is not manufacturerspecific and is used for configuring, parameterizing, commissioning and diagnosing intelligent process devices. SIMATIC PDM makes it possible to configure a large variety of process devices with a single software on a standardized user interface.

### Supply unit

A supply unit supplies power to the line.

### Terminating resistor

A terminating resistor is a resistor that terminates the data transmission line to avoid reflections.

### Time synchronization

Time synchronization ensures that all clocks run synchronously. A master clock distributes the time in a configurable cycle to all other components in the automation system that have a clock. The components use this distributed time to set their own clocks.

### TN-S system

In a TN-S system, the neutral conductor (N) and protective conductor (PE) are routed separately from each other. The neutral conductor is connected to the grounded protective conductor at a central point, and only there. The conductor can be grounded any number of times.

#### Token

In network technology a token refers to a bit pattern that is passed from one bus node to another, enabling that node to access the bus.

## Transmission speed

The transmission speed specifies the number of bits transmitted per second.

# Type of protection

The special measures applied to electrical equipment to prevent the ignition of a potentially explosive ambient atmosphere.

## Update

Following (compatible) functional extensions or improvements to performance you should update the IM 153-2 interface module to the respective most recent firmware version.

# Index

	В
A	Bus module BM FDC/FDC (redundant), 37
Accessories	Bus terminal resistors
for PROFIBUS DP, 246	Y coupler, 104
for PROFIBUS PA, 247	Bus terminating resistor
Active field distributor (AFD)	DP/PA coupler, 109
replace, 147	
Technical specifications, 237	
Active Field Distributor AFD, 33	C
Active field splitter (AFS)	CE mark, 216, 219, 221, 223
replace, 147	Center feed, 63, 101, 120
Technical specifications, 236	Changes
AFD	compared to previous manual, 4
Functions, 33	compatibility
Grounding, 33	Bus module BM FDC/FDC (redundant), 37
Properties, 33	DP/PA coupler FDC 157-0, 37
AFDiS, 34	Components
Grounding, 53	For DP/PA coupler in redundancy mode, 76
Mounting, 44	for DP/PA coupler in stand-alone mode, 75
replace, 56	for the DP/PA link in non-redundant mode, 79
Safety information, 43	for the DP/PA link in redundant mode, 81
supplement, 56	for Y link, 83
AFS, 32	Order numbers, 245
Functions, 32	Conditions of use, 227
Grounding, 32	Configuration frame, 126, 135
Properties, 32	Configuring
Aggregate cable, 252	Configuration for DP/PA link, 127
Aggregate current	DP slaves, 133
of the connected PA field devices, 250	DP slaves for Y link, 136
Ambient conditions	DP/PA coupler, 115
mechanical, 227	DP/PA link, 122, 126
Operation, 227	GSD file, 114
Transport and storage, 226	PROFIBUS PA system, 124
Appendix	Y link, 130, 135
Change to redundancy, 146	Connecting AFDiS
expand, 146	Examples, 49
Applications	Rules, 49
DP/PA coupler FDC 157-0, 57	Safety information, 46
Settings, 113	Coupler redundancy, 62
Arc-over, 40	Power supply, 62
ATEX mark, 216, 219	Current value
Availability DP/PA coupler FDC 157-0, 21	Limits, 169
DE /E A COUPLE EDO 101-0, 21	Current values
	read, 165

D	DPV0 / DPV1
Default diagnosis, 185	DP/PA link in redundant mode, 122
Degree of protection, 230	DP/PA link in the S7 standard mode, 122
Delivery condition	Y link, 131
DP/PA coupler FDC 157-0, 37	
Device identifier, 187	
,	E
Device-related diagnostics	Floatrical inclusion 07
Module status, 189	Electrical isolation, 87
Status message, 191	Electrical properties, 87
Device-specific parameters	Electromagnetic compatibility, 224
DP/PA coupler, 118	Equipment, 40
Diagnostic interrupt, 198	open, 73
Diagnostics function	Error types
Settings, 113	DP/PA coupler FDC 157-0, 214
Disposal, 5	Explosion hazard, 39, 46
Distributed I/O, 14	Explosion-proof equipment, 40
DP slaves	
Configuring, 133	F
configuring for Y link, 136	F
DP/PA coupler	Failure
commissioning for stand-alone operation, 111	DP/PA coupler FDC 157-0, 77
Configuring with STEP 7, 115	PA field devices, 77
Device-specific parameters, 118	Failure of components of the redundant DP master
in the DP/PA link, 64	system, 140
Installation with coupler redundancy, 62	Field device supply, 250
Installation with ring redundancy, 59	Field distributor AFDiS
Mounting for non-redundant mode, 75	cleaning, 55
Mounting for redundancy mode, 76	Functions, 35
Properties, 23	Grounding, 53
removing, 76	Maintaining, 54
replace, 146	Mounting, 44
wiring for stand-alone operation, 93	Properties, 35
DP/PA coupler Ex [i]	Repeater function, 36
Technical specifications, 234	replace, 56
DP/PA coupler FDC 157-0	Special properties, 35
Applications, 21	supplement, 56
Availability, 21	Technical specifications, 238
Commissioning, 112	Field distributors AFD/AFS
Configuration frame, 172	Grounding, 90
Error types, 214	Mounting on substrate, 78
Input data, 172	Flying Redundancy, 154
Properties, 22	Functions
Technical specifications, 232	DP/PA coupler FDC 157-0, 57
DP/PA coupler FDC 157-0 overvoltage protection, 77	•
DP/PA link	
configuring with COM PROFIBUS, 125	G
Mounting for non-redundant mode, 79	
Mounting for redundancy mode, 81	Grounding, 87
Startup characteristics in the non-redundant	GSD file
mode, 141	DP/PA coupler, 114
wiring for non-redundant mode, 102	
wiring for redundant mode, 103	

Н	Mounting system, 73
H status, 194	
Heat ignition, 249	N
	non-redundancy mode, 27
1	non-redundancy mode, 27
Identification data, 163 Identifier-related diagnostics, 187 IECEx	O Order numbers, 245 Overvoltage protection, 77  P PA bus terminator switch, 101 PA field devices Configuration for DP/PA link, 127 Parameter assignment frame, 126, 135 Power supply, 105 Connecting, 105 for the DP/PA link in non-redundant mode, 102 for the DP/PA link in redundant mode, 103 for Y link, 104 Process input image, 172 PROFIBUS address set, 120 PROFIBUS address of the DP master, 187 PROFIBUS address of the IM 153-2 in the PA master system, 124, 127 in the underlying DP master system, 133, 136 set, 85 PROFIBUS DP Connecting, 106 PROFIBUS PA Bus terminal switch, 109 Commissioning guide, 107, 249 Connecting, 107 Extension, 250 Field device supply, 250 Properties AFD, 33 AFS, 32
M	DP/PA coupler FDC 157-0, 22 Field distributor AFDiS, 35
Manufacturer ID, 207	Protection class, 230 Proxy diagnostic interrupt, 198
Master->Reserve switchover, 140	Froxy diagnostic interrupt, 190
Maximum configuration, 251	
Mixed operation, 16	R
Module replacement, 145 Module status, 189	Radio Interference
Mounting position, 73	Emission, 226
- · · · · · · · · · · · · · · · · · · ·	

Rated voltage, 230	Т
Reading data records, 156	Technical support, 5
Reconfiguring the hardware, 162	Terminating resistor, 101, 120
Recycling, 5 Redundancy	Test voltages, 230
Flying, 154	Topology, 252
System, 154	Training center, 5
Redundancy mode	Type of protection, 249
Coupler redundancy, 62	Types of protection, 40
Ring redundancy, 59	
set, 120	U
Reference potential	O
grounded, 90	User data frame, 166
ungrounded, 92	
Remove / insert	1/
DP/PA coupler, 77	V
DP/PA coupler FDC 157-0, 77	Vibrations, 227
IM 153-2,	Voltage measurement, 166
Interrupt, Y coupler,	Voltage value
Repeater function	Limits, 169
AFDIS, 36	Voltage values
Ring redundancy, 59, 62	read, 165
Behavior in the event of errors, 61	
Power supply, 59	W
Rules	
Connecting AFDiS, 49	Wirebreak,
3311133111g / 11 213, 13	
	V
S	Υ
	Y Y coupler
S Safety information AFDIS, 43	Y coupler Technical specifications, 235
S Safety information AFDiS, 43 Connecting AFDiS, 46	Y coupler Technical specifications, 235 Y link
S Safety information AFDiS, 43 Connecting AFDiS, 46 Service & Support, 6	Y coupler Technical specifications, 235 Y link Configuring, 130
S Safety information AFDiS, 43 Connecting AFDiS, 46 Service & Support, 6 Settings	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249 Sparks, 40	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249 Sparks, 40 Startup characteristics    DP/PA link in the non-redundant mode, 141 Start-up delay, 139, 192	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249 Sparks, 40 Startup characteristics    DP/PA link in the non-redundant mode, 141 Start-up delay, 139, 192 Station status, 186	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
S Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249 Sparks, 40 Startup characteristics    DP/PA link in the non-redundant mode, 141 Start-up delay, 139, 192 Station status, 186 Status message, 191	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104
Safety information    AFDiS, 43    Connecting AFDiS, 46 Service & Support, 6 Settings    Diagnostics function, 113    Redundancy mode, 113 Short-circuit, 59 Slave diagnostics, 183 Spark ignition, 249 Sparks, 40 Startup characteristics    DP/PA link in the non-redundant mode, 141 Start-up delay, 139, 192 Station status, 186	Y coupler Technical specifications, 235 Y link Configuring, 130 configuring with COM PROFIBUS, 134 Mounting, 83 wiring, 104