

SIEMENS

SITRANS F

Electromagnetic flowmeters TRANSMAG 2 with MAG 911/E


Operating Instructions


<u>Introduction</u>	1
<u>Safety notes</u>	2
<u>Description</u>	3
<u>Installing/mounting</u>	4
<u>Connecting</u>	5
<u>Commissioning</u>	6
<u>Operating</u>	7
<u>Functions</u>	8
<u>Service and Maintenance</u>	9
<u>Troubleshooting</u>	10
<u>Technical specifications</u>	11
<u>Dimension drawings</u>	12
<u>Parameters</u>	A
<u>Profibus Communication</u>	B
<u>Product documentation and support</u>	C


Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.

 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.

 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.

NOTICE
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	7
1.1	Purpose of this documentation	7
1.2	History.....	7
1.3	Checking the consignment.....	7
1.4	Items supplied	8
1.5	Designated use	8
1.6	Security information	8
1.7	Transportation and storage	9
1.8	Notes on warranty	9
2	Safety notes	11
2.1	General safety instructions.....	11
2.2	Laws and directives	11
2.3	Use in hazardous areas.....	13
3	Description	15
3.1	Overview	15
3.2	Features	15
3.3	BUS Communication	16
3.4	Theory of operation	17
3.5	Operating principle	18
4	Installing/mounting	19
4.1	Installation safety precautions.....	19
4.2	Sensor installation	19
4.2.1	Determining a location.....	19
4.2.2	Orienting the sensor	22
4.2.3	Removing the liner protectors	23
4.2.4	Mounting	24
4.2.5	Potential equalization.....	27
4.2.6	Installation with grounding rings.....	28
4.3	Transmitter installation	30
4.3.1	Standard wall-mounting bracket.....	30
4.3.2	Pipe or wall mounting with special wall-mounting bracket.....	30
4.4	Turning the local display.....	32
5	Connecting	33
5.1	General Information.....	33

5.2	Installing ferrite beads on unshielded cables.....	35
5.3	Step 1: Connecting power supply	35
5.4	Step 2: Connecting signal cables	36
5.5	Step 3: Connecting terminal box and transmitter	37
6	Commissioning	41
6.1	Operating TRANSMAG 2	41
6.2	Write protection	44
6.3	Language and illumination.....	44
7	Operating.....	45
7.1	Operating examples.....	45
7.2	SIMATIC PDM	49
7.2.1	Overview SIMATIC PDM	49
7.2.2	Check SIMATIC PDM version	49
7.2.3	Deactivate buffers when connecting via serial modem	50
7.2.4	Updating the Electronic Device Description (EDD)	51
8	Functions	53
8.1	Menu structure	53
8.2	Function Group Display	53
8.3	Function Group Diagnostics	54
8.4	Function Group Measuring Functions	57
8.5	Function Group Device Outputs.....	64
8.6	Function Group Identification	71
8.7	Function Group Service	73
9	Service and Maintenance	77
9.1	Maintenance.....	77
9.2	Ordering of spare parts	78
10	Troubleshooting.....	79
10.1	Quick sensor check-up	79
10.2	Application Problems	80
10.3	Error messages	82
11	Technical specifications	85
12	Dimension drawings.....	89
A	Parameters.....	93
B	Profibus Communication	105
B.1	PROFIBUS Communication	105
B.2	Wiring devices with Profibus PA	106

B.3	Cyclic Data Traffic.....	107
B.4	Input Data (from Slave to Master).....	108
B.5	Status bytes	108
B.6	Output Data (from Master to Slave).....	111
B.7	Diagnostics	111
B.8	Write Protection	114
B.9	Device Database File (GSD)	114
C	Product documentation and support	121
C.1	Product documentation	121
C.2	Technical support.....	122
	Index.....	123

Introduction

1.1 Purpose of this documentation

These instructions contain all information required to commission and use the device. Read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons mechanically installing the device, connecting it electronically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

See also

Technical support (Page 122)

1.2 History

The contents of these instructions are regularly reviewed and corrections are included in subsequent editions. We welcome all suggestions for improvement.

The following table shows the most important changes in the documentation compared to each previous edition.

Edition	Remarks
03/2021	Explanation for ferrite beads, corrections regarding dimensions and EU directives
08/2010	TRANSMAG 2 Op. Instr. <ul style="list-style-type: none"> Information on the compact version was removed.
02/2009	TRANSMAG 2 Op. Instr. <ul style="list-style-type: none"> Restructuring of contents.
02/2008	TRANSMAG <ul style="list-style-type: none"> All information concerning Intermag was removed.
02/2008	TRANSMAG / Intermag

1.3 Checking the consignment


1. Check the packaging and the delivered items for visible damages.
2. Report any claims for damages immediately to the shipping company.

3. Retain damaged parts for clarification.
4. Check the scope of delivery by comparing your order to the shipping documents for correctness and completeness.

⚠ WARNING
Using a damaged or incomplete device
Risk of explosion in hazardous areas.
<ul style="list-style-type: none">• Do not use damaged or incomplete devices.

1.4 Items supplied

- SITRANS FM TRANSMAG 2
- Standard wall-mounting bracket
- Cable glands
- Ferrite beads
- DVD with documentation and certificates



1.5 Designated use

Use the device in accordance with the information on the nameplate and in the Technical specifications (Page 85).

NOTICE
Use in a domestic environment
This Class A Group 1 equipment is intended for use in industrial areas.
In a domestic environment this device may cause radio interference.

1.6 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit

<https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

<https://www.siemens.com/industrialsecurity>.

1.7 Transportation and storage

To guarantee sufficient protection during transport and storage, observe the following:

- Keep the original packaging for subsequent transportation.
- Devices/replacement parts should be returned in their original packaging.
- If the original packaging is no longer available, ensure that all shipments are properly packaged to provide sufficient protection during transport. Siemens cannot assume liability for any costs associated with transportation damages.

NOTICE

Insufficient protection during storage

The packaging only provides limited protection against moisture and infiltration.

- Provide additional packaging as necessary.

Special conditions for storage and transportation of the device are listed in Technical specifications (Page 85).

1.8 Notes on warranty

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.


The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.

Safety notes

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

2.1 General safety instructions

	CAUTION
Correct, reliable operation of the product requires proper transport, storage, positioning and assembly as well as careful operation and maintenance.	
Only qualified personnel should install or operate this instrument.	

Note

Alterations to the product, including opening or improper modifications of the product are not permitted.

If this requirement is not observed, the CE mark and the manufacturer's warranty will expire.

2.2 Laws and directives

General requirements

Installation of the equipment must comply with national regulations.

Instrument safety standards

The device has been tested at the factory, based on the safety requirements. In order to maintain this condition over the expected life of the device, the requirements described in these Operating Instructions must be observed.

Environmental conditions according to IEC61010-1:

- Indoor/Outdoor use
- Altitude up to 2000 m
- Maximum relative humidity 80% for temperatures up to 31°C (88 °F) decreasing linearly up to 50% relative humidity from 40 °C (104 °F)

2.2 Laws and directives

- Overvoltage category II
- Pollution degree 2


NOTICE
Material compatibility Siemens Flow Instruments can provide assistance with the selection of wetted sensor parts. However, the full responsibility for the selection rests with the customer and Siemens Flow Instruments can take no responsibility for any failure due to material incompatibility.

CE-marked equipment

The CE marking on the device symbolizes the conformity with the following European directives:

Electromagnetic compatibility EMC 2014/30/EU	Directive of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to electromagnetic compatibility
Low voltage directive LVD 2014/35/EU	Directive of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits
Pressure equipment directive PED 2014/68/EU	Directive of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to the making available on the market of pressure equipment
2011/65/EU RoHS	Directive of the European Parliament and the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment

The SITRANS FM magnetic-inductive measuring devices comply with protection class I.


 WARNING
Improper device modifications Risk to personnel, system and environment can result from modifications to the device, particularly in hazardous areas. <ul style="list-style-type: none">• Only carry out modifications that are described in the instructions for the device. Failure to observe this requirement cancels the manufacturer's warranty and the product approvals.


2.3 Use in hazardous areas

Qualified personnel for hazardous area applications

Persons who install, connect, commission, operate, and service the device in a hazardous area must have the following specific qualifications:

- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures, aggressive, and hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.

 WARNING
Use in hazardous area Risk of explosion. <ul style="list-style-type: none">• Only use equipment that is approved for use in the intended hazardous area and labeled accordingly.• Do not use devices that have been operated outside the conditions specified for hazardous areas. If you have used the device outside the conditions for hazardous areas, make all Ex markings unrecognizable on the nameplate.

 WARNING
Loss of safety of device with type of protection "Intrinsic safety Ex i" If the device or its components have already been operated in non-intrinsically safe circuits or the electrical specifications have not been observed, the safety of the device is no longer ensured for use in hazardous areas. There is a risk of explosion. <ul style="list-style-type: none">• Connect the device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.• Observe the specifications for the electrical data on the certificate and/or in Technical specifications (Page 85).

2.3 Use in hazardous areas

Description

3.1 Overview

SITRANS FM TRANSMAG 2 is a pulsed alternating field magnetic flowmeter where the magnetic field strength is much higher than conventional DC pulsed magnetic flowmeters.

This makes it ideal for difficult applications as:

- High concentrated paper stock > 3 %
- Heavy mining slurries
- Mining slurries with magnetic particles

The complete flowmeter consists of the flow sensor MAG 911/E and the associated SITRANS FM TRANSMAG 2 transmitter.

TRANSMAG 2 is available in a remote version. The MAG 911/E sensor is available with diameters from DN 15 to DN 1000 (1/2" to 40").

3.2 Features

- Fast signal processing with 16-bit technology
- Automatic recognition of the sensor type and calibration data as result of SmartPLUG. The SmartPLUG is a pre-amplifier in the sensor with integrated data module which contains the stored factory data of the sensor and customer-specific data.
- PROFIBUS-PA (Profile 2.0) or HART communication
- Simple, multi-language menu-guided operation with two-line display and four optical input elements
- Self-monitoring function
- Internal simulation for all input and output functions
- Monitoring of the sensor using magnetizing current and reference voltage as well as wet electrode function
- Analog output and digital outputs for pulses, device status, limits, flow direction, frequency output
- Optional passive switch input for resetting the counter values or for switching off the measuring equipment (PZR)
- With pulsed alternating field for minimum conductivity of 0.1 $\mu\text{S}/\text{cm}$

3.3 BUS Communication

- Slurry mode
- Parameters can be specifically selected and modified, e.g.:
 - Operating parameters such as measuring range, physical dimensions or device information
 - Limits for flow, counter configurations
 - Noise suppression using separate interference suppression and damping as well as hysteresis functions
 - Automatic mains synchronization
 - Display parameters (freely configurable text display)
 - Display in volume or mass units
 - Density as constant input value for conversion of volume into mass
 - Low flow cut-off
 - Forward and reverse flow measurements
 - Flow direction display and evaluation
 - Diagnostics functions and control values
 - PROFIBUS address
 - Functions of analog output: proportional flow, failure signal
 - Functions of digital output 1 (transistor): pulse output, frequency output proportional to flow, alarm, forward or reverse flow signal, min. or max. limit for flow and counter
 - Functions of digital output 2 (relay): alarm, forward or reverse flow signal, min. or max. limit for flow and counter
 - Simulation of output signal via analog output, digital output 1 and digital output 2
 - Option: digital output 2 as digital input for resetting counter values or for interruption in measurement (PZR)


3.3 BUS Communication

SITRANS FM TRANSMAG 2 is available with HART or PROFIBUS communication.

- The HART protocol is superimposed on the analog output (current output). This communication capability permits parameterization of the device using the HART communicator or a PC/laptop and SIMATIC PDM software in addition to local operation.
- In the PROFIBUS PA version, the analog output and the digital output 2 are replaced by the digital PROFIBUS PA output. Parameterization of the device is then possible using PROFIBUS communication and SIMATIC PDM in addition to local operation.

3.4 Theory of operation

The flow measuring principle is based on Faraday's law of electromagnetic induction.



U_i = When an electrical conductor of length L is moved at velocity v , perpendicular to the lines of flux through a magnetic field of strength B , the voltage U_i is induced at the ends of the conductor

$$U_i = L \times B \times v$$

- U_i = Induced voltage
- L = Conductor length = Inner pipe diameter = k_1
- B = Magnetic field strength = k_2
- v = Velocity of conductor (media)
- $k = k_1 \times k_2$

$U_i = k \times v$, the electrode signal is directly proportional to the fluid velocity

Operating principle

The coil current module generates a pulsating magnetizing current that drives the coils in the sensor. The current is permanently monitored and corrected. Errors or cable faults are registered by the self-monitoring circuit.

The input circuit amplifies the flow-proportional induced voltage signal from the electrodes. The input impedance is extremely high: $>10^{14} \Omega$ which allows flow measurements on fluids with conductivities as low as $5 \mu\text{S}/\text{cm}$. Measuring errors due to cable capacitance are eliminated due to active cable screening.

The digital signal processor converts the analog flow signal to a digital signal and suppresses electrode noise through a digital filter. Inaccuracies in the transmitter as a result of long-term drift and temperature drift are monitored and continuously compensated for via the self-monitoring circuit. The analog to digital conversion takes place in an ultra low noise ASIC with 23 bit signal resolution. This has eliminated the need for range switching. The dynamic range of the transmitter is therefore unsurpassed with a turn down ratio of minimum 3000:1.

3.5 Operating principle


SITRANS FM TRANSMAG 2 is a microprocessor-based transmitter with a built-in alphanumeric display in several languages. The transmitters evaluate the signals from the associated electromagnetic sensors and also fulfil the task of a power supply unit which provides the magnet coils with a constant current.

The magnetic flux density in the sensor is additionally monitored by reference coils. Further information on connection, mode of operation and installation can be obtained from the sensor data sheets.



Figure 3-1 SITRANS FM TRANSMAG 2 magnetic-inductive flow transmitter

Installing/mounting



SITRANS F flowmeters with minimum IP65/NEMA 4X enclosure rating are suitable for indoor and outdoor installations.

- Make sure that pressure and temperature specifications indicated on the device nameplate / label will not be exceeded.

! WARNING

Installation in hazardous location

Special requirements apply to the location and interconnection of sensor and transmitter. See Use in hazardous areas (Page 13)

4.1 Installation safety precautions

! WARNING

High pressure hazard

In applications with working pressures/media that can be dangerous to people, surroundings, equipment or others in case of pipe fracture, we recommend that special precautions such as special placement, shielding or installation of a pressure guard or a safety valve are taken when the flowmeter is mounted.

4.2 Sensor installation

4.2.1 Determining a location

Note

The sensor must always be completely filled with liquid.




Figure 4-1 Correct installation with filled pipes

- Avoid the following installations
 - Installation at the highest point in the pipe system
 - Installation in vertical pipes with free outlet




Figure 4-2 Wrong installation at high point





Figure 4-3 Correct installation at low point before outlet

Inlet and outlet conditions

To achieve accurate flow measurement it is essential to have straight lengths of inlet and outlet pipes and a certain distance to pumps and valves.

It is also important to centre the flowmeter in relation to pipe flanges and gaskets.



4.2.2 Orienting the sensor

The sensor operates in all orientations, but Siemens has the following recommendations:

- Vertical installation with an upwards flow




Figure 4-4 Vertical orientation, upwards flow

NOTICE
Abrasive liquids / liquids containing solid particles A vertical installation minimizes wear and deposits in the sensor

Note

Gas/air bubbles in the liquid

A vertical installation minimizes any negative effect of gas/air bubbles in the liquid

- Horizontal installation, terminal box upwards or downwards




Figure 4-5 Horizontal installation, various terminal box positions

NOTICE
Do NOT mount the sensor with the terminal box sideways This will position the electrodes at the top where there is possibility for air bubbles and at the bottom where there is possibility for mud, sludge, sand etc.

Note

Empty pipe detection

For applications with empty pipe detection, the sensor can be tilted 45°, as shown above.

4.2.3 Removing the liner protectors

NOTICE

Sensors with PTFE or PFA liners only!

The following information is only relevant for sensor types with PTFE or PFA liners!

Sensors with PTFE liner

At delivery the sensor is mounted with wooden blanks to hold the liner in place during transportation and storage. After only a few hours without the blanks, the liner will creep back towards its original shape and installation will be more difficult to carry out.




Figure 4-6 Sensor with wooden blanks

- Remove the blanks immediately before mounting the sensor




Figure 4-7 Removing wooden blanks

Sensors with PFA liner

At delivery the sensor is mounted with blanks to protect the liner during transportation and storage.




Figure 4-8 Sensor with blanks

- Remove the blanks immediately before mounting the sensor




Figure 4-9 Removing blanks

NOTICE

Do not use sharp objects to remove the blanks as this can damage the liner!

4.2.4 Mounting

- Install the sensor in rigid pipelines in order to support the weight of the meter.
- Center the connecting pipelines axially in order to avoid turbulent flow profiles.

- Use proper gaskets according to liner type.
- If earthing rings are used, use standard flange gaskets on both sides of the ring.




Figure 4-10 Correct installation with gaskets




Figure 4-11 Inlet protection

Vibrations

In installations with strong vibrations remote installation of the transmitter is recommended. Alternatively mitigate vibrations by installing pipe support in close proximity to the flowmeter.




Figure 4-12 Avoid vibrations




Figure 4-13 Pipe support variant 1




Figure 4-14 Pipe support variant 2

Mounting

Fasten screws according to the torques values below




Figure 4-15 Mounting

Leakage/damage to flowmeter or piping may arise if bolts are overtightened.

Torque calculations

All values are theoretical and are calculated on the assumption that:

- All bolts are new and material selection is according to EN 1515-1 table 2.
- Gasket material not exceeding 75 shore A is used between the flowmeter and mating flanges.
- All bolts are galvanized and adequately lubricated.
- Flanges are made of carbon steel.
- Flowmeter and mating flanges are correctly aligned.

4.2.5 Potential equalization

To obtain optimum results from the measuring system, the sensor must have the same electrical potential as the liquid being measured.

This is achieved by means of built-in grounding electrodes.





Figure 4-16 Potential equalization with earthing electrodes

Cathodic protected piping

Special attention must be paid to systems with cathodic protection.

 WARNING
Use in hazardous area!
Cathodic pipe protection is not allowed in hazardous areas




Figure 4-17 Cathodic protection

- Isolate the sensor from cathodic protected pipes using insulated bolts.
- Use bypass cable between the mating flanges

Note

Remote mounted sensor versions


If the above is not acceptable, remote mounted sensors can alternatively be connected as follows:

- Connect coil current cable shield at sensor end via a 1.5 μ F condensator
- Make sure that electrode cable shield is not connected at both ends


4.2.6 Installation with grounding rings

NOTICE
Only sensors with PTFE or PFA liners without grounding electrodes
Installation with grounding rings is only relevant for sensors with PTFE or PFA liners

- Mount grounding rings where necessary on non-conductive pipes.



Installation with grounding rings on sensors with PTFE liner



Installation with flat grounding rings on sensors with PFA liner


Note

Potential equalization


For potential equalization one grounding ring is sufficient.

By unidirectional flow it is recommended to mount the grounding ring on the inlet side.

- Connect the grounding rings to the sensor with the enclosed grounding straps.



Grounding strap connection on type E grounding rings



Grounding strap connection on flat grounding rings

Note

Abrasive liquids

In special cases the grounding rings can work as inlet protection.

NOTICE

High temperature sensors

High temperature sensors are delivered with two factory mounted grounding rings. No further action need to be taken for potential equalisation.

4.3 Transmitter installation

4.3.1 Standard wall-mounting bracket

Wall mounting

1. Fit the mounting bracket on the transmitter using the mounting material provided.
2. Mount transmitter with mounting plate on the wall.




Figure 4-18 Standard wall-mounting bracket

Note

The standard wall-mounting bracket is only suitable for wall mounting.


4.3.2 Pipe or wall mounting with special wall-mounting bracket

Note

The special wall-mounting bracket is not part of the standard delivery and must be ordered separately.

Pipe mounting

1. Mount the assembly bracket on the pipe using the fastening brackets
2. Fasten the transmitter with the two screws provided.




Pipe mounting with assembly bracket

Wall mounting

1. Fasten the assembly bracket to the back of the transmitter
2. Fasten the transmitter and assembly bracket to the wall

Note

The fastening brackets and nuts are not needed for wall mounting.




Wall mounting with assembly bracket. Dimensions in mm (inch).

4.4 Turning the local display

The local display can be turned in 90° steps to enable better reading in case of vertical installation or overhead assembly.

1. Switch off the power supply.
2. Release the catch on the lid of the electronics compartment with a 3 mm Allen key.
3. Unscrew the cover.
4. Carefully release the fastening hooks of the local display using a screwdriver or similar tool
5. Pull out the unit, turn it to the desired position and push it back in.
6. Screw the lid back on and mount the lid catch.



① Fastening hooks

Figure 4-19 Unlocking the fastening hooks on the local display

Connecting


5.1 General Information

This chapter describes how to wire up the device.

When using unshielded cables start by installing ferrite beads (Page 35). Afterwards:

1. Connect power supply (Page 35)
2. Connect signal cables (Page 36)
3. Connect terminal box and transmitter (Page 37) (must always be carried out)

The chapter only describes wiring of devices with HART. In order to wire up devices with Profibus PA, refer to the Appendix: Wiring devices with Profibus PA (Page 106)



- ① Magnetic current cable
- ② Terminal box for power supply and signal cables
- ③ Potential equalization
- ④ Signal cable
- ⑤ Power supply
- ⑥ Electrode cable
- ⑦ Terminal box for magnetic current and electrode cables

Figure 5-1 Overview, Electrical connections

⚠ WARNING

The pertinent regulations must be observed for electrical installation.

Never install the device with the mains voltage switched on!


Danger of electric shock!

The electrodes and magnetic current cables may only be connected when the device is not connected to the power supply.

Housing covers may only be unscrewed by qualified personnel when the housing is under voltage (power supply).

Cable specifications

- Only use cables with at least the same degree of protection as the sensor to install the sensor.
- The cable length from the cable gland to the terminals must be kept as short as possible. Cable loops in the terminal box must be avoided.
- To guarantee the IP 67 degree of protection, use cables with the following external diameters:
The permissible external diameter for auxiliary power and signal cable (large terminal box) of the standard device (7ME5034-xxxx-xAA0) is 6 to 12 mm.
Magnetic field current and electrode cable (small terminal box):
 - Cable glands M20 x 1.5 6 to 12 mm
 - Cable glands 1/2" NPT 5 to 9 mm



① Lid of terminal box

② Cable gland

Figure 5-2 Example of lacing cables before connecting the cables

5.2 Installing ferrite beads on unshielded cables

Usage of ferrite beads

Ferrite beads are used to help reduce high-frequency interference on interface and control cables. Ferrite beads are only required when electromagnetic compatibility is an issue. When using shielded cables for inputs and outputs, ferrite beads are not needed.

Installing ferrite beads on the power supply, in/outputs, and bus signal cables

Included in the scope of delivery is a plastic bag containing the ferrite beads:

- One large ferrite bead in a shrink-down plastic tubing to be used for the power supply cable.
- Three small sized ferrites to be used for bus signal and in/output cables.

Install the ferrite beads by threading the cable in a loop through the ferrite bead.




Figure 5-3 Cable looped through ferrite bead

Note

Ferrite beads with shielded cables

If shielded cables are used, then the shield and shield drain wire must not pass through the bead. The ferrite beads should be installed as close as possible to the terminal connector of the device.

5.3 Step 1: Connecting power supply

CAUTION


Only connect the device to the supply which matches the specifications on the rating plate. Connect the power supply by an easily accessible and appropriately labeled isolating device and fuse (max. 4 A) or an easily accessible circuit breaker (max. 4 A).

Note

Use cables with a cross section of at least 1.5 mm² and double or reinforced insulation for the power supply.

Wiring guidelines

1. Release the catch on the lid of the terminal box using a 3 mm Allen key.
2. Unscrew the lid of the terminal box.
3. Push the supply cable through the cable glands up to the terminal strip. Lay the cable in a loop before the cable glands so that moisture does not get inside the terminal box.
4. Connect the cables according to the figure below.



- ① Ground connection for signal cable shield
- ② Digital output 2 (relay) or digital input
- ③ Digital output 1 (active/passive)
- ④ Analog output (active) 4 to 20 mA or PROFIBUS
- ⑤ Power supply: L/N for 100 to 230 V AC
- ⑥ Terminal for PE conductor

Figure 5-4 Connection diagram for power supply and signal cables

5.4 Step 2: Connecting signal cables

⚠ CAUTION

Lay the signal cables separately from cables with voltages > 60 V.

Avoid laying signal cables close to large electrical installations or use - if possible - only shielded cables.

Note

In a wet environment, the signal cable for digital output 2 (terminals 3 and 4) must be isolated when the feed-in voltage is more than 16 V AC/35 V DC (16 V RMS/ 22.6 V peak).

Only use signal cables with twisted wire pairs.

1. Push the signal cable through the cable gland up to the terminal strip. Lay the cable in a loop before the cable glands so that moisture does not get inside the terminal box.
2. Connect the cables according to the figure above.
3. Fit end ferrules to fine-wire cables.
4. Tighten the cable gland and check strain relief.
5. Screw the lid to the housing and tighten it. You must not use any tools. The sealing ring must be clean and undamaged.
6. Mount the lid catch.
7. For transmitters in remote design, also connect the housing to the local potential equalization to which the appropriate sensor must also be connected.

HART requirements

- The full HART 5.1 specification only applies when using shielded cables.
- Use signal cables with twisted wire pairs if the analog output and pulse/frequency output are used simultaneously and signals are transmitted in one cable.
- A load of at least 250 Ω must exist in the signal circuit (see also Technical specifications (Page 85)) for error free communication via the HART protocol.

5.5 Step 3: Connecting terminal box and transmitter



WARNING


High voltage

The SITRANS FM TRANSMAG 2 transmitter may only be connected to SITRANS FM MAG 911/E measuring sensor for alternating fields.

The magnetic circuit carries dangerous mains voltage. As long as the device is under voltage, the lid of the housing on the sensor connection area may only be opened by qualified personnel. Before removing the terminal cover, the auxiliary power must be switched off from all poles. Following installation, the terminal cover must be screwed back on again.


Preparing the cables

Prepare the cable before connection as shown below.



- ① Connector sleeve
- ② Braided screen

Figure 5-5 Preparation of the electrode and magnetic field current cable




- ① Lock nut
- ② Clamp
- ③ Cable shield
- ④ Threaded bush

Figure 5-6 Remote connection

Connecting

The sensor cable shield is connected to the transmitter and sensor as follows:

1. Bend the cable shield back over the clamping piece of the cable gland.
2. Push the clamping piece with the sensor cable into the threaded bush of the cable gland turning it slightly to the right.
3. Tighten the lock nut on the threaded bushing until the cable is connected tightly (IP67)



- ① Electrode cable
- ② Magnetic current cable

Figure 5-7 Signal transmission from the sensor to the transmitter

5.5 Step 3: Connecting terminal box and transmitter






Figure 5-8 Power supply and signal cables


Note

Cable coloring on IP68 rated sensors

With sensors with IP68 degree of protection, the cable colors or the identification tag on the sensor cables must be observed.

Commissioning

 WARNING
High voltage
Certain parts inside the device carry dangerous high voltage. The housing must be closed and grounded before switching the device on.

 WARNING
High pressure or corrosive media
The sensor connected to this device can be operated with high pressure and corrosive media. Therefore improper handling of the device can lead to serious injuries and/or considerable material damage.

Commissioning the device

- Switch on the power supply. The device runs a self-test which lasts about 30 seconds. During the self-test the smartPLUG data is pulled from the sensor. Afterwards the device is ready for operation and starts measuring.
- The tag data can then be changed permanently in the transmitter. These data are not read in again until a new sensor is connected.

Note

Gas/air in the line

If there is gas/air in the measuring tube or in the pipeline after assembly, a flashing "F" appears at the top of the first line in the display. The flowing medium removes the gas/air occlusions from the tag and the flow can be measured without interference after a few minutes.

6.1 Operating TRANSMAG 2

TRANSMAG 2 can optionally be operated in the following ways:

- via the local display
- via HART or Profibus
- with a PC/laptop and SIMATIC PDM software

Note

The following explains how to operate the device via the local display.

Operation via local display

The device is operated with the optical elements on the local display.

The elements are actuated by touching the glass panel above the appropriate operating element. The text display above the operating elements gives a menu-guided operation of the individual device functions/parameters.




Figure 6-1 Local display of the SITRANS F M TRANSMAG 2

Note

Operation does not require opening of the device. This means that the high degree of protection of IP67 is guaranteed at all times.

Navigating the menu structure

The available device functions and parameters are shown in the second line of the display. You can select them there with the and operating elements. You can scroll in the selected device function or setting level of the parameters (Enter function) with . It is possible to exit the selected function or setting level to the level above with .



The currently valid setting appears after selecting the setting level of a parameter. The programmable value flashes in the second line of the display when programming is enabled. You can change the parameter setting in this position. You have to decide between the following types of input to enter data:


- Direct numeric input
- Input from given table

In the numerical input, the and operating elements have the function of a cursor control. The selected digit flashes. You can now set the desired digit or move the point to the right or left with the and operating elements. Digits are input with carry over to the next highest place. After selecting the last digit you terminate the input by pressing the operating element. The entered value is accepted if it is within the permissible input range. In this case, the user guidance returns to the selection menu for the parameters of the group concerned. If the

entered value is rejected, an error message briefly appears on the display and then the previous setting. You can then change it again.

Note

If the  and  operating elements are kept actuated (with your finger continuously on the glass panel) the numeric value or setting option is changed continuously when using the tabular selection. A numeric input carries over to the next highest position.

If you want to prevent an accidentally changed setting from becoming active, you can exit the menu item by pressing the  operating element several times (return to the operating level above).

See also

The exact structure of the operating menu is explained in the appendix Parameters (Page 93) and an overview of the function groups of the menu is offered in chapter: Functions (Page 53).

Operating via BUS communication

The device is integrated into the system as shown below:




Figure 6-2 System integration via HART




Figure 6-3 System integration via Profibus

6.2 Write protection

The local display can be write-protected to prevent unauthorized manipulation by entering a freely selectable, personal code number.

In this case the device functions and parameters can only be changed after entering this code. You define the personal code number in the "6.2 Customer code" menu item.

If you actuate the and operating elements in the parameter setting level, the display prompts you to enter the code. You can also enter the code number in the "6.1 Enter Code" menu item. The programming is disabled again:

- after returning to display mode
- about 10 minutes after actuating an operating element
- after entering any number not the same as the code number in the "6.1 Enter Code" menu item

Note

With code = 0 (factory setting), the programming is always enabled.

You can always disable the operation by HART communication.

6.3 Language and illumination

The desired operating language can be set in the control and display unit in menu item "1.1.1 Language".

The background illumination of the LCD is switched on automatically the first time an operating element is actuated. The illumination ceases about 10 minutes after last actuating an operating element. If the display is constantly lit, you can set this using the menu item "1.1.5 Illumination".

Operating

7.1 Operating examples


Example 1: Changing engineering unit

In the following example, the engineering unit for the current flow value is changed from m³/h to l/min.

The operating path to be executed is shown semibold in the diagram below. The operating elements to be actuated are specified and the individual operating steps numbered consecutively.

The following display appears after completing the data input (8th operating step)

3.1. Flow
1 Engr. Unit

You return to the initial position by actuating the  operating element three times.

7.1 Operating examples




Figure 7-1 Setting current flow unit

Example 2: Changing pulse rate


In the following example the pulse rate is changed from 1 pulse per liter to 200 pulses per liter.

1. Navigate the menu and select menu item 4.2.3 "Pulse rate".

- 4.2 Digit.output1
- 3 Pulse rate

Note

See Operating TRANSMAG 2 (Page 41) for information on how to navigate the menu.

1. Enable the programming by pressing  once.
The unit in the second display line flashes


4.2.3 Unit

Imp/l

1. Press  once.
Digit 1 flashes


4.2.3 Pulse rate

+1.00 Imp./Unit

1. Change the digit from 1 to 2 by pressing  once


4.2.3 Pulse rate

+2.00 Imp./Unit

1. Select the decimal point by pressing  once

4.2.3 Pulse rate

+2.00 Imp./Unit

1. Move the decimal point two places to the right by pressing the  twice

4.2.3 Pulse rate

+200.00 Imp./Unit

1. Terminate the input by pressing  three times

4.2 Digit.output1

3 Pulse rate

7.1 Operating examples

The currently valid setting appears in the display.

4.2.	D	i	g	i	t	.	o	u	t	p	u	t	1
3	P	u	l	s	e	r	a	t	e				

1 x

Enable the programming.
The unit in the second display line flashes.

4.2.3	U	n	i	t									
I	m	p	/	I									

1 x

Digit 1 flashes.

4.2.3	P	u	l	s	e	r	a	t	e				
+ 1	.	0	0		I	m	p	.	/	U	n	i	t

1 x

Change the digit from 1 to 2 with the operating element

4.2.3	P	u	l	s	e	r	a	t	e				
+ 2	.	0	0		I	m	p	.	/	U	n	i	t

1 x

Select the point with the operating element.

4.2.3	P	u	l	s	e	r	a	t	e				
+ 2	.	0	0		I	m	p	.	/	U	n	i	t

2 x

Move the point two places to the right by pressing the operating element twice.

4.2.3	P	u	l	s	e	r	a	t	e				
+ 2	0	0	.	0	0	I	m	p	.	/	U	n	i

3 x

Select the last position of the number with and terminate the input by pressing the operating element (Enter function).

4.2.	D	i	g	i	t	.	o	u	t	p	u	t	1
3	P	u	l	s	e	r	a	t	e				

Figure 7-2 Fig_05_06

7.2 SIMATIC PDM

7.2.1 Overview SIMATIC PDM

SIMATIC PDM (Process Device Manager) is a general-purpose, manufacturer-independent tool for the configuration, parameter assignment, commissioning, diagnostics and maintenance of intelligent field devices and field components. Follow-up installations and additional information on SIMATIC PDM are available on the Internet at SIMATIC PDM (<https://www.siemens.com/simatic-pdm>).

SIMATIC PDM monitors the process values, alarms and status signals of the device. It allows you to display, compare, adjust, verify, and simulate process device data; also to set schedules for calibration and maintenance.

For information on, for example, how to install and integrate devices, commission the software, see Operating Manual 'Help for SIMATIC PDM'. The manual is delivered with SIMATIC PDM software. Once the SIMATIC PDM is installed on your computer you find the manual under: Start > All programs > Siemens Automation > SIMATIC > Documentation. Link at our website: SIMATIC PDM instructions and manuals (<https://support.industry.siemens.com/cs/ww/en/ps/16983/man>).

Note

Field device parameters

- For a list of parameters and additional information, consult section "Functions (Page 53)".
 - The field device remains in measurement mode during the time you configure the field device.
-

7.2.2 Check SIMATIC PDM version

Procedure

1. Go to SIMATIC PDM Download (<http://www.siemens.com/simaticpdm/downloads>).
2. Check the support page to make sure you have:
 - The latest version of SIMATIC PDM
 - The most recent Service Pack (SP)
 - The most recent hot fix (HF)

7.2.3 Deactivate buffers when connecting via serial modem

Introduction

This deactivation is required to align SIMATIC PDM with the HART modem when using a Microsoft Windows operating systems.


Deactivating buffers is not necessary when connecting via USB.

Condition

- You connect via RS232 (COM1).
- You have administrative rights on your operating system.
- You know the hardware and software requirements SIMATIC PDM installation documentation.

Procedure

1. Check the Operating Instructions for SIMATIC PDM for hardware and software requirements.
2. From the computer desktop, click "Start > Control Panel" to begin configuration.
3. Click "System and Security".
4. Select "Device Manager" under "System".
5. Open folder "Ports".
6. Double click the COM Port used by the system to open the properties window.
7. Select the tab "Port Settings".
8. Click the "Advanced" button.
If the "Use FIFO buffers" radio box is selected, click to deselect.



① Deselect "Use FIFO buffers" radio box

9. Click "OK" button to close out.
10. Close all screens.
11. Restart the computer.

7.2.4 Updating the Electronic Device Description (EDD)

Procedure

1. Check that the EDD revision match the Firmware revision in the device according to the table in section History (Page 7).
2. Go to the support page Software downloads (<https://www.siemens.com/processinstrumentation/downloads>).
3. Enter the product name in the field "Enter search term...".
4. Download the most current EDD of your device.
5. Save files to your computer in an easily accessed location.
6. Launch SIMATIC PDM – Device Integration Manager.
From the File menu, click "Read device descriptions from compressed source...".
7. Browse to the zipped EDD file, select and open it.
8. Use the "Integration" function to integrate the EDD into the device catalog. The EDD is now accessible via SIMATIC Manager.

Functions

8.1 Menu structure

Operation is based on a hierarchically structured operating concept, i.e. all functions/ parameters are grouped logically and carry a menu code.

The first (top) level is the main menu. You can select one of the following function groups:

1. Display
2. Diagnosis
3. Measuring functions
4. Device inputs and outputs
5. Identification
6. Service

The individual functions and parameters for further groups are combined under these main groups.

8.2 Function Group Display

The main display (multi display) appears after restarting the transmitter.

Display parameters (Menu item 1.1)

Within the menu you have the following display or setting options:

- Language, menu item 1.1.1
- Line 1, menu item 1.1.2 (definition of measured value)
- Line 2, menu item 1.1.3 (definition of measured value)
- Display of flow value, menu item 1.1.4 (only for line 2)
- Illumination, menu item 1.1.5 (display test)

Multi display (menu item 1.2)

Simultaneous display of two measuring variables

Flow (menu item 1.3)

Display of current flow

Totalizer (menu item 1.4)

Display of total flow

This menu displays all totalizers which can all be reset together.

These are:

- Totalizer forwards, menu item 1.4.1
- Totalizer reverse, menu item 1.4.2
- Totalizer net, menu item 1.4.3
- Set (all), menu item 1.4.4

Note

The totalizers show the total flow volume since starting the measurement. Use the menu items 3.2, 3.3 and 3.4 for separate setting and resetting of the units. The totalizer is restarted when it overruns.

Note

The value range of the totalizers in PROFIBUS and HART communication is principally -10^{38} m^3 to $+10^{38} \text{ m}^3$. However, since the value range of the local display is limited to 999 999 999, the display stays at 999 999 999 when this range is exceeded, while totalizing continues internally.

Flow velocity (menu item 1.5)

Display of current measured value in m/s

Frequency (menu item 1.6)

Display of current measured value in Hz

Analog Out1,2 (menu item 1.7)

Display of current measured value in mA

8.3 Function Group Diagnostics

Device status (Menu item 2.1)

During normal operation, test routines are run continuously.

The display "OK" appears in the case of error-free operation after selecting menu item 2.1 (device status). An error message is displayed in clear text in the event of an error.

The possible error messages are listed in the table below and the assignment of the error messages to the individual outputs specified. The error message can only be output via the digital outputs 1 and 2 and the analog output if configured accordingly (selection of 'Alarm')

function for the digital outputs or 'Failure signal' for the analog output) (see menu items 4.1.2, 4.2.1 and 4.3.1).





- A flashing "F" process related error at the top right of the display indicates a process error.
- A flashing "D" at the top right of the display indicates a device error.

Should errors in groups 'F' and 'D' occur at the same time, only 'D' will flash.

In communication via PROFIBUS, the diagnostic message displayed here is also reported under the extended diagnosis with the diagnostic bit "EXTENSION_AVAILABLE".

Table 8-1 Error messages

Error message	Flashing indication in display menu	Error is Signaled at the analog output	Error is signaled at digital output 1 and 2	PROFIBUS
Measurement module failure	F	-	-	x
Calibration failure measurement module	F	-	-	x
Simulation is running	F	-	-	x
Flow measurement unreliable	F	-	-	x
Calibration is running	F	x	x	x
Tube empty	F	x	x	x
Measuring range overflow > 110 %	F	x	x	x
COM Module failure	D	-	-	-
Memory failure	D	x	x	x
Software failure	D	x	x	x
Sensor failure	D	x	x	x
Flow measurement disturbed	D	x	x	x

For texts with more than 16 characters, the marks  and  in the first and last segment of the device display respectively indicate that there are other characters to the left and/or right of the displayed text. You can display these by actuating the  and  operating elements.

Electrode check (Menu item 2.2)

The electrode DC voltage is scanned cyclically when this menu item has been selected. This detects e.g. deposits on the electrodes. If there is a fault or an error, the alarm signal 'Flow measurement unreliable' is triggered.

Note

This function requires a sensor with SmartPLUG.

Empty Pipe Det. (menu item 2.3)

The function checks whether the electrodes of the sensor are wetted by the medium. To do this, you have to determine the monitoring interval.

If the electrodes have no contact with the medium, the alarm signal "Tube empty" is triggered through the digital outputs. This alarm is also triggered in the case of an insulating coating on the electrodes.



WARNING

This message does not mean that the tube has actually run empty. Therefore you must make sure that the pipeline is actually empty before you remove the tube!

Note

Response threshold and timing behavior of the "immersion check" function depend on the conductivity of the medium and the nominal width and cladding of the sensor (min 50µS/cm). The switching threshold can be adapted to these conditions, if necessary (see menu item 6.7.5).

Device test (Menu item 2.4)

The device test comprises the following test components:

- Self test, menu item 2.4.1
The self test routines are inserted in the current measurements and are completed after about 60 seconds. If there is no error, "OK" is displayed, otherwise "not OK". The type of error can then be read out in the menu item "2.1 Device status".
- Display test, menu item 2.4.2
The LCD is checked with this menu item. The display is initially dark for approx. 5 seconds and then bright for approx. 5 seconds.





Simulation flow (Menu item 2.5.1)

The flow can be simulated in a range from ±110 %.

Here you also have the possibility of checking displays, totalizers, limit values and outputs in certain measuring ranges. The running simulation is indicated by a flashing 'F'. It ends at the end of a previously set period or after entering the 'End' parameter in this menu item.

Simulation outputs (Menu item 2.5.2, 2.5.3, 2.5.4)

With this function you can check the signal circuits of the analog output, the digital outputs 1 and 2 as well as the flow.

In the individual menu items, you select the value to be simulated with the  and  operating elements. You activate the setting by confirming the selected value with the operating element . The running simulation is indicated by a flashing 'F'. You end simulation of the output signal by actuating the operating element  (exit the menu item).

Digital output 1 must be configured for the "Alarm" function for simulation of the alarm signal (setting in the menu item "4.2.1 Function").

8.4 Function Group Measuring Functions

Flow (Menu item 3.1)

You have the following setting options in this menu:

- **Engineering unit**, menu item 3.1.1
This function offers you the possibility of choosing between units of volume flow (volume unit per time unit) or mass flow (mass unit per time). If a unit of mass is selected, it is mandatory to enter the density of the medium in menu item 3.1.4.
- **Flow Upper Range Value (URV)**, menu item 3.1.2
The full scale value is set depending on the nominal width of the sensor and the valid speed range (0.25 - 12 m/s). The start of scale value is always 0 (zero).

Note

Devices with PROFIBUS PA

Although the profile parameter for the start of scale value (0%) can always be written by acyclic communication, values not equal to 0 are rejected.

The output scale does not appear in the local operating unit. It is always automatically set to be identical with measuring scale, i.e. the profile parameters start / end of the output scale are automatically set to 0 or "URV". Other values are rejected in acyclic PROFIBUS communication.

The set URV only has an influence on the percentage defined values such as "flow in %", hysteresis and the digital output 1.

Measured values outside this range are also reported by PROFIBUS as valid measured values providing they are within the sensor limits. The sensor limits for flow depend on the nominal width and correspond to a flow velocity range of about -13 m/s to +13 m/s.

Measured values outside the sensor limits are displayed but are no longer within the specified range; "uncertain, nonspecific, low limited" or "uncertain, nonspecific, high limited" is then reported as a measured value status.

- **Limits**, menu item 3.1.3, consisting of:
 - Low Alarm Limit, menu item 3.1.3.1 and
 - High Alarm Limit, menu item 3.1.3.2

The input is made in absolute values within the sensor limits (depending on the nominal width, corresponding to -13 m/s to +13 m/s). Alarm limits of min. 10% and max. 90% of the URV are set at the factory.

Exceeding or dropping below these limit values are signaled at digital output 1 or 2 if the function of these outputs is configured appropriately (menu items 4.2.1 and 4.3.1). In PROFIBUS communication, these events are reported by the limit bits in the measured value status.

Note

Devices with PROFIBUS PA

The profile parameters for the "Low Warning Limit" and "High Warning Limit", can be set independently of the alarm limits by acyclic PROFIBUS communication. They do not appear in the local operating unit. Exceeding of the warning limits is only signaled by PROFIBUS communication.

- **Hysteresis**, menu item 3.1.3.3
 The limit values (menu items 3.1.3.1 and 3.1.3.2) can have a hysteresis added to prevent "fluttering" of the switching output.




Figure 8-1 Limit value message and hysteresis

- **Density**, menu item 3.1.4
You must specify unit and density here. The volume flow q_v is converted to mass flow q_m automatically using the formula ($q_m = q_v \cdot \rho$).
 - **Direction**, menu item 3.1.5.
This item is divided into:
 - **Flow direction**, menu item 3.1.5.1
 - **Measuring direction**, Menu item 3.1.5.2
 - **Hysteresis**, Menu item 3.1.5.3
1. The flow direction (3.1.5.1) is preset at the factory and indicated by the arrow on the sensor. If the flow direction does not match the direction of the arrow it must be adapted in this menu item.





Figure 8-2 Setting Forw. and Rev. (left) and setting Forw. only (right)

2. With measuring direction (3.1.5.2) it is possible to detect flow in forward and backward direction and to pass on the appropriate signal proportionally to the analog or digital output. In "forwards" parameterization, only signals in this direction are output or accumulated internally.

Example 1: Hysteresis = 0%



Example 2: Hysteresis = 0%




Figure 8-3 Hysteresis flow direction

1. Hysteresis (3.1.5.3). The limit values (menu items 3.1.5.1 and 3.1.5.2) can have a hysteresis added to prevent "fluttering" of the switching output. This setting is made in % of the set full scale value in the menu item 3.1.5.3 "Hysteresis". If, for example, the hysteresis is 1 %, the relay contact does not switch until a flow of -1% of the full scale value and returns to the original position at a flow of +1% of the full scale value.

Table 8-2 Switching status of the relay for selected signal type

- Contact closes:	a →	Relay contact closed
	b →	Relay contact open
- Contact opens:	a →	Relay contact open
	b →	Relay contact closed

- **Low flow cut**, menu item 3.1.6
 This parameter determines the switching point for low flow cut-off. The low flow cut prevents flow being measured in the lower range (e.g. fluctuating liquid columns at a standstill). The low flow cut-off affects: display, totalizers, analog output and pulse frequency output as well as HART and PROFIBUS communication.
 - In devices with HART communication, the value of the low flow is related percentage-wise to the upper range value (menu item 3.1.2).
 - In devices with PROFIBUS communication, the absolute value must be entered in the selected unit of flow (menu item 3.1.1).
- **Filter time constant**, menu item 3.1.7.1
 The jump response can be suppressed in this menu item. This may be necessary depending on the application, for example in the case of fast changing flows to keep the display value or analog value stable.


- Noise Suppress**, menu item 3.1.7.3

This function serves to eliminate temporary, application-related interference within a fixed time frame.

Every measured value within a measuring pulse is compared with the previously determined value. If it is outside the tolerance band set under menu item 3.1.7.3 (the specified % value refers to the set full scale value), the device operates with a filter time constant of 10 s. This applies for the suppress time set in menu item 3.1.7.3. If a greater deviation occurs during this time, the time starts again from the beginning. If a disturbed signal is applied continuously, the device remains set to the greater filter time constant until the unattenuated measured values are back within the selected tolerance band. The device switches back to normal mode at the end of time "t" after the last detected deviation.
- Slurry mode**, menu item 3.1.8

For media with high solids content, magnetically conductive solids or air locks, the stability of the measured values can be significantly improved with this setting, while the reaction speed remains the same when the flow is altered.

If necessary, the stability of the measured value can be further increased using the "Filter time constant" (menu item 3.1.7.1) or "Error blanking" functions, although this will in turn reduce the measuring dynamics.



- ① Un-attenuated measuring variable
- ② Time
- ③ Tolerance band
- ④ t = suppress time



- ① Flow in % with filter time constant
- ② Time

Effect of a noise signal filter (example)

Total. forwards (Menu item 3.2)

You have the following setting options in this menu:

- **Set**, menu item 3.2.1
 In this menu you can reset the forwards totalizer to zero and restart if necessary. If the totalizer overruns the optical display of the totalizer stops at "999999999" but the device continues counting internally. You have to set a greater unit to be able to read the current totalizer reading again.
 You have the following individual setting options:
 - Reset+Stop: the totalizer is set to 0 and held.
 - Reset+Start: the totalizer is set to 0 and restarted 1,2
 - Totalize: the totalizer is started 3
- **Unit**, menu item 3.2.2
 With this function you can select physical units or switch from one unit to another. In the latter case the device converts the previous totalizer reading into the new unit.
- **Alarm limit**, menu item 3.2.3
 Here you can set all values from 0 to +108. You can assign reaching or exceeding this limit value as a signal to a digital output.

Total. reverse (Menu item 3.3)

You have the following setting options in this menu:

- **Set**, menu item 3.3.1
In this menu you can reset the reverse totalizer to zero and restart if necessary. If the totalizer overruns the optical display of the totalizer stops at "999999999" but the device continues counting internally. You have to set a greater unit to be able to read the current totalizer reading again.
You have the following individual setting options:
 - Reset+Stop: the totalizer is set to 0 and held.
 - Reset+Start: the totalizer is set to 0 and restarted 1,2
 - Totalize: the totalizer is started 3
- **Unit**, menu item 3.3.2
With this function you can select physical units or switch from one unit to another. In the latter case the device converts the previous totalizer reading into the new unit.
- **Alarm limit**, menu item 3.3.3
Here you can set all values from 0 to -108. You can assign reaching or exceeding this limit value as a signal to a digital output.

Totalizer net (Menu item 3.4)

You have the following setting options in this menu:

- **Set**, menu item 3.4.1
In this menu you can reset the totalizer net to zero and restart if necessary. The net totalizer forms the difference (error sum) between forward and backward flow. If the totalizer overruns the optical display of the totalizer stops at "999999999" but the device continues counting internally. You have to set a greater unit to be able to read the current totalizer reading again.
You have the following individual setting options:
 - Reset+Stop: the totalizer is set to 0 and held.
 - Reset+Start: the totalizer is set to 0 and restarted 1,2
 - Totalize: the totalizer is started 3
- **Unit**, menu item 3.4.2
With this function you can select physical units or switch from one unit to another. In the latter case the device converts the previous totalizer reading into the new unit.
- **Low Alarm Limit value**, menu item 3.4.3
Here you can set all values from -1 to -109. You can assign reaching or exceeding this limit value as a signal to a digital output.
- **High Alarm Limit**, menu item 3.4.4
Here you can set all values from 1 to +109. You can assign reaching or exceeding this limit value as a signal to a digital output.
- **Hysteresis**, menu item 3.4.5
The limit values (menu items 3.4.3 and 3.4.4) can have a hysteresis added to prevent "fluttering" of the switching output.

8.5 Function Group Device Outputs


Analog out (Menu item 4.1)

This menu only appears in devices with a 20 mA output (7ME5034-0xxxx and -2xxxx).

The following settings are possible:

- **Current limiting**, menu item 4.1.1

The upper current limit for the output signal is determined in this menu item.



- ① Current
- ② Parameter range
- ③ Measured value

Figure 8-4 Current limiting

- **Failure signal**, menu item 4.1.2
In the event of a fault, e.g. a device error or measuring error due to entrapment of air, the analog output shows a predefined current.
The following settings are possible:
 - 3.6 mA
 - 22 mA
 - 24 mA
 - Hold for a defined time (5...240 seconds), then 3.6 mA
 - Hold permanently
With the "Hold 5 s" setting you can bypass temporary faults (e.g. air entrapment in the medium) for up to about 5 s without the analog signal outputting an error message. The same applies accordingly for "Hold 20 s", "Hold 40 s" etc. The last valid measured value is output during the fault. If the fault lasts less than 5 s the current measured value is output at the end of the fault. If the fault persists, the output signal is set to 3.6 mA.
In the "Hold permanently" setting the last valid value is output until the fault is eliminated. In the current range between 0 and 20 mA, the 3.6 mA failure signal or "Stop" is not recommended; in this case, the setting '22 mA' or '24 mA' must be selected.
- **Split mode** (combined counter), menu item 4.1.4
The Split mode is activated when 'Active' is selected.
The "Split value" divides the measuring range (URV) set in menu item 3.1.2. The split value is only effective when it is smaller than the full-scale value (upper range value, URV).
When Split mode is activated, if there is a current flow value in the lower sub-domain (0 to split value), this sub-domain is shown in a linear way on the set current range (0-20 mA or 4-20 mA), i.e. a current of 20 mA corresponds to the split value. This status can be indicated on digital outputs 1 or 2, if the "Split value active" function has been set (menu 4.2.1 and 4.3.1)
If the current flow value is within the upper sub-domain (split value to full-scale value), the range 0 to URV is shown in a linear way on the set current range as for the inactive Split mode.




Figure 8-5 Split mode in domain 4 ... 20 mA

Profibus (Menu item 4.1)

This menu only appears in PROFIBUS devices. (7ME 5034-1xxxx).

This menu gives you the following setting options:

- Bus address, menu item 4.1.1
The address 126 (factory setting) is reserved for newly connected devices and must be changed to a smaller value at the latest after commissioning on the bus. A value between 30 and 125 is recommended because addresses below 30 are only assigned for bus masters as a rule.
An address < 126 is only addressable when no cyclic communication is taking place and all acyclic connections are closed.
With the PROFIBUS variable "factory_reset = 2712" the address can be reset to the factory setting 126.

Note

Each address may only be assigned for one device on the connected bus!

- Ident No., menu item 4.1.2
The device profile for the cyclic data traffic can be selected here.
You have the following options:
 - Profile-specific (=Ident No. 0x9740) means:
Restricted functions; i.e. only cyclic parameters according to profile 3.0 (flow and totalizer net).
 - Manufacturer-specific (= Ident No. 0x80C4) means:
Full functions, i.e. cyclic parameters according to profile 3.0 and additional manufacturer-specific parameters (e.g. totalizer forwards, totalizer reverse).

Note


The connected PROFIBUS master must be configured with a device database file (GSD) according to the set ID No.

See also Device Database File (GSD) (Page 114)

Digital output 1 (Menu item 4.2)

You have the following setting options in this menu:

- **Function**, menu item 4.2.1
 You can configure digital output 1 as a pulse, frequency, alarm or status output
 When "Split value active" is selected, the output is active when the current level of the flow value is within the lower sub domain 0 to "Split value"; the output current is then scaled to the 0 to "Split value" range. If the flow value exceeds this sub-domain, the output current is scaled to the 0 to URV range.
- **Signal type**, menu item 4.2.2
 You can configure different signal types for the output signal of digital output 1:
 - Active:
 The device-internal voltage is used (+24 V).
 - Passive:
 External supply required.




- ① Active
- ② Passive
- ③ Counter
- ④ External supply max. DC 30 V

Figure 8-6 Active and passive signals

You can generate signals with positive and negative logic (positive and negative pulses). The figure below illustrates the setting options.

- **Pulse rate**, menu item 4.2.3
The pulse valence indicates how many pulses are output per unit of volume or mass. When the "Pulse" function is selected, you have to set the number of pulses per unit of volume or mass.
- **Pulse width**, menu item 4.2.4
You can determine the pulse/pause ratio of the pulse output with the pulse width. The pulse width can be set in a range from 0.1 to 2000 ms. A maximum pulse width is calculated in relation to the set full scale value and the set pulse valence. The maximum pulse frequency is 5 kHz.



- ① Active-positive
- ② Active-negative
- ③ Passive-positive
- ④ Passive-negative
- ⑤ Transistor T_2 conductive
- ⑥ Transistor T_2 disabled
- ⑦ Time

Figure 8-7 Signal types for digital output 1

- **Full scale frequency**, menu item 4.2.5
The frequency is permanently assigned to the flow. The pulse/pause ratio is constant 1:1. If the "Full scale frequency" function is selected, the frequency is set in the range from 2 ... 10000 Hz.

Digital output 2 (Menu item 4.3)

The digital output 2 is available in device variants with the MLFB-No. 7ME5034-0xxxx-xxxx (Hart communication and digital output). You have the following setting options in this menu:

- **Function**, menu item 4.3.1
You can configure the digital output 2 (relay contact) as an alarm or status output.

When "Split value active" is selected, the output is active when the current level of the flow value is within the lower sub-domain 0 to "Split value". In this case the output current is scaled to the 0 to "Split value" range. If the flow value exceeds this sub-domain, the output current is scaled to the 0 to URV range.

Note



The relay contact is open in the "no function" setting.


• **Signal type, menu item 4.3.2**

You can set the function of the relay as follows in this menu item:

1. When the relay need to be closed in the event of an alarm:
 Flow in forward direction
 Limit value message
2. When the relay need to be open in the event of an alarm:
 Flow in forward direction
 Limit value message

Table 8-3 Relay status

Setting	No alarm Reverse flow No limit signalling	Alarm message Forward flow Limit signalling
1. Contact closes 2. Contact opens		



- ① Electronic fuse
- ② External supply

Figure 8-8 Digital output 2

NOTICE


At high inductive loads, the digital output must be protected against transient overvoltage with a suitable external recovery diode.

The electronic fuse is tripped in the event of overloading. The recovery time of the fuse is a few minutes. The relay contact is open in the no-load state.

Digital input (Menu item 4.3)

The digital input is available with the device variant 7ME5034-2xxxx (Hart communication and digital input). You have the following setting options in this menu:

- **Function**, menu item 4.3.1
By applying an external power supply, you can create a switching input, for example using a switch (see also Figure 5-12). You have the following possibilities depending on the configuration:
 - Set the measured value to "0" (all outputs and displays are reset to zero and the totalizers are stopped)
 - Reset the forwards totalizer
 - Reset the reverse totalizer
 - Reset the net totalizer
 - Reset all totalizers



- ① Electronic fuse
- ② External switch
- ③ External supply 11 ... 24 V (max. 30 V)

Figure 8-9 Circuit diagram of digital input

- **Signal type**, menu item 4.3.2
You can determine the signal type (high-active) with this.

8.6 Function Group Identification

Funct. unit (Menu item 5.1)

You can call or enter device-specific or tag-related data in this menu.


You have the following options:

- TAG (tag number), menu item 5.1.1
- Tag description, menu item 5.1.2
- Message, menu item 5.1.3

8.6 Function Group Identification

You can enter tag-specific data in these menu items. The and operating elements take on the function of a cursor control here. The numbers, letters and text characters are selected with the and operating elements.

If no text is stored, the end of text character flashes when opening these menu items. Actuation of the and operating elements moves the end of text character one position to the right and a character can be selected from the character set. The following characters are available:



The selected character is transferred by pressing the operating element and the end of text character flashes again. Another character can be selected with the and operating elements. Text input is ended by actuating the operating element when the end of text character flashes.

The number of characters is limited to:

Table 8-4 Max. number of characters

	PROFIBUS	HART
• Tag number (TAG):	32 characters	8 characters
• Tag name:	32 characters	16 characters
• Tag message	32 characters	32 characters

The Hart communication transmits only capital letters. For texts with more than 16 characters, the marks and in the first and last segment of the device display respectively indicate that there are other characters to the left and/or right of the displayed text.

You delete text by selecting the end of text character from the character set with the and operating elements and then actuating the operating element. All inputs to the right of the end of text character are then deleted.

Note

When the and operating elements are actuated continuously (your finger stays on the glass panel), the characters are scrolled automatically.

Manufacturer data, menu item 5.2

You can read out the serial number, order number and software version of the device in the individual menu items.

The serial number and the order number of the device electronics are always displayed; in case of replaced electronics the latter is different from that of the device rating plate.

- **Nominal width**, menu item 5.2.6.2
In this menu item you can set the nominal width in older generations of sensors manually if no SmartPLUG data are available.
When you have selected "Probe", you must enter the interior diameter of the surrounding tube in "Diameter".

8.7 Function Group Service

Enter Code (menu item 6.1)

You can disable the control and display unit with a personal, freely selectable code number to prevent programming of the device by unauthorized persons. By entering the appropriate code number in this menu item, the programming is enabled and you can change the device settings.

- Factory set code "0"
- Customer code (see menu item 6.2 "Code change")

Note

If you actuate one of the or operating elements in the setting level of the parameter, you are automatically prompted to enter the code in the device display. The programming is disabled after returning to the display mode. The programming can also be disabled by entering any number which does not match the actual customer code in this menu item. After input of '3333' the fixed personal code is briefly displayed (help function as reminder).

Customer code (Menu item 6.2)

You can change the personal code number in this menu item.

The code is factory set to 0. The menu item is only accessible after entering the personal code even when programming has already been enabled.

Note

Programming is always enabled when the code = 0.

Service code (Menu item 6.3)

The calibration data of the device are protected by a special code (factory code). The appropriate menu items are only available after entering this factory code.

Reset (Menu item 6.4)

Here you can perform a "warm start" of the controller.

This retains all saved units, but the volume totalizer is reset to zero.

Control values (Menu item 6.5)

These display values are for trained service personnel, since they are device-internal data mainly for error diagnosis.

These include:

- **Magnet voltage U_m , U_{ref}** , menu item 6.5.1
- **Signal voltage U_{sig}** , menu item 6.5.2
- **Electrode voltage U_{el1}** , menu item 6.5.3
- **Electrode voltage U_{el2}** , menu item 6.5.4
- **Current flow** in % of the set full scale value, menu item 6.5.5
- **Measuring frequency**, menu item 6.5.6
- **Self test**, menu item 6.5.7
- **Service information**, menu item 6.5.8
- **Digital input**, menu item 6.5.9

Zero Trim (Menu item 6.6)

This function is divided into:

- **Zero flow correction**, menu item 6.6.1

This menu item serves to adapt the local hydraulic conditions. The zero point has a speed value of -1 to +1 m/s added. This setting is undone by entering "0".

- **Start correction**, menu item 6.6.2
This automatically determines the hydraulic zero point. This value is visible in menu item 6.6.1 and can be adapted there, if necessary, or undone by entering "0".

Trim param. (menu item 6.7)

You have the following setting options in this menu:

- **Calibration factor**, menu item 6.7.1
Due to the local hydraulic conditions, any error related to the full scale value is corrected in this menu item. The value to be set here corresponds to a multiplier of the measured value. An absolutely correctly set zero point is the prerequisite for proper functioning.
- **CFH**, menu item 6.7.2
This is a factory determined hydraulic calibration value at a flow of 1 m/s. This value is automatically taken from the SmartPLUG of the measuring sensor. For older measuring sensors without a SmartPLUG, the value must be transferred manually from the nameplate.
- **CFR**, menu item 6.7.2
This is a calibration value for the reference inductor in the measuring sensor calculated in the factory. This value is automatically adopted by the SmartPLUG.

- **ZPH**, menu item 6.7.3
This is a factory-determined hydraulic calibration value at a flow of 0 m/s. This value is automatically taken from the SmartPLUG of the measuring sensor. For older measuring sensors without a SmartPLUG, the value must be transferred manually from the nameplate.
- **Excitation frequency**, menu item 6.7.4
This setting option depends on the type or the nominal width of the sensor or the probes.

Signal Transmitter	Sensor	Nominal width	Magnet frequency (=mains frequency)
TRANSMAG 2	MAG 911/E Standard applications	(all)	Bipolar prepulse f/5
	MAG 911/E Rapid applications	(all)	Bipolar f/3
	MAG 911/E up to 1995	DN ≤ 150	Unipolar f/6

- **Immersion check**, menu item 6.7.5
The "Tube empty" detection depends basically on the conductivity of the medium. The switching threshold is set to a typical value. Adjustment may be necessary in special cases.
Here you have to determine the current internal measured values for electrodes 1 and 2 for a filled and empty measuring tube under the menu items 'Act.Value EI1' and 'Act.Value EI2'. The switching threshold of the immersion check should be set under menu item 'Threshold' to about midway between these two values.

Service and Maintenance

9.1 Maintenance

The device is maintenance-free. However, a periodic inspection according to pertinent directives and regulations must be carried out.

An inspection can include check of:

- Ambient conditions
- Seal integrity of the process connections, cable entries, and cover screws
- Reliability of power supply, lightning protection, and grounds

NOTICE
Repair and service must be carried out by Siemens authorized personnel only.

Note

Siemens defines flow sensors as non-repairable products.


Cleaning the enclosure

- Clean the outside of the enclosure with the inscriptions and the display window using a cloth moistened with water or a mild detergent.
- Do not use any aggressive cleansing agents or solvents, e.g. acetone. Plastic parts or the painted surface could be damaged. The inscriptions could become unreadable.

Enclose the bill of lading, return document and decontamination certificate in a clear plastic pouch and attach it firmly to the outside of the packaging.

Required forms

- Delivery note
- Return goods delivery note (<https://www.siemens.com/processinstrumentation/returngoodsnote>)
with the following information:
 - Product (item description)
 - Number of returned devices/replacement parts
 - Reason for returning the item(s)
- Decontamination declaration (<https://www.siemens.com/sc/declarationofdecontamination>)
With this declaration you warrant "that the device/replacement part has been carefully cleaned and is free of residues. The device/replacement part does not pose a hazard for humans and the environment."
If the returned device/replacement part has come into contact with poisonous, corrosive, flammable or water-contaminating substances, you must thoroughly clean and decontaminate the device/replacement part before returning it in order to ensure that all hollow areas are free from hazardous substances. Check the item after it has been cleaned. Any devices/replacement parts returned without a decontamination declaration will be cleaned at your expense before further processing.



Devices described in this manual should be recycled. They may not be disposed of in the municipal waste disposal services according to the Directive 2012/19/EC on waste electronic and electrical equipment (WEEE).

Devices can be returned to the supplier within the EC, or to a locally approved disposal service for eco-friendly recycling. Observe the specific regulations valid in your country.

Further information about devices containing batteries can be found at: Information about battery / product return (WEEE) (<https://support.industry.siemens.com/cs/document/109479891/>)

9.2 Ordering of spare parts

Ensure that your ordering data is not outdated. The latest ordering data is always available on the Internet: Process instrumentation catalog (<http://www.siemens.com/processinstrumentation/catalogs>)

Troubleshooting

10.1 Quick sensor check-up

Resistance check

Between the sensor terminals 5 and 6, the resistance should be between 8 and 20Ω, when the transmitter is disconnected. If the measured value is outside the recommended area, the sensor is defective.

Isolation check

Between sensor terminal 5 and 7 as well as 6 and 7, the resistance must be $\geq 10 \text{ M}\Omega$. If this is not the case, humidity is present in the sensor. The check can also be carried out with the sensor cable connected. If the measured values are too low, the sensor is defective.

NOTICE

Make sure the transmitter is disconnected during resistance and isolation check!
--

Check of electrode circuit

For sensors with SmartPLUG, the voltage must be:

- - 5.3 V DC $\pm 10\%$ between terminal 22 and 29
- + 5.3 V DC $\pm 10\%$ between terminal 22 and 30

This should be measured directly at the transmitter and then at the sensor.

If the measured values are too low, transmitter is defective.

If the measured values are zero or with a wrong polarity, check cable leads.

See also

If the sensor or transmitter is defective, contact your local Siemens representative:

Local contact person (<http://www.automation.siemens.com/partner>)

10.2 Application Problems

Table 10-1 Troubleshooting list

Error	Diagnosis	Remedy
Sensor does not work or no display or no output signal	Power supply missing	Connect or switch on power supply
	Device fuse defective	Check device fuse and replace if necessary
Transmitter does not react to controls	Reflections in the glass	Clean glass
	Glass is not tight to the operating unit	Screw in the electronic cover tightly
Transmitter cannot be parameterized by the operating module	Personal code is activated	Enter personal code (menu 6.1 or deactivate by entering 0 in menu 6.2)
	Local operation lock activated by HART or PROFIBUS	Cancel operation lock
Output signal OK but no display visible	Ambient temperature outside permissible range	Remote design: bring transmitter into a temperature range of 0 to 50 °C
	Display defective	Change operating module
Flow display = 0 at available flow	Low flow cut-off set too high	Reduce low flow cut (menu 3.1.6)
	Flow opposite to preferable direction at setting of measuring direction to "forwards only"	Switch over preferred direction menu (3.1.5.1) or set measuring direction to "forw.+rev." (menu 3.1.5.2)
	Measured value set to 0 via digital input	Switch over signal at digital input (menu 4.3.2) or switch off function (menu 3.3.1)
	Cable connection to sensor defective (only for remote design)	Check cable connection and exchange as required
	SmartPLUG defective	Have SmartPLUG exchanged (only by service personnel)
Transmitter indicates flow at zero flow	Hydraulic zero point drift, application-dependent	Perform zero correction (menu 6.6.2) or enter correction value directly (menu 6.6.1)
	Grounding problems	Provide potential equalization (see Installation with grounding rings (Page 28))
Fluctuating measuring results at constant flow	Air, gas occlusions	Eliminate gas occlusions or use gas trap
	Grounding problems	Provide potential equalization (see Installation with grounding rings (Page 28))
	Vibrations in the sensor and/or in the cable run	Fix the sensor better, strap cables
	Medium conductivity too low	Check conductivity; measuring method may be unsuitable
	Proportion of solids too high	Reduce proportion of solids, measuring method may be unsuitable
	Very unstable measurement, strongly fluctuating values, output going towards zero	Check for moisture in SmartPlug If fitted with round SmartPlug call factory product support

Error	Diagnosis	Remedy
Measuring deviations, measuring errors	Inlet and outlet lines insufficient	Change installation (see Determining a location (Page 19))
	Highly turbulent flow profile	Change inlet line, use flow rectifier, reduce diameter of tube
	For mass measurement: medium density set incorrectly	Correct density according to current medium (menu 3.1.4)
	Hydraulic calibration values faulty	Check hydraulic calibration values CFH and ZPH. According to the sensor rating plate and correct if necessary (menus 6.7.2 and 6.7.3).
	Electric calibration faulty	Run self-test (menu 2.4.1); Check device status (menu 2.1): if "Calibration failure measuring module" is displayed, send in the complete electronics for repair
	Application-dependent calibration values faulty	Reset zero point correction (menu 6.6.1) to 0 and/or reset calibration factor (menu 6.7.1) to 1.0. Alternatively: Make zero correction (menu 6.6.2) and manual adaptation of the calibration factor (menu 6.7.1)
Measured value too low at dosing	Set attenuation too high	Reduce filter time constant (menu 3.1.7.1)
	Fault blanking activated	Deactivate noise suppression (menu 3.1.7.3)
	Magnetic field frequency too low	Device may not be suitable for this application
	Magnetic field frequency too low	Change excitation to Bipolar (menu 6.7.4)
Measured value too low in pulsed flow	Temporary exceeding of internal working range	Increase URV (menu 3.1.2)
	Unfavorable hydraulic conditions	Install sensor on the suction side of the corresponding pump or in front of the feeding valve
	Unfavorable hydraulic conditions	Change excitation to Bipolar (menu 6.7.4)
Output current does not correspond to the current flow and remains at a constant value	There is a fault, failure signal 3.6, 22 or 24 mA is output (depending on the setting under menu 4.1.2)	Determine source of fault under device status (menu 2.1)
	Load too high	Reduce total load including the resistance to < 600 Ω
	Current output or power supply defective	Replace complete electronics
Communication via HART not possible	Minimum load of 230 Ω not available	Increase load to at least 230 Ω and connect HART Modem/Communicator parallel to this load
Communication via PROFIBUS not possible	Device address set incorrectly (assigned more than once on the same bus or not configured in the master)	Correct address under menu 4.1.1 or request and correct by acyclic communication
	Current load on bus too high for connected feeding device	Try disconnecting other devices from the bus Adapt the feeding device if necessary
	Baud rate between master and coupler/link not correct	Adapt baud rate to coupler/link
	More than two bus terminations exist (incl. coupler and link)	Reduce to two bus terminations
	PROFIBUS interface defective	Check device status (menu 2.1): if "COM module failure" is signaled, replace the complete electronics

10.3 Error messages

Errors are indicated by a flashing "D" (Device error) or "F" (Measurement error) in the top right hand corner of the local display.

Table 10-2 Error messages

Error		Diagnosis	Remedy
D	Flashing "D" in the top right hand corner of the display	General device error (see also section 5.3.2)	Menu 2.1 Call device status
D	Device status (menu 2.1) "Memory failure"	Internal memory defective	Replace complete electronics
D	Device status (menu 2.1) "COM Module failure"	HART interface not available in the transmitter	Replace complete electronics
		PROFIBUS interface not available in the transmitter	
D	Device status (menu 2.1) "Software failure"	General software error	Do a restart (menu 6.4); If error persists: have firmware reloaded (by service personnel), alternatively: replace complete electronics
D	Device status (menu 2.1) "Sensor failure"	Magnetic field current fuse defective	Change magnetic field current fuse (see section 6.3.1)
		Magnetic current cable defective (at terminals 5 and 6 in remote design)	Check cable and change if necessary
		Magnet coil defective	Check on remote design: Switch off device, disconnect magnetic field current cable, measure resistance at terminals 5 and 6 on sensor: setpoint: 8 ... 20 Ω. Otherwise: change sensor
		Reference coil improperly connected (terminals 55, 66)	Check cable and replace if necessary
		Electronics defective	Change complete electronics
D	Device status (menu 2.1) "Flow measurement disturbed"	No measurement possible (group message)	Change complete electronics
	"SmartPLUG read failure"	Connected sensor without SmartPLUG or defective SmartPLUG	Check parameterization (range, unit etc.) A correct measurement is still possible when the calibration values CFH and ZPH match the values on the rating plate of the sensor. Check whether this is the case and correct if necessary under the menus 6.7.2 and 6.7.3
F	Flashing "F" in the top right hand corner of the display	General incorrect measurements, process errors or incorrect parameterization.	Menu 2.1 Call device status

Error		Diagnosis	Remedy
F	Device status (menu 2.1) "Measurement module failure"	Measuring range overflow	Reduce flow quantity or increase upper range value in menu 3.1.2
F	Device status (menu 2.1) "Measurement module"	Measuring electronics defective	Measurement with reduced accuracy still possible; replace complete electronics
		Defective immersion check	Deactivate immersion check (menu 2.3)
		Magnetic field current outside the calibrated range	Recalibrate unit
		Fault in measuring function (incorrect measuring frequency)	Turn off mains synchronization (menu 3.1.7.2).
F	Device status (menu 2.1) "Calibration failure measuring module"	Self-test made with the result: measuring tolerances too high in relation to factory calibration	Electronics must be recalibrated, send in device (See chapter Return procedures)
F	Device status (menu 2.1) "Simulation is running"	Device not in "Measure" status, Simulation is switched on	End simulation (exit the menu "Simulation" 2.5.2, 2.5.3 or 2.5.4 or select "End" in menu 2.5.1). Alternatively: Restart the device
F	Device status (menu 2.1) "Calibration is running"	Zero calibration (menu 6.6.2) started and active	Device returns to measuring mode automatically at the end of calibration
F	Device status (menu 2.1) "Tube empty" (only possible with immersion check: menu 2.3) activated)	Measuring tube empty or only partially filled	Fill measuring tube with medium, ensure it is completely full
		High percentage of gas	Clear gas occlusions or use gas trap
F	Device status (menu 2.1) "Flow measurement uncertain"	Electrode DC voltage outside permitted range	Clean sensor electrodes
F	Device status (menu 2.1) "Measuring range overflow"	Current flow too high	Reduce flow
		Full scale value set too low	Increase upper range value in menu 3.1.2 or reduce flow rate

Technical specifications

Mode of operation

Mode of operation and design	
Measuring principle	Electromagnetic with pulsed alternating field (PAC)
Magnetic field excitation	Automatic power supply synchronization
50 Hz AC power supply	<ul style="list-style-type: none"> • Bipolar 16.7 Hz • Bipolar with prepulse 10 Hz • Unipolar 8,33 Hz
60 Hz AC power supply	<ul style="list-style-type: none"> • Bipolar 20 Hz • Bipolar with prepulse 12 Hz • Unipolar 10 Hz

Measuring accuracy under reference conditions

Measuring tolerance of pulse output	
At $v > 0.25$ m/s (0.82 ft/s)	$\cong 0.5$ % of the measured value, ± 0.0012 m/s (0.0039 ft/s)
At $v < 0.25$ m/s (0.82 ft/s)	$\cong 0.0025$ m/s (0.0082 ft/s)
Measuring tolerance of analog output 4 to 20 mA	Same as pulse output; plus ± 0.1 % conversion error ± 20 μ A
Repeatability	0.2 % of the measured value

Reference conditions

Reference conditions	
Medium process temperature	$+25$ °C ± 5 °C (77 °F ± 9 °F)
Ambient temperature	$+25$ °C ± 5 °C (77 °F ± 9 °F)
Warm-up time min.	30 min
Installation conditions	
Inlet pipe section	$\cong 10$ x DN
Outlet pipe section	$\cong 5$ x DN; installed centered to pipe
Medium	water without gaseous and solid parts
Conductivity	> 200 μ S/cm
Magnetic current frequency	bipolar with prepulse

Outputs and inputs

Outputs and Inputs	
Electrical isolation	Outputs electrically isolated from each other and from the power supply, max. 60 V permissible against PE/ equipotential bonding
Current output	0/4 ... 20 mA (Only 20 mA / HART devices (7ME5034-0.... and -2.....))
Signal range	
Upper limit	0/4 ... 20 mA, selectable
Failure signal	20 ... 22.5 mA optional: 3.6 mA, 20 mA or 24 mA
Load	
Output	Max. 600 Ω, load voltage max. 15 V For HART communication: $\geq 250 \Omega$
Communication	Via analog output with PC coupling module or HART communicator
Protocol	HART version 5.1
Digital output 1	
Signal	
Output	Configurable for positive or negative logic
Active signal	DC 24 V, ≤ 24 mA, $R_i = 170 \Omega$
Passive signal	Open collector, max. DC 30 V, 200 mA
Output configuration	
Pulse	
Significance	≤ 5000 pulses/s
Pulse width	≥ 0.1 ms
Frequency	≤ 10.000 Hz
Limits	For flow and quantity, flow direction, alarm
Digital output 2 (relay)	only 7ME5034-0....
Relay	NC or NO function
Rating	Rating max. 5 W, UC 50 V, 200 mA
Output configuration	limits for flow and quantity, flow direction, alarm
Digital input	Only as alternative to digital output 2 (only 7ME5034-2....)
Input function configurable high or low active	Set measured value or counter to zero
Signal voltage	max. 30 V, $R_e = 3 \text{ k}\Omega$
High level	DC +11 to 30 V
Low level	DC -30 to +5 V
PROFIBUS-PA	
Communication	For PROFIBUS devices (7ME5034-1....)
Transmission	Layer 1 and 2 according to PROFIBUS-PA
Protocol layer	According to IEC 1158-2
Protocol layer	Layer 7 according to PROFIBUS-PA and DP V1 (EN 50 170)
Device class	B

Outputs and Inputs	
Device profile	3.0; max. 4 simultaneous C2 connections
Bus voltage	Permissible 9 to 32 V
Current consumption from bus	10 mA, limited to ≤ 15 mA in the event of an error by electrical current limitation

Rated operating conditions

Ambient temperatures	
Remote design	-20 °C to +60 °C (-4 °F to +140 °F)
Display unit	0 °C to +50 °C (32 °F to 122 °F)
Storage	-25 °C to +80 °C (-13 °F to +176 °F)
Degree of protection	IP67, NEMA 4X, 5
Electromagnetic compatibility (EMC)	
Emitted interference	According to EN 61236 for use in industrial areas
Noise immunity	<ul style="list-style-type: none"> • According to EN 61326 for use in industrial areas • According to NAMUR NE21 for use in residential areas
Medium conditions	
Minimum conductivity of the medium	≥ 1 μ S/cm, on request 0,1 μ S/cm, depending on medium
Calibration	
Standard production calibration, calibration report shipped with sensor	2 x 20 %, 2 x 50 % and 2 x 100 %

Design

Design	
Weight of transmitter	4.4 kg (9.7 lb)
Remote version	Transmitter must be connected to the sensor using shielded cables
Maximum cable length	100 m; (328 ft)
Housing	Die-cast aluminum, painted

Local display

Display	
General display	LCD, background illumination, two lines with 16 characters each
Multi-display	For flow, quantity, flow velocity
Keypad	4 operating elements for entering parameters

Power supply

Power supply	
AC voltage	AC 100 to 250 V, $\pm 15\%$, 47 to 63 Hz
Power consumption	Approx. 120 to 630 VA, dependent on sensor
Power failure	Bridging of at least 1 power supply cycle (> 20 ms)
Cable fuse	AC 100 to 230 V: T1.6A
Magnetic current fuse	F5A/250 V

Dimension drawings




Figure 12-1 SITRANS FM TRANSMAG 2 transmitter with standard wall-mounting bracket




Figure 12-2 SITRANS FM TRANSMAG 2 transmitter with special wall-mounting bracket for pipeline mounting




Figure 12-3 SITRANS FM MAG 911/E sensor

Table 12-1 Dimensions, nominal diameter DN 15 ... DN 100

Nominal diameter	DN 15	DN 25	DN 40	DN 50	DN 65	DN 80	DN 100
	½"	1"	1½"	2"	2½"	3"	4"
Built-in length (L)							
• Hard rubber version	270 (10.63)		280 (11.02)		330 (12.99)	340 (13.39)	
• Linatex / neopren version	270 (10.63)		280 (11.02)		330 (12.99)	340 (13.99)	
• PTFE-liner without protection rings	270 (10.63)		280 (11.02)		330 (12.99)	340 (13.99)	
• Novolak-version	-			275 (10.83)	325 (12.79)	335 (13.19)	333 (13.11)
Dimensions of sensor housing							
Width	170 (6.69)						
Height	206 (8.11)		222 (8.74)	229 (9.02)	262 (10.32)		274 (10.79)
Diameter	135 (5.35)		167 (6.58)	182 (7.17)	247 (9.73)		272 (10.71)
Weight of PN 16 Version in kg (MWP 145 psi Version in lb)	8.0 (17.6)	8.5 (18.7)	11.5 (25.4)	25.0 (55.1)	26 (57.3)	27 (59.5)	28 (61.7)

Table 12-2 Dimension, nominal diameter DN 125 ... DN 400

Nominal diameter	DN 125	DN 150	DN 200	DN 250	DN 300	DN 350	DN 400
	5"	6"	8"	10"	12	14"	16"
Built-in length							
• Hard rubber version	370 (14.57)		410 (16.14)	470 (18.50)	500 (19.68)	550 (21.65)	600 (23.62)
• Linatex / neopren version	370 (14.57)		410 (16.14)	470 (18.50)	500 (19.68)	550 (21.65)	600 (23.62)
• PTFE-liner without protection rings	370 (14.57)		410 (16.14)	470 (18.50)	500 (19.68)	550 (21.65)	600 (23.62)
• Novolak-version	362 (14.25)		401 (15.79)	460 (18.11)	489 (19.25)	538 (21.18)	592 (23.31)
Dimensions of sensor housing							
Width (B)	170 (6.69)		240 (9.45)			225 (8.86)	250 (9.84)
Height (A)	286 (11.26)	299 (11.78)	334 (13.15)	258 (14.10)	383 (15.08)	375 (14.76)	400 (15.75)
Diameter (D ₁)	296 (11.65)	322 (12.68)	392 (15.43)	440 (17.32)	490 (19.29)	474 (18.66)	524 (20.63)
Weight of PN 10 Version in kg (MWP 145 psi Version in lb)	34 (75.0)	38 (83.8)	68 (149.9)	81 (178.6)	95 (209.4)	118 (260.2)	161 (354.9)

Table 12-3 Dimension, nominal diameter DN 450 ... DN 1000

Nominal diameter	DN 450	DN 500	DN 600	DN 700	DN 750	DN 800	DN 900	DN 1000
	18"	20"	24"	28"	30"	32"	36"	40"
Built-in length								
<ul style="list-style-type: none"> • Hard rubber version • Linatex / neopren version 	650 (25.59)	650 (25.59)	780 (30.71)	910 (35.83)		1040 (40.95)	1170 (46.06)	1300 (51.18)
<ul style="list-style-type: none"> • PTFE-liner without protection rings 	660 (25.98)	650 (25.59)	780 (30.71)	-				
<ul style="list-style-type: none"> • Novolak-version 	638 (25.12)	638 (25.12)	772 (30.39)	903 (35.55)		1033 (40.63)	1163 (45.79)	1293 (50.91)
Dimensions of sensor housing								
Width (B)	270 (10.63)	300 (11.81)	360 (14.17)	420 (16.54)		550 (19.69)	560 (22.05)	620 (24.41)
Height (A)	433 (17.05)	453 (17.84)	505 (19.88)	558 (21.97)	590 (23.23)	608 (23.94)	658 (25.91)	713 (28.07)
Diameter (D ₁)	591 (23.27)	629 (24.76)	734 (28.90)	839 (33.03)	904 (35.59)	939 (36.97)	1039 (40.91)	1150 (45.28)
Weight of PN 10 Version in kg (MWP 145 psi Version in lb)	185 (407.9)	233 (513.7)	401 (884.1)	420 (925.9)	450 (992.1)	500 (1102.3)	560 (1234. 6)	620 (1366.9)

Parameters

The device functions and parameters are listed below with the factory setting and setting option. The menu code only appears in the local display.

Display

Table A-1 Function group display parameters

Menu code	Device function, Parameters	Description	Factory setting	Setting options
1.1	Display Param.	Setting parameter for the local display		
	Language	Language for user guidance	Deutsch	<ul style="list-style-type: none"> English Deutsch Français Italiano Español Nederlands
1.1.2	Line 1	Definition of measured values to be displayed for line 1 in multi-display	Flow	<ul style="list-style-type: none"> Flow Totalizer net Flow velocity Analog Val. 1, 2, Frequency
1.1.3	Line 2	Definition of measured values to be displayed for line 2 in multi-display	Totalizer net	<ul style="list-style-type: none"> Flow Totalizer net Flow velocity Analog Val. 1, 2, Frequency
1.1.4	Display flow	Selection for type of presentation of the flow rate (% and bargraph only apply to line 2) When the "Flow" parameter has been selected for lines 1 and 2, "Bargraph in %" is always shown in line 2.	Engineering Unit	<ul style="list-style-type: none"> Engineering Unit % Bargraph in %
1.1.5	LCD lighting	Lighting of the display On: permanently switched on Off: automatic switch on by pressing key, switch off after 10 min	Off	<ul style="list-style-type: none"> On Off

Menu code	Device function, Parameters	Description	Factory setting	Setting options
1.2	Multi-Display	Simultaneous display of two measuring variables	(actual measured value line 1) (actual measured value line 2)	<ul style="list-style-type: none"> • Menu 1.1.2 • Menu 1.1.3
1.3	Flow	Flow value	(actual measured value)	
1.4	Totalizer	Flow quantity since totalizer start; volume or mass, depending on selected unit (menu 3.1.1)	(actual totalizer reading)	
1.4.1	Total. forward	Forward flow only	(actual totalizer reading)	
1.4.2	Total. rev.	Reverse flow only	(actual totalizer reading)	
1.4.3	Total. net	Flow difference forward - reverse	(actual totalizer reading)	
1.4.4	Set (all)	Reset all totalizers simultaneously to zero and stop or start; (separate setting of totalizers, see menu 3.2.1, 3.3.1, 3.4.1)	Cancel	<ul style="list-style-type: none"> • Reset+Stop, • Reset+Start • Cancel
1.5	Flow Velocity	Flow velocity in measuring tube in m/s	(actual measured value)	
1.6	Frequency	Calculated frequency value for actual flow in Hz	(actual measured value)	
1.7	Analog Out 1, 2	Calculated current value for actual flow in mA	(actual measured value)	

Diagnostics

Table A-2 Function group diagnostics parameters

2.1	Device status	Device status, error messages	("OK" or error messages)	
2.2	Electr.Check	Supervision of electrodes in sensor	Inactive	<ul style="list-style-type: none"> • Active • Inactive
2.3	EmptyTube Det.	Time interval for immersion check of electrodes or deactivation of immersion check. In case of insufficient immersion of both electrodes in conductive medium, 'Tube empty' is reported under device status.	Inactive	<ul style="list-style-type: none"> • Inactive • 15 s • 30 s • 60 s • 120 s • 300 s
2.4	Device Test			
	Self Test	Check device status (duration approx. 60s)		
2.4.2	Display Test	Visual check of local display		
2.5	Simulation			

2.5.1	Flow	Simulation of a flow value; affects all outputs, totalizers, limit values and display. "F" flashes in the top right of the display during simulation and "Simulation" is displayed under device status.		
	Value	Simulation value in % of full scale value	0 %	-110% to +110%
	Time	Duration of simulation After expiration of this time or with input of "End" the normal measuring mode is resumed	End	<ul style="list-style-type: none"> • End • 10 min • 30 min • 60 min
2.5.2	Dig. Out.1	Simulation of output signal at the digital output 1	End	<ul style="list-style-type: none"> • End • 0.1 Hz • 1 Hz • 10 Hz • 100 Hz • 1 kHz, • 10 kHz • Alarm on • Alarm off
2.5.3	Dig. Out.2 ¹	Simulation of the output signal at the digital output 2	End	<ul style="list-style-type: none"> • Alarm on • Alarm off
2.5.4	Analog Out. ^{1,2}	Simulation of the output signal at the analog output	4 mA	<ul style="list-style-type: none"> • 0 mA • 4mA • 10mA • 12mA • 20mA • Failure signal

¹⁾ Parameters apply only to devices with 20 mA/Hart communication and digital output 2 (7ME5034-0xxxx)

²⁾ Parameters apply only to devices with 20 mA/Hart communication and digital input (7ME5034-2xxxx)

Measuring functions

Table A-3 Function group Measuring functions parameters

3.1	Flow			
3.1.1	Engr. Unit	Engineering unit for volume flow or mass flow Note: When you select a unit of mass flow (see right column), you must enter the actual medium density (menu 3.1.4).	DN 2 ... 12: l/h DN >12: m ³ /h	<ul style="list-style-type: none"> • m³/s, m³/min, m³/h, m³/d • l/s, l/min, l/h • hl/s, hl/min, hl/h • Ml/d • ft³/s, ft³/min, ft³/h, ft³/d • gal/s, gal/min, gal/h, gal/d • Mgal/d • ImpGal/s, ImpGal/min, ImpGal/h, ImpGal/d • g/s, g/min • kg/s, kg/min, kg/h, kg/d • t/min, t/h, t/d • lb/s, lb/min, lb/h, lb/d, • STon/min, STon/h, STon/d • LTon/d
3.1.2	Flow URV	Upper range value (URV) At the analog output the amount of the measured value in the range 0 up to URV is displayed linear to the current range 4 to 20mA, at the digital output 1 to the frequency range 0 to end frequency	Depending on the nominal width according to 2...3m/s	Depending on the nominal width (according to 0.25 ... 12 m/s)
3.1.3	Limits	Absolute values in flow units from menu 3.1.1		
3.1.3.1	Lo Alarm Limit	Lower alarm limit (the lower alarm limit must be smaller than the upper alarm limit)	10% of the URV (depending on the nominal width according to 0.2 ... 0.3 m/s)	Depending on the nominal width (according to -13 ... +13 m/s)
3.1.3.2	Hi Alarm Limit	Upper alarm limit (the upper alarm limit must be greater than the lower alarm limit)	90% of the URV (depending on the nominal width according to 1.8 ... 2.7 m/s)	Depending on the nominal width (according to -13 ... +13 m/s)
3.1.3.3	Hysteresis	Hysteresis for limit values in % of full scale value	1 %	0 to 20 %
3.1.4	Density Engr. Unit Density	Density of the medium Engineering unit of the medium density Density value for calculation of mass flow	kg/m ³ +1000.00 kg/m ³	<ul style="list-style-type: none"> • g/cm³, kg/m³, lb/gal, kg/l, g/l, lb/in³, lb/lmpgal • 200 ... 5000 kg/m³
3.1.5	Direction			

3.1.5.1	Flow Direction	Main flow direction related to direction arrow on measuring tube (= forwards, positive flow values)	+Direction	<ul style="list-style-type: none"> +Direction, -Direction
3.1.5.2	Meas.Direction	Output of suppression of reverse flow Affects all outputs, totalizers and display	forw.+rev.	<ul style="list-style-type: none"> forward only, forw.+rev.
3.1.5.3	Hysteresis	Hysteresis of detection of flow direction in % of full scale value	0.2 %	0 to 20 %
3.1.6	Low flow cut	Threshold for low flow cut in % of full scale value 1, 2 or absolute value in flow unit 3	1 %	0 to 20 %
3.1.7	Noise filter			
3.1.7.1	Fltr.Time Con.	Time constant τ for measured value attenuation; after a jump in the measuring variable, the output measured value reaches about 99% of the new setpoint after $5 \cdot \tau$ Does not affect totalizers.	3.00 s	0.0 ... 200.0 s
3.1.7.2	Line Synchron.		Auto mode	Not available
3.1.7.3	Noise Suppress	Values outside a tolerance range are evaluated for the duration of the blanking time with high attenuation.		
	Suppress Time	Time of effect of increased attenuation (0 s = blanking off)	0 s	0 ... 100
	Suppress Limit	Tolerance range = floating average + tolerance value	0 %	0 ... 100
3.1.8	Slurry mode	This is used when signals are severely impaired, e.g. for media with a high solids content or air locks	Off	<ul style="list-style-type: none"> On Off
3.2	Total. Forw.	Totalizer forwards		
3.2.1	Set forward	Reset totalizer to zero and stop or start	Cancel 1,2 Totalize 3	<ul style="list-style-type: none"> Cancel 1,2, Reset+Stop, Reset+Start 1,2, Totalize 3
3.2.2	Engr. Unit	Engineering unit of volume or Engineering unit of mass When you select a unit of mass, entry of the actual medium density is mandatory (menu 3.1.4)	DN 2...12: l DN >12: m3	<ul style="list-style-type: none"> l, hl, m3, MI, ft3, Gal, MGal, ImpGal, MImpGal kg, t, g, lb
3.2.3	Alarm Limit		+1000000 l	-108 ... +108
3.3	Total. rev.	Totalizer reverse		
3.3.1	Set reverse	Reset totalizer to zero and stop or start	Cancel 1,2 Totalize 3	<ul style="list-style-type: none"> Cancel 1,2, Reset+Stop, Reset+Start 1,2, Totalize 3

3.3.2	Engr. Unit	Engineering unit of volume or Engineering unit of mass When you select a unit of mass, entry of the actual medium density is mandatory (menu 3.1.4)	DN 2...12: l DN >12: m ³	<ul style="list-style-type: none"> l, hl, m³, MI, ft³, Gal, MGal, ImpGal, MImpGal kg, t, g, lb
3.3.3	Alarm Limit		-1 000 000 l	-108 to +108
3.4	Total. net	Totalizer forw./rev.		
3.4.1	Set net	Reset totalizer to zero and stop or start	Cancel 1,2 Totalize 3	<ul style="list-style-type: none"> Cancel 1,2, Reset+Stop, Reset+Start 1,2, Totalize 3
3.4.2	Engr. Unit	Engineering unit of volume or Engineering unit of mass When you select a unit of mass, entry of the actual medium density is mandatory (menu 3.1.4).	DN 2...12: l DN >12: m ³	<ul style="list-style-type: none"> l, hl, m³, MI, ft³, Gal, MGal, ImpGal, MImpGal kg, t, g, lb
3.4.3	Lo Alarm Limit	Lower alarm limit (the lower alarm limit must be smaller than the upper limit.)	-1 000 000 l -	Frequency 108 ... +108
3.4.4	Hi Alarm Limit	Upper alarm limit (the upper alarm limit must be greater than the lower limit.)	+1 000 000 l	-108 ... +108
3.4.5	Hysteresis	Hysteresis for limit values	0 l	0 ... +108 (Unit the same as the counter unit in the menu 3.4.2)

Device Outputs

Table A-4 Function group Device outputs parameters

4.1	Analog Out ^{1, 2}	Analog output 4 to 20mA with HART communication		
4.1.1	Current limit	Upper limit of analog current	22 mA	20 ... 22.5mA
4.1.2	Error signal	Output current in case of failure. With the setting "Hold ..s" a current of 3.6 mA is only output in the case of a longer failure, shorter failures are bridged with output of the last valid current	3.6 mA	<ul style="list-style-type: none"> 3.6mA, 22mA, 24mA, Hold continuous, Hold 5s, 20s, 40s, 60s, 120s, 240s
4.1.3	Current range	Selecting the current range at the analog output on which the measuring range (menu 3.1.2) is shown. For the setting 0 to 20 mA the failure signal (menu 4.1.2) must be set to 22 or 24 mA.	4 ... 20 mA	<ul style="list-style-type: none"> 4 ... 20 mA; 0 ... 20 mA

4.1.4	Split mode	The split mode divides the measuring range into two domains: <ul style="list-style-type: none"> Domain 1 from 0 to 'Split value' Domain 2 from 'Split value' to 'URV' (upper range value, menu 3.1.2) At digital outputs 1 or 2, it is possible to indicate whether the current measured value is within domain 1. To do this, the function 'Split value active' must be set (menu 4.2.1 and 4.3.1)	Inactive	<ul style="list-style-type: none"> Inactive Active
	Split value	End value of domain 1 (only when 'Split mode = active')	URV (menu 3.1.2)	Depends on the nominal width (corresponding to 0.25 ... 12 m/s, <URV)
4.1	PROFIBUS ³	PROFIBUS communication		
4.1.1	Bus Address	PROFIBUS address	126	1 to 126
4.1.2	Ident-Nr.	Selection of appropriate device database file (GSD)	Manufact.spec.	<ul style="list-style-type: none"> Profile spec. Manufact.spec.
4.2	Digit.Output ¹	Frequency or pulse signal for flow or alarm signal		
4.2.1	Function	Assignment of a function to digital output 1 'Split value active': the active output indicates a current flow value in the 0 to 'Split value' range (not effective for PROFIBUS).	Pulse	<ul style="list-style-type: none"> Pulse, Frequency, Alarm, Flow direction forw. Flow min, Flow max, Flow min/max, Total. forw. max, Total. rev. min, Total. net max, Total. net min Split value active, No function
4.2.2	Signal Type	Definition of signal logic for active event	Passive-pos.	<ul style="list-style-type: none"> Active-pos., 1, 2 Active-neg., 1, 2 Passive-pos. Passive-neg.
4.2.3	Pulse Rate Engr. Unit Pulse Rate	Number of pulses per unit of quantity (only effective with "Pulse" function) Engineering unit of quantity to which the number of pulses refers Number of pulses per unit of quantity	DN1...12: Imp/l >DN12: Imp/m ³ Depending on the nominal width 10Imp/l... 1Imp/m ³	<ul style="list-style-type: none"> pulses/l, m³, MI, ft³, Gal, MGal, ImpGal, Mimp• Gal, kg, t, lb, 0.01 ... 9999 pulses/unit
4.2.4	Pulse Width	(only with "Pulse" function)	+0.1 ms	0.1 ... 2000 ms

4.2.5	Fullsc. Freq	Frequency output at full scale flow value at digital output 1 (only effective for "Frequency" function)	10000 Hz	2 ... 10000 Hz
4.3	Digit.Output2 ¹			
4.3.1	Function	Assignment of a function to digital output 2 'Split value active': the active output indicates a current flow value in the 0 to 'Split value' range (not effective for PROFIBUS).	Alarm	<ul style="list-style-type: none"> • Alarm, Flow dir. forw., • Flow min, Flow max, Flow min/max, • Total. forw. max, • Total. rev. max, • Total. net max, • Total. net min, • Split value active, • No function
4.3.2	Signal type	Definition of signal logic for active event	Contact closes	<ul style="list-style-type: none"> • Contact closes • Contact opens
4.3	Digit.input ²			
4.3.1	Function	Assignment of a function to the input: Measured value=0: Measured value is set to 0 (affects all outputs and totalizers) Totalizer reset: reset+start	Measured value = 0	<ul style="list-style-type: none"> • Meas. val. = 0, • Total. forw. reset, • Total. rev. reset, • Total. net reset, • Total. all reset, • No function
4.3.2	Signal Type	Definition of signal logic	High-active	<ul style="list-style-type: none"> • High-active, • Low-active

¹⁾ Parameters apply only to devices with 20 mA/Hart communication and digital output 2 (7ME5034-0xxxx)

²⁾ Parameters apply only to devices with 20 mA/Hart communication and digital input (7ME5034-2xxxx)

³⁾ Parameters apply only to devices with PROFIBUS communication (7ME5034-1xxxx)

Identification

Table A-5 Function group Identification parameters

5.1	Funct. Unit			
5.1.1	Tag	Tag number	(Customer-specific)	Text max.: <ul style="list-style-type: none"> • 32 characters 3 / • 8 characters 1,2
5.1.2	Descriptor	Tag descriptor	(Customer-specific) DN 2...12: l DN >12: m ³	Text max. <ul style="list-style-type: none"> • 32 characters 3 • 16 characters 1,2
5.1.3	Message	Tag message	(Customer-specific)	Text max. 32 characters
5.2	Manuf.Ident.			

5.2.1	Product type	Transmitter order number	(7ME5034-xxxx-xxA0)	
5.2.2	Serial number	Transmitter serial number	(N1xxxx-82xxxxx)	
5.2.3	Software Rev.	Software version in the transmitter	(3.x.x)	
5.2.4	Device ID	Clear device identification; corresponds to HART long address	(Device-specific HART long address)	1 ... 99 999 (Can only be set with factory code by HART)
5.2.5	Manuf. Date	Transmitter manufacture date; form: DDMMYY	(Device-specific manufacture date)	DDMMYY (Can only be set with factory code by HART)
5.2.6	Sensor	Input only possible if no data can be read from SmartPLUG		
5.2.6.1	Nom.Diameter ⁵ Diameter	Inside nominal diameter of the sensor with probes: interior diameter of the surrounding tube	(Nominal width) 0.1 m	DN2 ... 2000 / 0.5 ... 80 in, probe (Only after 'Probe' is selected:) 0,1 ... 5 m
5.2.6.2	Product Type ⁴	Sensor order number	(7ME5034-xxxx-xxA0)	From SmartPLUG
5.2.6.2	Analog TRANS-MAG ⁵	Select 'Yes' for measuring sensors with an R100 constant In this case, a CFH value must be entered in the 6.7.2 menu according to the following formula: $CFH = 176,715 * DN2/R100$, DN = nominal diameter in mm)	No	<ul style="list-style-type: none"> No Yes
5.2.6.3	Serial Number ⁴	Serial number of sensor	(Serial number)	From SmartPLUG

⁴⁾ Parameters apply only to devices with 20 mA/Hart communication and digital output 2 (7ME504x-0xxxx)

⁵⁾ Parameters apply only to devices with 20 mA/Hart communication and digital input (7ME504x-2xxxx)

Service

Table A-6 Function group Service parameters

6.1	Enter Code	Input of code number agreed under "Customer Code" (menu 6.2) for releasing local parameterization	0	0 ... 9999 (according to setting under menu 6.2)
6.2	Customer Code	Selection of personal code: <ul style="list-style-type: none"> Code 0: Parameters are not protected by a code. Code >0: Parameters can only be changed after entering the code under "Enter Code" (menu 6.1) 	0	0 ... 9999
6.3	Service Code	Input of factory code for extended service functions	0	0 ... 99999
6.4	Reset	Device reset (without parameter changes)	Cancel	<ul style="list-style-type: none"> Cancel Reset

Parameters

6.5	Control Values			
6.5.1	Volt. Um Volt. Uref	Control value for magnetic field current Control value for reference voltage		
6.5.2	Volt. Usig	Electrode differential voltage		
6.5.3	Volt. Uel1	Control value for voltage between electrode 1 and medium		
6.5.4	Volt. Uel2	Control value for voltage between electrode 2 and medium		
6.5.5	Flow % Range ^{1,2}	Actual flow in % of set full scale value		
6.5.6	Sampl. Frequ.	Actual measuring frequency	(Approx. 2 x magnetic frequency)	
6.5.7	Selftest 0 % FS	Display of internal control values of measuring electronics. Run self-test to update (menu 2.4.1) Zero Gain	(Result display of the last self-test) (xxxxxxx) (Current status active/inactive)	Triggered when selecting menu 2.4.1
6.5.8	Service Info	Coded service information	(Info)	
6.5.9	Digital Input ²	Status of the digital input under consideration of the set signal type	(Actual status active/inactive)	
6.6	Zero Trim			
6.6.1	Zero Flow Cor.	Correction value for the zero point of the flow measurement in m/s	-1 ... +1 m/s	
6.6.2	Start Correct.	Start of zero calibration; The medium must be at a standstill during calibration!	Cancel	<ul style="list-style-type: none"> • Cancel • Start
6.7	Trim Parameter	Values in 6.7.2.4 can only be written if no SmartPlug data can be read		
6.7.1	Cal.factor	User-specific calibration factor; the measured flow value is multiplied by this factor before output (affects all outputs, totalizers and display)	1.0	0.5 ... 1.5
6.7.2	CFH ⁵ CFR ⁵	Calibration value for hydraulic reference point at 1m/s Calibration value for reference path	400 100	
6.7.3	ZPH ⁵	Calibration value for hydraulic zero point	0	

6.7.4	Excitat.Freq. ⁵	<p>Magnetic current curve:</p> <ul style="list-style-type: none"> • Bipolar PP f/5: Standard applications • Bipolar f/3: rapid applications • Unipolar f/6: Measuring sensors \leqDN150 up to year of construction 1995 	Bipolar PP	<ul style="list-style-type: none"> • PP f/5 • Bipolar f/3, • Unipolar f/6
6.7.5	<p>EmptyTube Det.</p> <p>Act.Value EI¹</p> <p>Act.Value EI²</p> <p>Threshold</p>	<p>Adjustment of electrode immersion check</p> <p>Display of actual control value of electrode EI1 in % of end value</p> <p>Display of actual control value of electrode EI12 in % of end value</p> <p>Threshold of diagnostic function "Immersion check" for "Tube empty" message (see menu 2.3)</p>	33 %	5 ... 95 %

¹⁾ Parameters apply only to devices with 20 mA/Hart communication and digital output 2 (7ME5034-0xxxx)

²⁾ Parameters apply only to devices with 20 mA/Hart communication and digital input (7ME5034-2xxxx)

⁵⁾ Parameters apply only to devices with 20 mA/Hart communication and digital input (7ME504x-2xxxx)

Profibus Communication

B.1 PROFIBUS Communication

The following functions of the standard device (with 20 mA/HART interface) are not offered in the PROFIBUS version (7ME5034-1xxxx) because they are covered indirectly by the PROFIBUS function:

- Analog output (0/4 to 20mA)
- HART communication
- Digital output 2 (relay output)

Data transfer

The SITRANS F M TRANSMAG 2 has a PROFIBUS-PA connection compliant with IEC 1158 (synchronous transmission) which transfers data at a fixed speed of 31.25 kBit/s. The min. TSDR at startup is 11 bit times and can then be changed using the "Set_Prm" service. The bus address has the value 126 in the as-delivered state and can be changed either with the DP service "Set_Slave_Add" or on the local operating unit (menu 4.1.1).

Communication via PROFIBUS takes place with the EN50170 standard (PROFIBUS DP and DP V1).

The data traffic and the data formats are described in the following sections.

DP services

The following DP services are supported as slaves for a class 1 master:


- Data_Exchange
- Rd_Inp
- Rd_Outp
- Set_Prm
- Chk_Cfg
- Slave_Diag
- Set_Slave_Add
- Global_Control
- Get_Cfg

DP V1 services

The following DP V1 services are supported as slaves for a class 2 master DP V1 services supported as slaves:

- MSAC2_Initiate (Indication and Response)
- MSAC2_Abort (Request, Indication and Response)
- MSAC2_Read (Indication and Response)
- MSAC2_Write (Indication and Response)

B.2 Wiring devices with Profibus PA

 WARNING
Lid over terminals for power supply may not be removed! Use only certified measuring instruments!

The Profibus PA variant of the SITRANS F M TRANSMAG 2 differs from the HART variant with the 4-20 mA output in the bus interface and the omission of the digital output 2. The basic functions of the device including the operation and display remain basically the same.

The TRANSMAG 2 terminals 7 and 8 are reserved for the Profibus PA connection.

- 7: PA wire 1. This device is polarity independent
- 8: PA wire 2. This device is polarity independent

The PA interface is polarity independent, so the wires can be connected arbitrarily.

PA supports LINE, DROP, STAR topology and a combination of the three.




Figure B-1 PA wiring




Figure B-2 PA wiring with T-connector

Shielding

- Only use shielded cables for the PROFIBUS connection. Any connection polarity is possible.
- The shield must be laid to cover all assigned terminal boxes, distributors up to the coupler or link.
- The shield must be connected and fixed with the shield clamp.
- To achieve the best EMC performance, the unshielded wires should be as short as possible, 3-4 cm.

Note

The specified immunity and radiated emission are only guaranteed if the bus shielding is fully effective. This includes connecting the shields to the metal connections of TRANSMAG 2, but also laying the shields to the terminal compartment, distributor, DP/PA coupler or DP/PA link.

Terminators

To ensure trouble-free communication, the PROFIBUS must have a bus terminator at both ends. This is usually already provided by the coupler or link at the control system end. An additional bus terminator must be fitted at the remote bus end.

B.3 Cyclic Data Traffic

Cyclic data transmission serves for fast exchange of process data between a Master class 1 (control system or PLC) and the slave (SITRANS F M).

Up to four different measured values (= modules) can be transmitted cyclically from the device to the control system as input data in one telegram with the "Data_Exchange" service.

The following measured values are available for selection in the given order:

1. Flow (volume or mass flow)
2. Totalizer (volume or mass) net
3. Totalizer (volume or mass) forwards
4. Totalizer (volume or mass) reverse

The output data are sent to the device with the cyclic request telegram. The number and type of actually transferred data can be determined with the aid of the configuration data (see Device Database File (GSD) (Page 114))

Acyclic data traffic

Acyclic data transmission is mainly used for remote control of devices, i.e. for transmitting parameters during commissioning, maintenance, batch processes or for displaying variables which are not included in the cyclic process data traffic.

Acyclic accesses can be carried out by Master class 1 (C1 connection) or Master class 2 (C2 connection). SITRANS F M supports up to 4 simultaneous C2 connections.

The more than 300 parameters including address (Slot and Index), format, value range, start value and attributes are stored in an object list "Obj80C4.rtf" which will be provided on request.

Note

Acyclic operation with SIMATIC PDM

We recommend using the SIMATIC PDM software package and a PC (compatible with industry standard) or a programming unit for acyclic operation.

B.4 Input Data (from Slave to Master)

Input data are process data (measured values) which are transmitted from the device to the master in the following format:

Every measured value consists of 5 bytes which are composed of a floating point value corresponding with IEEE - 754 (4 bytes) and the correspondent measured value status (1 byte). In the PROFIBUS telegram, the measured value is transmitted first and then the corresponding status.

Table B-1 Measured value format

Byte No.	Bit							
	7 (MSB)	6	5	4	3	2	1	0 (LSB)
1	VZ	E 2^7	E 2^6	E 2^5	E 2^4	E 2^3	E 2^2	E 2^1
2	E 2^0	M 2^{-1}	M 2^{-2}	M 2^{-3}	M 2^{-4}	M 2^{-5}	M 2^{-6}	M 2^{-7}
3	M 2^{-8}	M 2^{-9}	M 2^{-10}	M 2^{-11}	M 2^{-12}	M 2^{-13}	M 2^{-14}	M 2^{-15}
4	M 2^{-9}	M 2^{-9}	M 2^{-9}	M 2^{-9}	M 2^{-9}	M 2^{-9}	M 2^{-9}	M 2^{-9}

VZ: sign: 0 positive, 1 negative E: Exponent M: Mantissa

B.5 Status bytes

Status bytes

The status bytes consist of three components:

- Quality (the MSBs 6 and 7):
Describes the basic quality of the corresponding measured value
- Substatus (bits 2 to 5):
Differentiates the quality of the corresponding measured value
- Limits (the LSBs 0 and 1):
Indicate exceeding of the limit value

Table B-2 Status byte formats

Byte	Bit							
No.	7 (MSB)	6	5	4	3	2	1	0 (LSB)
5	Quality		Substatus				Limits	

These components may adopt the following values in SITRANS F:

Table B-3 Formats of the quality bits

Bit 7	Bit 6	Profile Designation	Meaning
0	0	bad	Measured value cannot be used
0	1	uncertain	Measured value uncertain
1	0	good (not cascade)	Measured value OK

Table B-4 Formats of the substatus bits

Bit 5	Bit 4	Bit 3	Bit 2	Profile Designation	Meaning
0	0	0	1	configuration error	Parameter error, i.e. upper and lower value for measuring or output scale identical
0	0	1	1	device failure	RAM or EEPROM defective; Diagnostic bit "Memory error" is also set and the diagnosis message "RAM error" or "EEPROM error" displayed locally
				sensor failure	Measurement was not possible; Diagnostic bit "Memory error" is also set and the diagnosis message "Measuring path fault" displayed locally
0	1	1	1	out of service	Corresponding function block is in "Out of service" mode (see parameter "MODE_BLK actual")
0	0	0	0	non specific	Measurement contains too many implausible measured values, e.g. due to solids or gas bubbles in the medium. Diagnostic bit "Memory error" is also set and the diagnosis message "RAM error" or "EEPROM error" displayed locally
0	0	0	1	last usable value	Failsafe mode: the current measured value has been replaced with the last good measured value
0	0	1	0	substitute set	Failsafe mode: the current measured value has been replaced with the agreed failsafe value
0	1	0	0	initial value	Failsafe mode or state before the first measurement: the current measured value has been replaced with the start value
0	1	0	0	sensor conversion not accurate	Measured value is outside the sensor limits (Table 5-1, Page 30)
				O.K.	Measured value is OK (normal state)
0	0	0	1	update event	A parameter with the "static" memory attribute has been changed locally or on the PROFIBUS

B.5 Status bytes

Bit 5	Bit 4	Bit 3	Bit 2	Profile Designation	Meaning
0	0	1	0	active advisory alarm	Upper warning limit value has been exceeded or the lower warning limit value has been undershot below
0	0	1	1	active critical alarm	Upper alarm limit value has been exceeded or the lower alarm limit value has been undershot

Table B-5 Formats of the limit bits

Bit 1	Bit 0	Profile Designation	Meaning
0	0	O.K.	The measured value is within the limit values (normal state)
0	1	low limited	The measured value has exceeded the upper limit (alarm, warning or sensor limit)
1	0	high limited	The measured value has exceeded the upper limit value (alarm, warning or sensor limit)
1	1	constant	Measured value remains constant

Note

Limit bits can only be clearly evaluated in combination with the quality information!

Status byte combinations

The following combinations of the values of the status bytes described above are possible in normal operation (i.e. when the input value of the function block concerned incl. status is not simulated:

Table B-6 Valid combinations of the status byte

Value hex	Meaning substatus		applies to				
	quality		limits	flow	total net	total	total
1F	bad	out of service	constant	X			
0F	bad	device failure	constant	X			
0C	bad	device failure	O.K.		X	X	X
11	bad	sensor not connected	constant		X	X	X
07	bad	configuration error	constant	X	X	X	X
00	bad	non specific	O.K	X	X	X	X
52	uncertain	sensor conversion not accurate	high limited	X	X	X	X
51	uncertain	sensor conversion not accurate	low limited	X	X	X	X
4F	uncertain	initial value	constant	X			
4B	uncertain	substitute set	constant	X			
47	uncertain	last usable value	constant	X			
8E	good	active critical alarm	High limited	X	X	X	X
8D	good	active critical alarm	low limited	X	X	X	X

Value hex	Meaning substatus		applies to				
	quality		limits	flow	total net	total	total
8A	good	active advisory alarm	high limited	X	X	X	X
89	good	active advisory alarm	low limited	X	X	X	X
84	good	active update event	O.K.	X	X	X	X
80	good	O.K.	O.K.	X	X	X	X

Note

The status conditions have decreasing priority from top to bottom. If several status conditions are fulfilled, the current status with the highest priority will be signaled.

B.6 Output Data (from Master to Slave)

The output data consist per totalizer (net, forwards and reverse) of one byte of which only the two LSBs respectively are evaluated. All other bits are not evaluated but should be set to 0 for safety. This value represents the "SET_TOT" parameter of the "Totalizer Function Block" defined in the PROFIBUS-PA profile.

Table B-7 Totalizer mode "SET_TOT"

Bit 1	Bit 0	Profile description	Meaning
0	0	cancel	totalizer is running
0	1	reset	totalizer is stopped and reset to 0
1	0	preset	Totalizer is stopped and reset to a preset value (PRE-SET_TOT parameter, only acyclic access)

The transferred value is effective until it is changed, i.e. after the value 1 (reset totalizer) is sent, for example, the totalizer will remain on the value 0 until the SET_TOT parameter is changed again.

Each SET_TOT value affects the corresponding totalizer independently of the others. The quantities are also cumulated independently of each other, i.e. the net quantity does not have to be equal to the sum of the quantity forwards and quantity reverse especially if a totalizer has been reset or was preset.

B.7 Diagnostics

The diagnostic data can be requested with the "Slave_Diag" service.

B.7 Diagnostics

If extended diagnostic messages (Ext_Diag_Data) exist, this is displayed by the "Diag_Flag" of the "Data_Exchange" service. If the master then calls the "Slave_Diag" service, the external diagnostic data are supplied in the following form by the device:

Table B-8 Format of diagnostic data

Byte No.	Profile designation	Value	Meaning
1	Header	8 (dec.)	(fixed) length of diagnostic data (number of bytes)
2		254 (dec.)	(fixed)
3		1	(fixed)
4		0 or 1	Display of changes in diagnostic data (see below)
5	Diagnosis	Byte 1	(s. below) Diagnostic information
6		Byte 2	-- (not supported)
7		Byte 3	-- (reserved)
8		Byte 4	(s. below) Note on additional diagnostic data

The total length of the external diagnostic data is always 8 including the header.

The "Diag_Flag" is always set when something has changed in the last four bytes of the diagnostic data (corresponds to the parameter "DIAGNOSIS") since the last message, i.e. even when diagnostic messages disappear again so that the master can register every change in the diagnostic data.

When a diagnostic message is active, the corresponding bit is set otherwise reset.

The following bits of the external diagnostic data are supported by SITRANS F M (all other bits stay reset at all times):

Table B-9 Format of the diagnostic data, byte 4

Bit No.	Description	Meaning
0	Error appears	At least one bit of the following 4 bytes (DIAGNOSIS) was set
1	Reset	At least one bit of the following 4 bytes (DIAGNOSIS) was reset
2 ... 7	Reserved	---

The "Error appears" message has priority over the "Error disappears" message, i.e. if one diagnostic bit is set and another reset simultaneously, "Error appears" is reported.

The DIAGNOSIS part contains diagnostic messages of the device and has the following structure (Bit 0 = LSB, Bit 7 = MSB):

Table B-10 Format of the diagnostic data, Byte 5 (=DIAGNOSIS Byte 1)

Bit No.	Description	Meaning	Cause (local message)
0	DIA_HW_ELETR	Hardware failure of the electronic	"Com.--Module failure"
			Communications module cannot be addressed
			Sensor failure (sensor failure)
			"Measurement module failure"
4	DIA_MEM_CHKSUM	Memory error	Memory failure"

Bit No.	Description	Meaning	Cause (local message)
5	DIA_MEASUREMENT	Measurement failure	Flow measurement failure" "Tube empty" "Measuring range overflow"

Table B-11 Format of diagnostic data, Byte 8 (=DIAGNOSIS Byte 4)

Bit No.	Description	Meaning	Cause (local message)
0 ... 6	reserved	---	
7	EXTENSION_AVAILABLE	More diagnosis information is available	More diagnosis information available (here: Local messages see DIAGNOSIS--Byte 1)

The bits in DIAGNOSIS usually take over the function of a group message which can then be split up in detail using the local messages.

The EXTENSION_AVAILABLE bits indicates that other diagnostic information is available, basically details of the DIAGNOSIS message. This information is displayed locally.

Additionally, the measured value-related messages are transmitted cyclically with the measured values in the status byte (Substatus).

Examples for telegrams with diagnostic data (Ext_Diag_Data)

All diagnostic bits are reset in the initial state. When the "Tube empty" event occurs (byte 5, bit 5 set), this gives the following diagnostic data:

Diagnosis Byte No.	1	2	3	4	5	6	7	8
Value (hex)	08	FE	01	01	20	00	00	80
Meaning	Header					Diagnosis		

Initial state: all diagnostic bits are reset. With the occurrence of the events "Memory failure" (byte 5, bit4) and "Flow outside sensor limits" (byte 5, bit 5), this gives the following diagnostic data:

Diagnosis Byte No.	1	2	3	4	5	6	7	8
Value (hex)	08	FE	01	01	30	00	00	80
Meaning	Header					Diagnosis		

Initial state: at least one diagnostic bit is set. As soon as all diagnostic messages are reset, the following diagnostic data result:

Diagnosis Byte No.	1	2	3	4	5	6	7	8
Value (hex)	08	FE	01	02	00	00	00	80
Meaning	Header					Diagnosis		

B.8 Write Protection

General write protection can be enabled with the WRITE_LOCKING PROFIBUS parameter. This will then prevent any changes being made to parameters locally or using PROFIBUS.

- 0: General write protection enabled: Parameters cannot be edited. Exception: Output data for totalizers (set, start) when they are transmitted cyclically (with the data exchange service).
This write protection can be disabled locally by entering the code "2457" (menu 6.1), when there is a continued communication failure.
- >0: General write protection disabled

Note

Parameter consistency between the device and control system is decisive for the correct interpretation of the cyclical measured values. During operation the local write protection (menu 6.2) or WRITE_LOCKING should therefore be enabled.

Hardware Write Protection

If write protection with hardware components is not set, the HW_WRITE_PROTECTION PROFIBUS parameter will not be of any significance.

Calibration data

Access to calibration data and special service parameters can only be enabled by entering a factory code. Improper changes to these data can cause the device to seriously malfunction.

Locking local operation

Local operation can be locked using the LOCAL_OP_ENABLE PROFIBUS parameter:

- 0: Local operation is disabled completely and the last valid display status remains. If communication fails for longer than 30 s, the local lock will be disabled automatically until communication is restored.
- 1: Local operation is enabled and if necessary limited with the WRITE_LOCKING write protection or a customer code.

B.9 Device Database File (GSD)

The device database file (GSD) is used to configure the format and order of the cyclic data. The acyclic parameter "IDENT_NUMBER_SELECTOR" must be set to select the GSD (0 = profile GSD, 1 = manufacturer-specific GSD = factory setting). This can also be done on the local operating unit under menu item 4.1.2.

The GSD lists all permissible identifiers for every measured value (= module). They can be freely combined with the restriction that only one identifier may be used per module and the order of the identifiers must be the same as the order of modules. At least one measured value must be requested, i.e. the number of identifiers must be at least 1 and 4 at the most.

The formats "resettable quantity" and "quantity" are accepted for the totalizer modules. The identifiers are checked independently of each other, i.e. when polling several measured values, combinations with different formats are permissible.

The order of measured values specified in the GSD is defined in the cyclic telegram and cannot be changed (see also section 5.4.1). If one of the four measured values is omitted, "Free Place" must be specified as an identifier.

Rules are stored in the GSD for use in the "SIMATIC S7/HW-Config" control system which prevent wrong configuration.

Note

As an alternative to the device-specific GSD, standard GSD for magnetic-inductive flow transmitters described in profile 3.0 can also be used, but does not support the manufacturer-specific extensions.

Example

The measured values "Totalizer net" and "Totalizer forwards" should be transmitted. Then the following identifier combination must be specified:

- Free Place (for flow)
- long Identifier (for totalizer net)
- long Identifier (for totalizer forwards)

No identifier for the totalizer reverse is necessary here because the value of the totalizer forwards is the last measured value to be transmitted.

The following files (GSD and bitmap) can be downloaded from the internet using the address http://www.ad.siemens.de/csi_e/gsd

These files are also implemented in the device install files for SIMATIC PDM software.

GSD files (version 31.07.2001)

```
#Profibus_DP
GSD_Revision = 3
Vendor_Name = "SIEMENS AG"
Model_Name = "SITRANS FM"
Revision = "Revision 01"
Ident_Number = 0x80C4
Protocol_Ident = 0
Station_Type = 0
FMS_supp = 0
Hardware_Release = "A01"
Software_Release = "Z01"
```

```
Bitmap_Device = "SIE80C4n"
31.25_supp = 1
45.45_supp = 1
93.75_supp = 1
MaxTsdR_31.25 = 100
MaxTsdR_45.45 = 250
MaxTsdR_93.75 = 1000
Redundancy = 0
Repeater_Ctrl_Sig = 0
24V_Pins = 0
Freeze_Mode_supp = 0
Sync_Mode_supp = 0
Auto_Baud_supp = 0
Set_Slave_Add_supp = 1
Min_Slave_Intervall = 200
Modular_Station = 1
Max_Module = 4
Max_Input_Len = 20
Max_Output_Len = 3
Max_Data_Len = 23
Fail_Safe = 0
Slave_Family = 12
Max_Diag_Data_Len = 20
;----- Description of device related diagnosis: -----
;
Unit_Diag_Bit(16) = "Error appears"
Unit_Diag_Bit(17) = "Error disappears"
Unit_Diag_Bit(24) = "Hardware failure electronics"
Unit_Diag_Bit(25) = "Hardware failure mechanics"
Unit_Diag_Bit(26) = "Motor temperature too high"
Unit_Diag_Bit(27) = "Electronic temperature too high"
Unit_Diag_Bit(28) = "Memory error"
Unit_Diag_Bit(29) = "Measurement failure"
Unit_Diag_Bit(30) = "Device not initialized"
Unit_Diag_Bit(31) = "Device initialization failed"
```

```
Unit_Diag_Bit(32) = "Zero point error"
Unit_Diag_Bit(33) = "Power supply failed"
Unit_Diag_Bit(34) = "Configuration invalid"
Unit_Diag_Bit(35) = "Restart"
Unit_Diag_Bit(36) = "Coldstart"
Unit_Diag_Bit(37) = "Maintenance required"
Unit_Diag_Bit(38) = "Characteristics invalid"
Unit_Diag_Bit(39) = "Ident_Number violation"
Unit_Diag_Bit(55) = "Extension Available"
User_Prm_Data_Len = 0
;===== Description of modules =====
;
; Use always the module order specified in this file.
; Use exactly one identifier per module.
; If you don't want to get the measuring value of a certain module ; from the device with the
input data, use Free place for this module ; instead of another identifier.
;
; For the module 1 you have the choice between these different ; identifiers:
;
; - Free Place
; - Short identifier format (identifier byte)
; - Long identifier format (extended identifier)
;
; For the modules 2, 3 and 4 you have the choice between these ; different identifiers:
;
; - Free Place
; - Long identifier format (extended identifier)
; - Long identifier format, resettable (extended identifier)
;
; With the "resettable" format it is possible to reset the totalizer,
; transmitting suitable output data to the device.
;-----
; Free place - usable for each module instead of another identifier
;-----
Module = "Free place" 0x00
```

```
0
EndModule
;-----
; Module 1 - Flow
;-----
Module = "Flow" 0x94
1
EndModule
;-----
; Module 2 - Quantity net
;-----
Module = "Quantity net" 0x41, 0x84, 0x85
2
EndModule
Module = "Resettable quantity net" 0xC1, 0x80, 0x84, 0x85
3
EndModule
;-----
; Module 3 - Quantity forward
;-----
Module = "Quantity forward" 0x41, 0x84, 0x85
4
EndModule
Module = "Resettable quant. forw." 0xC1, 0x80, 0x84, 0x85
5
EndModule
;-----
; Module 4 - Quantity reverse
;-----
Module = "Quantity reverse" 0x41, 0x84, 0x85
6
EndModule
Module = "Resettable quant. rev." 0xC1, 0x80, 0x84, 0x85
7
EndModule
```

```
;-----  
;SlotDefinition  
;-----  
SlotDefinition  
Slot(1) = "Flow" 1 0,1 ;Default am zykl. Verkehr  
Slot(2) = "Quantity net" 2 0,2,3 ;Default am zykl. Verkehr  
Slot(3) = "Quantity forward" 0 0,4,5 ;Default nicht am zykl. Verkehr  
Slot(4) = "Quantity reverse" 0 0,6,7 ; Default nicht am zykl. Verkehr EndSlotDefinition
```

GSD: Device database file
LSB: Least significant Bit
MSB: Most Significant Bit
PDM: Process Device Manager
PNO: PROFIBUS user organization
PROFIBUS PA: Process Fieldbus for Process Automation

Product documentation and support

C.1 Product documentation

Process instrumentation product documentation is available in the following formats:

- Certificates (<http://www.siemens.com/processinstrumentation/certificates>)
- Downloads (firmware, EDDs, software) (<http://www.siemens.com/processinstrumentation/downloads>)
- Catalog and catalog sheets (<http://www.siemens.com/processinstrumentation/catalogs>)
- Manuals (<http://www.siemens.com/processinstrumentation/documentation>)
You have the option to show, open, save, or configure the manual.
 - "Display": Open the manual in HTML5 format
 - "Configure": Register and configure the documentation specific to your plant
 - "Download": Open or save the manual in PDF format
 - "Download as html5, only PC": Open or save the manual in the HTML5 view on your PC

You can also find manuals with the Mobile app at Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/sc/2067>). Download the app to your mobile device and scan the device QR code.

Product documentation by serial number

Using the PIA Life Cycle Portal, you can access the serial number-specific product information including technical specifications, spare parts, calibration data, or factory certificates.

Entering a serial number

1. Open the PIA Life Cycle Portal (<https://www.pia-portal.automation.siemens.com>).
2. Select the desired language.
3. Enter the serial number of your device. The product documentation relevant for your device is displayed and can be downloaded.

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

Scanning a QR code

1. Scan the QR code on your device with a mobile device.
2. Click "PIA Portal".

To display factory certificates, if available, log in to the PIA Life Cycle Portal using your login or register.

C.2 Technical support

Technical support

If this documentation does not completely answer your technical questions, you can enter a Support Request (<http://www.siemens.com/automation/support-request>).

Additional information on our technical support can be found at Technical Support (<http://www.siemens.com/automation/csi/service>).

Service & support on the Internet

In addition to our technical support, Siemens offers comprehensive online services at Service & Support (<http://www.siemens.com/automation/serviceandsupport>).

Contact

If you have further questions about the device, contact your local Siemens representative at Personal Contact (<http://www.automation.siemens.com/partner>).

To find the contact for your product, go to "all products and branches" and select "Products & Services > Industrial automation > Process instrumentation".

Contact address for business unit:

Siemens AG
Digital Industries
Process Automation
Östliche Rheinbrückenstr. 50
76187 Karlsruhe, Germany

Index

A

Abrasive liquids, 22, 29
Acyclic data transmission, 107
Analog output, 64
Analog Output, 54
Applications, 15

B

Bus communication solutions, 16

C

Cable specifications, 34
 Remote version, 38
Calibration factor, 74
Catalog
 catalog sheets, 121
Cathodic protection, 27
Certificates, 121
Cleaning, 77
Commissioning, 41
Commissioning
 Safety, 41
Compliance, (See Laws and directives)
Control values, 74
Current limiting, 64
Customer code, 73
Customer Support, (Refer to Technical support)
Cyclic data transmission, 107

D

Density, 59
Design, 87
Device database file (GSD), (See Device database file (GSD))
Device status, 54
Device test, 56
Digital input, 71
Digital output 1, 68
Digital output 2, 69
Dimensions, 89

Direction

 Flow, 59
 Measurement, 59
Display, 53
Disposal, 78
Downloads, 121

E

Electrical connection
 Cable specifications, 34
 Connection diagram, 36
 HART, 37
 Power supply, 35
 Profibus, 106
 Remote version, 37
 Resistance check, 79
 Safety, 33
 Signal cables, 36
Electrode check, 55
Electrode circuit, 79
EMC performance, 107
Empty pipe detection, 22
Empty Pipe Detection, 55
Engineering unit, 45, 57
Enter Code, 73
Error messages, 55, 82

F

Failure signal, 65
Features, 15
Filter time constant, 60
Flow, 53
Flow Upper Range Value, 57
Flow velocity, 54
Frequency, 54
Function group
 Analog output, 64
 Device outputs, 98
 Diagnostics, 54, 94
 Display, 93
 Flow, 57
 Identification, 71, 100
 Measuring functions, 96
 Service, 73, 101
Function Group
 Display, 53

G

Gas / Air bubbles, 22
grounding rings, 28
GSD, 114

H

HART, 16
 System integration, 43
Hazardous area
 Qualified personnel, 13
Horizontal Pipes, 22
Hotline, (Refer to Support request)
Hysteresis, 58, 59

I

Illumination, 44
Immersion check, 75
Inlet / outlet conditions, 20
Input, 86
Installation
 Horizontal Pipes, 22
 in U-tube, 20
 Indoor/outdoor, 19
 Location in system, 19
 Mounting of sensor, 24
 Pipe mounting, 31
 Pipes with free outlet, 20
 Safety instructions, 19
 Vertical pipes, 22
Items supplied, 8

L

Language, 44
Laws and directives, 11
Limits, 58
Liner
 Protectors, 23
Local display, 42, 87
 Turn, 32
Low flow cut-off, 60

M

Maintenance, 77
Manuals, 121

Manufacturer data, 72
Material compatibility, 12
Measurement principle, 17
Measuring accuracy, 85
Menu structure, 53
Modifications
 correct usage, 12
 improper, 12
Mounting, (See Installation)
Multi display, 53

N

Noise Suppress, 61
Nominal width, 73

O

Operating conditions, 87
Operating principle, 18
Operation, 42
 Mode, 85
 Operating examples, 45
 Via bus communication, 43
 Via local display, 42
Output, 86
Output data, 111

P

Parameters, (See Function group)
Potential equalization, 27
Power supply, 88
Pressure
 Safety instructions, 19
Profibus, 105
 Bus address, 67
 Data transfer, 105
 Data transfer (acyclic), 107
 Data transfer (cyclic), 107
 Diagnostics, 111
 Electrical connection, 106
 GSD, 67
 Identity number, 67
 Input data, 108
 Menu item 4.1, 66
 System integration, 43
Profibus PA, 16
Pulse rate, 46, 69
Pulse width, 69

Q

Qualified personnel, 13

R

Reference conditions, 85
Repair, 77
Reset, 73
Resistance, 79
Return procedure, 77

S

Safety, 11
 Instrument safety standards, 11
 Sensor installation, 19
Scope of delivery, 8
Sensor (911/E), 15
Sensor orientation, 22
Service, 77, 122
Service and support
 Internet, 122
Service code, 73
Simulation flow, 56
Simulation outputs, 56
Slurry mode, 61
SmartPLUG, 15, 41
Split mode, 65
Status byte combinations, 110
Status bytes, 108
Support, 122
Support request, 122

T

Tag data, 41, 71
Technical data, 85
Technical support, 122
 partner, 122
 personal contact, 122
Theory of operation, 17
Totalizer forwards, 62
Totalizer mode "SET_TOT", 111
Totalizer net, 63
Totalizer reverse, 63
Totalizers, 54
Troubleshooting, 79, 80

U

URV, (See Flow Upper Range Value)

V

Vertical Pipes, 22
Vibrations, 25

W

Warranty, 9
Wiring, (See Electrical connection)
Write protection, 44

Z

Zero flow correction, 74
Zero Trim, 74

