

SIEMENS

Ingenuity for life

24/7

NEWS

Industry Online Support

Home

Support Packages for TIA Portal V14

May 2019

<https://support.industry.siemens.com/cs/ww/EN/view/72341852>

Siemens
Industry
Online
Support



This entry is from the Siemens Industry Online Support. The general terms of use (http://www.siemens.com/terms_of_use) apply.

Security information

Security information

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions only form one element of such a concept. Customer is responsible to prevent unauthorized access to its plants, systems, machines and networks. Systems, machines and components should only be connected to the enterprise network or the internet if and to the extent necessary and with appropriate security measures (e.g. use of firewalls and network segmentation) in place. Additionally, Siemens' guidance on appropriate security measures should be taken into account. For more information about industrial security, please visit <http://www.siemens.com/industrialsecurity>. Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends to apply product updates as soon as available and to always use the latest product versions. Use of product versions that are no longer supported, and failure to apply latest updates may increase customer's exposure to cyber threats. To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under <http://www.siemens.com/industrialsecurity>.

Table of contents

1	Support Packages for STEP 7	4
1.1	Support Packages for STEP 7 Basic or Professional V14	4
1.1.1	HSP 0114	4
1.1.2	HSP 0132 V2.0.....	4
1.1.3	HSP 0135	4
1.1.4	HSP 0169 V1.0.....	4
1.1.5	HSP 0181	5
1.1.6	HSP 0186	5
1.1.7	HSP 0187	5
1.1.8	HSP 0192	5
1.1.9	HSP 0193	5
1.1.10	HSP 0194	5
1.1.11	HSP 0195	6
1.1.12	HSP 0197 – for usage with V14 SP1 Update 2 of V14 SP1 is required!	6
1.1.13	HSP 0199	6
1.1.14	HSP 0205	6
1.1.15	HSP 0220	6
1.1.16	HSP 0222	6
1.1.17	HSP 0223	7
1.1.18	HSP 0239	7
1.1.19	HSP 0240	7
1.1.20	HSP 0241 V2.0.....	7
1.2	Support Packages for STEP 7 Professional V14	8
1.2.1	HSP 0108	8
1.2.2	HSP 0185 V1.0.....	8
1.2.3	HSP 0190	8
1.2.4	HSP 0209	8
1.2.5	HSP 0221	9
1.3	Support Packages for STEP 7 Basic or Professional V14 SP1	10
1.3.1	HSP 0103 V2.0.....	10
1.3.2	HSP 0113 V2.0.....	10
1.3.3	HSP 0134	10
1.3.4	HSP 0135 V4.0.....	10
1.3.5	HSP 0169 V2.0.....	10
1.3.6	HSP 0214	11
1.3.7	HSP 0224	11
1.3.8	HSP 0227	11
1.3.9	HSP 0234	11
1.4	Support Packages for STEP 7 Professional V14 SP1	12
1.4.1	HSP 0185 V3.0.....	12
2	Support Packages for WinCC.....	13
2.1	Support Packages for WinCC V14 SP1	13
2.1.1	HSP 0116 V2.0.....	13
2.1.2	New: HSP 0207	13
2.1.3	HSP 0211	13
2.1.4	HSP 0212	13
2.1.5	HSP 0226	13
3	Support Packages for STEP 7 Safety	14
3.1	Support Packages for STEP 7 Safety Basic or Advanced V14	14
3.1.1	HSP 0202	14
3.1.2	HSP 0210	14

1 Support Packages for STEP 7

1.1 Support Packages for STEP 7 Basic or Professional V14

You can use these HSP with STEP 7 Basic V14 and STEP 7 Professional V14.
At least STEP 7 Basic V14 or STEP 7 Professional V14 is required.

1.1.1 HSP 0114

is necessary for these devices:

SIPLUS HCS4300

- 6BK1943-1AA00-0AA0
- 6BK1943-2AA00-0AA0

1.1.2 HSP 0132 V2.0

is necessary for these devices:

SIRIUS ACT with PROFINET

- 3SU1400-1LK10-. BA1
- 3SU1400-1LL10-. AA1
- 3SU1400-1MA10-1BA1
- 3SU1401-1MC.0-1CA1
- 3SU1401-1ME.0-1DA1

1.1.3 HSP 0135

is necessary for these devices:

SIPLUS HCS4200

- 6BK1942-1AA00-0AA.
- 6BK1942-2AA00-0AA.

1.1.4 HSP 0169 V1.0

is necessary for these devices:

SENTRON PAC / 3VA2

- 7KM211.-.BA00-.AA0; 7KM421.-.B.00-.AA0
- 3VA2...-.JP...-.....; 3VA2...-.JQ...-.....; 3VA2...-.KP...-.....; 3VA2...-.KQ...-.....
- 3VA2...-.MQ...-.....
- 3VA9987-0TA10; 3VA9987-0TA20
- 7KM9300-0AE01-0AA0; 7KM9300-0AB01-0AA0

1.1.5 HSP 0181

is necessary for this module:

SIMATIC S7-1500 PTO Module

- 6ES7553-1AA00-0AB0

1.1.6 HSP 0186

is necessary for these modules:

SIMATIC S7-1500 analogue modules

- 6ES7531-7NF10-0AB0 – FW V2.1
- 6ES7532-5HF00-0AB0 – FW V2.1
- 6ES7531-7NF00-0AB0 – FW V1.1
- 6ES7531-7PF00-0AB0 – FW V1.1
- 6ES7532-5ND00-0AB0 – FW V1.1

1.1.7 HSP 0187

is necessary for this module:

SIMATIC ET 200MP Interface module 155-5 PN BA for FW-Version 4.0

- 6ES7155-5AA00-0AA0

1.1.8 HSP 0192

is necessary for this device:

SIMATIC NET IE/PB LINK PN IO for FW-Version 3.0

- 6GK1411-5AB10

1.1.9 HSP 0193

is necessary for this device:

SIMATIC ET 200Pro IO-Link HF

- 6ES7147-4JD00-0AB0

1.1.10 HSP 0194

is necessary for these modules:

SIMATIC ET 200AL

- 6ES7143-5AH00-0BA0
- 6ES7145-5ND00-0BA0

1.1.11 HSP 0195

is necessary for these devices:

SIMATIC ET 200SP Motor starter

- 3RK1308-0AB00-0CP0; 3RK1308-0AC00-0CP0; 3RK1308-0AD00-0CP0
- 3RK1308-0BB00-0CP0; 3RK1308-0BC00-0CP0; 3RK1308-0BD00-0CP0
- 3RK1308-0CB00-0CP0; 3RK1308-0CC00-0CP0; 3RK1308-0CD00-0CP0
- 3RK1308-0CE00-0CP0
- 3RK1308-0DB00-0CP0; 3RK1308-0DC00-0CP0; 3RK1308-0DD00-0CP0
- 3RK1308-0DE00-0CP0

1.1.12 HSP 0197 – for usage with V14 SP1 Update 2 of V14 SP1 is required!

NOTE For HSP0197 STEP 7 V14 is required. For usage with **V14 SP1** Update 2 of **V14 SP 1** is required!

is necessary for this device:

SIMATIC PN/CAN LINK

- 6BK1620-0AA00-0AA0

1.1.13 HSP 0199

is necessary for this module:

SIMATIC ET 200SP TM Count 24V for FW-Version 1.2

- 6ES7138-6AA00-0BA0

1.1.14 HSP 0205

is necessary for this module:

SIMATIC ET 200SP IM 155-6PN Standard

- 6ES7155-6AU01-0BN0

1.1.15 HSP 0220

is necessary for these modules:

SIMATIC S7-1500 Analog Module for FW-Version 2.1

- 6ES7531-7KF00-0AB0
- 6ES7532-5HD00-0AB0

1.1.16 HSP 0222

is necessary for these modules:

SIMATIC ET 200SP Digital modules

- 6ES7131-6BF01-0AA0; 6ES7131-6BF01-0BA0; 6ES7131-6BF61-0AA0
- 6ES7131-6BH01-0BA0; 6ES7131-6FD01-0BB1
- 6ES7132-6BF01-0AA0; 6ES7132-6BF01-0BA0; 6ES7132-6BF61-0AA0
- 6ES7132-6BH01-0BA0; 6ES7132-6GD51-0BA0; 6ES7132-6HD01-0BB1

1.1.17 HSP 0223

is necessary for this module:

SIMATIC ET 200MP IM155-5PN Standard for FW-Version 4.1

- 6ES7155-5AA01-0AB0

1.1.18 HSP 0239

is necessary for these modules:

SIMATIC ET 200SP Analog modules for FW-Version 2.0

- 6ES7134-6GD01-0BA1
- 6ES7134-6HD01-0BA1

1.1.19 HSP 0240

is necessary for these modules:

SIMATIC ET 200SP Digital modules

- 6ES7132-6FD00-0CU0
- 6ES7132-6BH00-0AA0

1.1.20 HSP 0241 V2.0

is necessary for these modules:

SIMATIC ET 200SP Potential distributor modules

- 6ES7193-6TP00-0TP1
- 6ES7193-6TP00-0TP2
- 6ES7193-6TP00-0TN0
- 6ES7193-6TP00-0TP0

1.2 Support Packages for STEP 7 Professional V14

You can use these HSP with STEP 7 Professional V14. **At least** STEP 7 Professional V14 is required.

1.2.1 HSP 0108

is necessary for these modules:

SIMATIC S7-41x PLC >= FW-Version 7.0

- 6ES7412-1XJ07-0AB0; 6ES7412-2XK07-0AB0
- 6ES7414-2XL07-0AB0; 6ES7414-3XM07-0AB0
- 6ES7416-2XP07-0AB0; 6ES7416-2FP07-0AB0; 6ES7416-3XS07-0AB0

1.2.2 HSP 0185 V1.0

is necessary for these devices:

SINAMICS V90 PROFINET

- 6SL3210-5FB10-1UF0; 6SL3210-5FB10-2UF0; 6SL3210-5FB10-4UF1
- 6SL3210-5FB10-8UF0; 6SL3210-5FB11-0UF1; 6SL3210-5FB11-5UF0
- 6SL3210-5FB12-0UF0
- 6SL3210-5FE10-4UF0; 6SL3210-5FE10-8UF0; 6SL3210-5FE11-0UF0;
- 6SL3210-5FE11-5UF0; 6SL3210-5FE12-0UF0; 6SL3210-5FE13-5UF0
- 6SL3210-5FE15-0UF0; 6SL3210-5FE17-0UF0

1.2.3 HSP 0190

is necessary for these devices:

SIMATIC IPC

- 6AG4141-..
- 6AV7241-.B.. ; 6AV7241-.D.. ; 6AV7241-.E..
- 6AV7241-.J.. ; 6AV7241-.K.. ; 6AV7241-.L..

1.2.4 HSP 0209

is necessary for these devices:

Extension Units PROFINET for SIMATIC HMI PRO devices

- 6AV7674-1LA32-0AA0
- 6AV7674-1LA42-0AA0
- 6AV7674-1LA52-0AA0
- 6AV7674-1LA62-0AA0

1.2.5 HSP 0221

is necessary for these modules:

SIMATIC Communication modules, KP12 module and RGB Button for Extension Units Advanced

- 6AV2185-8AT10-0AA0; 6AV2185-8AT20-0AA0;
- 6AV2185-8AB01-2AA0; 6AV2185-8AB02-2AA0

Usage with these Extension Units Advanced:

- 6AV2185-8CE01-0AA0; 6AV2185-8CE08-0AA0; 6AV2185-8CF01-0AA0;
- 6AV2185-8DE01-0AA0; 6AV2185-8DE08-0AA0; 6AV2185-8DF01-0AA0;
- 6AV2185-8EE01-0AA0; 6AV2185-8EE08-0AA0; 6AV2185-8EF01-0AA0;
- 6AV2185-8FE01-0AA0; 6AV2185-8FE08-0AA0; 6AV2185-8FF01-0AA0;

1.3 Support Packages for STEP 7 Basic or Professional V14 SP1

You can use these HSP with STEP 7 Basic V14 **SP1** and STEP 7 Professional V14 **SP1**. **At least** STEP 7 Basic V14 **SP1** or STEP 7 Professional V14 **SP1** is required.

1.3.1 HSP 0103 V2.0

is necessary for these devices:

SITOP PSU 8600 – FW V1.4

- 6EP3436-8MB00-2CY0; 6EP3436-8SB00-2AY0
- 6EP3437-8MB00-2CY0; 6EP3437-8SB00-2AY0
- 6EP4143-8JB00-0XY0; 6EP4145-8GB00-0XY0; 6EP4197-8AB00-0XY0
- 6EP4293-8HB00-0XY0; 6EP4295-8HB00-0XY0;
- 6EP4297-8HB00-0XY0; 6EP4297-8HB10-0XY0
- 6EP4436-8XB00-0DY0; 6EP4436-8XB00-0CY0
- 6EP4437-8XB00-0CY0

1.3.2 HSP 0113 V2.0

is necessary for this module:

SIPLUS CMS1200 SM1281

- 6AT8007-1AA10-0AA0

1.3.3 HSP 0134

is necessary for this module:

SIMATIC ET 200PRO frequency converter FC-2 – FW V4.7

- 6SL3514-1KE13-5AE0

1.3.4 HSP 0135 V4.0

is necessary for these devices:

SIPLUS HCS4200

- 6BK1942-1AA00-0AA; 6BK1942-2AA00-0AA

1.3.5 HSP 0169 V2.0

is necessary for these devices:

SENTRON PAC / 3VA2 / 3VA6

- 7KM211.-.BA00-.AA0; 7KM421.-.B.00-.AA0
- 3VA2...-.JP...-.; 3VA2...-.JQ...-.; 3VA2...-.KP...-.; 3VA2...-.KQ...-.;
- 3VA2...-.MQ...-.;
- 3VA6...-.JP...-.; 3VA6...-.JT...-.; 3VA6...-.KL...-.; 3VA6...-.KM...-.;
- 3VA6...-.KP...-.; 3VA6...-.KQ...-.; 3VA6...-.KT...-.;
- 3VA6...-.MQ...-.;

- 3VA9987-0TA10; 3VA9987-0TA20
- 7KM9300-0AE01-0AA0; 7KM9300-0AB01-0AA0

1.3.6 HSP 0214

is necessary for this module:

SIMATIC PN/BACnet LINK

- 6BK1621-0AA00-0AA0

1.3.7 HSP 0224

is necessary for this module:

SIMATIC ET 200SP AI HS

- 7MH4134-6LB00-0DA0

1.3.8 HSP 0227

is necessary for this module:

SIMATIC ET 200 PRO IM154-3 PN HF for FW-Version 7.1

- 6ES7154-3AB00-0AB0

1.3.9 HSP 0234

is necessary for this module:

SIMATIC ET 200SP TM ECC 2xPWM

- 6FE1242-6TM10-0BB1

1.4 Support Packages for STEP 7 Professional V14 SP1

You can use these HSP with STEP 7 Professional V14 **SP1**. **At least** STEP 7 Professional V14 **SP1** is required.

1.4.1 HSP 0185 V3.0

is necessary for these devices:

SINAMICS V90 PROFINET

- 6SL3210-5FB10-1UF0; 6SL3210-5FB10-2UF0; 6SL3210-5FB10-4UF1
- 6SL3210-5FB10-8UF0; 6SL3210-5FB11-0UF1; 6SL3210-5FB11-5UF0
- 6SL3210-5FB12-0UF0
- 6SL3210-5FE10-4UF0; 6SL3210-5FE10-8UF0; 6SL3210-5FE11-0UF0;
- 6SL3210-5FE11-5UF0; 6SL3210-5FE12-0UF0; 6SL3210-5FE13-5UF0
- 6SL3210-5FE15-0UF0; 6SL3210-5FE17-0UF0

2 Support Packages for WinCC

2.1 Support Packages for WinCC V14 SP1

2.1.1 HSP 0116 V2.0

is necessary for these devices:

SIMATIC Mobile Client 900 RFN/RXA

- 6AV6645-7CJ00-2AA0
- 6AV6645-7CG00-2AA0

2.1.2 New: HSP 0207

is necessary for this device:

SIMATIC HMI TP1000F MOBILE:

- 6AV2145-6KB20-0AS0

2.1.3 HSP 0211

is necessary for these devices:

SIMATIC Comfort Panel: KP1500, TP1500, TP1900, TP2200

- 6AV2124-1QC02-0AX1
- 6AV2124-0QC02-0AX1
- 6AV2124-0UC02-0AX1
- 6AV2124-0XC02-0AX1

2.1.4 HSP 0212

is necessary for these devices:

SIMATIC Comfort PRO Panel: TP1500, TP1900, TP2200

- 6AV2124-0QC24-0AX0; 6AV2124-0QC24-0BX0; 6AV2124-0QC24-1AX0
- 6AV2124-0UC24-0AX0; 6AV2124-0UC24-0BX0; 6AV2124-0UC24-1AX0
- 6AV2124-0XC24-0AX0; 6AV2124-0XC24-0BX0; 6AV2124-0XC24-1AX0

2.1.5 HSP 0226

is necessary for these devices:

SIMATIC TP1200 Comfort PRO Panel

- 6AV2124-0MC24-0AX0; 6AV2124-0MC24-1AX0; 6AV2124-0MC24-0BX0
- 6AV2124-0MC24-0AB0; 6AV2124-0MC24-1AB0; 6AV2124-0MC24-0BB0

3 Support Packages for STEP 7 Safety

3.1 Support Packages for STEP 7 Safety Basic or Advanced V14

3.1.1 HSP 0202

is necessary for this module:

SIMATIC ET 200SP F-DQ

- 6ES7136-6DC00-0CA0

3.1.2 HSP 0210

Is necessary for these devices:

SIMATIC Extension Units PROFIsafe

- 6AV7674-1LA33-0AA0; 6AV7674-1LA43-0AA0; 6AV7674-1LA53-0AA0
- 6AV7674-1LA63-0AA0; 6AV7674-1MA00-0AA0