

SIMATIC Safety Integrated for Factory Automation

Fail-Safe Drives

SINAMICS G120 (FW3.2)

Controlled via PROFINET, Safety functions using PROFIsafe,
Category 3 (EN 954-1), SIL 2 (IEC 61508) and PLd (ISO 13849-1)

safety
INTEGRATED

SIEMENS

Preliminary remark

The Functional Examples dealing with “Safety Integrated” are fully functional and tested automation configurations based on A&D standard products for simple, fast and inexpensive implementation of automation tasks in safety engineering. Each of these Functional Examples covers a frequently occurring subtask of a typical customer problem in safety engineering.

Aside from a list of all required software and hardware components and a description of the way they are connected to each other, the Functional Examples include the tested and commented code. This ensures that the functionalities described here can be reset in a short period of time and thus also be used as a basis for individual expansions.

Important note

The Safety Functional Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Safety Functional Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly.

These Safety Functional Examples do not relieve you of the responsibility of safely and professionally using, installing, operating and servicing equipment. When using these Safety Functional Examples, you recognize that Siemens cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Safety Functional Examples at any time without prior notice. If there are any deviations between the recommendations provided in these Safety Function Examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

List of contents

1	Warranty, Liability and Support	5
2	Automation function.....	6
2.1	Description of the functionality	6
2.2	Expanded functionality from firmware V3.2 onwards	7
2.3	Functionality of the function example	8
2.3.1	Task description	8
2.3.2	Solution	8
2.4	Advantages / customer benefits	8
2.5	Structure of the function example	8
2.6	Restrictions.....	9
3	Components that are required	10
3.1	Hardware components	10
3.2	Software components.....	10
4	Configuration and wiring.....	11
4.1	Overview of the hardware configuration.....	11
4.2	Connecting-up the hardware components	12
4.2.1	S7-300 control and CU240S PN-F.....	12
4.2.2	PM240 and motor.....	13
4.3	Fault 395 (acceptance test / acknowledgement present)	14
4.4	Important hardware component settings.....	15
4.4.1	SM374 simulation module	15
4.4.2	Safety digital input module SM326.....	15
4.5	Overview of inputs and outputs.....	16
4.5.1	Simulation module SM374	16
4.5.2	Safety digital input module SM326.....	17
4.5.3	SINAMICS G120	17
4.6	Download	19
4.6.1	S7 program.....	19
4.6.2	Setting the SINAMICS G120 IP address and device name	20
4.6.3	SINAMICS G120 configuration	24
4.6.3.1	Safety functions	25
4.6.3.2	"Enables" tab	26
4.6.3.3	"Safe Torque Off" (STO) tab	27
4.6.3.4	"Safe Stop 1" (SS1) tab.....	29
4.6.3.5	Safely Limited Speed (SLS) tab.....	30
4.6.3.6	Accepting settings.....	36
4.6.3.7	Exiting the STARTER parameterizing software.....	36
4.6.4	Function test.....	37
4.6.5	Acceptance test and acceptance report.....	39
5	Key performance data of the SIMATIC CPU	40
6	Example code.....	41
6.1	Settings in the hardware configuration.....	41
6.1.1	Properties of the CPU	42
6.1.2	Properties of the F-DI module	43
6.1.3	Properties of the SINAMICS G120.....	45
6.1.3.1	PROFIsafe telegram	47
6.1.3.2	Standard Telegram	51
6.2	Functions of the Step 7 program (without safety program).....	52
6.2.1	Program overview	52
6.2.2	DB1, Axis_DB.....	53
6.2.3	FB10, Organization	54
6.2.4	FC100, Control of SINAMICS G120.....	54
6.3	Functions of the Step 7 safety program	55
6.3.1	Program overview	55

6.3.2	FB201, Safety program	56
6.4	SINAMICS G120 - parameterization the safety functions.....	58
6.5	SINAMICS G120 parameterization	59
6.5.1	SIMATIC Manager - inserting SINAMICS G120	59
6.5.2	Calling the STARTER parameterization tool.....	61
6.5.3	STARTER - carrying out quick commissioning	61
6.5.4	STARTER - carrying out a motor identification routine	62
6.5.5	STARTER - setting the Profinet communications	63
7	Evaluation according to IEC 62061 and ISO 13849-1	65
8	Appendix	66
8.1	Reference data.....	66
8.2	Internet link data.....	66
8.3	History	66
8.4	Evaluation / feedback.....	67

1 Warranty, Liability and Support

We accept no liability for information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Safety Functional Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). However, claims arising from a breach of a condition which goes to the root of the contract shall be limited to the foreseeable damage which is intrinsic to the contract, unless caused by intent or gross negligence or based on mandatory liability for injury of life, body or health. The above provisions do not imply a change in the burden of proof to your detriment.

Copyright© 2010 Siemens A&D. It is not permissible to transfer or copy these Application Examples or excerpts of them without first having prior authorization from Siemens A&D in writing.

For questions about this document please use the following e-mail-address:

Online-support.automation@siemens.com

2 Automation function

2.1 Description of the functionality

The SINAMICS G120 drive inverter is a modular inverter system with degree of protection IP20. It comprises the two function units Control Unit (CU) and Power Module (PM).

When using the Control Unit CU240S PN-F, you have access to the following safety functions that are integrated in the drive inverter:

Designation	Function	Description
STO	Safe Torque Off (acc. to EN60204)	The drive is safely brought into a no-torque condition
		Prevents the drive from accidentally starting
		Preventing a restart does not require electrical isolation between the motor and drive inverter
SS1	Safe Stop 1 (acc. to EN60204)	The drive is quickly stopped and safely monitored
		Independent and continuous monitoring guarantees the shortest response times when a fault occurs
		A speed encoder is not required
SLS	Safely Limited Speed (acc. to EN60204)	The drive speed is limited and monitored
		Independent and continuous monitoring guarantees the shortest response times when a fault occurs
		A speed encoder is not required
SBC	Safe Brake Control	An 24V external brake is safely controlled
		In this case, it is necessary to use the <i>Safe Brake Relay</i>

All safety functions are certified according to EN 954-1 (Cat. 3), IEC 61508 (SIL 2) and ISO 13849-1 (PL d).

The safety functions are either controlled through two fail-safe digital inputs (4 digital inputs, which are evaluated through 2 channels in a fail-safe fashion in the CU 240S PN F) or via PROFIsafe in conjunction with a fail-safe CPU.

2.2 Expanded functionality from firmware V3.2 onwards

With firmware V3.2, the safety functions of SINAMICS G120 have been expanded as follows:

- The SLS safety function has been expanded by mode 3 (refer to Chapter 4.6.2.5):
 - Using this mode it is possible to start the motor with SLS activated. This means that the motor speed/velocity can be safely monitored / limited from the start.
 - Further, when SLS is activated it is possible to operate with a frequency below 1Hz for a maximum of 5s.
 - Reversing operation is possible when SLS is activated.
- The safety-relevant feedback signals of the safety functions in the PROFIsafe telegram have been revised. Now, activation is no longer signalled to the F-CPU - but instead the actual status of the safety function (refer to Chapter 6.3.2).
- The acknowledgement of F395 has been significantly simplified (an acceptance test is required) (refer to Chapter 4.3.1).

2.3 Functionality of the function example

2.3.1 Task description

A SINAMICS G120 with its integrated safety functions is to be controlled using an F-CPU via PROFINET.

2.3.2 Solution

In this particular function example, a specific program example will be used to demonstrate the control of a SINAMICS G120 (control word and frequency set-point) and the control of the safety-relevant functions (STO, SLS and SS1) with an F-CPU.

This program example comprises an S7 program to control the SINAMICS G120, an S7 safety program and a configured SINAMICS G120.

2.4 Advantages / customer benefits

Combining safety-relevant and standard programs in one common CPU and establishing communications between the CPU and drive inverter via a common bus (PROFINET) simplify the system design.

The safety functions are integrated in the drive inverter and are implemented without any speed feedback signal. This means that to some extent complex external shutdown and monitoring devices can be eliminated.

A SINAMICS G120 with Safety Control Unit can replace an existing drive inverter. This means that safety functions can be added to an existing system with low associated costs and expenditure.

2.5 Structure of the function example

The download and test of the program examples supplied are described in Chapters 3 to 5.

More in-depth information is provided in Chapter 6 – together with a description of the steps necessary to commission the SINAMICS G120 - so that you can engineer and implement your own projects.

2.6 Restrictions



Caution

Please take careful note that the two safety functions SLS and SS1 may not be used for loads that can drive the motor or loads that are continually in the regenerative mode.

Elevating platforms, winders, wind turbines are examples of such loads that can drive motor or continually regenerate in to the line supply.

An important prerequisite when using fail-safe functions is that the closed-loop control functions absolutely perfectly. The drive (system comprising the drive inverter + motor + driven load) must be engineered so that all operating situations of the particular application are always completely under control.



Caution

After the STO and SS1 safety functions have been activated there is no electrical isolation between the line power supply of the SINAMICS G120 and the motor. If this electrical isolation is required in your particular application, then you must install an appropriate line contactor upstream of the SINAMICS G120.

3 Components that are required

An overview of the hardware and software components required for the function example is provided in the Chapter.

3.1 Hardware components

Component	Type	Order No./ordering data	Qty	Manufacturer
S7 control				
Power supply	PS307 5A	6ES7307-1EA00-0AA0	1	SIEMENS
S7-F CPU	CPU 315F-2 PN/DP	6ES7315-2FH13-0AB0	1	
Memory Card	MMC 512 KB	6ES7953-8LJ11-0AA0	1	
DI / DO simulation module	SM374	6ES7374-2XH01-0AA0	1	
Safety digital input	SM326	6ES7326-1BK01-0AB0	1	
Front connector	40 pin	6ES7392-1AM00-0AA0	1	
Profile rail	Profile rail	6ES7390-1AE80-0AA0	1	
PROFINET RJ45 connector *	PROFINET connector	6GK1901-1BB10-2AA0	4	
PROFINET cable	PROFINET cable	6XV1840-2AH10	5m	
Drive				
SINAMICS G120 Control Unit	CU240S PN F (FW3.2)	6SL3244-0BA21-1FA0	1	SIEMENS
SINAMICS G120 Power Module	PM240	6SL3224-0BE21-5UA0	1	
Basic Operator Panel	BOP	6SL3255-0AA00-4BA1	1	
Motor	Three-phase induction motor 0,12kW	1LA7060-4AB10	1	
Command devices				
Empty enclosure	Empty enclosure with 4 command sources (e.g. pushbuttons)	3SB3804-0AA3	1	SIEMENS
Emergency Stop mushroom pushbutton (to activate STO and SS1)	Emergency Stop mushroom pushbutton	3SB3000-1HA20	2	
Mushroom pushbutton (to activate SLS)	Mushroom pushbutton, red	3SB3000-1DA21	1	
Pushbutton (acknowledge safety functions)	Pushbutton, red	3SB3000-0AA21	1	
Contact	1NC, screw terminal	3SB3420-0C	6	
Contact	1NO, screw terminal	3SB3420-0B	2	

Note

The functionality was tested with the specified hardware components. Similar components that are different from those listed above can be used. Please note that in such a case it may be necessary to change the code example (e.g. setting other addresses).

3.2 Software components

Component	Version	Order No. / ordering data	Qty	Manufacturer
SIMATIC STEP 7	V5.4 + SP5 + HF1	6ES7810-4CC08-0YA5	1	SIEMENS
SIMATIC Distributed Safety	V5.4 + SP5	6ES7833-1FC02-0YA5	1	
STARTER	V4.1 + SP5 + HF1	http://support.automation.siemens.com/WW/view/en/26233208	1	
GSDML-File CU240S PN-F	V3.2	http://support.automation.siemens.com/WW/view/en/26641490	1	

4 Configuration and wiring

The hardware configuration and connecting-up the function example are described in this Chapter.


Please carefully observe the following safety information & instructions when using the SINAMICS G120:



Warning


The SINAMICS G120 has hazardous voltages and controls rotating mechanical parts that can also be potentially hazardous. If the warning information is not observed or the information & instructions from the instructions belonging to SINAMICS G120 are not complied with this could result in death, severe bodily injury or significant material damage.

4.1 Overview of the hardware configuration




4.2 Connecting-up the hardware components

4.2.1 S7-300 control and CU240S PN-F



4.2.2 PM240 and motor



For more detailed information regarding the installation please refer to the **SINAMICS G120 Hardware Installation Manual Power Module PM240**. Download from: <http://support.automation.siemens.com/WW/view/en/22339653/133300>

4.3 Fault 395 (acceptance test / acknowledgement present)

Fault F395 is output when powering-up for the first time and after replacing the Control Unit (CU) or the Power Module (PM).

This fault does not represent an incorrect drive inverter function. The reason for this fault message is to monitor the individual drive inverter components (CU and PM) to prevent them from being replaced by unauthorized personnel.

Acknowledging fault F395 beginning with firmware V3.2

The acknowledgment of F395 has been significantly simplified with the introduction of firmware V3.2. Just like any other fault, it can be acknowledged using an appropriately parameterized input, via the field bus or using the STARTER parameterizing software.

Acknowledging fault F395 with older firmware versions (<V3.2)

To acknowledge the F395 in conjunction with older firmware versions, proceed as follows:

- Set parameter p0010 to 30
- Enter the safety password (standard = 12345) into parameter p9761
- Set parameter p7844 to 0
- → F395 will no longer be displayed

Next steps

The user must then carry-out an acceptance test/check. More information is provided in the **G120 Operating Instructions** in Chapter **Appendix** under **Acceptance Log**.

Download from:

<http://support.automation.siemens.com/WW/view/en/22339653/133300>

Download Acceptance test report from:

<http://support.automation.siemens.com/WW/view/en/35014199>

4.4 Important hardware component settings

Most of the module/board settings are made in the HW Config in the software. Hardware settings are only required for the following modules/boards.


The modules/boards must be set with the control system in a no-voltage state.

4.4.1 SM374 simulation module

This module can be operated as 16 x DO (output via LED), 16 x DI (input via switch) or as combined 8 x DI / 8 x DO. The last combination is used in this function description.

The function of the module is selected using a rotary switch behind the front cover between the series of switches.


As shown in the following diagram set the function switches to the setting **8 x Output 8 x Input**.



4.4.2 Safety digital input module SM326


Before installation, the PROFIsafe address must be set at the rear of the module according to HW Config.

Set the DIL switches as shown in the following diagram.



4.5 Overview of inputs and outputs

4.5.1 Simulation module SM374



Address	Function	Symbolic address	Default	Explanation
O 0.7	Indicator lamp Safety functions active or error	Safe_stop_or_error	0	Activated safety functions (flashing light) and faults (steady light) are signaled via this output
I 0.0	SINAMICS G120 start	Start_G120	0	The motor connected to SINAMICS G120 is started by activating the input
I 0.1	SINAMICS G120 reverse	Reverse_G120	0	After the input is activated, a negative frequency setpoint is entered (direction of rotation reversal)
I 0.5	Increase frequency	Increase_frequency	0	The motor frequency can be increased using this input
I 0.6	Decrease frequency	Decrease_frequency	0	The motor frequency can be reduced using this input
I 0.7	Acknowledge error	ACK_error	0	Fault messages that are present can be acknowledged using this input.

4.5.2 Safety digital input module SM326

Overview of the pushbuttons that are connected:

Address	Function	Symbolic address	Default	Explanation
I 24.0	STO pushbutton	Safety_PB_STO	1	The safety function STO (Safe Torque Off) is initiated using this pushbutton
I 24.1	SS1 pushbutton	Safety_PB_SS1	1	The safety function SS1 (Safe Stop 1) is initiated using this pushbutton
I 24.2	SLS pushbutton	Safety_PB_SLS	1	The safety function SLS (Safely Limited Speed) is initiated using this pushbutton
I 24.3	Pushbutton for safety functions and acknowledging faults	Safety_PB_ACK	0	The activated safety functions can be acknowledged using this pushbutton - and parallel to I0.7 – also any fault messages that might be present,

4.5.3 SINAMICS G120

The SINAMICS G120 is controlled and the feedback signals read-in via the I/O addresses listed below.

Address	Function
S7 program -> SINAMICS G120	
PQW256	Control word 1
PQW258	Frequency setpoint
PQW260	Torque setpoint
PQW262	Control word 2
PAW264	-- Reserve --
PAW266	-- Reserve --
SINAMICS G120 -> S7 program	
PIW256	Status word 1
PIW258	Frequency actual value
PIW260	Current actual value
PIW262	Status word 2
PIW264	Last fault number
PIW266	Last alarm number

For more detailed information about the configuration of the individual signals, please refer to **SINAMICS G120 Operating Instructions Control Unit CU240S**, Chapter **Commissioning**.

Download from:

<http://support.automation.siemens.com/WW/view/en/22339653/133300>

The safety functions of the SINAMICS G120 are controlled from the S7 safety program and the status of the safety functions of the SINAMICS G120 is signaled back to the S7 safety program using the following signals:

Address	PROFIsafe telegram bit	Symbolic address	Function
S7 safety program -> SINAMICS G120			
Q 14.0	Bit 0	Safety_S7 -> G120_STO	By switching out this signal, the STO function (Safe Torque Off) is activated in the SINAMICS G120
Q 14.1	Bit 1	Safety_S7 -> G120_SS1	By switching out this signal, the SS1 function (Safe Stop 1) is activated in the SINAMICS G120
Q 14.4	Bit 4 *	Safety_S7 -> G120_SLS_V2	By switching out this signal, the SLS function (Safely Limited Speed) is activated in the SINAMICS G120 The active bit (bit 4 or bit 8) is selected using parameterization (refer to Chapter 4.6.2.2)
Q 15.0	Bit 8 *	Safety_S7 -> G120_SLS_V1	
SINAMICS G120 -> S7 safety program			
I 14.0	Bit 0	Safety_G120 -> S7_STO_PR	Feedback signal from SINAMICS G120 to the S7 safety program, STO (Safe Torque Off) and power removed was activated
I 14.1	Bit 1	Safety_G120 -> S7_SS1	Feedback signal from the SINAMICS G120 to the S7 safety program that the SS1 (Safe Stop 1) deceleration ramp is active.
I 14.4	Bit 4 **	Safety_G120 -> S7_SLS_V2	Feedback signal from the SINAMICS G120 to the S7 safety program that the actual motor frequency lies below the SLS (Safely Limited Speed) limit frequency. Both bits have the same priority and are used to feed back the SLS status to the S7 safety program.
I 15.0	Bit 8 **	Safety_G120 -> S7_SLS_V1	

* With the introduction of firmware V3.2, in addition to bit 8, which already existed, bit 4 has been introduced - in conformance with PROFIsafe. This is used to control the SLS safety functions The parameterization defines as to whether the original bit is used or the new bit (refer to Chapter 4.6.2.2).

** the SLS status bit is signaled back to the S7 safety program using bit 8 and the new bit 4 that is in conformance with PROFIsafe.

4.6 Download

4.6.1 S7 program


To download the S7 program, you will require a connection between the MPI interface of your PG/PC and the MPI interface of the S7 CPU.

- Start the **SIMATIC Manager**.
- De-archive the function example supplied.
- Open the **G120_Safety_App_3_V20** project.
- Select the **MPI** interface parameterization using **Options > Select PG/PC interface...** .
- Open **HW-Config** and download this into the control. After the download re-close **HW-Config**.
- In the SIMATIC Manager, select **CPU315F-2 PN/DP**.
- Open the Safety Program dialog box using **Options > Edit safety program**.
- Press the **Download** button and in the dialog window that is then displayed, press **Yes** to download the standard blocks.
- Enter the password **siemens** into the **Password for Safety Program** dialog window that opens.
- After you have successfully downloaded the standard blocks you can re-close the **Safety Program** dialog box.


4.6.2 Setting the SINAMICS G120 IP address and device name

Different than for Profibus, for PROFINET, the node addresses are not set in the hardware, but in the software. To do this, a connection is required between the PG/PC and the PROFINET interface of the SINAMICS G120 via TCP/IP.

- To do this, connect the PROFINET cable from the SINAMICS G120, interface X01 P2 to the Ethernet interface (port) of your PG/PC (refer to Chapter 4.1).
- Set the IP address and the subnet mask of the Ethernet card of your PG/PC as follows.




- Using **Options > Set PG/PC Interface....** select the TCP/IP interface parameterization. You can carry out all additional steps via this interface during the course of the function example.



- Then, using **PLC > Edit Ethernet Node...**, open the dialog box **Edit Ethernet Node**.

- Press the **Browse...** button




The screenshot shows the 'Edit Ethernet Node' dialog box. The 'Browse...' button is highlighted with a red rectangle. The dialog box contains the following sections:

- Ethernet node:** MAC address field and 'Browse...' button.
- Nodes accessible online:** (Header for the next section)
- Set IP configuration:**
 - Use IP parameters
 - IP address: []
 - Subnet mask: []
 - Gateway:
 - Do not use router
 - Use router
 - Address: []
 - Obtain IP address from a DHCP server
 - Identified by:
 - Client ID
 - MAC address
 - Device name
 - Client ID: []

- Assign device name:** Device name: [] Assign Name
- Reset to factory settings:** Reset
- Close, Help

- In the dialog box that then opens, select the node with the SINAMICS device type and then press the **OK** button.



The screenshot shows the 'Browse Network - 2 Nodes' dialog box. The first row of the table is highlighted with a red rectangle. The dialog box contains the following sections:

- Start, Stop
- Fast search
- Flash
- MAC address: [08-00-06-9C-CC-AF]
- OK, Cancel, Help

IP address	MAC address	Device type	Device name
0.0.0.0	08-00-06-9C-CC-AF	SINAMICS	
192.168.0.1	08-00-06-99-55-52	S7-300	pr-10

- **(1.)** Now, enter under **IP-adresse: 192.168.0.2** and under **Subnetmask: 255.255.255.0**. **(2.)** Then press the **Assign IP Configuration** button.


Copyright © Siemens AG 2010 All rights reserved
SD_FE_I_005_V20_EN.doc

- **(3.)** After completing the IP configuration assignment, enter the device name - assigned in HW Config - under **Device name:** (in this particular function example, **G120**). **(4.)** This is then assigned to the SINAMICS G120 by pressing the **Assign Name** button.
- Close the mask by pressing the **Close** button.


4.6.3 SINAMICS G120 configuration

When this has been completed, download the SINAMICS G120 configuration using the STARTER parameterizing tool.

- Starting from the main path of the SIMATIC Manager, start the STARTER parameterizing software by selecting the **SINAMICS_G120** icon and double click on the **Inbetriebnahme** icon.




- Then, in the Project Navigator of the STARTER parameterizing software select the object "**G120**" (1.) and press the button  (2.) to establish the online connection to the drive inverter.



- After you have established the online connection, press the button  to download the SINAMICS G120 drive parameters.
- Follow the instructions on the screen and acknowledge the prompt **"After loading, copy RAM to ROM"**.
- You must then enter the safety parameters of the SINAMICS G120. These may not be - and cannot for safety reasons - be transferred into the drive inverter by downloading from the PG / PC.


4.6.3.1 Safety functions

- In the Project Navigator, select **Functions** and then open the dialog box for the safety functions by double clicking on **Safety Integrated**.



- Before you start the safety commissioning change the **PROFIsafe destination address (1.)** to 200. This value can't be changed with the other safety parameters in the password protected area.
- Then press the button **Change settings (2.)** and enter **12345** (standard password) in the password screen that then opens.
- From the following screen forms transfer the appropriate values into your project. Take into consideration that in certain instances there are different value formats for processor 1 and 2 (e.g. s and ms, Hz and kHz). The reason for this, is that for the two processors in the SINAMICS G120, which should operate in parallel and should come to the same result, separate parameter sets are available for safety reasons.

4.6.3.2 "Enables" tab




In this screen parameterize which source (**PROFIsafe** or the **Safe digital inputs**) is used to activate the safety functions of SINAMICS G120.

- **Upper section:**
 - **1.)** Path to activate the safety functions via **PROFIsafe** (this path is used in this function example).
 - **2.)** Path to select the PROFIsafe protocol version. Deactivated switches select the previous version with SLS control using bit 8. Activated switches select the new control that uses bit 4 in the PROFIsafe telegram – and which is in conformance with PROFIsafe.
- **Center section:** Path to activate the safety functions using **Safe digital inputs 0 and 1** (not used in this function example).
- **Lower section:** Here, the monitoring of the **Safe Brake Control** module can be activated (not used in this function example).

After you have parameterized the enable signals, then select the tab **Safe Torque Off**.

4.6.3.3 "Safe Torque Off" (STO) tab



The shutdown paths of a safety-relevant plant or system must be subject to a forced checking procedure at regular intervals. This is in order to identify "dormant" errors. SINAMICS G120 automatically carries out a forced checking procedure of the shutdown paths in the drive unit. This procedure is known as the forced checking procedure.

A reduced form of the forced checking procedure limited to self-test the brakes and processor is always automatically executed after "Safe Torque Off" (STO) is exited. This type of forced checking procedure is known as the process checking procedure.


Further, by appropriately parameterizing the system, it is possible to initiate a forced checking procedure each time that STO is exited.

- **Upper section:** Using *Test of the shutdown channels when leaving STO*, you can select how the forced checking procedure for the shutdown channels is carried-out.
 - **Activated:** A dynamization (forced checking procedure) is carried-out when first powering-up after "Safe Torque Off" (STO). It takes about 2.4s to check the shutdown channels. This delay time should be taken into account for an on command.
 - **Deactivated:** The shutdown channels are only checked after initiating the function "Latched Safe Torque Off" (LSTO) in a fault condition/situation and after switching-out the power supply voltage and switching-in again. When exiting an STO, a delay time is not incurred as only the process checking procedure is carried-out.

- **Center section:** When activating the safety functions via the safe digital inputs of the SINAMICS G120, a **debounce time** and a filter for the **response time** can be set here. These settings are not relevant for the function example described here.
- **Lower section:** The SINAMICS G120 automatically monitors when a forced checking procedure was carried-out the last time. Set the time up to the next forced checking procedure in the field **Test periods for shutdown paths**. The time can be selected between 0.1 and 8760 hours (6 min up to 1 year). The timer is re-started after each forced checking procedure. Alarm A1699 is output in operation to flag you that this monitoring time has expired. A process checking procedure does not replace forced checking procedure and therefore does not reset the timer.

After you have parameterized the **Safe Torque Off** function, select the tab **Safe Stop 1**.

4.6.3.4 "Safe Stop 1" (SS1) tab



The parameters relevant for "Safe Stop 1" (SS1) are set in this screen form.

- **(1.)** Using the threshold value **Standstill detection**, define the speed at which standstill (zero speed) is detected and "Safe Torque Off" (STO) is activated. Please note that the value should be entered once in kHz and once in Hz.
- **(2.)** The **Ramp-down time Tr for SS1 ...** should then be entered. Please note that the value is entered once in s and once in ms. The ramp-down time Tr always refers to the safety reference frequency of 200Hz in the drive itself. This ramp-down time is also used for the deceleration for "Safely Limited Speed" (SLS).
- **(3.)** The monitoring tolerance is set using **Delay Tv, until monitoring active**. The drive inverter continually monitors - with tolerance Tv - the braking of the drive. If the tolerance is selected too low, then the monitoring function could be incorrectly tripped. If the tolerance is too high, then if an actual fault does develop, an unnecessarily long time is wasted. Please note that the value is entered once in s and once in ms.
- You can download an Excel tool to calculate SS1 and SLS parameters under the following link:
<http://support.automation.siemens.com/WW/view/en/24488874>

After you have parameterized the function **Safe Stop 1**, select the tab **Safely Limited Speed**.

4.6.3.5 Safely Limited Speed (SLS) tab

Enables | Safe torque off (STO) | Safe stop 1 (SS1) | **Safely-limited speed (SLS)**

Response to violation of the setpoint for SLS at the time of activation

[1] Activate braking ramp while $f > f_{SLS}$ & [1] Activate braking ramp while $f > f_{SLS}$ 1.

Frequency

Setpoint for SLS

$f = 10.0$ Hz
 $f = 0.0100$ kHz

Upper SLS limit $f = 130$ Hz
 $f = 0.0130$ kHz

Lower SLS limit 1 Hz

Time

Diagnostics of the safety functions

Safety function errors

STO active

SS1 active

SLS selected

SLS active

Brake closed

Shutdown paths require testing

The parameters relevant for “Safely Limited Speed” are entered in this screen form.

- (1.) The SLS mode is defined here. For this function example set mode 1 (**Activate the braking ramp while $f > f_{SLS}$ (1)**).
- The following four modes - with the appropriate properties - are available:

SLS Mode	Properties
Mode 0	<p data-bbox="467 416 1230 510"><i>Initiate STO with braking ramp and drive fault when $f > f_{SLS(0)}$ →</i> Limiting to a safely limited speed The speed can not be changed via frequency setpoint</p> <div data-bbox="467 555 1214 987"> <p>The graph illustrates the SLS Mode 0 behavior. The y-axis represents frequency f and the x-axis represents time. A black line shows the speed setpoint, which ramps down to a 'Setpoint for SLS' and then ramps back up. A cyan line shows the actual speed, which follows the setpoint but is limited to a 'Safe speed control active' region between 1Hz and the 'Upper SLS limit'. Vertical dashed lines mark 'SLS activation' and 'SLS deactivation'.</p> </div> <ul data-bbox="379 1055 1369 1451" style="list-style-type: none"> ▪ If, when SLS is activated, the actual frequency is greater than the Upper SLS limit, SS1 is activated and then LSTO (safe torque shutdown with latching). ▪ If, when SLS is activated, the actual frequency lies between the Upper SLS limit and the Setpoint for SLS, then the Setpoint for SLS is activated. The frequency cannot be changed. ▪ If the actual frequency lies below the Setpoint for SLS, the actual frequency is kept. The frequency cannot be changed. ▪ STO is activated if the actual frequency is below 1Hz. ▪ SLS can be ended with ON/OFF1, OFF2 and OFF3 – and as a consequence, the drive is stopped. The drive can only be re-started if SLS was withdrawn. In just the same way - SLS is ended by activating STO and SS1.

SLS Mode	Properties
Mode 1	<p data-bbox="539 371 1158 465"><i>Activate braking ramp while $f > f_{SLS(1)}$</i> Reducing to a safely limited speed The speed can not be changed via frequency setpoint</p> <div data-bbox="475 517 1214 936"> </div> <ul data-bbox="379 1010 1366 1361" style="list-style-type: none"> ▪ If, when activating SLS, the actual frequency is greater than the Upper SLS limit, the Setpoint for SLS is activated and the drive is braked down to this setpoint using the SS1 safe braking ramp (refer to Safe Stop 1 tab, parameter Ramp-down time T_r for SS1 ...). ▪ If the actual frequency lies below the Setpoint for SLS, the actual frequency is kept. The frequency cannot be changed. ▪ STO is activated if the actual frequency is below 1Hz. ▪ SLS can be ended with ON/OFF1, OFF2 and OFF3 – and as a consequence, the drive is stopped. The drive can only be re-started if SLS was withdrawn. In just the same way - SLS is ended by activating STO and SS1.


SLS Mode	Properties
Mode 2	<p data-bbox="437 371 1262 468"><i>Initiate STO without braking ramp and with drive fault while $f > f_{SLS}$ →</i> Limiting to a safely limited speed The speed can be changed via frequency setpoint</p> <div data-bbox="475 517 1214 943"> <p>The graph plots frequency f on the vertical axis against time on the horizontal axis. A black line represents the 'Speed setpoint', which starts at a constant high frequency, then ramps down to a minimum value, and finally ramps back up to the original high frequency. A cyan line represents the 'Actual speed', which follows the setpoint but is constrained to a minimum of 1 Hz and an 'Upper SLS limit'. A yellow shaded region between the 1 Hz line and the upper SLS limit is labeled 'Safe speed control active'. Vertical dashed lines indicate the 'SLS activation' and 'SLS deactivation' points. The text 'SLS Mode 2' is centered below the graph.</p> </div> <ul data-bbox="379 1010 1358 1397" style="list-style-type: none"> ▪ If, when activating SLS, the actual frequency is greater than the Upper SLS limit, LSTO (safe torque shutdown with latching) is activated. ▪ If, when activating SLS, the actual frequency lies below the Upper SLS limit, the frequency is kept. The frequency can be changed between 1 Hz and the Upper SLS limit (Caution: For V/f, take into account the slip compensation). ▪ If the actual frequency drops below 1 Hz or the Upper SLS limit is reached, STO is activated. If the upper tolerance limit for velocity monitoring is exceeded, then STO is latched – i.e. LSTO. ▪ SLS can be ended with ON/OFF1, OFF2 and OFF3 – and as a consequence, the drive is stopped. The drive can only be re-started if SLS was withdrawn. In just the same way - SLS is ended by activating STO and SS1.

SLS Mode	Properties
Mode 3	<p data-bbox="639 371 1058 405">SLS with ramp down from 0Hz (3) →</p> <p data-bbox="571 407 1126 436">Start with active SLS, limit to a safely-limited speed.</p> <p data-bbox="571 439 1126 468">It is possible to vary the speed via the setpoint input.</p> <p data-bbox="475 470 1222 499">The speed can be reduced to 0Hz and reversing operation is possible.</p> <div data-bbox="451 555 1225 1041"> <p data-bbox="722 562 922 618">Legend: ■ Actual speed ■ Speed setpoint</p> <p data-bbox="743 987 884 1016">SLS Mode 3</p> </div> <ul data-bbox="379 1088 1370 1883" style="list-style-type: none"> ▪ If SLS is activated at standstill, then the frequency inverter must be started within 5s and a frequency of 1Hz must be exceeded. Otherwise, the frequency inverter switches into the safe state with STO. If the frequency setpoint that has been entered lies above the Upper SLS limit, LSTO (Safe Torque Off with latching) is activated. ▪ In JOG-Mode with activated SLS please ensure that the drive frequency reaches 1Hz within 5s. Otherwise upon the 3rd activation of SLS the drive will be switched off with LSTO and error F1614 (additional info 105 / 205). ▪ If, when activating SLS, the actual frequency is higher than the Upper SLS limit, LSTO (Safe Torque Off with latching) is activated. ▪ If, when activating SLS, the actual frequency is below the Upper SLS limit, then the frequency is kept. The frequency can be varied between 0Hz and the Upper SLS limit (caution, for V/f control take into account the slip compensation). However, the frequency range below 1Hz must be again exited within 5s - otherwise the frequency inverter will shut down (trip) with STO. ▪ In reversing operation, the frequency range between +/- 1Hz must be passed through within 5s - otherwise the frequency inverter will shutdown (trip) with STO. ▪ With ON/OFF1, OFF2 und OFF3 the drive can be stopped. In addition SLS needs to be deactivated manually. For example after deactivation of ON/OFF1 with active SLS the drive can only be started after a deactivation of SLS and if necessary reactivation of SLS. ▪ SLS is also ended by activating STO and SS1.

You can obtain more detailed information about the SLS modes from the **Function Manual SINAMICS G120, SINAMICS G120D, SIMATIC ET200S FC, SIMATIC ET200pro FC** in Chapter **Fail-Safe Functions** under **Safely Limited Speed**.

Download from:

<http://support.automation.siemens.com/WW/view/en/25021636/133300>



- **(2.)** These input fields are displayed only for SLS mode 0 and 1. **Setpoint for SLS** is used to set the frequency to which the frequency setpoint is internally limited in the drive unit after the function Safely Limited Speed SLS has been selected. Please note that the value is entered once in Hz and once in kHz.
- **(3.)** The monitoring limit is set using the **Upper SLS limit**. If Safely Limited Speed SLS is active and the actual frequency exceeds this value, then SINAMICS G120 outputs a fault message and goes into the safe condition (Safe Torque Off, STO). Please note that the value should be entered once in Hz and once in kHz.
- You can download an Excel tool to calculate SS1 and SLS parameters under the following link:

<http://support.automation.siemens.com/WW/view/en/24488874>


4.6.3.6 Accepting settings

- After you have made all of the settings press the **Accept settings** button.
- You can now change the standard password. If you are still not certain that your safety parameterization has been completed, then you should press the **Later** button.

However, after you have completed the commissioning phase, do not forget to change the standard password for a password that only you know or a person that you trust. Only then can you be sure that only authorized persons can change/modify safety parameters.

- To complete the parameterization of the safety functions you must now acknowledge the checksums of the two processors. To do this, transfer the first checksum, processor 1 into the set checksum, processor 1. Do exactly the same for the checksum of processor 2.

Please note that the two actual checksums and therefore the two set checksums must be the same. If this is not the case, then you must re-check your parameterization of the safety functions and resolve the different values.



4.6.3.7 Exiting the STARTER parameterizing software

- If you don't wish to set any additional parameters, then you can now exit the STARTER commissioning tool.
- In the tree select SINAMICS G120 and transfer all of the parameter changes into the ROM memory of the SINAMICS G120 by pressing the  button
- Then transfer all of the parameters into your offline a project by pressing the  button.
- Disconnect the PG / PC from SINAMICS G120 by pressing the  button.
- Now you can close STARTER using **Project > Close** or by pressing the  button.

4.6.4 Function test

The function test can be carried-out, if

- The hardware components are connected-up
- The hardware settings have been made
- The S7 project is in the CPU
- The configured software has been downloaded into the SINAMICS G120 and the safety functions have been parameterized
- The CPU is in the RUN state

No.	Action	Response
1	If it is pressed, release the Emergency Stop pushbutton.	
2	Press the pushbutton " Acknowledge safety functions and faults " (I 24.3). Please wait during BUSY (DB1. DBX17.0 = 0) is displayed on the BOP.	The signal lamp for " Safety functions activated or fault " (Q 0.7) goes dark. At SINAMICS G120 LEDs RDY , STO , SS1 and SLS are bright → the drive and all of the safety functions are in the ready state.
3	Press the switch " SINAMICS G120 Start " (I 0.0)	The motor starts to run.
Safety function STO (Safe Torque Off)		
1	Press the " Emergency Stop pushbutton STO " (I 24.0).	The motor coasts down and is not braked. The signal lamp for " Safety functions activated or fault " (Q 0.7) starts to flash. At the SINAMICS G120 the LED ES is bright and LED STO flashes → STO is active, the motor is brought into a no-torque condition.
2	De-activate the control of the SINAMICS G120 using the switch " SINAMICS G120 Start " (I 0.0).	
3	Release the " Emergency Stop pushbutton STO " (I 24.0) and press the pushbutton " Acknowledge safety functions and faults " (I 24.3). Please wait during BUSY (DB1. DBX17.0 = 0) is displayed on the BOP.	The signal lamp for " Safety functions activated and fault " (Q 0.7) goes dark. At the SINAMICS G120, the LEDs RDY , STO , SS1 and SLS are bright → the drive and all safety functions are in the ready state.
4	Press the switch " SINAMICS G120 Start " (I 0.0)	The motor starts to operate again.

No.	Action	Response
Safety function SS1 (Safe Stop 1)		
1	Press the "Emergency Stop pushbutton SS1" (I 24.1)	<p>The motor follows the parameterized braking ramp down to the minimum frequency and stops.</p> <p>The signal lamp for "Safety functions activated and fault" (Q 0.7) starts to flash.</p> <p>At the SINAMICS G120 the LED ES is bright and LED SS1 flashes → SS1 is active, the motor has been brought into a no-torque condition.</p>
2	De-activate the control of the SINAMICS G120 using the switch "SINAMICS G120 Start" (I 0.0).	
3	Release the "Emergency Stop pushbutton SS1" (I 24.1) and press the pushbutton "Acknowledge safety functions and faults" (I 24.3). Please wait during BUSY (DB1. DBX17.0 = 0) is displayed on the BOP.	<p>The signal lamp for "Safety functions activated or fault" (Q 0.7) goes dark.</p> <p>At the SINAMICS G120 the LEDs RDY, STO, SS1 and SLS are bright → the drive and all of the safety functions are in the ready state.</p>
4	Press the switch "SINAMICS G120 Start" (I 0.0).	The motor starts to operate again.
Safety function SLS (Safely Limited Speed) Mode 1		
1	Press the "Pushbutton SLS" (I 24.2) and keep it pressed.	<p>The motor follows the parameterized braking ramp down to the safely limited speed.</p> <p>The signal lamp for "Safety functions activated and fault" (Q 0.7) is not bright (is dark).</p> <p>At the SINAMICS G120 the LED ES is bright and LED SLS flashes → SLS is active, the motor is monitored to ensure that it does not exceed the safely limited speed.</p>
2	Release "Pushbutton SLS" (I 24.2) again	<p>The motor accelerates back to the normal speed.</p> <p>At the SINAMICS G120 LEDs RDY, STO, SS1 and SLS are bright → the drive and all safety functions are in the ready state.</p>

4.6.5 Acceptance test and acceptance report

An acceptance test must be carried-out when the machine is commissioned for the first time and also if a completely saved set of the safety-relevant parameters is changed. This procedure is used to verify the safety-relevant parameters. This acceptance test must be appropriately documented. The acceptance reports must be appropriately stored and archived.

The checksum ensures that all subsequently made changes are identified.

Information about the acceptance test are provided in the ***Operating Instruction Control Unit CU240S*** in Chapter ***Appendix*** under ***Acceptance Log***.

Download from:

<http://support.automation.siemens.com/WW/view/en/22339653/133300>

Download Acceptance test report from:

<http://support.automation.siemens.com/WW/view/en/35014199>

5 Key performance data of the SIMATIC CPU

Load memory and working memory

	Total
Load memory	Approx. 62 k
Working memory	Approx. 41 k

Cycle time

Total cycle time (typical)	Approx. 1 ms	Standard and safety program
----------------------------	--------------	-----------------------------

6 Example code

The individual functions of the example code are explained in the following Chapters so that you will then be in a position to implement your own project.

For this function example, the settings described no longer have to be made.

Note

In this example code, passwords are used for the safety functions. These are as follows:


S7 safety program and HW Config: **siemens**
 STARTER Safety Screens: **12345**

6.1 Settings in the hardware configuration

Slot	Module	Order number	Firmware	MPI address	I address	Q address	Comment
1	PS 307 5A	6ES7 307-1EA00-0AA0					
2	CPU 315F-2 PN/DP	6ES7 315-2FH13-0AB0	V2.5				
X1	MPI/DP				2047*		
X2	PN-IO				2046*		
X2 P1	Port 1				2045*		
3							
4	DI8/DO8xDC24V/0.5A	6ES7 323-1BH01-0AA0			0	0	
5	DI24xDC24V	6ES7 326-1BK01-0AB0			24...33	24...27	
6							
7							

6.1.1 Properties of the CPU

Before the safety functions of the CPU can be used, they must be released. The **Properties** window of the CPU is opened by double clicking on the CPU315F-2 PN/DP.




Under the **Protection** tab, the safety functions of the CPU are enabled by selecting the following functions:


- **Protection level; 1: Access protect for F CPU,**
- Activate **Can be bypassed with password,**
- Enter a **password** (in this example code, **siemens**),
- Activate **CPU contains safety program.**

6.1.2 Properties of the F-DI module

The signal sources for the safety functions (pushbuttons to acknowledge STO, SS1, SLS and Emergency Stop) are read-in using the fail-safe module DI24xDC24V (6ES7326-1BK01-0AB0). The Properties dialog box opens after double clicking on the module. The properties of the module can be parameterized by selecting the **Parameters** tab.



- (1.) Also for this module, safety-relevant operation must be enabled by selecting **Safety mode** as the operating mode.
- (2.) The binary code that is specified under **DIP switch setting (9.....0)** must be set at the rear of the module.

DIL switch on the module:


- (3.) The short-circuit and cross-circuit fault monitoring of the channel group can be activated by selecting the function **Sensor supply via module**. This function should be activated as a result of how the function example is connected-up.
- (4.) The properties of the individual channels of the module (channels 0,12 up to 3,15) are parameterized as shown under **Channel 0, 12**.

For more detailed information please refer to the Manual **SIMATIC Automation System S7-300 Fail-Safe Signal Modules**.

Download from:


<http://support.automation.siemens.com/WW/view/en/12265765/133300>

- In order that the buttons for **STO**, **SS1**, **SLS** and **ACK** can be used in the safety program, symbolic addresses must be assigned for the inputs of the safety input module. The input window for the symbolic addresses is opened by selecting the module, pressing the righthand mouse key and selecting **Edit Symbols...**




6.1.3 Properties of the SINAMICS G120

The window of the SINAMICS G120 PROFINET properties (2.) is displayed by clicking once on the SINAMICS G120 icon (1.).



The PROFIBUS telegram (2.) between the CPU and the SINAMICS G120 comprises two components. One is the **Standard Telegram**, in this particular example, **Standard Telegram 352** for the communications of the SINAMICS G120 (control signals, status signals, frequency setpoint, frequency actual value etc.) and the other is the **PROFIsafe** for PROFIsafe communications.

The telegram is selected in the Catalog after pressing the  button.



You can download the GSD files for the SINAMICS G120 under the following link:

<http://support.automation.siemens.com/WW/view/en/23450835>


GSD files are required to operate a node (e.g. the SINAMICS G120) on PROFINET – and to register (log-on) the device to the engineering tool.

The PROFIsafe SIEMENS T352 telegram is used in this example.


6.1.3.1 PROFIsafe telegram

The PROFIsafe communication of the SINAMICS G120 safety functions are realized using the **PROFIsafe telegram**.

The **Properties** window of the module opens after double-clicking on the **PROFIsafe telegram**.



- The **PROFIsafe properties** window is displayed after pressing the **PROFIsafe...** button (1).
- The PROFIsafe properties are displayed after entering the safety password **siemens**.



- The value of **F_Dest_Add** specified by HW Config (PROFIsafe address of the SINAMICS G120) must be entered into SINAMICS G120 **parameter p9810** (refer to Capture 4.6.3.1).

- For ***F_WD_Time*** (PROFIsafe Watchdog Time) minimum twice the value of the call environment cycle of the S7 safety program must be entered. In this particular function example the S7 safety program is called every 100 ms in OB35 (refer to ***HW-config, Properties CPU, Cyclic Interrupts***).

Properties - CPU 315F-2 PN/DP - (R0/S2)


	General	Startup	Synchronous Cycle Interrupts		
	Diagnostics/Clock	Protection	Communication	F Parameters	Web
	Cycle/Clock Memory	Retentive Memory	Interrupts	Time-of-Day Interrupts	Cyclic Interrupts
	Priority	Execution	Phase offset	Unit	Process image partition
OB30:	0	5000	0	ms	---
OB31:	0	2000	0	ms	---
OB32:	0	1000	0	ms	---
OB33:	0	500	0	ms	---
OB34:	0	200	0	ms	---
OB35:	12	100	0	ms	---
OB36:	0	50	0	ms	---
OB37:	0	20	0	ms	---
OB38:	0	10	0	ms	---

OK Cancel Help

- This means that a value of 200 must be entered for ***F_WD_Time***.


In order that SINAMICS G120 can use the safety functions in the safety program, symbolic addresses must be assigned for the inputs and outputs of the **PROFIsafe module**.

The input window for the symbolic addresses is opened by selecting the PROFIsafe module in the HW-Config, pressing the righthand mouse key and selecting **Edit symbols...**



Only the inputs and outputs listed in this example are relevant for communications.

6.1.3.2 Standard Telegram




Various pre-assigned telegrams are available for this communication; these can be selected from the hardware catalog (refer to Capture 6.1.3).

The **Standard Telegram 352** is used in this function example. It contains a length of 6 words sending (output) and receiving (input) – beginning from starting address **256**.

6.2 Functions of the Step 7 program (without safety program)

6.2.1 Program overview



The Step 7 program essentially comprises blocks FB10, FC100 and DB1 that are called in the cyclic program (OB1).

6.2.2 DB1, Axis_DB

The Axis_DB represents the interface between the S7 program and the SINAMICS G120 via FC100.

Axis_DB is generated from **UDT 1 (Axis_DB_G120)**

Principal structure of Axis_DB:

Address	Symbolic name	Type	Function
Internal data			
DBW0	Basic_Data.Moduleaddress	INT	I/O start address of the SINAMICS G120 (refer to HW Config)
DBB3	Basic_Data.Drivetyp	Byte	Drive type, must be 2
S7 -> SINAMICS G120			
DBW4	Control_signals.STW2	Bool	Control word 2 (for details, refer to the S7 program)
DBW6	Control_signals.STW1	Bool	Control word 1 (for details, refer to the S7 program)
DBW8	Control_signals.Frequency_set	INT	Frequency setpoint in x.x %
DBW10	Control_signals.Torque_set	INT	Torque setpoint in x.x %
SINAMICS G120 -> S7			
DBW14	Status_signals.ZSW2	Bool	Status word 2 (for details, refer to the S7 program)
DBW16	Status_signals.ZSW1	Bool	Status word 1 (for details, refer to the S7 program)
DBW18	Status_signals.Actual_frequency	INT	Frequency actual value in x.x %
DBW20	Status_signals.Actual_current	INT	Current actual value (Value from SINAMICS G120)
DBW22	Status_signals.Actual_current_A	INT	Current actual value in x.xx A
Error messages			
DBW24	Faults.Drive_error_number	INT	Actual error number of the SINAMICS G120
DBW26	Faults.Drive_alarm_number	INT	Actual alarm number of the SINAMICS G120

In this function example the individual data of the DB1 are supplied in FB10.

6.2.3 FB10, Organization

This block is called-up in absolute terms in OB1 and in turn calls up FC100.

Principle of the FB10

Network	Function
1	Calls the FB11 to generate the frequency setpoint
2	Controls the SINAMICS G120 via the axis-DB, DB1.
	Calls the SINAMICS G120 control block FC100.
	Provides the feedback signals – incl. error and alarm number
	This network can be used as template for additional SINAMICS G120 control functions.
3	Controls the signal lamp for "Safety function activated or fault active".

6.2.4 FC100, Control of SINAMICS G120

SINAMICS G120 is controlled using the FC100 via PROFINET.

Only signals from the Axis_DB are used to control the block - but no fixed addresses - this is the reason that instances can be used.

This block can be used in the same way for both a standard and a Safety SINAMICS G120.

Formal operands of the FC100

Formal operands	Type	Description
Nr_Axis_DB	IN	Number of the Axis-DB generated using UDT1
Internal_Error	OUT	Displays an internal error 0 = no error 1 = incorrect Axis-DB type (wrong UDT)

Principle structure of the FC100


Network	Function
1	Opens the Axis_DB specified using the formal operands Nr_Axis_DB .
	Generates the internal error message.
2	Reads-in the SINAMICS G120 status words, processes these and saves them in the Axis_DB.
3	Resets internal error messages.
4	Converts frequency and torque setpoint from the Axis_DB (entered in x.x %) into the SINAMICS G120 format (hex).
5	Enters SINAMICS G120 error and alarm number into the Axis_DB.
6	Sends control words from the Axis_DB to the SINAMICS G120

6.3 Functions of the Step 7 safety program

The basic programming of Distributed Safety - the S7 programming tool for F control systems - is not discussed in this function example.

This function example only explains and discusses the FB201 user block for safety functions.

6.3.1 Program overview



6.3.2 FB201, Safety program

The individual safety sensors are read into the FB201, interlocked with one another (logically combined) and the SINAMICS G120 safety functions controlled.

It is necessary to enter the safety password to process/handle the FB201. This password is **siemens**.

Principle structure of the FB201

Network	S7-Program	Function
1		<p>Safe Torque Off (STO) Reads-in the Emergency Stop pushbutton Safety_PB_STO (I 24.0), logically interlocked using the F-Standard block FB215 (F_ESTOP1) and forms auxiliary flag No_STO</p> <p>Acknowledges the safety function</p>
2		<p>Safe Stop 1 (SS1) Reads-in the Emergency Stop pushbutton Safety_PB_SS1 (I 24.1), logically interlocked using the F-Standard block FB215 (F_ESTOP1) and forms auxiliary flag No_SS1</p> <p>Acknowledges the safety function</p>
3		<p>Controls the SINAMICS G120 safety function STO (Q 14.0).</p>
4		<p>Controls the SINAMICS G120 safety function SS1 (Q 14.1).</p>
5		<p>Controls the SINAMICS G120 safety function SLS (Q 15.0). With the introduction of firmware V3.2 - in addition to the previous bit 8 (Q15.0), bit 4 (Q14.4) has been inserted to control the SLS safety function. Bit 4 is in conformance with PROFIsafe. The parameter assignment is used to define as to whether the original or the new bit is used (refer to Chapter 4.6.2.2). You can delete the bit that is not used in your program.</p>

Copyright © Siemens AG 2010 All rights reserved SD_FE_I_005_V20_EN.doc

Network	S7-Program	Function
6	<pre> "FO0014_ PROFIsafe" .ACK_REI #ACK --- & --- = </pre>	Acknowledges passivation and safety communication errors between the S7-CPU and the SINAMICS G120.
7	<pre> "ACK_error" POS #FM_ACK_nonsafe --- M_BIT Q --- = "FO0024 DI24xDC24V .ACK_REI </pre>	Acknowledges passivation and safety communication errors between the S7-CPU and the safety digital input module SM326.
8	<pre> #No_STO --- & --- = #No_SS1 --- "Safety->S7_RS_c" </pre>	No STO and no SS1 → standard program.
9	<pre> #ACK --- & --- = "Safety->S7_ACK_RS" </pre>	Signal "Emergency Stop acknowledge" → standard program.
10	<pre> "Safety_G120->S7_STO_PR" --- & --- = "Safety->S7_G120_STO" </pre>	Feedback signal STO / Power removed from SINAMICS G120 → standard program. Instead of being transferred to the standard program it goes without saying that this signal can be used in the safety program.
11	<pre> "Safety_G120->S7_SS1" --- & --- = "Safety->S7_G120_SS1" </pre>	Feedback signal SS1 from SINAMICS G120 → standard program. Instead of being transferred to the standard program it goes without saying that this signal can be used in the safety program.
12 and 13	<pre> "Safety_G120->S7_SLS_V1" --- & --- = "Safety->S7_G120_SLS_V1" "Safety_G120->S7_SLS_V2" --- & --- = "Safety->S7_G120_SLS_V2" </pre>	Feedback signal SLS (original PROFIsafe telegram = network 12, signal in conformance with PROFIsafe = network 13) from SINAMICS G120 → Standard program. In your program you can delete the network that is not being used. Instead of being transferred to the standard program it goes without saying that this signal can be used in the safety program.

Copyright © Siemens AG 2010 All rights reserved
SD_FE_I_005_V20_EN.doc

6.4 SINAMICS G120 - parameterization the safety functions

Refer to Chapter 4.6.2, SINAMICS G120 parameterization


6.5 SINAMICS G120 parameterization

In order that the basic SINAMICS G120 functions can be parameterized, the safety functions in the S7-CPU and in the drive inverter itself must already have been commissioned.

The reason for this is that during parameterization a motor identification routine is carried-out (the motor and cables are measured) - and if vector control is activated - the controller is optimized. Both of these functions require that the safety functions are in the ready state.

6.5.1 SIMATIC Manager - inserting SINAMICS G120

- In SIMATIC Manager select the tree **G120_Safety_App_1** and using **Insert > Program > SINAMICS** select a **SINAMICS G120** type object.



- Make the following settings and press the **OK** button.

Insert single drive unit

General | Drive Unit / Bus Address

Device family: SINAMICS

Device: SINAMICS G120

Device characteristic:

Characteristic	Order no.
CU230P-2 CAN	6SL3 243-xxxx0-xCxx
CU230P-2 DP	6SL3 243-xxxx0-xPxx
CU230P-2 HVAC	6SL3 243-xxxx0-xHxx
CU240	6SL3 244-xxxxx-xxxx

Version: 3.2x

Online access: IP


Address: 192.168.0.2

Slot: 2


OK Cancel Help

6.5.2 Calling the STARTER parameterization tool

- Starting from the main path of the SIMATIC Manager, start the STARTER parameterization software by selecting **SINAMICS_G120** and double click on **Inbetriebnahme**.



- Then, in the Project Navigator of the STARTER parameterization software select the object **G120 (1)** and press button  **(2.)** to establish an online connection to the drive inverter.




6.5.3 STARTER - carrying out quick commissioning

- The screen form with the actual configuration is opened by double clicking on **Configuration** in the Project Navigator.
- The quick commissioning Wizard is started after pressing the **Wizard...** button.
- Enter the appropriate values into the **Control structure** to **Encoder** screen forms. You can call-up corresponding help texts in the individual screen forms by pressing on the **Help** button.
- In the screen form **Drive functions**, select for **Motor identification**, the function **Ident. of al param. in standstill incl. the saturation curve (3)**.
- Enter the corresponding parameters into the **Important parameters** screen form.


- In the screen form **Calculation of the motor data**, select **Restore factory setting and calculate motor data**.
- In the screen form **Summary** do not activate the function **RAM -> ROM**, but instead press the **Finish** button.

6.5.4 STARTER - carrying out a motor identification routine

- After completing the quick commissioning, alarm **A0541** (Motor data-identification active) is displayed. Please carefully note that when starting the motor identification routine current flows in the motor. For hanging (suspended) axes the load must always be supported.
- To start the motor data identification routine, in the Project Navigator select the menu item **Commissioning** and activate by double clicking on **Control panel**.




- Press **Assume control priority** and carefully note the security/safety information and instructions. Then activate **Enables**.




- **1.)** If the Control panel isn't completely displayed on your PG/PC, then press the  button.
- The motor data identification routine is started by pressing the  button. Do not exit the STARTER software and go to another task as otherwise the motor data identification routine will be interrupted for safety reasons.
- Please wait until the  button changes back to the  button.
- Return the control priority to the S7 control by pressing the **Give up control priority!** button.

6.5.5 STARTER - setting the Profinet communications


- Communications between the CPU and the SINAMICS G120 must then be parameterized. To do this, open the screen for the communication settings using **Communication** -> **Profinet**. Select the tab **Transmit direction**.
- To start, select the **Standard-Telegram 350 (350)** from **Message frame: (1.)**. This pre-assigns the telegram.



- Then replace telegram 350 by telegram type **Free BICO connection (999) (1.)**. Deactivate any possibly active **Suppress inactive interconnections** function **(2.)** and establish the following interconnections **(3.)**:
 - PZD 5 = r2131 (Last fault number code)
 - PZD 6 = r2132 (First warning number code)



- Finally, you only have to save the SINAMICS G120 configured software in the ROM memory of the drive inverter. To do this in the Project Navigator select the menu item **G120**



- In the function bar press the  button.
- Please wait until the download operation has been completed.

7 Evaluation according to IEC 62061 and ISO 13849-1

With this function example two Safety Evaluation Tool projects for each standard are provided.

IEC 62061: SD_FE_I_005_V20_EN_IEC.set

ISO 13849-1: SD_FE_I_005_V20_EN_ISO.set

Link to the Safety Evaluation Tool:

www.siemens.com/safety-evaluation-tool

8 Appendix

8.1 Reference data

This list is in no way complete and only reflects a selection of suitable references.

Subject area	Title
Application sample	Safety INTEGRATED Order-No.: 6ZB5310-0MK01-0BA2

8.2 Internet link data

Subject area	Title
Link to safety items	http://support.automation.siemens.com/WW/view/en/20810941
SINAMICS G120 Documentation	http://support.automation.siemens.com/WW/view/en/22339653/133300
Siemens customer support homepage	Customer Support
Safety integrated homepage	Safety Integrated
SINAMICS G120 Homepage	http://www.automation.siemens.com/sd/sinamicsg120/index_00.htm
Safety Evaluation Tool	www.siemens.com/safety-evaluation-tool

8.3 History

Version	Datum	Change
V1.0	October 2006	First edition
V2.0	June 2010	General reworking of the document Changeover to firmware V3.2 Expanded functionality for evaluation according to IEC 62061

8.4 Evaluation / feedback

I DT MC PMA APC
D-91506 Erlangen

Fax.: 09131 98 – 1297

Mail: Online-support.automation@siemens.com

--

<p>Sender Name: Department: Location: Telephone: Internet address:</p>	<p>If you came across errors when reading this document please let us know using this form. We'd also be thankful for any suggestions and recommendations for improvement.</p>
--	--

Evaluation of the function example

Extremely good Good

Not so good because

.....

Subject of interest Subject not interesting

Scope sufficient Too detailed Too superficial

Understandable Sometimes understandable Not understandable

Good layout Average layout Poor layout

Often used Infrequently used Used only once

Time saving by using the document when compared to before:

No time saving approx. 5% approx. 10% other.....%

Suggestions:

.....