

SIEMENS

SIMATIC

Industrial PC SIMATIC IPC547E

Operating Instructions

Preface

Overview

1

Safety instructions

2

Installing and connecting the device

3

Commissioning the device

4

Expanded device functions

5

Expanding and assigning parameters to the device

6

Device maintenance and repair

7

Technical specifications

8

Technical support

A

List of abbreviations

B

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.
NOTICE
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

These operating instructions contain all the information you need for commissioning and operation of the SIMATIC IPC547E.

It is intended both for programming and testing personnel who commission the device and connect it with other units (automation systems, programming devices), as well as for service and maintenance personnel who install add-ons or carry out fault/error analyses.

Basic knowledge required

A solid background in personal computers and Microsoft operating systems is required to understand this manual. General knowledge in the field automation control engineering is recommended.

Validity of the Operating Instructions

These operating instructions are valid for all supplied versions of the SIMATIC IPC547E.

Scope of this documentation

The documentation for the SIMATIC IPC547E includes the following sections:

- Product Information "Important notes on your device"
- Quick Install Guide SIMATIC IPC547E
- SIMATIC IPC547E operating instructions in English and German

The documentation is part of the "Documentation and Drivers" DVD supplied with the product.

Refer to the corresponding user documentation for information and instructions on using software.

Conventions

The terms "PC" or "device" are sometimes used in place of the product name SIMATIC IPC547E in these operating instructions.

History

Currently released versions of these operating instructions:

Version	Comments
09/2013	First edition
02/2014	Second edition, amendment: SIMATIC IPC547E with short enclosure
03/2015	Third edition, amendment: Windows Server 2012 R2

Table of contents

	Preface	3
1	Overview.....	9
1.1	Product description	9
1.1.1	Scope of application.....	10
1.1.2	Highlights	10
1.2	Device configuration	14
1.2.1	Interfaces	16
1.2.2	Operator controls	18
1.2.3	Status displays.....	20
1.3	Accessories.....	22
2	Safety instructions.....	25
2.1	General safety instructions	25
2.2	Notes on use.....	30
3	Installing and connecting the device	33
3.1	Preparing for installation	33
3.1.1	Checking the delivery package.....	33
3.1.2	Device identification data.....	35
3.2	Mounting the device.....	36
3.2.1	Installation guidelines.....	36
3.2.2	Mounting location and position	37
3.3	Connecting the device	39
3.3.1	Connection information.....	39
3.3.2	Connection of equipotential bonding	41
3.3.3	Connecting the power supply	42
3.3.4	Connecting peripheral equipment.....	45
3.3.5	Connecting the device to networks.....	46
3.3.6	Multi-monitoring	47
4	Commissioning the device	49
4.1	General information on commissioning	49
4.2	Switching on the device	49
4.3	Automatic switching on of the device.....	50
4.4	Notes on various device configurations	50
4.4.1	DVD burner drive	50
4.4.2	Hard disks in removable rack	51
4.4.3	System with two drives	53

4.4.4	RAID systems	54
4.4.4.1	Manage RAID system	54
4.4.4.2	RAID1 system	55
4.4.4.3	RAID5 system	55
4.4.4.4	RAID system with hot spare drive	55
4.5	Windows Action Center	56
4.6	Switching off the device	56
5	Expanded device functions	59
5.1	Monitoring functions	59
5.1.1	Temperature monitoring and temperature display	60
5.1.2	Fan monitoring	61
5.1.3	Watchdog (WD).....	61
5.1.4	Battery monitoring	62
5.1.5	Drive monitoring	62
5.2	Trusted Platform Module (TPM).....	64
6	Expanding and assigning parameters to the device	65
6.1	Opening the front door	65
6.2	Remove the fan cover	66
6.3	Open the device	66
6.4	Memory expansion.....	68
6.5	Installing expansion cards.....	68
6.6	Drives	69
6.6.1	Removing and installing the drive cage	69
6.6.2	Removing and installing the hard disk drive from the removable drive bay	71
6.6.3	Removing and installing an internal hard disk	74
6.6.4	Replacing a defective hard disk drive in the RAID system	76
6.6.5	Installing a 5.25" front hard disk drive	79
6.6.6	Removing and installing a DVD drive	80
7	Device maintenance and repair.....	83
7.1	Repair information.....	83
7.2	Maintenance.....	84
7.2.1	Maintenance intervals	84
7.2.2	Replacing filters.....	84
7.3	Manage onboard RAID system.....	85
7.3.1	Example for a RAID1 system during the boot phase of the system	85
7.3.2	Example for a RAID5 system during the boot phase of the system	86
7.3.3	RAID software	86
7.3.4	Checking the status of the RAID system	87
7.3.5	Displaying a defective hard disk of a RAID system in the RAID software.....	87
7.3.6	Special feature: Replacing hard disk in the RAID system when switched off	88
7.3.7	Integrating a new hard disk drive in the RAID system	89
7.3.8	Integrating a hot spare hard disk drive in the RAID system	91

7.4	Removing and installing hardware.....	92
7.4.1	Removing the device fan	92
7.4.2	Replacing the backup battery	94
7.4.3	Removing the power supply	95
7.4.4	Removing module of the redundant power supply	96
7.4.5	Removing the enclosure of the redundant power supply from the module	96
7.4.6	Removing the motherboard	97
7.4.7	Replacing the processor	99
7.5	Installing the software	101
7.5.1	Sources for installation of the operating system	101
7.5.2	Updating the operating system	101
7.5.3	Installing drivers and software	102
7.5.4	Installing Windows	102
7.5.5	Setting up the language selection using the Multilanguage User Interface (MUI)	107
7.5.6	Restoring the delivery state	109
7.5.7	Installing onboard RAID controller software	111
7.5.8	Backing up data and changing partitions at a later time	111
8	Technical specifications	113
8.1	Certificates and approvals	113
8.2	Directives and declarations.....	115
8.2.1	CE marking	115
8.2.2	ESD guideline	115
8.3	Dimension drawings.....	118
8.3.1	Dimension drawing of the device.....	118
8.3.2	Dimension drawing of the expansion cards	119
8.3.3	Dimension drawing of the telescope rails	120
8.4	Technical specifications	121
8.4.1	General technical specifications	121
8.4.2	Current and power requirements	127
8.4.3	AC power supply.....	128
8.4.4	AC power supply, redundant	129
8.4.5	Technical specifications of the telescopic rails	129
8.5	Hardware description	130
8.5.1	Motherboard.....	130
8.5.2	System resources	130
8.5.3	Interrupt assignment	131
8.6	BIOS description	133
8.7	Active Management Technology (AMT)	134
8.7.1	AMT basics	134
8.7.2	Overview of AMT	135
8.7.3	Activate AMT.....	135
8.7.4	Advanced settings.....	136
8.7.5	Reset AMT with Unconfigure ME.....	137
8.7.6	Determining the network address	137
8.7.7	Forcing user consent	138
8.8	Assignment of expansion interface to the software in the TIA Portal (CP assignment)	138

A	Technical support.....	139
A.1	Service and support	139
A.2	Troubleshooting	140
A.3	RAID system and device startup.....	141
A.4	Notes on the use of third-party modules	143
B	List of abbreviations	145
	Glossary	149
	Index	155

Overview

1.1 Product description

Note
Depending on the configuration ordered the features and illustrations described in this manual may differ from the features of your device.

The SIMATIC IPC547E is a powerful industrial PC in 19" rack format design (4 HE). It is perfectly suited for high-performance industrial PC applications.

- Maximum performance
- Attractive price

SIMATIC IPC547E (enclosure depth 446 mm)



SIMATIC IPC547E with short enclosure (enclosure depth 356 mm)



1.1.1 Scope of application

The SIMATIC IPC offers system integrators, cabinet designers, system engineers and machine designers a 19" rack PC platform for high-performance applications and IT applications on the control and cell level for:

- Process and visualization applications
- Industrial image processing
- Quality assurance and monitoring tasks
- Measurement, control and rule-based tasks
- Data acquisition and management

The SIMATIC IPC has CE certification for use in the industrial sector as well as in residential and commercial areas and small businesses. In addition to the industrial applications, therefore, it can also be used in building automation or in public facilities.

1.1.2 Highlights

Highlights

The latest PC technology

- State-of-the-art Intel® technology, 4th Generation Intel® Core™ i processors
- High performance and scalability
- Expansion card slots
2 × PCIe x16, 1 × PCIe x8, 4 × PCI
- Solid State Drive (SSD) included in scope of delivery

Industrial compatibility

- Dust protection
- Service-friendly
- CE certification for industrial and office use
- Transport safety for expansion cards
- Monitoring functions

Security of investment

- Guaranteed spare parts availability for at least 3 years

High system availability

- SIMATIC PC DiagMonitor – PC diagnostics and message software via OPC/SNMP/LAN
- Preventative data backup with the SIMATIC IPC Image & Partition Creator
- RAID configurations: RAID controller onboard
- RAID1 – Disk mirroring on two drives, "hot swap" in connection with SATA removable drive bays
- RAID5 – Striping with parity on three drives, "hot swap" in connection with SATA removable drive bays
- Redundant power supply

Features**Note****Please take note of the version ordered**

Depending on the configuration ordered the features and illustrations described in this manual may differ from the features of your device.

Basic data

	SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
Design	<ul style="list-style-type: none"> • 19" rack, 4 HU • Robust full metal case, lacquered outside (optional) and coated inside • Prepared for mounting telescopic rails • Can be installed in a horizontal and vertical position • Tower setup with tower kit • Lockable front door as access protection 	<ul style="list-style-type: none"> • 19" rack, 4 HU • Robust full metal case, coated inside and outside • Prepared for mounting telescopic rails • Can be installed in a horizontal position
Enclosure	<ul style="list-style-type: none"> • Dust protection by means of overpressure ventilation using bearing seated front fan through filter • Card retainers secure PC modules for transport (vibration, shock) 	
Drive bays	<ul style="list-style-type: none"> • On the front: <ul style="list-style-type: none"> – 3 × 5.25" or – 1 × 5.25" and maximum 3 × slimline removable drive bay or – 4 × slimline removable drive bay and – 1 x slimline format for DVD burner • Internal: <ul style="list-style-type: none"> – 2 x 3.5" 	

1.1 Product description

	SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
Expansion card slots	<ul style="list-style-type: none"> • 4 × PCI • 1 × PCIe x16 (4 lanes) • 1 × PCIe x8 (1 lane) • 1 × PCIe x16 <p>You can use expansion cards with a length of up to 312 mm.</p>	<ul style="list-style-type: none"> • 4 × PCI • 1 × PCIe x16 (2 lanes) • 1 × PCIe x8 (1 lane) • 1 × PCIe x16 <p>You can use expansion cards with a length of up to 260 mm.</p>
Power supply	100V to 240V AC	
Power supply, redundant	2 × 100V to 240V AC	-
Interfaces	See chapter "Interfaces (Page 16)".	

Monitoring and safety functions

	SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
Temperature	<ul style="list-style-type: none"> • Violation of high/low limits of permitted operating temperature 	
Fan	<ul style="list-style-type: none"> • Speed monitoring 	
Watchdog	<ul style="list-style-type: none"> • Monitoring functions for program execution • Monitoring time can be parameterized in software • Restart can be parameterized in the event of a fault • Warnings can be analyzed by application program (local, via LAN) 	
Status displays, front	<ul style="list-style-type: none"> • POWER – internal power supply available, PC switched on • HDD – access to hard disk • TEMP – temperature status • FAN – fan status • 4 × HDD alarm – drive status in connection with RAID and monitoring software 	<ul style="list-style-type: none"> • POWER – internal power supply available, PC switched on • HDD – access to hard disk • TEMP – temperature status • FAN – fan status
Status displays, rear	<ul style="list-style-type: none"> • Power supply, redundant 	-

Operating system

	SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
Operating system	<ul style="list-style-type: none"> • Without • Pre-installed, included on Restore DVD: <ul style="list-style-type: none"> – Microsoft Windows 7 Ultimate, 32-bit and 64-bit, MUI ¹ – Microsoft Windows Server 2008 R2, 64-bit including 5 clients, MUI ¹ – Microsoft Windows Server 2012 R2, 64-bit including 5 clients, MUI ¹ 	<ul style="list-style-type: none"> • Without • Pre-installed, included on Restore DVD: <ul style="list-style-type: none"> – Microsoft Windows 7 Ultimate, 32-bit and 64-bit, MUI ¹

¹ 5 languages (English, German, French, Italian, Spanish)

Operating system languages

The following languages for the operating system can be installed at a later time from the recovery DVD:

Language	Windows Server 2008 R2	Windows Server 2012 R2	Windows 7 32/64-bit
German (Germany)	X	X	X
English (United States)	X	X	X
French (France)	X	X	X
Italian (Italy)	X	X	X
Spanish (Spain)	X	X	X
Japanese (Japan)	X	X	X
Korean (Korea)	-	X	-
Russian (Russia)	X	X	X
Chinese (PRC)	X	X	X
Chinese (Hong Kong S.A.R.)	X	X	X
Chinese (Taiwan)	X	X	X


Optional software	
SIMATIC IPC DiagMonitor V4.4.3 or higher	Software tool for monitoring local and remote SIMATIC PCs: <ul style="list-style-type: none"> • Watchdog • Temperature • Fan • Battery • Hard disk monitoring (SMART, RAID status ¹)
SIMATIC IPC Image & Partition Creator V3.3.3 or higher	Software tool for local data backup and setting up of the hard disks.

¹ A hot-spare drive of a RAID system is not displayed.


1.2 Device configuration

Device front with open front door

SIMATIC IPC547E




SIMATIC IPC547E with short enclosure



- | | | |
|---|-----------------------------|--|
| ① | Fan cover | Fan cover with openings for ventilation of the device |
| ② | Status displays | See chapter "Status displays (Page 20)." |
| ③ | On/off button | See chapter "Operator controls (Page 18)." |
| ④ | 2 × USB 3.0 | Connections for USB devices, backward compatible with USB 2.0/1.1 |
| ⑤ | Optical drive | DVD burner drive |
| ⑥ | Mounting locations | For removable drive bays with drives (HDD or SSD) or for 5.25" drives |
| ⑦ | 1 to 4 removable drive bays | Depending on configuration, 1 to 4 removable drive bays with drives (HDD or SSD) |
| ⑧ | Front panel | Is removed for taking out and installing the internal hard disk drives |

Rear of the device

SIMATIC IPC547E



SIMATIC IPC547E with short enclosure




- | | |
|---|--|
| <ul style="list-style-type: none"> ① Power supply ② Air outlet ③ Interfaces ④ Dual-head graphics card ⑤ Expansion card slots | <p>See section "Interfaces (Page 16)", power supply connection</p> <p>See chapter "Interfaces (Page 16)."</p> <p>DMS59 connection of optional dual-head graphics card</p> <ul style="list-style-type: none"> • 4 × PCI • 2 × PCIe x16 • 1 × PCIe x8 |
|---|--|


1.2.1 Interfaces

Interfaces

SIMATIC IPC547E



SIMATIC IPC547E with short enclosure



- | | |
|---------------|--------------------------------|
| ① Mouse | Connection for a PS/2 mouse |
| ② Keyboard | Connection for a PS/2 keyboard |
| ③ 4 x USB 2.0 | Connections for USB devices |

④	DPP1 DPP2 or DPP1	Connection for monitors with DisplayPort interface
⑤	DVI-I	Connection for CRT or LCD monitor with DVI interface, VGA via DVI/VGA adapter (optional)
⑥	COM1	Serial interface 1 (V.24), 9-pin D-sub socket
⑦	LPT	Parallel interface, 25-pin (optional)
⑧	2 x USB 3.0	Connections for USB devices, backward compatible with USB 2.0/1.1
⑨	LAN 1 LAN 2 or LAN1	RJ45 Ethernet connections for 10/100/1000 Mbps ¹⁾ LAN 1 is iAMT capable (for SIMATIC IPC547E only)
⑩	2 x USB 2.0	Connections for USB devices
⑪	COM2	Serial interface 2 (V.24), 9-pin D-sub socket (optional)
⑫	Line in (blue) Line out (green) Microphone (pink)	Connection for analog audio source, 3.5 mm phono jack Connection for active speakers or headset, 3.5 mm phono jack Connection for microphone, 3.5 mm phono jack
⑬	Dual-head graphics card	DMS59 connection of optional dual-head graphics card

¹⁾ The Ethernet interfaces are numbered on the enclosure to identify them clearly. The numbering by the operating system may deviate from this.

Dual-head adapter for connection of two monitors to the optional graphics card



①	DMS59 connector	DMS59 connection
②	DVI-I connector	DVI-I connections
③	VGA connector	VGA connections

Power supply connections

The following figure shows the connections for the power supply for devices with single or redundant power supply.



1.2.2 Operator controls


<p>⚠ WARNING</p> <p>Risk of electric shock</p> <p>The on/off button and on/off switch do not fully disconnect the device from the mains. If the device is switched off with the on/off switch, there remains a risk of electric shock and fire hazard, for example, if the device or connection cables are damaged or if the device is used improperly.</p> <p>Always fully disconnect the device from the mains voltage as follows before performing work on the device or when the device will not be used over an extended period of time:</p> <ul style="list-style-type: none">• Pull the power plug on the rear of the device.• For control cabinet mounting: Take additional precautions, for example, by using a circuit breaker.
--

Read the information in section "Switching off the device (Page 56)".

On/Off switch and alarm reset button

The following figures show the location of the on/off switch on the rear of the device for devices with simple or redundant power supply.

The alarm reset button is only available for devices with redundant power supply.



- ① On/Off switch
- ② Alarm reset button can be used to switch off the warning signal

On/off button

The On/off button is located on the front of the device behind the front door and is used to start and shut down the operating system.

You can find additional information in the chapters "Switching on the device (Page 49)" and "Switching off the device (Page 56)."



1.2.3 Status displays

Front status displays

The status displays integrated in the front door provide information on the status of the device components listed in the following table.




Item	Status display	Meaning	LED	Description
①	POWER	Operating mode of the PC	OFF	Hibernate, switched off or disconnected from the mains
			GREEN flashing	Windows is in Standby mode
			GREEN	PC in operation
②	HDD	Access to hard disk	OFF	No access
			GREEN	Access
③	TEMP	Temperature status	OFF	No error
			RED flashing	Possible causes: <ul style="list-style-type: none"> • CPU temperature is critical • Device temperature is critical
④	FAN	Fan status	OFF	No error
			RED flashing	Possible causes: <ul style="list-style-type: none"> • CPU heat sink fan fault • Enclosure fan fault • Power supply fan fault
⑤	HDD0 Alarm	HDD alarm in connection with RAID and monitoring software	OFF	RAID is OK
⑥	HDD1 Alarm		A RED LED is lit up	The associated drive is not OK
⑦	HDD2 Alarm		All RED LEDs are flashing	RAID synchronization in progress
⑧	HDD3 Alarm		All RED LEDs are lit up	RAID is not OK The faulty drive could not be localized by the monitoring software. It may be possible to detect the defective drive with the RAID software, see chapter "RAID1 system (Page 55)", "RAID5 system (Page 55)" or "RAID system with hot spare drive (Page 55)".

Rear status displays

The following status displays are located on the rear of the device:

- LEDs of the Ethernet interface



Status display	Meaning	Status	Meaning of the status
LED 1 ¹	Connection status	OFF	<ul style="list-style-type: none"> • No cable connected • Cable disabled • Interface disabled
		GREEN	<ul style="list-style-type: none"> • Active cable connected
		GREEN, flashing	<ul style="list-style-type: none"> • Data transfer active
LED 2 ¹	Data transmission rate	OFF	<ul style="list-style-type: none"> • 10 Mbps
		GREEN	<ul style="list-style-type: none"> • 100 Mbps
		YELLOW	<ul style="list-style-type: none"> • 1000 Mbps

¹ For unique labeling, the Ethernet ports are numbered on the enclosure. The numbering by the operating system may deviate from this.

- Redundant power supply



The "Power" LED has the following meaning:

- Lights up green:
Power supply module is operating.
If there is no redundancy, you will hear an acoustic signal permanently. Redundancy is in effect when both power supply modules are operating.
- Not lit:
Power supply module is out of service.

1.3 Accessories

Accessories are available for your device. These are not included in the scope of delivery. Information on available accessories is listed in the table below and on the Internet at the following addresses:

- IPC expansion components (http://www.automation.siemens.com/mcms/pc-based-automation/en/industrial-pc/expansion_components_accessories)
- Industry Mall (<https://mall.industry.siemens.com>)

Name	Description	IPC547E	IPC547E short	Order No./MLFB
Retainer for locking the internal USB interface	<p>The retainer is a mechanical safety device for the internal USB interface. It optimizes the protection of an internal USB memory stick against loads caused by vibration and shock during transportation or operation.</p> <p>This increases the reliability and operational safety of the SIMATIC IPC547E.</p>	x	-	<p>6ES7648-1AA00-0XK0</p> 
Tower Kit	<p>You can use the Tower Kit to convert the SIMATIC IPC547E into an industrial Tower PC. This step expands the operating range beyond the control cabinet.</p> <p>Components of the Tower Kit:</p> <ul style="list-style-type: none"> • Cover • Feet • Accessories: Screws and rubber feet 	x	-	<p>6ES7648-1AA00-0XC0</p> 

Name	Description	IPC547E	IPC547E short	Order No./MLFB
Rack unit for low-profile swap frame	<p>The removable drive bay makes for quick and simple replacement of a 3.5" SATA hard disk without having to open the SIMATIC IPC547E or remove it from the control cabinet. The result is the following advantages for service and maintenance, data backup and data transfer:</p> <ul style="list-style-type: none"> • Replacement of a failed hard disk in operation ("hot-swap") • Downloading different system states or operating systems from different hard drives during a short period of time. • Simplified data backup by copying, for example, to a backup hard drive. • Simple transportation of backup data • Separate data storage and archiving possible 	x	-	6ES7648-0EG01-1BA0 
VGA / DVI adapter	Graphics adapter cable DVI-I to VGA, 250 mm long	x	x	6ES7648-3AB00-0XA0
DP / DVI adapter	Graphics adapter cable, DisplayPort to DVI	x	x	6ES7648-3AF00-0XA0 
DP / VGA adapter	Graphics adapter cable, DisplayPort to VGA	x	x	6ES7648-3AG00-0XA0 

Safety instructions

2.1 General safety instructions

Fully disconnecting the device from mains voltage

 WARNING
Risk of fire and electric shock
<p>The on/off button and on/off switch do not fully disconnect the device from the mains. If the device is switched off with the on/off switch, there remains a risk of electric shock and fire hazard, for example, if the device or connection cables are damaged or if the device is used improperly.</p>
<p>Always fully disconnect the device from the mains voltage as follows before performing work on the device or when the device will not be used over an extended period of time.</p>
<ul style="list-style-type: none">• If the device was not mounted in a control cabinet: Shut down the operating system and pull the power plug on the rear of the device.• If the device was mounted in a control cabinet: Shut down the operating system and switch the AC circuit breaker to "Off".• Properly connect the device to a protective conductor.

Devices in the control cabinet

 WARNING
Life-threatening voltages are present with an open control cabinet
<p>When you open the control cabinet, some areas or components may be carrying life-threatening voltages.</p>
<p>If you touch these areas or components, you may be killed by electric shock.</p>
<p>Switch off the power supply to the cabinet before opening it.</p>

System expansions

NOTICE

Damage to the device, machine or plant due to device and system expansions

Device and system expansions may contain faults and affect the entire device, machine or plant.

Device and system expansions may violate safety rules and regulations regarding radio interference suppression. If you install or replace device or system expansions and damage your device, the warranty is voided.

Note the following:

- Only install device or system expansions designed for this device. Contact your technical support team or the point of sale to find out which device and system expansions are suitable for installation.
- Please observe the information on electromagnetic compatibility in the technical specifications.

CAUTION

Fire hazard due to overheating of the device

Expansion cards generate additional heat. The device can overheat or cause a fire.

- Observe the safety and installation instructions for the expansion cards.
- If necessary, install the device in an enclosure that meets the requirements of paragraphs 4.6 and 4.7.3 of the standards EN 60950-1:2006 and IEC/UL/EN/DIN-EN 60950-1.

Battery

 WARNING
Risk of explosion and release of harmful substances Improper handling of lithium batteries can result in an explosion of the batteries. Explosion of lithium batteries and the released pollutants can cause serious physical injury. Damaged batteries jeopardize the function of the device. Note the following when handling lithium batteries: <ul style="list-style-type: none">• Replace used batteries in good time; see the section "Replacing the backup battery" in the section "Device maintenance and repair".• Replace the lithium battery only with an identical battery or types recommended by the manufacturer (order no.: A5E00369854).• Do not throw lithium batteries into fire, do not solder on the cell body, do not recharge, do not open, do not short-circuit, do not reverse polarity, do not heat above 100°C and protect from direct sunlight, moisture and condensation.

Strong high-frequency radiation

NOTICE
Observe immunity to RF radiation The device has an increased immunity to RF radiation according to the specifications on electromagnetic compatibility in the technical specifications. Radiation exposure in excess of the specified immunity limits can impair device functions, result in malfunctions and therefore injuries or damages. Read the information on immunity to RF radiation in the technical specifications.

ESD directive



Electrostatic sensitive devices can be labeled with an appropriate symbol.

NOTICE
Electrostatic sensitive devices (ESD) When you touch electrostatic sensitive components, you can destroy them through voltages that are far below the human perception threshold. If you work with components that can be destroyed by electrostatic discharge, observe the ESD directive in the technical specifications.

Industrial Security

Siemens offers products and solutions with Industrial Security functions that support the safe operation of equipment, solutions, machines, devices and/or networks. They are important components in a comprehensive Industrial Security concept. As a result the products and solutions from Siemens are constantly evolving. Siemens recommends obtaining regular information regarding product updates.

For safe operation of Siemens products and solutions appropriate protective measures (e.g., cell protection concept) must be taken and each component must be integrated in a comprehensive Industrial Security concept, which corresponds with the current state of technology. The products of other manufacturers need to be taken into consideration if they are also used. You can find addition information on Industrial Security under (<http://www.siemens.com/industrialsecurity>).

Sign up for our product-specific newsletter to receive the latest information on product updates. For more information, see under (http://www.siemens.de/automation/csi_en_WW).

Disclaimer for third-party software updates

This product includes third-party software. Siemens AG only provides a warranty for updates/patches of the third-party software, if these have been distributed as part of a Siemens software update service contract or officially released by Siemens AG. Otherwise, updates/patches are undertaken at your own risk. You can find more information about our Software Update Service offer on the Internet at Software Update Service (<http://www.automation.siemens.com/mcms/automation-software/en/software-update-service/Pages/Default.aspx>).

Notes on protecting administrator accounts

A user with administrator privileges has extensive access and manipulation options in the system.

Therefore, ensure there are adequate safeguards for protecting the administrator accounts to prevent unauthorized changes. To do this, use secure passwords and a standard user account for normal operation. Other measures, such as the use of security policies, should be applied as needed.

Access protection

 CAUTION
<p>Protection against access by unauthorized persons</p> <p>An unauthorized user can operate the device incorrectly and bypass logon by restarting the device.</p> <p>Operator actions by unauthorized persons jeopardize operational reliability.</p> <p>Take the following safety precautions:</p> <ul style="list-style-type: none">• Lock the front door and the removable drive bay.• Do not use keyboards with an on/off button (Power button).• If the device has a on/off button, assign the parameters of the function of the on/off button to meet your requirements under Windows. You can find the settings in the "Power Options" menu.

Headphones

 CAUTION
<p>Impaired hearing due to excessive sound pressure</p> <p>The setting of the volume and the equalizer can increase the sound pressure in the headphones. Other factors not mentioned by the manufacturer can also influence the sound pressure, for example, the operating system, equalizer software, firmware and driver.</p> <p>Excessive sound pressure from headphones can result in impaired hearing or even loss of hearing.</p> <p>Set the volume control and equalizer to the lowest value before you put on the headphones. Keep checking the volume control setting. Only use headphones and software approved by the manufacturer.</p>

2.2 Notes on use

NOTICE
Possible functional restrictions in case of non-validated plant operation
The device is tested and certified on the basis of the technical standards. In rare cases, functional restrictions can occur during plant operation.
Validate the correct functioning of the plant to avoid functional restrictions.

NOTICE
Rack-mount instructions
A) Elevated Operating Ambient - If installed in a closed or multi-unit rack, the operating ambient temperature of the rack environment may be greater than the room ambient. Therefore consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T _{ma}) specified by the manufacturer.
B) Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
C) Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
D) Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
E) Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e. g. use of power strips).

Note

Use in an industrial environment without additional protective measures

This device was designed for use in a normal industrial environment according to IEC 60721-3-3.

Ambient and environmental conditions

WARNING

Voided approvals

If the following conditions for system installation are not observed, approvals in accordance with UL 60950-1 and EN 60950-1 are rendered void and there is a risk of overheating and personal injury.

NOTICE

Damage of device caused by ambient conditions

Ambient conditions for which the device is not suitable can cause faults or damage the device.

Note the following:

- Operate the device only in closed rooms. Failure to comply nullifies the warranty.
- Operate the device only in accordance with the ambient conditions.
- Observe the permitted mounting positions of the device.

When you plan your project, you should make allowances for:

- Climatic and mechanical environmental conditions defined in the "General technical data" chapter of the operating instructions.
- This device was designed for use in a normal industrial environment. SIMATIC Rack PCs may not be operated in severe environments which are subject to caustic vapors or gases without taking additional protective measures (such as the provision of clean air.)
- Avoid extreme ambient conditions as far as possible, for example, heat.
- Do not expose the device to direct sunlight or other powerful light sources.
- Install the device in such a way that it poses no danger, for example, by falling over.
- Always maintain a minimum clearance of 50 mm to the area of the ventilation slots in order to ensure adequate ventilation of the PC.
- Do not cover the ventilation slots of the enclosure. There must be distance of at least 5 cm at the back of the device, depending on wiring.
- The device meets requirements for fire protection housings to EN 60950-1 and can be installed without additional fire protection enclosure.
- The connected or built-in peripherals should not introduce a counter emf in excess of 0.5 V into the device.
- The device conforms to protection class IP30 at the front panel. Ensure that the installation opening for the device is splash-proof in areas which may be subject to splash water.

Installing and connecting the device

3.1 Preparing for installation

3.1.1 Checking the delivery package

Procedure

1. When accepting a delivery, please check the packaging for visible transport damage.
2. If any transport damage is present at the time of delivery, lodge a complaint at the shipping company in charge. Have the shipper confirm the transport damage immediately.
3. Unpack the device at its installation location.
4. Keep the original packaging in case you have to transport the unit again.

Note

Damage to the device during transport and storage

If a device is transported or stored without packaging, shocks, vibrations, pressure and moisture may impact the unprotected unit. Damaged packaging indicates that ambient conditions have already had a massive impact on the device and it may be damaged.

This may cause the device, machine or plant to malfunction.

- Keep the original packaging.
- Pack the device in the original packaging for transportation and storage.

-
5. Check the contents of the packaging and any accessories you may have ordered for completeness and damage.

3.1 Preparing for installation

- Please inform the delivery service immediately if the package contents are incomplete or damaged or do not correspond with your order. Fax the enclosed form "SIMATIC IPC/PG Quality Control Report".

 WARNING
Electric shock and fire hazard due to damaged device A damaged device can be under hazardous voltage and trigger a fire in the machine or plant. A damaged device has unpredictable properties and states. Death or serious injury could occur. Make sure that the damaged device is not inadvertently installed and put into operation. Label the damaged device and keep it locked away. Send off the device for immediate repair.

NOTICE
Damage from condensation If the device is subjected to low temperatures or extreme fluctuations in temperature during transportation, as is the case in cold weather, for example, moisture can build up on or inside the device (condensation). Moisture causes a short circuit in electrical circuits and damages the device. In order to prevent damage to the device, proceed as follows: <ul style="list-style-type: none">• Store the device in a dry place.• Bring the device to room temperature before starting it up.• Do not expose the device to direct heat radiation from a heating device.• If condensation develops, wait approximately 12 hours or until the device is completely dry before switching it on.

- Please keep the enclosed documentation in a safe place. It belongs to the device. You need the documentation when you commission the device for the first time.
- Write down the identification data of the device.

3.1.2 Device identification data


The device can be clearly identified with the help of this identification data in case of repairs or loss.

The following illustrations are examples. The data of your device may differ from the data in these examples.

- Rating plate


The rating plate is located on the inside of the front door for the SIMATIC IPC547E and on the rear panel of the SIMATIC IPC547E with short enclosure.

The rating plate of the SIMATIC IPC547E is shown below.



- COA label

The COA label (Certificate of Authenticity) is only provided with a pre-installed Windows operating system. Open the front door to check for the COA label.



- Component label

The component label is located inside the front door.

SIMATIC IPC547E		Slot 1
Order No.: 6AG4-104-3....-....		Slot 2
Serial No.: SVP...		Slot 3
Core i5 CPU ...		Slot 4
RAID1 (2x500GB ...		Slot 5
... GB DDR3 ...		Slot 6
DVD+/-RW		Slot 7
seriell (COM2) ...		
Windows Server 2008 ...		
110/230 VAC Industrie ...		
Onboard MAC-Adresses:		
Ethernet LAN 1: 000E8C8E81CE	Service & Support	
Ethernet LAN 2: 000E8C8E07C8	//www.siemens.com/asis	

Procedure

Identification date	Source	Value
Order number	Rating plate	6AG4104-3 ...
Serial number	Rating plate	S VP...
Manufacturing version	Rating plate	FS
Microsoft Windows Product Key	COA label	
Ethernet address 1, MAC address	BIOS setup > "Main" menu	
Ethernet address 2, MAC address (not for SIMATIC IPC547E with short enclosure)	or: Component label	

1. Copy the order number, serial number and manufacturing version in the table listed above.
2. Copy the Windows "Product Key" to the table.
3. Copy the Ethernet addresses from the component label to the table.

The Ethernet addresses can also be found in the BIOS setup (F2 key) under "Main > System Information", entries "LAN 1 MAC" and "LAN 2 MAC".

3.2 Mounting the device

3.2.1 Installation guidelines

 WARNING
<p>Danger, high voltage</p> <p>A high voltage may be present in the switchgear cabinet and could cause a dangerous electric shock.</p> <p>It may result in death or serious physical injury.</p> <p>Isolate the power supply to the switchgear cabinet before opening it. Ensure that the power to the switchgear cabinet cannot be turned on accidentally.</p>

<p>NOTICE</p>
<p>Fire hazard</p> <p>If you install the device in an unapproved mounting position or if you do not observe the ambient conditions, the device can overheat. UL approval and conformity with the low-voltage directive (EN 60950-1:2006 and DIN EN 60950-1:2006-11) become void.</p> <p>Overheating can cause a fire. Proper functioning of the device is no longer guaranteed.</p> <p>Before you install the device, note the following general installation information.</p>

Note

The device fulfills the requirements for a fire protection housing according to EN 60950-1. Therefore, it can be installed without additional fire protection.

- Install the device only in one of the described permitted mounting positions.
 - Provide adequate volume in the switchgear cabinet for air circulation and heat transport.
 - Do not cover the ventilation slots of the device. There must be distance of at least 5 cm at the back of the device, depending on wiring.
 - Ensure that the maximum air intake temperature directly in front of the air intake opening does not exceed the permitted temperature according to the technical specifications of the device. The maximum air intake temperature must be accounted for especially when sizing closed switchgear cabinets.
 - Install the device in such a way that it does not pose a danger, for example, by falling over.
-

Note

For more details, consult the "Technical Data" in the "Ambient conditions" chapter.

3.2.2 Mounting location and position

Mounting location

The device can be installed in control cabinets and 19" rack systems.

Mounting position

The devices can be installed in the following ways:

- Mounting with mounting brackets, horizontal
- Mounting on device stands, horizontal
- Tower setup, vertical (not for SIMATIC IPC547E with short enclosure):
You can order a Tower Kit for tower installation.
- Mounting on telescopic rails

When telescopic rails are used for mounting, the device can be withdrawn fully from the cabinet or rack. Note the information in section "Technical specifications of the telescopic rails (Page 129)".

⚠ CAUTION
Risk of physical injury
The device is too heavy to be mounted exclusively with the 19 inch brackets of the front panel. The device may fall down, injure people and get damaged.
Secure the device using additional measures. The mounting screws of the telescopic rails may not protrude more than 5 mm into the device.

Note

For vertical operation, mount the device on a horizontal base made of metal and secure it against falling. The following device stands are available from the Rittal company:


Rittal type TE 7000.620, Rittal type VR 5501.655, Rittal type DK 5501.655.

Please observe the instructions from the cabinet manufacturer.


Position of the mounting holes for angle brackets or telescopic rails

The dimensions for the mounting holes are listed in the chapter "Dimension drawing of the telescope rails (Page 120)".

Mounting holes for SIMATIC IPC547E



Mounting holes for SIMATIC IPC547E with short enclosure



3.3 Connecting the device

3.3.1 Connection information

 WARNING**Risk of fire and electric shock**

The on/off button and on/off switch do not fully disconnect the device from the mains. If the device is switched off with the on/off switch, there remains a risk of electric shock and fire hazard, for example, if the device or connection cables are damaged or if the device is used improperly.

Always fully disconnect the device from the mains voltage as follows before performing work on the device or when the device will not be used over an extended period of time.

- If the device was not mounted in a control cabinet: Shut down the operating system and pull the power plug on the rear of the device.
- If the device was mounted in a control cabinet: Shut down the operating system and switch the AC circuit breaker to "Off".
- Properly connect the device to a protective conductor.

 WARNING**Risk of lightning strikes**

A lightning flash may enter the mains cables and data transmission cables and jump to a person.

Death, serious injury and burns can be caused by lightning.

Take the following precautions:

- Pull out the power plug in good time when a thunderstorm is approaching.
- Do not touch mains cables and data transmission cables during a thunderstorm.
- Keep sufficient distance from electric cables, distributors, systems, etc.

Note

Make sure that the shockproof power outlet of the building installation is freely accessible and as close as possible to the device, especially when the power plug is secured with a locking power plug latch.

 WARNING
Operation only in TN networks The device is designed for use on a grounded power supply grid (TN networks per VDE 0100 Part 100 or IEC 60364-1). Operation with non-grounded or impedance-grounded networks (IT networks) is not permitted.
Rated voltage The permitted nominal voltage of the device must conform with local mains voltage.

I/O devices

NOTICE
Fault caused by I/O devices The connection of I/O devices can cause faults in the device. The result may be personal injury and damage to the machine or plant. Note the following: <ul style="list-style-type: none">• Connect only I/O devices which are approved for industrial applications in accordance with EN 61000-6-2/IEC 61000-6-2.• Non-hot-plug capable I/O devices may only be connected when the power supply to the device is switched off.
Damage through regenerative feedback Regenerative feedback of voltage to ground by a connected or installed component can damage the device. Connected or built-in I/Os, for example, a USB drive, are not permitted to supply any voltage to the device. Regenerative feedback is generally not permitted.

See also

Switching off the device (Page 56)

3.3.2 Connection of equipotential bonding

A low-impedance earth connection ensures that interference signals generated by external power supply cables, signal cables or other cables to the I/O devices are safely discharged to earth.

The equipotential bonding connection on a device has a large surface and makes contact over a large area. The equipotential bonding connection is identified by the following symbol:



Requirement

- T20 screwdriver

Procedure



1. Connect the identified equipotential bonding connection to the protective conductor of the control cabinet in which the device is installed.

The minimum cross-section of the equipotential bonding line is 2.5 mm².

3.3.3 Connecting the power supply

Please observe before connecting

 WARNING
Injury to persons or damage to property when operated on an incorrect power supply system
If you connect the device to an unsuitable power supply, the device receives voltages and currents that are too high or too low.
Injuries to persons, malfunctions or a damage to the device can result.
Note the following information regarding the power supply system:
<ul style="list-style-type: none">• The permitted nominal voltage of the device must correspond to the local mains voltage.• Do not operate the device via non-grounded or impedance-grounded networks (IT networks).• Operate the device only in grounded power networks (TN networks in accordance with VDE 0100, Part 300 or IEC 60364-3).

Note
Operation with uninterruptible power supply

An uninterruptible AC power supply (UPS) must be used when this device is operated with a PFC (Power Factor Correction) circuit that supplies a sinusoidal output voltage in normal and buffer mode.

UPS characteristics are described and classified in the standards EN 50091-3 or IEC 62040-3. Devices with sinusoidal output voltage in the normal and buffered mode are identified with the classification "VFI-SS-...." or "VI-SS-....".

Note

The power supply of the device contains a PFC (Power Factor Correction) circuit to conform to the EMC directive.

Country-specific information on supply voltage

230 V supply voltage outside of the USA and Canada

This device is equipped with a safety-tested power cord which may only be connected to a grounded shockproof power outlet. If you do not use the power supply cable, use a flexible cable with the following features:

- Conductor cross-section $\geq 0.82 \text{ mm}^2$
- Grounded safety plug 15 A, 250 V

The power supply cable must conform to the safety regulations of the country in which the devices are installed and bear the marks required in each case.

230 V supply voltage for the USA and Canada

Use a CSA or UL-listed power supply cable for operation in the United States and Canada. The connector must be compliant with NEMA 5-15.

120 V supply voltage


Use a flexible cable with UL approval and CSA marking as well as the following features:

- Type SJT with three conductors
- Conductor cross-section ≥ 18 AWG
- Cable length ≤ 4.5 m
- Parallel grounding-type plug 15 A, ≥ 125 V

240 V supply voltage

Use a flexible cable with UL approval and CSA marking as well as the following features:

- Type SJT with three conductors
- Conductor cross-section ≥ 18 AWG
- Cable length ≤ 4.5 m
- Tandem grounding-type plug 15 A, ≥ 250 V


Connecting an AC power supply

1. Make sure that the on-off switch ① is in the '0' (off) position.

This prevents unintentional startup of the device when you plug in the power cable.

2. Connect the power cable to socket ②.
3. Insert the power cable in the electrical socket.
4. Switch the on-off switch ① to on.

To prevent unintentional removal of the power cable, you can secure the plug as follows:



1. Remove the retaining screw ①.
2. Screw on the latch for the power plug ②.

Connecting a redundant power supply




1. Make sure that the on/off switch ① is in the '0' position.
2. Connect a power cable to the two sockets ④.
3. Switch on the two on/off switches ①.

The "Power" LEDs ② on the power supply modules light up green.

Note:

If only one of the power supply modules works, a warning signal sounds. You turn off the warning signal by pressing the ③ button on the working power supply module.

To prevent unintentional removal of the power cable, you can secure the power plug as follows:



1. Remove the retaining screws ①.
2. Screw on the latch for the power plug ②.

3.3.4 Connecting peripheral equipment

Note**Observe suitability for industrial applications**

Only connect I/O devices that are suitable for industrial applications in accordance with EN IEC 61000-6-2.

Note**I/O devices capable of hot-plugging (USB)**

Hot-plug I/O devices (USB) may be connected while the PC is in operation.

NOTICE**Non-hot-plug I/O devices**

I/O devices that do not support hot-plugging may not be connected until the device is powered off. Strictly adhere to the specifications in the I/O manuals.

Note

Wait at least ten seconds before you reinsert USB devices.

Note that the EMC immunity of standard USB devices is designed only for office environments. These USB devices are appropriate for handling commissioning and service tasks. Only industrial grade USB devices are permitted for use in industrial environments. The USB devices are developed and marketed by the respective supplier. The respective product supplier provides support for the USB devices. The manufacturer's terms of liability shall apply.

Note

A monitor should be connected and switched on before device booting to ensure it is correctly detected and run by the BIOS and the operating system. The screen may otherwise remain dark.

Note

The connected or built-in I/Os should not introduce a counter emf into the device.

A counter e.m.f. greater than 0.5 V to ground on the + 3.3 V DC / + 5 V DC / + 12 V DC due to a connected or integrated component can prevent normal operation or even destroy the computer.

When measuring the counter emf, remember the following:

- The computer in question must be turned off and the power supply connector must be plugged in.
 - During the measurement, all cables from the plant to the computer should be connected.
 - All other components in the plant must be active.
-

3.3.5 Connecting the device to networks

The following options are available for integrating the device into existing or planned system environments and networks.

Ethernet

Wake on LAN and Remote Boot are supported.

You can use the integrated Ethernet interfaces (10/100/1000 Mbps) for communication and data exchange with automation devices, such as SIMATIC S7.

You need the "SOFTNET S7" software package for this.

PROFINET

PROFINET can be operated via:

- Standard Ethernet interfaces (RT)

SIMATIC NET

Use this software package to create, operate and configure an innovative network for Field & Control level. Information on this can be found on the SIMATIC NET Manual Collection CD. The software package and the documentation are not included in the scope of delivery.

Additional information

You can find additional information on the Internet at: Technical Support (http://www.siemens.de/automation/csi_en_WW)

3.3.6 Multi-monitoring

You can simultaneously operate up to five monitors on the interfaces of the integrated graphics controller in combination with the optional graphics card: (with SIMATIC IPC547E short enclosure: up to 4 monitors). Parameter assignment is performed by means of the Control Panel in Windows.

The following monitors can be operated simultaneously on the motherboard:

SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
<ul style="list-style-type: none"> • 2 × DisplayPort, 1 × DVI • 2 × DisplayPort, 1 × VGA • 1 × DisplayPort, 1 × DVI via DisplayPort-DVI adapter ¹, 1 × DVI • 1 × DisplayPort, 1 × VGA via DisplayPort-VGA adapter ¹, 1 × VGA via DVI/VGA adapter ¹ • 1 × DVI via DisplayPort-DVI adapter, 1 × DVI via DisplayPort-DVI adapter ², 1 × DVI • 1 × VGA via DisplayPort-VGA adapter, 1 × VGA via DisplayPort-VGA adapter, 1 × VGA via DVI/VGA adapter <p>¹ available as accessories ² active DisplayPort-DVI adapter Detailed information is available in section "Accessories".</p> <p>Note: When using passive DisplayPort-DVI adapters a maximum of one additional DVI monitor can be connected to an existing DVI connector. There are no restrictions when using the active DisplayPort-DVI adapters.</p>	<ul style="list-style-type: none"> • 1 × DisplayPort, 1 × DVI • 1 × DisplayPort, 1 × VGA • 1 × DVI via DisplayPort-DVI adapter ¹, 1 × DVI • 1 × VGA via DisplayPort-VGA adapter ¹, 1 × VGA via DVI/VGA adapter ¹ <p>¹ available as accessories</p>

Commissioning the device

4.1 General information on commissioning

Requirements for commissioning

The following requirements have to be met before you can start commissioning:

- I/O devices, keyboard, mouse and monitor are connected.
- The power supply is connected.
- An operating system is installed.

The device can be supplied without an operating system. Information on installation of the operating system is available in the section "Installing the software (Page 101)".

4.2 Switching on the device

After the initial switch on, the operating system is set up automatically on the device.

NOTICE
Faulty installation
If you change the default values in the BIOS setup or if you turn off the device during installation, you disrupt the installation and the operating system is not installed correctly. The operating safety of the device and the plant is at risk.
Do not switch off the device during the entire installation process. Do not change the default values in the BIOS setup.

Procedure

1. Switch the on/off switch to position I. Information on the position of the switch is available in the section "Operator controls (Page 18)".
2. Press the on/off button.
The "POWER" LED lights up. The module carries out a self-test. Then Windows is started.
3. Follow the instructions on the screen.

The following steps are required only when switching on the device for the first time after delivery:

4. Make the required region and language settings.

If you want your system language to be international, select English. Information for subsequent changing of the region and language settings, see the section "Setting up the language selection using the Multilanguage User Interface (MUI) (Page 107)".

Note

Once the operating system has been set up, the device may restart.

5. Type in the product key as required.

The product key is located on the "Certificate of Authentication" in the "Product Key" line, see section "Device identification data (Page 35)".

Result

The interface of the operating system is displayed every time you turn on the device and after the startup routine.

4.3 Automatic switching on of the device

You can specify "Power Failure Recovery" in the BIOS Setup entry so that the device automatically starts up again after a separation from the mains voltage for more than 20 seconds.

Automatic startup may endanger the operation of the machine or plant, for example, after a power failure.

Take the BIOS Setup entry "Power Failure Recovery" into consideration in the plant planning.

4.4 Notes on various device configurations

4.4.1 DVD burner drive

The DVD burner drive is an optional device feature. Recording methods supported by the disk drive:

- Disc-At-Once
- Track-At-Once
- Session-At-Once
- Packet writing

For additional information, refer to the technical specifications.

Software

In order to use full functionality of the DVD burner you do not need to install additional software under Windows. The software for the DVD burner is part of the mentioned operating systems.

If you are using a different operating system, ensure that the software required for the DVD burner is installed.

Operation

Note

When first starting the burner software, no disks should be inserted in the drive. Faulty data storage media can interrupt the automatic drive recognition. This makes it impossible to correctly display the possible burner functions.

Burner operation is only permitted in an environment free of shock and vibration.

NOTICE
Data errors during burning
It cannot be ruled out that vibrations in the environment and varying quality of raw discs could result in data errors when burning data media, even when no error message occurs.
Data comparison is the only guarantee that data has been written correctly. Perform data comparison each time you burn a disc.

4.4.2 Hard disks in removable rack

The hard disks in the removable drive bay can be replaced during operation in connection with RAID (hot swap).

Requirement

- A hard disk of the same interface type

The interface type of the hard disk is displayed on the front door. Always replace the defective hard disk with a new one of the same interface type and capacity.

- A key for the hard disk lock

Procedure

NOTICE


Damage to the hard disk and loss of data

When you remove the hard disk while data is being written to the hard disk, you may damage the hard disk and destroy data.

- Only remove the hard disk tray from the removable drive bay when the hard disk is inactive. Inactive means the hard disk status display of the removable drive bay is not flashing.
- Observe the EGB guidelines.

1. Identify which hard disk the RAID controller has reported as being faulty (see status indicators).
2. Open the front panel.
3. Slide the cover ① of the removable drive bay lock to the right.

The marked lock is exposed.



4. Open the lock with the appropriate key.
 5. Fold out the tray bracket somewhat to the front and pull out the hard disk tray by the tray bracket.
- The procedure is described in more detail in the section "Removing and installing the hard disk drive from the removable drive bay (Page 71)".
6. Insert the hard disk tray with the replaced hard disk into the removable drive bay and push it all the way in.

7. Fold back the tray bracket until it rests completely against the hard disk tray.

The power supply LED ② must be on.

8. Slide the cover of the removable drive bay lock to the left.
9. Lock it with the appropriate key.

Note

Always lock the hard disk tray in the removable drive bay to ensure reliable operation of a device with removable drive bay.

4.4.3 System with two drives

The system with two drives is an optional feature for the device.

When the device ships, the second drive is connected to SATA port 1. This hard disk drive is not set up. This gives you the option of backing up your data to this hard disk drive. Refer to your order documentation for information on hard disk drive capacity.

Bootling from the second hard disk drive

In order to allow bootling from the second hard disk drive, you need to configure it as the primary boot device (Boot Option #1). To do this, make the following settings in your BIOS Setup:

1. Select the "Boot" tab.
2. Select the first entry from the list in the "Boot Option Properties": "Boot Option #1" and press the Return key.
3. Select the corresponding drive (slave drive) in the "Boot Option #1" window, e.g. STxxxxxxx, and press the Return key.

The second hard disk drive (slave drive) becomes the primary boot device.

Note

The drive letters for the partitions on both drives are assigned by the operating system in use. You can change these in the Control Panel as required.

4.4.4 RAID systems

4.4.4.1 Manage RAID system

RAID system management functions

The RAID system is fully set up ex works. The installed SIMATIC diagnostic software is used to display the status of the RAID system. Additional software is not required. Detailed information on hard disk replacement is available in section "Expansion and parameter assignment of device", "Replace defective hard disk in RAID system".

Note

A hard disk can be synchronized at operating system level if a fault is detected. It may take a very long time to synchronize a new hard disk in the background, depending on the size of the hard disk and on the system load. It may take several hours or even days in the case of extremely high hard disk load. Guide value for the duration: < 3 h with 90% HDD system load and RAID5 with HDD 1 TB.

The safe system states RAID Level, for example, 1 are only reached once synchronization has been successfully completed. In addition, system performance may be limited in the case of a manually started maintenance operation until completion of the maintenance phase.

Replacing a faulty drive in the RAID system

Replace the faulty drive with a new drive of the same type and capacity to return to the safe RAID1 or RAID5 state after a fault.

The diagnostic software indicates the following:

- A defective drive
- Details of the functioning hard disk

The defective hard disk is displayed with port number. You can find detailed information on drive replacement in the following sections:

- "Commissioning the device", "Hard disks in the removable drive bay"
- "Expansion and parameter assignment of device", "Replacing a defective hard disk in the RAID system".

Integrating a new hard disk

A hard disk is integrated automatically into the RAID if it fulfills one of the following requirements:

- The hard disk is brand new.
- The hard disk is set up as a global spare drive.
- The hard disk is set up as a specific dedicated spare drive.

4.4.4.2 RAID1 system

This is a RAID1 system configuration (data mirroring with two drives). This means that if there is a defective hard disk or there are cable problems, the system can continue to operate in one channel and achieve a high degree of availability.

Note

You will find information about the RAID controller in the "Drivers\RAID-AHCI\Intel" directory on the "Documentation and Drivers" DVD that ships with the product.

Additional information on RAID1 systems can be found in the section "Manage onboard RAID system (Page 85)".

4.4.4.3 RAID5 system

This is a RAID5 system configuration (striping with parity). This means that if there is a defective hard disk or there are cable problems, the system can continue to operate in one channel and achieve a high degree of availability.

Note

You will find information about the RAID controller in the "Drivers\RAID-AHCI\Intel" directory on the "Documentation and Drivers" DVD that ships with the product.

Additional information on RAID5 systems can be found in the section "Manage onboard RAID system (Page 85)".

4.4.4.4 RAID system with hot spare drive

In the factory state, the device is configured as a RAID1 or RAID5 system with a hot spare drive. A hot spare drive is a drive included in the device as spare.

If a defective drive is detected in the RAID1 or RAID5 system, the hot spare drive is automatically integrated during ongoing operation instead of the defective drive and takes over its function. The rebuild process to the hot spare drive starts automatically.

The defective drive is signaled as status display by the SIMATIC IPC DiagBase Alarm Manager.

A data-secure system is restored once synchronization is complete.

To restore full functionality of the RAID system with hot spare drive, you must replace the defective drive with a new one and integrate it once again as hot spare drive in the RAID system in the RAID software.

- Information on replacing the hot spare drive is available in the section "Replacing a defective hard disk drive in the RAID system (Page 76)".
- Information on integration of a replaced hot spare drive into the RAID system is available in the section "Integrating a hot spare hard disk drive in the RAID system (Page 91)".

See also

Status displays (Page 20)

4.5 Windows Action Center

Warning from the Windows Action Center

The Action Center checks the status of the device with regard to the important safety aspects listed below. If a problem is found, the Action Center provides recommendations on how you can better protect the device.

- **Firewall:** The Windows Firewall adds protection to the device by blocking network or Internet access to the device by unauthorized users. The firewall is enabled in the delivery state.
- **Antivirus software:** Antivirus programs add protection to the device by searching for and eliminating viruses and other security threats. No antivirus software is installed in the delivery state.
- **Automatic updates:** Using the Automatic Update feature allows Windows to regularly search for the latest critical updates for the device and to install them automatically.

This option is disabled in the delivery state for Windows Server 2008 R2 and Windows Server 2012 R2. You can enable or disable this option for Windows 7 during commissioning of Windows.

- **User Account Control:** User Account Control issues a warning when programs attempt to modify important Windows settings. You can then either acknowledge this warning or prevent the program from changing the Windows settings.

This option is disabled in the delivery state for Windows Server 2008 R2 and Windows Server 2012 R2. This option is enabled in the delivery state for Windows 7.

4.6 Switching off the device

Shutting down the operating system

For Windows operating systems:

1. Right-click on the Windows desktop.
 2. Press the key combination <Alt+F4>.
 3. Select "Shutdown".
- Alternatively, briefly press the on/off button (unless otherwise configured in the power options). Information on the position of the button is available in the section "Operator controls (Page 18)".

For non-Windows operating systems:

- Briefly press the on/off button.

The operating system is shut down. The "POWER" LED goes out. The device is switched off but not fully disconnected from the mains voltage.

Fully disconnecting the device from mains voltage

WARNING

Risk of fire and electric shock

The on/off button and on/off switch do not fully disconnect the device from the mains. If the device is switched off with the on/off switch, there remains a risk of electric shock and fire hazard, for example, if the device or connection cables are damaged or if the device is used improperly.

Always fully disconnect the device from the mains voltage as described below before performing work on the device or when the device will not be used over an extended period of time.

If the device was not mounted in a control cabinet:

- Shut down the operating system and pull the power plug on the rear of the device.

If the device was mounted in a control cabinet:

- Shut down the operating system and switch the AC circuit breaker to "Off".

The device is switched off and fully disconnected from the mains voltage. No trickle current is flowing.

Hardware reset

You can perform a hardware reset to switch off the device when the operating system no longer responds to input from the keyboard or mouse. The operating system is not safely shut down in this case.

NOTICE

Risk of data loss

The device is restarted in the case of a hardware reset. Data in the main memory can be deleted. Data on the drive may be lost. The device may be damaged.

Perform a hardware reset only in the case of an emergency.

For all operating systems:

- Press the on/off button for more than 4 seconds.

Expanded device functions

5.1 Monitoring functions

SIMATIC IPC DiagBase software

Even in its basic version, the device supports the use of monitoring functions. The SIMATIC IPC DiagBase software, which is included in the scope of delivery, provides the following local display, monitoring and control functions:

- Temperature monitoring (over-temperature, under-temperature or cable break at a temperature sensor)
- Fan monitoring (fan speed too low, fan failure, or a break in a tachometer line)
- Monitoring of drives (HDD and SSD) with S.M.A.R.T functionality even in a RAID system
- Watchdog (hardware or software reset of the computer)
- Operating hours meter (information on the cumulative run time)
- Battery monitoring

The charge level of the CMOS battery is monitored.

Use the "Management Explorer" application for clear control. Use the "Alarm Manager" to receive notifications about individual alarms.

Note

Additional information on the functionality of the SIMATIC IPC DiagBase software is available in the online help.

SIMATIC IPC DiagMonitor software

The SIMATIC IPC DiagMonitor software is available on DVD and can be ordered as an option with the configurator of the IPC547E. The software is included with the device when you order it. The SIMATIC IPC DiagMonitor software offers additional alarm and linking options in addition to the local monitoring functions of the SIMATIC IPC DiagBase software and includes:

- The software for the stations to be monitored.
- A library for creating user-specific applications.

Note

SIMATIC IPC DiagMonitor supports the device hardware as of version 4.4.3. Devices with Adaptec Hardware RAID adapter card are supported as of version 4.4.4.

Older versions do not support the device hardware.

5.1.1 Temperature monitoring and temperature display

The temperature is detected at critical device locations by temperature sensors. A temperature sensor monitors the processor temperature. Other temperature sensors monitor further critical points.

If the set temperature threshold is exceeded at a temperature sensor, the following reactions are triggered:

- The "TEMP" status display flashes red.
- The device fans are running at full speed.
- The power supply fan is controlled by the power supply itself.
- A temperature alarm is output if the SIMATIC monitoring software is installed.

Note

When the device is operated according to instructions, no temperature error occurs.

In the event of a temperature error, check the following possible causes:

- Ventilation openings are covered
- Filter is heavily polluted
- Fan has failed
- Ambient temperature is above the permitted value
- Output power of the power supply is exceeded

The temperature error remains stored until the monitored temperatures fall below the temperature threshold that is set. You can reset the error message with one of the following measures:

- Acknowledge error message with SIMATIC IPC DiagBase or SIMATIC IPC DiagMonitor
- Short-term disconnection of the device from the power supply
- Shut down device
- Restart the device

5.1.2 Fan monitoring

The operation of the front, CPU and power supply fans is monitored.

If a fan fails, the following reactions are triggered:

- The "FAN" status display lights up red.
- If the SIMATIC monitoring software is installed, a fan alarm is output.

The fan error remains stored until the cause has been rectified. You can reset the error message with one of the following measures:

- Acknowledge error message with SIMATIC IPC DiagBase or SIMATIC IPC DiagMonitor
- Short-term disconnection of the device from the power supply
- Shut down device
- Restart the device

5.1.3 Watchdog (WD)

Configuration

You configure the watchdog with the DiagBase or DiagMonitor software.

Function

The watchdog is able to monitor system runtime and informs the user about the different reactions that are triggered if the system does not respond to the watchdog within the specified monitoring time.

A watchdog alarm is retained after a restart and is reset and logged by the DiagBase or DiagMonitor software. The watchdog configuration is retained in the process.

Watchdog reactions

The following reactions can occur if the watchdog is not addressed within the set time:

Option	Reaction
Reset on	Executes a hardware reset when the watchdog expires
Reset off	Executes no action when the watchdog expires
Restart	Restarts the operating system when the watchdog expires
Shutdown	Shuts down the operating system when the watchdog expires

NOTICE

"Reset on" option

The "Reset on" option immediately triggers a hardware reset that may result in loss of data under Windows and damage to the installation.

Watchdog monitoring times

The monitoring time can be configured with the DiagBase or DiagMonitor software.

Note

When you change the monitoring time, the change becomes effective immediately.

5.1.4 Battery monitoring

The installed backup battery for backup of CMOS data has a limited life span. Information on the shelf life is available in the section "Replacing the backup battery (Page 94)".

A two-tier battery monitoring checks the status of the backup battery. The SIMATIC IPC DiagBase and SIMATIC IPC DiagMonitor diagnostic software determines the status of the backup battery.

When the first warning threshold is reached, the backup battery will run for at least one more month.

5.1.5 Drive monitoring

The SIMATIC IPC DiagBase software and SIMATIC IPC DiagMonitor software determine the status of the drives.

SMART messages of the hard drives are signaled.

In a RAID array the states "Normal," "Degraded" and "Rebuild" are displayed.

The status of an inactive hot swap drive is not displayed.

Active Management Technology (AMT) is technology for the remote maintenance of computers, simply called AMT-PC in the remainder of the document, which includes the following functions:

- Keyboard-Video-Mouse-Redirection

Using KVM that is integrated in the AMT hardware you access the AMT PC remotely. With KVM Redirection, you can also control AMT PCs that have no operating system or a defective operating system. A KVM remote session is always possible with the KVM server integrated in the firmware. This means you can restart the PC and change the BIOS setup remotely.

- Remote power management

AMT PCs can be turned on and off and restarted from another PC.

- Serial over LAN

Redirection of the data of a serial interface to the network. The main use of the function is text-based remote control of an AMT PC using a console.

- IDE redirection
An ISO file on the help desk PC can be mounted on the AMT PC and used as a DVD drive. An ISO file contains a memory image of the content of a CD or DVD structured in the ISO 9660 format.
- Remote reboot
An AMT PC can be booted remotely from a bootable ISO file made available by another PC.

SIMATIC IPC Remote Manager

The "SIMATIC IPC Remote Manager" software is available for utilization of the AMT functions with SIMATIC IPCs. The software can be ordered from the Siemens online ordering system. For detailed information about "SIMATIC IPC Remote Manager", refer to the corresponding product documentation: SIMATIC IPC Remote Manager (<http://support.automation.siemens.com/WW/view/en/48707158>)

Typical areas of application and functions of the SIMATIC IPC Remote Manager:

- Remote maintenance of SIMATIC IPC with AMT, for example, for service purposes in the case of a defective operating system or for adapting BIOS settings
- Diagnostics without on-site use
- Convenient service by access to AMT clients, such as headless systems, without additional hardware
- Resource management

Requirement

- A device with a Intel® Core™ i5 processor or Core™ i7 processor
- A functioning and configured "Management Engine"
- A functioning and configured Ethernet connection
- A help desk PC with a functioning and configured Ethernet connection for the full AMT functionality

Configuring AMT-PC

You configure AMT by means of the BIOS setup and MEBx. MEBx is a BIOS extension for configuring AMT.

5.2 Trusted Platform Module (TPM)

Depending on the ordered configuration of your device, a Trusted Platform Module according to Standard 1.2 may be available. The Trusted Platform Module is a chip that enhances your device with security functions. It provides an improved protection from manipulation of the PC. The current operating systems Windows 7 and Windows 8 support these security functions. You can enable the Trusted Platform Module in the "Security" menu in the BIOS Setup. Please note the respective import and export provisions for the Trusted Platform Module.

Using the Trusted Platform Module

The TPM can be used with the "BitLocker" drive encrypter, for example, in Windows operating systems. Please follow the instructions for this in the operating system.

Note

Risk of data loss

If you lose the password for the drive encryption, you will not be able to restore the data. You will then lose access to the encrypted drive.

The warranty does not cover a reset of the hardware in the event of a loss of a password.


Please store the password carefully and make sure it is protected against unauthorized access.

Expanding and assigning parameters to the device

6.1 Opening the front door


Procedure for SIMATIC IPC547E

- 1. Open the front door with the key.
- 2. Pull the front door downwards.



Procedure for SIMATIC IPC547E with short enclosure

- 1. Open the front door in the direction of the arrow.



6.2 Remove the fan cover

Requirement

- The front door is open, see "Opening the front door (Page 65)".

Procedure



1. Press the marked at the same time to release the fan cover.
2. Open the fan cover in the direction of the arrow and remove the fan cover.

6.3 Open the device

NOTICE

Malfunctions and electric shock through repair

Improper repairs jeopardize operational reliability and damage the device.

The results are personal injuries and damage to the plant.

Take the following precautions:

- Always disconnect the power plug before you open the device.
- Close the device after every repair.

⚠ CAUTION

Electrostatic sensitive devices (ESD)

The device contains electronic components which are destroyed by electrostatic charges. This can result in malfunctions and damage to the machine or plant.

Take the appropriate precautions. Additional information is available in the section "Switching off the device (Page 56)".

Limitation of liability

All technical specifications and approvals apply only to expansions which are approved by the Siemens AG. We are not liable for functional limitations caused by the use of third-party devices or components.

Observe the installation instructions for the components. UL approval of the device is valid only if UL-approved components are used in observance of their intended purpose ("Conditions of Acceptability").

Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- All connection cables are unplugged.
- T10 screwdriver

Procedure



1. Remove the highlighted retaining screws.
2. Lift the enclosure cover from the back and remove it.
3. If necessary, remove the fan cover, see chapter "Remove the fan cover (Page 66)".

6.4 Memory expansion

Depending on the device version there are two or four slots for memory modules on the motherboard. You can expand the memory up to 32 GB (for SIMATIC IPC547E with short enclosure up to 16 GB). Of which 3.2 GB can be used in a 32-bit operating system.

A detailed description of possible memory expansion options is available in the manual of the motherboard on the supplied "Documentation and Drivers" DVD.

6.5 Installing expansion cards

Note the following:

- Specification of the expansion cards

The device is designed for use with expansion cards conforming to PCI specification 2.3 and PCIe specification 2.0. The expansion cards must not exceed the specified dimensions. If the height is exceeded, you may experience contact problems, malfunctions and difficulties with the assembly.

You can find the permitted dimensions for expansion cards in the chapter "Dimension drawing of the expansion cards (Page 119)".

Note

Output is limited for PCI expansion cards with 5 V supply voltage. The total current consumption of the expansion card must be ≤ 25 W.

- Full-length PCI and full-length PCIe expansion cards

To insert such expansion cards into the guide rails, they must be equipped with an extender.


Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the section "Open the device (Page 66)".

Note

The accessory pack of the device includes three long card retainers for expansion cards with low overall height. Use these instead of the card retainers installed in the device.

Procedure



1. Hold the bar ① with the card retainer on both ends and remove it by pulling it upwards.

The bar is latched on both ends.

2. Remove the slot bracket ② for the expansion card from the required slot.
3. Insert the expansion card into the free slot on the motherboard.
4. Secure the expansion card with the screw ③.
5. Insert the bar ① with the card retainers.
6. Loosen the card retainer and place it on the expansion card in the slot ④.
7. Secure the card retainer with the screw ⑤.

If you are installing a short expansion card, remove the locking screw from the card retainer and install it in the opposite hole.

8. Close the device.

6.6 Drives

6.6.1 Removing and installing the drive cage


Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the section "Open the device (Page 66)".
- The front door is open, see chapter "Opening the front door (Page 65)".


Procedure

Removal


1. Remove the highlighted screws.



2. Remove the accessible power supply and data cables from the drives.



3. Hold the drive cage at the marked areas, push it in the direction of the arrow, then lift the drive cage completely out of the device.



Installation

Follow the steps described under removal in the reverse order.

6.6.2 Removing and installing the hard disk drive from the removable drive bay

Requirement

- The device is fully disconnected from the mains voltage, see section "Switching off the device (Page 56)".
- The front door is open, see section "Opening the front door (Page 65)".
- T10 screwdriver

Procedure

Removal

1. Slide the cover of the locking mechanism of the removable drive bay in the direction of the arrow.



2. Unlock the tray on the removable drive bay with the key provided.




3. Open the handle on the removable drive bay and open it at the highlighted spot in direction of the arrow until you feel a slight resistance.



4. Now grip the handle to the right of the notch from where it was pulled out, and pull the tray all the way out of the removable drive bay.



5. Loosen the highlighted screws on the bottom of the tray and remove the drive.



Installation

1. Carefully insert the new drive into the tray.
Take care not to touch the contacts of the drive when you do this.
2. Fasten the new drive with the screws to the base of the tray.
Only use the original screws.
3. Carefully insert the tray back into the removable drive bay on the drive cage.
4. Fold the handle out of the tray as far as it will go and slide the tray fully into the removable drive bay with unfolded handle.
Make sure that the tray is completely inserted into the removable drive bay.
5. Close the handle and lock the tray.

Note

The tray must always be locked in the removable drive bay to ensure reliable operation of the devices with removable drive bays.

6.6.3 Removing and installing an internal hard disk




Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the chapter "Open the device (Page 66)".
- T10 screwdriver

Procedure

Removal

	SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
1.	-	Open the front door.
2.	-	Loosen the two highlighted screws and remove the front panel. 

SIMATIC IPC547E	SIMATIC IPC547E with short enclosure
<p>The internal hard disks are located on the side wall of the device.</p> 	<p>The internal hard disks are located on the front wall of the device.</p> 
<p>3. Disconnect the power supply and data cables from the hard disk that you are removing.</p> <p>4. Loosen the highlighted fixing screws and remove the internal hard disk from the device. The figures below show the two possible slots for internal hard disks and the positions of the four screws for each slot.</p>	
	

Installation

1. Hold the new hard disk to the drive bay plate.
2. Fasten the hard disk with the four fixing screws from the outside to the drive bay plate.
3. Connect the power supply and data cables to the hard disk.
4. Close the device.

6.6.4 Replacing a defective hard disk drive in the RAID system

Hard disk drives can be replaced during operation in the removable drive bay in connection with a configured RAID1 system or RAID5 system. This functionality is referred to as "Hot Swap".

Note

If you have configured a non-RAID system with several hard disk drives, you need to turn off the device before you replace a hard disk drive.

 CAUTION
--

Damaging the drive

If you replace a drive while it is active, the drive and data are corrupted. The device can no longer be operated without problems.

Replace the drive in the removable drive bay when the "HDD" status display of the device is not lit.
--

Observe the EGB guidelines. Always replace the drive with a new drive of the same type and capacity.


Mounting locations for hard disk drives in the RAID1 system

Hard disk drives for a RAID1 system can be installed either in the device or on the front in the removable drive bay.

Note

The replacement of a hard disk drive with removable drive bay and in the RAID system can be performed without shutting down the device. An internal hard disk drive may only be replaced when the device is switched off.

The new hard disk drive can be integrated into the RAID1 system at operating system level with the RAID software. Synchronization may take several hours, depending on system load.



- ① Removable drive bay 0
- ② Removable drive bay 1
- ③ "Power" LED; power supply available
- ④ "HDD" LED, access to hard disk drive

Status displays of the hard disk drives in a RAID1 system

A defective hard disk drive in the RAID system is signaled with the status displays at the front of the device.

The following table includes information on the alarms of the status displays. If the hard disk drive is defective and the SIMATIC monitoring software is installed, the LEDs of the status display light up individually or simultaneously.

Internal hard disk drive or hard disk drive in removable drive bay

Status display	RAID BIOS	RAID software	Data cable connection	Drive
HDD0 alarm	Port 0	Device port 0	0	0
HDD1 alarm	Port 1	Device port 1	1	1

Mounting locations for hard disk drives in the RAID5 system


Unlike a RAID1 system, hard disk drives can only be installed on the front in the removable drive bay for a RAID5 system.

Note

The replacement of a hard disk drive with removable drive bay and in the RAID system can be performed without shutting down the device.

The new hard disk drive can be integrated into the RAID5 system at operating system level with the RAID software. Synchronization may take several hours, depending on system load.

The following figure shows an RAID5 system with three hard disk drives as an example and a hot spare hard disk drive in the removable drive bay.



- ① Removable drive bay 0
- ② Removable drive bay 1
- ③ Removable drive bay 2
- ④ Removable drive bay 3
- ⑤ "Power" LED; power supply available
- ⑥ "HDD" LED, access to hard disk drive

Status displays of the hard disk drives in a RAID5 system

A defective hard disk drive in the RAID system is displayed by the status displays at the front of the device.

The following table includes information on the alarms of the status displays. If the hard disk drive is defective and the SIMATIC monitoring software is installed, the LEDs of the status display light up individually or simultaneously.

Status display	RAID BIOS	RAID software	Data cable connection	Drive
HDD0 alarm	Port 0	Device port 0	0	0
HDD1 alarm	Port 1	Device port 1	1	1
HDD2 alarm	Port 2	Device port 2	2	2
HDD3 alarm	Port 3	Device port 3	3	3

Replacing a defective hard disk drive in the RAID system

1. Determine which hard disk drive has been reported as defective by the RAID software (HDD on port 0, 1, 2 or 3).
2. Remove the defective hard disk drive (internal drive or drive in removable drive bay).
3. Replace the defective hard disk with a hard disk of the same type and capacity.

6.6.5 Installing a 5.25" front hard disk drive

Requirement


- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The drive cage has been removed, see chapter "Removing and installing the drive cage (Page 69)".
- T10 screwdriver

Procedure


1. If a removable drive bay is already installed at the location in the drive cage where you want to install the 5.25" hard drive it can be removed by removing the screws on the sides of the drive cage and then taking out the removable drive bay.
or:
Remove the corresponding panel if the space in the drive cage where you want to install the 5.25" hard disk drive is still available.
2. Carefully insert the 5.25" hard disk drive into the drive cage from the front.
Take care not to touch the contacts of the drive when you do this.

3. Fasten the 5.25"hard disk drive with the screws to the the drive cage.

The figure below shows the possible positions of the screws on the left side of the drive cage.



The figure below shows the possible positions of the screws on the right side of the drive cage.



4. Install the drive cage back into the device, see section "Removing and installing the drive cage (Page 69)".

6.6.6 Removing and installing a DVD drive

Requirement


- The device is fully disconnected from the mains voltage, see section "Switching off the device (Page 56)".
- The drive cage is removed, see section "Removing and installing the drive cage (Page 69)".
- T6 screwdriver

Procedure

Removal

1. Remove the screws on the side of the drive cage.

The figure below shows the positions of the screws on the left side of the drive cage.



The figure below shows the positions of the screws on the right side of the drive cage.



The figure below shows the fixing screw on the drive cage.



2. Take the DVD drive out of drive cage from the front.

Installation

1. Carefully insert the new DVD drive into the drive cage from the front.
Take care not to touch the contacts of the DVD drive when you do this.
2. Fasten the DVD drive with the screws according to the diagram on the drive cage.
3. Install the drive cage back into the device, see section "Removing and installing the drive cage (Page 69)".

Device maintenance and repair

7.1 Repair information

Carrying out repairs

Only qualified personnel are permitted to repair the device.

 WARNING
Unauthorized opening and improper repairs on the device may result in substantial damage to equipment or endanger the user.
<ul style="list-style-type: none">• Always disconnect the power plug before you open the device.• Only install system expansion devices designed for this device. If you install other expansion devices, you may damage the device or violate the safety requirements and regulations on RF suppression. Contact your technical support team or where you purchased your PC to find out which system expansion devices may be installed.

If you install or exchange system expansions and damage your device, the warranty becomes void.

 CAUTION
Electrostatic sensitive devices (ESD)
The device contains electronic components which are destroyed by electrostatic charges. This can result in malfunctions and damage to the machine or plant.
Make sure you take precautionary measures even when you open the device, for example, when opening device doors, device covers or the enclosure cover. For more information, please refer to the chapter "ESD directives".

Limitation of liability

All technical specifications and approvals of the device only apply if you use expansion components that have a valid CE approval (CE mark). The installation instructions for expansion components in the associated documentation must be observed.

UL approval of the device only applies when the UL-approved components are used according to their "Conditions of Acceptability".

We are not liable for functional limitations caused by the use of third-party devices or components.

Tools

You can make repairs on the device with the following tools:

- T20 screwdriver for protective conductor connection and enclosure
- T6 screwdriver for removing and installing the DVD drive
- T10 screwdriver for all of the remaining screws

See also

ESD guideline (Page 115)

Spare parts and repairs (<http://support.automation.siemens.com/WW/view/en/16611927>)

7.2 Maintenance

7.2.1 Maintenance intervals

To maintain high system availability, we recommend the preventative replacement of those PC components that are subject to wear in accordance with the intervals for replacement indicated in the table below.

Component	Replacement interval
Drives	3 years
Backup battery	5 years
Device fan	3 years
Filter pad	Depending on the degree of soiling

7.2.2 Replacing filters

The filter pad is located behind the fan cover.

Requirement

- The device is disconnected from the power supply, see section "Switching off the device (Page 56)".
- The front door is open, see section "Opening the front door (Page 65)".
- The fan cover has been removed, see section "Remove the fan cover (Page 66)".
- A filter pad (order number A5E02399219)

Procedure

1. Remove the filter pad from the fan cover.
2. Insert the new filter pad into the fan cover.
3. Replace the fan cover.

7.3 Manage onboard RAID system

The RAID system is fully set up ex works. The installed SIMATIC diagnostic software is used to display the status of the RAID system. Additional software is not required. Additional information is available in the sections "RAID systems (Page 54)" and "Replacing a defective hard disk drive in the RAID system (Page 76)".

In "Legacy" mode, you can configure RAID hardware with <CTRL+I> in the boot phase. The associated description is available on the "Documentation and Drivers" DVD.

Note

The key combination <CTRL+I> is only effective in "Legacy" mode. If the "Boot Type" parameter is set to "UEFI Boot Type" in the "Boot" menu in the BIOS setup, the RAID hardware is configured by using the "Device Management" button in the BIOS selection menu.

7.3.1 Example for a RAID1 system during the boot phase of the system

```
Intel(R) Rapid Storage Technology - Option ROM - 12.7.0.1936
Copyright(C) 2003-13 Intel Corporation. All Rights Reserved.

RAID Volumes:
  ID   Name           Level           Strip           Size Status           Bootable
  0    Volume0         RAID1(Mirror)   N/A            931.5GB Normal           Yes

Physical Devices:
  Port Device Model      Serial #           Size Type/Status(Vol ID)
  0    ST9300120AS            20130402          931.5GB Member Disk(0)
  1    ST9300120AS            20130402          931.5GB Member Disk(0)

Press <CTRL-I> to enter Configuration Utility...
```


7.3.2 Example for a RAID5 system during the boot phase of the system



7.3.3 RAID software

Die RAID software "Intel Rapid Storage Technology" offers advanced functions to use and manage the RAID system.

1. Select the RAID software via "Start > Programs > Intel Rapid Storage Technology".



2. Select "Manage" > "Advanced" to display details of the RAID system.
3. Select "Help" > "System Report" > "Save" to create a report with the details of the RAID system.

7.3.4 Checking the status of the RAID system

By default, the status of the RAID system is displayed in the Windows Event Viewer and in a log file of the program. If an error occurs, a hard disk can be synchronized at the operating system level.

Note

It may take a very long time (hours or even days in the case of a high drive load) to synchronize a new hard disk in the background, depending on its size and on the system load.

The redundant system state is reached again only after synchronization is completed.

NOTICE

Operator errors on the machine or plant
--

Data is synchronized if a hard disk fails. Depending on the work load of the processor and hard disks, the system may react with some delay. Execution of keyboard, mouse or touch screen commands may be briefly delayed in extreme situations. This could result in operator errors on the machine or plant.
--

Do not operate safety-critical functions when a hard disk has failed.

7.3.5 Displaying a defective hard disk of a RAID system in the RAID software

Note

Always replace the defective hard disk with a new hard disk of the same type and capacity.


If an error is detected the defective hard disk must be replaced with a new hard disk to return to a secure RAID status after an error.

The RAID software indicates the following:

- A defective hard disk
- Details of the functioning hard disk:

The functioning hard disk is indicated by BIOS with its port number or by the RAID software with its device port number.

The following figure shows the corresponding window in the RAID software with a RAID1 system.



You can find information on how to detect and replace a defective hard disk in the RAID system in the section "Replacing a defective hard disk drive in the RAID system (Page 76)".

7.3.6 Special feature: Replacing hard disk in the RAID system when switched off

The RAID system does not automatically boot up when restarted if a defective hard disk was replaced while the RAID system is switched off. Therefore, place the RAID system in the first place of the bootable sources in the BIOS setup menu "Boot". Otherwise, the system will boot from the hard disk you have just installed and the message "Operating system not found" will be displayed.

7.3.7 Integrating a new hard disk drive in the RAID system

The RAID system is configured in the delivery state so that a new hard disk must be integrated manually when a defective hard disk was replaced.

However, you can configure the RAID system for automatic integration of a new hard disk after replacement of a defective hard disk.

RAID systems with a hot-spare hard disk are configured so that the hot-spare hard disk is automatically integrated in the event of an error.

Configuration of the automatic integration of a new hard disk (prior to replacing a defective hard disk)

NOTICE
Risk of data loss
If a new hard disk is automatically integrated in case of an error, the new hard disk is not checked for partition information or existing data.
All partitions and data on the new hard disk are erased without warning.
Only use a brand-new hard disk or a hard disk that is configured as a replacement drive. Notes on creating spare drives are available in the controller documentation.

1. Select "Start" > "Programs" > "Intel Rapid Storage Technology".
2. Select the "Preferences" menu.
3. Go to the "Automatic Rebuild" area and activate the "Auto-rebuild on hot plug" option.

Configuration of the manual integration of a new hard disk (prior to replacing a defective hard disk)

The RAID system is configured in the delivery state so that a new hard disk must be integrated manually when a defective hard disk was replaced.

You can configure the manual integration of the hard disk or check the settings yourself.

1. Select "Start" > "Programs" > "Intel Rapid Storage Technology".
2. Select the "Preferences" menu.
3. Go to the "Automatic Rebuild" area and deactivate the "Auto-rebuild on hot plug" option.

Manual integration of the hard disk (in the event of an error)

1. Select "Start" > "Programs" > "Intel Rapid Storage Technology".
2. Click  "Run Hardware Scan now".

The new hard disk is found and displayed.

Click on the link "Rebuild to another Disk".


Or:

1. Reboot the device.

The RAID software automatically integrates the hard disk.

2. Click on the link "Rebuild to another Disk".

Synchronization of the RAID system is initiated after clicking the link "Rebuild to another disk".




Display of the defective hard disk in the RAID software (in the event of an error)

The defective hard disk being replaced remains displayed in the RAID software during the rebuild process. The defective hard disk is no longer displayed when the rebuild process is complete.

1. Select "Start" > "Programs" > "Intel Rapid Storage Technology".
2. Select the "Status" menu.

The illustration below shows an example of the automatic rebuild process for a RAID1 system.



If you shut down and restart the system without installing a functioning new hard disk, "unused" is displayed for the corresponding SATA port. You can install the functioning hard disk while the system is running. The new hard disk is then assigned to a SATA port and is integrated into the RAID system.

7.3.8 Integrating a hot spare hard disk drive in the RAID system

If the hot spare hard disk drive was replaced in a RAID system, the new hot spare hard disk drive must be integrated in the RAID system once again.

Requirement

A hot spare hard disk drive was replaced in the RAID system, see section "Replacing a defective hard disk drive in the RAID system (Page 76)".

Procedure

1. Select "Start" > "Programs" > "Intel Rapid Storage Technology".

The RAID system is configured in the delivery state in such a way that a new hot-spare drive is automatically integrated.

If the automatic integration of a hard disk in the RAID system is deactivated, the hard disk must be integrated manually as described below.

2. Click  "Run Hardware Scan now".

The new hard disk is found and displayed.

3. Use the right mouse button to mark the new hard disk and select the menu item "Mark Disk as Spare" in the context menu.

4. Confirm the alarm in the "Mark Disk as Spare" window with "Yes".

7.4 Removing and installing hardware

7.4.1 Removing the device fan

Requirement

- The device is fully disconnected from the mains voltage, see section "Switching off the device (Page 56)".
- The front door is open, see section "Opening the front door (Page 65)".
- The fan cover has been removed, see section "Remove the fan cover (Page 66)".
- The device is open, see the section "Open the device (Page 66)".
- T20 screwdriver
- A fan

Use only a fan of the same type.

Procedure

Removal

1. Pull the fan plug from the motherboard, see labels in the following figure.



2. Remove the screws highlighted in the following figure.



3. Take the fan out of the enclosure.

Installation

To install the fan, follow the steps for removing it in reverse order.

Note

Installing device fans correctly

Two small arrows are shown on the device fan. These indicate the rotating direction of the fan and the direction of the airflow. Insert the device fan so that the arrow indicating the direction of the air flow points inside the enclosure.

7.4.2 Replacing the backup battery

Note

Note the following points:

- Batteries are wearing parts.
Backup batteries should be replaced at intervals of 5 years in order to maintain PC functionality.
 - The configuration data of the device are deleted when the battery is replaced.
Note the current BIOS setup settings.
 - Dispose of used batteries in accordance with local regulations.
-

Requirement

- A lithium battery recommended by the manufacturer or one that is identical
Information on original spare parts for SIMATIC IPCs is available at SIMATIC IPC after-sales information system (<http://www.siemens.com/asis>).

Procedure

1. The location of the backup battery on the motherboard and the procedure for replacing it are described in the manual of the motherboard on the supplied "Documentation and Drivers" DVD.
2. Reset the BIOS setup.

7.4.3 Removing the power supply

Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the section "Open the device (Page 66)".
- T10 screwdriver
- Diagonal cutter

Procedure

1. Disconnect the cables from the drives and the motherboard.
2. Remove the cable ties securing the power cables in the enclosure.
3. Remove the fixing screw that is marked in the figure below.



4. Remove the four fixing screws that are marked in the figure below.



5. Pull the power supply upward and out of the housing.

7.4.4 Removing module of the redundant power supply

Execute this step if one or both power supply modules must be replaced.

Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- T10 screwdriver

Procedure



1. Remove the screws that are marked in the figure below.
2. Pull out the power supply module from the enclosure using the handle.

7.4.5 Removing the enclosure of the redundant power supply from the module

Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the chapter "Open the device (Page 66)".
- The module of the redundant power supply has been removed, see chapter "Removing module of the redundant power supply (Page 96)".
- T10 screwdriver

Procedure

Removal



1. Remove the cable ties securing the power cables in the enclosure.
2. Disconnect the cables of the drives and the motherboard.
3. Remove the highlighted screws.
4. Pull out the enclosure of the power supply from the IPC housing from the back.

Installation

For installation, follow the steps for removal in reverse order.

7.4.6 Removing the motherboard

Requirement


- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the chapter "Open the device (Page 66)".
- A motherboard
The motherboard as spare part is supplied without processor and memory modules.
- T10 screwdriver

Procedure

Removal

1. Remove the expansion cards from the slots, see chapter "Installing expansion cards (Page 68)".
2. Note the assignment of all cables to the motherboard.

3. Disconnect all cables from the motherboard.
4. Remove the ten screws highlighted in the figure.



Installation

1. For installation, follow the steps for removal in reverse order.
2. Update the BIOS to match the version of the motherboard. Please note during the update if you operate a device with or without a RAID system.

7.4.7 Replacing the processor

Requirement

- The device is fully disconnected from the mains voltage, see chapter "Switching off the device (Page 56)".
- The device is open, see the section "Open the device (Page 66)".
- A suitable processor


Only an approved processor is permitted to be installed on the motherboard of the device. Information about original spare parts for SIMATIC IPCs is available on the Internet at:

- SIMATIC IPC after-sales information system (<http://www.siemens.com/asis>)
- Contacts (<http://www.siemens.com/automation/partner>)
- Manual of the motherboard on the supplied "Documentation and Drivers" DVD.

Procedure


Removal

1. Remove the highlighted fan connector and loosen the four highlighted screws.



2. Remove the heat sink.

3. Unlock the socket and lift the socket cover.




4. Remove the processor.

Installation

1. Install the new processor on the socket, as shown in the figure.

During positioning, make sure to take the highlighted arrow on the processor into consideration.



The rest of the procedure is described in the manual for the motherboard on the supplied "Documentation and Drivers" DVD.

2. If you use a processor of a different type, perform a BIOS update.

The microcode matching the processor is loaded in the process.

<p>NOTICE</p> <p>Damage to the processor</p> <p>If the installed processor is operated with a higher clock frequency than permitted, it can be destroyed or cause loss of data.</p> <p>Operate the processor only at a clock frequency that is equal to or less than the permitted clock frequency.</p>

7.5 Installing the software

7.5.1 Sources for installation of the operating system

If the operating system is faulty, you can reinstall it with one of these DVDs:

- With the recovery DVD and "Documentation and Drivers" DVD

The recovery DVD is included in the scope of delivery when you have ordered a device with operating system. The recovery DVD includes:

- The installation program for installing the operating system with the supported languages
- The tools for setting up the drives

The basic language of the installed operating system is English. If additional languages are required, install these from the recovery DVD.

The "Documentation and Drivers" DVD contains the documentation and the hardware drivers.

- From the Restore DVD

The Restore DVD is included in the scope of delivery when you have ordered a device with operating system. The DVD contains an image file with the following software:

- Operating system with installed hardware drivers
- Monitoring software, e.g., DiagBase.

7.5.2 Updating the operating system

Windows

The latest updates for the Windows operating system are available on the Internet at Microsoft (<http://www.microsoft.com>) and on the device in the Start menu "Start > All Programs > Windows Update > Check for updates".

Note

Before you install new drivers or operating system updates for Windows MUI versions, configure the regional menu and dialog settings and the default English (US) language.

other operating systems

Contact the corresponding manufacturer.

7.5.3 Installing drivers and software

Requirement

You need the "Documentation and Drivers" DVD included in the scope of delivery to install Windows drivers.

Procedure

Installing drivers

1. If your device has no DVD drive, connect an external USB DVD drive to a USB port.
2. Insert the supplied "Documentation and Drivers" DVD.
3. Start the "Start" program.
4. Accept the licensing conditions.
5. Select "Drivers" from the index.
6. Select the device and operating system.
7. Select the required driver.
8. Open the folder with the driver data. Click on the link next to "driver path".
9. Start the setup program in this folder.

Note

The driver for the chepset must be installed first with a new Windows installation. Then you can install the drivers of all other devices.

Installing the software

- You can find information about installing SIMATIC software packages in the corresponding documentation.
- You can obtain information about driver updates and installing application programs from the respective manufacturers.

7.5.4 Installing Windows

Note

Specific information on using the Windows operating systems is available on the Internet:

- Microsoft Technet Windows (<http://technet.microsoft.com/windows>)
 - Microsoft Technet Windows Server (<http://technet.microsoft.com/windowsserver>)
-

Requirement

You need the Recovery DVD for the operating system you want to install. The recovery DVD is included in the scope of delivery when you have configured a device with operating system.

If you use storage controllers that are unknown to the operating system, for example a RAID or AHCI controller, copy the respective controller driver to a USB stick and keep this USB stick to hand. The controller driver is required during installation.

Procedure

1. If your device has no DVD drive, connect an external USB DVD drive to a USB port.
2. Insert the Recovery DVD into the DVD drive.
3. Reboot the device.
4. Press the <F12> key when the device boots and keep it pressed.

The boot menu is displayed after initialization is completed.

5. Select the optical drive using the cursor keys.

For your system to boot in "UEFI" mode after installation, you must also boot the recovery DVD using UEFI. Your data storage medium will be set up with GPT partition management during installation of Windows.

To boot the recovery DVD in "UEFI" mode, in the "Boot" menu in BIOS setup select the item for which the optical drive is identified with "UEFI" in front of the name. Example:

UEFI: MATSHITADVD-RAM UJ8E0

For your system to boot in "Legacy" mode after installation, you must also boot the recovery DVD using Legacy. Your data storage medium will be set up with MBR partition management during installation of Windows.

To boot the recovery DVD in "Legacy" mode, in the "Boot" menu in BIOS setup select the item for which the optical drive is identified with "P" in front of the SATA port number.

Example:

P5: MATSHITADVD-RAM UJ8E0

6. Confirm the selection by pressing ENTER.
7. **Immediately** press any key when you see the following prompt to install the operating system from the Recovery DVD.

```
Press any key to boot from CD or DVD ..
```

After a few seconds, you will see the "Install Windows" installation program.

8. Now follow the instructions in the installation program.

You can find additional information on this in the next section.


"Install Windows" installation program

The language of the installation program and the operating system is preset to English. You can change the language of the operating system after the installation. Information on this topic is available in the section "Setting up the language selection using the Multilanguage User Interface (MUI)".


Setting up partitions and integrating storage controllers unknown to the operating system

You can set up partitions during the installation process and integrate storage controllers that are unknown to the operating system. To do so, select "Custom (advanced)" when prompted for the installation type in the "Install Windows" installation program.

The following dialog boxes are available:



Refresh	Updating
Load Driver	Integration of controller drivers unknown to the operating system and required for installation. Please read the information in the section "Information for systems with RAID or AHCI controller".
Drive options (advanced)	For display of additional functions that you can use to set up the data medium, see figure "Windows installation window "Drive options (advanced)"".



Refresh	Updating
Load Driver	Integration of controller drivers unknown to the operating system and required for installation. Please read the information in the section "Information for systems with RAID or AHCI controller".
Delete	Deleting a partition
Extend	Changing the partition size
Format	Formatting a partition
New	Creating new partitions
	Identification for error messages, for example, if the data medium was not formatted in the required "NTFS" format.

Note

If you want to install the operating system on a data medium connected to a storage controller unknown to the operating system, you have to integrate the driver of the storage controller. Integrate this driver before you partition the data medium and before you install the operating system. For more information on integrating the storage controller, refer to the section "Information for systems with RAID or AHCI controller".

7.5 Installing the software

1. Make sure that the partition on which you want to install the operating system is large enough and is set up with a NTFS file system.

The recommended minimum size of this partition varies, depending on the operating system, how much RAM you have available and how much additional software you want to use. Information on how the data medium is partitioned in its factory state is available in the tables below.

2. Select the partition on which you want to install the operating system.
3. Click "Next".

Installation is started. The Windows operating system is installed on the data medium.

Partitions in delivery state for Windows 7 and Windows Server 2008 R2

The following information applies to data storage media ≥ 100 GB.

Partition	Name	Size	File system
First	BOOT	100 MB	Automatically set up by installation program
Second	SYSTEM	100 GB	NTFS not compressed
Third	DATA	Remainder	NTFS not compressed

Windows Server 2012 R2 partitions in the factory state

The following information applies to data storage media ≥ 100 GB.

Partition	Name	Size	File system
First	WinRE	300 MB	NTFS
Second	Boot	260 MB	FAT32, automatically set up by installation program
Third	MSR	128 MB	FAT32, automatically set up by installation program
Fourth	System	100 GB	NTFS not compressed
Fifth	Data	Remainder	NTFS not compressed

Information for systems with RAID or AHCI controller

Data carrier controllers unknown to the operating system must be made known to the operating system prior to installation in the "Install Windows" installation program.

Requirement

You have copied the relevant controller driver to a USB stick.

Procedure

1. Connect the USB stick with the controller driver to the device.
2. Start the "Install Windows" installation program as described above.
3. Select "Load Drivers" in the Windows installation window.
4. Select the respective driver on the USB stick.

7.5.5 Setting up the language selection using the Multilanguage User Interface (MUI)

You can set the display of menus, dialogs or other information, such as date and time, to a different language. For this purpose, you can either select one of the preinstalled languages or install a new language package.

The following command sequences are described in English. Depending on the default setting, they can be displayed in another language.

Procedure

Changing the settings for language, region and formats of a registered user account

Windows 7 and Windows Server 2008 R2:

1. Choose:
"Start > Control Panel > Clock, Language, and Region > Regional and Language Options"
2. You can make the desired changes in the "Formats" and "Location und Keyboards and Languages" tabs.

Windows Server 2012 R2:

1. Choose:
"Start > Control Panel > Clock, Language, and Region > Region"
2. You can make the desired changes in the "Formats" and "Location" tabs.

Changing the settings for language, region and formats of the system account and the standard user account

You can change the settings for language, region and formats of the system account (for example, the language in the user login dialog) and the settings of the standard user account (standard setting for new users). The settings of the registered user are copied to the system account and the standard user account for this purpose.

Windows 7 and Windows Server 2008 R2:

1. Choose:
"Start > Control Panel > Clock, Language, and Region > Regional and Language Options"
2. You can make the required changes in the "Administrative" tab. You copy the settings by clicking the respective button.

Windows Server 2012 R2:

1. Choose:
"Start > Control Panel > Clock, Language, and Region > Region"
2. You can make the required changes in the "Administrative" tab. You copy the settings by clicking the respective button.

Installing language package

The available language packages are described in the chapter "Design of the device". Some language packages are available on the Recovery DVD in the "Languagepacks" folder.

Windows 7 and Windows Server 2008 R2:

1. Choose:
"Start > Control Panel > Clock, Language, and Region > Regional and Language Options"
2. Select the "Keyboards and Languages" tab.
3. Click the "Install/uninstall languages" button and make the required changes.

Windows Server 2012 R2:

1. Right-click the start menu in the task bar and select "Command Prompt (Admin)".
2. Enter the following command in the command line:

```
Dism /online /Add-Package /PackagePath:#Path to the language pack#
```

For "#Path to language pack#", enter the path to the language pack you want to install.
Example:

```
Dism /online /Add-Package /PackagePath:E:\Languagepacks\ja-jp\lp.cab
```

7.5.6 Restoring the delivery state

You can restore the original software using the Restore DVD. The DVD contains the necessary images and tools for transferring the software to the hard disk drive or SSD of your device.

The following options are available for restoring the delivery state:

- Restore the entire hard disk/SSD with drives C and D
- Restore drive C

This means data stored on drive D are retained.

Back-up authorization or license key

- Check whether you can back-up your authorization or license key from the drive and perform this procedure if possible.
- If backup is not possible, please contact Customer Support. There you can obtain information necessary for corresponding software authorization.

NOTICE
<p>Risk of data loss</p> <p>If "Restore system partition only" is set all data on drive C: (system partition) will be deleted. All data, user settings and all authorizations or license keys on drive C: are lost! All data on drive C: will be completely deleted, reformatted and overwritten with the original factory software.</p> <p>If "Restore entire drive" is set ALL data, user settings, authorizations or license keys will be lost on the entire drive.</p>

Procedure

1. If your device has no DVD drive, connect an external USB DVD drive to a USB port.
2. Insert the Restore DVD into the DVD drive.
3. Reboot the device.
4. Press the <F12> key when the device boots and keep it pressed.

The boot menu is displayed after initialization is completed.

5. In the boot menu, select the optical drive using the cursor keys.

To restore a system which boots in "UEFI" mode, you must also boot the restore DVD using UEFI.

To boot the restore DVD in "UEFI" mode, in the "Boot" menu in BIOS setup select the item for which the optical drive is identified with "UEFI" in front of the name. Example:

UEFI: MATSHITADVD-RAM UJ8E0

To restore a system which boots in "Legacy" mode, you must also boot the restore DVD using Legacy.

To boot the recovery DVD in "Legacy" mode, in the "Boot" menu in BIOS setup select the item for which the optical drive is identified with "P" in front of the SATA port number.

Example:

P5: MATSHITADVD-RAM UJ8E0

Note

Windows Server 2012 R2 boots in "UEFI" mode in the factory state.

Windows 7 and Windows Server 2008 R2 boot in "Legacy" mode in the factory state.

6. Follow the instructions on the screen.
-

Note

All existing data, programs, user settings, authorizations and license keys on the drives are deleted.

7.5.7 Installing onboard RAID controller software

You install the software of the onboard RAID controller with its driver.

7.5.8 Backing up data and changing partitions at a later time

We recommend the software tool SIMATIC IPC Image & Partition Creator to back up data under Windows operating systems. This tool provides convenient and efficient functions for backing up and restoring the full content of memory cards, hard disks and individual partitions (images).

SIMATIC IPC Image & Partition Creator supports the burning of DVD media. You can order the tool using the Siemens online ordering system Industry Mall (<https://mall.industry.siemens.com>). For more information on SIMATIC IPC Image & Partition Creator, refer to the corresponding product documentation.

Note

SIMATIC IPC Image & Partition Creator supports the device hardware as of version 3.3.3. Data storage media set up with GPT partition management are supported as of version 3.4. Older versions do not support the device hardware.

For devices with a Hardware RAID adapter card, the device driver must be downloaded subsequently. A function is available for this in the SIMATIC IPC Image & Partition Creator. For information on SIMATIC IPC Image & Partition Creator, refer to the corresponding product documentation.

Technical specifications

8.1 Certificates and approvals

ISO 9001 certificate

The Siemens quality management system for our entire product creation process (development, production and sales) meets the requirements of ISO 9001:2008.

This has been certified by DQS (the German society for the certification of quality management systems).

Certificate no.: 001323 QM08

Software license agreements

If the device is supplied with preinstalled software, you must observe the corresponding license agreements.

UL approval



The following approvals are available for the device:

- Underwriters Laboratories to Standard-UL 60950-1, File no. E11 5352
- Canadian National Standard CAN/CSA-C22.2 No. 60950-1-07 (I.T.E)

FCC and Canada

USA	
Federal Communications Commission Radio Frequency Interference Statement	This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
Shielded Cables	Shielded cables must be used with this equipment to maintain compliance with FCC regulations.
Modifications	Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.
Conditions of Operations	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CANADA	
Canadian Notice	This Class B digital apparatus complies with Canadian ICES-003.
Avis Canadien	Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

AUSTRALIA / NEW ZEALAND



This product meets the requirements of the standard EN 61000-6-3:2007 Generic standards
- Emission standard for residential, commercial and light-industrial environments.

This product meets the requirements of the standard EN 61000-6-3:2007 Generic standards
- Emission standard for residential, commercial and light-industrial environments.

Identification for Eurasian Customs Union



- EAC (Eurasian Conformity)
- Customs union of Russia, Belarus and Kazakhstan
- Declaration of conformity according to Technical Regulations of the Customs Union (TR CU)

KOREA



This product meets the requirements of Korean certification.

This product satisfies the requirement of the Korean Certification (KC Mark).

이 기기는 업무용(A급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기
바라며 가정 외의 지역에서 사용하는 것을 목적으로 합니다.

8.2 Directives and declarations

8.2.1 CE marking



The device meets the guidelines listed in the following sections.

EC Declaration of Conformity

The associated declaration of conformity is available on the Internet at the following address:
SIEMENS Industry Online Support
(<http://support.automation.siemens.com/WW/view/en/10805661/130000>).

Electromagnetic compatibility

This product meets the requirements of EC Directive 2004/108/EC "Electromagnetic Compatibility".

The device is designed for the following areas of application corresponding to the CE marking:

Scope of application	Requirements for	
	Interference emission	Immunity to interference
Industrial area	EN 61000-6-4 : 2007 +A1:2011	EN 61000-6-2 : 2005
Residential and commercial areas and small businesses	EN 61000-6-3 : 2007 +A1:2011	EN 61000-6-1 : 2007

The devices comply with the standards EN 61000-3-2:2006 +A1:2009 +A2:2009 (harmonic currents) and EN 61000-3-3:2008 (voltage fluctuations and flicker).

Low-voltage directive

The device with AC power supply complies with the requirements of the EC Directive 2006/95/EC "Low Voltage Directive". Compliance with this standard has been verified according to EN 60950-1:2006 + A11:2009 +A1:2010 +A12:2011.

8.2.2 ESD guideline

What does ESD mean?

An electronic module is equipped with highly integrated components. Due to their design, electronic components are highly sensitive to overvoltage and thus to the discharge of static electricity. Such electronic components or modules are labeled as electrostatic sensitive devices.

The following abbreviations are commonly used for electrostatic sensitive devices:

- ESD – Electrostatic sensitive device
- ESD – Electrostatic Sensitive Device as a common international designation

Electrostatic sensitive devices can be labeled with an appropriate symbol.



NOTICE

Damage to ESD from touch

Electrostatic sensitive devices, ESD, can be destroyed by voltages which are far below the human perception limit. If you touch a component or electrical connections of a module without discharging any electrostatic energy, these voltages may arise.


The damage to a module by an overvoltage can often not be immediately detected and only becomes evident after an extended period of operation. The consequences are incalculable and range from unforeseeable malfunctions to a total failure of the machine or system.

Avoid touching components directly. Make sure that persons, the workstation and the packaging are properly grounded.

Charge

Every person without a conductive connection to the electrical potential of his/her surroundings can be electrostatically charged.

The material with which this person comes into contact is of particular significance. The figure shows the maximum electrostatic voltages with which a person is charged, depending on humidity and material. These values conform to the specifications of IEC 61000-4-2.



- ① Synthetic materials
- ② Wool
- ③ Antistatic materials such as wood or concrete

NOTICE

Grounding measures

There is no equipotential bonding without grounding. An electrostatic charge is not discharged and may damage the ESD.
--

Protect yourself against discharge of static electricity. When working with electrostatic sensitive devices, make sure that the person and the workplace are properly grounded.


Protective measures against discharge of static electricity

- Disconnect the power supply before you install or remove modules which are sensitive to ESD.
- Pay attention to good grounding:
 - When handling electrostatic sensitive devices, make sure that persons, the workstation and devices, tools and packaging used are properly grounded. This way you avoid static discharge.
- Avoid direct contact:
 - As a general rule, do not touch electrostatic sensitive devices, except in the case of unavoidable maintenance work.
 - Hold the modules at their edge so that you do not touch the connector pins or conductor paths. This way, the discharge energy does not reach and damage the sensitive components.
 - Discharge your body electrostatically before you take a measurement at a module. Do so by touching grounded metallic parts. Always use grounded measuring instruments.

8.3 Dimension drawings


8.3.1 Dimension drawing of the device

SIMATIC IPC547E: Front view and top view




All dimensions in mm.

SIMATIC IPC547E with short enclosure: Front view and top view



All dimensions in mm.


8.3.2 Dimension drawing of the expansion cards



All dimensions in mm.


8.3.3 Dimension drawing of the telescope rails

SIMATIC IPC547E: Dimensions for bore holes for telescopic rails



All dimensions in mm.

SIMATIC IPC547E with short enclosure: Dimensions for bore holes for telescopic rails



All dimensions in mm.

8.4 Technical specifications

8.4.1 General technical specifications

Note

Applicability of technical specifications

The following technical specifications only apply under the following conditions:

- The device is in good working order.
- The fan cover and filter pad are installed.
- The device is closed.

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Order numbers	6AG4104-3....-.... (for details, refer to the ordering documentation)	
Dimensions	433.5 x 176.5 x 445.5 (W x H x D in mm)	433.5 x 176.5 x 355.5 (W x H x D in mm)
	Detailed information on the dimensions can be found in the chapter "Dimension drawing of the device (Page 118)".	
Weight	15 up to 23 kg; depending on the equipment	
Supply voltage (V _N)	<ul style="list-style-type: none"> • Power supply: 100V to 240V AC (-15 %; +10 %) • Redundant power supply: 2 x 100V AC up to 240V AC (-15 %; +10 %) 	<ul style="list-style-type: none"> • Power supply: 100V to 240V AC (-15 %; +10 %)
Input current	<ul style="list-style-type: none"> • Continuous current at 100 V: ≤ 6 A • Continuous current at 240 V: ≤ 3 A 	
	<ul style="list-style-type: none"> • Power supply: At startup ≤ 80 A for 3.6 ms • Redundant power supply: At startup ≤ 210 A for 1.65 ms for each module 	<ul style="list-style-type: none"> • Power supply: At startup ≤ 80 A for 3.6 ms
Frequency	50 to 60 Hz Minimum 47 Hz up to 63 Hz; sinusoidal	
Transient voltage interruption	20 ms at 93 V; ≤ 10 events/h; recovery time ≥ 1 s	
Power consumption, at maximum configuration	With 230 W secondary: <ul style="list-style-type: none"> • Power supply: ≤ 290 W; with 80% efficiency • Redundant power supply: ≤ 290 W; with 80% efficiency 	With 230 W secondary: <ul style="list-style-type: none"> • Power supply: ≤ 290 W; with 80% efficiency
Power loss, heat emission	290 W = 290 J/s = 0.28 BTU/s	

8.4 Technical specifications

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Current delivery (DC)	+5 V; 26 A / +3.3 V; 24 A / a total of 190 W is allowed +12 V; 15 A / +12 V; 15 A -12 V; 0.2 A / +5 V _{aux} ; 2 A The total sum of all voltages is max. 230 W.	
Noise emission	< 45 dB (A) to DIN 45635 At 20 °C and in Windows idle mode the result is 40 dB (A).	
Degree of protection	<ul style="list-style-type: none"> IP 30 with closed front door IP 20 on the rear according to EN 60529 	
Dust protection	With closed front door Filter class G2 EN 779; particles > 0.5 mm are 99% retained	
Safety		
Protection class	Protection class I compliant with IEC 61140	
Safety regulations	<ul style="list-style-type: none"> IEC 60950-1 EN 60950-1 UL 60950-1 CSA C22.2 No 60950-1-07 	

Electromagnetic compatibility

Emitted interference (AC)	EN 61000-6-3; EN 61000-6-4; CISPR 22, EN 55022 Class B; FCC Class A / EN 61000-3-2 class D, EN 61000-3-3
Noise immunity: interference conducted on the power supply lines	± 2 kV; according to IEC 61000-4-4; burst ± 1 kV; according to IEC 61000-4-5; surge symm ± 2 kV; according to IEC 61000-4-5; surge symm
Noise immunity on signal lines	± 2 kV; according to IEC 61000-4-4; burst; length > 30 m ± 1 kV; according to IEC 61000-4-4; burst; length < 30 m ± 2 kV; according to IEC 61000-4-5; burst; length > 30 m
Immunity to discharges of static electricity	± 4 kV contact discharge (according to IEC 61000-4-2) ± 8 kV air discharge; (according to IEC 61000-4-2)
Immunity to RF interference	<ul style="list-style-type: none"> 10 V/m; 80 up to 1000 MHz; 80% AM to IEC 61000-4-3 3 V/m; 1.4 to 2 GHz; 80% AM to IEC 61000-4-3 1 V/m; 2 up to 2.7 GHz; 80% AM to IEC 61000-4-3 10 V; 150 kHz up to 80 MHz; 80% AM to IEC 61000-4-6
Magnetic field	30 A/m; 50 Hz; 60 Hz (according to IEC 61000-4-8)

Ambient conditions

Climatic ambient conditions	
Temperature	Tested according to IEC 60068-2-2; IEC 60068-2-1; IEC 60068-2-14
Operation	+5 °C up to +40 °C ¹ Gradient: ≤ 10 K/h; no condensation
Storage/transportation	-20 °C up to +60 °C Gradient: ≤ 20 K/h; no condensation
Relative humidity	Tested according to IEC 60068-2-78; IEC 60068-2-30
Operation	5 % up to 80% at 25 °C; no condensation Gradient: ≤ 10 K/h; no condensation
Storage/transportation	5 % up to 95% at 25 °C; no condensation Gradient: ≤ 20 K/h; no condensation
Atmospheric pressure	
Operation	1080 up to 795 hPa, Corresponds to an altitude of -1000 m to 2000 m
Storage/transportation	1080 up to 660 hPa, Corresponds to an altitude of -1000 m to 3500 m
Mechanical ambient conditions	
Vibration	Tested according to IEC 60068-2-6; 10 cycles
<ul style="list-style-type: none"> • Operation ² • Storage/transportation 	<ul style="list-style-type: none"> • 20 up to 58 Hz; amplitude 0.015 mm; 58 up to 200 Hz: 2 m/s² • 5 up to 8.51 Hz; amplitude 3.5 mm; 8.51 up to 500 Hz: 9.8 m/s²
Resistance to shock	Tested in accordance with IEC 60068-2-27
<ul style="list-style-type: none"> • Operation ² • Storage/transportation 	<ul style="list-style-type: none"> • Half-sine; 9.8 m/s²; 20 ms; 100 shocks per axis • Half-sine; 250 m/s²; 6 ms; 1000 shocks per axis
Special features	
Quality assurance	In accordance with ISO 9001

¹ No burner operation.

At +5 °C up to +35 °C, without limitation; CPU up to 65 W power loss; see notes on retrofitting

² The device must be free of any mechanical faults when installing hard drives in removable drive bays. No mechanical interferences may be present during the burning process when using DVD burner drives.

Motherboard

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Chipset	Intel® LynxPoint 8 series (Q87)	Intel® LynxPoint 8 series (H81)
Processor	<ul style="list-style-type: none"> Intel® Pentium® Dual Core™ G3420 (2C/2T; 3.2 GHz; 3 MB cache) Intel® Core™ i5-4570S (4C/4T; 2.9 (3.6) GHz; 6 MB cache; iAMT) Intel® Core™ i7-4770S (4C/8T; 3.1 (3.9) GHz; 8 MB cache; iAMT) 	<ul style="list-style-type: none"> Intel® Celeron® G1820 (2C/2T; 2.7 GHz; 2 MB cache) Intel® Pentium® Dual Core™ G3420 (2C/2T; 3.2 GHz; 3 MB cache)
RAID (on-board)	Intel® PCH with Intel® Rapid Storage Technology	-
Slots for memory modules	4 x DIMM slots for DDR3, expandable to 32 GB	2 x DIMM slots for DDR3, expandable to 16 GB
Main memory	2 up to 32 GB; DDR3 1600 SDRAM (PC3-12800)	2 up to 16 GB; DDR3 1600 SDRAM (PC3-12800)
	Max. of 3.2 GB can be used for 32-bit versions of operating system and applications; see order documents for equipment	
Expansion card slots	<ul style="list-style-type: none"> 4 x PCI 1 x PCIe x16 (4 lanes); Gen 2.0 1 x PCIe x8 (1 lane); Gen 2.0 1 x PCIe x16; Gen 3.0 You can use expansion cards with a length of up to 312 mm.	<ul style="list-style-type: none"> 4 x PCI 1 x PCIe x16 (2 lanes); Gen 2.0 1 x PCIe x8 (1 lane); Gen 2.0 1 x PCIe x16; Gen 2.0 You can use expansion cards with a length of up to 260 mm.
Power consumption per PCI slot, maximum permitted	<ul style="list-style-type: none"> 5 V; 5 A or 3.3 V; 7 A 12 V; 0.5 A 12 V; 0.05 A 3.3 V_{aux}; 0.4 A 	
Power consumption per PCIe slot with x4 expansion card, maximum permitted	<ul style="list-style-type: none"> 3.3 V; 3 A 12 V; 2.1 A 3.3 V_{aux}; 0.4 A 	
Power consumption per PCIe slot with x16 expansion card, maximum permitted	<ul style="list-style-type: none"> 3.3 V; 3 A 12 V; 2.1 A 3.3 V_{aux}; 0.4 A 	
Power consumption per slot, permitted	≤ 25 W	
Power loss all slots, permitted	≤ 80 W In sum, the current for 3.3 V _{aux} may not exceed 1.2 A.	

Drives

Information on the drives is available in your order documents.

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
SATA drive	<ul style="list-style-type: none"> • 3.5" SATA, 6 GB/s; 500 GB • 3.5" SATA, 6 GB/s; 1000 GB Native Command Queuing is supported.	
Flash memory	2.5" SSD	-
DVD burner ¹	Slimline SATA Read: <ul style="list-style-type: none"> • DVD ROM, Single Layer and Dual Layer: 8 × • DVD+R/RW, DVD-R/RW, DVD-RAM: 8 × • CD-ROM, CD-R, CD-RW: 24 × Write: <ul style="list-style-type: none"> • DVD-R: 8 × • DVD-R DL: 6 × • DVD-RW: 6 × • DVD+R: 8 × • DVD+R DL: 6 × • DVD+RW: 8 × • DVD-RAM: 5 × • CD-R: 10 × • CD-RW: 16 × 	-

¹ No mechanical interferences may be present during the burning process when using a DVD burner drive.

Graphics

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Graphic controller	<ul style="list-style-type: none"> • Intel® HD Graphics 4400 (integrated in processor: Intel® Pentium® Dual Core™ G3420) • Intel® HD Graphics 4600 (integrated in processor: Intel® Core™ i5-4570S) • Intel® HD Graphics 4600 (integrated in processor: Intel® Core™ i7-4770S) 	<ul style="list-style-type: none"> • Intel® HD Graphics 4400 (integrated in processor: Intel® Celeron® G1820) • Intel® HD Graphics 4400 (integrated in processor: Intel® Pentium® Dual Core™ G3420)
Graphics memory	Dynamic Video Memory Technology, occupies 32 MB to 1.7 GB of main memory	

8.4 Technical specifications

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Resolutions/frequencies /colors	<ul style="list-style-type: none"> • DVI (VGA via adapter) up to 1920 x 1200 pixels at 60 Hz, color depth up to 32-bit/pixel • DisplayPort up to 3840 x 2160 pixels at 60 Hz; color depth up to 32-bit/pixel 	
Graphics card (optional)	PCIe x16; Dual Head; 2 x DisplayPort; 2 x VGA or 2 x DVI-D ¹ <ul style="list-style-type: none"> • Type: NVIDIA NVS 300, 512 MB of graphics memory • Maximum resolution: <ul style="list-style-type: none"> – DisplayPort 2560 x 1600 at 60 Hz; 32-bit color depth – DVI 1920 x 1200 at 60 Hz; 32-bit color depth – VGA 2048 x 1536 at 60 Hz; 32-bit color depth 	

¹ Adapter for VGA and DVI-D supplied

Interfaces

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
COM 1,	Serial interface 1 (V.24), 9-pole sub D socket	-
COM 2 (optional)	Serial interface 2 (V.24), 9-pole sub D socket	
LPT (optional)	Parallel interface (standard, EPP and ECP mode) Port for printer with parallel interface	
VGA	Connecting an analog monitor; via adapter cable; optional	
DisplayPort V1.2	For connecting a digital monitor	
DVI-I	For connecting a digital monitor	
2 x DVI-D/VGA with dual-head graphics card (optional)	For connecting two digital or analog monitors	
PS/2 keyboard	Keyboard connection	
PS/2 mouse	Mouse connection	
USB 2.0	USB 2.0 HighSpeed <ul style="list-style-type: none"> • Back of device: 6 x 500 mA / high current • Internal: 1 x 500 mA / high current with mechanical lock; optional 	USB 2.0 HighSpeed <ul style="list-style-type: none"> • Back of device: 6 x 500 mA / high current
USB 3.0	USB 3.0 SuperSpeed backward compatible with USB 2.0/1.1 <ul style="list-style-type: none"> • Back of device: 2 x 500 mA / high current • Front of device: 2 x 500 mA / high current 	USB 3.0 SuperSpeed backward compatible with USB 2.0/1.1 <ul style="list-style-type: none"> • Front of device: 2 x 500 mA / high current

	SIMATIC IPC547E:	SIMATIC IPC547E with short enclosure:
Ethernet	2 × Ethernet interface (RJ45) 10/100/1000 Mbps <ul style="list-style-type: none"> • Ethernet 1: Intel® Clarkville i217LM, AMT capable¹ • Ethernet 2: Intel® Springville i210-AT 	1 × Ethernet interface (RJ45) 10/100/1000 Mbps <ul style="list-style-type: none"> • Ethernet 1: Intel® Clarkville i217LM
	Wake on LAN, Remote Boot and the Teaming modes are supported: <ul style="list-style-type: none"> • Adapter Fault Tolerance (AFT) • Adaptive Load Balancing (ALB) • IEEE 802.3ad Dynamic Link Aggregation (DLA) • Static Link Aggregation (SLA) • Switch Fault Tolerance (SFT) 	Wake on LAN and Remote Boot are supported.
Audio <ul style="list-style-type: none"> • Micro • Line In • Line Out 	Realtek ALC671, 6-channel DAC support 2 W at 4 Ω	

¹ AMT and teaming cannot be used simultaneously on the Ethernet interface.

8.4.2 Current and power requirements

Device components

	Voltage					
	+5 V	+3.3 V	+12 V (1)	+12 V (2)	-12 V	5 Vaux
FTS motherboard with processor and heat sink	5 A	2 A	–	9.5 A	0.1 A	0.3 A
Front fan			2.0 A			
Basic system ¹⁾	5 A	2 A	16 A		0.01 A	0.5 A

¹ Depends on the selected device configuration

Device expansions

	Voltage					
	+5 V	+3.3 V	+12 V (1)	+12 V (2)	-12 V	5 Vaux
SATA drive ¹	0.5 A		2.0 A			
DVD burner ¹	1.1 A		2.0 A			
Current per voltage	≤ 20 A	≤ 20 A	≤ 11 A	≤ 14 A	≤ 0.5 A	≤ 2 A

¹ Depending on the selected device expansion

Note the information in the sections "AC power supply (Page 128)" and "AC power supply, redundant (Page 129)".

8.4.3 AC power supply

Voltage	Maximum current	Voltage stability
+12 V	11 A	± 5%
+12 V	14 A	± 5%
-12 V	0.3 A	± 10%
+5 V	25 A ¹	+ 5%, - 4%
+3.3 V	20 A ¹	+ 5%, - 4%
+5 V _{aux}	2.5 A	+ 5%, - 3%

¹ The total output of the +5 V and +3.3 V voltage must be ≤ 190 W.

The inrush current is:

- ≤ 80 A for 3.6 ms

Note

Operation on an uninterruptible power supply (UPS)

The power supply contains an active PFC (Power Factor Correction) circuit for adherence to the EMC guidelines.

Uninterruptible power supplies must supply a sinusoidal output voltage in normal and buffered mode when used with SIMATIC IPCs with an active PFC.

The characteristics of uninterruptible power supplies are described and classified in the standards EN 50091-3 or IEC 62040-3. Devices with sinusoidal output voltage in normal and buffered mode are identified with the classification "VFI-SS-...." or "VI-SS-....".

8.4.4 AC power supply, redundant

Voltage	Max. current	Voltage stability
+12 V	18 A ²	± 5%
+12 V	18 A ²	± 5%
+12 V	14 A ²	± 5%
-12 V	0.8 A	± 10%
+5 V	20 A ¹	+ 5%, - 4%
+3.3 V	20 A ¹	+ 5%, - 4%
+5 V aux	2.0 A	+ 5%, - 3%

¹ The total output of the +5 V and +3.3 V voltage must be ≤ 100 W.

² The total current of the +12 V voltage must be ≤ 25 A.

The inrush current of a plug-in module is:

- ≤ 210 A for 1.65 ms

8.4.5 Technical specifications of the telescopic rails

Ultimate load per pair	≥ 30 kg
Full extraction length	≥ 470 mm
Rail thickness	≤ 9.7 mm
Mounting screws	M5 x 6 mm The mounting screws of the telescopic rails may not protrude by more than 5 mm into the enclosure.

See also

Dimension drawing of the telescope rails (Page 120)

8.5 Hardware description

8.5.1 Motherboard

A detailed description of the motherboard and the ports is available in the manual for the motherboard on the supplied "Documentation and Drivers" DVD.

8.5.2 System resources

All system resources (hardware addresses, memory configuration, allocation of interrupts, DMA channels) are assigned dynamically by the Windows OS, depending on the hardware configuration, drivers and connected external devices. You can view the current configuration of system resources or possible conflicts with the following operating systems:

Microsoft Windows 7 Ultimate (32-bit and 64-bit) Microsoft Windows Server 2012 R2 (64-bit) incl. 5 clients	<ol style="list-style-type: none">1. Select in the Windows Start menu "Start" > "Search".2. Enter "msinfo32" in the search function.3. Open the application.
Microsoft Windows Server 2008 R2 (64-bit) incl. 5 clients	<ol style="list-style-type: none">1. Select in the Windows Start menu "Start" > "Run".2. Enter "msinfo32" in the Open field and confirm your input with "OK".

8.5.3 Interrupt assignment

Interrupt assignment depending on operating system

The functions are assigned different interrupts (IRQ), depending on the operating system. A distinction is made between the PIC and APIC modes.

Function	IRQ Number																Comment								
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15		16	17	18	19	20	21	22	23
IRQ (APIC-Mode)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	
IRQ (PIC-Mode)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	
Host PCI IRQ Line																	A	B	C	D	E	F	G	H	1)
Function																									
Timer 0	X																								Fixed
PS/2 Keyboard	X																								Fixed
Serial Port 2			X																						Can be disabled
Serial Port 1				X																					Can be disabled
Parallel Port					X																				Can be disabled
PS/2 Mouse												X													Fixed
Numeric Processor													X												Fixed
SATA AHCI / IDE #1										Z												Y			Fixed
SATA IDE #2										Z												Y			Fixed
SMBus										Z												Y			Fixed
Ethernet 1 (LAN i217)											Z								Y						Can be disabled
Ethernet 2 (LAN i210)											Z								Y						Can be disabled
HD Audio											Z											Y			Can be disabled
CPU int. Grafic Audio											Z														Can be disabled
CPU int. Grafic											Z						Y								Fixed
LPC Controller											Z											Y			Can be disabled
USB2 EHCI1											Z											Y			Can be disabled
USB2 EHCI2											Z											Y			Can be disabled
USB3 xHCI											Z											Y			Can be disabled
PCH ME #1											Z											Y			Fixed
PCH ME #2											Z											Y			Fixed

- 1) Host PCI-IRQ A to H is assigned to IRQ 16 to 23 permanently in APIC mode.
Host PCI-IRQ A to H is assigned to IRQ 0 to 15 automatically by the BIOS in PIC mode.
A specific assignment cannot be forced.
- X Interrupt PIC and APIC mode
- Y Interrupt APIC mode
- Z BIOS Default Interrupt PIC mode, e.g. DOS

Slot-specific interrupt assignment

Interrupt routing of the slot connectors on the motherboard.

Function	IRQ Number																Comment										
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15		16	17	18	19	20	21	22	23		
IRQ (APIC-Mode)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23			
IRQ (PIC-Mode)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23			
Host PCI IRQ Line																	A	B	C	D	E	F	G	H	1)		
Function																											
Slot 1 (PEG)																											
PCI IRQ A											Z					Y											
PCI IRQ B										Z						Y											
PCI IRQ C									Z									Y									
PCI IRQ D										Z									Y								
Slot 2 (PCIe-X1 Slot x8)																											
PCI IRQ A											Z						Y										
PCI IRQ B										Z								Y									
PCI IRQ C										Z									Y								
PCI IRQ D										Z							Y										
Slot 3 (PCIe-X4 Slot x16)																											
PCI IRQ A											Z						Y										
PCI IRQ B											Z							Y									
PCI IRQ C										Z									Y								
PCI IRQ D										Z										Y							
Slot 4 (PCI)																											
PCI IRQ A							Z																		Y		
PCI IRQ B										Z												Y					
PCI IRQ C											Z												Y				
PCI IRQ D												Z												Y			
Slot 5 (PCI)																											
PCI IRQ A											Z														Y		
PCI IRQ B												Z													Y		
PCI IRQ C													Z												Y		
PCI IRQ D														Z											Y		
Slot 6 (PCI)																											
PCI IRQ A												Z													Y		
PCI IRQ B													Z												Y		
PCI IRQ C														Z											Y		
PCI IRQ D															Z										Y		
Slot 7 (PCI)																											
PCI IRQ A																									Y		
PCI IRQ B																									Y		
PCI IRQ C																									Y		
PCI IRQ D																									Y		
Slot 8 (PCI)																											
PCI IRQ A																									Y		
PCI IRQ B																									Y		
PCI IRQ C																									Y		
PCI IRQ D																									Y		

- 1) Host PCI-IRQ A to H is assigned to IRQ 16 to 23 permanently in APIC mode. Host PCI-IRQ A to H is assigned to IRQ 0 to 15 automatically by the BIOS in PIC mode. A specific assignment cannot be forced.
- Y Interrupt APIC mode
- Z BIOS Default Interrupt PIC mode, e.g. DOS

Exclusive PCI hardware interrupt

Applications demanding a high-performance interrupt require a high-speed hardware interrupt reaction. The PCI hardware interrupt should be used only by one resource in order to ensure high-speed reaction of the hardware.

Setting up an exclusive interrupt on the device (APIC mode only)

An exclusive interrupt can only be used for PCI slot 4 and PCI slot 5. Further exclusive interrupts for use at the slots are not available.

Assigning exclusive interrupts in BIOS Setup (PIC mode only)

The interrupts are automatically assigned to the slots at system startup due to the default settings in system BIOS. Several slots may share the same interrupt, depending on the system configuration. This functionality is known as interrupt sharing.

Exclusive interrupts are not available in PIC mode. Disable specific system resources in order to obtain exclusive interrupts. BIOS assigns the PIC interrupts at random during restart of the system.

8.6 BIOS description

You can configure the system functions and hardware configuration in the BIOS.

The BIOS is set to a default state suitable to the respective device configuration prior to delivery. The most important settings are shown in the table below.

Tab	Option	Setting
Advanced	SATA configuration	AHCI mode or RAID ¹
	System Monitoring > Fan Control	Enhanced
	CPU Configuration > Enhanced SpeedStep	Disabled
Boot	CSM Configuration > Launch PXE OpROM policy	Do not launch

¹ Optional for RAID systems

For a detailed description of how to call up and operate the BIOS setup and which menus and setting options are available, refer to the BIOS reference manual on the "Documentation and Drivers" DVD that ships with the manual.

Note

After a BIOS update, you need to execute the "Restore Defaults" command. Executing the "Restore Defaults" command restores all BIOS settings to their original state.

Power failure recovery

The following two settings are possible in the "Power Failure Recovery" BIOS setup entry:

- The device switches on automatically.

The device switches on automatically when the device was separated from the mains supply for at least 20 s. This setting is of importance even if the device is always switched off with a hardware reset. The device always starts automatically when the power supply is re-connected at a later time.

- The on/off/ button must be operated.

The device does not switch on automatically.

Note


Automatic startup may endanger the operation of the machine or plant, for example, after a power failure. Take this into account when designing the plant.

8.7 Active Management Technology (AMT)

8.7.1 AMT basics

The processors Intel® Core™ i5 and Core™ i7 support Intel® vPro™ and Intel Active Management Technology at the hardware end. An administrator at the Help Desk PC accesses the AMT PCs. Only the AMT PCs must have an integrated Intel AMT.

The following figure shows the possible structure of a network for remote management on the basis of SIMATIC AMT-PCs.



From a SIMATIC IPC which does not have Intel AMT functions, you can access networked SIMATIC IPCs with Intel AMT using the SIMATIC IPC Remote Manager and/or a web browser.

A SIMATIC IPC that supports AMT features two onboard Ethernet interfaces, each with a separate controller. You can configure the controller integrated in the chipset for use with Intel AMT. Further details about the controller can be found in the technical specification.

For security reasons, AMT is disabled when you receive the SIMATIC IPC. Enable AMT in the BIOS setup. Afterwards the Intel® Management Engine (Intel® ME) has to be activated and set for AMT. Set the following in the Management Engine:

- Configure network for access via AMT
- Create password

8.7.2 Overview of AMT

This section describes the required measures and settings on the local IPC so that the IPC can be controlled and maintained remotely from a management station known below as the help desk PC.

The local IPC is known below as the "AMT PC".

The sections contain the following information:

- AMT settings in the MEBx and in the BIOS setup
- Basic configuration of AMT
- Further useful notes

8.7.3 Activate AMT

For security reasons, AMT is not enabled on new devices.

Procedure

1. Connect the AMT PC by means of "Create Internet connection" when using the corresponding LAN controller (LAN 1).
2. If necessary, first reset AMT to the default status.
You can find the required information in the chapter "Reset AMT with Unconfigure ME (Page 137)".
3. To access the BIOS, press the <F2> key while the device is booting.
4. In the Advanced menu, enable "Intel AMT Support", and "Intel AMT Setup Prompt".
5. Exit the BIOS with the <F10> key "Save and Exit".

The AMT PC starts.

6. To access the MEBx, press the <Ctrl+P> keyboard shortcut at system power-up.
7. In the login dialog, enter the standard password "admin".

8. Change the default password.

The new password must include the following characters:

- In total at least eight characters
- One upper case letter
- One lower case letter
- One number
- One of the special characters ! @ # \$ % ^ & * @ # \$ % ^ & *

Note

The underscore and blank space are valid password characters but do not increase password complexity.

9. Enable "Intel (R) AMT Configuration > Manageability Feature Selection".

10. Enable "Intel (R) ME General Settings > Activate Network Access".

8.7.4 Advanced settings

The BIOS and the MEBx contain the most important basic settings for AMT. Additional tools are necessary if you want to make more advanced settings. If required, these must be downloaded from the relevant manufacturer's site. For information on the options and use of these tools, refer to the relevant documentation of the manufacturer.

- Manageability Commander and other tools of the Intel DTK (Manageability Developer Tool Kit): Programs from the Intel DTK that you can download from the Internet at "<http://software.intel.com/en-us/manageability>".
- AMT Web interface: For encrypted connections, the URL of the Web interface is "[https:// <Fully qualified domain name>:16993](https://<Fully qualified domain name>:16993)" and for unencrypted connections "<http://<IP address>:16992>".
- WinRM: A command line program that is part of Windows as of Windows Vista. This tool can be downloaded for older Windows versions.

8.7.5 Reset AMT with Unconfigure ME

Note

If the factory setting for the AMT PC was not changed, you can skip this chapter.

If you have already configured AMT previously, discard all previous AMT settings made in the MEBx.

Note

Note the following points:

- All previous settings in the Management Engine are deleted.
 - Correct operation in the plant may be at risk.
 - Note down all the settings in the MEBx. Make the settings again as necessary following Unconfigure.
-

The device continues booting in factory setting.

Procedure

1. Enable the "Unconfigure ME" entry in "Advanced > Active Management Technology Support" in the BIOS.
2. Exit BIOS with the <F10> key.
Your entry is saved and BIOS is closed. The AMT PC starts.
3. After the start, a user prompt appears asking whether you really want to discard all the settings in the Management Engine.

```
Intel(R) Management Engine BIOS Extension v6.1.0.0005
Copyright(C) 2003-10 Intel Corporation. All Rights Reserved.

Found unconfigure of Intel(R) ME
Continue with unconfiguration (Y/N)
```

4. Confirm with "Y". On a German keyboard, this means pressing the <Z> key.

8.7.6 Determining the network address

To connect the AMT PC with the AMT server, the network address that uniquely localizes the AMT server on the AMT PC must be entered.

If DHCP is set for the automatic assignment of the network address in "Network Setup" in the MEBx of the AMT PC, the network address is not fixed.

Procedure

If the AMT server uses the same network address as the operating system of the AMT PC (most common situation):

1. You can obtain the address of the AMT server in the command line in Windows using "ipconfig" and in UNIX using "ifconfig".

If the AMT server and operating system do not use the same network address, ask your network administrator for the address you have been assigned.

8.7.7 Forcing user consent

When establishing a connection to the AMT PC, the KVM viewer may prompt the user to enter a six-figure code. This code is displayed on the screen of the AMT PC. The user of the AMT PC must inform the user of the KVM viewer of this code.

This code query needs to be set up on the KVM viewer.

Procedure

1. Select "Intel(R) AMT Configuration > User Consent" in the MEBx.
2. Select the value "KVM" for "User Consent".

To allow a user with administrator privileges to avoid this code query, follow these steps:

1. Select "Intel(R) AMT Configuration > User Consent" in the MEBx.
2. Enable "Opt-in configurable from remote IT".

8.8 Assignment of expansion interface to the software in the TIA Portal (CP assignment)

The table below shows the correlation between enclosure labeling of the IPC expansion slots and the labeling that is used during assignment of interfaces to the software in the TIA Portal.

Enclosure labeling	TIA Portal
1	X100
2	X101
3	X102
4	X103
5	X104
6	X105
7	X106

Technical support

A.1 Service and support

You can find additional information and support for the products described on the Internet at the following addresses:

- Technical support (http://www.siemens.de/automation/csi_en_WW)
- Support request form (<http://www.siemens.com/automation/support-request>)
- After Sales Information System SIMATIC IPC/PG (<http://www.siemens.com/asis>)
- SIMATIC Documentation Collection (<http://www.siemens.com/simatic-tech-doku-portal>)
- Your local representative
(<http://www.automation.siemens.com/mcms/aspa-db/en/Pages/default.aspx>)
- Training center (<http://sitrain.automation.siemens.com/sitrainworld/?AppLang=en>)
- Industry Mall (<https://mall.industry.siemens.com>)

When contacting your local representative or Technical Support, please have the following information at hand:

- MLFB of the device
- BIOS version for industrial PC or image version of the device
- Other installed hardware
- Other installed software

Tools & downloads

Please check regularly if updates and hotfixes are available for download to your device. The download area is available on the Internet at the following link:

After Sales Information System SIMATIC IPC/PG (<http://www.siemens.com/asis>)

A.2 Troubleshooting

This chapter provides you with tips on how to locate and/or troubleshoot problems which occur.

Problem	Cause	Remedy
The device is not operational	No power supply	<ul style="list-style-type: none"> • Check the power supply, the power cable and the power plug. • Check to see if the on-off switch is in the correct position.
	Device is being operated outside the specified ambient conditions	<ul style="list-style-type: none"> • Check the ambient conditions. • After transport in cold weather do not turn the power on until after a waiting period of approximately 12 hours.
The monitor remains dark	The monitor is switched off	Switch on the monitor.
	The monitor is in "power save" mode	Press any key on the keyboard.
	The brightness button has been set to dark	Increase brightness using the brightness button. Detailed information can be found in the operating manual for the monitor.
	The power cord or the monitor cable is not connected.	<ul style="list-style-type: none"> • Check if the power cord is properly connected to the monitor and to the system unit or to the grounded shockproof power outlet. • Check to make sure the monitor cable is properly connected to the system unit and the monitor. <p>Contact your technical support team if the screen still remains dark after all these controls and measures.</p>
The mouse pointer does not appear on the screen	The mouse driver is not loaded	Check whether the mouse driver is properly installed and available when you start the user program. Detailed information about the mouse driver is available in the corresponding documentation.
	Mouse not connected	<ul style="list-style-type: none"> • Check to make sure that the mouse cable is properly connected to the system unit. • If you use an adapter or extension cable for the mouse cable make sure to check these connections as well. <p>Contact your technical support team if the mouse pointer still does not appear on the screen after these controls and measures.</p>
Time and/or date of the PC is not correct		<ol style="list-style-type: none"> 1. Press <F2> during the booting process to open the BIOS Setup. 2. Set the time and date in the setup menu.
Although the BIOS setting is OK, the time and data are still wrong	The backup battery is dead.	Replace the backup battery.

Problem	Cause	Remedy
USB device not responding	The USB ports are disabled in BIOS.	Use a different USB port or activate the port.
	USB-2.0/3.0 device connected and USB-2.0/3.0 is disabled	Activate the USB.
	The operating system does not support the USB ports.	<ul style="list-style-type: none"> Switch on the USB legacy support for the mouse and keyboard. For other devices, you need the USB device drivers for the required operating system.
DVD drive does not open	The device is switched off or the open/close button is disabled by a software application.	Emergency removal of the data medium: <ol style="list-style-type: none"> Switch off the device. Insert a pointed object such as a straightened paper clip into the emergency eject opening of the drive and press gently until the front loader opens. Use your hand to pull the loader out further.

A.3 RAID system and device startup

Problem	Cause	Remedy
The RAID software reports the following errors: <ul style="list-style-type: none"> The RAID plug-in failed to load, because the drive is not installed. The Serial ATA plug-in failed to load, because the driver is not installed correctly. The Intel® Matrix Storage Console was unable to load a page for the following reason: <ul style="list-style-type: none"> A plug-in did not provide a page for the selected device A plug-in failed to load 	RAID is not activated	The messages have no negative effect on the operation of the device and can be ignored. Acknowledge the messages.
	RAID is activated	Install the software again from the supplied "Documentation and Drivers" DVD.
After changing the drive, the system does not boot from the RAID system	RAID system does not have highest boot priority	BIOS setup, Boot menu: <ul style="list-style-type: none"> Permit RAID system in the boot priority Set the RAID system to be first in the boot priority order.
After changing the drive, "unused" is indicated for the relevant SATA port	System was booted without functioning drive. The removable drive bay might not be switched on.	Reboot the system with a functioning drive.

Problem	Cause	Remedy
<p>Computer does not boot or "Boot device not found" is displayed</p>	<ul style="list-style-type: none"> • The boot device is not permitted • The boot device is not in first place of the boot priority in the BIOS setup • The boot data carrier is set up with GPT and UEFI boot is deactivated in the BIOS setup 	<ul style="list-style-type: none"> • In the BIOS setup "Boot" menu, permit the boot device in the boot priority • In the BIOS setup "Boot" menu, change the boot priority of the Boot device • Activate UEFI boot in the BIOS setup.
<p>The startup of a Windows operating system on a GPT data carrier is aborted with the following error message: "Status: 0xc0000225 Info: The boot selection failed because a required device is inaccessible"</p>	<p>The boot parameters in the boot loader file "BCD" are incorrect or damaged.</p>	<p>Execute "Startup and Repair" from Microsoft Windows:</p> <ol style="list-style-type: none"> 1. Insert the Recovery DVD into the optical drive. 2. Select the line with "UEFI" in front of the name of the optical drive. 3. Click "Next" in the language selection window. 4. In the following "Install Windows" dialog, click on "Repair your computer" or press the <R> key. The "System Recovery Options" dialog appears. The system is checked for errors. 5. Next, click "Repair and restart".

A.4 Notes on the use of third-party modules

Problem	Cause	Remedy
The device crashes during startup	<ul style="list-style-type: none"> • Redundant I/O addresses • Redundant hardware interrupts and/or DMA channels • Signal frequencies or signal levels are not adhered to • Different pin assignment 	<p>Check your computer configuration:</p> <ul style="list-style-type: none"> • If the computer configuration corresponds to the delivery state, contact your technical support team. • In the case of a change in the configuration, restore the delivery state. To do this, remove the third-party modules and restart the device. If the error no longer occurs, the third-party module being used was the cause of the fault. Replace the third-party module with a Siemens module or contact the module supplier.
		If the device still crashes, contact your technical support team.
	Insufficient output of an external power supply, e.g., UPS	Use a higher capacity power supply
The device does not start up or switches off immediately	A counter voltage is fed into the device by connected or installed third-party components	<p>Clarify the following with the supplier of the component:</p> <ul style="list-style-type: none"> • The component can be operated without an external power supply. • The component can be reconfigured so that it only uses the external power supply or that of the device.

List of abbreviations

Abbreviation	Term	Meaning
AC	Alternating current	Alternating current
PLC	Programmable controller	
AGP	Accelerated Graphics Port	High speed bus system
AHCI	Advanced Host Controller Interface	Standardized controller interface for SATA devices. This is supported in Microsoft Windows XP as of SP1 and IAA driver.
APIC	Advanced Programmable Interrupt Controller	Extended programmable interrupt controller
AT	Advanced Technology	
ATA	Advanced Technology Attachment	
AWG	American Wire Gauge	US standard for the cable diameter
BIOS	Basic Input Output System	Basic Input Output System
CAN	Controller Area Network	
CD-ROM	Compact Disc – Read Only Memory	Removable storage medium for large data volumes
CD-RW	Compact Disc – Rewritable	Rewritable CD
CE	Communauté Européenne (CE symbol)	The product is in conformance with all applicable EC directives
CF	Compact Flash	
CMOS	Complementary Metal Oxide Semiconductors	Complementary metal oxide semiconductors
COA	Certificate of authentication	Microsoft Windows Product Key
COM	Communications Port	Term for the serial interface
CP	Communication Processor	Communication computer
CPU	Central Processing Unit	CPU
CRT	Cathode Ray Tube	
CSA	Canadian Standards Association	Canadian organization for tests and certifications according to own or binational standards (with UL / USA) standards
DRAM	Dynamic Random Access Memory	
DMA	Direct Memory Access	Direct memory access
DOS	Disk Operating System	Operating system without GUI
DVD	Digital Versatile Disk	
DVI	Digital Visual Interface	Digital display interface
DVI-I	Digital Visual Interface	Digital display interface with digital and VGA signals
ECP	Extended capability port	Extended parallel port

Abbreviation	Term	Meaning
EFI	Extensible Firmware Interface	
ESD	Components sensitive to electrostatic charge	
EN	European standard	
EPP	Enhanced Parallel Port	Bi-directional Centronics interface
HD	Hard Disk	Hard disk
HDD	Hard Disk Drive	Hard disk drive
HU	Height unit	
HT	Hyper Threading	
I/O	Input/Output	Data input/output on computers
IAA	Intel Application Accelerator	
IDE	Integrated Device Electronics	
IEC	International Electrotechnical Commission	
IP	Ingress Protection	Degree of protection
IRQ	Interrupt Request	Interrupt request
ISA	Industry Standard Architecture	Bus for expansion modules
LAN	Local Area Network	Computer network that is limited to a local area.
LCD	Liquid Crystal Display	Liquid crystal display
LED	Light Emitting Diode	Light emitting diode
LPT	Line Printer	Printer port
MAC	Media access control	Media access control
MLFB	Machine-readable product designation	
MUI	Multilanguage User Interface	Language localization in Windows
NEMA	National Electrical Manufacturers Association	Syndicate of manufacturers of electrical components in the USA
NTFS	New Technology File System	Secure file system for Windows versions (2000, XP, 7)
OPC	OLE for Process Control	Standardized interface for industrial processes
PC	Personal computer	
PCI	Peripheral Component Interconnect	High-speed expansion bus
PCIe	Peripheral Component Interconnect express	High-speed serial, differential full-duplex PtP interface with high data rate.
PFC	Power Factor Correction	Harmonic suppression for operation on public networks.
PG	Programming device	
PIC	Programmable Interrupt Controller	Programmable interrupt controller
PXE	Preboot Execution Environment	Software for running new PCs without drive data via the network
RAID	Redundant Array of Independent Disks	Redundant drive array
RAM	Random Access Memory	
ROM	Read-Only Memory	
SDRAM	Synchronous DRAM	

Abbreviation	Term	Meaning
SJT	Service [Grade] Junior (Hard Service) Thermoplastic	PVC armored cable
SNMP	Simple Network Management Protocol	Network protocol
SSD	Solid State Drive	
UEFI	Unified Extensible Firmware Interface	
UL	Underwriters Laboratories Inc.	US organization for tests and certifications according to own or binational standards (with CSA / Canada) standards
URL	Uniform Resource Locator	Designation of the full address of an Internet page
USB	Universal Serial Bus	
V.24		ITU-T standardized recommendation for data transfer via serial ports
VDE	Verband der Elektrotechnik Elektronik Informationstechnik e.V	since 1998: Verband der Elektrotechnik Elektronik Informationstechnik e.V formerly: Verband Deutscher Elektrotechniker
VGA	Video Graphics Array	Video adapter which meets industrial standard
VT	Virtualization Technology	Intel technology with which a virtually closed environment can be made available
WD	Watchdog	Program monitoring with error detection and alarming

Glossary

APIC mode

Advanced peripheral interrupt controller. 24 interrupt lines are available.

Automation system

A programmable controller (PLC) of the SIMATIC S7 system consist of a central controller, one or several CPUs, and various I/O modules.

BIOS Setup

A program in which information about the device configuration (that is the configuration of the hardware on the PC/PG) is defined. The device configuration of the PC/PG is preset with defaults. Changes must therefore be entered in the SETUP if a memory expansion, new modules or a new drive are added to the hardware configuration.

Cache

High-speed access buffer for interim storage (buffering) of requested data.

Card retainer

The card retainer is used to fasten expansion cards and ensure safe contact and transport. Large, heavy expansion cards are particularly affected by shocks and vibrations. We therefore recommend that you use the card retainer for this type of expansion card. Very short, compact and light expansion cards are also available on the market. The card retainer was not designed for these expansion cards because standard fastening is sufficient for them.

CE marking

CE stands for Communauté Européenne. The CE symbol confirms the conformity of the product with all applicable EC directives such as the EMC Directive.

Chipset

The chipset sits on the motherboard and connects the processor to the RAM, the graphics card, the PCI bus and the external interfaces.

Configuration files

These are files containing data which define the configuration after restart. Examples of such files are CONFIG.SYS, AUTOEXEC.BAT and the registry files .

Controller

Integrated hardware and software controllers that control the functions of certain internal or peripheral devices (for example, the keyboard controller).

Device configuration

The configuration of a PC or programming device contains information on hardware and device options, such as memory configuration, drive types, monitor, network address, etc. The data are stored in a configuration file and enable the operating system to load the correct device drivers and configure the correct device parameters. . If changes are made to the hardware configuration, the user can change entries in the configuration file using the SETUP program. .

Disc-At-Once

With this burning technique, data are written to a CD in a single session, and the CD is then closed. Further write access is then no longer possible.

DisplayPort

DisplayPort is a VESA standardized, universal and license-free connection standard for the transmission of image and sound signals. Areas of application are mainly the connection of screens and TVs to computers, DVD players and similar devices.

Drivers

Program parts of the operating system. They adapt user program data to the specific formats required by I/O devices such as hard disks, printers, and monitors.

DVD

The DVD (short for: Digital Versatile Disc; English for: Digital Versatile Disc) is a digital optical storage medium, like a CD, but with a larger capacity. R "Recordable" stands for writable once, RW "Rewritable" means you can rewrite the DVD up to approximately 1000 times.

Energy options

The energy options can be used to reduce energy consumption of the computer, while keeping it ready for immediate use. This can be configured in Windows by selecting Settings > Control Panel > Energy options.

Ethernet

Local network (bus structure) for text and data communication with a transfer rate of 10/100/1000 Mbps.

Extensible Firmware Interface

Refers to the central interface between the firmware, the individual components of a computer and the operating system. EFI is located logically beneath the operating system and represents the successor to PC BIOS, focusing on 64-bit systems.

Image

This refers to the image, for example, of hard disk partitions saved to a file in order to restore them when necessary.

Intel Active Management Technology

This technology permits the diagnostics, management and remote control of PCs. It is only effective when all relevant system components, such as processors, operating systems and applications are supported.

Interface

- Physical interconnection (cable) of hardware elements such as PLCs, PCs, programming devices, printers or monitors.
- Interface for interactive software applications.

Interface

See Interface

- Physical interconnection (cable) of hardware elements such as PLCs, PCs, programming devices, printers or monitors.
- Interface for interactive software applications.

Interface, multi-point

MPI is the programming interface of SIMATIC S7/M7. Allows remote access to programmable modules, text-based displays and OPs from central locations. The MPI nodes can intercommunicate.

LAN

LAN is a local network that consists of a group of computers and other devices that are distributed across a relatively restricted range and are linked with communication cables. The devices connected to a LAN are called nodes. The purpose of networks is the mutual use of files, printers or other resources.

License key

The license key represents the electronic license stamp of a license. Siemens AG issues a license key for each software that is protected by a license.

Module

Modules are plug-in units for PLCs, programming devices or PCs. They are available as central modules, interface modules, expansion cards or mass storage (mass storage module).

Motherboard

The motherboard is the core of the computer. Here, data are processed and stored, and interfaces and device I/Os are controlled and managed.

Operating system

Generic term which describes all functions for controlling and monitoring user program execution, distribution of system resources to the user programs and the operating mode in cooperation with the hardware (for example Windows XP Professional).

Packet writing

The CD-RW is used as a disk medium. The CD can then be read only by packet-writing compatible software or has to be finalized. Finalization of a CD closes the CD within an ISO9660 shell. You can still write to the CD-RW several times in spite of finalization. Not all CD drives can read packet-written CDs . There are restrictions to using this method in general data transfer.

PCIe

PCI-Express (Peripheral Component Interconnect Express) is an extension standard for connection of I/O devices with the chipset of a main processor. PCIe is the successor of PCI, PCI-X and AGP and offers a higher data transmission rate in comparison to its predecessors.

PIC mode

Peripheral interrupt controller. 15 interrupt lines are available.

PROFIBUS, MPI

Process Field Bus (standard bus system for process applications)

PROFINET

PROFINET is the name of the standard for Industrial Ethernet developed and maintained by the PROFIBUS user organization. PROFINET unites protocols and specifications with which Industrial Ethernet meets the requirements of industrial automation technology.

Programmable controller

The programmable controllers of the SIMATIC S5 system consist of a central controller, one or more CPUs, and various other modules (e.g. I/O modules).

Recovery DVD

Contains the tools for configuring hard disks and the Windows operating system.

Reset

Hardware reset: Reset/restart of the PC using a button/switch.

Restart

Warm restart of a computer without switching the power off (Ctrl + Alt + Del)

Restore DVD

The Restore DVD is used to restore the system partition or the entire hard disk to factory state if the system has crashed. The DVD contains all the necessary image files and is bootable.

S.M.A.R.T

SMART or S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) is an industry standard that is installed in storage media. It makes for permanent monitoring of important parameters and early detection of imminent problems.

SATA

Serial ATA Interface for hard disk drives and optical drives with serial data transmission rates of up to 300 Mbps.

Session-At-Once

In session-at-once, the CD can be written to both with an audio session and a data session. The two sessions are written to at once (as in disc-at-once).

Solid State Drive

A Solid State Drive is a drive that can be installed like any other drive; it does not contain a rotating disk or other moving parts because only semiconductor memory chips of similar capacity will be used. This design makes SSDs more rugged, provides shorter access times, low energy consumption and rapid data transfer.

Track-At-Once

In track-at-once recording, a CD can be written to in bits in several sessions if the CD was not closed.

Wake on LAN

Wake on Local area network. This function allows the PC to be started via the LAN interface.

Index

2

2 HDD system, (System with two drives)

5

5.25" drive
Installing, 79

A

Access protection, 29
AHCI controller
 Making known to the operating system, (See storage controllers)
Alarm reset button, 19
Angle brackets, 38
Antivirus software, 56
Approval, (EAC)
Approvals, 31
Australia, 114
Authorization, 109
Automatic Update, 56

B

Backup battery, 62
 Maintenance interval, 84
Basic data, 11
Battery monitoring, 62

C

Cabinet manufacturer, 38
Canada, 114
CE marking, 115
Certificates, 115
 Certifications and approvals, 113
COA label, 35
COM interface
 Technical specifications, 126
COM1
 Connection, 17
COM2
 Connection, 17

Component label, 35
Components sensitive to electrostatic charge, 115
Condensation, 34
Connecting
 Equipotential bonding, 41
 I/O devices, 40
 Power supply, 45
Connection of equipotential bonding, 41
Connections, (Interfaces)
Country-specific information, 42

D

Data carrier controller
 Making known to the operating system, 104
Data exchange, 46
Degree of protection, 122
Device configuration, 133
Device fan, 92
 Maintenance interval, 84
 Removing and installing, 92
DiagMonitor, 13
 Temperature monitoring, 60
Dimension drawings, 118
Directive
 ESD Directive, 115
DisplayPort
 Connection, 17
Documentation and Drivers CD/DVD, 101
Drive cage
 Removal, 70
Drivers
 Installing, 102
Drives
 Maintenance interval, 84
 Mounting locations, 11
 Technical specifications, 125
Dust protection, 122
DVD drive
 Removing and installing, 80
DVI-I
 Connection, 17

E

EAC, 114
EC Declaration of Conformity, 115

Electromagnetic compatibility, 115
 for system expansions, 26
EMC, (Electromagnetic compatibility)
 UPS, 128
Equipotential bonding, 41
ESD, 115
ESD Directive, 115
Ethernet, 46
 Connection, 17
 Status display, 21
Ethernet address, 36
Expansion cards
 Installing, 68
 Slots on motherboard, 124
 Specification, 68
 Types, 12

F

Fan, (Device fan)
Fan cover
 Location of filter pad, 84
 Open, 66
FCC, 113
Filter, (Filter pad)
Filter pad
 Changing, 84
 Maintenance interval, 84
Fire protection, 37
Fire protection housing, 37
Firewall, 56
Front panel, (Fan cover)
 Configuration, 14
FS, (Manufacturing version)

G

Graphic controller, 125
Graphics card, 126
Graphics memory, 125

H

Hard disk
 installing in removable drive bay, 73
 remove from removable drive bay, 71
Hard disk drive
 Second hard disk drive, (System with two drives)
Hardware reset, 57
Highlights, 10
Hot spare drive, 55

I

I/O devices
 Connecting, 40
Identification data, 35
Image & Partition Creator, 13
Initial commissioning, 49
Inrush current
 Redundant power supply, 129
 Single power supply, 128
Installation
 5.25" drive, 79
 Expansion cards, 68
 Mounting locations, 37
 Mounting methods, 37
Installation information, 36
Installing
 Windows, 103
Installing language package, (See MUI)
Integration
 Ethernet, 46
 PROFINET, 46
Interface
 COM1, 17
 COM2, 17
 DisplayPort, 17
 DVI-I, 17
 Ethernet, 17
 LPT, 17
 USB 2.0, 16, 17
 USB 3.0, 17
 VGA, 17
Interfaces
 On the device rear, 16
 Parallel, 126
IT communication, 46

L

Labeling, 114
 Korea, 114
LAN, (Ethernet)
LEDs, (Status displays)
License key, 109
Limitation of liability, 83
LPT
 Connection, 17
LPT1, 126

M

Main memory, 124

- Manufacturing version
 - of the device, 36
 - Marking
 - EC Declaration of Conformity, 115
 - Memory modules
 - Slots on motherboard, 124
 - Modules, (Expansion cards)
 - Monitoring
 - Fan, 61
 - Temperature, 60
 - Monitoring functions
 - Overview, 12, 59
 - Motherboard, (See motherboard)
 - Removal, 97
 - Mounting holes, 38
 - MUI, 107
 - Multi-monitoring, 47
- N**
- NCQ, 125
 - New Zealand, 114
 - Note, 36
 - Installation guidelines, 36
- O**
- On/off button, 19
 - On/Off switch
 - Basic power supply, 19
 - Redundant power supply, 19
 - Open
 - Device, 67
 - Open the device, 67
 - Operating system, 12
 - Initial commissioning, 49
 - Installing, 103
 - Shutdown, 56
 - Updates, 101
 - Operator controls, 19
- P**
- Package contents, 33
 - Checking, 33
 - Packaging, 33
 - Checking, 33
 - Removing, 33
 - Partitions
 - Setting up, 104
 - Windows, 106
 - Power consumption, 121
 - Power plug latch, 43, 44
 - Power requirements, 127, 128
 - Power supply
 - basic, 12
 - Connecting, 42
 - Connecting a single power supply, 43
 - Redundant, 12
 - Processor, 124
 - Changing, 99
 - Product version
 - of the device, (Manufacturing version)
 - PROFIBUS
 - Integration, 46
 - PROFINET, 46
 - Protection class, 31, 122
 - Protective measure
 - Static electricity, 117
- R**
- Radiation, 27
 - High frequency radiation, 27
 - RAID, 141
 - RAID controller
 - Making known to the operating system, (See storage controllers)
 - RAID system
 - Automatic integration of new hard disk, 89
 - Checking status, 87
 - Displaying the defective HDD in the RAID software, 87
 - Integrating hot-spare drive, 92
 - Management functions, 54, 86
 - Manual integration of new hard disk, 89
 - RAID1 system, 55
 - Mounting locations for hard disk drives, 77
 - Replacing a defective hard disk drive, 79
 - Status displays of the hard disk drives, 77
 - RAID1 system with hot spare drive, 55
 - RAID5 system, 55
 - Detecting a defective hard disk drive, 78
 - Mounting locations for hard disk drives, 78
 - Replacing a defective hard disk drive, 79
 - Status displays of the hard disk drives, 79

- RAID5 system with hot spare drive, 55
- Rating plate, 35
- Rear of the device
 - Configuration, 15
- Recovery DVD, 101
- Removable hard disk, 52
- Removal
 - Device fan, 92
 - Drive cage, 70
 - DVD drive, 80
 - Motherboard, 97
 - Processor, 99
 - Redundant power supply, 96
 - Single power supply, 95
- Repairs, 83, 84
- Restore DVD, 101
- Restoring the factory state, 109

S

- Safety information
 - Storage, 34
 - Transportation, 34
- Serial number, 36
- SIMATIC NET, 46
- SIMATIC S7, 46
 - Integration, 46
- SIMATIC software
 - Installing, 102
- Slave drive, (System with two drives)
- Software
 - Installing, 102
- Static electricity
 - Protective measures, 117
- Status displays, 20
 - Ethernet interface, 21
- Status indicators, (Status displays)
- Supply voltage, 42, 121
- Switching off the device
 - Disconnect from mains voltage, 57
 - Forced shutdown, (Hardware reset)
 - Hardware reset, 57
 - Shutting down the operating system, 56
- Switching on the device
 - Configure automatic startup, 50
 - Switching on for the first time, 49
- System partition, 109
- System resources, 130
- System with two drives, 53

T

- Technical specifications, 121
- Telescopic rails, 38
 - Technical specifications (basic configuration), 129
- Temperature monitoring, 60
- Tools, 84

U

- UL approval, 113
- Uninterruptible power supply, 128
- Update,
 - Updates
 - Operating system, 101
- UPS, (Uninterruptible power supply)
- USB 2.0
 - Connection, 16, 17
- USB 3.0
 - Connection, 17
- User Account Control, 56

V

- Ventilation slots, 31, 37
- VGA
 - Connection, 17

W

- Warranty, 26
- Watchdog, 12, 61
 - Monitoring function, 61
 - Monitoring times, 62
- Windows
 - Installing, 103
 - Partitions, 106
- Windows Action Center, 56