

# SIEMENS

## SIMATIC

### Engineering Tools

## S7-PLCSIM V15.1 installation notes

### Readme

## The installation disk

The installation disk for S7-PLCSIM V15.1 performs the following function:

- Installs S7-PLCSIM V15.1

## Prerequisites to installation

You must meet the following prerequisites before you install S7-PLCSIM V15.1:

- Your programming device must meet the hardware and software system requirements.
- You have administrator rights on the programming device.
- Exit or disable any running Siemens applications or other programs.

### Security settings

In order to operate S7-PLCSIM, you must enter port 4410 for TCP as an exception in the Windows firewall during installation.

### License requirements

It is possible to install S7-PLCSIM without an individual license key.

However, you require a valid STEP 7 Basic or Professional license to run S7-PLCSIM.

### Hardware and software requirements

S7-PLCSIM V15.1 has the same hardware and software requirements as the TIA Portal V15 SP1, with one exception. For acceptable performance, your programming device should have a quad core processor that is equal to, or better than, an Intel® Core™ i5-6440EQ Processor, up to 3.40 GHz.

Refer to the Installation section of the TIA Portal V15 SP1 online help for specific details.

## Installing S7-PLCSIM

Follow these steps to install S7-PLCSIM V15.1:

1. Insert the installation medium into your computer's DVD drive. The setup program starts automatically unless you have disabled Autostart on the programming device or PC. If the setup program does not start automatically, start it manually by double-clicking the "Start.exe" file. The "General settings" window displays.
2. Select the check box for the language you want to use during installation.
3. Click "Read installation notes" to display installation information. Close the file after you read the notes.
4. Click "Read product information" to display the Readme file. Close the file after you read it.
5. The check box for "Create desktop icon" is selected by default. If you do not want a shortcut to S7-PLCSIM on your computer desktop, clear the check box.
6. Click "Browse" if you want to change the default installation path. The path name can contain a maximum number of 89 characters and cannot contain UNICODE characters. Note that if you change the installation path, it is possible that the desktop shortcut icon might not display correctly.

7. Click "Next". The security settings window opens. To continue installation, select the check box at the bottom of the screen to accept changes to your system's security and permissions settings.
8. The overview screen displays your installation details. Click "Install". The installation process runs and S7-PLCSIM installs on your computer system.
9. You must reboot your computer after setup completes. Select "Yes, restart my computer now." to restart the computer immediately, or select "No, I will restart my computer later." to postpone rebooting.
10. Click "Restart." If the computer does not restart, click "Exit" and perform the reboot from the Windows start menu.

## Modifying S7-PLCSIM

You can modify your S7-PLCSIM installation to change the installed language or to add languages.

### Requirements for modifying the installation

Be sure you meet the following conditions before you begin to modify the installation:

- Your hardware and software meet the system requirements.
- You have administrator privileges on the installation computer.
- No other programs are running.

### Procedure to modify the installation

Follow these steps to modify your S7-PLCSIM installation:

1. Insert the installation disk into your disk drive. The setup program starts automatically unless you have disabled "Autostart" on the programming device or PC.
2. If the setup program does not start automatically, start it manually by double-clicking the "Start.exe" file.
3. Follow the prompts until you reach the Configuration window. Select the "Modify Upgrade" option button.
4. Continue to follow the prompts to modify your installation.
5. Restart your computer to finish the installation process.

---

### Note

You cannot change the target directory because you are modifying an existing installation.

---

## Repairing S7-PLCSIM

Use the S7-PLCSIM disk to repair your installation.

### Requirements for repairing the installation

Be sure you meet the following conditions before you begin the repair process:

- Your hardware and software meet the system requirements.
- You have administrator rights on the installation computer.
- No other programs are running.

## Procedure to repair the installation

Follow these steps to repair your installation:

1. Insert the installation disk into your disk drive. The setup program starts automatically unless you have disabled Autostart on the programming device or PC. If the setup program does not start automatically, start it manually by double-clicking the "Start.exe" file.
2. Follow the prompts until you reach the Configuration window. Select the "Repair" option button.
3. Continue to follow the prompts to repair your installation.
4. Restart your computer to finish the repair process.

## Uninstalling S7-PLCSIM

You have two options for removing S7-PLCSIM from your computer system:

- Remove the program by using the Windows Control Panel
- Remove the program by using the installation disk

### Removing S7-PLCSIM using the Windows Control Panel

Follow these steps to remove S7-PLCSIM using the Windows Control Panel:

1. In the Windows Control Panel, click "Programs and Features".
2. Right-click "SIMATIC S7-PLCSIM V15.1" and select "Uninstall".
3. Follow the prompts to uninstall S7-PLCSIM.
4. Restart your computer to complete the uninstall process.

### Removing S7-PLCSIM using the installation disk

To remove S7-PLCSIM using the installation disk, follow these steps:

1. Insert the installation disk into your disk drive. The setup program starts automatically unless you have disabled Autostart on the programming device or PC. If the setup program does not start automatically, start it manually by double clicking the "Start.exe" file.
2. Follow the prompts until you reach the "Configuration" window. Click the "Uninstall" option button.
3. Continue to follow the prompts to uninstall S7-PLCSIM.
4. Restart your computer to complete the uninstall process.

Siemens AG  
Division Digital Factory  
Postfach 48 48  
90026 NÜRNBERG  
GERMANY

S7-PLCSIM V15.1 installation notes  
A5E44431907-AA, v15.1, 10/2018