

CP	Firmware Version	Product Release	Order Number
PROFIBUS CPs			
CM 1542-5	from V1.0	1	6GK7542-5DX00-0XE0
CP 1542-5	from V1.0	2	6GK7542-5FX00-0XE0
CP 342-5	from V3.0	2	6GK7342-5DA01-0XE0
	from V4.0	-	6GK7342-5DA02-0XE0
	from V6.0	-	6GK7342-5DA03-0XE0
CP 342-5 FO	from V4.0	-	6GK7342-5DF00-0XE0
CP 343-5	from V3.0	6	6GK7343-5FA00-0XE0
	from V4.0	-	6GK7343-5FA01-0XE0
CP 443-5 BASIC	from V3.0	1	6GK7443-5FX01-0XE0
	from V4.0	-	6GK7443-5FX02-0XE0
CP 443-5 EXTENDED	from V2.0	-	6GK7443-5DX02-0XE0
	from V4.0	-	6GK7443-5DX03-0XE0
	from V6.0	-	6GK7443-5DX04-0XE0
	from V7.0	-	6GK7443-5DX05-0XE0
Industrial Ethernet CPs			
CM 1542-1	from V1.0	-	6GK7542-1AX00-0XE0
CP 1543-1	from V1.0	-	6GK7543-1AX00-0XE0
CP 1243-1	from V2.0	-	6GK7243-1BX30-0XE0
CP 343-1 Standard	from V4.0	6	6GK7343-1EX00-0XE0
	from V1.0	-	6GK7343-1EX10-0XE0
	from V2.0	-	6GK7343-1EX11-0XE0
	from V1.0	-	6GK7343-1EX20-0XE0
	from V1.0	-	6GK7343-1EX21-0XE0
	from V2.0	-	6GK7343-1EX30-0XE0
CP 343-1 ISO	from V4.0	6	6GK7343-1BA00-0XE0
CP 343-1 IT	from V1.0	-	6GK7343-1GX00-0XE0
	from V2.0	-	6GK7343-1GX11-0XE0
	from V1.0	-	6GK7343-1GX20-0XE0
CP 343-1 Advanced	from V1.0	-	6GK7343-1GX21-0XE0
	from V1.0	-	6GK7343-1GX30-0XE0
	from V3.0	-	6GK7343-1GX31-0XE0
CP 343-1 Lean	from V1.0	-	6GK7343-1CX00-0XE0
	from V1.0	-	6GK7343-1CX10-0XE0
CP 343-1 PN	from V1.0	-	6GK7343-1HX00-0XE0
CP 443-1 Standard	from V1.0	-	6GK7443-1EX01-0XE0
	from V1.0	-	6GK7443-1EX02-0XE0
	from V1.0	-	6GK7443-1EX10-0XE0
	from V1.1	-	6GK7443-1EX11-0XE0
	from V1.0	-	6GK7443-1EX20-0XE0
	from V3.0	-	6GK7443-1EX30-0XE0
CP 443-1 IT	from V1.0	-	6GK7443-1GX10-0XE0
	from V1.0	-	6GK7443-1GX11-0XE0
CP 443-1 Advanced	from V1.0	-	6GK7443-1EX40-0XE0
	from V1.0	-	6GK7443-1EX41-0XE0
	from V2.0	-	6GK7443-1GX20-0XE0
	from V3.0	-	6GK7443-1GX30-0XE0
CP 443-1 ISO	from V1.0	1	6GK7443-1BX01-0XE0

This entry is from the Service&Support portal
of Siemens AG, Siemens Industry Online Support.

The general terms of use

CP	Firmware Version	Product Release	Order Number
PROFIBUS PC CPs			
CP 5511	-	-	6GK1551-1AA00
CP 5512	-	-	6GK1551-2AA00
CP 5711	-	-	6GK1571-1AA00
CP 5611	-	-	6GK1561-1AA00
CP 5611 A2	-	-	6GK1561-1AA01
CP 5612	-	-	6GK1561-2AA00
CP 5621	-	-	6GK1562-1AA00
CP 5622	-	-	6GK1562-2AA00
CP 5613	-	-	6GK1561-3AA00
CP 5613 A2	-	-	6GK1561-3AA01
CP 5613 A3	-	-	6GK1561-3AA02
CP 5623	-	-	6GK1562-3AA00
CP 5613 FO	-	-	6GK1561-3FA00
CP 5614	-	-	6GK1561-4AA00
CP 5614 A2	-	-	6GK1561-4AA01
CP 5614 A3	-	-	6GK1561-4AA02
CP 5624	-	-	6GK1562-4AA00
CP 5614 FO	-	-	6GK1561-4FA00
PROFIBUS PC Adapter			
PC Adapter USB A2	-	-	6GK1571-0BA00-0AA0
Industrial Ethernet PC CPs			
CP 1612	-	-	6GK1161-2AA00
CP 1612 A2	-	-	6GK1161-2AA01
CP 1613	-	-	6GK1161-3AA00
CP 1613 A2	-	-	6GK1161-3AA01
CP 1623	-	-	6GK1162-3AA00
CP 1628	-	-	6GK1162-8AA00

This entry is from the Service&Support portal
of Siemens AG, Siemens Industry Online Support.

The general terms of use

(http://www.siemens.com/terms_of_use) apply.