ProTool/Pro V6.0 + SP3 (11/2004) **released for Windows 98SE , Windows ME , Windows NT 4.0 + SP6a (Workstat.) , Windows 2000 + SP2/3/4 (Professional) and Windows XP Professional + SP1/2**	**6AV658*-*BX06-0DX0**
SIMATIC NET --- V6.2 - CD 11/2003 + SP1 (07/2004) **Products --- V6.0 - CD 07/2001 + SP5+HF2 (08/2003)**	
CP 5611 **CP 5611 A2** (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1561-1AA00 6GK1561-1AA01
CP 5511 (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1551-1AA00
CP 5512 (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1551-2AA00
CP 5613 **CP 5613 A2** **CP 5614** **CP 5614 A2** (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00 6GK1561-3AA01 6GK1561-4AA00 6GK1561-4AA01
S7-5613 V6.0 (CD 07/2001 + SP5+HF2) released for Windows NT 4.0 (Workstat. / Server)	6GK1713-5CB61-3AA0
S7-5613 V6.2 (CD 11/2003 + SP1) released for Windows 2000 (Professional/Server) and Windows XP Professional	6GK1713-5CB62-3AA0

= please see the operating system restriction from ProTool / NET

ProTool/Pro V6.0 + SP2 (02/2003)	**6AV658*-*BX06-0CX0**
released for Windows 98SE, Windows ME, Windows NT 4.0 + SP6a (Workstat.), Windows 2000 + SP2/3 (Professional) and Windows XP	
SIMATIC NET --- V6.1 - CD 11/2002 (01/2003) **Products --- V6.0 - CD 07/2001 + SP5 (01/2003)**	
CP 5611 (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1551-1AA00
CP 5512 (Communication software for Windows 98, Windows NT, Windows 2000 and Windows XP included in ProTool/Pro RT)	6GK1551-2AA00
CP 5613 **CP 5614** (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00 6GK1561-4AA00
S7-5613 V6.0 (CD 07/2001 + SP5) released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional/Server)	6GK1713-5CB61-3AA0
S7-5613 V6.1 (CD 11/2002) released for Windows XP Professional	6GK1713-5CB61-3AA0

= please see the operating system restriction from ProTool / NET

ProTool/Pro V6.0 + SP1a (10/2002) **released for Windows 98SE, Windows ME, Windows NT 4.0 + SP6a (Workstat.) and Windows 2000 + SP2/3 (Professional)**	**6AV658*-*BX06-0BX0**
SIMATIC NET Produkte - CD 07/2001 + SP4 (04/2002)	
CP 5611 (Communication software for Windows 98, Windows NT and Windows 2000 included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 98, Windows NT and Windows 2000 included in ProTool/Pro RT)	6GK1551-1AA00
CP 5613 **CP 5614** (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00 6GK1561-4AA00
S7-5613 V6.0 released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional/Server)	6GK1713-5CB60-3AA0

= please see the operating system restriction from ProTool / NET

ProTool/Pro V6.0 + SP1 (06/2002) **released for Windows 98SE , Windows ME , Windows NT 4.0 + SP6a (Workstat.) and Windows 2000 + SP2 (Professional)**	**6AV658*-*BX06-0AX0**
SIMATIC NET products - CD 07/2001 + SP4 (04/2002)	
CP 5611 (Communication software for Windows 98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1551-1AA01
CP 5613 (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00
S7-5613 V6.0 released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional/Server)	6GK1713-5CB60-3AA0

ProTool/Pro V6.0 (02/2002) **released for Windows 98SE , Windows ME , Windows NT 4.0 + SP6a (Workstat.) and Windows 2000 (Professional)**	**6AV658*-*BX06-0AX0**
SIMATIC NET products - CD 07/2001 + SP2 (02/2002)	
CP 5611 (Communication software for Windows 98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1551-1AA01
CP 5613 (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00
S7-5613 V6.0 released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional/Server)	6GK1713-5CB60-3AA0

ProTool/Pro V5.2 + SP3 (02/2001) **released for Windows 95/98 , Windows ME , Windows NT 4.0 + SP5/6 (Workstat.) and Windows 2000 (Professional)**	**6AV658*-*BX05-2CX0**
SIMATIC NET products (CD 05/2000)	
CP 5611 (Communication software for Windows 95/98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 95 , Windows NT and Windows 2000 are included in ProTool/Pro RT) Not released for ProTool/Pro ander Windows 98 !	6GK1551-1AA01
CP 5613 (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs or Touch Panel are not supported.	6GK1561-3AA00
S7-5613 V2.1 released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional)	6GK1713-5CB21-3AA0
CP 5412 A2# (communicationssoftware S7-5412 must be order seperatly). CP 5412 A2 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5412 A2 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs, Grafic-OPs or Touch Panels are not supported.	6GK1541-2AA00
S7-5412 V5.2 + SP2 incl. FDL-Protocol released for Windows 98 , NT 4.0 (Workstat. / Server)	6GK1702-5CW52-3AA0

= please see the operating system restriction from ProTool / NET

\# = are not available to order

ProTool/Pro V5.2 + SP2 (08/2000) **released for Windows 95/98 , Windows ME , Windows NT 4.0 + SP4/5 (Workstat.) and Windows 2000 (Professional)**	**6AV658*-*BX05-2BX0**
SIMATIC NET products (CD 05/2000)	
CP 5611 (Communication software for Windows 95/98 , Windows NT and Windows 2000 are included in ProTool/Pro RT)	6GK1561-1AA00
CP 5511 (Communication software for Windows 95 , Windows NT and Windows 2000 are included in ProTool/Pro RT) Not released for ProTool/Pro ander Windows 98 !	6GK1551-1AA01
CP 5613 (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs or Touch Panel are not supported.	6GK1561-3AA00
S7-5613 V2.1 released for Windows NT 4.0 (Workstat. / Server) and Windows 2000 (Professional)	6GK1713-5CB21-3AA0
CP 5412 A2 (communicationssoftware S7-5412 must be order seperatly). CP 5412 A2 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5412 A2 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs, Grafic-OPs or Touch Panels are not supported.	6GK1541-2AA00
S7-5412 V5.2 + SP2 incl. FDL-Protocol released for Windows 98 , NT 4.0 (Workstat. / Server)	6GK1702-5CW52-3AA0

= please see the operating system restriction from ProTool / NET

\# = are not available to order

ProTool/Pro V5.2 + SP1 (02/2000) **released for Windows 95/98 and Windows NT 4.0 + SP4/5 (Workstat.)**	**6AV658*-*BX05-2AX0**
SIMATIC NET products (CD 11/1999)	
CP 5611 (Kommunikationssoftware für Windows 95/98 and Windows NT bei ProTool/Pro RT enthalten)	6GK1561-1AA00
CP 5511 (Communication software for Windows 95 , Windows NT and Windows 2000 are included in ProTool/Pro RT) Not released for ProTool/Pro under Windows 98 !	6GK1551-1AA01
CP 5613 (communicationssoftware S7-5613 must be order seperatly). CP 5613 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5613 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs are not supported.	6GK1561-3AA00
S7-5613 V2.0 released for Windows NT 4.0 (Workstat. / Server)	6GK1713-5CB20-3AA0
CP 5412 A2 (communicationssoftware S7-5412 must be order seperatly). CP 5412 A2 with ProTool/Pro is released only for communication with SIMATIC S7. Download of the configuration with CP 5412 A2 from ProTool/Lite, ProTool and ProTool/Pro to Zeilen-OPs, Grafic-OPs or Touch Panels are not supported.	6GK1541-2AA00
S7-5412 V5.2 incl. FDL-Protocol released for Windows 98 , NT 4.0 (Workstat. / Server)	6GK1702-5CW52-3AA0

= please see the operating system restriction from ProTool / NET

\# = are not available to order