

## SITRANS F R Rotary-Piston Meters PN 40

Operating Instructions

Edition 09/2001

### 7MR1.30



DN 15  
with dial type 01  
without accessories



DN 80  
with dial type 01  
with pulser



DN 50  
with dial type 01  
with cooling attachment  
and pulser

SIMATIC®, SIPART®, SIREC®, SITRANS®  
are registered trademarks of Siemens

All other product or system names are (registered) trademarks of their respective owners and must be treated accordingly.

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights created by the granting of patents or registration of a design are reserved.

Technical data subject to change without notice

## Contents

1	Description .....	7
1.1	Application .....	7
1.2	Design .....	8
1.3	Mode of operation .....	12
1.4	Technical data .....	13
2	Installation and operation .....	21
2.1	Unpacking .....	21
2.2	Drilling the flanges .....	21
2.3	Mounting .....	21
2.4	Commissioning .....	23
3	Maintenance .....	25
3.1	Checking and servicing .....	25
3.2	Recalibration .....	25
3.3	Removing the rotary-piston meter, replacing the piston and cleaning the sieve ...	25
3.4	Cleaning the rotary-piston meters, industrial design, DN 15 .....	26
3.4.1	Dismantling the rotary-piston meter .....	26
3.4.2	Assembly of the rotary-piston meter .....	28
3.5	Cleaning the rotary-piston meters, industrial design, DN 25, DN 50 and DN 80 ...	29
3.5.1	Dismantling the rotary-piston meter .....	29
3.5.2	Assembly of the rotary-piston meter .....	31
3.6	Troubleshooting .....	32
3.7	Determining the error in indication .....	33
3.8	Adjustment .....	34
4	Spare parts .....	37



# General Security Notes

Safety notes and warnings serve to avoid danger to the life and limb of users or maintenance personnel or material damage. They are highlighted in this manual by the terms defined here.

They are also identified by warning symbols (pictograms) at the places where they appear. The terms used have the following meanings in the sense of this manual and the signs on the product itself:



## DANGER

indicates an immediate hazardous situation which, if not avoided, **will** result in death or serious injury.

---



## WARNING

Indicates an potentially hazardous situation which, if not avoided, **could** result in death or serious injury.

---



## CAUTION

with a warning triangle indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury..

---

## CAUTION

without a warning triangle indicates a potentially hazardous situation which, if not avoided, may result in property damage.

---

## ATTENTION

means that an undesirable result or condition may occur when the appropriate instruction is not observed.

---



## NOTE

Means that a possible advantage is to be gained from following the appropriate recommendation.

---

# General Notes



---

## NOTE

Dear customer,

These operating manual do not claim to cover all details or variations in equipment, not to provide for every possible contingency that may arise during installation, operation or maintenance.

Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purposes, the matter should be referred to the local Siemens Sales Office.

The contents of the instruction manual shall not become part of or modify any prior or existing agreement, commitment or relationship. The Sales Contract contains the entire obligations of Siemens. The warranty contained in the contract between the parties is the sole warranty of Siemens. Any statements contained herein do not create new warranties or modify the existing warranty.

The contents reflect the latest state at the time of going to print. Subject to technical modifications in the course of further development.

---



---

## WARNING

Devices with the protection type "flameproof enclosure" may only be opened when the power is off.

Devices with the protection type "intrinsically safe" lose their certification as soon as they are operated with circuits that do not conform to the specifications laid down in the EC type examination certificate valid in your country.

This equipment may be used under high pressure and with aggressive media. Improper use of this equipment may therefore result in severe personal injury or extensive damage to property.

The successful and safe operation of this equipment is dependent upon its proper handling, installation, operation and maintenance.

The device may be used solely for the purposes described in this operating manual.

---

## Qualified Personnel

are persons familiar with the installation, assembly, commissioning and operation of the product and who have the appropriate qualifications for their activities such as:

- training or instruction or authorization to operate and maintain devices/systems according to the standard of safety technology for electrical circuits, high pressures and corrosive as well as hazardous media.
- for devices with explosion protection: training or instruction or authorization to be allowed to work on electrical circuits for potentially explosive systems.
- training or instruction according to the standards of safety engineering in the care and use of suitable safety equipment.

# 1 Description

## 1.1 Application

The positive displacement meters with rotary-piston mechanisms described in these Instructions - referred to simply as rotary-piston meters below - are used for volumetric measurements in the delivery, distribution or processing of liquids of most different types (e.g. acids, bases, solvents, diluents, fuels etc.) especially in the primary industry, chemical industry, food industry as well as in power stations and district heating power stations. Their main features are high accuracy, great reliability and negligible pressure loss.

The meters are approved in Germany and in many other countries for custody transfer. The local licensing rules must be observed. Meters which are intended for custody transfer in Germany have already been tested by the authorities before delivery.



---

### WARNING

The rotary-piston meters must only be used for the liquid they were ordered for and the specified flow range. The material of the rotary piston has been carefully selected to meet the requirements of the application and the measuring tolerance applies accordingly. Using the meters for a different liquid or for the same liquid at a different viscosity or temperature as well as violation of the rated pressure may lead to errors in measurement, excessive wear or failure of the meter.

In this case persons could be injured or property damaged.

If the operating data provided with the order were incomplete or missing, no guarantee can be accepted for correct design of the meters.

The liquid to be measured should not contain solid impurities such as suspended substances, sediments or sticky materials. The sieve in the rotary-piston meter is not designed to serve as a filter for such impurities. The use of a filter is prescribed in applications of the rotary-piston meters for custody transfer.

Sudden rises in pressure (liquid hammer), which occur for example in long lines when a shut-off valve is suddenly closed, should be avoided to prevent damaging the meter.

If a rotary-piston meter is used in a line under vacuum (e.g. suction line of a pump), care must be taken to prevent the entry of air and the evaporation of the measured liquid. Air or gas pockets in the liquid are also measured and lead to false results. To prevent this, a gas separator can be inserted in front of the meter.

---

## 1.2 Design

The rotary-piston meter consists of at least three modules: the metering mechanism, the intermediate gear and the register (Figure 1/1, page 9). The three modules are combined into one unit. In addition, further modules, e.g. sensors, can be inserted between the flanges.

### Metering mechanism

The metering mechanism consists of the housing (upper and lower parts with the flanges), the measuring system and the transmission system.

The measuring system consists of the chamber with lid, rotary piston and partition. The slotted rotary piston is arranged in the measuring chamber with the partition radially.

The piston movement in the transmission system is transmitted to the register by a driver, the mechanism shaft, a magnet coupling and the two adjustable gear wheels. One of the gear wheels belongs to the metering mechanism, the other to the intermediate gear.

The rotary-piston meters with heater are designed for hot liquids which must not cool down in the meter. A heating coil is fitted in the bottom part of the metering mechanism in the DN 25, 50 and 80 meters. In the DN 15 meters, heating channels are used instead of a heating coil. Oil, steam or hot water can be used for heating. The adjacent table provides details on the heating connections provided.

DN	PN	Connection	Dimensions, see
15	40	Female thread G $\frac{3}{8}$	Figure 1/10, page 15
25, 50 and 80	40	Flange DN 10/PN 10	Figure 1/14, page 19






Figure 1/1 Rotary-piston meter DN 50/ PN 40 with heater and resettable double-pointer dial type 12

### Intermediate gear

The intermediate gear is flanged between the metering mechanism and the register. Its gear wheel mechanism matches the measuring chamber contents (which depend on the meter size) to the rotational values.

### Registers

All registers, such as dial or drum-type registers, are provided with a uniform flange for mounting on the intermediate gear. The registers are provided with a code number (Figure 1/2, page 10 to Figure 1/5, page 11 and Figure 1/10, page 15 to Figure 1/14, page 19) depending on the design and position of the scale with respect to the mounting flange.

The non-resettable dial and drum-type counter type 01 is a single-pointer dial with a 5-digit drum-type counter. One revolution of the pointer corresponds to the progression by one digit on the fastest drum of the drum-type counter. Individual quantities are calculated from the difference between two readings. The scale is always horizontal (with reference to a vertical metering mechanism shaft).




Figure 1/2 Non-resettable dial and drum-type counter type 01

The resettable dial and drum-type counters of types 11, 12, 13 and 14 are double-pointer dials with two resettable pointers and a 5-digit drum-type totalizer. The smaller pointer indicates the full revolution values of the larger pointer. One revolution of the larger pointer corresponds to one revolution of the last drum of the drum-type totalizer. The types of double-pointer dials only differ in the arrangement of the scale.




Figure 1/3 Resettable dial and drum-type counters of types 11, 12, 13 and 14

Double-pointer dials	Scale
11	Horizontal
12	Vertical
13	Inclined by 45°

The drum-type totalizer counts all measured values continuously and cannot be reset. The pointers can be reset by rotating knob 1 (Figure 1/3, page 10) in the counterclockwise direction.

The resettable drum-type counter type 21 has a drum-type counter with 5 large, resettable drums and an 8-digit, non-resettable drum-type totalizer. The scale is inclined by 45°. The drum-type totalizer counts all measured values continuously. The large drums can be reset by turning the crank (Figure 1/4, page 11) in the clockwise direction.



Figure 1/4 Resettable drum-type counter type 21

The resettable drum-type counter with ticket printer type 22 consists of the drum-type counter type 21 described above with an additional 6-digit ticket printer arranged in a common housing. Its application is recommended wherever a printed receipt is required for the quantities received or output. A digital resolution of the analog indication of the last drum with respect to the drum-type counter takes place with the additional 6th digit of the printer. Additional print rollers enable a two-digit identification of the measuring point on the printed ticket. The scale is also inclined by 45° with this unit (Figure 1/5, page 11).





Figure 1/5 Resettable drum-type counter with ticket printer type 22

### 1.3 Mode of operation


The measuring principle is based on the continuous filling and emptying of the measuring spaces formed by the walls of the measuring chamber and the rotary piston as well as the partition which is radially inserted between the inlet and outlet openings.

The liquid flowing through the mechanism moves the rotary piston. In the process, the piston is moved in such a way by the piston pin which runs in the guide slot around the chamber pin that it slides to and fro on the partition with its slot. The rotational movement of the piston pin is transferred to the indicator mechanism by the transmission system. One revolution of the piston pin corresponds to the flow of a liquid quantity equal to the volume of the measuring chamber.




#### Position 1

The liquid enters through the inlet (E) into the shaded part of the measuring chambers. Due to the overpressure, the liquid fills the inner space of the rotary piston and moves it in the direction of the arrow.



#### Position 2

The inner space of the rotary piston (volume  $V_2$ ) is now filled and shut off. The liquid continues to flow into the measuring chamber and moves the piston further in the same direction.



#### Position 3

The inner space of the rotary piston is partly over the outlet (A). The contents ( $V_2$ ) can flow out or are forced through the outlet by the further movement of the piston.



#### Position 4

The outer measuring space ( $V_1$ ) is filled and shut off. The inner space of the rotary piston is partly over the inlet and continues to move back to position 1 again as it is filled. In the process, the contents ( $V_1$ ) are over the outlet and flow through this. The sum of the two volumes ( $V_1 + V_2$ ) represents the displacement of the measuring chamber.

- A Outlet for liquid
- E Inlet for liquid
- 1 Measuring chamber
- 2 Rotary piston
- 3 Chamber pin
- 4 Partition
- 5 Piston pin

Figure 1/6 Schematic representation of the measuring principle

## 1.4 Technical data

### Error limits

Between  $\pm 0.2\%$ ,  $\pm 0.5\%$  and  $\pm 2\%$  (with PTFE-carbon pistons) of the setpoint (depending on the measured liquid, the range and the respective calibration regulations).

### Permissible operating temperature

The permissible temperature of the measured liquid for rotary-piston meters depends on the piston material, the number of cooling attachments between the meter and accessory modules. The ordering data apply in all cases.

### Pressure loss

The pressure loss in the rotary-piston meters depends on the flow rate and the viscosity of the medium. Figure 1/7, page 14 to Figure 1/9, page 14 shows an example of the pressure loss for rotary-piston meters DN 15, DN 25, DN 50 and DN 80 depending on the flow rate.

### Filters

Mesh size standardized approx. 0.8 mm.

Rated size, rated pressure, flow rate

Rated size DN  mm	Rated pressure PN (DIN 2401)  bar	Permissible flow rate in l/min <sup>1)</sup>					
		Minimum flow rate with a liquid viscosity of				Maximum flow rate with	
		0.6 mPa·s	1 mPa·s	5 mPa·s	800 mPa·s	continuous operation	intermittent opera- tion, approx. 1000 hours/ year
15	40	1,5	1,5(3)	1,5(3)	0,5(1)	10	20(16)
25	40	6	5(10)	3(6)	1(2)	50	100(60)
50	40	20	18(36)	10(20)	2(4)	165	500(400)
80	40	35	25(50)	10(20)	5(10)	350	1000(800)

<sup>1)</sup> The values in parentheses apply to rotary-piston meters with metal pistons




Figure 1/7 Pressure loss depending on the flow and viscosity of the measured liquid in a rotary-piston meter DN 15




Figure 1/8 Pressure loss for liquid gas with 0.25 mPa·s, approx. 16 °C and PN 16 (values for liquid gas authorized by the German calibration authorities: 100, 400 and 800 l/min)





Figure 1/9 Operating ranges for rotary-piston meters DN 25, DN 50 and DN 80; pressure loss depending on the flow and viscosity of the measured liquid



**Dimensions of the rotary-piston meters, industrial design, with pointer dials**

**DN15 and PN 40**



with register type 01





DN 15/PN 40 with heater type 01




Register type 11



Register type 12



Register type 13




Metering mechanism				Connection for heater (PN 16)		
DN15	a	b	c	d	e	f
PN 40 without heater	194	60	100	-	-	-
PN 40 with heater	202	68	108	92	G <sup>3</sup> / <sub>8</sub> 26	

Figure 1/10 Rotary-piston meters DN 15 (industrial design)

Dimensions of the rotary-piston meters, industrial design, with pointer dials

DN 25, DN50 und DN 80  
PN 40




Rated size	Rated pressure						Number of holes								
		$\phi a$	$b$	$c$	$d$	$\phi d_1$		$\phi e$	$f$	$\phi g$	$h_1$	$h_2$	$h_3$	$h_4$	$\phi k$
DN 25	PN 40	32	270	144	80	14	4	115	18	205	292	322	495	460	85
DN 50	PN 40	50	400	205	120	18	4	165	20	330	347	377	550	515	125
DN 80	PN 40	80	540	271	155	18	8	200	22	450	415	445	618	583	160

Figure 1/11 Rotary-piston meters DN 25, DN 50 and DN 80, PN 40 (industrial design) with pointer dials



### Dimensions of the rotary-piston meters, industrial design, with drum-type counters

DN 25, DN 50 und DN 80  
PN 40




Rated size	Rated pressure						Number of holes						
		Øa	b	c	d	Ød <sub>1</sub>		Øe	f	Øg	h <sub>1</sub>	h <sub>2</sub>	Øk
DN 25	PN 40	32	270	144	80	14	4	115	18	205	425	431	85
DN 50	PN 40	50	400	205	120	18	4	165	20	330	480	486	125
DN 80	PN 40	80	540	271	155	18	8	200	22	450	548	554	160


Figure 1/12 Rotary-piston meters DN 25, DN 50 and DN 80, PN 40 (industrial design) with drum-type counters.

**Dimensions of the rotary-piston meters, industrial design, with drum-types counters with ticket printers and quantity preset registers**


**DN 25, DN 50 und DN 80  
PN 40**



With register type 22 or type 42



With register type 24 or type 44




With register type 30, type 50, type 51, type 52, type 53 or type 54

Rated size	Rated pressure						Number of holes								
		Øa	b	c	d	Ød <sub>1</sub>		Øe	f	Øg	h <sub>1</sub>	h <sub>2</sub>	h <sub>4</sub>	h <sub>5</sub>	Øk
DN 25	PN 40	32	270	144	80	14	4	115	18	205	480	520	495	550	85
DN 50	PN 40	50	400	205	120	18	4	165	20	330	535	575	550	605	125
DN 80	PN 40	80	540	271	155	18	8	200	22	450	603	643	618	673	160

Figure 1/13 Rotary-piston meters DN 25, DN 50 and DN 80, PN 40 ( industrial design) with drum-type counters with ticket printers and with quantity preset registers.


**Dimensions for heater connection of the rotary-piston meters**

**DN 25, DN 50 und DN 80  
PN 40**



Rated pressure (DIN 2401)	a	b
PN 40	39	140

Meters with connection width 25 mm  
Heater connection: DN 10/ PN 10



Rated size mm	Rated pressure (DIN 2401)	a	b
DN 50	PN 40	48	206
DN 80	PN 40	63	256

Meters with connection widths 50 and 80 mm  
Heater connection: DN 10/ PN 10

Figure 1/14 Dimensions for heater connection of rotary-piston meters DN 25, DN 50 and DN 80, PN 40



## 2 Installation and operation

### 2.1 Unpacking

Remove all packing material from the rotary-piston meter. In order to prevent foreign matter from entering the internal parts of the meter, the cover plates over the flanges should be left in place until the meter is mounted in the plant.

### 2.2 Drilling the flanges


Rotary-piston meters can be delivered with undrilled flanges on request. In such a case, we recommend drilling of the flanges in accordance with the application specifications (DIN 2501 in Germany) (exception: enamel/plastic designs of the meters).

When drilling the flanges, care must be taken to ensure that no foreign matter or borings enter the meter. These materials may later block the meter when in operation or may cause damage to the sensitive rotary pistons (e.g. carbon pistons). Careful sealing of the two connection openings prevents the entry of foreign matter during drilling. The material used for covering must be completely removed again afterwards. To prevent borings from falling into the meter, hold the meter such that the stuffing material can only be removed downwards. The flanges must again be closed by the specially provided covers until the meters are finally mounted in the plant.

### 2.3 Mounting

If the rotary-piston meter is mounted outdoors, sufficient protection against climatic conditions is recommended; freezing of the liquid can destroy the meter. If possible, the rotary-piston meter should be mounted in the pressure line and, especially when measuring corrosive liquids, mounted in such a position that it remains filled with the liquid even during pauses in operation. The meter can be mounted in any position which only depends on the readability of the register. During installation of the piping, a fitting tube (a tube matching the mounting dimensions of the meter, see Figure 1/10, page 15 and Figure 1/11, page 16), must be mounted instead of the meter. In this manner the rotary-piston meter is protected from mechanical shocks or stresses in the piping during pipe work and also after it has been mounted. In the case of heated meters, the inlet and outlet lines for the heater must also be laid without causing additional stress. It is recommendable to support heavy meters (depending on the stability and anchoring of the piping).

If it is not permissible to interrupt the flow of liquid for manufacturing reasons when cleaning the rotary-piston meter or the sieve, a bypass line can be installed as in Figure 2/1, page 22.



Shut-off valve	Flow through	
	meter	bypass
1	Open	Closed
3	Open	Closed
4	Closed	Open

- 1, 3 and 4 Shut-off valves
- 2 Rotary-piston meter

Figure 2/1 Example of a bypass line

Before mounting the rotary-piston meter in the plant, all foreign matter must be completely removed from the piping. This is done most effectively with the fitting piece mounted and by flushing with the highest possible flow rate. The fitting piece can be removed following flushing and replaced by the rotary-piston meter. The meter must be installed with the correct direction of flow (marked by an arrow on the housing). The sealing surfaces of the flanges must be clean and the flange bolts must be tightened uniformly in a diagonally opposite sequence.



**WARNING**

The sealing material must be selected according to the liquid and the rated pressure ( information can be obtained from manufacturer), especially as to avoid the possible danger to persons and property by escaping liquid.

## **2.4 Commissioning**

The rotary-piston meters are tested before leaving the factory and operate trouble-free if they are correctly mounted.

When using a rotary-piston meter for the first time, it is advisable to start with a low flow and to check whether the register operates. In this manner, faults (e.g. solid foreign material in the metering mechanism) can be detected at an early stage and extensive damage can be prevented by immediately stopping the flow. Faults can be detected and corrected as in Chapter 3.6, page 32.

If no faults are observed with a low flow rate, the flow should be increased up to the maximum permissible value if possible (see Figure 1/7, page 14 to Figure 1/9, page 14). Any remaining air in the rotary-piston meter is removed by the fast flow of liquid. Otherwise air pockets which remain in the meter would lead to errors in the measurements. When removing the air, the maximum permissible flow rate must not be exceeded to prevent overloading. In addition, do not exceed the rated pressure (it is advisable to fit a pressure gauge in the inlet line to the meter) and the maximum permissible temperature of the liquid.

Meters used for custody transfer must be calibrated by the appropriate gauging authorities.

Before using the rotary-piston meter, reset the register to zero in the case of meters with a resettable register, or note the indicated value on meters with a non-resettable register.





## 3 Maintenance

### 3.1 Checking and servicing

Since the rotary-piston meters are provided with a magnetic coupling for transmitting the measured values from the metering mechanism to the register, regular servicing (e.g. lubrication etc.) is not required.



---

#### **WARNING**

It is only important to comply with the prescribed operating conditions (e.g. operating time, characteristics and temperature of measured liquid, operating pressure etc.) as described in Chapter 1.4, page 13. The rotary-piston meters must be protected using suitable means (e.g. cover with plastic hood) against splashing water and flooding which might occur when cleaning the plant with water hoses. It is recommendable to occasionally check joints for leaks to prevent possible danger.

---

### 3.2 Recalibration

In the case of rotary-piston meters used for custody transfer, the meters must be recalibrated every 2 years by the appropriate calibration office. Checking and recalibration are also required following maintenance work (e.g. replacement of piston, cleaning of meter etc.) where a lead seal has been damaged or removed. The regulations of the local gauging authorities must be complied with in all cases.

### 3.3 Removing the rotary-piston meter, replacing the piston and cleaning the sieve

The meter must be removed from the plant in order to clean it, to replace the piston and to clean the sieve. The supply of liquid must first be shut off. If a bypass line has been provided, the meter can be taken out of operation as in Figure 2/1, page 22 without disturbing the process. After removing the flange bolts and nuts on both sides of the meter, the meter can be removed from the plant (if it is without a heater)

When removing rotary-piston meters with a heater, the flange bolts and nuts of the heating lines must also be removed.

To replace the rotary piston, the measuring system must be removed from the meter housing and taken apart. The same procedure must be followed as when cleaning the rotary-piston meter (Chapter 3.4, page 26).


The measuring system must also be taken out of the meter housing in order to clean the sieve. It is therefore advisable to clean the meter completely. The only additional work required is to take apart the measuring system and reassemble it, which can be carried out within a relatively short time. If it is not necessary to clean the measuring system, however, the taking apart and reassembling of the measuring system as described in Chapter 3.4, page 26 does not apply.

## **3.4 Cleaning the rotary-piston meters, industrial design, DN 15**

see **Figure 3/1, page 27**

### **3.4.1 Dismantling the rotary-piston meter**

- Use a pointed tool (marking tool, screwdriver) to pierce and remove the lead sealing disks (12). Remove all sealing screws (14) and sealing blocks (13).
- After removing all screws on the connection flange of the metering mechanism, cautiously lift off the register and intermediate gear including any intermediate modules. Do not damage the transmission wheels for the measured value!
- Loosen the nuts (17) of the housing connection and open the housing by lifting the upper part (1). Do not tilt sideways in the process, otherwise the shaft (4) of the metering mechanism could be warped. If the gasket sticks, separate the parts of the housing by gently hitting with a plastic hammer.
- Remove the gasket.
- Take out the entire measuring chamber (9) including the shaft (4) of the metering mechanism from the lower part of the housing (15). Take out the sieve (19) after removing the split pin (18).
- Remove the lid (23) of the measuring chamber after unscrewing the securing screws (24). If the lid sticks, gently hit with a plastic hammer. Remove the rotary piston (21) and the partition from the chamber.
- Carry out thorough mechanical cleaning of the measuring chamber, measuring chamber lid and all sealing surfaces.
- After cleaning, the shaft of the metering mechanism must be easy to turn without noticeable friction. All parts of the metering mechanism must be clean and free of even minimum residues of cleaning material.



- 1 Upper part of housing
- 2 Flange for outlet line
- 3 Magnetic coupling
- 4 Shaft of metering mechanism
- 5 Driver
- 6 Housing gasket
- 7 Upper piston pin (approx. 4 mm)
- 8 Lower piston pin (approx. 7 mm)
- 9 Measuring chamber
- 10 Chamber pin
- 11 Guide slot
- 12 Sealing disk
- 13 Sealing block
- 14 Sealing screw
- 15 Lower part of housing
- 16 Housing bolt (stud bolt)
- 17 Nut for housing bolt
- 18 Sieve holder (split pin or screw with washer)
- 19 Sieve
- 20 Groove for sieve
- 21 Rotary piston
- 22 Flange for liquid inlet
- 23 Measuring chamber lid
- 24 Securing screw for measuring chamber lid

Figure 3/1 Rotary-piston meter DN 15/PN 40 with heater

### 3.4.2 Assembly of the rotary-piston meter

The rotary-piston meter is assembled as described above for dismantling, but in the reverse order. The parts dismantled last are assembled first. All parts must be undamaged and free of any foreign matter. Damaged or worn parts must be replaced by new parts made of the same material.



---

#### CAUTION

The following points must also be observed when assembling:


- The housing gasket (6) must be replaced by a new one. The gasket must be undamaged.
  - The sieve (19) must fit with its edge in the groove (20) in the bottom of the measuring chamber. It can only be secured when it is correctly seated. Also ensure that the sieve holder (18) is secure.
  - Insert the rotary piston (21) in such a way that the lower piston pin (8) fits into the guide slot (11) in the bottom of the measuring chamber. The piston must then move freely in the measuring chamber (9) as shown in Figure 1/7, page 14.
  - When replacing the measuring chamber lid (23) ensure that the driver (5) fits with its cut-out over the upper piston pin (7). The measuring chamber lid can then be fitted onto the measuring chamber (9) and pressed down firmly. When turning the coupling part carefully, the rotary piston must move freely in the measuring chamber. The piston movement can be observed through the outlet opening in the measuring chamber lid.
  - Tighten the securing screws (24) for the measuring chamber lid uniformly. Check the free movement of the piston again as above.
  - Do not damage the sieve when placing the measuring system into the lower part of the housing (15).
  - Before replacing the upper part of the housing (1), the magnetic coupling (3), especially the inner part, must be free of any foreign material. The upper part of the housing can then be carefully placed onto the lower part.
  - Screw the nuts (17) onto the housing bolts (16) and tighten uniformly in a diagonally opposite sequence. It is recommendable to check for leaks. Screw in the sealing screw (14) with sealing block (13).
  - Meters with worn or replaced pistons must be readjusted (Chapter 3.8, page 34).
  - Meters used for custody transfer must be tested and recalibrated by the gauging authorities (see Chapter 3.2, page 25). If the rotary-piston meter is not immediately mounted in the plant after being assembled, the connection flanges must be covered to prevent the entry of foreign material. When storing for a short time, it is sufficient to pack the meter in a sealed plastic bag. When storing a meter for a longer period, it is advisable to grease the metering mechanism parts to protect them from corrosion.
  - The comments made in Section 2 must be observed when mounting the rotary-piston meter in the plant and when commissioning.
-

## **3.5 Cleaning the rotary-piston meters, industrial design, DN 25, DN 50 and DN 80**

see Figure 3/2, page 30

### **3.5.1 Dismantling the rotary-piston meter**

- Use a pointed tool to pierce and remove the lead sealing disks (14). Unscrew the sealing screws (15) and remove with the sealing blocks (13).
- Remove the register with all additional units from the metering mechanism (see Chapter 3.4.1, page 26).
- Loosen the nuts (8) from the housing bolts (7) and remove. Remove the bolts (7) if they are not stud bolts.
- Loosen the upper part of the housing (1) from the lower part (12) by screwing in the jack screws (16) and then screw the latter back again. Lift off the upper part of the housing with the register from the lower part. Do not tilt sideways in the process, otherwise the shaft of the mechanism could be warped. Do not damage the coupling parts of the magnetic coupling (2), and keep away from ferro-magnetic materials (e.g. iron filings etc.).
- In the case of the DN 80 meters, lift out the measuring system using the 2 lugs provided on the chamber lid (5). Be careful not to damage the sieve (18).
- Unscrew the securing screws (22) of the measuring chamber lid and lift off the lid with the shaft of the metering mechanism and the coupling part.
- Lift out the rotary piston (10) from the measuring chamber (9). Be careful since carbon or hard rubber pistons are extremely brittle. In some meters a sliding roller is provided over the piston pin (21). Do not loose this roller.
- In the case of DN 25 and DN 50 meters, take out the measuring chamber from the lower part of the housing (12).
- Remove the sieve holder (17) and take off the sieve (18).
- Clean all parts. The upper part of the housing with the register must not come into contact with the cleaning agent or solvent. After cleaning, the shaft of the metering mechanism must be easy to turn without noticeable friction. All parts of the metering mechanism must be clean and free of even minimum residues of cleaning material.



- 1 Upper part of housing
- 2 Magnetic coupling
- 3 Shaft of metering mechanism
- 4 Driver
- 5 Measuring chamber lid
- 6 Housing gasket
- 7 Housing bolt (hexagon or stud bolt)
- 8 Nut for housing bolt
- 9 Measuring chamber
- 10 Rotary piston
- 11 Guide slot
- 12 Lower part of housing
- 13 Sealing block
- 14 Sealing disk
- 15 Sealing screw
- 16 Jack screw
- 17 Sieve holder (split pin or screw with washer)
- 18 Sieve
- 19 Groove for sieve
- 20 Long piston pin
- 21 Short piston pin (in some meters a sliding roller is provided over the piston pin)
- 22 Securing screw for measuring chamber lid

Figure 3/2 Rotary-piston meters DN 25/PN 40

### 3.5.2 Assembly of the rotary-piston meter

The rotary-piston meter is assembled as described above for dismantling, but in the reverse order. The parts dismantled last are assembled first. All parts must be undamaged and free of any foreign matter. Damaged or worn parts must be replaced by new parts made of the same material.



---

#### CAUTION

The following points must also be observed when assembling:

- The housing gasket (6) must be replaced by a new one. The gasket must be undamaged.
  - The sieve (18) must fit with its edge in the groove (19) in the bottom of the measuring chamber. It can only be secured when it is correctly seated. Also ensure that the sieve holder (17) is secure.
  - Insert the rotary piston (10) in such a way that the lower piston pin (20) fits into the guide slot (11) in the bottom of the measuring chamber. The piston must then move freely in the measuring chamber (9) as shown in Figure 1/6, page 12. If a sliding roller was fitted on the piston pin (21), replace it.
  - When replacing the measuring chamber lid (5) ensure that the driver (4) fits with its cut-out over the upper piston pin (21). The measuring chamber lid can then be fitted onto the measuring chamber (9) and pressed down firmly. When turning the coupling part carefully, the rotary piston must move freely in the measuring chamber. The piston movement can be observed through the outlet opening in the measuring chamber lid.
  - Tighten the securing screws (22) for the measuring chamber lid uniformly. Check the free movement of the piston again as above.
  - Do not damage the sieve when placing the measuring system into the lower part of the housing (12).
  - Before replacing the upper part of the housing (1), check that the jack screws (16) are screwed back sufficiently that they no longer protrude out of the thread. The magnetic coupling (2), especially the inner part, must be free of any foreign material. The upper part of the housing can then be carefully placed onto the lower part.
  - Insert the housing bolts (7) (if they are not stud bolts) and tighten the nuts (8) uniformly in a diagonally opposite sequence. It is recommendable to check for leaks. Screw in the sealing screw (15) with sealing block (13).
  - Meters with worn or replaced pistons must be readjusted (Chapter 3.8, page 34).
  - Meters used for custody transfer must be tested and recalibrated by the gauging authorities (see Chapter 3.2, page 25). If the rotary-piston meter is not immediately mounted in the plant after being assembled, the connection flanges must be covered to prevent the entry of foreign material. When storing for a short time, it is sufficient to pack the meter in a sealed plastic bag. When storing a meter for a longer period, it is advisable to grease the metering mechanism parts to protect them from corrosion.
  - The comments made in Chapter 2, page 21 must be observed when mounting the rotary-piston meter in the plant and when commissioning.
-

### 3.6 Troubleshooting

The rotary-piston meters are of simple construction and, if used correctly, render years of reliable service. Besides normal wear, faults seldom occur. Should trouble or faulty measurements be encountered during commissioning or after an extended period in operation, however, the cause can be located by means of the following table and eliminated.

Fault	Cause	Fault in plant or meter	Remedy
1. Meter reading too high.	Measured liquid contains air or gas	a) Meter is under vacuum and draws in air b) Measured liquid contains air or gives off gas c) Measured liquid evaporates due to too high vacuum	Change installation or install gas separator
		d) Air is carried over from an overhead tank	Install a stabilizer or gas separator
2. Meter reading too low	Flow rate below permissible minimum level	a) Pump delivery too small b) Outlet into closed container, air vent not provided	Change installation.
		c) Sieve in meter dirty, filter or pipeline blocked	Clean sieve (see Chapter 3.3, page 25), filter or pipeline
	Tolerance between rotary piston and measuring chamber too large because piston is worn	d) Piston slightly worn.	Determine measuring error, replace gear wheels (see Chapter 3.7, page 33 and Chapter 3.8, page 34).
		e) Piston severely worn	Replace piston (see Chapter 3.3, page 25)
3. Register remains stationary, flow through meter not possible	Piston does not rotate	a) Measuring chamber dirty b) Foreign matter in measuring chamber.	Clean meter (see Chapter 3.4, page 26 to Chapter 3.5, page 29).
		c) Piston and measuring chamber corroded.	Replace meter.
4. Register stationary, flow through meter continues	Piston broken		Replace piston (see Chapter 3.3, page 25)
	Magnetic coupling or register damaged		Return meter for repair (remove meter as in Chapter 3.3, page 25)



### 3.7 Determining the error in indication

To determine the error in indication, proceed as follows:

1. In the case of single-pointer dials, note the reading. In the case of resettable dials, set to zero.
2. Collect the liquid flowing through the rotary-piston meter in a calibrated container (calibration standard).
3. The difference between the quantity N collected in the container and the meter reading A is the error F ( $F = A - N$ ). A positive error is where the meter reading is too high, a negative error where it is too low.
4. Only certified standards may be used for official calibration purposes. The quantity used for testing should normally cause at least 3 rotations of the dial or drum of the fastest moving pointer or drum. The lowest flow quantity specified on the scale is also tested during official calibration.

When returning a rotary-piston meter to the factory because of incorrect accuracy, please supply the following information:

1. Test quantity in calibrated container (liters or ccm)
2. Value indicated by register for the test quantity
3. Type and temperature of liquid during test
4. Flow through the meter (liters/min) during the test.

The meter must be completely emptied before shipping. This is particularly important if the meter was used to measure flammable or corrosive liquids.

After an extended period of operation, the measuring accuracy can be affected by the normal wear of the metering mechanism parts. The meter then indicates a value smaller than the actual quantity. It is therefore advisable to check the measuring accuracy at regular intervals depending on the demands imposed on the meter. If the accuracy does not meet the requirements, the indicating error can be compensated by readjustment (matching the metering mechanism to the register). If the meter is readily accessible, it is not necessary to remove it from the plant. It is important to ensure that the meter can be taken out of operation from the beginning to the end of the adjustment and is protected from being mistakenly put into operation again. Proceed as in Chapter 3.3, page 25 if the rotary-piston meter is taken out of the plant for readjustment.


Once the quantity error has been determined, it is necessary to calculate the percentage error. The error of the meter must be referred to the actual reading.

If the reading is taken as „A“ (actual value) and the quantity collected in the calibration container as „N“ (nominal value), the percentage error „F“ is determined as follows:

$$F \text{ in } \% = \frac{A - N}{N} \cdot 100$$

If the error calculated according to this equation provides a value, for example, of  $F = -0.44\%$ , this means that the meter indicates a quantity that is 0.44% smaller than the actual quantity which has flown through.

### 3.8 Adjustment



- 1 Metering mechanism
- 2 Gear wheel of metering mechanism
- 3 Gear wheel of intermediate gear
- 4 Intermediate gear
- 5 Register

Figure 3/3 Gear wheels on metering mechanism and on register with intermediate gear

The rotary-piston meter is adjusted by replacing the gear wheels (2 and 3, Figure 3/3) arranged between the metering mechanism (1) and the intermediate gear (4). The gear wheels are not directly above the metering mechanism in the case when insulation attachments are used. Replace the gear wheels as follows:

1. After dismantling the meter from the plant or, if it remains fitted, after closing the supply of liquid, remove the seal on the mounting flange of the meter (use a pointed tool to pierce and lift out the sealing disk) and unscrew the sealing screw. Loosen all flange bolts.
2. Cautiously lift off the register (5) with the intermediate gear (4) from the metering mechanism flange. The gear wheel (2) of the metering mechanism flange. The gear wheel (3) of the intermediate gear are now accessible.
3. Unscrew the nut from the gear wheel (2) (right-hand thread). Lift off the spring washer and the gear wheel and read and note the designation (stamped figures or figures and letters).
4. Unscrew the nut from the gear wheel (3) (left-hand thread). Lift off spring washer and gear wheel and read and note the designation.
5. Determine the new gear wheels required as in the following example:

### Example

A rotary-piston meter manufactured in 1995 has an indicating error of -0.44 % as determined by testing. The designation on the gear wheel of the metering mechanism is e.g. „1-54“ and on the intermediate gear „1-104“. Look up the pair of gear wheels in column 3 in the table in Chapter 4. It is important to look for the pair of gear wheels on the same line within a column. In this example the pair of gear wheels can be found in column 3 (example shown in bold-face type).

In column 1 in the same line it can be seen that this pair of gear wheels already compensates an indicating error of -0.17 % . Thus the total deviation of the meter is

$$(- 0.17) + (- 0.44) = - 0.61 \%$$

where:

- 0.17= indicating error already compensated
- 0.44= the indicating error determined and
- 0.61= the sum of both values and therefore the total deviation of the reading from the nominal value.

Now look for the total error (-0.61%) in column 1. The designations of the new pair of gear wheels to be fitted can be found in the same line, but in column 3. In this example, the value -0.61 % cannot be found in column 1. The closest value (-0.62%) must then be taken. In this line, the designation „1-57“ is found in column 3 for the gear wheel of the metering mechanism and „1-107“ for the gear wheel of the intermediate gear. The existing pair of gear wheels must then be replaced by the pair found in this manner. The gear wheels belonging to a pair cannot be interchanged when inserting since they are provided with conical holes of different diameters.

Reassemble the meter in the reverse sequence to that described above for removing the gear wheels. The following information is important:

After fitting the new gear wheels, they must be well secured by means of the spring washers and nuts. When placing the register with intermediate gear onto the metering mechanism housing, care must be taken to ensure that the teeth of the gear wheels engage correctly. The gears must not rest on one another. The gear wheels would be damaged or the gear shafts bent if the register were then tightened. When correctly seated, the register can be secured with the bolts and nuts and the sealing screw. The rotary-piston meter is then ready for operation again. If the meter was removed from the plant for adjustment, install in accordance with Section 2. Meters in plants for custody transfer must be tested and recalibrated by the gauging authorities (Chapter 3.2, page 25).

To check whether the meter operates correctly, first carry out a test run with a low flow rate. If the meter operates correctly, it is advisable to recheck the measuring accuracy as carried out before. The required accuracy must now be obtained. Any deviation still present can only be caused by an error in determining the fault or selection of the gear wheels.



## 4 Spare parts

If a rotary-piston meter is repaired on site by the customer and not returned to the factory for repair or readjustment, the technical data of the meter must be exactly specified when ordering spare parts. The details can be obtained from the dispatch note of the original delivery. It is therefore advisable to keep the original dispatch note with the instruction manual. It is not possible to supply the correct spare parts without correct details on the serial number and the technical data.

Spare parts lists for the rotary-piston meters described in this manual can be obtained from us using the following Order Nos.:

DN 15	PN 40:	C73000-E5174-C10
DN 25 to 80	PN 40:	C73000-E5174-C1

1	2		3		
Indicating error of meter	Number of teeth of wheels:		New designation of gear wheels:		
	on metering mechanism	on intermediate module	on metering mechanism	on intermediate module	
Positive	2.02 %	31	33	1-61	1-112
	1.82 %	32	34	1-62	1-113
	1.64 %	33	35	1-63	1-114
	1.47 %	34	36	1-64	1-116
	1.31 %	35	37	1-65	1-117
	1.16 %	36	38	1-66	1-118
	1.01 %	37	39	1-67	1-120
	0.88 %	38	40	1-68	1-121
	0.75 %	39	41	1-70	1-122
	0.63 %	40	42	1-71	1-123
	0.51 %	41	43	1-72	1-124
	0.40 %	21	22	1-51	1-101
	0.29 %	43	45	1-74	1-125
	0.19 %	22	23	1-52	1-102
0.09 %	45	47	1-76	1-126	
0.00 %	23	24	1-53	1-103	
Negative	0.09 %	47	49	1-78	1-127
	0.17 %	24	25	1-54	1-104
	(0.25 %)	49	51	1-80	1-128
	0.33 %	25	26	1-55	1-105
	(0.41 %)	51	53	1-82	1-129
	0.48 %	26	27	1-56	1-106
	(0.55 %)	53	55	1-83	1-131
	0.62 %	27	28	1-57	1-107
	0.75 %	28	29	1-58	1-108
	0.87 %	29	30	1-59	1-109
	0.98 %	30	31	1-60	1-110
	1.09 %	31	32	1-61	1-111
	1.19 %	32	33	1-62	1-112
	1.28 %	33	34	1-63	1-113
	1.37 %	34	35	1-64	1-115
	1.45 %	35	36	1-65	1-116
	1.53 %	36	37	1-66	1-117
	1.60 %	37	38	1-67	1-119
	1.68 %	38	39	1-68	1-120
	1.74 %	39	40	1-69	1-121
	1.80 %	40	41	1-71	1-122
	1.86 %	41	42	1-72	1-123
	1.92 %	42	43	1-73	1-124
2.03 %	44	45	1-75	1-125	
2.13 %	46	47	1-77	1-126	
2.22 %	48	49	1-79	1-127	
(2.30 %)	50	51	1-81	1-128	
(2.41 %)	53	54	1-83	1-130	



Siemens AG  
Bereich Automatisierungs- und Antriebstechnik  
Geschäftsgebiet A&D PI  
D-76181 Karlsruhe

Siemens Aktiengesellschaft

© Siemens AG 1995  
Subject to change without prior notice

Order No. C73000-B5176-C30

AG 0901 40 GB

