SINAMICS S120

Control Units and additional system components

Manual · 01/2012

SINAMICS

SIEMENS

SIEMENS

Preface	
System overview	1
Control Units	2
Additional system components	3
Encoder system connection	4
Cabinet design and electromagnetic compatibility (EMC)	5
Appendix A	Α
	R

Appendix B

SINAMICS

S120 Control Units and additional system components

Manual

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.

∕\ WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.

↑ CAUTION

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

CAUTION

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

NOTICE

indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

∕ WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

SINAMICS documentation

The SINAMICS documentation is organized in the following categories:

- General documentation/catalogs
- User documentation
- Manufacturer/service documentation

More information

Using the following link, you can find information on the topics:

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

http://www.siemens.com/motioncontrol/docu

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following e-mail address: docu.motioncontrol@siemens.com

My Documentation Manager

Using the following link, you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation:

http://www.siemens.com/mdm

Training

Using the following link, you can find information on SITRAIN - training from Siemens for products, systems and automation engineering solutions: http://www.siemens.com/sitrain

FAQs

You can find Frequently Asked Questions in the Service&Support pages under **Product Support**:

http://support.automation.siemens.com

SINAMICS

You can find information on SINAMICS under: http://www.siemens.com/sinamics

Usage phases and the available tools/documents

Table 1 Usage phases and the available tools/documents

Usage phase	Tools
Orientation	SINAMICS S sales documentation
Planning/engineering	SIZER configuration tool
	Configuration manuals, motors
Decision making/ordering	SINAMICS S Catalogs
Configuring/installation	SINAMICS S120 Equipment Manual for Control Units and Additional System Components
	SINAMICS S120 Equipment Manual for Booksize Power Units
	SINAMICS S120 Equipment Manual for Chassis Power Units
	SINAMICS S120 Equipment Manual for AC Drives
	SINAMICS S120M Equipment Manual Distributed Drive Technology
Commissioning	STARTER commissioning tool
	SINAMICS S120 Getting Started
	SINAMICS S120 Commissioning Manual
	SINAMICS S120 CANopen Commissioning Manual
	SINAMICS S120 Function Manual
	SINAMICS S120/S150 List Manual
Using/operating	SINAMICS S120 Commissioning Manual
	SINAMICS S120/S150 List Manual
Maintenance/Service	SINAMICS S120 Commissioning Manual
	SINAMICS S120/S150 List Manual
List of references	SINAMICS S120/S150 List Manual

Target group

This documentation is intended for machine manufacturers, commissioning engineers, and service personnel who use the SINAMICS drive system.

Benefits

This Manual provides all the information, procedures and operational instructions required for commissioning and servicing SINAMICS S120.

Standard scope

The scope of the functionality described in this document can differ from the scope of the functionality of the drive system that is actually supplied.

- Other functions that are not explained in this documentation may be able to be executed
 in the drive system. However, no claim can be made regarding the availability of these
 functions when the equipment is first supplied or in the event of servicing.
- The documentation can also contain descriptions of functions that are not available in a
 particular product version of the drive system. The functionalities of the supplied drive
 system should only be taken from the ordering documentation.
- Extensions or changes made by the machine manufacturer must be documented by the machine manufacturer.

For reasons of clarity, this documentation does not contain all of the detailed information on all of the product types. This documentation cannot take into consideration every conceivable type of installation, operation and service/maintenance.

Technical Support

Country-specific telephone numbers for technical support are provided in the Internet under Contact:

http://www.siemens.com/automation/service&support

EC Declarations of Conformity

The EC Declaration of Conformity for the EMC Directive can be found on the Internet at:

http://support.automation.siemens.com

There – as a search term – enter the number 15257461 or contact your local Siemens office.

The EC Declaration of Conformity for the Low Voltage Directive can be found on the Internet at:

http://support.automation.siemens.com

There - as a search term - enter the number 22383669.

EMC limit values in South Korea

이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

For sellers or other user, please keep in mind that this device in an A-grade electromagnetic wave device. This device is intended to be used in areas other than home.

The EMC limit values to be complied with for South Korea correspond to the limit values of the EMC product standard for variable-speed electric drives EN 61800-3, Category C2 or limit value class A, Group 1 according to EN55011. By applying suitable supplementary measures, the limit values according to Category C2 or according to limit value class A, Group 1 are maintained. Further, additional measures may be required, for instance, using an additional radio interference suppression filter (EMC filter).

The measures for EMC-compliant design of the system are described in detail in this manual respectively in the Installation Guideline EMC.

Please note that the final statement on compliance with the standard is given by the respective label attached to the individual unit.

Spare parts

Spare parts are available on the Internet at: http://support.automation.siemens.com/WW/view/de/16612315

Test certificates

The Safety Integrated functions of SINAMICS components are generally certified by independent institutes. An up-to-date list of already certified components is available on request from your local Siemens office. If you have any questions relating to certifications that have not been completed, please ask your Siemens contact.

ESD information

/ CAUTION

Electrostatic sensitive devices (ESDs) are individual components, integrated circuits, or boards that may be damaged by either electrostatic fields or electrostatic discharge.

Regulations for handling ESD components:

When handling electronic components, you must ensure that the person carrying out the work, the work place, and packaging are properly grounded.

Personnel in ESD areas with conductive flooring may only handle electronic components if:

They are grounded with an ESD wrist band

They are wearing ESD shoes or ESD shoe grounding straps

Electronic boards should only be touched if absolutely necessary. They must only be handled on the front panel or, in the case of printed circuit boards, at the edge.

Electronic boards must not come into contact with plastics or items of clothing containing synthetic fibers.

Boards must only be placed on conductive surfaces (work surfaces with ESD surface, conductive ESD foam, ESD packing bag, ESD transport container).

Electronic components may not be placed near display units, monitors or televisions (minimum distance from the screen > 10 cm).

Measurements may only be taken on boards when the measuring instrument is grounded (via protective conductors, for example) or the measuring probe is briefly discharged before measurements are taken with an isolated measuring device (for example, touching a bare metal housing).

DANGER

Electrical, magnetic and electromagnetic fields (EMF) that occur during operation can pose a danger to persons who are present in the direct vicinity of the product - especially persons with pacemakers, implants, or similar devices.

The relevant directives and standards must be observed by the machine/plant operators and persons present in the vicinity of the product. These are, for example, EMF Directive 2004/40/EEC and standards EN 12198-1 to -3 applying to the European Economic Area (EEA) and in Germany the accident prevention regulation BGV 11 and the associated rule BGR 11 "Electromagnetic fields" from the German employer's liability accident insurance association.

These state that a hazard analysis must drawn up for every workplace, from which measures for reducing dangers and their impact on persons are derived and applied, and exposure and danger zones are defined and observed.

The relevant safety notes in each chapter must be observed.

General safety guidelines

DANGER

Commissioning is absolutely prohibited until it has been completely ensured that the machine, in which the components described here are to be installed, is in full compliance with the provisions of the EC Machinery Directive.

Only qualified personnel may install, commission and service SINAMICS S units.

The personnel must take into account the information provided in the technical customer documentation for the product, and be familiar with and observe the specified danger and warning notices.

Operational electrical equipment and motors have parts and components which are at hazardous voltage levels that may cause serious injuries or death when touched.

All work on the electrical system must be carried out when the system has been disconnected from the power supply.

/!\warning

Correct and safe operation of SINAMICS S equipment assumes correct transportation, storage, setup, and installation, as well as careful operation and maintenance.

The details in the catalogs and proposals also apply to the design of special equipment versions.

In addition to the danger and warning information provided in the technical customer documentation, the applicable national, local, and system-specific regulations and requirements must be taken into account.

According to EN 61800-5-1 and UL 508, only safely isolated protective extra-low voltages may be connected to any of the terminals on the electronic modules.

/!\DANGER

Using protection against direct contact via DVC A (PELV) is only permissible in areas with equipotential bonding and in dry rooms indoors. If these conditions are not fulfilled, other protective measures against electric shock must be applied, e.g., shock-hazard protection.

CAUTION

Operating the components in the immediate vicinity (< 1.5 m) of mobile telephones with a transmitting power of > 1 W may lead to incorrect functioning of the devices.

Explanation of symbols

Table 2 Symbols

Symbol	Meaning
	Protective earth (PE)
	Ground (e.g. M 24 V)
	Functional ground Equipotential bonding

Residual risks

Residual risks of power drive systems

The control and drive components of a power drive system (PDS) are approved for industrial and commercial use in industrial line supplies. Their use in public line supplies requires a different configuration and/or additional measures.

These components may only be operated in closed housings or in higher-level control cabinets with protective covers that are closed, and when all of the protective devices are used.

These components may only be handled by qualified and trained technical personnel who are knowledgeable and observe all of the safety information and instructions on the components and in the associated technical user documentation.

When carrying out a risk assessment of a machine in accordance with the EU Machinery Directive, the machine manufacturer must consider the following residual risks associated with the control and drive components of a power drive system (PDS).

- 1. Unintentional movements of driven machine components during commissioning, operation, maintenance, and repairs caused by, for example:
 - Hardware defects and/or software errors in the sensors, controllers, actuators, and connection technology
 - Response times of the controller and drive
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - Parameterization, programming, cabling, and installation errors
 - Use of radio devices / cellular phones in the immediate vicinity of the controller
 - External influences / damage
- 2. Exceptional temperatures as well as emissions of light, noise, particles, or gas caused by, for example:
 - Component malfunctions
 - Software errors
 - Operating and/or ambient conditions not within the scope of the specification
 - External influences / damage
- 3. Hazardous shock voltages caused by, for example:
 - Component malfunctions
 - Influence of electrostatic charging
 - Induction of voltages in moving motors
 - Operating and/or ambient conditions not within the scope of the specification
 - Condensation / conductive contamination
 - External influences / damage

- 4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc. if they are too close.
- 5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly.

Note

Functional safety of SINAMICS components

The components must be protected against conductive contamination (e.g. by installing them in a cabinet with degree of protection IP54B to EN 60529).

Assuming that conductive contamination at the installation site can definitely be excluded, a lower degree of cabinet protection may be permitted.

For more information about residual risks of the components in a power drive system, see the relevant chapters in the technical user documentation.

Table of contents

	Preface.		
1	System o	overview	2°
	1.1	Field of application	2
	1.2	Platform Concept and Totally Integrated Automation	22
	1.3	Introduction	24
	1.4	SINAMICS S120 components	26
	1.5	System data	29
	1.6	Standards	3
	1.7	Recycling and disposal	34
2	Control U	Units	35
	2.1	Introduction	35
	2.2	Control Unit CU320-2 PN (PROFINET)	39
	2.2.1	Description	
	2.2.2	Safety information	
	2.2.3	Interface description	
	2.2.3.1	Overview	
	2.2.3.2	X100-X103 DRIVE-CLiQ interfaces	
	2.2.3.3	X122 digital inputs/outputs	
	2.2.3.4	X132 digital inputs/outputs	
	2.2.3.5	X124 electronics power supply	
	2.2.3.6	X127 LAN (Ethernet)	
	2.2.3.7	X140 serial interface (RS232)	
	2.2.3.7	X150 P1/P2 PROFINET	
	2.2.3.0	Measuring sockets	
	2.2.3.9		
	2.2.3.10		
	2.2.3.11	Connection example	
	2.2.5	Meaning of LEDs	
	2.2.5.1	Description of the LED statuses	
	2.2.5.2	Behavior of the LEDs during booting	
	2.2.5.3	Behavior of the LEDs in the operating state	
	2.2.6 2.2.7	Dimension drawing Technical data	50
	2.3	Control Unit CU320-2 DP (PROFIBUS)	
	2.3.1	Description	
	2.3.2	Safety information	
	2.3.3	Interface description	
	2.3.3.1	Overview	
	2.3.3.2	X100-X103 DRIVE-CLiQ interfaces	
	2.3.3.3	X122 digital inputs/outputs	

	2.3.3.4	X132 digital inputs/outputs	64
	2.3.3.5	X124 electronics power supply	65
	2.3.3.6	X126 PROFIBUS	66
	2.3.3.7	PROFIBUS address switch	67
	2.3.3.8	X127 LAN (Ethernet)	68
	2.3.3.9	X140 serial interface (RS232)	69
	2.3.3.10	Measuring sockets	69
	2.3.3.11	DIAG button	69
		Slot for memory card	
	2.3.4	Connection example	
	2.3.5	Meaning of LEDs	
	2.3.5.1	Description of the LED statuses	
	2.3.5.2	Behavior of the LEDs during booting	
	2.3.5.3	Behavior of the LEDs in the operating state	
	2.3.6	Dimension drawing	
	2.3.7	Technical data	75
	2.4	Installation	76
	2.4.1	Mounting to a Line Module	
	2.4.2	Mounting on the mounting surface	
	2.4.3	Opening and removing the cover	
3	Additiona	Il system components	02
,		·	
	3.1	Basic Operator Panel BOP20	
	3.1.1	Description	
	3.1.2	Interface description	
	3.1.3	Installation	
	3.1.4	Removal	87
	3.2	Option Board: CAN Communication Board CBC10	88
	3.2.1	Description	88
	3.2.2	Safety information	
	3.2.3	Interface description	
	3.2.3.1	Overview	
	3.2.3.2	X451 CAN bus interface	
	3.2.3.3	X452 CAN bus interface X452	
	3.2.3.4	2-pin SMD DIL switch	
	3.2.4	Meaning of the LED	
		Installation	
	3.2.6	Technical data	93
	3.3	Option Board: Communication Board Ethernet CBE20	94
	3.3.1	Description	94
	3.3.2	Safety information	94
	3.3.3	Interface description	95
	3.3.3.1	Overview	95
	3.3.3.2	X1400 Ethernet interface	96
	3.3.4	Meaning of LEDs	97
	3.3.5	Installation	99
	3.3.6	Technical data	99

3.4	Option Board: Terminal Board TB30	100
3.4.1	Description	100
3.4.2	Safety information	100
3.4.3	Interface description	101
3.4.3.1	Overview	
3.4.3.2	X424 power supply, digital outputs	
3.4.3.3	X481 digital inputs/outputs	
3.4.3.4	X482 analog inputs/outputs	
3.4.4	Connection example	
3.4.5	Installation	
3.4.6	Shield support	
3.4.7	Technical data	107
3.5	Terminal Module TM15	108
3.5.1	Description	
3.5.2	Safety information	
3.5.3	Interface description	
3.5.3.1	Overview	109
3.5.3.2	X500/X501 DRIVE-CLiQ interfaces	110
3.5.3.3	X520 bidirectional digital inputs/outputs	
3.5.3.4	X521 bidirectional digital inputs/outputs	111
3.5.3.5	X522 bidirectional digital inputs/outputs	112
3.5.3.6	X524 electronics power supply	113
3.5.4	Connection example	114
3.5.5	Meaning of the LED	115
3.5.6	Dimension drawing	116
3.5.7	Installation	
3.5.8	Protective conductor connection and shield support	
3.5.9	Connector coding	
3.5.10	Technical data	120
3.6	Terminal Module TM31	122
3.6.1	Description	
3.6.2	Safety information	
3.6.3	Interface description	
3.6.3.1	Overview	
3.6.3.2	X500/X501 DRIVE-CLiQ interfaces	
3.6.3.3	X520 digital inputs	
3.6.3.4	X521 analog inputs	
3.6.3.5	S5 current/voltage changeover switch for analog inputs	
3.6.3.6	X522 analog outputs/temperature sensor	
3.6.3.7	X524 electronics power supply	
3.6.3.8	X530 digital inputs	
3.6.3.9	X540 auxiliary voltage for the digital inputs	130
3.6.3.10	X541 bidirectional digital inputs/outputs	
3.6.3.11	X542 relay outputs	
3.6.4	Connection example	
3.6.5	Meaning of the LED	
3.6.6	Dimension drawing	
3.6.7	Installation	
3.6.8	Protective conductor connection and shield support	
3.6.9	Connector coding	
3.6.10	Technical data	139

3.7	Terminal Module TM41	140
3.7.1	Description	140
3.7.2	Safety information	140
3.7.3	Interface description	141
3.7.3.1	Overview	141
3.7.3.2	X500/X501 DRIVE-CLiQ interfaces	142
3.7.3.3	X514 and X524 power supply	142
3.7.3.4	X520 encoder interface	
3.7.3.5	X521 bidirectional digital inputs/outputs	144
3.7.3.6	X522 isolated digital inputs	
3.7.3.7	X523 analog input	
3.7.4	Connection example	147
3.7.5	Meaning of LEDs.	
3.7.6	Dimension drawing	
3.7.7	Installation	
3.7.8	Protective conductor connection and shield support	
3.7.9	Technical data	
3.8	Terminal Module TM54F	
3.8.1	Description	
3.8.2	Safety information	
3.8.3	Interface description	
3.8.3.1	Overview	
3.8.3.2	X500/X501 DRIVE-CLiQ interfaces	
3.8.3.3	X514 power supply for digital outputs and sensors	
3.8.3.4	X520 sensor power supply	
3.8.3.5	X521 fail-safe digital inputs + power supply with forced dormant error detection	
3.8.3.6	X522 fail-safe digital inputs	157
3.8.3.7	X523 fail-safe digital output	
3.8.3.8	X524 electronics power supply	159
3.8.3.9	X525 fail-safe digital output	160
	X531 fail-safe digital inputs + power supply with forced dormant error detection	
3.8.3.11	X532 fail-safe digital inputs	162
3.8.3.12	X533 fail-safe digital output	163
3.8.3.13	X535 fail-safe digital output	164
3.8.4	Connection example	165
3.8.5	Meaning of LEDs	166
3.8.6	Dimension drawing	168
3.8.7	Installation	169
3.8.8	Protective conductor connection and shield support	170
3.8.9	Technical data	171
2.0	Tamaia al Markela TM400	470
3.9	Terminal Module TM120	
3.9.1	Description	
3.9.2	Safety information	
3.9.3	Interface description	
3.9.3.1	Overview	
3.9.3.2	X500/X501 DRIVE-CLiQ interfaces	
3.9.3.3	X521 temperature sensor input	
3.9.3.4	X524 electronics power supply	
3.9.4	Connection examples	
3.9.5	Meaning of the LED	
3.9.6	Dimension drawing	181

3.9.7	Installation	
3.9.8	Protective conductor connection and shield support	
3.9.9	Technical data	184
3.10	Terminal Module TM150	185
3.10.1	Description	
3.10.2	Safety information	
3.10.3	Interface description	
3.10.3.1		
	X500/X501 DRIVE-CLiQ interfaces	
	X524 electronics power supply	
	X531-X536 temperature sensor inputs	
3.10.4	Connection examples	
3.10.5	Meaning of the LED	
3.10.6	Dimension drawing	
3.10.7	Installation	
3.10.8	Protective conductor connection and shield support	
3.10.9	Technical data	195
3.11	DRIVE-CLiQ Hub Module DMC20	196
3.11.1	Description	196
3.11.2	Safety information	196
3.11.3	Interface description	197
3.11.3.1	Overview	197
3.11.3.2	X500 - X505 DRIVE-CLiQ interfaces	198
3.11.3.3	X524 electronics power supply	
3.11.4	Meaning of the LED	200
3.11.5	Dimension drawing	
3.11.6	Installation	
3.11.7	Protective conductor connection and shield support	
3.11.8	Technical data	203
3.12	DRIVE-CLiQ Hub Module External DME20	204
3.12.1	Description	
3.12.2	Safety information	
3.12.3	Interface description	
3.12.3.1	Overview	
	X500-X505 DRIVE-CLiQ interfaces	
	X524 electronics power supply	
3.12.4	Dimension drawing	208
3.12.5	Installation	209
3.12.6	Technical data	209
3.12.7	Specifications for use with UL approval	210
3.13	Voltage Sensing Module VSM10	211
3.13.1	Description	
3.13.1	Safety information	
3.13.3	Interface description	
3.13.3.1	Overview	
	X500 DRIVE-CLiQ interface	
	X520 analog inputs/temperature sensor	
	X521 three-phase line supply voltage sensing up to 100 V (phase-to-phase)	
	X522 three-phase line supply voltage sensing up to 690 V 3-ph. AC	
	X524 electronics power supply	
2 3.0.0	7.02 - 0.000 porror oupprj	

	3.13.4	Connection example	
	3.13.5	Meaning of the LED	220
	3.13.6	Dimension drawing	
	3.13.7	Protective conductor connection and shield support	
	3.13.8	Technical data	223
4	Encode	r system connection	225
	4.1	Introduction	225
	4.2	Overview of Sensor Modules	226
	4.3	Sensor Module Cabinet-Mounted SMC10	229
	4.3.1	Description	229
	4.3.2	Safety information	229
	4.3.3	Interface description	
	4.3.3.1	Overview	230
	4.3.3.2	X500 DRIVE-CLiQ interface	231
	4.3.3.3	X520 encoder system interface	232
	4.3.3.4	X524 electronics power supply	
	4.3.4	Connection example	
	4.3.5	Meaning of the LED	
	4.3.6	Dimension drawing	
	4.3.7	Installation	
	4.3.8	Technical data	
	4.4	Sensor Module Cabinet-Mounted SMC20	240
	4.4 4.4.1		
	4.4.1	Description	
	4.4.2 4.4.3	Safety information	
	4.4.3 4.4.3.1	Interface description	
	4.4.3.1	Overview	
		X500 DRIVE-CLiQ interface	
	4.4.3.3	X520 encoder system interface	
	4.4.3.4	X524 electronics power supply	
	4.4.4	Connection example	
	4.4.5	Meaning of the LED	
	4.4.6	Dimension drawing	
	4.4.7	Installation	
	4.4.8	Technical data	
	4.5	Sensor Module Cabinet-Mounted SMC30	
	4.5.1	Description	
	4.5.2	Safety information	
	4.5.3	Interface description	
	4.5.3.1	Overview	
	4.5.3.2	X500 DRIVE-CLiQ interface	
	4.5.3.3	X520 encoder system interface	
	4.5.3.4	X521 / X531 alternative encoder system interface	
	4.5.3.5	X524 electronics power supply	
	4.5.4	Connection examples	
	4.5.5	Meaning of LEDs	259
	4.5.6	Dimension drawing	
	4.5.7	Installation	
	4.5.8	Protective conductor connection and shield support	262
	4.5.9	Technical data	263

4.6	Sensor Module External SME20	268
4.6.1	Description	268
4.6.2	Safety Information	268
4.6.3	Interface description	269
4.6.3.1	Overview	269
4.6.3.2	DRIVE-CLiQ interface	270
4.6.3.3	Encoder system interface	271
4.6.4	Connection example	272
4.6.5	Dimension drawing	272
4.6.6	Installation	273
4.6.7	Technical data	274
4.7	Sensor Module External SME25	276
4.7.1	Description	
4.7.2	Interface description	
4.7.2.1	Overview	
4.7.2.2	DRIVE-CLiQ interface	
4.7.2.3	Encoder system interface	
4.7.3	Connection example	
4.7.4	Dimension drawing	
4.7.5	Installation	
4.7.6	Technical data	
4.8	Sensor Module External SME120	
4.8.1	Description	
4.8.2	Safety information	
4.8.3	Interface description	
4.8.3.1	Overview	
4.8.3.2	X100 encoder system interface	
4.8.3.3	X200 thermistor sensor input	
4.8.3.4	X300 Hall sensor input	
4.8.3.5	X500 DRIVE-CLiQ interface	
4.8.4	Connection examples	
4.8.5	Dimension drawing	
4.8.6	Installation	
4.8.7	Technical data	293
4.9	Sensor Module External SME125	295
4.9.1	Description	
4.9.2	Safety information	295
4.9.3	Interface description	
4.9.3.1	Overview	
4.9.3.2	X100 encoder system interface	298
4.9.3.3	X200 thermistor sensor input	
4.9.3.4	X500 DRIVE-CLiQ interface	300
4.9.4	Connection examples	301
4.9.5	Dimension drawing	
4.9.6	Installation	
4.9.7	Technical data	
4.10		
4.10	DRIVE-CLiQ encoder	
4.10.1	Description	
4.10.2	Safety information	
4.10.3	Interface description	310

		Overview	
	4.10.3.2	DRIVE-CLiQ interface	310
	4.10.4	Dimension drawings	311
	4.10.5	Installation	313
	4.10.6	Technical data	315
5	Cabinet	design and electromagnetic compatibility (EMC)	317
	5.1	Tightening torques for screws and screw connections	317
	5.2	Information on control cabinet installation and EMC	318
Α	Appendi	x A	319
	A.1	Spring-loaded terminals	319
	A.2	Screw terminals	320
В	Appendi	x B	323
	B.1	List of abbreviations	323
	Index		335

System overview

1.1 Field of application

SINAMICS is the family of drives from Siemens designed for machine and plant engineering applications. SINAMICS offers solutions for all drive tasks:

- Simple pump and fan applications in the process industry.
- Complex individual drives in centrifuges, presses, extruders, elevators, as well as conveyor and transport systems.
- Drive line-ups in textile, plastic film, and paper machines, as well as in rolling mill plants.
- High-precision servo drives in the manufacture of wind turbines
- Highly dynamic servo drives for machine tools, as well as packaging and printing machines.




Figure 1-1 SINAMICS applications

1.2 Platform Concept and Totally Integrated Automation

Depending on the application, the SINAMICS range offers the ideal variant for any drive task.

- SINAMICS G is designed for standard applications with induction motors. These
 applications have less stringent requirements regarding the dynamic performance of the
 motor speed.
- SINAMICS S handles complex drive tasks with synchronous/induction motors and fulfills stringent requirements regarding
 - the dynamic performance and accuracy
 - the integration of extensive technological functions in the drive control system
- SINAMICS DC MASTER is the DC drive belonging to the SINAMICS family. As a result of
 its standard expandability, it addresses both basic as well as demanding drive
 applications and in complementary markets.

1.2 Platform Concept and Totally Integrated Automation

All SINAMICS versions are based on a platform concept. Joint hardware and software components, as well as standardized tools for design, configuration, and commissioning tasks ensure high-level integration across all components. SINAMICS handles a wide variety of drive tasks with no system gaps. The different SINAMICS versions can be easily combined with each other.

Totally Integrated Automation (TIA) with SINAMICS S120

Apart from SIMATIC, SIMOTION and SINUMERIK, SINAMICS is one of the core components of TIA. The STARTER commissioning tool is an integral element of the TIA platform. It is thus possible to parameterize, program and commission all components in the automation system using a standardized engineering platform and without any gaps. The system-wide data management functions ensure consistent data and simplify archiving of the entire plant project.

PROFIBUS DP, the standard fieldbus of the TIA system, is supported by all SINAMICS S120 variants. It provides a high-performance, system-wide communication network which links all automation components: HMI, controls, drives and I/O devices.

SINAMICS S120 is also available with a PROFINET interface. This Ethernet-based bus enables control data to be exchanged at high speed via PROFINET IO with IRT or RT and makes SINAMICS S120 a suitable choice for integration in top-performance multi-axis applications. At the same time, PROFINET also uses standard IT mechanisms (TCP/IP) to transport information, e.g. operating and diagnostic data, to higher-level systems. This makes it easy to integrate into an IT corporate network.



Figure 1-2 SINAMICS as part of the Siemens modular automation system

1.3 Introduction




Figure 1-3 SINAMICS S120 system overview

Modular system for sophisticated drive tasks

SINAMICS S120 solves complex drive tasks for a wide range of industrial applications and is, therefore, designed as a modular system. Users can choose from many different harmonized components and functions to create a solution that best meets their requirements. SIZER, a high-performance engineering tool, makes it easier to choose and determine the optimum drive configuration.

SINAMICS S120 is supplemented by a wide range of motors. Whether torque, synchronous or induction motors, whether rotating or linear motors, all of these motors are optimally supported by SINAMICS S120.

System architecture with a central Control Unit

On the SINAMICS S120, the drive intelligence is combined with closed-loop control functions into Control Units. These units are capable of controlling drives in the vector, servo and V/f modes. They also perform the speed and torque control functions plus other intelligent drive functions for all axes on the drive. Inter-axis connections can be established within a component and easily configured in the STARTER commissioning tool using a mouse.

Functions for higher efficiency

- Basic functions: Speed control, torque control, positioning functions
- Intelligent starting functions for independent restart after power supply interruption
- BICO technology with interconnection of drive-related I/Os for easy adaptation of the drive system to its operating environment
- Integrated safety functions for rational implementation of safety concepts
- Regulated infeed/regenerative feedback functions for preventing undesirable reactions on the supply, allowing recovery of braking energy and ensuring greater stability against line fluctuations.

DRIVE-CLiQ - the digital interface between SINAMICS components

The SINAMICS S120 components, including the motors and encoders, are interconnected via a joint serial interface called DRIVE-CLiQ. The standardized cables and connectors reduce the variety of different parts and cut storage costs. Encoder evaluations for converting standard encoder signals to DRIVE-CLiQ are available for third-party motors or retrofit applications.

Electronic rating plates in all components

An important digital linkage element of the SINAMICS S120 drive system are the electronic type plates integrated in every component. They allow all drive components to be detected automatically via a DRIVE-CLiQ link. As a result, data do not need to be entered manually during commissioning or component replacement – helping to ensure that drives are commissioned successfully!

The rating plate contains all the relevant technical data about that particular component. In the motors, for example, this data includes the parameters of the electric equivalent circuit diagram and characteristic values for the built-in motor encoder.

In addition to the technical data, the rating plate includes logistical data (manufacturer ID, order number, and ID). Since this data can be called up electronically on site or remotely, all the components used in a machine can always be individually identified, which helps simplify servicing.

1.4 SINAMICS S120 components



Figure 1-4 Overview of SINAMICS S120 components

System components

- Line-side power components, such as fuses, contactors, reactors, and filters for switching the power supply and meeting EMC requirements.
- Line Modules, which supply power centrally to the DC link.
- DC-link components (optional), which stabilize the DC-link voltage.
- Motor Modules, which act as inverters, receive power from the DC link, and supply the connected motors.

To carry out the required functions, SINAMICS S120 is equipped with:

- Control Units that processes the drive and technological functions across all axes.
- Supplementary system components that enhance functionality and offer different interfaces for encoders and process signals.

SINAMICS S120 components are intended for installation in cabinets. They have the following features and characteristics:

- Easy to handle, simple installation and wiring
- Practical connection system, cable routing in accordance with EMC requirements
- Standardized design, seamless integration

Note

Installation location in the cabinet

The SINAMICS S120 components must always be mounted vertically in the cabinet. Other permissible installation locations are given in the descriptions for the individual components.

Booksize format

Booksize format units are optimized for multi-axis applications and are mounted adjacent to one another. The connection for the shared voltage-source DC link is an integral feature.

The booksize format offers various cooling options:

- Internal air cooling
- External air cooling
- Cold plate cooling
- Liquid Cooled

Booksize compact format

The booksize compact format combines all benefits of the booksize format and provides the same performance with an even smaller overall height and an extended overload capability. The booksize compact format is thus particularly well suited for integration into machines with high dynamic requirements and confined installation conditions.

The booksize compact format offers the following cooling options:

- Internal air cooling
- Cold plate cooling

1.4 SINAMICS S120 components

Power units

Line Modules

Convert the three-phase supply into a DC voltage for the DC link.

- Basic Line Modules
 Basic Line Modules generate a non-regulated DC link voltage and are not capable of regenerative feedback.
- Smart Line Modules

The Smart Line Modules generate a non-regulated DC link voltage and are capable of regenerative feedback.

Active Line Modules

The Active Line Modules generate a regulated DC link voltage and are capable of regenerative feedback.

Motor Modules

Convert energy from the DC link for the connected motors with variable voltage and variable frequency.

1.5 System data

Unless explicitly specified otherwise, the following technical data are valid for components of the SINAMICS S120 booksize drive system.

Table 1- 1 Electrical data

Electronics power supply	24 VDC -15/+20%, protective extra-low voltage DVC A (PELV)
Line connection voltage	3-ph. 380 V to 480 V AC ±10% (-15% < 1 min)
Line frequency	47 Hz to 63 Hz
Radio interference suppression acc. to EN 61800-3	Category C3 (standard) Category C2 (option) for systems implemented in conformance with the EC Declaration of Conformity for EMC and Configuration Manual, EMC Installation Guidelines, Order No.: 6FC5297-□AD30-0AP□
Overvoltage category	III according to EN 61800-5-1
Pollution degree	2 according to EN 61800-5-1

Table 1-2 Environmental conditions

Degree of protection	IP20 or IPXXB acc. to EN 60529, open type acc. to UL 508
Degree of protection for SME20/25/120/125 and DME20	IP67, with mounted connectors or protective caps.
Protection class line supply circuits Protection class electronic circuits	I with protective conductor connection III safety extra-low voltage DVC A (PELV) acc. to EN 61800-5-1
Permissible ambient temperature in the cabinet during operation	0 °C to +55 °C up to 2000 m above sea level. Above an altitude of 2000 m, the max. ambient temperature decreases by 3.5 K every 500 m. Installation altitude: max. 4000 m above sea level
Chemically active substances	
Long-term storage in the transport packaging	Class 1C2 according to EN 60721-3-1
Transport in the transport packaging	Class 2C2 according to EN 60721-3-2
Operation	Class 3C2 according to EN 60721-3-3
Biological environmental conditions	
Long-term storage in the transport packaging	Class 1B1 according to EN 60721-3-1
Transport in the transport packaging	Class 2B1 according to EN 60721-3-2
Operation	Class 3B1 according to EN 60721-3-3

1.5 System data

Vibratory load	
Long-term storage in the transport packaging	Class 1M2 in accordance with EN 60721-3-1
Transport in the transport packaging	Class 2M3 in accordance with EN 60721-3-2
Operation (except SME20/25/120/125)	Test values: Frequency range: 10 Hz to 58 Hz With constant deflection = 0.075 mm Frequency range: 58 Hz to 200 Hz With constant acceleration of 1 g
Test values for SME20/25/120/125 and DME20	
Operation	Frequency range: 10 Hz to 58 Hz With constant deflection = 0.37 mm Frequency range: 58 Hz to 200 Hz With constant acceleration of 5 g
Shock load	
Long-term storage in the transport packaging	Class 1M2 in accordance with EN 60721-3-1
Transport in the transport packaging	Class 2M3 in accordance with EN 60721-3-2
Operation (except SME20/25/120/125)	Test values: 15 g / 11 ms
Test values for SME20/25/120/125 and DME20	
Operation	Test values: 25 g / 6 ms
Climatic environmental conditions	
Long-term storage in the transport packaging	Class 1K4 according to EN 60721-3-1 Temperature: -25°C to +55°C
Transport in the transport packaging	Class 2K4 according to EN 60721-3-2 Temperature: -40°C to +70°C
Operation	Class 3K3 to EN 60721-3-3 Temperature +0°C to +40°C Relative humidity: 5% to 90% Oil mist, salt mist, ice formation, condensation, dripping water, spray, splash water, water jets are not permitted
SME20/25/120/125 and DME20	
Operation	Temperature: +0°C to +55°C Air humidity: ≥ 5 % to ≤ 65 % annual average ≤ 85 % for max. 2 months / year moisture condensation and the formation of ice not permissible

Table 1-3 Certificates

Declarations of Conformity	CE (Low-Voltage and EMC Directives)
Approvals	cULus

1.6 Standards

Note

The standards listed in the table below are non-binding and do not in any way claim to be complete. The standards listed do not represent a guaranteed property of the product.

Only the statements made in the Declaration of Conformity shall be deemed binding.

Table 1-4 Fundamental, application-relevant standards in succession: EN, IEC/ISO, DIN, VDE

	Table 1-4 Tundamental, application-relevant standards in succession. EN, 120/100, DIN, VDE	
Standards*	Title	
EN 1037 ISO 14118 DIN EN 1037	Safety of machinery; avoiding unexpected starting	
EN ISO 9001 ISO 9001 DIN EN ISO 9001	Quality management systems - requirements	
EN ISO 12100-x ISO 12100-x DIN EN ISO 12100-x	Safety of Machinery; General Design Guidelines; Part 1: Basic terminology, methodology Part 2: Technical Principles and Specifications	
EN ISO 13849-x ISO 13849-x DIN EN ISO 13849-x	Safety of machinery; safety-related parts of control systems; Part 1: General basic design principles Part 2: Validation	
EN ISO 14121-1 ISO 14121-1 DIN EN ISO 14121-1	Safety of Machinery - Risk Assessment; Part 1: Guidelines	
EN 55011 CISPR 11 DIN EN 55011 VDE 0875-11	Industrial, scientific and medical high-frequency devices (ISM devices) - radio interference - limit values and measuring techniques	
EN 60146-1-1 IEC 60146-1-1 DIN EN 60146-1-1 VDE 0558-11	Semiconductor converters; general requirements and line-commutated converters; Part 1-1: Defining the basic requirements	
EN 60204-1 IEC 60204-1 DIN EN 60204-1 VDE 0113-1	Electrical equipment of machines; Part 1: General definitions	
EN 60228 IEC 60228 DIN EN 60228 VDE0295	Conductors for cables and insulated leads	
EN 60269-1 IEC 60269-1 DIN EN 60269-1 VDE 0636-1	Low-voltage fuses; Part 1: General requirements	

1.6 Standards

Standards*	Title
IEC 60287-1 to -3	Cables - Calculation of the current carrying capacity Part 1: Current carrying capacity equations (100 % load factor) and calculating the losses Part 2: Thermal resistance - Part 3: Main sections for operating conditions
HD 60364-x-x IEC 60364-x-x DIN VDE 0100-x-x VDE 0100-x-x	Erection of power installations with nominal voltages up to 1000 V; Part 200: Definitions Part 410: Protection for safety, protection against electric shock Part 420: Protection for safety, protection against thermal effects Part 430: Protection of cables and conductors for over-current Part 450: Protection for safety, protection against undervoltage Part 470: Protection for safety; use of protection for safety Part 5xx: Selecting and erecting electrical equipment Part 520: Wiring systems Part 540: Earthing, protective conductor, potential bonding conductor Part 560: Electrical equipment for safety purposes
EN 60439 IEC 60439 DIN EN 60439 VDE 0660-500	Low-voltage switchgear assemblies; Part 1: Type-tested and partially type-tested assemblies
EN 60529 IEC 60529 DIN EN 60529 VDE 0470-1	Degrees of protection provided by enclosures (IP code)
EN 60721-3-x IEC 60721-3-x DIN EN 60721-3-x	Classification of environmental conditions Part 3-0: Classification of environmental parameters and their severities; Introduction Part 3-1: Classification of environmental parameters and their severities; Long-term storage Part 3-2: Classification of environmental parameters and their severities; Transport Part 3-3: Classification of environmental parameters and their severities; stationary use, weather protected
EN 60947-x-x IEC 60947 -x-x DIN EN 60947-x-x VDE 0660-x	Low-voltage switchgear
EN 61000-6-x IEC 61000-6-x DIN EN 61000-6-x VDE 0839-6-x	Electromagnetic compatibility (EMC) Part 6-1: Generic standard; Immunity for residential, commercial and light-industrial environments Part 6-2: Generic standards; Immunity for industrial environments Part 6-3: Generic standards; Generic standard emission for residential, commercial and light-industrial environments Part 6-4: Generic standards; Generic standard noise emission for industrial environments
EN 61140 IEC 61140 DIN EN 61140 VDE 0140-1	Protection against electric shock; Common aspects for installation and equipment
EN 61800-2 IEC 61800-2 DIN EN 61800-2 VDE 0160-102	Adjustable-speed electrical power drive systems; Part 2: General requirements - Rating specifications for low-voltage adjustable frequency a.c. power drive systems
EN 61800-3 IEC 61800-3 DIN EN 61800-3 VDE 0160-103	Adjustable-speed electrical power drive systems; Part 3: EMC - Requirements and specific test methods

Standards*	Title
EN 61800-5-x IEC 61800-5-x DIN EN 61800-5-x VDE 0160-105-x	Adjustable-speed electrical power drive systems; Part 5: Safety requirements; Main section 1: Electrical, thermal and energy requirements Main section 2: Functional safety requirements
EN 62061 IEC 62061 DIN EN 62061 VDE 0113-50	Safety of machinery; Functional safety of safety-related electrical, electronic and programmable electronic control systems
UL 50 CSA C22.2 No. 94.1	Enclosures for Electrical Equipment
UL 508 CSA C22.2 No. 142	Industrial Control Equipment Process Control Equipment
UL 508C CSA C22.2 No. 14	Power Conversion Equipment Industrial Control Equipment

^{*} The technical requirements in the standards listed are not necessarily identical.

1.7 Recycling and disposal

1.7 Recycling and disposal

The applicable national guidelines must be observed when disposing of the product.

The products described in this Equipment Manual are extensively recyclable on account of the low-toxic composition of the materials used. For environmentally-compliant recycling and disposal of your electronic waste, please contact a company for the disposal of electronic waste.

Control Units

2.1 Introduction

Description

Control Units CU320-2 PN and CU320-2 DP of the SINAMICS S system are designed for use with several drives.

The number of variable-speed drives depends on:

- The required performance
- The required special functions
- The required operating mode (servo, vector, or u/f).


The software and the parameters are stored on a plug-in memory card.

The option slot is used to expand the number of terminals or adapt to other communication interfaces (to the higher-level control).

Compatible firmware versions:


- CU320-2 PN V4.4 or higher
- CU320-2 DP V4.3 or higher

2.1 Introduction



- ① Cover
- ② Blanking cover
- ③ Option Board (optional)
- 4 Memory card

Figure 2-1 Overview, Control Unit CU320-2 PN



- ① Cover
- ② Blanking cover
- ③ Option Board (optional)
- 4 Memory card

Figure 2-2 Overview, Control Unit CU320-2 DP

Note

The Control Unit, the option board, and the memory card must be ordered separately.

If your application requires more than one Control Unit, the number can be increased accordingly. The Control Units are then interconnected via PROFIBUS, for example.

A Control Unit communicates with the associated components (Motor Modules, Line Modules, Sensor Modules, Terminal Modules, and so on) via the system-internal DRIVE-CLiQ interface.

2.1 Introduction




Figure 2-3 Sample configuration

2.2.1 Description

The Control Unit CU320-2 PN is a central control module in which the closed-loop and open-loop functions are implemented for one or more Line Modules and/or Motor Modules. It can be used with firmware version 4.4 or higher.

The CU320-2 PN has the following interfaces (ports):

Table 2- 1 Overview of the CU320-2 PN interfaces

Туре	Quantity
Isolated digital inputs	12
Non-isolated digital inputs/outputs	8
DRIVE-CLiQ interfaces	4
PROFINET interfaces	2
LAN (Ethernet)	1
Serial interface (RS232)	1
Option slot	1
Measuring sockets	3

2.2.2 Safety information



The ventilation spaces of 80 mm above and below the component must be observed.

/!\CAUTION

An equipotential bonding conductor must be used between components in a system that are located at a distance from each other. If an equipotential bonding conductor is not used, high leakage currents that could destroy the Control Unit or other PROFINET nodes can be conducted via the PROFINET cable.

CAUTION

The Option Board should only be inserted and removed when the Control Unit and Option Board are at zero current.

2.2.3 Interface description

2.2.3.1 Overview




Figure 2-4 Interface overview CU320-2 PN (without cover and blanking cover)




Figure 2-5 Interface X140 and measuring sockets T0 to T2 - CU320-2 PN (view from below)

2.2.3.2 X100-X103 DRIVE-CLiQ interfaces

Table 2- 2 X100-X103 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
ППВ	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
A A	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

2.2.3.3 X122 digital inputs/outputs

Table 2-3 X122 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	DI 0	Voltage (max.): -3 V to +30 V DC
	2	DI 1	Typical current consumption: 9 mA at 24 V
	3	DI 2	Electrical isolation: The reference potential is terminal M1
	4	DI 3	Level (incl. ripple)
	5	DI 16	High level: 15 V to 30 V
	6	DI 17	Low level: -3 V to +5 V
			Input delay (typ.): For "0" \rightarrow "1": 50 μ s For "1" \rightarrow "0": 150 μ s
	7	M1	Reference potential for terminals 1 to 6
	8	М	Electronics ground
	9	DI/DO 8	As input:
	10	DI/DO 9	Voltage: -3 V to +30 V DC
	11	M	Typical current consumption: 9 mA at 24 V
	12	DI/DO 10	Level (incl. ripple) High level: 15 V to 30 V
	13	DI/DO 11	Low level: -3 V to +5 V
	14	М	DI/DO 8, 9, 10, and 11 are "rapid inputs" $^{2)}$ Input delay (typ.): For "0" \rightarrow "1": 5 μ s For "1" \rightarrow "0": 50 μ s
			As output: Voltage: 24 V DC Max. load current per output: 500 mA Continued-short-circuit-proof Output delay (typ./max.): ³⁾ For "0" → "1": 150 μs/400 μs For "1" → "0": 75 μs/100 μs Switching frequency:
	table cross-sect		For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

¹⁾ DI: digital input; DI/DO: bidirectional digital input/output; M: electronics ground; M1: reference potential

Type: Spring-loaded terminal 3 (see Appendix A)

²⁾ The rapid inputs can be used as probe inputs or as inputs for the external zero mark

³⁾ Data for: V_{cc} = 24 V; load 48 Ω ; high ("1") = 90% V_{out} ; low ("0") = 10% V_{out}

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M1 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (**Notice**! This removes the electrical isolation for these digital inputs.

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

2.2.3.4 X132 digital inputs/outputs

Table 2-4 X132 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	DI 4	Voltage (max.): -3 V to +30 V DC
	2	DI 5	Typical current consumption: 9 mA at 24 V
	3	DI 6	Electrical isolation: The reference potential is termina M2
	4	DI 7	Level (incl. ripple)
	5	DI 20	High level: 15 V to 30 V
	6	DI 21	Low level: -3 V to +5 V
			Input delay (typ.): For "0" → "1": 50 µs For "1" → "0": 150 µs
$\bigcirc \square \qquad \boxed{7}$	7	M2	Reference potential for terminals 1 to 6
	8	M	Electronics ground
	9	DI/DO 12	As input:
	10 DI/DO 13	DI/DO 13	Voltage: -3 V to +30 V DC
	11	Typical current consumption: 9 mA at 24	
	12	DI/DO 14	Level (incl. ripple) High level: 15 V to 30 V
	13	DI/DO 15	Low level: -3 V to +5 V
14	14	М	DI/DO 12, 13, 14, and 15 are "rapid inputs" $^{2)}$ Input delay (typ.): For "0" \rightarrow "1": 5 μ s For "1" \rightarrow "0": 50 μ s
			As output: Voltage: 24 V DC Max. load current per output: 500 mA Continued-short-circuit-proof Output delay (typ./max.): ³) For "0" → "1": 150 µs/400 µs For "1" → "0": 75 µs/100 µs Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz
			For lamp load: Max. 10 Hz Maximum lamp load: 5 W

Type: Spring-loaded terminal 3 (see Appendix A)

¹⁾ DI: digital input; DI/DO: bidirectional digital input/output; M: electronics ground; M2: reference potential

²⁾ The rapid inputs can be used as probe inputs or as inputs for the external zero mark

³⁾ Data for: V_{cc} = 24 V; load 48 Ω ; high ("1") = 90% V_{out} ; low ("0") = 10% V_{out}

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M2 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (**Notice**! This removes the electrical isolation for these digital inputs.)

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

2.2.3.5 X124 electronics power supply

Table 2-5 X124 electronics power supply

	Terminal	Designation	Technical specifications			
	+	Electronics power supply	Voltage: 24 V DC (20.4 V to 28.8 V)			
	+	Electronics power supply	Current consumption: Max. 1.0 A (without DRIVE-CLiQ			
	M	Electronics ground	or digital outputs)			
	M	Electronics ground	Max. current via jumper in connector: 20 A			
	Max. connectable cross-section: 2.5 mm ²					
Type: Screw term	inal 2 (see Appe	endix A)				

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node and digital outputs.

Note

The terminal block must be screwed on tightly using a flat-bladed screwdriver.

2.2.3.6 X127 LAN (Ethernet)

Table 2- 6 X127 LAN (Ethernet)

	Pin	Signal name	Technical specifications
	1	TXP	Ethernet transmit data +
	2	TXN	Ethernet transmit data -
	3	RXP	Ethernet receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Ethernet receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
Connector type:	RJ45 sock	et	

Note

The LAN (Ethernet) interface does not support Auto MDI(X). For this reason, only crossed cables may be used to connect devices.

For diagnostic purposes, the X127 LAN interface features a green and a yellow LED. These LEDs indicate the following status information:

Table 2-7 LED statuses for the X127 LAN interface

LED	Color	Status	Description	
Link port	-	Off	Missing or faulty link	
	Green	Continuous light	10 or 100 Mbit link available	
Activity	-	Off	No activity	
port	Yellow	Flashing light	Sending or receiving	

2.2.3.7 X140 serial interface (RS232)

An external display and operator device for operator control/parameterization can be connected via the serial interface. The interface is located on the lower side of the Control Unit.

Table 2-8 X140 serial interface (RS232)

	Pin	Signal name	Technical data	
	1	Reserved, do not use		
	2	RxD	Receive data	
9	3	TxD	Transmit data	
	4	Reserved, do not use		
	5	Ground	Ground reference	
	6	Reserved, do not use		
	7	Reserved, do not use		
	8	Reserved, do not use		
9 Reserved, do not use		Reserved, do not use		
Connector type: 9-p	in SUB D co	onnector		

2.2.3.8 X150 P1/P2 PROFINET

The PROFINET interfaces can be operated isochronously.

Table 2- 9 X150 P1 and X150 P2 PROFINET

	Pin	Signal name	Technical specifications
	1	RXP	Receive data +
	2	RXN	Receive data -
	3	TXP	Transmit data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	TXN	Transmit data -
	7	Reserved, do not use	
8 Reserved, do not use		Reserved, do not use	
Connector type: F Cable type: PRO			

Note

The PROFINET interfaces support Auto MDI(X). It is therefore possible to use both crossed and uncrossed cables to connect the devices.

For diagnostic purposes, the two PROFINET interfaces are equipped with a green and a yellow LED. These LEDs indicate the following status information:

Table 2- 10 LED states at the X150 P1/P2 PROFINET interface

LED	Color	Status	Description	
Link port	-	Off	Missing or faulty link	
	Green	Continuous light	10 or 100 Mbit link available	
Activity	-	Off	No activity	
port	Yellow	Flashing light	Data is being received or sent at port x	

2.2.3.9 Measuring sockets

Table 2- 11 Measuring sockets T0, T1, T2

	Socket	Function	Technical specifications	
T0 = 0 0 T1	ТО	Measuring socket 0	Voltage: 0 V to 5 V	
	T1	Measuring socket 1	Resolution: 8 bits	
	T2	Measuring socket 2	Load current: max. 3 mA Continued-short-circuit-proof	
T2 🗐 🔘 M	М	Ground	The reference potential is terminal M	
The measuring sockets are only suitable for bunch pin plugs with a diameter of 2 mm.				

Note

The measuring sockets support commissioning and diagnostic functions. It must not be connected for normal operation.

2.2.3.10 DIAG button

The DIAG pushbutton is reserved for service functions.

2.2.3.11 Slot for memory card



Figure 2-6 Slot for memory card

CAUTION

The memory card may only be removed and inserted when the Control Unit is in a voltagefree state; doing this during operation instead could result in a loss of data and, where applicable, a plant standstill.

The memory card may only be inserted as shown in the photo above (arrow at top right).

CAUTION

The memory card is an electrostatic sensitive component. ESD regulations must be observed when inserting and removing the card.

NOTICE

When returning a defective Control Unit, remove the memory card and keep it for insertion in the replacement unit. This is important, otherwise the data on the memory card (parameters, firmware, licenses, and so on) may be lost.

Note

Please note that only SIEMENS memory cards can be used to operate the Control Unit.

2.2.4 Connection example




Figure 2-7 Connection example of a Control Unit CU320-2 PN

2.2.5 Meaning of LEDs

2.2.5.1 Description of the LED statuses

The different statuses that arise during the booting procedure are indicated by means of the LEDs on the Control Unit.

- The duration of the individual statuses varies.
- If an error occurs, the booting procedure is terminated and the cause is indicated accordingly via the LEDs.
- Once the unit has successfully booted up, all the LEDs are switched off briefly.
- Once the unit has booted up, the LEDs are controlled via the loaded software.

2.2.5.2 Behavior of the LEDs during booting

Table 2- 12 Load software

	LED		State	Comment
RDY	PN	OPT		
Red	Orange	Orange	Reset	Hardware reset RDY LED lights up red, all other LEDs light up orange
Red	Red	Off	BIOS loaded	_
Red flashing light 2 Hz	Red	Off	BIOS error	Error occurred while loading the BIOS
Red flashing light 2 Hz	Red flashing light 2 Hz	Off	File error	 Memory card not inserted or faulty Software on memory card not present or corrupted
Red	Orange flashing light	Off	FW loading	RDY LED lights up red, PN LED flashes orange without fixed frequency
Red	Off	Off	FW loaded	_
Off	Red	Off	FW checked (no CRC error)	
Red flashing light 0.5 Hz	Red flashing light 0.5 Hz	Off	FW checked (CRC error)	CRC invalid

Table 2- 13 Firmware

LED		State	Comment	
RDY	PN	OPT		
Orange	Off	Off	Initializing	_
	Alternating		Running	See the table below

2.2.5.3 Behavior of the LEDs in the operating state

Table 2- 14 Control Unit CU320-2 PN – Description of the LEDs after booting

LED	Color	Status	Description, cause	Remedy
RDY (READY)	-	OFF	Electronics power supply is missing or outside the permissible tolerance range.	Check power supply
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-
		0.5 Hz flashing light	Commissioning/reset	-
		2 Hz flashing light	Writing to the memory card	-
	Red	2 Hz flashing light	General error	Check parameterization/ configuration data
	Red/ green	0.5 Hz flashing light	Control Unit is ready for operation. However there are no software licenses.	Obtain licenses
	Orange	0.5 Hz flashing light	Updating the firmware of the DRIVE-CLiQ components	-
		2 Hz flashing light	DRIVE-CLIQ component firmware update complete. Wait for POWER ON for the components in question.	Turn POWER ON for the components in question
	Green/ orange or red/ orange	2 Hz flashing light	Component detection via LED is activated (p0124[0]). Note: Both options depend on the LED status when component detection is activated via p0124[0] = 1.	-
DP PROFIdrive cyclic operation	_	Off	Cyclic communication has not (yet) taken place. Note: The PROFIdrive is ready to communicate when the Control Unit is ready to operate (see LED RDY).	_
	Green	Continuous light	Cyclic communication is taking place.	_
		0.5 Hz flashing light	Full cyclic communication has not yet taken place. Possible causes:	_
			 The controller is not transferring any setpoints. During isochronous operation, no global 	
			control (GC) or a faulty global control (GC) is transferred by the controller.	
			"Shared Device" is selected (p8929=2) and only one controller connected.	

LED	Color	Status	Description, cause	Remedy
	Red C		Bus error, incorrect parameter assignment/configuration	Adapt configuration between controller and devices
		2 Hz flashing light	Cyclic bus communication has been interrupted or could not be established	Remove fault
OPT (OPTION)	_	Off	Electronics power supply is missing or outside the permissible tolerance range.	Check power supply and/or component
			Component is not ready.	
			Option board not installed or no associated drive object has been created.	
	Green	Continuous light	Option board is ready.	-
		0.5 Hz flashing light	Depends on the option board used.	_
	Red	2 Hz flashing light	This component has at least one fault. The Option Board is not ready (e.g. after switching on).	Remove the fault and acknowledge
RDY and DP	Red	2 Hz flashing light	Bus error - communication has been interrupted	Remove fault
RDY and OPT	Orange	0.5 Hz flashing light	Firmware update in progress for connected Option Board CBE20	-

2.2.6 Dimension drawing




Figure 2-8 Dimension drawing of CU320-2 PN, all data in mm and (inches)

2.2.7 Technical data

Table 2- 15 Technical data

6SL3040-1MA01-0AA0	Unit	Value
Electronics power supply Voltage Current (without DRIVE-CLiQ and digital outputs)	V _{DC} A _{DC}	DC 24 (20.4 to 28.8) 1.0
Power loss Total maximum permissible output currents Maximum DRIVE-CLiQ cable length	W A m	24 5.5
PE/ground connection	On housing with M5/3 Nm sc	rew
Response time	The response time of digital i evaluation (refer to the function	nputs/outputs depends on the on diagram).
	Additional information: SINAI Chapter "Function block diag	MICS S120/S150 List Manual, rams"
Weight	kg	2.3

2.3 Control Unit CU320-2 DP (PROFIBUS)

2.3.1 Description

The Control Unit CU320-2 DP is a central control module in which the closed-loop and open-loop functions are implemented for one or more Line Modules and/or Motor Modules. It can be used with firmware version 4.3 or higher.

The CU320-2 DP has the following interfaces (ports):

Table 2- 16 Overview of the CU320-2 DP interfaces

Туре	Quantity
Isolated digital inputs	12
Non-isolated digital inputs/outputs	8
DRIVE-CLiQ interfaces	4
PROFIBUS interface	1
LAN (Ethernet)	1
Serial interface (RS232)	1
Option slot	1
Measuring sockets	3

2.3.2 Safety information



The ventilation spaces of 80 mm above and below the component must be observed.

CAUTION

The Option Board should only be inserted and removed when the Control Unit and Option Board are at zero current.

2.3.3 Interface description

2.3.3.1 Overview




Figure 2-9 Interface overview CU320-2 DP (without cover and blanking cover)

2.3 Control Unit CU320-2 DP (PROFIBUS)




Figure 2-10 Interface X140 and measuring sockets T0 to T2 - CU320-2 DP (view from below)

2.3.3.2 X100-X103 DRIVE-CLiQ interfaces

Table 2- 17 X100-X103 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications	
	1	TXP	Transmit data +	
	2	TXN	Transmit data -	
8 B B A	3	RXP	Receive data +	
	4	Reserved, do not use		
A A	5	Reserved, do not use		
	6	RXN	Receive data -	
	7	Reserved, do not use		
	8	Reserved, do not use		
	Α	+ (24 V)	Power supply	
	В	M (0 V)	Electronics ground	
Connector type	RJ45 soc	ket	·	

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

2.3 Control Unit CU320-2 DP (PROFIBUS)

2.3.3.3 X122 digital inputs/outputs

Table 2- 18 X122 digital inputs/outputs

 Terminal	Designation 1)	Technical specifications
1	DI 0	Voltage (max.): -3 V to +30 V DC
2	DI 1	Typical current consumption: 9 mA at 24 V Electrical isolation: The reference potential is terminal
3	DI 2	M1
4	DI 3	Level (incl. ripple)
5	DI 16	High level: 15 V to 30 V
6	DI 17	Low level: -3 V to +5 V
		Input delay (typ.): For "0" \rightarrow "1": 50 μ s For "1" \rightarrow "0": 150 μ s
7	M1	Reference potential for terminals 1 to 6
8	M	Electronics ground
9	DI/DO 8	As input:
10	DI/DO 9	Voltage: -3 V to +30 V DC
11	M	Typical current consumption: 9 mA at 24 V
12	DI/DO 10	Level (incl. ripple) High level: 15 V to 30 V
13	DI/DO 11	Low level: -3 V to +5 V
14	М	DI/DO 8, 9, 10, and 11 are "rapid inputs" $^{2)}$ Input delay (typ.): For "0" \rightarrow "1": 5 μ s For "1" \rightarrow "0": 50 μ s
		As output: Voltage: 24 V DC Max. load current per output: 500 mA Continued-short-circuit-proof Output delay (typ./max.): $^{3)}$ For "0" \rightarrow "1": 150 µs/400 µs For "1" \rightarrow "0": 75 µs/100 µs Switching frequency:
ctable cross-secti	an 1.5 mm²	For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

Max. connectable cross-section: 1.5 mm²
Type: Spring-loaded terminal 3 (see Appendix A)

¹⁾ DI: digital input; DI/DO: bidirectional digital input/output; M: electronics ground; M1: reference potential

²⁾ The rapid inputs can be used as probe inputs or as inputs for the external zero mark

³⁾ Data for: V_{cc} = 24 V; load 48 Ω ; high ("1") = 90% V_{out} ; low ("0") = 10% V_{out}

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M1 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (**Notice**! This removes the electrical isolation for these digital inputs.

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

2.3 Control Unit CU320-2 DP (PROFIBUS)

2.3.3.4 X132 digital inputs/outputs

Table 2- 19 X132 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	DI 4	Voltage (max.): -3 V to +30 V DC
	2	DI 5	Typical current consumption: 9 mA at 24 V
	3	DI 6	Electrical isolation: The reference potential is terminal M2
	4	DI 7	Level (incl. ripple)
	5	DI 20	High level: 15 V to 30 V
	6	DI 21	Low level: -3 V to +5 V
			Input delay (typ.): For "0" \rightarrow "1": 50 μ s For "1" \rightarrow "0": 150 μ s
	7	M2	Reference potential for terminals 1 to 6
	8	M	Electronics ground
	9	DI/DO 12	As input:
	10	DI/DO 13	Voltage: -3 V to +30 V DC
	11	M	Typical current consumption: 9 mA at 24 V
	12	DI/DO 14	Level (incl. ripple) High level: 15 V to 30 V
	13	DI/DO 15	Low level: -3 V to +5 V
	14	М	DI/DO 12, 13, 14, and 15 are "rapid inputs" $^{2)}$ Input delay (typ.): For "0" \rightarrow "1": 5 μ s For "1" \rightarrow "0": 50 μ s
			As output: Voltage: 24 V DC Max. load current per output: 500 mA Continued-short-circuit-proof Output delay (typ./max.): ³⁾ For "0" → "1": 150 μs/400 μs For "1" → "0": 75 μs/100 μs
	ctable cross-secti		Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

Type: Spring-loaded terminal 3 (see Appendix A)

¹⁾ DI: digital input; DI/DO: bidirectional digital input/output; M: electronics ground; M2: reference potential

²⁾ The rapid inputs can be used as probe inputs or as inputs for the external zero mark

³⁾ Data for: V_{cc} = 24 V; load 48 Ω ; high ("1") = 90% V_{out} ; low ("0") = 10% V_{out}

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M2 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (**Notice**! This removes the electrical isolation for these digital inputs.)

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

2.3.3.5 X124 electronics power supply

Table 2- 20 X124 electronics power supply

	Terminal	Designation	Technical specifications			
	+	Electronics power supply	Voltage: 24 V DC (20.4 V to 28.8 V)			
	+	Electronics power supply	Current consumption: Max. 1.0 A (without DRIVE-CLiQ			
	М	Electronics ground	or digital outputs)			
	M	Electronics ground	Max. current via jumper in connector: 20 A			
Max. connectable						
Type: Screw term	Type: Screw terminal 2 (see Appendix A)					

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node and digital outputs.

Note

The terminal block must be screwed on tightly using a flat-bladed screwdriver.

2.3 Control Unit CU320-2 DP (PROFIBUS)

2.3.3.6 X126 PROFIBUS

The PROFIBUS interface can be operated isochronously.

Table 2-21 X126 PROFIBUS interface

	Pin	Signal name	Meaning	Range		
	1	-	Not assigned			
	2	M24_SERV	Teleservice supply, ground	0 V		
	3	RxD / TxD-P	Receive/transmit data P (B)	RS485		
	4	CNTR-P	Control signal	TTL		
	5	DGND	PROFIBUS data reference potential			
	6	VP	Supply voltage plus	5 V ± 10%		
	7	P24_SERV	Teleservice supply, + (24 V)	24 V (20.4 V to 28.8 V)		
	8	RxD / TxD-N	Receive/transmit data N (A)	RS485		
	9	-	Not assigned			
<u> </u>						
Connector type	e: 9-pin Sub-D	socket				

A teleservice adapter can be connected to the PROFIBUS interface for remote diagnostics. The power supply for the teleservice (terminals 2 and 7) can have a load of up to 150 mA.



A potential bonding conductor with a cross-section of at least 25 mm² must be used between components in a system that are located at a distance from each other. If a potential bonding conductor is not used, high leakage currents that could destroy the Control Unit or other PROFIBUS nodes can be conducted via the PROFIBUS cable.

CAUTION

No CAN cables must be connected to interface X126. If CAN cables are connected, the Control Unit and other CAN bus nodes may be destroyed.

PROFIBUS connectors

The first and last nodes in a bus must contain terminating resistors. Otherwise, data transmission will not function correctly.

The bus terminating resistors are activated in the connector.

The cable shield must be connected at both ends and over a large surface area.

2.3.3.7 PROFIBUS address switch

On the CU320-2, the PROFIBUS address is set as a hexadecimal value using two rotary coding switches. Values between $0_{dec} (00_{hex})$ and $127_{dec} (7F_{hex})$ can be set as the address. The upper rotary coding switch (H) is used to set the hexadecimal value for 16^{1} and the lower rotary coding switch (L) is used to set the hexadecimal value for 16^{0} .

Table 2- 22 PROFIBUS address switch

Rotary coding switches	Significance	Examples		
		21 _{dec}	35 _{dec}	126 _{dec}
		15 _{hex}	23 _{hex}	7E _{hex}
DP H	161 = 16	1	2	7
DP L	160 = 1	5	3	E

Setting the PROFIBUS address

The factory setting for the rotary coding switches is 0_{dec} (00_{hex}).

There are two ways to set the PROFIBUS address:

- 1. Using parameter p0918
 - To set the bus address for a PROFIBUS node using STARTER, first set the rotary code switches to O_{dec} (00_{hex}) and/or 127_{dec} (7F_{hex}).
 - Then use parameter p0918 to set the address to a value between 1 and 126.
- 2. Using the PROFIBUS address switches on the Control Unit
 - The address is set manually to values between 1 and 126 using the rotary coding switches. In this case, p0918 is only used to read the address.

Note

The rotary coding switches used to set the PROFIBUS address are located beneath the blanking cover Figure 2-2 Overview, Control Unit CU320-2 DP (Page 37).

More information

Additional information about setting the PROFIBUS address is provided in the following document:

SINAMICS S120 Function Manual (FH1)

2.3 Control Unit CU320-2 DP (PROFIBUS)

2.3.3.8 X127 LAN (Ethernet)

Table 2-23 X127 LAN (Ethernet)

	Pin	Signal name	Technical specifications
	1	TXP	Ethernet transmit data +
	2	TXN	Ethernet transmit data -
	3	RXP	Ethernet receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Ethernet receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
Connector type: I	RJ45 socket		

Note

The LAN (Ethernet) interface does not support Auto MDI(X). For this reason, only crossed cables may be used to connect devices.

For diagnostic purposes, the X127 LAN interface features a green and a yellow LED. These LEDs indicate the following status information:

Table 2- 24 LED statuses for the X127 LAN interface

LED	Color	Status	Description
Link port	-	Off	Missing or faulty link
	Green	Continuous light	10 or 100 Mbit link available
Activity	-	Off	No activity
port	Yellow	Flashing light	Sending or receiving

2.3.3.9 X140 serial interface (RS232)

An external display and operator device for operator control/parameterization can be connected via the serial interface. The interface is located on the lower side of the Control Unit.

Table 2- 25 X140 serial interface (RS232)

	Pin	Signal name	Technical data		
	1	Reserved, do not use			
	2	RxD	Receive data		
9	3	TxD	Transmit data		
	4	Reserved, do not use			
	5	Ground	Ground reference		
	6	Reserved, do not use			
	7	Reserved, do not use			
	8	Reserved, do not use			
	9	Reserved, do not use			
Connector type: 9-pin SUB D connector					

2.3.3.10 Measuring sockets

Table 2- 26 Measuring sockets T0, T1, T2

	Socket	Function	Technical specifications			
	ТО	Measuring socket 0	Voltage: 0 V to 5 V Resolution: 8 bits			
T0 = 6 11	T1	Measuring socket 1				
	T2	Measuring socket 2	Load current: max. 3 mA Continued-short-circuit-proof			
T2 M	M	Ground	The reference potential is terminal M			
The measuring sockets are only suitable for bunch pin plugs with a diameter of 2 mm.						

Note

The measuring sockets support commissioning and diagnostic functions. It must not be connected for normal operation.

2.3.3.11 **DIAG** button

The DIAG pushbutton is reserved for service functions.

2.3.3.12 Slot for memory card



Figure 2-11 Slot for memory card

CAUTION

The memory card may only be removed and inserted when the Control Unit is in a voltagefree state; doing this during operation instead could result in a loss of data and, where applicable, a plant standstill.

The memory card may only be inserted as shown in the photo above (arrow at top right).

CAUTION

The memory card is an electrostatic sensitive component. ESD regulations must be observed when inserting and removing the card.

NOTICE

When returning a defective Control Unit, remove the memory card and keep it for insertion in the replacement unit. This is important, otherwise the data on the memory card (parameters, firmware, licenses, and so on) may be lost.

Note

Please note that only SIEMENS memory cards can be used to operate the Control Unit.

2.3.4 Connection example




Figure 2-12 Connection example of CU320-2 DP

2.3.5 Meaning of LEDs

2.3.5.1 Description of the LED statuses

The different statuses that arise during the booting procedure are indicated by means of the LEDs on the Control Unit.

- The duration of the individual statuses varies.
- If an error occurs, the booting procedure is terminated and the cause is indicated accordingly via the LEDs.
- Once the unit has successfully booted up, all the LEDs are switched off briefly.
- Once the unit has booted up, the LEDs are controlled via the loaded software.

2.3.5.2 Behavior of the LEDs during booting

Table 2- 27 Load software

LED			Status	Comment
RDY	DP	OPT		
Red	Orange	Orange	Reset	Hardware reset RDY LED lights up red, all other LEDs light up orange
Red	Red	Off	BIOS loaded	_
Red 2 Hz	Red	Off	BIOS error	Error occurred while loading the BIOS
Red 2 Hz	Red 2 Hz	Off	File error	Memory card not inserted or defective
				Software on memory card not present or corrupted
Red	Orange Flashing light	Off	FW loading	RDY LED lights up red, PN LED flashes orange without fixed frequency
Red	Off	Off	FW loaded	-
Off	Red	Off	FW checked (no CRC error)	
Red 0.5 Hz	Red 0.5 Hz	Off	FW checked (CRC error)	CRC invalid

Table 2- 28 Firmware

LED		Status	Comment	
RDY	DP	OPT		
Orange	Off	Off	Initializing	_
	Alternating		Running	See the table below

2.3.5.3 Behavior of the LEDs in the operating state

Table 2- 29 Control Unit CU320-2 DP – Description of the LEDs after booting

LED	Color	Status	Description, cause	Remedy
RDY (READY)	-	OFF	Electronics power supply is missing or outside the permissible tolerance range.	Check power supply
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
		0.5 Hz flashing light	Commissioning/reset	-
		2 Hz flashing light	Writing to the memory card	-
	Red	2 Hz flashing light	General error	Check parameterization/ configuration data
	Red/ green	0.5 Hz flashing light	Control Unit is ready for operation. However there are no software licenses.	Obtain licenses
	Orange	0.5 Hz flashing light	Updating the firmware of the DRIVE-CLiQ components	_
		2 Hz flashing light	DRIVE-CLiQ component firmware update complete. Wait for POWER ON for the components in question.	Turn POWER ON for the components in question
	Green/ orange or red/ orange	2 Hz flashing light	Component detection via LED is activated (p0124[0]). Note: Both options depend on the LED status when component detection is activated via p0124[0] = 1.	_
DP PROFIdrive cyclic operation	_	Off	Cyclic communication has not (yet) taken place. Note: The PROFIdrive is ready to communicate when the Control Unit is ready to operate (see LED RDY).	_
	Green	Continuous light	Cyclic communication is taking place.	_
		0.5 Hz flashing light	Full cyclic communication has not yet taken place. Possible causes:	_
			The controller is not transferring any setpoints.	
			During isochronous operation, no global control (GC) or a faulty global control (GC) is transferred by the controller.	

2.3 Control Unit CU320-2 DP (PROFIBUS)

LED	Color	Status	Description, cause	Remedy
Red 0.5 Hz flashing light		flashing	PROFIBUS master is sending wrong parameterization/configuration data	Adapt configuration between master/controller and CU
		2 Hz flashing light	Cyclic bus communication has been interrupted or could not be established	Remove fault
OPT (OPTION)	_	Off	Electronics power supply is missing or outside the permissible tolerance range.	Check power supply and/or component
			Component is not ready.	
			Option board not installed or no associated drive object has been created.	
	Green	Continuous light	Option board is ready.	-
		0.5 Hz flashing light	Depends on the Option Board used.	_
	Red	2 Hz flashing light	This component has at least one fault. The Option Board is not ready (e.g. after switching on).	Remove the fault and acknowledge
RDY and DP	Red	2 Hz flashing light	Bus error - communication has been interrupted	Remove fault
RDY and OPT	Orange	0.5 Hz flashing light	Firmware update in progress for connected Option Board CBE20	-

2.3.6 Dimension drawing




Figure 2-13 Dimension drawing of CU320-2 DP, all data in mm and (inches)

2.3.7 Technical data

Table 2- 30 Technical data

6SL3040-1MA00-0AA0	Unit	Value	
Electronics power supply			
Voltage	V _{DC}	24 DC (20.4 to 28.8)	
Current (without DRIVE-CLiQ or digital outputs)	A _{DC}	1.0	
Power loss Maximum DRIVE-CLiQ cable length	W m	24 100	
PE/ground connection	At the housing with M5/3 Nm so	crew	
Response time	The response time of digital inp (refer to the function diagram).	uts/outputs depends on the evaluation	
	Additional information: SINAMICS S120/S150 List Manual (LH1), Chapter "Function block diagrams"		
Weight	kg	2.3	

2.4 Installation

2.4.1 Mounting to a Line Module


Mounting a CU320-2 PN or CU320-2 DP Control Unit directly to a Line Module in booksize or chassis format

For mounting the Control Unit onto a Line Module, initially three support brackets must be attached to the Line Module. They are included each Line Module accessories kit.

Table 2-31 Mounting the support brackets onto a Line Module in the booksize format



Insert the mount into the installation opening provided.



Use a suitable tool (such as a screwdriver) to push the mount in as far as it will go.




Attached mounts (x 3)

Then install the Control Unit on the Line Module.

Table 2- 32 Installing the Control Unit on a Line Module using the CU320-2 DP as an example








Push the Control Unit downwards until it latches into place



Control Unit installed - the front is flush to the Line Module

2.4 Installation



① Opening on the Line Module Chassis for fastening the Control Unit

Figure 2-14 Installing a Control Unit on a Line Module, chassis format

2.4.2 Installation on the mounting surface

Installing a CU320-2 DP and CU320-2 PN directly on a mounting surface

To install the Control Unit directly on the mounting surface, move the fixing lug on the back of the Control Unit up.

Table 2- 33 Moving the fixing lug using a CU320-2 DP as an example



- 1. Unscrew the screws 1 with Torx T10
- 2. Push up the fixing lug






- 3. Tighten the screws (M3) with Torx T10, tightening torque 0.8 Nm
- 4. Installing the Control Unit on a mounting surface with M6 screws, tightening torque 6 Nm

Installing a CU320-2 DP or CU320-2 PN onto a mounting surface with spacer elements

To increase the mounting depth of the Control Unit to the 270 mm mounting depth of a Line Module in booksize format, spacer elements (2 pieces: 6SL3064-1BB00-0AA0) can be installed.



Spacer

Figure 2-15 CU320-2 DP with spacers for installation on a mounting surface

2.4.3 Opening and removing the cover

Table 2- 34 Opening and lifting the cover using the CU320-2 DP as an example





Table 2- 35 Removing the cover using a CU320-2 DP as an example



2.4 Installation

Additional system components

3

3.1 Basic Operator Panel BOP20

3.1.1 Description

The Basic Operator Panel BOP20 contains six keys and a backlit display unit. The BOP20 can be plugged onto a SINAMICS Control Unit and operated.

The following functions are possible with the BOP:

- Input of parameters and activation of functions
- Display of operating modes, parameters, alarms and faults

3.1.2 Interface description



Figure 3-1 Basic Operator Panel BOP20

Overview of displays and keys




Figure 3-2 Overview of displays and keys

Table 3- 1 Displays

Display	Meaning
top left 2 positions	The active drive object of the BOP is displayed here. The displays and key operations always refer to this drive object.
RUN	Is lit (bright) if the displayed drive is in the RUN state (in operation).
top right	The following is displayed in this field:
2 positions	 More than 6 digits: Characters that are still present but are invisible (e.g. "r2" -> 2 characters to the right are invisible, "L1" -> 1 character to the left is invisible)
	Faults: Selects/displays other drives with faults
	Designation of BICO inputs (bi, ci)
	Designation of BICO outputs (bo, co)
	Source object of a BICO interconnection to a drive object different than the active one.
S	Is (bright) if at least one parameter was changed and the value was not transferred into the non-volatile memory.
Р	Is lit (bright) if, for a parameter, the value only becomes effective after pressing the P key.
С	Is light (bright) if at least one parameter was changed and the calculation for consistent data management has still not been initiated.
Below, 6 position	Displays, e.g. parameters, indices, faults and alarms.

BOP20 keyboard

Table 3-2 Assignment of the BOP20 keyboard

Key	Name	Meaning
	ON	Powering-up the drives for which the command "ON/OFF1", "OFF2" or "OFF3" should come from the BOP.
0	OFF	Powering-down the drives for which the commands "ON/OFF1", "OFF2" or "OFF3" should come from the BOP.
		Note:
		The effectiveness of these keys can be defined using the appropriate BICO parameterization (e.g. using these keys, it is possible to simultaneously control all of the axes that have been configured).
		The structure of the BOP control word corresponds to the structure of the PROFIBUS control word.
	Functions	The meaning of these keys depends on the actual display.
FN		Note:
		The effectiveness of this key to acknowledge faults can be defined using the appropriate BiCo parameterization.
Р	Parameter	The meaning of these keys depends on the actual display.
Δ	Raise	The keys are dependent on the actual display and are used to raise or lower values.
∇	Lower	

Display and operator controls of the BOP20

For information about display and operator controls of the BOP20, refer the SINAMICS S120 Commissioning Manual.


3.1.3 Installation

NOTICE

Make sure that you insert and withdraw the BOP20 straight into/out of the Control Unit and that it is not tilted up or down.

This prevents damage to the interface for the BOP20 at the Control Unit.

Table 3-3 Installing a Basic Operator Panel BOP20 using the CU320-2 DP as an example



3.1.4 Removal

Please note the following information when removing the BOP20 from the Control Unit:

- 1. The latching cams on the BOP20 must be pressed together simultaneously.
- 2. The BOP20 must be pulled out straight (i.e. not at an angle). The bottom edge of the BOP20 must never be pulled forwards to remove the device, as this could damage the interface on the rear.



Figure 3-3 Incorrect removal of the BOP20 from a CU320-2 DP (example)

3.2 Option Board: CAN Communication Board CBC10

3.2.1 Description

The Communication Board CBC10 is a communication module for linking to CAN.

3.2.2 Safety information

CAUTION

The Option Board should only be inserted and removed when the Control Unit and Option Board are at zero current.

CAUTION

The CBC10 must only be operated by qualified personnel. The ESC notices must be observed.

3.2.3 Interface description

3.2.3.1 Overview




Figure 3-4 Interface overview of the CBC10

3.2.3.2 X451 CAN bus interface

Table 3-4 X451 CAN bus interface

	Pin	Designation	Technical specifications	
	1	Reserved, do not use		
	2	CAN_L	CAN signal (dominant low)	
	3	CAN_GND	CAN ground	
	4	Reserved, do not use		
	5	CAN_SHLD	Optional shield	
	6	GND	CAN ground	
	7	CAN_H	CAN signal	
	8	Reserved, do not use		
	9	Reserved, do not use		
Type: SUB-D	female, 9-pir	n		

/ CAUTION


If the CAN bus interface is connected to the PROFIBUS connector, then this can destroy the CAN interface.

3.2.3.3 X452 CAN bus interface X452

Table 3-5 X452 CAN bus interface

	Pin	Designation	Technical specifications	
	1	Reserved, do not use		
	2	CAN_L	CAN signal (dominant low)	
	3	CAN_GND	CAN ground	
9	4	Reserved, do not use		
	5	CAN_SHLD	Optional shield	
• •	6	GND	CAN ground	
	7	CAN_H	CAN signal	
8		Reserved, do not use		
	9	Reserved, do not use		
Type: 9-pin SL	JB-D male			

3.2.3.4 2-pin SMD DIL switch



- ① Switch 2
- 2 Switch 1

Figure 3-5 2-pin SMD DIL switch 1 and 2 on the CBC10

Table 3- 6 2-pin SMD DIL switch

ID on the component	Switch	Function	Switch position		Default
	2	Bus terminating	Off	Inactive	Off
		resistor 120 Ohm	ON	Active	
	1	Operation with/without	Off	Ground-free operation	Off
///		ground	ON	Operation with ground	

3.2.4 Meaning of the LED

Table 3-7 Meaning of the LEDs on the Communication Board CAN CBC10


LED	Color	Status	Description, cause	Remedy
OPT on the Control Unit	_	OFF	Electronics power supply is missing or outside permissible tolerance range.	-
			Communication Board either defective or not inserted.	
	Green	Continuous light	OPERATIONAL	_
		Flashing	PREOPERATIONAL	_
		light	No PDO communication possible	
		Single flash	STOPPED	
			Only NMT communication possible	
	Red	Continuous	BUS OFF	Check baud rate
		light		Check cabling
		Single flash	ERROR PASSIVE MODE	Check baud rate
			The error counter for "error passive" has reached the value 127. After the SINAMICS drive system was booted no further active CAN component was on the bus.	Check cabling
		Double flash	Error Control Event, a Guard Event has occurred	Check connection to CANopen master

3.2.5 Installation

- 1. Release the screws and remove the protective cover from the Control Unit
- 2. Insert the Option Board in the Control Unit slot and tighten the screws

Screws: M3

Tool: Torx T10 screwdriver **Tightening torque**: 0.8 Nm



- 1 Protective cover
- Option Board

Figure 3-6 Installing an Option Board using a CU320-2 DP as an example

3.2.6 Technical data

Table 3-8 Technical data

6SL3055-0AA00-2CAx	Unit	Value
Max. current requirements (at 24 V DC)	Apc	0.1
Power loss	W	<10
Weight, approx.	kg	0.1

3.3 Option Board: Communication Board Ethernet CBE20

3.3.1 Description

The SINAMICS S120 system can be connected to PROFINET using the Communication Board CBE20 interface board. The module supports PROFINET IO with Isochronous Realtime Ethernet (IRT), PROFINET IO with RT. Mixed operation is not permissible! PROFINET CBA is not supported.

The option board has an X1400 interface with 4 ports for communication.

Note

Only one communication interface can be used in isochronous operation when operating the Option Board CBE20 in a Control Unit CU320-2. For the CU320-2 DP, this is either the DP interface of the Control Unit or the PN interfaces of the CBE20.

For the CU320-2 PN, either the internal PN interfaces or the external PN interfaces of the CBE20 are used in isochronous operation.

3.3.2 Safety information

CAUTION

The Option Board should only be inserted and removed when the Control Unit and Option Board are at zero current.

CAUTION

The CBE20 must only be operated by qualified personnel. The ESC notices must be observed.

3.3.3 Interface description

3.3.3.1 Overview




Figure 3-7 Interface overview CBE20

3.3.3.2 X1400 Ethernet interface

Table 3-9 X1400 Ethernet, ports 1-4

	Pin	Signal name	Technical specifications
	1	RXP	Receive data +
	2	RXN	Receive data -
	3	TXP	Transmit data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	TXN	Transmit data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Screened backshell	M_EXT	Screen, permanently connected
Connector type	RJ45 socket		

For diagnostic purposes, the ports have one green and one yellow LED (refer to "Meaning of the LEDs" for descriptions)

Cable and connector types

Information on PROFINET cables and connectors can be found in the following catalog: Industrial Communication Catalog IK PI, 2009 edition,

3.3.4 Meaning of LEDs

Meaning of the LEDs on the CBE20 Communication Board Ethernet

Table 3- 10 Meaning of the LEDs at ports 1 to 4 of the X1400 interface

LED	Color	Status	Description
Link port	-	Off	Electronics power supply is missing or outside permissible tolerance range (link missing or defective).
	Green	Continuous light	A different device is connected to port x and a physical connection exists.
Activity port	-	Off	Electronics power supply is missing or outside permissible tolerance range (no activity).
	Yellow	Flashing light	Data is being received or sent at port x.

Table 3- 11 Meaning of the Sync and Fault LEDs on the CBE20

LED	Color	Status	Description	
Fault	-	Off	If the link port LED is green: The CBE20 is operating normally, data is being exchanged with the configured IO Controller.	
	Red	Flashing	 The response monitoring interval has elapsed. Communications is interrupted. The IP address is incorrect. Incorrect or no configuration. Incorrect parameter settings. Incorrect or missing device name. IO Controller not connected/switched off, although an Ethernet connection has been established. Other CBE20 errors CBE20 bus error 	
		light	 No physical connection to a subnet/switch. Incorrect transmission rate Full duplex transmission is not activated. 	
Sync	_	Off	If the link port LED is green: Control Unit task system is not synchronized with the IRT clock. An internal substitute clock is generated.	
	Green	Flashing light	Control Unit task system has synchronized with the IRT clock and data is being exchanged.	
		Continuous light	Task system and MC-PLL have synchronized with the IRT clock.	

3.3 Option Board: Communication Board Ethernet CBE20

Table 3- 12 Meaning of the OPT LED on the Control Unit


LED	Color	Status	Description, cause	Remedy
OPT	_	OFF	Electronics power supply is missing or outside permissible tolerance range.	_
			Communication Board either defective or not inserted.	
	Green	Continuous light	Communication Board is ready and cyclic communication is taking place.	_
		Flashing light 0.5 Hz	The Communication Board is ready, but cyclic communications is not running. Possible causes:	-
			At least one fault is present.	
			Communication is being established.	
	Red	Continuous light Cyclic communication via PROFINET has not yet be established. However, non-cyclic communications a possible. SINAMICS waits for a parameterizing/contelegram		-
Flashing light 0.5 Hz			The firmware update into the CBE20 has been completed with an error. Possible causes:	-
			The CBE20 is defective.	
			The memory card for the Control Unit is defective. In this state CBE20 cannot be used.	
		Flashing light 2 Hz	There is a communications error between the Control Unit and the CBE20. Possible causes:	Correctly insert the board, if required, replace.
			Board was withdrawn after booting.	
			The board is defective	
	Orange	Flashing light 0.5 Hz	Firmware is being updated.	_

3.3.5 Installation

- 1. Release the screws and remove the protective cover from the Control Unit
- 2. Insert the Option Board in the Control Unit slot and tighten the screws

Screws: M3

Tool: Torx T10 screwdriver **Tightening torque**: 0.8 Nm



- 1 Protective cover
- Option Board

Figure 3-8 Installing the Option Board using a CU320-2 DP as an example

3.3.6 Technical data

Table 3- 13 Technical data

Communication Board CBE20 6SL3055-0AA00-2EBx	Unit	Value
Max. current requirements (at 24 V DC)	A _{DC}	0.1
Power loss	W	2.4
Weight	kg	<0.1

3.4 Option Board: Terminal Board TB30

3.4.1 Description

The Terminal Board TB30 is a terminal expansion board for plugging onto the Control Unit. The TB30 contains the following terminals:

Table 3- 14 Interface overview of the TB30

Туре	Quantity
Digital inputs	4
Digital outputs	4
Analog inputs	2
Analog outputs	2

3.4.2 Safety information

CAUTION

The Option Board should only be inserted and removed when the Control Unit and Option Board are at zero current.

CAUTION

The TB30 must only be operated by qualified personnel. The ESC notices must be observed.

3.4.3 Interface description

3.4.3.1 Overview




Figure 3-9 Interface overview of the TB30

3.4.3.2 X424 power supply, digital outputs

Table 3- 15 X424 power supply

	Terminal	Designation	Technical specifications	
	+	Power supply	Voltage: 24 V DC (20.4 V – 28.8 V)	
+	+	Tower supply	Current consumption: Max. 4 A (per digital output max. 0.5 A)	
	M		Max. current via jumper in connector: 20 A	
M Ground				
Max. connecta	Max. connectable cross-section: 2.5 mm ²			

Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

This power supply is required for the digital outputs only.

The electronics power supply and the power supply for the analog inputs/outputs are taken from the option slot of the Control Unit.

Note

The power supply of the digital outputs and the electronics power supply of the Control Unit are isolated.

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

3.4.3.3 X481 digital inputs/outputs

Table 3- 16 X481 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	DI 0	Voltage: - 3 V to +30 V
	2	DI 1	Typical current consumption: 10 mA at 24 V DC
	3	DI 2	Ground reference: X424. M Input delay:
	4	DI 3	- for "0" to "1": 20 μs - for "1" to "0": 100 μs
			Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to 5 V
	5	DO 0	Voltage: 24 V DC
	6	DO 1	Max. load current per output: 500 mA
	7	DO 2	Ground reference: X424.M Sustained short-circuit-proof
	8	DO 3	Output delay: - for "0" to "1": Typically 150 µs at 0.5 A ohmic load (500 µs maximum) - for "1" to "0": Typically 50 µs at 0.5 A ohmic load
	Switching frequency: For resistive load: Max. For inductive load: Max. For lamp load: Max. 10		Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
Max. connecta Type: Spring-lo		on: 0.5 mm ² 1 (see Appendix A)	

1) DI: digital input, DO: digital output

Note

An open input is interpreted as "low".

The power supply and the digital inputs/outputs are isolated with respect to the Control Unit.

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

3.4 Option Board: Terminal Board TB30

3.4.3.4 X482 analog inputs/outputs

Table 3- 17 X482 analog inputs/outputs

	Terminal	Designation 1)	Technical specifications	
	1	AI 0+	Analog inputs (AI)	
	2	AI 0-	Voltage: -10 V to +10 V	
	3	Al 1+	Internal resistance: 65 kΩ Resolution: 13 bits + sign	
3 3	4	AI 1-	Toolston to site very	
	5	AO 0+	Analog outputs (AO) Voltage range: -10 V to +10 V	
	6	AO 0-		
6	7	AO 1+	Load current: max3 mA to +3 mA Resolution: 11 bit + sign	
	8	AO 1-	Continuously short-circuit proof	
8 0				

Max. connectable cross-section: 0.5 mm² Type: Spring-loaded terminal 1 (see Appendix A)

Note

An open input is interpreted as approximately "0 V".

The power supply of the analog inputs/outputs is taken from the option slot of the Control Unit and not from X424.

The shield is connected to the Control Unit (refer to Chapter "Electrical Connection").

CAUTION

The common-mode range must not be infringed.

The analog differential voltage signals can have a maximum offset voltage of +/-30 V with respect to the ground potential. If the range is infringed, incorrect results may occur during analog/digital conversion.

Handling analog inputs

The following document contains more information about analog inputs:

SINAMICS S120 Commissioning Manual (IH1)

¹⁾ Al: analog input, AO: analog output

3.4.4 Connection example





Figure 3-10 Example connection of TB30

3.4.5 Installation

- 1. Release the screws and remove the protective cover from the Control Unit
- 2. Insert the Option Board in the Control Unit slot and tighten the screws

Screws: M3

Tool: Torx T10 screwdriver **Tightening torque**: 0.8 Nm



- 1 Protective cover
- Option Board

Figure 3-11 Installing an Option Board using a CU320-2 DP as an example

3.4.6 Shield support




Figure 3-12 Shield support for TB30 on the CU320-2 DP

The permissible bending radii for the cables must not be exceeded when the cables are being installed.

3.4.7 Technical data

Table 3- 18 Technical data

3SL3055-0AA00-2TAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current via the option slot of the CU (without digital outputs)	A _{DC}	0.05
Power loss	W	<3
Response time	The response time of the digital inputs/outputs and the analog inputs/outputs depends on the evaluation on the Control Unit (s function diagram).	
	Additional information: SINAMICS S120/S150 List Manual (LH1), Chapter "Function block diagrams"	
Weight	kg	0.1

3.5 Terminal Module TM15


3.5.1 Description

The Terminal Module TM15 is a terminal expansion for snapping on to an EN 60715 DIN rail. The TM15 can be used to increase the number of available digital inputs/outputs within a drive system.

Table 3- 19 Interface overview of the TM15

Туре	Quantity
Bidirectional digital inputs/outputs	24
	(isolation in 3 groups each with 8 DI/DO)

3.5.2 Safety information



3.5.3 Interface description

3.5.3.1 Overview




Figure 3-13 TM15 interface overview

3.5 Terminal Module TM15

3.5.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 20 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
A B	5	Reserved, do not use	
6		RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

3.5.3.3 X520 bidirectional digital inputs/outputs

Table 3- 21 X520 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications	
	1	L1+	See Chapter, "Technical data"	
1	2	DI/DO 0		
	3	DI/DO 1		
	4	DI/DO 2		
	5	DI/DO 3		
	6	DI/DO 4		
X520	7	DI/DO 5		
*	8	DI/DO 6		
	9	DI/DO 7		
	10	M1 (GND)		
10				
Max. connectable	Max. connectable cross-section: 1.5 mm ²			

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

M1: A ground reference for DI/D 0 to 7 (first potential group) must always be connected if at least one DI/DO of the potential group is used as either input or output.

DI/DO: bidirectional digital input/output

¹⁾ L1+: A 24 V DC power supply for DI/DO 0 to 7 (first potential group) must always be connected if at least one DI/DO of the potential group is used as output.

3.5.3.4 X521 bidirectional digital inputs/outputs

Table 3- 22 X521 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	L2+	See Chapter, "Technical data"
	2	DI/DO 8	
	3	DI/DO 9	
	4	DI/DO 10	
	5	DI/DO 11	
	6	DI/DO 12	
X521	7	DI/DO 13	
₩\	8	DI/DO 14	
	9	DI/DO 15	
	10	M2 (GND)	
10			

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

DI/DO: bidirectional digital input/output

¹⁾ L2+: A 24 V DC power supply for DI/DO 8 to 15 (second potential group) must always be connected if at least one DI/DO of the potential group is used as output.

M2: A ground reference for DI/DO 8 to 15 (second potential group) must always be connected if at least one DI/DO of the potential group is used as either input or output.

3.5 Terminal Module TM15

3.5.3.5 X522 bidirectional digital inputs/outputs

Table 3- 23 X522 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	1	L3+	See Chapter, "Technical data"
	2	DI/DO 16	
	3	DI/DO 17	
	4	DI/DO 18	
	5	DI/DO 19	
	6	DI/DO 20	
X522	7	DI/DO 21	
 	8	DI/DO 22	
	9	DI/DO 23	
	10	M3 (GND)	
10			

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

M3: A ground reference for DI/D 16 to 23 (third potential group) must always be connected if at least one DI/DO of the potential group is used as either input or output.

DI/DO: bidirectional digital input/output

¹⁾ L3+: A 24 V DC power supply for DI/DO 16 to 23 (third potential group) must always be connected if at least one DI/DO of the potential group is used as output.

3.5.3.6 X524 electronics power supply

Table 3- 24 X524 electronics power supply

	Terminal	Designation	Technical specifications	
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)	
	+	Electronics power supply	Current consumption: max. 0.15 A	
	M	Electronics ground	Max. current via jumper in connector: 20 A	
Z	M	Electronics ground	iviax. current via jumper in connector. 20 A	
Max. connectable cross-section: 2.5 mm²				
Type: Screw terminal 2 (see Appendix A)				

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ participants. The digital outputs are supplied via terminals X520, X521 and X522.

3.5.4 Connection example




Figure 3-14 Example connection of TM15

3.5.5 Meaning of the LED

Table 3- 25 Meanings of the LEDs on the Terminal Module TM15

LED	Color	Status	Description, cause	Remedy
READY	-	Off	Electronics power supply is missing or outside permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/ red	Flashing light 0.5 Hz	Firmware is being downloaded.	_
		Flashing light 2 Hz	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.	_

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.5.6 Dimension drawing




Figure 3-15 Dimension drawing of Terminal Module TM15, all data in mm and (inches)


3.5.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail



- Mounting slide
- 2 Mounting rail

Figure 3-16 Removal of a component from a DIN rail

3.5.8 Protective conductor connection and shield support

It is always advisable to shield the digital input/output wiring.

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- ① Protective conductor connection M4/1.8 Nm
- Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-17 Shield support and protective conductor connection

DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.


The TM15 housing is connected to the ground terminal of the module supply (terminal X524). If the ground terminal is actually grounded, then the housing is also grounded. An additional ground connection using the M4 screw is especially necessary if high potential bonding currents can flow (e.g. through the cable shield).

3.5.9 Connector coding

A series of coding elements ("coding sliders") are supplied with each Terminal Module TM15.

Connector coding

- 1. Insert at least one coding slider at the required position.
- 2. Remove the associated coding lug at the connector.



- Coding slider
- Coding lug at the connector to be removed

Figure 3-18 Connector coding using the example of interface X521

To avoid wiring errors, unique coding patterns can be defined for the connectors X520, X521 and X522. Examples of possible patterns:

- 3 connectors on one component are encoded differently (i.e. X520, X521 and X522).
- Different component types are encoded differently.
- Identical components on the same machine are encoded differently (e.g. several TM15type components).

3.5.10 Technical data

Table 3- 26 Technical data

6SL3055-0AA00-3FAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ or digital outputs)	A _{DC}	0.15
Power loss	W	<3
Ambient temperature up to an altitude of 2,000 m	°C	0 - 60
Storage temperature	°C	-40 to +85
Relative humidity	5 % to 95 %, no	moisture condensation
1/0		
Digital inputs/outputs	Can either be pa	arameterized as DI or DO
Number of digital inputs/outputs	24	
Electrical isolation	Yes, in groups of	of 8
Max. cable length	m	30
Digital inputs		
Voltage	V _{DC}	-30 to +30
Low-level (an open digital input is interpreted as "low")	V _{DC}	-30 to +5
High level	V _{DC}	15 to 30
Input Impedance	kΩ	2.8
Current consumption (at 24 V DC)	mA	11
Max. voltage in OFF state	V _{DC}	5
Current in OFF state	mA	0.0 to 1.0 (per channel)
Typical input delay of the digital inputs	μs	"0" → "1": 50 "1" → "0": 100
Digital outputs (continued-short-circuit-proof)		
Voltage	V _{DC}	24
Max. load current per digital output	A _{DC}	0.5
Output delay (ohmic load)		
typical	μs	"0" → "1": 50 "1" → "0": 150
maximum	μs	"0" → "1": 100 "1" → "0": 225
Min. output pulse (100% amplitude, 0.5 A with resistive load)	μs	125 (typ.) 350 (max.)
Switching frequency		
For resistive load	Hz	Max. 100
For inductive load	Hz	Max. 0.5
For lamp load	Hz	Max. 10
Maximum lamp load	W	5
Max. switching frequency (100% amplitude, 50%/50% duty cycle; with 0.5 A and a resistive load)	kHz	1 (typ.)

6SL3055-0AA00-3FAx	Unit	Value	
Voltage drop in ON state	V _{DC}	0.75 (max.) for maximum load in all circuits	
Leakage current in OFF state	μΑ	max. 10 per channel	
Voltage drop, output (I/O power supply to the output)	V _D C	0.5	
Max. total current of outputs (per group) up to 60 °C up to 50 °C up to 40 °C	ADC ADC ADC	2 3 4	
Response time	The response time of the digital inputs/outputs comprises the following:		
	 Response time on the component itself (approx. 1/2 DRIVE-CLiQ cycle). 		
	 Response transmit time via the DRIVE-CLiQ connection (approx. 1 DRIVE-CLiQ cycle). 		
	Evaluation on the Control Unit (see function diagram)		
	Further information: SINAMICS S120/S150 List Manual (LH1), Chapter "Function block diagrams"		
PE/ground connection	At the housing with	M4/1.8 Nm screw	
Weight	kg	0.86	
Degree of protection	IP20		
Approbation	UL and cULus (http://www.ul.com) File: E164110, Vol. 2, Sec. 9		

Note

In order to guarantee the degree of protection, all of the connectors must be correctly screwed into place and appropriately locked.

3.6 Terminal Module TM31

3.6.1 Description

The Terminal Module TM31 is a terminal expansion that is snapped onto an EN 60715 standard mounting rail. Terminal Module TM31 can be used to increase the number of available digital inputs/digital outputs and also the number of analog inputs/analog outputs within a drive system.

The TM31 contains the following interfaces:

Table 3-27 Interface overview of the TM31

Туре	Quantity
DRIVE-CLiQ interfaces	2
Digital inputs	8
Bidirectional digital inputs/outputs	4
Analog inputs	2
Analog outputs	2
Relay outputs	2
Temperature sensor input	1

3.6.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.



Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

3.6.3 Interface description

3.6.3.1 Overview




Figure 3-19 Interface overview TM31

3.6 Terminal Module TM31

3.6.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 28 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
R R	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
A B	5	Reserved, do not use	
6		RXN	Receive data -
	7 Reserved, do not use8 Reserved, do not use		
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

3.6.3.3 X520 digital inputs

Table 3- 29 X520 digital inputs

	Terminal	Designation 1)	Technical specifications
	1	DI 0	Voltage: - 3 V to +30 V
	2	DI 1	Typical current consumption: 10 mA at 24 V DC
1 2 3	3	DI 2	Input delay:
	4	DI 3	- For "1" to "0": Typ. 130 µs max. 150 µs
4	5	M1	Electrical isolation: Reference potential is Terminal M1
5 6		М	Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V

Type: Screw terminal 1 (see Appendix A)

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M1 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (Notice! This removes the electrical isolation for these digital inputs.)

¹⁾ DI: digital input; M: electronics ground; M1: ground reference

3.6 Terminal Module TM31

3.6.3.4 X521 analog inputs

Table 3- 30 X521 analog inputs

	Terminal	Designation 1)	Technical specifications
	1	AI 0+	The analog inputs can be toggled between current and
	2	AI 0-	voltage input using switches S5.0 and S5.1
	3	Al 1+	Voltage: -10 V to +10 V; $R_i = 100 \text{ k}\Omega$
3 4	4	AI 1-	Resolution: 11 bits + sign Current: -20 mA to +20 mA; R_i = 250 Ω Resolution: 10 bits + sign
5	5	P10	Auxiliary voltage:
6	6	М	P10 = 10 V
	7	N10	N10 = -10 V
8	8	M	Continued-short-circuit-proof

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

CAUTION

If more than ±35 mA flows through the analog current input, then the component could be destroyed.

Permissible input voltage ±30 V (destruction limit).

Permissible common-mode voltage ±10 V, more errors if exceeded.

Permissible back-EMF at the auxiliary voltage outputs ±15 V.

Note

The power supply for the analog inputs can be taken internally or from an external power supply unit

3.6.3.5 S5 current/voltage changeover switch for analog inputs

Table 3- 31 Current/voltage selector S5

	Switch	Function
V 🖂 I S5.0	S5.0	Selector voltage (V)/current (I) Al0
V	S5.1	Selector voltage (V)/current (I) Al1

¹⁾ Al: analog inputs; P10/N10: auxiliary voltage; M or GND: ground reference

3.6.3.6 X522 analog outputs/temperature sensor

Table 3- 32 X522 analog outputs/temperature sensor

	Terminal	Designation 1)	Technical specifications
	1	AO 0V+	You can set the following output signals using parameters:
	2	AO 0-	Voltage: -10 V to 10 V (max. 3 mA)
	3	AO 0C+	Current 1: 4 mA to 20 mA (max. load resistance ≤ 500 Ω)
$ _{\omega} $	4	AO 1V+	Current 2: -20 mA to 20 mA (max. load resistance ≤ 500 Ω)
4	5	AO 1-	Current 3: 0 mA to 20 mA (max. load resistance ≤ 500 Ω)
5	6	AO 1C+	Resolution: 11 bits + sign
6			Continued-short-circuit-proof
	7	+ Temp	Temperature sensor KTY84-1C130/PTC
8	8	- Temp Measuring current via temperature sensor	
	table cross-secti terminal 1 (see		•

¹⁾ AO xV: analog output voltage; AO xC: analog output current

CAUTION

Permissible back-EMF at the outputs: ±15 V

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

!\DANGER

Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

3.6 Terminal Module TM31

3.6.3.7 X524 electronics power supply

Table 3- 33 X524 electronics power supply

	Terminal	Designation	Technical specifications
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)
	+	Electronics power supply	Current consumption: max. 0.5 A
	М	Electronics ground	Max. current via jumper in connector: 20 A
	M	Electronics ground	
	able cross-secti		

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node and digital outputs.

3.6.3.8 X530 digital inputs

Table 3- 34 X530 digital inputs

	Terminal	Designation 1)	Technical specifications
	1	DI 4	Voltage: -3 V to +30 V
	2	DI 5	Typical power consumption: 10 mA at 24 V DC
	3	DI 6	Input delay: - for "0" to "1": Typ. 50 µs max. 100 µs
ω ω	4	DI 7	- For "1" to "0": Typ. 130 µs max. 150 µs
4	5	M2	Electrical isolation: Reference potential is Terminal M2
5 6	6	М	Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
	table cross-sect		

Type: Screw terminal 1 (see Appendix A)

NOTICE

An open input is interpreted as "low".

To enable the digital inputs (DI) to function, terminal M2 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (Notice! This removes electrical isolation for these digital inputs).

¹⁾ DI: digital input; M: electronics ground; M2: ground reference

3.6 Terminal Module TM31

3.6.3.9 X540 auxiliary voltage for the digital inputs

Table 3- 35 X540 auxiliary voltage for digital inputs

	Terminal	Designation	Technical specifications
	8	+24 V	Voltage: +24 V DC
	7	+24 V	Max. total load current of +24 V auxiliary voltage for terminals
"	6	+24 V	X540 and X541 combined: 150 mA
	5	+24 V	
5	4	+24 V	
	3	+24 V	
ω	ω 2 +24 V		
2	1	+24 V	
<u> </u>			
Max. connecta	able cross-secti	on: 1.5 mm²	

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

Note

This voltage supply is only for powering the digital inputs.

3.6.3.10 X541 bidirectional digital inputs/outputs

Table 3- 36 X541 bidirectional digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
	6	M	Auxiliary voltage:
6	5	DI/DO 11	Voltage: +24 V DC
5	4	DI/DO 10	Max. total load current of +24 V auxiliary voltage of terminals X540 and X541 combined: 150 mA
4	3	DI/DO 9	As input:
<u>ω</u> ω	2	DI/DO 8	Voltage: -3 V to 30 V
2 1	1	+24 V	Typical current consumption: 10 mA at 24 V DC Input delay: - for "0" to "1": Typ. 50 µs - For "1" to "0". Typ. 100 µs
			As output: Voltage: 24 V DC Max. load current per output: 500 mA Max. total current of outputs (including currents to the inputs): 100 mA/1 A (can be parameterized) Continued-short-circuit-proof
		Output delay: - For "0" to "1": Typ. 150 μs at 0.5 A resistive load (500 μs maximum) - For "1" to "0": Typ. 50 μs at 0.5 A resistive load	
		Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W	

Type: Screw terminal 1 (see Appendix A)

Note

An open input is interpreted as "low".

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

¹⁾ DI/DO: Bidirectional digital input/output; M: Electronics ground

3.6 Terminal Module TM31

3.6.3.11 X542 relay outputs

Table 3- 37 X542 relay outputs

	Terminal	Designation 1)	Technical specifications		
	1	DO 0.NC	Contact type: Two-way contact max. load current: 8 A		
	2	DO 0.COM	Max. switching voltage: 250 V _{AC} , 30 V _{DC}		
	3	DO 0.NO	max. switching power at 250 V _{AC} : 2000 VA (cosφ = 1) max. switching power at 250 V _{AC} : 750 VA (cosφ = 0.4)		
ω 🕽	4	DO 1.NC	max. switching power at 30 V _{DC} : 240 W (resistive load)		
4	5	DO 1.COM	Required minimum current: 100 mA		
5 6	6	DO 1.NO	Output delay: ≤ 20 ms ²⁾ Overvoltage category: Class III to EN 60 664-1		
	Max. connectable cross-section 2.5 mm ² Type: Screw terminal 3 (see Appendix A)				

¹⁾ DO: digital output, NO: normally-open contact, NC: normally-closed contact, COM: mid-position contact

²⁾ depending on the parameters assigned and the supply voltage (P24) of the TM31

3.6.4 Connection example




Figure 3-20 Connection example of TM31

3.6.5 Meaning of the LED

Table 3- 38 Meanings of the LEDs on the Terminal Module TM31

LED	Color	Status	Description, cause	Remedy
READY	ADY - OFF		Electronics power supply is missing or outside the permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red Continuous At least one fault Note: The LED is active		At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/ red	0.5 Hz flashing light	Firmware is being downloaded.	_
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange	Flashing light	Component recognition via LED is activated (p0154). Note:	-
	or		Both options depend on the LED status when component recognition is activated via p0154 = 1.	
	Red/ orange		recognition is activated via poto4 – 1.	

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.6.6 Dimension drawing




Figure 3-21 Dimension drawing of Terminal Module TM31, all data in mm and (inches)


3.6.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail




- Mounting slide
- 2 Mounting rail

Figure 3-22 Removal of a component from a DIN rail

3.6.8 Protective conductor connection and shield support

It is always advisable to shield the digital input/output wiring.

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-23 Shield support and protective conductor connection

DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.6.9 Connector coding

To ensure that identical connectors are assigned correctly on the TM31, the connecters are encoded as shown in the following diagram.




Figure 3-24 Example of connector coding at the TM31

The bending radii of the cables must be taken into account (see description of MOTION-CONNECT).

3.6.10 Technical data

Table 3- 39 Technical data

6SL3055-0AA00-3AAx	Unit	Value
Electronics power supply Voltage Current (without DRIVE-CLiQ and digital outputs)	V _{DC} A _{DC}	24 DC (20.4 to 28.8) 0.5
Power loss	W	<10
Response time		e time of the digital inputs/outputs and the s/outputs comprise the following:
		e time on the component itself 1/2 DRIVE-CLiQ cycle).
		e transmit time via the DRIVE-CLiQ connection 1 DRIVE-CLiQ cycle).
	Additional inf	or on the Control Unit (see function diagram). ormation: SINAMICS S120/S150 List Manual
DE/ground connection	(LH1),Chapter "Function block diagrams" At the housing with M4/1.8 Nm screw	
PE/ground connection		g with M4/1.0 Mill Screw
Weight	kg	
Degree of protection	IP20	

Note

In order to guarantee the degree of protection, all of the connectors must be correctly screwed into place and appropriately locked.

3.7 Terminal Module TM41

3.7.1 Description

The Terminal Module TM41 is an expansion module that is snapped onto an EN 60715 standard mounting rail.

The encoder interface of the TM41 can be used to emulate an incremental encoder. The TM41 can also be used to connect analog controls to SINAMICS.

The TM41 contains the following interfaces:

Table 3-40 Interface overview of the TM41

Туре	Quantity
Digital inputs, floating	4
Bidirectional digital inputs/outputs	4
Analog inputs	1
TTL encoder output	1

3.7.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

3.7.3 Interface description

3.7.3.1 Overview




Figure 3-25 TM41 interface overview

3.7.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 41 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
8 B A	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

3.7.3.3 X514 and X524 Power supply

The X514 interface supplies the X521 interface with current.

The X524 interface provides the electronics power supply.

Table 3- 42 X514 and X524 Power supply

	Terminal	Designation	Technical specifications		
+	+	Power supply	Voltage: 24 V DC (20.4 V – 28.8 V) Current consumption: max. 0.5 A Max. current via jumper in connector: 20 A		
	+	Power supply			
	М	Electronics ground			
	М	Electronics ground			
Max. connectable cross-section: 2.5 mm²					
Type: Screw terminal 2 (see Appendix A)					

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current drain of X524 increases by the value for the DRIVE-CLiQ node.

The current drain of X514 increases by the value for the digital outputs.

3.7.3.4 X520 encoder interface

Table 3-43 X520 encoder interface

	Pin	Signal name	Technical specifications		
	1	А	Incremental signal A		
	2	R	Reference signal R		
	3	В	Incremental signal B		
	4	Reserved, do not use			
	5	Reserved, do not use			
	6	A*	Inverse incremental signal A		
	7	R*	Inverse reference signal R		
	8	B*	Inverse incremental signal B		
	9	М	Ground		
Connector type:	9-pin SUB-D socket; TTL encoder (RS422)				
max. cable len	igth: 100 m				

Note

The X520 encoder interface produces signals acc. to RS422 standard.

3.7.3.5 X521 bidirectional digital inputs/outputs

Table 3- 44 X521 digital inputs/outputs

	Terminal	Designation 1)	Technical specifications
1 2 3 4 5 6 7 8	1 2 3 4	DI/DO 0 DI/DO 1 DI/DO 2 DI/DO 3	As input: Voltage: -3 V to +30 V DC Typical current consumption: 10 mA at 24 V Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V Input delay: For "0" → "1": typ. 50 μs max. 100 μs - For "1" to "0": typ. 50 μs, max. 100 μs As output: Voltage: 24 V DC Max. load current per output: 0.5 mA Max. total current of outputs: 2 A Continued-short-circuit-proof Output delay: For "0" → "1": typ. 150 μs at 0.5 A resistive load (500 μs maximum) For "1" → "0": Typ. 150 μs at 0.5 A resistive load Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 100 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W
	5	+24 V	Voltage: 24 V DC
	6	+24 V	Max. load current per terminal: 500 mA
	7	+24 V	
	8	+24 V	
Max. connecta Type: Screw te			

1) DI/DO: bidirectional digital input/output

Note

This power supply is only for supplying the digital inputs.

Note

An open input is interpreted as "low".

Note

If the 24 V supply is briefly interrupted, then the digital outputs are deactivated during this time.

3.7.3.6 X522 isolated digital inputs

Table 3- 45 X522 digital inputs

	Terminal	Designation 1)	Technical specifications
	1	DI 0	Voltage: 3 V to +30 V DC
	2	DI 1	Typical current consumption: 6.5 mA at 24 V
1 2 3 4 5 6	3	DI 2	Electrical isolation: The reference potential is terminal M1
	4	DI 3	Level (incl. ripple) High level: 15 V to 30 V
	5	M1	Low level: -3 V to +5 V
	6	М	Input delay: For "0" → "1": typ. 50 μs max. 100 μs - For "1" to "0": typ. 110 μs, max. 150 μs
	table cross-secti		Тот т со о тур. тто ро, так. тоо ро

1) DI: digital input; M: electronics ground; M1: ground reference

NOTICE

To enable the digital inputs to function, terminal M1 must be connected.

This is achieved by:

- 1. Routing the ground reference of the digital inputs as well, or
- 2. A jumper to terminal M (Notice! This removes electrical isolation for these digital inputs).

3.7 Terminal Module TM41

3.7.3.7 X523 analog input

Table 3- 46 X523 analog input

	Terminal	Designation 1)	Technical specifications		
	1	Al 0- Voltage: -10 V to +10 V; $R_i = 40 \text{ k}\Omega$			
	2	AI 0+	for component3PA1: Ri = $100 \text{ k}\Omega$		
2 3	3	Reserved, do not use	Resolution: 14 bits (13 bits + sign) ²⁾ Resolution: 13 bits (12 bits + sign) ³⁾		
Max. connectable cross-section: 1.5 mm²					

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

1) AI: analog input

2) Component order numbers that end with ..-3PA0

3) Component order numbers that end with ..-3PA1

CAUTION

The Common Mode range may not be violated.

Permissible input voltage ±30 V (destruction limit).

Permissible Common Mode voltage ±10 V, increased faults if exceeded.

If the range is infringed, incorrect results may occur during analog/digital conversion

3.7.4 Connection example




Figure 3-26 Sample connection of TM41

3.7.5 Meaning of LEDs

Table 3- 47 Meaning of the LEDs on the Terminal Module TM41

LED	Color	Status	Description, cause	Remedy
READY	-	Off	Electronics power supply is missing or outside the permissible tolerance range.	_
	Green Co		The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/ red		Firmware is being downloaded.	_
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON.	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.	-
Z pulses	_	Off	Zero mark found; wait for zero marker output; OR component switched off.	-
	Red	Continuous light	Zero mark not enabled or zero mark search.	_
	Green	Continuous light	Stopped at zero mark.	_
		Flashing light	Zero mark is output at each virtual revolution.	-

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.7.6 Dimension drawing




Figure 3-27 Dimension drawing of Terminal Module TM41, all data in mm and (inches)


3.7.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail



- Mounting slide
- 2 Mounting rail

Figure 3-28 Removal of a component from a DIN rail

3.7.8 Protective conductor connection and shield support

It is always advisable to shield the digital input/output wiring.

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-29 Shield support and protective conductor connection

The bending radii of the cables must be taken into account (see description of MOTION-CONNECT).

/ DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.7.9 Technical data

Table 3-48 Technical data

6SL3055-0AA00-3PAx	Unit	Value		
Electronics power supply Voltage Current (without DRIVE-CLiQ and digital outputs)	V _{DC} A _{DC}	24 DC (20.4 to 28.8) 0.5		
Power loss	W	12		
Response time	The response time of the digital inputs/outputs and the analog input comprise the following:			
	Response time on the component itself (approx. 1/2 DRIVE-CLiQ cycle).			
	Response transmit time via the DRIVE-CLiQ connection (approx. 1 DRIVE-CLiQ cycle).			
	Evaluation on the Control Unit (see function diagram).			
	Additional information: SINAMICS S120/S150 List Manual (LH1),Chapter "Function block diagrams"			
PE/ground connection	At the housing	with M4/1.8 Nm screw		
Weight	kg	0.85		
Degree of protection	IP20			

Note

In order to guarantee the degree of protection, all of the connectors must be correctly screwed into place and appropriately locked.

3.8 Terminal Module TM54F

3.8.1 Description

The Terminal Module TM54F is a terminal expansion for snapping on to an EN 60715 standard mounting rail. The TM54F has fail-safe digital inputs and outputs for controlling SINAMICS Safety Integrated functions.

The TM54F connection should be established via the DRIVE-CLiQ directly at a Control Unit. Only one TM54F can be assigned to each Control Unit.

Additional DRIVE-CLiQ nodes can be operated at the TM54F, such as Sensor Modules and Terminal Modules (excluding an additional TM54F). Motor Modules and Line Modules should not be connected to a TM54F.

TM54F features the following interfaces:

Table 3-49 Interface overview of the TM54F

Туре	Quantity
Fail-safe digital outputs (F-DO)	4
Fail-safe digital inputs (F-DI)	10
Sensor ¹⁾ power supplies, dynamization supported ²⁾	2
Sensor ¹⁾ power supply, no dynamization	1
Digital inputs to check F_DO for a test stop	4

- 1) Sensors: Fail-safe devices to issue commands and sense, for example, Emergency Stop pushbuttons and safety locks, position switches and light arrays/light curtains.
- 2) Dynamization: The sensor power supply is cycled on and off by the TM54F when the forced checking procedure is active for the sensors, cable routing, and the evaluation electronics.

The TM54F has 4 fail-safe digital outputs and 10 fail-safe digital inputs. A fail-safe digital output consists of a 24 V DC switching output, a ground switching output, and a digital input for checking the switching state. A fail-safe digital input comprises two digital inputs.

Note

The rated values of the F-DO meet the requirements of EN 61131-2 for digital DC outputs with 0.5 A rated current.

The operating ranges of the F-DI meet the requirements of EN 61131-2 for Type 1 digital inputs.

Note

Please note that the F-DIs must take the form of shielded cables if they are > 30 m in length.

3.8 Terminal Module TM54F

3.8.2 Safety information

/ WARNING

The ventilation spaces of 50 mm above and below the component must be observed.

3.8.3 Interface description

3.8.3.1 Overview




Figure 3-30 TM54 interface overview

3.8.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 50 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
1 A	4	Reserved, do not use	
A B	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

3.8.3.3 X514 power supply for digital outputs and sensors

Table 3- 51 X514 power supply

	Terminal	Designation	Technical specifications		
	+	Power supply	Voltage: 24 V DC (20.4 V – 28.8 V)		
	+	Power supply	Current consumption: max. 4 A 1)		
	M1	Electronics ground	Max. current via jumper in connector: 20 A		
E	M1	Electronics ground			
Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)					

¹⁾ including the current consumption for the digital outputs and the sensor supply.

Note

The two "+" or "M1" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

3.8 Terminal Module TM54F

3.8.3.4 X520 sensor power supply

Table 3- 52 X520 sensor power supply

	Terminal	Designation	Technical specifications
	1		Voltage: +24 V DC Max. total load current: 500 mA,
2	2	M1	

Without forced dormant error detection

3.8.3.5 X521 fail-safe digital inputs + power supply with forced dormant error detection

Table 3- 53 X521 fail-safe digital inputs

	Terminal	Designation 1)		Technical specifications
	1	L1+		Switched voltage: +24 V DC Max. total load current: 500 mA (voltage is switched for a test stop)
2	2	DI 0	F-DI 0	Voltage: -3 V to +30 V DC
ω	3	DI 1+		Typical current consumption: 3.2 mA at 24 V
4	4	DI 2	F-DI 1	Electrical isolation: Reference potential, refer to terminals 6, 7, 8
5	5	DI 3+		All digital inputs are electrically isolated.
6 7 8				Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
				Input delay: $^{2)}$ For "0" \rightarrow "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)
	6	DI 1-	F-DI 0	Reference potential for DI 1+
	7	DI 3-	F-DI 1	Reference potential for DI 3+
	8	M1		Reference potential for DI 0, DI 2, L1+

An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out.

F-DI 0 = terminals 2, 3 and 6

F-DI 1 = terminals 4, 5 and 7

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

1) DI: digital input, F-DI: fail-safe digital input

2) Pure hardware delay

NOTICE

The test stop of the F-DI 0 to F-DI 4 can only be performed if the F-DI is supplied from L1+.

NOTICE

For the digital inputs DIx+ to function, the reference potential must be connected to input DIx- in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

3.8.3.6 X522 fail-safe digital inputs

Table 3- 54 X522 fail-safe digital inputs

	Terminal	Designation 1)		Technical specifications
	1	DI 4	F-DI 2	Voltage: -3 V to +30 V DC
	2	DI 5+		Typical current consumption: 3.2 mA at 24 V
	3	DI 6	F-DI 3	Electrical isolation: Reference potential, refer to terminals 7, 8, 9, 10
ω ω	4	DI 7+		All digital inputs are electrically isolated.
	5	DI 8	F-DI 4	Level (incl. ripple)
5	6	DI 9+		High level: 15 V to 30 V Low level: -3 V to +5 V
6 7 8				Input delay: $^{2)}$ For "0" \rightarrow "1": 30 μ s (100 Hz) For "1" to "0": 60 μ s (100 Hz)
	7	DI 5-	F-DI 2	Reference potential for DI 5+
	8	DI 7-	F-DI 3	Reference potential for DI 7+
	9	DI 9-	F-DI 4	Reference potential for DI 9+
	10	M1		Reference potential for DI 4, DI 6 and DI 8

An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out.

F-DI 2 = terminals 1, 2 and 7

F-DI 3 = terminals 3, 4 and 8

F-DI 4 = terminals 5, 6 and 9

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

- 1) DI: digital input, F-DI: fail-safe digital input
- 2) Pure hardware delay

NOTICE

The test stop of the F-DI 0 to F-DI 4 can only be performed if the F-DI is supplied from L1+.

3.8 Terminal Module TM54F

NOTICE

For the digital inputs DIx+ to function, the reference potential must be connected to input DIx- in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

3.8.3.7 X523 fail-safe digital output

Table 3- 55 X523 fail-safe digital output

	Terminal	Designation 1)		Technical specifications
1 2	1	DI 20		Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated.
ω				Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
			- F-DO 0	Input delay: ²⁾ For "0" → "1": 30 µs (100 Hz) For "1" to "0": 60 µs (100 Hz)
	2	DO 0+] F-DO 0	0.5 A
	3	DO 0-		Reference potential is terminal M1
				0.5 A Reference potential is terminal L1+, L2+ or L3+
				Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs
				Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA
				Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

An F-DO comprises two digital outputs and a digital input for the feedback signal

F-DO 0 = terminals 1, 2 and 3

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

- 1) DI: digital input; DO: digital output F-DO: fail-safe digital output
- 2) Pure hardware delay

3.8.3.8 X524 electronics power supply

Table 3- 56 X524 electronics power supply

	Terminal	Designation	Technical specifications		
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)		
	+	Electronics power supply	Current consumption: Max. 0.7 A		
	M	Electronics ground	Max. current via jumper in connector: 20 A		
	М	Electronics ground			
Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)					

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node.

3.8 Terminal Module TM54F

3.8.3.9 X525 fail-safe digital output

Table 3- 57 X525 fail-safe digital output

	Terminal	Designation 1)		Technical specifications
1 2 3	1	DI 21		Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated. Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
			5 DO 4	Input delay: ²⁾ For "0" → "1": 30 µs (100 Hz) For "1" to "0": 60 µs (100 Hz)
	2	DO 1+	F-DO 1	0.5 A
	3	DO 1-		Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+
				Output delay: ²⁾ For "0" → "1": 300 µs For "1" → "0": 350 µs
				Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA
				Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

An F-DO comprises two digital outputs and a digital input for the feedback signal

F-DO 1 = terminals 1, 2 and 3

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

2) Pure hardware delay

¹⁾ DI: digital input; DO: digital output F-DO: fail-safe digital output

3.8.3.10 X531 fail-safe digital inputs + power supply with forced dormant error detection

Table 3-58 X531 fail-safe digital inputs

	Terminal	Designation	1)	Technical specifications
_	1	L2+		Switched voltage: +24 V DC Max. total load current: 500 mA (voltage is switched for a test stop)
N	2	DI 10	F-DI 5	Voltage: -3 V to +30 V DC
ω	3	DI 11+		Typical current consumption: 3.2 mA at 24 V
4	4	DI 12	F-DI 6	Electrical isolation: Reference potential, refer to terminals 6, 7, 8
5	5	DI 13+		All digital inputs are electrically isolated.
6 7 8				Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
				Input delay: ²⁾ For "0" → "1": 30 µs (100 Hz) - For "1" to "0": 60 µs (100 Hz)
	6	DI 11-	F-DI 5	Reference potential to DI 11+
	7	DI 13-	F-DI 6	Reference potential to DI 13+
	8	M1		Reference potential to DI 10, DI 12, L2+

An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out.

F-DI 5 = terminals 2, 3 and 6

F-DI 6 = terminals 4, 5 and 7

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

- 1) DI: digital input, F-DI: fail-safe digital input
- 2) Pure hardware delay

NOTICE

The test stop of the F-DI 5 to F-DI 9 can only be performed if the F-DI is supplied from L2+.

NOTICE

For the digital inputs DIx+ to function, the reference potential must be connected to input DIx- in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

3.8 Terminal Module TM54F

3.8.3.11 X532 fail-safe digital inputs

Table 3- 59 X532 fail-safe digital inputs

	Terminal	Designation 1)		Technical specifications
	1	DI 14	F-DI 7	Voltage: -3 V to +30 V DC
	2	DI 15+		Typical current consumption: 3.2 mA at 24 V
	3	DI 16	F-DI 8	Electrical isolation: Reference potential, refer to terminals 7, 8, 9, 10
in the second se	4	DI 17+		All digital inputs are electrically isolated.
	5	DI 18	F-DI 9	Level (incl. ripple)
5	6	DI 19+		High level: 15 V to 30 V Low level: -3 V to +5 V
6 7 8				Input delay: $^{2)}$ For "0" \rightarrow "1": 30 μ s (100 Hz) For "1" to "0": 60 μ s (100 Hz)
	7	DI 15-	F-DI 7	Reference potential for DI 15+
	8	DI 17-	F-DI 8	Reference potential for DI 17+
	9	DI 19-	F-DI 9	Reference potential for DI 19+
	10	M1		Reference potential for DI 14, DI 16 and DI 18

An F-DI comprises a digital input and a 2nd digital input where, in addition, the cathode of the optocoupler is fed-out.

F-DI 7 = terminals 1, 2 and 7

F-DI 8 = terminals 3, 4 and 8

F-DI 9 = terminals 5, 6 and 9

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

1) DI: digital input, F-DI: fail-safe digital input

2) Pure hardware delay

NOTICE

The test stop of the F-DI 5 to F-DI 9 can only be performed if the F-DI is supplied from L2+.

NOTICE

For the digital inputs Dlx+ to function, the reference potential must be connected to input Dlx- in each case.

This is achieved by:

- 1) Routing the ground reference of the digital inputs as well, or
- 2) A jumper between DIx and terminal M1.

3.8.3.12 X533 fail-safe digital output

Table 3- 60 X533 fail-safe digital output

	Terminal	Designation 1)		Technical specifications
1 2	1	DI 22		Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated.
ω				Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
			F-DO 2	Input delay: ²⁾ For "0" → "1": 30 µs (100 Hz) For "1" to "0": 60 µs (100 Hz)
	2	DO 2+	11-002	0.5 A
	3	DO 2-		Reference potential is terminal M1 0.5 A Reference potential is terminal L1+, L2+ or L3+
				Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs
				Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA
				Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

An F-DO comprises two digital outputs and a digital input for the feedback signal

F-DO 2 = terminals 1, 2 and 3

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

¹⁾ DI: digital input; DO: digital output F-DO: fail-safe digital output

²⁾ Pure hardware delay

3.8 Terminal Module TM54F

3.8.3.13 X535 fail-safe digital output

Table 3- 61 X535 fail-safe digital output

	Terminal	Designation 1)		Technical specifications
1 2	1	DI 23		Voltage: -3 V to +30 V DC Typical current consumption: 3.2 mA at 24 V Electrical isolation: Reference potential is terminal M1 The digital input is electrically isolated.
ω				Level (incl. ripple) High level: 15 V to 30 V Low level: -3 V to +5 V
			- F-DO 3	Input delay: ²⁾ For "0" → "1": 30 μs (100 Hz) For "1" to "0": 60 μs (100 Hz)
	2	DO 3+		0.5 A
	3	DO 3-		Reference potential is terminal M1
				0.5 A Reference potential is terminal L1+, L2+ or L3+
				Output delay: ²⁾ For "0" → "1": 300 μs For "1" → "0": 350 μs
				Total current consumption of all DOs: 2 A Max. leakage current: < 0.5 mA
				Switching frequency: For resistive load: Max. 100 Hz For inductive load: Max. 0.5 Hz For lamp load: Max. 10 Hz Maximum lamp load: 5 W

An F-DO comprises two digital outputs and a digital input for the feedback signal

F-DO 3 = terminals 1, 2 and 3

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

2) Pure hardware delay

¹⁾ DI: digital input; DO: digital output F-DO: fail-safe digital output

3.8.4 Connection example




Figure 3-31 Connection example off TM54F

3.8.5 Meaning of LEDs

Table 3- 62 Meaning of the LEDs on the Terminal Module TM54F

LED	Color	Status	Description, cause	Remedy
READY	- Off		Electronics power supply is missing or outside the permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated irrespective of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/red	0.5 Hz flashing light	Firmware is being downloaded.	_
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/orange or Red/orange	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.	_
L1+, L2+,	-	ON	The controllable sensor power supply is functioning fault-free.	_
	Red	Continuous light	There is a fault in the controllable sensor power supply.	-
L3+	_	ON	Sensor power supply is functioning fault-free.	
	Red	Continuous light	There is a fault in the sensor power supply.	

LED	С	olor	Status	Description, cause	Remedy
Fail-safe in	puts / dou	ble inputs			
F_DI z	LED	LED			_
(input x,	х	x+1		NC contact / NC contact 1): (z = 09, x = 0, 2,18)	
(x+1)+, (x+1)-)	_	Red	Continuous light	Different signal states at input x and x+1	
	_	-	_	No signal at input x and no signal at input x+1	
				NC contact / NO contact ¹⁾ : (z = 09, x = 0, 2,18)	
	-	Red	Continuous light	Same signal states at input x and x+1	
	_	_	_	No signal at input x and no signal at input x+1	
	LED	LED			
	х	x+1		NC contact / NC contact ¹⁾ : $(z = 09, x = 0, 2,18)$	
	Green	Green	Continuous light	One signal at input x and one signal at input x+1	
				NC contact / NO contact ¹⁾ : (z = 09, x = 0, 2,18)	
	Green	Green	Continuous light	One signal at input x and no signal at input x+1	_
p10040 (7 p10040 (7	M54F) = 0 M54F) = 1): Input x+1 : Input x+1	can be set individ is an NC contact is NO contact. =) = 0 for all input		
Single digi	tal inputs,	not fail-safe	•		
DI x	_		Off	No signal at digital input x (x = 2023)	_
	Green		Continuous light	Signal at digital input x	_
Fail-safe d	igital outpu	uts with ass	ociated readback	channel	
F_DO y (0+3+, 03-)	+3+, light			Output y (y=0 3) carries a signal	_
			F_DO y (y = 03 ends on the type) at test stop. of external circuit.	
DI 2y	_		Off	One of the two output lines y+ or y- or both lines of output y carry a signal	_
	Green		Continuous light	Both output lines y+ and y- carry no signal	-

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.8.6 Dimension drawing




Figure 3-32 Dimension drawing of Terminal Module TM54F, all data in mm and (inches)


3.8.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail



- Mounting slide
- 2 Mounting rail

Figure 3-33 Removal of a component from a DIN rail

3.8.8 Protective conductor connection and shield support

It is always advisable to shield the digital input and output wiring.

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-34 Shield support and protective conductor connection

/!\DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.8.9 Technical data

Table 3- 63 Technical data

6SL3055-0AA00-3BAx	Unit	Value
Current requirement (X524 at 24 V DC) without DRIVE-CLiQ supply	mA	160
Current requirement (X514 at 24 V DC) without digital outputs and sensor power supply	mA	38
Sensor power supply with and without forced dormant error detection (L1+, L2+, L3+)		
Voltage	V	24
Max. load current per output	Α	0.5
 cable length for the 24 V power supply: For longer cable lengths, the "Weidmüller Type No. PU DS 24 16A" surge protector must be used. 	m	< 30
 Fail-safe digital inputs (F-DI) (with electrical isolation) 		10
 Fail-safe digital outputs (F-DO) (with electrical isolation) 		4
 Standard digital inputs (with electrical isolation) 		4
Fail-safe digital inputs (F-DI) and standard digital inputs		
Voltage	V	0 to 30
Low-level (an open digital input is interpreted as "low")	V	-3 to +5
High level	V	15 to 30
Current consumption (at 24 V DC)	mA	>2
• Input delay 1)		00 (400 11)
- for "0" to "1" - for "1" to "0"	μs μs	approx. 30 (100 Hz) approx. 60 (100 Hz)
Fail-safe digital outputs (F-DO), continuous short-circuit proof		
Voltage	V	24
Max. load current per digital output	Α	0.5
Output delay 1)		
-for "0" to "1"	μs	300
- for "1" to "0"	μs	350
Power loss	W	4.5 at 24 V
PE/ground connection		On enclosure with M4 screw
Weight	kg	approx. 0.9

¹⁾ Pure hardware delay

3.9 Terminal Module TM120

3.9.1 Description

The Terminal Module TM120 is a DRIVE-CLiQ component for safe electrically isolated temperature evaluation. It can be used for 1FN, 1FW6, and third-party motors in which the temperature sensors cannot be installed with safe electrical separation. The TM120 is installed in the control cabinet and can be snapped on to a DIN rail (EN 60715).

When a TM120 is being used, temperature evaluation and encoder evaluation functions are separated off from one another. The TM120 can detect the motor temperature via 4 channels with different temperature sensors. Encoder evaluation functions are performed via Sensor Modules (e.g. SMCxx, SMExx). This means that, when connected to a Sensor Module SMCxx, the TM120 represents a control cabinet alternative to the SME120/SME125.

The TM120 contains the following interfaces:

Table 3- 64 Overview of the TM120 interfaces

Туре	Quantity
DRIVE-CLiQ interfaces	2
Temperature sensor inputs	4

3.9.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

/ CAUTION

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

NOTICE

If sensors other than those specified are connected, this may result in incorrect measured values.

3.9.3 Interface description

3.9.3.1 Overview




Figure 3-35 Interface overview TM120

3.9.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 65 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
1 A	4	Reserved, do not use	
A B	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ34plus	socket	·

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) order number: 6SL3066-4CA00-0AA0

NOTICE

The maximum DRIVE-CLiQ cable length is 100 m.

3.9.3.3 X521 temperature sensor input

Table 3- 66 X521 temperature sensor input

	Terminal	Function	Technical specifications
	1	- Temp	Temperature sensor connection KTY84-1C130/PTC/
	2	+ Temp	bimetallic switch with NC contact In linear motor applications, connect the KTY84-1C130 motor temperature sensor here
	3	- Temp	Temperature sensor connection KTY84-1C130/PTC/
	4	+ Temp	bimetallic switch with NC contact In linear motor applications, connect the PTC triple element 1 or bimetallic switch here
	5	- Temp	Temperature sensor connection KTY84-1C130/PTC/
	6	+ Temp	bimetallic switch with NC contact In linear motor applications, connect the PTC triple element 2 here
	7	- Temp	Temperature sensor connection KTY84-1C130/PTC/
	8	+ Temp	bimetallic switch with NC contact In linear motor applications, connect the PTC triple element 3 here

Max. connectable cross-section: 6 mm²

Type: Spring-loaded terminal 5 (see Appendix A)

measuring current via temperature sensor connection: 2 mA

NOTICE

When connecting several temperature sensors, the individual sensors must be separately connected to "+ Temp" and "- Temp".

It is not permissible that the "+ Temp" and "- Temp" signals are interconnected with one another!

The table below shows the preferable assignment of the connecting terminal for the temperature sensor input:

3.9 Terminal Module TM120

Table 3- 67 Preferable assignment, X521 temperature sensor input

	Signal name	Meaning				
Terminal	1FW6	1FN3 (2x1FN3)	1FN1	Segment motor 4 segments		
1	KTY N	KTY N	KTY N	1 PTC 120°C	KTY, negative pole	
2	KTY P	KTY P	KTY P	1 PTC 120°C	KTY, positive pole	
3	PTC 130°C	PTC 120°C	Bimetallic switch with NC contact	2_PTC 120°C	PTC triple element 1 or bimetallic switch with NC	
4	PTC 130°C	PTC 120°C	Bimetallic switch with NC contact	2_PTC 120°C	contact	
5	PTC 150 °C	(2_KTY_N)		3_PTC 120°C	PTC triple element 2	
6	PTC 150 °C	(2_KTY_P)		3_PTC 120°C		
7		(2 PTC 120°C)		4 PTC 120°C	PTC triple element 3	
8		(2 PTC 120°C)		4 PTC 120°C		

The interconnection given is a suggestion (software default setting). Which temperature sensor is connected to which input can be freely configured.

NOTICE

The maximum length of the temperature sensor cable is 100 m. The cables must be shielded.

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

Note

A 6FX7008-1BCx1 power cable is recommended for connecting the KTY temperature sensors.

3.9.3.4 X524 electronics power supply

Table 3- 68 X524 electronics power supply

	Terminal	Designation	Technical specifications		
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)		
+		Electronics power supply	Current consumption (max./typ.): 0.5 A/0.1 A		
	М	Electronics ground	May gurrent via jumper in connectors 20 A		
	M	Electronics ground	Max. current via jumper in connector: 20 A		
	able cross-secti erminal 2 (see /				

The maximum cable length that can be connected is 10 m.

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node.

3.9.4 Connection examples

Each TM120 is directly connected to an encoder evaluation unit (SMCxx or SMExx) by looping the corresponding DRIVE-CLiQ channel via the TM120. This ensures that encoders are automatically assigned to the temperature signals and, consequently, to the correct axis. The assignment can also be performed manually.




Figure 3-36 Connection example of TM120




Figure 3-37 Connection example of TM120 with Motor Module and SMC20 (encoder evaluation)

3.9.5 Meaning of the LED

Table 3- 69 Meaning of the LEDs on the Terminal Module TM120

LED	Color	Status	Description, cause	Remedy
	-	Off	Electronics power supply is missing or outside permissible tolerance range.	Check power supply
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-
DEADY	Orange	Continuous light	DRIVE-CLiQ communication is being established.	-
READY	Red	·		Remedy and acknowledge fault
	Green/ Flashing light 0.5 Hz		Firmware is being downloaded.	-
		Flashing light 2 Hz	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
Green/ orange or red/ orange		Flashing light 2 Hz	Detection of the components via LED is activated (p0154). Note: Both options depend on the LED status when module recognition is activated via p0154 = 1.	-

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.9.6 Dimension drawing




Figure 3-38 Dimension drawing of Terminal Module TM120, all data in mm and (inches)


3.9.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail




- Mounting slide
- 2 Mounting rail

Figure 3-39 Removal of a TM120 from a DIN rail

3.9.8 Protective conductor connection and shield support

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-40 Shield support and protective conductor connection of the TM120

/!\danger

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.9 Terminal Module TM120

3.9.9 Technical data

Table 3- 70 Technical data

6SL3055-0AA00-3KAx	Unit	Value	
Electronics power supply Voltage Current (without DRIVE-CLiQ) Power loss	V _{DC} A _{DC} W	24 DC (20.4 – 28.8) 0.20/0.1 (typ.) 2.4 (typ.)	
PE/ground connection	At the housing with	M4/1.8 Nm screw	
Weight	kg	0.41	
Degree of protection	IP20	IP20	

NOTICE

In order to guarantee the degree of protection, all of the plug connectors must be correctly screwed into place and appropriately locked.

3.10 Terminal Module TM150

3.10.1 Description

The terminal module TM150 is a DRIVE-CLiQ component for temperature evaluation. The temperature is measured in a temperature range from -99 °C to +250 °C for the following temperature sensors:

- PT100 (with monitoring for wire breakage and short-circuit)
- PT1000 (with monitoring for wire breakage and short-circuit)
- KTY84 (with monitoring for wire breakage and short-circuit)
- PTC (with short-circuit monitoring)
- Bimetallic NC contact (without monitoring)

For the temperature sensor inputs, for each terminal block the evaluation can be parameterized for 1x2-wire,

2x2-wire, 3-wire or 4-wire. There is no galvanic isolation in the TM150.

The TM150 is mounted in the control cabinet and can be snapped on to a standard mounting rail (EN 60715).

The TM150 contains the following interfaces:

Table 3- 71 Overview of the TM150 interfaces

Туре	Quantity
DRIVE-CLiQ interfaces	2
Temperature sensor inputs	6/12
Electronics power supply	1

3.10.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

3.10.3 Interface description

3.10.3.1 Overview




Figure 3-41 Interface overview of Terminal Module TM150

3.10.3.2 X500/X501 DRIVE-CLiQ interfaces

Table 3- 72 X500/X501 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
R R	2	TXN	Transmit data -
	3	RXP	Receive data +
1 A	4	Reserved, do not use	
A	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply, max. 450 mA
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pcs) order number: 6SL3066-4CA00-0AA0

NOTICE	
The maximum DRIVE-CLiQ cable length is 100 m.	

3.10.3.3 X524 electronics power supply

Table 3-73 X524 electronics power supply

	Terminal	Designation	Technical specifications	
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)	
	+	Electronics power supply	Current consumption (max./typ.): 0.5 A/0.1 A	
	М	Electronics ground	May augrent via jumper in connector, 20 A	
	M	Electronics ground	Max. current via jumper in connector: 20 A	
Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)				

The maximum cable length that can be connected is 10 m.

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ node.

3.10 Terminal Module TM150

3.10.3.4 X531-X536 temperature sensor inputs

Table 3- 74 X531-X536 temperature sensor inputs

	Terminal	Function 1x2- / 2x2-wire	Function 3 and 4-wire	Technical specifications
	1	+ Temp (channel x)	+ (channel x)	Temperature sensor connection for sensors with 1x2 wires
				Connection of the 2nd measurement cable for sensors with 4-wires
	2	- Temp (channel x)	- (channel x)	Temperature sensor connection for sensors with 1x2 wires
				Connection of the 1st measurement cable for sensors with 3 and 4-wires.
	3	+ Temp (channel y)	+ I _c (constant current, positive channel x)	Temperature sensor connection for sensors with 2x2, 3 and 4-wires
	4	- Temp (channel y)	- I _c (constant current, negative channel x)	

Max. connectable cross-section: 1.5 mm²

Type: Spring-loaded terminal 3_1 (see Appendix A)

measuring current via temperature sensor connection: approx. 0.83 mA

When connecting temperature sensors with 3 wires, a jumper must be inserted between X53x.2 and X53x.4.

Table 3- 75 Channel assignment

Terminal	Channel number [x] for 1x2, 3 and 4-wires	Channel number [y] for 2x2 wires
X531	0	6
X532	1	7
X533	2	8
X534	3	9
X535	4	10
X536	5	11

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

NOTICE

When connecting several temperature sensors, the individual sensors must be separately connected to "+ Temp" and "- Temp".

It is not permissible to jumper the "+ Temp" and "- Temp" signals between the individual terminal blocks!

NOTICE

Cable length and cross section

Cable length and cross section might influence the temperature measurement (10 Ω cable resistance for a PT100, can falsify the measurement result by 10 %). For cable lengths > 100 m, cables with a cross-section of \geq 1 mm² must be used.

The maximum cable length is 300 m.

/ CAUTION

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

3.10.4 Connection examples




Figure 3-42 Connecting a PT100/PT1000 with 2x2, 3 and 4-wires to the temperature sensor inputs X53x of Terminal Module TM150

3.10 Terminal Module TM150




Figure 3-43 Connection example for a Terminal Module TM150

3.10.5 Meaning of the LED

Table 3- 76 Meaning of the LEDs on the Terminal Module TM150

LED	Color	Status	Description, cause	Remedy
	-	Off	Electronics power supply is missing or outside the permissible tolerance range.	Check power supply
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	-
DEADY	Orange	Continuous light	DRIVE-CLiQ communication is being established.	-
READY	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
Green/ 0.5 Hz Red flashing light		flashing	Firmware is being downloaded.	-
		flashing	Firmware has been downloaded. Wait for POWER ON.	Carry out a POWER ON
orange or flashing or State St		Detection of the components via LED is activated (p0154). Note: Both options depend on the LED status when module recognition is activated via p0154 = 1.	-	

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.10.6 Dimension drawing




Figure 3-44 Dimension drawing of Terminal Module TM150, all data in mm and (inches)


3.10.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail




- Mounting slide
- 2 Mounting rail

Figure 3-45 Removing a TM150 from a mounting rail

3.10.8 Protective conductor connection and shield support

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-46 Shield support and protective conductor connection of the TM150

DANGER

If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.10.9 Technical data

Table 3- 77 Technical data

6SL3055-0AA00-3LA0	Unit	Value
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ)	A _{DC}	0.07
Power loss	W	1.6
PE/ground connection	At the housing with	M4/1.8 Nm screw
Weight	kg	0.4
Degree of protection	IP20	

NOTICE

In order to guarantee the degree of protection, all of the connectors must be correctly screwed into place and appropriately locked.

3.11 DRIVE-CLiQ Hub Module DMC20

3.11.1 Description

The DRIVE-CLiQ DMC20 Hub Module is used to implement star-shaped distribution of a DRIVE-CLiQ line. With the DMC20, an axis grouping can be expanded with 5 DRIVE-CLiQ sockets for additional subgroups.

The component is especially suitable for applications which require DRIVE-CLiQ nodes to be removed in groups, without interrupting the DRIVE-CLiQ line and, therefore, the data exchange process.

3.11.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

3.11.3 Interface description

3.11.3.1 Overview




Figure 3-47 Interface overview of the DMC20

3.11.3.2 X500 - X505 DRIVE-CLiQ interfaces

Table 3-78 X500-X505 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
□ B	3	RXP	Receive data +
8 B B A	4	Reserved, do not use	
	5	Reserved, do not use	
A	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used to establish connections. The maximum length of MOTION-CONNECT 500 is 100 m and for MOTION-CONNECT 800PLUS cables, 75 m.

3.11.3.3 X524 electronics power supply

Table 3-79 X524 electronics power supply

	Terminal	Designation	Technical specifications			
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)			
	+	Electronics power supply	Current consumption: Max. 0.5 A			
	M	Electronics ground				
	М	Electronics ground	Max. current via jumper in connector: 20 A			
-1						
Max. connectable cross-section: 2.5 mm ²						
Type: Screw te	Гуре: Screw terminal 2 (see Appendix A)					

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

The current consumption increases by the value for the DRIVE-CLiQ participants.

3.11.4 Meaning of the LED

Table 3-80 Description of the LEDs on the DRIVE-CLiQ Hub Module DMC20

LED	Color	Status	Description, cause	Remedy
READY	OY - Off Electronics power supply is missing or outside the permissible tolerance range.		· · · · · · · · · · · · · · · · · · ·	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.		Remedy and acknowledge fault
	Green/red	0.5 Hz flashing light	Firmware is being downloaded.	_
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange or Red/	Flashing light	Component recognition via LED is activated (p0154). Note: Both options depend on the LED status when component recognition is activated via p0154 = 1.	-
	orange			

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.11.5 Dimension drawing




Figure 3-48 Dimension drawing of the DRIVE-CLiQ Hub Module DMC20, all data in mm and (inches)


3.11.6 Installation

Installation

- 1. Tilt the component backwards slightly and attach it to the DIN rail using the hook.
- 2. Push the component towards the DIN rail until you hear the mounting slide at the rear latch into position.
- 3. You can now move the component to the left or right along the DIN rail, until it reaches its final position.

Removal

- 1. The lug on the mounting slide first needs to be pushed down to unlock the slide from the DIN rail.
- 2. The component can now be tilted forwards and pulled up and off the DIN rail.




- Mounting slide
- 2 Mounting rail

Figure 3-49 Removal of a component from a DIN rail

3.11.7 Protective conductor connection and shield support

The following diagram shows a typical Weidmüller shield connection clamp for the shield supports.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-50 Shield support and protective conductor connection



If the shielding procedures described and the permissible cable lengths are not observed, the machine may malfunction.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.11.8 Technical data

Table 3-81 Technical data of the DMC20

6SL3055-0AA00-6AAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ node)	Apc	0.15
PE/ground connection	At the housing with M4/1.8 Nm screw	
Weight	kg	0.8

3.12 DRIVE-CLiQ Hub Module External DME20

3.12.1 Description

The DRIVE-CLiQ Hub Module External DME20 is used to implement star-shaped distribution of a DRIVE-CLiQ line. With the DME20, an axis grouping can be expanded with 5 DRIVE-CLiQ sockets for additional subgroups.

The component has degree of protection IP67 and is especially suitable for applications which require DRIVE-CLiQ nodes to be removed in groups, without interrupting the DRIVE-CLiQ line and therefore the data exchange.

3.12.2 Safety information

NOTICE

In order to guarantee degree of protection IP67, all of the plug connectors must be correctly screwed into place and appropriately locked.

NOTICE

The unused DRIVE-CLiQ interfaces must be closed using a protective cap that is included in the scope of delivery.

Note

All components operated on the DRIVE-CLiQ must be integrated into the equipotential bonding concept.

They should preferably be connected by installing them on bright machine parts and devices, which are all bonded to one another in an equipotential manner.

Alternatively, equipotential bonding can be achieved by means of a conductor (min. 6 mm²), which should be routed parallel to the DRIVE-CLiQ where possible. This applies to all distributed DRIVE-CLiQ nodes such as DM20, SME2x, SM12x, etc. For the DME20, this also applies to the 24 V power supply.

3.12.3 Interface description

3.12.3.1 Overview




Figure 3-51 Interface overview of the DME20

3.12.3.2 X500-X505 DRIVE-CLiQ interfaces

Table 3- 82 X500-X505 DRIVE-CLiQ interfaces

	Pin	Signal name	Technical specifications	
	1	TXP	Transmit data +	
	2	TXN	Transmit data -	
R R	3	RXP	Receive data +	
8 B B A	4	Reserved, do not use		
	5	Reserved, do not use		
A	6	RXN	Receive data -	
	7	Reserved, do not use		
	8	Reserved, do not use		
	Α	+ (24 V)	Power supply	
	В	M (0 V)	Electronics ground	
Connector type	RJ45 socket	·		

The blanking covers for the DRIVE-CLiQ interfaces are included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used to establish connections. The maximum length of MOTION-CONNECT 500 is 100 m and for MOTION-CONNECT 800PLUS cables, 75 m.

3.12.3.3 X524 electronics power supply

Table 3-83 X524 electronics power supply

	Pin	Designation	Technical specifications
	1	Electronics power supply	The connection voltage of 20.4 V – 28.8 V refers
2	2	Electronics power supply	to the (terminal) voltage at the DME20. This
3 5 1	3	Electronics ground	must be taken into account when selecting the cable cross-section and supply cable lengths.
	4	Electronics ground	Pins 1 and 2: jumpered internally
6	5	not connected	Pins 3 and 4: jumpered internally
5-pin socket,			

max. connectable cross-section: 4 x 0.75 mm²

Note

The maximum cable length for the P24 supply of the DME20 is 100 m.

In case no UL-compliant design is required, is the use of the following cables and connectors from Siemens is recommended:

Pre-assembled cables

Connecting cable for power supply with M12 plug and M12 socket,

A-coded, 4-pin,

order number: 6XV1801-5D..

Cables to be assembled by the user

Cable	Connector
24 V DC cable,	M12 plug connector,
2-wire, 2 x 0.75 mm ² ,	4-pin, A-coded,
order number: 6XV1812-8A	order number: 6GK1907-0DC10-6AA3

Table 3-84 Cable length P24 supply cable

connected	1	2	3	4	5
loads 1)					
Cross section					
0.34 mm²	75 m	45 m	30 m	25 m	20 m
2 x 0.34 mm²	100 m	90 m	65 m	50 m	40 m
0.75 mm²	100 m	100 m	75 m	60 m	50 m
2 x 0.75 mm²	100 m				
T ₀ = 55 °C	•	•	•	•	•

100 m DRIVE-CLiQ

¹⁾ Connected motors with DRIVE-CLiQ encoder, DRIVE CLiQ mounted encoder SME

3.12.4 Dimension drawing





Figure 3-52 Dimension drawing of the DRIVE-CLiQ Hub Module External DME20, all data in mm and (inches)

3.12.5 Installation



Contact surface

Figure 3-53 Mounting dimensions DME20

Installation

- 1. Transfer the drilling pattern to the contact surface the contact surfaces must be bare unpainted metal.
- 2. Holes Ø5.3 or threads M5
- 3. Tighten with a tightening torque of 6.0 Nm.

3.12.6 Technical data

Table 3- 85 Technical data of the DME20

6SL3055-0AA00-6ABx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ node)	A _{DC}	0.15
PE/ground connection	Fastened to housing M5 / 6 Nm	
Degree of protection	IP67	
Weight	kg	0.8

3.12 DRIVE-CLiQ Hub Module External DME20

3.12.7 Specifications for use with UL approval

Pre-assembled cables

Sensor/actuator cable, 5-pin, variable cable, free cable end at straight socket M12-SPEEDCON, cable length: 2, 5, 10, 15 m SAC-5P-xxx-186/FS SCO Up to 100 m on request

Phoenix Contact

Cables to be assembled by the user

Cable	Connector
Cable coil, black PUR/PVC, 5-pin Conductor colors: brown/white/blue/black/gray Cable length: 100 m	Sensor/actuator connector, socket, straight, 5-pin, M12, A-coded Screw connection, metal knurl,
SAC-5P-100.0-186/0.75 Order number: 1535590	cable gland Pg9 SACC-M12FS-5CON-PG9-M Order number: 1681486
Phoenix Contact	9.44.

Power supply

The DME20 must be connected to a 24 V power supply with voltage limitation.

- SITOP 6EP1x.. or 6ES7307..
- SINAMICS Control Supply Module 6SL3100-1DE22-0Axx

Pin assignment of the cable

Table 3- 86 Connection to X524 electronics power supply

	Pin	Designation	Technical specifications
	1 (brown) 1)	Electronics power supply	The connection voltage of 20.4 V – 28.8 V refers to
6	2 (white) 1)	Electronics power supply	the (terminal) voltage at the DME20. This must be
	3 (black) 1)	Electronics ground	taken into account when selecting the cable cross- section and supply cable lengths.
4 0	4 (blue) 1)	Electronics ground	Pins 1 and 2: jumpered internally
	5 (gray) 1)	Not connected internally	Pins 3 and 4: jumpered internally

¹⁾ The colors stated refer to the cable specified above

3.13 Voltage Sensing Module VSM10

3.13.1 Description

The Voltage Sensing Module VSM10 is a voltage sensing module that is used to sense the actual value for Active Line Modules and Smart Line Modules from 16 kW and upwards. The Voltage Sensing Module is used to sense the three-phase line supply voltage upstream of the line reactor, which is then provided to the corresponding infeed control ¹⁾.

For booksize units, these components can be optionally used to increase the degree of ruggedness against irregularities in the line supply.

In addition to the voltage sensing, a temperature sensor can be connector to the VSM10 to thermally monitor the line reactor. Further, the functionality of the line filter can checked using two analog inputs.

The VSM10 can be used with firmware version 2.4 or higher.

1) The infeed control is a firmware function that is required for the open-loop and closed-loop control, monitoring, and communication of an infeed.

Table 3-87 Interface overview of the VSM10

Туре	Quantity
Analog inputs	2
Line supply voltage connections (690 V)	3
Line supply voltage connections (100 V)	3
Temperature sensor input	1

3.13.2 Safety information



Cooling clearances

The cooling clearances of 50 mm above and below the components must be observed.



Temperature sensor cables

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

CAUTION

Output voltage measurement

When using long motor cables, it is not permissible that the output voltage of the Motor Module is directly measured at the motor. If this is not observed, the Voltage Sensing Module could be destroyed as a result of the high voltage load across the insulating clearance.

NOTICE

The VSM10 has two terminal strips to sense the three-phase line supply voltage (X521 and X522). The voltage strength of terminal X521 is a maximum of 100 V (phase-to-phase) and is used for voltage sensing via a potential transformer. A maximum voltage to be sensed of up to 690 V (phase-to-phase) can be directly connected to terminal X522. Only one of the two terminals X521 and X522 may be used. Nothing may be connected to the unused terminal.

3.13.3 Interface description

3.13.3.1 Overview




Figure 3-54 Interface overview of the VSM10

3.13.3.2 X500 DRIVE-CLiQ interface

Table 3-88 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
1 A	4	Reserved, do not use	
A B	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45plus socket	·	

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

3.13.3.3 X520 analog inputs/temperature sensor

Table 3-89 Terminal block X520

	Terminal	Designation	Technical specifications
1 Al 0+ 2 Al 0-	1	AI 0+	2 analog differential inputs +/- 10V to monitor the line filter
	AI 0-	resonance	
	3	AI 1+	Resolution: 12 bits
ω ω l	4	AI 1-	
4	5	+ Temp	Temperature sensor KTY84-1C130 / PTC
5	6	- Temp	
6			

Max. connectable cross-section: 1.5 mm² Type: Screw terminal 1 (see Appendix A)

Note

In order to minimize noise emission, shielded cables should be used.

CAUTION

The common mode range may not be violated. This means that the analog differential voltage signals can have a maximum offset voltage of +/-30 V with respect to the ground potential. If the range is infringed, incorrect results may occur during analog/digital conversion.

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats.

Note

The maximum cable length for a shielded cable – connected at both ends – to the temperature sensor and to the analog inputs is 30 m.



Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp".

If these instructions are not complied with, there is a risk of electric shock!

3.13 Voltage Sensing Module VSM10

3.13.3.4 X521 three-phase line supply voltage sensing up to 100 V (phase-to-phase)

This interface is not relevant for booksize units.

3.13.3.5 X522 three-phase line supply voltage sensing up to 690 V 3-ph. AC

Table 3-90 X522 line-voltage sensing submodule 690 V

	Terminal	Designation	Technical specifications		
	1	Phase voltage U	Directly connected to sense the line supply		
2 3	2	Phase voltage V	voltage		
	3	Phase voltage W			
May compatable areas patient Carrel					

Max. connectable cross-section: 6 mm² Type: Screw terminal 5 (see Appendix A)

NOTICE

Only one of the two terminals X521 and X522 may be used. Nothing may be connected to the unused terminal.

NOTICE

The line phases must be connected to the VSM10 with the same sequence as that of the Line Module. If this is not observed, when the Line Module is enabled, overcurrents can occur.

NOTICE

If the configuration has a line filter, then the phase voltages for the VSM (X522) must be taken from in front of the line filter. If the configuration does not have a line filter, then X522 must be connected to the line side of the line reactor (voltages are taken from in front of the line reactor).

3.13.3.6 X524 electronics power supply

Table 3- 91 X524 electronics power supply

	Terminal	Designation	Technical specifications		
	+	Electronics power supply	Voltage: 24 V DC (20.4 V – 28.8 V)		
	+	Electronics power supply	Current consumption: max. 0.2 A		
	М	Electronics ground	May aurrent via iumner in connector; 20 A		
 	М	Electronics ground	Max. current via jumper in connector: 20 A		
Max. connectable cross-section: 2.5 mm² Type: Screw terminal 3 (see Appendix A)					

The maximum cable length that can be connected is 10 m.

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

3.13.4 Connection example




Figure 3-55 Connection example, VSM10

- 1) It is only possible to omit the fuses if the cables to the Voltage Sensing Module are laid according to EN 60439-1 so that no short-circuit or ground fault can be expected under normal operating conditions (short-circuit-proof installation).
- 2) The line supply voltage is tapped as an actual value for the Voltage Sensing Module VSM10 in accordance with the system design; for examples see the table.

Table 3- 92 Suggestions for terminals and cable lugs which can be used to connect a VSM10 to the line

Conductor cross-section	VSM connection	Example components
Up to 6 mm ²	Direct connection possible	Smart Line Modules 5 kW and 10 kW
6 mm ² to 16 mm ²	ST16-TWIN terminal blocks, if required with a reducing comb and ST4-TWIN or ST2.5-TWIN Phoenix Contact	Active Line Modules 16 kW Smart Line Modules 16 kW Active Interface Module 16 kW
16 mm² to 50 mm²	AGK10 UKH tap-off terminals with UKH terminals Phoenix Contact	Active Line Modules 36 kW and 55 kW Smart Line Modules 36 kW and 55 kW Active Interface Module 36 kW and 55 kW
> 50 mm ²	Ring cable lug DIN 46234-8-2.5	Components with M8 connection bolt
	Intermediate high-current connector, type UHV (Phoenix Contact) and ring cable lug DIN 46234-8-2.5	Active Line Modules 55 kW, 80 kW, and 120 kW Active Interface Module 80 kW and 120 kW

3.13.5 Meaning of the LED

Table 3- 93 Meanings of the LEDs on the Voltage Sensing Module VSM10

LED	Color	Status	Description, cause	Remedy
READY	-	OFF	Electronics power supply is missing or outside the permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/red	0.5 Hz flashing light	Firmware is being downloaded.	_
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0144). Note: Both options depend on the LED status when component recognition is activated via p0144 = 1.	_

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

3.13.6 Dimension drawing




Figure 3-56 Dimension drawing of the Voltage Sensing Module VSM10, all data in mm and (inches)

3.13.7 Protective conductor connection and shield support

The following shield connection clamps can be used on the bottom part of the component housing for shield connection of the analog inputs:

Shield connection clamp		Order number
Phoenix Contact	SK8	3025163
Phoenix Contact	SK14	3025176
Phoenix Contact	SK20	3025189
Weidmüller	KLBÜ CO1	1753311001

The following pictures show the shield contacts with a shield connection clamp from Weidmüller.



- 1 Protective conductor connection M4/1.8 Nm
- Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 3-57 Shield support and protective conductor connection at the VSM10

/ DANGER

If the shielding procedures described and the specified cable lengths are not observed, the machine may not operate properly.

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

3.13.8 Technical data

Table 3- 94 Technical data

6SL3053-0AA00-3AAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without DRIVE-CLiQ or digital outputs)	A _{DC}	0.3
Power loss	W	<10
PE/ground connection	At the housing v	with M4/1.8 Nm screw
Weight	kg	1
Degree of protection		IP20

3.13 Voltage Sensing Module VSM10

Encoder system connection

4.1 Introduction

The encoder system should be connected to SINAMICS S120 via DRIVE-CLiQ.

Motors with DRIVE-CLiQ interfaces (e.g. synchronous motors 1FK7 and 1FT6, and induction motors 1PH7) are designed for this purpose. These motors simplify commissioning and diagnostics because the motor and encoder type are identified automatically.

Motors and external encoders without DRIVE-CLiQ interface

Motors without DRIVE-CLiQ interfaces, as well as external encoders, must be connected via Sensor Modules to enable the encoder and temperature signals to be evaluated. Sensor Modules Cabinet-Mounted (SMC) are available for installation in control cabinets and Sensor Modules External (SME) for installation outside control cabinets.

If not otherwise specified, only one encoder system can be connected to each Sensor Module.

Motors and external encoders with DRIVE-CLiQ interface

Motors with DRIVE-CLiQ interfaces can be connected to the associated Motor Module directly via the MOTION-CONNECT DRIVE-CLiQ cables available. The connection of the MOTION-CONNECT DRIVE-CLiQ cable at the motor has degree of protection IP67.

The DRIVE-CLiQ interface supplies the motor encoder via the integrated 24 VDC supply and transfers the motor encoder and temperature signals and the electronic rating plate data, e.g. a unique identification number, rated data (voltage, current, torque, etc.) directly to the Control Unit. Different encoder cable are therefore no longer required for the various encoder types, e.g. resolvers or absolute encoders. Wiring can be effected throughout with a MOTION-CONNECT DRIVE-CLiQ cable.

DRIVE-CLiQ encoder

The DRIVE-CLiQ encoder is an absolute encoder with integrated DRIVE-CLiQ interface (see the section titled "DRIVE-CLiQ encoder").

NOTICE

The encoder cables to Siemens motors may only disconnected and connected when the system is in a no-voltage condition.

For direct measuring systems (third-party encoders), ask the manufacturer whether it is permissible to disconnected/connect under voltage.

4.2 Overview of Sensor Modules

Sensor Modules Cabinet-Mounted (SMC)

Sensor Modules Cabinet-Mounted SMC10, SMC20 and SMC30 can be ordered and configured separately. They are used when a motor with a DRIVE-CLiQ interface is not available or when external encoders in addition to the motor encoder are required. Only one encoder system can be connected to each Sensor Module Cabinet-Mounted. The SMCs evaluate these measuring systems and convert the calculated values to DRIVE-CLiQ. Neither motor nor encoder data are saved.

Note

The SMC supplies the power to the encoder; the SMC, however, must be provided separately with 24 VDC power.




Figure 4-1 Overview of Sensor Modules Cabinet-Mounted (SMC)

Sensor Modules External (SME)

The Sensor Modules External SME20, SME25, SME120, and SME125 are only intended for use on machines (in North America, in accordance with the NFPA 79 "Electrical Standard for Industrial Machinery") and may only be connected to the DRIVE-CLiQ interfaces of the components.

Direct encoder systems outside the cabinet can be connected to the Sensor Modules External. The SMEs evaluate these encoder systems and convert the calculated values to DRIVE-CLiQ. No motor or encoder data is stored in the SMEs.

Note

The SME provides the encoder power supply. The power supply for the SME is provided from the connected DRIVE-CLiQ cable. This must be taken into consideration when the DRIVE-CLiQ cable is selected.

The Sensor Modules External have a higher degree of protection (IP67) and are therefore suitable for installation outside the cabinet.




Figure 4-2 Overview of Sensor Modules External (SME)

4.2 Overview of Sensor Modules

Connectable encoder systems

Table 4-1 Overview of the connectable encoder systems

		SMC			;	SME	
Encoder systems	SMC10	SMC20	SMC30	SME20	SME25	SME120	SME125
Resolver	Yes	-	-	-	-	-	-
Incremental encoder sin/cos (1 Vpp) with/without reference signal	-	Yes	-	Yes	-	Yes	-
Absolute encoder EnDat 2.1	-	Yes	-	-	Yes	-	Yes
Incremental encoder TTL / HTL	-	-	Yes	-	-	-	-
Absolute encoder SSI	-	Yes 1)	Yes 2)	-	Yes 1)	-	Yes 1)
Temperature evaluation	Yes	Yes	Yes	Yes 3)	-	Yes (electricall y isolated)	Yes (electricall y isolated)

¹⁾ Only possible for SSI encoders with 5 V supply

²⁾ Possible for SSI encoders with 5 V or 24 V supply

³⁾ With prescribed adapter cable 6FX8002-2CA88

4.3 Sensor Module Cabinet-Mounted SMC10

4.3.1 Description

The Sensor Module Cabinet-Mounted SMC10 evaluates encoder signals and transmits the speed, actual position value, rotor position and, if necessary, the motor temperature via DRIVE-CLiQ to the Control Unit.

The SMC10 is used to evaluate sensor signals from resolvers.

4.3.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

NOTICE

Only one encoder system may be connected per Sensor Module.

Note

There must be no electrical connection between the encoder system housing and the signal cables, or the encoder system electronics. If this is not carefully observed, under certain circumstances the system will not be able to reach the required interference immunity level (there is then a danger of equalization currents flowing through the electronics ground).

/ CAUTION

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

4.3 Sensor Module Cabinet-Mounted SMC10

4.3.3 Interface description

4.3.3.1 Overview




Figure 4-3 Interface overview for the SMC10

4.3.3.2 X500 DRIVE-CLiQ interface

Table 4-2 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications	
	1	TXP	Transmit data +	
	2	TXN	Transmit data -	
	3	RXP	Receive data +	
1 A	4	Reserved, do not use		
A B	5	Reserved, do not use		
	6	RXN	Receive data -	
	7	Reserved, do not use		
	8	Reserved, do not use		
	Α	Reserved, do not use		
	В	M (0 V)	Electronics ground	
Connector type	RJ45 sock	et	·	·

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

4.3.3.3 X520 encoder system interface

Table 4-3 X520 encoder system interface

	Pin	Signal name	Technical specifications
	1	Reserved, do not use	
	2	Reserved, do not use	
	3	S2	Resolver signal A (sin+)
25	4	S4	Inverted resolver signal A (sin-)
• :	5	Ground	Ground (for internal shield)
	6	S1	Resolver signal B (cos+)
••	7	S3	Inverted resolver signal B (cos-)
	8	Ground	Ground (for internal shield)
	9	R1	Resolver excitation positive
• •	10	Reserved, do not use	
:•	11	R2	Resolver excitation negative
[••]	12	Reserved, do not use	
	13	+ Temp	Motor temperature measurement KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130 / PTC
	14	Reserved, do not use	
	15	Reserved, do not use	
	16	Reserved, do not use	
	17	Reserved, do not use	
	18	Reserved, do not use	
	19	Reserved, do not use	
	20	Reserved, do not use	
	21	Reserved, do not use	
	22	Reserved, do not use	
	23	Reserved, do not use	
	24	Ground	Ground (for internal shield)
	25	- Temp	Motor temperature measurement KTY84-1C130 (KTY-) Temperature sensor KTY84-1C130 / PTC
Connector type:	25-pin SUE	B D connector	
Measuring currer	nt via tempera	ature sensor connection: 2 mA	

NOTICE

The KTY temperature sensor must be connected with the correct polarity If the sensor is connected with the incorrect polarity, it cannot detect if a motor overheats.



Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

4.3.3.4 X524 electronics power supply

Table 4-4 X524 electronics power supply

	Terminal	Function	Technical specifications
	+	Electronics power supply	Voltage: 24 V (20.4 V – 28.8 V)
	+	Electronics power supply	Current consumption: Max. 0.35 A
	М	Electronics ground	Maximum current via jumper in connector: 20 A
\[\]	М	Electronics ground	
Mary	l-1	U2	

Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix)

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

4.3.4 Connection example




Figure 4-4 Connection of an encoder system via a Sensor Module Cabinet-Mounted (SMC) for a motor without a DRIVE-CLiQ interface

4.3.5 Meaning of the LED

Table 4-5 Meaning of LEDs on the Sensor Module Cabinet-Mounted SMC10

LED	Color	Status	Description, cause	Remedy
RDY READY	-	Off	Electronics power supply is missing or outside permissible tolerance range.	-
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/re d	Flashing light 0.5 Hz	Firmware is being downloaded.	_
		Flashing light 2 Hz	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/or ange or Red/oran ge	Flashing light	Component recognition via LED is activated (p0144). Note: Both options depend on the LED status when component recognition is activated via p0144 = 1.	_

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

4.3.6 Dimension drawing




Figure 4-5 Dimension drawing of the Sensor Module Cabinet SMC10, all dimensions in mm and (inches)


4.3.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail



- Mounting slide
- 2 Mounting rail

Figure 4-6 Removal of a component from a DIN rail

4.3.8 Technical data

Table 4- 6 Technical data

6SL3055-0AA00-5AAx	Unit	Value
Electronics power supply Voltage Current (without encoder system) Current (with encoder system) Power loss	VDC ADC ADC W	24 DC (20.4 – 28.8) ≤ 0.20 ≤ 0.35 ≤ 10
Specification Transformation ratio of the resolver (ü) Excitation voltage on the SMC10 when ü=0.5 Amplitude monitoring threshold (secondary tracks) of the SMC10	V _{rms}	0.5 4.1 1
Excitation voltage (cannot be parameterized)	V _{rms}	4.1
Excitation frequency (synchronized to the current controller clock cycle)	kHz	5 to 16
PE/ground connection		At the housing with M4/1.8 Nm screw
Max. encoder cable length	m	130
Weight	kg	0.45
Degree of protection		IP20 or IPXXB

Table 4-7 Max. frequency that can be evaluated (speed)

Resolver		Max. speed resolver / motor		
Number of poles	Number of pole pairs	8 kHz/125 µsec	4 kHz/250 μsec	2 kHz/500 μsec
2-pole	1	120000 rpm	60000 rpm	30000 rpm
4-pole	2	60000 rpm	30000 rpm	15000 rpm
6-pole	3	40000 rpm	20000 rpm	10000 rpm
8-pole	4	30000 rpm	15000 rpm	7500 rpm

The ratio between the ohmic resistance R and the inductance L (the primary winding of the resolver) determines whether the resolver can be evaluated with the SMC10. See the following diagram:




Figure 4-7 Connectable impedances with an excitation frequency f = 5000 Hz

4.4 Sensor Module Cabinet-Mounted SMC20

4.4.1 Description

The Sensor Module Cabinet-Mounted SMC20 evaluates encoder signals and transmits the speed, actual position value, rotor position and, if necessary, the motor temperature and reference point via DRIVE-CLiQ to the Control Unit.

The SMC20 is used to evaluate encoder signals from incremental encoders with SIN/COS (1 Vpp) or absolute encoders with EnDat 2.1 or SSI.

4.4.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

NOTICE

Only one encoder system may be connected per Sensor Module.

Note

There must be no electrical connection between the encoder system housing and the signal cables, or the encoder system electronics. If this is not carefully observed, under certain circumstances the system will not be able to reach the required interference immunity level (there is then a danger of equalization currents flowing through the electronics ground).



Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

4.4.3 Interface description

4.4.3.1 Overview




Figure 4-8 Interface description of the SMC20

4.4 Sensor Module Cabinet-Mounted SMC20

4.4.3.2 X500 DRIVE-CLiQ interface

Table 4-8 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
8 B	3	RXP	Receive data +
1 A	4	Reserved, do not use	
A A	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	Reserved, do not use	
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

4.4.3.3 X520 encoder system interface

Table 4-9 X520 encoder system interface

	Pin	Signal name	Technical specifications
	1	P encoder	Encoder power supply
	2	M encoder	Ground for encoder power supply
	3	А	Incremental signal A
25	4	A*	Inverse incremental signal A
• :	5	Ground	Ground (for internal shield)
	6	В	Incremental signal B
••	7	B*	Inverse incremental signal B
• •	8	Ground	Ground (for internal shield)
: :	9	Reserved, do not use	
• •	10	Clock	Clock, EnDat interface, SSI clock
:•	11	Reserved, do not use	
	12	Clock*	Inverted clock, EnDat interface, inverted SSI clock
	13	+Temp	Motor temperature measurement KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130 / PTC
	14	P sense	Sense input encoder power supply
	15	Data	Data, EnDat interface, SSI data
	16	M sense	Ground sense input encoder power supply
	17	R	Reference signal R
	18	R*	Inverse reference signal R
	19	С	Absolute track signal C
	20	C*	Inverse absolute track signal C
	21	D	Absolute track signal D
	22	D*	Inverse absolute track signal D
	23	Data*	Inverse data, EnDat interface, Inverse SSI data
	24	Ground	Ground (for internal shield)
	25	-Temp	Motor temperature measurement KTY84-1C130 (KTY-) Temperature sensor KTY84-1C130 / PTC
Connector type:	25-pin SU	JB D connector	
Measuring curre	ent via tempe	erature sensor connection: 2 mA	

NOTICE

The KTY temperature sensor must be connected with the correct polarity If the sensor is connected with the incorrect polarity, it cannot detect if a motor overheats.

4.4 Sensor Module Cabinet-Mounted SMC20

DANGER

Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

4.4.3.4 X524 electronics power supply

Table 4- 10 X524 electronics power supply

	Terminal	Function	Technical specifications
	+	Electronics power supply	Voltage: 24 V (20.4 V – 28.8 V)
+	+	Electronics power supply	Current consumption: Max. 0.35 A
	М	Electronics ground	Maximum current via jumper in connector: 20 A
	М	Electronics ground	

Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

4.4.4 Connection example




Figure 4-9 Connection of an encoder system via a Sensor Module Cabinet-Mounted (SMC) for a motor without a DRIVE-CLiQ interface

4.4.5 Meaning of the LED

Table 4- 11 Meaning of LEDs on the Sensor Module Cabinet-Mounted SMC20

LED	Color	Status	Description, cause	Remedy
RDY READY	-	Off	Electronics power supply is missing or outside the permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/red	0.5 Hz flashing light	Firmware is being downloaded.	-
		2 Hz flashing light	Firmware download is complete. Wait for POWER ON	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0144). Note: Both options depend on the LED status when component recognition is activated via p0144 = 1.	-

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

4.4.6 Dimension drawing




Figure 4-10 Dimension drawing of the Sensor Module Cabinet SMC20, all data in mm and (inches)


4.4.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail



- Mounting slide
- ② Mounting rail

Figure 4-11 Removal of a component from a DIN rail

4.4.8 Technical data

Table 4- 12 Technical data

6SL3055-0AA00-5BAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A _{DC}	≤ 0.20
Current (with encoder system)	ADC	≤ 0.35
Power loss	W	≤ 10
Encoder system power supply		
Voltage	Vencoder	5 V DC (with Remote Sense) 1)
Current	Aencoder	0.35
Encoder frequency that can be evaluated	kHz	≤ 500
(f _{encoder})		
SSI baud rate ²⁾	kHz	100 - 250
Max. encoder cable length	m	100
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0.45
Degree of protection		IP20 or IPXXB

A controller compares the encoder system supply voltage - sensed via the Remote Sense cables - with the reference supply voltage of the encoder system, and adjusts the supply voltage for the encoder system at the output of the sensor module until the required supply voltage is obtained directly at the encoder system (only for 5 V encoder system power supply).

2) Only possible for SSI encoders with 5 V supply

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μ s, an SMC20 with order number 6SL3055-0AA00-5BA3 must be used.

4.5 Sensor Module Cabinet-Mounted SMC30

4.5.1 Description

The Sensor Module Cabinet-Mounted SMC30 evaluates encoder signals and transmits the speed, actual position value and, if necessary, the motor temperature and reference point via DRIVE-CLiQ to the Control Unit.

The SMC30 is used to evaluate encoder signals from encoders with TTL, HTL, or SSI interfaces.

A combination of TTL/HTL signal and SSI absolute signal is possible at terminals X521/X531, if both signals are derived from the same measured variable.

4.5.2 Safety information



The ventilation spaces of 50 mm above and below the component must be observed.

NOTICE

Only one encoder system may be connected per Sensor Module.

Note

There must be no electrical connection between the encoder system housing and the signal cables, or the encoder system electronics. If this is not carefully observed, under certain circumstances the system will not be able to reach the required interference immunity level (there is then a danger of equalization currents flowing through the electronics ground).

CAUTION

When the encoder system is connected via terminals, make sure that the cable shield is connected to the component.



Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the ground potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

4.5.3 Interface description

4.5.3.1 Overview




Figure 4-12 Interface description of the SMC30

4.5 Sensor Module Cabinet-Mounted SMC30

4.5.3.2 X500 DRIVE-CLiQ interface

Table 4- 13 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications	
	1	TXP	Transmit data +	
	2	TXN	Transmit data -	
	3	RXP	Receive data +	
	4	Reserved, do not use		
L A	5	Reserved, do not use		
	6	RXN	Receive data -	
	7	Reserved, do not use		
	8	Reserved, do not use		
	Α	Reserved, do not use		
	В	M (0 V)	Electronics ground	
Connector type	RJ45 socket			

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

4.5.3.3 X520 encoder system interface

Table 4- 14 X520 encoder system interface

	Pin	Signal name	Technical specifications		
	1	+Temp	Motor temperature sensing KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130/PTC/ bimetallic switch with NC contact		
	2	Clock	SSI clock		
15 0	3	Clock*	Inverse SSI clock		
	4	P encoder 5 V / 24 V	Encoder power supply		
	5	P encoder 5 V / 24 V			
	6	P sense	Sense input encoder power supply		
	7	M encoder (M)	Ground for encoder power supply		
	8	- Temp	Motor temperature sensing KTY84-1C130 (KTY-) Temperature sensor KTY84-1C130/PTC/ bimetallic switch with NC contact		
	9	M sense	Ground sense input		
	10	R	Reference signal R		
	11	R*	Inverse reference signal R		
	12	B*	Inverse incremental signal B		
	13	В	Incremental signal B		
	14	A* / data*	Inverted incremental signal A/inverted SSI data		
	15	A / data	Incremental signal A/SSI data		
Connector type:	15-pin Sub-D socket				
Measuring curren	nt via temperatur	re sensor connection: 2 mA			

CAUTION

The encoder supply can be parameterized to 5 V or 24 V. The sensor may be destroyed if you enter the wrong parameters.

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

Information for parameterizing the KTY temperature sensor can be found in the SINAMICS S120 Function Manual (FH1) in Chapter "Monitoring and protective functions/thermal motor monitoring".

4.5 Sensor Module Cabinet-Mounted SMC30

DANGER

Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

4.5.3.4 X521 / X531 alternative encoder system interface

Table 4- 15 X521 / X531 alternative encoder system interface

	Pin	Designation	Technical specifications
X521	1	А	Incremental signal A
	2	A*	Inverse incremental signal A
	3	В	Incremental signal B
3	4	B*	Inverse incremental signal B
4	5	R	Reference signal R
5	6	R*	Inverse reference signal R
6	7	CTRL	Control signal
7	8	M	Ground
8			
	1	P_Encoder 5 V / 24 V	Encoder power supply
	2	M_Encoder	Ground for encoder power supply
X531	3	-Temp	Motor temperature sensing KTY84-1C130 (KTY-) Temperature sensor KTY84-1C130/PTC/ bimetallic switch with NC contact
2 3 4	4	+Temp	Motor temperature sensing KTY84-1C130 (KTY+) Temperature sensor KTY84-1C130/PTC/ bimetallic switch with NC contact
5	5	Clock	SSI clock
6	6	Clock*	Inverse SSI clock
7	7	Data	SSI data
8	8	Data*	Inverse SSI data

Max. connectable cross-section: 1.5 mm²

Measuring current via the temperature sensor connection: 2 mA

When unipolar HTL encoders are used, A*, B*, and R* on the terminal block must be jumpered with M_Encoder (X531)1).

¹⁾ Because the physical transmission media is more robust, the bipolar connection should always be used. The unipolar connection should only be used if the encoder type does not output push-pull signals.

CAUTION

When the encoder system is connected via terminals, make sure that the cable shield is connected to the component. Refer to the Chapter "Electrical connection".

Temperature sensor

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats

Information for parameterizing the KTY temperature sensor can be found in the SINAMICS S120 Function Manual (FH1) in Chapter "Monitoring and protective functions/thermal motor monitoring".

NOTICE

The maximum length of the temperature sensor cable is 100 m. The cables must be shielded.



Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

4.5 Sensor Module Cabinet-Mounted SMC30

4.5.3.5 X524 electronics power supply

Table 4- 16 X524 electronics power supply

	Terminal	Function	Technical specifications				
	+	Electronics power supply	Voltage: 24 V (20.4 V – 28.8 V)				
	+	Electronics power supply	Current consumption: max. 0.55 A				
	М	Electronics ground	Max. current via jumper in connector: 20 A				
 I I I I I I I I I 	М	Electronics ground					
Max. connecta	Max. connectable cross-section: 2.5 mm²						

Max. connectable cross-section: 2.5 mm² Type: Screw terminal 2 (see Appendix A)

Note

The two "+" or "M" terminals are jumpered in the connector. This ensures that the supply voltage is looped through.

4.5.4 Connection examples

Connection example 1: HTL encoder, bipolar, with reference signal




Figure 4-13 Connection example 1: HTL encoder, bipolar, with reference signal

Signal cables must be twisted in pairs in order to improve noise immunity against induced noise.

Connection example 2: HTL encoder, unipolar, with reference signal




Figure 4-14 Connection example 2: HTL encoder, unipolar, with reference signal¹⁾

¹⁾ Because the physical transmission media is more robust, the bipolar connection should always be used. The unipolar connection should only be used if the encoder type does not output push-pull signals.

4.5 Sensor Module Cabinet-Mounted SMC30



Figure 4-15 Photo of connection example 2: SMC30, 30 mm wide

Note: Diagram of the wire jumpers to connect unipolar HTL encoders with reference signal

4.5.5 Meaning of LEDs

Table 4- 17 Meaning of LEDs on the Sensor Module Cabinet SMC30

LED	Color	Status	Description, cause	Remedy
RDY READY	-	Off	Electronics power supply is missing or outside permissible tolerance range.	_
	Green	Continuous light	The component is ready for operation and cyclic DRIVE-CLiQ communication is taking place.	_
	Orange	Continuous light	DRIVE-CLiQ communication is being established.	_
	Red	Continuous light	At least one fault is present in this component. Note: The LED is activated regardless of whether the corresponding messages have been reconfigured.	Remedy and acknowledge fault
	Green/ red	Flashing 0.5 Hz	Firmware is being downloaded.	_
	Green/ red	Flashing 2 Hz	Firmware download is complete. Wait for POWER ON.	Carry out a POWER ON
	Green/ orange or Red/ orange	Flashing light	Component recognition via LED is activated (p0144). Note: Both options depend on the LED status when component recognition is activated via p0144 = 1.	_
OUT > 5 V	-	Off	Electronics power supply is missing or outside permissible tolerance range. Power supply ≤ 5 V.	_
	Orange	Continuous light	Electronics power supply for encoder system available. Power supply > 5 V. Important: Make sure that the connected encoder can be operated with a 24 V power supply. If an encoder that is designed for a 5 V supply is operated with a 24 V supply, this can destroy the encoder electronics.	_

Cause and rectification of faults

The following documents contain information about the cause of faults and how they can be rectified:

SINAMICS S120 Commissioning Manual (IH1)

SINAMICS S120/S150, List Manual (LH1)

4.5.6 Dimension drawing




Figure 4-16 Dimension drawing of the Sensor Module Cabinet SMC30, all data in mm and (inches)


4.5.7 Installation

Installation

- 1. Slightly tilt the component backwards and attach it to the mounting rail using the hook.
- 2. Swivel the component on the mounting rail until the mounting slide at the rear audibly latches
- 3. Shift the components on the mounting rail to the left or right until they reach their final position

Removal

- 1. First shift the mounting slide downwards at the lug to release the interlocking with the mounting rail
- 2. Swivel the component towards the front and then remove it upwards from the mounting rail




- Mounting slide
- ② Mounting rail

Figure 4-17 Removal of a component from a DIN rail

4.5.8 Protective conductor connection and shield support

Shield contacts are only required if the system is connected to X521/X531.



- 1 Protective conductor connection M4/1.8 Nm
- ② Shield connection terminal, Weidmüller company, type: KLBÜ CO1, order number: 1753311001

Figure 4-18 Shield support and protective conductor connection

The bending radii of the cables must be taken into account (see MOTION-CONNECT description).

NOTICE

Only use screws with a permissible insertion depth of 4 - 6 mm.

4.5.9 Technical data

Table 4- 18 Technical data

6SL3055-0AA00-5CA2	Unit	Value
Electronics power supply Voltage Current (without encoder system) Current (with encoder system)	V _{DC} A _{DC} A _{DC}	24 DC (20.4 – 28.8) ≤ 0.20 ≤ 0.55
Power loss Encoder system power supply Voltage Current	Vencoder Aencoder	≤ 10 5 VDC (with or without Remote Sense) ¹) or V _{DC} - 1 V 0.35
Encoder frequency that can be evaluated (fencoder)	kHz	≤ 300
SSI baud rate	kHz	100 - 250
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight		0.45
Degree of protection		IP20 or IPXXB

A controller compares the encoder system supply voltage - sensed via the Remote Sense cables - with the reference supply voltage of the encoder system, and adjusts the supply voltage for the encoder system at the output of the sensor module until the required supply voltage is obtained directly at the encoder system (only for 5 V encoder system power supply). Remote Sense only to X520.

4.5 Sensor Module Cabinet-Mounted SMC30

Table 4- 19 Specification of encoder systems that can be connected

Parameter	Designation	Threshold	Min.	Max.	Unit
High signal level (TTL bipolar at X520 or X521/X531) ¹⁾	U _{Hdiff}		2	5	V
Low signal level (TTL bipolar at X520 or X521/X531) ¹⁾	U _{Ldiff}		-5	-2	V
Signal level high	U _H 3)	High	17	Vcc	V
(HTL unipolar)		Low	10	Vcc	V
Signal level low	U _L 3)	High	0	7	V
(HTL unipolar)		Low	0	2	V
High signal level (HTL bipolar) ²⁾	U _{Hdiff}		3	Vcc	V
Low signal level (HTL bipolar) ²⁾	U _{Ldiff}		-Vcc	-3	V
High signal level (SSI bipolar at X520 or X521/X531) ¹⁾	U _{Hdiff}		2	5	V
Low signal level (SSI bipolar at X520 or X521/X531) ¹⁾	U _{Ldiff}		-5	-2	V
Signal frequency	f _S		-	300	kHz
Edge clearance	t _{min}		100	-	ns
"Zero pulse inactive time" (before and after A=B=high)	tLo		640	(t _{ALo-BHi} - t _{Hi})/2 ⁴⁾	ns
"Zero pulse active time" (while A=B=high and beyond) 5)	t _{Hi}		640	talo-BHi - 2*tlo 4)	ns

- 1) Other signal levels according to the RS 422 standard.
- 2) The absolute level of the individual signals varies between 0 V and VCC of the encoder system.
- 3) Only with order number 6SL3055-0AA00-5CA2 and firmware version 2.5 SP1 or higher can this value be configured using software. For older firmware releases and Order Nos. less than 6SL3055-0AA00-5CA2 then the "low" threshold applies.
- 4) t_{ALo-BHi} is not a specified value, but is the time between the falling edge of track A and the next but one rising edge of track B
- 5) Further information on setting the "Zero pulse active time" can be found in the manual: SINAMICS S120, Function Manual, tolerant encoder monitoring for SMC30

Table 4- 20 Encoders that can be connected

	X520 (SUB-D)	X521 (terminal)	X531 (terminal)	Track monitoring	Remote Sense ²⁾
HTL bipolar 24 V	Yes	Yes		Yes	No
HTL unipolar 24 V ¹⁾	Yes	Yes (however, a bipolar connection is recommended) 1)		No	No
TTL bipolar 24 V	Yes	Yes		Yes	No
TTL bipolar 5 V	Yes	Yes		Yes	To X520
SSI 24 V/5 V	Yes	Yes		No	No
TTL unipolar		No			

- 1) Because the physical transmission media is more robust, the bipolar connection should always be used. The unipolar connection should only be used if the encoder type does not output push-pull signals.
- 2) A controller compares the encoder system supply voltage sensed via the Remote Sense cables with the reference supply voltage of the encoder system, and adjusts the supply voltage for the encoder system at the output of the sensor module until the required supply voltage is obtained directly at the encoder system (only for 5 V encoder system power supply).

Table 4-21 Maximum encoder cable length

Encoder type	Maximum encoder cable length in m	
TTL ¹⁾	100	
HTL unipolar ²⁾	100	
HTL bipolar	300	
SSI	100	

- 1) For TTL encoders at X520 \rightarrow Remote Sense \rightarrow 100 m
- 2) Because the physical transmission properties are more robust, the bipolar connection should always be used. The unipolar connection should only be used if the encoder type does not output push-pull signals.

For encoders with a 5 V supply at X521/X531, the cable lengths depend on the encoder current (for 0.5 mm² cable cross-sections):




Figure 4-19 Max. cable length as a function of the encoder current drawn

For encoders without Remote Sense the permissible cable length is restricted to 100 m (reason: the voltage drop depends on the cable length and the encoder current).




Figure 4-20 Signal characteristic of track A and track B between two edges: Time between two edges with pulse encoders




Figure 4-21 Position of the zero pulse to the track signals

4.6 Sensor Module External SME20

4.6.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME20. The SME20 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

Incremental direct encoder systems with SIN/COS (1 Vpp) and reference signal can be connected.

It is possible to connect a motor with a 17-pole circular connector for the encoder to the 12-pole circular connector of the SME20 using adapter cable 6FX 8002-2CA88-xxxx.

- KTY/PTC temperature sensors can be used for evaluation of the motor temperature.
- The Sensor Module is only suitable for motors without absolute track signals (C/D track):
 - Induction motors (e.g. 1PH)
 - Synchronous motors with pole position identification (e.g. 1FN, 1FW, 1FE)

Neither motor nor encoder data are saved in the SME20.

4.6.2 Safety Information

CAUTION

Connecting cables to temperature sensors must always be installed with shielding. The cable shield must be connected to the chassis potential at both ends over a large surface area. Temperature sensor cables that are routed together with the motor cable must be twisted in pairs and shielded separately.

4.6.3 Interface description

4.6.3.1 Overview




Figure 4-22 Interface description SME20

4.6 Sensor Module External SME20

4.6.3.2 DRIVE-CLiQ interface

Table 4- 22 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications	
	1	TXP	Transmit data +	
	2	TXN	Transmit data -	
8 B	3	RXP	Receive data +	
	4	Reserved, do not use		
A	5	Reserved, do not use		
	6	RXN	Receive data -	
	7	Reserved, do not use		
	8	Reserved, do not use		
	Α	+ (24 V)	Power supply	
	В	M (0 V)	Electronics ground	
Connector type	RJ45 socket			
Current consumption	max. 0.25 A			

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.

4.6.3.3 Encoder system interface

Table 4-23 Encoder system interface SME20

	Pin	Signal name	Technical specifications	
	1	B*	Inverse incremental signal B	
	2	P5	Encoder power supply	
	3	R	Reference signal R	
	4	R*	Inverse reference signal R	
8 9 1	5	Α	Incremental signal A	
7 12 10 2	6	A*	Inverse incremental signal A	
60 11 03	7	-Temp ¹⁾	Temperature sensor connection ²⁾ KTY84-1C130 or PTC	
5 4	8	В	Incremental signal B	
	9	+Temp 1)	Temperature sensor connection ²⁾ KTY84-1C130 or PTC	
	10	M	Ground for encoder power supply	
	11	M	Ground for encoder power supply	
	12	P5	Encoder power supply	
Connector kit:	12-pin, order number: 6FX2003-0SA12			

Measuring current via temperature sensor connection: 2 mA

Blanking cover for encoder system interface: Pöppelmann GmbH & Co. KG, Lohne,

Order No.: GPN 300 F211

1) These connections do not have protective separation!

2) Connection cable: Order number 6FX8002-2CA88-xxxx

NOTICE

The KTY temperature sensor must be connected with the correct polarity. A sensor connected up with the incorrect polarity cannot detect if the motor overheats



Risk of electric shock!

Only temperature sensors that meet the safety isolation specifications contained in EN 61800-5-1 may be connected to terminals "+Temp" and "-Temp". If safe electrical separation cannot be guaranteed (for linear motors or third-party motors, for example), a Sensor Module External (SME120 or SME125) or Terminal Module TM120 must be used.

If these instructions are not complied with, there is a risk of electric shock!

4.6 Sensor Module External SME20

4.6.4 Connection example




Figure 4-23 Connection of a direct encoder system via a Sensor Module External (SME)

4.6.5 Dimension drawing





Figure 4-24 Dimension drawing of the Sensor Module External SME20, all data in mm and (inches)

4.6.6 Installation



Contact surface

Figure 4-25 Drilling pattern for installing the SME20/SME25

Installation

- 1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
- 2. Drill two holes with \emptyset 5.3 or M5 threaded holes according to the drilling pattern.
- 3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

4.6 Sensor Module External SME20

4.6.7 Technical data

Table 4- 24 Technical data

6SL3055-0AA00-5EAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A _{DC}	≤ 0.15
Current (with encoder system)	ADC	≤ 0.25
Power loss	W	≤ 4
Encoder system power supply		
Voltage	Vencoder	5 VDC
Current	Aencoder	0.35
Encoder frequency that can be evaluated	kHz	≤ 500
(fencoder)		
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0.31
Degree of protection		IP67

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μ s, an SME20 with order number 6SL3055-0AA00-5EA3 must be used.

The maximum cable length for the encoder system interface depends on the current consumption of the encoder system and the cross-section of the wire in the cable. However, the maximum length is 10 m. The figure below applies to encoder systems that operate in the supply voltage range between 4.75 V and 5.25 V. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply plus 0.14 mm² Remote Sense wires) and 0.64 mm² (0.5 mm² supply plus 0.14 mm² Remote Sense wires).




Figure 4-26 Max. cable length as a function of the current drawn by the encoder system

Besides the encoder systems for the supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for the extended range down to 3.6 V. These are generally operable using encoder system cables up to 10 m in length, provided that the total cross-section of the supply plus Remote Sense wires does not fall below 0.14 mm².

4.7 Sensor Module External SME25

4.7.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME25. The SME25 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

Direct encoder systems with EnDat 2.1 or SSI with SIN/COS (1 Vpp) incremental signals can be connected, however without reference signal.

Neither motor nor encoder data are saved in the SME25.

4.7.2 Interface description

4.7.2.1 Overview




Figure 4-27 Interface description SME25

4.7.2.2 DRIVE-CLiQ interface

Table 4- 25 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
A A	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		
Current consumption	max. 0.25 A		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.

4.7.2.3 Encoder system interface

Table 4- 26 Encoder system interface SME25

	Pin	Signal name	Technical specifications		
	1	P5	Encoder power supply		
	2	Reserved, do not use			
	3	Reserved, do not use			
	4	M	Ground for encoder power supply		
	5	Reserved, do not use			
	6	Reserved, do not use			
	7	P5	Encoder power supply		
20 12 10 3 13 0 16 9	8	Clock	Clock, EnDat interface, SSI clock		
4 14 15 8 5 0 7	9	Clock*	Inverted clock, EnDat interface, inverted SSI clock		
5 6 7	10	M	Ground for encoder power supply		
	11	Housing potential			
	12	В	Incremental signal B		
	13	B*	Inverse incremental signal B		
	14	Data	Data, EnDat interface, SSI data		
	15	Α	Incremental signal A		
	16	A*	Inverse incremental signal A		
	17	Data*	Inverse data, EnDat interface, Inverse SSI data		
onnector kit:	17-pin, or	der number: 6FX2003-0SA17	17-pin, order number: 6FX2003-0SA17		

Order No.: GPN 300 F211

4.7.3 Connection example




Figure 4-28 Connection of a direct encoder system via a Sensor Module External (SME)

4.7.4 Dimension drawing





Figure 4-29 Dimension drawing of the Sensor Module External SME25, all data in mm and (inches)

4.7.5 Installation



Contact surface

Figure 4-30 Drilling pattern for installing the SME20/SME25

Installation

- 1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
- 2. Drill two holes with \emptyset 5.3 or M5 threaded holes according to the drilling pattern.
- 3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

4.7 Sensor Module External SME25

4.7.6 Technical data

Table 4- 27 Technical data

6SL3055-0AA00-5HAx	Unit	Value
Electronics power supply Voltage Current (without encoder system) Current (with encoder system) Power loss	V _{DC} A _{DC} A _{DC} W	24 DC (20.4 – 28.8) ≤ 0.15 ≤ 0.25 ≤ 4
Encoder system power supply Voltage Current	Vencoder Aencoder	5 VDC 0.35
Encoder frequency that can be evaluated (fencoder)	kHz	≤ 500
SSI/EnDat 2.1 baud rate	kHz	100
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0,31
Degree of protection		IP67

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μs , an SME25 with order number 6SL3055-0AA00-5HA3 must be used.

The maximum cable length for the encoder system interface depends on the current consumption of the encoder system and the cross-section of the wire in the cable. However, the maximum length is 10 m. The figure below applies to encoder systems that operate in the supply voltage range between 4.75 V and 5.25 V. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply plus 0.14 mm² Remote Sense wires) and 0.64 mm² (0.5 mm² supply plus 0.14 mm² Remote Sense wires).




Figure 4-31 Max. cable length as a function of the current drawn by the encoder system

Besides the encoder systems for the supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for the extended range down to 3.6 V. These are generally operable using encoder system cables up to 10 m in length, provided that the total cross-section of the supply plus Remote Sense wires does not fall below 0.14 mm².

4.8 Sensor Module External SME120

4.8.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME120. The SME120 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

The components are always used when the temperature signals of the motors do not have protective separation or where this separation is not possible for certain reasons. SME120 is mainly used in linear motor applications.

A Hall sensor box can be connected to determine the commutation position of a linear motor.

Incremental direct encoder systems with SIN/COS (1 Vpp) and reference signal can be connected.

Neither motor nor encoder data are saved in the SME120.

4.8.2 Safety information

Sensor Module External SME120 is a device of safety class I.

NOTICE

Only encoder systems in which the power supply for the encoder system is not grounded may be connected.

/!\DANGER

All of the work must be carried out by qualified, appropriately trained personnel. Prior to commencing any work on the Sensor Module External the 5 safety rules have to be observed:

- · Disconnect the system.
- Protect against reconnection.
- · Make sure that the equipment is de-energized.
- Ground and short circuit.
- Cover or enclose adjacent components that are still live.

Never disable protective functions and devices even for trial operation.

It is mandatory that a protective conductor with a minimum cross-section of 2.5 mm² is connected in order to guarantee safe electrical separation.

In order to ensure the degree of protection, all connections, even connections that are not used, must be closed with connectors or suitable sealing caps.

The specified torques must be observed.

The plastic covers of connections X100, X200, and X500 do not comply with the degree of protection and must be replaced by the corresponding connectors prior to commissioning.

It is not permitted to open up the devices! This may result in the units no longer being adequately sealed! Repair and maintenance work may only be performed by a SIEMENS service center.

The unit should not be put into operation if it is evident that the packaging has been damaged by water.

4.8.3 Interface description

4.8.3.1 Overview




Figure 4-32 Interface description, SME120

4.8.3.2 X100 encoder system interface

Table 4- 28 X100 encoder system interface

	Pin	Signal name	Technical specifications
8 9 1 7 12 10 0 ² 6 11 0 ₃ 5 4	1	B*	Inverse incremental signal B
	2	P5	Encoder power supply
	3	R	Reference signal R
	4	R*	Inverse reference signal R
	5	Α	Incremental signal A
	6	A*	Inverse incremental signal A
	7	Reserved, do not use	
	8	В	Incremental signal B
	9	Reserved, do not use	
	10	M	Ground for encoder power supply
	11	M	Ground for encoder power supply
	12	P5	Encoder power supply
onnector kit:	12-pin, order number: 6FX2003-0SA12		

Control Units and additional system components Manual, (GH1), 01/2012, 6SL3097-4AH00-0BP2

4.8.3.3 X200 thermistor sensor input

Table 4- 29 X200 thermistor sensor input

	Pin	Function	Technical specifications
	1	-Temp	Temperature sensor connection KTY84-1C130/PTC/bimetallic
	2	+Temp	switch with NC contact In linear and torque motor applications, connect the KTY84- 1C130 motor temperature sensor here
	3	+Temp	Temperature sensor connection KTY84-1C130/PTC/bimetallic
	4	-Temp	switch with NC contact In linear and torque motor applications, connect the PTC triple element 1 or bimetallic switch here
	5	+Temp	Temperature sensor connection KTY84-1C130/PTC/bimetallic
	6	-Temp	switch with NC contact In torque motor applications, connect the PTC triple element 2 here
Connector kit:	6+1 pin, order number: 6FX2003-0SU07		
Measuring current via temperature sensor connection: 2 mA			

NOTICE

When connecting several temperature sensors, the individual sensors must be separately connected to "+ Temp" and "- Temp".

It is not permissible that the "+ Temp" and "- Temp" signals are interconnected with one another!

4.8.3.4 X300 Hall sensor input

Table 4- 30 X300 Hall sensor input

	Pin	Signal name	Technical specifications
	1	С	Absolute track signal C
	2	C*	Inverse absolute track signal C
2 O O 1	3	P5	Encoder power supply
P 09 08	4	M	Ground for encoder power supply
	5	D	Absolute track signal D
0 0 07	6	D*	Inverse absolute track signal D
	7	Not assigned	
	8	not assigned	
	9	Ground	Ground (for internal shield)

4.8 Sensor Module External SME120

4.8.3.5 X500 DRIVE-CLiQ interface

Table 4- 31 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
Г В В	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		
Current consumption	max. 0.30 A		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.

4.8.4 Connection examples




Figure 4-33 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface and molded connecting cables with terminated cable ends

4.8 Sensor Module External SME120




Figure 4-34 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface and molded connecting cables with open cable ends




Figure 4-35 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface, with an integrated 2-hole terminal box

4.8 Sensor Module External SME120

Connection examples for motors connected in parallel




Figure 4-36 Connecting motor encoders via SME for torque motors connected in parallel without a DRIVE-CLiQ interface




Figure 4-37 Connecting motor encoders via SME for linear motors connected in parallel without a DRIVE-CLiQ interface

4.8.5 Dimension drawing





Figure 4-38 Dimension drawing of the Sensor Module External SME120, all data in mm and (inches)

4.8.6 Installation



Contact surface

Figure 4-39 Hole drilling pattern for installation

Installation

- 1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
- 2. Drill two holes with \emptyset 5.3 or M5 threaded holes according to the drilling pattern.
- 3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

4.8.7 Technical data

Table 4- 32 Technical data

6SL3055-0AA00-5JAx	Unit	Value
Electronics power supply		
Voltage	V _{DC}	24 DC (20.4 – 28.8)
Current (without encoder system)	A _{DC}	≤ 0.20
Current (with encoder system)	A _{DC}	≤ 0.30
Power loss	W	≤ 4.5
Encoder system power supply		
Voltage	Vencoder	5 VDC
Current	Aencoder	0.35
Encoder frequency that can be evaluated	kHz	≤ 500
(f _{encoder})		
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0.7
Degree of protection		IP67

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μ s, an SME120 with order number 6SL3055-0AA00-5JA3 must be used.

NOTICE

In order to guarantee the degree of protection, all of the plug connectors must be correctly screwed into place and appropriately locked.

4.8 Sensor Module External SME120

The maximum cable length for the encoder system interface depends on the current consumption of the encoder system and the cross-section of the wire in the cable. However, the maximum length is 10 m. The figure below applies to encoder systems that operate in the supply voltage range between 4.75 V and 5.25 V. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply plus 0.14 mm² Remote Sense wires) and 0.64 mm² (0.5 mm² supply plus 0.14 mm² Remote Sense wires).




Figure 4-40 Max. cable length as a function of the current drawn by the encoder system

Besides the encoder systems for the supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for the extended range down to 3.6 V. These are generally operable using encoder system cables up to 10 m in length, provided that the total cross-section of the supply plus Remote Sense wires does not fall below 0.14 mm².

4.9 Sensor Module External SME125

4.9.1 Description

Direct encoder systems outside the cabinet can be connected to the Sensor Module External SME125. The SME125 evaluates these encoder systems and converts the calculated values to DRIVE-CLiQ.

The components are always used when the temperature signals of the motors do not have protective separation or where this separation is not possible for certain reasons. SME125 is mainly used in linear motor applications.

Direct encoder systems with EnDat 2.1 or SSI with SIN/COS (1 Vpp) incremental signals can be connected, however without reference signal.

Neither motor nor encoder data are saved in the SME125.

4.9.2 Safety information

Sensor Module External SME125 is a device of safety class I.

NOTICE

Only encoder systems in which the power supply for the encoder system is not grounded may be connected.

4.9 Sensor Module External SME125

/!\DANGER

All of the work must be carried out by qualified, appropriately trained personnel. Prior to commencing any work on the Sensor Module External the 5 safety rules have to be observed:

- Disconnect the system.
- Protect against reconnection.
- Make sure that the equipment is de-energized.
- · Ground and short circuit.
- Cover or enclose adjacent components that are still live.

Never disable protective functions and devices even for trial operation.

It is mandatory that a protective conductor with a minimum cross-section of 2.5 mm² is connected in order to guarantee safe electrical separation.

In order to ensure the degree of protection, all connections, even connections that are not used, must be closed with connectors or suitable sealing caps.

The specified torques must be observed.

The plastic covers of connections X100, X200, and X500 do not comply with the degree of protection and must be replaced by the corresponding connectors prior to commissioning.

It is not permitted to open up the devices! This may result in the units no longer being adequately sealed! Repair and maintenance work may only be performed by a SIEMENS service center.

The unit should not be put into operation if it is evident that the packaging has been damaged by water.

Note

The safety information on the Sensor Module must be observed.

After the product has served its lifetime, the individual parts should be disposed of in compliance with local regulations.

4.9.3 Interface description

4.9.3.1 Overview




Figure 4-41 Interface description, SME125

4.9.3.2 X100 encoder system interface

Table 4- 33 X100 encoder system interface

	Pin	Signal name	Technical specifications
	1	P5	Encoder power supply
	2	Reserved, do not use	
	3	Reserved, do not use	
	4	M	Ground for encoder power supply
	5	Reserved, do not use	
1 11 10	6	Reserved, do not use	
$\begin{pmatrix} 3 & 13 & 0 & 16 & 9 \end{pmatrix}$	7	P5	Encoder power supply
	8	Clock	Clock, EnDat interface, SSI clock
4 14 15 08 5 0 7 7 8 7 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	9	Clock*	Inverted clock, EnDat interface, inverted SSI clock
	10	M	Ground for encoder power supply
	11	Housing potential	
	12	В	Incremental signal B
	13	B*	Inverse incremental signal B
	14	Data	Data, EnDat interface, SSI data
	15	A	Incremental signal A
	16	A*	Inverse incremental signal A
	17	Data*	Inverse data, EnDat interface, Inverse SSI data
Connector kit:	17-pin, or	der number: 6FX2003-0SA17	

Blanking plate for encoder system interface: Pöppelmann GmbH & Co. KG, Lohne,

Order No.: GPN 300 F211

4.9.3.3 X200 thermistor sensor input

Table 4- 34 X200 thermistor sensor input

	Pin	Function	Technical specifications
	1 -Temp Temperature sensor connection KTY84-1C130/l	Temperature sensor connection KTY84-1C130/PTC/bimetallic	
	2	+Temp	switch with NC contact In linear and torque motor applications, connect the KTY84- 1C130 motor temperature sensor here
	3	+Temp	Temperature sensor connection KTY84-1C130/PTC/bimetallic
	4	-Temp	switch with NC contact In linear and torque motor applications, connect the PTC triple element 1 or bimetallic switch here
	5	+Temp Temperature sensor connection KTY84-1C130/PTC/bim	
	6	-Temp	switch with NC contact In torque motor applications, connect the PTC triple element 2 here
Connector kit:	6+1 pin, order number: 6FX2003-0SU07		
Measuring current via temperature sensor connection: 2 mA			nA

NOTICE

When connecting several temperature sensors, the individual sensors must be separately connected to "+ Temp" and "- Temp".

It is not permissible that the "+ Temp" and "- Temp" signals are interconnected with one another!

4.9 Sensor Module External SME125

4.9.3.4 X500 DRIVE-CLiQ interface

Table 4- 35 X500 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
	2	TXN	Transmit data -
	3	RXP	Receive data +
8 S S S S S S S S S S S S S S S S S S S	4	Reserved, do not use	
A A	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	+ (24 V)	Power supply
	В	M (0 V)	Electronics ground
Connector type	RJ45 socket		
Current consumption	max. 0.30 A		

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

Note

Only MOTION-CONNECT DRIVE-CLiQ cables may be used for connections. The maximum cable length is 100 m for MOTION-CONNECT 500, and 75 m for MOTION-CONNECT 800PLUS cables.

4.9.4 Connection examples




Figure 4-42 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface and molded connecting cables with terminated cable ends

4.9 Sensor Module External SME125




Figure 4-43 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface and molded connecting cables with open cable ends




Figure 4-44 Connecting motor encoders via SME for motors without a DRIVE-CLiQ interface, with an integrated 2-hole terminal box

4.9 Sensor Module External SME125

Connection examples for motors connected in parallel




Figure 4-45 Connecting motor encoders via SME for torque motors connected in parallel without a DRIVE-CLiQ interface




Figure 4-46 Connecting motor encoders via SME for linear motors connected in parallel without a DRIVE-CLiQ interface

4.9.5 Dimension drawing





Figure 4-47 Dimension drawing of the Sensor Module External SME125, all data in mm and (inches)

4.9.6 Installation



Contact surface

Figure 4-48 Hole drilling pattern for installation

Installation

- 1. Place the drilling pattern on the mounting surface. Make sure that the contact surface is bare, unpainted metal.
- 2. Drill two holes with \emptyset 5.3 or M5 threaded holes according to the drilling pattern.
- 3. Fix the Sensor Module to the mounting surface. The tightening torque is 6 Nm.

4.9.7 Technical data

Table 4- 36 Technical data

6SL3055-0AA00-5KAx	Unit	Value
Electronics power supply Voltage Current (without encoder system) Current (with encoder system) Power loss	V _{DC} A _{DC} A _{DC} W	24 DC (20.4 – 28.8) ≤ 0.20 ≤ 0.30 ≤ 4.5
Encoder system power supply Voltage Current	Vencoder Aencoder	5 VDC 0.35
Encoder frequency that can be evaluated (fencoder)	kHz	≤ 500
SSI/EnDat 2.1 baud rate	kHz	100
PE/ground connection		At the housing with M4/1.8 Nm screw
Weight	kg	0.7
Degree of protection		IP67

Note

Current controller clock cycle

For a current controller clock cycle of 31.25 μs , an SME125 with order number 6SL3055-0AA00-5KA3 must be used.

NOTICE

In order to guarantee the degree of protection, all of the plug connectors must be correctly screwed into place and appropriately locked.

4.9 Sensor Module External SME125

The maximum cable length for the encoder system interface depends on the current consumption of the encoder system and the cross-section of the wire in the cable. However, the maximum length is 10 m. The figure below applies to encoder systems that operate in the supply voltage range between 4.75 V and 5.25 V. The sample parameters shown are 0.28 mm² cross-section (0.14 mm² supply plus 0.14 mm² Remote Sense wires) and 0.64 mm² (0.5 mm² supply plus 0.14 mm² Remote Sense wires).




Figure 4-49 Max. cable length as a function of the current drawn by the encoder system

Besides the encoder systems for the supply voltage range of 4.75 V to 5.25 V in the figure above, encoder systems are also available for the extended range down to 3.6 V. These are generally operable using encoder system cables up to 10 m in length, provided that the total cross-section of the supply plus Remote Sense wires does not fall below 0.14 mm².

4.10 DRIVE-CLiQ encoder

4.10.1 Description

The DRIVE-CLiQ encoder is available as an absolute encoder with integrated DRIVE-CLiQ interface. The multiturn design of the encoder senses absolute position values extending over 4096 revolutions. The singleturn design senses the absolute position within a revolution.

The most important advantages are:

- Automatic commissioning via DRIVE-CLiQ
- High operating temperatures of 100 °C are possible
- Integrated diagnostics concept

Table 4-37 Encoder for mounting with DRIVE-CLiQ

Designation	Order number	Description
DRIVE-CLiQ synchronous flange VW 6 mm	6FX2001-5FD13-0AAx	Absolute encoder with DRIVE-CLiQ, single-turn
DRIVE-CLiQ clamping flange VW 10 mm	6FX2001-5QD13-0AAx	Absolute encoder with DRIVE-CLiQ, single-turn
DRIVE-CLiQ hollow shaft 10 mm	6FX2001-5VD13-0AAx	Absolute encoder with DRIVE-CLiQ, single-turn
DRIVE-CLiQ hollow shaft 12 mm	6FX2001-5WD13-0AAx	Absolute encoder with DRIVE-CLiQ, single-turn
DRIVE-CLiQ synchronous flange VW 6 mm	6FX2001-5FD25-0AAx	Absolute encoder with DRIVE-CLiQ, multiturn
DRIVE-CLiQ clamping flange VW 10 mm	6FX2001-5QD25-0AAx	Absolute encoder with DRIVE-CLiQ, multiturn
DRIVE-CLiQ hollow shaft 10 mm	6FX2001-5VD25-0AAx	Absolute encoder with DRIVE-CLiQ, multiturn
DRIVE-CLiQ hollow shaft 12 mm	6FX2001-5WD25-0AAx	Absolute encoder with DRIVE-CLiQ, multiturn

4.10.2 Safety information



The encoder has direct contact to components that can be destroyed by electrostatic discharge (ESDS). Neither hands nor tools that could be electrostatically charged should come into contact with the connections.

NOTICE

The encoder cables to Siemens motors may only disconnected and connected when the system is in a no-voltage condition.

4.10 DRIVE-CLiQ encoder

4.10.3 Interface description

4.10.3.1 Overview



Figure 4-50 DRIVE-CLiQ encoder

4.10.3.2 DRIVE-CLiQ interface

Table 4- 38 DRIVE-CLiQ interface

	Pin	Signal name	Technical specifications
	1	TXP	Transmit data +
R R	2	TXN	Transmit data -
	3	RXP	Receive data +
	4	Reserved, do not use	
A B	5	Reserved, do not use	
	6	RXN	Receive data -
	7	Reserved, do not use	
	8	Reserved, do not use	
	Α	Reserved, do not use	
	В	M (0 V)	Electronics ground

The blanking cover for the DRIVE-CLiQ port is included in the scope of delivery.

Blanking covers (50 pieces) Order number: 6SL3066-4CA00-0AA0

4.10.4 Dimension drawings




Figure 4-51 Dimension drawing of synchronous flange, all data in mm and (inches)




Figure 4-52 Dimension drawing of clamping flange, all data in mm and (inches)

4.10 DRIVE-CLiQ encoder




Figure 4-53 Dimension drawing of hollow shaft, all data in mm and (inches)

Table 4- 39 Dimensions

	Dimensions		Unit
Hollow shaft ØA	10+0.012 (0.39)	12+0.012 (0.47)	mm (inch)
Connection shafts ØC	10 (0.39)	12 (0.47)	mm (inch)
Clamping ring ØB	18 (0.70)	20 (0.78)	mm (inch)
L min.	15 (0.59)	18 (0.70)	mm (inch)
L max.	20 (0.78)	20 (0.78)	mm (inch)
Shaft code	2 (0.07)	7 (0.27)	mm (inch)

L = Engaged depth of the connection shaft into the encoder

4.10.5 Installation




Figure 4-54 Installation: Synchronous flange, 1: Clamp straps

Clamp straps / couplings

Clamp straps and couplings are required as mounting accessories. The clamp straps are used to fix the encoders with a synchronous flange.

Table 4- 40 Selection and ordering data

Designation	Order No.
Clamp strap (No.1 in the drawing) for encoder with synchronous flange (3 units are required)	6FX2001-7KP01
Spring disk coupling Shaft diameter:	
• 6 mm / 6 mm	6FX2001-7KF10
• 6 mm / 5 mm	6FX2001-7KF06
Plug-in coupling Shaft diameter:	
• 6 mm / 6 mm	6FX2001-7KS06
• 10 mm / 10 mm	6FX2001-7KS10

4.10 DRIVE-CLiQ encoder

Table 4- 41 Installation instructions

Product name	Spring disk coupling	Plug-in coupling
Transmission torque, max.	0.8 Nm	0.7 Nm
Shaft diameter	6 mm both ends or $d_1 = 6$ mm, $d_2 = 5$ mm	6 mm both ends or 10 mm both ends
Center offset of shafts, max.	0.4 mm	0.5 mm
Axial offset	± 0.4 mm	± 0.5 mm
Angular displacement of shafts, max.	3°	1°
Torsional rigidity	150 Nm / rad	31 Nm / rad
Lateral spring stiffness	6 N / mm	10 N / mm
Moment of inertia	19 gcm ²	20 gcm ²
Max. speed	12000 rpm	12000 rpm
Operating temperature	-20 +150 °C	-20 +80 °C
Weight, approx.	16 g	20 g




Figure 4-55 Installation: Hollow shaft, A: Spring plate (included in scope of supply)

4.10.6 Technical data

Table 4- 42 Technical data of DRIVE-CLiQ encoders

Design	Unit	Absolute encoder with DRIVE-CLiQ
Operating voltage at encoder	V	24 V -15% / +20%
Power consumption Single-turn Multiturn	mA mA	approx. 245 approx. 325
Interface		DRIVE-CLiQ
Speed electrically permissible mechanical, max.	rpm rpm	14000 10000
Cable length, max.	m	100
Connection		DRIVE-CLiQ connector, radial
Resolution Single-turn Multiturn	Bit Bit	22 34 (22 bit single-turn + 12 bit multiturn)
Accuracy	Angular seconds	±35
Frictional torque	Nm	≤ 0.01 (at 20°C)
Starting torque	Nm	≤ 0.01 (at 20°C)
Shaft load capability d 10x19.5 70° n > 6000 rpm n ≤ 6000 rpm		axial 40 N / radial 40 N at the shaft end axial 40 N / radial 60 N at the shaft end
Angular acceleration, , max.	rad/s ²	10 ⁵
Moment of inertia of the rotor Solid shaft Hollow shaft	kgm² kgm²	1.90 * 10 ⁻⁶ kgm ² 2.80 * 10 ⁻⁶ kgm ²
Vibratory load acc. to DIN IEC 68-2-6	m/s ²	≤ 100 (10 - 500 Hz)
Shock (6 ms) acc. to DIN IEC 68-2-27	m/s ²	≤ 1000 (6 ms)
Operating temperature min. max.	°C °C	-20 100
Degree of protection (acc. to DIN EN 60529)		IP67 at the frame IP64 at the shaft input
Weight Single-turn Multiturn	kg kg	0.40 0.44
CE mark		Yes

4.10 DRIVE-CLiQ encoder

Cabinet design and electromagnetic compatibility (EMC)

5.1 Tightening torques for screws and screw connections

For screws and screw connections of components that are described in this manual, the following tightening torques apply:

Table 5- 1 Tightening torques for ground connections, protective conductor screw connections and control cabinet installation

Thread	Tightening torque in Nm
M3	0.8 Nm
M4	1.8 Nm
M5	3.0 Nm
M6	6.0 Nm
M8	13.0 Nm
M10	25.0 Nm

Tolerance -> 0 to +30 %

Deviating tightening torques

For screw terminals on components and for mounting individual components in the control cabinet, the following deviating tightening torques apply. The corresponding data are described in the following chapters:

- "Mounting" for SME20/25 and SME120/125
- "Screw terminals" in Appendix A

5.2 Information on control cabinet installation and EMC

Information on control cabinet installation and electromagnetic compatibility (EMC), as well as on overcurrent and overvoltage protection, can be found in the following manuals:

- Components in the booksize format: SINAMICS S120 Manual for Booksize Power Units (GH2)
- Components in the blocksize format: SINAMICS S120 Manual AC Drive (GH6)
- Components in the chassis format: SINAMICS S120 Manual Chassis Power Units (GH3))SINAMICS S120 Manual Chassis Units Liquid-Cooled (GH7)

Appendix A



A.1 Spring-loaded terminals

The type of spring-loaded terminal can be taken from the interface description of the particular component.

Table A-1 Connectable conductor cross-sections for spring-loaded terminals

Sprin	g-loaded terminal type				
1	Connectable conductor cross- sections	Rigid Flexible Flexible with end sleeve without plastic sleeve AWG/kcmil	0.14 mm ² to 0.5 mm ² 0.14 mm ² to 0.5 mm ² 0.25 mm ² to 0.5 mm ² 26 to 20		
	Stripping length	8 mm			
2	Connectable conductor cross- sections	Flexible	0.08 mm ² to 2.5 mm ²		
	Stripping length	8 to 9 mm			
3	Connectable conductor cross- sections	Rigid Flexible Flexible with end sleeve without plastic sleeve Flexible with end sleeve with plastic sleeve AWG/kcmil	0.2 mm ² to 1 mm ² 0.2 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.75 mm ² 24 to 16		
	Stripping length	8 mm			
3_1	Connectable conductor cross- sections	Rigid Flexible Flexible with end sleeve without plastic sleeve Flexible with end sleeve with plastic sleeve AWG/kcmil	0.2 mm ² to 1.5 mm ² 0.2 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.75 mm ² 24 to 16		
	Stripping length	10 mm			
4	Connectable conductor cross- sections	25 mm ² to 95 mm ² AWG 4 to 4/0			
	Stripping length	35 mm			
5	Connectable conductor cross- sections	Rigid Flexible Flexible with end sleeve without plastic sleeve Flexible with end sleeve with plastic sleeve AWG/kcmil	0.2 mm ² to 10 mm ² 0.2 mm ² to 6 mm ² 0.25 mm ² to 6 mm ² 0.25 mm ² to 4 mm ² 24 to 8		
	Stripping length	15 mm			

A.2 Screw terminals

The type of screw terminal can be taken from the interface description of the particular component.

Table A-2 Connectable conductor cross-sections and tightening torques for screw terminals

Screv	v terminal type		
1	Connectable conductor cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.08 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.5 mm ²
	Stripping length	7 mm	
	Tool	Screwdriver 0.4 x 2.0 mm	
	Tightening torque	0.22 to 0.25 Nm	
1_1	Connectable conductor cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.14 mm ² to 1.5 mm ² 0.25 mm ² to 1.5 mm ² 0.25 mm ² to 0.5 mm ²
	Stripping length	7 mm	
	Tool	Screwdriver 0.4 x 2.5 mm	
	Tightening torque	0.22 to 0.25 Nm	
2	Connectable conductor cross- sections	Rigid, flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.08 mm ² to 2.5 mm ² 0.5 mm ² to 2.5 mm ² 0.5 mm ² to 1.5 mm ²
	Stripping length	7 mm	
	Tool	Screwdriver 0.6 x 3.5 mm	
	Tightening torque	0.5 to 0.6 Nm	
3	Connectable conductor cross- sections	Flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.2 mm ² to 2.5 mm ² 0.25 mm ² to 1 mm ² 0.25 mm ² to 1 mm ²
	Stripping length	9 mm	
	Tool	Screwdriver 0.6 x 3.5 mm	
	Tightening torque	0.5 to 0.6 Nm	
4	Connectable conductor cross- sections	Flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.2 mm ² to 4 mm ² 0.25 mm ² to 4 mm ² 0.25 mm ² to 4 mm ²
	Stripping length	7 mm	
	Tool	Screwdriver 0.6 x 3.5 mm	
	Tightening torque	0.5 to 0.6 Nm	
5	Connectable conductor cross- sections	Flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.5 mm ² to 6 mm ² 0.5 mm ² to 6 mm ² 0.5 mm ² to 6 mm ²
	Stripping length	12 mm	
	Tool	Screwdriver 1.0 x 4.0 mm	
	Tightening torque	1.2 to 1.5 Nm	

A.2 Screw terminals

Screw terminal type						
6	Connectable conductor cross- sections	Flexible With wire end ferrule, without plastic sleeve With wire end ferrule, with plastic sleeve	0.5 mm ² to 10 mm ² 0.5 mm ² to 10 mm ² 0.5 mm ² to 10 mm ²			
	Stripping length	11 mm				
	Tool	Screwdriver 1.0 x 4.0 mm				
	Tightening torque	1.5 to 1.8 Nm				
7	Connectable conductor cross- sections	0.5 mm ² to 16 mm ²				
	Stripping length	14 mm				
	Tool	Screwdriver 1.0 x 4.0 mm				
	Tightening torque	1.5 to 1.7 Nm				

A.2 Screw terminals

Appendix B

B.1 List of abbreviations

Note:

The following list of abbreviations includes all abbreviations and their meanings used in the entire SINAMICS user documentation.

Abbreviation	Source of abbreviation	Meaning	
Α			
A	Alarm	Alarm	
AC	Alternating Current	Alternating current	
ADC	Analog Digital Converter	Analog digital converter	
Al	Analog Input	Analog input	
AIM	Active Interface Module	Active Interface Module	
ALM	Active Line Module	Active Line Module	
AO	Analog Output	Analog output	
AOP	Advanced Operator Panel	Advanced Operator Panel	
APC	Advanced Positioning Control	Advanced Positioning Control	
AR	Automatic Restart	Automatic restart	
ASC	Armature Short Circuit	Armature short circuit	
ASCII	American Standard Code for Information Interchange	American standard code for information interchange	
ASM	Asynchronmotor	Induction motor	
В			
BERO	-	Contactless proximity switch	
BI	Binector Input	Binector input	
BIA	Berufsgenossenschaftliches Institut für Arbeitssicherheit	Germany's Institute for Occupational Safety and Health	
BICO	Binector Connector Technology	Binector connector technology	
BLM	Basic Line Module	Basic Line Module	
ВО	Binector Output	Binector output	
BOP	Basic Operator Panel	Basic Operator Panel	

Abbreviation	Source of abbreviation	Meaning	
С			
С	Capacitance	Capacitance	
C	-	Safety message	
CAN	Controller Area Network	Serial bus system	
CBC	Communication Board CAN	Communication board CAN	
CD	Compact Disc	Compact Disc	
CDC	Crosswise data comparison	Crosswise data comparison	
CDS	Command Data Set	Command data set	
CF Card	CompactFlash Card	CompactFlash Card	
CI	Connector Input	Connector input	
CLC	Clearance Control	Clearance control	
CNC	Computer Numerical Control	Computer numerical control	
CO	Connector Output	Connector output	
CO/BO	Connector Output/Binector Output	Connector/binector output	
COB ID	CAN Object Identification	CAN Object identification	
COM	Common contact of a changeover relay	Center contact of a changeover contact	
COMM	Commissioning	Commissioning	
CP	Communication Processor	Communication processor	
CPU	Central Processing Unit	Central processing unit	
CRC	Cyclic Redundancy Check	Cyclic redundancy check	
CSM	Control Supply Module	Control Supply Module	
CU	Control Unit	Control Unit	
CUA	Control Unit Adapter	Control Unit Adapter	
CUD	Control Unit DC MASTER	Control Unit DC MASTER	
D			
DAC	Digital Analog Converter	Digital analog converter	
DC	Direct Current	DC current	
DC link	DC link	DC link	
DCB	Drive Control Block	Drive Control Block	
DCC	Drive Control Chart	Drive Control Chart	
DCC	Data Cross Check	Crosswise data comparison	
DCN	Direct Current Negative	DC current negative	
DCP	Direct Current Positive	DC current positive	
DDS	Drive Data Set	Drive data set	
DI	Digital Input	Digital input	
DI/DO	Digital Input/Digital Output	Digital input/output bidirectional	
DMC	DRIVE-CLiQ Hub Module Cabinet	DRIVE-CLiQ Hub Module Cabinet	
DME	DRIVE-CLiQ Hub Module External	DRIVE-CLiQ Hub Module External	
DO	Digital Output	Digital output	
DO	Drive Object	Drive object	

Abbreviation	Source of abbreviation	Meaning		
DP	Decentralized Peripherals	Distributed IOs		
DPRAM	Dual Ported Random Access Memory Memory with dual access po			
DRAM	Dynamic Random Access Memory	Dynamic memory		
DRIVE-CLiQ	Drive Component Link with IQ	Drive Component Link with IQ		
DSC	Dynamic Servo Control	Dynamic Servo Control		
E				
EASC	External Armature Short Circuit	External armature short circuit		
EDS	Encoder Data Set	Encoder data set		
ESD	Electrostatic Sensitive Devices	Electrostatic sensitive devices		
ELCB	Earth Leakage Circuit Breaker	Earth leakage circuit breaker		
ELP	Earth Leakage Protection	Earth leakage protection		
EMC	Electromagnetic Compatibility	Electromagnetic compatibility		
EMF	Electromagnetic Force	Electromagnetic force		
EMC	Electromagnetic compatibility	Electromagnetic compatibility		
EN	European standard	European standard		
EnDat	Encoder Data Interface	Encoder interface		
EP	Enable Pulses	Pulse enable		
EPOS	Einfachpositionierer	Basic positioner		
ES	Engineering System	Engineering System		
ESB	Equivalent circuit diagram	Equivalent circuit diagram		
ESD	Electrostatic Sensitive Devices	Electrostatic sensitive devices		
ESR	Extended Stop and Retract	Extended stop and retract		
F				
F	Fault	Fault		
FAQs	Frequently Asked Questions	Frequently asked questions		
FBL	Free Blocks	Free function blocks		
FCC	Function Control Chart	Function Control Chart		
FCC	Flux Current Control	Flux current control		
FD	Function Diagram	Function diagram		
F-DI	Failsafe Digital Input	Fail-safe digital input		
F-DO	Failsafe Digital Output	Fail-safe digital output		
FEM	Fremderregter Synchronmotor	Separately excited synchronous motor		
FEPROM	Flash EPROM	Non volatile read and write memory		
FG	Function Generator	Function generator		
FI	-	Fault current		
FOC	Fiber-Optic Cable	Fiber-optic cable		
FP	Function diagram	Function diagram		
FPGA	Field Programmable Gate Array	Field Programmable Gate Array		

Abbreviation	Source of abbreviation	Meaning	
FW	Firmware	Firmware	
G			
GB	Gigabyte	Gigabyte	
GC	Global Control	Global Control Telegram (Broadcast Telegramm)	
GND	Ground	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as G)	
GSD	Generic Station Description	Generic station description: Describes the characteristics of a PROFIBUS slave	
GSV	Gate Supply Voltage	Gate Supply Voltage	
GUID	Globally Unique Identifier	Globally unique identifier	
Н			
HF	High Frequency	High frequency	
HFD	Hochfrequenzdrossel	High-frequency reactor	
НМІ	Human Machine Interface	Human machine interface	
HTL	High-Threshold Logic	Logic with a high fault threshold	
HW	Hardware	Hardware	
I			
I/O	Input/Output	Input/output	
I2C	Inter-Integrated Circuit	Internal serial data bus	
IASC	Internal Armature Short Circuit	Internal armature short circuit	
IBN	Inbetriebnahme	Commissioning	
ID	Identifier	Identification	
IE	Industrial Ethernet	Industrial Ethernet	
IEC	International Electrotechnical Commission	International Electrotechnical Commission	
IF	Interface	Interface	
IGBT	Insulated Gate Bipolar Transistor	Insulated gate bipolar transistor	
IGCT	Integrated Gate-Controlled Thyristor	Semiconductor power switch with integrated control electrode	
IL	Impulslöschung	Pulse cancelation	
IP	Internet Protocol	Internet Protocol	
IPO	Interpolator	Interpolator	
IT	Isolé Terré	Non-grounded three-phase power supply	
IVP	Internal Voltage Protection	Internal voltage protection	
J			
JOG	Jogging	Jogging	


Abbreviation K	Source of abbreviation	Meaning	
KIP	Kinetische Pufferung	Kinetic buffering	
Кр	-	Proportional gain	
KTY	-	Special temperature sensor	
L		·	
L	-	Formula symbol for inductance	
LED	Light Emitting Diode	Light Emitting Diode	
LIN	Linear motor	Linear motor	
LSB	Least Significant Bit	Least significant bit	
LSC	Line-Side Converter	Line-side converter	
LSS	Line Side Switch	Line side switch	
LU	Length Unit	Length unit	
M			
M	-	Formula symbol for torque	
M	Masse	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as GND)	
MB	Megabyte	Megabyte	
MCC	Motion Control Chart	Motion Control Chart	
MDS	Motor Data Set	Motor data set	
MLFB	Maschinenlesbare Fabrikatebezeichnung	Machine-Readable Product Code	
MMC	Man-Machine Communication	Man-machine communication	
MMC	Micro Memory Card	Micro memory card	
MSB	Most Significant Bit	Most significant bit	
MSC	Motor-Side Converter	Motor-side converter	
MSCY_C1	Master Slave Cycle Class 1	Cyclic communication between master (Class 1) and slave	
MSR	Motorstromrichter	Motor-side converter	
MT	Machine Tool	Machine tool	
N			
N. C.	Not Connected	Not connected	
N	No Report	No message or internal message	
NAMUR	Normenarbeitsgemeinschaft für Mess- und Regeltechnik in der chemischen Industrie	d Standardization association for measure- ment and control in the chemical industry	
NC	Normally Closed (contact)	NC contact	
NC	Numerical Control	Numerical control	
NEMA	National Electrical Manufacturers Association	Standardization body in the US	
NM	Nullmarke	Zero mark	
NO	Normally Open (contact)	NO contact	

Abbreviation	Source of abbreviation	Meaning	
NSR	Netzstromrichter	Line-side converter	
NVRAM	Non-Volatile Random Access Memory	Non-volatile read/write memory	
0	·	·	
OA	Open Architecture	Open Architecture	
ОС	Operating Condition	Operating condition	
OEM	Original Equipment Manufacturer	Original Equipment Manufacturer	
OLP	Optical Link Plug	Fiber-optic bus connector	
OMI	Option Module Interface	Option module interface	
P			
p	-	Adjustable parameters	
РВ	PROFIBUS	PROFIBUS	
PC	Position Controller	Position Controller	
PcCtrl	PC Control	Control for master	
PD	PROFIdrive	PROFIdrive	
PDS	Power unit Data Set	Power unit data set	
PE	Protective Earth	Protective earth	
PELV	Protective Extra Low Voltage	Protective extra low voltage	
PEM	Permanenterregter Synchronmotor	Permanent-magnet synchronous motor	
PG	Programmiergerät	Programming device	
PI	Proportional Integral	Proportional integral	
PID	Proportional Integral Differential	Proportional integral differential	
PLC	Programmable Logic Controller	Programmable logic controller	
PLL	Phase-Locked Loop	Phase-locked loop	
PN	PROFINET	PROFINET	
PNO	PROFIBUS Nutzerorganisation	PROFIBUS user organization	
PPI	Point-to-Point Interface	Point-to-point interface	
PRBS	Pseudo Random Binary Signal	White noise	
PROFIBUS	Process Field Bus	Serial data bus	
PS	Power Supply	Power supply	
PSA	Power Stack Adapter	Power Stack Adapter	
PTC	Positive Temperature Coefficient	Positive temperature coefficient	
PTP	Point-To-Point	Point-to-Point	
PWM	Pulse Width Modulation	Pulse width modulation	
PZD	Prozessdaten	Process data	
R			
r	-	Display parameters (read-only)	
RAM	Random Access Memory	Read/write memory	
RCCB	Residual Current Circuit Breaker	Residual current operated circuit breaker	
RCD	Residual Current Device	Residual current operated circuit breaker	
RCM	Residual Current Monitor	Residual current monitor	

Abbreviation	Source of abbreviation	Meaning
RFG	Ramp-Function Generator	Ramp-function generator
RJ45	Registered Jack 45	Term for an 8-pin socket system for data transmission with shielded or non-shielded multi-wire copper cables
RKA	Rückkühlanlage	Cooling unit
RO	Read Only	Read only
RPDO	Receive Process Data Object	Receive process data object
RS232	Recommended Standard 232	Interface standard for cable-connected serial data transmission between a sender and receiver (also known under EIA232)
RS485	Recommended Standard 485	Interface standard for a cable-connected differential, parallel, and/or serial bus system (data transmission between a number of senders and receivers, also known under EIA485)
RTC	Real Time Clock	Real time clock
RZA	Raumzeigerapproximation	Space vector approximation
S		
S1	-	Uninterrupted duty
S3	-	Intermittent duty
SBC	Safe Brake Control	Safe brake control
SBH	Sicherer Betriebshalt	Safe operating stop
SBR	-	Safe acceleration monitoring
SCA	Safe Cam	Safe cam
SD Card	SecureDigital Card	Secure digital memory card
SE	Sicherer Software-Endschalter	Safe software limit switch
SG	Sicher reduzierte Geschwindigkeit	Safely reduced speed
SGA	Sicherheitsgerichteter Ausgang	Safety-related output
SGE	Sicherheitsgerichteter Eingang	Safety-related input
SH	Sicherer Halt	Safe standstill
SI	Safety Integrated	Safety Integrated
SIL	Safety Integrity Level	Safety Integrity Level
SLM	Smart Line Module	Smart Line Module
SLP	Safely-Limited Position	Safely-limited position
SLS	Safely Limited Speed	Safely limited speed
SLVC	Sensorless Vector Control	Vector control without encoder
SM	Sensor Module	Sensor Module
SMC	Sensor Module Cabinet	Sensor Module Cabinet
SME	Sensor Module External	Sensor Module External
SN	Sicherer Software-Nocken	Safe software cam
sos	Safe Operating Stop	Safe operating stop

Abbreviation	Source of abbreviation	Meaning
SP	Service Pack	Service pack
SPC	Setpoint Channel	Setpoint channel
SPI	Serial Peripheral Interface	Serial interface for connecting peripherals
SS1	Safe Stop 1	Safe stop 1 (monitored for time and ramping up)
SS2	Safe Stop 2	Safe stop 2
SSI	Synchronous Serial Interface	Synchronous serial interface
SSM	Safe Speed Monitor	Safe feedback for speed monitoring (n < nx)
SSP	SINAMICS Support Package	SINAMICS support package
STO	Safe Torque Off	Safe torque off
STW	Steuerwort	Control word
Т		
ТВ	Terminal Board	Terminal Board
TIA	Totally Integrated Automation	Totally Integrated Automation
TM	Terminal Module	Terminal module
TN	Terre Neutre	Grounded three-phase supply network
Tn	-	Integral time
TPDO	Transmit Process Data Object	Transmit process data object
TT	Terre Terre	Grounded three-phase supply network
TTL	Transistor-Transistor Logic	Transistor-transistor logic
Tv	-	Rate time
U		
u.d.	under development	Under development: This feature is not currently available
UL	Underwriters Laboratories Inc.	Underwriters Laboratories Inc.
UPS	Uninterruptible Power Supply	Uninterruptible power supply
UTC	Universal Time Coordinated	Universal time coordinated
V		
VC	Vector Control	Vector control
Vdc	-	DC link voltage
VdcN	-	Partial DC link voltage negative
VdcP	-	Partial DC link voltage positive
VDE	Verband Deutscher Elektrotechniker	Association of German electrical engineers
VDI	Verein Deutscher Ingenieure	Association of German Engineers
VPM	Voltage Protection Module	Voltage Protection Module
Vpp	Volt peak-to-peak	Volt peak-to-peak
VSM	Voltage Sensing Module	Voltage Sensing Module

Abbreviation	Source of abbreviation	Meaning
X		
XML	Extensible Markup Language	Standard language for Web publishing and document management
Z		
ZM	Zero Mark	Zero mark
ZSW	Zustandswort	Status word



Index

Basic Operator Panel BOP20, 83 Communication Board CBC10, 88 Communication Board CBE20, 94 Components Basic Operator Panel BOP20, 83 Communication Board CBC10, 88 Communication Board CBC10, 88 Communication Board CBC20, 94 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ Hub Module External DME20, 204 Terminal Module TM120, 172 Terminal Module TM15, 108 Terminal Module TM15, 108 Terminal Module TM41, 140 Terminal Module TM31, 122 Terminal Module TM41, 140 Terminal Module TM41, 140 Terminal Module TM41, 140 Terminal Module TM5, 1185 Terminal Module TM5, 119 Terminal Module TM31, 138 Control Unit CU320-2 PP, 58 LEDs after booting, 73 LEDs during booting, 72 Control Unit CU320-2 PN, 39 LEDs after booting, 54 LEDs during booting, 53 Terminal Module TM31, 134 Terminal Module TM31, 134 Terminal Module FM31, 136 Terminal Module External DME20, 204 Terminal Module TM120, 172 Terminal Module TM15, 118 Terminal Module TM120, 236 Sensor Module Cabinet SMC20, 247 Sensor Module External SME125, 306 Sensor Module External SME125, 306 Sensor Module External SME25, 279 Terminal Module TM15, 116 Terminal Module TM15, 116 Terminal Module TM120, 236 Sensor Module Cabinet SMC20, 247 Sensor Module External SME125, 306 Sensor Module External SME125, 306 Sensor Module External SME125, 306 Sensor Module External SME25, 279 Terminal Module TM15, 116 Terminal Module TM15, 118 Terminal Module TM120, 122 Sensor Module Cabinet SMC20, 201 Tontol Unit CU320-2 PN, 39 DRIVE-CLiQ Hub Module External DME20, 204 Extended TM31, 134 Terminal Module TM15, 116 Terminal Mod	A Address Setting the PROFIBUS address, 67 Ambient temperature, 29 B	Communication Board CBC10, 92 Communication Board CBE20, 97 Control Unit CU320-2 DP, 73 Control Unit CU320-2 PN, 54 DRIVE-CLiQ Hub Module DMC20, 200 Sensor Module Cabinet SMC10, 235 Sensor Module Cabinet SMC20, 246 Sensor Module Cabinet SMC30, 259 Terminal Module TM120, 180 Terminal Module TM15, 115
Communication Board CBC10, 88 Communication Board CBE20, 94 Components Basic Operator Panel BOP20, 83 Communication Board CBE20, 94 Control Unit CU320-2 PN, 56 DRIVE-CLiQ encoder, 311 DRIVE-CLiQ Hub Module DMC20, 201 Control Unit CU320-2 PN, 39 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ hub Module DMC20, 196 DRIVE-CLiQ Hub Module External DME20, 204 Terminal Board TB30, 100 Terminal Module TM15, 108 Terminal Module TM15, 108 Terminal Module TM5, 153 Voltage Sensing Module VSM10, 211 Connector coding Terminal Module TM5, 119 Terminal Module TM5, 138 Control Unit CU320-2 PN, 39 LEDs after booting, 72 Control Unit CU320-2 PN, 39 LEDs after booting, 54 LEDs during booting, 53 Voltage Sensing Module VSM10, 221 Dimension drawings Control Unit CU320-2 DP, 58 LEDs after booting, 54 LEDs during booting, 53 Voltage Sensing Module VSM10, 221 Drive-CLiQ encoder, 311 DRIVE-CLiQ Hub Module External DME20, 208 Sensor Module Cabinet SMC30, 260 Sensor Module External SME120, 292 Sensor Module External SME25, 279 Terminal Module External SME25, 279 Terminal Module TM15, 116 Terminal Module TM15, 116 Terminal Module TM15, 119 Terminal Module TM5, 119 Terminal Module TM5, 119 Terminal Module TM5, 119 Terminal Module TM31, 138 Control Unit CU320-2 PP, 58 LEDs after booting, 73 LEDs during booting, 72 Control Unit CU320-2 PN, 39 LEDs after booting, 54 LEDs during booting, 53		Terminal Module TM31, 134 Terminal Module TM41, 148
Communication Board CBC10, 88 Communication Board CBE20, 94 Components Basic Operator Panel BOP20, 83 Communication Board CBC10, 88 Communication Board CBC10, 88 Communication Board CBC20, 94 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ hub Module DMC20, 196 DRIVE-CLiQ hub Module DMC20, 196 DRIVE-CLiQ Hub Module External DME20, 204 Terminal Board TB30, 100 Terminal Module TM120, 172 Terminal Module TM15, 108 Terminal Module TM54, 153 Voltage Sensing Module VSM10, 211 Connector coding Terminal Module TM15, 119 Terminal Module TM31, 138 Control Unit CU320-2 PP, 38 Control Unit CU320-2 DP, 58 LEDs after booting, 73 LEDs during booting, 72 Control Unit CU320-2 PN, 39 LEDs after booting, 54 LEDs during booting, 53 Control Unit CU320-2 DP, 58 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 LEDs after booting, 54 LEDs during booting, 53 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 Control Unit CU320-2 PN, 39 LEDs after booting, 53 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 LEDs during booting, 53 Control Unit CU320-2 PN, 56 DRIVE-CLiQ Hub Module External DME20, 208 Sensor Module Cabinet SMC20, 208 Sensor Module Cabinet SMC20, 208 Sensor Module External SME120, 292 Sensor Module External SME20, 272 Sensor Module External SME20, 272 Sensor Module External SME20, 272 Sensor Module External SME120, 292 Sensor Module External DME20, 204 Sensor Module External SME120, 292 Sensor Module External DME20, 204 Sensor Module External SME120, 292 Sensor Module External DME20, 204 Sensor Module External SME20, 206 Sensor Module External S	C	Voltage Sensing Module VSM10, 220
D.	Communication Board CBE20, 94 Components Basic Operator Panel BOP20, 83 Communication Board CBC10, 88 Communication Board CBE20, 94 Control Unit CU320-2 DP, 58 Control Unit CU320-2 PN, 39 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ Hub Module DMC20, 196 DRIVE-CLiQ Hub Module External DME20, 204 Terminal Board TB30, 100 Terminal Module TM120, 172 Terminal Module TM15, 108 Terminal Module TM50, 185 Terminal Module TM41, 140 Terminal Module TM54F, 153 Voltage Sensing Module VSM10, 211 Connector coding Terminal Module TM31, 138 Control Unit CU320-2 DP, 58 LEDs after booting, 73 LEDs during booting, 72 Control Unit CU320-2 PN, 39 LEDs after booting, 54	Control Unit CU320-2 DP, 75 Control Unit CU320-2 PN, 56 DRIVE-CLiQ encoder, 311 DRIVE-CLiQ Hub Module DMC20, 201 DRIVE-CLiQ Hub Module External DME20, 208 Sensor Module Cabinet SMC10, 236 Sensor Module Cabinet SMC20, 247 Sensor Module Cabinet SMC30, 260 Sensor Module External SME120, 292 Sensor Module External SME125, 306 Sensor Module External SME20, 272 Sensor Module External SME20, 272 Sensor Module External SME25, 279 Terminal Module TM120, 181 Terminal Module TM15, 116 Terminal Module TM150, 192 Terminal Module TM31, 135 Terminal Module TM41, 149 Terminal Module TM41, 149 Terminal Module TM54F, 168 Voltage Sensing Module VSM10, 221 DRIVE-CLiQ encoder, 309 DRIVE-CLiQ Hub Module DMC20, 196 DRIVE-CLiQ Hub Module External DME20, 204
	D	F Field of application, 21

Diagnostics via LEDs

l	Sensor Module Cabinet SMC20, 246
Installation	Sensor Module Cabinet SMC30, 259
Basic Operator Panel BOP20, 86	Terminal Module TM120, 180
Communication Board CBC10, 93	Terminal Module TM15, 115
Communication Board Ethernet (CBE20), 99	Terminal Module TM150, 191
Control Unit CU320-2 DP/PN, 76	Terminal Module TM31, 134
DRIVE-CLiQ encoder, 313	Terminal Module TM41, 148
DRIVE-CLiQ Hub Module DMC20, 202	Terminal Module TM54F, 166
Sensor Module Cabinet, 237, 248, 261	Voltage Sensing Module VSM10, 220
Sensor Module External SME120, 292	
Sensor Module External SME125, 306	D
Sensor Module External SME20/SME25, 273, 279	Р
Terminal Board TB30, 106	Platform Concept, 22
Terminal Module TM120, 182	PROFIBUS
Terminal Module TM150, 193	Setting the address, 67
Terminal Modules, 117, 136, 150, 169	PROFINET cables, 96
Interface descriptions	Protective conductor connection and shield support
Basic Operator Panel BOP20, 83	DRIVE-CLiQ Hub Module DMC20, 203
Communication Board CBC10, 89	Terminal Module TM120, 183
Communication Board CBE20, 95	Terminal Module TM15, 118
Control Unit CU320-2 DP, 59	Terminal Module TM150, 194
Control Unit CU320-2 PN, 40	Terminal Module TM31, 137
DRIVE-CLiQ Hub Module DMC20, 197	Terminal Module TM41, 151
DRIVE-CLiQ Hub Module External DME20, 205	Terminal Module TM54F, 170
Sensor Module Cabinet SMC10, 230	Voltage Sensing Module VSM10, 222
Sensor Module Cabinet SMC20, 241	
Sensor Module Cabinet SMC30, 251	
Sensor Module External SME120, 284	R
Sensor Module External SME125, 297	Residual risks, 10
Sensor Module External SME20, 269	Residual risks of power drive systems, 10
Sensor Module External SME25, 276	residual fisits of power affect systems, To
Terminal Board TB30, 101	
Terminal Module TM120, 173	S
Terminal Module TM150, 186	
Terminal Module TM31, 123	Safety information
Terminal Module TM41, 141	Communication Board CBC10, 88
Terminal Module TM54F, 154	Communication Board CBE20, 94
Voltage Sensing Module VSM10, 213	Control Unit CU320-2 DP, 58
Interface Descriptions	Control Unit CU320-2 PN, 39
Terminal Module TM15, 109	DRIVE-CLIQ Hub Module DMC20, 196
Introduction, 24	DRIVE-CLIQ Hub Module External DME20, 204
	Sensor Module Cabinet SMC10, 229
1	Sensor Module Cabinet SMC20, 240
L	Sensor Module Cabinet SMC30, 250
LEDs	Sensor Module External SME120, 282
Communication Board CBC10, 92	Sensor Module External SME125, 296
Communication Board CBE20, 97	Sensor Module External SME20, 268
Control Unit CU320-2 DP, 73	Terminal Board TB30, 100
Control Unit CU320-2 PN, 54	Terminal Module TM120, 172
DRIVE-CLiQ Hub Module DMC20, 200	Terminal Module TM15, 108 Terminal Module TM150, 185
Sensor Module Cabinet SMC10, 235	Terminal Module TM150, 165 Terminal Module TM31, 122
	TEHTIIII AI MOUUIE TIMOT, IZZ

Terminal Module TM41, 140 Terminal Module TM54F, 154 Voltage Sensing Module VSM10, 212 Sensor Modules, 227 Specification of encoder systems and encoders Sensor Module Cabinet SMC30, 264 Standards, 31 Storage, 29 Switches for PROFIBUS address, 67

Т

Technical data Communication Board CBC10, 93 Control Unit CU320-2 DP, 75 Control Unit CU320-2 PN, 57 DRIVE-CLiQ encoder, 315 DRIVE-CLiQ Hub Module DMC20, 203 DRIVE-CLiQ Hub Module External DME20, 209 Electronics power supply, 29 Sensor Module Cabinet SMC10, 238 Sensor Module Cabinet SMC20, 249 Sensor Module Cabinet SMC30, 263 Sensor Module External SME120, 293 Sensor Module External SME125, 307 Sensor Module External SME20, 274 Sensor Module External SME25, 280 Terminal Board TB30, 107 Terminal Module TM120, 184 Terminal Module TM15, 120 Terminal Module TM150, 195 Terminal Module TM31, 139 Terminal Module TM41, 152 Terminal Module TM54F, 171 Voltage Sensing Module VSM10, 223 Terminal Board TB30, 100 Terminal Module TM120, 172 Terminal Module TM15, 108 Terminal Module TM150, 185 Terminal Module TM31, 122 Terminal Module TM41, 140 Terminal Module TM54F, 153 Tightening torques, 317 Totally Integrated Automation, 22 Transport, 29

V

Voltage Sensing Module VSM10, 211

Siemens AG Industry Sector Drive Technologies Motion Control Systems P.O. Box 3180 91050 ERLANGEN GERMANY

Subject to change without prior notice © Siemens AG 2012

www.siemens.com/motioncontrol