



Library description • 03/2016

Library for Controlled System Simulation with STEP 7 (TIA Portal)

STEP 7 V13 SP1



<https://support.industry.siemens.com/cs/ww/en/view/79047707>

Warranty and liability

Note

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These Application Examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice.

If there are any deviations between the recommendations provided in these Application Examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document. Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act ("Produkthaftungsgesetz"), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract ("wesentliche Vertragspflichten"). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of the Siemens AG.

Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks. In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions only form one element of such a concept.

Customer is responsible to prevent unauthorized access to its plants, systems, machines and networks. Systems, machines and components should only be connected to the enterprise network or the internet if and to the extent necessary and with appropriate security measures (e.g. use of firewalls and network segmentation) in place.

Additionally, Siemens' guidance on appropriate security measures should be taken into account. For more information about industrial security, please visit <http://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends to apply product updates as soon as available and to always use the latest product versions. Use of product versions that are no longer supported, and failure to apply latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under <http://www.siemens.com/industrialsecurity>.

Table of contents

| | |
|--|-----------|
| Warranty and liability..... | 2 |
| 1 Library Overview..... | 4 |
| 1.1 Different user scenarios | 4 |
| 1.2 Hardware and software requirements | 5 |
| 1.3 Library resources..... | 6 |
| 2 Blocks of the Library | 7 |
| 2.1 List of the blocks..... | 7 |
| 2.2 Explanation of the blocks | 8 |
| 2.2.1 FB „LSim_PT1“ (FB 50)..... | 8 |
| 2.2.2 FB „LSim_PT1asym“ (FB 51)..... | 10 |
| 2.2.3 FB „LSim_PT2osc“ (FB52)..... | 12 |
| 2.2.4 FB „LSim_PT2aper“ (FB 53) | 14 |
| 2.2.5 FB „LSim_PT3“ (FB54)..... | 16 |
| 2.2.6 FB „LSim_PDT1“ (FB55) | 18 |
| 2.2.7 FB „LSim_I“ (FB56) | 20 |
| 2.2.8 FB „LSim_IT1“ (FB 57) | 22 |
| 2.2.9 FB „LSim_TempProcess“ (FB58) | 24 |
| 2.2.10 FB „LSim_Lagging“ (FB59) | 28 |
| 2.2.11 FB „ LSim_DT1“ (FB60) | 29 |
| 2.2.12 FB „LSim_AllPass1OrdReal“ (FB61)..... | 31 |
| 2.2.13 FB „LSim_AllPass2OrdReal“ (FB62)..... | 33 |
| 2.2.14 FB „LSim_Valve“ (FB63) | 35 |
| 2.2.15 FB „LSim_PT3HeatCool“ (FB 64) | 36 |
| 3 Working with the Library..... | 38 |
| 3.1 Integrating the library into STEP 7 | 38 |
| 3.2 Integrating the library blocks into STEP 7 | 39 |
| 3.3 Interconnecting controlling elements..... | 40 |
| 4 Notes and Support..... | 41 |
| 5 Related literature | 41 |
| 6 History..... | 41 |

1 Library Overview

What you get

This document describes the “LSim” block library. The block library provides you with the tested code with clearly defined interfaces. They can be used as a basis for your task to be implemented.

A key concern of the document is to describe

- all blocks of the block library
- the functionality implemented through these blocks.

Furthermore, this documentation shows possible fields of application and helps you integrate the library into your STEP 7 project using step-by-step instructions.

1.1 Different user scenarios

Possible application(s) for the “LSim” library

The “LSim” library allows you to simulate controlled systems in an S7 CPU.

The blocks of the library simulate various simple controlling elements through linear transfer elements. Suitable serial or parallel interconnection of the individual system elements allows you to simulate even very complex controlled systems.

The library can be used, for example, in the following scenarios:

- Optimizing a controller: Simulation of the controlled system where commissioning on the real process is difficult or hardly possible.
- For training purposes: Simulation of individual controlled system elements for a clear representation of control engineering processes and demonstration of software controllers.

1.2 Hardware and software requirements

Requirements for this library

To be able to use the functionality of the library described in this document, the following hardware and software requirements must be met:

Hardware

The library was tested with CPUs of the SIMATIC S7-1200 and S7-1500 series. However, other SIMATIC controllers can also be used as hardware.

Software

Table 1-1

| Component | Article number |
|-------------------------------------|--------------------|
| STEP 7 V13 SP1 (TIA Portal V13 SP1) | 6ES7822-1AE03-0YA5 |

Note

The SCL blocks can be very easily ported to STEP 7 V5.5.

1.3 Library resources

What will you find in this section?

The following section gives you an overview of the size of the blocks of the "LSim" library in the main memory.

Size of the individual blocks

Table 1-2

| FB no. | Name | S7-1200 allocation (in bytes) | | S7-1500 allocation (in bytes) | |
|-------------------------|----------------------|-------------------------------|-------------|-------------------------------|-------------|
| | | Load memory | Main memory | Load memory | Main memory |
| 50 | LSim_PT1 | 7438 | 287 | 7451 | 358 |
| 51 | LSim_PT1asym | 9747 | 443 | 9721 | 514 |
| 52 | LSim_PT2osc | 11651 | 639 | 11676 | 710 |
| 53 | LSim_PT2aper | 10982 | 606 | 10927 | 677 |
| 54 | LSim_PT3 | 9966 | 563 | 10004 | 629 |
| 55 | LSim_PDT1 | 9417 | 428 | 9381 | 500 |
| 56 | LSim_I | 7646 | 282 | 7688 | 361 |
| 57 | LSim_IT1 | 9820 | 495 | 9836 | 566 |
| 58 | LSim_TempProcess | 9568 | 414 | 9528 | 485 |
| 59 | LSim_Lagging | 5556 | 220 | 5542 | 284 |
| 60 | LSim_DT1 | 8591 | 353 | 8592 | 425 |
| 61 | LSim_Allpass1OrdReal | 8326 | 354 | 8323 | 425 |
| 62 | LSim_Allpass2OrdReal | 11009 | 615 | 10987 | 687 |
| 63 | LSim_Valve | 16110 | 496 | 16275 | 537 |
| 64 | LSim_PT3HeatCool | 13871 | 801 | 13835 | 866 |
| Total allocation | | 149698 | 6996 | 149766 | 8024 |

2 Blocks of the Library

What will you find in this section?

This chapter lists (chapter [2.1](#)) and explains (chapter [2.2](#)) all blocks of the “LSim” library.

2.1 List of the blocks

The following table lists all the blocks of the “LSim” library.

Chapter [2.2](#) provides a detailed description of the blocks.

Table 2-1

| Block | Name | Brief description | |
|-------|----------------------|---|-------------------------------------|
| FB50 | LSim_PT1 | Simulation of a PT1 system | Self-regulating systems |
| FB51 | LSim_PT1asym | Simulation of an asymmetrical PT1 system | |
| FB52 | LSim_PT2osc | Simulation of a PT2 system in the periodic case | |
| FB53 | LSim_PT2aper | Simulation of a PT2 system in the aperiodic case | |
| FB54 | LSim_PT3 | Simulation of a PT3 system | |
| FB55 | LSim_PDT1 | Simulation of a PDT1 system | |
| FB58 | LSim_TempProcess | Simulation of a temperature process | |
| FB60 | LSim_DT1 | Simulation of a DT1 system | |
| FB61 | LSim_Allpass1OrdReal | Simulation of a first-order all-pass | |
| FB62 | LSim_Allpass2OrdReal | Simulation of a second-order all-pass | |
| FB64 | LSim_PT3HeatCool | Simulation of a PT3 system with separate inputs for heating and cooling | Systems without inherent regulation |
| FB56 | LSim_I | Simulation of an I system | |
| FB57 | LSim_IT1 | Simulation of an IT1 system | |
| FB63 | LSim_Valve | Simulation of a valve | |
| FB59 | LSim_Lagging | Simulation of a lag element | |

2.2 Explanation of the blocks

This chapter introduces the parameters of the blocks.

For some parameters, it shows the transfer function of the block and the step response of the respective block.

2.2.1 FB „LSim_PT1“ (FB 50)

FB “LSim_PT1” (FB50) simulates a PT1 element. The PT1 element is a proportional transfer element with first-order order delay.

Use case

A PT1 element can be used, for example, to simulate a temperature system.

Transfer function

$$F(p) = \frac{gain}{tmLag1 * p + 1}$$

Figure

Figure 2-1: PT1 element



Input parameters

Table 2-2

| Parameter | Data type | Description |
|-----------|-----------|--|
| calcParam | Bool | Recalculation of the internal parameters (activation required when "tmLag1", "gain" or "cycle" changes) |
| input | Real | Input variable |
| tmLag1 | Real | Time constant (in seconds) |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, "output" = "maxOut" will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, "output" = "minOut" will be set) |
| reset | Bool | Resets all relevant parameters to '0', including "output". |

Output parameters

Table 2-3

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If "tmLag1" <= 0, "error" = TRUE will be set. |
| status | Word | If "tmLag1" <= 0, "status" = 16#8001 will be set. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain * (1 - e^{-\frac{tmLag1}{t}})$$

Figure 2-2: PT1 element step response



2.2.2 FB „LSim_PT1asym” (FB 51)

FB “LSim_PT1asym” (FB 51) simulates a PT1 system whose time response differs depending on whether the trigger is positive or negative. This makes it an asymmetrical PT1 system.

Use case

An asymmetrical PT1 element can be used, for example, to simulate a temperature system with different behavior for heating and cooling.

Transfer function


Unlike FB “LSim_PT1”, the transfer function internally consists of two different PT1 elements for the up and down movement of the process value.

$$F_{up}(p) = \frac{gain}{tmLag1up * p + 1}$$

$$F_{down}(p) = \frac{gain}{tmLag1down * p + 1}$$

Figure

Figure 2-3: Asymmetrical PT1 element



Input parameters

Table 2-4

| Parameter | Data type | Description |
|------------|-----------|---|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1up”, “tmLag1down”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1up | Real | Time constant (in seconds) in the event of positive triggering (“input” > “output”) |
| tmLag1down | Real | Time constant (in seconds) in the event of negative triggering (“input” < “output”) |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the |

| Parameter | Data type | Description |
|-----------|-----------|--|
| | | maximum limit, "output" = "maxOut" will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, "output" = "minOut" will be set) |
| reset | Bool | Resets all relevant parameters to '0', including "output". |

Output parameters

Table 2-5


| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If "tmLag1up" <= 0 or "tmLag1down" <= 0, "error" = TRUE will be set. |
| status | Word | If "tmLag1up" <= 0 or "tmLag1down" <= 0, "status" = 16#8001 will be set. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain * (1 - e^{-\frac{tmLag1up}{t}}) \text{ for a positive unit step}$$

$$y(t) = gain * (1 - e^{-\frac{tmLag1down}{t}}) \text{ for a negative unit step}$$

Figure 2-4: Asymmetrical PT1 element step response



2.2.3 FB „LSim_PT2osc“ (FB52)

FB “Sim_PT2osc” (FB52) simulates an oscillating PT2 system. Accordingly, the damping factor selected for this system must be less than 1. Accordingly, the system is in the periodic case.

Use case


A periodic PT2 element can be used, for example, to simulate mechanical systems that execute a stroke/rotation and are oscillating.

Transfer function

$$F(p) = \frac{gain}{(\frac{p}{omega})^2 + 2 * damp * \frac{p}{omega} + 1}$$

Figure

Figure 2-5: PT2 element in the periodic case



Input parameters

Table 2-6

| Parameter | Data type | Description |
|-----------|-----------|--|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “omega”, “damp”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| omega | Real | Angular frequency of the free oscillation |
| damp | Real | Damping ratio: $0 < \text{damp} < 1$ |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |


Output parameters

Table 2-7

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the conditions $0 < \text{damp} < 1$ or $\text{omega} > 0$ are not met, "error" = TRUE will be set. |
| status | Word | If the conditions $0 < \text{damp} < 1$ or $\text{omega} > 0$ are not met, "status" = 16#8001 will be output. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain - \frac{gain}{\sqrt{1-damp^2}} e^{-damp*tmLag1*T} * \sin \left[\frac{\sqrt{1-damp^2}}{tmLag1} t + \arctan \left(\frac{\sqrt{1-damp^2}}{damp} \right) \right]$$

Figure 2-6: PT2 element with $0 < \text{damp} < 1$ 

2.2.4 FB „LSim_PT2aper” (FB 53)

FB “LSim_PT2aper” (FB53) simulates a PT2 system with a damping factor >1. The system is in the aperiodic case where no overshoot occurs.

Use case

An aperiodic PT2 element can be used, for example, to simulate a spring pendulum.


Transfer function

Unlike FB “LSim_PT2osc”, the transfer function internally consists of two PT1 elements connected in series:

$$F(p) = \frac{gain}{(tmLag1 * p + 1) * (tmLag2 * p + 1)}$$

Figure

Figure 2-7



Input parameters

Table 2-8

| Parameter | Data type | Description |
|-----------|-----------|---|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1up”, “tmLag1down”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Time constant for the first PT1 element (in seconds) |
| tmLag2 | Real | Time constant for the second PT1 element (in seconds) |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |

| Parameter | Data type | Description |
|-----------|-----------|--|
| reset | Bool | Resets all relevant parameters to '0', including "output". |

Output parameters

Table 2-9


| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the time constants are identical or <= 0, "error" = TRUE will be set. |
| status | Word | If the time constants are identical or <= 0, "status" = 16#8001 will be output. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain - \frac{gain}{tmLag1 - tmLag2} \left[tmLag1 e^{\frac{-t}{tmLag1}} - tmLag2 e^{\frac{-t}{tmLag2}} \right]$$

$$tmLag1 <> tmLag2$$

Figure 2-8: Step response of PT2 element with D>1



2.2.5 FB „LSim_PT3“ (FB54)

FB “LSim_PT3” (FB54) simulates a third-order delay element. Internally, it consists of the serial interconnection of three PT1 systems.


Use case

A PT3 element can be used, for example, to simulate a temperature system with multiple storage elements.

Transfer function


$$F(p) = \frac{gain}{(tmLag1 * p + 1) * (tmLag2 * p + 1) * (tmLag3 * p + 1)}$$

Figure 2-9: Structure and parameters of the “LSim_PT3” system block



Figure

Figure 2-10: PT3 element



Input parameters

Table 2-10

| Parameter | Data type | Description |
|-----------|-----------|--|
| input | Real | Input variable |
| tmLag1 | Real | Time constant for the first PT1 element (in seconds) |
| tmLag2 | Real | Time constant for the second PT1 element (in seconds) |
| tmLag3 | Real | Time constant for the third PT1 element (in seconds) |
| gain | Real | Gain factor |
| disturb | Real | Disturbance variable (applied at the “input” input) |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| reset | Bool | Resets all relevant parameters (including “output” = “input”). |


Output parameters

Table 2-11

| Parameter | Data type | Description |
|-----------|-----------|--|
| error | Bool | If one of the time constants ≤ 0 , "error" = TRUE will be set. |
| status | Word | If one of the time constants ≤ 0 , "status" = 16#8001 will be output. |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

Figure 2-11: PT3 element step response



2.2.6 FB „LSim_PDT1“ (FB55)


FB “LSim_PDT1” (FB55) simulates the behavior of a PDT1 element (generic rational first-order element).

Transfer function

$$F(p) = \frac{gain * (1 + tmLag2 * p)}{(1 + tmLag1 * p)}$$

Figure

Figure 2-12



Input parameters

Table 2-12

| Parameter | Data type | Description |
|-----------|-----------|---|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1”, “tmLag2”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | First time constant (in seconds) |
| tmLag2 | Real | Second time constant (in seconds) |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |


Output parameters

Table 2-13

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If one of the time constants ≤ 0 , "error" = TRUE will be set. |
| status | Word | If one of the time constants ≤ 0 , "status" = 16#8001. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = GAIN \left(1 + \frac{(tmLag2 - tmLag1)}{tmLag1} * e^{-\frac{t}{tmLag1}} \right); \text{ } tmLag1 > 0$$

Figure 2-13: PDT1 element step response ($tmLag1/tmLag2 < 1$)

2.2.7 FB „LSim_I“ (FB56)

FB “LSim_I” (FB56) simulates a simple integrating system.

Use case


An I element can be used, for example, to simulate a fill level system (container).

Transfer function

$$F(p) = \frac{1}{(tmLag1 * p)}$$

Figure

Figure 2-14



Input parameters

Table 2-14

| Parameter | Data type | Description |
|-----------|-----------|--|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Integral action time (in seconds) |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |

Output parameters


Table 2-15

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the integral action time ≤ 0 , "error" = TRUE will be set. |
| status | Word | If the integral action time ≤ 0 , "status" = 16#8001. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = \frac{t}{tmLag1}, \quad t \geq 0$$

Figure 2-15: I element step response



2.2.8 FB „LSim_IT1” (FB 57)

FB “LSim_IT1” (FB57) simulates a delayed integrator.

Use case


An IT1 element can be used, for example, to simulate a valve with servomotor.

Transfer function

$$F(p) = \frac{gain}{p * (tmLag1 * p + 1)}$$

Figure

Figure 2-16



Input parameters

Table 2-16

| Parameter | Data type | Description |
|-----------|-----------|--|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Integral action time (in seconds) |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |

Output parameters

Table 2-17

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the integral action time <= 0, "error" = TRUE will be set. |
| status | Word | If the integral time <= 0, "status" = 16#8001. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain[t - tmLag1(1 - e^{\frac{-t}{tmLag1}})]$$

Figure 2-17: IT1 element step response




2.2.9 FB „LSim_TempProcess” (FB58)

FB “LSim_TempProcess” (FB58) simulates an asymmetrical temperature process that can be actively heated (using aids) and cooled (both actively and passively).

Connection diagram


FB “LSim_TempProcess” (FB58) uses the following equivalent connection diagram:

Figure 2-18



Figure

Figure 2-19



Parameters

Table 2-18

| Parameter | Data type | Description |
|---------------|-----------------|---|
| inTemp | IN: Real | Temperature input value (usable only when “useHeatPow” = FALSE) |
| useHeatPow | IN: Bool | FALSE: “inTemp” is used as the heat source TRUE: “heatPow” in conjunction with “activHeat” is used as the heat source. |
| activHeat | IN: Bool | Activate heating with “heatPow” (usable only when “useHeatPow” = TRUE) |
| activCoolRth | IN: Bool | Active cooling to ambient temperature via internal thermal resistance “statRThCool” |
| activCoolPow | IN: Bool | Active cooling via cooling power “coolPow” (even below ambient temperature) |
| coolPow | IN: Real | Cooling power as a positive value in W (active only when “activCoolPow” = TRUE) |
| ambTemp | IN: Real | Ambient temperature |
| cycle | IN: Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| reset | IN: Bool | Reset all relevant parameters (“outTemp” = “ambTemp”). |
| heatPow | INOUT: Real | Heating power in W (as an input when “useHeatPow” = TRUE and “activHeat” = TRUE / as an output when “useHeatPow” = FALSE) |
| outTemp | OUT: Real | Output temperature |
| interTemp | OUT: Real | Intermediate temperature (auxiliary quantity) |
| statRthTrans1 | Static: Real | Input thermal resistance in K/W (active only when “useHeatPow” = FALSE) |
| statRth1 | Static: Real | Thermal resistance parallel to thermal capacity 1 in K/W |
| statRthTrans2 | Static: Real | Thermal resistance for heat flow between thermal capacity 1 and 2 in K/W |
| statRth2 | Static: Real | Thermal resistance parallel to thermal capacity 2 in K/W |
| statRthCool | Static: Real | Thermal resistance for active cooling in K/W (active only when “activCoolRth” = TRUE) |
| statCth1 | Static: Real | Thermal capacity 1 in Ws/K |
| statCth2 | Static: Real | Thermal capacity 2 in Ws/K |

Possible applications

The following applications can be implemented with FB “LSim_TempProcess” (heating and cooling can also be combined):

Table 2-19: Selection of heating options (1 out of 3)

| Heating | via power input “heatPow” | | via temperature input “inTemp” (for an example, see Figure 2-20) |
|------------|----------------------------|----------------------------|---|
| Parameter | analog | PWM signal | |
| inTemp | irrelevant | irrelevant | variable input quantity |
| useHeatPow | TRUE | TRUE | FALSE |
| activHeat | TRUE | PWM signal | irrelevant |
| heatPow | variable input quantity | constant input quantity | output quantity |

Table 2-20: Selection of cooling options with power setting (1 out of 2)

| Cooling even below ambient temperature (with cooling power setting) | | |
|---|-------------------------|-------------------------|
| Parameter | analog | PWM signal |
| activCoolPow | FALSE | PWM signal |
| coolPow | variable input quantity | constant input quantity |


Table 2-21: Selection of cooling options via thermal resistance (coexistent)

| Cooling to ambient temperature (via thermal resistance) | | |
|---|-------------|----------|
| Parameter | Active | Passive |
| Thermal resistance | statRthCool | statRth2 |
| activCoolRth | TRUE | |

Cascading

To map more complex processes, “LSim_TempProcess” can also be cascaded as follows:

Figure 2-20: Thermal influence of neighboring processes (cascade)



The first process is heated. The determined temperature “outTemp” of the first instance (DB1) is used as the input temperature “inTemp” of the second instance (DB2). This requires that input “useHeatPow” (DB2) be reset (FALSE). Therefore, the second process extracts energy from the first process. This means that the determined power “heatPow” of the second instance (DB2) must be returned to the first instance as cooling power “coolPow”. This requires that input “activCoolPow” (DB1) be set (TRUE).

Each process can be additionally cooled passively with “activCoolRth” via the thermal resistance. The second process, in turn, can be cooled actively via “coolPow” in conjunction with “activCoolPow” (for example, by the next instance).

2.2.10 FB „LSim_Lagging” (FB59)

FB “LSim_Lagging” (FB59) simulates a lag element.

Use case


FB “Sim_Lagging” (FB59) allows you to simulate, for example, conveyor systems.

Transfer function

$$F(p) = e^{-p * \text{delayCycles} * \text{cycle}}$$

Figure

Figure 2-21



Parameters


Table 2-22

| Parameter | Data type | Description |
|-------------|---------------|---|
| input | IN: Real | Input variable |
| delayCycles | INOUT: UInt | Number of cycles by which the input signal is delayed (max. internal constant “MAX”; when exceeded, “delayCycles” = “MAX” will be set). |
| output | OUT: Real | Output variable |
| MAX | Constant: Int | Upper limit of the field for buffering the input signal (default: 100) |

Step response

$$y(t) = u(t - \text{delayCycles} * \text{cycle})$$

Figure 2-22: Lag element step response



2.2.11 FB „LSim_DT1“ (FB60)


FB “LSim_DT1” (FB60) simulates a delaying derivative action element.

Transfer function

$$F(p) = \frac{gain * tmLag2 * p}{(tmLag1 * p + 1)}$$

Figure

Figure 2-23



Input parameters

Table 2-23

| Parameter | Data type | Description |
|-----------|-----------|---|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1”, “tmLag2”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Derivative action time |
| tmLag2 | Real | Delay time |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |

Output parameters


Table 2-24

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the derivative action time ≤ 0 , "error" = TRUE will be set. |
| status | Word | If the derivative action time ≤ 0 , "status" = 16#8001. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = \frac{tmLag2}{tmLag1} e^{-\frac{t}{tmLag1}}, \quad t \geq 0$$

Figure 2-24: DT1 element step response



2.2.12 FB „LSim_AllPass1OrdReal” (FB61)

FB “LSim_AllPass1OrdReal” (FB61) simulates a first-order all-pass with real zeros.

Transfer function

$$F(p) = \frac{gain * (1 - tmLag1 * p)}{(1 + tmLag1 * p)}$$

Figure

Figure 2-25



Input parameters

Table 2-25

| Parameter | Data type | Description |
|-----------|-----------|--|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Time constant |
| gain | Real | Gain factor |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |

Output parameters


Table 2-26

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the time constant <= 0, "error" = TRUE will be set. |
| status | Word | If the time constant <= 0, "status" = 16#8001. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain * (1 - 2 * e^{\frac{t}{tmLag}})$$

Figure 2-26



2.2.13 FB „LSim_AllPass2OrdReal” (FB62)


FB “LSim_AllPass2OrdReal” (FB62) simulates a second-order all-pass with real zeros.

Transfer function

$$F(p) = \frac{gain * (1 - tmLag1 * p) * (1 - tmLag2 * p)}{(1 + tmLag1 * p) * (1 + tmLag2 * p)}$$

Figure

Figure 2-27



Input parameters

Table 2-27

| Parameter | Data type | Description |
|-----------|-----------|---|
| calcParam | Bool | Recalculation of the internal parameters (activation required when “tmLag1”, “tmLag2”, “gain” or “cycle” changes) |
| input | Real | Input variable |
| tmLag1 | Real | Time constant for the first PT1 element (in seconds) |
| tmLag2 | Real | Time constant for the second PT1 element (in seconds) |
| gain | Real | Gain factor |
| disturb | Real | Disturbance variable (applied at the “input” input) |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| maxOut | Real | Maximum limit of the output signal (when the signal is above the maximum limit, “output” = “maxOut” will be set) |
| minOut | Real | Minimum limit of the output signal (when the signal is below the minimum limit, “output” = “minOut” will be set) |
| reset | Bool | Resets all relevant parameters to ‘0’, including “output”. |

Output parameters


Table 2-28

| Parameter | Data type | Description |
|------------|-----------|---|
| error | Bool | If the time constants are identical or <= 0, "error" = TRUE will be set. |
| status | Word | If the time constants are identical or <= 0, "status" = 16#8001 will be output. |
| maxReached | Bool | When "maxReached" = TRUE, the "output" output variable was limited to the maximum value "maxOut". |
| minReached | Bool | When "minReached" = TRUE, the "output" output variable was limited to the minimum value "minOut". |
| output | Real | Output variable (valid only when "error" = FALSE) |

Step response

$$y(t) = gain * (1 + K * e^{\frac{t}{tmLag1}} - K * e^{\frac{t}{tmLag1} - \frac{t}{tmLag2}}), \text{ with } K = \frac{2*(tmLag1+tmLag2)}{tmLag2-tmLag1}$$

Figure 2-28




2.2.14 FB „LSim_Valve” (FB63)

FB “LSim_Valve” (FB62) simulates a valve with adjustable travel time.

Figure

Figure 2-29



Input parameters

Table 2-29

| Parameter | Data type | Description |
|-------------|-----------|---|
| inputUp | Real | “Open valve” control signal |
| inputDn | Real | “Close valve” control signal |
| inputPer | Int | Analog manipulated variable |
| perOn | Bool | Selection switch to set whether “inputUp” / “inputDn” or “inputPer” will be used (when TRUE, “inputPer” will be used) |
| perMax | Real | Upper limit of the analog value of the valve position |
| perMin | Real | Lower limit of the analog value of the valve position |
| realMax | Real | Upper limit of the converted floating-point value for the valve position |
| realMin | Real | Lower limit of the converted floating-point value for the valve position |
| transitTime | Real | Travel time of the valve between the end positions |
| cycle | Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| reset | Bool | Resets “output” to “realMin” |

Output parameters

Table 2-30

| Parameter | Data type | Description |
|-----------|-----------|--|
| output | Real | Calculated valve position (within the “realMin” and “realMax” limits) |
| outputPer | Int | Calculated analog valve position (within the “perMin” and “perMax” limits) |
| highLimit | Bool | Simulated upper valve end position reached when “highLimit” = TRUE. |
| lowLimit | Bool | Simulated lower valve end position reached when “lowLimit” = TRUE. |


2.2.15 FB „LSim_PT3HeatCool“ (FB 64)

FB “LSim_PT3HeatCool” (FB64) simulates a PT3 temperature system. The block has separate inputs for heating and cooling.

Use case

The block can be used to simulate a temperature system (for example, with the “PID_Temp” technology object).


Figure 2-30: Sample control loop “PID_Temp” with “LSim_PT3HeatCool”



Connection diagram

FB “LSim_PT3HeatCool” (FB64) uses the following equivalent connection diagram:

Figure 2-31: Structure and parameters of the “LSim_PT3HeatCool” system block



Figure

Figure 2-32


**Parameters**

Table 2-31

| Parameter | Data type | Description |
|--------------|-------------|--|
| inputHeat | IN: Real | Input variable (heat) |
| inputCool | IN: Real | Input variable (cool) |
| disturbHeat | IN: Real | Disturbance variable (heat); applied at the "inputHeat" input |
| disturbCool | IN: Real | Disturbance variable (cool); applied at the "inputCool" input |
| ambTemp | IN: Real | Ambient temperature |
| gainHeat | IN: Real | Gain factor (heat) |
| gainCool | IN: Real | Gain factor (cool) |
| tmLag(x)Heat | IN: Real | x-order lag factor (heat) |
| tmLag(x)Cool | IN: Real | x-order lag factor (cool) |
| cycle | IN: Real | Cycle time of the calling cyclic interrupt OB (in seconds) |
| reset | INOUT: Bool | Reset all relevant parameters ("output" = "ambTemp"); "reset" will be reset autonomously |
| output | OUT: Real | Output variable (valid only when "error" = FALSE) |

3 Working with the Library

What will you find in this section?

This chapter consists of instructions for integrating the „LSim“ library into your STEP 7 project and instructions for using the library blocks.


3.1 Integrating the library into STEP 7

The table below lists the steps for integrating the „LSim“ library into your STEP 7 project. Subsequently, you can use the blocks of the „LSim“ library.

Note

The following section assumes that a STEP 7 project exists.


Table 3-1

| No. | Action | Note |
|-----|---|---|
| 1. | Download the “79047707_LSim_LIB_v20.zip” file and extract the file on your engineering station. | |
| 2. | In the right-hand pane, open the “Libraries” tab and click “Open global library”. Navigate to the storage location of the extracted folder and double-click to open the “LSim” file. |  <p>The screenshot shows two windows. The top window is titled "Global libraries" and displays a tree view with nodes like "Bit-and-Switches", "Logic functions", "Monitoring-and-control-objects", "Documentation templates", and "WinAC_MP". A red circle with the number 1 points to the "Open global library" button at the top of the tree view. The bottom window is titled "Open global library" and shows a file selection dialog. It has a "Look in:" dropdown set to "LSim" and a "Name" dropdown set to "AdditionalFiles". Below these are icons for "Recent Places", "Desktop", and "Libraries". In the "Libraries" section, there is a list of files: "AdditionalFiles", "IM", "System", "TMP", "UserFiles", and "LSim.all3". A red circle with the number 2 points to the "LSim.all3" file in the list.</p> |

3.2 Integrating the library blocks into STEP 7

The table below lists the steps for integrating the blocks of the „LSim“ library into your STEP 7 program.

Table 3-2

| No. | Action | Note |
|-----|--|--|
| 1. | Use drag and drop to drag the simulation blocks you want to use from the “Master copies” of the library to the program blocks folder of your user program. |  |
| 2. | Now you can use the inserted blocks in your user program to simulate systems. | |

3.3 Interconnecting controlling elements

Controlled system

As an example, we will implement a controlled system with the following controlling elements:

Figure 3-1 Controlled system




Table 3-3

| No. | Action | Note |
|-----|--|---|
| 1. | Add the controlling elements you want to use as described in Table 3-2 . In this example, these are the following controlling elements: <ul style="list-style-type: none"> • PT1 (FB “LSim_PT1”) • PDT1 (FB “LSim_PDT1”) • Lag element (FB “LSim_Lagging”) • PT2 in the periodic case (FB “LSim_PT2osc”) | |
| 2. | Insert the function blocks into your cyclic interrupt OB and between each call, leave one network free for the MOVE commands. | |
| 3. | Use MOVE commands to interconnect the outputs of the controlling elements with the input of the respective following controlling element. | <p>MOVE ... — EN — "Scenario2Tags". PT1.output — OUT1 — PDT1.input — IN — ENO —</p> |
| 4. | Now you have set up a complete controlled system. Note If you want to monitor the controlled system, you can use the S7-1500 “Traces” function. | <p>Time axis: 5.0, 10.0, 15.0, 20.0, 25.0, 30.0, 35.0 Y-axis label: t=1</p> |

4 Notes and Support

Overview

The “LSim” library is used to simulate controlled systems in STEP 7.

Examples

The documentation “Closed-Loop Control with PID_Compact V2.2” contains examples of how the blocks of the simulation library can be called and used.

The complete documentation, including the library and a sample project, can be downloaded at the following link:

<https://support.industry.siemens.com/cs/ww/en/view/79047707>

5 Related literature

Table 5-1

| | Topic |
|-----|---|
| \1\ | Siemens Industry Online Support https://support.industry.siemens.com |
| \2\ | Download page of this entry https://support.industry.siemens.com/cs/ww/en/view/79047707 |
| \3\ | Function Manual: SIMATIC S7-1200, S7-1500 PID Control https://support.industry.siemens.com/cs/ww/en/view/108210036 |
| \4\ | Application Example: „Single and Multi Loop Controller Structures (Cascade Control) with PID_Temp“ https://support.industry.siemens.com/cs/ww/en/view/103526819 |
| \5\ | Application Example: “3-Point Stepper Control with SIMATIC S7-1500” https://support.industry.siemens.com/cs/ww/en/view/68011827 |
| \6\ | Application Example: PID Control with PID_Compact (S7-1200) https://support.industry.siemens.com/cs/ww/en/view/100746401 |

6 History

Table 6-1

| Version | Date | Modifications |
|---------|---------|---|
| V1.0 | 08/2013 | First version |
| V1.1 | 12/2014 | “LSim_PT3HeatCool” block added |
| V2.0 | 03/2016 | Review and publication for STEP 7 V13 SP1 |