

# SIEMENS

## SIMATIC

ET 200SP  
Technology Module  
TM Count 1x24V  
(6ES7138-6AA00-0BA0)  
Manual

Preface

---

Documentation guide

---

1

Product overview

---

2

Wiring

---

3

Configuring/address space

---

4

Interrupts/diagnostic  
messages

---

5

Technical specifications

---

6

Parameter data records




---

A

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.
 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.
 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.
<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Preface

## Purpose of the documentation

This manual includes module-specific information on wiring, diagnostics and the technical specifications of the technology module.

General information regarding design and commissioning of the ET 200SP is available in the ET 200SP system manual.

The counting and measuring functions of the TM Count 1x24V technology module are described in more detail in the Counting, Measurement and Position Detection (<http://support.automation.siemens.com/WW/view/en/59709820>) function manual.

## Conventions

Please observe notes marked as follows:

---

### Note

A note contains important information on the product described in the documentation, on the handling of the product and on the section of the documentation to which particular attention should be paid.

---

## Security information

Siemens provides automation and drive products with industrial security functions that support the secure operation of plants or machines. They are an important component in a holistic industrial security concept. With this in mind, our products undergo continuous development. We therefore recommend that you keep yourself informed with respect to our product updates. Please find further information and newsletters on this subject at: <http://support.automation.siemens.com>.

To ensure the secure operation of a plant or machine it is also necessary to take suitable preventive action (e.g. cell protection concept) and to integrate the automation and drive components into a state-of-the-art holistic industrial security concept for the entire plant or machine. Any third-party products that may be in use must also be taken into account. Please find further information at: <http://www.siemens.com/industrialsecurity>

### Copyright notice for the open-source software used

Open-source software is used in the firmware of the product described. The open-source software is provided free of charge. We are liable for the product described, including the open-source software contained in it, pursuant to the conditions applicable to the product. Siemens accepts no liability for the use of the open source software over and above the intended program sequence, or for any faults caused by modifications to the software.

For legal reasons, we are obliged to publish the original text of the following copyright notices.

© Copyright William E. Kempf 2001

Permission to use, copy, modify, distribute and sell this software and its documentation for any purpose is hereby granted without fee, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation. William E. Kempf makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

Copyright © 1994 Hewlett-Packard Company

Permission to use, copy, modify, distribute and sell this software and its documentation for any purpose is hereby granted without fee, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation. Hewlett-Packard Company makes no representations about the suitability of this software for any purpose. It is provided ``as is" without express or implied warranty.

# Table of contents

	<b>Preface .....</b>	<b>3</b>
<b>1</b>	<b>Documentation guide .....</b>	<b>7</b>
<b>2</b>	<b>Product overview.....</b>	<b>9</b>
	2.1 Properties .....	9
	2.2 Functions .....	12
	2.2.1 Detection of counting signals.....	12
	2.2.2 Measured value determination.....	14
	2.2.3 Switching the outputs at comparison values.....	15
	2.2.4 Position input for Motion Control.....	15
	2.2.5 Additional functions .....	16
<b>3</b>	<b>Wiring .....</b>	<b>17</b>
	3.1 Pin assignment.....	17
<b>4</b>	<b>Configuring/address space .....</b>	<b>23</b>
	4.1 Configuring.....	23
	4.2 Reaction to CPU STOP .....	25
	4.3 Address space .....	26
	4.4 Control and feedback interface.....	27
	4.4.1 Assignment of the control interface.....	27
	4.4.2 Assignment of the feedback interface .....	29
<b>5</b>	<b>Interrupts/diagnostic messages.....</b>	<b>31</b>
	5.1 Status and error displays.....	31
	5.2 Diagnostic messages .....	34
	5.3 Interrupts.....	36
	5.3.1 Trigger a diagnostic interrupt.....	36
	5.3.2 Cause of the error triggering a diagnostic interrupt.....	37
	5.3.3 Triggering of a Hardware Interrupt.....	38
	5.3.4 Events which can trigger a hardware interrupt .....	39
<b>6</b>	<b>Technical specifications .....</b>	<b>41</b>
<b>A</b>	<b>Parameter data records.....</b>	<b>49</b>



# Documentation guide

## Introduction

This modular documentation of the SIMATIC products covers diverse topics concerning your automation system.

The complete documentation for the ET 200SP and S7-1500 systems consists of the respective system manuals, function manuals and device manuals.

The STEP 7 information system (TIA Portal) also helps you configure and program your automation system.

## Overview of the documentation provided for technology module TM Count 1x24V

The following table lists further documentation that you will need when using the TM Count 1x24V technology module.

Table 1- 1 Documentation for technology module TM Count 1x24V

Topic	Documentation	Most important contents
System description	System manual ET 200SP distributed I/O system ( <a href="http://support.automation.siemens.com/WW/view/en/58649293">http://support.automation.siemens.com/WW/view/en/58649293</a> )	<ul style="list-style-type: none"> <li>• Application planning</li> <li>• Installing</li> <li>• Connecting</li> <li>• Commissioning</li> </ul>
	System manual S7-1500 Automation System ( <a href="http://support.automation.siemens.com/WW/view/en/59191792">http://support.automation.siemens.com/WW/view/en/59191792</a> )	
	Device manual ET 200SP Interface Module ( <a href="http://support.automation.siemens.com/WW/view/en/55683316/133300">http://support.automation.siemens.com/WW/view/en/55683316/133300</a> )	<ul style="list-style-type: none"> <li>• Connecting</li> <li>• Interrupts, diagnostics, error, and system alarms</li> <li>• Technical specifications</li> <li>• Dimensional drawing</li> </ul>
	Device manual ET 200SP BaseUnits ( <a href="http://support.automation.siemens.com/WW/view/en/58532597/133300">http://support.automation.siemens.com/WW/view/en/58532597/133300</a> )	<ul style="list-style-type: none"> <li>• Technical specifications</li> </ul>
Interference-free installation of control systems	Function manual Interference-free Installation of Control Systems ( <a href="http://support.automation.siemens.com/WW/view/en/59193566">http://support.automation.siemens.com/WW/view/en/59193566</a> )	<ul style="list-style-type: none"> <li>• Basics</li> <li>• Electromagnetic compatibility</li> <li>• Lightning protection</li> </ul>

Topic	Documentation	Most important contents
Counting and measuring	Function manual Counting, Measurement and Position Detection ( <a href="http://support.automation.siemens.com/WW/view/en/59709820">http://support.automation.siemens.com/WW/view/en/59709820</a> )	<ul style="list-style-type: none"><li>• Counting functions</li><li>• Measuring functions</li><li>• Position detection</li><li>• Control and feedback interface</li></ul>
Motion Control	Function manual S7-1500 Motion Control ( <a href="http://support.automation.siemens.com/WW/view/en/59381279">http://support.automation.siemens.com/WW/view/en/59381279</a> )	<ul style="list-style-type: none"><li>• Configuration</li><li>• Programming</li><li>• Commissioning</li><li>• Diagnostics</li></ul>

### SIMATIC manuals

All current manuals for the SIMATIC products are available for download free of charge from the Internet (<http://www.siemens.com/automation/service&support>).



## Product overview

### 2.1 Properties

#### Order number

6ES7138-6AA00-0BA0

#### View of the module




Figure 2-1 View of the TM Count 1x24V module

## Properties

The TM Count 1x24V technology module has the following properties:

- Technical properties
  - One channel
  - Interfaces:
    - 24 V encoder signals A, B and N from sourcing, sinking or push pull encoders and sensors
    - 24 V encoder supply output, short-circuit proof
    - DI0, DI1 and DI2 digital input signals
    - DQ0 and DQ1 digital output signals
    - L+ supply voltage
  - Count range: 32 bits
  - Monitoring of encoder signals for wire break
  - Hardware interrupts configurable
  - Input filters for suppression of interferences at encoder inputs and digital inputs can be configured
- Supported encoder/signal types
  - 24 V incremental encoder with and without N signal
  - 24 V pulse encoder with direction signal
  - 24 V pulse encoder without direction signal
  - 24 V pulse encoders for up & down pulses
- Supported system functions
  - Isochronous mode
  - Firmware Update
  - Identification data I&M

## Accessories

The following accessories can be used with the module and are not included in the scope of delivery:

- Labeling strip
- Color identification labels
- Reference identification labels
- Shield connector

A BaseUnit of the A0 type is required to operate the technology module. For an overview of the BaseUnits that you can use with the technology module, please refer to the product information on the documentation for the ET 200SP Distributed I/O System (<http://support.automation.siemens.com/WW/view/en/73021864>).

For detailed information on the installation procedure, refer to the ET 200SP Distributed I/O System (<http://support.automation.siemens.com/WW/view/en/58649293>) system manual.

## 2.2 Functions

### 2.2.1 Detection of counting signals

Counting refers to the detection and summation of events. The counters of the technology module detect encoder signals and pulses and evaluate them accordingly. The count direction can be specified using encoder or pulse signals or through the user program.

You can control the counting processes with the digital inputs.

You can specify the counter characteristics using the functions described below.

#### Counting limits

The counting limits define the counter value range used. The counting limits are configurable and can be modified during runtime with the user program.

The maximum possible counting limit is 2147483647 ( $2^{31}-1$ ). The minimum possible counting limit is -2147483648 ( $-2^{31}$ ).

You can configure the response of the counter at the counting limits:

- Continue or stop counting upon violation of a counting limit (automatic gate stop)
- Set counter value to start value or to other counting limit upon violation of a counting limit

#### Start value

You can configure a start value within the counting limits. The start value can be modified during runtime with the user program.

Depending on the parameter assignment, the technology module can set the current counter value to the start value upon synchronization, upon Capture function activation, upon violation of a counting limit or when the gate is opened.

#### Gate control

Opening and closing the hardware gate and software gate defines the period of time during which the counting signals are captured.

The control of the hardware gate takes place externally via the digital inputs of the technology module. Control of the software gate takes place via the user program. The hardware gate can be enabled through parameter assignment. The software gate (bit in the control interface of the cyclic I/O data) cannot be disabled.

## **Capture**

You can configure an external reference signal edge that triggers the saving of the current counter value as Capture value. The following external signals can trigger the Capture function:

- Rising or falling edge of a digital input
- Both edges of a digital input
- Rising edge of the N signal at the encoder input

You can configure whether counting continues from the current counter value or from the start value after the Capture function.

## **Synchronization**

You can configure the edge of an external reference signal to load the counter with the specified start value. The following external signals can trigger a synchronization:

- Rising or falling edge of a digital input
- Rising edge of the N signal at the encoder input
- Rising edge of the N signal at the encoder input depending on the level of the assigned digital input

## **Hysteresis**

You can specify hysteresis for the comparison values, within which a digital output will be prevented from switching again. An encoder can come to a standstill at a specific position, and slight movements may make the counter value fluctuate around this position. If a comparison value or a counting limit lies within this fluctuation range, the corresponding digital output will be switched on and off with corresponding frequency if hysteresis is not used. The hysteresis prevents these unwanted switching operations.

### 2.2.2 Measured value determination

The following measuring functions are available:

Measurement type	Description
Frequency measurement	The mean frequency is calculated at set measuring intervals on the basis of the time profile of the count pulses and returned in hertz as the floating point number.
Period measurement	The mean period duration is calculated at set measuring intervals on the basis of the time profile of the count pulses and returned in seconds as the floating point number.
Velocity measurement	The mean velocity is calculated at set measuring intervals on the basis of the time profile of the count pulses and other parameters, and returned in the configured unit of measurement.

The measured value and the counter value are available concurrently in the feedback interface.

#### Update time

You can configure the interval at which the technology module updates the measured values cyclically as the update time. Setting longer update time intervals allows uneven measured variables to be smoothed and increases measuring accuracy.

#### Gate control

Opening and closing the hardware gate and software gate defines the period of time during which the counting signals are captured. The update time is asynchronous to the opening of the gate, which means that the update time is not started when the gate is opened. After closing, the last measured value captured continues to be returned.

#### Measuring ranges

The measuring functions have the following measuring range limits:

Measurement type	Low measuring range limit	High measuring range limit
Frequency measurement	0.04 Hz	800 kHz*
Period measurement	1.25 µs*	25 s
Velocity measurement	Depends on the configured number of "increments per unit" and the "time base for velocity measurement"	

\* Applies to 24 V incremental encoders and "quadruple" signal evaluation.

All measured values are returned as signed values. The sign indicates whether the counter value increased or decreased during the relevant time period.

### 2.2.3 Switching the outputs at comparison values

You define two comparison values that can control the two digital outputs independent of the user program. The comparison values are configurable and can be modified during runtime with the user program.

#### Comparison values in the Counting mode

You define two comparison values in the Counting mode. If the current counter value meets the configured comparison condition, the corresponding digital output can be set to directly initiate control processes in the process.

#### Comparison values in the Measuring mode

You define two comparison values in the Measuring mode. If the current measured value meets the configured comparison condition, the corresponding digital output can be set to directly initiate control processes in the process.

### 2.2.4 Position input for Motion Control

You can use the technology module with an incremental encoder for position detection with S7-1500 Motion Control . Position detection is based on the counting function of the technology module which evaluates the captured encoder signals and sends them to the S7-1500 Motion Control.

In the device configuration of the technology module in STEP 7 (TIA Portal), select "Position detection for Motion Control".

#### Additional information

A detailed description of the use of Motion Control and its configuration is available in the function manual S7-1500 Motion Control as a download from the Internet (<http://support.automation.siemens.com/WW/view/en/59381279>).

## 2.2.5 Additional functions

### Hardware interrupts

The technology module can trigger a hardware interrupt in the CPU, for example, if a compare event occurs, in the event of overflow or underflow, in the event of a zero crossing of the counter and/or of a change of count direction (direction reversal). You can specify which events (Page 39) are to trigger a hardware interrupt during operation.

### Diagnostic interrupt

The technology module can trigger a diagnostic interrupt in the event of a missing supply voltage or an error at the digital outputs, for example. Select the diagnostic interrupts (Page 37) in the device configuration freely.

### Input filter

To suppress interference, you can configure an input filter for the 24 V encoder inputs and for the digital inputs.

### Distributed application

You can use the technology module in a distributed system by means of an interface module in the ET 200SP distributed I/O device. The following applications are possible:

- Distributed operation in an S7-1500 system
- Distributed operation in an S7-1200 system
- Distributed operation in an S7-300/400 system
- Distributed operation in a third-party system

### Isochronous mode

The technology module supports the system function "Isochronous mode". This system function enables counter values and measured values to be acquired in a defined system cycle.

In isochronous mode, the cycle of the user program, the transmission of the input signals and processing in the technology module are synchronized. The output signals switch immediately if the relevant comparison condition is met. A change in the state of a digital input immediately affects the planned reaction of the technology module and changes the status bit of the digital input in the feedback interface (Page 29).

#### Data processing

The data that was transmitted to the technology module in the current bus cycle via the control interface takes effect when it is processed in the internal technology module cycle. The counter value and the measured value as well as status bits are captured at time  $T_i$  and made available in the feedback interface for retrieval in the current bus cycle.

In isochronous mode, there is always data consistency across all bytes in the feedback interface.



## Wiring

### 3.1 Pin assignment

The TM Count 1x24V is used with a BaseUnit of the A0 type.

The encoder signals, the digital input and output signals and the encoder supply are connected to the BaseUnit of the technology module. The supply voltage feed on the light BaseUnit BU...D of the associated potential group supplies the module and the digital outputs, and generates the encoder supply voltage.

#### BaseUnit

The BaseUnit is not included in the scope of delivery of the module and must be ordered separately.

For an overview of the BaseUnits to be used with the technology module, refer to the product information on the documentation for the ET 200SP Distributed I/O System (<http://support.automation.siemens.com/WW/view/en/73021864>).

You can find information about selecting a suitable BaseUnit in the ET 200SP Distributed I/O System (<http://support.automation.siemens.com/WW/view/en/58649293>) system manual and ET 200SP BaseUnits (<http://support.automation.siemens.com/WW/view/en/58532597/133300>) device manual.


You can find information on wiring the BaseUnit, connecting cable shields, etc. in the Connecting section of the ET 200SP Distributed I/O System (<http://support.automation.siemens.com/WW/view/en/58649293>) system manual.

3.1 Pin assignment

**Terminal assignment of the BaseUnit**

The table below shows the pin assignment, using the BaseUnit BU15-P16+A0+2B as an example.

Table 3- 1 Pin assignment of the BaseUnit BU15-P16+A0+2B

View	Signal name		Designation					
			24 V incremental encoder		24 V pulse encoder			
			With signal N	Without signal N	with direction signal	without direction signal	up/down	
	1	A	Encoder signal A		Counting signal A		Up counting signal A	
	3	B	Encoder signal B		Direction signal B	—	Down counting signal B	
	5	N	Encoder signal N	—				
	2	DI0	Digital input DI0					
	4	DI1	Digital input DI1					
	6	DI2	Digital input DI2					
	8	DQ0	Digital output DQ0					
	10	DQ1	Digital output DQ1					
	7	—	—					
	9	—	—					
	11	—	—					
	13	—	—					
	<b>Supply voltage, encoder supply and ground</b>							
	15	24VDC	24 V encoder supply					
	12	M	Ground for encoder supply, digital inputs and digital outputs					
	14	M						
16	M							
	L+	DC 24V Supply voltage						
	M	Ground for supply voltage						

**Block diagram**

The figure below shows the block diagram of the technology module with a connected incremental encoder.

You must ground the shields of the cables between encoder and technology module both through the shield terminal on the BaseUnit (shield bracket and terminal) and also on the encoder.




Figure 3-1 Block diagram with incremental encoder

### L+/M supply voltage

Connect the supply voltage (DC 24V) to the L+ and M connections. An internal protective circuit protects the technology module from polarity reversal of the supply voltage. The technology module monitors the connection of the supply voltage.

### 24VDC encoder supply

To supply the encoder and sensors at the digital inputs, the technology module supplies the DC 24V supply voltage at the 24VDC output with reference to M. Voltage is supplied from the L+/M supply voltage and monitored for short circuits and overload.

### 24 V encoder signals/count signals

The 24 V encoder signals are designated A, B and N. You can connect the following encoder types:

- Incremental encoder with signal N:  
The signals A, B and N are connected by means of the correspondingly labeled terminals. Signals A and B are the two incremental signals phase-shifted by 90°. N is the zero mark signal which returns one pulse per revolution.
- Incremental encoder without signal N:  
The signals A and B are connected by means of the correspondingly labeled terminals. Signals A and B are the two incremental signals phase-shifted by 90°. The N terminal remains disconnected.
- Pulse encoders without direction signal:  
The counting signal is connected to the A terminal. The count direction is specified via the control interface. The B and N terminals remain disconnected.
- Pulse encoders with direction signal:  
The counting signal is connected to the A terminal. The direction signal is connected to the B terminal. The N terminal remains disconnected.
- Pulse encoders with counting signal up/down:  
The up counting signal is connected to the A terminal. The down counting signal is connected to the B terminal. The N terminal remains disconnected.

The inputs are not electrically isolated from each other. The inputs are isolated against the backplane bus.

You can connect the following encoders or sensors at inputs A, B and N:

- Sourcing output:  
The inputs A, B and N are switched by the encoder or sensor after 24VDC .
- Sinking output:  
The inputs A, B and N are switched by the encoder or sensor after ground M .
- Push pull:  
The inputs A, B and N are switched by the encoder or sensor alternately after 24VDC and ground M . Monitoring for wire break is possible with this type of encoder/sensor. The wire break detection procedure (alternate switching) allows the counter value to change in the event of an error (wire break) even without count pulses until the wire break is detected.

### Input filter for 24 V encoder signals

To suppress interferences, you can configure an input filter for the counting inputs A, B and N. The selected filter frequency is based on a pulse-break ratio of between 40:60 and 60:40. This produces a set minimum pulse/break time. Signal changes with a duration shorter than the minimum pulse/break time are suppressed.

You can specify the following values for the filter frequency:

Table 3- 2 Filter frequency and respective minimum pulse/break time

Filter frequency	Minimum pulse/break time
100 Hz	4.0 ms
200 Hz	2.0 ms
500 Hz	800 $\mu$ s
1 kHz	400 $\mu$ s
2 kHz	200 $\mu$ s
5 kHz	80 $\mu$ s
10 kHz	40 $\mu$ s
20 kHz	20 $\mu$ s
50 kHz	8.0 $\mu$ s
100 kHz	4.0 $\mu$ s
200 kHz (default)	2.0 $\mu$ s

### Digital inputs DI0, DI1 and DI2

There are three digital inputs. The digital inputs are used for gate control, synchronization and the Capture function. Alternatively, you can use one or more digital inputs without the mentioned functions and read the signal state of the respective digital input via the feedback interface.

The digital inputs are not electrically isolated from each other.

### Input filters for digital inputs

To suppress interferences, you can configure an input filter for the digital inputs.

You can specify the following values for the filter time:

- None
- 0.05 ms
- 0.1 ms (default)
- 0.4 ms
- 0.8 ms
- 1.6 ms
- 3.2 ms
- 12.8 ms
- 20 ms

---

#### Note

If you select the "None" or "0.05 ms" option, you have to use shielded cables for connection of the digital inputs.

---

### Digital outputs DQ0 and DQ1

There are two digital outputs. The two digital outputs DQ0 and DQ1 can be activated/switched directly by the specified comparison values or by the user program.

The digital outputs are not isolated from each other.

The digital outputs are 24 V sourcing outputs in reference to M and can carry a rated load current of 0.5 A. They are protected from overload and short-circuit.

---

#### Note

Relays and contactors can be connected direct without external circuitry. You can find information on the maximum possible operating frequencies and the inductive loads at the digital outputs in the section Technical specifications (Page 41).

---

## Configuring/address space

### 4.1 Configuring

#### Introduction

The technology module is configured and assigned parameters with the configuration software.

The technology module functions are controlled and monitored by the user program.

#### System environment

The technology module can be used in the following system environments:

Applications	Components required	Configuration software	In the user program
Distributed operation in an S7-1500 system	<ul style="list-style-type: none"> <li>S7-1500 automation system</li> <li>ET 200SP distributed I/O system</li> <li>TM Count 1x24V</li> </ul>	STEP 7 (TIA Portal): <ul style="list-style-type: none"> <li>Device configuration with hardware configuration (HWCN)</li> <li>Parameter setting with High_Speed_Counter technology object</li> </ul>	Counting and measuring functions: High_Speed_Counter instruction for the technology object
		STEP 7 (TIA Portal): Device configuration with hardware configuration (HWCN) in operating mode "Position Detection for Motion Control"	Control by means of a technology object
Distributed operation in an S7-300/400 or S7-1200 system	<ul style="list-style-type: none"> <li>S7-300/400 or S7-1200 automation system</li> <li>ET 200SP distributed I/O system</li> <li>TM Count 1x24V</li> </ul>	STEP 7 (TIA Portal): Device configuration and parameter settings with hardware configuration (HWCN) STEP 7: Device configuration and parameter settings with HSP	Direct access to the control and feedback interface (Page 27) of the TM Count 1x24V in the I/O data
Distributed operation in a third-party system	<ul style="list-style-type: none"> <li>Third-party automation system</li> <li>ET 200SP distributed I/O system</li> <li>TM Count 1x24V</li> </ul>	Third-party configuration software: Device configuration and parameter settings with GSD file	Direct access to the control and feedback interface (Page 27) of the TM Count 1x24V in the I/O data

### Additional information

A detailed description of the counting and measuring functions and their configuration is available:

- In the Counting, Measurement and Position Input Function Manual available as download on the Internet (<http://support.automation.siemens.com/WW/view/en/59709820>)
- In the STEP 7 (TIA Portal) information system under "Using technology functions > Counting, measurement and position detection" > Counting, measurement and position detection (S7-1500)"

A detailed description of the use of Motion Control and its configuration is available:

- In the S7-1500 Motion Control function manual available as a download from the Internet (<http://support.automation.siemens.com/WW/view/en/59381279>)
- In the STEP 7 (TIA Portal) information system under "Using technology functions > Motion Control > Motion Control (S7-1200, S7-1500)"

### Hardware Support Package

The Hardware Support Packages (HSP) are available for download from the Internet (<http://support.automation.siemens.com/WW/view/en/72341852>).

---

#### Note

If you integrate the TM Count 1x24V via HSP in an S7-300/400 system, you can use the "Isochronous mode" system function.

---

### GSD file

The GSD files for the ET 200SP distributed I/O system are available for download from the Internet (<http://support.automation.siemens.com/WW/view/en/57138621>).



## 4.2 Reaction to CPU STOP

### Reaction to CPU STOP

You set the response of the technology module to CPU STOP for each channel in the basic parameters of the device configuration.

Table 4- 1 Response of the technology module to CPU STOP depending on parameter assignment

<b>Basic parameters</b>	<b>Reaction to CPU STOP</b>
Continue operation	The technology module remains fully functional. Incoming count pulses are processed. The digital outputs continue to switch according to the parameter assignment.
Output substitute value	The technology module outputs the configured substitute values at the digital outputs until the next CPU STOP-RUN transition. The technology module is returned to its startup state after a STOP-RUN transition: The counter value is set to the start value and the digital outputs switch according to the parameter assignment.
Keep last value	The technology module outputs the values at the digital outputs that were valid when the transition to STOP took place until the next CPU STOP-RUN transition. The technology module is returned to its startup state after a STOP-RUN transition: The counter value is set to the start value and the digital outputs switch according to the parameter assignment.

## 4.3 Address space

### Address space of the technology module

Table 4- 2 Range of the input addresses and output addresses of the TM Count 1x24V

	<b>Inputs</b>	<b>Outputs</b>
Range	16 bytes	12 bytes

Table 4- 3 Range of the input and output addresses of the TM Count 1x24V in the "Position detection for Motion Control" mode

	<b>Inputs</b>	<b>Outputs</b>
Range	16 bytes	4 bytes

### Additional information

A description on how to use the control and feedback interface of TM Count 1x24V can be found in the section Control and feedback interface (Page 27).

## 4.4 Control and feedback interface

Information on using the control and feedback interface can be found in the section Configuring (Page 23).

A detailed description of the TM Count 1x24V control and feedback bits is available in the Counting, Measurement and Position Detection function manual which can be downloaded from the Internet (<http://support.automation.siemens.com/WWW/view/en/59709820>).

---

### Note

The control and feedback interface is compatible with the control and feedback interface of the TM Count 2x24V technology module of the S7-1500 automation system.

---

### 4.4.1 Assignment of the control interface

The user program uses the control interface to influence the behavior of the technology module.

#### Control interface

The following table shows control interface assignment:

Offset to the start address	Parameter	Meaning				
Bytes 0 to 3	Slot 0	Load value (the significance of the value is specified in LD_SLOT_0)				
Bytes 4 to 7	Slot 1	Load value (the significance of the value is specified in LD_SLOT_1)				
Byte 8	LD_SLOT_0*	Specifies the significance of the value in Slot 0				
		<b>Bit 3</b>	<b>Bit 2</b>	<b>Bit 1</b>	<b>Bit 0</b>	
		0	0	0	0	No action, idle
		0	0	0	1	Load counter value
		0	0	1	0	Reserve
		0	0	1	1	Load start value
		0	1	0	0	Load comparison value 0
		0	1	0	1	Load comparison value 1
		0	1	1	0	Load low counting limit
		0	1	1	1	Load high counting limit
		1	0	0	0	Reserve
		to				
1	1	1	1			

4.4 Control and feedback interface

Offset to the start address	Parameter	Meaning																																																											
Byte 8	LD_SLOT_1*	Specifies the significance of the value in Slot 1																																																											
		<table border="1"> <thead> <tr> <th>Bit 7</th> <th>Bit 6</th> <th>Bit 5</th> <th>Bit 4</th> <th></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>No action, idle</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Load counter value</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Reserve</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Load start value</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>0</td> <td>Load comparison value 0</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>Load comparison value 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>Load low counting limit</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>Load high counting limit</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td rowspan="2">Reserve</td> </tr> <tr> <td colspan="4">to</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td></td> </tr> </tbody> </table>	Bit 7	Bit 6	Bit 5	Bit 4		0	0	0	0	No action, idle	0	0	0	1	Load counter value	0	0	1	0	Reserve	0	0	1	1	Load start value	0	1	0	0	Load comparison value 0	0	1	0	1	Load comparison value 1	0	1	1	0	Load low counting limit	0	1	1	1	Load high counting limit	1	0	0	0	Reserve	to				1	1	1	1	
		Bit 7	Bit 6	Bit 5	Bit 4																																																								
		0	0	0	0	No action, idle																																																							
		0	0	0	1	Load counter value																																																							
		0	0	1	0	Reserve																																																							
		0	0	1	1	Load start value																																																							
		0	1	0	0	Load comparison value 0																																																							
		0	1	0	1	Load comparison value 1																																																							
		0	1	1	0	Load low counting limit																																																							
		0	1	1	1	Load high counting limit																																																							
		1	0	0	0	Reserve																																																							
to																																																													
1	1	1	1																																																										
Byte 9	EN_CAPTURE	Bit 7: Capture function enable																																																											
	EN_SYNC_DN	Bit 6: Enable synchronization down																																																											
	EN_SYNC_UP	Bit 5: Enable synchronization up																																																											
	SET_DQ1	Bit 4: Set DQ1																																																											
	SET_DQ0	Bit 3: Set DQ0																																																											
	TM_CTRL_DQ1	Bit 2: Enable technological function DQ1																																																											
	TM_CTRL_DQ0	Bit 1: Enable technological function DQ0																																																											
	SW_GATE	Bit 0: Software gate																																																											
Byte 10	SET_DIR	Bit 7: Count direction (for encoders without direction signal)																																																											
	–	Bits 2 to 6: Reserve; bits must be set to 0																																																											
	RES_EVENT	Bit 1: Reset of saved events																																																											
	RES_ERROR	Bit 0: Reset of saved error states																																																											
Byte 11	–	Bits 0 to 7: Reserve; bits must be set to 0																																																											

\* If values are loaded simultaneously via LD\_SLOT\_0 and LD\_SLOT\_1, the first value is taken internally from Slot 0 and then the value from Slot 1 is taken. This may lead to unexpected intermediate states.

## 4.4.2 Assignment of the feedback interface

The user program receives current values and status information from the technology module by means of the feedback interface.

### Feedback interface

The following table shows the assignment of the feedback interface:

Offset to the start address	Parameter	Meaning
Bytes 0 to 3	COUNT VALUE	Current counter value
Bytes 4 to 7	CAPTURED VALUE	The last acquired Capture value
Bytes 8 to 11	MEASURED VALUE	Current measured value
Byte 12	–	Bits 3 to 7: Reserve; set to 0
	LD_ERROR	Bit 2: Error when loading via control interface
	ENC_ERROR	Bit 1: Incorrect encoder signal
	POWER_ERROR	Bit 0: Supply voltage L+ too low
Byte 13	–	Bits 6 to 7: Reserve; set to 0
	STS_SW_GATE	Bit 5: Software gate state
	STS_READY	Bit 4: Technology module started up and configured
	LD_STS_SLOT_1	Bit 3: Load request for Slot 1 detected and carried out (toggling)
	LD_STS_SLOT_0	Bit 2: Load request for Slot 0 detected and carried out (toggling)
	RES_EVENT_ACK	Bit 1: Reset of event bits active
Byte 14	–	Bit 0: Reserve; set to 0
	STS_DI2	Bit 7: Status DI2
	STS_DI1	Bit 6: Status DI1
	STS_DI0	Bit 5: Status DI0
	STS_DQ1	Bit 4: Status DQ1
	STS_DQ0	Bit 3: Status DQ0
	STS_GATE	Bit 2: Status of internal gate
	STS_CNT	Bit 1: Count pulse detected within the last 0.5 s
STS_DIR	Bit 0: Direction of last counter value change	
Byte 15	STS_M_INTERVAL	Bit 7: Count pulse detected in previous measurement interval
	EVENT_CAP	Bit 6: Capture event has occurred
	EVENT_SYNC	Bit 5: Synchronization has occurred
	EVENT_CMP1	Bit 4: Comparison event for DQ1 has occurred
	EVENT_CMP0	Bit 3: Comparison event for DQ0 has occurred
	EVENT_OFLW	Bit 2: An overflow has occurred
	EVENT_UFLW	Bit 1: An underflow has occurred
	EVENT_ZERO	Bit 0: A zero pass has occurred



## Interrupts/diagnostic messages

### 5.1 Status and error displays

#### LEDs

The figure below shows you the LED displays (status and error displays) of TM Count 1x24V.




Figure 5-1 LEDs of the TM Count 1x24V

5.1 Status and error displays

**Meaning of the LED displays**

The following tables explain the meaning of the status and error displays. Remedial measures for diagnostic messages can be found in the section Diagnostic messages (Page 34).

Table 5- 1 Status and error displays DIAG











LED DIAG	Meaning	To correct or avoid errors
 Off	Backplane bus supply of the ET 200SP not OK	Check or switch on the supply voltage on the CPU or on the interface module.
 Flashes	Technology module not configured	---
 On	Technology module configured but no module diagnostics	
 Flashes	Technology module configured and module diagnostics (at least one error pending)	Evaluate the diagnostic messages and eliminate the error.

Table 5- 2 PWR/24VDC status displays

LEDs		Meaning	To correct or avoid errors
PWR	24VDC		
 Off	 Off	Supply voltage missing	<ul style="list-style-type: none"> <li>• Check the supply voltage.</li> <li>• Check the BaseUnit type and the wiring of the BaseUnit.</li> </ul>
 On	 On	Supply voltage is present and OK	---
 On	 Off	Short-circuit or overload at the encoder supply or supply voltage too low	<ul style="list-style-type: none"> <li>• Check the encoder wiring.</li> <li>• Check the loads connected to the encoder supply.</li> <li>• Check the supply voltage.</li> </ul>



### ChannelLEDs

The LEDs A, B, N and DI<sub>m</sub> indicate the current level of the associated signals. The LEDs of the digital outputs DQ<sub>m</sub> indicate the desired state.

The LEDs UP and DN indicate the logical counting direction.

The flashing frequency of the channel LEDs is limited to ca. 12 Hz. If higher frequencies are present, the channel LEDs will flash at 12 Hz instead of indicating the current status.

Table 5- 3 A/B/N/DI<sub>m</sub>/DQ<sub>m</sub> status displays

A/B/N/DI <sub>m</sub> /DQ <sub>m</sub> LEDs	Meaning
□ Off	Counter input / digital input / digital output at 0 level
■ On	Counter input / digital input / digital output at 1 level

Table 5- 4 Status displays UP/DN

LEDs		Meaning
UP	DN	
□ Off	□ Off	No count pulse has been detected for the last 0.5 s.
■ On	□ Off	The last count pulse has incremented the counter and took place no more than 0.5 s ago.
□ Off	■ On	The last count pulse has decremented the counter and took place no more than 0.5 s ago.

## 5.2 Diagnostic messages

### Diagnostic alarms

If a diagnostic alarm is pending, the DIAG LED flashes red.

The diagnostic alarms are displayed as clear text in STEP 7 (TIA Portal) in the online and diagnostics view. You can evaluate the error codes with the user program.

The following diagnostics can be signaled:

Table 5- 5 Diagnostic alarms, their meaning and remedies

Diagnostic alarm	Error code	Meaning	To correct or avoid errors
Error	9H	<ul style="list-style-type: none"> <li>Internal module error occurred</li> <li>Possible cause: Technology module defective</li> </ul>	Replace technology module
Load voltage missing	11H	No technology module L+ supply voltage	<ul style="list-style-type: none"> <li>Check BaseUnit type</li> <li>Check the wiring of the supply voltage L+ on the BaseUnit</li> </ul>
Hardware interrupt lost	16H	<ul style="list-style-type: none"> <li>Technology module cannot send an interrupt because a previous interrupt has not been processed</li> <li>Possible causes:                             <ul style="list-style-type: none"> <li>Parameter assignment error</li> <li>Too many hardware interrupts in too short a time</li> </ul> </li> </ul>	Change interrupt processing in the CPU and re-assign technology module parameters correspondingly
Module temporarily unavailable	1FH	<ul style="list-style-type: none"> <li>No normal operation of the technology module possible</li> <li>Possible cause: Technology module is performing a firmware update</li> </ul>	Wait until technology module is available again
Internal error	100H	Technology module defective	Replace technology module
Watchdog tripped. Module is defective.	103H	Firmware error	Run firmware update
		Technology module defective	Replace technology module
Short circuit or overload at external encoder supply	10EH	<ul style="list-style-type: none"> <li>Error at encoder supply</li> <li>Possible causes:                             <ul style="list-style-type: none"> <li>Short circuit</li> <li>Overload</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>Check encoder wiring</li> <li>Check consumers connected to encoder supply</li> </ul>
Error at digital outputs	10FH	<ul style="list-style-type: none"> <li>Error at the digital outputs</li> <li>Possible causes:                             <ul style="list-style-type: none"> <li>Short circuit</li> <li>Overload</li> <li>External feed</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>Check wiring at the digital outputs</li> <li>Check consumers connected to the digital outputs</li> </ul>

Diagnostic alarm	Error code	Meaning	To correct or avoid errors
Faulty external auxiliary voltage	110 <sub>H</sub>	<ul style="list-style-type: none"> <li>• Error at supply voltage L+</li> <li>• Possible causes: <ul style="list-style-type: none"> <li>– Low voltage</li> <li>– Wiring of L+ supply voltage defective</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Check the L+ supply voltage</li> <li>• Check the wiring of the supply voltage L+ on the BaseUnit</li> </ul>
Illegal A/B signal ratio	500 <sub>H</sub>	<ul style="list-style-type: none"> <li>• Time profile of signals A and B of the incremental encoder does not meet certain specifications</li> <li>• Possible causes: <ul style="list-style-type: none"> <li>– Signal frequency too high</li> <li>– Encoder faulty</li> <li>– Process wiring faulty</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Check process wiring</li> <li>• Check encoder/sensor</li> <li>• Check parameter assignment</li> </ul>
Wire break at digital input A, B or N	505 <sub>H</sub>	Channel not connected	Connect the channel
		Resistance of encoder circuit too high	<ul style="list-style-type: none"> <li>• Use a different encoder type or modify the wiring, for example, use shorter cables with larger cross-sections</li> <li>• Check encoders</li> </ul>
		Interruption of the line between technology module and encoder	Check process wiring
		Sensor used is sourcing output or sinking output only	Correct parameter assignment
Overheating	506 <sub>H</sub>	Possible causes: <ul style="list-style-type: none"> <li>• Short circuit or overload at the digital outputs or output of the encoder supply</li> <li>• Ambient temperature outside specifications</li> </ul>	<ul style="list-style-type: none"> <li>• Check process wiring</li> <li>• Improve cooling</li> <li>• Check connected loads</li> </ul>

## 5.3 Interrupts

### 5.3.1 Trigger a diagnostic interrupt

#### Enabling the diagnostic interrupts

You enable the diagnostic interrupt for wire break and the diagnostic interrupts for additional errors in the basic parameters during device configuration.

A list of all errors that can trigger a diagnostic interrupt is available at Cause of the error triggering a diagnostic interrupt (Page 37).

#### Reactions to a diagnostic interrupt

The following happens when an event occurs that triggers a diagnostic interrupt:

- The DIAG LED flashes red.  
Once you have remedied the error, the DIAG LED goes out.
- The S7-1500 CPU interrupts the processing of the user program. The diagnostic interrupt OB (e.g. OB 82) is called. The event that triggered the interrupt is entered in the start information of the diagnostic interrupt OB.
- The S7-1500 CPU remains in RUN, even if no diagnostic interrupt OB is present in the CPU. The technology module continues working unchanged if this is possible despite the error.

Detailed information on the error event is available with the instruction "RALRM" (read additional interrupt information).

#### Default setting

These diagnostic interrupts are not enabled in the default setting.

### 5.3.2 Cause of the error triggering a diagnostic interrupt

#### Which errors can trigger a diagnostic interrupt?

The technology module can trigger the following diagnostic interrupts:

Table 5- 6 Possible diagnostic interrupts

Diagnostic interrupt	Monitoring
<ul style="list-style-type: none"> <li>• Internal error</li> <li>• Watchdog tripped. Module is defective.</li> </ul>	Monitoring is always active. A diagnostic interrupt is triggered each time an error is detected.
<ul style="list-style-type: none"> <li>• Wire break at digital input A, B or N</li> </ul>	Monitoring is active if a push-pull switching encoder has been configured. A detected error only triggers a diagnostic interrupt if "Enable diagnostic interrupt for wire break" has been enabled in the device configuration.
<ul style="list-style-type: none"> <li>• Error</li> <li>• Load voltage missing</li> <li>• Hardware interrupt lost</li> <li>• Module temporarily unavailable</li> <li>• Short circuit or overload at external encoder supply</li> <li>• Error at digital outputs</li> <li>• Faulty external auxiliary voltage</li> <li>• Illegal A/B signal ratio</li> <li>• Overheating</li> </ul>	Monitoring is always active. A detected error only triggers a diagnostic interrupt if "Enable additional diagnostic interrupts" has been enabled in the device configuration.

### **5.3.3 Triggering of a Hardware Interrupt**

#### **Introduction**

For the technology module, you can configure which events are to trigger a hardware interrupt during operation.

#### **What is a Hardware Interrupt?**

The technology module will trigger a hardware interrupt as configured in response to specific events/states. When a hardware interrupt occurs, the CPU interrupts execution of the user program and processes the assigned hardware interrupt OB. The event that triggered the interrupt is entered in the start information of the assigned hardware interrupt OB by the CPU.

#### **Activating the hardware interrupts**

You activate the hardware interrupts in STEP 7 (TIA Portal) under "Basic parameters > Hardware interrupts" during device configuration of the technology module.

A list of the individual hardware interrupts is available at Events which can trigger a hardware interrupt (Page 39).

#### **Lost hardware interrupt**

If an event occurs which is supposed to trigger a hardware interrupt but there is an identical, previous event which has not yet been processed, no further hardware interrupt will be triggered. The hardware interrupt is lost. This may lead to the "Hardware interrupt lost" diagnostic interrupt, depending on the parameter assignment.

#### **Default setting**

No hardware interrupts are activated in the default setting.

### 5.3.4 Events which can trigger a hardware interrupt

#### Which events can trigger a hardware interrupt?

A hardware interrupt is triggered if the condition for changing the respective status bit or event bit in the feedback interface is fulfilled.

The EventType tag, among others, is entered in the start information of the assigned hardware interrupt OB when a hardware interrupt is triggered. The EventType tag specifies the number of the event type to which the event triggering the interrupt belongs.

You can configure hardware interrupts to be triggered for the following event types:

Hardware interrupt	EventType number
Internal gate opening (Gate start)	1
Internal gate closing (Gate stop)	2
Overflow (high counting limit violated)	3
Underflow (low counting limit violated)	4
Compare event for DQ0 has occurred	5
Compare event for DQ1 has occurred	6
Zero pass	7
New Capture value available <sup>1)</sup>	8
Synchronization of the counter by an external signal	9
Direction reversal <sup>2)</sup>	10

<sup>1)</sup> Can only be configured in Counting mode

<sup>2)</sup> The feedback bit STS\_DIR has the default value "0". A hardware interrupt is not triggered when the first counter value is changed immediately after switching on the technology module in the *down direction*.

You can activate any combination of events to trigger hardware interrupts.





## Technical specifications

<b>6ES7138-6AA00-0BA0</b>	
Product type designation	TM Count 1x24V
<b>General information</b>	
BaseUnits that can be used	BU type A0
<b>Product function</b>	
I&M data	Yes; I&M0 to I&M3
<b>Engineering with</b>	
STEP 7 TIA Portal can be configured/integrated as of version	V12 SP1 / V13
STEP 7 can be configured/integrated as of version	V5.5 SP3 / V5.5 SP4
<b>Supply voltage</b>	
<b>Load voltage L+</b>	
Rated value (DC)	24 V
Low limit of valid range (DC)	19.2 V
High limit of valid range (DC)	28.8 V
Reverse polarity protection	Yes
<b>Input current</b>	
Current consumption, max.	60 mA; without load
<b>Encoder supply</b>	
Number of outputs	1
<b>24 V encoder supply</b>	
24 V	Yes; L+ (-0.8 V)
Short-circuit protection	Yes
Output current, max.	300 mA
<b>Power loss</b>	
Power loss, typ.	1 W
<b>Address area</b>	
<b>Occupied address area</b>	
Inputs	16 bytes
Outputs	12 bytes; 4 bytes with Motion Control
<b>Digital inputs</b>	
Number of inputs	3
Digital inputs, configurable	Yes
Input characteristics to IEC 61131, Type 3	Yes

<b>6ES7138-6AA00-0BA0</b>	
<b>Digital input functions, configurable</b>	
Gate start/stop	Yes
Capture	Yes
Synchronization	Yes
Freely assignable digital input	Yes
<b>Input voltage</b>	
Rated value, DC	24 V
For signal "0"	-30 V to +5 V
For signal "1"	+11 V to +30 V
Permitted voltage at input, min.	-30 V
Permitted voltage at input, max.	30 V
<b>Input current</b>	
for signal "1", typ.	2.5 mA
<b>Input delay (at rated value of input voltage)</b>	
For standard inputs	
• Configurable	Yes; none / 0.05 / 0.1 / 0.4 / 0.8 / 1.6 / 3.2 / 12.8 / 20 ms
• at "0" to "1", min.	6 µs; with parameter assignment "none"
• at "1" to "0", min.	6 µs; with parameter assignment "none"
For counters/technological functions	
• Configurable	Yes
<b>Cable length</b>	
Cable length shielded, max.	1000 m
Cable length unshielded, max.	600 m
<b>Digital outputs</b>	
Type of digital output	Transistor
Number of outputs	2
Digital outputs, configurable	Yes
Short-circuit protection	Yes; electronic/thermal
• Response threshold, typ.	1 A
Limiting of inductive shutdown voltage to	L+ (-33 V)
Control of a digital input	Yes
<b>Digital output functions, configurable</b>	
Switch at comparison values	Yes
Freely assignable digital output	Yes
<b>Output switching capacity</b>	
With resistive load, max.	0.5 A; per digital output
With lamp load, max.	5 W
<b>Load resistance range</b>	
Low limit	48 Ω
High limit	12 kΩ

<b>6ES7138-6AA00-0BA0</b>	
<b>Output voltage</b>	
for signal "1", min.	23.2 V; L+ (-0.8 V)
<b>Output current</b>	
for signal "1" rated value	0.5 A; per digital output
for signal "1" permissible range, max.	0.6 A; per digital output
for signal "1" minimum load current	2 mA
for signal "0" residual current, max.	0.5 mA
<b>Output delay with resistive load</b>	
"0" to "1", max.	50 µs
"1" to "0", max.	50 µs
<b>Switching frequency</b>	
With resistive load, max.	10 kHz
With inductive load, max.	0.5 Hz; to IEC 947-5-1, DC-13; observe derating curve
With lamp load, max.	10 Hz
<b>Total current of outputs</b>	
Max. current per module	1 A
<b>Cable length</b>	
Cable length shielded, max.	1000 m
Cable length unshielded, max.	600 m
<b>Encoders</b>	
<b>Supported encoders</b>	
2-wire sensor	Yes
<ul style="list-style-type: none"> <li>Permitted quiescent current (2-wire sensor), max.</li> </ul>	1.5 mA
<b>Encoder signals, incremental encoders (asymmetrical)</b>	
Input voltage	24 V
Input frequency, max.	200 kHz
Counting frequency, max.	800 kHz; with quadruple evaluation
Signal filter, configurable	Yes
Cable length shielded, max.	600 m; depends on input frequency, encoder and cable quality; max. 50 m with 200 kHz
Incremental encoder with A/B tracks, phase-shifted by 90°	Yes
Incremental encoder with A/B tracks, phase-shifted by 90°, and zero track	Yes
Pulse encoder	Yes
Pulse encoder with direction	Yes
Pulse encoder with one pulse signal per count direction	Yes
24 V encoder signal	
<ul style="list-style-type: none"> <li>Permitted voltage at input, min.</li> </ul>	-30 V
<ul style="list-style-type: none"> <li>Permitted voltage at input, max.</li> </ul>	30 V
<b>Interface hardware</b>	
Input characteristics to IEC 61131, Type 3	Yes
Sinking/sourcing input	Yes

	6ES7138-6AA00-0BA0
<b>Isochronous mode</b>	
Isochronous mode (application synchronized until terminal)	Yes
Bus cycle time (TDP), min.	250 µs
<b>Interrupts/diagnostics/status information</b>	
Activation of substitute values	Yes; configurable
<b>Interrupts</b>	
Diagnostic interrupt	Yes
Hardware interrupt	Yes
<b>Diagnostic messages</b>	
Monitoring of supply voltage	Yes
Wire break	Yes
Short circuit	Yes
A/B transition error with incremental encoder	Yes
Group error	Yes
<b>LED diagnostics display</b>	
Monitoring of supply voltage	Yes, green PWR LED
For module diagnostics	Yes; green / red DIAG LED
Count down status display (green)	Yes
Count up status display (green)	Yes
<b>Integrated functions</b>	
Number of counters	1
Counting frequency (counters), max.	800 kHz; with quadruple evaluation
<b>Counting functions</b>	
Can be used with TO High_Speed_Counter	Yes
Continuous counting	Yes
Counter response configurable	Yes
Hardware gate by means of digital input	Yes
Software gate	Yes
Event-triggered stop	Yes
Synchronization by means of digital input	Yes
Counting range, configurable	Yes
Comparator	
• Number of comparators	2
• Direction-dependent	Yes
• Can be changed from user program	Yes
<b>Position detection</b>	
Suitable for S7-1500 Motion Control	Yes


<b>6ES7138-6AA00-0BA0</b>	
<b>Measuring functions</b>	
Measuring time, configurable	Yes
Dyn. measuring time adjustment	Yes
Number of threshold values, configurable	2
Measuring range	
• Frequency measurement, min.	0.04 Hz
• Frequency measurement, max.	800 kHz
• Period measurement, min.	1.25 µs
• Period measurement, max.	25 s
Accuracy	
• Frequency measurement	100 ppm; depends on measuring interval and signal evaluation
• Velocity measurement	100 ppm; depends on measuring interval and signal evaluation
• Period measurement	100 ppm; depends on measuring interval and signal evaluation
<b>Electrical isolation</b>	
<b>Electrical isolation channels</b>	
Between the channels and the backplane bus	Yes
<b>Permitted potential difference</b>	
Between the different circuits	75 V DC / 60 V AC (basic insulation)
<b>Insulation</b>	
Insulation tested with	707 V DC (type test)
<b>Ambient conditions</b>	
<b>Operating temperature</b>	
Horizontal installation, min.	0 °C
Horizontal installation, max.	60 °C; note derating
Vertical installation, min.	0 °C
Vertical installation, max.	50 °C; note derating
<b>Dimensions</b>	
Width	15 mm
<b>Weights</b>	
Weight, approx.	45 g

### Derating information for total current of outputs

If the digital outputs of the TM Count 1x24V are operated with resistive or inductive loads, you should derate the total current of the loads at the digital outputs of the technology module. The total current is the sum of the load currents at all digital outputs of the module (without encoder supply).

The following derating curve shows the load capacity of the digital outputs depending on the ambient temperature and mounting position under the following conditions:

- Load resistance: 48 Ω (IEC 947-5-1)




- ① Vertical installation of the system
- ② Horizontal installation of the system

Figure 6-1 Total current depending on ambient temperature and mounting position for resistive loads

The following derating curve shows the load capacity of the digital outputs depending on the ambient temperature and mounting position under the following conditions:

- Maximum switching frequency at digital outputs of 0.5 Hz
- Load resistance: 48  $\Omega$  (IEC 947-5-1)
- Load inductance: 1150 mH (IEC 947-5-1)



- ① Vertical installation of the system  
 ② Horizontal installation of the system

Figure 6-2 Total current by ambient temperature and mounting position for inductive loads

**Note**

If the switching frequency is greater than 0.5 Hz or there is greater inductance at the digital outputs, the total current must be reduced further.

**Dimensional drawing**

See ET 200SP BaseUnits  
<http://support.automation.siemens.com/WW/view/en/58532597/133300> manual





## Parameter data records

You may edit the module parameters in RUN. The WRREC instruction is used to transfer the parameters to the module using data record 128.

If errors occur during the transfer of parameters with the WRREC instruction, the module continues operation with the previous parameter assignment. A corresponding error code is then written to the STATUS output parameter. If no errors occur, the STATUS output parameter contains the length of the actually transferred data.

The description of the WRREC instruction and the error codes is available in the STEP 7 (TIA Portal) Online Help.

### Structure of the data record for a distributed configuration with PROFINET

The table below shows you the structure of data record 128 for TM Count 1x24V with 1 channel. The values in byte 0 to byte 3 are fixed and may not be changed. The value in byte 4 can only be changed by means of new parameter assignment and not in RUN mode.

Table A- 1 Parameter data record 128 for central and distributed configuration with PROFINET

Bit →	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0...3	<b>Header</b>							
0	Major Version = 0				Minor Version = 1			
1	Length of the parameter data = 48							
2	Reserved <sup>2)</sup>							
3	Reserved <sup>2)</sup>							
4...51	<b>Counting channel</b>							
4	<b>Operating mode</b>							
4	Reserved <sup>2)</sup>				Operating mode:			
					0000 <sub>B</sub> : Reserved			
					0001 <sub>B</sub> : Counting			
					0010 <sub>B</sub> : Measuring			
					0011 to 1111 <sub>B</sub> : Reserved			
5	<b>Basic parameters</b>							
5	Reserved <sup>2)</sup>				Enable additional diagnostic interrupts <sup>1)</sup>		Reaction to CPU STOP:	
							00 <sub>B</sub> : Output substitute value	
							01 <sub>B</sub> : Keep last value	
							10 <sub>B</sub> : Continue operation	
							11 <sub>B</sub> : Reserved	

Bit →	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte ↓	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>6...7</b>	<b>Counter inputs</b>							
<b>6</b>	Sensor type:		Signal evaluation:		Signal type:			
	00 <sub>B</sub> : Sourcing output		00 <sub>B</sub> : Single		0000 <sub>B</sub> : Pulse (A)			
	01 <sub>B</sub> : Sinking output		01 <sub>B</sub> : Double		0001 <sub>B</sub> : Pulse (A) and direction (B)			
	10 <sub>B</sub> : Push-pull (sinking and sourcing output)		10 <sub>B</sub> : Quadruple		0010 <sub>B</sub> : Count up (A), count down (B)			
	11 <sub>B</sub> : Reserved		11 <sub>B</sub> : Reserved		0011 <sub>B</sub> : Incremental encoder (A, B phase-shifted)			
					0100 <sub>B</sub> : Incremental encoder (A, B, N) 0101 to 1111 <sub>B</sub> : Reserved			
<b>7</b>	Reaction to signal N:		Invert direction <sup>1)</sup>	Enable diagnostics interrupt at wire break <sup>1)</sup>	Filter frequency:			
	00 <sub>B</sub> : No reaction to signal N				0000 <sub>B</sub> : 100 Hz			
	01 <sub>B</sub> : Synchronization at signal N				0001 <sub>B</sub> : 200 Hz			
	10 <sub>B</sub> : Capture at signal N				0010 <sub>B</sub> : 500 Hz			
	11 <sub>B</sub> : Reserved				0011 <sub>B</sub> : 1 kHz			
			0100 <sub>B</sub> : 2 kHz					
			0101 <sub>B</sub> : 5 kHz					
			0110 <sub>B</sub> : 10 kHz					
			0111 <sub>B</sub> : 20 kHz					
			1000 <sub>B</sub> : 50 kHz					
			1001 <sub>B</sub> : 100 kHz					
		1010 <sub>B</sub> : 200 kHz						
		1011 to 1111 <sub>B</sub> : Reserved						
<b>8...9</b>	<b>Hardware interrupts<sup>1)</sup></b>							
<b>8</b>	Reserved <sup>2)</sup>	Reserved <sup>2)</sup>	Reserved <sup>2)</sup>	Change of direction	Underflow (low counting limit violated)	Overflow (high counting limit violated)	Gate stop	Gate start
<b>9</b>	Synchronization of the counter by an external signal	New Capture value available	Reserved <sup>2)</sup>	Zero pass	Reserved <sup>2)</sup>	Comparison event for DQ1 has occurred	Reserved <sup>2)</sup>	Comparison event for DQ0 has occurred

Bit →									
Byte ↓	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
<b>10...15</b>	<b>Behavior of DQ0/1</b>								
<b>10</b>	Set output (DQ1):				Set output (DQ0):				
	0000 <sub>B</sub> : Use by user program				0000 <sub>B</sub> : Use by user program				
	0001 <sub>B</sub> : Between comparison value and high counting limit; Measuring: Measured value >= comparison value				0001 <sub>B</sub> : Between comparison value and high counting limit; Measuring: Measured value >= comparison value				
	0010 <sub>B</sub> : Between comparison value and low counting limit; Measuring: Measured value <= comparison value				0010 <sub>B</sub> : Between comparison value and low counting limit; Measuring: Measured value <= comparison value				
	0011 <sub>B</sub> : At comparison value for a pulse duration				0011 <sub>B</sub> : At comparison value for a pulse duration				
	0100 <sub>B</sub> : Between comparison value 0 and 1				0100 <sub>B</sub> : Reserved				
	0101 <sub>B</sub> : After set command from CPU until comparison value				0101 <sub>B</sub> : After set command from CPU until comparison value				
	0110 <sub>B</sub> : Not between comparison value 0 and 1 0111 to 1111 <sub>B</sub> : Reserved				0110 to 1111 <sub>B</sub> : Reserved				
<b>11</b>	Count direction (DQ1):		Count direction (DQ0):		Reserved <sup>2)</sup>	Reserved <sup>2)</sup>	Substitute value for DQ1	Substitute value for DQ0	
	00 <sub>B</sub> : Reserved		00 <sub>B</sub> : Reserved						
	01 <sub>B</sub> : Forward		01 <sub>B</sub> : Forward						
	10 <sub>B</sub> : Backward		10 <sub>B</sub> : Backward						
	11 <sub>B</sub> : In both directions		11 <sub>B</sub> : In both directions						
<b>12</b>	Pulse duration (DQ0):								
<b>13</b>	WORD: Value range in ms/10: 0 to 65535 <sub>D</sub>								
<b>14</b>	Pulse duration (DQ1):								
<b>15</b>	WORD: Value range in ms/10: 0 to 65535 <sub>D</sub>								
<b>16</b>	<b>Behavior of DI0</b>								
<b>16</b>	Behavior of counter value after Capture (DI0):	Edge selection (DI0):		Select level (DI0):	Reserved <sup>2)</sup>	Set function of DI (DI0):			
		00 <sub>B</sub> : Reserved				0 <sub>B</sub> : Active with high level	000 <sub>B</sub> : Gate start/stop (level-triggered)		
		01 <sub>B</sub> : At rising edge					001 <sub>B</sub> : Gate start (edge-triggered)		
	10 <sub>B</sub> : At falling edge		11 <sub>B</sub> : At rising and falling edge	1 <sub>B</sub> : Active with low level		010 <sub>B</sub> : Gate stop (edge-triggered)			
	0 <sub>B</sub> : Continue counting					011 <sub>B</sub> : Synchronization			
	1 <sub>B</sub> : Set to start value and continue counting					100 <sub>B</sub> : Enable synchronization at signal N			
						101 <sub>B</sub> : Capture			
					110 <sub>B</sub> : Digital input without function				
					111 <sub>B</sub> : Reserved				

Bit →	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte ↓	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
17	<b>Behavior of DI1:</b> See Byte 16							
18	<b>Behavior of DI2:</b> See Byte 16							
19	Frequency:	Reserved <sup>2)</sup>			Filter time:			
	0 <sub>B</sub> : Once				0000 <sub>B</sub> : None			
	1 <sub>B</sub> : Periodic				0001 <sub>B</sub> : 0.05 ms			
					0010 <sub>B</sub> : 0.1 ms			
					0011 <sub>B</sub> : 0.4 ms			
					0100 <sub>B</sub> : 0.8 ms			
					0101 <sub>B</sub> : 1.6 ms			
					0110 <sub>B</sub> : 3.2 ms			
					0111 <sub>B</sub> : 12.8 ms			
					1000 <sub>B</sub> : 20 ms			
1001 to 1111 <sub>B</sub> : Reserved								
20...43	<b>Values</b>							
20...23	High counting limit: DWORD: Value range: -2147483648 to 2147483647 <sub>D</sub> or 80000000 to 7FFFFFFF <sub>H</sub>							
24...27	Comparison value 0: Operating mode Counting: DWORD: Value range: -2147483648 to 2147483647 <sub>D</sub> or 80000000 to 7FFFFFFF <sub>H</sub> ; Operating mode Measuring: REAL: Floating point number in the configured unit of the measured variable							
28...31	Comparison value 1: Operating mode Counting: DWORD: Value range: -2147483648 to 2147483647 <sub>D</sub> ; or 80000000 to 7FFFFFFF <sub>H</sub> ; Operating mode Measuring: REAL: Floating point number in the configured unit of the measured variable							
32...35	Start value: DWORD: Value range: -2147483648 to 2147483647 <sub>D</sub> or 80000000 to 7FFFFFFF <sub>H</sub>							
36...39	Low counting limit: DWORD: Value range: -2147483648 to 2147483647 <sub>D</sub> or 80000000 to 7FFFFFFF <sub>H</sub>							
40...43	Update time: DWORD: Value range in μs: 0 to 25000000 <sub>D</sub>							
44	<b>Counter behavior at limits and gate start</b>							
44	Reaction to gate start:	Reaction to violation of a counting limit:			Reset when counting limit is violated:			
	00 <sub>B</sub> : Set to start value	000 <sub>B</sub> : Stop counting			000 <sub>B</sub> : To other counting limit			
	01 <sub>B</sub> : Continue with current value	001 <sub>B</sub> : Continue counting			001 <sub>B</sub> : To start value			
	10 to 11 <sub>B</sub> : Reserved	010 to 111 <sub>B</sub> : Reserved			010 to 111 <sub>B</sub> : Reserved			

Bit →	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte ↓	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
<b>45</b>	<b>Specify measured value</b>							
<b>45</b>	Reserved <sup>2)</sup>			Time base for velocity measurement:			Measured variable:	
				000 <sub>B</sub> : 1 ms			00 <sub>B</sub> : Frequency	
				001 <sub>B</sub> : 10 ms			01 <sub>B</sub> : Period	
				010 <sub>B</sub> : 100 ms			10 <sub>B</sub> : Velocity	
				011 <sub>B</sub> : 1 s			11 <sub>B</sub> : Reserved	
				100 <sub>B</sub> : 60 s/1 min				
				101 to 111 <sub>B</sub> : Reserved				
<b>46</b>	Increments per unit:							
<b>47</b>	WORD: Value range: 1 to 65535 <sub>D</sub>							
<b>48</b>	Set the hysteresis range: Value range: 0 to 255 <sub>D</sub>							
<b>49...51</b>	Reserved <sup>2)</sup>							

1) You enable a specific parameter by setting the corresponding bit to 1.

2) Reserved bits must be set to 0.

