# **Protection Equipment**

# **Overload Relays**

Reference Manual • 04/2011



# **Industrial Controls**

Answers for industry.



# **Protection Equipment**



2	Introduction
	Overload Relays
	General data
	- Overview
	3RU1 Thermal Overload Belays
	3BLI11 for standard applications
	- Overview
	- Design
8	- Function
9	- Technical specifications
14	- Characteristic curves
15	- Dimensional drawings
16	- Schematics
	Accessories
	3BB2 Solid-State Overload Belays
	3BB20_3BB21 for standard
	applications
18	- Overview
18	- Design
19	- Function
20	- Technical specifications
25	- Characteristic curves
26	- Dimensional drawings
27	- Schematics
	3RB22, 3RB23 for high-feature
	applications
28	- Overview
29	- Design
30	- Function
32	- rechnical specifications
37	- Unaracteristic Curves
30	- Dimensional drawings
40	
42	70063301163

# **Protection Equipment**

# Introduction

# Overview

																			×				
Туре		3RU	11			3RB	20					3RB	21					3RE	322/3	RB2	3		
Overload relays up to 630 A																							
Applications																							
System protection		✓ <sup>1)</sup>				✓ <sup>1)</sup>						✓ <sup>1)</sup>						✓ <sup>1)</sup>					
Motor protection		✓				✓						1						✓					
Alternating current, three-phase		1				1						1						1					
Alternating current, single-phase		1																1					
Direct current		1																					
Size of contactor		S00,	00, S0, S2, S3 S0		S00 S12			S00 S12			S00 S12												
Rated operational current I <sub>e</sub>																							
Size S00 Size S0	A A	Up t Up t	o 12 o 25			Up t Up t	o 12 o 25					Up te Up te	o 12 o 25					} U	p to 2	25			
Size S2 Size S3	A A	Up t Up t	Jp to 50 U Jp to 100 U		Up to 50 Up to 100				Up te Up te	o 50 o 10(	C				} U	p to 1	00						
Size S6 Size S10/S12, Size 14 (3TF6)	A A		L		Up to 200 Up to 630				Up to 200 Up to 630				Up to 200 Up to 630										
Rated operational voltage Ue	V	690/	1000	AC <sup>2)</sup>		690/	1000	AC <sup>3</sup>	)			690/	1000	AC <sup>3</sup>	)			690	/1000	D AC	1)		
Rated frequency	Hz	50/6	0			50/6	0					50/6	0					50/6	60				
Trip classes		CLA	SS 10	)		CLA CLA	SS 1 SS 2	0, 0				CLA Adju	SS 5 Istab	, 10, : le	20, 3	0		CL/ Adj	ASS 5 ustab	i, 10, ile	20, 3	0	
Thermal overload releases	A A	0.11 to 80	0. <sup>.</sup> . 100	16																			
Solid-state overload releases	A A					0.1 . to 160	0.4 63	0				0.1 . to 160	0.4 63	1 30				0.3 to 63 .	3 630	)			
Rating for induction motor at 400 V AC	kW kW	0.04 to 45				0.04 Up t 90	0. o . 450	.09				0.04 to 90	0. . 450	.09 )				0.09 to 37 .	9 1 450	.1 )			
Accessories																							
For sizes		S00	S0	S2	S3	S00	S0	S2	S3	S6	S10/ S12	S00	S0	S2	S3	S6	S10/ S12	SOC	) S0	S2	S3	S6	S10/ S12
Terminal brackets for stand-alone installation		1	1	1	1	1	1	5)	5)	5)	5)	1	1	5)	5)	5)	5)	5)	5)	5)	5)	5)	5)
Mechanical RESET		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1						
Cable releases for RESET		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1						
Electrical remote RESET		1	1	1	1							Integ	grate	d in tl	he ur	nit		Inte	grate	d in t	he u	nit	

------1 1 1

1 1 1 1 1 1 1 1 1 1 1

The units are responsible in the main circuit for overload protection of the assigned electrical loads (e. g.motors), feeder cable and other switching and protection devices in the respective load feeder.

---

---1 1 ---

Integrated in the unit  $\checkmark$ 

2) Size S3 up to 1000 V AC.

Terminal covers

Sealable covers

for setting knobs

3) Size S2 (only with straight-through transformer), S3, S6, S10, S12 up to 1000 V AC.

4) With reference to the 3RB29 .6 current measuring modules.

5) Stand-alone installation without accessories is possible.

✓ Has this function or can use this accessory

-----1 1

---

-- Does not have this function or cannot use this accessory

✓ -- -- --

1

1

1 1

1 1 1

1

# **General data**

# Overview



		211 412 613 1422 42				
Features	Benefits	3RU11	3RB20/3RB21	3RB22/3RB23		
General data						
Sizes	<ul> <li>Are coordinated with the dimensions, connections and technical characteristics of the other devices in the SIRIUS modular system (contactors, soft starters,)</li> </ul>	S00S3	S00 S12	S00 S12		
	<ul> <li>Permit the mounting of slim and compact load feeders in widths of 45 mm (S00), 45 mm (S0), 55 mm (S2), 70 mm (S3), 120 mm (S6) and 145 mm (S10/S12)</li> </ul>					
	<ul> <li>Simplify configuration</li> </ul>					
Seamless current range	<ul> <li>Allows easy and consistent configuration with one series of overload relays (for small to large loads)</li> </ul>	0.11 100 A	0.1 630 A	0.3 630 A ( 820 A) <sup>1)</sup>		
Protection functions						
Tripping in the event of overload	<ul> <li>Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to overload</li> </ul>	V	v	v		
Tripping in the event of phase unbalance	<ul> <li>Provides optimum inverse-time delayed protection of loads against excessive temperature rises due to phase unbalance</li> </ul>	(🗸)	v	v		
Tripping in the event of phase failure	<ul> <li>Minimizes heating of induction motors during pha- se failure</li> </ul>	. 🗸	4	4		
Protection of single-phase loads	<ul> <li>Enables the protection of single-phase loads</li> </ul>	~		~		
Tripping in the event of overheating	Provides optimum temperature-dependent pro-	2)	2)	~		
by	ses, e, g, for stator-critical motors or in the event of					
interveted the subject of a star	insufficient coolant flow, contamination of the mo-					
protection function	tions					
	<ul> <li>Eliminates the need for additional special equipment</li> </ul>					
	<ul> <li>Saves space in the control cabinet</li> </ul>					
	<ul> <li>Reduces wiring outlay and costs</li> </ul>					
Tripping in the event of a ground fault by	<ul> <li>Provides optimum protection of loads against high-resistance short-circuits or ground faults due to moisture, condensed water, damage to the in- sulation material, etc.</li> </ul>		✓ (only 3RB21)	v		
internal ground-fault detection (activatable)	Eliminates the need for additional special equipment.					
	<ul> <li>Saves space in the control cabinet</li> </ul>					
	<ul> <li>Reduces wiring outlay and costs</li> </ul>					
Features						
RESET function	• Allows manual or automatic resetting of the relay	<b>v</b>	<b>v</b>	<b>v</b>		
Remote RESET function	Allows the remote resetting of the relay	(by means of sepa- rate module)	✓ (only 3RB21 with 24 V DC)	4		
TEST function for auxiliary contacts	<ul> <li>Allows easy checking of the function and wiring</li> </ul>	<b>v</b>	<ul> <li> /</li> <li>/</li> </ul>	~		
TEST function for electronics	Allows checking of the electronics		~	~		
Status display	Displays the current operating state	<b>v</b>	~	~		
Large current adjustment button	Makes it easier to set the relay exactly to the cor- rect current value	~	~	~		
Integrated auxiliary contacts (1 NO + 1 NC)	<ul><li>Allows the load to be switched off if necessary</li><li>Can be used to output signals</li></ul>	~	v	✔ (2 ×)		
1) Motor currents up to 820 A can be real	corded and evaluated by a current					

measuring module, e. g. 3RB29 06-2BG1 (0.3 ... 3 A), in combination with a 3UF18 68-3GA00 (820 A/1 A) series transformer.

2) The SIRIUS 3RN thermistor motor protection devices can be used to provide additional temperature-dependent protection.

General data

Features	Benefits	3RU11	3RB20/3RB21	3RB22/3RB23
Design of load feeders		-	_	_
Short-circuit strength up to 100 kA at 690 V (in conjunction with the corresponding fuses or the corresponding motor starter protector)	<ul> <li>Provides optimum protection of the loads and ope- rating personnel in the event of short-circuits due to insulation faults or faulty switching operations</li> </ul>	<i>v</i>	V	V
Electrical and mechanical matching to 3RT1 contactors	<ul> <li>Simplifies configuration</li> <li>Reduces wiring outlay and costs</li> <li>Enables stand-alone installation as well as space- saving direct mounting</li> </ul>	V	V	✓ <sup>1)</sup>
Straight-through transformers for main circuit <sup>2)</sup> (in this case the cables are routed through the feed-through openings of the overload relay and connected directly to the box terminals of the contactor)	<ul> <li>Reduces the contact resistance (only one point of contact)</li> <li>Saves wiring costs (easy, no need for tools, and fast)</li> <li>Saves material costs</li> <li>Reduces installation costs</li> </ul>		✔ (S2 S6)	(S00 S6)
Spring-type terminal connection system for main circuit $^{\!$	<ul> <li>Enables fast connections</li> <li>Permits vibration-resistant connections</li> <li>Enables maintenance-free connections</li> </ul>	(S00)		
Spring-type terminal connection system for auxiliary circuits $^{2)} \label{eq:spring}$	<ul><li>Enables fast connections</li><li>Permits vibration-resistant connections</li><li>Enables maintenance-free connections</li></ul>	V	V	V
Other features				
Temperature compensation	<ul> <li>Allows the use of the relays at high temperatures without derating</li> </ul>	v	<b>v</b>	~
	<ul> <li>Prevents premature tripping</li> <li>Allows compact installation of the control cabinet without distance between the devices/load feeders</li> <li>Simplifies configuration</li> <li>Enables space to be saved in the control cabinet</li> </ul>			
Very high long-term stability	<ul> <li>Provides safe protection for the loads even after years of use in severe operating conditions</li> </ul>	(🖌)	~	V
Wide setting ranges	<ul> <li>Reduce the number of variants</li> <li>Minimize the engineering outlay and costs</li> <li>Minimize storage overhead, storage costs, tied-up capital</li> </ul>		<b>*</b> (1:4)	<b>(</b> 1:10)
Trip class CLASS 5	• Enables solutions for very fast starting motors re- quiring special protection (e. g. Ex motors)		✓ (only 3RB21)	~
Trip classes > CLASS 10	<ul> <li>Enables heavy starting solutions</li> </ul>		<b>v</b>	<b>v</b>
Low power loss	<ul> <li>Reduces power consumption and energy costs (up 98 % less power is used than for thermal over- load relays).</li> <li>Minimizes temperature rises of the contactor and control cabinet – in some cases this may eliminate the need for controlgear cabinet cooling.</li> <li>Direct mounting to contactor saves space, even for high motor currents (i. e. no heat decoupling is</li> </ul>		v	v

000000

1) Exception: up to size S3, only stand-alone installation is possible.

2) Alternatively available for screw terminals.

# General data

ODUIAA	

Features	Benefits	3RU11	3RB20/3RB21	3RB22/3RB23
Other features				
Internal power supply	<ul> <li>Eliminates the need for configuration and connec- ting an additional control circuit</li> </ul>	1)	<b>v</b>	
Variable adjustment of the trip clas- ses	<ul> <li>Reduces the number of variants</li> </ul>		<b>v</b>	~
	<ul> <li>Minimizes the configuring outlay and costs</li> </ul>		(only 3RB21)	
(The required trip class can be adjusted by means of a rotary switch depending on the current start-up condition.)	Minimizes storage overhead, storage costs, and tied-up capital			
Overload warning	<ul> <li>Indicates imminent tripping of the relay directly on the device due to overload, phase unbalance or phase failure</li> </ul>			V
	<ul> <li>Allows the imminent tripping of the relay to be signaled</li> </ul>			
	Allows measures to be taken in time in the event of continuous inverse-time delayed overloads			
	<ul> <li>Eliminates the need for an additional device</li> </ul>			
	<ul> <li>Saves space in the control cabinet</li> </ul>			
	<ul> <li>Reduces wiring outlay and costs</li> </ul>			
Analog output	<ul> <li>Allows the output of an analog output signal for ac- tuating moving-coil instruments, feeding program- mable logic controllers or transfer to bus systems</li> </ul>	- <u></u>		V
	<ul> <li>Eliminates the need for an additional measuring transducer and signal converter</li> </ul>			
	<ul> <li>Saves space in the control cabinet</li> </ul>			
	<ul> <li>Reduces wiring outlay and costs</li> </ul>			

1) The SIRIUS 3RU11 thermal overload relays use a bimetal contactor and therefore do not require a control supply voltage.

# **General data**

	Overload relay	Current	Current	Contactors (type, size, rating in kW)										
		measure- ment	range	3RT10 1	3RT10 2	3RT10 3	3RT10 4	3RT10 5	3RT10 6	3RT10 7	3TF68/69			
				S00	S0	S2	S3	S6	S10	S12	Size 14			
	Туре	Туре	А	3/4/5.5	5.5/7.5/11	15/18.5/22	30/37/45	55/75/90	110/132/160	200/250	375/450			
3RU11 thermal or	verload relays													
l l l <b>l a f</b>	3RU11 1	Integrated	0.11 12	~										
	3RU11 2	Integrated	1.8 25		~									
	3RU11 3	Integrated	5.5 50			~								
	3RU11 4	Integrated	18 100				~							
3RB20 <sup>1)</sup> solid-sta	ate overload re	lays												
	3RB20 1	Integrated	0.1 12	~										
	3RB20 2	Integrated	0.1 25		~									
	3RB20 3	Integrated	6 50			<b>v</b>								
	3RB20 4	Integrated	12.5 100				~							
	3RB20 5	Integrated	50 200					~						
000000	3RB20 6	Integrated	55 630						~	~	~			
2T1 4T2 6T3 1422 A2	3RB20 1 + 3UF18	Integrated	630 820								~			
3RB21 <sup>1)</sup> solid-sta	te overload re	lays												
I LET IN	3RB21 1	Integrated	0.1 12	~										
	3RB21 2	Integrated	0.1 25		~									
SIRUS I	3RB21 3	Integrated	6 50			~								
	3RB21 4	Integrated	12.5 100				~							
	3RB21 5	Integrated	50 200					~						
000000	3RB21 6	Integrated	55 630						~	~	~			
211 412 613 1472 K2	3RB21 1 + 3UF18	Integrated	630 820								~			
3RB22/3RB23 <sup>1)</sup> s	olid-state over	load relays	;											
		3RB29 0	0.3 25	~	~									
666666		3RB29 0	10 100			~	~							
000000	3RB22/3RB23 +	3RB29 5	20 200					~						
SIEMENS SIRIUS		3RB29 6	63 630						~	~	~			
		3RB29 0 + 3UF18	630 820								~			

When using the overload relays with trip class ≥ CLASS 20, see "Technica specifications", "Short-Circuit Protection with Fuses for Motor Feeders", and the Configuration Manual "SIRIUS Configuration - Selection data for Fuseless Load Feeders", Order No. 3ZX1012-0RA21-0AC0" or as a PDF file on the Internet at http://www.npart.eu/ap.140625241 1)

#### **Connection methods**

The 3RB20 and 3RB21 relays are available with screw terminals (box terminals) or spring-type terminals on the auxiliary current side; the same applies for the evaluation modules of the 3RB22/3RB23 relays.

The 3RU11 relays come with screw terminals.

$\bigcirc$	Screw terminals (box terminals)
	Spring-type terminals
	These connections are indicated in the Technical specifications by orange backgrounds.

# **3RU11 for standard applications**

"Increased safety" type of protection EEx e acc. to ATEX directive 94/9/EC

The 3RU11 thermal overload relays are suitable for the overload protection of explosion-proof motors with "increased safety" type of protection EEx e;

see Catalog LV 1, Chapter 20 "Appendix" --> "Standards and approvals" --> "Type overview of approved devices for explosionprotected areas (ATEX Explosion Protection)".

EC type test certificate for Category (2) G/D exists. It has the number DMT 98 ATEX G 001.

## Design

## Device concept

The 3RU11 thermal overload relays are compact devices, i. e. current measurement and the evaluation unit are integrated in a single enclosure.

#### Mounting options

The 3RU11 thermal overload relays can be mounted directly onto the 3RT1 contactors (exception: size S00 with Cage Clamp terminals can only be installed as a stand-alone installation). With the matching terminal brackets the devices can still be installed as stand-alone units.

For more information on the mounting options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

#### **Connection methods**

All sizes of the 3RU11 thermal overload relays with screw terminal can be connected to the auxiliary and main current paths. Rails can be connected to the main conductor connections of size S3 overload relays if the box terminals are removed.

As an alternative, the devices are also available with Cage Clamp terminals. The auxiliary conductor connections of these devices, and for size S00 the main conductor connections as well, are fitted with Cage Clamp terminals.

# For more information on the connection options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

# Overload relays in contactor assemblies for wye-delta starting

When overload relays are used in combination with contactor assemblies for wye-delta starting it must be noted that only 0.58 times the motor current flows through the line contactor. An overload relay mounted onto the line contactor must be set to 0.58 times the motor current.

An assignment of the 3RU11 thermal overload relays to the line contactors of our 3RA contactor assemblies for wye-delta starting can be found under "Controls ---> Contactors and Contactor Assemblies".

### **Operation with frequency converter**

The 3RU11 thermal overload relays are suitable for operation with frequency converters. Depending on the frequency of the converter, a higher current than the motor current must be used in some cases due to eddy-currents and skin effects.

#### (1)Connection for mounting onto contactors:

Optimally adapted in electrical, mechanical and design terms to the contactors and soft starters, these connecting pins can be used for direct mounting of the overload relays. Stand-alone installation is possible as an alternative (in some cases in conjunction with a stand-alone installation module).

(2) Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.

- (3)Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- (4) Motor current setting: Setting the device to the

Setting the device to the rated motor current is easy with the large rotary knob.

(5)STOP button:

Overview

If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.

(6) Transparent sealable cover

Secures the motor current setting and the TEST function against adjustment.

(7) Supply terminals:

The generously sized terminals permit connection of two conductors with different cross-sections for the main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.

The 3RU11 thermal overload relays up to 100 A have been designed for inverse-time delayed protection of loads with normal starting (see "Function") against excessive temperature rises due to overload or phase failure. An overload or phase failure results in an increase of the motor current beyond the set rated motor current. Via heating elements, this current rise heats up the bimetal strips inside the device which then bend and as a result trigger the auxiliary contacts by means of a tripping mechanism. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_e$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves").

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed (see "Function").

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials.

They comply with all important worldwide standards and approvals.



# 3RU11 for standard applications

## Function

## **Basic functions**

The 3RU11 thermal overload relays are designed for:

- Inverse-time delayed protection of loads from overloading
- Inverse-time delayed protection of loads from phase failure

#### **Control circuit**

The 3RU11 thermal overload relays do not require an additional supply voltage for operation.

#### Short-circuit protection

Fuses or motor starter protectors must be used for short-circuit protection.

For assignments of the corresponding short-circuit protection devices to the 3RU11 thermal overload relays with/without contactor see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

#### Trip classes

The 3RU11 thermal overload relays are available for normal starting conditions with trip class CLASS 10. For heavy starting conditions see 3RB2 solid-state overload relays.

For details of the trip classes see "Characteristic Curves".

#### Phase failure protection

The 3RU11 thermal overload relays are fitted with phase failure sensitivity (see "Characteristic Curves") in order to minimize temperature rises of the load in the case of a phase failure during single-phase operation.

#### Settina

The 3RU11 thermal overload relays are set to the rated motor current by means of a rotary knob. The scale of the rotary knob is shown in ampere.

#### Manual and automatic reset

Automatic and manual reset is selected by pressing and turning the blue button (RESET button). If the button is set to manual reset, the overload relay can be reset directly by pressing the RESET button. Resetting is possible in combination with mechanical and electrical reset options from the range of accessories (see "Accessories"). If the blue button is set to automatic RESET, the relay is reset automatically.

The time between tripping and resetting is determined by the recovery time.

#### Recovery time

After tripping due to overload, the 3RU11 thermal overload relays require some time until the bimetal strips have cooled down. The device can only be reset after the bimetal strips have cooled down. This time (recovery time) depends on the tripping characteristics and strength of the tripping current.

The recovery time allows the load to cool down after tripping due to overload.

#### **TEST** function

The TEST slide can be used to check whether the operational 3RU11 thermal overload relay is working properly. Actuating the slide simulates tripping of the relay. During this simulation the NC contact (95-96) is opened and the NO contact (97-98) is closed. This tests whether the auxiliary circuit has been correctly connected to the overload relay. If the 3RU11 thermal overload relay has been set to automatic RESET, the overload relay is automatically reset when the TEST slide is released. The relay must be reset with the RESET button if it has been set to manual RESET.

#### STOP function

If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream and thus the load. The load is switched on again when the STOP button is released.

#### Display of the operating state

The respective operating state of the 3RU11 thermal overload relay is displayed by means of the position of the marking on the TEST function/switch position indicator slide. After tripping due to overload or phase failure, the marking on the slide is to left on the "O" mark, otherwise it is on the "I" mark.

### Auxiliary contacts

The 3RU11 thermal overload relays are fitted with an NO contact for the tripped signal, and an NC contact for disconnecting the contactor.

3RU11 for standard applications

# Technical specifications

Туре		3RU11 16	3RU11 26	3RU11 36	3RU11 46			
Size		S00	SO	S2	S3			
Width		45 mm	45 mm	55 mm	70 mm			
General data								
Trips in the event of		Overload and pha	se failure					
	224 17	10						
Phase follows acce. to inco 00347-4-1	OLAGO	Yee						
		Tes						
Overload warning		No						
Reset and recovery								
Reset options after tripping		ivianual, automatic	and remote RESE	.1 ''				
Recovery line     Eor automatic PESET	min	Depends on the st	renath of the tripp	ing current and cha	ractoristic			
- For manual RESET	min	Depends on the st	trength of the tripp	ing current and cha	racteristic			
- For remote BESET	min	Depends on the st	renath of the tripp	ing current and cha	racteristic			
		Bopondo on ale et	angar or are arpp	ing canone and one				
Display of operating state on device		Yes by means of T	TEST function/swite	ch position indicato	r slide			
TEST function		Yes	LOT MICTOR/SWIC	on position indicato	1 31100			
BESET button		Yes						
STOP button		Yes						
Safe operation of motors with "increased safety" type of protect	tion							
EC type test certificate number acc. to		DMT 98 ATEX G 0	01 🔂 II (2) GD.					
directive 94/9/EC		DMT 98 ATEX G 0	01 N1					
Ambient temperature								
Storage/transport	°C	-55 +80						
Operation	°C	-20 +70						
Temperature compensation	°C	Up to 60						
<ul> <li>Permissible rated current at</li> </ul>								
<ul> <li>Temperature inside control cabinet 60 °C</li> </ul>	%	100 (over +60 °C o	current reduction is	s not required)				
<ul> <li>Temperature inside control cabinet 70 °C</li> </ul>	%	87						
Repeat terminals								
<ul> <li>Coil repeat terminal</li> </ul>		Yes	Not required					
<ul> <li>Auxiliary contact repeat terminal</li> </ul>		Yes	Not required					
Degree of protection acc. to IEC 60529		IP20		IP20 <sup>2)</sup>				
Touch protection acc. to IEC 61140		Finger-safe						
Shock resistance with sine acc. to IEC 60068-2-27	g/ms	8/10						
Electromagnetic compatibility (EMC) – Interference immunity								
Conductor-related interference								
- Burst acc. to IEC 61000-4-4	kV	EMC interference	immunity is not rele	evant for thermal ov	erload relays			
(corresponds to degree of severity 3)	1.1.4							
- Surge acc. to IEC 61000-4-5	KV	EIVIC Interference	immunity is not rele	evant for thermal ov	erioad relays			
Electrostatic discharge acc. to IEC 61000-4-2	k\/	EMC interference i	immunity is not rele	evant for thermal ov	erload relays			
(corresponds to degree of severity 3)	1				onoda rolayo			
• Field-related interference acc. to IEC 61000-4-3	V/m	EMC interference	immunity is not rele	evant for thermal ov	erload relays			
(corresponds to degree of severity 3)								
Electromagnetic compatibility (EMC) – Emitted interference		EMC interference	immunity is not rele	evant for thermal ov	erload relays			
Resistance to extreme climates – Air humidity	%	100						
Dimensions		See dimensional d	Irawings					
Installation altitude above sea level	m	Lin to 2000: above	this please enqui	ire				
Mounting position		The diagrams above	w the permissible		for mounting onto oon			
		tactors and stand- correction of 10 %	alone installation. I must be implement	For installation in the need.	e hatched area, a setting			
		Stand-alone install	lation:					
			0°					
		(		45° 0°	45° V Ie x 1.1			
		(		90°	90°			
		135° 🕈	135°	NSB01364	4			
			<i>I</i> <sub>e</sub> x 1,1					
		Contactor + overlo	oad relay:					
			0°	22,5° 22,	5°			

135°

*I*<sub>e</sub> x 1,1

135°

Type of mounting

Footnotes see page 10.

Siemens · 2011

NSB01363

Direct mounting/stand-alone installation with terminal  $\ensuremath{\mathsf{bracket}}^4)$ 

# **3RU11** for standard applications

Тупе		3BU11116	3BU11 26	3BU11 36	3BU11.46
Size		SOO	SO	S2	S3
Width		45 mm	45 mm	55 mm	70 mm
Main circuit			-0 11111	00 11111	70 mm
Rated insulation voltage U <sub>i</sub> (degree of pollution 3)	V	690			1000
Rated impulse withstand voltage U <sub>imp</sub>	kV	6			8
Rated operational voltage U <sub>e</sub>	V	690			1000
Type of current • Direct current • Alternating current		Yes Yes, frequency range	up to 400 Hz		
Current setting	А	0.11 0.16 to 9 12	1.8 2.5 to 20 25	5.5 8 to 40 50	18 25 to 80 100
Power loss per unit (max.)	W	3.9 6.6	3.9 6	6 9	10 16.5
<ul><li>Short-circuit protection</li><li>With fuse without contactor</li><li>With fuse and contactor</li></ul>		See "Selection and ord See "Technical specific motor feeders)	dering data" cations" (short-circuit pro	otection with fuses/moto	r starter protectors for
Protective separation between main and auxiliary conducting path acc. to IEC 60947-1	V	440	440 / 690 <sup>3)</sup>	500	690
Connection for main circuit					
Connection type		Screw terminal	s with box terminal		
Terminal screw		Pozidriv size 2			Allen screw 4 mm
<ul> <li>Tightening torque</li> </ul>	Nm	0.8 1.2	2 2.5	3 4.5	4 6
<ul> <li>Conductor cross-sections (min./max.),</li> <li>1 or 2 conductors</li> <li>Solid</li> </ul>	mm <sup>2</sup>	2 x (0.5 1.5) <sup>2)</sup> 2 x (0.75 2.5) <sup>2)</sup>	$2 \times (1 \dots 2.5)^{2}$	2 x (0.75 16)	2 x (2.5 16)
- Finely stranded with end sleeve	mm <sup>2</sup>	Max. 2 x $(1 4)^{2}$ 2 x $(0.5 1.5)^{2}$ 2 x $(0.75  cmod 2.5)^{2}$	Max. $2 \times (2.5 \dots 10)^{2}$ $2 \times (1 \dots 2.5)^{2}$ $2 \times (2.5 \dots 6)^{2}$	2 x (0.75 16) 1 x (0.75 25)	2 x (2.5 35) 1 x (2.5 50)
- Stranded	mm <sup>2</sup>	$2 \times (0.15 \dots 1.5)^{2})$ $2 \times (0.75 \dots 1.5)^{2})$ $2 \times (0.75 \dots 2.5)^{2})$ Max $2 \times (1  4)^{2}$	$2 \times (1 \dots 2.5)^{2})$ $2 \times (2.5 \dots 6)^{2})$ Max 2 x (2.5 \dot 10)^{2})	2 x (0.75 25) 1 x (0.75 35)	2 x (10 50) 1 x (10 70)
- AWG cables, solid or stranded	AWG	2 x (18 14)	2 x (14 10)	2 x (18 3) 1 x (18 1)	2 x (10 1/0) 1 x (10 2/0)
- Ribbon cable conductors (number x width x thickness)	mm			2 x (6 x 9 x 0.8)	2 x (6 x 9 x 0.8)
Busbar connections		Busbar connection <sup>1)</sup>			
Terminal screw					M6 x 20
Tightening torque	Nm				4 6
<ul> <li>Conductor cross-sections (min./max.)</li> <li>Finely stranded with cable lug</li> <li>Stranded with cable lug</li> <li>AWG cables, solid or stranded, with cable lug</li> <li>With connecting bar (max. width)</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> AWG mm	  			2 x 70 3 x 70 2/0 12
Connection type		OC Cage Clamp ter	minals		
<ul> <li>Conductor cross-sections (min./max.)</li> <li>Solid</li> <li>Finely stranded without end sleeve</li> <li>Finely stranded with end sleeve</li> <li>Stranded</li> <li>AWG cables, solid or stranded</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	2 x (0.25 2.5) 2 x (0.25 2.5) 2 x (0.25 1.5)  2 x (24 14)			
Footnotes for page 9:		Foo	tnotes for page 10:		

1) Remote RESET in combination with the corresponding accessories.

2) Terminal compartment: degree of protection IP00.

#### 3) The 3RU11 16 overload relay with Cage Clamp terminals can only be installed as a stand-alone installation.

4) For screw and snap-on mounting TH 35 standard mounting rail; size S3 also for TH 75 standard mounting rail. For more detailed information about termi-nal brackets see "Accessories" --> "Technical specifications".

- 1) The box terminal is removable. Rail and cable lug connections are possible if the box terminal is removed.
- 2) If two different conductor cross-sections are connected to one clamping point, both cross-sections must lie in the range specified. If identical crosssections are used, this restriction does not apply.
- An operating voltage of 690 V with safe isolation only applies to devices with screw-type connections; for devices with spring-type connections an operating voltage of 440 V is applicable.

3RU11 for standard applications

Туре		3RU11 16	3RU11 26	3RU11 36	3RU11 46
Size		S00	SO	S2	S3
Width		45 mm	45 mm	55 mm	70 mm
Auxiliary circuit					
Number of NO contacts		1			
Number of NC contacts		1			
Auviliary contacts - assignment		1 NO for the sig	nal "trippod"		
Auxiliary contacts – assignment		1 NC for discon	necting the contactor		
Rated insulation voltage U	V	690	0		
(degree of pollution 3)					
Rated impulse withstand voltage Uimp	kV	6			
Contact rating of the auxiliary contacts					
• NC contact with alternating current AC-14/AC-15, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :					
- 24 V	A	4			
- 120 V	A	4			
- 125 V	A	4			
- 230 V	A	3			
- 400 V	A	2			
- 600 V	A A	0.6			
<ul> <li>NO contact with alternating current AC-14/AC-15, rated operational current L at 1/L;</li> </ul>	A	0.0			
- 24 V	А	3			
- 120 V	A	3			
- 125 V	А	3			
- 230 V	А	2			
- 400 V	А	1			
- 600 V	А	0.6			
- 690 V	А	0.5			
• NC contact, NO contact with direct current DC-13, rated operational current $I_{\rm e}$ at $U_{\rm e}$ :	٨				
- 24 V	A	1			
- 60 V 110 V	A	0.00			
- 110 V - 125 V	A	0.22			
- 125 V - 220 V	Δ	0.22			
• Convertional thermal surrent I	^	c <sup>2</sup> )			
• Conventional thermal current Ith	А	6-/			
Contact reliability     (suitability for PLC control: 17 V 5 mA)		Yes			
Short-circuit protection					
• With fue					
- al /aG operational class	Δ	6			
- Quick	A	10			
With miniature circuit breaker (C characteristic)	Δ	6			
Protective separation between main and auxiliary	V	440			
Acc. to IEC 60947-1	v	440			
CSA, UL, UR rated data					
Auxiliary circuit – switching capacity		B600, R300			
Connection of the auxiliary circuit					
Connection type		Screw ter	minals		
Torminal corow		Pozidriu cizo 0			
Terminal screw		POZIUNV SIZE Z			
Ightening torque	Nm	0.8 1.2			
Conductor cross-sections (min./max.), 1 or 2 conductors	2	a (a = 4 = 3)	0 (0 75 0 5)3)		
- Solid	mm <sup>2</sup>	2 x (0.5 1.5) <sup>9</sup>	<sup>7</sup> , 2 x (0.75 2.5) <sup>67</sup>		
- Finely stranded without end sleeve	$mm^2$		$) 2 \times (0.75 - 2.5)^{3})$		
- Stranded	mm <sup>2</sup>	$2 \times (0.5 \dots 1.5)$ $2 \times (0.5 \dots 1.5)^{3}$	$(0.75 2.5)^{(0.73)}$		
- AWG cables, solid or stranded	AWG	2 x (18 14)	, 2 X (0.70 2.0)		
Connection type			mp terminals		
<ul> <li>Conductor cross-sections (min./max.)</li> </ul>					
- Solid		2 x (0.25 2.5)			
<ul> <li>Finely stranded without end sleeve</li> </ul>		2 x (0.25 2.5)			
- Finely stranded with end sleeve		2 x (0.25 1.5)			
- Stranded					
- AWG cables, solid or stranded		2 x (24 14)			
1) On request.		3)	If two different conducto	or cross-sections are co	onnected to one clamping
2) Up to $l_{\rm k} \le 0.5$ kA; $\le 260$ V.			cross-sections are used	l, this restriction does n	e specified. It identical ot apply.

# **3RU11** for standard applications

### Short-circuit protection with fuses/motor starter protectors for motor feeders

With short-circuit currents up to 100 kA at rated operational voltages up to AC 50/60 Hz 690 V Permissible short-circuit protection fuse for motor starters comprising overload relay and contactor, type of coordination 2<sup>1)</sup>

Overload relay Setting range	3 kW ≘ 3 <i>I</i> <sub>e max</sub> = (at AC 50	RT10 15 7 A 0 Hz 400 \	/)	4 kW ≘ 3RT10 16 I <sub>e max</sub> = 9 A (at AC 50 Hz 400 V)			5.5 kW ≅ I <sub>e max</sub> = (at AC 5	3RT10 1 12 A 0 Hz 400	7 V)	UL-listed fuses RK5	Motor starter protector for starter combinations at $I_{\rm q} = 50$ kA/400 V AC
А	gL/gG	aM	BS 88	gL/gG	aM	BS 88	gL/gG	aM	BS 88	А	
Size S00											
0.11 0.16	0.5			0.5		-	0.5	-	-	1	
0.14 0.2	1			1		-	1	-	-	1	3RV13 21-0BC10
0.18 0.25	1			1		-	1	-	-	1	3RV13 21-0CC10
0.22 0.32	1.6		2	1.6		2	1.6	-	2	1	3RV13 21-0DC10
0.28 0.4	2		2	2		2	2	-	2	1.6	3RV13 21-0EC10
0.35 0.5	2		2	2		2	2	-	2	2	3RV13 21-0FC10
0.45 0.63	2		4	2		4	2	-	4	2.5	3RV13 21-0GC10
0.55 0.8	4		4	4		4	4	-	4	3	3RV13 21-0HC10
0.7 1	4		6	4		6	4	-	6	4	3RV13 21-0JC10
0.9 1.25	4		6	4		6	4	-	6	5	3RV13 21-0KC10
1.1 1.6	6		10	6		10	6	-	10	6	3RV13 21-1AC10
1.4 2	6		10	6		10	6	-	10	8	3RV13 21-1BC10
1.8 2.5	10		10	10		10	10	-	10	10	
2.2 3.2	10		16	10		16	10	-	16	12	
2.8 4	16		16	16		16	16	-	16	16	
3.5 5	20	6	20	20	6	20	20	6	20	20	
4.5 6.3	20	6	20	20	6	20	20	6	20	25	
5.5 8	20	10	20	20	10	20	20	10	20	30	
7 10				20	16	20	20	16	20	40	
9 12							20	16	25	45	

Overload relay Setting range	5.5 kW ≘ I <sub>e max</sub> = <sup>-</sup> (at AC 50	3RT10 24 12 A ) Hz 400 V	()	7.5 kW ≘ I <sub>e max</sub> = (at AC 50	3RT10 25 17 A ) Hz 400 V	()	11 kW ≘ I <sub>e max</sub> = 3 (at AC 50	3RT10 26 25 A ) Hz 400 V	()	UL-listed fuses RK5	Motor starter protector for starter combinations at $I_{\rm q}$ = 50 kA/400 V AC
А	gL/gG	aM	BS 88	gL/gG	aM	BS 88	gL/gG	aM	BS 88	А	
Size S0											
1.8 2.5	10	-	10	10	-	10	10	-	10	10	3RV13 21-1CC10
2.2 3.2	10	-	16	10	-	16	10	-	16	12	3RV13 21-1DC10
2.8 4	16	-	16	16	-	16	16	-	16	16	3RV13 21-1EC10
3.5 5	20	6	20	20	6	20	20	6	20	20	3RV13 21-1FC10
4.5 6.3	20	6	25	20	6	25	20	6	25	25	3RV13 21-1GC10
5.5 8	25	10	25/32 <sup>2)</sup>	25	10	25/32 <sup>2)</sup>	25	10	32	30	3RV13 21-1HC10
7 10	25	16	25/32 <sup>2)</sup>	25	16	25/32 <sup>2)</sup>	32	16	35	40	3RV13 21-1JC10
9 12.5	25	20	25/32 <sup>2)</sup>	25	20	25/32 <sup>2)</sup>	35	20	35	45	3RV13 21-1KC10
11 16	25	20	25/32 <sup>2)</sup>	25	20	25/32 <sup>2)</sup>	35	20	35	60	3RV13 21-4AC10
14 20				25	20	25/32 <sup>2)</sup>	35	20	35	80	3RV13 21-4BC10
17 22							35	20	35	80	3RV13 21-4CC10
20 25							35	20	35	100	

For type of coordination "1"<sup>1</sup> see short-circuit protection of the contactors without overload relay under "Controls - Contactors and Contactor Assemblies"

1) Assignment and short-circuit protective devices according to

IEC 60947-4-1:

The contactor or starter must not endanger persons or the installation in the

event of a short-circuit. **Type of coordination "1":** The contactor or the starter may be non-operational after every short-circuit release.

Type of coordination "2": The contactor or the starter must be operational after a short-circuit release (without replacement of parts). Welding of the contacts is permissible however.

2) At max. 415 V.

## 3RU11 for standard applications

### Short-circuit protection with fuses/motor starter protectors for motor feeders

With short-circuit currents up to 100 kA at rated operational voltages up to AC 50/60 Hz 690 V Permissible short-circuit protection fuse for motor starters comprising overload relay and contactor, type of coordination 2<sup>1)</sup>

Overload relay Setting range	15 kW ≘ I <sub>e max</sub> = 3 (at AC 50	3RT10 34 32 A ) Hz 400 V	()	18.5 kW = I <sub>e max</sub> = 4 (at AC 50	≘ 3RT10 3 40 A ) Hz 400 V	5	22 kW ≘ I <sub>e max</sub> = 5 (at AC 50	3RT10 36 50 A ) Hz 400 V	)	UL-listed fuses RK5	Motor starter protector for starter combinations at $I_{\rm q}$ = 50 kA/400 V AC
А	gL/gG	аM	BS 88	gL/gG	aM	BS 88	gL/gG	aM	BS 88	А	
Size S2											
5.5 8	25	10	25	25	10	25	25	10	25	30	
7 10	32	16	32	32	16	32	32	16	32	40	
9 12.5	35	16	35	35	16	35	35	16	35	50	
11 16	40	20	40	40	20	40	40	20	40	60	
14 20	50	25	50	50	25	50	50	25	50	80	
18 25	63	32	63	63	32	63	63	32	63	100	3RV13 31-4DC10
22 32	63	35	63	63	35	63	80	35	80	125	3RV13 31-4EC10
28 40	63	50	63	63	50	63	80	50	80	150	3RV13 31-4FC10
36 45				63	50	80	80	50	80	175	3RV13 31-4GC10
40 50							80	50	80	200	3RV13 31-4HC10

Overload relay Setting range	30 kW ≘ I <sub>e max</sub> = 0 (at AC 50	3RT10 44 65 A ) Hz 400 V	()	37 kW			45 kW ≘ I <sub>e max</sub> = 9 (at AC 50	3RT10 46 95 A ) Hz 400 \	/)	UL-listed fuses RK5	Motor starter protector for starter combinations at $I_{\rm q}$ = 50 kA/400 V AC
A	gL/gG	aM	BS 88	gL/gG	aM	BS 88	gL/gG	aM	BS 88	A	
Size S3											
18 25	63	32	63	63	32	63	63	32	63	100	
22 32	80	35	80	80	35	80	80	35	80	125	
28 40	80	50	80	80	50	80	80	50	80	150	
36 50	125	50	125	125	50	125	125	50	125	200	
45 63	125	63	125	160	63	160	160	63	160	250	3RV13 41-4JC10
57 75				160	80	160	160	80	160	300	3RV13 41-4KC10
70 90							160	100	160	350	3RV13 41-4LC10
80 100							160	100	160	350	3RV13 41-4MC10

For type of coordination "1"<sup>1)</sup> see short-circuit protection of the contactors without overload relay under "Controls - Contactors and Contactor Assemblies".

1) Assignment and short-circuit protective devices according to IEC 60947-4-1:

The contactor or starter must not endanger persons or the installation in the event of a short-circuit. **Type of coordination "1":** The contactor or the starter may be non-ope-

Type of coordination "1": The contactor or the starter may be non-operational after every short-circuit release. Type of coordination "2": The contactor or the starter must be operatio-

**Type of coordination "2":** The contactor or the starter must be operational after a short-circuit release (without replacement of parts). Welding of the contacts is permissible however.

# 3RU11 for standard applications

# Characteristic curves

The tripping characteristics show the relationship between the tripping time and tripping current as multiples of the current setting  $I_e$  and are given for symmetrical three-pole and two-pole loads from the cold state.

The smallest current used for tripping is called the minimum tripping current. According to IEC 60947-4-1, this current must be within specified limits. The limits of the minimum tripping current for the 3RU11 thermal overload relays for symmetrical three-pole loads are between 105 and 120 % of the current setting.

The tripping characteristic starts with the minimum tripping current and continues with higher tripping currents based on the characteristics of the so-called trip classes (CLASS 10, CLASS 20 etc.). The trip classes describe time intervals within which the overload relays have to trip with 7.2 times the current setting  $I_e$  from the cold state for symmetrical three-pole loads.

The tripping times are as follows for:

Trip class	Tripping times
CLASS 10A	2 s 10 s
CLASS 10	4 s 10 s
CLASS 20	6 s 20 s
CLASS 30	9 s 30 s



This is the schematic representation of a characteristic curve. The characteristic curves of the individual 3RU11 thermal overload relays can be ordered from "Technical Assistance":

- Either by e-mail to: technical-assistance@siemens.com
- Or on the Internet at: <u>http://www.siemens.com/automation/service&support</u>

The tripping characteristic for a three-pole 3RU11 thermal overload relay (see characteristic curve for symmetrical three-pole loads from the cold state) only applies if all three bimetal strips are simultaneously loaded with the same current. If only two bimetal strips are heated due to a phase failure, these two strips alone must generate the necessary force to trigger the tripping mechanism which would result in a longer tripping time or require a higher current. If these higher currents are applied over a longer period, they usually cause damage to the load. To avoid damage, the 3RU11 thermal overload relays are fitted with phase failure sensitivity which ensures faster tripping in accordance with the characteristic curve for 2-pole loads from the cold state by means of a suitable mechanical mechanism.

Compared with a cold load, a load at operating temperature obviously has a lower temperature reserve. This is taken into account by the 3RU11 thermal overload relays by reducing the tripping time to about 25 % when loaded with the current setting  $I_e$  for an extended period.

# **3RU11** for standard applications

# Dimensional drawings

## Screw connection

Lateral distance to grounded components: at least 6 mm.

#### 3RU11 16-..B0

Size S00, with mechanical RESET



1) Mechanical RESET

- 2) Cable release (400 mm or 600 mm long, mounting on the front or laterally on the holder)
- 3) Holder for RESET
- 4) Pushbutton
- 5) Extension plunger

### 3RU11 16-..B.

Size S00, with terminal bracket for stand-alone installation, with remote RESET



### 3RU11 26-...B.

Size S0, with terminal bracket for stand-alone installation



#### 3RU11 36-..B.

Size S2, with terminal bracket for stand-alone installation



#### 3RU11 46-..B.

Size S3, with terminal bracket for stand-alone installation



1) For mounting on TH 35 - 15 or TH 75 standard mounting rail acc. to EN 60715

## Cage Clamp connection

The lateral distance to grounded components must be at least 6 mm.

#### 3RU11 16 -..C1

Size S00, with mechanical RESET (same for sizes S00 to S3).



1) Mechanical RESET

- 2) Cable release (400 mm or 600 mm long,
- mounting on the front or laterally on the holder)
- 3) Holder for RESET
- 4) Pushbutton
- 5) Extension plunger

# 3RU11 for standard applications

3RU11 16 -..C1 Size S00, with remote RESET



1) Remote RESET

### 3RU11 26-..D.

Size S0, with terminal bracket for stand-alone installation



## 3RU11 36-..D.

Size S2, with terminal bracket for stand-alone installation



### 3RU11 46-..D.

Size S3, with terminal bracket for stand-alone installation



For dimensional drawings of overload relays mounted onto contactors see Contactors and Contactor Assemblies.

# Schematics

3RU11 16



## 3RU11 26 to 3RU11 46



# Protection of DC motors





# Overview

The following accessories are available for the 3RU11 thermal overload relays:

- For the four overload relay sizes S00 to S3 one terminal bracket each for stand-alone installation
- One electrical remote RESET module in three voltage variants for all sizes
- One mechanical RESET module for all sizes
- One cable release for resetting devices which are difficult to access (for all sizes)
- Terminal covers

# Technical specifications

## Terminal brackets for stand-alone installation

Туре		3RU19 16-3AA01	3RU19 26-3AA01	3RU1 936-3AA01	3RU19 46-3AA01				
For overload relays		3RU11 16	3RU11 26	3RU11 36	3RU11 46				
Mounting type		For screw and snap-on mounting onto TH 35 standard mounting rails, size S3 also for TH 75 standard mounting rails.							
Connection for main circuit									
Connection type		Screw termina	lls	Box terminal	ls with				
Terminal screw		Pozidriv size 2			Allen screw 4 mm				
Conductor cross-section (min./max.), 1 or 2 conductors									
- Solid	mm <sup>2</sup>	1 x (0.5 2.5), max. 1 x ( 4)	1 x (1 6), max. 1 x ( 10)	2 x (0.75 16)	2 x (2.5 16)				
- Finely stranded without end sleeve	mm <sup>2</sup>								
- Finely stranded with end sleeve	mm <sup>2</sup>	1 x (0.5 2.5)	1 x (1 6)	2 x (0.75 16), 1 x (0.75 25)	2 x (2.5 35), 1 x (2.5 50)				
- Stranded	mm <sup>2</sup>	1 x (0.5 2.5), max. 1 x ( 4)	1 x (1 6), max. 1 x ( 10)	2 x (0.75 25), 1 x (0.75 35)	2 x (10 50), 1 x (10 70)				
- AWG cables, solid or stranded	AWG	1 x (18 14)	1 x (14 10)	2 x (18 3), 1 x (18 1)	2 x (10 1/0), 1 x (10 2/0)				
- Ribbon cable conductors (number x width x thickness)	mm			2 x (6 x 9 x 0.8)	2 x (6 x 9 x 0.8)				

## 3RB20, 3RB21 for standard applications

# Overview



(1)Connection for mounting onto contactors:

Optimally adapted in electrical, mechanical and design terms to the contactors and soft starters, these connecting pins can be used for direct mounting of the overload relays. Stand-alone installation is possible as an alternative (in some cases in conjunction with a stand-alone installation module).

- (2) Selector switch for manual/automatic RESET and RESET button: With the slide switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. On the 3RB21 a solid-state remote RESET is integrated.
- (3)Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.
- (4)Solid-state test (device test): Enables a test of all important device components and functions.
- (5)Motor current setting:
- Setting the device to the rated motor current is easy with the large rotary knob.
- (6) Trip class setting/internal ground-fault detection (only 3RB21): Using the rotary switch you can set the required trip class and activate the internal ground-fault detection dependent on the start-up conditions.
- (7)Connecting terminals (removable joint block for auxiliary circuits): The generously sized terminals permit connection of two conductors with different cross-sections for the main and auxiliary circuits. The auxiliary circuit can be connected with screw terminals and alternatively with spring-type terminals.

The 3RB20 and 3RB21 solid-state overload relays up to 630 A with internal power supply have been designed for inverse-time delayed protection of loads with normal and heavy starting (see "Function") against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by the current transformers integrated into the devices and evaluated by corresponding solid-state circuits which then output a pulse to the auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_e$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Curves").

In addition to inverse-time delayed protection of loads against excessive temperature rises due to overload, phase unbalance and phase failure, the 3RB21 solid-state overload relays also allow internal ground-fault detection (not possible in conjunction with contactor assemblies for wye-delta starting). This provides protection of loads against high-resistance short-circuits due to damage to the insulation material, moisture, condensed water etc.

The "tripped" status is signaled by means of a switch position indicator. Resetting takes place either manually or automatically after the recovery time has elapsed (see "Function").

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable ma-

terials. They comply with all important worldwide standards and approvals.

#### "Increased safety" type of protection EEx e acc. to ATEX directive 94/9/EC

The 3RB20/3RB21 solid-state overload relays are suitable for the overload protection of explosion-proof motors with "increased safety" type of protection EEx e;

see Catalog LV 1, Chapter 20 "Appendix" --> "Standards and approvals" --> "Type overview of approved devices for explosion-protected areas (ATEX Explosion Protection)".

## Design

#### Device concept

The 3RB20/3RB21 solid-state overload relays are compact devices, i. e. current measurement (transformer) and the evaluation unit are integrated in a single enclosure.

#### Mounting options

The 3RB20/3RB21 solid-state overload relays are suitable for direct and space-saving mounting onto 3RT1 contactors and 3RW30/3RW31 soft starters as well as for stand-alone installation.

For more information on the mounting options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

#### **Connection methods**

#### Main circuit

All sizes of the 3RB20/3RB21 solid-state overload relays can be connected with screw terminals. As an alternative for sizes S3 to S10/S12, the main current paths can be connected with the help of rails. Sizes S2 to S6 of the 3RB20/3RB21 relays are also available with a straight-through transformer. In this case, the cables of the main circuit are routed directly through the feed-through openings of the relay to the contactor terminals.

#### Auxiliary circuit

Connection of the auxiliary circuit (removable terminal block) is possible with either screw or spring-type terminal connection system (special device variants).

For more information on the connection options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

# Overload relays in contactor assemblies for wye-delta starting

When overload relays are used in combination with contactor assemblies for wye-delta starting it must be noted that only 0.58 times the motor current flows through the line contactor. An overload relay mounted onto the line contactor must be set to 0.58 times the motor current.

An assignment of the 3RB20 solid-state overload relays to the line contactors of our 3RA contactor assemblies for wye-delta starting can be found in Chapter 3 "Controls: Contactors and Contactor Assemblies".

When 3RB21 solid-state overload relays are used in combination with contactor assemblies for wye-delta starting, the internal ground-fault detection must not be activated.

#### Operation with frequency converter

The 3RB20/3RB21 solid-state overload relays are suitable for frequencies of 50/60 Hz and the associated harmonics. This permits the 3RB20/3RB21 overload relays to be used on the input side of the frequency converter.

If motor protection is required on the outgoing side of the frequency converter, Siemens recommends the 3RN thermistor motor protection devices or the 3RU11 thermal overload relays for this purpose.

# Function

## **Basic functions**

The 3RB20/3RB21 solid-state overload relays are designed for:

- Inverse-time delayed protection of loads from overloading
- Inverse-time delayed protection of loads from phase unbalance
- Inverse-time delayed protection of loads from phase failure
- Protection of loads from high-resistance short-circuits (internal ground-fault detection only with 3RB21).

#### **Control circuit**

The 3RB20/3RB21 solid-state overload relays have an internal power supply, i. e. no additional supply voltage is required.

#### Short-circuit protection

Fuses or motor starter protectors must be used for short-circuit protection.

For assignments of the corresponding short-circuit protection devices to the 3RB20/3RB21 solid-state overload relays with/without contactor see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

#### Trip classes

The 3RB20 solid-state overload relays are available for normal starting conditions with trip CLASS 10 or for heavy starting conditions with trip CLASS 20 (fixed setting in each case).

The 3RB21 solid-state overload relays are suitable for normal and heavy starting conditions. The required trip class (CLASS 5, 10, 20 or 30) can be adjusted by means of a rotary switch depending on the current start-up condition.

For details of the trip classes see "Characteristic Curves".

#### Phase failure protection

The 3RB20/3RB21 solid-state overload relays are fitted with phase failure protection (see "Characteristic Curves") in order to minimize temperature rises of the load during single-phase operation.

Phase failure protection is not effective for loads with star-connection and a grounded neutral point or a neutral point which is connected to a neutral conductor.

#### Setting

The 3RB20/3RB21 solid-state overload relays are set to the rated motor current by means of a rotary knob. The scale of the rotary knob is shown in ampere.

With the 3RB21 solid-state overload relay it is also possible to select the trip class (CLASS 5, 10, 20 or 30) using a second rotary knob and to switch the internal ground-fault detection on and off.

#### Manual and automatic reset

In the case of the 3RB20/3RB21 solid-state overload relays, a slide switch can be used to choose between automatic and manual resetting.

If manual reset is set, a reset can be carried out directly on the device after a trip by pressing the blue RESET button. Resetting is possible in combination with mechanical and mechanical reset options from the range of accessories (see Catalog LV 1, "Accessories"). As an alternative to the mechanical RESET options, the 3RB21 solid-state overload relays can be equipped with electrical remote RESET by applying a voltage of 24 V DC to the terminals A3 and A4.

If the slide switch is set to automatic RESET, the relay is reset automatically.

The time between tripping and resetting is determined by the recovery time.

#### **Recovery time**

With the 3RB20/3RB21 solid-state overload relays the recovery time after inverse-time delayed tripping is 3 minutes when automatic RESET is set. This recovery time allows the load to cool down.

If the button is set to manual RESET and automatic RESET, the 3RB20/3RB21 devices can be reset immediately after tripping.

#### **TEST** function

With motor current flowing, the TEST button can be used to check whether the relay is working correctly (device/solid-state test). Current measurement, motor model and trip unit are tested. If these components are OK, the device is tripped according to the table below. If there is an error, no tripping takes place.

Trip clas- ses	Required loading with the rated current prior to pressing the TEST button	Tripping within
CLASS 5	3 min	30 s
CLASS 10	5 min	1 min
CLASS 20	10 min	2 min
CLASS 30	15 min	3 min

Note: The TEST button must be kept pressed throughout the test. In this case the motor current must be equal to more than 80 % of the current setting  $I_e$  and have at least the value of the lower current setting.

Testing of the auxiliary contacts and the control current wiring is possible with the switch position indicator slide. Actuating the slide simulates tripping of the relay. During this simulation the NC contact (95-96) is opened and the NO contact (97-98) is closed. This tests whether the auxiliary circuit has been correctly wired.

After a test trip the relay is reset by pressing the RESET button.

#### Self-monitoring

The 3RB20/3RB21 solid-state overload relays have a self-monitoring feature, i. e. the devices constantly monitor their own basic functions and trip if an internal fault is detected.

### Display of operating state

The respective operating state of the 3RB20/3RB21 solid-state overload relays is displayed by means of the position of the marking on the switch position indicator slide. After tripping due to overload, phase failure, phase unbalance or ground fault (ground-fault detection possible only with 3RB21) the marking on the slide is to left on the "O" mark, otherwise it is on the "I" mark.

#### **Auxiliary contacts**

The 3RB20/3RB21 solid-state overload relays are fitted with an NO contact for the "tripped" signal, and an NC contact for switching off the contactor.

3RB20, 3RB21 for standard applications

# Technical specifications

Туре		3RB20 16, 3RB21 13	3RB20 26, 3RB21 23	3RB20 36, 3RB21 33	3RB20 46, 3RB21 43	3RB20 56, 3RB21 53	3RB20 66, 3RB21 63					
Size		S00	SO	S2	S3	S6	S10/S12					
Width		45 mm	45 mm	55 mm	70 mm	120 mm	145 mm					
General data												
Trips in the event of		Overload, pha	ase failure, and	phase unbalan	се							
		+ ground faul	It (for 3RB21 on	y)								
Trip class acc. to IEC 60947-4-1	CLASS	10/20/5, 10, 20 and 30 adjustable (depending on the version)										
Phase failure sensitivity		Yes										
Overload warning		No										
Reset and recovery												
<ul> <li>Reset options after tripping</li> </ul>		Manual, autor	matic and remo	te RESET (depe	ending on the ve	ersion)						
Recovery time												
- For automatic RESET	min.	Approx. 3 mir	า									
- For manual RESET	min. min	Immediately										
		Inneclatery										
Display of operating state on device		Voc. by moon	is of switch posi	tion indicator of	ido							
Display of operating state of device     TEST function		Yes, by mean	actropica by pr	tion indicator si	button /							
• TEST function		test of auxilia	rv contacts and	wiring of contro	ol circuit							
		by actuating t	the switch posit	ion indicator slie	de /							
		self-monitorin	g									
RESET button		Yes										
STOP button		No										
Explosion protection – safe operation of motors with "increased safety" type of protection			_									
EC type test certificate number acc. to		PTB 06 ATEX 3001 🕢 II (2) GD										
Ambient temperatures												
Storage/transport	°C	-40 +80										
	°C	-40 +60										
	°C	-25 +00										
Temperature compensation	C											
<ul> <li>Permissible rated current at</li> <li>Temperature inside control cabinet 60 °C, stand-alone installation</li> </ul>	%	100	100 <sup>2)</sup>	100	100	100	100 or 90 <sup>3)</sup>					
- Temperature inside control cabinet 60 °C,	%	100	100 <sup>2)</sup>	100	100	70	70					
mounted on contactor		1)										
- Temperature inside control cabinet 70 °C	%	1)										
Coil repeat terminal		Yes Not required										
Auxiliary contact repeat terminal		Yes Not required										
Degree of protection acc. to IEC 60529		IP20		IP20 <sup>4)</sup>								
Touch protection acc. to IEC 61140		Finger-safe				Finger-safe,	Finger-safe					
		0				for busbar connection with cover	with cover					
Shock resistance with sine acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 <sup>5)</sup>										
Electromagnetic compatibility (EMC) – Interference immunity	-											
Conductor-related interference     Burst acc. to IEC 61000-4-4	kV	2 (power ports), 1 (signal ports)										
(corresponds to degree of severity 3) - Surge acc. to IEC 61000-4-5	kV	2 (line to earth), 1 (line to line)										
<ul><li>(corresponds to degree of severity 3)</li><li>Electrostatic discharge acc. to IEC 61000-4-2</li></ul>	kV	8 (air dischar	ge), 6 (contact	discharge)								
<ul><li>(corresponds to degree of severity 3)</li><li>Field-related interference acc. to IEC 61000-4-3</li></ul>	V/m	10										
(corresponds to degree of severity 3)												
Electromagnetic compatibility (EMC) – Emitted interference		Degree of sev	gree of severity B acc. to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)									
Resistance to extreme climates – air humidity	%	100										
Dimensions		See dimensio	onal drawings									
Installation altitude above sea level	m	Up to 2000										
Mounting position		Any										
Type of mounting		Direct mounti installation wi cket	ng/stand-alone th terminal bra-	Direct mounti	ng/stand-alone	installation						
1) On request.			3) 90 % for	relay with curre	nt setting range	160 630 A.						

2) S0 for 6 ... 25 A, CLASS 20,  $I_{emax} = 19$  A; S0 for 6 ... 25 A, CLASS 30,  $I_{emax} = 16$  A.

- 3) 90 % for relay with current setting range 160 ... 630 A.
- 4) Terminal compartment: degree of protection IP00.
- 5) Signaling contact 97/98 in position "tripped": 4/11 g/ms.

3RB20, 3RB21 for standard applications

Туре		3RB20 16, 3RB21 13	3RB20 26, 3RB21 23	3RB20 36, 3RB21 33	3RB20 46, 3RB21 43
Size Width		S00 45 mm	S0 45 mm	S2 55 mm	S3 70 mm
Main circuit					
Rated insulation voltage U <sub>i</sub> (degree of pollution 3)	V	690		690/1000 <sup>1)</sup>	1000
Bated impulse withstand voltage //	kV	6		6/8 <sup>2)</sup>	8
Bated operational voltage //	V	690		690/1000 <sup>1)</sup>	1000
Type of current	v	000		000/1000	1000
Direct current		No			
Alternating current		Yes, 50/60 Hz ±5 %			
Current setting	A	0.1 0.4 to 3 12	0.1 0.4 to 6 25	6 25 and 12.5 50	12.5 50 and 25 100
Power loss per unit (max.)	W	0.05			
Short-circuit protection • With fuse without contactor • With fuse and contactor		See Catalog LV 1, "Se See "Technical speci	election and ordering fications" (short-circu	data" it protection with fuses fo	r motor feeders)
Protective separation between main and auxiliary con- ducting path acc. to IEC 60947-1 (degree of pollution 2)	V	690 <sup>3)</sup>			
Connection for main circuit					
Connection type		Screw termina	als with box terminal		
Terminal screw     Tightening torque	Nm	Pozidriv size 2	2 25	3 45	Allen screw 4 mm
<ul> <li>Conductor cross-sections (min./max.), 1 or 2 conductors</li> </ul>			2 2.0	0 110	1
- Solid	mm <sup>2</sup>	$2 \times (0.5 \dots 1.5)^{4}$	$2 \times (1 \dots 2.5)^{4}$	2 × (1 16)	2 × (2.5 16)
Finally stranded without and sloove	mm <sup>2</sup>	2 × (0.75 2.5)*'	$2 \times (2.5 \dots 6)^{+/}$		
- Finely stranded with end sleeve	mm <sup>2</sup>	2 × (0.5 1.5) <sup>4)</sup> ,	2 × (1 2.5) <sup>4)</sup> ,	2 × (1 16) <sup>4)</sup> ,	2 × (2.5 35),
		2 × (0.75 2.5) <sup>4)</sup>	2 × (2.5 6) <sup>4)</sup>	1 × ( 1 25́) <sup>4)</sup>	1 × (2.5 50)
- Stranded	mm <sup>2</sup>			2 × (max. 25), 1 × (1 35)	2 × (10 50), 1 × (10 70)
- AWG cables, solid or stranded	AWG	2 × (18 14)	2 × (14 10)	2 × (max. 4).	2 × (10 1/0).
				1 × (18 2)	1 × (10 2/0)
<ul> <li>Ribbon cable conductors (number x width x thickness)</li> </ul>	mm			2 × (6 × 9 × 0.8)	2 × (6 × 9 × 0.8)
Connection type		Bushar connection	e		
Terminal screw			3		M 6 x 20
Tightening torque	Nm				4 6
Conductor cross-section (min./max.)	-				
- Finely stranded with cable lug	mm <sup>2</sup>				2 × 70
- Stranded with cable lug	mm <sup>2</sup>				3 × 70
<ul> <li>Awu cable, solid or stranded, with cable lug</li> <li>With connecting har (max, width)</li> </ul>	AWG mm				2/U 12
Connection type		Straight-through tra	Insformers		12
Diameter of opening	mm			15	18
				10	10
1) For version with straight-through transformer up to 1000	V AC.				
2) For version with straight-through transformer up to 8 kV.					
3) For grounded networks, otherwise 600 V.					
<ol> <li>If two different conductor cross-sections are connected point, both cross-sections must lie in the range specifie</li> </ol>	to one d If ide	clamping			

# 3RB20, 3RB21 for standard applications

Туре		3RB20 56,	3RB20 66,
		3RB21 53	3RB21 63
Size		S6	S10/S12
Width		120 mm	145 mm
Main circuit			
Rated insulation voltage U <sub>i</sub>	V	1000	
(degree of pollution 3)			
Rated impulse withstand voltage Uimp	kV	8	
Rated operational voltage U <sub>e</sub>	V	1000	
Type of current			
Direct current		No	
<ul> <li>Alternating current</li> </ul>		Yes, 50/60 Hz ±5 %	
Current setting	А	50 200	55 250 to
C C			160 630
Power loss per unit (max.)	W	0.05	
Short-circuit protection			
- With fuse without contactor		See Catalog LV 1, "Selection and ordering da	ta"
- With fuse and contactor		See "Technical specifications" (short-circuit pr	rotection with fuses for motor feeders)
Protective separation between main and auxiliary con-	V	690 <sup>1)</sup>	
ducting path acc. to IEC 60947-1 (degree of pollution 2)	-		
Connection for main circuit			
Connection type		Screw terminals with box terminal	
connection type			
Terminal screw		4 mm Allen screw	5 mm Allen screw
Tightening torque	Nm	10 12	20 22
<ul> <li>Conductor cross-sections (min./max.), 1 or 2 conductors</li> </ul>			
- Solid	mm <sup>2</sup>		
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	With 3RT19 55-4G box terminal:	2 × (50 185),
		$2 \times (1 \times \max. 50, 1 \times \max. 70),$	Front clamping point only:
		$1 \times (10 \dots 70)$	$1 \times (70 \dots 240)$
		$2 \times (1 \times max 95, 1 \times max 120)$	$1 \times (120  185)$
		1 × (10 120)	1 × (120 100)
<ul> <li>Finely stranded with end sleeve</li> </ul>	mm <sup>2</sup>	With 3RT19 55-4G box terminal:	2 × (50 185),
		$2 \times (1 \times \text{max}, 50, 1 \times \text{max}, 70),$	Front clamping point only:
		1 × (10 70)	1 × (70 240)
		With $3R11956-4G$ box terminal:	Hear clamping point only: $1 \times (120 - 185)$
		$1 \times (10 \dots 120)$	1 × (120 100)
- Stranded	mm <sup>2</sup>	With 3RT19 55-4G box terminal:	2 × (70 240),
		2 × (max. 70),	Front clamping point only:
		1 × (16 70)	1 × (95 300)
		With 3R119 56-4G box terminal:	Rear clamping point only:
		$2 \times (1100, 120),$ $1 \times (16, 120)$	1 x (120 240)
- AWG cables, solid or stranded	AWG	With 3RT19 55-4G box terminal:	2 × (2/0 500 kcmil).
		$2 \times (max. 1/0),$	Front clamping point only:
		1 × (6 2/0)	1 × (3/0 600 kcmil)
		With 3RT19 56-4G box terminal:	Rear clamping point only:
		$2 \times (\text{max}, 3/0),$ 1 × (6 250 kcmil)	1 x (250 kcmii 500 kcmii)
- Ribbon cable conductors	mm	With 3RT19 55-4G box terminal:	$2 \times (20 \times 24 \times 0.5)$
(number x width x thickness)		$2 \times (6 \times 15.5 \times 0.8),$	$1 \times (6 \times 9 \times 0.8 \dots 20 \times 24 \times 0.5)$
		$1 \times (3 \times 9 \times 0.8 \dots 6 \times 15.5 \times 0.8)$	
		With 3RT19 56-4G box terminal:	
		$2 \times (10 \times 15.5 \times 0.8),$ 1 × (3 × 9 × 0.8 10 × 15.5 × 0.8)	
Connection type		Pushar connections	
		Busbar connections	14.40 00
Ierminal Screw     Tightoping torque	NI	N δ X 25	IVI TU X 30
Ingnitening torque     Conductor cross spatian (min (max))	INM	10 14	1424
Conductor cross-section (min./max.)     Eipoly stranded with eable lug	mm <sup>2</sup>	$16  05^{(2)}$	$50  240^{(3)}$
<ul> <li>Finery stranded with cable lug</li> <li>Stranded with cable lug</li> </ul>	mm <sup>2</sup>	$10 \dots 90^{-2}$	$30 \dots 240^{-7}$
- Stranded with Cable lug		4 250 kcmil	2/0 500 kcmil
- With connecting bar (max width)	mm	15	25
Connection type		Straight-through transformore	
		Suaight-unough transformers	
Diameter of opening	mm	24.0	-
1) For grounded networks, otherwise 600 V			

When connecting cable lugs according to DIN 46235, use the 3RT19 56-4EA1 terminal cover for conductor cross-sections from 95 mm<sup>2</sup> to

ensure phase spacing. 3) When connecting cable lugs according to DIN 46234 for conductor cross-sections from 240 mm<sup>2</sup> as well as DIN 46235 for conductor cross-sections from 185 mm<sup>2</sup>, use the 3RT19 66-4EA1 terminal cover to ensure phase spacing.

3RB20, 3RB21 for standard applications

				3nD20, 3		Stanuaru a	pplications
Туре		3RB20 16, 3RB21 13	3RB20 26, 3RB21 23	3RB20 36, 3RB21 33	3RB20 46, 3RB21 43	3RB20 56, 3RB21 53	3RB20 66, 3RB21 63
Size Width		S00 45 mm	S0 45 mm	S2 55 mm	S3 70 mm	S6 120 mm	S10/S12 145 mm
Auxiliary circuit							
Number of NO contacts		1					
Number of NC contacts		1					
Auxiliary contacts – assignment		1 NO for the si 1 NC for disco	ignal "tripped", onnecting the co	ontactor			
Rated insulation voltage <i>U</i> <sub>i</sub> (degree of pollution 3)	V	300					
Rated impulse withstand voltage U	kV	4					
Auxiliary contacts - contact rating							
• NC contact with alternating current AC-14/AC-15 Rated operational current $I_e$ at $U_e$ :	Δ	Δ					
- 120 V	A	4					
- 125 V	А	4					
- 250 V	А	3					
• NO contact with alternating current AC-14/AC-15: Rated operational current $I_{\rm e}$ at $U_{\rm e}$ :							
- 24 V	A	4					
- 120 V - 125 V	A A	4					
- 250 V	A	3					
• NC, NO contact with direct current DC-13: Rated operational current $I_e$ at $U_e$ :							
- 24 V	A	2					
- 60 V - 110 V	A A	0.55					
- 125 V	A	0.3					
- 250 V	А	0.11					
• Conventional thermal current $I_{ m th}$	А	5					
Contact reliability		Yes					
(suitability for PLC control; 17 V, 5 mA)							
Short-circuit protection							
With fuse, gL/gG operational class	A	6	<i>.</i>				
Ground-fault protection (only 3RB21)		The informatio	n refers to sinu	soidal residual	currents at 50/6	iu Hz	
• Tripping value $I_{\Delta}$		> 0.75 × I <sub>moto</sub>	r	1 05			
• Operating range I		Lower current	setting value <	$I_{\rm motor} < 3.5 \times 10^{-1}$	upper current s	etting value	
Response time t <sub>trip</sub> (in steady-state condition)	S	< 1					
Connecting terminale A2, A4		24 V DC 100	mA 24Wabar	t torm			
Protoctive concretion between main and cuviliany con	V	24 V DC, 100	111A, 2.4 W SHOI	l-lenn			
ducting path acc. to IEC 60947-1	· v	300					
CSA, UL, UR rated data		D000 D000					
Auxiliary circuit – switching capacity		B300, R300					
Connection of the auxiliary circuit Connection type		Screw to	erminals				
- · · ·							
• Lerminal screw		Pozidriv size 2					
Ingntening torque	Nm	0.8 1.2					
Conductor cross-sections (min./max.), 1 or 2 conductors     Solid	mm <sup>2</sup>	1 × (0.5 4),	2 × (0.5 2.5)				
<ul> <li>Finely stranded with end sleeve</li> <li>Finely stranded with end sleeve</li> </ul>	mm <sup>2</sup>	- 1 x (0.5 2.5	), $2 \times (0.5 \pm 1)$	5)			
- Stranded	mm <sup>2</sup>	-	), 2 × (0.0 1.	0)			
- AWG cables, solid or stranded	AWG	$2\times(20\dots14)$					
Connection type		O Spring-t	type terminals				
Conductor cross-sections (min./max.), 1 or 2 conductors	5						
- Solid	mm <sup>2</sup>	2 × (0.25 1.	5)				
- Finely stranded without end sleeve	mm <sup>∠</sup> 2		-				
<ul> <li>Finely stranded with end sleeve</li> <li>Stranded</li> </ul>	mm <sup>2</sup>	2 × (0.25 1. 2 × (0.25 1	5) 5)				
- AWG cables, solid or stranded	AWG	2 × (24 16)	0)				
Footnotes for name 24:		/	3) 11 - 500 1				
1) Please observe operational voltage			4) Contactor	cannot he mou	inted		
<ul> <li>7) The association and short-circuit protective devices ac</li> <li>2) Type of coordination and short-circuit protective devices ac</li> </ul>	c to IEC	60947-4-1	5) Please en	sure that the me	aximum AC-3 o	perational ourre	nt has sufficient
Type of coordination "1": The contactor or the starter tional after every short-circuit release. Type of coordination "2": The contactor or the starter nal after a release (without replacement of parts). There welding	may be must be is a risk	operatio- c of contact	<ul><li>6) With 3UF1</li></ul>	arance from the 8 68-3GA00 cu	rated current o	of the fuses. er.	

# 3RB20, 3RB21 for standard applications

# Short-circuit protection with fuses for motor feeders

For short-circuit currents up to 50 kA or 100 kA at rated operational voltages up to 690 V

Overload relays	Contac-	CLAS	S 5 and	10	CLASS	S 20		CLASS	S 30		690 V 50 kA	,	690 V/		690 V/	415 V/ 50 kA	600 V/ SSCB
											Fuse I	nks <sup>1)</sup>	T 0		Fuses <sup>1</sup>	)	
											DIAZE NEOZ	D ED	Type 3 Type 3 Type 3	INA ISB ISE	Iype 3ND	ACC. to BS 88	Listed acc. to UL, BK5
Setting range	Туре	Rated	operatio	onal cur	rent I <sub>e</sub> //	AC-3 in	A				Opera Rated	tional cla operation	ass gG onal cur	rent I <sub>e</sub> /A	aM AC-3 in <i>I</i>		CL. L
		at V	500	600	400	500	<b>COO</b>	400	500	<b>600</b>	for typ	be of coo	ordinatio	on <sup>2)</sup>	•	0	
A Sizo S00		400	500	690	400	500	690	400	500	690	1	2	I	2	2	2	
01 04	3BT10 15	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	35	13)	20	13)			16
0.32 1.25	3RT10 15	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	35	2	20	2		2	5
1 4	3BT10 15	4	4	4	4	4	4	4	4	4	35	10	20	10		10	15
	3RT10 16	4	4	4	4	4	4	4	4	4	35	10	20	10		10	15
	3RT10 17	4	4	4	4	4	4	4	4	4	35	10	20	10		10	15
3 12	3RT10 16 3RT10 17	9 12	6.5 9	5.2 6.3	9 10	6.5 9	5.2 6.3	9 9	6.5 9	5.2 6.3	35 35	20 20	20 20	20 20		20 20	45 45
Size S0																	
0.1 0.4	3RT10 23	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	35	1 <sup>3)</sup>	20	1 <sup>3)</sup>			1.6
0.32 1.25	3RT10 23	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	1.25	35	2	20	2		2	5
1 4	3RT10 23	4	4	4	4	4	4				63	10	20	10		10	15
3 12	3RT10 24	4	65	5.2	4	65	5.2	4	4	4	63	25	20	20		20	15
5 12	3RT10 24	12	12	9	12	12	9	12	12	9	63	25	25	20	20	20	45
	3RT10 25	12	12	12	12	12	12	12	12	12	63	25	25	20	20	20	45
6 25	3RT10 24	12	12	9	12	12	9	12	12	9	63	25	25	25	20	25	70
	3RT10 25	17 25	17	13	16 16	16 16	13	14 14	14	13	63 100	25 35	25 35	25	20	25 25	70
Size S2	3111020	23	10	13	10	10	13	14	14	13	100	55	33	55	20	20	100
6 25	3RT10 34	25	25	20	22.3	22.3	20	19.1	19.1	19.1	125	63	63	63	50	63	100
40.5 50	3RT10 35	25	25	24	25	25	24	25	25	24	125	63	63	63	50	80	100
12.5 50	3RT10 34 3RT10 35	32 40	32 40	20 24	22.3	22.3 29.4	20 24	19.1 26.5	19.1 26.5	19.1 24	125	63 63	63 63	63 63	50 50	63 80	125 150
	3RT10 36	50	50	24	32.7	32.7	24	26.5	26.5	24	160	80	80	80	50	80	200
Size S3																	
12.5 50	3RT10 44	50	50	47	49	49	47	41.7	41.7	41.7	200	125	125	125	63	125	200
	3RT10 45	50	50	50	50	50	50	45	45	45	200	160	160	160	80	160	200
25 100	3RT10 44	65	65	47	49	49	47	41.7	41.7	41.7	200	125	125	125	63	125	250
	3RT10 45	95	95	58	59	59	58	43 50	43 50	43 50	200	160	160	160	100	160	350
	3RT10 54	100	100	100	81.7	81.7	81.7	69	69	69	355	315	315	315	160	250	400
	3RT10 55				100	100	100	90	90	90	355	315	315	315	200	315	400
Size S6	00740.54		1.15	1.15	04.7						055	0.15	0.15	0.15	100	050	150
50 200	3RT10 54	115	115	115	81.7	81.7	81.7	69	69	69	355	315	315	315	160	250	450 500
	3RT10 56	185	185	170	131	131	131	111	111	111	355	315	315	315	200	315	500
Size S10																	
55 250	3RT10 64	225	225	225	160	160	160	135	135	135	500	400	400	400	250	400	600
	3RT10 65	250	250	250	188	188	188	159	159	159	500	400	400	400	315	400	700
Sizo S12	3RT 10 66	250	250	250	213	213	213	180	180	180	500	400	400	400	315	400	700
160 630	3BT10.64	225	225	225	160	160	160				500	400	400	400	250	400	600
100 000	3RT10 65	265	265	265	188	188	188				500	400	400	400	315	400	700
	3RT10 66	300	300	280	213	213	213	180	180	180	500	400	400	400	315	400	800
	3RT10 75	400	400	400	284	284	284	240	240	240	630	500	500	500	400	450	1000
	3HI 10 /6	200	200	450	355	305	305	300	300	300	630	500	500	500	400	300	600
	3RT12 65	225 265	265	265	265	225 265	225 265	204	204	204	500	500	500	500	400	450 450	700
	3RT12 66	300	300	300	300	300	300	231	231	231	500	500	500	500	400	450	800
	3RT12 75	400	400	400	400	400	400	316	316	316	800	800	800		630	800	1000
	3HI1276	500	500	500	500	500	500	385	385	385	800	800	800		630	800	1200
	3TF69 <sup>4)</sup>	630 630	630 630	630 630	440 572	440 572	440 572	376 500	376 500	376 500	800 800	630 <sup>5)</sup>	630 <sup>5)</sup>		630 630	500 630	1600
Size 14																	
0.32 1.25 <sup>6)</sup>	3TF69 <sup>4)</sup>	820	820	820	572	572	572	500	500	500	800	630 <sup>5)</sup>	630 <sup>5)</sup>		630	630	1600

For footnotes see page 23.

SSCR = Standard Short-Circuit Rating

# 3RB20, 3RB21 for standard applications

# **Characteristic curves**

The tripping characteristics show the relationship between the tripping time and tripping current as multiples of the current setting  $I_e$  and are given for symmetrical three-pole and two-pole loads from the cold state.

The smallest current used for tripping is called the minimum tripping current. According to IEC 60947-4-1, this current must be within specified limits. The limits of the total tripping current for the 3RB20/3RB21 solid-state overload relays for symmetrical three-pole loads are between 105 and 120 % of the current setting.

The tripping characteristic starts with the minimum tripping current and continues with higher tripping currents based on the characteristics of the so-called trip classes (CLASS 10, CLASS 20 etc.). The trip classes describe time intervals within which the overload relays have to trip with 7.2 times the current setting  $I_e$  from the cold state for symmetrical three-pole loads.

The tripping times according to IEC 60947-4-1, tolerance band E, are as follows for:

Trip class	Tripping time
CLASS 5	35s
CLASS 10	5 10 s
CLASS 20	10 20 s
CLASS 30	20 30 s

The tripping characteristic for a three-pole overload relay from the cold state (see illustration 1) only apply if all three phases are simultaneously loaded with the same current. In the event of a phase failure the 3RB20/3RB21 solid-state overload relays switch off the contactor more quickly in order to minimize heating of the load in accordance with the tripping characteristic for twopole loads from the cold state (see illustration 2). With phase unbalance the devices switch off depending on the degree of the unbalance between the two characteristic curves.

Compared with a cold load, a load at operating temperature obviously has a lower temperature reserve. The tripping time of the 3RB20/3RB21 solid-state overload relays is reduced therefore to about 20 % when loaded with the current setting  $I_e$  for an extended period.

Tripping characteristics for 3-pole loads



Illustration 1

Tripping characteristics for 2-pole loads



#### Illustration 2

The above illustrations are schematic representations of characteristic curves. The characteristic curves of the individual 3RB20/3RB21 electronic overload relays can be ordered from "Technical Assistance":

- Either by e-mail to:
- technical-assistance@siemens.com
- Or on the Internet at: http://www.siemens.com/automation/service&support

# 3RB20, 3RB21 for standard applications

# Dimensional drawings

3RB20 16, 3RB21 13, size S00



3RB20 16, 3RB21 13, size S00, stand-alone installation



3RB20 26, 3RB21 23, size S0



3RB20 26, 3RB21 23, size S0, stand-alone installation



### 3RB20 36, 3RB21 33, size S2



3RB20 46, 3RB21 43, size S3



# 3RB20 56, 3RB21 53, size S6



3RB20 66, 3RB21 63, size S10/S12



# 3RB20, 3RB21 for standard applications

3RB20 56, 3RB21 53, size S6 with straight-through transformer



3RB20 46, 3RB21 43, size S3 with straight-through transformer





# Schematics

3RB20 16



## 3RB20 26 to 3RB20 66



3RB21 13



# 3RB21 23 to 3RB21 63



## 3RB22, 3RB23 for high-feature applications

## Overview



#### 3RB22/3RB23 evaluation module

(1)Green "READY" LED:

- A continuous green light signals that the device is working correctly. (2) Red "GND FAULT" LED
- A continuous red light signals a ground-fault tripping.

## (3)Red "THERMISTOR" LED:

A continuous red light signals an active thermistor trip.

- (4)Red "OVERLOAD" LED:
- A continuous red light signals an active overload trip; a flickering red light signals an imminent trip (overload warning).
- (5)Motor current and trip class setting: Setting the device to the motor current and to the required trip class dependent on the start-up conditions is easy with the two rotary switches.
- (6) Selector switch for manual/automatic RESET: With this switch you can choose between manual and automatic RESET.
- (7) TEST/RESET button:

Enables testing of all important device components and functions, plus resetting of the device after a trip when manual RESET is selected.

(8)Connecting terminals (removable joint block):

The generously sized terminals permit connection of two conductors with different cross-sections for the auxiliary, control and sensor circuits. Connection is possible with screw connection and alternatively with spring-type connection.

- (9)3RB29 85 function expansion module:
- Enables more functions to be added, e. g. internal ground-fault detection and/or an analog output with corresponding signals.





The modular, solid-state overload relays with external power supply type 3RB22 (with monostable auxiliary contacts) and type 3RB23 (with bistable auxiliary contacts) up to 630 A (up to 820 A possible with a series transformer) have been designed for inverse-time delayed protection of loads with normal and heavy starting (see "Function") against excessive temperature rises due to overload, phase unbalance or phase failure. An overload, phase unbalance or phase failure result in an increase of the motor current beyond the set rated motor current. This current rise is detected by means of a current measuring module and electronically evaluated by a special evaluation module which is connected to it. The evaluation electronics sends a signal to the auxiliary contacts. The auxiliary contacts then switch off the load by means of a contactor. The break time depends on the ratio between the tripping current and current setting  $I_e$  and is stored in the form of a long-term stable tripping characteristic (see "Characteristic Cur-. The "tripped" status is signaled by means of a continuous red "OVERLOAD" LED.

The LED indicates imminent tripping of the relay due to overload, phase unbalance or phase failure by flickering when the limit current has been violated. This warning can also be issued as a signal through auxiliary contacts.

In addition to the described inverse-time delayed protection of loads against excessive temperature rises, the 3RB22/3RB23 solid-state overload relays also allow direct temperature monitoring of the motor windings (full motor protection) by connection with short-circuit and open-circuit detection of a PTC sensor circuit. With this temperature-dependent protection, the loads can be protected against overheating caused indirectly by reduced coolant flow, for example, which cannot be detected by means of the current alone. In the event of overheating, the devices switch off the contactor, and thus the load, by means of the auxiliary contacts. The "tripped" status is signaled by means of a continuously illuminated "THERMISTOR" LED.

To also protect the loads against high-resistance short-circuits due to damage to the insulation, humidity, condensed water, etc., the 3RB22/3RB23 solid-state overload relays offer the possibility of internal ground-fault detection in conjunction with a function expansion module (for details see Catalog LV 1,

"Selection and ordering data"; not possible in conjunction with contactor assembly for wye-delta starting). In the event of a ground fault the 3RB22/3RB23 relays trip. The "tripped" status is signaled by means of a continuous red "GND FAULT" LED. Signaling through auxiliary contacts is also possible.

After tripping due to overload, phase unbalance, phase failure, thermistor or ground-fault tripping, the relay is reset manually or automatically after the recovery time has elapsed (see "Function").

In conjunction with a function expansion module the motor current measured by the microprocessor can be output in the form of an analog signal 4 ... 20 mA DC for operating rotary coil instruments or for feeding into analog inputs of programmable logic controllers. With an additional AS-Interface analog module the current values can also be transferred over the AS-i bus system.

The devices are manufactured in accordance with environmental guidelines and contain environmentally friendly and reusable materials.

They comply with all important worldwide standards and approvals.

#### "Increased safety" type of protection EEx e acc. to ATEX directive 94/9/EC

The 3RB22 (monostable) solid-state overload relays are suitable for the overload protection of explosion-proof motors with "increased safety" type of protection EEx e;

see Catalog LV 1, Chapter 20 "Appendix" --> "Standards and Approvals" --> "Type Overview of Approved Devices for Explosion-Protected Areas (ATEX Explosion Protection)".

# Design

#### Device concept

The 3RB22/3RB23 solid-state overload relays are based on a modular device concept. Each device always comprises an evaluation module, which is independent of the motor current, and a current measuring module, which is dependent on the motor current. The two modules are electrically interconnected by a connection cable through the system interface.

The basic functionality of the evaluation module can be optionally expanded with corresponding function expansion modules. The function expansion modules are integrated in the evaluation module for this purpose through a simple plug-in connection.

#### Mounting options

#### Current measuring modules

The current measuring modules size S00/S0 and S2/S3 are designed for stand-alone installation. By contrast, the current measuring modules size S6 and S10/S12 are suitable for standalone installation and mounting onto contactors.

#### Evaluation modules

The evaluation modules can be mounted either on the current measuring module (only sizes S00/S0 and S2/S3) or separately.

For more information on the mounting options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

# 3RB22, 3RB23 for high-feature applications

## **Connection methods**

#### Main circuit (current measuring module)

For sizes S00/S0, S2/S3 and S6, the main circuit can also be connected by the straight-through transformer method. In this case, the cables of the main circuit are routed directly through the feed-through openings of the relay to the contactor terminals.

For sizes S6 and S10/S12, the main circuit can be connected with the help of rails. In conjunction with the corresponding box terminals, screw connection is also possible.

## Auxiliary circuit (evaluation module)

Connection of the auxiliary circuit (removable joint block) is possible with either screw or spring-type terminal connection system (special versions).

For more information on the connection options see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

# Overload relays in contactor assemblies for wye-delta starting

When overload relays are used in combination with contactor assemblies for wye-delta starting it must be noted that only 0.58 times the motor current flows through the line contactor. An overload relay mounted onto the line contactor must be set to 0.58 times the motor current.

When 3RB22/3RB23 solid-state overload relays are used in combination with contactor assemblies for wye-delta starting, the function expansion modules for internal ground-fault detection must not be used.

#### **Operation with frequency converter**

The 3RB22/3RB23 solid-state overload relays are suitable for frequencies of 50/60 Hz and the associated harmonics. This permits the 3RB22/3RB23 overload relays to be used on the input side of the frequency converter.

If motor protection is required on the outgoing side of the frequency converter, Siemens recommends the 3RN thermistor motor protection devices or the 3RU11 thermal overload relays for this purpose.

# 3RB22, 3RB23 for high-feature applications

## Function

## **Basic functions**

The 3RB22/3RB23 solid-state overload relays are designed for:

- Inverse-time delayed protection of loads from overloading
- Inverse-time delayed protection of loads from phase unbalance
- · Inverse-time delayed protection of loads from phase failure
- Temperature-dependent protection of loads by connecting a PTC sensor circuit
- · Protection of loads from high-resistance short-circuits (internal ground-fault detection; detection of fault currents > 30 % of the current setting  $I_{\rm e}$ )
- Output of an overload warning
- Output of an analog signal 4 to 20 mA DC as image of the flowing motor current

The basic functions of the evaluation modules in conjunction with function expansion modules are listed in the following table:

Evaluation modules	Function expan- sion modules	Basic functions
3RB22 83-4AA1 3RB22 83-4AC1 3RB23 83-4AA1	None	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning
3RB23 83-4AC1	3RB29 85-2CA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning
	3RB29 85-2CB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal
	3RB29 85-2AA0	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning, analog output
	3RB29 85-2AA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning, analog output
	3RB29 85-2AB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal, analog output

#### Control circuit

The 3RB22/3RB23 solid-state overload relays require an external power supply, i. e. an additional supply voltage is necessary. Power is supplied through a wide-range power supply unit for 24 to 240 V AC/DC.

#### Short-circuit protection

Fuses or motor starter protectors must be used for short-circuit protection.

For assignments of the corresponding short-circuit protection devices to the 3RB22/3RB23 solid-state overload relays with/without contactor see "Technical specifications" and Catalog LV 1, "Selection and ordering data".

#### Trip classes

The 3RB22/3RB23 solid-state overload relays are suitable for normal and heavy starting conditions. The required trip class (CLASS 5, 10, 20 or 30) can be adjusted by means of a rotary switch depending on the current start-up condition.

For details of the trip classes see "Characteristic Curves".

#### Phase failure protection

The 3RB22/3RB23 solid-state overload relays are fitted with phase failure protection (see "Characteristic Curves") in order to minimize temperature rises of the load during single-phase operation.

#### Setting

The 3RB22/3RB23 solid-state overload relays are set to the rated motor current by means of two rotary knobs.

- The upper rotary knob (CLASS/ $I_{emax}$ ) is divided into 4 ranges: 1 A, 10 A, 100 A and 1000 A. The zone must be selected which corresponds to the rated motor current and the current measuring module to be used with it. With the range selected the required trip class (CLASS 5, 10, 20 or 30) can be determined.
- The lower rotary knob with percent scale (10 ... 100 %) is then used to set the rated motor current in percent of the range selected with the upper rotary knob.

#### Example

- Rating of induction motor = 45 kW (AC 50 Hz, 400 V)
- Rated motor current = 80 A
- Required trip class = CLASS 20
- Selected transformer: 10 ... 100 A

#### Solution

- Step 1: Use the upper rotary knob (CLASS) to select the 100 A range
- Step 2: Within the 100 A range set the trip class CLASS 20
- Step 3: Set the lower rotary knob to 80 % (= 0.8) corresponding to  $100 \text{ A} \times 0.8 = 80 \text{ A}.$

If the current which is set on the evaluation module does not correspond to the current range of the connected current transformer, an error will result.

#### Manual and automatic reset

In the case of the 3RB22/3RB23 solid-state overload relays, a slide switch can be used to choose between automatic and manual resetting.

If manual reset is set, a reset can be carried out directly on the device after a trip by pressing the blue TEST/RESET button. A remote RESET can be carried out electrically by jumpering the terminals Y1 and Y2.

If the slide switch is set to automatic RESET, the relay is reset automatically.

The time between tripping and resetting is determined by the recovery time.

#### **Recovery time**

With the 3RB22/3RB23 solid-state overload relays the recovery time after inverse-time delayed tripping is approx. 3 minutes regardless of the selected reset mode. The recovery time allows the load to cool down.

However, in the event of temperature-dependent tripping by means of a connected PTC sensor circuit, the device can only be manually or automatically reset once the winding temperature at the installation location of the PTC thermistor has fallen 5 Kelvin below its response temperature.

After a ground-fault tripping the 3RB22/3RB23 solid-state overload relay trips can be reset immediately without a recovery time.

#### **TEST** function

The combined TEST/RESET button can be used to check whether the relay is working correctly. The test can be aborted at any time by letting go of the TEST/RESET button.

LEDs, the device configuration (this depends on which expansion module is plugged in) and the device hardware are tested while the button is kept pressed for 6 seconds. Simultaneously and for another 18 seconds a direct current proportional in size to the maximum phase of the main current is fed in at the terminals I(+) and I(-). By comparing the analog signal, which is to be measured, with the main current, the accuracy of the current measurement can be determined. In this case 4 mA corresponds to 0 % and 20 mA to 125 % of the current setting. After 24 seconds the auxiliary contacts are switched and the feeder switch off as the result, bringing the test to an end.

After a test trip a faultless relay is reset by pressing the TEST/ RESET button. If a hardware fault is detected, the device trips and cannot be reset.

#### Self-monitoring

The 3RB22/3RB23 solid-state overload relays have a self-monitoring feature, i. e. the devices constantly monitor their own basic functions and trip if an internal fault is detected.

#### Display of the operating state

The particular operating state of the 3RB22/3RB23 solid-state overload relays is displayed by means of four LEDs:

- Green "READY" LED: A continuous green light signals that the overload relay is ready for operation. The 3RB22/3RB23 overload relays are not ready (LED "OFF") if there is no control supply voltage or if the function test was negative.
- Red "GND FAULT" LED: A continuous red light signals a ground fault.
- Red "THERMISTOR" LED: A continuous red light signals a temperature-dependent trip.
- Red "OVERLOAD" LED: A continuous red light signals an inverse-time delayed trip; a flickering red light signals an imminent inverse-time delayed trip (overload warning).

## 3RB22, 3RB23 for high-feature applications

## Auxiliary contacts

The 3RB22/3RB23 solid-state overload relays have two outputs, each with one NO contact and one NC contact. Their basic assignment/function may be influenced by function expansion modules.

The 3RB22 and 3RB23 differ with respect to the tripping characteristics of their auxiliary contacts – monostable or bistable:

The monostable 3RB22 solid-state overload relays will enter the "tripped" state if the control voltage fails (> 200 ms), and return to the original state they were in before the control supply voltage failed when the voltage returns. These devices are therefore especially suited for plants in which the control voltage is not strictly monitored.

The bistable 3RB23 overload relays do not change their "tripped" or "not tripped" status if the control voltage fails. The auxiliary contacts only switch over in the event of an overload and if the supply voltage is present. These devices are therefore especially suited for plants in which the control voltage is monitored separately.

#### Response if the control supply voltage fails

If the control supply voltage fails for more than 0.2 s, the output relays respond differently depending on the version: monostable or bistable.

Response of the output relays in the event of	Monostable 3RB22	Bistable 3RB23
Failure of the control supply voltage	The device trips	No change of the swit- ching state of the auxiliary contacts
Return of the control supply voltage wit- hout previous trip- ping	The device resets	No change of the swit- ching state of the auxiliary contacts
Return of the control supply voltage after	The device remains trip- ped	The device remains trip- ped
previous tripping	Reset: • For overload tripping, after 3 minutes • For thermistor tripping, after the temperature has fallen 5 K below the response temperature • For ground-fault trip- ping, immediately	Reset: • For overload tripping, after 3 minutes • For thermistor tripping, after the temperature has fallen 5 K below the response temperature • For ground-fault trip- ping, immediately

Monostable and bistable responses of the output relays



# 3RB22, 3RB23 for high-feature applications

# Technical specifications

Type – Overload relay of complete system		3RB22, 3RB23
Size Conorol data		300 310/312
General data		Querland phase failure and phase uphalance (s. 40.0% and to NEMA)
inps in the event of		+ ground fault (with corresponding function expansion module) and activation of the thermistor motor protection (with closed PTC sensor circuit)
Trip class acc. to IEC 60947-4-1	CLASS	5, 10, 20 and 30 adjustable
Phase failure sensitivity		Yes
Overload warning		Yes, from 1.125 x $I_{\rm e}$ for symmetrical loads and from 0.85 x $I_{\rm e}$ for unsymmetrical loads
Reset and recovery <ul> <li>Reset options after tripping</li> </ul>		Manual, automatic and remote RESET
Recovery time     For automatic RESET	min	<ul> <li>For tripping due to overcurrent: 3 (stored permanently)</li> <li>For tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> </ul>
- For manual RESET	min	<ul> <li>For tripping due to a ground fault: no automatic RESET</li> <li>For tripping due to overcurrent: 3 (stored permanently)</li> <li>For tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> </ul>
- For remote RESET	min	<ul> <li>For tripping due to a ground fault: immediately</li> <li>For tripping due to overcurrent: 3 (stored permanently)</li> <li>For tripping by thermistor: time until the motor temperature has fallen 5 K below the response temperature</li> <li>For tripping due to a ground fault: immediately</li> </ul>
Features		
Display of operating state on device     TEST function		Yes, with 4 LEDs: Green "Ready" LED, red "Ground Fault" LED, red "Thermistor" LED and red "Overload" LED Yes, test of LEDs, electronics, auxiliary contacts and wiring of control circuit by press-
RESET button		ing the button TEST/RESET / self-monitoring Yes, with the TEST/RESET button
• STOP button		No
Explosion protection – safe operation of motors with "increased safety" type of protection		
EC type test certificate number acc. to directive 94/9/EC (ATEX)		PTB 05 ATEX 3022 🙀 II (2) GD
Ambient temperatures		
Storage/transport	°C	-40 +80
Operation	°C	-25 +60
Temperature compensation	°C	+60
<ul> <li>Permissible rated current</li> </ul>		
- Temperature inside control cabinet 60 °C	%	100
- Temperature inside control cabinet 70 °C	%	1)
Repeat terminals		Not required
Auxiliary contact repeat terminal		Not required
Degree of protection acc. to IEC 60529		IP20 <sup>2)</sup>
Touch protection acc. to IEC 61140		Finger-safe <sup>2)</sup>
Shock resistance with sine acc. to IEC 60068-2-27	a/ms	15/11
Electromagnetic compatibility (EMC)	0.	
- Interference immunity		
Conductor-related interference     Burst acc. to IEC 61000-4-4     (corresponds to degree of severity 3)	kV	2 (power ports), 1 (signal ports)
- Surge acc. to IEC 61000-4-5 (corresponds to degree of severity 3)	kV	2 (line to earth), 1 (line to line)
<ul> <li>Electrostatic discharge acc. to IEC 61000-4-2 (corresponds to degree of severity 3)</li> </ul>	kV	8 (air discharge), 6 (contact discharge)
• Field-related interference acc. to IEC 61000-4-3 (corresponds to degree of severity 3)	V/m	10
Electromagnetic compatiblity (EMC) – emitted interference		Degree of severity A acc. to EN 55011 (CISPR 11) and EN 55022 (CISPR 22)
Resistance to extreme climates – air humidity	%	100
Dimensions		See dimensional drawings
Installation altitude above sea level	m	Up to 2000
Mounting position		Any
Type of mounting		Evaluation module: stand-alone installation, current measuring module size S00 to S3: stand-alone installation, current measuring module size S6 and S10/S12: stand-alone installation and moun- ting onto contactors

<sup>1)</sup> On request.

2) Current measuring modules size S6 and S10/S12 with busbar connection in conjunction with cover.

3RB22, 3RB23 for high-feature applications

Type – Overload relay of current measuring module	•	3RB29 06	3RB29 06	3RB29 56	3RB29 66
Size		S00/S0	S2/S3	S6	S10/S12
Width		45 mm	55 mm	120 mm	145 mm
Main circuit					
Rated insulation voltage <i>U</i> <sub>i</sub> (degree of pollution 3)	V	1000			
Rated impulse withstand voltage U <sub>imp</sub>	kV	6		8	
Rated operational voltage U <sub>e</sub>	V	1000			
Type of current					
Direct current		No			
Alternating current		Yes, 50/60 H	Iz ±5 %		
Current setting	A	0.3 3; 2.4 25	10 100	20 200	63 630
Power loss per unit (max.)	W	0.5			
Short-circuit protection		Can Catalan	LV 1 "Coloction	a and ordering date"	
With fuse and contactor		See "Technic	LV 1, Selection	n and ordening data .	s for motor feeders)
Protective separation between main and auxiliary	V	690 <sup>1)</sup>			
conducting path acc. to IEC 60947-1 (degree of pollution 2)	•	000			
Connection for main circuit					
Connection type			terminals with	n box terminal	
Terminal screw				4 mm Allen screw	5 mm Allen screw
Tightening torque	Nm			10 12	20 22
Conductor cross-sections (min./max.), 1 or 2 conductors	0				
- Solid	mm²				
<ul> <li>Finely stranded with end sleeve</li> </ul>	mm <sup>2</sup>			With 3RT 19 55-4G box terminal: 2 × (1 × max. 50, 1 × max. 70), 1 × (10 70) With 3RT 19 56-4G box terminal: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT 19 55-4G box terminal:	$\begin{array}{l} 2 \times (30 \dots 163),\\ \text{Front clamping point only:}\\ 1 \times (70 \dots 240)\\ \text{Rear clamping point only:}\\ 1 \times (120 \dots 185)\\ 2 \times (50 \dots 185), \end{array}$
- Stranded	mm <sup>2</sup>			2 × (1 × max. 50, 1 × max. 70), 1 × (10 70) With 3RT19 56-4G box terminal: 2 × (1 × max. 95, 1 × max. 120), 1 × (10 120) With 3RT19 55-4G box terminal: 2 × (max. 70), 1 × (16 70)	Front clamping point only: $1 \times (70 \dots 240)$ Rear clamping point only: $1 \times (120 \dots 185)$ $2 \times (70 \dots 240)$ , Front clamping point only: $1 \times (95 \dots 300)$
- AWG cables, solid or stranded	AWG			With 3R119 56-4G box terminal: $2 \times (max. 120),$ $1 \times (16 120)$ With 3RT19 55-4G box terminal: $2 \times (max. 1/0),$ $1 \times (6 2/0)$ With 3RT19 56-4G box terminal: $2 \times (max. 3/0),$ $1 \times (6 - 560 \text{ fcomil})$	Hear clamping point only: $1 \times (120 \dots 240)$ $2 \times (2/0 \dots 500$ kcmil), Front clamping point only: $1 \times (3/0 \dots 600$ kcmil) Rear clamping point only: $1 \times (250$ kcmil 500 kcmil)
- Ribbon cable conductors (number x width x thickness)	mm			With $3RT1955-4G$ box terminal: 2 × (6 × 15.5 × 0.8), 1 × (3 × 9 × 0.8 6 × 15.5 × 0.8) With $3RT1956-4G$ box terminal: 2 × (10 × 15.5 × 0.8), 1 × (3 × 9 × 0.8 10 × 15.5 × 0.8)	2 × (20 × 24 × 0.5), 1 × (6 × 9 × 0.8 20 × 24 × 0.5)
Connection type		Busbar con	nections		
Terminal screw				M8 × 25	M10 × 30
Tightening torque	Nm			10 14	14 24
Conductor cross-section (min./max.)	0				
- Solid with cable lug	mm <sup>∠</sup>			$16 \dots 95^{-1}$	$50 \dots 240^{3}$
<ul> <li>Stranded with cable lug</li> <li>AWG cables, solid or stranded</li> </ul>	AWG			4 250 kcmil	2/0 240 7 2/0 500 kcmil
with cable lug	/ 0/0				
- With connecting bar (max. width)	mm			15	25
Connection type		Straight-thr	ough transform	ners	
Diameter of opening	mm	7.5	14	25	

1) For grounded networks, otherwise 600 V.

 When connecting cable lugs according to DIN 46235, use the 3RT19 56-4EA1 terminal cover for conductor cross-sections from 95 mm<sup>2</sup> to ensure phase spacing. 3) When connecting cable lugs according to DIN 46234 for conductor cross-sections from 240 mm<sup>2</sup> as well as DIN 46235 for conductor cross-sections from 185 mm<sup>2</sup>, use the 3RT19 56-4EA1 terminal cover to ensure phase spacing.

# 3RB22, 3RB23 for high-feature applications

Type – Overload relay of evaluation module		3RB22 83, 3RB23 83
Size		S00 S10/S12
Width		45 mm
Auxiliary circuit		
Number of NO contacts		2
Number of NC contacts		2
Auxiliary contacts – assignment		<ol> <li>NO for the signal "tripped due to overload and/or thermistor",</li> <li>NC for switching off the contactor</li> <li>NO for the signal "tripped due to ground fault",</li> <li>NC for switching off the contactor or<sup>1</sup>)</li> <li>NO for the signal "tripped due to overload and/or thermistor and/or ground fault",</li> <li>NO for the signal "tripped due to overload and/or thermistor and/or ground fault",</li> <li>NC for switching off the contactor</li> <li>NC for switching off the contactor</li> <li>NC for switching off the contactor</li> </ol>
Rated insulation voltage U <sub>i</sub>	V	1 NC for switching off the contactor 300
(degree of pollution 3)		
Rated impulse withstand voltage Uimp	kV	4
Auxiliary contacts – contact rating		
<ul> <li>NC contact with alternating current AC-14/AC-15 Rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> <li>120 V</li> </ul>	A A	6 6
- 125 V	A	6
<ul> <li>250 V</li> <li>NO contact with alternating current AC-14/AC-15: Rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> </ul>	A	6
- 120 V	A	6
- 125 V	А	6
- 250 V	A	3
<ul> <li>NC, NO contact with direct current DC-13: Rated operational current I<sub>e</sub> at U<sub>e</sub>:</li> <li>24 V</li> <li>60 V</li> <li>110 V</li> <li>125 V</li> </ul>	A A A	2 0.55 0.3 0.3
- 250 V	А	0.2
<ul> <li>Conventional thermal current I<sub>th</sub></li> <li>Contact reliability (suitability for PLC control; 17 V, 5 mA)</li> </ul>	A	5 Yes
Short-circuit protection		
<ul> <li>With fuse, gL/gG operational class</li> </ul>	A	6
<ul> <li>With miniature circuit breaker (C characteristic)</li> </ul>	А	1.6
Protective separation between main and auxiliary conducting path Acc. to IEC 60947-1	V	300
CSA, UL, UR rated data		
Auxiliary circuit – switching capacity		B300, R300
Connection of the auxiliary circuit		
Connection type		Screw terminals
Terminal screw		Pozidriv size 2
<ul> <li>Tightening torque</li> </ul>	Nm	0.8 1.2
<ul> <li>Conductor cross-section (min./max.), 1 or 2 conductors</li> <li>Solid</li> <li>Finely stranded without end sleeve</li> <li>Finely stranded with end sleeve</li> <li>Stranded</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup>	1 × (0.5 4), 2 × (0.5 2.5)  1 × (0.5 2.5), 2 × (0.5 1.5) 
- AWG cables, solid or stranded	AWG	2 × (20 14)
Connection type		Spring-type terminals
<ul> <li>Conductor cross-section (min./max.), 1 or 2 conductors</li> <li>Solid</li> <li>Finely stranded without end sleeve</li> <li>Finely stranded with end sleeve</li> <li>Stranded</li> <li>AWG cables, solid or stranded</li> </ul>	mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> mm <sup>2</sup> AWG	$2 \times (0.25 \dots 1.5)$ - $2 \times (0.25 \dots 1.5)$ $2 \times (0.25 \dots 1.5)$ $2 \times (24 \dots 16)$
,		

1) The assignment of auxiliary contacts may be influenced by function expansion modules.

3RB22, 3RB23 for high-feature applications

Type – Overload relay of evaluation module		3RB22 83, 3RB23 83
Size		S00 S10/S12
Width		45 mm
Control and sensor circuit as well as the analog ou	tput	
Rated insulation voltage U <sub>i</sub> (degree of pollution 3) <sup>1)</sup>	V	300
Rated impulse withstand voltage U <sub>imp</sub> <sup>1)</sup>	kV	4
Rated control supply voltage $U_s^{(1)}$		
• AC 50/60 Hz	V	24 240
• DC	V	24 240
Operating range <sup>1)</sup>		
• AC 50/60 Hz		0.85 × U <sub>s min</sub> ≤U <sub>s</sub> ≤1.1 × U <sub>s max</sub>
• DC		$0.85 \times U_{\rm s \ min} \leq U_{\rm s} \leq 1.1 \times U_{\rm s \ max}$
Rated power <sup>1)</sup>		
• AC 50/60 Hz	W	0.5
• DC	W	0.5
Mains buffering time <sup>1)</sup>	ms	200
Thermistor motor protection (PTC thermistor detector) $^{2)}$		
Summation cold resistance	kΩ	≤1.5
Response value	kΩ	3.4 3.8
Return value	kΩ	1.5 1.65
Ground-fault detection		The information refers to sinusoidal residual currents at 50/60 Hz
• Tripping value ${I_\Delta}^{3)}$		
- For $0.3 \times I_{e} < I_{motor} < 2.0 \times I_{e}$		$> 0.3 \times I_{\rm e}$
- For $2.0 \times I_e < I_{motor} < 8.0 \times I_e$		$> 0.15 \times I_{motor}$
• Response time <i>t</i> <sub>trip</sub>	ms	500 1000
Analog output <sup>(3)4)</sup>		
Output signal	mA	4 20
Measuring range		0 to 1.25 × $I_e$ 4 mA corresponds to 0 × $I$
		16.8 mA corresponds to $1.0 \times I_{\rm e}$
		20 mA corresponds to 1.25 $\times I_{\rm e}^{\circ}$
• Load, max.	Ω	100
Connection for the control and sensor circuit as well as the analog output		
Connection type		Screw terminals
Terminal screw		Pozidriv size 2
Tightening torque	Nm	0.8 1.2
Conductor cross-section (min /max ) 1 or 2 conductors		
- Solid	mm <sup>2</sup>	1 × (0.5 4), 2 × (0.5 2.5)
<ul> <li>Finely stranded without end sleeve</li> </ul>	mm <sup>2</sup>	
- Finely stranded with end sleeve	mm <sup>2</sup>	1 × (0.5 2.5), 2 × (0.5 1.5)
- Stranded	mm- AWG	$^{}$ 2 × (20 14)
Connection type	////0	Spring-type terminals
<ul> <li>Conductor cross-section (min./max.), 1 or 2 conductors</li> <li>Solid</li> </ul>	mm <sup>2</sup>	2 x (0.25 1.5)
- Finely stranded without end sleeve	mm <sup>2</sup>	
- Finely stranded with end sleeve	mm <sup>2</sup>	2 × (0.25 1.5)
- Stranded	mm <sup>2</sup>	2 × (0.25 1.5)
- AWG cables, solid or stranded	AWG	2 × (24 16)
1) Control circuit.		4) Analog input modules, e. g. SM 331, must be configured for 4-wire
2) Sensor circuit		measuring transducers. In this case the analog input module must not

3) In conjunction with corresponding function expansion module.

supply current to the analog output of the 3RB22/3RB23 relay.

# 3RB22, 3RB23 for high-feature applications

## Short-circuit protection with fuses for motor feeders

For short-circuit currents up to 50 kA or 100 kA at rated operational voltages up to 690 V

Overload relays	Contac- tors	CLAS	S 5 and	10	CLASS	CLASS 20		CLASS 20 CLASS 30				690 V 50 kA	1	690 V/ 100 k/	, A	690 V/50 kA	415 V/50 kA	600 V/ SSCR
											Fuse I LV HR DIAZE NEOZ	inks <sup>1)</sup> C ED ED	Type 3 Type 5 Type 5	BNA SB SE	Fuses <sup>1</sup> Type 3ND	) Acc. to BS 88	Listed acc. to UL, RK 5	
Setting range	Type	Rated	operati	onal cur	rent I., A	C-3 in A					Opera Rated	itional cla operation	ass gG onal cur	rrent I.	aM <b>AC-3 in /</b>		CL. L	
j j	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	at \	/								for type of coordination <sup>2)</sup>							
A	3)	400	500	690	400	500	690	400	500	690	1	2	1	2	2	2		
0.3 3	3BT10.15	3	3	3	3	3	3	3	3	3	35	20	20	20		20	10	
0.0 0	3RT10 16	3	3	3	3	3	3	3	3	3	35	20	20	20		20	10	
2.4 25	3RT10 15	7	5	4	7	5	4	7	5	4	35	20	20	20		20	60	
	3RT10 16 3RT10 17	9 12	6.5 9	5.2 6.3	10	6.5 9	5.2 6.3	9	6.5 9	5.2 6.3	35	20 20	20 20	20		20	60 60	
	3RT10 23	9	6.5	5.2	9	6.5	5.2				63	25	25	25		25	70	
	3RT10 24 3RT10 25	12 17	12 17	9 13	12 16	12 16	9 13	12 14	12 14	9 13	63 63	25 25	25 25	25 25	20 20	25 25	70 70	
	3RT10 26	25	18	13	16	16	13	14	14	13	100	35	35	35	20	25	100	
	3RT10 34	25 25	25 25	20 24	22.3 25	22.3 25	20 24	19.1 25	19.1 25	19.1 24	125	63 63	63	63	50	63 63	100	
Size S2/S3 <sup>3)</sup>	511110 55	20	20	24	20	20	24	20	20	24	120	00	00	00	50	00	100	
10 100	3RT10 34	32	32	20	22.3	22.3	20	19.1	19.1	19.1	125	63	63	63	50	63	125	
	3RT10 35 3RT10 36	40 50	40 50	24 24	29.4 32.7	29.4 32.7	24 24	26.5 26.5	26.5 26.5	24 24	125 160	63 80	63 80	63 80	50 50	80 80	150 200	
	3RT10 44	65 80	65 80	47 58	49 53	49 53	47 53	41.7 45	41.7 45	41.7 45	200	125 160	125 160	125 160	63 80	125 160	250 300	
	3RT10 46	95	95	58	59	59	58	50	50	50	200	160	160	160	100	160	350	
	3RT10 54	100	100	100	81.7	81.7	81.7	69	69	69	355	315	315	315	160	250	400	
Size S6	3611035				100	100	100	90	90	90	300	310	315	310	200	310	400	
20 200	3RT10 54	115	115	115	81.7	81.7	81.7	69	69	69	355	315	315	315	160	250	450	
	3RT10 55 3RT10 56	150 185	150 185	150 170	107 131	107 131	107 131	90 111	90 111	90 111	355 355	315 315	315 315	315 315	200	315 315	500 500	
Size S10/S12	2	100	100	170	101	101	101				000	010	010	010	200	010	000	
63 630	3RT10 64	225	225	225	160	160	160	135	135	135	500	400	400	400	250	400	600	
	3RT10 65 3RT10 66	265 300	265 300	265 280	188 213	188 213	188 213	159 180	159 180	159 180	500 500	400 400	400 400	400 400	315 315	400 400	700 800	
	3RT10 75	400	400	400	284	284	284	240	240	240	630	500	500	500	400	450	1000	
	3RT10 76	500	500	450	355	355	355	300	300	300	630	500	500	500	500	500	1200	
	3RT12.64 3RT12.65	225 265	225 265	225 265	225 265	225 265	225 265	173 204	173 204	173 204	500 500	500 500	500 500	500 500	400 400	450 450	600 700	
	3RT12 66	300	300	300	300	300	300	231	231	231	500	500	500	500	400	450	800	
	3RT12 75 3RT12 76	400 500	400 500	400 500	400 500	400 500	400 500	316 385	316 385	316 385	800 800	800 800	800 800		630 630	800 800	1000 1200	
	3TF68 <sup>3)</sup>	630	630	630	440	440	440	376	376	376	800	500 <sup>4)</sup>	500 <sup>4)</sup>	500 <sup>4)</sup>	630	500	1600	
Size 14	3TF69 <sup>3)</sup>	630	630	630	572	572	572	500	500	500	800	630 <sup>4)</sup>	630 <sup>4)</sup>		630	630	1600	
5126 14																		

1) Please observe operational voltage.

3TF69<sup>3)</sup>

2) Assignment and short-circuit protective devices according to

820

IEC 60947-4-1:

0.3 ... 3<sup>5)</sup>

The contactor or starter must not endanger persons or the installation in the event of a short-circuit.

820 572

572

572

500

820

Type of coordination "1": The contactor or the starter may be non-operational after every short-circuit release. Type of coordination "2": The contactor or the starter must be operational

**Type of coordination "2":** The contactor or the starter must be operational after a short-circuit release (without replacement of parts). There is a risk of contact welding.

3) Contactors not mountable.

4) Please ensure that the maximum AC-3 operational current has sufficient safety clearance from the rated current of the fuses.

5) With 3UF18 68-3GA00 current transformer.

SSCR = Standard Short-Circuit Rating

500 500 800 630<sup>4)</sup> 630<sup>4)</sup> -- 630 630 1600

3RB22, 3RB23 for high-feature applications

# Characteristic curves

The tripping characteristics show the relationship between the tripping time and tripping current as multiples of the current setting  $I_e$  and are given for symmetrical three-pole and two-pole loads from the cold state.

The smallest current used for tripping is called the minimum tripping current. According to IEC 60947-4-1, this current must be within specified limits. The limits of the minimum tripping current for the 3RB22/3RB23 solid-state overload relays for symmetrical three-pole loads lie between 105 and 120 % of the current setting.

The tripping characteristic starts with the minimum tripping current and continues with higher tripping currents based on the characteristics of the so-called trip classes (CLASS 10, CLASS 20 etc.). The trip classes describe time intervals within which the overload relays have to trip with 7.2 times the current setting  $I_e$  from the cold state for symmetrical three-pole loads.

The tripping times according to IEC 60947-4-1, tolerance band E, are as follows for:

Trip class	Tripping time
CLASS 5	35s
CLASS 10	5 10 s
CLASS 20	10 20 s
CLASS 30	20 30 s

The tripping characteristic for a three-pole overload relay from the cold state (see illustration 1) only apply if all three phases are simultaneously loaded with the same current. In the event of a phase failure or a current unbalance of more than 40 %, the 3RB22/3RB23 solid-state overload relays switch off the contactor more quickly in order to minimize heating of the load in accordance with the tripping characteristic for two-pole loads from the cold state (see illustration 2).

Compared with a cold load, a load at operating temperature obviously has a lower temperature reserve. The tripping time of the 3RB22/3RB23 solid-state overload relays is reduced therefore to about 20 % when loaded with the current setting  $I_e$  for an extended period.

#### Tripping characteristics for 3-pole loads



Illustration 1

Tripping characteristics for 2-pole loads



#### Illustration 2

The above illustrations are schematic representations of characteristic curves. The characteristic curves of the individual 3RB22/3RB23 electronic overload relays can be ordered from "Technical Assistance":

- Either by e-mail to:
- technical-assistance@siemens.com
- Or on the Internet at: http://www.siemens.com/automation/service&support

# 3RB22, 3RB23 for high-feature applications

# Dimensional drawings

## 3RB22 83-4, 3RB23 83-4 evaluation module



## 3RB29 06-2BG1, 3RB29 06-2DG1 current measuring module



#### 3RB29 56-2TG2 current measuring module



# 3RB29 06-2JG1 current measuring module



3RB22, 3RB23 for high-feature applications

#### 3RB29 56-2TH2 current measuring module



#### 3RB29 66-2WH2 current measuring module



**VSB0** 

П

П

# 3RB22, 3RB23 for high-feature applications

# Schematics

# Protection of single-phase motors

(not in conjunction with internal ground-fault detection) 3RB29 06-2.G1, 3RB29 56-2TG2





́М 1~

Schematic representation of a possible application (3-phase)



# 3RB22, 3RB23 for high-feature applications

# Connections

Evaluation modules	With function	Basic functions	Inputs						
	expansion module		A1/A2	T1/T2	Y1/Y2				
3RB22 83-4AA1 3RB22 83-4AC1 3RB23 83-4AA1		Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				
3RB23 83-4AC1	3RB29 85-2CA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				
	3RB29 85-2CB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				
	3RB29 85-2AA0	Inverse-time delayed protection, temperature-dependent protection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				
	3RB29 85-2AA1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, overload warning, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				
	3RB29 85-2AB1	Inverse-time delayed protection, temperature-dependent protection, internal ground-fault detection, electrical remote RESET, ground-fault signal, analog output	Power supply 24 240 V AC/DC	Connection for PTC sensor	Electrical remote RESET				

Evaluation modules	With function	Outputs									
	expansion module	l (–) / l (+)	95/96 NC	97/98 NO	05/06 NC	07/08 NO					
3RB22 83-4AA1 3RB22 83-4AC1 3RB23 83-4AA1 3RB23 83-4AC1		No	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Overload warning	Overload warning					
	3RB29 85-2CA1	No	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning					
	3RB29 85-2CB1	No	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Switching off the contactor (ground fault)	Signal "ground-fault tripping"					
	3RB29 85-2AA0	Analog signal	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Overload warning	Overload warning					
	3RB29 85-2AA1	Analog signal	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection + ground fault)	Signal "tripped"	Overload warning	Overload warning					
	3RB29 85-2AB1	Analog signal	Disconnection of the contactor (inverse- time delayed/tempe- rature-dependent protection)	Signal "tripped"	Switching off the contactor (ground fault)	Signal "ground-fault tripping"					

## Accessories

# Overview

## Overload relays for standard applications

The following accessories are available for the 3RB20/3RB21 solid-state overload relays:

- One terminal bracket each for the overload relays size S00 and S0 (sizes S2 to S12 can be installed as stand-alone installation without a terminal bracket)
- · One mechanical remote RESET module for all sizes
- One cable release for resetting devices which are difficult to access (for all sizes)
- One sealable cover for all sizes
- Box terminal blocks for sizes S6 and S10/S12
- Terminal covers for sizes S2 to S10/S12

# Technical specifications

## Terminal brackets for stand-alone installation

# Overload relays for high-feature applications

The following accessories are available for the 3RB22/3RB23 solid-state overload relays:

- A sealable cover for the evaluation module
- Box terminal blocks for the current measuring modules size S6 and S10/S12
- Terminal covers for the current measuring modules size S6 and S10/S12

Туре		3RB29 13-0AA1	3RB29 23-0AA1
For overload relays		3RB20 16, 3RB21 13	3RB20 26, 3RB21 23
Size		S00	SO
General data			
Type of mounting		For screw and snap-on mounting onto TH 35	standard mounting rail
Connection for main circuit			
Connection type		Screw terminals	
Terminal screw		Pozidriv size 2	
Tightening torque	Nm	0.8 1.2	2 2.5
• Conductor cross-section (min./max.), 1 or 2 conductors			
- Solid	mm <sup>2</sup>	1 × (0.5 2.5), max. 1 × ( 4)	1 × (1 6), max. 1 × ( 10)
- Finely stranded without end sleeve	mm <sup>2</sup>		
- Finely stranded with end sleeve	mm <sup>2</sup>	1 × (0.5 2.5)	1 × (1 6)
- Stranded	mm <sup>2</sup>	1 × (0.5 2.5), max. 1 × ( 4)	1 × (1 6), max. 1 × ( 10)
- AWG cables, solid or stranded	AWG	1 × (18 14)	1 × (14 10)

# Service & Support

Download catalogs and information material: www.siemens.com/industrial-controls/catalogs

Newsletter - always up to date: www.siemens.com/industrial-controls/newsletter

E-Business in the Industry Mall: www.siemens.com/industrial-controls/mall

Online-Support: www.siemens.com/industrial-controls/support

Contact for all technical information: Technical Assistance Tel.: +49 (911) 895-5900 E-Mail: technical-assistance@siemens.com www.siemens.com/industrial-controls/technical-assistance

Siemens AG Industry Sector Postfach 23 55 90713 FÜRTH GERMANY Subject to change without prior notice

© Siemens AG 2009